

# **NEW MICE-II USER'S MANUAL**

**FOR 8-BIT ZILOG**

**SERIES MICROPROCESSORS**

**- Z80, NSC800, Z8, ZS8 -**



USER'S MANUAL FOR NEW MICE-II

Z80  
NSC800  
Z8  
ZS8

Doc No. I49-000115  
2nd Edition  
January 1989



**DISCLAIMER**

© 1989 MICROTEK INTERNATIONAL, INC. All rights reserved.

This manual is subject to change without notice. Nothing herein shall be construed as a recommendation to use any product in violation of existing patents or other rights of third parties.

NEW MICE-II AND THIS MANUAL ARE COVERED BY THE LIMITED WARRANTY SUPPLIED WITH NEW MICE-II AND REPRODUCED IN APPENDIX N OF THIS MANUAL.

Printed in Taiwan, ROC  
January 1989

**MICROTEK INTERNATIONAL INC.**  
6 Industrial Road East 3  
Science-Based Industrial Park  
Hsinchu, Taiwan, 30077, R.O.C.  
TEL: (035)772155  
TLX: 32169 MICROTEK  
FAX: (035)772598



## PREFACE

Microtek International Inc. proudly presents the award winning Micro-In-Circuit-Emulator, NEW MICE-II. You have made an excellent purchase and will soon benefit from the many advance features that Microtek designs into all of its products.

With the detailed instructions provided in this manual, you can rapidly set up and operate your new NEW MICE-II. The information provided in this user's manual is believed accurate and complete, but no responsibility is assumed for any error or omission.

Microtek is dedicated in providing leadership in the microcomputer-based industry. We continue to design new emulators with enhanced features, low cost and always geared toward the microprocessor designer's need. Thank you for choosing Microtek; and may we suggest that you also investigate the many other fine products that Microtek has to offer.

The sale of any Microtek product is subject to all Microtek Terms and Conditions of Sale and Sales Policies, copies of which are available upon request.

Microtek supplies a variety of hi-tech equipment to the microprocessor-based industry. For further information on other Microtek products and/or any other questions regarding this manual, please contact Microtek headquarters.





---

# **NEW MICE-II**

## *Section*

## TABLE OF CONTENTS

	Page
<b>CHAPTER 1: GENERAL INTRODUCTION</b>	1-1
1.1 Introduction to MICE	1-1
1.2 Introduction to NEW MICE-II	1-3
1.2.1 Enhanced Features	1-3
1.2.2 New Breakpoint Processor	1-4
1.2.3 Major Hardware Overview	1-5
1.2.4 Conclusion	1-6
1.3 NEW MICE-II Operating Configurations	1-7
1.3.1 Universal Symbolic Debugger (USD)	1-8
1.4 NEW MICE-II Applications	1-12
1.5 NEW MICE-II Definitions	1-13
<b>CHAPTER 2: NEW MICE-II INSTALLATION PROCEDURES</b>	2-1
2.1 Setting Up NEW MICE-II	2-1
2.1.1 Opening the NEW MICE-II Case	2-1
2.1.2 Replacing the Personality Board or Emulation CPU	2-3
2.1.3 Internal Adjustments	2-4
2.1.4 Connecting the ICE Cable	2-4
2.1.5 Connecting the External Trace Cable	2-8
2.1.6 Closing the NEW MICE-II Case	2-9
2.2 NEW MICE-II Specifications	2-10
2.3 Communicating with NEW MICE-II	2-11
2.4 Control Emulation Processor Board (CEP) Setup	2-11
2.4.1 Interface Parameter Selection	2-11
2.4.2 Clock Selection	2-13
2.4.3 Ready Signal Selection (Z80 and NSC800)	2-16
2.4.4 Bus State Selection (Z80)	2-16

2.4.5	Vcc Selection (NSC800)	2-17
2.4.6	ISR Function (Z80)	2-18
2.5	High Performance Universal Emulation Memory (HUEM) Setup	2-19
2.5.1	U14 and U36: Emulation Memory Enable/Disable	2-19
2.5.2	U28 and U43: Memory Segment Selection	2-20
2.5.3	Factory Preset	2-21
2.6	Memory Selection for Microcontrollers (Z8 and ZS8)	2-22
2.6.1	Memory Selection for NEW MICE-II Z8	2-22
2.6.2	Memory Selection for NEW MICE-II ZS8	2-26
2.7	RS-232C Cable Connection	2-30
2.8	Applying Power to NEW MICE-II	2-33
2.8.1	No Response	2-35
2.8.2	Failure Device	2-36
2.9	Control Processor Software Reset Command	2-36
<b>CHAPTER 3:</b>	<b>NEW MICE-II COMMAND LANGUAGE</b>	3-1
3.1	Command Syntax	3-3
3.2	Notations and Conventions	3-4
3.3	Editing Characters	3-6
3.4	Control Characters and Delimiters	3-7
3.5	Reference Program for Examples	3-8
<b>CHAPTER 4:</b>	<b>NEW MICE-II UTILITY COMMANDS</b>	4-1
4.1	? Help Command	4-2
4.2	! Attention Command	4-4

<b>CHAPTER 5: MEMORY, PORT AND REGISTER COMMANDS</b>	5-1
5.1 M Memory Display/Examine/Modify/ Fill/Search Command	5-3
5.1.1 Memory Display	5-5
5.1.2 Memory Examine/Modify	5-6
5.1.3 Memory Fill	5-7
5.1.4 Memory Search	5-8
5.2 T Memory Checksum/Test/Transfer/ Compare Command	5-9
5.2.1 Memory Checksum	5-10
5.2.2 Memory Test	5-11
5.2.3 Memory Transfer	5-12
5.2.4 Memory Compare	5-14
5.3 A Line Assembly Command	5-16
5.4 Z Disassembly Command	5-20
5.5 I Port Input Command	5-23
5.6 O Port Output Command	5-25
5.7 X Reset/Initialization Command	5-26
5.8 R Register Display/Modify Command	5-28
5.8.1 Register Command for NEW MICE-II Z80 and NSC800	5-28
5.8.2 Register Command for NEW MICE-II Z8	5-30
5.8.3 Register Command for NEW MICE-II ZS8	5-33
5.9 J Jump/Branch Command	5-38
 <b>CHAPTER 6: CONTROL SIGNAL COMMANDS</b>	 6-1
6.1 E Enable/Display Control Signal Command	6-3
6.2 D Disable/Display Control Signal Command	6-4

<b>CHAPTER 7: EMULATION AND TRACE CONTROL</b>	
<b>COMMANDS</b>	7-1
7.1 G Go/Execution Command	7-4
7.2 H Halt/Breakpoint Set Command	7-5
7.2.1 Halt	7-6
7.2.2 Set Breakpoint	7-6
7.2.3 Display Breakpoint	7-8
7.2.4 Clear Breakpoint	7-9
7.3 F Forward Trace Command	7-10
7.4 B Backward Trace Command	7-14
7.5 L List/Display Trace Buffer Command	7-17
<b>CHAPTER 8: STEPPED EMULATION COMMANDS</b>	8-1
8.1 C Single Cycle, Step Command	8-2
8.2 S Instruction Step Command	8-4
8.2.1 Instruction Step	8-5
8.2.2 Instruction Step in Mnemonic Form	8-6
8.2.3 Instruction Step with Register Content	8-6
8.2.4 Instruction Step with Count	8-9
8.2.5 Instruction Step with Cycle Status	8-10
8.3 Application Note for Stepped Emulation Commands	8-11
<b>CHAPTER 9: UTILITY COMMANDS INVOLVING A SYSTEM</b>	9-1
9.1 : Download Command (Intel Format)	9-2
9.2 / Download Command (Tektronix Format)	9-6
9.3 U Upload Command	9-9

## APPENDICES

A: Summary of NEW MICE-II Commands	A-1
B: Hexadecimal-Decimal Conversion	B-1
C: ASCII Code Lists and Definitions	C-1
D: Writing a Driver Program	D-1
E: NEW MICE Driver Programs	E-1
F: High Performance Universal Emulation Memory Board (HUEM)	F-1
G: Real-time Trace Board (RTT)	G-1
H: Control Emulation Processor Board (CEP)	H-1
I: Z80	I-1
J: NSC800	J-1
K: Z8	K-1
L: ZS8	L-1
M: Error Messages	M-1
N: Warranty and Service	N-1

**MICE International Distributors**



## CHAPTER 1

### GENERAL INTRODUCTION

---

#### 1.1 Introduction To MICE

Microtek's versatile Micro-In-Circuit-Emulator (MICE) is a low-cost development tool that emulates most industry-standard microprocessors. It has set new standards for universal, high-performance emulation, at an exceptionally low cost-per-function.

Traditionally, microprocessor development was done on dedicated systems. The computer system had its complement of peripheral devices and sufficient mass storage to accommodate user programs, data, etc. A dedicated emulator was attached to the system to assist the designer in ensuring that both hardware and software were functioning properly.

Recently, a variety of general purpose computers have been designed for use in microprocessor development. Through the use of cross assemblers, code can be generated for the target system. However, these emulators are still dedicated to the particular computer.

With MICE, a third and more practical approach to microprocessor development is now available; one that uses fewer resources, performs most of the same functions, yet costs only a fraction compared with its predecessors. The MICE module is controlled via an RS-232C compatible interface. All software required to operate the MICE module are contained in EPROMs within the module. MICE can be operated by using a display



terminal only or in conjunction with a computer system. Different processors can be emulated by merely changing the personality card and associated EPROMs.

Some key features of MICE are:

- \* Operation at speeds up to the maximum rated frequency of the specified microprocessor.
- \* Target processor retains its entire memory and I/O space.
- \* Enabling and disabling of hardware control signals to the processor with console commands.
- \* Resident assembler and two-pass disassembler which assigns labels to subroutine and branch addresses.
- \* Built-in memory diagnostics and block memory transfer for target processor memory.
- \* Downloading and uploading of target program between MICE and host computer system.
- \* Help command that lists all commands along with the proper syntax.

## 1.2 Introduction to NEW MICE-II

### 1.2.1 Enhanced Features

NEW MICE-II is an enhanced member of the MICE family. Aside from retaining the original MICE features, NEW MICE-II has substantially been upgraded to include the following new features:

- \* High Performance Universal Emulation Memory (HUEM) with memory size selectable at 64K or 128K bytes (2 independent 64K settings) of static RAM for 8-bit NEW MICE-II models (user must specify if required for microcontroller versions).
- \* ~~Super Universal Emulation Memory (SUEM) with memory size 256K bytes of static RAM for 8 bit NEW MICE-II models.~~
- \* 8/256 Kbytes block enable/disable capability for HUEM/SUEM.
- \* User-qualified trigger to specify start or end of tracing for source code and machine statuses. Up to 2048 cycles and 40 channels of signals may be recorded for program debug.
- \* Supports up to 8 hardware trace points for program debug.

- \* Real-time forward and backward trace for up to 2048 machine cycles.
- \* Two real-time breakpoints.
- \* Supports disassembly for both Instruction Step and List Trace commands.
- \* With built-in power supply and cooling fan.

### 1.2.2 Breakpoint Processor

NEW MICE-II may also be equipped with the new Breakpoint Processor (BPP) board at user's option. The board allows the NEW MICE-II to provide more advanced features as summarized below:

- \* Sophisticated breakpoint logic, with up to 120 new breakpoint constructs.
- \* Flexible trigger constructs that can define single events, multiple activities or external hardware signals.
- \* Two data breakpoints and two external hardware breakpoints.
- \* Breakpoint interval timer that displays the interval between initial trigger and emulation stops.

### 1.2.3 Major Hardware Overview

NEW MICE-II is a low-cost powerful emulation instrument basically equipped with the following boards:

#### **Control Emulation Processor (CEP)**

- also called personality board

#### **Real-time Trace (RTT)**

#### **High Performance Universal Emulation Memory (HUEM) or**

#### **Super Universal Emulation Memory (SUEM)**

- also called memory board

#### **BreakPoint Processor (BPP)**

Remember that the CEP board can be interchanged to form any other NEW MICE-II. If more emulation memory is needed, additional HUEM boards may be added. And where more powerful emulation breakpoint or triggering capability is required, the BPP board is available.

#### 1.2.4 Conclusion

At half the cost of competitive units, NEW MICE-II provides features not available with other emulators. Some of the advantages of NEW MICE-II over other emulators are:

- universality** A wide variety of microprocessors can be emulated using this single development tool, thus avoiding both the inflexibility of dedicated systems and the heavy capital investment required for general purpose systems.
- versatility** Emulation of a different processor only requires changing the personality board. Multiple design projects can be carried out concurrently, and the CEP board can be reused for different projects.
- flexibility** With NEW MICE-II providing its own resident assembler and disassembler, it can be minimally configured with just a display terminal and power supply. After the target program has been downloaded from the host computer, testing can be done off-line, thereby freeing the computer.

### 1.3 NEW MICE-II Operating Configurations

NEW MICE-II can be used in several configurations. The simplest configuration requires only an RS-232C compatible terminal as the display console and command entry device. A computer system can also be configured as the controlling device.





Figure 1-1  
Configuring NEW MICE-II With an RS-232C  
Compatible Terminal or Host Computer

When a computer system is interfaced with NEW MICE-II, a driver program must be resident in the system. Driver programs and symbolic translator drivers are available for various systems. (See Appendix E for a detailed listing.)

Microtek has access to various sources of driver programs and other software tools. For updated information contact your local Microtek representative.

### 1.3.1 Universal Symbolic Debugger (USD)

The USD (Universal Symbolic Debugger), is a sophisticated software package designed specifically to enhance the debugging and other capabilities of Microtek's MICE series of emulators. USD acts an interface between the MICE user, MICE, and the host computer system, to make the optimum use of the resources available on each. It enhances the range of development, emulation, analysis and debugging features of MICE to a new dimension and providing MICE users with a high quality and broad range of support to suit their various engineering applications.



- \* Universal
- \* Enhanced symbol processing capability
- \* File management
- \* Command file
- \* Logic state analysis
- \* Software performance analysis
- \* Sophisticated utility commands
- \* Fully supports object files, and MICE's

### **\* Universal**

Almost all popular cross-assembler/cross-compiler formats, such as 2500AD, IAR, intel OMF51/85/86, and MRI format symbol tables are accepted. MICE command for all type MICE are fully transparent.

### **\* Enhanced symbolic processing capability**

Symbol table file can be: loaded/listed/saved; symbols can also be created/deleted. Any address can be qualified to check for symbol equivalence.

### **\* File management**

Hex file can be down loaded to emulation/user memory, and data in memory can be uploaded to host computer. All MICE and USD commands can be logged as a macro command file; all debug commands as well as the command output can be logged as an output file. The logged output file is especially useful in detailed checking of sophisticated debug session.

### **\* Command file**

Unlimited command lines can be edited in a command file. 10 replaceable parameters are permitted; conditional subcommands and loop block capability are provided.

### **\* Logic state analysis**

Trace buffer data, such as address bus, data bus, control, and spare signals can all be displayed in waveform.



**\* Software performance analysis**

**Module entry histogram:**

Display the number of calls for specified program addresses, along with a bar graph showing the percentage of processor activity for each address.

**Execution interval histogram:**

Display the number of times a program routine executes within different timing frames, along with a bar graph showing the percentage of processor activity for each range.

**\* Sophisticated utility commands**

Help for USD commands

Window facility is provided: foreground and background windows

Up to 16 command lines can be retained

DOS commands access

**\* Fully supports object files, and MICE's**

Firmware version supported (for the firmware and higher version).

For NEW MICE-II

Z80            V3.1 & later

NSC800        V3.2 & later

Z8             V3.1 & later

ZS8            V3.0 & later

**\* Host computers supported**

IBM PC/XT/AT (MS-DOS 2.0)

NEC 9801 (MS-DOS 3.0)

SUN MICRO WORKSTATION (UNIX 2.0)

VAX/VMS 4.1

uVAX/ULTRIX

#### 1.4 NEW MICE-II Applications

Because of its unique design, NEW MICE-II offers new applications which include:

1. Inexpensive evaluation of new microprocessors without purchasing a special evaluation board or expensive development system.
2. Several designers can share the use of a single development system, eliminating the difficult problem of allocating a single resource and the need for multiple work-stations. Large programs can be edited, assembled or compiled, and then downloaded to the target system. Since NEW MICE-II has its own assembler and disassembler, the programs can then be tested using only a display terminal.
3. NEW MICE-II's compact size, light weight, and rugged construction makes it an ideal field service instrument. Easily transported and set up in remote locations, NEW MICE-II can reduce downtime, provide on the spot diagnosis and resolution of field problems, avoiding customer inconvenience and expensive service delays. With its RS-232C interface, NEW MICE-II can be quickly interfaced with any compatible display terminal. Diagnostic programs can be generated using the resident assembler.
4. Personal computers can be upgraded to development systems at a fraction of the typical costs. Driver programs for various computers have already been written, allowing programs assembled or compiled to be downloaded.

## 1.5 NEW MICE-II Definitions

**MICE** is a patented trade name for Microtek emulators and stands for Micro-In-Circuit-Emulator.

**ICE cable** is an In-Circuit-Emulator cable that joins NEW MICE-II to the target.

**NEW MICE-IIH** is a conventional MICE emulator module consisting of three interconnected printed circuit boards. These boards are:

1. Control Emulation Processor (CEP) board.
2. Real-time Trace (RTT) board.
3. High Performance Emulation Memory (HUEM) board.

**NEW MICE-IIS** is a conventional MICE emulator module consisting of four interconnected printed circuit boards. These boards are:

1. Control Emulation Processor (CEP) board.
2. Real-time Trace (RTT) board.
3. Super Universal Emulation Memory (SUEM) board.
4. Breakpoint Processor (BPP) Board.



## CHAPTER 2

### NEW MICE-II INSTALLATION PROCEDURES

---


NEW MICE-II comes from the factory preset and completely assembled. The NEW MICE-II module consists of three printed circuit boards: Control Emulation Processor board (CEP), Real-time Trace board (RTT) and High Performance Universal Emulation Memory board (HUEM). ICE cables are also included which must be connected between NEW MICE-II and the target system.

#### 2.1 Setting Up NEW MICE-II

Detailed instructions for setting up the NEW MICE-II module are as follows:

##### 2.1.1 Opening the NEW MICE-II Case

NEW MICE-II is contained in a two piece high impact metal case. To open the case, hold the lower portion of the vertical end (rear) firmly with both hands and with your thumbs slide the top half forward about one half inch. This will separate the top from the bottom half.



NEW MICE-IIH

NEW MICE-IIS

Figure 2-1  
Opening The NEW MICE-II Case

### 2.1.2 Replacing the Personality Board (CEP) or Emulation CPU

1. To install a personality board in place of the current card, the cover of the NEW MICE-II case must first be removed. With power off, carefully remove the top personality card (CEP) from the NEW MICE-II module by disconnecting the two ribbon cable connectors which join the CEP board to the RTT board below, and then removing the six locking screws and six brass spacers.

Install the new personality board into the module by refastening the brass spacers and locking screws to hold the replacement card permanently in position. Then reconnect the two ribbon cable connectors from the RTT board below to the CEP board; the arrows indicating pin 1 must be aligned.

2. Only one CPU is supplied with NEW MICE-II per the customer's specification. To emulate the other processor, replace the CPU as indicated below:

<u>NEW MICE-II</u>	<u>CPU</u>	<u>Location</u>
* Z80	Z80/Z80A/Z80B/Z80H	U36
NSC800	NSC800	U24
Z8	Z8612	U38
ZS8	Z8883	U42

\* CPU alteration applicable to Z80 only.



### 2.1.3 Internal Adjustments

Access to all adjustment switches is possible with the NEW MICE-II cover removed. The DIP switch on the personality board is readily accessed from the top; and the three DIP switches for memory board selection are located in the opening at the end of the NEW MICE-II case, which results when the cover is removed. Pre-set instructions are explained in the following sections of this chapter.

### 2.1.4 Connecting the ICE Cable

#### 1. Z80

The ICE (In-Circuit-Emulator) cable assembly consists of one flat-wire cable with a 40-pin connector at one end and an IC header at the other end. To install the ICE cable after setup has been completed, remove the cover to NEW MICE-II, and attach the 40-pin connector at position J5 on the CEP board. Thread the IC header end through the rectangular opening in the NEW MICE-II case and slide the cover shut (section 2.1.6). Then attach the end with the IC header to the 40-pin target processor socket on the target board. Note that the ICE cable cannot be interchanged with other NEW MICE-II models.

## 2. NSC800

The ICE cable assembly (Figure 2-2) consists of an IC header at the Target Connected Board (TCB-NSC800DP). To install the ICE cable after setup has been completed, remove the cover of the NEW MICE-II, thread the connector end through the rectangular opening in the NEW MICE-II case, attach the 40-pin connector on the CEP board and slide the cover shut. At the target end of the cable, remove the protective padding from the bottom of the IC header. Gently insert the header into the appropriate CPU socket on the target board.




Figure 2-2

## 3. Z8

The ICE cable assembly (Figure 2-3) consists of two flat-wire cables with dual 40-pin connectors at one end (CHZ8) and a single 40-pin connector at the other end (THZ8). To install the ICE cable after setup has been completed, remove the NEW MICE-II cover and attach the end with dual 40-pin connectors at position J5 on the CEP board. Thread the IC header end through the

rectangular opening in the NEW MICE-II case and slide the cover shut (section 2.1.6). Then attach the end with a single 40-pin connector to the 40-pin target processor socket on the target board. (Note that the ICE cable cannot be interchanged with other NEW MICE-II models.)






Figure 2-3

#### 4. ZS8

Two different ICE cables are used for 40 and 48 pin target CPUs. The ICE cable assembly for a 40-pin target CPU (Figure 2-4) consists of two flat-wire cables with dual 40-pin connectors at one end and a single 40-pin connector at the other end (THZS8-40). The ICE cable assembly for a 48-pin target CPU (Figure 2-5) consists of two flat-wire cables with dual 50-pin connectors at one end and a single 48-pin connector at the other end (THZS8-48).

To install the ICE cable after setup has been com-

pleted, remove the NEW MICE-II cover and attach the end with dual 40/50 pin connectors at position J6/J5 on the CEP board. Thread the IC header end through the rectangular opening in the NEW MICE-II case and slide the cover shut (section 2.1.6). Then attach the end with a single 40/48 pin connector to the 40/48 pin target processor socket on the target board. Note that the ICE cable cannot be interchanged with other NEW MICE-II models.



### 2.1.5 Connecting the External Trace Cable

The external trace cable shown below is used for recording external signals during trace operations. To monitor any external activity not automatically recorded by trace commands, the input cable must be connected from the trace point connector on the CEP board to the target. This connector consists of a 9 post stick header on the CEP board designated X0-X7 from right to left, plus XG for ground.

The monitored signals are called spare bits and support concurrent trace with the address, data and status bus. Any of these bits can be monitored by trace commands to display hardware status (in the SPARE column) by executing List, Cycle Step and Instruction Step commands; where "1" represents a high (or floating) signal and "0" indicates a low signal.




Figure 2-6  
Signal Monitor Cable

### **2.1.6 Closing the NEW MICE-II Case**

To close the cover, set it over the base leaving a 1/2 inch gap. Holding the base firmly in the front, use your thumbs to push the cover the remaining distance. This will force the locking tabs into position and firmly attach the top to the base.

## 2.2 NEW MICE-II Specifications

Mechanical specifications for NEW MICE-II are:

Width	26.0 cm	(10.24 in.)
Height	12.7 cm	( 5.00 in.)
Length	33.0 cm	(13.00 in.)
Weight	5.0 kg	(11.00 lb.)

The minimum and maximum operation and storage limits for temperature and humidity are:

Operating Temperature:	0°~50°C(32°~122°F)
Storage Temperature:	-10°~65°C(14°~149°F)
Relative Humidity:	20 ~80%

NEW MICE-II equips one built-in power supply.

Power Consumption: AC100-120V~: 1.3A MAX  
AC200-240V~: 0.65A MAX  
47-63HZ

Voltage requirements: AC100-120V~ or  
AC200-240V~  
Factory-set

### 2.3 Communicating with NEW MICE-II

Whether NEW MICE-II is connected to a terminal or to a computer system, the connection between the controlling device and NEW MICE-II is across a programmable RS-232C compatible interface.

### 2.4 Control Emulation Processor Board (CEP) Setup

Other NEW MICE-II emulators can be formed simply by replacing the personality (CEP) board. If a change of personality boards is required, or modification to the factory preset conditions is necessary, the adjustment options are described in the following sections.

#### 2.4.1 Interface Parameter Selection

On the CEP board locate the six position DIP switch (NSC800 - U35 and all others - U17). This switch sets the following communication modes which are only examined by the control processor during power-up and re-set.

<u>Switch Selection</u>	<u>Description</u>
S1-S2-S3	Baud Rate
S4	7/8 Data Bits
S5	Disable/Enable Parity
S6	Odd/Even Parity

The number of stop bits is permanently set at two; and communication is full duplex. Each data frame consists of 1 start bit, 2 stop bits, 7/8 data bits and 1 parity bit if parity is enabled.



The transmission rate can be specified from 150-19200 baud by setting S1-S2-S3 of the DIP switch as follows:


Baud Rate	Switch Section		
	S1	S2	S3
150	ON	OFF	OFF
300	OFF	ON	OFF
600	ON	ON	OFF
1200	OFF	OFF	ON
2400	ON	OFF	ON
4800	OFF	ON	ON
9600	ON	ON	ON
19200	OFF	OFF	OFF *

\* This setting is only effective for the following (or later) firmware versions: V3.0 - ZS8, V3.1 - Z80/Z8 and V3.2 - NSC800. For all previous versions, this switch setting indicates 110 baud.

The number of data bits and parity can be specified by setting S4, S5 and S6 of the DIP switch as follows:

Mode	Switch Section		
	S4	S5	S6
8 Data Bits	OFF		
7 Data Bits	ON		
Parity Enable		OFF	
Parity Disable		ON	
Even Parity			OFF
Odd Parity			ON

NEW MICE-II personality boards are shipped from the factory preset to 9600 baud, 8 data bits, and none parity. Switch position for this default selection is as follows:



#### Default setting

When parity is disabled, the odd/even parity switch (S6) section can be set to either position since it is ignored.

### 2.4.2 Clock Selection

#### 1. For NEW MICE-II Z80

NEW MICE-II Z80 supports the Z80 dynamic RAM refresh function and is available in the following versions:

Z80	-	2.5MHz	clock oscillator
Z80A	-	4MHz	clock oscillator
Z80B	-	6MHz	clock oscillator
Z80H	-	8MHz	clock oscillator

The target's clock, the on-board clock, or the on-board clock with an option to support the target can be selected by placing jumpers on the personality board as follows:

	X8	X9	X10	X11	
EXT	C	0	0	C	
INT	0	C	C	0	
INT -->					C: Close
TARGET	C	0	C	0	0: Open

**Internal/External Clock Selection**

2. For NEW MICE-II NSC800

The target's clock or the on-board 5 MHz clock can be selected by placing jumpers on the personality board as follows:

	X8	X9	X10	X11	X1	X2	X3
INT	0	0	C	0	0	0	0
EXT							
TTL CLOCK	C	C	0	0	0	C	0
EXT							
CRYSTAL	C	C	0	0	C	0	C

**Internal/External Clock Selection**      C: Close  
0: Open

### 3. For NEW MICE-II Z8

The target's clock or the on-board 12MHz clock can be selected by placing jumpers on the personality board as follows:

THZ8\*  
Adapter

	X8	X9	X1	X2	X3
INT	C	O	O	O	O
EXT TTL CLOCK	O	C	O	C	O
EXT CRYSTAL	O	C	C	O	C

C: Close  
O: Open

**Internal/External Clock Selection**

\*The THZ8 Adapter is located on the target side of the ICE cable.

### 4. Clock Selection for NEW MICE-II ZS8

The target's clock or the on-board 20MHz clock can be selected by placing jumpers on the personality board as follows:

THZS8\*  
Adapter

	X8	X9	X1	X2	X3
INT	C	O	O	O	O
EXT TTL CLOCK	O	C	O	C	O
EXT CRYSTAL	O	C	C	O	C

C: Close  
O: Open

**Internal/External Clock Selection**

\* The THZS8 Adapter is located on the target side of the ICE cable.

### 2.4.3 Ready Signal Selection (Z80 and NSC800)

#### 1. For NEW MICE-II Z80

The target ready signal, or on-board ready signal (when memory is located in SUEM/HUEM) can be selected by placing jumpers on the personality board as follows:

	X14	X15	
TARGET	O	C	C: Close
ON-BOARD	C	O	O: Open

#### 2. For NEW MICE-II NSC800

The target ready signal can be selected by removing the jumper at X14; or if MICE emulation memory is selected, the on-board ready signal can be used by connecting a jumper at X14.

### 2.4.4 Bus State Selection (Z80)

NEW MICE-II Z80 permits the CPU to be stopped at either WAIT or BUSAK state. Stopped at WAIT state, the two refresh signals RFSH, MREQ will be lost but the CPU will stop in the middle of the machine cycle. Therefore, the messages displayed have not yet been executed. Under this condition, the DATA BUS, ADDRESS BUS and STATUS signals are still active and can be read. This simplifies hardware debug. Stopped at BUSAK state, refresh is still supported to the target; and the CPU will stop at the end of the machine cycle where the messages displayed have already been executed. Selection is shown below:

X12 X13

$\overline{\text{WAIT}}$	C	O	C: Close
$\overline{\text{BUSA\overline{K}}}$	O	C	O: Open

**$\overline{\text{WAIT}}/\overline{\text{BUSA\overline{K}}}$  Mode Selection**

**2.4.5 Vcc Selection (NSC800)**

The NSC800 Vcc on the target can be selected by removing the jumper at X12; or the on-board Vcc can be used by placing a jumper at X13.

	X12	X13	
INT	O	C	C: Close
EXT	C	O	O: Open

**Internal/External Vcc Selection**

### 2.4.6 ISR Function (Z80)

CEP-Z80 revision M supports ISR (Interrupt Service Routine) function in emulation memory. Mini-jumper X24 is used to enable/disable ISR.

X24	ON	ISR disable (default)
	OFF	ISR enable

#### Application Notes

When applying ISR function, if RETI instruction is placed in MICE emulation memory, take limitations below:

1. In the target, data buffer is not allowed between CPU and I/O devices.
2. Target memory location must not overlap with MICE emulation memory.
3. Before setting X24 to OFF, be sure to connect X19.

It is not able to implement ISR function by reworking previous version CEP L1 or earlier versions. ISR function only applies to firmware V2.1 and later.

## 2.5 High Performance Universal Emulation Memory Board (HUEM) Setup

There are four DIP switches located at the front of the HUEM board (bottom board in the NEW MICE-II module); U14/U28 (enabled for both the standard 64K byte version and the optional 128K byte version) and U36/U43 (enabled only for the optional 128K byte version). The individual keys on the switches are designated S1 through S8 or S10. (Refer to the placement chart on Appendix F for the board location of these switches.)

There are two separate 64K memory banks in the HUEM. U14 and U28 set bank 1; and U36 and U43 set bank 2. Note that bank 2 is only populated for the optional 128K byte version.

The DIP switches setup are explained in the following paragraphs.

### 2.5.1 U14 and U36: Emulation Memory Enable/Disable

The user can select any memory block of 8K bytes to disable or enable depending on the amount of emulation memory needed. Set individual keys ON for enable and OFF for disable.

S1	S2	S3	S4	S5	S6	S7	S8
Lowest 8K	.....	.....	.....	.....	.....	.....	Highest 8K

Position S9 and S10 are used as follows:



Mode	S9	S10
Write Enable	ON	
Write Protect	OFF	
Memory Enable		OFF
Memory Disable		ON

### 2.5.2 U28 and U43: Memory Segment Select

Memory segments may be selected within 16M bytes by setting U28 and U43 as follows:

Segment	Start Address	S1	S2	S3	S4	S5	S6	S7	S8
OK	0H	ON	ON	ON	ON	ON	ON	ON	ON
64K	10000H	OFF	ON	ON	ON	ON	ON	ON	ON
128K	20000H	ON	OFF	ON	ON	ON	ON	ON	ON
"	"				"				
"	"				"				
16320K	FF0000H				All	OFF			

Note: If bank 1 and bank 2 have the same start address (i.e. U28 and U43 have the same key setting), HUEM will select bank 1 only and disregard the U43 key setting for bank 2.

### 2.5.3 Factory Preset

HUEM is preset at the factory with the following switch positions (0-128K bytes):

U14,U36	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10
	ON	ON	ON	ON	ON	ON	ON	ON	ON	OFF

In this configuration all blocks (64K byte x 2) of emulation memory are enabled and write enabled.

U28	S1	S2	S3	S4	S5	S6	S7	S8
	ON	ON	ON	ON	ON	ON	ON	ON

All U28 keys are in the ON position. In this configuration, the bank 1 memory segment start address is 0000H.

U43	S1	S2	S3	S4	S5	S6	S7	S8
	OFF	ON	ON	ON	ON	ON	ON	ON

Only S1 is OFF. In this configuration, the bank 2 memory segment start address is 10000H.

Setting U14, U28, U36 and U43 completes setup of the HUEM board.

## 2.6 Memory Selection for Microcontrollers (Z8 and Z8S)

### 2.6.1 Memory Selection for NEW MICE-II Z8

1. The Z8 family of processors has three types of memory: internal program memory (P), external program memory (P), and external data memory (X). P and X serve as optional qualifiers for M/T commands, with program memory (P) as the default value. Note that if qualifier X is used to address internal program memory, an error message will display:

"LOCATION ERROR!"

CPU	Addressable Memory			Addressable I/O
	Internal Program	External Program	External Data	
Z8611/Z8613	000H-FFFH	1000H-FFFFH	1000H-FFFFH	Ports P0-P3
Z8601/Z8603/Z8671	000H-7FFH	800H-FFFFH	800H-FFFFH	Ports P0-P3
Z8681	none	000H-FFFFH	000H-FFFFH	Ports P0-P3
Z8682*	none	800H-FFFFH	800H-FFFFH	Ports P0-P3

\*000H-7FFH is not addressable.

2. Internal program memory (4K bytes) is located in emulation memory on the CEP board (6264 RAM at U51).
3. If program memory is larger than 4K bytes or external data memory is used, then a SUEM/HUEM board must be used for emulation memory. To select SUEM/HUEM, set control register P01M (F8H) with the R command, or with the user's program, to define Port 0 in address mode (P0=ADDR) and Port 1 in address/data mode (P1=A/D); i.e. set D7; D4 & D1=1 and D3=0 in register P01M (RF8=1XX10X1X).  
Example: Set RF8=96H to specify -

a) P00-P07=A8-A15

- b) P10-P17=AD0-AD7
- c) internal stack pointer
- d) normal external memory timing

4. However, if memory space is segregated, then input the EX command (Chapter 6), and logically select program memory and data memory using Data Memory select output. Define Port3-pin4 for Data Memory output, by setting control register P3M (F7H) with the R command, or with the user's program, to P34=DM. External segregated emulation memory is located in SUEM/HUEM, with program memory at 1000H-FFFFH and data memory at 11000H-1FFFFH.

Example: If the program memory range is 0 3FFFH and data memory range is 1000H 1FFFFH, then set emulation memory as indicated below for SUEM or HUEM.

- SUEM Set these two parameters regardless of the option selected -
- \* emulation memory block enable/disable
  - \* memory offset address to 0H
- a) Emulate program memory only by setting -
- \* memory segment to 0H
  - \* starting address to 0H
- b) Or emulate data memory only by setting -
- \* memory segment to 10000H

**HUEM** Enable all emulation memory by setting -  
 \* U14 and U36 S1-S9 ON and S10 OFF  
 Emulate program memory in bank 1 by setting -  
 \* memory segment to 0H (U28 S1-8 all ON)  
 Emulate data memory in bank 2 by setting -  
 \* memory segment to 10000H (U43 S1 OFF, all others ON)

5. HUEM can cover the entire emulation memory range required for external program and external data memory (max 120K bytes).

Because the offset address **cannot** be defined for HUEM, the first 4K bytes of both memory banks are disabled. For information on HUEM switch settings refer to section 2.5.

**Emulation Memory Selection**

Required Memory Size Emulation Memory Location	<4K bytes	>4K bytes	
		Segregated (set EX, & P34=DM)	Combined (set DX)
SUEM	Not needed	Use for program or data memory (max 120K bytes)	Max 60K bytes
HUEM	Not needed	Use for program or data memory, or both (max 120K bytes)	Max 60K bytes
CEP U51(6264)*	Used as internal program memory (Max 4K bytes)		

\*If program memory (0-4K) is located in target ROM, either read the data into the host computer and then download it to MICE emulation memory, or place the target ROM (if a 2732 or 2764) on the CEP-Z8 at U51.

- a) If HUEM is selected and memory is combined, then both program and data memory must be located in the same memory bank (HUEM has two separate 64K byte memory banks) with the memory segment set to OH (U37/U43 S1-8 all ON). Because the first 4K bytes (in each memory bank) are always disabled (0K-4K internal program memory is located on the CEP-Z8), the maximum addressable memory on HUEM is 60K bytes.

However, if memory is segregated, then program memory should be located in one memory bank and data memory in the other bank. The maximum addressable memory on HUEM is then 120K bytes.

- b) When using SUEM, up to 120K bytes of external memory can be defined. The start address for 120K bytes of emulation memory can be specified anywhere within the available emulation memory (refer to SUEM section).
- c) The first 4K bytes are always internal program memory. Remember that the 2K to 4K bytes of external program memory downloaded to the CEP-Z8 for the Z8601, Z8603, Z8671 and Z8682 is addressed as internal memory.

## 2.6.2 Memory Selection for NEW MICE-II ZS8

1. The Super-8 family of processors has three types of memory: internal program memory (P), external program memory (P), and external data memory (X). P and X serve as optional qualifiers for M/T commands, with program memory (P) as the default value.

CPU	Addressable Memory			Addressable I/O
	Internal Program	External Program	External Data	
Z8811/Z8813	0000H-0FFFH	1000H-FFFFH	0000H-FFFFH	Ports P0-P3
Z8821/Z8823	0000H-1FFFH	2000H-FFFFH	0000H-FFFFH	Ports P0-P3
Z8831/Z8833	0000H-3FFFH	4000H-FFFFH	0000H-FFFFH	Ports P0-P3
Z8810/Z8812	0000H-0FFFH	1000H-FFFFH	0000H-FFFFH	Ports P0-P4
Z8820/Z8822	0000H-1FFFH	2000H-FFFFH	0000H-FFFFH	Ports P0-P4
Z8830/Z8832	0000H-3FFFH	4000H-FFFFH	0000H-FFFFH	Ports P0-P4
Z8801	none	0000H-FFFFH	0000H-FFFFH	Ports P2-P3(P0)
Z8800	none	0000H-FFFFH	0000H-FFFFH	Ports P2-P4(P0)

The Z8800 and Z8801 microprocessors can use port P0 for addressable I/O or external memory, where the address range is selectable at 0000H-0FFFH or 0000H-FFFFH depending on address pin definition.

2. Internal program memory (0/4/8/16 Kbytes) is located in emulation memory on the CEP board (two 6264 RAMs at U52 and U53). The size of the internal memory to be emulated is selected by placing jumpers on the personality board as follows.

Internal Memory Size	Jumper Setting			
	X10	X11	X12	X13
none (ROMless)	C	O	C	O
4K	O	C	O	C
8K	C	O	O	C
16K	O	C	C	O

C: Close  
O: Open

**Size of Internal Program Memory**

3. If the user's program is larger than internal program memory or external data memory is used, then a SUEM/HUEM board must be used for emulation memory. To select SUEM/HUEM, set mode register POM (FOH, BANKO) and PM (F1H, BANKO) with the R command, or with the user's program, to define Port 0 in address mode (P0=ADDR) and Port 1 in address/data mode (P1=A/D); i.e. set D7-D0=1 in register POM (RSOF0=FF), and D5=1 in register PM (RSOF1=20).

Example: Set RSOFO=FF and RSOF1=20 to specify -

- a) P00-P07=A8-A15
- b) P10-P17=AD0-AD7

4. However, if memory space is segregated, then input the EX command (Chapter 6), and logically select program memory and data memory using Data Memory select output. Define Port3-pin5 for Data Memory output, by setting mode register PM (F1H, BANKO) with the R command, or with the user's program, to P35=DM. External segregated emulation memory is located in SUEM/HUEM, with program memory at 0000H-FFFFH and data memory at 11000H-1FFFFH.



Example: If the external program memory range is 4000H-BFFFH and data memory range is 1000H-8FFFH, then set emulation memory as indicated below for SUEM or HUEM.

SUEM a) Emulate program memory only by setting -  
\* memory segment to 0H  
\* starting address to 4000H

b) Or emulate data memory only by setting -  
\* memory segment to 10000H  
\* starting address to 1000H

HUEM Enable all emulation memory by setting -  
\* U14 and U36 S1-S9 ON and S10 OFF  
Emulate program memory in bank 1 by setting -  
\* memory segment to 0H (U28S1-8 all ON)  
Emulate data memory in bank 2 by setting -  
\* memory segment to 10000H (U43 S1 OFF, all others ON)

5. SUEM/HUEM can cover the entire emulation memory range required for external program and external data memory (max 128K bytes).

Because internal program memory is located on the CEP board at U52/U53, do not set the address for SUEM within the internal memory range. However, the offset address **cannot** be defined for HUEM. Therefore, the first 0/4/8/16 Kbytes of the memory bank containing program memory are disabled when emulation memory is segregated, and the first 0/4/8/16 Kbytes of both memory banks are disabled when emulation memory is combined. For information on HUEM switch settings refer to section 2.5.

**Emulation Memory Selection**

Required Memory Size Emulation Memory Location	0, <4/8/16 Kbytes* (Microcontroller)	>0/4/8/16 Kbytes* (Microcomputer)	
		Segregated (set EX, & P35=DM)	Combined (set DX)
SUEM	Not required	Use for program or data memory (max 128K bytes)	Max 64K bytes
HUEM	Not required	Use for program or data memory, or both (max 128K bytes)	Max 64K bytes
CEP U52/53(6264x2)**	Used as internal program memory (Max 16K bytes)		

\* Depends on the target processor under emulation.

\*\* If internal program memory is located in target ROM, either read the data into the host computer and then download it to MICE emulation memory, or place the target ROM (if a 2764) on the CEP-ZS8 at U52 or U53.

a) If HUEM is selected and memory is combined, then both program and data memory must be located in the same memory bank (HUEM has two separate 64K byte memory banks) with the memory segment set to 0H (U37/U43 S1-8 all ON). Because the internal memory range is always disabled (0/4/8/16 Kbytes internal program memory is located on the CEP-ZS8), the maximum addressable memory on HUEM is 64 Kbytes.

However, if memory is segregated, then program memory should be located in one memory bank and data memory in the other bank. The maximum addressable memory on HUEM is then 128K bytes.

b) When using SUEM, up to 128K bytes of external memory can be defined. The start address can be specified anywhere within the available emulation memory (SUEM section).

## 2.7 RS-232C Cable Connection


After selecting the proper data rate and transmission characteristics, next determine whether the controlling device has a data terminal equipment (DTE) interface or a data communication equipment (DCE) interface, with or without handshaking. Display terminals are usually equipped with DTE interface; computer systems usually have both.

There are several methods for determining the type of interface on the controlling device. The first method is by simple trial and error. If this fails, procedures two and three listed below can be used to determine the interface type. (It must be known beforehand whether or not handshaking is selected as a software option for the controlling device, as it cannot be easily detected by examining hardware signals.) Subsequent instructions detail how to accomplish interface header rewiring if required.

1. Try connecting the two devices together. If the response is correct, the interfaces match and no further adjustment is required. If the interconnect does not work, a mismatch exists and indicates that a connection change is necessary.
2. Data are transmitted on pin 2 and received on pin 3 of the D-connector for DTE devices; the reverse is true for DCE devices.
3. When not transmitting, the voltage (with respect to pin 7 [ground] of the D-connector) is -12 VDC on pin 2 for DTE devices and -12 VDC on pin 3 for DCE devices.

The header designated as U13 on the CEP board is used to configure the interface between NEW MICE-II and the controlling device. NEW MICE-II are shipped from the factory with a straight-wired header for DTE with hand-shaking.


Pins 1-7 on the interface header are connected to the female D-connector (J2) while pins 8-14 are connected to the NEW MICE-II, RS-232C interface logic. Pin definitions on the header are shown below:



\*RS-232C interface gate for 1488 or 1489 depending on signal Input or Output.

The wiring configuration for all three header types is shown below. Note that if the controlling device has a DCE interface, incoming signals are now outgoing, and vice versa, on the same pins. By removing the cover to the header, the interface type used by MICE can be determined according the following wiring configuration.

**DTE with      DCE with      DTE without      DCE without**  
**handshaking    handshaking    handshaking    handshaking**



When wired for DTE, connect NEW MICE-II using a straight-wire cable with male D-connectors; for other header types, the cable must be rewired accordingly. If a display terminal is connected after making the proper connections, NEW MICE-II should respond when power is applied. (A display terminal should always be used to check new NEW MICE-II units to ensure that they are properly functioning.)

Finally, NEW MICE-II requires that both Request to Send and Data Terminal Ready inputs, pins 10 and 13 respectively on the logic side of the header, be at +12 VDC before it transmits any data. If the controlling device does not supply the necessary voltage, it can be obtained by reconnecting pins 10 and 13 directly to pin 14 (Received Line Signal Detector) of header U13 which is always at +12 VDC.

To accommodate computer systems which are sending commands and data too fast for NEW MICE-II, the Data Set Ready output, normally at +12 VDC, is pulled low by NEW MICE-II to -12 VDC. The signal is restored to +12 VDC when NEW MICE-II is again ready. Also, to accommodate display terminals with slow carriage-returns or line-feeds, six null characters are always transmitted after a carriage-return is issued.

## 2.8 Applying Power to NEW MICE-II

Connect the RS-232C cable from the controlling device to the female D-connector at the rear of NEW MICE-II. (The recommended power-on sequence is to first apply power to the target and then to NEW MICE-II; and to use the opposite sequence when powering off.) With the controlling device ready, connect the power cable with the locking tab pointing up, and apply power. Within a few seconds, the following start-up message should display:

---

```
***MICE-II-type V#.****
```

```
>
```

---

**type** identifies target processor being emulated by the personality card.

**#.** **#** indicates version number of controlling program on personality card.

**>** is the prompt character indicating that NEW MICE-II is ready for a command.

In response to the command prompt character ">" enter a question mark "?", immediately followed by a carriage

return. If the data bits and parity are correctly matched, the NEW MICE-II command summary is listed; otherwise, the error message "WHAT?" is printed. Reset the switch section where necessary and remember to wait a few seconds before power is turned on again.

Notes 1. If target VCC is not provided when NEW MICE-II is powered up, the following message will display:

Z80 - NO TARGET VCC; NMI, INTR, RESET, BUSRQ DISABLED!  
NSC800 - NO TARGET VCC; NMI, INTR, BREQ DISABLED!  
Z8 - NO TARGET VCC; IRQ, RESET DISABLED, MEMORY COMBINED!  
ZS8 - NO TARGET VCC; RESET DISABLED, MEMORY COMBINED!

2. The CPU is automatically reset after power-up, software reset command "r" (section 2.9) or MICE Reset command X (section 5.7). If the target system has any peripheral devices or slave processors which must be synchronized with a CPU reset, then the reset must be performed on the target side. A target reset signal will also reset the emulation CPU. However, the reset control signal for MICE must be enabled (section 6.2) for the Z80/Z8/ZS8, otherwise the target reset signal cannot reset the emulation CPU.

Note that a synchronized reset may be performed by either MICE or the target system for the NSC800, since this processor supports a RESET output signal when the reset line for peripheral devices or slave processors on the target side is connected to reset pin-37.

### 2.8.1 No Response

If there is no response from NEW MICE-II, check the following items:

1. Check the RS-232C cable connection at both ends.
2. Check the power supply connections and voltages.
3. Check that the header has the proper interface.
4. Check that both Request to Send and Data Terminal Ready, pins 10 and 13 on the header are at +12 VDC.
5. Check that the controlling device has the proper voltage level requirements on its RS-232C inputs for transmission and reception.
6. Check that the baud rates of the controlling device and NEW MICE-II are the same, resetting if necessary. If a message does appear but is garbled, any combination of the baud rate, data length or parity could be incorrectly set.
7. Check the RS-232C cable for incorrectly wired or loose pins.
8. If a computer system is the controlling device, check that the driver program is running and the RS-232C cable is connected to the correct port and that the port is working.



Note: When changing the communication configuration switch, note that it is only read during a power-up or reset. After turning the power off, wait a few seconds before the power is turned on again to allow the capacitors to fully discharge.

If the problem still cannot be found, contact your local Microtek representative for further assistance.

### 2.8.2 Failure Device

During the delay prior to the start-up message the RAMs and EPROMs on the CEP board are tested. If any component failures exist, they are listed as detected in the following format: "U## - FAILURE", where ## is the component number on the personality board.

## 2.9 Control Processor Software Reset Command

The character "r" is the command to reset NEW MICE-II. Remember that except for this command all alphabetic characters must be entered in upper-case; no other lower-case characters are recognized.

## CHAPTER 3

### NEW MICE-II COMMAND LANGUAGE

---

All NEW MICE-II products have a common set of commands identified by a single or double character regardless of the processor being emulated. No additional time or effort is required to learn a new command language when the target processor changes.

These commands are described in the following chapters along with a variety of available options, though not all options are applicable for the different types of processors. For the specific processor being emulated, consult the Help "?" command. The commands described in the following chapters are grouped as follows:

#### **NEW MICE-II Utility Commands**

- ? Help Command
- ! Attention Command

#### **Memory, Port and Register Commands**

- M Memory Display/Examine/Modify/Fill/Search Command
- T Memory Checksum/Test/Transfer/Compare Command
- A Line Assembly Command
- Z Disassembly Command
- I Port Input Command
- O Port Output Command
- R Register Display/Modify Command
- J Jump/Branch Command
- X Reset/Initialization Command

### **Control Signal Commands**

- D Disable/Display Control Signal Command
- E Enable/Display Control Signal Command

### **Emulation and Trace Control Commands**

- G Go/Execution Command
- H Halt/Breakpoint Set Command
- F Forward Trace Command
- B Backward Trace Command
- L List Trace Buffer Command

### **Stepped Emulation Commands**

- C Single Cycle, Step Command
- S Instruction Step Command

### **Utility Commands Involving a System**

- : Download Command (Intel Format)
- / Download Command (Tektronix Format)
- U Upload Command

### 3.1 Command Syntax

NEW MICE-II indicates that it is ready to accept a command line by printing a greater-than character ">" on a new line. A command may then be entered and must be terminated by a carriage-return <CR>. The general syntax of NEW MICE-II commands is:

**command [parameters] <CR>**

where: **command** is the command representation.

**parameters** are one or more variable data supplied with the command. Parameters are alphanumeric; when a numeric parameter is called for, it must be entered in hexadecimal.

Where a space is shown in the syntax, either a space or comma can be used. A <CR> must be used to terminate a command input line. In most cases line feed <LF> or <CR> have the same effect, except where otherwise noted. Note that brackets [ ] and braces { } are used for describing command syntax only, and are not used in command input.

### 3.2 Notations and Conventions

A set of conventions is used to describe the structure of commands. The notations and rules are as follows:

1. An upper-case entry must be input.
2. A lower-case entry in the description of a command is the class-name for a parameter. A particular value for this class must be entered. A classname never appears in an actual operable command. For example, the lower-case entry - "**start-address**" means that NEW MICE-II will only accept a hexadecimal value as an address in the target processor's memory space.
3. A required entry is shown without any enclosures; whereas an optional entry is denoted by enclosing it in brackets. For example, in the command description - "**G[address]**", the command "G" is required, and the brackets around the entry "address" means that it is optional in this command.

Where brackets are within another set of brackets, the entry enclosed by the inner brackets may only be entered if the items outside those inner brackets are first entered. For example, in the command description - "**I port[ count[ time]]**", the "I port" is required; and the brackets mean that the combination of "count" and "time" is optional. However, a "count" must first be entered and a "time" value is to be specified.

4. Where an entry must be selected from a choice of two or more, the choices for the required entry are enclosed in braces and separated by vertical bars. For example - "S|M|a3[ V]" indicates that either "S", "M" or "a3" must be entered.
5. Where a choice exists for an optional entry, the choices are enclosed in brackets and separated by vertical bars. For example, "[I|H|T]" indicates that either "I", "H" or "T" may be entered.
6. "Addx" is a hex address with a wildcard byte pair of "XX" or "XXXX", or a wildcard nibble of "X" [only for the third digit (e.g. X23) for 8048]; where X indicates that the digits are "don't care". For example - "12XX" means all addresses between 1200H and 12FFH.
7. Commands A/C/S/I/R all use carriage-return <CR> or line-feed <LF> to display the next line.
8. In the Memory Modify (M) command, use a <CR> to advance to the next location and a <LF> to return to the previous location.
9. Entries underlined in command examples indicate user input.

### 3.3 Editing Characters

Each character entered on the keyboard is stored in a line editing buffer until <CR> is entered. If more than 80 characters are entered without inputting a <CR>, an error message is printed, and the command is ignored.

The line editing buffer can be edited or entirely deleted by using special non-printable editing characters. Control characters are entered by holding down the control key <CTRL> while the character is typed. Control character input is expressed with the control command enclosed in < > brackets.

**BACKSPACE** deletes the preceding character from the line buffer and from the display. Repeated usage is allowed. <CTRL-H> performs the same function. When a hardcopy terminal is used instead of a display screen, RUBOUT should be used.

**RUBOUT** deletes the preceding character from the line buffer and echoes the deleted character on the display, preceded by a backslash character. Repeated usage is allowed. On some terminals, this key may be labeled as DELETE or DEL.

**ESCAPE** ignores the current contents of the line buffer and prompts ">" for a new command on the next line. This key is also used to terminate commands in process and to return to the prompt state. ESCAPE is also expressed as <ESC>. On some terminals, this key may be labeled ESC. <CTRL-Y> performs the

same function.

- <CTRL-R> causes a <CR> or <LF>, followed by a redisplaying of the current undeleted contents in the line buffer. This is useful to see a clean copy of the command line after RUBOUT has been used.
- <CTRL-X> ignores the current contents of the line buffer and shifts the cursor to the first position of the next line, awaiting input of new data.

### 3.4 Control Characters and Delimiters

The following control characters have special meaning for all NEW MICE-II firmware:

- <CTRL-J>: is the same as <LF>.
- <CTRL-M>: is the same as <CR>.
- <CTRL-S>: stops data transmission from NEW MICE-II.
- <CTRL-Q>: continues data transmission from NEW MICE-II.
- <CTRL-Y>: is the same as <ESC>.



### 3.5 Reference Program for Examples

The following sample program for a Z80 target is used as the basis for most of the examples listed in this user's manual. It includes commonly used instructions for performing various bus cycles.

LOC	OBJ	LINE	LABEL	SOURCE CODE
0000	310020	0001	B0000	LD SP,2000
0003	CD0001	0002		CALL 0100
0006	DD210030	0003		LD IX,3000
000A	110010	0004		LD DE,1000
000D	1A	0005	B000D	LD A,(DE)
000E	DD7700	0006		LD (IX+00),A
0011	DD23	0007		INC IX
0013	13	0008		INC DE
0014	7B	0009		LD A,E
0015	FE0F	0010		CP OF
0017	C20D00	0011		JP NZ,000D
001A	C30000	0012		JP 0000
0100	110010	0001		LD DE,1000
0103	3E20	0002	B0103	LD A,20
0105	12	0003		LD (DE),A
0106	7B	0004		LD A,E
0107	13	0005		INC DE
0108	FE0F	0006		CP OF
010A	C20301	0007		JP NZ,0103
010D	C9	0008		RET
010E	3A003A	0009		LD A,(3A00)

## CHAPTER 4

### NEW MICE-II UTILITY COMMANDS

---

These commands allow the user to query NEW MICE-II for a summary of the commands and syntax that are available for the target under emulation. In addition, the user can query to display the processor type being used.

- Notes: 1. If any code other than FFH\*<sup>1</sup> is placed in firmware at the location indicated in table 4-1, it will cause the handshaking code at this location to be sent to the host computer (or terminal) when MICE is waiting for input. This extra code can be used to improve interface efficiency with the host.
2. The handshaking code 03H\*<sup>2</sup> is sent to the host computer when MICE is waiting for input. Any code other than 003H may be placed in firmware (table 4-1) to suit the user's specific requirements.

NEW MICE-II	CEP Location	Address	Handshaking Code	
			FFH <sup>1</sup>	03H <sup>2</sup> (ETX)
Z80	U4	1FFDH	V1.0-V3.0	V3.1 & later
NSC800	U4	1FFDH	V1.0-V3.1	V3.2 & later
Z8	U1	3FFDH	V3.0	V3.1 & later
ZS8	U1	3FFDH		V3.0 & later

Table 4-1 Handshaking Codes

## 4.1 Help Command - ?

---

?

---

? is the command for Help.

The command summary or the target processor currently being emulated is displayed on the terminal. All commands are common regardless of target processor type, but command parameters may differ for the different processors under emulation.

Example: Display the command summary for NEW MICE-II Z80.

>?

ASSEMBLY	A [loc]
BACKWARD TRACE	B [R] addr[ c[ q]]
CYCLE STEP	C [c]
DISABLE	D [N I B R]
ENABLE	E [N I B R]
FORWARD TRACE	F [R] addr[ c[ q]]
EXECUTION	G [address]
BREAKPOINT	H [0 1 2] 1 [addr[ c[ q]]] 2 [addr]]
INPUT	I port[ c[ time]]
JUMP	J address
LIST TRACE	L [step[ a1[ a2[ q...]]] S[step] Z[step] N]
MEMORY	M [a1[ a2[ d1...[ d8]][ S]]]
OUTPUT	O port d1[ d2[...[ d8]]]
REGISTER	R [P][A B C D E H L I F X Y S]
INSTRUCTION STEP	S [S R][c] Z]
TRANSFER/TEST	T a1 a2 S M a3[ V]
UPLOAD	U a1 a2 [ T  I]
RESET	X
DISASSEMBLY	Z [a1[ a2]]
DOWNLOAD	: (INT), / (TEK)

HELP                   ? [B]  
ATTENTION             !  
>

The above summary does not fully follow the notations and conventions previously described to avoid a lengthy display.

NEW MICE-II Z80 is used as the basis for all examples in this manual. Command syntax varies for different NEW MICE-II emulators; for the proper syntax consult the Help (?) command.

## 4.2 Attention Command - !

---

!

---

! is the command for Attention.

The target processor type currently being emulated together with firmware version number by the personality card in NEW MICE-II is displayed on the terminal. Six characters are used for identification.

Example: Display the processor type currently being emulated (Z80).

```
>!
EPZ80R
>
```

The messages for 8-bit series processor types are:

<u>NEW MICE-II</u>	<u>TARGET PROCESSOR TYPE</u>
Z80	(Zilog Corporation) - EPZ80/EPZ80R
NSC800	(National Semiconductor) - EP800
Z8	(Zilog Corporation) - CEP-Z8
ZS8	(Zilog Corporation) - EP-ZS8

## CHAPTER 5

### MEMORY, PORT AND REGISTER COMMANDS

---

These commands give access to the contents or current values stored in designated memory locations, I/O ports and registers. The memory type, maximum amount of addressable memory, and total amount of addressable I/O are shown below. Note that targets with only one memory type have no distinction between program and data memory. For microcontroller versions with multiple memory types, refer to section 2.6.

CPU	Addressable Memory	Addressable I/O
Z80	0000H-FFFFH	0000H-FFH
NSC800	0000H-FFFFH	00H-FFH

NEW MICE-II always checks that memory type and memory/port addresses are valid before an operation is performed. References to an invalid address result in an error message (**ERROR!**) being printed and the command ended. NEW MICE-II will verify memory write operations. However, it will not verify memory read or I/O operations. If there is no memory when executing a memory read operation, then data read is random. And if there is nothing connected to the port when executing an I/O operation, then data written is lost and data read is random.

- Notes: 1. When performing READ/WRITE functions, if external circuitry does not respond with the following signal, "TARGET IS NOT READY!!" will appear on the console and the contents of the registers will be retained.

Z80	WAIT
NSC800	WAIT

However, if the target does not respond when performing READ/WRITE functions for NEW MICE-II Z8 or ZS8, incorrect data will be displayed.

2. A blank space (ASCII 20H) along with a handshaking code (ASCII 03H) is sent at the end of each displayed line immediately before the cursor for the Assembly, Memory Modify and Register Modify commands. This code serves as an end of data message to the host computer; and is provided to help in implementing symbolic debuggers. (Refer to page 4-1.)

## 5.1 Memory Display/Examine/Modify/Fill/Search Command - M

---

Z80/NSC800 - M[start-address[ end-address[ data-1[ data-2[ ...data-8]]] S|]]]  
Z8/ZS8 - M[[P|X][start-address[ end-address[ data-1|..data-8]]] S|]]

---

**M** is the command for Memory Display/Examine/Modify/Fill/Search. If no other parameters are specified, inputting "M<CR>" will display the next 256 bytes starting at the current PC.

**P|X** are memory type designations for micro-controllers indicating program memory and external data memory respectively. (Refer to section 2.6 for a detailed description of memory types.)

**start-address** is a hexadecimal address of the emulation CPU indicating a memory location where the operation is to begin.

**end-address** is a hexadecimal address of the emulation CPU indicating the last memory location of the specified range.



data-1...8 are hexadecimal or ASCII data. Data in ASCII must be enclosed within two apostrophes (e.g. 'AR'). Where a "block fill" or "block search" operation is specified, the block may be up to 8 bytes in hex or 8 characters in ASCII. Combined use of hex and ASCII is permitted. If the address range (from start to end-address) is smaller than the block size (data1 - data8), then block-fill is still executed but excess trailing data is ignored; for block-search however, **"MEMORY SEARCH FAILURE!"** will display. (Note that the apostrophe ['], lower case "r" and MICE editing/control characters are not allowed for ASCII input.)

S defines a "search" option which looks for specified data.

Where the start and end-address are defined for a memory range in the emulation processor, the end-address must be greater than or equal to the start-address or an error message is printed and the command ends.

### 5.1.1 Memory Display

---

**M[start-address[ end-address]]**

---

Input a start and end-address to display the content of a memory range. Memory contents are displayed in hexadecimal and ASCII. Note that data without an ASCII equivalent is indicated by a period. The end-address must be greater than or equal to the start-address or an error message is printed and the command ends. The display can be terminated by entering an <ESC>.

Example: Display program memory contents 0H to 16H.

```
>MO 16
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
0000 31 00 20 DD 21 31 00 CD 1B 00 DD 21 54 00 CD1B 1. .!1.....!T...
0010 00 DD 21 99 00 CD 1B                               ..!....
>
```

## 5.1.2 Memory Examine/Modify

---

### M start-address

---

If only the start-address is specified, the content of that memory location is first displayed. NEW MICE-II then waits for input. To advance to the next memory address, a <CR> should be entered; the next memory location's content is then displayed, and NEW MICE-II again waits. To go back to the previous memory address a <LF> should be entered; the previous memory location's content is then displayed, and NEW MICE-II again waits. Entering a <CR> or <LF> repeats the entire sequence. If an <ESC> is entered, the command ends.

To change the memory content displayed, enter a new value and a <CR> or <LF>. (Note that the apostrophe ['], lower case "r" and MICE editing/control characters are not allowed for ASCII input.) After writing data to memory, verification of memory starts automatically. If any data does not match, the following message displays: "**MEMORY VERIFICATION FAILURE!**".

Example: Examine and modify the memory contents from address location 1000H, then display the results.

```
>M 1000
1000 00 31<CR>
1001 00 'A'<CR>
1002 00 <LF>
1001 41 31<CR>
1002 00 <ESC>
>M 1000 100F
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
1000 31 31 00 00 00 00 00 00 00 00 00 00 00 00 0000 11.....
>
```

### 5.1.3 Memory Fill

---

**M start-address end-address data-1[ data-2[ ...data-8]]**

---

Input a start and end-address for the memory range to be filled. A specified data value or data block may be written into the defined range.

Example: Write the ASCII value "NEW DATA" into the memory range 1017H to 102FH and then display the memory contents for the range 1000H to 102FH.

>M 1017 102F 'NEW DATA'

>M 1000 102F

	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F	ASCII-CODE	
1000	31	31	00	00	00	00	00	00	00	00	00	00	00	00	00	0000	11.....	
1010	00	00	00	00	00	00	00	00	4E	45	57	20	44	41	54	41	4E	.....NEW DATAN
1020	45	57	20	44	41	54	41	4E	45	57	20	44	41	54	41	4E	EW DATANEW DATAN	

>

#### 5.1.4 Memory Search

---

**M start-address end-address data-1[ data-2[ ...data-8]] S**

---

Input a start and end-address for the memory range to be searched. A specified data value or data block may be searched for within the defined range.

Example: Search for string "BA 10" in the range 0H to 1FH, which is not found; then search for string 'NEW' in the same address range.

```
>M 1000 102F
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
1000 31 31 00 00 00 00 00 00 00 00 00 00 00 00 0000 11.....
1010 00 00 00 00 00 00 00 4E 45 57 20 44 41 54 41 4E .....NEW DATAN
1020 45 57 20 44 41 54 41 4E 45 57 20 44 41 54 41 4E EW DATANEW DATAN
>M 1000 102F BA 10 S
MEMORY SEARCH FAILURE!
>M 1000 102F 'NEW' S
MEMORY MATCH AT ADDRESS 1017
>
```

## 5.2 Memory Checksum/Test/Transfer/Compare Command - T

---

Z80/NSC800 - T start-address end-address {S|M|address-3[ V]}  
Z8/ZS8 - T[P|X]start-address end-address {S|M|address-3[ V]}

---

- T** is the command for Memory Checksum/Test/Transfer/Compare.
- P|X** are memory type designations for micro-controllers indicating program memory and external data memory respectively. (Refer to section 2.6 for a detailed description of memory types.)
- start-address** is a hexadecimal address of the emulation CPU indicating a memory location where the operation is to begin.
- end-address** is a hexadecimal address of the emulation CPU indicating the last memory location of the specified range.
- S** displays the checksum of the contents in the specified range.
- M** performs a memory test for the specified range.
- address-3** is a hexadecimal address in the emulation CPU specifying either a destination address, where data is to be transferred, or the start of a second memory range used in "block compare" (section 5.2.4).

V specifies "block compare".

Define the start and end-address for a memory range in the emulation processor. The end-address must be greater than or equal to the start-address or an error message is printed and the command ends.

### 5.2.1 Memory Checksum

---

T start-address end-address S

---

An "S" following the range specification causes the checksum to be displayed. The checksum is calculated by taking the hexadecimal sum of the contents for the indicated range, with carry added back, modulo 256.

Example: First display the program memory contents for the range 1025H-102AH, and then calculate the checksum for the same range.

```
>M 1025 102A
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F   ASCII-CODE
1020                54 41 4E 45 57 20                   TANEW
>T 1025 102A S
THE CHECKSUM IS: A0
>
```

## 5.2.2 Memory Test

---

T start-address end-address M

---

An "M" following the range specification causes a memory test to be performed on the indicated range. The upper-byte and lower-byte of the address whose memory is to be tested are exclusive-or'ed (XOR) and written into memory for the entire range. The data are verified and then their complements are written into the entire range and thoroughly checked again. If the comparison fails in either pass, the test is stopped at the failed address and that address is displayed. The original contents in memory are destroyed in this test.

Example: Test the memory range 1019H through 1023H, displaying the memory contents for the range 1010H to 102FH both before and after.

```
>M 1010 102F
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
1010  00 00 00 00 00 00 00 00 4E 45 57 20 44 41 54 41 4E  ....NEW DATAN
1020  45 57 20 44 41 54 41 4E 45 57 20 44 41 54 41 4E  EW DATANEW DATAN
>T 1019 1023 M
RAM OK!
>M 1010 102F
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
1010  00 00 00 00 00 00 00 00 4E 45 F6 F5 F4 F3 F2 F1 F0  ....NE.....
1020  CF CE CD CC 41 54 41 4E 45 57 20 44 41 54 41 4E  ....ATANEW DATAN
>
```



Example: Test the memory range 3FF0H through 400FH,  
where memory is enabled only through 3FFFH.

>T3FF0 400F M

ADDRESS (4000) RAM ERROR!

>M3FF0 400F

	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F	ASCII-CODE
3FF0	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F	0123456789:;<=>?
4000	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	.....

>

### 5.2.3 Memory Transfer

---

T start-address end-address address-3

---

An address-3 (dest-address) specification indicates that the memory content in the defined range is to be transferred into memory beginning at address-3. Data is transferred, one location at a time beginning at the start address of the destination range. If the memory ranges defined in the transfer command overlap, the transfer will begin at the end address of the destination range to prevent overwrite.

Example: First display the memory content for the range 1000H to 102FH, then transfer the memory content from the range 2000H-202FH to memory beginning at 1000H. Finally, display the results of the transfer.

>M 2000 202F

	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F	ASCII-CODE
2000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	0000	.....
2010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	0000	.....
2020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	0000	.....

>T 1000 102F 2000

>M 2000 202F

	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F	ASCII-CODE
2000	31	31	00	00	00	00	00	00	00	00	00	00	00	00	00	00	11.....
2010	00	00	00	00	00	00	00	4E	45	F6	F5	F4	F3	F2	F1	F0	.....NE.....
2020	CF	CE	CD	CC	41	54	41	4E	45	57	20	44	41	54	41	4E	....ATANEW DATAN

>

## 5.2.4 Memory Compare

---

**T start-address end-address address-3 V**

---

A "V" following the address-3 specification executes block compare for the indicated memory ranges. The block from start-address to end-address is compared with the block beginning at address-3. If comparison is successful, "COMPARISON OK!" will display; otherwise the failure addresses along with the incorrect data are displayed.

Example: First display the memory contents from 1000H to 102FH and 2000H-202FH, then compare the data block.

```
>M 1000 102F
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
1000 31 31 00 00 00 00 00 00 00 00 00 00 00 00 0000 11.....
1010 00 00 00 00 00 00 00 4E 45 F6 F5 F4 F3 F2 F1 F0 .....NE.....
1020 CF CE CD CC 41 54 41 4E 45 57 20 44 41 54 41 4E ....ATANEW DATAN
>M 2000 202F
      00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
2000 31 31 00 00 00 00 00 00 00 00 00 00 00 00 0000 11.....
2010 00 00 00 00 00 00 00 4E 45 F6 F5 F4 F3 F2 F1 F0 .....NE.....
2020 CF CE CD CC 41 54 41 4E 45 57 20 44 41 54 41 4E ....ATANEW DATAN
>T 1000 102F 2000 V
      COMPARISON OK!
>
```

Example: Compare the data block from 1000H to 102FH  
with the address range beginning at 0H.

>T 1000 102F 0 V

(1001)=31 ;(block 1 failure address) = data 1

(0001)=00 ;(block 2 failure address) = data 2

>

### 5.3 Line Assembly Command - A

---

#### A[start-address]

---

**A** is the command for Assembly. If no other parameters are specified, inputting "A<CR>" will execute assembly beginning at the current PC.

**start-address** is the hexadecimal address in the emulation processor's program memory where MICE begins storing the entered assembly language program. Note that only emulation program memory may be specified or the Z8 and ZS8.)

Rather than enter programs or program changes in machine code using the previously described memory (M) command, the NEW MICE-II resident assembler accepts and converts mnemonic inputs into machine code. The converted code is then stored in the emulation processor's program memory starting at the indicated start-address. The assembler does not recognize symbolic labels or constants other than hexadecimal values. The instruction mnemonics accepted are those adopted by the original manufacturer for the processor being emulated. In addition to these mnemonic codes (listed in the appendices), the following three instructions are also supported during assembly.

<b>DB</b> - Define Byte	(1-6 bytes)
<b>DW</b> - Define Word	(1 word)
<b>DS</b> - Define Storage	(0H-FFFFH)

DB accepts both hex and ASCII codes, while DW and DS are restricted to hex data. (Note that the apostrophe ['], lower case "r" and MICE editing/control characters are not allowed for ASCII input.) If more than 6 bytes are keyed in for DB, excess data is truncated on the right and NEW MICE-II displays: "**WARNING: ONLY 6 BYTES ARE VALID!**". If more than 1 word (4 digits) are keyed in for DW or DS, the input data is ignored and "**ERROR CODE, TRY AGAIN!**" is displayed.

After inputting the assembly command, NEW MICE-II displays the following column headings:

```
>AO
LOC      OBJ      LINE      LABEL      SOURCE CODE
0000                0001                *
```

where the decimal value of 0001 under the column "LINE" indicates the line number being entered and the "\*" indicates the new cursor position. NEW MICE-II then waits for an assembly language line input from the user. The source code column consists of an opcode and operand, and must be terminated with either a <CR> or <LF>. NEW MICE-II assembles the line and stores the machinecode beginning at the indicated start-address. The code for the program memory location to be stored is printed under the column "OBJ". The next line number is printed and NEW MICE-II again waits. If an <ESC> is entered instead, the command ends.

NEW MICE-II performs data verification after executing a memory WRITE. If any data does not match, the following message displays: "**MEMORY WRITE FAILURE!**". If an invalid program instruction is entered, NEW MICE-II displays: "**ERROR CODE, TRY AGAIN!**".

Example: Enter a simple program starting at location 0H.

```
>A0
LOC      OBJ      LINE      LABEL      SOURCE CODE
0000     310020    0001                LD SP,2000 <CR>
0003     CD0001    0002                CALL 100 <CR>
0006     DD210030  0003                LD IX,3000 <CR>
000A     110010    0004                LD DE,1000 <CR>
000D     1A        0005                LD A,(DE) <CR>
000E     DD7700    0006                LD (IX+0),A <CR>
0011     DD23      0007                INC IX <CR>
0013     13        0008                INC DE <CR>
0014     7B        0009                LD A,E <CR>
0015     FEOF      0010                CP OF <CR>
0017     C20D00    0011                JP NZ,OD <CR>
001A     C30000    0012                JP O <CR>
001D                                <ESC>
>
```

```
>A100
LOC      OBJ      LINE      LABEL      SOURCE CODE
0100     110010    0001                LD DE,1000 <CR>
0103     3E20     0002                LD A,20 <CR>
0105     12        0003                LD (DE),A <CR>
0106     7B        0004                LD A,E <CR>
0107     13        0005                INC DE <CR>
0108     FEOF      0006                CP OF <CR>
010A     C20301    0007                JP NZ,103 <CR>
010D                                <ESC>
>
```

Example: An error occurs when an incorrect mnemonic is entered. In this case, non-hexadecimal data cannot be used in the data field.

```
>A E
LOC      OBJ          LINE   LABEL      SOURCE CODE
000E                    0011          LD A(IX+00)
ERROR CODE, TRY AGAIN!
000E      DD7E00      0011          LD A,(IX+00)
0011                    0012          <ESC>
>
```

When making changes in an existing program, it is advisable to check the program around the modified area using the Disassembly command (section 5.4) before and after the change. Rechecking the modified area is important to assure that new program changes do not affect the surrounding program.



## 5.4 Disassembly Command - Z

---

**Z[start-address[ end-address]]**

---

**Z** is the command for Disassembly. If no other parameters are specified, inputting "Z<CR>" will execute disassembly for the next 16 lines starting at the current PC.

**start-address** is the hexadecimal address in emulation processor's program memory where display of disassembled memory content begins. (Remember that only emulation program memory may be specified for the Z8 and ZS8.)

**end-address** is the hexadecimal address in the emulation processor's program memory indicating the last memory location of the range to be disassembled and displayed. (Remember that only emulation program memory may be specified for the Z8 and ZS8.)

If only the start-address is specified, the content for that memory location is disassembled and displayed; more data are then read from subsequent locations to complete the instruction if necessary. An end-address specification causes the memory contents in the defined memory range to be disassembled and displayed. The end-address must be greater than or equal to the start-address or an error message is printed (**INPUT ADDRESS ERROR**) and the command ends. If an illegal machine code is encountered, disassembly terminates at the illegal

code's address.

NEW MICE-II uses a two-pass disassembler with all branch and subroutine call addresses first identified and converted to labels; a total of 900 labels can be stored for disassembly. Depending on the range to be disassembled, there may be a pause before any data is displayed.

Example: Disassemble the previously entered program. Note that the byte following the end-address is also read in order to complete the instruction for this example. Labels include a prefix (B for branch or S for subroutine) and address.

```
>ZO 1A
LOC      OBJ          LINE      LABEL      SOURCE CODE
0000     310020       0001     B0000     LD      SP,2000
0003     CD0001       0002             CALL    0100
0006     DD210030     0003             LD      IX,3000
000A     110010       0004             LD      DE,1000
000D     1A           0005     B000D     LD      A,(DE)
DD7700           0006             LD      (IX+00),A
0011     DD23         0007             INC     IX
0013     13           0008             INC     DE
0014     7B           0009             LD      A,E
0015     FEOF        0010             CP      OF
0017     C20D00     0011             JP      NZ,000D
001A     C30000     0012             JP      0000
```

DISASSEMBLY COMPLETED

>

Example: If an illegal machine code is encountered, disassembly terminates at the illegal code's address.

```
>Z1E 30
LOC      OBJ          LINE   LABEL      SOURCE CODE
001E    110010       0010           LD      DE,1000
0021    DDEEOOFE     0011    B0021
          ERROR CODE!
>
```

## 5.5 Port Input Command - I

---

**I port[ count[ duration]]**

---

**I** is the command for Port Input.

**port** is the hexadecimal address of the emulation processor's input port that is to be read and displayed. Note that only port 0-3 (0H-3H) can be used for NEW MICE-II Z8 and only port 0-4 (0H-D4H) can be used for NEW MICE-II ZS8.

**count** is a hexadecimal value from 00H to FFH specifying the number of times the input port is to be read, with 00H indicating 256 times.

**duration** is a hexadecimal value from 00H to FFH specifying the interval in milliseconds between each read, with 00H indicating 256 milliseconds.

The input port command has two modes of operation. If neither the count nor the duration is specified, a range of port contents can be read and displayed beginning with the indicated port address.

NEW MICE-II first reads and displays the contents of the port specified and waits for input from the user. To advance to the next port, enter either a <CR> or <LF>; the next port's content is then read and displayed, and NEW MICE-II again waits. Entering a <CR> or <LF> repeats the entire sequence.

Example: Read and display the contents of ports 80, 81 and 82.

```
>I80
 80 DC<CR>
 81 87<LF>
 82 FF<ESC>
>
```

Specifying a **count** with or without a duration interval, NEW MICE-II first reads from the specified input port the number of times indicated and then displays the contents.

**Duration** defines the interval between each read in milliseconds, permitting compensation for data inputs which are time critical. If no interval is specified, then data is read at one millisecond intervals.

Example: Read and display the next 64 (40H) values for port DOH at 10 (0AH) millisecond intervals.

```
>ID0 40 A
PORT 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F      ASCII-CODE
DO   36 22 AE 9B 2B 18 C7 77 26 D6 86 35 E5 95 44 F4  6"...+..w&..5..D.
     A3 53 03 B2 62 12 C1 71 20 D0 80 2F DF 8E 3E EE  .S..b..q ../..>.
     9D RD FD AC 5C 0B BB 6B 1A CA 7A 29 D9 88 38 E8  .M..\..k..z)..8.
     97 47 F6 A6 56 05 B5 65 14 C4 73 23 D3 82 32 E0  .G..V..e..s#..2.
>
```

Note that the interval can be up to 256 milliseconds (approximately a quarter of a second). If the number of times the port to be read is also 256, the elapse time before any data displayed is approximately 65 seconds. Therefore, to end the command before display begins, enter an <ESC>.

## 5.6 Port Output Command - 0

---

0 port data-1[ data-2[ ...data-8]]

---

0 is the command for Port Output.

**port** is a hexadecimal address of the emulation processor's output port. Note that only port 0-3 (0H-3H) can be used for NEW MICE-II Z8 and only port 0-4 (0H-D4H) can be used for NEW MICE-II ZS8.

**data-1...8** are hexadecimal values to be written into the specified output port of the emulation processor in sequential order.

If only one value is specified, it is written to the indicated output port. If more than one value is specified, each value is written to the indicated port at one millisecond intervals with the first value going out immediately.

Example: Write the value 48H to port 01H.

```
>0 1 48  
>
```

Example: Write values 1, 2 and 3 to port 05H. Value 1 is written immediately followed by value 2 after one millisecond and value 3 after another millisecond.

```
>0 5 1 2 3  
>
```

## 5.7 Reset/Initialization Command - X

---

X[address]

---

X is the command for Reset/Initialization.

address is a hexadecimal addresses in the emulation CPU's program memory where emulation is to begin.

A signal pulse is generated on the appropriate pin of the emulation processor to reset it. The processor's program counter, internal registers and flags are all altered. A start address can be defined which sets the emulation processor's program counter to the specified program memory address. Only the emulation processor is reset; any logic or peripherals connected to the target input reset pin are not affected.

In addition, control and interrupt signals to the emulation processor that are selectively controllable by the Disable and Enable commands are activated if NEW MICE-II is connected to a power-applied target system. However, if no target system is connected to NEW MICE-II, those signals will be disabled.

Example: Reset the emulation processor, showing changes in the program counter (PC) and registers before and after.

```
>R
  A B C D E H L I F X Y S PC
FF F7 FE FD EF FB FF 00 FF FFFF FEFF FFFB 0010
>X
>R
  A B C D E H L I F X Y S PC
FF F7 FE FD EF FB FF 00 FF FFFF FEFF FFFB 0000
>
```



## 5.8 Register Display/Modify Command - R

### 5.8.1 Register Command for NEW MICE-II Z80 and NSC800

---

R[register]

---

R is the command for Register Display/Modification.

register is an alphabetic character indicating the target register whose content is to be displayed or modified. The Z80 and NSC800 have two sets of registers that may be displayed or changed with the R command. Input "R" to select the current set or "RP" to select the alternate set. The register set that can be displayed and changed by the R command is listed in the following table; where alternates are available, they are listed under the mnemonic heading with an apostrophe.

<u>Mnemonic</u>	<u>Register</u>	<u>Contents</u>
A A'	Accumulator	8 bits
B B'	General Purpose	8 bits
C C'	General Purpose	8 bits
D D'	General Purpose	8 bits
E E'	General Purpose	8 bits
H H'	General Purpose	8 bits
L L'	General Purpose	8 bits
I	Interrupt Mask	8 bits
F F'	Flags	8 bits(6 flags)
X	Index IX	16 bits address
Y	Index IY	16 bits address
S	Stack Pointer	16 bits address

### 5.8.1.1 Display Registers

---

R

---

All register contents are displayed if no specific register is defined. Note that the displayed value of the program counter (PC) always indicates the address for the current instruction's opcode.

Example: Display register contents.

```
>R
  A B C D E H L I F X Y S PC
  FF F7 FE FD EF FB FF 00 FF FFFF FEFF FFFB 0000
>
```

### 5.8.1.2 Modify Registers

---

R register

---

If a register is specified, the content of that register is first displayed; NEW MICE-II then waits for input. To advance to the next register enter either a <CR> or <LF>; the next register's content is then displayed and NEW MICE-II again waits. Entering a <CR> or <LF> repeats the entire sequence unless the next register to display is "PC". The J command (section 5.9) must be used to change the program counter. If an <ESC> is entered, the command ends. To change the content of the displayed register, enter a new value in hex or ASCII (enclosed with two apostrophes, e.g. 'A') and <CR> or <LF>.

Example: Examine the specified register and change its content.

```
>RA
A FF 02<CR>
B F7 03<CR>
C FE <ESC>
>R
A B C D E H L I F X Y S PC
02 03 FE FD EF FB FF 00 FF FFFF FEFF FFFB 0000
>
```

### 5.8.2 Register Command for NEW MICE-II Z8

---

R[P|G|W|a1[ a2[ d1[..d8]]]]

---

NEW MICE-II Z8 has three sets of registers:

- |    |   |
|----|---|
| R  | displays all register contents.   |
| RP | displays control or peripheral register contents.   |
| RG | displays general purpose register contents (4H-7FH).  |
| RW | displays working register contents (16 bytes within 0H-7FH where the start-address is 0H or a multiple of 10H). The pointer can be set by the user program or by modifying register "FD". If the register pointer is at an unused range (80H-E0H), working register contents will display as "--" |

Ra1[ a2[ d1[..**d8**]] can display, modify or fill general purpose registers. Note that 4H<a1<a2<7FH. See section 5.1 for more information on addresses (a1-a2) and data (d1-d8).

Example: Display all control and peripheral register contents. The current PC is shown as 000C. Note that "--" indicates write only registers.

```
>RP
PC  SIO TMR T1 PRI TO PRO P2M P3M P01 IPR IRQ IMR FLG RP SPH SPL
    F0 F1 F2 F3 F4 F5 F6 F7 F8 F9 FA FB FC FD FE FF
000C 00 50 00 -- FF -- -- -- -- -- 00 36 89 20 34 56
>
```

Example: Display all general purpose register contents. "WR" indicates working registers. Note that "\*\*\*" indicates I/O registers.

```
>RG
    0  1  2  3  4  5  6  7  8  9  A  B  C  D  E  F
R0  ** ** ** ** 01 01 01 01 01 01 01 01 01 01 01 01
R1  12 12 12 12 12 12 12 12 12 12 12 12 12 12 12
WR  0A 31 0C E3 00 BF 46 23 23 23 23 78 DA 0E 23 23
R3  34 34 34 34 34 34 34 34 34 34 34 34 34 34 34
R4  45 45 45 45 45 45 45 45 45 45 45 45 45 45 45
R5  56 56 56 56 56 56 56 56 56 56 56 56 56 56 56
R6  67 67 67 67 67 67 67 67 67 67 67 67 67 67 67
R7  78 78 78 78 78 78 78 78 78 78 78 78 78 78 78
>
```

Example: Display working register contents with the register pointer (RP) set to 20H.

>RW

RP	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	0A	31	0C	E3	00	BF	46	23	23	23	23	78	DA	0E	23	23

>

Example: Modify the contents of register "F8".

>RF8<CR>  
RF8 FF 96<CR>  
RF9 FF<ESC>  
>

### 5.8.3 Register Command NEW MICE-II ZS8

---

R[Rn|Fflag]|G[ a1[ a2[ d1[..d8]]]]|S[[0|1]a1]

---

- R displays working register contents (16 bytes within 00H-FFH). The pointer can be set by the user program or by modifying registers D7H/D6H. The contents of reserved registers and "write only" registers are displayed as "--", while the contents of port registers are displayed as "\*\*\*".
- RRn permits modification of working registers.
- RFflag permits modification of flag register with binary input.
- RG displays general purpose register contents (00H-FFH).
- RG a1[ a2[ d1[..d8] can display, modify or fill general purpose registers.
- RS displays contents of special purpose registers, including system register (DOH-DFH), mode and control registers (EOH-FFH), and registers COH-CFH (used as working registers only).

RS[0|1]a1 permits modification of special purpose registers, where [0|1] indicate bank selection.

See section 5.1 for more information on addresses (a1-a2) and data (d1-d8).

Example: Display working register contents with the register pointers RPO and RP1 set to COH and C8H respectively, and the PC set to 0020. Also note that the flags "CZSVDHFB" are displayed with binary data.

```
>R
RPO(CO) R0=55 R1=AA R2=A2 R3=55 R4=75 R5=AA R6=AA R7=55 CZSVDHFB PC=0020
RP1(C8) R8=55 R9=FA RA=AA RB=55 RC=77 RD=AE RE=AB RF=75 01010000
>
```

Example: Modify working register R8.

```
>RR8<CR>
R8 55 AA<CR>
R9 FA <ESC>
>
```

**Example: Modify the content of the flag with binary input (1 or 0).**

```
>RFC
C 0 <CR>
Z 1 0<CR>
S 0 1<CR>
V 1 <ESC>
>
```

**Example: Display all general purpose register contents.**

```
>RG
    0   1   2   3   4   5   6   7   8   9   A   B   C   D   E   F
RG0 55 A2 AA 15 57 BA AA D6 55 A8 AA 5C 55 BE AE F5
RG1 55 AA AA 55 55 AA AA F5 45 AA AA 15 55 AA AA 55
RG2 45 AA AA 55 7F AE 2B D7 55 AA EA 55 55 AA AB F5
RG3 54 AA AA 55 55 AF 9A 55 55 AA AA 55 D5 BB AA 55
RG4 15 AA A2 55 5D BA EE 57 55 88 AA 51 57 BA EA 5D
RG5 55 AA 8A 15 5D AA A9 55 55 8A AA 55 57 AA A2 5F
RG6 55 AA 0A 55 57 AB FA D5 51 2A AA 84 75 FA BA 55
RG7 55 AA AA 15 57 AB AA 5D 51 22 AA 15 75 AB AA 55
RG8 55 A8 AA 55 55 BB AA 55 41 A2 A2 40 5F BA BB 5D
RG9 55 AA AA 55 75 BA AA 75 55 AA AA 70 D5 AA AE D5
RGA 71 AA AE 55 D5 EA BA 57 55 2A A2 55 55 BE BA 55
RGB 55 AA AA D5 D5 AE AA 55 55 AA AA 55 D5 BE AA D5
RGC 51 AA A8 55 55 EA FA 5D 55 AA 8A 45 75 AA AA D5
RGD 55 8A AA 55 55 AA AA 55 57 AA 8A 55 55 AB EA D5
RGE 45 AA 8A 55 55 2A AA 5D 55 AA AA D5 7D FE AE 5D
RGF 55 AA AA 55 55 FB EB F5 D5 AA AA 75 57 FA AA 55
>
```



Example: Modify the contents of general purpose register "15".

```
>RG15<CR>
  RG15 AA 33<CR>
  RG16 AA<ESC>
>
```

Example: Display all special purpose register contents.  
Note that the symbol "--" indicates write only registers.

```
>RS
C0 C1 C2 C3 C4 C5 C6 C7 C8 C9 CA CB CC CD CE CF
55 AA A2 55 75 AA AA 55 AA FA AA 55 77 AE AB 75
```

SYSTEM REGISTERS:

```
FLAG RP0 RP1 SPH SPL IPH IPL IRQ IMR SYM
D5 D6 D7 D8 D9 DA DB DC DD DE
30 C0 C8 00 00 00 00 00 00 60
```

MODE AND CONTROL REGISTER:

BANK 0 REGISTERS

```
COCT C1CT COCH COCL C1CH C1CL UTC CRC UIE UIO POM PM
E0 E1 E2 E3 E4 E5 EB EC ED EF F0 F1
0A 08 00 00 00 00 02 00 00 00 00 --
```

```
HOC H1C P4D P40D P2AM P2BM P2CM P2DM P2AI P2BI EMT IPR
F4 F5 F6 F7 F8 F9 FA FB FC FD FE FF
-- -- FF 00 -- -- -- -- 00 00 7C 00
```

BANK 1 REGISTERS

```
COM C1M COTH COTL C1TH C1TL DCH DCL UBGH UBGL UMA UMB WUMC WUMS
E0 E1 E2 E3 E4 E5 F0 F1 F8 F9 FA FB FE FF
20 00 00 00 00 00 00 00 00 00 00 00 00 00
```

>

Example: Modify the contents of the system register or registers CO-CF (used as working registers only).

```
>RSC0<CR>  
RSC0 55 11<CR>  
RSC1 AA <ESC>  
>
```

Example: Modify the contents of mode and control register in BANK1 at E2.

```
>RS1E2<CR>  
RS1E2 00 FF<CR>  
RS1E3 00 <ESC>  
>
```

## 5.9 Jump/Branch Command - J

---

### J address

---

J is the command for Jump/Branch.

address is a hexadecimal address of the emulation processor's program memory where the program counter is to be set.

Changing the emulation processor's program counter causes subsequent emulation to continue from that address in program memory space.

Example: Change the program counter from the current address to 5H.

```
>J6
>R
  A B C D E H L I F X Y S PC
02 03 FE FD EF FB FF 00 FF FFFF FEFF FFFB 0006
>
```

## CHAPTER 6

### CONTROL SIGNAL COMMANDS

These commands enable or disable specific control signals going to the emulation processor. The available signal is either enabled or disabled at the input pin on the emulation processor. Only sense input to the processor is affected; circuits which generate the control signal in the target system are unaffected. The control characters and signal designation for hardware control signals (including pin numbers) and software control signals that are affected by the Disable and/or Enable commands are listed below:

Signal Designation	Z80	NSC800	Z8	ZS8
<b>B</b> - Bus Hold Request	BUSRQ - 25 BUSAK - 23	BREQ - 36 BACK - 35		
<b>I</b> - Interrupt Request	INT - 16	RSTA - 22 RSTB - 23 RSTC - 24 INTR - 25	IRQ0 - 12 IRQ1 - 30 IRQ2 - 39 IRQ3 - 5	
<b>N</b> - Non-Maskable Interrupt Request	NMI - 17	NMI - 21		
<b>R</b> - System Reset	RESET - 26		RESET - 6	RESET - 26 (40-pin) 30 (48-pin)
<b>X</b> - Specify Program Memory and Data Memory Space			*	*

- \* 1. This is a software control function; no pin signals are affected. Emulation memory (HUEM/SUEM) is configured by using the following commands.

DX - combined memory space  
EX - segregated memory space

2. A/Z/M/T/U and Download commands are not affected by EX or DX.
3. After power-up, or reset by the X command, MICE is set to DX mode (i.e. external memory space is combined).

- Notes
- 1) NEW MICE-II NSC800 - to control emulation of the processor, MICE shares the use of WAIT input (pin-38), pulling the signal low to suspend emulation.
  - 2) NEW MICE-II Z8 - D and E commands cannot control internal interrupt.
  - 3) NEW MICE-II ZS8 - D and E commands cannot control internal or external interrupt.

## 6.1 Enable/Display Control Signal Command - E

---

E[control-signal]

---

**E** is the command for Enable. If no signals are specified, keying in "E" will display the control signals that are enabled.

**control-signal** is a single alphabetic character indicating a control signal to the emulation processor.

The control signal specified is activated at the pin of the emulation processor. When resetting the processor with the X command (section 5.7), these signals are not activated unless MICE is connected to a power-applied target system.

Example: Activate interrupt request control signal.

```
>E I
>
```

Example: Display the enabled control signals.

```
>E
ENABLE -INT
>
```

## 6.2 Disable/Display Control Signal Command - D

---

D[control-signal]

---

D is the command for Disable. If no signals are specified, keying in "D" will display the disabled control signals.

**control-signal** is a single alphabetic character indicating a control signal to the emulation processor.

The control signal specified is deactivated at the pin of the emulation processor. When resetting the processor using the X command (section 5.7), these signals are activated if MICE is connected to a power-applied target system.

Example: Deactivate the interrupt request (INT) control signal, thereby not processing any interrupts which may occur. Note that this command does not affect the interrupt mask list in the processor status register.

```
>DI  
>
```

Example: Display the disabled control signals.

```
>D  
DISABLE -NMI  
          -INT  
          -DMA  
          -RESET  
>
```

## CHAPTER 7

### EMULATION AND TRACE CONTROL COMMANDS

---

These commands perform free-running emulation or tracing for the emulation processor in real-time. Program operation may be recorded with user defined trigger addresses to specify the start or end of tracing. Up to 2048 machine cycles can be recorded.

Status information displayed by these commands use the following column headings: "IFADDR ADDRESS DATA STATUS SPARE(8 BITS)"

where: IFADDR is the instruction fetch address.  
ADDRESS is the hexadecimal value on the address bus.  
DATA is the hexadecimal value on the data bus.  
STATUS is the type of processor activity.  
SPARE is the status of the headers on the personality (CEP) board.

The specific types of processor activity that can be displayed in the status column are indicated below. The mnemonics listed for each processor also serve as qualifiers for H/F/B/L and BPP commands, as well as being displayed as statuses for C/SZ commands.



CPU Statuses	Z80	NSC	Z8	ZS8
Instruction Fetch Cycle	S	S	S	S
Memory Read Cycle	R	R	R	R
Memory Write Cycle	W	W	W	W
Port Input	I	I		
Port Output	O	O		
Interrupt Acknowledge	A	A		
Interrupt Cycle, Instruction Fetch			AS	
Interrupt Cycle, Memory Read			AR	AR
Interrupt Cycle, Memory Write			AW	AW

The following status designators apply only for the NEW MICE-II Z80 and NSC800.

1. The statuses "E" and "?" may be displayed for Cycle/ Instruction Step and List Trace commands; where "E" indicates a second opcode fetch cycle, and "?" indicates either a first or second opcode fetch cycle which NEW MICE-II cannot distinguish. Remember that these statuses cannot be used as qualifiers for command specification.
2. When selecting "S" activity as a qualifier in the List Trace command, the displayed messages will include "S", "E" and "?" qualifiers.
3. When using a qualifier in the Halt or Trace commands, if the breakpoint or trigger address is at the second opcode, then the qualifier "S" should be specified.

Trace point connections are also provided for monitoring external signals. There is a 8 post stick header on the CEP board designated X0-X7 from right to left. Any cable or wiring can be used to connect from these test points to the target. The monitored signals are called spare bits and support con-current trace for the address, data and status bus. Any of these bits can be monitored by trace commands to provide hardware status for display (under the SPARE column) in List, Cycle Step and Instruction Step commands; where "1" represents a high (or floating) signal and "0" indicates a low signal.

## 7.1 Go/Execution Command - G

---

G[address]

---

G is the command for Go/Execution.

address is a hexadecimal address of the emulation processor's program memory where emulation will begin.

The emulation processor's program counter is first set to the address indicated. NEW MICE-II then starts real-time emulation of the target processor. If no address is specified, program emulation will start at the current program counter.

Example: Display register content (PC=0006H), and start emulation from address 0H.

```
>R
  A B C D E H L I F X Y S PC
02 03 FE FD EF FB FF 00 FF FFFF FEFF FFFB 0006
>G0
>
```

Example: Display register content, and resume emulation from the current PC.

```
>R
  A B C D E H L I F X Y S PC
20 03 FE 10 5D FB FF 00 02 0099 FEFF 1FFA 0108
>G
>
```

Note: ?/!/D/E/L/BS\* commands may be input without halting emulation, while the processor is executing G/FR/BR commands, or while executing F/B commands after the trigger has been matched. (\* BS is a BPP command.)

## 7.2 Halt/Breakpoint Set Command - H

---

H[0[1|2]|1 [addx[ count[ qualifier]]]|2 [address-2]]

---

**H** is the command for Halt/Breakpoint Set.

**0** is the command to clear a breakpoint.

**1** is breakpoint 1.

**2** is breakpoint 2. (Count, qualifier and wildcard do not apply.)

**addx** is an up to 4 digit hexadecimal address setting for breakpoint 1, with a wildcard byte pair of "XX" or "XXXX".

**count** is a hexadecimal value from 1 to 4000H which specifies the number of times the indicated condition must be matched before emulation stops.

**qualifier** is a single alphabetic character indicating the type of processor activity to be selected.

**address-2** is an up to 4 digit hexadecimal address setting for breakpoint 2. (No wildcard, count or qualifier is permitted.)

### 7.2.1 Halt

---

H

---

Input "H" during emulation or tracing to stop execution immediately and display the current address.

Example: Stop emulation and display the current address.

```
>G
>H
PROGRAM BROKE AT ADDRESS 0106
>
```

### 7.2.2 Set Breakpoint

---

H 1[addx[ count [ qualifier]]]|2 address-2

---

NEW MICE-II supports two real-time breakpoints. Breakpoint 1 can be used to specify a program address where emulation will stop. A count may also be specified to define the number of times the indicated condition is to be matched before emulation stops. If no count is specified, the default is one and emulation stops at the first breakpoint address matched. A qualifier can also be selected to choose the type of processor activity which must be matched along with the breakpoint address and count to stop emulation. If no qualifier is specified, all machine cycles are chosen. To enter a qualifier, a count must first be defined.

Breakpoint 2 can be used to specify a program address where emulation or tracing will stop. When setting breakpoint 2, set the breakpoint address only.

Example: Set breakpoint 1 to address 7H and count to 1.

```
>H1 7 1  
>
```

Example: Set breakpoint 2 to address 1BH.

```
>H2 1B  
>
```

Breakpoints 1 and 2 only set breakpoint conditions. Unless the emulation CPU is in execution, an emulation or trace command must be input to start the CPU. If H1 or H2 is matched, NEW MICE-II will stop the emulation processor and display the current address (at the specified breakpoint address). Breakpoint 1 will reset automatically after the Trace command since it shares the same logic as the Forward/Backward Trace commands. Note that breakpoints are not active in Cycle Step and Instruction Step commands.

Note: For NEW MICE-II Z8 and ZS8, when the breakpoint is matched, the CPU will finish executing the current instruction cycle and stop at the opcode fetch of the next instruction.

Example: Set an emulation program at 0H; then set breakpoint 1 to 3H, count to 1, qualifier for instruction fetch cycle (S), and breakpoint 2 to 1BH.

```
>J0
>H1 3 1 S
>H2 1B
>G
PROGRAM BROKE AT ADDRESS 0003
>
```

Note: Z80 (WAIT mode) will display: "PROGRAM BROKE AT ADDRESS XXXX".

Example: Set the breakpoint address to XXFFH, the count to 1 and qualifier for memory write cycle (W).

```
>H1 XXFF 1 W
>G
PROGRAM BROKE AT ADDRESS 1FFE
>
```

### 7.2.3 Display Breakpoint

---

H 1|2

---

Input H1 or H2 to display breakpoint 1 or breakpoint 2 messages respectively.

Example: Display breakpoint 1 and 2 messages. Note that the address, count and qualifier are displayed for breakpoint 1; and only address is displayed for breakpoint 2.

```
>H1
H1= XXFF 1 W
>H2
H2= 1B
>
```

## 7.2.4 Clear Breakpoint

---

H 0[1|2]

---

NEW MICE-II can clear all breakpoints concurrently or separately.

Example: Clear breakpoint 1 only.

```
>H01
>H1
H1=
>
```

Example: Clear all breakpoints concurrently.

```
>H0
>H1
H1=
>H2
H2=
>
```



### 7.3 Forward Trace Command - F

---

**F[R]addr[ count[ qualifier]]**

---

- F** is the command for Forward Trace.
- R** continues running the emulation processor after the trace stops.
- addr** is an up to 4 digit hexadecimal trigger address with a wildcard byte pair of "XX" or "XXXX" where NEW MICE-II begins recording trace information.
- count** is a hexadecimal value from 1 to 4000H which specifies the number of times the target condition must be matched before the trace records information.
- qualifier** is a single alphabetic character indicating the type of processor activity that must be matched with the trigger address.

Forward tracing starts real-time emulation of the target and begins recording target status information when the trigger condition is matched. Forward trace will stop when the trace buffer is full or breakpoint 2 is reached. Forward trace can record up to 2048 machine cycles.

When the trace stops, MICE halts the emulation CPU at the break address. The recorded information can be examined by using the List Trace Buffer command.

Note: For NEW MICE-II Z8 and ZS8, when the breakpoint is matched or the trace buffer filled, the CPU will finish executing the current instruction cycle and stop at the opcode fetch of the next instruction.

Option R allows the emulation CPU to continue running after the trace stops but breakpoint 2 will force the CPU to stop. Without option R, the CPU will stop whenever the trace stops. If only the trigger address is specified, all machine cycles after that trigger address is encountered are recorded. If a count is specified, the trace will record information after the number of matches of the indicated trigger condition occur. If no count is specified, the trace will begin recording information as soon as the trigger condition is matched.

A single qualifier may be specified to choose the type of processor activity associated with the trigger address; default is for all machine cycles. To enter a qualifier, a count must first be defined. When specified, the trace will start recording only when the trigger address together with the qualifier occurs the number of times defined by count.

Example: Begin recording program status from the trigger address of 3H. In the following message, **STEP** indicates the last trace frame recorded. The trace count begins at zero, so the actual value is one more than the step number shown. The trace buffer is completely filled if **STEP 07FF** is displayed.

```
>F3  
THE TRACE STOPS AT STEP 07FF  
>
```

Depending on command specifications, the elapse time before the buffers fill may be long. Entering <ESC> terminates the trace, yet retains the information already recorded.

Example: Specify a trigger address of 112H which the program never reaches; the trace buffer is emptied. Note that if breakpoint 2 is encountered before the trigger address is reached, the message will be displayed without entering <ESC>.

```
>F112  
<ESC>  
FORWARD TRACE FAILS  
>
```

Example: Begin tracing when the memory location 2H is addressed and stop at breakpoint 2 before the trace buffer is filled.

```
>J0  
>H2 7  
>F2  
THE TRACE STOPS AT STEP 00BD  
PROGRAM BROKE AT ADDRESS 0007  
>
```

Example: Begin recording status information the first time the program writes to an address in the range of 1F00H to 1FFFH. Continue running after the trace stops until the program addresses 001BH. Note that qualifiers are only associated with the trigger address; all machine cycles are recorded after the trace has begun.

```
>JO  
>H2 1B  
>FR 1FXX 1 W  
THE TRACE STOPS AT STEP 01A1  
PROGRAM BROKE AT ADDRESS 001B  
>
```

## 7.4 Backward Trace Command - B

---

**B[R]addrx[ count[ qualifier]]**

---

- B** is the command for Backward Trace.
- R** continues running the emulation processor after the trace stops.
- addrx** is an up to 4 digit hexadecimal trigger address with a wildcard byte pair of "XX" or "XXXX" where emulation is to stop.
- count** is a hexadecimal value from 1 to 4000H which specifies the number of times the target condition must be matched before the trace stops recording information.
- qualifier** is a single alphabetic character indicating the type of processor activity that must be matched with the trigger address.

Backward tracing starts real-time emulation of the target and immediately begins recording target status information until the trigger address or breakpoint 2 is reached. When the trace is matched, NEW MICE-II halts the emulation processor at the specified break address.

Note: For NEW MICE-II Z8 and ZS8, when the breakpoint is matched or the trace buffer filled, the CPU will finish executing the current instruction cycle and stop at the opcode fetch of the next instruction.

Backward trace can record up to 2048 cycles and the recorded information can be examined using the List Trace Buffer command. If more than 2048 cycles elapse before backward tracing ends, only the last 2048 cycles are recorded. Option R allows the emulation processor to continue running after the trace stops, however breakpoint 2 will force the CPU to stop and display a breakpoint match message.

Without option R, the CPU will stop whenever the trace stops. If only the trigger-address is specified, all machine cycles are recorded up to and including the trigger-address encountered. If a count is specified, backward tracing will record all information before the number of matches of the indicated trigger-address. If no count is specified, the trace will stop after the first match.

A single qualifier may be specified to choose the type of processor activity associated with the trigger-address. To enter any qualifier, a count must first be defined.

Example: Begin tracing immediately and stop when the memory location 1BH is addressed. Note that the trace will also stop when breakpoint 2 is encountered.

```
>J0
>H2 7
>B1B
  THE TRACE STOPS AT STEP 00BF
  PROGRAM BROKE AT ADDRESS 0007
>
```

In the above example, the breakpoint message following the command line indicates that 07H cycles have been recorded. The counter is a hexadecimal value from 0 to 7FFH. The trace count begins at zero, so the actual value is one more than the step number shown.

Again, depending on the specification, elapse time before the trigger address is encountered may be long. Entering an `<ESC>` terminates the trace, yet retains the information already recorded.

Example: Specify a trigger address of 112H which the program never reaches. The trace buffer is filled with the cycles immediately before `<ESC>` is received.

```
>H0  
>B112  
<ESC>  
THE TRACE STOPS AT STEP 07FF  
>
```

Example: Begin tracing immediately and stop the 1st time the program reads from the address range of 1FO0H to 1FFFH. Continue running after the trace stops, until the program addresses 001BH. Note that qualifiers are only associated with the trigger address; all machine cycles are recorded once the trace begins.

```
>J0  
>H2 1B  
>BR 1FXX 2 W  
THE TRACE STOPS AT STEP 0007  
PROGRAM BROKE AT ADDRESS 001B  
>
```

## 7.5 List/Display Trace Buffer Command - L

---

**L**[step[ address-1[ address-2[ qualifier(s)]]]]**S**[step]**Z**[step]**N**

---

**L** is the command for List/Display Trace Buffer.

**step** is a hexadecimal value from 0 to 7FFH indicating the initial cycle step to display.

**address-1** is the starting address of the range to be listed.

**address-2** is the ending address of the range to be listed.

**qualifier(s)** are single characters indicating the type of processor activities to list.

**S** lists the trace buffer using mnemonic code.

**Z** lists the trace buffer displaying mnemonic code and all machine statuses.

**N** displays the frame number where the last trace stopped.

Status information recorded during a trace command is displayed using this command. If a step is specified, NEW MICE-II lists the trace buffer from the specified step to the last recorded step. If no step is specified, NEW MICE-II will list all records in the trace buffer. An optional address range can be entered to specify the



range to be listed. If no address range is specified, then the display range is from 0000H to FFFFH.

The type of information to be listed is specified by entering qualifier(s). If no qualifier is entered, all machine cycles within the specified address range are listed. To enter a qualifier, an address range must first be defined. To enter an address range, a step must first be entered. The List command accepts multiple qualifiers; and displays only machine cycles that match the specified qualifiers. If the buffer is listed with the LS or LZ command, only "step" can be specified.

Example: List all records in the trace buffer. Note that the list operation can be terminated by entering an <ESC>. Note that **FRAME** is the sequence number of the trace step in hexadecimal; the range is 0 to 2047 (7FFF).

```
>L
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0000          0000  31    ?    11111111
0001          0001  00    R    11111111
0002          0002  20    R    11111111
0003    0003    0003  CD    S    11111111
0004          0004  00    R    11111111
0005          0005  01    R    11111111
0006          1FFF  00    W    11111111
0007          1FFE  06    W    11111111
>
```

Example: List the trace buffer from the 3th step to the last step, and terminate the operation before the listing is completed.

>L2

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0002		0002	20	R	11111111
0003	0003	0003	CD	S	11111111
0004		0004	00	R	11111111
0005		0005	01	R	11111111
0006		1FFF	00	W	11111111
0007		1FFE	06	W	11111111

>

Example: List the trace buffer write cycles in the range 3H to 5H starting at step 2.

>L2 3 5

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0003		0003	CD	S	11111111
0004		0004	00	R	11111111
0005		0005	01	R	11111111

>

Example: List the trace buffer from 0H to FH, with qualifier S.

>LO O F S

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0000		0000	31	?	11111111
0003	0003	0003	CD	S	11111111

>

Example: List trace message with source code; the operation is terminated before the listing is completed. Note that the command also ends if the trace buffer is empty or if nothing is recorded within the specified range.

>LS

FRAME	IFADDR	ADDRESS	DATA	SOURCE CODE
0000	0000	0000	31	LD SP,2000
0003	0003	0003	CD	CALL 0100

>

Example: List trace message with mnemonic code and all machine statuses; then display the frame number of the last trace.

>LZ

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE	SOURCE CODE
0000		0000	31	?	11111111	
0001		0001	00	R	11111111	
0002		0002	20	R	11111111	
0003	0003	0003	CD	S	11111111	CALL 0100
0004		0004	00	R	11111111	
0005		0005	01	R	11111111	
0006		1FFF	00	W	11111111	
0007		1FFE	06	W	11111111	

>

>LN

THE TRACE STOPS AT STEP 0007

>

## CHAPTER 8

### STEPPED EMULATION COMMANDS

---

These commands perform cycle-stepped or instruction-stepped emulation of the emulation processor in real time. Note that breakpoints are not active for C/S commands. Refer to page 7-1 for a description of the displayed status information.

Note: A blank space (ASCII 20H) is sent at the end of each displayed line immediately before the cursor for C/S commands. This code serves as an end of data message to the host computer; and is provided to help in implementing symbolic debuggers.

## 8.1 Cycle Step Command - C

---

C[count]

---

C is the command for Cycle Step.

count specifies the machine cycle interval between displayed messages. The range is 0-FFFFH. Note that an input value of "0" represents 10000H.

The Cycle Step command first stops the emulation processor, then steps and executes one program one cycle, stopping the processor in HALT state (**where the displayed target status has already been executed**). NEW MICE-II then awaits a <CR> or <LF> to execute and display the next machine cycle. Enter a <CR> or <LF> to repeat the entire sequence, or an <ESC> to terminate the single-cycle mode of emulation.

Because the Z8 and ZS8 cannot be stopped, MICE keeps the CPU running in place with a jump instruction, **where the displayed instruction (including all associated machine cycles) has already been executed**.

However, note that the Z80 (WAIT Mode) stops the emulation processor at WAIT state instead, **where the displayed cycle status has not yet been executed**. Because the displayed status is still active in this situation, debug for associated hardware signals is simplified.

Example: Cycle step the following program.

>J0  
>C

IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0000	0000	31	S	11111111 <CR>
	0001	00	R	11111111 <CR>
	0002	20	R	11111111 <CR>
0003	0003	CD	S	11111111 <CR>
	0004	00	R	11111111 <CR>
	0005	01	R	11111111 <CR>
	1FFF	00	W	11111111 <CR>
	1FFE	06	W	11111111 <CR>
0100	0100	11	S	11111111 <CR>
	0101	00	R	11111111 <CR>
	0102	10	R	11111111 <CR>
0103	0103	3E	S	11111111 <ESC>

>

Example: Cycle step the above program using a count of 3.

>J0  
>C3

IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
	0002	20	R	11111111 <CR>
	0005	01	R	11111111 <CR>
0100	0100	11	S	11111111 <CR>
0103	0103	3E	S	11111111 <CR>
	1000	20	W	11111111 <CR>
0108	0108	FE	S	11111111 <CR>
	010B	03	R	11111111 <ESC>

>

## 8.2 Instruction Step Command - S

---

S[S|R][count]|Z

---

- S is the command for Instruction Step.
- S(option) displays messages in mnemonic form.
- R displays register contents in addition to mnemonic code.
- count is an hexadecimal value from 0000H to FFFFH specifying the step interval between status display. (Note that 0000H indicates 10000H steps.)
- Z displays cycle status in addition to mnemonic code.

## 8.2.1 Instruction Step

---

S

---

If count is not specified for instruction step, the default is one. In this mode, MICE first **displays the current instruction to be executed** and waits for input. To cause the emulation processor to execute this instruction, a <CR> or <LF> should be entered; the new status is then displayed and MICE again waits. Enter a <CR> or <LF> to repeat the entire sequence, displaying the new status after every instruction. Enter <ESC> to terminate the single step mode of emulation. (Remember that breakpoints are not active for the S command.)

Instruction step only displays "S" status to indicate an instruction fetch cycle; no other status types are displayed. If a more careful examination of a program is required, first Instruction Step to the problem area, and then Cycle Step through the problem area for a more detailed display.

Example: Instruction step the previous program. Note that the processor does not begin emulation until the current status displays and either a <CR> or <LF> is entered.

>JO

>S

IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0000	0000	31	S	11111111 <CR>
0003	0003	CD	S	11111111 <CR>
0100	0100	11	S	11111111 <ESC>

>



## 8.2.2 Instruction Step in Mnemonic Form

---

SS

---

Example: Instruction step with S option.

>J0

>SS

IFADDR	ADDRESS	DATA	SOURCE CODE
0000	0000	31	LD SP,2000 <CR>
0003	0003	CD	CALL 0100 <CR>
0100	0100	11	LD DE,1000 <ESC>

>

## 8.2.3 Instruction Step with Register Content

---

SR

---

The R option displays register content along with mnemonic information. All register contents associated with the current step in program execution can be observed; but remember that the contents displayed are prior to executing the instruction.

Example: Instruction step with R option.

>J0

>SR

IFADDR	ADDRESS	DATA	SOURCE CODE
A=00 B=00 C=06 D=10 E=01 H=F7 L=FF I=00 F=9B X=300F Y=FFFF S=1FFE PC=0000	0000	0000 31	LD SP,2000 <CR>
A=00 B=00 C=06 D=10 E=01 H=F7 L=FF I=00 F=9B X=300F Y=FFFF S=2000 PC=0003	0003	0003 CD	CALL 0100 <ESC>

>

The SR command for NEW MICE-II Z8 and ZS8 displays working register content for the current instruction step in addition to mnemonic code (refer to RW command, section 5.8)

Example: Execute instruction-step with mnemonic code for NEW MICE-II Z8.

```
>SR
  IFADDR ADDRESS DATA      SOURCE CODE
  000C    000C    31      SRP   #40
RP   0   1   2   3   4   5   6   7   8   9   A   B   C   D   E   F
40   00  00  00  00  47  00  00  00  00  00  00  10  00  00  00  00<CR>
      000E    000E    4C      LD   R04,#AA
RP   0   1   2   3   4   5   6   7   8   9   A   B   C   D   E   F
40   00  00  00  00  AA  00  00  00  00  00  00  10  00  00  00  00<CR>
      0010    0010    31      SRP   #50
RP   0   1   2   3   4   5   6   7   8   9   A   B   C   D   E   F
50   00  00  00  00  AA  00  00  00  00  00  00  10  00  00  00  00<CR>
      0012    0012    4C      LD   R04,#55
RP   0   1   2   3   4   5   6   7   8   9   A   B   C   D   E   F
50   00  00  00  00  55  00  00  00  00  00  00  10  00  00  00  00<ESC>
>
```

Example: Execute instruction -step with mnemonic code  
for NEW MICE-II ZS8.

>SR

IFADDR	ADDRESS	DATA	SOURCE	CODE
0020	0020	FF	NOP	
RP0(C0)	R0=11 R1=AA R2=A2 R3=55 R4=75 R5=AA R6=AA R7=55		CZSVDHFB	PC=0021
RP1(C8)	R8=AA R9=FA RA=AA RB=55 RC=77 RD=AE RE=AB RF=75		00110000	<CR>
	0021 31	SRP	#50	
RP0(50)	R0=55 R1=AA R2=8A R3=15 R4=5D R5=AA R6=A9 R7=55		CZSVDHFB	PC=0023
RP1(58)	R8=55 R9=8A RA=AA RB=55 RC=57 RD=AA RE=A2 RF=5F		00110000	<CR>
	0023 31	SRP	#E0	
RP0(E0)	R0=0A R1=08 R2=00 R3=00 R4=00 R5=00 R6=-- R7=--		CZSVDHFB	PC=0025
RP1(E8)	R8=-- R9=-- RA=-- RB=02 RC=00 RD=00 RE=-- RF=00		01010000	<CR>
	0025 FF	NOP		
RP0(E0)	R0=0A R1=08 R2=00 R3=00 R4=00 R5=00 R6=-- R7=--		CZSVDHFB	PC=0026
RP1(E8)	R8=-- R9=-- RA=-- RB=02 RC=00 RD=00 RE=-- RF=00		01010000	<ESC>

>

## 8.2.4 Instruction Step with Count

---

### S[S|R] count

---

If an instruction count of one (default) is entered, the current instruction to be executed is displayed; NEW MICE-II does not step. If an instruction count other than one is entered, emulation immediately begins from the current program counter and continues until the count of the next instruction to be executed equals the number specified. The current status is then displayed and NEW MICE-II waits for a <CR> or <LF> before executing the next "count" instruction. Enter an <ESC> to terminate the multi-step mode of emulation. For large intervals, emulation may be terminated by entering an <ESC> before the specified number of instructions are executed.

Instruction Step executes "count-1" instructions before the first status line is displayed and then executes "count" instructions between subsequent displays.

Example: Multi-step the program and compare results with the first example.

>JO

>S3

IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0007	0007	CD	S	11111111 <CR>
0103	0103	3E	S	11111111 <CR>
0107	0107	E5	S	11111111 <CR>
010D	010D	E1	S	11111111 <ESC>

>

## 8.2.5 Instruction Step with Cycle Status

---

### SZ

---

The SZ option includes a memory and I/O access message that provides data for bus cycles R/W/I/O/A [e.g. 7FEF-W-12]. The first four digits (7FEF) indicate the memory address; the capital letter (W) represents the type of bus cycle; and the last two digits (12) are the data transferred.

Example: Instruction step the program displaying Cycle status together with mnemonic code.

>JO

>SZ

IFADDR	ADDRESS	DATA	SOURCE CODE
0000	0000	31	LD SP,2000 <CR>
0003	0003	CD	CALL 0100 <CR>
	1FFF	-W- 00	
	1FFE	-W- 06 <CR>	
0100	0100	11	LD DE,1000 <CR>
0103	0103	3E	LD A,20 <ESC>

>

### 8.3 Application Notes for Stepped Emulation Commands

---

1. To make debugging easier, there are two available methods for slowing down the CPU's execution speed.

a) Use the C command with a "0" count to slow execution speed as follows:

NEW MICE-II	Speed
Z80	1/150
NSC800	1/130
Z8	1/708
ZS8	1/454

b) Use the S command with a "0" count to slow execution speed as follows:

NEW MICE-II	Speed
Z80	1/7980
NSC800	1/6450
Z8	1/710
ZS8	1/459

c) Typing ahead with <CR> will keep the processor running.

Example: >C0  
          <CR>  
          <CR>  
          <CR>

## CHAPTER 9

### UTILITY COMMANDS INVOLVING A SYSTEM

---

These commands are only applicable when NEW MICE-II is connected to a host system. Programs and data can be downloaded from a file in a host computer to memory in the target system. Conversely, information can also be uploaded from the target back to the host.

Intel and Tektronix loading formats, both of which are recognized by MICE, are described in detail in the following pages.

Note: For the microcontrollers Z8 and ZS8, Upload and Download commands can only access emulation program memory, i.e. memory type "P". (Refer to section 2.6 for a detailed description of memory types).

## 9.1 Download Command (Intel Format) - :

---

### :load-record

---

: is the command keyword for Download.

load-record is a string of ASCII data containing up to 256 bytes of program information.

Each record transferred contains the record type, length, memory load address, and checksum in addition to data. Each transfer is limited to 256 bytes of program data. The general format of a record, shown with spaces separating each field, is:

RECORD MARK	RECORD LENGTH	LOAD ADDRESS	RECORD TYPE	PROGRAM DATA	CHECK- SUM
:	##	aaaa	tt	dd...dd	cc

where:

: is the keyword used to signal start of record.

## is a two ASCII hexadecimal value indicating the record length, the number of data bytes in the record.

aaaa is a four ASCII hexadecimal value indicating the program memory load-address, the address at which the first byte is to be loaded. (For record type 01 [next item], this field contains "0000".) Successive data bytes are stored in the following memory locations.



**tt** is a two ASCII hexadecimal value representing the record type:

<u>tt</u>	<u>##</u>
00 - data record	actual data length
01 - end of file record	00

**dd...dd** is a two ASCII hexadecimal value per byte representation of the program.

<u>tt</u>	<u>dd...dd</u>
00	A pair of hex digits representing the ASCII code for each data byte, where the high order digit is the 1st digit of each pair.
01	none

**cc** is a two ASCII hexadecimal value representing the negative sum of the record. Beginning with the record length "##" and ending with the checksum "cc", the hexadecimal sum, taken two at a time, modulo 256 should be zero.

When NEW MICE-II receives a ":", it reads the record length (##). The rest of the record is then read and verified. If the incoming checksum agrees with the computed checksum, NEW MICE-II stores the data into program memory of the target system and reprompts after the following acknowledgement response <ACK sequence> is sent:

ACK LF CR NUL NUL NUL NUL NUL

If the checksum does not agree, NEW MICE-II also reprompts but the alternate negative acknowledgement response <NAK sequence> is sent:

NAK LF CR NUL NUL NUL NUL NUL

Example: Download with an end-record into a target system using Intel format. Note that the received characters are not echoed. A <CR> is not required at the end of the input line.

```
>:060000002300A8A917046B<ACK sequence>  
>:00000001FF<ACK sequence>  
>
```

In the above example, the first load record is

```
##      = 06H  
aaaa   = 0000H  
tt     = 00H  
dd...dd = 23H, 00H, A8H, A9H, 17H, 04H  
cc     = 6BH
```

where:  $06H+00H+00H+00H+23H+00H+A8H+A9H+17H+04H+6BH = 00H$   
For the end-record,

```
##      = 00H  
aaaa   = 0000H  
tt     = 01H  
cc     = FFH
```

where:  $00H+00H+00H+01H+FFH = 00H$

Example: Download with an end-record into a target system using Intel type 2 format.

```
>:1000000004992DB246DB6FF4891DA263CB5FE47E5<ACK sequence>  
>:0600100090D9226BB4FD43<ACK sequence>  
>:020000020036C6<ACK sequence>  
>:100000000062C42688EA4CAE1072D43698FA5CBE00<ACK sequence>  
>:080010002082E446A80A6CCE30<ACK sequence>  
>:00000001FF<ACK sequence>  
>
```

End-of-record must then be specified by 01 in the last line of transmission.

## 9.2 Download Command (Tektronix Format) - /

---

/load-record

---

/ is the command keyword for Download.

**load-record** is a string of ASCII data containing up to 128 bytes of program information.

Each record transferred contains the record type, length, memory load address and checksum in addition to data. Each transfer is limited to 128 bytes of program data. The general format of a record, shown with spaces separating each field, is:

RECORD MARK	LOAD ADDRESS	RECORD LENGTH	LOAD SUM	PROGRAM DATA	CHECK- SUM
/	aaaa	##	ss	dd...dd	cc

where:

/ is the keyword used to signal start of record.

**aaaa** is a four ASCII hexadecimal value indicating the program memory load-address, the address at which the first byte is to be loaded. Successive data bytes are stored in the following memory locations.

**##** is a two ASCII hexadecimal value indicating record length, the number of data bytes in the record. A record length of zero indicates end-of-file.

**ss** is a two ASCII hexadecimal value representing the sum of the preceding six digits, load-address and record length.

**dd...dd** is a two ASCII hexadecimal value per byte representation of the program.

**cc** is a two ASCII hexadecimal value representing the sum of the digits comprising the data, modulo 256.

When NEW MICE-II receives a "/", input is read until a <CR> terminates the line. Checksums are then computed and compared. If the incoming checksum agrees with the computed checksum, NEW MICE-II stores the data into program memory of the target system and reprompts after the following acknowledgement response <ACK sequence> is sent:

**ACK LF CR NUL NUL NUL NUL NUL**

If the checksum does not agree, NEW MICE-II also reprompts but the alternate negative acknowledgement response <NAK sequence> is sent:

**NAK LF CR NUL NUL NUL NUL NUL**

Example: Download with an end-record into a target system using Tektronix format.

```
>/000006062300A8A9170436<CR>  
<ACK sequence>  
>/00000000<CR>  
<ACK sequence>  
>
```

In the above example, the load record is

aaaa = 0000H  
## = 06H  
ss = 06H  
dd...dd = 23H, 00H, A8H, A9H, 17H, 04H  
cc = 36H

where: ss = 0H+0H+0H+0H+0H+6H = 06H  
cc = 2H+3H+0H+0H+AH+8H+AH+9H+1H+7H+0H+4H = 36H

For the end-record,

aaaa = 0000H  
## = 00H  
ss = 00H

where: ss = 0H+0H+0H+0H+0H+0H = 00H

### 9.3 Upload Command - U

---

**U start-address end-address [format]**

---

**U** is the command for Upload.

**start-address** is a logical hexadecimal address of the emulation processor's memory where data transfer begins.

**end-address** is the last logical hexadecimal address of the emulation processor's program memory where data transfer ends.

**format** is a single alphabetic character [I|T] indicating the load-record format to be used.

I - Intel  
T - Tektronix

Memory contents defined by the memory range start-address to end-address are transferred to the host system using either Intel or Tektronix format. If the format is not specified, then Intel is used. Also, the end-address must be greater than or equal to the start-address or an error message is sent and the command ended.

NEW MICE-II first sends the current segment value record to the host system. It then reads data from memory and sends a maximum of 32 bytes (depending on data length) to the host system using one of the above formats. Data transmission continues in this manner until an end address is sent. NEW MICE-II then sends an end-

of-record file and prompts for the next command.

If anything other than an <ACK> is received when NEW MICE-II is waiting for an acknowledgement response, the same block is retransmitted. If after five retries transmission is still unsuccessful, the command is aborted, and an error message is sent to the host system before NEW MICE-II prompts for the next command. The command can also be aborted by the host system when NEW MICE-II receives an <ESC> character from the console.

Example: Upload from NEW MICE-II using Intel format. Note that load records are shown on separate lines for clarity. No <CR> or <LF> characters are generated by NEW MICE-II, and anything received other than an <ACK>, is treated the same as a <NAK>.

```
>U 0 6 I<CR>  
:070000002300A8917046E8FF<ACK>  
:00000001FF<ACK>  
>
```

Example: Upload using Tektronix format.

```
>U 0 6 T<CR>  
/000007072300A8917046E848<CR>  
<NAK>  
/000007072300A8917046E848<CR>  
<ACK>  
/00000000  
<ACK>  
>
```



In the above example, the host system did not acknowledge the first transmission when Tektronix format was used. Hence, the first line was retransmitted until an <ACK> was received.

## Appendix A

### Summary of MICE-II Commands

---

#### MICE-II UTILITY COMMANDS

- ? - Help Command
- ! - Attention Command

#### MEMORY, PORT AND REGISTER COMMANDS

- M** - Memory Display/Examine/Modify/Fill/Search Command  
M[start-address[ end-address[ data-1[...data-8][S]]]]
- T** - Memory Checksum/Test/Transfer/Compare Command  
T start-address end-address {S|M|address-3[ V]}
- A** - Line Assembly command  
A[start-address]
- Z** - Disassembly Command  
Z[start-address[ end-address]]
- I** - Port Input Command  
I port[ count[ duration]]
- O** - Port Output Command  
O port data-1 [ ...data-8]
- X** - Reset/Initialization Command  
X[address]

R - Register Display/Modify Command  
R[register]

J - Jump/Branch Command  
J address

#### CONTROL SIGNAL COMMANDS

D - Disable/Display Control Signal Command  
D[control signal]

E - Enable/Display Control Signal Command  
E[control signal]

#### EMULATION AND TRACE CONTROL COMMANDS

G - Go/Execution Command  
G[address]

H - Halt/Breakpoint Set Command  
H[0|1|2]1[address-1[ count[ qualifier]]]2 [address-2]]

F - Forward Trace Command  
F[R]trigger-address[ count[ qualifier]]

B - Backward Trace Command  
B[R]trigger-address[ count[ qualifier]]

L - List/Display Trace Buffer Command  
L[step[ address-1[ address-2[ qualifier(s)]]]|S[step]|Z[step]|N]

## STEPPED EMULATION COMMANDS

C - Single Cycle/Step Command  
C[count]

S - Instruction Step Command  
S[[S|R][count]|Z]

## UTILITY COMMANDS INVOLVING A SYSTEM

: - Download Command (Intel Format)  
:load-record

/ - Download Command (Tektronix Format)  
/load-record

U - Upload Command  
Ustart-address end-address [I|T]

## Appendix B

### Hexadecimal-Decimal Conversion

---

To find the decimal equivalent of a hexadecimal number, first locate your hex number in the correct position (1st through 4th place digit) in the following table. Note the decimal equivalent for each hex digit in your number and then add up these decimal values.

To find the hexadecimal equivalent of a decimal number, locate the next lower decimal number in the table, write down the hex equivalent and its position (1st through 4th place digit). Subtract this decimal number from yours, take the difference and continue this process until conversion is completed.

BYTE				BYTE			
4th place digit		3rd place digit		2nd place digit		1st place digit	
HEX	DEC	HEX	DEC	HEX	DEC	HEX	DEC
0	0	0	0	0	0	0	0
1	4096	1	256	1	16	1	1
2	8192	2	512	2	32	2	2
3	12288	3	768	3	48	3	3
4	16384	4	1024	4	64	4	4
5	20480	5	1280	5	80	5	5
6	24576	6	1536	6	96	6	6
7	28672	7	1792	7	112	7	7
8	32768	8	2048	8	128	8	8
9	36864	9	2304	9	144	9	9
A	40960	A	2560	A	160	A	10
B	45056	B	2816	B	176	B	11
C	49152	C	3072	C	192	C	12
D	53248	D	3328	D	208	D	13
E	57344	E	3584	E	224	E	14
F	61440	F	3840	F	240	F	15

## Appendix C

### ASCII Code Lists and Definitions

Table C-1  
ASCII Code List

HEX	DEC	CHAR	HEX	DEC	CHAR
00	0	NUL	18	24	CAN
01	1	SOH	19	25	EM
02	2	STX	1A	26	SUB
03	3	ETX	1B	27	ESC
04	4	EOT	1C	28	FS
05	5	ENQ	1D	29	GS
06	6	ACK	1E	30	RS
07	7	BEL	1F	31	US
08	8	BS	20	32	SP
09	9	HT	21	33	!
0A	10	LF	22	34	"
0B	11	VT	23	35	#
0C	12	FF	24	36	\$
0D	13	CR	25	37	%
0E	14	SO	26	38	&
0F	15	SI	27	39	'
10	16	DLE	28	40	(
11	17	DC1	29	41	)
12	18	DC2	2A	42	*
13	19	DC3	2B	43	+
14	20	DC4	2C	44	,
15	21	NAK	2D	45	-
16	22	SYN	2E	46	.
17	23	ETB	2F	47	/

## Appendix C

### ASCII Code Lists and Definitions

Table C-1  
ASCII Code List (Cont.)

HEX	DEC	CHAR	HEX	DEC	CHAR
30	48	0	46	70	F
31	49	1	47	71	G
32	50	2	48	72	H
33	51	3	49	73	I
34	52	4	4A	74	J
35	53	5	4B	75	K
36	54	6	4C	76	L
37	55	7	4D	77	M
38	56	8	4E	78	N
39	57	9	4F	79	O
3A	58	:	50	80	P
3B	59	;	51	81	Q
3C	60	<	52	82	R
3D	61	=	53	83	S
3E	62	>	54	84	T
3F	63	?	55	85	U
40	64	@	56	86	V
41	65	A	57	87	W
42	66	B	58	88	X
43	67	C	59	89	Y
44	68	D	5A	90	Z
45	69	E	5B	91	[



## Appendix C

### ASCII Code Lists and Definitions

Table C-1  
ASCII Code List (Cont.)

HEX	DEC	CHAR	HEX	DEC	CHAR
5C	92	\	6E	110	n
5D	93	]	6F	111	o
5E	94	^	70	112	p
5F	95	-	71	113	q
60	96	`	72	114	r
61	97	a	73	115	s
62	98	b	74	116	t
63	99	c	75	117	u
64	100	d	76	118	v
65	101	e	77	119	w
66	102	f	78	120	x
67	103	g	79	121	y
68	104	h	7A	122	z
69	105	i	7B	123	{
6A	106	j	7C	124	
6B	107	k	7D	125	}
6C	108	l	7E	126	~
6D	109	m	7F	127	DEL

## Appendix C

### ASCII Code Lists and Definitions

---

Table C-2  
ASCII-Code Definitions

---

ABB	CTRL	MEANING	HEX
NUL		NULL Character	00
SOH	A	Start of Heading	01
STX	B	Start of Text	02
ETX	C	End of Text	03
EOT	D	End of Transmission	04
ENQ	E	Enquiry	05
ACK	F	Acknowledge	06
BEL	G	Bell	07
BS	H	Backspace	08
HT	I	Horizontal Tabulation	09
LF	J	Line Feed	0A
VT	K	Vertical Tabulation	0B
FF	L	Form Feed	0C
CR	M	Carriage Return	0D
SO	N	Shift Out	0E
SI	O	Shift In	0F
DLE	P	Data Link Escape	10
DC1	Q	Device Control 1	11
DC2	R	Device Control 2	12
DC3	S	Device Control 3	13
DC4	T	Device Control 4	14
NAK	U	Negative Acknowledgement	15
SYN	V	Synchronous Idle	16

## Appendix C

### ASCII Code Lists and Definitions

Table C-2  
ASCII-Code Definitions (Cont.)

ABB	CTRL	MEANING	HEX
ETB	W	End of Transmission Block	17
CAN	X	Cancel	18
EM	Y	End of Medium	19
SUB	Z	Substitute	1A
ESC		Escape	1B
FS		File Separator	1C
GS		Group Separator	1D
RS		Record Separator	1E
US		Unit Separator	1F
SP		Space	20
DEL		Delete	7F

## Appendix D

### Writing a NEW MICE-II Driver Program

---

If for some reasons user wishes to write his own NEW MICE-II driver program, the following guides are provided and should be considered in writing such program.

#### D.1 System Setup

User's system must have an RS-232C series communication port.

Communication protocol refer to section 2.5.

## D.2 MICE Command Transparency

STEP	DRIVER ACTION	REMARKS
1	<p>Sends 'CR' to try to initiate communication with MICE. If it receives no response, send the character which has just been input from keyboard.</p> <p>Receive all responses from MICE and display them until a prompt (&gt;) followed by handshaking code appear on the screen.</p>	<p>;MICE responds with self-diagnostic results.</p>
2	<p>Pick up one key (keyboard input) say "char-X", and send it to MICE.</p> <p>Receive response from MICE and display it until MICE echo with message- "char-Y" where:</p> <p>If "char-X" is BS, receive two data            If the second data is SP,                "char-Y" is BS.            else "char-Y" is handshaking code.</p> <p>If "char-X" is ESC,                "char-Y" is handshaking code,            else "char-Y" is the same as "char-X".</p>	<p>;BS (Back Space=08H)            ;SP (Space bar=20H)              ;ESC=1BH</p>
3	<p>If "char-X" is 'CR',</p> <p>Receive response from MICE and display received messages until a prompt (&gt;) followed by handshaking code appear on the screen.</p> <p>At the same time, scan keyboard input during display and send any received data to MICE.</p>	<p>;CR=0DH</p>
4	<p>Goto Step 2.</p>	

### D.3 Upload

STEP	DRIVER ACTION	REMARKS
1	Send attention command to MICE. If displayed title includes version description, set flag.	;Command syntax: "! CR"
2	Send upload command to MICE. Receive echo messages until 'CR' is detected.	;Command syntax: "U start_addr end_addr CR"
3	If flag on, receive upload data until handshaking code is detected. else receive upload data counted by record length.	
4	Store record to file.	
5	Send ACK (CTRL-F) to MICE.	
6	If not end-record, goto Step 3. Otherwise close the file.	

## D.4 Download

STEP	DRIVER ACTION	REMARKS
1	Get one record from file.	
2	Send one record to MICE and receive one character (e.g. char-Z) from MICE.	
3	<p>If "char-Z" is ACK (Ctrl-F),            receive until handshaking code is detected.            If it is the end-record, close the file,            else goto Step 2.</p> <p>If "char-Z" is NACK (Ctrl-U),            receive until handshaking code is detected.            If the same record is sent 5 times, abort            download,            else goto step 3.</p> <p>Else display "char-Z",            receive and display until handshake code            appears on the screen.            Abort download.</p>	<p>:For next record.</p> <p>:Retry.</p> <p>:Error message from            MICE.</p>

## Appendix E

### NEW MICE Driver Programs

---

USD (Universal Symbolic Debugger) available on various host computer and its medium:

	Host Computer	Standard Medium
USD/PC	IBM/PC/XT/AT	5-1/4" DSDD floppy diskette
USD/PC	IBM PS/2	3-1/2" 2S/HD floppy diskette
USD/9801	NEC PC-9801 family	5-1/4" DSDD floppy diskette
USD/VMS	VAX	TU-80 Magtape, Files-11 format
USD/VMS	Micro VAX	TK-50 Cartridge tape, Files-11 format
USD/ULTRIX	Micro VAX	TK-50 Cartridge tape, Tar format
USD/SUN	SUN microsystems	1/4" Cartridge tape, Tar format



## Appendix F


### High Performance Universal Emulation Memory Board (HUEM)

---

The High Performance Universal Emulation Memory (HUEM) board is the bottom board in the conventional three board NEW MICE-II module. Each memory board supports 128K bytes of emulation memory.


## Appendix F

### High Performance Universal Emulation Memory Board (HUEM) Placement Chart




## Appendix F

### High Performance Universal Emulation Memory Board (HUEM) Block Diagram




# Appendix G

## Real-time Trace Board (RTT) Block Diagram



## Appendix H

### Control Emulation Processor Board (CEP) Block Diagram




# Appendix I


## Z80

### I.1 Hardware

#### I.1.1 Control Emulation Processor Board, CEP-Z80



### I.1.2 Interface Diagram from Target Processor to CEP-Z80



SIZE	CODE	NUMBER	REV
B		140112-303	B
DATE	7/7/86	SHEET	2 OF 2

## I.2 Application Notes for the Z80 Command Set

1. If a trace or breakpoint is set to stop at a memory write cycle, NEW MICE-II Z80 will stop at the next cycle.
2. For Z80 peripheral chips which use the RETI instruction to reset interrupt requests or internal flags, the instruction must reside in target system memory (not in emulation memory).
3. When executing a RETI instruction (whose opcodes are ED and 4D) while in BUSAK mode, the peripheral does not allow the CPU to stop in the middle of these two bytes (ED and 4D).



### I.3 Assembly Mnemonic Code Summary, with Disassembly Examples

LOC	OBJ	LINE	LABEL	SOURCE CODE
0000	ED5A	0001	S0000	ADC HL,DE
0002	CE00	0002		ADC A,00
0004	87	0003		ADD A,A
0005	C600	0004		ADD A,00
0007	86	0005		ADD A,(HL)
0008	DD8600	0006		ADD A,(IX+00)
000B	FD8600	0007		ADD A,(IY+00)
000E	19	0008		ADD HL,DE
000F	DD19	0009		ADD IX,DE
0011	FD19	0010		ADD IY,DE
0013	E600	0011		AND 00
0015	CB4B	0012		BIT 1,E
0017	CB4E	0013		BIT 1,(HL)
0019	DDCB004E	0014		BIT 1,(IX+00)
001D	FDCB094E	0015		BIT 1,(IY+09)
0021	CD0000	0016		CALL 0000
0024	E40000	0017		CALL PO,0000
0027	3F	0018		CCF
0028	FE00	0019		CP 00
002A	EDA9	0020		CPD
002C	EDB9	0021		CPDR
002E	EDA1	0022		CPI
0030	EDB1	0023		CPIR
0032	2F	0024		CPL
0033	27	0025	B0033	DAA
0034	1B	0026		DEC DE
0035	DD2B	0027		DEC IX
0037	FD2B	0028		DEC IY
0039	05	0029		DEC B
003A	F3	0030		DI

LOC	OBJ	LINE	LAB	SOURCE CODE
003B	10C3	0031		DJNZ 0000
003D	FB	0032		EI
003E	EB	0033		EX DE,HL
003F	08	0034		EX AF,AF'
0040	E3	0035		EX (SP),HL
0041	DDE3	0036		EX (SP),IX
0043	FDE3	0037		EX (SP),IY
0045	D9	0038		EXX
0046	76	0039		HALT
0047	ED46	0040		IM 0
0049	ED56	0041		IM 1
004B	ED5E	0042		IM 2
004D	DBA0	0043		IN A,(AO)
004F	ED78	0044		IN A,(C)
0051	3C	0045		INC A
0052	34	0046		INC (HL)
0053	DD3409	0047		INC (IX+09)
0056	FD3407	0048		INC (IY+07)
0059	14	0049		INC D
005A	DD23	0050		INC IX
005C	FD23	0051		INC IY
005E	EDAA	0052		IND
0060	EDBA	0053		INDR
0062	EDA2	0054		INI
0064	EDB2	0055		INIR
0066	E9	0056		JP (HL)
0067	DDE9	0057		JP (IX)
0069	FDE9	0058		JP (IY)
006B	C30000	0059		JP 0000
006E	FA0000	0060		JP M,0000
0071	188D	0061		JR 0000
0073	388B	0062		JR C,0000
0075	30FF	0063		JR NC,0076
0077	28BA	0064	B0077	JR Z,0033
0079	20FC	0065		JR NZ,0077

LOC	OBJ	LINE	LABEL	SOURCE CODE
007B	51	0066		LD D,C
007C	1699	0067		LD D,99
007E	66	0068		LD H,(HL)
007F	DD4E07	0069		LD C,(IX+07)
0082	FD5606	0070		LD D,(IY+06)
0085	210D00	0071		LD HL,000D
0088	DD7707	0072		LD (IX+07),A
008B	FD7106	0073		LD (IY+06),C
008E	3602	0074		LD (HL),02
0090	DD360643	0075		LD (IX+06),43
0094	FD360677	0076		LD (IY+06),77
0098	0A	0077		LD A,(BC)
0099	1A	0078		LD A,(DE)
009A	3A6500	0079		LD A,(0065)
009D	02	0080		LD (BC),A
009E	12	0081		LD (DE),A
009F	326600	0082		LD (0066),A
00A2	ED57	0083		LD A,I
00A4	ED5F	0084		LD A,R
00A6	ED47	0085		LD I,A
00A8	ED4F	0086		LD R,A
00AA	118800	0087		LD DE,0088
00AD	DD218800	0088		LD IX,0088
00B1	FD214400	0089		LD IY,0044
00B5	2A4400	0090		LD HL,(0044)
00B8	ED4B4400	0091		LD BC,(0044)
00BC	DD2A7600	0092		LD IX,(0076)
00C0	FD2A7500	0093		LD IY,(0075)
00C4	227600	0094		LD (0076),HL
00C7	ED535400	0095		LD (0054),DE
00CB	DD224400	0096		LD (0044),IX
00CF	FD226600	0097		LD (0066),IY
00D3	F9	0098		LD SP,HL
00D4	DDF9	0099		LD SP,IX
00D6	FDF9	0100		LD SP,IY

LOC	OBJ	LINE	LABEL	SOURCE CODE
OOD8	EDA8	0101		LDD
OODA	EDE8	0102		LDDR
OODC	EDA0	0103		LDI
OODE	EDB0	0104		LDIR
OOEO	ED44	0105		NEG
OOE2	00	0106		NOP
OOE3	B7	0107		OR A
OOE4	EDBB	0108		OTDR
OOE6	EDE3	0109		OTIR
OOE8	D307	0110		OUT (07),A
OOEA	ED79	0111		OUT (C),A
OOEC	EDAB	0112		OUTD
OOEE	EDA3	0113		OUTI
OOFO	D1	0114		POP DE
OOF1	DDE1	0115		POP IX
OOF3	FDE1	0116		POP IY
OOF5	D5	0117		PUSH DE
OOF6	DDE5	0118		PUSH IX
OOF8	FDE5	0119		PUSH IY
OOFA	CB8F	0120		RES 1,A
OOFC	C9	0121		RET
OOFD	F8	0122		RET M
OOFE	ED4D	0123		RETI
0100	ED45	0124		RETN
0102	CB17	0125		RL A
0104	17	0126		RLA
0105	CB01	0127		RLC C
0107	CB06	0128		RLC (HL)
0109	DDCB0706	0129		RLC (IX+07)
010D	FDCB0706	0130		RLC (IY+07)
0111	07	0131		RLCA
0112	ED6F	0132		RLD
0114	CB1F	0133		RR A
0116	1F	0134		RRA
0117	CBOA	0135		RRC D


LOC	OBJ	LINE	LABEL	SOURCE CODE
0119	OF	0136		RRCA
011A	ED67	0137		RRD
011C	C7	0138		RST 00
011D	98	0139		SBC A,B
011E	ED52	0140		SBC HL,DE
0120	37	0141		SCF
0121	CBCF	0142		SET 1,A
0123	CBCE	0143		SET 1,(HL)
0125	DDCB07CE	0144		SET 1,(IX+07)
0129	FDCB67CE	0145		SET 1,(IY+67)
012D	CB20	0146		SLA B
012F	CB2B	0147		SRA E
0131	CB3A	0148		SRL D
0133	90	0149		SUB B
0134	AF	0150		XOR A

# Appendix J


## NSC800

### J.1 Hardware

#### J.1.1 Control Emulation Processor Board, CEP-NSC800



### J.1.2 Interface Diagram from Target Processor to CEP-NSC800



J-2

SIZE	CODE	NUMBER	REV
B		140112-310	A
DATE	SHEET 2 OF 2		

## J.2 Application Notes for NSC800 Command Set

1. During I/O read and write cycles, the I/O port address is duplicated in the upper byte of the address. If port addresses are used as halt or trace addresses, the command specification must also duplicate the port address in the upper byte.
2. Dynamic memory refresh from the NSC800 is not supported by NEW MICE-II NSC800 during Cycle Step or Instruction Step operation.

## J.3 Assembly Mnemonic Code Summary, with Disassembly Examples

Refer to section I.3.



## Appendix K

### Z8


---

#### K.1 Hardware


NEW MICE-II Z8 comes with two or three boards, depending on the user's specified emulation requirements. When only internal memory is used, the CEP-Z8 and RTT boards are all that is required. However, when external memory is used, SUEM or HUEM is also required. When replacing the CEP board on another MICE model with the CEP-Z8, SUEM/HUEM may be removed if desired.

1. The CEP-Z8 uses a Z8612 to emulate Z8611, Z8613 and Z8681 processors.
2. Z8601, Z8603, Z8671, Z8681 and Z8682 processors can also be emulated; but external program memory (2K-4K bytes for Z8601, Z8603, Z8671, Z8682, or 0K-4K bytes for Z8681) must be transferred to the CEP-Z8 RAM at U51(6264). Either read the data into the host computer and then download it to MICE emulation memory, or place the target ROM on the CEP-Z8 at U51. However, note that data memory (2K-4K bytes for Z8601, Z8603, Z8671, Z8682, or 0K-4K bytes for Z8681) cannot be accessed by the user program.

# K.1.1 Control Emulation Processor Board, CEP-Z8



### K.1.2 Interface Diagram from Target Processor to CEP-Z8



## K.2 Application Notes for the Z8 Command Set

1. The Z8 family has no HALT or READY state. When the emulation CPU is stopped by any MICE command, it will execute a "JR \$" instruction to prevent the program counter from changing to another location.
2. If execution is halted by H3/H4 at a one-byte instruction at the last cycle of a multi-byte instruction, the program counter will equal the halt address plus two instructions. For any other break location, the program counter will equal the halt address plus one instruction. If any other breakpoint is encountered, or the program is cycle-stepped or in-instruction-stepped, the program counter will point to next instruction.
3. When port 1 is set at high impedance mode (i.e. D3 & D4 = 1 in RF8 [RF8 = XXX11XXX]), MICE control program will overwrite one register during A/I/J/M/O/R/SR/T/Z, Upload and Download commands. The user should define any general purpose register R4-R7F to be overwritten, otherwise default is for R4.

Example: If RF8(P01M) = 9EH, then RW will display as indicated below.

```
>RW
*** HIGH-IMPEDANCE AD0-AD7,AS~,DS~,R/W~!
*** OVERWRITE WHICH REGISTER (04H_7FH, <CR>=04H)? 3F
RP   0   1   2   3   4   5   6   7   8   9   A   B   C   D   E   F
20  0A  31  0C  E3  00  BF  46  23  23  23  23  78  DA  0E  23  23
>
```

4. If PC(H/L) and FLAGS are saved at R04H-R06H on the stack, and an internal interrupt is accepted during A/I/J/M/O/R/SR/T/Z, Upload or Download command execution, the PC and FLAGS will be overwritten.
5. If P0/P1 are both set to I/O mode, and R04 $\geq$ 10H, and the register pointer (RP) is within an unused range (i.e. 80H-E0H), the contents of RFEH and RFFH will be overwritten during A/I/J/M/O/R/SR/T/Z, Upload or Download command execution.

### K.3 Z8 Assembly Mnemonic Code Summary, with Disassembly Examples

LOC	OBJ	LINE	LABEL	SOURCE CODE
0004	140100	0003		ADC 00,01
0007	1402E4	0004		ADC R04,02
000A	14E503	0005		ADC 03,R05
000D	150604	0006		ADC 04,@06
0010	1507E6	0007		ADC R06,@07
0013	15E708	0008		ADC 08,@R07
0016	160901	0009		ADC 09,#01
0019	16E823	0010		ADC R08,#23
001C	170A45	0011		ADC @0A,#45
001F	17E967	0012		ADC @R09,#67
0022	02AB	0013		ADD R0A,R0B
0024	03CD	0014		ADD R0C,@R0D
0026	040COB	0015		ADD 0B,0C
0029	040DEE	0016		ADD R0E,0D
002C	04EFOE	0017		ADD 0E,0F
002F	05100F	0018		ADD 0F,@10
0032	0511E0	0019		ADD R00,@11
0035	05E112	0020		ADD 12,@R01
0038	061389	0021		ADD 13,#89
003B	06E2AB	0022		ADD R02,#AB
003E	0714CD	0023		ADD @14,#CD
0041	07E3EF	0024		ADD @R03,#EF
0044	5245	0025		AND R04,R05
0046	5367	0026		AND R06,@R07
0048	541615	0027		AND 15,16
004B	5417E8	0028		AND R08,17
004E	54E918	0029		AND 18,R09
0051	551A19	0030		AND 19,@1A
0054	551BEA	0031		AND R0A,@1B
0057	55EB1C	0032		AND 1C,@R0B
005A	561D41	0033		AND 1D,#41
005D	56EC42	0034		AND R0C,#42

LOC	OBJ	LINE	LABEL	SOURCE CODE
0060	571E43	0035		AND @1E,#43
0063	57ED44	0036		AND @ROD,#44
0066	D60012	0037		CALL \$0012
0069	D420	0038		CALL @20
006B	D4EE	0039		CALL @RROE
006D	EF	0040		CCF
006E	B021	0041		CLR 21
0070	B0EF	0042		CLR ROF
0072	B122	0043		CLR @22
0074	B1E0	0044		CLR @R00
0076	6023	0045		COM 23
0078	60E1	0046	B0078	COM R01
007A	6124	0047		COM @24
007C	61E2	0048		COM @R02
007E	A234	0049		CP R03,R04
0080	A356	0050		CP R05,@R06
0082	A42625	0051		CP 25,26
0085	A427E7	0052		CP R07,27
0088	A4E828	0053		CP 28,R08
008B	A52A29	0054		CP 29,@2A
008E	A52BE9	0055		CP R09,@2B
0091	A5EA2C	0056		CP 2C,@ROA
0094	A62DFE	0057		CP 2D,#FE
0097	A6EBDC	0058		CP ROB,#DC
009A	A72EBA	0059	B009A	CP @2E,#BA
009D	A7EC98	0060		CP @ROC,#98
00A0	402F	0061		DA 2F
00A2	40ED	0062		DA ROD
00A4	4130	0063		DA @30
00A6	41EE	0064		DA @ROE
00A8	0031	0065		DEC 31
00AA	00EE	0066	B00AA	DEC ROE
00AC	0132	0067		DEC @32
00AE	01EF	0068		DEC @ROF
00B0	8032	0069		DECW 32

LOC	OBJ	LINE	LABEL	SOURCE CODE
00B2	80E0	0070		DECW RROO
00B4	8133	0071		DECW @33
00B6	81E1	0072		DECW @R01
00B8	8F	0073		DI
00B9	2A7F	0074		DJNZ R02,\$013A
00BB	3A80	0075		DJNZ R03,\$003D
00BD	9F	0076		EI
00BE	4E	0077		INC R04
00BF	2034	0078		INC 34
00C1	2135	0079		INC @35
00C3	21E5	0080		INC @R05
00C5	A036	0081		INCW 36
00C7	AOE6	0082		INCW RRO6
00C9	A137	0083		INCW @37
00CB	A1E7	0084		INCW @R07
00CD	BF	0085		IRET
00CE	0D0034	0086		JP F,\$0034
00D1	1D0056	0087		JP LT,\$0056
00D4	2D0078	0088		JP LE,\$0078
00D7	3D009A	0089		JP ULE,\$009A
00DA	4D00BC	0090		JP OV,\$00BC
00DD	5D00DE	0091		JP MI,\$00DE
00E0	6D00F0	0092		JP EQ,\$00F0
00E3	7D0100	0093		JP ULT,\$0100
00E6	8D0200	0094		JP \$0200
00E9	9D0300	0095		JP GE,\$0300
00EC	AD0400	0096		JP GT,\$0400
00EF	BD0500	0097		JP UGT,\$0500
00F2	CD0600	0098		JP NOV,\$0600
00F5	DD0700	0099		JP PL,\$0700
00F8	ED0800	0100		JP NE,\$0800
00FB	FD0900	0101		JP UGE,\$0900
00FE	OBCA	0102		JR F,\$00CA
0100	1BA8	0103	B0100	JR LT,\$00AA
0102	2B86	0104		JR LE,\$008A



OBJ	LINE	LABEL	SOURCE CODE
0104	3B32	0105	JR ULE,\$0138
0106	4B33	0106	JR OV,\$013B
0108	5B3E	0107	JR MI,\$0148
010A	6B4E	0108	JR EQ,\$015A
010C	7B6E	0109	JR ULT,\$017C
010E	8B7E	0110	JR \$018E
0110	9B77	0111	JR GE,\$0189
0112	AB71	0112	JR GT,\$0185
0114	BB63	0113	JR UGT,\$0179
0116	CB55	0114	JR NOV,\$016D
0118	DB42	0115	JR PL,\$015C
011A	EB37	0116	JR NE,\$0153
011C	FB36	0117	JR UGE,\$0154
011E	8C44	0118	LD RO8,#44
0120	9839	0119	LD RO9,39
0122	A8EB	0120	LD ROA,ROB
0124	B93A	0121	LD 3A,ROB
0126	E3CD	0122	LD ROC,@ROD
0128	F3EF	0123	LD @ROE,ROF
012A	E4603B	0124	LD 3B,60
012D	E53E3C	0125	LD 3C,@3E
0130	E53FE0	0126	LD ROO,@3F
0133	E5E140	0127	LD 40,@R01
0136	E64245	0128	LD 42,#45
0139	2C46	0129	LD R02,#46
013B	E74300	0130	LD @43,#00
013E	E7E301	0131	LD @R03,#01
0141	F54544	0132	LD @44,45
0144	F546E4	0133	LD @R04,46
0147	F5E547	0134	LD @47,R05
014A	C76748	0135	LD R06,48(R07)
014D	C78AE9	0136	LD R08,R09(ROA)
0150	D7CB49	0137	LD 49(ROB),ROC
0153	D7FEED	0138	LD B0153 ROD(ROE),ROF

OBJ	LINE	LABEL	SOURCE CODE
0156	C202	0139	LDC R00,@RRO2
0158	D254	0140	LDC @RRO4,R05
015A	C368	0141	LDCI @R06,@RRO4
015C	D3BA	0142	LDCI @RROA,@ROI
015E	82CE	0143	LDE ROC,@RROE
0160	9210	0144	LDE @RRO0,R01
0162	8324	0145	LDEI @R02,@RRO4
0164	9356	0146	LDEI @RRO6,@RRO5
0166	FF	0147	NOP
0167	4278	0148	OR R07,R08
0169	439A	0149	OR R09,@ROA
016B	444B4A	0150	OR 4A,4B
016E	444CEB	0151	OR ROB,4C
0171	44EC4D	0152	OR 4D,ROC
0174	454F4E	0153	OR 4E,@4F
0177	4550ED	0154	OR ROD,@50
017A	45EE51	0155	OR 51,@ROE
017D	465202	0156	OR 52,#02
0180	46EF03	0157	OR ROF,#03
0183	475304	0158	OR @53,#04
0186	47E005	0159	OR @R00,#05
0189	5054	0160	POP 54
018B	50E1	0161	POP R01
018D	5155	0162	POP @55
018F	51E2	0163	POP @R02
0191	7056	0164	PUSH 56
0193	70E2	0165	PUSH R02
0195	7157	0166	PUSH @57
0197	71E3	0167	PUSH @R03
0199	CF	0168	RCF
019A	AF	0169	RET
019B	9058	0170	RL 58
019D	90E4	0171	RL R04
019F	9159	0172	RL @59
01A1	91E5	0173	RL @R05

B015A  
B015C

B0189

OBJ	LINE	LABEL	SOURCE CODE
01A3	105A	0174	RLC 5A
01A5	10E6	0175	RLC R06
01A7	115B	0176	RLC @5B
01A9	11E7	0177	RLC @R07
01AB	E05C	0178	RR 5C
01AD	E0E8	0179	RR R08
01AF	E15D	0180	RR @5D
01B1	E1E8	0181	RR @R08
01B3	C05E	0182	RRC 5E
01B5	C0E9	0183	RRC R09
01B7	C15F	0184	RRC @5F
01B9	C1EA	0185	RRC @ROA
01BB	32BC	0186	SBC ROB,ROC
01BD	33DE	0187	SBC ROD,@ROE
01BF	346160	0188	SBC 60,61
01C2	34FFEF	0189	SBC ROF,FF
01C5	34E062	0190	SBC 62,R00
01C8	356463	0191	SBC 63,@64
01CB	3565E1	0192	SBC R01,@65
01CE	35E266	0193	SBC 66,@R02
01D1	366706	0194	SBC 67,#06
01D4	36E307	0195	SBC R03,#07
01D7	376808	0196	SBC @68,#08
01DA	37E409	0197	SBC @R04,#09
01DD	DF	0198	SCF
01DE	D069	0199	SRA 69
01E0	DOE5	0200	SRA R05
01E2	D16A	0201	SRA @6A
01E4	D1E6	0202	SRA @R06
01E6	310A	0203	SRP #0A
01E8	2278	0204	SUB R07,R08
01EA	239A	0205	SUB R09,@ROA
01EC	246C6B	0206	SUB 6B,6C
01EF	246DEB	0207	SUB ROB,6D
01F2	24EC6E	0208	SUB 6E,ROC

OBJ	LINE	LABEL	SOURCE CODE
01F5	25706F	0209	SUB 6F,@70
01F8	2571ED	0210	SUB ROD,@71
01FB	25EE72	0211	SUB 72,@ROE
01FE	26730B	0212	SUB 73,#OB
0201	26EFOC	0213	SUB ROF,#OC
0204	27740D	0214	SUB @74,#OD
0207	27E00E	0215	SUB @ROO,#OE
020A	F075	0216	SWAP 75
020C	FOE1	0217	SWAP R01
020E	F176	0218	SWAP @76
0210	F1E2	0219	SWAP @R02
0212	6234	0220	TCM R03,R04
0214	6356	0221	TCM R05,@R06
0216	647877	0222	TCM 77,78
0219	6479E7	0223	TCM R07,79
021C	64E87A	0224	TCM 7A,R08
021F	657C7B	0225	TCM 7B,@7C
0222	657DE9	0226	TCM R09,@7D
0225	65EA7E	0227	TCM 7E,@ROA
0228	667F0F	0228	TCM 7F,#OF
022B	66EB10	0229	TCM ROB,#10
022E	67F020	0230	TCM @FO,#20
0231	67EC30	0231	TCM @ROC,#30
0234	72DE	0232	TM ROD,ROE
0236	73FO	0233	TM ROF,@ROO
0238	74F2F1	0234	TM F1,F2
023B	74F3E1	0235	TM R01,F3
023E	74E2F4	0236	TM F4,R02
0241	74FEE3	0237	TM R03,FE
0244	74E4F5	0238	TM F5,R04
0247	75F7F6	0239	TM F6,@F7
024A	75F8E5	0240	TM R05,@F8
024D	75E6F9	0241	TM F9,@R06
0250	76FA40	0242	TM FA,#40
0253	76E750	0243	TM R07,#50

OBJ	LINE	LABEL	SOURCE CODE
0256	77FB60	0244	TM @FB,#60
0259	77E870	0245	TM @R08,#70
025C	B29A	0246	XOR R09,ROA
025E	B3BC	0247	XOR ROB,@ROC
0260	B40100	0248	XOR 00,01
0263	B402ED	0249	XOR ROD,02
0266	B4EE03	0250	XOR 03,ROE
0269	B50504	0251	XOR 04,@05
026C	B506EF	0252	XOR ROF,@06
026F	B5E007	0253	XOR 07,@R00
0272	B60880	0254	XOR 08,#80
0275	B6E190	0255	XOR R01,#90
0278	B709A0	0256	XOR @09,#A0
027B	B7E2B0	0257	XOR @R02,#B0

## Appendix L

### ZS8

---


#### L.1 Hardware

NEW MICE-II ZS8 comes with two or three boards, depending on the user's specified emulation requirements. When only internal memory is used, the CEP-ZS8 and RTT boards are all that is required. However, when external memory is used, HUEM is also required. When replacing the CEP board on another MICE model with the CEP-ZS8, SUEM/HUEM may be removed if desired.


The CEP-ZS8 uses a Z8883 to emulate the following processors:

Z8800	Z8811	Z8820	Z8823	Z8832
Z8801	Z8812	Z8821	Z8830	Z8833
Z8810	Z8813	Z8822	Z8831	

### L.1.1 Control Emulation Processor Board, CEP-ZS8




L.1.2 Interface Diagram from Target Processor to CEP-ZS8



SIZE	CODE	NUMBER	REV
B		140112-316	A
DATE		SHEET 2 OF 2	





SIZE	CODE	NUMBER	REV
B		140112-317	A
DATE	SHEET 2 OF 2		

## L.2 Application Notes for the ZS8 Command Set

1. The ZS8 family has no HALT or READY state. When the emulation CPU is stopped by any MICE command, it will execute a "JR \$" instruction to prevent the program counter from changing to another location.
2. If execution is halted by H3/H4 at a one-byte instruction at the last cycle of a multi-byte instruction, the program counter will equal the halt address plus two instructions. For any other break location, the program counter will equal the halt address plus one instruction. If any other breakpoint is encountered, or the program is cycle-stepped or instruction-stepped, the program counter will point to next instruction.

### L.3 ZS8 Assembly Mnemonic Code Summary, with Disassembly Examples

LOC	OBJ	LINE	LABEL	SOURCE CODE
0020	1201	0001		ADC R00,R01
0022	1323	0002		ADC R02,@R03
0024	1403C5	0003		ADC R05,03
0027	1507C6	0004		ADC R06,@07
002A	16C7FF	0005		ADC R07,#FF
002D	03AB	0006		ADD ROA,@ROB
002F	04CDOC	0007		ADD 0C,ROD
0032	050E0D	0008		ADD 0D,@0E
0035	061012	0009		ADD 10,#12
0038	0201	0010		ADD R00,R01
003A	0323	0011		ADD R02,@R03
003C	04C514	0012		ADD 14,R05
003F	051716	0013		ADD 16,@17
0042	061912	0014		ADD 19,#12
0045	67801A	0015		BAND R08,1A,#0
0048	6782C9	0016		BAND R08,R09,#1
004B	67C7CB	0017		BAND ROB,#3,ROC
004E	17D81C	0018		BCP ROD,1C,#4
0051	17EACF	0019		BCP ROE,ROF,#5
0054	570C	0020		BITC R00,#6
0056	771E	0021		BITR R01,#7
0058	7721	0022		BITS R02,#0
005A	07321D	0023		BOR R03,1D,#1
005D	0744C5	0024		BOR R04,R05,#2
0060	07671E	0025		BOR 1E,#3,R06
0063	0789C7	0026		BOR R07,#4,R08
0066	379AFD	0027	B0066	BTJRF \$0066,R09,#5
0069	37AD00	0028		BTJRT \$006C,ROA,#6
006C	27BE1F	0029	B006C	BXOR ROB,1F,#7
006F	27COCD	0030		BXOR ROC,ROD,#0

LOC	OBJ	LINE	LABEL	SOURCE CODE
0072	27E320	0031		BXOR 20,#1,ROE
0075	2705CF	0032		BXOR ROF,#2,ROO
0078	F60000	0033		CALL \$0000
007B	F422	0034		CALL @22
007D	D440	0035		CALL #\$40
007F	EF	0036		CCF
0080	BOC1	0037		CLR R01
0082	6025	0038		COM 25
0084	60C2	0039		COM R02
0086	6126	0040		COM @26
0088	A234	0041		CP R03,R04
008A	A356	0042		CP R05,@R06
008C	A42827	0043		CP 27,28
008F	A4C82A	0044		CP 2A,R08
0092	A52C2B	0045		CP 2B,@2C
0095	A6CA56	0046	B0095	CP ROA,#56
0098	C2CBFA	0047		CPIJE ROB,@ROC,\$0095
009B	D2ED00	0048		CPIJNE ROD,@ROE,\$009E
009E	402F	0049	B009E	DA 2F
00A0	40CF	0050		DA ROF
00A2	4130	0051		DA @30
00A4	0031	0052		DEC 31
00A6	00C0	0053		DEC R00
00A8	0132	0054		DEC @32
00AA	80C2	0055		DECW RR02
00AC	943736	0056		DIV 36,37
00AF	94C53A	0057		DIV 3A,R05
00B2	94C7C6	0058		DIV RR06,R07
00B5	953EC8	0059		DIV RR08,@3E
00B8	969ACA	0060		DIV RROA,#9A
00BB	BA00	0061		DJNZ ROB,\$00BD
00BD	20C3	0062	BO0BD	INC R03
00BF	A042	0063		INCW 42
00C1	AOCE	0064		INCW RROE
00C3	A143	0065		INCW @43

LOC	OBJ	LINE	LABEL	SOURCE	CODE
00C5	BF	0066		IRET	
00C6	1D4321	0067		JP	LT, \$4321
00C9	7D1111	0068		JP	ULT, \$1111
00CC	8D3333	0069		JP	\$3333
00CF	9D2233	0070		JP	GE, \$2233
00D2	FD8899	0071		JP	UGE, \$8899
00D5	3044	0072		JP	@44
00D7	6B00	0073		JR	EQ, \$00D9
00D9	EB00	0074	BOOD9	JR	NE, \$00DB
00DB	18C2	0075	BOODB	LD	RO1, RO2
00DD	C745	0076		LD	RO4, @RO5
00DF	E44847	0077		LD	47, 48
00E2	984A	0078		LD	RO9, 4A
00E4	E54C4B	0079		LD	4B, @4C
00E7	D64EFO	0080		LD	@4E, #FO
00EA	F5504F	0081		LD	@4F, 50
00ED	87DFCE	0082		LD	ROD, CE (ROF)
00FO	9743C2	0083		LD	C2 (RO3), RO4
00F3	4768C7	0084		LDB	RO6, RO7, #4
00F6	47ADC9	0085		LDB	RO9, #6, ROA
00F9	C3DF	0086		LDE	ROD, @RROE
00FB	D333	0087		LDE	@RRO2, RO3
00FD	E74610	0088		LDC	RO4, \$10 (RRO6)
0100	E77920	0089		LDE	RO7, \$20 (RRO8)
0103	A7DE3412	0090		LDC	ROD, \$1234 (RROE)
0107	A7F37856	0091		LDE	ROF, \$5678 (RRO2)
010B	A7700010	0092		LDC	RO7, \$1000
010F	A7810020	0093		LDE	RO8, \$2000
0113	E2BC	0094		LDCD	ROB, @RROC
0115	E2DF	0095		LDED	ROD, @RROE
0117	E3FO	0096		LDCI	ROF, @RROO
0119	E313	0097		LDEI	RO1, @RRO2
011B	F234	0098		LDCPD	@RRO4, RO3
011D	F257	0099		LDEPD	@RRO6, RO5
011F	F378	0100		LDCPI	@RRO8, RO7

LOC	OBJ	LINE	LABEL	SOURCE CODE
0121	F39B	0101		LDEPI @RROA,R09
0123	C4CE5A	0102		LDW 5A,RROE
0126	C4C2C0	0103		LDW RROO,RRO2
0129	C55D5C	0104		LDW 5C,@5D
012C	C6C60020	0105		LDW RRO6,#0020
0130	846162	0106		MULT 62,61
0133	84CBCA	0107		MULT RROA,ROB
0136	8568CC	0108		MULT RROC,@68
0139	86306A	0109		MULT 6A,#30
013C	OF	0110		NEXT
013D	42F0	0111		OR ROF,R00
013F	4312	0112		OR R01,@R02
0141	456FC5	0113		OR R05,@6F
0144	46C660	0114		OR R06,#60
0147	50C7	0115		POP R07
0149	5172	0116		POP @72
014B	9275C8	0117		POPUD R08,@75
014E	9378C9	0118		POPUI R09,@78
0151	7079	0119		PUSH 79
0153	827DCB	0120		PUSHUD @7D,ROB
0156	837E7F	0121		PUSHUI @7E,7F
0159	CF	0122		RCF
015A	9081	0123		RL 81
015C	10CE	0124		RLC ROE
015E	1184	0125		RLC @84
0160	E085	0126		RR 85
0162	COC0	0127		RRC ROO
0164	C188	0128		RRC @88
0166	4F	0129		SBO
0167	5F	0130		SB1
0168	3334	0131		SBC R03,@R04
016A	34C58B	0132		SBC 8B,R05
016D	358F8E	0133		SBC 8E,@8F
0170	369170	0134		SBC 91,#70
0173	DF	0135		SCF

LOC	OBJ	LINE	LABEL	SOURCE	CODE
0174	DOC8	0136		SRA	R08
0176	D193	0137		SRA	@93
0178	3190	0138		SRP	#90
017A	31A2	0139		SRP0	#A0
017C	31B1	0140		SRP1	#B0
017E	23BC	0141		SUB	ROB,@ROC
0180	24CEB3	0142		SUB	B3,ROE
0183	25COCF	0143		SUB	ROF,@CO
0186	26C2D0	0144		SUB	RO2,#D0
0189	F0D4	0145		SWAP	D4
018B	6367	0146		TCM	RO6,@R07
018D	64D9C8	0147		TCM	R08,D9
0190	65DCDB	0148		TCM	DB,@DC
0193	66E3E0	0149		TCM	E3,#E0
0196	72CD	0150		TM	ROC,ROD
0198	76C255	0151		TM	RO2,#55
019B	3F	0152		WFI	
019C	B234	0153		XOR	R03,R04
019E	B356	0154		XOR	R05,@R06
01A0	B4F3C7	0155		XOR	R07,F3
01A3	B5F6F5	0156		XOR	F5,@F6
01A6	B5F7C9	0157		XOR	R09,@F7
01A9	B6FFDD	0158		XOR	FF,#DD
01AC	B6CAEE	0159		XOR	ROA,#EE

## Appendix M

### Error Messages

---

#### 1. ADDRESS xxxx RAM ERROR!

Condition: Memory addressed in Memory Test (T) command failed.

Recovery: Verify that specified address is write enabled RAM; and then see if the address bus and/or data bus are open or shorted.

#### 2. BACKWARD TRACE FAILS!

Condition: Trace buffer is empty when the breakpoint is matched, or <ESC> is input, or the processor is stopped without stepping any machine cycles.

Recovery: See if the READY signal is always inactive, or the HOLD signal is always active. Then see if the trigger address or a specified breakpoint (H1-H6) was matched immediately.

#### 3. BC TABLE FULL

Condition: Instructions branched to and called in the disassembly command exceed 900.



**4. BUS REQUESTING!**

Condition: Target bus requesting signal always active.

Recovery: Verify that target has a bus request signal.

**5. COMMAND TOO LONG!**

Condition: Instruction string in assembly command exceeds 50 characters.

**6. ERROR!**

Condition: Command syntax error.

**7. ERROR CODE!**

Condition: Instruction error in disassembly command.

**8. ERROR CODE, TRY AGAIN!**

Condition: Instruction error in assembly command.

**9. FORWARD TRACE FAILS!**

Condition: Trace buffer is empty when the breakpoint is matched, or <ESC> is input, or the processor is stopped without stepping any machine cycles.

Recovery: See if the trigger address was invalid, or a specified breakpoint was matched before the trace started.

10. Hx NOT SET!

Condition: Specified breakpoint not set prior to executing BT command.

11. MEMORY SEARCH FAILURE!

Condition: Data string not found within specified address range for Memory Search (M) command.

12. MEMORY VERIFICATION FAILURE!

Condition: Data cannot be written to address memory in Modify (M) command.

Recovery: Verify that specified address is valid and write enabled.

13. MEMORY WRITE FAILURE!

Condition: Data cannot be written to addressed memory in assembly command.

Recovery: Verify that specified address is valid and write enabled.

14. NO BPP CARD!

Condition: BPP commands cannot be executed without a BPP card.

15. PROGRAM HALT!

Condition: Emulation processor halted by instruction.

Recovery: Use an interrupt or reset to recover; then perform a trace to see where the HALT instruction occurred.

#### 16. TARGET CAN'T STEP! \*

Condition: Emulation processor does not respond after applying power or inputting the software reset command "r" (see Section 2.10). There is a problem with emulation processor that prevents a program from executing; there are several possibilities which can generate this message:

1. There is no clock.
2. There is a problem with the address line.
3. Target does not support the "ready" signal.
4. There is a problem with the RTT, CEP or HUEM/SUEM board.
5. Other component failure.

Recovery: Check to be sure the emulation processor clock signal is correct and verify that the clock source selection switch is properly adjusted (see CEP Placement Chart in the appropriate appendix for switch location).

#### 17. TARGET IS NOT READY!

Condition: Target memory or input/output ready signal is inactive.

Recovery: Use a valid physical location in the command specification.

18. **Ux -- FAILURE! \***

Condition: MICE selftest indicates location number for failure device.

Recovery: Contact your nearest Microtek distributor for assistance.

19. **WARNING: ONLY 6 BYTES ARE VALID**

Condition: Define byte (DB) in assembly command exceeds 6 bytes.

20. **WHAT? \***

Condition: RS-232C communication with parity or framing error.

Recovery: Check interface setting for communications at U13.

\*Potentially fatal error; if problem cannot be resolved, contact your nearest Microtek distributor for assistance..

## APPENDIX N

### LIMITED WARRANTY; service

---

Microtek International Inc. ("Microtek") warrants NEW MICE-II (the "Product") and the user's manual for the Product, to be free from physical defects for a period of twelve (12) months from the date of the original retail purchase. This warranty applies only to the original retail purchaser who bought this Product from an authorized Microtek representative. This warranty is void if the Product is damaged by improper or abnormal use or by accident, if the Product is altered or modified in any way, or if any attempt is made to repair the Product without authorization from Microtek.

If you find a Product to be defective, contact your authorized Microtek representative or Microtek. When you receive authorization to do so, return the Product as directed; include proof of purchase and purchase date. Microtek will correct physical defects in Products under warranty at no charge to you by repairing or, at its option, replacing such Products. THIS IS THE SOLE AND EXCLUSIVE REMEDY AVAILABLE FOR BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY WITH RESPECT TO MICROTEK PRODUCTS. Product repairs not covered by warranty, and Product updates, are provided at a set rate.

ALL OTHER WARRANTIES AND REPRESENTATIONS, ORAL OR WRITTEN, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXCLUDED AND DO NOT APPLY. Except as set forth in this limited warranty,

the purchaser assumes the risk as to these Products' quality, accuracy, design, and performance.

It is solely the purchaser's responsibility to determine the suitability of these Products for each particular application. Microtek Products are in all events not suitable, and are not authorized, for use in connection with life support devices or systems, or in other devices or systems potentially injurious to life or health.

IN NO EVENT WILL MICROTEK BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY, even if advised of the possibility of such damages. Microtek is thus not liable for lost profits or goodwill; downtime; damage or destruction of any program, data, equipment, or other property; costs of recovering, reprogramming, or reproducing any program, data, or equipment; personal injury or loss; or any other damages.

Except as required by law, no representative, agent, or employee of Microtek is authorized to commit Microtek to warranties, representations, or obligations inconsistent with or in addition to those set forth in this limited warranty.

Please complete and return the registration section of the warranty card (provided in the packing box) to Microtek.

---

# **BPP**

## *Section*

BPP SECTION FOR

Z80  
NSC800  
Z8  
Z88

1st Edition  
August 1988

MICROTEK INTERNATIONAL INC.  
No. 6 Industry E. Road 3  
Science-Based Industrial Park  
Hsinchu, Taiwan 30077, R.O.C.  
TEL: (035) 772155  
TLX: 32169 MICROTEK  
FAX: (035) 772598



## TABLE OF CONTENTS

	Page
<b>SECTION 1: INTRODUCTION</b> .....	1-1
1.1 Installation .....	1-3
1.2 Electrical and Environmental Specifications .....	1-4
<b>SECTION 2: BPP FUNCTIONS</b> .....	2-1
2.1 Halt Breakpoints and Breakpoint Commands .....	2-1
2.2 Breakpoint Syntax .....	2-3
2.3 Data Breakpoints (H3/H4) .....	2-4
2.4 External Hardware Breakpoints (H5/H6)	2-10
<b>SECTION 3: BREAKPOINT TRACE LOGIC</b> .....	3-1
3.1 Breakpoint Trace - BT .....	3-1
3.1.1 Event Count Trace (with H3) ...	3-2
3.1.2 Delay Trigger Trace (with H4) .	3-3
3.1.3 Breakpoint Interval Timer .....	3-5
3.2 Armed Trigger Trace .....	3-7
3.3 AND Trigger Trace .....	3-12
3.4 OR Trigger Trace .....	3-17
<b>SECTION 4: SYNC SIGNAL OUTPUT</b> .....	4-1
4.1 External Hardware Trigger Output ....	4-1
4.2 Output Signal Timing .....	4-3
<b>APPENDIX A: BPP BLOCK DIAGRAM</b> .....	A-1
<b>APPENDIX B: BPP PLACEMENT CHART</b> .....	B-1
<b>APPENDIX C: TIMING FOR BREAK OPERATION (H1-H6)</b> .....	C-1
C.1 Emulation Status .....	C-1
C.2 Timing for Breakpoints H1/H2 .....	C-3
C.3 Timing for Breakpoints H3/H4 .....	C-7
C.4 Timing for Breakpoints H5/H6 .....	C-8
C.5 Timing Diagrams for Break Operation	C-10
C.6 Breakpoint Timing (H5/H6) for Respective NEW MICE-II .....	C-15

## SECTION 1

### INTRODUCTION

---

Microtek's BreakPoint Processor (BPP) is a comprehensive breakpoint control unit for all NEW MICE-II emulators. The BPP is an optional single card PCB that features sophisticated breakpoint logic. It includes up to 120 new breakpoint constructs for more flexibility in target system debug and development. The BPP also includes external hardware triggering and an execution interval timer. This powerful triggering system helps you to quickly solve the most difficult software and hardware bugs.

Breakpoint conditions designating precise events can be logically joined with ARM/AND/OR connectives, permitting you to -

- \* begin or end tracing
- \* activate another event group
- \* specify delayed trigger count
- \* initiate event counter
- \* use external signal as trace trigger
- \* send trigger signal to external device
- \* record execution time between two events
- \* break emulation

Flexible trigger constructs can be used to define single events, multiple activities or external hardware signals. These powerful triggers make it easy to specify complex processor and hardware sequences. Data breakpoints can be set for address, data, status, count and delay. While external hardware breakpoints can specify up to two triggers (each with any combination of two signals).

This breakpoint system combines a large number of trigger events, permitting you to begin target trace or break emulation on the following activities -


- \* Address Bus
- \* Data Bus
- \* Delay Count
- \* Event Counter (trigger match)
- \* Microprocessor Status Lines (Fetch, Read, Write, Input, Output and Interrupt Acknowledge)
- \* Logically Joined Breakpoints
- \* Sequence Levels
- \* Logical State Input

## 1.1 Installation

The BPP is a multilayer board added to the NEW MICE-II module.

To install the BPP board, first remove the cover to the NEW MICE-II case. With the power off, disconnect the two ribbon cable connectors; then remove the CEP and RTT boards. Replace the original brass spacers with the new ones provided with the BPP board. Reassemble all boards back into the MICE case, inserting the BPP board between the CEP and RTT boards. Then attach the new ribbon cable connectors (supplied with the BPP) firmly to each board.

Note: We recommend leaving the cover of the NEW MICE-II case off when using four boards, otherwise overheating may cause intermittent problems in operation.



## 1.2 Electrical and Environmental Specifications

### Electrical Characteristics

Power +5 VDC (For BPP board)  
Maximum current 1.3 Amp

NEW MICE-II equips one built-in power supply.

Power Consumption: AC100-120V~:1.3A MAX  
AC200-240V~:0.65A MAX  
47-63HZ

Voltage Requirements: AC100-120V~ or  
AC200-240V~  
Factory-set

### Environmental Characteristics

Operating temperature 0°~50°C (32°~122°F)  
Storage temperature -10°~65°C (14°~149°F)  
Relative humidity 20-80%

## SECTION 2

### BPP FUNCTIONS

---

The BPP includes four breakpoints (H3-H6), two triggers for transmitting a sync signal to an external device (BS1-BS2), and a Breakpoint Trigger Trace command (BT).

NEW MICE-II's other breakpoints (H1/H2) can be combined with the BPP commands; and H2-H6 can also serve as individual breakpoints for B/F/G commands (note that H1 can not be used for B/F commands).

#### 2.1 Halt Breakpoints and Breakpoint Commands

##### Breakpoints:

H3/H4 are data breakpoints.

H5/H6 are external hardware breakpoints.

##### Commands:

BS is the Breakpoint Sync command. It outputs a sync signal (to an external device) when the specified trigger condition is matched.

BT is the Breakpoint Trace command. It begins tracing from the current program address up to the specified trigger condition (Backward Trace).

?B is the command to display BPP syntax as illustrated below:

>?B

H ?|[0][3|4|5|6]

H3 addx[ data[ <dbwc>][ q[ cnt]]]

H4 addx[ data[ <dbwc>][ q[ dly]]]

H5 xx

H6 xx

BS 1|2[ addx[ data[<dbwc>][ q]]]

BT A[ B[ C[ D]]]

BT <A B C>

BT <A B>[ C[ D]]

BT (A B)[ C[ D]]

BT (A B C)[ D]

A-D ARE ANY OF H3~6

>

## 2.2 Breakpoint Syntax

### For H3/H4

- addr** - is an up to 4 digit hex address with an optional byte pair of "XX".
- data** - is an up to 2 digit hex data.
- <dbwc>** - is an up to 2 digit hex setting; interpreted as 16 binary data bits, where "0" indicates "don't care".
- q** - is a qualifier for the type of processor activity, where "X" indicates "don't care".
- cnt** - is a trigger count; the range is 1-4000H (for nth match).
- dly** - is a cycle count delay; the range is 2-FFFFH.

For a detailed description refer to section 2.3.

### For H5/H6

- H5 [**xx**] - are 2 spare bits (X1 and X0).
- H6 [**xx**] - are 2 spare bits (X3 and X2).

Spare bits are monitored signals input from stick headers X0~3 on the CEP board. They can be set to match signal input at HIGH, LOW or "don't care" (1/0/X). For a detailed description refer to section 2.4.



## 2.3 Data Breakpoints (H3/H4)

---

H3 [addr[ data [<dbwc>][ qualifier[ count]]]]

H4 [addr[ data [<dbwc>][ qualifier[ delay]]]]

---

**H3** is the command for a Data Breakpoint with an optional event count.

**H4** is the command for a Data Breakpoint with an optional cycle delay.

**addr** is the trigger address where emulation is to stop. This can be an up to four digit hex address with an optional byte pair of "XX". (The maximum address length depends on the address range for the current emulation processor.)

**data** is an up to 2 digit hex data to be matched with the trigger address.

**<dbwc>** is an up to 2 digit hex setting indicating a "data bit wildcard". To enter any <dbwc>, a **data** value must first be defined. The data bit wildcard is interpreted as 16 binary data bits, where "0" indicates "don't care". The default value for the dbwc is FFH.

**qualifier** is a single or double alphabetic character indicating the type of processor activity to be matched with the trigger address. (If a **count** or **delay** is to be input, an "X" may be used in the status specification to indicate "don't care".)

For a complete listing of qualifiers applicable for a particular processor, refer to the appropriate appendix in the NEW MICE-II User's Manual.

**count** is a hexadecimal value from 1~4000H that specifies the number of times the target condition must be matched before the trace stops. To enter a count, a **qualifier** must first be defined.

**delay** is a hexadecimal value from 2~FFFFH that specifies a cycle count delay. After all other trigger conditions have been matched, the trace will continue until the specified cycle count has expired. To enter a delay, a **qualifier** must first be defined.

The breakpoints H3 and H4 are latched on the rising edge of a STROBE signal from the CEP board. When the breakpoint is activated, emulation stops at the end of the next bus cycle. (See Appendix C for a detailed description of break operation.) If a trigger count or cycle delay is defined, then the specified value must also be matched before the breakpoint is activated. This method is useful for tracing data after all other trigger conditions have been matched.

When the specified break condition is matched, a sync signal is output. Note that **delay** is not calculated for

the sync signal; as soon as all other trigger conditions are matched, the sync signal is transmitted without waiting for the specified delay to transpire. A count, however, specifies the number of times a sync signal will be transmitted. Everytime the trigger condition is matched and the count incremented, and a sync signal is output.

The following sample program for an Z80 target is used as the basis for all the examples listed in this user's manual. This program includes commonly used instructions for performing various bus cycles. Without a target system connected, it executes in a simple loop and select BUSAK mode by X13 in CEP board.

```
>J0
>Z
LOC      OBJ          LINE      LABEL      SOURCE CODE
0000     00           0001      B0000      NOP
0001     00           0002                          NOP
0002     210003       0003                          LD    HL,0300
0005     3E55         0004                          LD    A,55
0007     77           0005                          LD    (HL),A
0008     DB00         0006                          IN   A,(00)
000A     00           0007                          NOP
000B     D300         0008                          OUT  (00),A
000D     110002       0009                          LD    DE,0200
0010     12           0010      B0010      LD    (DE),A
0011     13           0011                          INC  DE
0012     3C           0012                          INC  A
0013     FE0F         0013                          CP   0F
0015     20F9         0014                          JR   NZ,0010
0017     C30000       0015                          JP   0000
001A     00           0016                          NOP
DISASSEMBLY COMPLETED
>
```

**Example 1:** Use the "H?" command to display all breakpoint settings; then set H3 at address 0000H and begin program execution.

```

>H?                ;Display H1-H6 settings.
H1=
H2=
H3=
H4=
H5=
H6=
>J0                ;Reset the PC to 0000H.
>H3 0
>R                ;Examine the registers prior to program execution.
  A B C D E H L I F X Y S PC
  FF BF FF 02 00 03 00 00 4A BFBF FFFF FFFF 0000
>G                ;Breakpoint matched at 0000H.
PROGRAM BROKE AT BREAKPOINT-3
>C                ;Cycle command steps the program to address 01H.
IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
      0001  00   ?      11111111
      0002  0002  21   S      11111111
      0003  00   R      11111111 <ESC>
>

```

Note: For the Z80 if H3/H4 has been set and the trigger condition is matched at the current cycle, the CPU will stop at the next cycle (see Appendix C).

**Example 2:** Set H3 for any address with "don't care" and data for 0000. (Note that without a dbwc, all binary bits of the specified data value are qualified.)

```
>J0 ;Reset the PC to 0000H.
>H3 XXXX 00 ;Use H3 to break at data 00.
```

```
>G
PROGRAM BROKE AT BREAKPOINT-3
```

```
>C
IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
      0001 00 ? 11111111
0002 0002 21 S 11111111
      0003 00 R 11111111 <ESC>
```

>

**Example 3:** Set H3 with address and data of "don't care"; then set the status to Port Input with a count of 3.

```
>H0 ;Clear H1-H6 settings.
>H3 XXXX 00 <0> I 3 ;H3 set to break on 3rd input cycle.
>J0 ;Reset the PC to 0000H.
```

```
>G
PROGRAM BROKE AT BREAKPOINT-3
```

```
>C
IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
      000B D3 ? 11111101
      000C 00 F 11110000
      FF00 FF G 11111111
000D 000D 11 S 11110000 <ESC>
```

>

**Example 4:** Set H4 to any address XXXXH with a data bit wildcard that qualifies bit 1 only; then set the status to Port Output with a delay of 2.

```

>J0                ;Reset the PC to 0000H.
>H0                ;Clear H1-H6 settings.
>H4 XXXX FF <2> 0 2 ;H4 set for address XXXXH, data "xxxx xx1x".
>H?                ;Display H1-H6 settings.
H1=
H2=
H3=
H4= XXXX FF <2> 0 2
H5=
H6=
>G
PROGRAM BROKE AT BREAKPOINT-4
>C
      IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
          0012  3C   ?   11110010
0013  0013  FE   S   11111111
          0014  OF   R   11110100 <ESC>
>

```

## 2.4 External Hardware Breakpoints (H5/H6)

---

H5 [xx]

H6 [xx]

---

H5 is the command for an External Hardware Breakpoint set by monitored signals at X1 and X0 on the CEP board.

|-----↓  
xx indicates spare bit "X1" and spare bit "X0".  
|-----↑

H6 is the command for an External Hardware Breakpoint set by monitored signals at X3 and X2 on the CEP board.

|-----↓  
xx indicates spare bit "X3" and spare bit "X2".  
|-----↑

The breakpoints H5 and H6 use two external signal groups on the CEP board (X1/X0 and X3/X2 respectively). Mini-jumpers provided with the BPP can be used to connect from these test points to the target. The monitored signals are called spare bits and support concurrent trace for address, data and status bus. Any of these bits can be monitored to provide hardware status based on machine cycles. Hardware breakpoints are latched when the specified logic state occurs.

The spare bits input from stick headers X0-3 on the CEP board can be set to match signal input at HIGH, LOW or "don't care" (1/0/X), where

1 = high level  
0 = low level  
X = don't care (either 1 or 0)

Note: Input signals to X0-3 must meet specifications for the Schmitt trigger IC - 74LS132.

To demonstrate External Hardware Breakpoints in the following examples, jumpers are connected to the CEP board of a NEW MICE-II Z80. The spare bits X0, X1, X2, X3 are configured as shown below:

X0 is connected to U56-18 (CEP 74F244  $\overline{\text{IORQ\_T}}$ )  
X1 is connected to U56-16 (CEP 74F244  $\overline{\text{M1\_T}}$  )  
X2 is connected to U56-12 (CEP 74F244  $\overline{\text{RD\_T}}$  )  
X3 is connected to U56-3 (CEP 74F244  $\overline{\text{WR\_T}}$  )



**Example 1:** Use H5 to break emulation after an I/O cycle by setting the input trigger at 10 for X1/X0.

```
>H0 ;Clear H1-H6 settings.
>J0 ;Reset the PC to 0000H.
>H5 10 ;Break condition for X0=0, X1=1.
>H? ;Display H1-H6 settings.
```

```
H1=
H2=
H3=
H4=
H5= 10
H6=
>G
```

PROGRAM BROKE AT BREAKPOINT-5

```
>C
```

IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
	000A	00	?	11111001
000B	000B	D3	S	11111001
	000C	00	P	11111011 <ESC>

```
>
```

**Example 2:** Use H6 to break emulation after an Write cycle by setting the input trigger at 01 for X3/X2.

```
>J0                ;Reset the PC to 0000H.
>H0                ;Clear H1-H6 settings.
>H6 01             ;Set break condition for X2=1, X3=0.
>H?                ;Display H1-H6 settings.
```

```
H1=
H2=
H3=
H4=
H5=
H6= 01
```

```
>G
PROGRAM BROKE AT BREAKPOINT-6
```

```
>C
      IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
      000D  11  ?      11111001
      000E  00  R      11111011
      000F  02  R      11111011 <ESC>
```

```
>
```

## SECTION 3

### BREAKPOINT TRACE LOGIC

#### 3.1 Breakpoint Trace - BT

---

Refer to the following sections for description of syntax.

---

BT is the command for Breakpoint Tracing.

Breakpoint Tracing begins at the current address (Backward Trace) and continues until all the specified breakpoints are matched. H3-H6 must be set prior to command execution, and may be specified as a single breakpoint or in logical combinations (ARM/AND/OR) with the BT command. Note that H1 and H2 (specified prior to execution, and not within the BT command definition) can also be used to add another logical OR to the trigger construct (refer to the last example in section 3.1.1). The BPP performs the following types of tracing:

- Event Count Trace
- Delay Trigger Trace
- ARM Trigger Trace
- AND Trigger Trace
- OR Trigger Trace

### 3.1.1 Event Count Trace (with H3)

The address, data and qualifier of a specific program event can be defined along with a **count** in the H3 breakpoint. When the Event Count trigger is enabled, it is added as a logical OR to the breakpoint parameters defined in B/F commands. When enabled and then defined in the BT command, it can be used alone or in any legal combination with other breakpoints. (Also refer to the example in section 3.1.3.)

**Example:** Set break conditions for H3 at any address, any data, Write cycle and with a count of 2; then execute a trace using the BT command.

```
>J0                ;Reset the PC to 0000H.
>H0                ;Clear H1-H6 settings.
>H3 XXXX FF <0> W 2 ;Set the event count trigger.
>H?                ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF <0> W 2
H4=
H5=
H6=
>BTH3              ;Execute a Breakpoint Trace with H3.
THE TRACE STOPS AT STEP 0015
>LO 0 FFFF W
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
  0008          0300  55   W      11111000
  0014          0200  FF   W      11111111
>
```

**Example:** Set the break condition for H1 at address 0H, then execute a trace again using the BT command.

```
>J0 ;Reset the IP to 0000H.
>H1 0 ;Set H1 to address 0000H.
>BTH3
THE TRACE STOPS AT STEP 0000
PROGRAM BROKE AT BREAKPOINT-1 ;Tracing is stopped by H1.
>
```

### 3.1.2 Delay Trigger Trace (with H4)

The address, data and qualifier of specific program activity can be defined along with a **delay** in the H4 breakpoint. When the Delay Trigger is enabled, it is added as a logical OR to the breakpoint parameters defined in the B/F commands. When enabled and then defined in the BT command, it can be used alone or in any legal combination with other breakpoints. (Also refer the example in section 3.1.3.)

**Example:** Set the break conditions for H4 at address 200H, data FFH, Write cycle and with a delay of 5 machine cycles; then execute tracing using the BT command.

```
>J0 ;Reset the PC to 0000H.
>H0 ;Clear H1-H6 settings.
>H4 200 FF W 5 ;H4 set address for 200, data FFH,
; write status with delay 5 cycles.
>H? ;Display H1-H6 settings.
H1=
H2=
H3=
```

H4= 200 FF W 5

H5=

H6=

>BTH4 ;Execute trace.

THE TRACE STOPS AT STEP 0019

>L ;List all traced data.

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)	
0000		0000	00	?	10111110	
0001	0001	0001	00	S	11110000	
0002	0002	0002	21	S	11110010	
0003		0003	00	R	11110000	
0004		0004	03	R	11110100	
0005	0005	0005	3E	S	11110110	
0006		0006	55	R	11111000	
0007	0007	0007	77	S	11111110	
0008		0300	55	W	11111000	
0009	0008	0008	DB	S	11111101	
000A		0009	00	R	11110000	
000B		5500	FF	I	11111111	
000C	000A	000A	00	S	11110000	
000D	000B	000B	D3	S	11111101	
000E		000C	00	R	11110000	
000F		FF00	FF	O	11111111	
0010	000D	000D	11	S	11110000	
0011		000E	00	R	11110000	
0012		000F	02	R	11110100	
0013	0010	0010	12	S	11110100	
0014		0200	FF	W	11111111	;H4 setting matched.
0015	0011	0011	13	S	11110100-	
0016	0012	0012	3C	S	11110010	
0017	0013	0013	FE	S	11111111	>;Trace delayed for 5
0018		0014	0F	R	11110100	; cycles then stopped.
0019	0015	0015	20	S	11110010-	

>

### 3.1.3 Breakpoint Interval Timer

A timer is also supported for trigger trace mode which displays the interval from the initial trigger until emulation stops. (The interval will only display when an Armed breakpoint is encountered.) The timer can run for up to 35.39 minutes before the counter is reset. Note that resolution for the interval is down to microseconds. Time interval message syntax is as follows:

INITIAL TRIGGER TO BREAKPOINT INTERVAL-- aa:bb:ccc:ddd

where: **aa** = minute  
**bb** = second  
**ccc** = millisecond  
**ddd** = microsecond

**Example:** Display the execution interval for an Armed Trigger Trace. (Refer to section 3.2 for a description of the Arm Trigger.)

```
>J0 ;Reset the PC to 0000H.
>H3 XXXX FF 0
>H? ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF 0
H4= 200 FF W 5
H5=
H6=
>BTH3 H4 ;Execute BT command with H3, H4.
THE TRACE STOPS AT STEP 0019
INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:005
```

>L

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0000		B7D7	7E	?	10111110
0001	0001	0001	00	S	11110000
0002	0002	0002	21	S	11110010
0003		0003	00	R	11110000
0004		0004	03	R	11110100
0005	0005	0005	3E	S	11110110
0006		0006	55	R	11111000
0007	0007	0007	77	S	11111110
0008		0300	55	W	11111000
0009	0008	0008	DB	S	11111101
000A		0009	00	R	11110000
000B		5500	FF	I	11111111
000C	000A	000A	00	S	11110000
000D	000B	000B	D3	S	11111101
000E		000C	00	R	11110000
000F		FF00	FF	O	11111111 ;H3 matched.
0010	000D	000D	11	S	11110000
0011		000E	00	R	11110000
0012		000F	02	R	11110100
0013	0010	0010	12	S	11110100
0014		0200	FF	W	11111111 ;H4 setting matched.
0015	0011	0011	13	S	11110100-
0016	0012	0012	3C	S	11110010
0017	0013	0013	FE	S	11111111  >; Emulation stops
0018		0014	0F	R	11110100   ; after 5 cycles.
0019	0015	0015	20	S	11110010-

>



### 3.2 Armed Trigger Trace - BT

---

BT A[ B[ C[ D]]]

---

A[ B[ C[ D]]] Breakpoints A-D (which represent any of H3-6) can be logically joined in any Armed Trigger sequence. (The only exception being that they cannot be repeated).

There are up to 64 different Armed Trigger combinations. Sequential tracing is executed as follows -

if trigger A is matched, then trigger B is enabled;  
if trigger B is matched, then trigger C is enabled;  
and so on until the final breakpoint is matched.

**Example 1:** Execute a trigger trace using the single breakpoint of H5 set at (X1=1,X0=0).

```

>J0                ;Reset the PC to 0000H.
>H5 10            ;Break condition for X0=0, X1=1.
>H?              ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF 0
H4= 200 FF W 5
H5= 10
H6=
>BTH5            ;Execute trace.
THE TRACE STOPS AT STEP 000B
>L              ;List all trace data.
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0000      0000 0000 00 ? 10111111
0001 0001 0001 00 S 11111111
0002 0002 0002 21 S 11111111
0003      0003 0003 00 R 11111111
0004      0004 0004 03 R 11111111
0005 0005 0005 3E S 11111111
0006      0006 0006 55 R 11111111
0007 0007 0007 77 S 11111111
0008      0300 0008 55 W 11111111
0009 0008 0008 DB S 11111111
000A      0009 0009 00 R 11111111
000B      5500 000B FF I 11111111 ;H5 matched.
>

```

**Example 2:** Execute an armed trigger trace with a single sequence of H5-->H6.

```

>J0                               ;Reset the PC to 0000H.
>H?                               ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF 0
H4= 200 FF W 5
H5= 10                            ;Break condition for X0=0, X1=1.
H6= 01                            ;Break condition for X2=1, X3=0.
>BTH5 H6
THE TRACE STOPS AT STEP 000F
INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:002
>L                               ;List all traced data.
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0000          0000 00   ?   11111111
0001    0001  0001  00   S   11111111
0002    0002  0002  21   S   11111111
0003          0003  00   R   11111111
0004          0004  03   R   11111111
0005    0005  0005  3E   S   11111111
0006          0006  55   R   11111111
0007    0007  0007  77   S   11111111
0008          0300  55   W   11111111
0009    0008  0008  DB   S   11111111 ;H5 matched.
000A          0009  00   R   11111111
000B          5500  FF   I   11111111
000C    000A  000A  00   S   11111111
000D    000B  000B  D3   S   11111111
000E          000C  00   R   11111111
000F          FF00  FF   0   11111111 ;H6 matched.
>

```

**Example 3:** Execute an armed trigger trace using a sequence of twc triggers and a final breakpoint, i.e. H6-->H5-->H3.

```

>J0                ;Reset the PC to 0000H.
>H6 01            ;Break condition for X2=1, X3=0.
>H?              ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF 0
H4= 200 FF W 5
H5= 10
H6= 01
>BTH6 H5 H3      ;Execute the logical trace H6->H5->H3.
THE TRACE STOPS AT STEP 0010
INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:003
>L
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0000                0000 00 ? 10111110
0001 0001 0001 00 S 11110000
0002 0002 0002 21 S 11110010
0003                0003 00 R 11110000
0004                0004 03 R 11110100
0005 0005 0005 3E S 11110110
0006                0006 55 R 11111000
0007 0007 0007 77 S 11111110
0008                0300 55 W 11111000 ;H6 matched.
0009 0008 0008 DB S 11111101
000A                0009 00 R 11110000
000B                5500 FF I 11111111 ;H5 matched.
000C 000A 000A 00 S 11110000
000D 000B 000B D3 S 11111101
000E                000C 00 R 11110000
000F                FF00 FF O 11111111 ;H3 matched.
0010 000D 000D 11 S 11110000
>

```

**Example 4:** Execute an armed trigger trace using a sequence of three triggers and a final breakpoint, i.e. H5-->H6-->H3-->H4.

```

>J0                               ;Reset the PC to 0000H.
>H5 10                             ;Break condition for X0=0, X1=1.
>H?                                 ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF 0
H4= 200 FF W 5
H5= 10
H6= 01
>BTH5 H6 H3 H4                     ;Execute the logical trace.
THE TRACE STOPS AT STEP 001A
INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:013
>LO 0 FFFF I O W                   ;List all INPUT/OUTPUT/WRITE cycles.
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0008          0300 55 W 11111000
000B          5500 FF I 11111111
000F          FF00 FF O 11111111
0014          0200 FF W 11111111

```

### 3.3 AND Trigger Trace - BT

---

BT(A B C)[ D ]  
BT(A B)[ C[ D ]]

---

(A B C)[ D] The AND trigger (breakpoints A, B and C) can be used as a single breakpoint construct, or can serve as a trigger construct for breakpoint D.

(A B)[C [D]] The AND trigger (breakpoints A and B) can be used as a single breakpoint construct, or can serve as a trigger construct for breakpoint C or for the armed trigger construct of C-->D.

Breakpoints A-D can be combined in a two or three level AND construct. Armed breakpoints can also be specified following the AND trigger. There are up to 38 different AND trigger combinations. Note that parantheses "( )" must be used in the syntax when inputting an AND trigger construct.

**Example 1:** Run a trace with an AND trigger used as a single breakpoint construct with H4, H5 and H6. (Note that breakpoints specified in an AND construct can be matched in any order.)

```

>J0                ;Reset the PC to 0000H.
>H0                ;Clear H1-H6 settings.
>H3 XXXX FF <0> W 2
>H4 200 FF W 5
>H5 10
>H6 01
>H?                ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF <0> W 2
H4= 200 FF W 5
H5= 10
H6= 01
>BT(H5 H6 H4)     ;Trace with AND trigger.
THE TRACE STOPS AT STEP 001B
>L                ;List all traced data.

```

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0000		0000	00	?	10111110
0001	0001	0001	00	S	11110000
0002	0002	0002	21	S	11110010
0003		0003	00	R	11110000
0004		0004	03	R	11110100
0005	0005	0005	3E	S	11110110
0006		0006	55	R	11111000
0007	0007	0007	77	S	11111110
0008		0300	55	W	11111000
0009	0008	0008	DB	S	11111101 ;H5 matched.
000A		0009	00	R	11110000
000B		5500	FF	I	11111111
000C	000A	000A	00	S	11110000

000D	000B	000B	D3	S	11111101	
000E		000C	00	R	11110000	
000F		FF00	FF	O	11111111	
0010	000D	000D	11	S	11110000	
0011		000E	00	R	11110000	
0012		000F	02	R	11110100	
0013	0010	0010	12	S	11110100	;H6 matched.
0014		0200	FF	W	11111111	
0015	0011	0011	13	S	11110100	
0016	0012	0012	3C	S	11110010	
0017	0013	0013	FE	S	11111111	
0018		0014	0F	R	11110100	
0019	0015	0015	20	S	11110010	
001A		0016	F9	R	11111111	;H4 matched.*
001B	0010	0010	12	S	11111111	

>

\* H5, H6 and H4 all matched; breakpoint H4 stops emulation at the next cycle.



**Example 2:** Perform a trace using an AND construct as the trigger for an armed breakpoint.

```

>J0                ;Reseta the PC to 0000H.
>H?                ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF <0> W 2
H4= 200 FF W 5
H5= 10
H6= 01
>BT(H4 H5 H6) H3   ;Execute the logical trace.
THE TRACE STOPS AT STEP 0025
INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:022
>L0 0 FFFF I O W   ;List all INPUT/OUTPUT/WRITE cycles
                    ; between 0H-FFFFH, start at frame 0.

FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0008          0300 55 W 11111000
000B          5500 FF I 11111111
000F          FF00 FF O 11111111
0014          0200 FF W 11111111
001C          0201 00 W 11110000
0024          0202 01 W 11110000
>

```

**Example 3:** Run a trace with an AND trigg and an armed breakpoint sequence.

```

>J0                ;Reset the PC to 0000H.
>H?                ;Display H1-H6 settings.
H1=
H2=
H3= XXXX FF <0> W 2
H4= 200 FF W 5
H5= 10
H6= 01
>BT(H6 H5) H4 H3   ;Execute an AND trigger and H4→H3
                   ; as an armed breakpoint.

THE TRACE STOPS AT STEP 0025
INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:021
>LO 0 FFFF I O W   ;List all INPUT/OUTPUT/WRITE cycles
                   ; between 0H-FFFFH, start frame 0.

FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0008      0300  55    W    11111000
000B      5500  FF    I    11111111
000F      FF00  FF    O    11111111
0014      0200  FF    W    11111111 ;H4, H3 matched.
001C      0201  00    W    11110000
0024      0202  01    W    11110000
>

```

### 3.4 OR Trigger Trace - BT

---

BT<A B C>  
BT<A B>[ C[ D]]

---

<A B C>            The OR trigger (breakpoints A, B or C) can be used as a single breakpoint construct.

<A B>[C [D]]      The OR trigger (breakpoints A or B) can be used a single breakpoint construct, or can serve as a trigger for breakpoint C or for the armed trigger construct C-->D.

Breakpoints A-D can be combined in a two or three level OR construct. Armed breakpoints can also be specified after the OR trigger. If an armed trigger is used with the OR construct, the ORed pairs must be either data (H3,H4) or external breakpoints (H5,H6). There are up to 18 different OR trigger combinations. Note that angular brackets "< >" must be used in the syntax when inputting an OR trigger construct.

**Example 1:** Execute a trace using a two level OR construct.

```
>J0                                    ;Reset the PC to 0000H.  
>H?                                    ;Display H1-H6 settings.  
H1=  
H2=  
H3= XXXX FF <0> W 2  
H4= 200 FF W 5  
H5= 10  
H6= 01
```

>BT<H4 H5> ;Execute a trace with data breakpoint pair.  
THE TRACE STOPS AT STEP 000B

>L ;List all traced data.

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0000		0000	00	?	10111110
0001	0001	0001	00	S	11110000
0002	0002	0002	21	S	11110010
0003		0003	00	R	11110000
0004		0004	03	R	11110100
0005	0005	0005	3E	S	11110110
0006		0006	55	R	11111000
0007	0007	0007	77	S	11111110
0008		0300	55	W	11111000
0009	0008	0008	DB	S	11111101
000A		0009	00	R	11111111 ;H5 matched.
000B		5500	FF	I	11111111

>

**Example 2:** Execute a trace using an OR construct as the trigger for an armed breakpoint.

>J0 ;Reset the PC to 0000H.

>H3 XXXX FF <0> W

>H? ;Display H1-H6 settings.

H1=

H2=

H3= XXXX FF <0> W

H4= 200 FF W 5

H5= 10

H6= 01

>BT<H5 H6> H3 ;Execute the trace.

THE TRACE STOPS AT STEP 001D

INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:009

```

>L                                     ;list all trace data.
FRAME IFADDR ADDRESS DATA STATUS SPARE(8 BITS)
0000          0000 00 ? 10111110
0001 0001 0001 00 S 11110000
0002 0002 0002 21 S 11110010
0003          0003 00 R 11110000
0004          0004 03 R 11110100
0005 0005 0005 3E S 11110110
0006          0006 55 R 11111000
0007 0007 0007 77 S 11111110
0008          0300 55 W 11111000
0009 0008 0008 DB S 11111101
000A          0009 00 R 11110000
000B          5500 FF I 11111111 ;H5 matched.
000C 000A 000A 00 S 11110000
000D 000B 000B D3 S 11111101
000E          000C 00 R 11110000
000F          FF00 FF O 11111111
0010 000D 000D 11 S 11110000
0011          000E 00 R 11110000
0012          000F 02 R 11110100
0013 0010 0010 12 S 11110100
0014          0200 FF W 11111111 ;H3 matched.
0015 0011 0011 13 S 11110100

```

>

**Example 3:** Run a trace using an OR trigger and an armed breakpoint sequence.

```

>J0                               ;Reset the PC to 0000H.
>H5 10                             ;Break condition or X0=0, X1=1.
>H3 XXXX FF <0> W
>H?
H1=
H2=
H3= XXXX FF <0> W
H4= 200 FF W 5
H5= 10
H6= 01
>BT<H3 H4> H5 H6                 ;Execute an OR trigger and an armed
                                   ; breakpoint of H5->H6.

```

THE TRACE STOPS AT STEP 000F

INITIAL TRIGGER TO BREAKPOINT INTERVAL--00:00:000:003

```
>LO 0 FFFF I O W
```

FRAME	IFADDR	ADDRESS	DATA	STATUS	SPARE(8 BITS)
0008		0300	55	W	11111000 ;H3 matched.
000B		5500	FF	I	11111111
000F		FF00	FF	O	11111111

```
>
```

## SECTION 4

### SYNC SIGNAL OUTPUT

#### 4.1 External Hardware Trigger Output - BS

---

BS 1|2[addx[ data[ <dbwc>][ qualifier]]]

---

- BS** is the command for External Hardware Trigger Output.
- 1** specifies a positive signal pulse of 140~180ns. (Executing BS1 clears H3 because the same hardware circuit is used to support both of these breakpoints.)
- 2** specifies a positive signal pulse that lasts for the duration of the trigger condition. (Executing BS2 clears H4 because the same hardware circuit is used to support both of these breakpoints.)
- addx** is the trigger address that causes output of a sync signal. This can be an up to four digit hex address with an optional byte pair of "XX". (The maximum address length depends on the address range of the current emulation processor.)
- data** is an up to 2 digit hex data to be matched with the trigger address.

<dbwc> is an up to 2 digit hex setting indicating a "data bit wildcard". To enter any <dbwc>, a data value must first be defined. The data bit wildcard is interpreted as 8 binary data bits, where "0" indicates "don't care". The default value for the dbwc is FFH.

qualifier is a single or double alphabetic character indicating the type of processor activity to be matched with the trigger address. For a complete listing of the qualifiers applicable for a particular processor, refer to the appendices in the NEW MICE-II User's Manual.

The BS command can be used to trigger a sync signal to an external device (e.g. oscilloscope or logic analyzer). Connection is made on the BPP board at BSYNC1 (J3-1) or BSYNC2 (J3-2).


When the specified parameters are matched, a sync signal is transmitted. If no other breakpoints are specified before the BS command, emulation will continue after the trigger condition is met. To stop emulation before execution has been completed, input a Halt command.



## 4.2 Output Signal Timing


---

### 1) BSYNC 1 Output Timing



When the BS1 setting is matched, the BPP will issue a positive signal pulse as indicated in the figure above. The pulse width of  $t_0 = 140\sim 180\text{ns}$ .

### 2) BSYNC 2 Output Timing



When the BS2 setting is matched, the BPP will issue a positive signal pulse as indicated in the figure above. The pulse width of  $t_1$  is determined by the following conditions:

a) No "wait state" inserted


Pulse width of  $t_1$  = duration the trigger condition is matched on the bus (which depends on bus timing for the particular target system).

b) "Wait state" inserted


Pulse width of  $t_1$  = duration the trigger condition is valid on the bus, plus timing for wait state.

APPENDIX A

BPP BLOCK DIAGRAM



APPENDIX B  
BPP PLACEMENT CHART



## APPENDIX C

### TIMING FOR BREAK OPERATION (H1-H6)

---

#### C.1 Emulation Status

NEW MICE-II performs emulation in two different ways, depending on the type of processor.

##### 1) Hold State

The emulation processor bus is at high impedance whenever it stops. In this state all signals on the bus are floating and cannot be tested. Hold state is used in NEW MICE-II Z80.

##### 2) Wait State

The emulation processor bus is in wait state whenever it stops. In this state all signals on the bus are stable and can be tested with a logic probe or oscilloscope. Wait state is used in NEW MICE-II NSC800. In wait state, the bus indicates the current address for the NSC800.

### 3) Run State

Whenever user's program execution is stopped, the emulation processor is in free-run state, executing "JR \$" instructions. In this state the signals at the Input/Output pins are stable and can be tested, but the signals on the Address/Data bus are changing dynamically and cannot be tested. Run state is used for NEW MICE-II Z8 and ZS8.

The type of emulation performed determines timing for breakpoint operation. The following sections describe break operation for H1-H6. (The examples for hold state are based on the Z80, examples for wait state are based on the NSC800 and those for run state are based on the Z8.)

## C.2 Timing For Breakpoints H1/H2

### 1) Hold State

Emulation stops at the end of the bus cycle\* in which the break condition is matched; the bus cycle is completed.

\*bus cycle: complete operation of bus activity such as read/write data from/to memory, or input/output data from/to I/O port.

Now input a Cycle Step command to display the address of the next cycle (i.e. PC+1H for 8-bit systems, assuming no branch instruction is executed). Entering an Register command instead of the C command at this time may show that the PC does not equal PC+1H, though. If the current instruction has not yet been completed, the R command will finish it. Therefore, the PC displayed in the R command always points to the starting address of next unexecuted instruction; as illustrated by the program segment below.

ADDRESS	DATA	STATUS	SOURCE CODE
:	:	:	:
0008	00	S	NOP
0009	00	S	NOP ;*
000A	210003	S	LD HL,0300
000D		S	NOP
:	:	:	:

\* The break condition (H1 or H2) is matched and emulation stops.

In this example, the break condition is matched and emulation stops at the end of the current bus cycle (address 0009H). The C command displays address 000AH, but an R command displays 000DH instead. Because the first byte (21H) of the instruction (LD HL,0300) was already fetched when emulation stopped, entering an R command completes execution of this instruction and displays PC=000DH. (See figure C-1, section C.5.)



## 2) Wait State

Emulation stops at stable bus state, before the current cycle has been completed. (The bus can be tested with a oscilloscope or logic probe at this time.) Entering a C command displays the current cycle address; but inputting an R command instead will display a different address if the status of the break cycle is other than S (instruction fetch). This is illustrated in the following program segment.

ADDRESS	DATA	STATUS	SOURCE CODE
:	:	:	:
0008	00	S	NOP
0009	00	S	NOP
000A	21	S	LD HL,0300 ;Break condition 1
000B	00	R	;Break condition 2
000C	03	R	
000D	00	S	NOP
:	:	:	:

Note that no branch instruction is executed in the preceding example. In break condition 1, emulation is stopped at an instruction fetch cycle. Entering a C displays address 000AH. In break condition 2, however, emulation is stopped at a cycle where bus status is other than instruction fetch. Entering a C command displays 000BH; but inputting an R command finishes the instruction and displays PC=000DH. (See figure C-2 under section C.5.)

### 3) Run State

When the break condition is matched, emulation stops at the end of the current instruction. Entering a C command will execute the next instruction and then display the current status. However, entering an R command will display the current status without causing any instructions to be executed. This is illustrated in the following example.

ADDRESS	DATA	STATUS	SOURCE CODE
:	:	:	:
0000	FF	S	NOP
0001	FF	S	NOP
0002	561D41	S	AND 1D,#41 ;*
0003	1D	R	;
0004	41	R	;
0005	8C	S	LD R08,#44 ;*
0006	44	R	
0007	FF	S	NOP
:	:	:	:

\* The specified break condition (H1 or H2) may be matched at any cycle of this instruction.

Entering a C command will execute the next instruction at address 0005H-0006H and then display the current status; but entering the R command instead will simply display the current status, where the PC=0005H. (See figure C-3, section C.5.)

### C.3 Timing For Breakpoints H3/H4

The comparison operation for data breakpoints takes too long for emulation to be stopped at the current cycle. Also note that executing the C or R command after emulation has been stopped by H3 or H4 produces the same results as described above for H1/H2.

#### 1) Hold State

When the break condition is matched, emulation stops at the end of the next bus cycle. (See figure C-1, section C.5.)

#### 2) Wait State

When the break condition is matched, emulation stops at stable bus state for the next cycle. (See figure C-2, section C.5.)

#### 3) Run State

When the break condition is matched, emulation is stopped at the end of the current instruction. However, if it is matched at the last cycle of an instruction; emulation will be stopped at the end of the next instruction. (See figure C-4, section C.5.)

## C.4 Timing For Breakpoints H5/H6

### 1) Hold State

When H5 or H6 is matched, a signal is immediately (appx. 100ns) generated by MICE to stop emulation. Therefore, if the trigger occurs "early enough" in a bus cycle (e.g. before the last state of any M for Z80), emulation will stop at the end of the current cycle (same as H1/H2); but if the trigger occurs "too late" (e.g. after T2 for Z80), then emulation will be stopped at the end of the next cycle (same as H3/H4).

### 2) Wait State

When H5 or H6 is matched, a signal is immediately (appx. 100ns) generated by MICE to stop emulation at stable bus state. Therefore, if the trigger occurs "early enough" in a bus cycle (e.g. before T2 for NSC800), emulation will stop at valid state for the current cycle; but if the trigger occurs "too late" (e.g. after T2 for NSC800), then emulation will stop at valid state for the next cycle.

### 3) Run State

When H5 or H6 is matched, a signal is immediately (appx. 100ns) generated by MICE to stop emulation. Therefore, if the trigger occurs "early enough" (i.e. anywhere before the rising edge of  $\overline{DS}$  or  $\overline{MDS}$ \* for Z8/ZS8, during the last cycle of an instruction), emulation will be stopped at the end of the current instruction; but if the trigger occurs "too late" (i.e. after the rising edge of  $\overline{DS}$  or  $\overline{MDS}$  for Z8/ZS8, during the last cycle of an instruction), then emulation will be stopped at the end of the next instruction.

\*  $\overline{MDS}$  indicates internal program memory data strobe. This signal is output from the emulation CPU.

The break position for the emulation states described above is determined by the timing of H5/H6 and by the specific point in cycle execution that can be defined as "early enough" or "too late" (which depends on the type of emulation processor used, refer to section C.6).

## C.5 Timing Diagrams For Break Operation

The following diagrams show the timing of break condition match and emulation halt during bus cycle execution.

### 1) Hold State




Figure C-1 Hold State Timing Diagram

**S** is fetch state. (No I/O or R/W operation, or branch instruction is assumed in this example.)

**PC** is the program counter. (The increment per bus cycle is  $PC=PC+1$  for 8-bit microprocessors.)

**stable state** is a full bus cycle.

**transition state** is the end of a bus cycle and the start of the next one.

## 2) Wait State

There are 4 bus cycles illustrated in the following diagram. (Note that this diagram is applicable for the Wait State example under section C.2.)




Figure C-2 Wait State Timing Diagram

- S is an opcode fetch cycle (i.e. the 1st byte of an instruction; no branch instruction is assumed in this example).
- R is a memory read cycle or the subsequent byte read for an instruction.
- W is a memory write cycle.

PC is the program counter. (The increment per bus cycle is  $PC=PC+1$ ; the PC is 0008H in this example.)

stable state is a full bus cycle.

transition state is end of a bus cycle and start of the next one.

### 3) Run State

#### a) H1/H2





Figure C-3 Run State Timing Diagram for H1/H2



b) H3/H4



**Figure C-4 Run State Timing Diagram for H3/H4**

If execution is stopped by H3/H4, then the program counter will equal the halt address plus one instruction. However, if the halt address is at the last cycle of an instruction, the program counter will equal the halt address plus two instructions.

**S** is an opcode fetch cycle (i.e. 1st byte of an instruction; no branch instruction is assumed in this example).

**R** is a memory read cycle for an instruction.

**PC** is the program counter. (The increment per bus cycle is  $PC=PC+1$ .)


**stable state** is a full bus cycle.

**transition state** is end of a bus cycle and start of the next one.


## C.6 Breakpoint Timing (H5/H6) for Respective NEW MICE-II

NEW MICE-II	Break Match Timing	Stop CPU Setup Time	Emulation Processor	
	Minimum Value (tBMS)	Minimum Value		MHz
NSC800	202ns + tWS	LWS = 50ns	NSC800	5
		100ns	NSC800-1	2
		35ns	NSC800-4	8
Z80 WAIT Mode	249.8ns + Tsw	Tsw = 70ns	Z80	2.5
		70ns	Z80A	4
		60ns	Z80B	6
		50ns	Z80H	8
Z80 BUSAK Mode	209.2ns + Tsb	Tsb = 80ns	Z80	2.5
		50ns	Z80A	4
		50ns	Z80B	6
		40ns	Z80H	8
Z8	237ns		Z8612	12
ZS8	220ns		Z8884	20


### 1) NSC800




## 2) Z80 $\overline{\text{WAIT}}$ Mode



## 3) Z80 $\overline{\text{BUSAK}}$ Mode



#### 4) Z8 & ZS8



Note: Emulation will stop at the end of the current instruction, where  $\overline{STOP}$  means that the CPU will be executing "JR \$" instructions.

---

**SUEM**

*Section*

**SUEM SECTION**

**First Edition  
March 1988**

**Microtek International, Inc.  
No. 6, Industry East Road 3  
Science-based Industrial Park  
Hsinchu, Taiwan 30077, R.O.C.  
Tel: (035) 772155  
Tlx: 32169 MICROTEK  
Fax: (035) 772598**

© 1988 MICROTEK INTERNATIONAL INC. All rights reserved.

This manual is subject to change without notice. Nothing herein shall be construed as a recommendation to use any product in violation of existing patents or other rights of third parties.

SUEM AND THIS USER'S GUIDE ARE COVERED BY THE LIMITED WARRANTY SUPPLIED WITH SUEM AND REPRODUCED IN APPENDIX A OF THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS MANUAL IS ALSO COVERED BY THE LICENSE AGREEMENT SUPPLIED FOR UNIVERSAL SYMBOLIC DEBUGGER (USD). USD MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF THE LICENSE AGREEMENT.

Printed in Taiwan, ROC. March 1988



## C O N T E N T S

1.0	INTRODUCTION .....	1-1
2.0	SPECIFICATION .....	2-1
2.1	Description .....	2-1
2.2	Memory Size .....	2-1
2.3	Mapping Resolution .....	2-1
2.4	Non-Volatile Storage .....	2-1
2.5	Indications .....	2-1
2.5.1	Run Light .....	2-1
2.5.2	Power Light .....	2-2
2.6	Access Violation .....	2-2
2.7	Violation Access Settings .....	2-2
3.0	SWITCH SETTINGS .....	3-1
3.1	Description .....	3-1
3.2	Installation .....	3-2
4.0	COMMAND REFERENCE .....	4-1
4.1	Help Command - *? .....	4-1
4.2	Diagnostic Tests Command - *D .....	4-2
4.3	High Speed Download Command - *LOAD ...	4-3
4.4	Memory Map Control - *MAP .....	4-4
4.5	Mapping Resolution Control - *RANGE ...	4-5
4.6	Recall Memory Map .....	4-9
4.7	Save Memory Map .....	4-10
5.0	APPLICATION NOTES .....	5-1
5.1	Binary Download .....	5-1
5.2	Limitation of SUEM Firmware V1.1/V1.0 .	5-1

## APPENDICES

A	LIMITED WARRANTY; SERVICE .....	A-1
B	PROVIDING THE VIOLATION ACCESS BREAK ..	B-1

## 1.0 INTRODUCTION

This document provides reference information on the operation of the SUEM.

The user of this document is assumed to be reasonably familiar with the NEW MICE-II emulator family.

## 2.0 SPECIFICATION

### 2.1 DESCRIPTION

The SUEM is a high performance, soft mapped emulation memory board, that replaces an HUEM in all NEW MICE-II/S units.

### 2.2 MEMORY SIZE

256 Kbytes

### 2.3 MAPPING RESOLUTION

Three modes:

- 1) 128 byte resolution (address range 0 to 128K)  
(64K code, 64K data for microcontrollers)
- 2) 1 Kbyte resolution (address range 0 to 1M)
- 3) 8 Kbyte resolution (address range 0 to 16M)

### 2.4 NON-VOLATILE STORAGE

The memory map settings can be stored in EEPROM. This setup is automatically recalled on power up.

### 2.5 INDICATIONS

The SUEM provides two LED indicators

#### 2.5.1 Run Light

This shows whether the emulation processor is in a run state.

## 2.5.2 Power Light

This shows that 5 Volt supply is applied.

## 2.6 ACCESS VIOLATION

Outputs provided for address violation are:

- \* Internal (emulation memory) write access
- \* External (target memory) write access
- \* Guard memory (non-existent) access

## 2.7 VIOLATION ACCESS SETTINGS

The Violation Access Signals generated from SUEM are located at J3 (3-pin connector).

### J3 Pin Definition

Pin 1 (J3-1)	Guard access violation
Pin 2 (J3-2)	Write protect violation
Pin 3 (J3-3)	Either guard access or write protect violation

The signals are active at high level.

To enable the violation to break the program execution, J3-1 and J3-2 should be wired (using jumper wires or others) to CEP spare bits X0 and X2 respectively. Then use BPP command to set the break conditions H5, H6.

Application notice for violation access break see appendix B.

### 3.0 SWITCH SETTINGS

#### 3.1 DESCRIPTION:

SW1, an 8-way DIP switch, is located at the front of the SUEM and is accessible when the cover of the NEW MICE-II is removed. This switch configures the host interface (between host and MICE) and the inter board (between CEP and SUEM).

host baud rate	S1	S2	S3
150	on	off	off
300	off	on	off
600	on	on	off
1200	off	off	on
2400	on	off	on
4800	off	on	on
9600	on	on	on
19200	off	off	off

host mode	S4	S5	S6
8 data bits	off		
7 data bits	on		
parity enable		off	
parity disable		on	
even parity			off
odd parity			on

	SUEM DIP Switch			CEP DIP Switch					
	S7	S8	S1	S2	S3	S4	S5	S6	
inter comms*	n/u**	on	on	on	on	off	on	n/u**	
9600	n/u	off	off	off	off	off	on	n/u	
19200									

\* Note that inter communication mode is 8 data bits, no parity.  
 On CEP, the DIP switch should be set to 19200 (or 9600) bauds,  
 no parity and 8 data bits.

\*\* not used

### 3.2 INSTALLATION

#### NOTE

This section is applicable only when replacing an HUEM with SUEM in MICE-II

- a) Remove the existing HUEM board from NEW MICE-II and replace with the SUEM board.
- b) Reconnect the two 50-pin connectors to SUEM.
- c) Remove the Interface (DTE/DCE converter) header from the CEP board. Plug-in the CSCB (CEP SUEM Communication Board) cable header into the just vacated header socket.

## 4.0 COMMAND REFERENCE

### 4.1 HELP COMMAND

---

\*?

---

\*? is the command for SUEM help.

This command provides the user with a command summary together with a syntax guide.

#### EXAMPLE:

>\*?

SUEM V#.#  
-----

DIAGNOSTIC TESTS	*D	
HIGH SPEED DOWNLOAD	*L[OAD]	
MEMORY MAP CONTROL	*M[AP]	[ADDR1 ADDR2 I IR E ER G ][E D]
MAPPING RESOLUTION	*R[ANGE]	[0 1 2]
RECALL MAP	*RE[CALL]	
SAVE MAP	*S[AVE]	
HELP	*?	

>

## 4.2 DIAGNOSTIC TESTS COMMAND

---

**\*D**

---

\*D is the command for SUEM diagnosis. Issuing this command will test emulation memory as well as SUEM hardware circuits. Results are shown when diagnostic testing is completed.

After diagnostic testing, the original map settings, map resolution and contents in emulation memory are destroyed.

### EXAMPLE:

```
>*D
Diagnostics: testing U12 & U26
Diagnostics: testing U13 & U27
Diagnostics: testing U14 & U28
Diagnostics: testing U15 & U29
Diagnostics: 256K ram installed
>
```



### 4.3 HIGH SPEED DOWNLOAD COMMAND

---

#### \*LOAD

---

\*LOAD is the command for high speed download.

After entering this command, the SUEM will accept an hex file sent via the serial port. An end of file record or an escape will terminate this mode and return the MICE prompt.

#### EXAMPLE:

>\*LOAD <CR>

#### NOTE

The \*LOAD command does not use the ACK/NAK protocol, but it does support hardware or software handshaking for flow control. The MICE CEP must have the ETX handshaking code installed in the firmware for this command to function.

#### 4.4 MEMORY MAP CONTROL

---

**\*M[AP]**

**\*M[AP]** start-address end-address memory-attrib

**\*M[AP]** global-controls

---

This command has several options, allowing the memory map to be set, displayed or modified.

**\*M[AP]** is the command for memory map control. If no other parameters specified, inputting "MAP<CR>" displays the current memory map setting.

**start-address** is a hexadecimal address indicating the start of a boundary as defined by the current mapping range setting. (also refer to the \*RANGE command).

**end-address** is a hexadecimal address indicating the end of a boundary as defined by the current mapping range setting. (also refer to the \*RANGE command).

**memory-attrib** can be one of the following:

I - internal (emulation) memory with read/write access

IR - internal (emulation) memory with read only access

- E - external (target) memory with read/write access
- ER - external (target) memory with read only access
- G - guarded access

global-controls can be one of the following:

- E - enable map settings

The current memory map settings will be used by the emulator..

- D - disable map settings

The memory map settings are ignored and the emulator will use target system memory. The previously set memory map can be re-enabled by typing \*MAP E.

**EXAMPLE:**

```
>*MAP
Range: 0 to 16Mb with 8k resolution

000000 to FFFFFFFF      guarded          ( G)

>*MAP 0 1FFF I
>*MAP
Range: 0 to 16Mb with 8k resolution

000000 to 001FFF      internal read/write ( I)
002000 to FFFFFFFF      guarded          ( G)
```

```

>*MAP 100000 165FFF ER
>*MAP
Range: 0 to 16Mb with 8k resolution

000000 to 001FFF      internal read/write ( I)
002000 to 0FFFFFFF   guarded ( G)
100000 to 165FFF     external read only (ER)
166000 to FFFFFFFF   guarded ( G)

>*MAP D
Map: emulation memory globally disabled
>*MAP 0 1FFF E
Map: emulation memory globally disabled
>*MAP E
Map: emulation memory is enabled
>

>*MAP
Range: 0 to 16Mb with 8k resolution

000000 to 001FFF      internal read/write ( I)
002000 to 0FFFFFFF   guarded ( G)
100000 to 165FFF     external read only (ER)
166000 to FFFFFFFF   guarded ( G)

>

```

#### NOTE

The SUEM halts the emulation processor when modifying the memory map, but it does not halt the emulation processor when displaying the memory map. It is up to the user to take the appropriate action when using this command.

## 4.5 MAPPING RESOLUTION CONTROL

---

**\*R[ANGE]**

**\*R[ANGE] type**

---

This command allows the user to display or select three different types of mapping resolution.

**\*R[ANGE]** is the command for memory mapping resolution control. If no other parameters specified, inputting "**\*RANGE<CR>**" displays the current mapping resolution.

**type** may be one of the following:

- 0 - 128 byte resolution, in the range 0 to 128K (17-bit addressing). For processors with separate address space for code and data (8051, 80515, Z8, ZS8), the SUEM will use the 17th address line of the memory map to signify data memory. This gives us 0 to 64K for code and 0 to 64K for data (mapped from 64K to 128K). Processors having 16 address lines will only be able to access the first 64K of emulation memory.
- 1 - 1K resolution in the range 0 to 1M bytes (20-bit addressing).
- 2 - 8K resolution in the range 0 to 16M bytes (24-bit addressing).

The emulation processor will be halted after this command is executed.

**EXAMPLE:**

```
>*RANGE
Rang: 0 to 16Mb with 8k resolution
>*RANGE 1
Range: 0 to 1Mb with 1k resolution
>*RANGE 0
Range: 0 to 128K with 128 byte resolution
```

**NOTE**

When the mapping resolution is changed, all the memory is mapped GUARDED.

If the emulation processor's memory range is 0 to 16M byte (24-bit addressing) and the user want to get a smaller mapping resolution, user can set a lower type of mapping resolution (0 or 1) with \*RANGE command, but the memory will overlap.

**EXAMPLE:**

```
>*R 1
Range: 0 to 1Mb with 1k resolution
>*M 0 FFF I
>M FFO FFF AAAA
>M FFO FFF
      0000 0002 0004 0006 0008 000A 000C 000E      ASCII-CODE
000FF0 AAAA AAAA AAAA AAAA AAAA AAAA AAAA AAAA .....
>M 100FF0 100FFF
      0000 0002 0004 0006 0008 000A 000C 000E      ASCII-CODE
100FF0 AAAA AAAA AAAA AAAA AAAA AAAA AAAA AAAA .....
>
```

## 4.6 RECALL MEMORY MAP

---

### \*RECALL

---

This command allows the user to recall a previously saved memory map from the EEPROM. The current memory map will be destroyed.

#### EXAMPLE:

```
>*RECALL  
>
```

#### NOTE

The emulation processor will be halted after executing this command.

## 4.7 SAVE MEMORY MAP

---

### \*S[AVE]

---

SAVE is the command for saving memory map settings to EEPROM.

#### EXAMPLE:

```
>*SAVE  
.....  
>
```

#### NOTE

The \*SAVE command will take 20 seconds (worst case) to execute.



## 5.0 APPLICATION NOTES

### 5.1 BINARY DOWNLOAD

Applying an 8MHz IBM-PC/AT as the target, download speed under USD (software V2.3 and later versions) at 64K bytes record length is illustrated below.

Communication Protocol	19200 baud None parity 8 data bits 1 stop bit	19200 baud Even parity 7 data bits 1 stop bit
Transmission Format	Binary	Hex
Download Speed	51 seconds	2 min. 38 sec.

Note that while using binary transmission format, communication protocol should be set to none parity and 8 data bits.

### 5.2 LIMITATION OF SUEM FIRMWARE V1.0 AND V1.1

To get proper communication between SUEM and host, baud rate should not less than 2400.

## APPENDIX A

### LIMITED WARRANTY; Service

---

Microtek International Inc. (Microtek) warrants Super Universal Emulation Memory or SUEM (the Product) and the user's manual for the Product to be free from physical defects for a period of twelve (12) months from the date of the original retail purchase. This warranty applies only to the original retail purchaser who bought these Products from an authorized Microtek representative. This warranty is void if the Product is damaged by improper or abnormal use or by accident, if the Product is altered or modified in any way, or if any attempt is made to repair the Product without authorization from Microtek.

If you find a Product to be defective, contact your authorized Microtek representative or Microtek. When you receive authorization to do so, return the Product as directed; include proof of purchase and purchase date. Microtek will correct physical defects in Products under warranty at no charge to you by repairing or, at its option, replacing such Products. THIS IS THE SOLE AND EXCLUSIVE REMEDY AVAILABLE FOR BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY WITH RESPECT TO MICROTEK PRODUCTS. Product repairs not covered by warranty, and Product updates, are provided at a set rate.

ALL OTHER WARRANTIES AND REPRESENTATIONS, ORAL OR WRITTEN, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXCLUDED AND DO NOT AP-

PLY. Except as set forth in this limited warranty, the purchaser assumes the risk as to these Products' quality, accuracy, design, and performance.

It is solely the purchaser's responsibility to determine the suitability of these Products for each particular application. Microtek Products are in all events not suitable, and are not authorized, for use in connection with life support devices or systems, or in other devices or systems potentially injurious to life or health.

IN NO EVENT WILL MICROTEK BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY, even if advised of the possibility of such damages. Microtek is thus not liable for lost profits or goodwill; downtime; damage or destruction of any program, data, equipment, or other property; costs of recovering, reprogramming, or reproducing any program, data, or equipment; personal injury or loss; or any other damages.

Except as required by law, no representative, agent, or employee of Microtek is authorized to commit Microtek to warranties, representations, or obligations inconsistent with or in addition to those set forth in this limited warranty.


Please complete and return the registration section of the warranty card (provided in the packing box) to Microtek.

## APPENDIX B

### PROVIDING THE VIOLATION ACCESS BREAK

1. In order to provide a violation access break for New MICE-II/S, the trace cables have to be modified as follows:

- 1) Connect the violation access signals (SUEM J3) to New MICE-II case trace bits port (see figure 1).



D TYPE CONN.	.098" CONN.	WIRE COLOR
FEMALE, 15PIN	8PIN&2PIN&3PIN	
PIN NO.	PIN NO.	
1	G ( GND )	BLACK
9	0 ( 8 PIN )	BROWN
2	1 ( 8 PIN )	RED
10	2 ( 8 PIN )	ORANGE
3	3 ( 8 PIN )	YELLOW
11	4 ( 8 PIN )	GREEN
4	5 ( 8 PIN )	BLUE
12	8 ( 8 PIN )	PURPLE
5	7 ( 8 PIN )	GRAY
15	1 ( 2 PIN )	BLACK
8	2 ( 2 PIN )	BROWN
13	1 ( 3 PIN )	BLACK
6	2 ( 3 PIN )	BROWN

Figure 1

- \* 3-pin connector pin 1 (connecting to SUEM J3-1) connects to D type (female) connector pin 13.
  - \* 3-pin connector pin 2 (connecting to SUEM J3-2) connects to D type (female) connector pin 6.
- 2) Connect two IC clips (marked A and B with shorter wire) to D type (male) connector pin 13 and 6 on external trace cable (see figure 2).
- \* IC clip A connect to D type (male) connector pin 13.
  - \* IC clip B connect to D type (male) connector pin 6.




Figure 2

2. If user wants to use the violation access break feature, follow the procedure listed below:

- 1) Connect the red IC clip 0 (trace bit X0) to IC clip A.
- 2) Connect the red IC clip 2 (trace bit X2) to IC clip B.
- 3) Set the BPP external hardware breakpoint H5 and H6 as follows:

```
> H5 X1           ;for guard access violation
> H6 X1           ;for write protect violation
```

If an attempt is made to write into Read-only area (defined as "IR" or "ER" in the MAP command) while emulation processor running, this message will display -

**"PROGRAM BROKE AT BREAKPOINT-6"**

Likewise, if a non-existent area (defined as "G" in MAP command) is accessed, this message will display -

**"PROGRAM BROKE AT BREAKPOINT-5"**

- Notes:
1. Only the delivery of New MICE-II/S or/H includes these two trace cables (refer to fig. 1 and 2), SUEM single package does not.
  2. Only New MICE-II/S provides the violation access break.
  3. The PCB revision (Rev-B) of SUEM will move the position of J3 connector near the U63. This modification will shorten the wire length between the J3 and D type (female) connector.

**MICROTEK**