

C8002 User Guide

DRAFT EDITION - July 1980

Copyright © ONYX Systems, Inc., 1980

All rights reserved. No part of this publication may be reproduced without prior written permission. Request additional copies from:

ONYX Systems, Inc.
73 East Trimble Road
San Jose, CA 95131
(408) 946-6330

CONTENTS

INTRODUCTION

CHAPTER 1 THE C8002

General Description	1-1
Keyswitch	1-2
Power-On Indicator	1-2
Cartridge Opening	1-2
Reset Switch	1-2
Console Connector	1-3
Terminal Connectors	1-3
Modem Connector	1-3
Serial Printer Connector	1-3
Parallel Port Connector	1-3
RS 422 Interface Connector	1-4
Diagnostic Terminal Connector	1-4
Fuse Holder	1-4
Power Cord and Connector	1-4
Software Distribution Tape	1-4

CHAPTER 2 INSTALLING THE C8002

Introduction	2-1
Physical Requirements	2-1
Contents of Carton	2-2
Unpacking and Installing the C8002	2-2
Autoboot	2-3
Connecting Modems, Terminals and Printers	2-5
Warranty Terms	2-9
Return Procedures	2-9