

DLV11J


DLV11-J TEST
CNDLAAO

AH-T470A-MC
FICHE 1 OF 1

MAY 1983
COPYRIGHT © 82-83
MADE IN USA



Table with multiple columns and rows of data, including headers like 'TYPE', 'DESCRIPTION', 'QUANTITY', and 'UNIT'. The content is highly repetitive and difficult to read due to the image quality.



.REM %

IDENTIFICATION

PRODUCT CODE: AC-T469A-MC
PRODUCT NAME: CNDLAAO DLV11-J TEST
PRODUCT DATE: DEC, 1982
MAINTAINER: DIAGNOSTIC SERVICES/ISS

AUTHOR: DIAG/ISS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C)1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION.
1.1	PROGRAM PURPOSE (ABSTRACT).
1.2	SYSTEM REQUIREMENTS.
1.3	RELATED DOCUMENTS AND STANDARDS.
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES.
1.5	ASSUMPTIONS.
2.0	OPERATING INSTRUCTIONS.
2.1	LOADING AND STARTING PROCEDURES.
2.2	SPECIAL ENVIRONMENTS.
2.3	OPERATIONAL SWITCH SETTINGS
2.4	PROGRAM OPTIONS.
2.5	EXECUTION TIMES.
2.6	POWER FAIL.
3.0	ERROR INFORMATION.
3.1	ERROR REPORTING PROCEDURE.
3.2	ERROR HALTS.
4.0	PERFORMANCE AND PROGRESS REPORTS.
4.1	PERFORMANCE REPORTS.
5.0	DEVICE INFORMATION TABLES.
6.0	SUMMARY OF TESTS.

1.0 GENERAL PROGRAM INFORMATION.

1.1 PROGRAM PURPOSE (ABSTRACT).

THIS DIAGNOSTIC IS A LOGIC TEST TO VERIFY THE OPERATION OF THE DLV11-J SERIAL INTERFACE.
TESTING IS DONE IN TWO DISTINCT PHASES:

1. ALL SELECTED CHANNELS PER DLV11-J MODULE ARE TESTED INDIVIDUALLY
2. THE DLV11-J MODULE IS TESTED AS A WHOLE FOR CHANNEL INTERACTION PROBLEMS. THIS DIAGNOSTIC IS DESIGNED TO TEST AND DETECT ERRORS TO THE LOGIC LEVEL (NOT TO THE CHIP LEVEL).

THIS DIAGNOSTIC OPERATES UP TO 2 DLV11-J SERIAL LINE INTERFACES CONFIGURED AT CONSECUTIVE BASE ADDRESSES.
THE PROGRAM WILL DO AUTO-SIZING IF THE DEVICE MAP '\$DEVN' = 0.
ALTERNATELY, THE OPERATOR CAN SELECT OR DESELECT INDIVIDUAL MODULES & CHANNELS BY SETTING THE PROPER BITS IN '\$DEVN' (SEE PROGRAM OPTIONS SEC. 2.4) BEFORE RUNNING THE PROGRAM.
BY THIS METHOD, THE PROGRAM WILL BYPASS AUTO-SIZING AND TEST ONLY THOSE MODULES/CHANNELS IT FINDS IN \$DEVN.

IN EITHER CASE, THE PROGRAM WILL PRINT OUT ALL MODULES & CHANNELS TO BE TESTED BEFORE PROCEEDING.

THE OPERATOR MUST INSTALL DATA WRAP AROUND CONNECTORS TO DO DATA TESTING. TO BYPASS DATA TESTS, THE OPERATOR MUST MODIFY '\$USWR' (USER SWITCH REGISTER), SEE PROGRAM OPTIONS SEC. 2.4)

THE DEFAULT ADDRESSES & VECTORS ARE AS FOLLOWS:

177560 -CONSOLE INTERFACE DEVICE ADDRESS
176500 -FIRST SERIAL CHANNEL ADDRESS OF UP TO 8 CONSECUTIVE SERIAL LINE DEVICES.

60 - VECTOR FOR CONSOLE DEVICE INTERFACE.
300 - VECTOR FOR FIRST OF 16 DEVICES.

THIS PROGRAM IS DESIGNED TO RUN ON ANY Q-BUS PDP-11 WITH 4K OF MEMORY AND A DLV11-J (Q-BUS) MODULE. IT CAN RUN UNDER XXDP & APT MONITORS, AND ON PROCESSORS WITH NO HARDWARE SWITCH REGISTER.

1.2 SYSTEM REQUIREMENTS.

HARDWARE REQUIREMENTS:

ANY Q-BUS PDP-11 FAMILY PROCESSOR
4K MEMORY - MINIMUM
A SPECIAL DATA WRAP AROUND CONNECTOR OR EQUIVALENT
(REQ'D IF DATA WRAP AROUND TESTS DESIRED)

IF CHANNEL 3 IS CONFIGURED AS THE CONSOLE:
TESTS 6-12, 14-17, 21, 22 ARE BYPASSED.

IF DATA WRAP AROUND TESTS ARE BYPASSED:
TESTS 7-12, 14-17, 21, 22 ARE BYPASSED.

IF CHANNEL 3 IS CONFIGURED AS THE CONSOLE & A VT-100 IS
THE CONSOLE DEVICE, SWITCH THE VT-100 TO "JUMP SCROLL" MODE
TO AVOID LOOSING CHARACTERS ON THE SCREEN.

SOFTWARE REQUIREMENTS:

THIS DIAGNOSTIC IS DESIGNED TO RUN IN ANY OF THE
FOLLOWING WAYS:

STAND ALONE
WITH APT MONITOR
WITH XXDP MONITOR (CHAINABLE IF RENAMED TO .BIC EXTENSION)

THIS DIAGNOSTIC IS NOT DESIGNED TO RUN WITH THE
DIAGNOSTIC SUPERVISOR.

1.3 RELATED DOCUMENTS AND STANDARDS.

DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS	175-003-009-02
APT	MD-11-DZZMA
SYSMAC	MD-11-DZQAC

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES.

NO SPECIAL DIAGNOSTICS ARE REQUIRED TO RUN BEFORE THIS, BUT
THE PROCESSOR, MEMORY, AND BUS ARE ASSUMED TO BE FULLY
OPERATIONAL.

1.5 ASSUMPTIONS.

THIS DIAGNOSTIC ASSUMES THAT THE OPERATOR HAS INITIALIZED
LOCATION '\$USWR' AND '\$DEVM' TO THE PROPER VALUES. (SEE SEC. 2.4)

2.0 OPERATING INSTRUCTIONS.

2.1 LOADING AND STARTING PROCEDURES.

USE STANDARD PROCEDURE FOR PDP-11 ABSOLUTE BINARY FORMATTED MEDIA.

THERE ARE 2 STARTING LOCATIONS FOR THIS DIAGNOSTIC:

1. LOCATION 200 FOR ALL NORMAL TESTING STARTS & RESTARTS.
2. LOCATION 400 FOR INTERRUPT VECTOR DEBUG... OFFLINE ONLY.

THE 400 START SHOULD BE USED ONLY TO DEBUG FAULTY VECTOR ADDRESSES PUT OUT BY THE DLV11-J DURING INTERRUPTS. STARTING AT 400 WILL CAUSE THE ENTIRE VECTOR AREA, EXCEPT THAT NEEDED BY SYSMAC, TO BE OVERWRITTEN & TO POINT TO A COMMON SERVICE ROUTINE TO ENABLE LOOPING ON THE PROBLEM.

AS SOON AS TESTING STARTS, THE OPERATOR CAN CHANGE THE SWITCH REGISTER ONLY BY A 'BREAK' & MANUALLY LOADING LOCATION 176 (SWREG) WITH THE DESIRED CONTENTS (SEE SEC. 2.3) THEN DOING A 'P' TO PROCEED.

IT IS IMPORTANT THAT WHEN GOING BACK TO NORMAL TESTING A FRESH LOAD OF THE PROGRAM BE PERFORMED TO RESET THE VECTOR AREA.

THE USER CAN SELECT A SPECIFIC TEST TO BE EXECUTED BY SETTING BIT 8 IN SWREG AND THE TEST NUMBER (IN OCTAL) IN BITS <7:0>.

(NOTE: ALL TESTS PREVIOUS TO THE SELECTED ONE ARE EXECUTED WITHOUT ITERATIONS.)

2.2 SPECIAL ENVIRONMENTS.

THIS DIAGNOSTIC FOLLOWS THE STANDARD PROCEDURE FOR RUNNING UNDER APT,XXDP MONITORS, AS DESCRIBED IN THEIR RESPECTIVE PROCEDURES MANUAL AND SYSMAC PACKAGE.

2.3 OPERATIONAL SWITCH SETTINGS

THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED FOR ALL OPERATIONAL SWITCH SETTINGS. THIS CAN BE ACCOMPLISHED IN THE FOLLOWING WAY:

- 1) TYPE CONTROL G <^G>; THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: 'SWR=XXXXXX NEW=' (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
 - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED). LEADING ZEROS NEED NOT BE TYPED, AND IF MORE THAN 6 DIGITS ARE TYPED THE LAST 6 WILL BE USED. IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
 - B) IF A CONTROL U <^U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 3.
 - C) IF THE INPUT CHARACTER IS NOT ONE OF THE CHARACTERS MENTIONED ABOVE THEN A QUESTION MARK (?) WILL BE TYPED FOLLOWED BY A CARRAGE RETURN AND A LINE FEED SEQUENCE THEN PROCEED FROM STEP 3 (ERASING ALL PREVIOUS INPUT).
- 4) THE DIAGNOSTIC WILL CONTINUE ON TYPING <CR>.

NOTE: BECAUSE OF FREQUENT BUS RESETS IN THE PROGRAM, IT MAY BE NECESSARY TO DO 'CONTROL-G' SEVERAL TIMES. ALTERNATELY, A 'BREAK' & MANUALLY LOADING LOC. 176, FOLLOWED BY A 'P' TO PROCEED WILL ALSO WORK.

SOFTWARE SWITCH REGISTER OPTIONS (SWREG)

BIT 15 SET = 100000 = HALT ON ERROR
14 SET = 40000 = LOOP ON TEST (TO BE USED ONLY WHILE TESTING IN PROGRESS)
13 SET = 20000 = INHIBIT ERROR TIMEOUTS
12 SET = 10000 = ENABLE PERFORMANCE REPORTS
11 SET = 4000 = INHIBIT ITERATIONS
10 SET = 2000 = BELL ON ERROR
9 SET = 1000 = LOOP ON ERROR
8 SET = 400 = LOOP ON TEST IN SWR<7:0>
7:0 = NUMBER OF TEST TO LOOP ON (USED WITH BIT 8)
(ALL TESTS PREVIOUS TO THE SELECTED TEST
ARE EXECUTED FIRST WITH 1 ITERATION ONLY)


2.4 PROGRAM OPTIONS.

THIS PROGRAM REQUIRES THE ADDRESS OF THE FIRST RCSR (STORED AT '\$BASE') AND ITS INTERRUPT VECTOR (STORED AT '\$VECT1'). IT WILL BE ABLE TO ADDRESS ANY DLV11-J STARTING AT THE SPECIFIED BASE ADDRESS THRU 2 CONSECUTIVE MODULES.

EXAMPLES: \$BASE: 176500 (DEFAULT)
 \$VECT1: 300 (DEFAULT)

LOCATION '\$DEVN' IS USED AS A BIT MAP TO INDICATE WHICH UNIT NUMBERS ARE PRESENT AND WILL BE TESTED.

\$DEVN (BITS 15 THRU 8 NOT USED)



A BIT MAP CAN BE ENTERED AT '\$DEVN' PRIOR TO STARTING THE PROGRAM. IF '\$DEVN' IS LEFT AT ITS DEFAULT VALUE (0), THE PROGRAM WILL DO AUTO-SIZING BEGINNING AT THE DEVICE ADDRESS IN '\$BASE' & WILL SETUP '\$DEVN' ACCORDINGLY. IN EITHER CASE, THE PROGRAM WILL TYPE OUT A LIST OF ALL THE MODULES/CHANNELS TO BE TESTED BEFORE PROCEEDING.

NOTE: SIZING IS PERFORMED ONLY ONCE AT THE BEGINNING OF THE PROGRAM. IF \$DEVN IS TO BE CHANGED, THE PROGRAM MUST BE RESTARTED AT 200 FOR IT TO BE EFFECTIVE. OTHERWISE, \$DEVN WILL BE IGNORED.

OPTIONS

LOCATION \$USWR CONTAINS ALL THE USER SELECTABLE OPTIONS. THE VALUES IN THIS WORD MUST CONFORM TO THE ACTUAL BOARD CONFIGURATION.

BIT POSITION	DEFINITION	\$USWR	DEFAULT VALUE
0	# OF DATA BITS TRANSMITTED 0 = 7 BITS, 1 = 8 BITS	1	= 8 BITS
1	PARITY ENABLED	0	= NO
2	EVEN ODD PARITY	0	= ODD
3	BREAK DETECTION ENABLED	1	= YES
4	RUN DATA WRAP AROUND TESTS	1	= YES
<11:9>	CONSOLE DEVICE	1	= YES = CONSOLE ON MODULE 1, CHAN. 3

<11:9> = 0 = CONSOLE NOT ON DLV11-J
 <11:9> = 1 = CONSOLE ON MODULE 1
 <11:9> = 2 = CONSOLE ON MODULE 2

IMPORTANT:

1. FOR DIAGNOSTIC PURPOSES, ALL CHANNELS MUST BE CONFIGURED TO THE SAME BIT/WORD LENGTH.
2. THE 'SIZING' ROUTINE WILL SET THE APPROPRIATE CHAN 3 BIT IN \$DEVN IF BITS <11:9> ARE SET IN \$USWR.
3. IF RUNNING UNDER APT & THE CONSOLE IS ON THE DLV11-J, THE CONSOLE MUST NOT BE TESTED. THIS IS BECAUSE APT SENDS 'BREAKS' TO THE CONSOLE WHICH INTERFERES WITH THE TESTS.

FOR THIS CASE:

- A. ALLOW THE \$DEVN TO STAY EITHER AT ITS DEFAULT OF 0 OR CLEAR THE APPROPRIATE CHAN. 3 BIT.
- B. CLEAR BITS <11:9> IN \$USWR SO THE CONSOLE BIT WILL NOT BE SET INTO \$DEVN FOR TESTING.

SUMMARY OF DEVICE ADDRESSES & VECTORS.

	CHANNEL	DEV ADDRESS (RCSR)	VECTORS	
			REC	XMIT
MODULE #1	0	\$BASE+00	\$VECT1+00	\$VECT1+4
	1	+10	+10	+14
	2	+20	+20	+24
	3	+30	+30	+34
MODULE #2	0	+40	+40	+44
	1	+50	+50	+54
	2	+60	+60	+64
	3	+70	+70	+74
CONSOLE DEVICE	3	\$TKS	TKVEC=60	TPVEC=64

SUMMARY OF USER LOCATIONS & DEFAULTS.

	LOC	DEFAULT	
\$BASE	1250	176500	
\$VECT1	1244	300	
\$TKS	1144	177560	FOR CONSOLE DEVICE ON MODULE UNDER TEST
TKVEC		60	FOR CONSOLE DEVICE ON MODULE UNDER TEST
TPVEC		64	FOR CONSOLE DEVICE ON MODULE UNDER TEST
\$USWR	1220	31	SEE SEC. 2.4
\$DEVN	1252	17	SEE SEC. 2.4
SWREG	176	0	SEE SEC. 2.3

2.5 EXECUTION TIMES.

EXECUTION TIMES FOR AN LSI-11 PROCESSOR WITH ONE DLV11-J MODULE AT SHIPMENT CONFIGURATION:

CH. 0,1,2 AT 9600 BAUD.
 CH. 3 (CONSOLE) AT 300 BAUD.

ARE: FIRST PASS- 30 SEC
 ADDITIONAL PASSES 90 SEC

THE TEST TIME IS BAUD RATE DEPENDENT; HIGHER BAUD RATES RESULT IN SHORTER PASS TIMES.

2.6 POWER FAIL.

AUTO START FROM POWER FAIL IS NOT IMPLEMENTED IN THIS PROGRAM.

3.0 ERROR INFORMATION.

3.1 ERROR REPORTING PROCEDURE.

SINCE THIS DIAGNOSTIC WAS DESIGNED TO FIT IN 4K OF MEMORY THE ERROR TYPEOUT IS VERY BRIEF. THE FORMAT OF THE ERROR TYPEOUT IS AS FOLLOWS:

TEST#____,ERROR#____,PC=____,ADDRESS=____,VECTOR=____

WHERE ALL VALUES TYPED ARE OCTAL.
THE ADDRESS AND VECTOR REFER TO THE FAILING CHANNEL.
FOR FURTHER INFORMATION THE LISTING MUST BE CONSULTED.
BITS 15,13,10 AND 9 OF THE SWITCH REGISTER (SWREG) CONTROL THE SEQUENCE OF EVENTS AFTER AN ERROR IS CAUGHT.

BIT 15 SET: CAUSES THE PROGRAM TO HALT IN THE ERROR ROUTINE.
IF THE PROGRAM IS CONTINUED, IT WILL PROCEED FROM WHERE IT HALTED.

BIT 13 SET: DISABLES THE PRINTING OF THE ERROR MESSAGE.

BIT 10 SET: CAUSES THE BELL TO RING ON ERROR.

BIT 9 SET: CAUSES THE DIAGNOSTIC TO LOOP FROM BEGINNING OF TEST TO ERROR.

THE ERROR ROUTINE SUPPORTS THE CONTROL G <^G> FUNCTION.
REFER TO SECTION 2.3 FOR DETAILS.

3.2 ERROR HALTS.

THE ONLY HALT IN THIS DIAGNOSTIC IS IN THE ERROR ROUTINE, AND IS EXECUTED ONLY IF BIT 15 OF THE SWITCH REGISTER (SWREG) IS SET WHEN AN ERROR OCCURS.

4.0 PERFORMANCE AND PROGRESS REPORTS.

4.1 PERFORMANCE REPORTS. (BIT 12 SET IN THE SWITCH REGISTER 'SWREG')

AS EACH CHANNEL (4 CHANNELS/DLV11-J) COMPLETES ONE PASS OF THE DIAGNOSTIC THE FOLLOWING ITEMS ARE TYPED:

'CSR:----' : THE BASE ADDRESS OF THE LINE UNDER TEST
'VECTOR:--' : THE ASSOCIATED VECTOR
'ERRORS:--' : THE TOTAL NUMBER OF ERRORS ON THIS DEVICE ON THIS PASS.

AFTER ALL MODULES & CHANNELS TO BE TESTED HAVE BEEN EXERCISED, AN END PASS STATEMENT IS TYPED:

'END PASS#-----.'

EXAMPLE OF PRINTOUT ASSUMING: 2 DLV11-J MODULES
ALL CHANNELS ENABLED
SEPERATE CONSOLE DEVICE
NO ERRORS

CNDLAAO DLV11-J TEST

SWR= 000000 NEW= 10000<CR>

(ENABLE PERFORMANCE REPORTS)

WILL TEST:

MODULE 1 CHANNEL 0 1 2 3
MODULE 2 CHANNEL 0 1 2 3

** PHASE 1 SUMMARY **

CSR: 176500, VECTOR: 000300, ERRORS: 0
CSR: 176510, VECTOR: 000310, ERRORS: 0
CSR: 176520, VECTOR: 000320, ERRORS: 0
CSR: 176530, VECTOR: 000330, ERRORS: 0

** PHASE 2 SUMMARY **

CSR: 176500, VECTOR: 000300, ERRORS: 0

** PHASE 1 SUMMARY **


CSR: 176540, VECTOR: 000340, ERRORS: 0
CSR: 176550, VECTOR: 000350, ERRORS: 0
CSR: 176560, VECTOR: 000360, ERRORS: 0
CSR: 176570, VECTOR: 000370, ERRORS: 0

** PHASE 2 SUMMARY **

CSR: 176540, VECTOR: 000340, ERRORS: 0

END PASS # 1

5.0 DEVICE REGISTERS.



NOTES:

1. RCSR AT BASE ADDRESS (\$BASE)
 RBUF AT \$BASE+2
 TCSR AT \$BASE+4
 TBUF AT \$BASE+6
2. BLANK BOXES INDICATE UNUSED AND RESERVED BIT POSITIONS. SEE THE LISTING FOR AN EXPLANATION OF THE BITS.
3. ORERR = OVERRUN ERROR
 FRERR = FRAMING ERROR
 PERR = PARITY ERROR

6.0 SUMMARY OF TESTS AND SPECIAL SUBROUTINES.

PHASE 1 TESTS

TEST 1 ADDRESSABILITY

THIS TEST VERIFIES THAT ALL 4 REGISTERS OF THE CHANNEL
UNDER TEST RESPOND TO THEIR ADDRESSES.

THE FOLLOWING 3 TESTS TEST ALL 'READ WRITE' BITS

TEST 2 BREAK - TCSR 0 SET, CLEAR, RESET

TEST 3 XMITIE - TCSR 6 SET, CLEAR, RESET

TEST 4 RCVRIE - RCSR 6 SET, CLEAR, RESET

TEST 5 XMITRDY - TCSR 7 - IS SET BY INIT

TEST 6 XMIT RDY - TCSR 7 - CLEARS WHEN TBUF IS LOADED
----- WITH A CHARACTER AND THAT IT SETS WITHIN A
REASONABLE AMOUNT OF TIME.

TEST 7 OUTPUTTING A CHAR FROM TBUF (WITH WRAP AROUND CONNECTED)
----- RESULTS IN RCVRDONE SETTING WITHIN A
REASONABLE AMOUNT OF TIME AND THAT RESEI
CLEARS THE BIT.

TEST 10 RCVRDONE IS CLEARED BY SETTING READER ENABLE

TEST 11 RCVRDONE IS CLEARED BY READING RBUF

TEST 12 OVERRUN & ERROR BIT - RBUF 14

TEST 13 TRANSMITTER INTERRUPT LOGIC TEST

---- --

LOGICALLY THIS IS 4 SEPARATE TESTS

- A) DOES TRANSMITTER INTERRUPT LOGIC WORK
- B) AT PRIORITY OF 0
- C) AND ONLY ONCE
- D) BUT NOT WITH INTERRUPT ENABLE CLEAR

TEST 14 RECEIVER INTERRUPT LOGIC TEST THIS TEST COVERS ALL
---- -- OF THE RECEIVER SIDE OF THE INTERRUPT LOGIC IN
CHARACTER MODE.

TEST 15 TEST DATA WRAP AROUND: FLAG MODE.

---- --

TEST 16 TEST DATA WRAP AROUND: INTERRUPT MODE.

---- --

TEST 17 TEST BREAK DETECTION LOGIC TRANSMIT KNOWN CHAR

---- --

- A) TRANSMIT KNOWN CHAR WITH BREAK SET
AND COMPARE RECEIVED WITH 0
- B) TEST FOR FRAMING ERROR ON BREAK
- C) IF PARITY IS ENABLED AND ODD PARITY IS SELECTED,
CHECK TO BE SURE PARITY ERROR WAS GENERATED
- D) IF PARITY IS ENABLED AND EVEN PARITY IS SELECTED,
CHECK TO BE SURE NO PARITY ERROR OCCURRED

TEST 20 NOT A TEST - SEND BACK TO LOOP

PHASE 2 TESTS

TEST 21 TEST THAT CHANNELS INTERRUPT AT ASSIGNED PRIORITY

---- --

TEST 22 TEST DATA TRANSFERS WITH ALL ACTIVE LINES INTERRUPTING.

---- --

%

```

8719
8720
8721      .TITLE  CNDLAAO DLV11-J TEST
          :*COPYRIGHT (C) 1982
          :*DIGITAL EQUIPMENT CORP.
          :*MAYNARD, MASS. 01754
          :*
          :*PROGRAM BY GREGORY GLEZMAN & GARY PAPAZIAN
          :*
          :*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
          :*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
          :*
8722
8723      .SBTTL  OPERATIONAL SWITCH SETTINGS
          :*
          :*          SWITCH          USE
          :*          -----
          :*          15          HALT ON ERROR
          :*          14          LOOP ON TEST
          :*          13          INHIBIT ERROR TYPEOUTS
          :*          11          INHIBIT ITERATIONS
          :*          10          BELL ON ERROR
          :*          9          LOOP ON ERROR
          :*          8          LOOP ON TEST IN SWR<7:0>
8724      .SBTTL  BASIC DEFINITIONS
          :*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
          001100  STACK= 1100
          :*EQUIV  EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
          :*EQUIV  IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
          :*MISCELLANEOUS DEFINITIONS
          000011  HT= 11          ;;CODE FOR HORIZONTAL TAB
          000012  LF= 12          ;;CODE FOR LINE FEED
          000015  CR= 15          ;;CODE FOR CARRIAGE RETURN
          000200  CRLF= 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
          177776  PS= 177776     ;;PROCESSOR STATUS WORD
          :*EQUIV  PS,PSW
          177774  STKLMT= 177774  ;;STACK LIMIT REGISTER
          177772  PIRQ= 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
          177570  DSWR= 177570   ;;HARDWARE SWITCH REGISTER
          177570  DDISP= 177570  ;;HARDWARE DISPLAY REGISTER
          :****** THE FOLLOWING ODT START ADDRESS FOR SBC 11/21 IS ADDED
          170000  ODTST= 170000
          :*GENERAL PURPOSE REGISTER DEFINITIONS
          000000  R0= 00          ;;GENERAL REGISTER
          000001  R1= 01          ;;GENERAL REGISTER
          000002  R2= 02          ;;GENERAL REGISTER
          000003  R3= 03          ;;GENERAL REGISTER
          000004  R4= 04          ;;GENERAL REGISTER
          000005  R5= 05          ;;GENERAL REGISTER
          000006  R6= 06          ;;GENERAL REGISTER
          000007  R7= 07          ;;GENERAL REGISTER
          000006  SP= 06          ;;STACK POINTER
          000007  PC= 07          ;;PROGRAM COUNTER
  
```



```
(1) ;*PRIORITY LEVEL DEFINITIONS
(1) 000000 PR0= 0 ;:PRIORITY LEVEL 0
(1) 000040 PR1= 40 ;:PRIORITY LEVEL 1
(1) 000100 PR2= 100 ;:PRIORITY LEVEL 2
(1) 000140 PR3= 140 ;:PRIORITY LEVEL 3
(1) 000200 PR4= 200 ;:PRIORITY LEVEL 4
(1) 000240 PR5= 240 ;:PRIORITY LEVEL 5
(1) 000300 PR6= 300 ;:PRIORITY LEVEL 6
(1) 000340 PR7= 340 ;:PRIORITY LEVEL 7

(1) ;*'SWITCH REGISTER' SWITCH DEFINITIONS
(1) 100000 SW15= 100000
(1) 040000 SW14= 40000
(1) 020000 SW13= 20000
(1) 010000 SW12= 10000
(1) 004000 SW11= 4000
(1) 002000 SW10= 2000
(1) 001000 SW09= 1000
(1) 000400 SW08= 400
(1) 000200 SW07= 200
(1) 000100 SW06= 100
(1) 000040 SW05= 40
(1) 000020 SW04= 20
(1) 000010 SW03= 10
(1) 000004 SW02= 4
(1) 000002 SW01= 2
(1) 000001 SW00= 1
(1) .EQUIV SW09,SW9
(1) .EQUIV SW08,SW8
(1) .EQUIV SW07,SW7
(1) .EQUIV SW06,SW6
(1) .EQUIV SW05,SW5
(1) .EQUIV SW04,SW4
(1) .EQUIV SW03,SW3
(1) .EQUIV SW02,SW2
(1) .EQUIV SW01,SW1
(1) .EQUIV SW00,SW0

(1) ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
(1) 100000 BIT15= 100000
(1) 040000 BIT14= 40000
(1) 020000 BIT13= 20000
(1) 010000 BIT12= 10000
(1) 004000 BIT11= 4000
(1) 002000 BIT10= 2000
(1) 001000 BIT09= 1000
(1) 000400 BIT08= 400
(1) 000200 BIT07= 200
(1) 000100 BIT06= 100
(1) 000040 BIT05= 40
(1) 000020 BIT04= 20
(1) 000010 BIT03= 10
(1) 000004 BIT02= 4
(1) 000002 BIT01= 2
(1) 000001 BIT00= 1
(1) .EQUIV BIT09,BIT9
```

```
(1) .EQUIV BIT08,BIT8
(1) .EQUIV BIT07,BIT7
(1) .EQUIV BIT06,BIT6
(1) .EQUIV BIT05,BIT5
(1) .EQUIV BIT04,BIT4
(1) .EQUIV BIT03,BIT3
(1) .EQUIV BIT02,BIT2
(1) .EQUIV BIT01,BIT1
(1) .EQUIV BIT00,BIT0
(1)
(1) ;*BASIC "CPU" TRAP VECTOR ADDRESSES
(1) 000004 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
(1) 000010 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
(1) 000014 TBITVEC=14 ;: "T" BIT
(1) 000014 TRIVEC= 14 ;:TRACE TRAP
(1) 000014 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
(1) 000020 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
(1) 000024 PWRVEC= 24 ;:POWER FAIL
(1) 000030 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
(1) 000034 TRAPVEC=34 ;: "TRAP" TRAP
(1) 000060 TKVEC= 60 ;:TTY KEYBOARD VECTOR
(1) 000064 TPVEC= 64 ;:TTY PRINTER VECTOR
(1) ;***** THE FOLLOWING BREAK VECTOR AND LINE CLOCK VECTOR ARE INCLUDED
(1) 000100 LKVEC= 100 ;:LINE CLOCK VECTOR
(1) 000140 BRKVEC= 140 ;:BREAK VECTOR
(1) 000240 PIRQVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
8725
8726
8727
8728 000001 ADRS= R1
8729 176500 DLADDR= 176500
8730
8731 ; THE FOLLOWING DEFINITIONS APPLY TO THE GLOBAL SUBS
8732 177777 SET= -1
8733 000000 CLR= 0
8734 000001 TRUE= 1
```

8736
8737
8738
8739
8740
8741
8742
8743
8744
8745
8746
8747
8748
8749
8750
8751
8752
8753
8754
8755
8756
8757
8758
8759
8760
8761
8762
8763
8764
8765
8766
8767
8768
8769
8770
8771
8772
8773
8774
8775
8776
8777

000200
000100

000001

100000
040000
020000
010000

000200
000100
000040
000020
000010
000004
000002
000001

```

:*****
: RCSR REGISTER BIT NAMES
:*****
: UNUSED BIT15
: UNUSED BIT14
: UNUSED BIT13
: UNUSED BIT12
: UNUSED BIT11
: UNUSED BIT10
: UNUSED BIT09
: UNUSED BIT08
RCVRDONE= BIT07 : RECEIVER DONE
RCVRIE= BIT06 : RECEIVER INTERRUPT ENABLE
: UNUSED BIT05
: UNUSED BIT04
: UNUSED BIT03
: UNUSED BIT02
: UNUSED BIT01
RDRRUN= BIT00 : READER RUN
:*****
: RBUF REGISTER BIT NAMES
:*****
ERROR= BIT15 : ERROR INDICATOR
ORERR= BIT14 : OVERRUN ERROR
FRERR= BIT13 : FRAMING ERROR
PERR= BIT12 : PARITY ERROR
: UNUSED BIT11
: UNUSED BIT10
: UNUSED BIT09
: UNUSED BIT08
RDATA7= BIT07 : \
RDATA6= BIT06 : |
RDATA5= BIT05 : |
RDATA4= BIT04 : |
RDATA3= BIT03 : |
RDATA2= BIT02 : |
RDATA1= BIT01 : |
RDATA0= BIT00 : /
RECEIVED DATA BITS
  
```

8779
8780
8781
8782
8783
8784
8785
8786
8787
8788
8789
8790
8791
8792
8793
8794
8795
8796
8797
8798
8799
8800
8801
8802
8803
8804
8805
8806
8807
8808
8809
8810
8811
8812
8813
8814
8815
8816
8817
8818
8819
8820
8821
8822
8823
8824
8825
8826
8827
8828
8829

000200
000100

000001

000200
000100
000040
000020
000010
000004
000002
000001

000002
000004
000010
000020

```

;*****
; TCSR REGISTER BIT NAMES
;*****
: UNUSED BIT15
: UNUSED BIT14
: UNUSED BIT13
: UNUSED BIT12
: UNUSED BIT11
: UNUSED BIT10
: UNUSED BIT09
: UNUSED BIT08
XMITRDY= BIT07 ; TRANSMITTER READY
: UNUSED BIT06 ; TRANSMITTER INTERRUPT ENABLE
XMITIE= BIT06
: UNUSED BIT05
: UNUSED BIT04
: UNUSED BIT03
: UNUSED BIT02
: UNUSED BIT01
BREAK= BIT00 ; SEND BREAK (CONTINUOUS SPACE)

;*****
; TBUF REGISTER BIT NAMES
;*****
: UNUSED BIT15
: UNUSED BIT14
: UNUSED BIT13
: UNUSED BIT12
: UNUSED BIT11
: UNUSED BIT10
: UNUSED BIT09
: UNUSED BIT08
TDATA7= BIT07 : \
TDATA6= BIT06 : |
TDATA5= BIT05 : |
TDATA4= BIT04 : | TRANSMITTER DATA BUFFER
TDATA3= BIT03 : |
TDATA2= BIT02 : |
TDATA1= BIT01 : |
TDATA0= BIT00 : /

;*****
; FLAG BITS TO BE USE OR CLEARED IN $USWR.
PARITY = 2
EVENODD = 4
BRK = 10
WRAP = 20
    
```



```

8831
8832
8833
8834
(1)
(1)          000000
(1)
(1)
(1)
(1)          000174
(1) 000174 000000
(1) 000176 000000
(1)
(1) 000200 000137 001334
8835
8836
8837
8838
8839
8840
8841          000400
8842
8843 000400 005000
8844 000402 012720 013610
8845 000406 012720 000300
8846
8847 000412 020027 000400
8848 000416 001371
8849 000420 005037 000176
8850 000424 000137 001334

;*****
;SBTTL TRAP CATCHER
      .=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
      .=174
DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER
.SBTTL STARTING ADDRESS(ES)
      JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM

;
; OFFLINE TESTING FOR INTERRUPT VECTOR PROBLEMS
;
      .=400
1$:   CLR    R0
      MOV    #INTSRV,(R0)+ ;SET INTR HANDLER PTR
      MOV    #PR6,(R0)+   ;SET PRIORITY TO 6 TO BE
;                                     ;SPECIFIC TO 11/21 PROCESSOR
      CMP    R0,#400      ;ALL DONE?
      BNE    1$           ;BR IF NO
      CLR    176          ;CLEAN UP SWREG
      JMP    START        ;GO DO IT
  
```

```

8852
8853
8854      .SBTTL ACT11 HOOKS
(1)
(2)      ::*****
(1)      ::HOOKS REQUIRED BY ACT11
(1)      $SVPC=.          ;SAVE PC
(1)      .=46
(1) 000046 014450      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
(1)      000052      .=52
(1) 000052 000000      .WORD 0      ;;2)SET LOC.52 TO ZERO
(1)      000430      .=$SVPC      ;; RESTORE PC
8855      .=1000
8856      .SBTTL APT PARAMETER BLOCK
(1)
(2)      ::*****
(1)      ::SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
(2)      ::*****
(1)      .SX=.          ;;SAVE CURRENT LOCATION
(1)      .=24          ;;SET POWER FAIL TO POINT TO START OF PROGRAM
(1) 000024 000200      200          ;;FOR APT START UP
(1)      .=44          ;;POINT TO APT INDIRECT ADDRESS PNTR.
(1) 000044 001000      $APTHDR    ;;POINT TO APT HEADER BLOCK
(1)      001000      .=.$X      ;;RESET LOCATION COUNTER
(2)      ::*****
(1)      ::SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
(1)      ::INTERFACE SPEC.
(1)
(1) 001000      $APTHD:
(1) 001000 000000      $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
(1) 001002 001174      $MBADR: .WORD $MAIL    ;;ADDRESS OF APT MAILBOX (BITS 0-15)
(1) 001004 000031      $STM: .WORD 25.    ;;RUN TIM OF LONGEST TEST
(1) 001006 000144      $PASTM: .WORD 100.  ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
(1) 001010 000144      $UNITM: .WORD 100.  ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
(1) 001012 000030      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

```

8857

.SBTTL COMMON TAGS

(1)
(2)
(1)
(1)
(1)
(1)
(1) 001100 001100
(1) 001100 000000
(1) 001102 000
(1) 001103 000
(1) 001104 000000
(1) 001106 000000
(1) 001110 000000
(1) 001112 000000
(1) 001114 000
(1) 001115 001
(1) 001116 000000
(1) 001120 000000
(1) 001122 000000
(1) 001124 000000
(1) 001126 000000
(1) 001130 000000
(1) 001132 000000
(1) 001134 000
(1) 001135 000
(1) 001136 000000
(1) 001140 177570
(1) 001142 177570
(1) 001144 177560
(1) 001146 177562
(1) 001150 177564
(1) 001152 177566
(1) 001154 000
(1) 001155 002
(1)
(1) 001156 012
(1) 001157 000
(1) 001160 000000
(1) 001162 000000
(1) 001164 177607 000377
(1) 001170 077
(1) 001171 015
(1) 001172 000012

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.
.=1100
\$CMTAG: .WORD 0 ;; START OF COMMON TAGS
\$TSTNM: .BYTE 0 ;; CONTAINS THE TEST NUMBER
\$ERFLG: .BYTE 0 ;; CONTAINS ERROR FLAG
\$ICNT: .WORD 0 ;; CONTAINS SUBTEST ITERATION COUNT
\$LPADR: .WORD 0 ;; CONTAINS SCOPE LOOP ADDRESS
\$LPERR: .WORD 0 ;; CONTAINS SCOPE RETURN FOR ERRORS
\$ERTTL: .WORD 0 ;; CONTAINS TOTAL ERRORS DETECTED
\$ITEMB: .BYTE 0 ;; CONTAINS ITEM CONTROL BYTE
\$ERMAX: .BYTE 1 ;; CONTAINS MAX. ERRORS PER TEST
\$ERRPC: .WORD 0 ;; CONTAINS PC OF LAST ERROR INSTRUCTION
\$GDADR: .WORD 0 ;; CONTAINS ADDRESS OF 'GOOD' DATA
\$BDADR: .WORD 0 ;; CONTAINS ADDRESS OF 'BAD' DATA
\$GDDAT: .WORD 0 ;; CONTAINS 'GOOD' DATA
\$BDDAT: .WORD 0 ;; CONTAINS 'BAD' DATA
\$RESV: .WORD 0 ;; RESERVED--NOT TO BE USED
\$AUTOB: .BYTE 0 ;; AUTOMATIC MODE INDICATOR
\$INTAG: .BYTE 0 ;; INTERRUPT MODE INDICATOR
\$SWR: .WORD DSWR ;; ADDRESS OF SWITCH REGISTER
\$DISPLAY: .WORD DDISP ;; ADDRESS OF DISPLAY REGISTER
\$TKS: 177560 ;; TTY KBD STATUS
\$TKB: 177562 ;; TTY KBD BUFFER
\$TPS: 177564 ;; TTY PRINTER STATUS REG. ADDRESS
\$TPB: 177566 ;; TTY PRINTER BUFFER REG. ADDRESS
\$NULL: .BYTE 0 ;; CONTAINS NULL CHARACTER FOR FILLS
\$FILLS: .BYTE 2
\$FILLC: .BYTE 12 ;; CONTAINS # OF FILLER CHARACTERS REQUIRED
\$STPFLG: .BYTE 0 ;; INSERT FILL CHARS. AFTER A 'LINE FEED'
\$TIMES: 0 ;; 'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
\$ESCAPE: 0 ;; MAX. NUMBER OF ITERATIONS
\$BELL: .ASCIZ <207><377><377> ;; ESCAPE ON ERROR ADDRESS
\$QUES: .ASCII /?/ ;; CODE FOR BELL
\$CRLF: .ASCII <15> ;; QUESTION MARK
\$LF: .ASCIZ <12> ;; CARRIAGE RETURN
\$LF: .ASCIZ <12> ;; LINE FEED

.SBTTL APT MAILBOX-ETABLE

.EVEN
\$MAIL: .WORD 0 ;; APT MAILBOX
\$MSGTY: .WORD 0 AMSGTY ;; MESSAGE TYPE CODE
\$FATAL: .WORD 0 AFATAL ;; FATAL ERROR NUMBER
\$TESTN: .WORD 0 ATESTN ;; TEST NUMBER
\$PASS: .WORD 0 APASS ;; PASS COUNT
\$DEVCT: .WORD 0 ADEVCT ;; DEVICE COUNT
\$UNIT: .WORD 0 AUNIT ;; I/O UNIT NUMBER

(2)	001210	000000	\$MSGAD: .WORD	AMSGAD	::MESSAGE ADDRESS
(2)	001212	000000	\$MSGLG: .WORD	AMSGLG	::MESSAGE LENGTH
(2)	001214		\$ETABLE:		::APT ENVIRONMENT TABLE
(2)	001214	000	\$ENV: .BYTE	AENV	::ENVIRONMENT BYTE
(2)	001215	000	\$ENVM: .BYTE	AENVM	
(2)			::ENVIRONMENT	MODE BITS	
(2)	001216	000000	\$SWREG: .WORD	ASWREG	::APT SWITCH REGISTER
(2)	001220	000031	\$USWR: .WORD	AUSWR	::USER SWITCHES
(2)	001222	000000	\$CPUOP: .WORD	ACPUOP	::CPU TYPE,OPTIONS
(2)			::*		BITS 15-11=CPU TYPE
(2)			::*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
(2)			::*		11/70=06,PDQ=07,Q=10
(2)			::*		BIT 10=REAL TIME CLOCK
(2)			::*		BIT 9=FLOATING POINT PROCESSOR
(2)			::*		BIT 8=MEMORY MANAGEMENT
(2)	001224	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
(2)	001225	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE,BLK#1
(2)			::*		MEM.TYPE BYTE -- (HIGH BYTE)
(2)			::*		900 NSEC CORE=001
(2)			::*		300 NSEC BIPOLAR=002
(2)			::*		500 NSEC MOS=003
(2)	001226	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS,BLK#1
(2)			::*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
(2)	001230	000	\$MAMS2: .BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
(2)	001231	000	\$MTYP2: .BYTE	AMTYP2	::MEM. TYPE,BLK#2
(2)	001232	000000	\$MADR2: .WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
(2)	001234	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
(2)	001235	000	\$MTYP3: .BYTE	AMTYP3	::MEM. TYPE,BLK#3
(2)	001236	000000	\$MADR3: .WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
(2)	001240	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
(2)	001241	000	\$MTYP4: .BYTE	AMTYP4	::MEM. TYPE,BLK#4
(2)	001242	000000	\$MADR4: .WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
(2)	001244	000300	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
(2)	001246	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
(2)	001250	176500	\$BASE: .WORD	ABASE	
(2)			::BASE	ADDRESS	OF EQUIPMENT UNDER TEST
(2)	001252	000017	\$DEV: .WORD	ADEV	::DEVICE MAP
(2)	001254		\$ETEND:		
(2)			.MEXIT		


```

8870
8871 001334
(1)
(1)
(1) 001334 012706 001100
(1) 001340 005026
(1) 001342 022706 001140
(1) 001346 001374
(1) 001350 012706 001100
(1)
(1) 001354 012737 016210 000020
(1) 001362 012737 000300 000022
(1) 001370 012737 016010 000030
(1) 001376 012737 000300 000032
(1)
(1) 001404 012737 017142 000034
(1) 001412 012737 000300 000036
(1) 001420 013737 014416 014410
(1) 001426 005037 001160
(1) 001432 005037 001162
(1) 001436 112737 000001 001115
(1) 001444 012737 001444 001106
(1) 001452 012737 001452 001110
(2)
(2)
(2) 001460 013746 000004
(2) 001464 012737 001520 000004
(2) 001472 012737 177570 001140
(2) 001500 012737 177570 001142
(2) 001506 022777 177777 177424
(2) 001514 001012
(2)
(2) 001516 000403
(2) 001520 012716 001526 64$:
(2) 001524 000002
(2) 001526 012737 000176 001140 65$:
(2) 001534 012737 000174 001142
(2) 001542 012637 000004 66$:
(1)
(2) 001546 005037 001202
(2) 001552 132737 000200 001215
(2) 001560 001403
(2) 001562 012737 001216 001140
(2) 001570
8872
(1)
(1) 001570 005227 177777
(1) 001574 001043
(1) 001576 022737 014450 000042
(1) 001604 001437
(1) 001606 104401 001654
(2)
(2) 001612 005737 000042
(2) 001616 001012
(2) 001620 123727 001214 000001
(2) 001626 001406
  
```

```

START:
.SBTTL INITIALIZE THE COMMON TAGS
::CLEAR THE COMMON TAGS ($CMTAG) AREA
MOV #CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
CLR (R6)+ ;;CLEAR MEMORY LOCATION
CMP #SWR,R6 ;;DONE?
BNE #-6 ;;LOOP BACK IF NO
MOV #STACK,SP ;;SETUP THE STACK POINTER
::INITIALIZE A FEW VECTORS
MOV #SCOPE,@IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
MOV #PR6,@IOTVEC+2 ;;LEVEL 6
MOV #ERROR,@EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
MOV #PR6,@EMTVEC+2 ;;LEVEL 6
::BIT02
MOV #STRAP,@TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
MOV #PR6,@TRAPVEC+2;LEVEL 6
MOV $ENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
MOVB #1,$ERMAX ;;ALLOW ONE ERROR PER TEST
MOV #,$LPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
MOV #,$LPERR ;;SETUP THE ERROR LOOP ADDRESS
::SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
::EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
MOV @ERRVEC,-(SP) ;;SAVE ERROR VECTOR
MOV #64,$@ERRVEC ;;SET UP ERROR VECTOR
MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
CMP #-1,@SWR ;;TRY TO REFERENCE HARDWARE SWR
BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
;;AND THE HARDWARE SWR IS NOT = -1
BR 65$ ;;BRANCH IF NO TIMEOUT
MOV #65$,(SP) ;;SET UP FOR TRAP RETURN
MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
MOV #DISPREG,DISPLAY
MOV (SP)+,@ERRVEC ;;RESTORE ERROR VECTOR
CLR $PASS ;;CLEAR PASS COUNT
BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
BEQ 67$ ;;YES,USE NON-APT SWITCH
MOV #SSWREG,SWR ;;NO,USE APT SWITCH REGISTER
67$:
.SBTTL TYPE PROGRAM NAME
::TYPE THE NAME OF THE PROGRAM IF FIRST PASS
INC #-1 ;;FIRST TIME?
BNE 68$ ;;BRANCH IF NO
CMP #SENDAD,@#42 ;;ACT-11?
BEQ 68$ ;;BRANCH IF YES
TYPE ,69$ ;;TYPE ASCIZ STRING
.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
TST @#42 ;;ARE WE RUNNING UNDER XXDP/ACT?
BNE 70$ ;;BRANCH IF YES
CMPB $ENV,#1 ;;ARE WE RUNNING UNDER APT?
BEQ 70$ ;;BRANCH IF YES
  
```

```
(2) 001630 023727 001140 000176      CMP      SWR,#SWREG      ;;SOFTWARE SWITCH REG SELECTED?  
(2) 001636 001005                    BNE      71$           ;;BRANCH IF NO  
(2) 001640 104406                    GTSWR                    ;;GET SOFT-SWR SETTINGS  
(2) 001642 000403                    BR       71$           ;;  
(2) 001644 112737 000001 001134 70$:  MOVB     #1,$AUTOB     ;;SET AUTO-MODE INDICATOR  
(2) 001652 71$:                       ;;  
(1) 001652 000414                    BR       68$           ;;GET OVER THE ASCIZ  
(1) 69$:  .ASCIZ  <CRLF>*CNDLAAO DLV11-J TEST*<CRLF>  
(1) 001704 68$:
```

```
8874
8875
8876
8877 001704 004737 012700          JSR    PC,SIZE          ;SIZE THE BUS IF $DEV M = 0
8878
8879 001710 005037 014166          CLR    PHASE2          ;INIT FOR TESTS
8880 001714 012737 000001 001206  MOV    #1,$UNIT
8881 001722 005037 014164          CLR    CHAN
8882 001726 005037 014170          CLR    PICNT
8883
8884 001732 012706 001100          LOOP: MOV    #STACK,SP  ;RESET STACK POINTER
8885 001736 004737 013620          JSR    PC,CYCLE       ;SETUP MODULE AND CHANNEL
8886
8887
8888
8889
8890
8891
8892 001742
(4) 001742 012137 001254          MOV    (ADRS)+,DLADD  ;GET UNIT ADDRESS
8893
8894 001746
(4) 001746 011137 001256          MOV    (ADRS),DLVEC  ;GET UNIT VECTOR
8895
8896 001752
(4) 001752 013737 001254 001260  MOV    DLADD,RCSR    ;RCSR = DLADD + 0
8897 001760
(4) 001760 013737 001254 001262  MOV    DLADD,RBUF    RCSR := DLADD
(7) 001766 062737 000002 001262  ADD    #2,RBUF      RBUF := DLADD + #2
8898 001774
(4) 001774 013737 001254 001264  MOV    DLADD,TCSR    TCSR := DLADD + #4
(7) 002002 062737 000004 001264  ADD    #4,TCSR
8899 002010
(4) 002010 013737 001254 001266  MOV    DLADD,TBUF    TBUF := DLADD + #6
(7) 002016 062737 000006 001266  ADD    #6,TBUF
8900 002024
(4) 002024 012705 001332          MOV    #R5STACK,R5  R5 := #R5STACK
8901
8902 002030 012700 001000          MOV    #1000,RO     ;DELAY TO ALLOW PRINT TO FINISH
8903 002034 077001          SOB    RO,          ;BEFORE RESET
8904 002036
(1) 002036 000005          RESET              BRESET
8905 002040
(7) 002040 005237 001204          INC    $DEVCT       LET $DEVCT := $DEVCT + #1
8906 002044
(6) 002044 123727 014166 000001  CMPB   PHASE2,#TRUE  IFB PHASE2 EQ #TRUE THEN
(9) 002052 001003          BNE    $1
8907 002054 000137 007000          JMP    MODTST      ;GO TO PHASE 2 TESTING
8908 002060
(4) 002060 000402          BR     $2          ELSE
(3) 002062          $1:
8909 002062
(4) 002062 005037 001102          CLR    $STNM       LET $STNM := #0
8910 002066
(4) 002066          $2:
ENDIF
```

```
8922  
8923  
(3)  
(4)  
(4)  
(4)  
(4)  
(3)  
(2) 002066 000004  
(2)  
(1) 002070 012737 000002 001160  
(2) 002076 012737 000001 001200  
8928 002104  
(4) 002104 013701 001254  
8929  
8930 002110 012737 013610 000004  
8931 002116 012737 000300 000006  
8932  
8933 002124  
(4) 002124 005037 001270  
8934 002130  
(3) 002130  
8935 002130  
(5) 002130 012737 002136 001110  
8936  
8937 002136  
(4) 002136 005037 013616  
8938  
8939  
8940 002142 005711  
8941 002144  
(6) 002144 005737 013616  
(9) 002150 001401  
8942  
8943 002152  
(1) 002152 104001  
8944 002154  
(4) 002154  
8945 002154  
8946 002154  
(7) 002154 062737 000002 001270  
8947 002162  
(4) 002162 013701 001254  
(7) 002166 063701 001270  
8948 002172  
(3) 002172 023727 001270 000010  
(6) 002200 001353
```

```
*****  
*TEST 1 ADDRESSABILITY  
*  
* THIS TEST VERIFIES THAT ALL 4 REGISTERS OF THE CHANNEL UNDER TEST  
* RESPOND TO THEIR ADDRESSES.  
*  
*****  
TST1: SCOPE  
  
MOV #2,$TIMES ;:DO 2 ITERATIONS  
MOV #1,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX  
LET ADRS := DLADD  
; SET UP INTERRUPT  
MOV #INTSRV,ERRVEC  
MOV #PR6,ERRVEC+2 ;:PRIORITY LOWERED TO 6  
;:TO BE SPECIFIC TO PDP 11/21  
LET I := #0  
REPEAT  
BGNSUB  
;CLEAR FLAG  
LET INTFLAG := #0  
;READ FLAG  
IF INTFLAG NE #0 THEN  
TST @ADRS  
TST INTFLAG  
BEQ $4  
; FATAL ERROR  
ERRDF 1  
ENDIF  
ENDSUB  
LET I := I + #2  
LET ADRS := DLADD + I  
UNTIL I EQ #8.  
$3:  
MOV #64,$LPERR  
CLR INTFLAG  
TST @ADRS  
TST INTFLAG  
BEQ $4  
$4:  
ADD #2,I  
MOV DLADD,ADRS  
ADD I,ADRS  
CMP I,#8.  
BNE $3
```


8972
8977
8978
8979
8980
8981
8986
(3)
(4)
(4)
(3)
(2) 002264 000004
(2)
(1) 002266 012737 000010 001160
(2) 002274 012737 000002 001200
8987
8992 002302
(6) 002302 032737 000010 001220
(9) 002310 001001
8993 002312
(3) 002312 000452
8994 002314
(4) 002314
8995
8996
8997 002314
(5) 002314 012737 002322 001110
8998
8999 002322
(6) 002322 032777 000001 176734
(9) 002330 001401
9000
9001 002332
(1) 002332 104002
9002 002334
(4) 002334
9003 002334
9004
9005
9006 002334
(5) 002334 012737 002342 001110
9007 002342
(7) 002342 052777 000001 176714
9008
9009 002350
(6) 002350 032777 000001 176706
(9) 002356 001001
9010
9011 002360
(1) 002360 104003
9012 002362
(4) 002362
9013 002362
9014
9015
9016 002362

* THE FOLLOWING 3 TESTS TEST ALL 'READ WRITE' BITS

*TEST 2 BREAK - TCSR 0 SET, CLEAR, RESET
* THIS BIT IS THE ONLY ONE IN THIS POSITION
* THAT IS READ AND WRITE.

TST2: SCOPE

```
MOV #10,$TIMES      ;;DO 10 ITERATIONS
MOV #2,$TESTN       ;;SET TEST NUMBER IN APT MAIL BOX
                        IF #BRK NOTSETIN $USWR THEN
BIT #BRK,$USWR
BNE $5
BR TST3              ;;EXIT THIS TEST                EXIT ; BREAK NOT INSTALLED
                        ENDIF
$5:
                        ; SEE IF IT IS CLEAR
                        BGNSUB
MOV #64,$LPERR
                        IF #BREAK SETIN @TCSR THEN
BIT #BREAK,@TCSR
BEQ $6
                        ; BREAK DID NOT RESET IN TCSR
                        ERRHRD 2
ERROR 2
                        ENDIF
$6:
                        ENDSUB
                        ; TRY TO SET BREAK BIT
                        BGNSUB
MOV #64,$LPERR
BIS #BREAK,@TCSR
LET @TCSR := @TCSR SET.BY #BREAK
                        ; STUCK TO 0
                        IF #BREAK NOTSETIN @TCSR THEN
BIT #BREAK,@TCSR
BNE $7
                        ; BREAK DID NOT SET IN TCSR
                        ERRHRD 3
ERROR 3
                        ENDIF
$7:
                        ENDSUB
                        ; TRY TO CLEAR A SET BIT
                        BGNSUB
```



```

(5) 002362 012737 002370 001110      MOV      #64$, $LPERR
9017
9018 002370                                LET      @TCSR := @TCSR CLR.BY #BREAK
(7) 002370 042777 000001 176666      BIC      #BREAK, @TCSR
9019                                ; SHOULD HAVE CLEARED
9020 002376                                IF      #BREAK SETIN @TCSR THEN
(6) 002376 032777 000001 176660      BIT      #BREAK, @TCSR
(9) 002404 001401                        BEQ      $10
9021                                ; BREAK DID NOT CLEAR IN TCSR
9022 002406                                ERRHRD 4
(1) 002406 104004                        ERROR   4
9023 002410                                ENDIF
(4) 002410                                $10:
9024 002410                                ENDSUB
9025
9026                                ; NOW SEE IF RESET CLEARS IT
9027 002410                                BGNSUB
( ) 002410 012737 002416 001110      MOV      #64$, $LPERR
9028
9029 002416                                LET      @TCSR := @TCSR SET.BY #BREAK
(7) 002416 052777 000001 176640      BIS      #BREAK, @TCSR
9030                                ; ISSUE BUS RESET
9031 002424                                BRESËT
(1) 002424 000005                        RESET
9032 002426                                IF      #BREAK SETIN @TCSR THEN
(6) 002426 032777 000001 176630      BIT      #BREAK, @TCSR
(9) 002434 001401                        BEQ      $11
9033                                ; BREAK DID NOT RESET IN TCSR
9034 002436                                ERRHRD 5
(1) 002436 104005                        ERROR   5
9035 002440                                ENDIF
(4) 002440                                $11:
9036 002440                                ENDSUB

```



```

(4) 002564
9080 002564
9081
9082
9083 002564 012737 002572 001110
(5) 002564 012737 002572 001110 MOV #64$, $LPERR
9084
9085 002572 052777 000100 176464 BIS #XMITIE, @TCSR LET @TCSR := @TCSR SET.BY #XMITIE
(7) 002572 052777 000100 176464
9086
9087 002600 000005 RESET ; ISSUE BUS RESET
(1) 002600 000005
9088 002602 032777 000100 176454 BIT #XMITIE, @TCSR BRESÉT
(6) 002602 032777 000100 176454 BEQ $15 IF #XMITIE SET IN @TCSR THEN
(9) 002610 001401
9089
9090 002612 104015 ERROR 15 ; XMIT DID NOT RESET IN TCSR
(1) 002612 104015 ERRHRD 15
9091 002614
(4) 002614
9092 002614
  
```

\$14:

ENDSUB

; NOW SEE IF RESET CLEARS IT
 BGNSUB

\$15:

ENDIF

ENDSUB

9094
 9095
 9104
 (3)
 (4)
 (4)
 (3)
 (2) 002614 000004
 (2)
 (1) 002616 012737 000010 001160
 (2) 002624 012737 000004 001200
 9109
 9110 002632
 (5) 002632 012737 002640 001110
 9111
 9112 002640
 (6) 002640 032777 000100 176412
 (9) 002646 001401
 9113
 9114 002650
 (1) 002650 104035
 9115 002652
 (4) 002652
 9116 002652
 9117
 9118
 9119 002652
 (5) 002652 012737 002660 001110
 9120 002660
 (7) 002660 052777 000100 176372
 9121
 9122 002666
 (6) 002666 032777 000100 176364
 (9) 002674 001001
 9123
 9124 002676
 (1) 002676 104036
 9125 002700
 (4) 002700
 9126 002700
 9127
 9128
 9129 002700
 (5) 002700 012737 002706 001110
 9130
 9131 002706
 (7) 002706 042777 000100 176344
 9132
 9133 002714
 (6) 002714 032777 000100 176336
 (9) 002722 001401
 9134
 9135 002724
 (1) 002724 104037
 9136 002726
 (4) 002726

```

*****
*TEST 4          RCVRIE - RCSR 6          SET, CLEAR, RESET
*                THIS BIT IS THE ONLY ONE IN THIS POSITION
*                THAT IS READ AND WRITE.
*****
TST4:  SCOPE
      MOV      #10,$TIMES          ;;DO 10 ITERATIONS
      MOV      #4,$TESTN          ;;SET TEST NUMBER IN APT MAIL BOX
                                   ; SEE IF IT IS CLEAR
                                   BGNSUB
      MOV      #64,$LPERR
      IF      #RCVRIE SETIN @RCSR THEN
      BIT      #RCVRIE,@RCSR
      BEQ     $16
                                   ; RCVRIE DID NOT RESET IN RCSR
                                   ERRHRD 35
      ENDIF
      ENDSUB
                                   ; TRY TO SET RCVRIE BIT
                                   BGNSUB
      MOV      #64,$LPERR
      BIS      #RCVRIE,@RCSR
      LET     @RCSR := @RCSR SET.BY #RCVRIE
      ; STUCK TO 0
      IF      #RCVRIE NOTSETIN @RCSR THEN
      ; RCVRIE DID NOT SET IN RCSR
      ERRHRD 36
      ENDIF
      ENDSUB
                                   ; TRY TO CLEAR A SET BIT
                                   BGNSUB
      MOV      #64,$LPERR
      BIC     #RCVRIE,@RCSR
      LET     @RCSR := @RCSR CLR.BY #RCVRIE
      ; SHOULD HAVE CLEARED
      IF      #RCVRIE SETIN @RCSR THEN
      BIT      #RCVRIE,@RCSR
      BEQ     $20
                                   ; RCVRIE DID NOT CLEAR IN RCSR
                                   ERRHRD 37
      ENDIF
      ENDSUB
      $16:
      $17:
      $20:
  
```

```

9137 002726                                ENDSUB
9138
9139                                ; NOW SEE IF RESET CLEARS IT
9140 002726                                BGNSUB
(5) 002726 012737 002734 001110          MOV    #64$,SLPERR
9141
9142 002734                                LET    @RCSR := @RCSR SET.BY #RCVRIE
(7) 002734 052777 000100 176316          BIS    #RCVRIE,@RCSR
9143
9144 002742                                ; ISSUE BUS RESET
(1) 002742 000005                          BRESÉT
9145 002744                                IF    #RCVRIE SETIN @RCSR THEN
(6) 002744 032777 000100 176306          BIT    #RCVRIE,@RCSR
(9) 002752 001401                          BEQ    $21
9146
9147 002754                                ; RCVRIE DID NOT RESET IN RCSR
(1) 002754 104040                          ERRHRD 40
9148 002756                                ENDIF
(4) 002756
9149 002756                                ENDSUB

```

\$21:

```

9151
9152
9157          ;*****
          ;*TEST 5          TEST THAT XMITRDY - TCSR 7 - IS SET BY INIT
          ;*****
          TSTS:  SCOPE
          (2) 002756 000004
          (2)
          (1) 002760 012737 000010 001160      MOV  #10,$TIMES      ;;DO 10 ITERATIONS
          (2) 002766 012737 000005 001200      MOV  #5,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
9158
9163 002774
          (5) 002774 012737 003002 001110      MOV  #64$,$LPERR      BGNSUB
9164
9165 003002
          (6) 003002 032777 000200 176254      BIT  #XMITRDY,@TCSR      IF  #XMITRDY NOTSETIN @TCSR THEN
          (9) 003010 001002      BNE  $22
9166
9167
9168
9169 003012
          (1) 003012 104042      ERROR  42      ;RESET SHOULD HAVE SET BIT.
          ;XMITRDY DID NOT SET IN TCSR (AFTER RESE
          ERRHRD 42
9170
9171 003014
          (1) 003014 000005      RESET      ;ISSUE ANOTHER RESET
          BRESET
9172 003016
          (4) 003016          $22:      ENDIF
9173
9174 003016          ENDSUB      ;ALLOW LOOPING ON ERROR
  
```

```

9176
9177
9186
(3)
(4)
(4)
(3)
(2) 003016 000004
(2)
(1) 003020 012737 000010 001160 MOV #10,$TIMES ;;DO 10 ITERATIONS
(2) 003026 012737 000006 001200 MOV #6,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
9191
9192 003034 IF CONSOL EQ #TRUE THEN
(6) 003034 023727 013604 000001 CMP CONSOL,#TRUE
(9) 003042 001001 BNE $23
9193 003044
(3) 003044 000521 BR TST7 ;;EXIT THIS TEST
9194 003046
(4) 003046 $23: EXIT
ENDIF
9195
9196 003046 LET PASS := #0 ;INIT COUNT OF TIMES THRU
(4) 003046 005037 003302 CLR PASS LOOP ; START OF LOOP
9197 003052
(3) 003052 $24: ; MAX OF 2 TIMES THRU
9198
9199 003052 LET ERRORFLAG := #0
(4) 003052 005037 003304 CLR ERRORFLAG LET EXITFLAG := #0
9200 003056
(4) 003056 005037 003306 CLR EXITFLAG
9201 : LOAD TBUF WITH ONE CHARACTER
9202 : WAIT FOR READY TO SET
9203 : (SHOULD BE VERY SHORT WAIT
9204 : SINCE UART DOUBLE BUFFERS ITS INPUT)
9205
9206 :SEND A CHARACTER
9207 003062 LET @TBUF :B= #0
(4) 003062 105077 176200 CLR @TBUF
9208
9209 :WAIT A MAXIMUM
9210 :OF 50 MSEC FOR
9211 :XMIT RDY TO SET IN TCSR
9211 003066 CALL TIMER IN <#500,#XMITRDY,TCSR,#SET>
(3) 003066 010546 MOV R5,-(SP)
(7) 003070 012745 177777 MOV #SET,-(R5)
(6) 003074 013745 001264 MOV TCSR,-(R5)
(5) 003100 012745 000200 MOV #XMITRDY,-(R5)
(4) 003104 012745 000500 MOV #500,-(R5)
(3) 003110 004737 012446 JSR PC,TIMER
(3) 003114 012605 MOV (SP)+,R5
9212
9213 :TIMER RETURNS AN ERROR IF BIT DID
9214 :NOT MEET CONDITION WITHIN TIME LIMIT
9214 003116 IF.ERROR THEN
(6) 003116 103003 BCC $26
9215
9216 :XMIT RDY DID NOT SET IN TCSR
9216 003120 ERRHRD 66
(1) 003120 104066 ERROR
9217 003122 000137 003310 JMP TST7
  
```



```

9218 003126                                     ENDIF
(4) 003126
9219 003126 105077 176134 $26: CLR B @TBUF ;SHIP 1'ST CHAR
9220 003132 105777 176126 1$: TSTB @TCSR ;WAIT FOR RDY
9221 003136 100375 BPL 1$
9222 ; LOAD TBUF WITH A SECOND CHARACTER (TO DOUBLE BUFFER)
9223 ; CHECK IMMEDIATELY THAT XMITRDY IS CLEAR
9224 ; AND THEN WAIT FOR IT TO SET
9225
9226 ;SEND SECOND CHARACTER
9227 003140 LET @TBUF :B= #0
(4) 003140 105077 176122 CLR B @TBUF
9228 003144 000240 NOP ; GIVE IT TIME TO CLEAR
9229 ; XMITRDY SHOULD HAVE CLEARED UPON
9230 ; RECEIPT OF A CHARACTER
9231 003146 IF #XMITRDY SET IN @TCSR THEN
(6) 003146 032777 000200 176110 BIT #XMITRDY,@TCSR
(9) 003154 001404 BEQ $27
9232 ; XMITRDY DID NOT CLEAR IN TCSR
9233 ; WILL RESULT IN ERR 67 IF FAILS 2X
9234 003156 LET ERRORFLAG := #SET
(4) 003156 012737 177777 003304 MOV #SET,ERRORFLAG
9235 ; DEFER ERROR TYPEOUT
9236
9237 003164 ELSE
(4) 003164 000416 $27: BR $30
(3) 003166
9238 ;WAIT A MAXIMUM
9239 ;OF 100 MSEC FOR
9240 ;XMIT RDY TO SET IN TCSR
9241 003166 CALL TIMER IN <#1000,#XMITRDY,TCSR,#SET>
(3) 003166 010546 MOV R5,-(SP)
(7) 003170 012745 177777 MOV #SET,-(R5)
(6) 003174 013745 001264 MOV TCSR,-(R5)
(5) 003200 012745 000200 MOV #XMITRDY,-(R5)
(4) 003204 012745 001000 MOV #1000,-(R5)
(3) 003210 004737 012446 JSR PC,TIMER
(3) 003214 012605 MOV (SP)+,R5
9242 003216 IF.ERROR THEN
(6) 003216 103001 BCC $31
9243 ;XMIT RDY DID NOT SET IN TCSR
9244 003220 ERRHRD 70
(1) 003220 104070 ERROR 70
9245 003222 ENDIF
(4) 003222 $31: ENDIF ; OF DEFERED ERROR CALL
9246 003222 $30: IF ERRORFLAG EQ #SET THEN
(4) 003222
9247 003222 (6) 003222 023727 003304 177777 CMP ERRORFLAG,#SET
(9) 003230 001013 BNE $32
9248 003232 LET PASS := PASS + #1
(7) 003232 005237 003302 INC PASS
9249 003236 IF PASS GT #1 THEN
(6) 003236 023727 003302 000001 CMP PASS,#1
(9) 003244 003404 BLE $33
9250 ; CALL ERROR IF 2ND TRY
  
```



```
9265
9266
9275
(3)
(4)
(4)
(3)
(2) 003310 000004
(2)
(1) 003312 012737 000010 001160
(2) 003320 012737 000007 001200
9276
9281 003326
(6) 003326 032737 000020 001220
(8) 003334 001404
(6) 003336 023727 013604 000001
(9) 003344 001001
(6) 003346
9282 003346
(3) 003346 000434
9283 003350
(4) 003350
9284
9285 003350
(5) 003350 012737 003356 001110
9286
9287
9288 003356
(4) 003356 105077 175704
9289
9290
9291
9292
9293 003362
(3) 003362 010546
(7) 003364 012745 177777
(6) 003370 013745 001260
(5) 003374 012745 000200
(4) 003400 012745 000500
(3) 003404 004737 012446
(3) 003410 012605
9294
9295
9296 003412
(6) 003412 103001
9297
9298 003414
(1) 003414 104071
9299 003416
(4) 003416
9300
9301 003416
9302
9303 003416
(5) 003416 012737 003424 001110
9304
```

```
*****
*TEST 7 TEST THAT OUTPUTTING A CHAR FROM TBUF (WITH WRAP CONNECTED)
* RESULTS IN RCVRDONE SETTING WITHIN A REASONABLE AMOUNT OF TIME
* AND THAT RESET CLEARS THE BIT.
*****
TST7: SCOPE
MOV #10,$TIMES ;;DO 10 ITERATIONS
MOV #7,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
IF #WRAP NOTSET IN $USWR OR CONSOL EQ #TRUE THEN
BIT #WRAP,$USWR
BEQ $35
CMP CONSOL,#TRUE
BNE $36
$35: BR TST10 ;;EXIT THIS TEST
EXIT
ENDIF
$36:
BGNSUB
MOV #64,$SLPERR ; SEND A CHARACTER AND LET IT WRAP AROUND
; LET @TBUF :B= #0
; WAIT A MAXIMUM OF 50 MSEC
; FOR RCVR DONE TO SET IN
; RCSR
CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
MOV R5,-(SP)
MOV #SET,-(R5)
MOV RCSR,-(R5)
MOV #RCVRDONE,-(R5)
MOV #500,-(R5)
JSR PC,TIMER
MOV (SP)+,R5
;DIDN'T SET IN TIME
IF.ERROR THEN
; RCVRDONE DID NOT SET IN RCSR
ERRHRD 71
ENDIF
$37:
ENDSUB
BGNSUB
MOV #64,$SLPERR ; NOW THAT IT IS SET SEE IF IT CAN BE RESET
```

```
9305 003424                                BRESET  
  (1) 003424 000005                        RESET  
9306  
9307 003426                                IF #RCVRDONE SETIN @RCSR THEN  
  (6) 003426 032777 000200 175624        BIT #RCVRDONE,@RCSR  
  (9) 003434 001401                        BEQ $40  
9308  
9309 003436                                ; RCVRDONE DID NOT RESET IN RCSR.  
  (1) 003436 104072                        ERRHRD 72  
9310 003440                                ENDIF  
  (4) 003440                                $40:  
9311 003440                                ENDSUB
```

```

9313
9314
9319          ;:*****
(3)          ;*TEST 10          TEST THAT RCVRDONE IS CLEARED BY SETTING READER ENABLE
(3)          ;:*****
(2) 003440 000004          TST10: SCOPE
(2)
(1) 003442 012737 000010 001160          MOV #10,$TIMES          ;;DO 10 ITERATIONS
(2) 003450 012737 000010 001200          MOV #10,$TESTN          ;;SET TEST NUMBER IN APT MAIL BOX
9320
9325 003456          IF #WRAP NOTSETIN $USWR OR CONSOL EQ #TRUE THEN
(6) 003456 032737 000020 001220          BIT #WRAP,$USWR
(8) 003464 001404          BEQ $41
(6) 003466 023727 013604 000001          CMP CONSOL,#TRUE
(9) 003474 001001          BNE $42
(6) 003476          $41:
9326 003476          BR TST11          ;;EXIT THIS TEST
(3) 003476 000433          EXIT
9327 003500          ENDIF
(4) 003500          $42:
9328
9329 003500          BGNSUB
(5) 003500 012737 003506 001110          MOV #64,$LPERR          ; OUTPUT A CHARACTER AND WAIT FOR XMITRDY TO SET.
9330
9331
9332          ; OUTPUT A CHARACTER
9333 003506          LET @TBUF :B= #0
(4) 003506 105077 175554          CLRB @TBUF
9334          ; WAIT MAXIMUM OF 500 MSEC
9335          ; FOR RCVRDONE TO SET IN
9336          ; RCSR
9337          CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
(3) 003512          MOV R5,-(SP)
(7) 003514 012745 177777          MOV #SET,-(R5)
(6) 003520 013745 001260          MOV RCSR,-(R5)
(5) 003524 012745 000200          MOV #RCVRDONE,-(R5)
(4) 003530 012745 000500          MOV #500,-(R5)
(3) 003534 004737 012446          JSR PC,TIMER
(3) 003540 012605          MOV (SP)+,R5
9338          ; DID IT BECOME READY?
9339 003542          IF.ERROR THEN
(6) 003542 103001          BCC $43
9340          ;RCVRDONE DID NOT SET IN RCSR
9341 003544          ERRHRD 25
(1) 003544 104025          ERROR 25
9342          ; SET IT BACK TO CONTINUE
9343 003546          ENDIF
(4) 003546          $43:
9344 003546          ENDSUB
9345
9346          ;NOW THAT IT IS SET LETS SEE IF SETTING
9347          ;READER ENABLE CLEARS RCVRDONE
9348
9349 003546          LET @RCSR := @RCSR SET.BY #RDRRUN
(7) 003546 052777 000001 175504          BIS #RDRRUN,@RCSR
9350 003554          IF #RCVRDONE SETIN @RCSR THEN
  
```

CNDLAAO DLV11-J TEST MACY11 30(1046) 23-DEC-82 13:56 PAGE 170-1^{E 4}
CNDLAA.P11 23-DEC-82 13:55 T10 TEST THAT RCVRDONE IS CLEARED BY SETTING READER ENABLE SEQ 0043

(6)	003554	032777	000200	175476	BIT	#RCVRDONE,@RCSR	
(9)	003562	001401			BEQ	\$44	
9351							;RCVRDONE DID NOT CLEAR IN RCSR
9352	003564						ERRHRD 26
(1)	003564	104026			ERROR	26	
9353							; SET IT BACK TO CONTINUE
9354	003566						ENDIF
(4)	003566				\$44:		

```

9356
9357
9362 *****
(3) *TEST 11 TEST THAT RCVRDONE IS CLEARED BY READING RBUF *****
(3) *****
(2) 003566 000004 TST11: SCOPE
(2)
(1) 003570 012737 000010 001160 MOV #10,$TIMES ;;DO 10 ITERATIONS
(2) 003576 012737 000011 001200 MOV #11,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
9363
9368 003604 IF #WRAP NOTSET IN $USWR OR CONSOL EQ #TRUE THEN
(6) 003604 032737 000020 001220 BIT #WRAP,$USWR
(8) 003612 001404 BEQ $45
(6) 003614 023727 013604 000001 CMP CONSOL,#TRUE
(9) 003622 001001 BNE $46
(6) 003624 $45:
9369 003624 EXIT
(3) 003624 000432 BR TST12 ;;EXIT THIS TEST
9370 003626 ENDF
(4) 003626 $46:
9371
9372 003626 BGNSUB
(5) 003626 012737 003634 001110 MOV #64,$LPERR
9373 ; OUTPUT A CHARACTER AND WAIT FOR RCVRDONE TO SET.
9374
9375 ; OUTPUT A CHARACTER
9376 003634 LET @TBUF :B= #0
(4) 003634 105077 175426 CLRB @TBUF
9377 ; WAIT MAXIMUM OF 500 MSEC
9378 ; FOR RCVRDONE TO SET IN
9379 ; RCSR
9380 003640 CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
(3) 003640 010546 MOV R5,-(SP)
(7) 003642 012745 177777 MOV #SET,-(R5)
(6) 003646 013745 001260 MOV RCSR,-(R5)
(5) 003652 012745 000200 MOV #RCVRDONE,-(R5)
(4) 003656 012745 000500 MOV #500,-(R5)
(3) 003662 004737 012446 JSR PC,TIMER
(3) 003666 012605 MOV (SP)+,R5
9381
9382 003670 ; DID IT BECOME READY?
(6) 003670 103001 BCC $47 IF.ERROR THEN
9383 ;RCVRDONE DID NOT SET IN RCSR
9384 003672 ERRHRD 73
(1) 003672 104073 ERROR 73
9385 ; SET IT BACK TO CONTINUE
9386 003674 ENDF
(4) 003674 $47:
9387 003674 ENDSUB
9388
9389 ; NOW THAT IT IS SET LETS SEE IF READING THE
9390 ; BUFFER CLEARS RCVRDONE.
9391
9392 ;READ BUFFER
9393 003674 LET R0 :B= @RBUF
(4) 003674 117700 175362 MOVB @RBUF,R0
  
```


9394
9395 003700
 (6) 003700 032777 000200 175352
 (9) 003706 001401
9396
9397 003710
 (1) 003710 104074
9398
9399 003712
 (4) 003712
\$50:

IF #RCVRDONE SETIN @RCSR THEN

 :RCVRDONE DID NOT CLEAR IN RCSR
 ERRHRD 74

 : SET IT BACK TO CONTINUE
ENDIF

```

9401
9402
9407      ::*****
(3)      ::*TEST 12      TEST THE OVERRUN & ERROR BITS - RBUF 14
(3)      ::*****
(2) 003712 000004      TST12: SCOPE
(2)
(1) 003714 012737 000010 001160      MOV #10,$TIMES      ;;DO 10 ITERATIONS
(2) 003722 012737 000012 001200      MOV #12,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
9408
9413 003730                                IF CONSOL EQ #0 THEN
(6) 003730 005737 013604      TST CONSOL
(9) 003734 001007      BNE $51
9414 003736                                IF #WRAP SETIN $USWR THEN
(6) 003736 032737 000020 001220      BIT #WRAP,$USWR
(9) 003744 001401      BEQ $52
9415
9416 003746                                ;; NULL ---EXECUTE TEST
(4) 003746 000401      BR $53      ELSE
(3) 003750      $52:
9417 003750                                EXIT
(3) 003750 000524      BR TST13      ;;EXIT THIS TEST
9418 003752                                ENDIF
(4) 003752      $53:
9419 003752                                ELSE
(4) 003752 000401      BR $54
(3) 003754      $51:
9420 003754                                EXIT
(3) 003754 000522      BR TST13      ;;EXIT THIS TEST
9421 003756                                ENDIF
(4) 003756      $54:
9422
9423
9424
9425 003756                                BGNSUB
(5) 003756 012737 003764 001110      MOV #64,$LPERR
9426                                ;OUTPUT 2 CHARACTERS
9427                                ;THIS SHOULD AN CAUSE OVERRUN ERROR.
9428
9429                                ;OUTPUT 1 CHARACTER
9430 003764                                LET @TBUF :B= #0
(4) 003764 105077 175276      CLRB @TBUF
9431
9432                                CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
(3) 003770
(7) 003772 010546      MOV R5,-(SP)
(6) 003776 012745 177777      MOV #SET,-(R5)
(5) 004002 013745 001260      MOV RCSR,-(R5)
(4) 004006 012745 000200      MOV #RCVRDONE,-(R5)
(3) 004012 004737 000500      MOV #500,-(R5)
(3) 004016 012605      JSR PC,TIMER
9433      MOV (SP)+,R5
9434
9435                                ;DID IT SET IN TIME?
(6) 004020 103001      BCC $55      IF.ERROR THEN
9436                                ;RCVRDONE DID NOT SET IN RCSR
  
```

```

9437 004022 ERRHRD 16
(1) 004022 104016 ERROR 16
9438 004024 ENDIF
(4) 004024 $55:
9439
9440 ;OUTPUT 2ND CHARACTER
9441 004024 LET @TBUF :B= #0
(4) 004024 105077 175236 CLRB @TBUF
9442 ;LET OVERRUN HAPPEN
9443 004030 WAITMS 300.
(4) 004030 010546 MOV R5, -(SP)
(5) 004032 012745 000454 MOV #300, -(R5)
(4) 004036 004737 012620 JSR PC, WAIT
(4) 004042 012605 MOV (SP)+, R5
9444
9445 ;READ BUFFER AND ERROR BITS
9446 004044 LET R4 := @RBUF
(4) 004044 017704 175212 MOV @RBUF, R4
9447
9448 ;IT DIDN'T SET
9449 004050 IF #ORERR NOTSET IN R4 THEN
(6) 004050 032704 040000 BIT #ORERR, R4
(9) 004054 001002 BNE $56
9450 ;ORERR DID NOT SET IN RBUF
9451 004056 ERRHRD 101
(1) 004056 104101 ERROR 101
9452
9453 ;NO USE COMPOUNDING ERRORS
9454 004060 EXIT
(3) 004060 000460 BR TST13 ;:EXIT THIS TEST
9455 004062 ENDIF
(4) 004062 $56:
9456 004062 ENDSUB
9457
9458 ;NOW SEE IF ERROR BIT SET WITH OVERRUN ERROR:
9459 004062 BGNSUB
(5) 004062 012737 004070 001110 MOV #64$, $LPERR
9460 004070 IF #ERROR NOTSET IN R4 THEN
(6) 004070 032704 100000 BIT #ERROR, R4
(9) 004074 001002 BNE $57
9461
9462 ;ERROR DID NOT SET IN RBUF
9463 004076 ERRHRD 102
(1) 004076 104102 ERROR 102
9464
9465 ;-WHEN ORERR SET.
9466 ;GET OUT NOW.
9467 004100 EXIT
(3) 004100 000450 BR TST13 ;:EXIT THIS TEST
9468 004102 ENDIF
(4) 004102 $57:
9469 004102 ENDSUB
9470
9471 004102 BGNSUB
(5) 004102 012737 004110 001110 MOV #64$, $LPERR
9472 ;CHECK REAL RBUF TO SEE IF ORERR IS STILL SET.

```

```

9473
9474 004110                                IF #ORERR NOTSETIN @RBUF THEN
(6) 004110 032777 040000 175144          BIT   #ORERR,@RBUF
(9) 004116 001002                                BNE   $60
9475
9476                                ;READING RBUF CLEARED ORERR.
9477 004120                                ERRHRD 103
(1) 004120 104103          ERROR 103
9478                                ;SKIP REST OF TEST
9479 004122                                EXIT
(3) 004122 000437          BR     TST13          ;;EXIT THIS TEST
9480 004124                                ENDIF
(4) 004124                                $60:
9481 004124                                ENDSUB
9482
9483 004124                                BGNSUB
(5) 004124 012737 004132 001110          MOV   #64,$LPERR
9484                                ;READING RBUF ABOVE SHOULD ENABLE ERROR TO BE CLEARED
9485                                ;BY NEXT TRANSFER.
9486                                ;NOW SEE IF THEY CLEAR WHEN ANOTHER CHAR. IS RECEIVED
9487
9488                                ;SEND A CHARACTER AROUND.
9489 004132                                LET @TBUF :B= #0
(4) 004132 105077 175130          CLRB  @TBUF
9490 004136                                CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
(3) 004136 010546          MOV   R5,-(SP)
(7) 004140 012745 177777          MOV   #SET,-(R5)
(6) 004144 013745 001260          MOV   RCSR,-(R5)
(5) 004150 012745 000200          MOV   #RCVRDONE,-(R5)
(4) 004154 012745 000500          MOV   #500,-(R5)
(3) 004160 004737 012446          JSR   PC,TIMER
(3) 004164 012605          MOV   (SP)+,R5
9491
9492                                ;DID IT SET IN TIME?
9493 004166                                IF.ERROR THEN
(6) 004166 103001          BCC   $61
9494                                ;RCVRDONE DID NOT SET IN RCSR
9495 004170                                ERRHRD 20
(1) 004170 104020          ERROR 20
9496 004172                                ENDIF
(4) 004172                                $61:
9497
9498                                IF #ORERR SETIN @RBUF THEN
(6) 004172 032777 040000 175062          BIT   #ORERR,@RBUF
(9) 004200 001402                                BEQ   $62
9499
9500                                ;ORERR DID NOT CLEAR IN RBUF
9501 004202                                ERRHRD 104
(1) 004202 104104          ERROR 104
9502
9503                                ;-AFTER RECEIVING ANOTHER CHAR
9504 004204                                ;SKIP AROUND REST
(3) 004204 000406          BR     TST13          ;;EXIT THIS TEST
9505 004206                                EXIT
(4) 004206                                $62:
9506                                ENDIF

```

```

CNDLAAO DLV11-J TEST MACY11 30(1046) 23-DEC-82 13:56 PAGE 172-3K 4
CNDLAA.P11 23-DEC-82 13:55 T12 TEST THE OVERRUN & ERROR BITS - RBUF 14 SEQ 0049

9507 004206 IF #ERROR SETIN @RBUF THEN
(6) 004206 032777 100000 175046 BIT #ERROR,@RBUF
(9) 004214 001401 BEQ $63
9508 ;ERROR DID NOT CLEAR IN RBUF
9509 004216 ERRHRD 105
(1) 004216 104105 ERROR 105
9510
9511 004220 ENDIF
(4) 004220 $63:
9512 004220 ENDSUB
9513 004220 EXIT
(3) 004220 000400 BR TST13 ;;EXIT THIS TEST

```

9515
 9516
 9528
 (3)
 (4)
 (4)
 (4)
 (4)
 (4)
 (3)
 (2)
 (2)
 (1)
 (2)
 9533
 9534
 (4)
 9535
 9536
 9537
 (4)
 9538
 9539
 (7)
 9540
 9541
 9542
 9543
 (5)
 9544
 9545
 (3)
 (7)
 (6)
 (5)
 (4)
 (3)
 (3)
 9546
 9547
 9548
 (7)
 9549
 9550
 9551
 9552
 9553
 9554
 (7)
 9555
 9556
 (3)
 (7)
 (6)
 (5)
 (4)

004222 000004
 004224 012737 000010 001160
 004232 012737 000013 001200
 004240 005037 013616
 004244 013703 001256
 004250 062703 000004
 004254 012723 013610
 004260 012713 000300
 004264 012737 004272 001110
 004272 010546
 004274 012745 177777
 004300 013745 001264
 004304 012745 000200
 004310 012745 000500
 004314 004737 012446
 004320 012605
 004322 042777 000100 174734
 004330
 004342 052777 000100 174714
 004350 010546
 004352 012745 177777
 004356 012745 013616
 004362 012745 000001
 004366 012745 000500

```

*****
*TEST 13      TRANSMITTER INTERRUPT LOGIC TEST
*              LOGICALLY THIS IS 4 SEPARATE TESTS
*              A) DOES TRANSMITTER INTERRUPT LOGIC WORK
*              B) AT PRIORITY OF 0
*              C) AND ONLY ONCE
*              D) BUT NOT WITH INTERRUPT ENABLE CLEAR
*****
TST13:  SCOPE
        MOV     #10,$TIMES      ;;DO 10 ITERATIONS
        MOV     #13,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX
                                ;CLEAR 'INTERRUPT OCCURED' FLAG
                                LET INTFLAG := #0
        CLR     INTFLAG
                                ;GET VECTOR ADDRESS
                                LET R3 := DLVEC
                                ;FOR THE TRANSMITTER
                                LET R3 := R3 + #4
                                ;SET VECTOR TO POINT TO TRANS.SRV AT PRI
        ADD     #4,R3
        MOV     #INTSRV,(R3)+
        MOV     #PR6,(R3)
        MOV     #64,$LPERR
                                ;: MAKE SURE THAT TRANSMITTER READY IS SET
                                CALL TIMER IN <#500,#XMITRDY,TCSR,#SET>
        MOV     R5,-(SP)
        MOV     #SET,-(R5)
        MOV     TCSR,-(R5)
        MOV     #XMITRDY,-(R5)
        MOV     #500,-(R5)
        JSR     PC,TIMER
        MOV     (SP)+,R5
                                ;CLEAR INTERRUPT ENABLE
                                LET @TCSR := @TCSR CLR.BY #XMITIE
                                ;SET IT TO 0
        SETPRI #PRO
                                ;NOW SET I.E. BIT
                                LET @TCSR := @TCSR SET.BY #XMITIE
                                CALL TIMER IN <#500,#1,#INTFLAG,#SET>
        MOV     R5,-(SP)
        MOV     #SET,-(R5)
        MOV     #INTFLAG,-(R5)
        MOV     #1,-(R5)
        MOV     #500,-(R5)
  
```

```

(3) 004372 004737 012446      JSR    PC,TIMER
(3) 004376 012605      MOV    (SP)+,R5
9557
9558
9559 004400
(6) 004400 103001      BCC    $64
9560
9561 004402
(1) 004402 104106      ERROR  106
9562 004404
(4) 004404      $64:
9563
9564
9565 004404
(4) 004404 010546      MOV    R5, -(SP)
(5) 004406 012745 000764      MOV    #500, -(R5)
(4) 004412 004737 012620      JSR    PC,WAIT
(4) 004416 012605      MOV    (SP)+,R5
9566
9567
9568 004420
(6) 004420 023727 013616 000001      CMP    INTFLAG,#1
(9) 004426 003401      BLE    $65
9569
9570 004430
(1) 004430 104107      ERROR  107
9571 004432
(4) 004432      $65:
9572 004432
9573
9574 004432
(5) 004432 012737 004440 001110      MOV    #64$, $LPERR
9575
9576 004440
(7) 004440 042777 000100 174616      BIC    #XMITIE,@TCSR
9577
9578 004446
(4) 004446 005037 013616      CLR    INTFLAG
9579
9580
9581 004452
(4) 004452 005077 174610      CLR    @TBUF
9582
9583 004456
(3) 004456 010546      MOV    R5, -(SP)
(7) 004460 012745 177777      MOV    #SET, -(R5)
(6) 004464 012745 013616      MOV    #INTFLAG, -(R5)
(5) 004470 012745 000001      MOV    #1, -(R5)
(4) 004474 012745 001000      MOV    #1000, -(R5)
(3) 004500 004737 012446      JSR    PC,TIMER
(3) 004504 012605      MOV    (SP)+,R5
9584
9585 004506 103401      BCS    1$
9586
9587 004510
(1) 004510 104110      ERROR  110

```

```

;DID IT SET IN TIME?
IF.ERROR THEN
;INTERRUPT DID NOT OCCUR
ERRHRD 106
ENDIF

;LET POSSIBLE 2'ND INTERR OCCUR
WAITMS 500.

;DID EXACTLY 1 INTERRUPT OCCUR
IF INTFLAG GT #1 THEN
;TRANSMITTER INTERRUPTED TWICE
ERRHRD 107
ENDIF

ENDSUB
;INTERRUPT WITHOUT INTERRUPT ENABLE SET
BGNSUB

;CLEAR INTERRUPT ENABLE
LET @TCSR := @TCSR CLR.BY #XMITIE

;CLEAR 'INTERRUPT OCCURED' FLAG
LET INTFLAG := #0

;NO INTERRUPTS SHOULD OCCUR, PSW STILL AT 0.
;DARE IT TO HAPPEN
LET @TBUF := #0

;SEE IF INT FLAG EVER SETS
CALL TIMER IN <#1000,#1,#INTFLAG,#SET>

;DID IT SET DURING TIMER?
;BR IF NO
;INTERR STILL OCCURED WITH IE DISABLED
ERRHRD 110

```

CNDLAAO DLV11-J TEST MACY11 30(1046) 23-DEC-82 13:56 PAGE 173-2^{N 4}
CNDLAA.P11 23-DEC-82 13:55 T13 TRANSMITTER INTERRUPT LOGIC TEST

SEQ 0052

9588 004512

18:


```

9590
9591
9601          ;*****
(3)          ;*TEST 14      RECEIVER INTERRUPT LOGIC TEST
(4)          ;*                THIS TEST COVERS ALL OF THE RECEIVER
(4)          ;*                SIDE OF THE INTERRUPT LOGIC IN
(4)          ;*                CHARACTER MODE.
(3)          ;*****
(2) 004512 000004      TST14: SCOPE
(2)
(1) 004514 012737 000010 001160      MOV      #10,$TIMES      ;;DO 10 ITERATIONS
(2) 004522 012737 000014 001200      MOV      #14,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
9606 004530                                IF #WRAP NOTSETIN $USWR OR CONSOL EQ #TRUE THEN
(6) 004530 032737 000020 001220      BIT      #WRAP,$USWR
(8) 004536 001404                                BEQ      $66
(6) 004540 023727 013604 000001      CMP      CONSOL,#TRUE
(9) 004546 001002                                BNE      $67
(6) 004550                                $66:
9607 004550 000137 005046      JMP      TST15          ; EXIT TEST
9608 004554                                $67:
(4) 004554                                ; ENDIF
9609
9610                                ;CLEAR INTERRUPT OCCURED FLAG
9611                                ;SET UP RECEIVER INTER.VECTOR
9612 004554                                SETVEC DLVEC,#INTSRV,#PR6
(5) 004554 010146      MOV      R1,-(SP)
(5) 004556 013701 001256      MOV      DLVEC,R1
(5) 004562 012721 013610      MOV      #INTSRV,(R1)+
(5) 004566 012711 000300      MOV      #PR6,(R1)
(5) 004572 012601      MOV      (SP)+,R1
9613                                ;PRIORITY 0 AND MULTIPLE INTERRUPT TEST.-RCVRIE
9614 004574                                BGNSUB
(5) 004574 012737 004602 001110      MOV      #64,$SLPERR
9615 004602                                LET INTFLAG := #0
(4) 004602 005037 013616      CLR      INTFLAG
9616                                ;CLEAR INTERRUPTS
9617 004606                                LET @RCSR := @RCSR CLR.BY #RCVRIE
(7) 004606 042777 000100 174444      BIC      #RCVRIE,@RCSR
9618                                ;CHANGE PRIORITY
9619                                ;...TO 0
9620 004614      SETPRI #PRO
9621
9622                                ;SEND A CHARACTER
9623 004626                                LET @TBUF :B= #0
(4) 004626 105077 174434      CLRB    @TBUF
9624                                ;WAIT A MAXIMUM
9625                                ;OF 50 MSEC FOR
9626                                ;XMIT RDY TO SET IN TCSR
9627 004632                                CALL TIMER IN <#500,#RCVRDONE,TCSR,#SET>
(3) 004632 010546      MOV      R5,-(SP)
(7) 004634 012745 177777      MOV      #SET,-(R5)
(6) 004640 013745 001264      MOV      TCSR,-(R5)
(5) 004644 012745 000200      MOV      #RCVRDONE,-(R5)
(4) 004650 012745 000500      MOV      #500,-(R5)
(3) 004654 004737 012446      JSR      PC,TIMER
(3) 004660 012605      MOV      (SP)+,R5
  
```

```

9628
9629 004662          ;SET INTERRUPT ENABLE
      (7) 004662 052777 000100 174370  BIS  #RCVRIE,@RCR
9630
9631          ;LET IT COME IN.
9632 004670          CALL TIMER IN <#500,#1,#INTFLAG,#SET>
      (3) 004670 010546          MOV  R5,-(SP)
      (7) 004672 012745 177777    MOV  #SET,-(R5)
      (6) 004676 012745 013616    MOV  #INTFLAG,-(R5)
      (5) 004702 012745 000001    MOV  #1,-(R5)
      (4) 004706 012745 000500    MOV  #500,-(R5)
      (3) 004712 004737 012446    JSR  PC,TIMER
      (3) 004716 012605          MOV  (SP)+,R5
9633
9634          ;DID IT SET IN TIME?
9635 004720          IF.ERROR THEN
      (6) 004720 103001          BCC  $70
9636          ;INTERRUPT DID NOT OCCUR
9637 004722          ERRHRD 111
      (1) 004722 104111          ERROR 111
9638 004724          ENDIF
      (4) 004724          $70:
9639          ;LET POSSIBLE 2'ND INTERR OCCUR
9640 004724          WAITMS 500
      (4) 004724 010546          MOV  R5,-(SP)
      (5) 004726 012745 000500    MOV  #500,-(R5)
      (4) 004732 004737 012620    JSR  PC,WAIT
      (4) 004736 012605          MOV  (SP)+,R5
9641
9642          ;EXACTLY 1 INTERRUPT?
9643 004740          IF INTFLAG GT #1 THEN
      (6) 004740 023727 013616 000001  CMP  INTFLAG,#1
      (9) 004746 003401          BLE  $71
9644          ;RECEIVER INTERRUPTED TWICE
9645 004750          ERRHRD 112
      (1) 004750 104112          ERROR 112
9646 004752          ENDIF
      (4) 004752          $71:
9647 004752          ENDSUB
9648
9649
9650
9651
9652
9653
9654          ;INTERRUPT WITHOUT IE SET.
9655 004752          BGENSUB
      (5) 004752 012737 004760 001110  MOV  #64$, $LPERR
9656
9657          ;CLEAR INTERRUPT
9658 004760          LET @RCR := @RCR CLR.BY #RCVRIE
      (7) 004760 042777 000100 174272  BIC  #RCVRIE,@RCR
9659
9660          ;CLEAR INTERRUPT FLAG
      (4) 004766 005037 013616    CLR  INTFLAG
9661          ; SEND A CHARACTER

```

```

9662 004772          LET @TBUF :B= #0
(4) 004772 105077 174270      CLRB  @TBUF
9663                                     ; DARE IT
9664
9665 004776          CALL TIMER IN <#500,#1,#INTFLAG,#CLR>
(3) 004776 010546          MOV   R5,-(SP)
(7) 005000 012745 000000      MOV   #CLR,-(R5)
(6) 005004 012745 013616      MOV   #INTFLAG,-(R5)
(5) 005010 012745 000001      MOV   #1,-(R5)
(4) 005014 012745 000500      MOV   #500,-(R5)
(3) 005020 004737 012446      JSR   PC,TIMER
(3) 005024 012605          MOV   (SP)+,R5
9666                                     ;DID IT CLEAR IN TIME?
9667 005026          IF.ERROR THEN
(6) 005026 103001          BCC   $72
9668                                     ;INTERR STILL OCCURED WITH IE DISABLED
9669 005030          ERRHRD 113
(1) 005030 104113          ERROR 113
9670 005032          ENDIF
(4) 005032          $72: .
9671 005032          ENDSUB
9672 005032          SETPRI #PR6 ;RAISE CPU PRIORITY
9673                                     ;CLEAR THE WORLD
9674 005044          RESET      BRFSET
(1) 005044 000005
9675
9676
    
```

```

9678
9679
9684 *****
(3) *TEST 15 TEST DATA WRAP AROUND: FLAG MODE
(3) *****
(2) 005046 000004 TST15: SCOPE
(2)
(1) 005050 012737 000001 001160 MOV #1,$TIMES ;;DO 1 ITERATION
(2) 005056 012737 000015 001200 MOV #15,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
9689 005064 IF #WRAP NOTSETIN $USWR OR CONSOL EQ #TRUE THEN
(6) 005064 032737 000020 001220 BIT #WRAP,$USWR
(8) 005072 001404 BEQ $73
(6) 005074 023727 013604 000001 CMP CONSOL,#TRUE
(9) 005102 001001 BNE $74
(6) 005104 $73:
9690 ;CAN'T TEST WITHOUT A WRAP
9691 005104 BR TST16 EXIT
(3) 005104 000506 ;;EXIT THIS TEST
9692 005106 ENDF
(4) 005106 $74:
9693 005106 BRESET
(1) 005106 000005 RESET
9694 ;BINARY COUNT PATTERN
9695 005110 INCR R2 FROM #0 TO #377 BY #1
(4) 005110 005002 CLR R2
(5) 005112 000401 BR $75
(4) 005114 $76:
(8) 005114 005202 INC R2
(5) 005116 $75:
(5) 005116 020227 000377 CMP R2,#377
(7) 005122 003077 BGT $77
9696
9697
9698
9699 ; MAKE SURE IT'S READY
9700 CALL TIMER IN <#500,#XMITRDY,TCSR,#SET>
(3) 005124 MOV R5,-(SP)
(7) 005126 012745 177777 MOV #SET,-(R5)
(6) 005132 013745 001264 MOV TCSR,-(R5)
(5) 005136 012745 000200 MOV #XMITRDY,-(R5)
(4) 005142 012745 000500 MOV #500,-(R5)
(3) 005146 004737 012446 JSR PC,TIMER
(3) 005152 012605 MOV (SP)+,R5
9701 005154 IF.ERROR THEN
(6) 005154 103002 BCC $100
9702 ; TRANSMITTER NEVER BECAME READY
9703 ERRHRD 123
(1) 005156 104123 ERROR 123
9704 005160 EXIT
(3) 005160 000460 BR TST16 ;;EXIT THIS TEST
9705 005162 ENDF
(4) 005162 $100:
9706 ;START IT ON ITS WAY
9707 LET @TBUF :B= R2
9708 005162 110277 174100 MOVB R2,@TBUF
(4) 005162

```

```

9709
9710 005166
(3) 005166 010546
(7) 005170 012745 177777
(6) 005174 013745 001260
(5) 005200 012745 000200
(4) 005204 012745 000500
(3) 005210 004737 012446
(3) 005214 012605
9711 005216
(6) 005216 103002
9712 005220
(1) 005220 104124
9713
9714 005222
(3) 005222 000437
9715 005224
(4) 005224
9716
9717
9718 005224
(4) 005224 017703 174032
9719
9720 005230
(6) 005230 032703 100000
(9) 005234 001401
9721
9722 005236
(1) 005236 104200
9723 005240
(4) 005240
9724
9725
9726
9727 005240
(6) 005240 020302
(9) 005242 001415
9728 005244
(6) 005244 032737 000001 001220
(9) 005252 001006
9729 005254
(6) 005254 020227 000200
(9) 005260 002002
9730
9731 005262
(1) 005262 104117
9732 005264
(3) 005264 000416
9733 005266
(4) 005266
9734 005266
(4) 005266 000402
(3) 005270
9735
9736 005270
(1) 005270 104017

```

```

MOV R5, -(SP)
MOV #SET, -(R5)
MOV RCSR, -(R5)
MOV #RCVRDONE, -(R5)
MOV #500, -(R5)
JSR PC, TIMER
MOV (SP)+, R5

```

```

; NOW WAIT FOR RECIEVER DONE
CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>

```

```

IF.ERROR THEN
ERRHRD 124

```

```

; RECIEVER NEVER BECAME READY
EXIT

```

```

::EXIT THIS TEST
ENDIF

```

\$101:

```

;RETRIEVE
LET R3 := @RBUF

```

```

;CHECK FOR ERROR DURING TRANSFER
IF #ERROR SETIN R3 THEN

```

```

;ERROR BIT SET IN HIGH BYTE OF RBUF
ERRHRD 200

```

```

ENDIF

```

\$102:

```

;COMPARE DATA
IF R3 NE R2 THEN

```

```

IF #BIT0 NOTSETIN $USWR THEN

```

```

IF R2 LT #200 THEN

```

```

;DATA COMPARE ERR IN 7 BIT WORD
ERRHRD 117

```

```

EXIT

```

```

::EXIT THIS TEST
ENDIF

```

\$105:

```

ELSE

```

\$104:

```

;DATA COMP ERR IN 8 BIT WORD
ERRHRD 17

```

```

9737 005272
(3) 005272 000413 BR TST16 ::EXIT THIS TEST EXIT
9738 005274 $106: ENDF
(4) 005274
9739 005274 000411 BR $107 ELSE IF #BIT0 NOTSETIN $USWR AND R2 GT #177 THEN
(4) 005274
(3) 005276 $103:
(7) 005276 032737 000001 001220 BIT #BIT0,$USWR
(10) 005304 001005 BNE $110
(7) 005306 020227 000177 CMP R2,#177
(10) 005312 003402 BLE $110
9740 ;GETTING 8 BITS ON 7 BIT XMIT
9741 ;MAKE SURE $USWR SETUP CORRECTLY.
9742 005314 ERRHRD 22
(1) 005314 104022 ERROR 22
9743 005316 BR TST16 ::EXIT THIS TEST EXIT
(3) 005316 000401 ENDF
9744 005320 $110:
(4) 005320 $107:
(4) 005320
9745 005320 ENDINC ;R2
(4) 005320 000675 BR $76
(3) 005322 $77:
  
```

```

9747
9748
9753
(3)
(3)
(2) 005322 000004
(2)
(1) 005324 012737 000001 001160      MOV    #1,$TIMES      ;;DO 1 ITERATION
(2) 005332 012737 000016 001200      MOV    #16,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
9758 005340                                IF #WRAP NOTSETIN $USWR OR CONSOL EQ #TRUE THEN
(6) 005340 032737 000020 001220      BIT    #WRAP,$USWR
(8) 005346 001404                                BEQ    $111
(6) 005350 023727 013604 000001      CMP    CONSOL,#TRUE
(9) 005356 001002                                BNE    $112
(6) 005360                                $111:
9759 005360 000137 005772              JMP    TST17          ;EXIT TEST
9760 005364                                ENDIF
(4) 005364                                $112:

; THIS TEST WILL RUN BOTH TRANSMITTER AND
; RECIEVER AT FULL SPEED TESTING
; THE ABILITY OF THE MODULE
; TO HANDLE INTERRUPTS FROM BOTH SIDES AT ONCE.
;
; DOUBLE BUFFERING IS NOT FULLY TESTED BECAUSE OF
; APT CONSIDERATIONS. I.E. 'BREAK' FROM APT
; CAUSES OVERRUN ERRORS. THEREFORE TRANSMIT INTR IS
; ENABLED ONLY AFTER THE RECVR HAS OBTAINED THE LAST WORD
;
; THIS TEST WILL TRANSFER A MAXIMUM OF 400(8)
; CHARACTERS THROUGH THE MODULE, BUT IF AN ERROR
; IS DETECTED BY THE TEST A PREMATURE SHUTDOWN OCCURS.

;CHANGE PRIORITY
;..TO 0
9777
9778 005364      SETPRI #PRO
9779
9780 005376                                ;GET VECTOR ADDRESS
(4) 005376 013701 001256      MOV    DLVEC,R1      LET R1 := DLVEC
9781
9782 005402                                ;RCVR VECTOR
(4) 005402 012721 005664      MOV    #REC,(R1)+   LET (R1)+ := #REC
9783 005406                                LET (R1)+ := #PR6
(4) 005406 012721 000300      MOV    #PR6,(R1)+
9784
9785                                ;POINT TO TRANSMITTER VECTOR
9786 005412                                ;AND SET IT UP ALSO
(4) 005412 012721 005626      MOV    #TRAN,(R1)+ LET (R1)+ := #TRAN
9787 005416                                LET (R1) := #PR6
(4) 005416 012711 000300      MOV    #PR6,(R1)
9788
9789
9790 005422                                ; CLEAR ERROR COUNTER
(4) 005422 005037 005622      CLR    ERRCNT      LET ERRCNT := #0
9791 005426                                LET DATA := #0 ;XMIT DATA
(4) 005426 005037 005662      CLR    DATA
  
```

9792	005432						IF #BIT0 NOTSETIN \$USWR THEN
(6)	005432	032737	000001	001220	BIT	#BIT0,\$USWR	
(9)	005440	001004			BNE	\$113	
9793	005442						LET NUMBER := #200
(4)	005442	012737	000200	005624	MOV	#200,NUMBER	
9794	005450						ELSE
(4)	005450	000403			BR	\$114	
(3)	005452					\$113:	
9795	005452						LET NUMBER := #400
(4)	005452	012737	000400	005624	MOV	#400,NUMBER	
9796	005460						ENDIF
(4)	005460					\$114:	
9797							
9798	005460						BRESET ;SET UP ALL REGISTERS
(1)	005460	000005			RESET		
9799							
9800							;SET I.E. IN TRANSMITTER
9801	005462						LET @TCSR := @TCSR SET.BY #XMITIE
(7)	005462	052777	000100	173574	BIS	#XMITIE,@TCSR	
9802							;AND RECEIVER
9803	005470						LET @RCSR := @RCSR SET.BY #RCVRIE
(7)	005470	052777	000100	173562	BIS	#RCVRIE,@RCSR	
9804							
9805							
9806							;NOW WE WAIT
9807	005476						REPEAT
(3)	005476					\$115:	
9808	005476						UNTIL DATA EQ NUMBER OR ERRCNT GT #0
(4)	005476	023737	005662	005624	CMP	DATA,NUMBER	
(6)	005504	001403			BEQ	\$116	
(4)	005506	005737	005622		TST	ERRCNT	
(7)	005512	003771			BLE	\$115	
(4)	005514					\$116:	
9809							
9810							;NOW LETS CHECK.
9811							;TURN OFF ALL INTR ENABLE
9812	005514						LET @TCSR := @TCSR CLR.BY #XMITIE
(7)	005514	042777	000100	173542	BIC	#XMITIE,@TCSR	
9813	005522						LET @RCSR := @RCSR CLR.BY #RCVRIE
(7)	005522	042777	000100	173530	BIC	#RCVRIE,@RCSR	
9814	005530						IF ERRCNT NE #0 THEN
(6)	005530	005737	005622		TST	ERRCNT	
(9)	005534	001431			BEQ	\$117	
9815	005536						IF #ERROR SETIN RHL D THEN
(6)	005536	032737	100000	005770	BIT	#ERROR,RHL D	
(9)	005544	001424			BEQ	\$120	
9816	005546						IF #ORERR SETIN RHL D THEN
(6)	005546	032737	040000	005770	BIT	#ORERR,RHL D	
(9)	005554	001402			BEQ	\$121	
9817							;OVERRUN ERROR
9818	005556						ERRHRD 220
(1)	005556	104220			ERROR	220	
9819	005560						ELSE IF #FRERR SETIN RHL D THEN
(4)	005560	000415			BR	\$122	
(3)	005562					\$121:	
(7)	005562	032737	020000	005770	BIT	#FRERR,RHL D	


```

(10) 005570 001402          BEQ      $123
9820
9821 005572          ERROR    221          ;FRAMING ERROR
(1) 005572 104221          ;ERRHRD 221
9822 005574          ELSE IF #PERR SETIN RHLD THEN
(4) 005574 000407          BR      $124
(3) 005576          $123:
(7) 005576 032737 010000 005770 BIT    #PERR,RHLD
(10) 005604 001402          BEQ      $125
9823
9824 005606          ;PARITY ERROR
(1) 005606 104222          ERROR    222          ;ERRHRD 222
9825 005610          ELSE
(4) 005610 000401          BR      $126
(3) 005612          $125:
9826
9827 005612          ;UNKNOWN ERROR
(1) 005612 104024          ERROR    24          ;ERRHRD 24
9828 005614          ENDIF
(4) 005614          $126:
(4) 005614          $124:
(4) 005614          $122:
9829 005614          ELSE
(4) 005614 000401          BR      $127
(3) 005616          $120:
9830
9831 005616          ;DATA COMPARE ERROR
(1) 005616 104120          ERROR    120          ;ERRHRD 120
9832 005620          ENDIF
(4) 005620          $127:
9833 005620          ENDIF
(4) 005620          $117:
9834 005620          EXIT    ;SKIP OVER SUPPORT ROUTINES & STORAGE
(3) 005620 000464          BR      TST17          ;;EXIT THIS TEST
9835
9836
9837 005622 000000          ERRCNT: 0
9838 005624 000000          NUMBER: 0
  
```

```

9840
9841
9846
9847
9848
9853 005626
(1) 005626
9854 005626
(6) 005626 023737 005662 005624
(9) 005634 001406
(6) 005636 005737 005622
(9) 005642 001003
9855
9856 005644
(4) 005644 013777 005662 173414
9857 005652
(4) 005652
9858
9859 005652
(7) 005652 042777 000100 173404
9860 005660
(1) 005660 000002
9861
9862 005662 000000
9863
9868
9869
9870
9875 005664
(1) 005664
9876
9877 005664
(4) 005664 017737 173372 005770
9878
9879 005672
(6) 005672 032737 100000 005770
(8) 005700 001004
(6) 005702 023737 005770 005662
(9) 005710 001411
(6) 005712
9880
9881 005712
(4) 005712 013737 005624 005662
9882 005720
(7) 005720 042777 000100 173332
9883 005726
(7) 005726 005237 005622
9884 005732
(4) 005732 000415
(3) 005734
9885 005734
(7) 005734 005237 005662
9886 005740
(6) 005740 023737 005662 005624
(9) 005746 001004
9887 005750

```

```

;*****
;TRANSMIT INTERRUPT HANDLER
;*****
BGNSRV TRAN
TRAN:
IF DATA NE NUMBER AND ERRCNT EQ #0 THEN
    CMP DATA,NUMBER
    BEQ $130
    TST ERRCNT
    BNE $130
;SHIP OUT WORD
LET @TBUF := DATA
ENDIF
;STOP INTERR, NOT EXER DOUBL BUFFER
LET @TCSR := @TCSR CLR.BY #XMITIE
ENDSRV
RTI
DATA: 0
;*****
;RECEIVER INTERRUPT HANDLER
;*****
BGNSRV REC
REC:
;GET CHAR
LET RHL := @RBUF
;CHECK ERROR
IF #ERROR SETIN RHL OR RHL NE DATA THEN
    BIT #ERROR,RHL
    BNE $131
    CMP RHL,DATA
    BEQ $132
;STOP ALL INTERR PROC & GET OUT
LET DATA := NUMBER
LET @RCSR := @RCSR CLR.BY #RCVRIE
LET ERRCNT := ERRCNT + #1
ELSE
    BR $133
;STOP ALL INTERR PROC & GET OUT
LET DATA := DATA + #1
IF DATA EQ NUMBER THEN
    LET @RCSR := @RCSR CLR.BY #RCVRIE

```

```
(7) 005750 042777 000100 173302      BIC  #RCVRIE,@RCSR
9888 005756
(4) 005756 000403
(3) 005760      $134:
9889
9890 005760      ;ALLOW NEXT XMIT INTERR
(7) 005760 052777 000100 173276      BIS  #XMITIE,@TCSR
9891 005766      LET @TCSR := @TCSR SET.BY #XMITIE
(4) 005766      $135:
9892 005766      $133:
(4) 005766      $133:
9893 005766      ENDSRV
(1) 005766 000002      RTI
9894
9895 005770 000000      RHLD: 0
9896
```

9898
 9899
 9910
 (3)
 (4)
 (4)
 (4)
 (4)
 (3)
 (2)
 (2)
 (1)
 (2)
 9915
 9916
 9917
 9918
 (6)
 (8)
 (6)
 (9)
 (6)
 9919
 9920
 (4)
 (3)
 9921
 (6)
 (9)
 9922
 9923
 9924
 (4)
 9925
 (4)
 9926
 (5)
 9927
 9928
 (4)
 9929
 9930
 (7)
 9931
 9932
 (4)
 9933
 9934
 (3)
 (7)
 (6)
 (5)
 (4)
 (3)
 (3)
 9935

005772 000004
 005774 012737 000010 001160
 006002 012737 000017 001200
 006010
 006010 032737 000020 001220
 006016 001404
 006020 032737 000010 001220
 006026 001003
 006030
 006030 000137 006502
 006034 000406
 006036
 006036 023727 013604 000001
 006044 001002
 006046 000137 006502
 006052
 006052
 006052
 006052 012737 006060 001110
 006060
 006060 005037 006500
 006064 052777 000001 173172
 006072
 006072 012777 000125 173166
 006100
 006100 010546
 006102 012745 177777
 006106 013745 001260
 006112 012745 000200
 006116 012745 000500
 006122 004737 012446
 006126 012605
 006130

```

*****
*TEST 17      TEST BREAK DETECTION LOGIC
*              TRANSMIT KNOWN CHAR WITH BREAK SET
*              AND COMPARE RECEIVED WITH 0.
*              FRAMING ERROR WILL ALSO BE CHECKED
*              IF ERROR BITS ARE ENABLED.
*****
  
```

TST17: SCOPE

```

MOV #10,$TIMES      ;;DO 10 ITERATIONS
MOV #17,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX
                   ;;DONT DO THIS TEST IF 'BREAK' GENERATION
                   ;;ENABLED, ELSE WILL HALT TO CONSOLE ODT.
                   ;;DO IF BREAK 'DETECTION' IS ENABLED.
                   IF #WRAP NOTSETIN $USWR OR #BRK NOTSETIN $USWR THEN
BIT #WRAP,$USWR
BEQ $136
BIT #BRK,$USWR
BNE $137
$136: JMP TST20      ;EXIT TEST
ELSE
BR $140
$137:
IF CONSOL EQ #TRUE THEN
JMP TST20          ;CAN'T TEST CONSOLE
                   ;EXIT TEST
ENDIF
$141:
$140:
BGNSUB
LET ERRCHK := #0   ; CLEAR ERROR WORD
                   ;SET BREAK BIT
LET @TCSR := @TCSR SET.BY #BREAK
                   ;NON-ZERO CHAR. '*'
LET @TBUF := #125
                   ;WAIT FOR DONE
CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
MOV R5,-(SP)
MOV #SET,-(R5)
MOV RCSR,-(R5)
MOV #RCVRDONE,-(R5)
MOV #500,-(R5)
JSR PC,TIMER
MOV (SP)+,R5
IF.ERROR THEN
  
```

```

(6) 006130 103001          BCC      $142
9936
9937 006132                ERROR    115
(1) 006132 104115
9938 006134                $142:
(4) 006134
9939 006134                MOV     @RBUF,RO
(4) 006134 017700 173122
9940 006140                TSTB   RO
(6) 006140 105700          BEQ     $143
(9) 006142 001403
9941
9942 006144                BIS     #BIT0,ERRCHK
(7) 006144 052737 000001 006500
9943 006152                $143:
(4) 006152
9944 006152                BIT     #FRERR,RO
(6) 006152 032700 020000    BNE     $144
(9) 006156 001003
9945 006160                BIS     #BIT1,ERRCHK
(7) 006160 052737 000002 006500
9946 006166                $144:
(4) 006166
9947 006166                BIT     #PARITY,$USWR
(6) 006166 032737 000002 001220    BEQ     $145
(9) 006174 001421
9948
9949 006176                BIT     #EVENODD,$USWR
(6) 006176 032737 000004 001220    BNE     $146
(9) 006204 001007
9950
9951 006206                BIT     #PERR,RO
(6) 006206 032700 010000    BNE     $147
(9) 006212 001003
9952
9953 006214                BIS     #BIT2,ERRCHK
(7) 006214 052737 000004 006500
9954 006222                $147:
(4) 006222
9955 006222                BR     $150
(4) 006222 000406                $146:
(3) 006224
9956 006224                BIT     #PERR,RO
(6) 006224 032700 010000    BEQ     $151
(9) 006230 001403
9957 006232                BIS     #BIT3,ERRCNT
(7) 006232 052737 000010 005622
9958 006240                $151:
(4) 006240
9959 006240                $150:
(4) 006240
9960 006240                $145:
(4) 006240
9961
9962 006240                RESET
(1) 006240 000005
  
```

```

: RECIEVER DONE DID NOT SET
ERRHRD 115
ENDIF
LET RO := @RBUF
IFB RO NE #0 THEN
: BREAK DID NOT EQUAL 0
LET ERRCHK := ERRCHK SET.BY #BIT0
ENDIF
IF #FRERR NOTSETIN RO THEN
LET ERRCHK := ERRCHK SET.BY #BIT1
ENDIF
IF #PARITY SETIN $USWR THEN
: ODD PARITY ENABLED
IF #EVENODD NOTSETIN $USWR THEN
: BREAK SHOULD GENERATE A PAPITY ERRO
IF #PERR NOTSETIN RO THEN
: NO PAR ERROR WHEN THERE SHOULD
LET ERRCHK := ERRCHK SET.BY #BIT2
ENDIF
ELSE
IF #PERR SETIN RO THEN
LET ERRCNT := ERRCNT SET.BY #BIT3
ENDIF
ENDIF
ENDIF
BRESET ;CLEAN UP
  
```

```

9963 006242 032777 170000 173012      BIT    #170000,@RBUF
9964 006250 001401                      BEQ    1$
9965 006252 104033                      ERROR  33      ;RESET DID NOT CLEAR ERROR,FR ERR,OR PERR IN RBUF
9966 006254      1$:
9967
9968 006254      IF #BIT0 SETIN ERRCHK THEN
   (6) 006254 032737 000001 006500      BIT    #BIT0,ERRCHK
   (9) 006262 001401                      BEQ    $152
9969 006264      ERRHRD 121 ;BREAK ERROR
   (1) 006264 104121                      ERROR  121
9970 006266      ENDIF
   (4) 006266      $152:
9971 006266      IF #BIT1 SETIN ERRCHK THEN
   (6) 006266 032737 000002 006500      BIT    #BIT1,ERRCHK
   (9) 006274 001401                      BEQ    $153
9972 006276      ERRHRD 122 ; FRAMING ERROR
   (1) 006276 104122                      ERROR  122
9973 006300      ENDIF
   (4) 006300      $153:
9974 006300      IF #BIT2 SETIN ERRCHK THEN
   (6) 006300 032737 000004 006500      BIT    #BIT2,ERRCHK
   (9) 006306 001401                      BEQ    $154
9975 006310      ERRHRD 235
   (1) 006310 104235                      ERROR  235
9976      ;NO PARITY ERROR WHEN
9977      ;THERE SHOULD BE
9978 006312      ENDIF
   (4) 006312      $154:
9979 006312      IF #BIT3 SETIN ERRCHK THEN
   (6) 006312 032737 000010 006500      BIT    #BIT3,ERRCHK
   (9) 006320 001401                      BEQ    $155
9980 006322      ERRHRD 236
   (1) 006322 104236                      ERROR  236
9981      ;PARITY ERROR SHOULD NOT HAVE
9982      ;OCCURED WITH EVEN PARITY
9983      ;ENABLED AND BREAK SET
9984 006324      ENDIF
   (4) 006324      $155:
9985 006324      ENDSUB
9986 006324      BGNSUB
   (5) 006324 012737 006332 001110      MOV    #64$,$LPERR
9987      ;SET BREAK BIT
9988 006332      LET @TCSR := @TCSR SET.BY #BREAK
   (7) 006332 052777 000001 172724      BIS    #BREAK,@TCSR
9989
9990 006340      CALL TIMER IN <#500,#BREAK,TCSR,#SET>
   (3) 006340 010546                      MOV    R5,-(SP)
   (7) 006342 012745 177777              MOV    #SET,-(R5)
   (6) 006346 013745 001264              MOV    TCSR,-(R5)
   (5) 006352 012745 000001              MOV    #BREAK,-(R5)
   (4) 006356 012745 000500              MOV    #500,-(R5)
   (3) 006362 004737 012446              JSR    PC,TIMER
   (3) 006366 012605                      MOV    (SP)+,R5
9991
9992      ;DID IT SET?
9993 006370      IF.ERROR THEN
  
```

```

(6) 006370 103001          BCC      $156
9994                                     ;BREAK DID NOT SET
9995 006372                ERROR    21      ERRHRD 21
(1) 006372 104021          ENDIF
9996 006374                $156:
(4) 006374
9997
9998
9999 006374                ;CLEAR BREAK BIT
(7) 006374 042777 000001 172662      BIC      #BREAK,@TCSR      LET @TCSR := @TCSR CLR.BY #BREAK
10000 006402                WAITMS 100.
(4) 006402 010546          MOV      R5,-(SP)
(5) 006404 012745 000144      MOV      #100,-(R5)
(4) 006410 004737 012620      JSR     PC,WAIT
(4) 006414 012605          MOV      (SP)+,R5
10001
10002
10003
10004 006416                ;READ RBUF TO CLEAR ERRORS & REC DONE
(4) 006416 017700 172640      MOV      @RBUF,R0      LET R0 := @RBUF
10005
10006 006422                ;SEND CHAR
(4) 006422 012777 000125 172636      MOV      #125,@TBUF      LET @TBUF := #125
10007
10008 006430                ;WAIT FOR DONE BIT
(3) 006430 010546          MOV      R5,-(SP)      CALL TIMER IN <#500,#RCVRDONE,RCSR,#SET>
(7) 006432 012745 177777      MOV      #SET,-(R5)
(6) 006436 013745 001260      MOV      RCSR,-(R5)
(5) 006442 012745 000200      MOV      #RCVRDONE,-(R5)
(4) 006446 012745 000500      MOV      #500,-(R5)
(3) 006452 004737 012446      JSR     PC,TIMER
(3) 006456 012605          MOV      (SP)+,R5
10009 006460                IF.ERROR THEN
(6) 006460 103001          BCC      $157
10010
10011 006462                ;RECEIVER NEVER CAME READY
(1) 006462 104230          ERROR    230      ERRHRD 230
10012 006464                ENDIF
(4) 006464                $157:
10013
10014
10015 006464                ;WAS CHAR AFTER BREAK RECEIVED
(6) 006464 127727 172572 000125      CMPB    @RBUF,#125      IFB @RBUF NE #125 THEN
(9) 006472 001401          BEQ     $160
10016
10017 006474                ;CHAR AFTER BREAK NOT RECEIVED CORRECTLY
(1) 006474 104231          ERROR    231      ERRHRD 231
10018 006476                ENDIF
(4) 006476                $160:
10019 006476
10020 006476
(3) 006476 000401          BR      TST20
10021 006500 000000          ERRCHK: .WORD 0
    ENDSUB
    EXIT
    ;;EXIT THIS TEST
    
```

```

10023
10024
10029          ;:*****
(3)          ;*TEST 20      NOT A TEST - SEND BACK TO LOOP
(3)          ;:*****
(2) 006502 000004  TST20: SCOPE
(2)
(1) 006504 012737 000001 001160      MOV      #1,$TIMES      ;;DO 1 ITERATION
10034 006512 032777 010000 172420      BIT      #BIT12,@SWR      IF #BIT12 SETIN @SWR THEN
(6) 006512 032777 010000 172420      BEQ      $161
(9) 006520 001513
10035 006522                                IF PHASE2 EQ #TRUE THEN
(6) 006522 023727 014166 000001      CMP      PHASE2,#TRUE
(9) 006530 001021      BNE      $162
10036 006532      TYPTXT <<CRLF>/      ** PHASE 2 SUMMARY **/<CRLF>>
10037 006572                                ELSE
(4) 006572 000425      BR      $163
(3) 006574      $162:                                IF P1CNT EQ #0 THEN
10038 006574                                TST      P1CNT
(6) 006574 005737 014170      BNE      $164
(9) 006600 001022      TYPTXT <<CRLF>/      ** PHASE 1 SUMMARY **/<CRLF>>
10039 006602                                LET P1CNT := P1CNT + #1
10040 006642 005237 014170      INC      P1CNT
(7)
10041 006646      $164:                                ENDIF
(4) 006646      $163:                                ENDIF
10042 006646
(4) 006646
10043 006646      TYPTXT <*,CSR: *>
10044 006662      TYPOCT DLADD
10045 006670      TYPTXT <*,VECTOR: *>
10046 006710      TYPOCT DLVEC
10047 006716      TYPTXT <*,ERRORS: *>
10048 006736      TYPDEC $ERTTL
10049 006744 104401 001171      TYPE      , $CRLF
10050 006750                                ENDIF
(4) 006750      $161:                                ; RESET FOR NEXT DEVICE/PASS
10051 006750 005037 001112      CLR      $ERTTL      IF PHASE2 EQ #TRUE THEN
10052 006754                                CMP      PHASE2,#TRUE
(6) 006754 023727 014166 000001      BNE      $165
(9) 006762 001004
10053 006764                                LET PHASE2 := #0
(4) 006764 005037 014166      CLR      PHASE2
10054 006770                                LET $UNIT := $UNIT + #1
(7) 006770 005237 001206      INC      $UNIT
10055 006774                                ENDIF
(4) 006774      $165:                                ; BACK UP TO THE BEGINNING
10056 006774 000137 001732      JMP      LOOP

```



```

10058
10059
10060 007000
10070
(3)
(4)
(4)
(4)
(3)
(2) 007000 000004
(2)
(1) 007002 012737 000001 001160 MOV #1,$TIMES ;;DO 1 ITERATION
(2) 007010 012737 000021 001200 MOV #21,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
10071
10076
10077
10078 007016
(4) 007016 012700 007744 MOV #INTRTABLE,RO ;CLEAR OUT INTERRUPT TABLE
10079 007022 REPEAT
(3) 007022 $166: LET (RO)+ := #0
10080 007022 005020 CLR (RO)+ UNTIL RO EQ #TABEND
10081 007024 020027 007764 CMP RO,#TABEND
(3) 007024 001374 BNE $166 ;SET PRIORITY TO 6
10082
10083
10084 007032 SETPRI #PR6
10085
10086
10087 007044
(4) 007044 013700 001256 MOV DLVEC,RO ;SET UP ALL INTERRUPT VECTORS
10088 007050 LET R1 := #RCVROSRV
(4) 007050 012701 007424 MOV #RCVROSRV,R1
10089 007054 REPEAT
(3) 007054 $167: LET (RO)+ := R1
10090 007054 010120 MOV R1,(RO)+ LET (RO)+ := #PR6
10091 007056 012720 000300 MOV #PR6,(RO)+ LET R1 := R1 + #30
10092 007062 062701 000030 ADD #30,R1 UNTIL R1 EQ #SRVEND
10093 007066 020127 007724 CMP R1,#SRVEND
(3) 007066 001370 BNE $167 ;ENABLE INTERRUPTS ON ALL ACTIVE LINES,
10094 ;ALSO, XMIT CHAR'S TO PRIME RECEIVERS
10095
10096
10097
10098
10099 007074
(4) 007074 013737 014162 007764 MOV MASK,CHMASK ;COPY MASK
10100 007102 LET CHCNT := #0
(4) 007102 005037 007766 CLR CHCNT
10101 007106 LET RO := DLADD
(4) 007106 013700 001254 MOV DLADD,RO

```

10102	007112								REPEAT
(3)	007112								
10103	007112				\$170:				IF #BIT0 SET IN CHMASK THEN
(6)	007112	032737	000001	007764		BIT	#BIT0,CHMASK		
(9)	007120	001430				BEQ	\$171		
10104									;SET RCSR IE
10105	007122								LET (R0) := (R0) SET.BY #BIT6
(7)	007122	052710	000100			BIS	#BIT6,(R0)		
10106	007126								LET R0 := R0 + #4
(7)	007126	062700	000004			ADD	#4,R0		
10107									;SET XCSR IE
10108	007132								LET (R0) := (R0) SET.BY #BIT6
(7)	007132	052710	000100			BIS	#BIT6,(R0)		
10109									;LOAD XBUF
10110	007136								LET 2(R0) := #252
(4)	007136	012760	000252	000002		MOV	#252,2(R0)		
10111									;GO BACK TO RCSR
10112	007144								LET R0 := R0 - #4
(7)	007144	162700	000004			SUB	#4,R0		
10113									;LOOK FOR RCVR DONE
10114	007150								CALL TIMER IN <#500,#RCVRDONE,R0,#SET>
(3)	007150	010546				MOV	R5,-(SP)		
(7)	007152	012745	177777			MOV	#SET,-(R5)		
(6)	007156	010045				MOV	R0,-(R5)		
(5)	007160	012745	000200			MOV	#RCVRDONE,-(R5)		
(4)	007164	012745	000500			MOV	#500,-(R5)		
(3)	007170	004737	012446			JSR	PC,TIMER		
(3)	007174	012605				MOV	(SP)+,R5		
10115									;DID IT SET IN TIME?
10116	007176								IF.ERROR THEN
(6)	007176	103001				BCC	\$172		
10117									;RCVRDONE DID NOT SET IN RCSR
10118	007200								ERRHRD 23
(1)	007200	104023				ERROR	23		
10119	007202								ENDIF
(4)	007202				\$172:				
10120	007202								ENDIF
(4)	007202				\$171:				
10121									
10122	007202								LET R0 := R0 + #10
(7)	007202	062700	000010			ADD	#10,R0		
10123									;SETUP FOR NEXT CHANNEL
10124	007206								LET CHMASK := CHMASK SHIFT -1
(8)	007206	006237	007764			ASR	CHMASK		
10125	007212								LET CHCNT := CHCNT + #1
(7)	007212	005237	007766			INC	CHCNT		
10126	007216								IF CHCNT EQ #3 THEN
(6)	007216	023727	007766	000003		CMP	CHCNT,#3		
(9)	007224	001007				BNE	\$173		
10127	007226								CALL TSTCON
(3)	007226	004737	013530			JSR	PC,TSTCON		
10128	007232								IF CONSOLE NE #0 THEN
(6)	007232	005737	013604			TST	CONSOLE		
(9)	007236	001402				BEQ	\$174		
10129	007240								LET CHCNT := CHCNT + #1
(7)	007240	005237	007766			INC	CHCNT		


```
10176 007402 022120      CMP      (R1)+,(R0)+      :R1-R0
10177 007404 003367      BGT      4$              :BR IF R1>R0
10178 007406 005237 007770  INC      PRIERR          :ELSE ERROR
10179
10180 007412              5$:
10181 007412              IF PRIERR NE #0 THEN
   (6) 007412 005737 007770  TST      PRIERR
   (9) 007416 001401      BEQ      $175
10182 007420              ERRHRD 250
   (1) 007420 104250      ERROR    250
10183
10184
10185
10186
10187
10188 007422              :CHANNELS DID NOT INTR ACCORDING TO
   (4) 007422              :ASSIGNED PRIORITY. THE BYTE ENTRIES
10189
10190 007422              :IN INTRTABLE: SHOULD BE IN THE ORDER
   (3) 007422 000565      :THAT THEY APPEAR IN THE CHANNEL #
                                :TABLE .(EXCLUDING CHANNELS NOT ACTIVE)
                                ENDIF
                                EXIT
                                ;;EXIT THIS TEST
                                BR      TST22
```

10192
10193
10198
10199
10200
10205
10206
(1)
10207
10208
(4)
10209
10210
(4)
10211
(7)
10212
10213
(7)
10214
(1,
10215
10216
10217
(1)
10218
10219
(4)
10220
10221
(4)
10222
(7)
10223
10224
(7)
10225
(1)
10226
10227
(1)
10228
10229
(4)
10230
10231
(4)
10232
(7)
10233
10234
(7)
10235
(1)
10236
10237

007424
007424
007424 013724 007724
007430
007430 013737 001260 007774
007436 062737 000000 007774
007444
007444 042777 000100 000322
007452
007452 000002
007454
007454
007454 013724 007734
007460
007460 013737 001260 007774
007466 062737 000004 007774
007474
007474 042777 000100 000272
007502
007502 000002
007504
007504
007504 013724 007726
007510
007510 013737 001260 007774
007516 062737 000010 007774
007524
007524 042777 000100 000242
007532
007532 000002
007534

* START OF SERVICE ROUTINES *

```
RCVROSRV:                                BGNSRV RCVROSRV
                                           ;PUT INTR IDENTIFIER IN INTRTABLE
                                           LET (R4)+ := RCHO
                                           ;GENERATE CSR ADDRESS
                                           LET TEMP := RCSR
                                           LET TEMP := TEMP + #0
                                           ;ONE INTR IS ALL WE WANT FROM HERE
                                           LET @TEMP := @TEMP CLR.BY #BIT6
                                           ENDSRV

                                           BGNSRV XMITOSRV
                                           ;PUT INTR IDENTIFIER IN INTRTABLE
                                           LET (R4)+ := TCHO
                                           ;GENERATE CSR ADDRESS
                                           LET TEMP := RCSR
                                           LET TEMP := TEMP + #4
                                           ;ONE INTR IS ALL WE WANT FROM HERE
                                           LET @TEMP := @TEMP CLR.BY #BIT6
                                           ENDSRV

RCVR1SRV:                                BGNSRV RCVR1SRV
                                           ;PUT INTR IDENTIFIER IN INTRTABLE
                                           LET (R4)+ := RCH1
                                           ;GENERATE CSR ADDRESS
                                           LET TEMP := RCSR
                                           LET TEMP := TEMP + #10
                                           ;ONE INTR IS ALL WE WANT FROM HERE
                                           LET @TEMP := @TEMP CLR.BY #BIT6
                                           ENDSRV

                                           BGNSRV XMIT1SRV

MOV    RCHO,(R4)+
MOV    RCSR,TEMP
ADD    #0,TEMP
BIC    #BIT6,@TEMP
RTI

MOV    TCHO,(R4)+
MOV    RCSR,TEMP
ADD    #4,TEMP
BIC    #BIT6,@TEMP
RTI

MOV    RCH1,(R4)+
MOV    RCSR,TEMP
ADD    #10,TEMP
BIC    #BIT6,@TEMP
RTI
```



```
(7) 007656 062737 000030 007774      ADD      #30,TEMP
10273
10274 007664      ;ONE INTR IS ALL WE WANT FROM HERE
(7) 007664 042777 000100 000102      BIC      #BIT6,@TEMP      LET @TEMP := @TEMP CLR.BY #BIT6
10275 007672      ENDSRV
(1) 007672 000002      RTI
10276
10277 007674      BGNSRV XMIT3SRV
(1) 007674      XMIT3SRV:
10278      ;PUT INTR IDENTIFIER IN INTRTABLE
10279 007674      LET (R4)+ := TCH3
(4) 007674 013724 007742      MOV      TCH3,(R4)+
10280      ;GENERATE CSR ADDRESS
10281 007700      LET TEMP := RCSR
(4) 007700 013737 001260 007774      MOV      RCSR,TEMP
10282 007706      LET TEMP := TEMP + #34
(7) 007706 062737 000034 007774      ADD      #34,TEMP
10283      ;ONE INTR IS ALL WE WANT FROM HERE
10284 007714      LET @TEMP := @TEMP CLR.BY #BIT6
(7) 007714 042777 000100 000052      BIC      #BIT6,@TEMP
10285 007722      ENDSRV
(1) 007722 000002      RTI
10286 007724      SRVEND:
```

10288
10289
10290
10291
10292
10293
10294
10295
10296
10297 007724 000000
10298 007726 000001
10299 007730 000002
10300 007732 000003
10301 007734 000010
10302 007736 000011
10303 007740 000012
10304 007742 000013
10305
10306
10307
10308
10309
10310
10311 007744 000010
10312 007764
10313
10314 007764 000000
10315 007766 000000
10316 007770 000000
10317 007772 000000
10318 007774 000000
10319

***CHANNEL IDENTIFIER TABLE**
:THE ENTRIES FROM THIS
:TABLE ARE PLACED IN THE INTRTABLE
:IN THE ORDER THAT THE INTR'S
:OCCUR. (EXCLUDING NON-ACTIVE CH'S)

RCH0: .WORD 0
RCH1: .WORD 1
RCH2: .WORD 2
RCH3: .WORD 3
TCH0: .WORD 10
TCH1: .WORD 11
TCH2: .WORD 12
TCH3: .WORD 13

:THIS TABLE WILL CONTAIN ENTRIES
:REPRESENTING EACH INTR IN THE ORDER
:THAT IT OCCURED
: S/B IN THE ABOVE ORDER

INTRTABLE: .BLKW 8.
TABEND:

CHMASK: .WORD 0 ;BITS 3-0 INDICATE WHICH CH'S ARE ACTIVE FOR THIS TEST
CHCNT: .WORD 0 ;CHANNEL COUNTER
PRIERR: .WORD 0 ;ERROR WORD, CONTAINS NO. OF INTR OUT OF ORDER
TCNT: .WORD 0 ;TABLE PASS CTR
TEMP: .WORD 0 ;FOR SERVICE ROUTINES

10321
 10322
 10338
 (3)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (3)
 (2) 007776 000004
 (2)
 (1) 010000 012737 000001 001160
 (2) 010006 012737 000022 001200
 10343
 10344 010014
 (4) 010014 005037 012366
 10345
 10346
 10347
 10348 010020
 (4) 010020 012700 011360
 10349 010024
 (3) 010024
 10350 010024
 (4) 010024 005020
 10351 010026
 (3) 010026 020027 012360
 (6) 010032 001374
 10352
 10353
 10354 010034
 (4) 010034 012701 010660
 10355 010040
 (4) 010040 013700 001256
 10356 010044
 (3) 010044
 10357 010044
 (4) 010044 010120
 10358 010046
 (4) 010046 012720 000300
 10359 010052
 (7) 010052 062701 000054
 10360 010056
 (4) 010056 010120
 10361 010060
 (4) 010060 012720 000300
 10362 010064
 (7) 010064 062701 000044
 10363 010070
 (3) 010070 020127 011360
 (6) 010074 001363

```

*****
*TEST 22 TEST DATA TRANSFERS WITH ALL ACTIVE LINES INTERRUPTING
* IN THIS WE'LL ENABLE INTERRUPT ON ALL CHANNELS
* FOR THIS DLV11-J. THEN WE'LL XMIT AN INCREMENTING
* DATA PATTERN VIA INTERRUPTS AND RECORD THE RECEIVER
* INTR. IN THE RECEIVER STATUS TABLE.
* NOTE: DOUBLE BUFFERING CANNOT BE TESTED AT ITS MAX SPEED
* BECAUSE OF APT CONSIDERATIONS. I.E. APT SENDS
* 'BREAKS' WHICH CAUSE OVERRUN ERRORS. THEREFORE
* THE XMIT IE IS NOT ENABLED AGAIN UNTIL THE RECVR
* HAS OBTAINED THE PREVIOUS WORD.
*****
TST22: SCOPE
      MOV #1,$TIMES      ;;DO 1 ITERATION
      MOV #22,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX
                          ;CLR ERROR WORD,
                          LET ERWRD := #0
      CLR ERWRD
                          ;CLEAR OUT RECEIVER TABLES
                          LET RO := #CHOTAB
      REPEAT
        LET (RO)+ := #0
      UNTIL RO EQ #STATEND
      CMP RO,#STATEND
      BNE $176
                          ;SET UP ALL VECTORS
      LET R1 := #ROSRV
      LET RO := DLVEC
      REPEAT
        LET (RO)+ := R1
        LET (RO)+ := #PR6
        LET R1 := R1 + #54
        LET (RO)+ := R1
        LET (RO)+ := #PR6
        LET R1 := R1 + #44
      UNTIL R1 EQ #SEREND
      CMP R1,#SEREND
      BNE $177
  
```



```

10396 010232                                ENDIF
      (4) 010232                                $204:
10397 010232                                ENDIF
      (4) 010232                                $203:
10398 010232                                UNTIL CHCTR EQ #4
      (3) 010232 023727 012362 000004          CMP      CHCTR,#4
      (6) 010240 001334                          BNE      $200
10399
10400                                ;INIT BUFFER POINTERS FOR SERVICE ROUTINES
10401 010242                                LET R0 := #CH0TAB
      (4) 010242 012700 011360          MOV      #CH0TAB,R0
10402 010246                                LET R1 := #CH1TAB
      (4) 010246 012701 011560          MOV      #CH1TAB,R1
10403 010252                                LET R2 := #CH2TAB
      (4) 010252 012702 011760          MOV      #CH2TAB,R2
10404 010256                                LET R3 := #CH3TAB
      (4) 010256 012703 012160          MOV      #CH3TAB,R3
10405
10406                                ;FILL XBUF WORDS
10407                                ;FROM TMP0 THRU TMP3E
10408                                ;START WORD CH 0 ALWAYS 0
10409 010262                                LET TMP0 := #0
      (4) 010262 005037 012372          CLR      TMP0
10410                                ;OFFSET TO INDFX
10411 010266                                LET R4 := #0
      (4) 010266 005004          CLR      R4
10412                                ;PTR TO TABLE TO BE FILLED
10413 010270                                LET R5 := #TMPOE
      (4) 010270 012705 012374          MOV      #TMPOE,R5
10414 010274                                REPEAT
      (3) 010274                                IF #BIT0 NOTSETIN $USWR THEN
10415 010274                                $205:
      (6) 010274 032737 000001 001220    BIT      #BIT0,$USWR
      (9) 010302 001005                          BNE      $206
10416 010304                                LET (R5)+ := TABL7(R4)
      (4) 010304 016425 012426          MOV      TABL7(R4),(R5)+
10417 010310                                LET (R5)+ := TABL7(R4)
      (4) 010310 016425 012426          MOV      TABL7(R4),(R5)+
10418 010314                                ELSE
      (4) 010314 000404          BR       $207
      (3) 010316                                $206:
10419 010316                                LET (R5)+ := TABL8(R4)
      (4) 010316 016425 012436          MOV      TABL8(R4),(R5)+
10420 010322                                LET (R5)+ := TABL8(R4)
      (4) 010322 016425 012436          MOV      TABL8(R4),(R5)+
10421 010326                                ENDIF
      (4) 010326                                $207:
10422 010326                                LET R4 := R4 + #2
      (7) 010326 062704 000002          ADD      #2,R4
10423 010332                                UNTIL R4 EQ #10
      (3) 010332 020427 000010          CMP      R4,#10
      (6) 010336 001356                          BNE      $205
10424                                ;INIT TMP4
10425                                ;WILL BE DECR BY XMIT SERVICE ROUTINES TILL 0
10426 010340                                LET TMP4 := ACTCH
      (4) 010340 013737 012364 012414    MOV      ACTCH,TMP4

```


10461	010474					LET R1 := TMPO(R0)
(4)	010474	016001	012372	MOV	TMPO(R0),R1	
10462	010500					LET R0 := R0 + #2
(7)	010500	062700	000002	ADD	#2,R0	
10463						;GET MAX WORD FOR THAT CH.
10464	010504					LET R3 := TMPO(R0)
(4)	010504	016003	012372	MOV	TMPO(R0),R3	
10465						
10466	010510					REPEAT
(3)	010510					
10467	010510					IF #BIT15 SET IN (R2) THEN
(6)	010510	032712	100000	BIT	#BIT15,(R2)	
(9)	010514	001403		BEQ	\$215	
10468	010516					LET ERWRD := ERWRD SET.BY #BIT8
(7)	010516	052737	000400 012366	BIS	#BIT8,ERWRD	
10469	010524					ENDIF
(4)	010524					
10470						;CHECK FOR DATA COMPARE ERROR
10471	010524					IFB (R2) NE R1 THEN
(6)	010524	121201		CMPB	(R2),R1	
(9)	010526	001402		BEQ	\$216	
10472	010530					LET ERWRD := ERWRD + #1
(7)	010530	005237	012366	INC	ERWRD	
10473	010534					ENDIF
(4)	010534					
10474						;BUMP EXPECTED DATA WORD
10475	010534					LET R1 := R1 + #1
(7)	010534	005201		INC	R1	
10476						;BUMP TABLE PTR
10477	010536					LET R2 := R2 + #2
(7)	010536	062702	000002	ADD	#2,R2	
10478						
10479	010542					UNTIL R1 EQ R3 OR ERWRD NE #0
(4)	010542	020103		CMP	R1,R3	
(6)	010544	001403		BEQ	\$217	
(4)	010546	005737	012366	TST	ERWRD	
(7)	010552	001756		BEQ	\$214	
(4)	010554					
10480	010554					ENDIF
(4)	010554					
10481	010554					LET CHCTR := CHCTR + #1
(7)	010554	005237	012362	INC	CHCTR	
10482	010560					LET CHMSK := CHMSK SHIFT -1
(8)	010560	006237	012360	ASR	CHMSK	
10483	010564					IF CHCTR EQ #3 THEN
(6)	010564	023727	012362 000003	CMP	CHCTR,#3	
(9)	010572	001010		BNE	\$220	
10484	010574					CALL TSTCON
(3)	010574	004737	013530	JSR	PC,TSTCON	
10485	010600					IF CONSOLE EQ #TRUE THEN
(6)	010600	023727	013604 000001	CMP	CONSOLE,#TRUE	
(9)	010606	001002		BNE	\$221	
10486						;EXIT
10487	010610					LET CHCTR := CHCTR + #1
(7)	010610	005237	012362	INC	CHCTR	
10488	010614					ENDIF

```

(4) 010614 $221:
10489 010614
(4) 010614 $220:
10490 010614 UNTIL CHCTR EQ #4 OR ERWRD NE #0
(4) 010614 023727 012362 000004 CMP CHCTR,#4
(6) 010622 001403 BEQ $222
(4) 010624 005737 012366 TST ERWRD
(7) 010630 001707 BEQ $212
(4) 010632 $222:
10491
10492 010632 IF #BIT8 SET IN ERWRD THEN
(6) 010632 032737 000400 012366 BIT #BIT8,ERWRD
(9) 010640 001401 BEQ $223
10493 ;ERROR FLAG UP AFTER TRANSFER
10494 010642 ERRHRD 270
(1) 010642 104270 ERROR 270
10495 010644 ENDIF
(4) 010644 $223: IFB ERWRD NE #0 THEN
10496 010644 TSTB ERWRD
(6) 010644 105737 012366 BEQ $224
(9) 010650 001401 ;DATA COMPARE ERROR
10497 ERRHRD 271
10498 010652 ERROR 271
(1) 010652 104271 ENDIF
10499 010654 $224:
(4) 010654
10500
10501
10502 010654 000137 006502 JMP TST20 ;EXIT TEST
  
```

10504
10505
10510
10511
10512
10517

* START OF SERVICE ROUTINES *

10518 010660
(1) 010660
10519 010660
(4) 010660 013737 001260 012370
10520 010666
(7) 010666 062737 000002 012370
10521 010674
(4) 010674 017720 001470
10522 010700
(6) 010700 023737 012372 012374
(9) 010706 001407
10523
10524 010710
(7) 010710 062737 000002 012370
10525
10526 010716
(7) 010716 052777 000100 001444
10527 010724
(4) 010724 000402
(3) 010726
10528
10529 010726
(7) 010726 005337 012414
10530 010732
(4) 010732
10531 010732
(1) 010732 000002
10532
10533 010734
(1) 010734
10534 010734
(4) 010734 013737 001260 012370
10535 010742
(7) 010742 062737 000006 012370
10536 010750
(4) 010750 013777 012372 001412
10537 010756
(7) 010756 005237 012372
10538
10539 010762
(7) 010762 162737 000002 012370
10540
10541
10542 010770
(7) 010770 042777 000100 001372
10543 010776
(1) 010776 000002
10544
10545 011000
(1) 011000

ROSRV:

MOV RCSR, TMP
ADD #2, TMP
MOV @TMP, (RO)+
CMP TMPO, TMPOE
BEQ \$225

\$225:

DEC TMP4

\$226:

RTI

XOSRV:

MOV RCSR, TMP
ADD #6, TMP
MOV TMPO, @TMP
INC TMPO

R1SRV:

BGNSRV ROSRV

LET TMP := RCSR
LET TMP := TMP + #2
LET (RO)+ := @TMP
IF TMPO NE TMPOE THEN
;GO TO XCSR
LET TMP := TMP + #2
;ENABLE XMIT INTERR
LET @TMP := @TMP SET.BY #BIT6

ELSE

;ALL DONE
LET TMP4 := TMP4 - #1

ENDIF

ENDSRV

BGNSRV XOSRV

LET TMP := RCSR
LET TMP := TMP + #6
LET @TMP := TMPO
LET TMPO := TMPO + #1

;GO BACK TO XCSR
LET TMP := TMP - #2

;DISABLE XMIT INTERRUPTS,
;NOT EXER DOUBLE BUFFERING
LET @TMP := @TMP CLR.BY #BIT6

ENDSRV

BGNSRV R1SRV

```

10546 011000          MOV      RCSR,TMP          LET TMP := RCSR
(4) 011000 013737 001260 012370
10547 011006          ADD      #12,TMP          LET TMP := TMP + #12
(7) 011006 062737 000012 012370
10548 011014          MOV      @TMP,(R1)+        LET (R1)+ := @TMP
(4) 011014 017721 001350
10549 011020          CMP      TMP1,TMP1E        IF TMP1 NE TMP1E THEN
(6) 011020 023737 012376 012400
(9) 011026 001407          BEQ      $227
10550
10551 011030          ADD      #2,TMP          ;GO TO XCSR
(7) 011030 062737 000002 012370          LET TMP := TMP + #2
10552
10553 011036          BIS      #BIT6,@TMP        ;ENABLE XMIT INTERR
(7) 011036 052777 000100 001324          LET @TMP := @TMP SET.BY #BIT6
10554 011044          BR       $230          ELSE
(4) 011044 000402
(3) 011046          $227:
10555
10556 011046          DEC      TMP4          ;ALL DONE
(7) 011046 005337 012414          LET TMP4 := TMP4 - #1
10557 011052          $230:          ENDIF
(4) 011052
10558 011052          RTI          ENDSRV
(1) 011052 000002
10559
10560 011054          X1SRV:          BGNSRV X1SRV
(1) 011054
10561 011054          MOV      RCSR,TMP          LET TMP := RCSR
(4) 011054 013737 001260 012370
10562 011062          ADD      #16,TMP          LET TMP := TMP + #16
(7) 011062 062737 000016 012370
10563 011070          MOV      TMP1,@TMP        LET @TMP := TMP1
(4) 011070 013777 012376 001272
10564 011076          INC      TMP1          LET TMP1 := TMP1 + #1
(7) 011076 005237 012376
10565
10566 011102          SUB      #2,TMP          ;GO BACK TO XCSR
(7) 011102 162737 000002 012370          LET TMP := TMP - #2
10567
10568          ;DISABLE XMIT INTERRUPTS,
10569 011110          BIC      #BIT6,@TMP        ;NOT EXER DOUBLE BUFF
(7) 011110 042777 000100 001252          LET @TMP := @TMP CLR.BY #BIT6
10570 011116          RTI          ENDSRV
(1) 011116 000002
10571
10572 011120          R2SRV:          BGNSRV R2SRV
(1) 011120
10573 011120          MOV      RCSR,TMP          LET TMP := RCSR
(4) 011120 013737 001260 012370
10574 011126          ADD      #22,TMP          LET TMP := TMP + #22
(7) 011126 062737 000022 012370
10575 011134          MOV      @TMP,(R2)+        LET (R2)+ := @TMP
(4) 011134 017722 001230
10576 011140          CMP      TMP2,TMP2E        IF TMP2 NE TMP2E THEN
(6) 011140 023737 012402 012404

```



```

(9) 011146 001407          BEQ      $231
10577                                ;GO TO XCSR
10578 011150          ADD      #2,TMP      LET TMP := TMP + #2
(7) 011150 062737 000002 012370
10579                                ;ENABLE XMIT INTERR
10580 011156          BIS      #BIT6,@TMP  LET @TMP := @TMP SET.BY #BIT6
(7) 011156 052777 000100 001204
10581 011164          BR       $232          ELSE
(4) 011164 000402
(3) 011166          $231:
10582                                ;ALL DONE
10583 011166          DEC      TMP4      LET TMP4 := TMP4 - #1
(7) 011166 005337 012414
10584 011172          $232:          ENDIF
(4) 011172
10585 011172          RTI          ENDSRV
(1) 011172 000002
10586
10587 011174          X2SRV:          BGNSRV X2SRV
(1) 011174
10588 011174          MOV      RCSR,TMP      LET TMP := RCSR
(4) 011174 013737 001260 012370
10589 011202          ADD      #26,TMP      LET TMP := TMP + #26
(7) 011202 062737 000026 012370
10590 011210          MOV      TMP2,@TMP      LET @TMP := TMP2
(4) 011210 013777 012402 001152
10591 011216          INC      TMP2      LET TMP2 := TMP2 + #1
(7) 011216 005237 012402
10592                                ;GO BACK TO XCSR
10593 011222          SUB      #2,TMP      LET TMP := TMP - #2
(7) 011222 162737 000002 012370
10594                                ;DISABLE XMIT INTERRUPTS,
10595                                ;NOT EXER DOUBLE BUFF.
10596 011230          BIC      #BIT6,@TMP  LET @TMP := @TMP CLR.BY #BIT6
(7) 011230 042777 000100 001132
10597 011236          RTI          ENDSRV
(1) 011236 000002
10598
10599 011240          R3SRV:          BGNSRV R3SRV
(1) 011240
10600 011240          MOV      RCSR,TMP      LET TMP := RCSR
(4) 011240 013737 001260 012370
10601 011246          ADD      #32,TMP      LET TMP := TMP + #32
(7) 011246 062737 000032 012370
10602 011254          MOV      @TMP,(R3)+  LET (R3)+ := @TMP
(4) 011254 017723 001110
10603 011260          CMP      TMP3,TMP3E  IF TMP3 NE TMP3E THEN
(6) 011260 023737 012406 012410
(9) 011266 001407          BEQ      $233
10604                                ;GO TO XCSR
10605 011270          ADD      #2,TMP      LET TMP := TMP + #2
(7) 011270 062737 000002 012370
10606                                ;ENABLE XMIT INTERR
10607 011276          BIS      #BIT6,@TMP  LET @TMP := @TMP SET.BY #BIT6
(7) 011276 052777 000100 001064
10608 011304          ELSE
    
```

```
(4) 011304 000402
(3) 011306
10609
10610 011306
(7) 011306 005337 012414
10611 011312
(4) 011312
10612 011312
(1) 011312 000002
10613
10614 011314
(1) 011314
10615 011314
(4) 011314 013737 001260 012370
10616 011322
(7) 011322 062737 000036 012370
10617 011330
(4) 011330 013777 012406 001032
10618 011336
(7) 011336 005237 012406
10619
10620 011342
(7) 011342 162737 000002 012370
10621
10622
10623 011350
(7) 011350 042777 000100 001012
10624 011356
(1) 011356 000002
10625 011360
```

```
BR $234
$233:
DEC TMP4
$234:
RTI
X3SRV:
MOV RCSR,TMP
ADD #36,TMP
MOV TMP3,@TMP
INC TMP3
SUB #2,TMP
BIC #BIT6,@TMP
RTI
SEREND:
```

```
;ALL DONE
LET TMP4 := TMP4 - #1
ENDIF
ENDSRV
BGNSRV X3SRV
LET TMP := RCSR
LET TMP := TMP + #36
LET @TMP := TMP3
LET TMP3 := TMP3 + #1
;GO BACK TO XCSR
LET TMP := TMP - #2
;DISABLE XMIT INTERRUPTS,
;NOT EXER DOUBLE BUFF
LET @TMP := @TMP CLR.BY #BIT6
ENDSRV
```

10627
 10628
 10629
 10630
 10631 011360 000100
 10632 011560 000100
 10633 011760 000100
 10634 012160 000100
 10635 012360
 10636 012360 000000
 10637 012362 000000
 10638 012364 000000
 10639 012366 000000
 10640
 10641
 10642 012370 000000
 10643
 10644 012372 000000
 10645 012374 000000
 10646 012376 000000
 10647 012400 000000
 10648 012402 000000
 10649 012404 000000
 10650 012406 000000
 10651 012410 000002
 10652
 10653 012414 000000
 10654
 10655 012416 011360
 10656 012420 011560
 10657 012422 011760
 10658 012424 012160
 10659
 10660 012426 000040
 10661 012430 000100
 10662 012432 000140
 10663 012434 000200
 10664
 10665 012436 000100
 10666 012440 000200
 10667 012442 000300
 10668 012444 000400
 10669
 10670

;** RECEIVER STATUS TABLES **

CH0TAB: .BLKW 100	:7 BIT WDS	8 BIT WDS
CH1TAB: .BLKW 100	: 0- 37	0- 77
CH2TAB: .BLKW 100	: 40- 77	100-177
CH3TAB: .BLKW 100	:100-137	200-277
STATEND:	:140-177	300-377
CHMSK: .WORD 0	:MASK OF ACTIVE CHANNELS	
CHCTR: .WORD 0	:CHANNEL CTR	
ACTCH: .WORD 0	:ACTIVE CHANNEL CTR	
ERWRD: .WORD 0	:ERROR WORD, LOW BYTE IS NO. OF DATA ERRORS	
	:HIGH BYTE INDICATES ERROR FLAG DETECTED	
TMP: .WORD 0	:TEMP STORAGE FOR SERVICE ROUTINES	
TMP0: 0	:START WORD FOR CH 0	
TMP0E: 0	:END WORD FOR CH 0	
TMP1: 0	:START 1	
TMP1E: 0	:END 1	
TMP2: 0	:START 2	
TMP2E: 0	:END 2	
TMP3: 0	:START 3	
TMP3E: .BLKW 2	:END 3	
TMP4: .WORD		
TABL6: CH0TAB		
	CH1TAB	
	CH2TAB	
	CH3TAB	
TABL7: 40	:7 BIT WORD TABLE	
	100	
	140	
	200	
TABL8: 100	:8 BIT WORD TABLE	
	200	
	300	
	400	

K 7

10672
 10673
 10678
 10679
 10680
 10681
 10682
 10683
 10684
 10685
 10686
 10687
 10688
 10689
 10690
 10691
 10692
 10693
 10694
 10695
 10696
 10697
 10698
 10699
 10704
 (2)
 10705
 (4)
 10706
 (4)
 10707
 (4)
 10708
 10709
 10710
 10711
 10712
 (3)
 10713
 10714
 (6)
 (9)
 10715
 (4)
 10716
 (4)
 (3)
 10717
 (4)
 10718
 (4)
 10719
 10720
 10721
 (6)
 (9)

012446
 012446
 012446 016537 000004 012606
 012446 016537 000000 012610
 012462 105037 012612
 012466
 012466
 012466 036577 000002 000112
 012474 001003
 012476 105037 012613
 012502 000403
 012504
 012504 112737 177777 012613
 012512
 012512
 012512 123765 012613 000006
 012520 001003

```

*****
* ROUTINE:TIMER
* THIS ROUTINE IS USED TO TEST THE STATUS OF ANY BIT
* IN ANY REGISTER.
* INPUTS:
*   HOWLONG   THE MAXIMUM AMOUNT OF TIME TO SPEND IN
*              THIS ROUTINE.
*   WHICHBIT  A MASK WITH THE BIT(S) SET THAT ARE
*              TO BE CHECKED.
*   REG       A POINTER TO THE REGISTER TO BE CHECKED
*   SETCLR    THE DESIRED RESULTS
*              EITHER #SET OR #CLEAR
* OUTPUT:
*   THE 'C' BIT IS SET TO INDICATE AN ERROR
*   BUT IT IS TESTED BY THE IF.ERROR STATEMENT
*
* NOTE:: THE USE OF (R5) IS PART OF THE LINKAGE
*         MECHANISM BETWEEN THE CALLER AND THE CALLED
*****

```

```

ROUTINE TIMER <HOWLONG,WHICHBIT,REG,SETCLR>
TIMER:
MOV    REG(R5),REGSAV          LET    REGSAV := REG(R5) ; GET POINTER TO REGIST
MOV    HOWLONG(R5),TIMSAV     LET    TIMSAV := HOWLONG(R5) ; SAVE HOWLONG FOR
CLR    FLAG                   LET    FLAG :B= #0 ; INITIALIZE THE EXIT FLAG
;                               ; START OF AN INFINITE LOOP
LOOP
$237:
; TEST TO SEE I. WHICHBIT IS SET
; WHICHBIT(R5) NOTSETIN @REGSAV THEN
BIT    WHICHBIT(R5),@REGSAV
BNE    $241
CLR    HOLDSC
ELSE
BR     $242
$241:
MOV    #SET,HOLDSC
ENDIF
$242:
; NOW SEE IF THAT WAS WHAT WE WANTED
IFB    HOLDSC EQ SETCLR(R5) THEN
CMPB   HOLDSC,SETCLR(R5)
BNE    $243

```

```

10722                                     ; JUST THE THING WE NEEDED
10723 012522                               LET     FLAG :B= #TRUE
(4) 012522 112737 000001 012612        MOVB   #TRUE,FLAG
10724 012530                               ENDIF
(4) 012530                               $243:
10725
10726 012530                               EXIFB  FLAG EQ #TRUE OR TIMSAV LE #0
(4) 012530 123727 012612 000001        CMPB   FLAG,#TRUE
(6) 012536 001414                               BEQ   $240
(4) 012540 005737 012610                TST   TIMSAV
(6) 012544 003411                               BLE   $240
10727
10728                                     ; ONE WAY OR THE OTHER, WE ARE DONE
10729                                     ; IF WE ARE STILL HERE THEN HANG AROUND A WHILE
10730 012546                               WAITMS 1           ;WAIT FOR 1 MILLI-SECONDS
(4) 012546 010546                               MOV   R5,-(SP)
(5) 012550 012745 000001                MOV   #1,-(R5)
(4) 012554 004737 012620                JSR   PC,WAIT
(4) 012560 012605                MOV   (SP)+,R5
10731 012562                               LET   TIMSAV := TIMSAV - #1 ; COUNTING DOWN
(7) 012562 005337 012610                DEC   TIMSAV
10732 012566                               ENDL00P          ; CONTINUED AT THE TOP
(4) 012566 000737                               BR    $237
(3) 012570                               $240:
10733
10734                                     ; ONLY 2 WAYS TO GET HERE
10735                                     ; 1). WE RAN OUT OF TIME---ERROR !!
10736                                     ; 2). THE BIT IS IN THE CORRECT CONDITION--GOOD !!
10737
10738 012570                               IFB    FLAG EQ #TRUE THEN
(6) 012570 123727 012612 000001        CMPB   FLAG,#TRUE
(9) 012576 001001                               BNE   $244
10739 012600                               RETURN NO.ERROR   ; GOOD
(4) 012600 000405                               BR    $235
10740 012602                               ENDF
(4) 012602                               $244:
10741 012602                               RETURN ERROR      ; BAD
(2) 012602 000261                               SEC
(4) 012604 000404                               BR    $236
10742
10743 012606 000000        REGSAV: .WORD 0
10744 012610 000000        TIMSAV: .WORD 0
10745 012612 000         FLAG:   .BYTE 0
10746 012613 000         HOLDSC: .BYTE 0
10747
10748 012614                                     ; WE ARE DONE GO BACK HOME
(3) 012614                               ENDRTN
(2) 012614 000241        $235:
(3) 012616                               CLC
(2) 012616 000207        $236:
                               RTS    FC

```

10750
 10751
 10756
 10757
 10758
 10759
 10760
 10761
 10762
 10763
 10768 012620
 (2) 012620
 10769 012620
 10770 012626
 (4) 012626 016501 000000
 10771 012632
 (4) 012632 012702 000001
 (5) 012636 000402
 (4) 012640
 (8) 012640 062702 000001
 (5) 012644
 (5) 012644 020201
 (7) 012646 101010
 10772 012650
 (4) 012650 005003
 (5) 012652 000401
 (4) 012654
 (8) 012654 005203
 (5) 012656
 (5) 012656 020327 000100
 (7) 012662 003001
 10773 012664
 (4) 012664 000773
 (3) 012666
 10774 012666
 (4) 012666 000764
 (3) 012670
 10775 012670
 10776 012676
 (3) 012676
 (3) 012676
 (2) 012676 000207

```

*****
* ROUTINE:WAIT
* THIS ROUTINE IS USED TO DELAY EXECUTION OF THE
* MAIN PROGRAM FOR A SPECIFIED AMOUNT OF TIME.
* THIS IS ACCOMPLISHED BY INCREMENTING A
* REGISTER UP TO A LIMIT. THE INNER LOOP IS SET
* TO APPROXIMATE 1 MILLI SEC.
*****

```

```

ROUTINE WAIT <TIME>
WAIT:
      PUSH <R1,R2,R3>
      LET R1 := TIME(R5)
      MOV TIME(R5),R1
      INCRU R2 FROM #1 TO R1 BY #1
      MOV #1,R2
      BR $247
$250: ADD #01,R2
$247: CMP R2,R1
      BHI $251
      INCR R3 FROM #0 TO #100 BY #1
      CLR R3
      BR $252
$253: INC R3
$252: CMP R3,#100
      BGT $254
      ENDINC
$254: BR $253
      ENDINC
$251: BR $250
      ENDINC
      POP <R3,R2,R1>
      ENDRTN
$245:
$246: RTS PC

```

```

10778
10779
10780
10781          .SBTTL  ROUTINE TO SIZE THE BUS
10782
10783 012700 005737 001252          SIZE:  TST    $DEVM          ;BR IF INITIALLY SET
10784 012704 001060                    BNE    4$          ;BYPASS AUTO-SIZING
10785
10786 012706 012737 013610 000004 1$:  MOV    #INTSRV,ERRVEC
10787 012714 012737 000300 000006      MOV    #PR6,ERRVEC+2
10788
10789 012722 013737 001250 013514      MOV    $BASE,TMP6
10790 012730 012737 000001 013512      MOV    #1,SFTREG
10791
10792 012736 005037 013616          2$:  CLR    INTFLAG
10793 012742 005777 000546          TST    @TMP6          ;SEE IF THERE
10794 012746 005737 013616          TST    INTFLAG        ;GOT INTERRUPT?
10795 012752 001003                    BNE    3$          ;BR IF YES (NO DEVICE)
10796 012754 053737 013512 001252      BIS    SFTREG,$DEVM   ;ELSE THERE, SET MAP
10797
10798 012762 062737 000010 013514 3$:  ADD    #10,TMP6        ;GO TO NEXT CHANNEL
10799 012770 006337 013512          ASL    SFTREG
10800 012774 001360                    BNE    2$          ;BR IF MORE TO GO
10801
10802 012776 012737 000006 000004      MOV    #6,ERRVEC      ;RESTORE
10803 013004 005037 000006
10804
10805 013010 005737 001252          TST    $DEVM          ;ANYONE THERE?
10806 013014 001014                    BNE    4$          ;BR IF YES
10807 013016          TYPTXT <<CRLF>!NO DEV TO TEST!>
10808 013044 000777          BR      .            ;LOOP HERE TILL PROBLEM FIXED
10809                                     ;& RESTART AT 200
10810 013046 105737 001221          4$:  TSTB   $USWR+1
10811 013052 001434          BEQ    6$          ;SEE IF ANY CONSOLE
10812                                     ;BR IF NONE
10813 013054 010046          MOV    RO,-(SP)      ;SAVE RO
10814 013056 113700 001221          MOVB   $USWR+1,RO    ;GET CONSOLE DEVICE X2
10815 013062 020027 000010          CMP    RO,#10
10816 013066 003005          BGT    5$          ;BR IF TOO HI
10817 013070 056037 013516 001252      BIS    TABL1-2(RO),$DEVM ;SET CONSOLE BIT ON MAP
10818 013076 012600          MOV    (SP)+,RO     ;RESTORE RO
10819 013100 000421          BR      6$
10820
10821 013102          5$:  TYPTXT <<CRLF>!CONSOLE IN $USWR WRONG!>
10822 013140 000137 014362          JMP    $EOP          ;START ALL OVER
10823                                     ;STACK WILL RESET IN 'LOOP'
10824 013144 013737 001252 013502 6$:  MOV    $DEVM,MASK1
10825 013152 013737 001252 013504      MOV    $DEVM,MASK2
10826 013160 013737 001252 013506      MOV    $DEVM,MASK3
10827 013166 013737 001252 013510      MOV    $DEVM,MASK4
10828
10829 013174 042737 177760 013502      BIC    #^C<17>,MASK1 ;SAVE ONLY MODULE 1 CHANNELS
10830 013202 042737 177417 013504      BIC    #^C<360>,MASK2 ;
10831 013210 042737 170377 013506      BIC    #^C<7400>,MASK3 ;
10832 013216 042737 007777 013510      BIC    #^C<170000>,MASK4 ;
10833

```

```

10834 013224 006237 013504      ASR      MASK2
10835 013230 006237 013504      ASR      MASK2
10836 013234 006237 013504      ASR      MASK2
10837 013240 006237 013504      ASR      MASK2
10838                                     ;RIGHT JUSTIFY MODULE 2 CHANNELS
10839 013244 000337 013506      SWAB     MASK3
10840                                     ;
10841 013250 000337 013510      SWAB     MASK4
10842 013254 006237 013510      ASR      MASK4
10843 013260 006237 013510      ASR      MASK4
10844 013264 006237 013510      ASR      MASK4
10845 013270 006237 013510      ASR      MASK4
10846                                     ;
10847 013274                                     TYP TXT <<CRLF>!WILL TEST:!

```



```
10890
10891
10892
10893
10894
10895
10896 013530 113737 001221 013606 TSTCON: MOVB $USWR+1,TMP7 ;GET CONSOLE INFO ONLY
10897 013536 006237 013606 ASR TMP7 ;RIGHT JUSTIFY
10898 013542 023737 013606 001206 CMP TMP7,$UNIT ;SEE IF UNIT UNDER TEST HAS CONSOLE
10899 013550 001403 BEQ 1$ ;BR IF YES
10900 013552 005037 013604 CLR CONSOLE ;ELSE CLEAR STALE INFO
10901 013556 000207 RTS PC
10902
10903 013560 013737 001144 014156 1$: MOV $TKS,ADDRESS ;FORCE TTY ADDRESS
10904 013566 012737 000060 014160 MOV #TKVEC,VECTOR ;VECTOR
10905 013574 012737 000001 013604 MOV #TRUE,CONSOLE ;SET FLAG
10906 013602 000207 RTS PC
10907
10908 013604 000000 CONSOLE: 0 ;FLAG, 1= TESTING CONSOLE DEVICE
10909 013606 000000 TMP7: 0 ;HOLD CONSOLE #
10910
10911
10912
10913
10914
10919
10920
10921
10922
10923
10924
10929 013610 BGNSRV INTSRV ;GLOBAL INTERRUPT SERVICE ROUTINE
(1) 013610 INTSRV:
10930 ;ADD 1 TO 'INTERRUPT OCCURED' FLAG
10931 013610 005237 013616 INC INTFLAG LET INTFLAG := INTFLAG + #1
(7) 013610 ENDSRV ;THAT'S ALL
10932 013614 (1) 013614 000002 RTI
10933 013616 000000 INTFLAG: 0
10934
```

10936
 10937
 10938
 10939
 10940
 10945
 10946
 10947
 10948
 10949
 10954
 10955
 10956
 10957
 10958
 10959
 10960
 10961
 10962
 10963
 10964
 10965
 10966
 10967
 10968
 10969
 10970
 10971
 10972
 10973
 10974
 10975
 10976
 10977
 10978
 10979
 10980
 10981
 10982
 10983
 10984
 10985
 10986
 10987
 10988
 10989
 10990
 10991
 10992
 10993
 10994
 10995
 10996
 10997
 10998
 10999

.SBTTL ROUTINE TO SET UP FOR NEXT MODULE/CHANNEL ADDRESS

```

:*****
:* THIS ROUTINE CAUSES ADRS TO POINT TO THE
:* ADDRESS OF DLV11-J UNDER TEST, ADRS +2 TO
:* POINT TO THE VECTOR OF THE DLV11-J UNDER TEST.
:*****
  
```

```

CYCLE:  MOV  $BASE,ADDRESS
        MOV  $VECT1,VECTOR

        CMP  $UNIT,#5           ;DONE ALL MODULES?
        BNE  1$                ;BR IF NO
        CLR  PHASE2            ;RE-INIT
        CLR  CHAN
        MOV  #1,$UNIT
        CLR  P1CNT
        JMP  $EOP              ;& EXIT BACK TO 'LOOP'
                                       ;STACK WILL GET RESET THERE.

1$:     MOV  $UNIT,R0
        ASL  R0                ;MULT BY 2 TO INDEX INTO TABLES
        ADD  TABL2-2(R0),ADDRESS ;ADD MODULE OFFSET
        ADD  TABL2-2(R0),VECTOR  ;ADD VECTOR OFFSET
        MOV  @TABL3-2(R0),MASK   ;STORE CHANNELS IN 'MASK'

        CLR  CONSOLE
        TST  MASK              ;ANY CHANNELS TO BE TESTED?
        BNE  2$                ;BR IF YES
        INC  $UNIT             ;ELSE BUMP UNIT #
        JMP  CYCLE            ;TRY AGAIN

2$:     CMP  PHASE2,#TRUE      ;DOING PHASE 2?
        BEQ  6$                ;BR IF YES
        CMP  CHAN,#4          ;ELSE, DONE ALL CHANNELS?
        BNE  4$                ;BR IF NO

        CLR  CHAN              ;ELSE BACK TO 0
        BIT  #WRAP,$USWR      ;DOING DATA WRAP TESTS?
        BNE  3$                ;BR IF YES
        INC  $UNIT             ;ELSE GO TO NEXT UNIT, NO PHASE 2
        JMP  CYCLE            ;& DO IT

3$:     MOV  #TRUE,PHASE2
        CLR  P1CNT
        JMP  CYCLE            ;GO TO PHASE 2 TESTING

4$:     MOV  CHAN,R0
        ASL  R0                ;MULT BY 2 TO INDEX TABLE
        ADD  TABL4(R0),ADDRESS  ;ADD CHANNEL OFFSET
        ADD  TABL4(R0),VECTOR  ;ADD VECTOR OFFSET
        BIT  TABL5(R0),MASK    ;IS THAT CHANNEL TO BE TESTED?
        BEQ  7$                ;BR IF NO
  
```

```

11000 014060 023727 014164 000003      CMP      CHAN,#3      ;IS IT CHAN 3?
11001 014066 001002                      BNE      5$          ;BR IF NO
11002 014070 004737 013530      JSR      PC,TSTCON   ;ELSE SEE IF ITS THE CONSOLE
11003
11004 014074 005237 014164      5$:      INC      CHAN      ;BUMP CHANNEL CTR FOR NEXT TIME
11005 014100 012701 014156      6$:      MOV      #ADDRESS,ADRS
11006 014104 000207                      RTS      PC          ;GO TO PHASE 1 TESTS
11007
11008 014106 005237 014164      7$:      INC      CHAN
11009 014112 000137 013620      JMP      CHAN        ;TRY AGAIN
11010
11011 014116 000000      TABL2:  0            ;OFFSET FOR MODULE 1
11012 014120 000040                      40          ;
11013 014122 000100                      100         ;
11014 014124 000140                      140         ;
11015
11016 014126 013502      TABL3:  MASK1        ;MODULE 1 CHANNEL DATA
11017 014130 013504                      MASK2        ;
11018 014132 013506                      MASK3        ;
11019 014134 013510                      MASK4        ;
11020
11021 014136 000000      TABL4:  0            ;CHANNEL 0 OFFSET
11022 014140 000010                      10          ;
11023 014142 000020                      20          ;
11024 014144 000030                      30          ;
11025
11026 014146 000001      TABL5:  BIT0        ;BIT TO TEST CHANNEL 0 PRESENT
11027 014150 000002                      BIT1        ;
11028 014152 000004                      BIT2        ;
11029 014154 000010                      BIT3        ;
11030
11031 014156 000000      ADDRESS: 0
11032 014160 000000      VECTOR: 0
11033 014162 000000      MASK: 0
11034 014164 000000      CHAN: 0
11035 014166 000000      PHASE2: 0
11036 014170 000000      P1CNT: 0      ;CTR TO PRINT 'PHASE 1' ONLY ONCE
11037
11038

```


11062
 11063

.SBTTL END OF PASS ROUTINE

```

(1)
(2)
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1)
(1) 014362
(1) 014362 000004
(1) 014364 005037 001102
(1) 014370 005037 001160
(1) 014374 005237 001202
(1) 014400 042737 100000 001202
(1) 014406 005327
(1) 014410 000001
(1) 014412 003022
(1) 014414 012737
(1) 014416 000001
(1) 014420 014410
(1) 014422 104401 014467
(2) 014426 013746 001202
(2) 014432 104405
(1) 014434 104401 014464
(1) 014440 013700 000042
(1) 014444 001405
(1) 014446 000005
(1) 014450 004710
(1) 014452 000240
(1) 014454 000240
(1) 014456 000240
(1) 014460
(1) 014460 000137
(1) 014462 001732
(1)
(1)
(1) 014464 377 377 000
(1) 014467 015 042412 042116
(1) 014474 050040 051501 020123
(1) 014502 000043
    
```

```

*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
;*TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO LOOP

$EOP:
SCOPE
CLR $TSTNM ;;ZERO THE TEST NUMBER
CLR $TIMES ;;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;;INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?
$EOPCT: .WORD 1
BGT $DOAGN ;;YES
MOV (PC)+,@(PC)+ ;;RESTORE COUNTER
$ENDCT: .WORD 1
TYPE $SENDMG ;;TYPE 'END PASS #'
MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE $ENULL ;;TYPE A NULL CHARACTER
$GET42: MOV @#42,R0 ;;GET MONITOR ADDRESS
BEQ $DOAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
$ENDAD: JSR PC,(R0) ;;GO TO MONITOR
NOP ;;SAVE ROOM
NOP ;;FOR
NOP ;;ACT11
$DOAGN:
JMP @(PC)+ ;;RETURN
$RTNAD: .WORD LOOP

$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
$SENDMG: .ASCIZ <15><12>/END PASS #/
    
```



```

(1) 014664 105337 014762          DECB  $CHARCNT      ;;DO NOT COUNT AS A COUNT
(1) 014670 000770          BR    7$           ;;LOOP
(1)
(1)
(1) ;HORIZONTAL TAB PROCESSOR
(1) 014672 112716 000040      8$:  MOVB  #' ,(SP)      ;;REPLACE TAB WITH SPACE
(1) 014676 004737 014716      9$:  JSR   PC,$TYPEC     ;;TYPE A SPACE
(1) 014702 132737 000007 014762  BITB  #7,$CHARCNT     ;;BRANCH IF NOT AT
(1) 014710 001372          BNE   9$           ;;TAB STOP
(1) 014712 005726          TST   (SP)+        ;;POP SPACE OFF STACK
(1) 014714 000724          BR    2$           ;;GET NEXT CHARACTER
(1) 014716 105777 164226      $TYPEC: TSTB @STPS     ;;WAIT UNTIL PRINTER IS READY
(1) 014722 100375          BPL  $TYPEC
(1) 014724 116677 000002 164220  MOVB  2(SP),@STPB   ;;LOAD CHAR TO BE TYPED INTO DATA REG.
(1)
(1) 014732 122766 000015 000002  CMPB  #CR,2(SP)     ;;IS CHARACTER A CARRIAGE RETURN?
(1) 014740 001003          BNE   1$           ;;BRANCH IF NO
(1) 014742 105037 014762          CLRB  $CHARCNT     ;;YES--CLEAR CHARACTER COUNT
(1) 014746 000406          BR    $TYPEX       ;;EXIT
(1) 014750 122766 000012 000002  1$:  CMPB  #LF,2(SP)   ;;IS CHARACTER A LINE FEED?
(1) 014756 001402          BEQ  $TYPEX       ;;BRANCH IF YES
(1) 014760 105227          INCB  (PC)+        ;;COUNT THE CHARACTER
(1) 014762 000000          $CHARCNT: .WORD  0 ;;CHARACTER COUNT STORAGE
(1) 014764 000207          $TYPEX: RTS      PC
(1)
(1)
(1)

```

11068
 11069

.SBTTL TTY INPUT ROUTINE

.ENABL LSB

*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
 *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
 *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
 *WHEN OPERATING IN TTY FLAG MODE.

(1)	014766	022737	000176	001140	\$CKSWR: CMP	#SWREG,SWR	:: IS THE SOFT-SWR SELECTED?
(1)	014774	001074			BNE	15\$:: BRANCH IF NO
(1)	014776	105777	164142		TSTB	@\$TKS	:: CHAR THERE?
(1)	015002	100071			BPL	15\$:: IF NO, DON'T WAIT AROUND
(1)	015004	117746	164136		MOVB	@\$TKB,-(SP)	:: SAVE THE CHAR
(1)	015010	042716	177600		BIC	#^C177,(SP)	:: STRIP-OFF THE ASCII
(1)	015014	022726	000007		CMP	#7,(SP)+	:: IS IT A CONTROL G?
(1)	015020	001062			BNE	15\$:: NO, RETURN TO USER
(1)	015022	123727	001134	000001	CMPB	\$AUTOB,#1	:: ARE WE RUNNING IN AUTO-MODE?
(1)	015030	001456			BEQ	15\$:: BRANCH IF YES
(1)	015032	104401	015513				
(1)	015036	104401	015520		\$GTSWR: TYPE	,\$CNTLG	:: ECHO THE CONTROL-G (^G)
(2)	015042	013746	000176		TYPE	,\$MSWR	:: TYPE CURRENT CONTENTS
(2)	015046	104402			MOV	SWREG,-(SP)	:: SAVE SWREG FOR TYPEOUT
(1)	015050	104401	015531		TYPOC		:: GO TYPE--OCTAL ASCII(ALL DIGITS)
(1)	015054	005046			TYPE	,\$MNEW	:: PROMPT FOR NEW SWR
(1)	015056	005046			19\$: CLR	-(SP)	:: CLEAR COUNTER
(1)					CLR	-(SP)	
(1)	015060	105777	164060		:: THE NEW SWR		
(1)	015064	100375			7\$: TSTB	@\$TKS	:: CHAR THERE?
(1)					BPL	7\$:: IF NOT TRY AGAIN
(1)	015066	117746	164054				
(1)	015072	042716	177600		MOVB	@\$TKB,-(SP)	:: PICK UP CHAR
(1)					BIC	#^C177,(SP)	:: MAKE IT 7-BIT ASCII
(1)							
(1)	015076	021627	000025		9\$: CMP	(SP),#25	:: IS IT A CONTROL-U?
(1)	015102	001005			BNE	10\$:: BRANCH IF NOT
(1)	015104	104401	015506		TYPE	,\$CNTLU	:: YES, ECHO CONTROL-U (^U)
(1)	015110	062706	000006		20\$: ADD	#6,SP	:: IGNORE PREVIOUS INPUT
(1)	015114	000757			BR	19\$:: LET'S TRY IT AGAIN
(1)							
(1)	015116	021627	000015		10\$: CMP	(SP),#15	:: IS IT A <CR>?
(1)	015122	001022			BNE	16\$:: BRANCH IF NO
(1)	015124	005766	000004		TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
(1)	015130	001403			BEQ	11\$:: BRANCH IF YES
(1)	015132	016677	000002	164000	MOV	2(SP),@SWR	:: SAVE NEW SWR
(1)	015140	062706	000006		11\$: ADD	#6,SP	:: CLEAR UP STACK
(1)	015144	104401	001171		14\$: TYPE	,\$CRLF	:: ECHO <CR> AND <LF>
(1)	015150	123727	001135	000001	CMPB	\$INTAG,#1	:: RE-ENABLE TTY KBD INTERRUPTS?
(1)	015156	001003			BNE	15\$:: BRANCH IF NOT


```

(1) 015160 012777 000100 163756      MOV      #100,@$TKS      ;;RE-ENABLE TTY KBD INTERRUPTS
(1) 015166 000002                    15$: RTI                    ;;RETURN
(1) 015170 004737 014716              16$: JSR      PC,$TYPEC   ;;ECHO CHAR
(1) 015174 021627 000060              CMP      (SP),#60      ;;CHAR < 0?
(1) 015200 002420                    BLT      18$           ;;BRANCH IF YES
(1) 015202 021627 000067              CMP      (SP),#67      ;;CHAR > 7?
(1) 015206 003015                    BGT      18$           ;;BRANCH IF YES
(1) 015210 042726 000060              BIC      #60,(SP)+     ;;STRIP-OFF ASCII
(1) 015214 005766 000002              TST      2(SP)         ;;IS THIS THE FIRST CHAR
(1) 015220 001403                    BEQ      17$           ;;BRANCH IF YES
(1) 015222 006316                    ASL      (SP)          ;;NO, SHIFT PRESENT
(1) 015224 006316                    ASL      (SP)          ;;CHAR OVER TO MAKE
(1) 015226 006316                    ASL      (SP)          ;;ROOM FOR NEW ONE.
(1) 015230 005266 000002              17$: INC      2(SP)      ;;KEEP COUNT OF CHAR
(1) 015234 056616 177776              BIS      -2(SP), (SP)  ;;SET IN NEW CHAR
(1) 015240 000707                    BR       7$            ;;GET THE NEXT ONE
(1) 015242 104401 001170              18$: TYPE     $QUES     ;;TYPE ?<CR><LF>
(1) 015246 000720                    BR       20$          ;;SIMULATE CONTROL-U
(1) .DSABL  LSB
  
```

```

(1)
(1)
(2)
(1) *****
(1) *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
(1) *CALL:
(1) * RDCHR                    ;;INPUT A SINGLE CHARACTER FROM THE TTY
(1) * RETURN HERE              ;;CHARACTER IS ON THE STACK
(1) *
(1) * WITH PARITY BIT STRIPPED OFF
(1) *
  
```

```

(1) 015250 011646                    $RDCHR: MOV      (SP),-(SP)  ;;PUSH DOWN THE PC
(1) 015252 016666 000004 000002      MOV      4(SP),2(SP)   ;;SAVE THE PS
(1) 015260 105777 163660              1$: TSTB     @$TKS      ;;WAIT FOR
(1) 015264 100375                    BPL      1$            ;;A CHARACTER
(1) 015266 117766 163654 000004      MOVB     @$TKB,4(SP)   ;;READ THE TTY
(1) 015274 042766 177600 000004      BIC      #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
(1) 015302 026627 000004 000023      CMP      4(SP),#23    ;;IS IT A CONTROL-S?
(1) 015310 001013                    BNE      3$            ;;BRANCH IF NO
(1) 015312 105777 163626              2$: TSTB     @$TKS      ;;WAIT FOR A CHARACTER
(1) 015316 100375                    BPL      2$            ;;LOOP UNTIL ITS THERE
(1) 015320 117746 163622              MOVB     @$TKB,-(SP)   ;;GET CHARACTER
(1) 015324 042716 177600              BIC      #^C177,(SP)  ;;MAKE IT 7-BIT ASCII
(1) 015330 022627 000021              CMP      (SP)+,#21    ;;IS IT A CONTROL-Q?
(1) 015334 001366                    BNE      2$            ;;IF NOT DISCARD IT
(1) 015336 000750                    BR       1$            ;;YES, RESUME
(1) 015340 026627 000004 000140      3$: CMP      4(SP),#140  ;;IS IT UPPER CASE?
(1) 015346 002407                    BLT      4$            ;;BRANCH IF YES
(1) 015350 026627 000004 000175      CMP      4(SP),#175   ;;IS IT A SPECIAL CHAR?
(1) 015356 003003                    BGT      4$            ;;BRANCH IF YES
(1) 015360 042766 000040 000004      BIC      #40,4(SP)    ;;MAKE IT UPPER CASE
(1) 015366 000002                    4$: RTI                    ;;GO BACK TO USER
  
```

```

(2) *****
(1) *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
(1) *CALL:
(1) * RDLIN                    ;;INPUT A STRING FROM THE TTY
(1) * RETURN HERE              ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
(1) * TERMINATOR WILL BE A BYTE OF ALL 0'S
  
```

```

(1)
(1) 015370 010346          SRDLIN: MOV      R3,-(SP)          ;;SAVE R3
(1) 015372 012703 015476  1$:      MOV      #$TTYIN,R3      ;;GET ADDRESS
(1) 015376 022703 015506  2$:      CMP      #$TTYIN+8.,R3    ;;BUFFER FULL?
(1) 015402 101405          BLOS     4$          ;;BR IF YES
(1) 015404 104410          RDCHR          ;;GO READ ONE CHARACTER FROM THE TTY
(1) 015406 112613          MOVB    (SP)+,(R3)      ;;GET CHARACTER
(1) 015410 122713 000177  10$:     CMPB    #177,(R3)     ;;IS IT A RUBOUT
(1) 015414 001003          BNE     3$          ;;SKIP IF NOT
(1) 015416 104401 001170  4$:      TYPE    ,SQUES      ;;TYPE A '?'
(1) 015422 000763          BR      1$          ;;CLEAR THE BUFFER AND LOOP
(1) 015424 111337 015474  3$:      MOVB    (R3),9$      ;;ECHO THE CHARACTER
(1) 015430 104401 015474          TYPE    ,9$
(1) 015434 122723 000015          CMPB    #15,(R3)+    ;;CHECK FOR RETURN
(1) 015440 001356          BNE     2$          ;;LOOP IF NOT RETURN
(1) 015442 105063 177777          CLRB   -1(R3)       ;;CLEAR RETURN (THE 15)
(1) 015446 104401 001172          TYPE    ,SLF        ;;TYPE A LINE FEED
(1) 015452 012603          MOV     (SP)+,R3    ;;RESTORE R3
(1) 015454 011646          MOV     (SP),-(SP)  ;;ADJUST THE STACK AND PUT ADDRESS OF THE
(1) 015456 016666 000004 000002  MOV     4(SP),2(SP)  ;;FIRST ASCII CHARACTER ON IT
(1) 015464 012766 015476 000004  MOV     #$TTYIN,4(SP)
(1) 015472 000002          RTI
(1) 015474 000          9$:      .BYTE   0          ;;RETURN
(1) 015475 000          .BYTE   0          ;;STORAGE FOR ASCII CHAR. TO TYPE
(1) 015476 000010          $TTYIN: .BLKB  8.   ;;TERMINATOR
(1) 015506 052536 005015 000          $CNTLU: .ASCIZ  /^U/<15><12>  ;;RESERVE 8 BYTES FOR TTY INPUT
(1) 015513 0136 006507 000012  $CNTLG: .ASCIZ  /^G/<15><12>  ;;CONTROL 'U'
(1) 015520 005015 053523 020122  $MSWR:  .ASCIZ  <15><12>/SWR = /  ;;CONTROL 'G'
(1) 015526 020075 000
(1) 015531 040 047040 053505  $MNEW:  .ASCIZ  / NEW = /
(1) 015536 036440 000040
  
```

11071
 11072

.SBTTL APT COMMUNICATIONS ROUTINE

```

(1)
(2)
(1) 015542 112737 000001 016006 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
(1) 015550 112737 000001 016004 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
(1) 015556 000403 BR $ATYC
(1) 015560 112737 000001 016006 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
(1) 015566 $ATYC:
(3) 015566 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
(3) 015570 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
(1) 015572 105737 016004 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
(1) 015576 001450 BEQ 5$ ;;IF NOT: BR
(1) 015600 122737 000001 001214 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
(1) 015606 001031 BNE 3$ ;;IF NOT: BR
(1) 015610 132737 000100 001215 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
(1) 015616 001425 BEQ 3$ ;;IF NOT: BR
(1) 015620 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
(1) 015624 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
(1) 015632 005737 001174 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
(1) 015636 001375 BNE 1$ ;;IF NOT: WAIT
(1) 015640 010037 001210 MOV R0,$MSGAD
(1) ;;PUT ADDR IN MAILBOX
(1) 015644 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
(1) 015646 001376 BNE 2$
(1) 015650 163700 001210 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
(1) 015654 006200 ASR R0 ;;GET MESSAGE LNGTH IN WORDS
(1) 015656 010037 001212 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
(1) 015662 012737 000004 001174 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
(1) 015670 000413 BR 5$
(1) 015672 017637 000004 015716 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
(1) 015700 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
(3) 015706 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
(1) 015712 004737 014504 JSR PC,$TYPE ;;CALL TYPE MACRO
(1) 015716 000000 4$: .WORD 0
(1) 015720 5$:
(1) 015720 105737 016006 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
(1) 015724 001416 BEQ 12$ ;;IF NOT: BR
(1) 015726 005737 001214 TST $ENV ;;RUNNING UNDER APT?
(1) 015732 001413 BEQ 12$ ;;IF NOT: BR
(1) 015734 005737 001174 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
(1) 015740 001375 BNE 11$ ;;IF NOT: WAIT
(1) 015742 017637 000004 001176 MOV @4(SP),$FATAL ;;GET ERROR #
(1) 015750 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
(1) 015756 005237 001174 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
(1) 015762 105037 016006 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
(1) 015766 105037 016005 CLRB $LFLG ;;CLEAR LOG FLAG
(1) 015772 105037 016004 CLRB $MFLG ;;CLEAR MESSAGE FLAG
(3) 015776 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
(3) 16000 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
(1) 016002 000207 RTS PC ;;RETURN
(1) 016004 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
(1) 016005 000 $LFLG: .BYTE 0
(1) ;;LOG FLAG
(1) 016006 000 $FFLG: .BYTE 0 ;;FATAL FLAG
(1) 016010 .EVEN
  
```

(1)	000200	APTSIZE=200
(1)	000001	APTENV=001
(1)	000100	APTSPool=100
(1)	000040	APTCSUP=040

(1)	016434	011637	001110		MOV	(SP), \$LPERR	::SAVE ERROR LOOP ADDRESS
(1)	016440	005037	001162		CLR	\$ESCAPE	::CLEAR THE ESCAPE FROM ERROR ADDRESS
(1)	016444	112737	000001	001115	MOVB	#1, \$ERMAX	::ONLY ALLOW ONE(1) ERROR ON NEXT TEST
(1)	016452	013777	001102	162462	SOVER: MOV	\$TSTNM, @DISPLAY	::DISPLAY TEST NUMBER
(1)	016460	013716	001106		MOV	\$LPADR, (SP)	::FUDGE RETURN ADDRESS
(1)	016464	000002			RTI		::FIXES PS
(1)	016466	003720			\$MXCNT: 2000.		::MAX. NUMBER OF ITERATIONS

(3)	016650	012602			MOV	(SP)+,R2	::POP STACK INTO R2
(3)	016652	012601			MOV	(SP)+,R1	::POP STACK INTO R1
(3)	016654	012600			MOV	(SP)+,RO	::POP STACK INTO RO
(1)	016656	104401	016704		TYPE	\$DBLK	::NOW TYPE THE NUMBER
(1)	016662	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
(1)	016670	012616			MOV	(SP)+,(SP)	
(1)	016672	000002			RTI		::RETURN TO USER
(1)	016674	023420			\$DTBL:	10000.	
(1)	016676	001750				1000.	
(1)	016700	000144				100.	
(1)	016702	000012				10.	
(1)	016704	000004			\$DBLK:	.BLKW 4	


```

(1) 017054 001403          BEQ      5$          ;;BR IF YES
(1) 017056 005204          4$: INC      R4          ;;DON'T SUPPRESS ANYMORE 0'S
(1) 017060 052703 000060  BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
(1) 017064 052703 000040  5$: BIS      #' R3      ;;MAKE ASCII IF NOT ALREADY
(1) 017070 110337 017134  MOVB     R3,8$        ;;SAVE FOR TYPING
(1) 017074 104401 017134  1,PE     ,8$        ;;GO TYPE THIS DIGIT
(1) 017100 105337 017136  7$: DECB    $OCNT      ;;COUNT BY 1
(1) 017104 003347          BGT      2$          ;;BR IF MORE TO DO
(1) 017106 002402          BLT      6$          ;;BR IF DONE
(1) 017110 005204          INC      R4          ;;INSURE LAST DIGIT ISN'T A BLANK
(1) 017112 000744          BR       2$          ;;GO DO THE LAST DIGIT
(1) 017114 012605          6$: MOV     (SP)+,R5    ;;RESTORE R5
(1) 017116 012604          MOV     (SP)+,R4    ;;RESTORE R4
(1) 017120 012603          MOV     (SP)+,R3    ;;RESTORE R3
(1) 017122 016666 000002 000004 MOV     2(SP),4(SP) ;;SET THE STACK FOR RETURNING
(1) 017130 012616          MOV     (SP)+,(SP)
(1) 017132 000002          RTI          ;;RETURN
(1) 017134 000          8$: .BYTE  0          ;;STORAGE FOR ASCII DIGIT
(1) 017135 000          .BYTE  0          ;;TERMINATOR FOR TYPE ROUTINE
(1) 017136 000          $OCNT: .BYTE 0       ;;OCTAL DIGIT COUNTER
(1) 017137 000          $OFILL: .BYTE 0     ;;ZERO FILL SWITCH
(1) 017140 000000          $OMODE: .WORD 0     ;;NUMBER OF DIGITS TO TYPE
  
```


(1)	017222	104401	017230	\$CLKVEC:	TYPE,CLKMES
(1)	017226	000000			HALT
(1)	017230	005015	045514	042526	CLKMES: .ASCIZ <15><12>/LKVEC INTERRUPT - DISCONNECT LTC /
(1)	017236	020103	047111	042524	
(1)	017244	051122	050125	020124	
(1)	017252	020055	044504	041523	
(1)	017260	047117	042516	052103	
(1)	017266	046040	041524	000040	
11094		000001			.END

10008#	10040#	10053#	10054#	10078#	10080#	10087#	10088#	10090#	10091#	10092#	10099#	10100#		
10101#	10105#	10106#	10108#	10110#	10112#	10114#	10122#	10124#	10125#	10127#	10129#	10144#		
10152#	10154#	10155#	10157#	10208#	10210#	10211#	10213#	10219#	10221#	10222#	10224#	10229#		
10231#	10232#	10234#	10239#	10241#	10242#	10244#	10249#	10251#	10252#	10254#	10259#	10261#		
10262#	10264#	10269#	10271#	10272#	10274#	10279#	10281#	10282#	10284#	10344#	10348#	10350#		
10354#	10355#	10357#	10358#	10359#	10360#	10361#	10362#	10369#	10371#	10372#	10374#	10378#		
10380#	10381#	10383#	10384#	10386#	10388#	10391#	10393#	10395#	10401#	10402#	10403#	10404#		
10409#	10411#	10413#	10416#	10417#	10419#	10420#	10422#	10426#	10434#	10436#	10444#	10445#		
10446#	10447#	10449#	10450#	10453#	10455#	10457#	10459#	10461#	10462#	10464#	10468#	10472#		
10475#	10477#	10481#	10482#	10484#	10487#	10519#	10520#	10521#	10524#	10526#	10529#	10534#		
10535#	10536#	10537#	10539#	10542#	10546#	10547#	10548#	10551#	10553#	10556#	10561#	10562#		
10563#	10564#	10566#	10569#	10573#	10574#	10575#	10578#	10580#	10583#	10588#	10589#	10590#		
10591#	10593#	10596#	10600#	10601#	10602#	10605#	10607#	10610#	10615#	10616#	10617#	10618#		
10620#	10623#	10705#	10706#	10707#	10715#	10717#	10723#	10730#	10731#	10739#	10741#	10770#		
10771#	10772#	10931#												
\$ERROR	016010	8871	11075#											
\$ERRPC	001116	8857#	11049	11075*										
\$ERRTB	001254	8857#												
\$ERTTL	001112	8857#	10048	10051*	11075*									
\$ESCAP	001162	8857#	8871*	11075	11078*									
\$ETABL	001214	8857#												
\$ETEND	001254	8856	8857#											
\$FATAL	001176	8857#	11046*	11047	11072*									
\$FFLG	016006	11072#*												
\$FILLC	001156	8857#	11066											
\$FILLS	001155	8857#	11066											
\$FSAND=	000310	8612#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
		9122	9133	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368
		9395	9413	9414	9449	9460	9474	9498	9507	9568	9606	9643	9689	9720
		9727	9728	9729	9739	9758	9792	9814	9815	9816	9819	9822	9854	9879
		9886	9918	9921	9940	9944	9947	9949	9951	9956	9968	9971	9974	9979
		10015	10034	10035	10038	10052	10103	10126	10128	10181	10376	10392	10394	10415
		10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714	10721
		10738												
\$FSBAD=	000401	8612#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
		9122	9133	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368
		9395	9413	9414	9449	9460	9474	9498	9507	9568	9606	9643	9689	9720
		9727	9728	9729	9739	9758	9792	9814	9815	9816	9819	9822	9854	9879
		9886	9918	9921	9940	9944	9947	9949	9951	9956	9968	9971	9974	9979
		10015	10034	10035	10038	10052	10103	10126	10128	10181	10376	10392	10394	10415
		10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714	10721
		10738												
\$FSBLA=	000170	8612#												
\$FSCAS=	000150	8612#												
\$FSDEC=	000220	8612#												
\$FSGOO=	000400	8612#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
		9122	9133	9145	9165	9192	9214	9231	9242	9247	9249	9281	9296	9307
		9325	9339	9350	9368	9382	9395	9413	9414	9435	9449	9460	9474	9493
		9498	9507	9559	9568	9606	9635	9643	9667	9689	9701	9711	9720	9727
		9728	9729	9739	9758	9792	9814	9815	9816	9819	9822	9854	9879	9886
		9918	9921	9935	9940	9944	9947	9949	9951	9956	9968	9971	9974	9979
		9993	10009	10015	10034	10035	10038	10052	10103	10116	10126	10128	10181	10376
		10392	10394	10415	10452	10467	10471	10483	10485	10492	10496	10522	10549	10576
		10603	10714	10721	10738									
\$FSIF =	000110	8612#	8906	8908	8910	8941	8944	8992	8994	8999	9002	9009	9012	9020
		9023	9032	9035	9055	9058	9065	9068	9076	9079	9088	9091	9112	9115

9122	9125	9133	9136	9145	9148	9165	9172	9192	9194	9214	9218	9231
9237	9242	9245	9246	9247	9249	9254	9255	9257	9281	9283	9296	9299
9307	9310	9325	9327	9339	9343	9350	9354	9368	9370	9382	9386	9395
9399	9413	9414	9416	9418	9419	9421	9435	9438	9449	9455	9460	9468
9474	9480	9493	9496	9498	9505	9507	9511	9559	9562	9568	9571	9606
9608	9635	9638	9643	9646	9667	9670	9689	9692	9701	9705	9711	9715
9720	9723	9727	9728	9729	9733	9734	9738	9739	9744	9758	9760	9792
9794	9796	9814	9815	9816	9819	9822	9825	9828	9829	9832	9833	9854
9857	9879	9884	9886	9888	9891	9892	9918	9920	9921	9924	9925	9935
9938	9940	9943	9944	9946	9947	9949	9951	9954	9955	9956	9958	9959
9960	9968	9970	9971	9973	9974	9978	9979	9984	9993	9996	10009	10012
10015	10018	10034	10035	10037	10038	10041	10042	10050	10052	10055	10103	10116
10119	10120	10126	10128	10130	10131	10181	10188	10376	10385	10387	10392	10394
10396	10397	10415	10418	10421	10452	10467	10469	10471	10473	10480	10483	10485
10488	10489	10492	10495	10496	10499	10522	10527	10530	10549	10554	10557	10576
10581	10584	10603	10608	10611	10714	10716	10718	10721	10724	10738	10740	
8612#	9695	9745	10771	10772	10773	10774						
8612#	9197	9258	9259	10712	10726	10732						
8612#												
8612#	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122
9133	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368	9395
9413	9414	9449	9460	9474	9498	9507	9568	9606	9643	9689	9720	9727
9728	9729	9739	9758	9792	9814	9815	9816	9819	9822	9854	9879	9886
9918	9921	9944	9947	9949	9951	9956	9968	9971	9974	9979	10034	10035
10038	10052	10103	10126	10128	10181	10376	10392	10394	10415	10452	10467	10483
10485	10492	10522	10549	10576	10603	10714						
8612#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
9122	9133	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368
9395	9413	9414	9449	9460	9474	9498	9507	9568	9606	9643	9689	9720
9727	9728	9729	9739	9758	9792	9814	9815	9816	9819	9822	9854	9879
9886	9918	9921	9940	9944	9947	9949	9951	9956	9968	9971	9974	9979
10015	10034	10035	10038	10052	10103	10126	10128	10181	10376	10392	10394	10415
10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714	10721
10738												
8612#	10704	10748	10768	10776	11042	11055						
8612#												
8612#	8934	8948	9807	9808	10079	10081	10089	10093	10102	10132	10349	10351
10356	10363	10375	10398	10414	10423	10430	10431	10435	10437	10451	10466	10479
10490												
8612#	9281	9325	9368	9606	9689	9739	9758	9854	9879	9918		
8612#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
9122	9133	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368
9395	9413	9414	9449	9460	9474	9498	9507	9568	9606	9643	9689	9720
9727	9728	9729	9739	9758	9792	9814	9815	9816	9819	9822	9854	9879
9886	9918	9921	9940	9944	9947	9949	9951	9956	9968	9971	9974	9979
10015	10034	10035	10038	10052	10103	10126	10128	10181	10376	10392	10394	10415
10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714	10721
10738												
8857#												
8857#												
11063#												
11069#	11087											
8721												
8856#												
8857#	11078*											
8612#	8906#	8910#	8941#	8944#	8992#	8994#	8999#	9002#	9009#	9012#	9020#	9023#

SF\$INC= 000210
 SF\$L00= 000200
 SF\$NAM= 000160
 SF\$NO = 000403

SF\$OR = 000320

SF\$RTN= 000300
 SF\$SEL= 000140
 SF\$UNT= 000130

SF\$WHI= 000120
 SF\$YES= 000402

\$GDADR 001120
 \$GDDAT 001124
 \$GET42 014440
 \$GTSWR 015036
 \$HD = 000000
 \$HIBTS 001000
 \$ICNT 001104
 \$IFLEV= 177777

9032#	9035#	9055#	9058#	9065#	9068#	9076#	9079#	9088#	9091#	9112#	9115#	9122#
9125#	9133#	9136#	9145#	9148#	9165#	9172#	9192#	9194#	9214#	9218#	9231#	9242#
9245#	9246#	9247#	9249#	9254#	9257#	9281#	9283#	9296#	9299#	9307#	9310#	9325#
9327#	9339#	9343#	9350#	9354#	9368#	9370#	9382#	9386#	9395#	9399#	9413#	9414#
9418#	9421#	9435#	9438#	9449#	9455#	9460#	9468#	9474#	9480#	9493#	9496#	9498#
9505#	9507#	9511#	9559#	9562#	9568#	9571#	9606#	9608#	9635#	9638#	9643#	9646#
9667#	9670#	9689#	9692#	9701#	9705#	9711#	9715#	9720#	9723#	9727#	9728#	9729#
9733#	9738#	9739	9744#	9758#	9760#	9792#	9796#	9814#	9815#	9816#	9819	9822
9828#	9832#	9833#	9854#	9857#	9879#	9886#	9891#	9892#	9918#	9921#	9924#	9925#
9935#	9938#	9940#	9943#	9944#	9946#	9947#	9949#	9951#	9954#	9956#	9958#	9959#
9960#	9968#	9970#	9971#	9973#	9974#	9978#	9979#	9984#	9993#	9996#	10009#	10012#
10015#	10018#	10034#	10035#	10038#	10041#	10042#	10050#	10052#	10055#	10103#	10116#	10119#
10120#	10126#	10128#	10130#	10131#	10181#	10188#	10376#	10387#	10392#	10394#	10396#	10397#
10415#	10421#	10452#	10467#	10469#	10471#	10473#	10480#	10483#	10485#	10488#	10489#	10492#
10495#	10496#	10499#	10522#	10530#	10549#	10557#	10576#	10584#	10603#	10611#	10714#	10718#
10721#	10724#	10738#	10740#									
8857#	11069											
8906#	8910	8941#	8944	8992#	8994	8999#	9002	9009#	9012	9020#	9023	9032#
9035	9055#	9058	9065#	9068	9076#	9079	9088#	9091	9112#	9115	9122#	9125
9133#	9136	9145#	9148	9165#	9172	9192#	9194	9214#	9218	9231#	9246	9247#
9257	9281#	9283	9296#	9299	9307#	9310	9325#	9327	9339#	9343	9350#	9354
9368#	9370	9382#	9386	9395#	9399	9413#	9421	9435#	9438	9449#	9455	9460#
9468	9474#	9480	9493#	9496	9498#	9505	9507#	9511	9559#	9562	9568#	9571
9606#	9608	9635#	9638	9643#	9646	9667#	9670	9689#	9692	9701#	9705	9711#
9715	9720#	9723	9727#	9739#	9744	9758#	9760	9792#	9796	9814#	9833	9854#
9857	9879#	9892	9918#	9925	9935#	9938	9940#	9943	9944#	9946	9947#	9960
9968#	9970	9971#	9973	9974#	9978	9979#	9984	9993#	9996	10009#	10012	10015#
10018	10034#	10050	10052#	10055	10103#	10120	10126#	10131	10181#	10188	10376#	10387
10392#	10397	10415#	10421	10452#	10480	10483#	10489	10492#	10495	10496#	10499	10522#
10530	10549#	10557	10576#	10584	10603#	10611	10714#	10718	10721#	10724	10738#	10740
9242#	9245	9249#	9254	9414#	9418	9728#	9738	9815#	9832	9886#	9891	9921#
9924	9949#	9959	10035#	10042	10116#	10119	10128#	10130	10394#	10396	10467#	10469
10471#	10473	10485#	10488									
9729#	9733	9816#	9819#	9822#	9828	9951#	9954	9956#	9958	10038#	10041	
8857#	11046	11075*										
8857#	11066	11069	11075									
11072#*												
8612#	8906	8908	8910	8934	8941	8944	8948	8992	8994	8999	9002	9009
9012	9020	9023	9032	9035	9055	9058	9065	9068	9076	9079	9088	9091
9112	9115	9122	9125	9133	9136	9145	9148	9165	9172	9192	9194	9197
9214	9218	9231	9237	9242	9245	9246	9247	9249	9254	9255	9257	9258
9259	9281	9283	9296	9299	9307	9310	9325	9327	9339	9343	9350	9354
9368	9370	9382	9386	9395	9399	9413	9414	9416	9418	9419	9421	9435
9438	9449	9455	9460	9468	9474	9480	9493	9496	9498	9505	9507	9511
9559	9562	9568	9571	9606	9608	9635	9638	9643	9646	9667	9670	9689
9692	9695	9701	9705	9711	9715	9720	9723	9727	9728	9729	9733	9734
9738	9739	9744	9745	9758	9760	9792	9794	9796	9807	9808	9814	9815
9816	9819	9822	9825	9828	9829	9832	9833	9854	9857	9879	9884	9886
9888	9891	9892	9918	9920	9921	9924	9925	9935	9938	9940	9943	9944
9946	9947	9949	9951	9954	9955	9956	9958	9959	9960	9968	9970	9971
9973	9974	9978	9979	9984	9993	9996	10009	10012	10015	10018	10034	10035
10037	10038	10041	10042	10050	10052	10055	10079	10081	10089	10093	10102	10103
10116	10119	10120	10126	10128	10130	10131	10132	10181	10188	10344	10351	10356
10363	10375	10376	10385	10387	10392	10394	10396	10397	10398	10414	10415	10418
10421	10423	10430	10431	10435	10437	10451	10452	10466	10467	10469	10471	10473
10479	10480	10483	10485	10488	10489	10490	10492	10495	10496	10499	10522	10527

\$INTAG 001135
\$ISKO = 000001

\$ISK1 = 000001

\$ISK2 = 000001
\$ITEMB 001114
\$LF 001172
\$FLG 016005
\$LOCTA= 177777

\$LPADR 001106
\$LPERR 001110

\$LSTCN= 177777

\$LSTIN= 000000

10530	10549	10554	10557	10576	10581	10584	10603	10608	10611	10704	10712	10714
10716	10718	10721	10724	10726	10732	10738	10739	10740	10741	10748	10768	10771
10772	10773	10774	10776	11042	11055							
8857#	8871*	11078*										
8857#	8871*	8935*	8997*	9006*	9016*	9027*	9053*	9062*	9072*	9083*	9110*	9119*
9129*	9140*	9163*	9285*	9303*	9329*	9372*	9425*	9459*	9471*	9483*	9543*	9574*
9614*	9655*	9926*	9986*	11075	11078*							
8612#	8615#	8906	8908	8910	8934	8941	8944	8948	8992	8994	8999	9002
9009	9012	9020	9023	9032	9035	9055	9058	9065	9068	9076	9079	9088
9091	9112	9115	9122	9125	9133	9136	9145	9148	9165	9172	9192	9194
9197	9214	9218	9231	9237	9242	9245	9246	9247	9249	9254	9255	9257
9259	9281	9283	9296	9299	9307	9310	9325	9327	9339	9343	9350	9354
9368	9370	9382	9386	9395	9399	9413	9414	9416	9418	9419	9421	9435
9438	9449	9455	9460	9469	9474	9480	9493	9496	9498	9505	9507	9511
9559	9562	9568	9571	9606	9608	9635	9638	9643	9646	9667	9670	9689
9692	9695	9701	9705	9711	9715	9720	9723	9727	9728	9729	9733	9734
9738	9739	9744	9745	9758	9760	9792	9794	9796	9807	9808	9814	9815
9816	9819	9822	9825	9828	9829	9832	9833	9854	9857	9879	9884	9886
9888	9891	9892	9918	9920	9921	9924	9925	9935	9938	9940	9943	9944
9946	9947	9949	9951	9954	9955	9956	9958	9959	9960	9968	9970	9971
9973	9974	9978	9979	9984	9993	9996	10009	10012	10015	10018	10034	10035
10037	10038	10041	10042	10050	10052	10055	10079	10081	10089	10093	10102	10103
10116	10119	10120	10126	10128	10130	10131	10132	10181	10188	10349	10351	10356
10363	10375	10376	10385	10387	10392	10394	10396	10397	10398	10414	10415	10418
10421	10423	10430	10431	10435	10437	10451	10452	10466	10467	10469	10471	10473
10479	10480	10483	10485	10488	10489	10490	10492	10495	10496	10499	10522	10527
10530	10549	10554	10557	10576	10581	10584	10603	10608	10611	10704	10712	10714
10716	10718	10721	10724	10732	10738	10740	10748	10768	10771	10772	10773	10774
10776	11042	11055										
8612#	8613#	8892	8894	8896	8897	8898	8899	8900	8905	8906	8908	8909
8928	8933	8935	8937	8941	8946	8947	8948	8992	8997	8999	9006	9007
9009	9016	9018	9020	9027	9029	9032	9053	9055	9062	9063	9065	9072
9074	9076	9083	9085	9088	9110	9112	9119	9120	9122	9129	9131	9133
9140	9142	9145	9163	9165	9192	9196	9199	9200	9207	9211	9214	9227
9231	9234	9237	9241	9242	9247	9248	9249	9253	9255	9256	9258	9259
9281	9285	9288	9293	9296	9303	9307	9325	9329	9333	9337	9339	9349
9350	9368	9372	9376	9380	9382	9393	9395	9413	9414	9416	9419	9425
9430	9432	9435	9441	9443	9446	9449	9459	9460	9471	9474	9483	9489
9490	9493	9498	9507	9534	9537	9539	9543	9545	9548	9554	9556	9559
9565	9568	9574	9576	9578	9581	9583	9606	9612	9614	9615	9617	9623
9627	9629	9632	9635	9640	9643	9655	9658	9660	9662	9665	9667	9689
9695	9700	9701	9708	9710	9711	9718	9720	9727	9728	9729	9734	9739
9745	9758	9780	9782	9783	9786	9787	9790	9791	9792	9793	9794	9795
9801	9803	9808	9812	9813	9814	9815	9816	9819	9822	9825	9829	9854
9856	9859	9877	9879	9881	9882	9883	9884	9885	9886	9887	9888	9890
9918	9920	9921	9926	9928	9930	9932	9934	9935	9939	9940	9942	9944
9945	9947	9949	9951	9953	9955	9956	9957	9968	9971	9974	9979	9986
9988	9990	9993	9999	10000	10004	10006	10008	10009	10015	10034	10035	10037
10038	10040	10052	10053	10054	10078	10080	10081	10087	10088	10090	10091	10092
10093	10099	10100	10101	10103	10105	10106	10108	10110	10112	10114	10116	10122
10124	10125	10126	10127	10128	10129	10132	10144	10152	10154	10155	10157	10181
10208	10210	10211	10213	10219	10221	10222	10224	10229	10231	10232	10234	10239
10241	10242	10244	10249	10251	10252	10254	10259	10261	10262	10264	10269	10271
10272	10274	10279	10281	10282	10284	10344	10348	10350	10351	10354	10355	10357
10358	10359	10360	10361	10362	10363	10369	10371	10372	10374	10376	10378	10380
10381	10383	10384	10385	10386	10388	10391	10392	10393	10394	10395	10398	10401

\$NSK3 = 000110	10485#	10488	10714#	10716	10718	10721#	10724	10772#	10773				
\$NULL 001154	9729#	9733	10467#	10469	10471#	10473							
\$NWTST= 000001	8857#	11066											
	8923#	8986#	9044#	9104#	9157#	9186#	9275#	9319#	9362#	9407#	9528#	9601#	9684#
	9753#	9910#	10029#	10070#	10338#								
\$OCNT 017136	11084#*												
\$OMODE 017140	11084#*												
\$OVER 016452	11078#												
\$PASS 001202	8857#	8871*	11063*	11078									
\$PASTM 001006	8856#												
\$QUES 001170	8857#	11066	11069	11075									
\$RDCHR 015250	11069#	11087											
\$RDEC= ***** U	11087												
\$RDLIN 015370	11069#	11087											
\$RDOCT= ***** U	11087												
\$RDSZ = 000010	11069#												
\$RTNAD 014462	11063#												
\$R2A = ***** U	11087												
\$SAVLE= 177777	8612#	9259#	9695#	10732#	10771#	10772#							
\$SAVRE= ***** U	11087												
\$SCOPE 016210	8871	11078#											
\$SETUP= 000127	8868#	8871	8872	11063	11069	11075	11078						
\$SSKO = 000253	9259#	9695#	10732#	10771#	10772#								
\$STUP = 177777	8868#												
\$SVLAD 016416	11078#												
\$SVPC = 000430	8854#												
\$SWR = 167400	8617#	8721	8723	8857	8871	8923	8986	9044	9104	9157	9186	9275	9319
	9362	9407	9528	9601	9684	9753	9910	10029	10070	10338	11063	11075	11078
\$SWREG 001216	8857#	8871											
\$SWRMK= 000000	8723	11078											
\$TAGLE= 177777	8612#	8906#	8908#	8910#	8934#	8941#	8944#	8948#	8992#	8994#	8999#	9002#	9009#
	9012#	9020#	9023#	9032#	9035#	9055#	9058#	9065#	9068#	9076#	9079#	9088#	9091#
	9112#	9115#	9122#	9125#	9133#	9136#	9145#	9148#	9165#	9172#	9192#	9194#	9197#
	9214#	9218#	9231#	9237#	9242#	9245#	9246#	9247#	9249#	9254#	9255#	9257#	9258
	9259#	9281#	9283#	9296#	9299#	9307#	9310#	9325#	9327#	9339#	9343#	9350#	9354#
	9368#	9370#	9382#	9386#	9395#	9399#	9413#	9414#	9416#	9418#	9419#	9421#	9435#
	9438#	9449#	9455#	9460#	9468#	9474#	9480#	9493#	9496#	9498#	9505#	9507#	9511#
	9559#	9562#	9568#	9571#	9606#	9608#	9635#	9638#	9643#	9646#	9667#	9670#	9689#
	9692#	9695#	9701#	9705#	9711#	9715#	9720#	9723#	9727#	9728#	9729#	9733#	9734#
	9738#	9739#	9744#	9745#	9758#	9760#	9792#	9794#	9796#	9807#	9808#	9814#	9815#
	9816#	9819#	9822#	9825#	9828#	9829#	9832#	9833#	9854#	9857#	9879#	9884#	9886#
	9888#	9891#	9892#	9918#	9920#	9921#	9924#	9925#	9935#	9938#	9940#	9943#	9944#
	9946#	9947#	9949#	9951#	9954#	9955#	9956#	9958#	9959#	9960#	9968#	9970#	9971#
	9973#	9974#	9978#	9979#	9984#	9993#	9996#	10009#	10012#	10015#	10018#	10034#	10035#
	10037#	10038#	10041#	10042#	10050#	10052#	10055#	10079#	10081#	10089#	10093#	10102#	10103#
	10116#	10119#	10120#	10126#	10128#	10130#	10131#	10132#	10181#	10188#	10349#	10351#	10356#
	10363#	10375#	10376#	10385#	10387#	10392#	10394#	10396#	10397#	10398#	10414#	10415#	10418#
	10421#	10423#	10430#	10431#	10435#	10437#	10451#	10452#	10466#	10467#	10469#	10471#	10473#
	10479#	10480#	10483#	10485#	10488#	10489#	10490#	10492#	10495#	10496#	10499#	10522#	10527#
	10530#	10549#	10554#	10557#	10576#	10581#	10584#	10603#	10608#	10611#	10712#	10714#	10716#
	10718#	10721#	10724#	10726	10732#	10738#	10740#	10771#	10772#	10773#	10774#		
\$TAGNU= 000257	8612#	8906#	8908#	8934#	8941#	8992#	8999#	9009#	9020#	9032#	9055#	9065#	9076#
	9088#	9112#	9122#	9133#	9145#	9165#	9192#	9197#	9214#	9231#	9237#	9242#	9247#
	9249#	9255#	9281#	9296#	9307#	9325#	9339#	9350#	9368#	9382#	9395#	9413#	9414#
	9416#	9419#	9435#	9449#	9460#	9474#	9493#	9498#	9507#	9559#	9568#	9606#	9635#
	9643#	9667#	9689#	9695#	9701#	9711#	9720#	9727#	9728#	9729#	9734#	9739#	9758#

\$STRAP2 017164
\$TRP = 000012
\$TRPAD 017176
\$TSKO = 000251

11087#	8906#	8908#	8910	8934#	8948	8992#	8994	8999#	9002	9009#	9012	9020#	9023
11087#	9032#	9035	9055#	9058	9065#	9068	9076#	9079	9088#	9091	9112#	9115	9122#
11087#	9125	9133#	9136	9145#	9148	9165#	9172	9192#	9194	9197#	9259	9281#	9283
	9296#	9299	9307#	9310	9325#	9327	9339#	9343	9350#	9354	9368#	9370	9382#
	9386	9395#	9399	9413#	9419#	9421	9435#	9438	9449#	9455	9460#	9468	9474#
	9480	9493#	9496	9498#	9505	9507#	9511	9559#	9562	9568#	9571	9606#	9608
	9635#	9638	9643#	9646	9667#	9670	9689#	9692	9695#	9745	9758#	9760	9792#
	9794#	9796	9807#	9808	9814#	9833	9854#	9857	9879#	9884#	9892	9918#	9920#
	9925	9935#	9938	9940#	9943	9944#	9946	9947#	9960	9968#	9970	9971#	9973
	9974#	9978	9979#	9984	9993#	9996	10009#	10012	10015#	10018	10034#	10050	10052#
	10055	10079#	10081	10089#	10093	10102#	10132	10181#	10188	10349#	10351	10356#	10363
	10375#	10398	10414#	10423	10430#	10431	10435#	10437	10451#	10490	10492#	10495	10496#
	10499	10522#	10527#	10530	10549#	10554#	10557	10576#	10581#	10584	10603#	10608#	10611
	10712#	10732	10738#	10740	10771#	10774							

\$TSK1 = 000250

8941#	8944	9197#	9258	9259	9414#	9416#	9418	9695#	9745	9815#	9829#	9832
9886#	9888#	9891	9921#	9924	9949#	9955#	9959	10035#	10037#	10042	10103#	10120
10126#	10131	10376#	10385#	10387	10392#	10397	10415#	10418#	10421	10452#	10480	10483#
10489	10712#	10726	10732	10771#	10774							

\$TSK2 = 000254

9214#	9218	9231#	9237#	9246	9247#	9255#	9257	9701#	9705	9711#	9715	9720#
9723	9727#	9739#	9744	9816#	9819#	9828	9951#	9954	9956#	9958	10038#	10041
10116#	10119	10128#	10130	10394#	10396	10466#	10479	10485#	10488	10714#	10716#	10718

\$TSK3 = 000253

9242#	9245	9249#	9254	9728#	9734#	9738	9739#	9744	9819#	9822#	9828	10467#
10469	10471#	10473	10772#	10773								
9729#	9733	9822#	9825#	9828								

\$TSK4 = 000126

\$STSM 001004

\$STSTM 001102

\$STTYIN 015476

\$STYPBN= ***** U

\$STYPDS 016470

\$STYPE 014504

\$STYPEC 014716

\$STYPEX 014764

\$STYPOC 016740

\$STYPON 016754

\$STYPOS 016714

\$SUNIT 001206

\$SUNITM 001010

\$SUSWR 001220

8856#	8857#	8909*	11063*	11075	11078*								
11069#	11087												
11081#	11087												
11066#	11072	11087											
11066#	11069												
11066#													
11084#	11087												
11084#	11087												
11084#	11087												

\$SUNIT 001206

\$SUNITM 001010

\$SUSWR 001220

8857#	8880*	10054*	10898	10958	10962*	10966	10975*	10986*					
8856#													
8857#	8992	9281	9325	9368	9414	9606	9689	9728	9739	9758	9792	9918	
9947	9949	10415	10810	10814	10896	10984							

\$VECT1 001244

\$VECT2 001246

\$XTSTR 016222

\$YESNO= 000001

8857#	10956												
8897#	8898#	8899#	8905#	8946#	8947#	9007#	9018#	9029#	9063#	9074#	9085#	9120#	
9131#	9142#	9248#	9349#	9539#	9548#	9554#	9576#	9617#	9629#	9658#	9695#	9801#	
9803#	9812#	9813#	9859#	9882#	9883#	9885#	9887#	9890#	9930#	9942#	9945#	9953#	
9957#	9988#	9999#	10040#	10054#	10092#	10105#	10106#	10108#	10112#	10122#	10124#	10125#	
10129#	10211#	10213#	10222#	10224#	10232#	10234#	10242#	10244#	10252#	10254#	10262#	10264#	
10272#	10274#	10282#	10284#	10359#	10362#	10378#	10380#	10381#	10383#	10384#	10386#	10388#	
10391#	10395#	10422#	10436#	10455#	10459#	10462#	10468#	10472#	10475#	10477#	10481#	10482#	
10487#	10520#	10524#	10526#	10529#	10535#	10537#	10539#	10542#	10547#	10551#	10553#	10556#	
10562#	10564#	10566#	10569#	10574#	10578#	10580#	10583#	10589#	10591#	10593#	10596#	10601#	
10605#	10607#	10610#	10616#	10618#	10620#	10623#	10731#	10771#	10772#	10931#			

\$107	005320	9739	9744#
\$11	002440	9032	9035#
\$110	005320	9739	9744#
\$111	005360	9758#	
\$112	005364	9758	9760#
\$113	005452	9792	9794#
\$114	005460	9794	9796#
\$115	005476	9807#	9808
\$116	005514	9808#	
\$117	005620	9814	9833#
\$12	002510	9055	9058#
\$120	005616	9815	9829#
\$121	005562	9816	9819#
\$122	005614	9819	9828#
\$123	005576	9819	9822#
\$124	005614	9822	9828#
\$125	005612	9822	9825#
\$126	005614	9825	9828#
\$127	005620	9829	9832#
\$13	002536	9065	9068#
\$130	005652	9854	9857#
\$131	005712	9879#	
\$132	005734	9879	9884#
\$133	005766	9884	9892#
\$134	005760	9886	9888#
\$135	005766	9888	9891#
\$136	006030	9918#	
\$137	006036	9918	9920#
\$14	002564	9076	9079#
\$140	006052	9920	9925#
\$141	006052	9921	9924#
\$142	006134	9935	9938#
\$143	006152	9940	9943#
\$144	006166	9944	9946#
\$145	006240	9947	9960#
\$146	006224	9949	9955#
\$147	006222	9951	9954#
\$15	002614	9088	9091#
\$150	006240	9955	9959#
\$151	006240	9956	9958#
\$152	006266	9968	9970#
\$153	006300	9971	9973#
\$154	006312	9974	9978#
\$155	006324	9979	9984#
\$156	006374	9993	9996#
\$157	006464	10009	10012#
\$16	002652	9112	9115#
\$160	006476	10015	10018#
\$161	006750	10034	10050#
\$162	006574	10035	10037#
\$163	006646	10037	10042#
\$164	006646	10038	10041#
\$165	006774	10052	10055#
\$166	007022	10079#	10081
\$167	007054	10089#	10093
\$17	002700	9122	9125#

\$170	007112	10102#	10132
\$171	007202	10103	10120#
\$172	007202	10116	10119#
\$173	007244	10126	10131#
\$174	007244	10128	10130#
\$175	007422	10181	10188#
\$176	010024	10349#	10351
\$177	010044	10356#	10363
\$2	002066	8908	8910#
\$20	002726	9133	9136#
\$200	010132	10375#	10398
\$201	010170	10376	10385#
\$202	010174	10385	10387#
\$203	010232	10392	10397#
\$204	010232	10394	10396#
\$205	010274	10414#	10423
\$206	010316	10415	10418#
\$207	010326	10418	10421#
\$21	002756	9145	9148#
\$210	010360	10430#	10431
\$211	010374	10435#	10437
\$212	010450	10451#	10490
\$213	010554	10452	10480#
\$214	010510	10466#	10479
\$215	010524	10467	10469#
\$216	010534	10471	10473#
\$217	010554	10479#	
\$22	003016	9165	9172#
\$220	010614	10483	10489#
\$221	010614	10485	10488#
\$222	010632	10490#	
\$223	010644	10492	10495#
\$224	010654	10496	10499#
\$225	010726	10522	10527#
\$226	010732	10527	10530#
\$227	011046	10549	10554#
\$23	003046	9192	9194#
\$230	011052	10554	10557#
\$231	011166	10576	10581#
\$232	011172	10581	10584#
\$233	011306	10603	10608#
\$234	011312	10608	10611#
\$235	012614	10739	10748#
\$236	012616	10741	10748#
\$237	012466	10712#	10732
\$24	003052	9197#	9259
\$240	012570	10726	10732#
\$241	012504	10714	10716#
\$242	012512	10716	10718#
\$243	012530	10721	10724#
\$244	012602	10738	10740#
\$245	012676	10776#	
\$246	012676	10776#	
\$247	012644	10771#	
\$25	003300	9258	9259#
\$250	012640	10771#	10774

9165	9192	9214	9231	9242	9247	9249	9281	9296	9307	9325	9339	9350
9368	9382	9395	9413	9414	9435	9449	9460	9474	9493	9498	9507	9559
9568	9606	9635	9643	9667	9689	9701	9711	9720	9727	9728	9729	9739
9758	9792	9808	9814	9815	9816	9819	9822	9854	9879	9886	9918	9921
9935	9940	9944	9947	9949	9951	9956	9968	9971	9974	9979	9993	10009
10015	10034	10035	10036#	10038	10039#	10052	10081	10093	10103	10116	10126	10128
10132	10181	10311#	10351	10363	10376	10392	10394	10398	10415	10423	10431	10437
10452	10467	10471	10479	10483	10485	10490	10492	10496	10522	10549	10576	10603
10631#	10632#	10633#	10634#	10651#	10714	10721	10738	10808	10847#	10857#	10859#	11043#
11048#	11050#	11063	11066	11069#	11072#	11075	11078	11081#	11093#			
11072												
8856#												

.SASTA= ***** U
.SX = 001000

BEGIN	7390#														
BGNSRV	8624#	9853	9875	10206	10217	10227	10237	10247	10257	10267	10277	10518	10533	10545	10560
	10572	10587	10599	10614	10929										
BGNSUB	8634#	8935	8997	9006	9016	9027	9053	9062	9072	9083	9110	9119	9129	9140	9163
	9285	9303	9329	9372	9425	9459	9471	9483	9543	9574	9614	9655	9926	9986	
BRESET	8639#	8904	9031	9087	9144	9171	9305	9674	9693	9798	9962	10150	10440		
CALL	7063#	9211	9241	9293	9337	9380	9432	9443	9490	9545	9556	9565	9583	9627	9632
	9640	9665	9700	9710	9934	9990	10000	10008	10114	10127	10393	10484	10730		
CASE	7329#														
CLRVEC	8649#														
COMMEN	1566#	8724#													
DECR	6996#														
DECRU	7002#														
DEFAULT	7372#														
ELSE	6427#	8908	9237	9255	9416	9419	9734	9739	9794	9819	9822	9825	9829	9884	9888
	9920	9955	10037	10385	10418	10527	10554	10581	10608	10716					
END	7407#														
ENDCOM	1578#	8724#													
ENDDEC	7007#														
ENDDO	6498#														
ENDIF	6445#	8910	8944	8994	9002	9012	9023	9035	9058	9068	9079	9091	9115	9125	9136
	9148	9172	9194	9218	9245	9246	9254	9257	9283	9299	9310	9327	9343	9354	9370
	9386	9399	9418	9421	9438	9455	9468	9480	9496	9505	9511	9562	9571	9608	9638
	9646	9670	9692	9705	9715	9723	9733	9738	9744	9760	9796	9828	9832	9833	9857
	9891	9892	9924	9925	9938	9943	9946	9954	9958	9959	9960	9970	9973	9978	9984
	9996	10012	10018	10041	10042	10050	10055	10119	10120	10130	10131	10188	10387	10396	10397
	10421	10469	10473	10480	10488	10489	10495	10499	10530	10557	10584	10611	10718	10724	10740
ENDINC	6983#	9745	10773	10774											
ENDLOO	6871#	9259	10732												
ENDRTN	7225#	10748	10776	11055											
ENDSEL	7316#														
ENDSRV	8660#	9860	9893	10214	10225	10235	10245	10255	10265	10275	10285	10531	10543	10558	10570
	10585	10597	10612	10624	10932										
ENDSUB	8670#	8945	9003	9013	9024	9036	9059	9069	9080	9092	9116	9126	9137	9149	9174
	9301	9311	9344	9387	9456	9469	9481	9512	9572	9647	9671	9985	10019		
ERRDF	8674#	8943													
ERRHRD	8684#	9001	9011	9022	9034	9057	9067	9078	9090	9114	9124	9135	9147	9169	9216
	9244	9252	9298	9309	9341	9352	9384	9397	9437	9451	9463	9477	9495	9500	9509
	9561	9570	9587	9637	9645	9669	9703	9712	9722	9731	9736	9742	9818	9821	9824
	9827	9831	9937	9969	9972	9975	9980	9995	10011	10017	10118	10182	10494	10498	
ERROR	8724#	8943	8954	8958	8962	8966	9001	9011	9022	9034	9057	9067	9078	9090	9114
	9124	9135	9147	9169	9216	9244	9252	9298	9309	9341	9352	9384	9397	9437	9451
	9463	9477	9495	9500	9509	9561	9570	9587	9637	9645	9669	9703	9712	9722	9731
	9736	9742	9818	9821	9824	9827	9831	9937	9965	9969	9972	9975	9980	9995	10011
	10017	10118	10182	10494	10498										
ESCAPE	1698#	8724#													
EXIF	6829#	9258													
EXIFB	6851#	10726													
EXIT	8694#	8993	9193	9260	9282	9326	9369	9417	9420	9454	9467	9479	9504	9513	9691
	9704	9714	9732	9737	9743	9834	10020	10190							
GETPRI	1312#	8724#													
GETSWR	1771#	8724#	8872#												
IF	6332#	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122	9133	9145
	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368	9395	9413	9414	9449	9460
	9474	9498	9507	9568	9606	9643	9689	9720	9727	9728	9729	9758	9792	9814	9815
	9816	9854	9879	9886	9918	9921	9944	9947	9949	9951	9956	9968	9971	9974	9979

SPACE	8724#														
STARS	1485#	8724#	8739	8741	8759	8761	8781	8783	8802	8804	8823	8833	8854	8856	8857
	8923	8977	8979	8986	9044	9104	9157	9186	9275	9319	9362	9407	9528	9601	9684
	9753	9846	9848	9868	9870	9910	10029	10070	10198	10200	10338	10510	10512	10678	10697
	10756	10763	10919	10924	10945	10949	11063	11066	11069	11072	11075	11081	11084	11087	
STRUCT	5720#	8611#	8612												
SWRSU	1453#	8724#	8871#												
TRMTRP	11087#														
TYPBIN	2088#	8724#													
TYPDEC	2058#	8724#	10048	11063											
TYPNAM	1826#	8724#	8872												
TYPNUM	2025#	8724#													
TYPOCS	1978#	8724#	11047												
TYPOCT	1941#	8724#	10044	10046	11044	11049	11051	11053	11069						
TYPTXT	1894#	8724#	10036	10039	10043	10045	10047	10807	10821	10847	10857	10859	11043	11045	11048
	11050	11052													
UNTIL	6650#	8948	9808	10081	10093	10132	10351	10363	10398	10423	10431	10437	10479	10490	
UNTILB	6671#														
WAITMS	8714#	9443	9565	9640	10000	10730									
WHILE	6487#														
WHILEB	6492#														
\$ADDON	5805#	8906	8908	8934	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
	9122	9133	9145	9165	9192	9197	9214	9231	9237	9242	9247	9249	9255	9259	9281
	9296	9307	9325	9339	9350	9368	9382	9395	9413	9414	9416	9419	9435	9449	9460
	9474	9493	9498	9507	9559	9568	9606	9635	9643	9667	9689	9695	9701	9711	9720
	9727	9728	9729	9734	9739	9758	9792	9794	9807	9808	9814	9815	9816	9819	9822
	9825	9829	9854	9879	9884	9886	9888	9918	9920	9921	9935	9940	9944	9947	9949
	9951	9955	9956	9968	9971	9974	9979	9993	10009	10015	10034	10035	10037	10038	10052
	10079	10089	10102	10103	10116	10126	10128	10181	10349	10356	10375	10376	10385	10392	10394
	10414	10415	10418	10430	10435	10451	10452	10466	10467	10471	10479	10483	10485	10490	10492
	10496	10522	10527	10549	10554	10576	10581	10603	10608	10704	10712	10714	10716	10721	10732
	10738	10768	10771	10772	11042										
\$AND	6092#	9739	9854												
\$BRANC	5931#	8906	8908	8941	8948	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112
	9122	9133	9145	9165	9192	9214	9231	9237	9242	9247	9249	9255	9258	9259	9281
	9296	9307	9325	9339	9350	9368	9382	9395	9413	9414	9416	9419	9435	9449	9460
	9474	9493	9498	9507	9559	9568	9606	9635	9643	9667	9689	9695	9701	9711	9720
	9727	9728	9729	9734	9739	9745	9758	9792	9794	9808	9814	9815	9816	9819	9822
	9825	9829	9854	9879	9884	9886	9888	9918	9920	9921	9935	9940	9944	9947	9949
	9951	9955	9956	9968	9971	9974	9979	9993	10009	10015	10034	10035	10037	10038	10052
	10081	10093	10103	10116	10126	10128	10132	10181	10351	10363	10376	10385	10392	10394	10398
	10415	10418	10423	10431	10437	10452	10467	10471	10479	10483	10485	10490	10492	10496	10522
	10527	10549	10554	10576	10581	10603	10608	10714	10716	10721	10726	10732	10738	10739	10741
	10771	10772	10773	10774											
\$BRCOD	6230#	9258	9281	9325	9368	9606	9689	9695	9758	9808	9879	9918	10479	10490	10726
	10771	10772													
\$CALL	7039#	9211	9241	9293	9337	9380	9432	9443	9490	9545	9556	9565	9583	9627	9632
	9640	9665	9700	9710	9934	9990	10000	10008	10114	10127	10393	10484	10730		
\$CHECK	6288#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122	9133
	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368	9395	9413	9414	9449
	9460	9474	9498	9507	9568	9606	9643	9689	9720	9727	9728	9729	9739	9758	9792
	9814	9815	9816	9819	9822	9854	9879	9886	9918	9921	9940	9944	9947	9949	9951
	9956	9968	9971	9974	9979	10015	10034	10035	10038	10052	10103	10126	10128	10181	10376
	10392	10394	10415	10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714
	10721	10738													
\$CHK1	7725#	8892	8894	8896	8900	8909	8928	8933	8935	8937	8997	9006	9016	9027	9053

\$GENTA	5900#	8908	8910	8934	8944	8994	9002	9012	9023	9035	9058	9068	9079	9091	9115
	9125	9136	9148	9172	9194	9197	9218	9237	9245	9246	9254	9255	9257	9259	9281
	9283	9299	9310	9325	9327	9343	9354	9368	9370	9386	9399	9416	9418	9419	9421
	9438	9455	9468	9480	9496	9505	9511	9562	9571	9606	9608	9638	9646	9670	9689
	9692	9695	9705	9715	9723	9733	9734	9738	9739	9744	9745	9758	9760	9794	9796
	9807	9808	9819	9822	9825	9828	9829	9832	9833	9857	9879	9884	9888	9891	9892
	9918	9920	9924	9925	9938	9943	9946	9954	9955	9958	9959	9960	9970	9973	9978
	9984	9996	10012	10018	10037	10041	10042	10050	10055	10079	10089	10102	10119	10120	10130
	10131	10188	10349	10356	10375	10385	10387	10396	10397	10414	10418	10421	10430	10435	10451
	10466	10469	10473	10479	10480	10488	10489	10490	10495	10499	10527	10530	10554	10557	10581
	10584	10608	10611	10712	10716	10718	10724	10732	10740	10748	10771	10772	10773	10774	10776
	11055														
\$IF	6306#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122	9133
	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368	9395	9413	9414	9449
	9460	9474	9498	9507	9568	9606	9643	9689	9720	9727	9728	9729	9739	9758	9792
	9814	9815	9816	9819	9822	9854	9879	9886	9918	9921	9940	9944	9947	9949	9951
	9956	9968	9971	9974	9979	10015	10034	10035	10038	10052	10103	10126	10128	10181	10376
	10392	10394	10415	10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714
	10721	10738													
\$IFCOD	6178#	8906	8941	8948	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122
	9133	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368	9395	9413	9414
	9449	9460	9474	9498	9507	9568	9606	9643	9689	9720	9727	9728	9729	9739	9758
	9792	9808	9814	9815	9816	9819	9822	9854	9879	9886	9918	9921	9940	9944	9947
	9949	9951	9956	9968	9971	9974	9979	10015	10034	10035	10038	10052	10081	10093	10103
	10126	10128	10132	10181	10351	10363	10376	10392	10394	10398	10415	10423	10431	10437	10452
	10467	10471	10479	10483	10485	10490	10492	10496	10522	10549	10576	10603	10714	10721	10738
\$IFCON	6345#	9214	9242	9296	9339	9382	9435	9493	9559	9635	9667	9701	9711	9935	9993
	10009	10116													
\$IFOPR	5944#	8906	8941	8948	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122
	9133	9145	9165	9192	9214	9231	9242	9247	9249	9281	9296	9307	9325	9339	9350
	9368	9382	9395	9413	9414	9435	9449	9460	9474	9493	9498	9507	9559	9568	9606
	9635	9643	9667	9689	9701	9711	9720	9727	9728	9729	9739	9758	9792	9808	9814
	9815	9816	9819	9822	9854	9879	9886	9918	9921	9935	9940	9944	9947	9949	9951
	9956	9968	9971	9974	9979	9993	10009	10015	10034	10035	10038	10052	10081	10093	10103
	10116	10126	10128	10132	10181	10351	10363	10376	10392	10394	10398	10415	10423	10431	10437
	10452	10467	10471	10479	10483	10485	10490	10492	10496	10522	10549	10576	10603	10714	10721
	10738														
\$LET	7909#	8892	8894	8896	8897	8898	8899	8900	8905	8909	8928	8933	8935	8937	8946
	8947	8997	9006	9007	9016	9018	9027	9029	9053	9062	9063	9072	9074	9083	9085
	9110	9119	9120	9129	9131	9140	9142	9163	9196	9199	9200	9207	9227	9234	9248
	9253	9256	9285	9288	9303	9329	9333	9349	9372	9376	9393	9425	9430	9441	9446
	9459	9471	9483	9489	9534	9537	9539	9543	9548	9554	9574	9576	9578	9581	9612
	9614	9615	9617	9623	9629	9655	9658	9660	9662	9708	9718	9780	9782	9783	9786
	9787	9790	9791	9793	9795	9801	9803	9812	9813	9856	9859	9877	9881	9882	9883
	9885	9887	9890	9926	9928	9930	9932	9939	9942	9945	9953	9957	9986	9988	9999
	10004	10006	10040	10053	10054	10078	10080	10087	10088	10090	10091	10092	10099	10100	10101
	10105	10106	10108	10110	10112	10122	10124	10125	10129	10144	10152	10154	10155	10157	10208
	10210	10211	10213	10219	10221	10222	10224	10229	10231	10232	10234	10239	10241	10242	10244
	10249	10251	10252	10254	10259	10261	10262	10264	10269	10271	10272	10274	10279	10281	10282
	10284	10344	10348	10350	10354	10355	10357	10358	10359	10360	10361	10362	10369	10371	10372
	10374	10378	10380	10381	10383	10384	10386	10388	10391	10395	10401	10402	10403	10404	10409
	10411	10413	10416	10417	10419	10420	10422	10426	10434	10436	10444	10445	10446	10447	10449
	10450	10453	10455	10457	10459	10461	10462	10464	10468	10472	10475	10477	10481	10482	10487
	10519	10520	10521	10524	10526	10529	10534	10535	10536	10537	10539	10542	10546	10547	10548
	10551	10553	10556	10561	10562	10563	10564	10566	10569	10573	10574	10575	10578	10580	10583
	10588	10589	10590	10591	10593	10596	10600	10601	10602	10605	10607	10610	10615	10616	10617

	10618	10620	10623	10705	10706	10707	10715	10717	10723	10731	10770	10931			
\$LPCNT	6927#	9695	10771	10772											
\$OPADD	7566#	8897	8898	8899	8905	8946	8947	9248	9539	9695	9883	9885	10040	10054	10092
	10106	10122	10125	10129	10211	10222	10232	10242	10252	10262	10272	10282	10359	10362	10378
	10381	10384	10386	10391	10395	10422	10462	10472	10475	10477	10481	10487	10520	10524	10535
	10537	10547	10551	10562	10564	10574	10578	10589	10591	10601	10605	10616	10618	10771	10772
	10931														
\$OPAND	7608#														
\$OPCD1	7649#	8897	8898	8899	8905	8946	8947	9007	9018	9029	9063	9074	9085	9120	9131
	9142	9248	9349	9539	9548	9554	9576	9617	9629	9658	9695	9801	9803	9812	9813
	9859	9882	9883	9885	9887	9890	9930	9942	9945	9953	9957	9988	9999	10040	10054
	10092	10105	10106	10108	10112	10122	10124	10125	10129	10211	10213	10222	10224	10232	10234
	10242	10244	10252	10254	10262	10264	10272	10274	10282	10284	10359	10362	10378	10380	10381
	10383	10384	10386	10388	10391	10395	10422	10436	10455	10459	10462	10468	10472	10475	10477
	10481	10482	10487	10520	10524	10526	10529	10535	10537	10539	10542	10547	10551	10553	10556
	10562	10564	10566	10569	10574	10578	10580	10583	10589	10591	10593	10596	10601	10605	10607
	10610	10616	10618	10620	10623	10731	10771	10772	10931						
\$OPCD2	7524#	10124	10388	10455	10459	10482									
\$OPCOD	7710#	8897	8898	8899	8905	8946	8947	9007	9018	9029	9063	9074	9085	9120	9131
	9142	9248	9349	9539	9548	9554	9576	9617	9629	9658	9695	9801	9803	9812	9813
	9859	9882	9883	9885	9887	9890	9930	9942	9945	9953	9957	9988	9999	10040	10054
	10092	10105	10106	10108	10112	10122	10124	10125	10129	10211	10213	10222	10224	10232	10234
	10242	10244	10252	10254	10262	10264	10272	10274	10282	10284	10359	10362	10378	10380	10381
	10383	10384	10386	10388	10391	10395	10422	10436	10455	10459	10462	10468	10472	10475	10477
	10481	10482	10487	10520	10524	10526	10529	10535	10537	10539	10542	10547	10551	10553	10556
	10562	10564	10566	10569	10574	10578	10580	10583	10589	10591	10593	10596	10601	10605	10607
	10610	10616	10618	10620	10623	10731	10771	10772	10931						
\$OPCOM	7461#														
\$OPDEF	5909#	8892	8894	8896	8897	8898	8899	8900	8905	8906	8908	8909	8928	8933	8935
	8937	8941	8946	8947	8948	8992	8997	8999	9006	9007	9009	9016	9018	9020	9027
	9029	9032	9053	9055	9062	9063	9065	9072	9074	9076	9083	9085	9088	9110	9112
	9119	9120	9122	9129	9131	9133	9140	9142	9145	9163	9165	9192	9196	9199	9200
	9207	9211	9214	9227	9231	9234	9237	9241	9242	9247	9248	9249	9253	9255	9256
	9258	9259	9281	9285	9288	9293	9296	9303	9307	9325	9329	9333	9337	9339	9349
	9350	9368	9372	9376	9380	9382	9393	9395	9413	9414	9416	9419	9425	9430	9432
	9435	9441	9443	9446	9449	9459	9460	9471	9474	9483	9489	9490	9493	9498	9507
	9534	9537	9539	9543	9545	9548	9554	9556	9559	9565	9568	9574	9576	9578	9581
	9583	9606	9612	9614	9615	9617	9623	9627	9629	9632	9635	9640	9643	9655	9658
	9660	9662	9665	9667	9689	9695	9700	9701	9708	9710	9711	9718	9720	9727	9728
	9729	9734	9739	9745	9758	9780	9782	9783	9786	9787	9790	9791	9792	9793	9794
	9795	9801	9803	9808	9812	9813	9814	9815	9816	9819	9822	9825	9829	9854	9856
	9859	9877	9879	9881	9882	9883	9884	9885	9886	9887	9888	9890	9918	9920	9921
	9926	9928	9930	9932	9934	9935	9939	9940	9942	9944	9945	9947	9949	9951	9953
	9955	9956	9957	9968	9971	9974	9979	9986	9988	9990	9993	9999	10000	10004	10006
	10008	10009	10015	10034	10035	10037	10038	10040	10052	10053	10054	10078	10080	10081	10087
	10088	10090	10091	10092	10093	10099	10100	10101	10103	10105	10106	10108	10110	10112	10114
	10116	10122	10124	10125	10126	10127	10128	10129	10132	10144	10152	10154	10155	10157	10181
	10208	10210	10211	10213	10219	10221	10222	10224	10229	10231	10232	10234	10239	10241	10242
	10244	10249	10251	10252	10254	10259	10261	10262	10264	10269	10271	10272	10274	10279	10281
	10282	10284	10344	10348	10350	10351	10354	10355	10357	10358	10359	10360	10361	10362	10363
	10369	10371	10372	10374	10376	10378	10380	10381	10383	10384	10385	10386	10388	10391	10392
	10393	10394	10395	10398	10401	10402	10403	10404	10409	10411	10413	10415	10416	10417	10418
	10419	10420	10422	10423	10426	10431	10434	10436	10437	10444	10445	10446	10447	10449	10450
	10452	10453	10455	10457	10459	10461	10462	10464	10467	10468	10471	10472	10475	10477	10479
	10481	10482	10483	10484	10485	10487	10490	10492	10496	10519	10520	10521	10522	10524	10526
	10527	10529	10534	10535	10536	10537	10539	10542	10546	10547	10548	10549	10551	10553	10554

	10556	10561	10562	10563	10564	10566	10569	10573	10574	10575	10576	10578	10580	10581	10583
	10588	10589	10590	10591	10593	10596	10600	10601	10602	10603	10605	10607	10608	10610	10615
	10616	10617	10618	10620	10623	10705	10706	10707	10714	10715	10716	10717	10721	10723	10726
	10730	10731	10732	10738	10739	10741	10748	10770	10771	10772	10773	10774	10776	10931	11055
\$OPEQU	7642#														
\$OPNAN	7627#														
\$OPNEG	7473#														
\$OPNOR	7621#														
\$OPNOT	7616#	9018	9074	9131	9548	9576	9617	9658	9812	9813	9859	9882	9887	9999	10213
	10224	10234	10244	10254	10264	10274	10284	10542	10569	10596	10623				
\$OPOR	7603#	9007	9029	9063	9085	9120	9142	9349	9554	9629	9801	9803	9890	9930	9942
	9945	9953	9957	9988	10105	10108	10380	10383	10468	10526	10553	10580	10607		
\$OPROT	7493#														
\$OPRO	7752#	8892	8894	8896	8900	8909	8928	8933	8935	8937	8997	9006	9016	9027	9053
	9062	9072	9083	9110	9119	9129	9140	9163	9196	9199	9200	9207	9227	9234	9253
	9256	9285	9288	9303	9329	9333	9372	9376	9393	9425	9430	9441	9446	9459	9471
	9483	9489	9534	9537	9543	9574	9578	9581	9612	9614	9615	9623	9655	9660	9662
	9695	9708	9718	9780	9782	9783	9786	9787	9790	9791	9793	9795	9856	9877	9881
	9926	9928	9932	9939	9986	10004	10006	10053	10078	10080	10087	10088	10090	10091	10099
	10100	10101	10110	10144	10152	10154	10155	10157	10208	10210	10219	10221	10229	10231	10239
	10241	10249	10251	10259	10261	10269	10271	10279	10281	10344	10348	10350	10354	10355	10357
	10358	10360	10361	10369	10371	10372	10374	10401	10402	10403	10404	10409	10411	10413	10416
	10417	10419	10420	10426	10434	10444	10445	10446	10447	10449	10450	10453	10457	10461	10464
	10519	10521	10534	10536	10546	10548	10561	10563	10573	10575	10588	10590	10600	10602	10615
	10617	10705	10706	10707	10715	10717	10723	10770	10771	10772					
\$OPR1	7799#	9695	10771	10772											
\$OPR2	7868#	8897	8898	8899	8905	8946	8947	9007	9018	9029	9063	9074	9085	9120	9131
	9142	9248	9349	9539	9548	9554	9576	9617	9629	9658	9801	9803	9812	9813	9859
	9882	9883	9885	9887	9890	9930	9942	9945	9953	9957	9988	9999	10040	10054	10092
	10105	10106	10108	10112	10122	10124	10125	10129	10211	10213	10222	10224	10232	10234	10242
	10244	10252	10254	10262	10264	10272	10274	10282	10284	10359	10362	10378	10380	10381	10383
	10384	10386	10388	10391	10395	10422	10436	10455	10459	10462	10468	10472	10475	10477	10481
	10482	10487	10520	10524	10526	10529	10535	10537	10539	10542	10547	10551	10553	10556	10562
	10564	10566	10569	10574	10578	10580	10583	10589	10591	10593	10596	10601	10605	10607	10610
	10616	10618	10620	10623	10731	10931									
\$OPSHF	7510#	10124	10388	10455	10459	10482									
\$OPSUB	7586#	10112	10436	10529	10539	10556	10566	10583	10593	10610	10620	10731			
\$OPSWB	7485#														
\$OPXOR	7633#														
\$OR	6065#	9281	9325	9368	9606	9689	9758	9879	9918						
\$PUT	7022#	9211	9241	9293	9337	9380	9432	9443	9490	9545	9556	9565	9583	9627	9632
	9640	9665	9700	9710	9934	9990	10000	10008	10114	10730					
\$STRUC	5765#														
\$SUBON	5811#	8908	8910	8944	8948	8994	9002	9012	9023	9035	9058	9068	9079	9091	9115
	9125	9136	9148	9172	9194	9218	9237	9245	9246	9254	9255	9257	9259	9283	9299
	9310	9327	9343	9354	9370	9386	9399	9416	9418	9419	9421	9438	9455	9468	9480
	9496	9505	9511	9562	9571	9608	9638	9646	9670	9692	9695	9705	9715	9723	9733
	9734	9738	9739	9744	9745	9760	9794	9796	9808	9819	9822	9825	9828	9829	9832
	9833	9857	9884	9888	9891	9892	9920	9924	9925	9938	9943	9946	9954	9955	9958
	9959	9960	9970	9973	9978	9984	9996	10012	10018	10037	10041	10042	10050	10055	10081
	10093	10119	10120	10130	10131	10132	10188	10351	10363	10385	10387	10396	10397	10398	10418
	10421	10423	10431	10437	10469	10473	10479	10480	10488	10489	10490	10495	10499	10527	10530
	10554	10557	10581	10584	10608	10611	10716	10718	10724	10732	10740	10748	10771	10772	10773
	10774	10776	11055												
\$THEN	6027#	8906	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112	9122	9133
	9145	9165	9192	9231	9247	9249	9281	9307	9325	9350	9368	9395	9413	9414	9449

	9460	9474	9498	9507	9568	9606	9643	9689	9720	9727	9728	9729	9739	9758	9792
	9814	9815	9816	9819	9822	9854	9879	9886	9918	9921	9940	9944	9947	9949	9951
	9956	9968	9971	9974	9979	10015	10034	10035	10038	10052	10103	10126	10128	10181	10376
	10392	10394	10415	10452	10467	10471	10483	10485	10492	10496	10522	10549	10576	10603	10714
	10721	10738													
\$STILA	6526#														
\$STILO	6563#														
\$SUNTL2	6621#	9808	10479	10490											
\$SUNTL3	6600#														
\$SWHILE	6460#														
\$SSCMRE	8857#														
\$SSCTM	8857#														
\$SDEFA	7354#														
\$SENDS	7305#														
\$SERRO	6012#														
\$SESCA	1711#	8724#													
\$SGEN	5888#	8908	8910	8934	8944	8994	9002	9012	9023	9035	9058	9068	9079	9091	9115
	9125	9136	9148	9172	9194	9197	9218	9237	9245	9246	9254	9255	9257	9259	9281
	9283	9299	9310	9325	9327	9343	9354	9368	9370	9386	9399	9416	9418	9419	9421
	9438	9455	9468	9480	9496	9505	9511	9562	9571	9606	9608	9638	9646	9670	9689
	9692	9695	9705	9715	9723	9733	9734	9738	9739	9744	9745	9758	9760	9794	9796
	9807	9808	9819	9822	9825	9828	9829	9832	9833	9857	9879	9884	9888	9891	9892
	9918	9920	9924	9925	9938	9943	9946	9954	9955	9958	9959	9960	9970	9973	9978
	9984	9996	10012	10018	10037	10041	10042	10050	10055	10079	10089	10102	10119	10120	10130
	10131	10188	10349	10356	10375	10385	10387	10396	10397	10414	10418	10421	10430	10435	10451
	10466	10469	10473	10479	10480	10488	10489	10490	10495	10499	10527	10530	10554	10557	10581
	10584	10608	10611	10704	10712	10716	10718	10724	10732	10740	10748	10768	10771	10772	10773
	10774	10776	11042	11055											
\$SGETS	5851#	8908	8910	8944	8948	8994	9002	9012	9023	9035	9058	9068	9079	9091	9115
	9125	9136	9148	9172	9194	9218	9237	9245	9246	9254	9255	9257	9258	9259	9283
	9299	9310	9327	9343	9354	9370	9386	9399	9416	9418	9419	9421	9438	9455	9468
	9480	9496	9505	9511	9562	9571	9608	9638	9646	9670	9692	9695	9705	9715	9723
	9733	9734	9738	9739	9744	9745	9760	9794	9796	9808	9819	9822	9825	9828	9829
	9832	9833	9857	9884	9888	9891	9892	9920	9924	9925	9938	9943	9946	9954	9955
	9958	9959	9960	9970	9973	9978	9984	9996	10012	10018	10037	10041	10042	10050	10055
	10081	10093	10119	10120	10130	10131	10132	10188	10351	10363	10385	10387	10396	10397	10398
	10418	10421	10423	10431	10437	10469	10473	10479	10480	10488	10489	10490	10495	10499	10527
	10530	10554	10557	10581	10584	10608	10611	10716	10718	10724	10726	10732	10740	10748	10771
	10772	10773	10774	10776	11055										
\$SGETT	5861#	8908	9237	9255	9258	9416	9419	9734	9739	9794	9819	9822	9825	9829	9884
	9888	9920	9955	10037	10385	10418	10527	10554	10581	10608	10716	10726			
\$SSLPCN	6887#	9695	10771	10772											
\$SNEWT	1662#	8724#	8923	8986	9044	9104	9157	9186	9275	9319	9362	9407	9528	9601	9684
	9753	9910	10029	10070	10338										
\$SPOP	5875#	8908	8910	8944	8948	8994	9002	9012	9023	9035	9058	9068	9079	9091	9115
	9125	9136	9148	9172	9194	9218	9237	9245	9246	9254	9255	9257	9259	9283	9299
	9310	9327	9343	9354	9370	9386	9399	9416	9418	9419	9421	9438	9455	9468	9480
	9496	9505	9511	9562	9571	9608	9638	9646	9670	9692	9695	9705	9715	9723	9733
	9734	9738	9739	9744	9745	9760	9794	9796	9808	9819	9822	9825	9828	9829	9832
	9833	9857	9884	9888	9891	9892	9920	9924	9925	9938	9943	9946	9954	9955	9958
	9959	9960	9970	9973	9978	9984	9996	10012	10018	10037	10041	10042	10050	10055	10081
	10093	10119	10120	10130	10131	10132	10188	10351	10363	10385	10387	10396	10397	10398	10418
	10421	10423	10431	10437	10469	10473	10479	10480	10488	10489	10490	10495	10499	10527	10530
	10554	10557	10581	10584	10608	10611	10716	10718	10724	10732	10740	10748	10771	10772	10773
	10774	10776	11055												
\$SPUSH	5839#	8906	8908	8934	8941	8992	8999	9009	9020	9032	9055	9065	9076	9088	9112

.\$SCOP	2454#	8609#	11078
.\$SIZE	4361#		
.\$SUPR	4913#		
.\$STRAP	4073#	8609#	11087
.\$TYPB	3287#		
.\$TYPD	3209#	8609#	11081
.\$TYPE	2985#	8608#	11066
.\$TYPO	3112#	8610#	11084
.\$40CA	972#		

. ABS. 017274 000

ERRORS DETECTED: 0

CNDLAA,CNDLAA/CRF/NL:TOC=CNMAC2.SML,CNMAC.MAC,CNDLAA.P11
RUN-TIME: 80 82 5 SECONDS
RUN-TIME RATIO: 374/168=2.2
CORE USED: 42K (84 PAGES)