

CIP V10 L727

SOFTWARE RELEASE BULLETIN

June 7, 1989

Note: For CYBER 960/962/992/994 with a CC598 console, read the CC598 Software Release Bulletin before installing CIP V10 L727.

Important

Two copies of the CIP V10 L727 Software Release Bulletin (SRB) and the Field Change Announcement (FCA) are included in the CIP field kit. One copy is for the customer and the other is for the Control Data Customer Engineer (CE). The Maintenance Software Reference manuals and microfiche also need to be provided to the CE. Please ensure your CE receives this information. It is important that the CE be aware of all CIP features and cautions.

Control Data Corporation recommends that this Software Release Bulletin be read in its entirety prior to any CIP V10 L727 installation.

SMD800469

Contents

Chapter 1 - Introduction

| | |
|----------------------------|-----|
| Audience | 1-2 |
| CIP V10 L727 Support | 1-2 |

Chapter 2 - Installation

| | |
|---|------|
| Enhancements | 2-1 |
| CTI | 2-1 |
| EDD/RCM | 2-1 |
| DFT | 2-1 |
| SCI | 2-1 |
| Mainframe Microcode | 2-1 |
| 960/962 | 2-1 |
| 990/992/994/995 | 2-2 |
| Notes and Cautions | 2-2 |
| CIP V10 L727 Installation Procedure | 2-4 |
| CIP V10 and Operating System Compatibility | 2-4 |
| CIP V10 and On Systems with Dual IOUs | 2-4 |
| CIP V10 L727 Backlevel Support On Systems Without Dual IOUs | 2-4 |
| CC598 Installation | 2-4 |
| CIP Installation | 2-5 |
| Peripheral Microcode Installation | 2-6 |
| Enhancements | 2-7 |
| NOS Installation | 2-8 |
| NOS/BE Installation | 2-9 |
| NOS/BE UEM Requirements | 2-10 |

Chapter 3 - Maintenance Software Library

| | |
|--------------------------|-----|
| Enhancements | 3-1 |
| Notes and Cautions | 3-1 |

Chapter 4 - Configuration Management

| | |
|---|-----|
| Mainframe Microcode Levels | 4-1 |
| Peripheral Microcode Levels | 4-1 |
| Field Change Announcement (FCA) Index Levels..... | 4-1 |

Chapter 5 - Seldom Used or Obsolete Diagnostics

| | |
|--|-----|
| Notes and Cautions | 5-1 |
| Installation Instructions | 5-2 |
| NOS Instructions and NOS/BE Instructions | 5-2 |

Chapter 1

Introduction

The CYBER Initialization Package (CIP) consists of hardware/software interface modules. The modules are released on tape and must be installed to disk for system operation. The CIP V10 L727 release supports CYBER models 810, 815, 825, 830, 835, 840, 845, 850, 855, 860, 870, 960, 962, 990, 992, 994, and 995. The CIP V10 L727 module levels are listed in the table below:

NOTE: Please consult your Field Change Announcement (FCA) sheet to verify that the hardware is at the appropriate level prior to the installation of CIP V10 L727.

The CIP V10 L727 described in this document is being released at the following levels:

| <u>Module</u> | <u>Level</u> | |
|----------------|--------------|---|
| CTI | 716 | (Level 727 CYBER 960/962/990/992/994/995) |
| MSL | 716 | (Level 727 CYBER 960/962/990/992/994/995) |
| EDD/RCM | 716 | (Level 727 CYBER 960/962/990/992/994/995) |
| DFTx/DBDx/ECRx | 06 | |
| EI | 21 | |
| MDD | 13 | |
| SCI | 05 | |
| SCD | 05 | |

The file structure of the CIP V10 L727 tape for CYBER 810/815/825/830/835/840/845/850/855/860/960/990/994 is as follows:

- File 1 CIP V10 L727 deadstart file.
- File 2 CTITEXT.
- File 3 Empty file.
- File 4 NOS peripheral microcode.
- File 5 NOS/BE peripheral microcode.
- File 6 Procedure to install peripheral microcode onto the NOS/BE operating system.
- File 7 Seldom used and obsolete diagnostics that can be loaded at the option of the site maintenance personnel. Instructions for copying file 7 to a tape for installation are contained in chapter 5.

The file structure of the CIP V10 L727 tape for CYBER 962/992 is as follows:

- File 1 CIP V10 L727 file.

Audience

The SRB is written primarily for the site analyst and hardware maintenance personnel. Chapter 2 contains CIP installation information. Chapter 3 contains information concerning maintenance software. Chapter 4 contains configuration management information. Chapter 5 contains information intended for hardware maintenance personnel.

CIP V10 L727 Support

Any problem with CIP V10 L727 should be reported on a Programming System Report (PSR), specifying the nature of the problem. Please include the CIP type, version and level number on each PSR, for example CIP 960 V10 L727 where 960 is the type, 10 is the version, and 727 is the level.

Microcode problems should be reported on Technical Action Request (TAR) forms. To communicate verbally, contact Customer Service Support: 1-800-345-9903 for the United States and Canada and 612-851-4131 for international customers.

Any problem with the media or CIP V10 L727 package contents should be reported to Software Manufacturing and Distribution (SMD). A report form, "THE SOFTWARE MANUFACTURING AND DISTRIBUTION CRITIQUE LETTER," accompanies each CIP tape. To order replacement CIP tapes, please complete this form. Be sure to include a description of the problem, your return mailing address and the type of tape you require, such as CIP 960 V10 L727. Send the form with the defective tape to SMD so that a replacement tape can be sent to you.

Replacement tapes may also be ordered by phone, by calling 612-482-3747. Even if the replacement tape is ordered by phone, please return the defective CIP V10 L727 tape accompanied by the form.

Your site may also try to copy the defective CIP tape to another tape with the operating system. Try to use the new copy of the CIP tape. The recovery process is more extensive on the operating system and the new copy may correct your problem. If this does not correct the problem, please return the defective CIP tape accompanied by the form.

Chapter 2

Installation

Enhancements

CTI

The features to Computer Test and Initialization (CTI) are as follows:

- o Support for a secondary I4C (model 44) IOU on CYBER models 960/962/992/994.
- o Support for CYBER models 960/962 dual CPUs.
- o Support to hand off NIO PPs in 8K mode for stand alone on CYBER models 960, 962, 990, 992, 994, and 995.

EDD/RCM

The Express Deadstart Dump (EDD) and Restore Central Memory (RCM) utilities have been enhanced to include support for I4C (model 44) as a secondary IOU.

DFT

The Dedicated Fault Tolerance (DFT) module has the following modifications:

- o Support for CYBER models 960/962 with dual CPUs.
- o Support for a secondary I4C (model 44) IOU on CYBER models 960/962/992/994.

SCI

The System Console Interface (SCI) module has a parameter name changed in the display memory and enter memory commands. The AD parameter has been changed to MA for the commands DB, DC, DH, EB, and EC. For example, DB MA=3FF WC=10 should now be used in place of DB AD=3FF WC=10.

Mainframe Microcode

960/962

CIP 960/962 V10 L727 mainframe microcode was modified for this release as follows:

- o Modification to support OP code 07 for purge SFSA push stack.

990/992/994/995

The mainframe microcode M40Ax22, M41Ax22, M43Ax22, and M44Ax22 was modified for this release as follows:

- o Modification to support OP code 07 for purge SFSA push stack.

Notes and Cautions

- o Dual IOU systems must use CC598A/CC598B Console Software L727.
- o After the installation of the CC598 L727 console software, the L716 console software is obsolete and should never be used.
- o It is recommended that only one CIP V10 L727 operating system deadstart device per mainframe be used, due to the retention of mainframe configuration information between deadstarts by CTI on the deadstart disk. It is not recommended to have two mainframes share a common CIP V10 L727 device.
- o After performing any physical (hardware) mainframe reconfiguration, the mainframe reconfiguration table (MRT) must be cleared prior to an operating system load. After the MRT is cleared, any logical (CTI) reconfiguration information must be reentered. The steps required to clear the MRT are as follows:
 1. Deadstart from the CIP V10 L727 disk.
 2. At the CIP V10 L727 Initial Options display, enter a U (Utilities).
 3. At the Utilities display, enter an H (clear the mainframe reconfiguration table). The following messages are displayed:

CLEARING THE MRT WILL CAUSE THE
FOLLOWING ITEMS ON THE NEXT
DEADSTART,

ALL MAINFRAME MEMORIES WILL
BE INITIALIZED FOR OS LOADS.

CM RELOAD FROM EDD TAPE OPTION
WILL NOT BE AVAILABLE.

(CR) TO CONTINUE

4. Enter a (CR).

The MRT is now cleared and all previous reconfiguration entries are deleted. Please reference the CYBER Initialization Package (CIP) User's Handbook for a detailed description.

- o MDD mode of SCI is designed to allow an analyst to observe the condition of a mainframe before NOS/VE begins its initialization routines. For SCI to begin the deadstart of NOS/VE, the user should press the F7 key on a CC634B OR CC598A/CC598B console. If a console other than a CC634B or CC598A/CC598B is used, the operator should enter an RS (RECORD SEPARATOR = 1E hexadecimal) and a lower case w. This is true regardless of the origin port of the deadstart or the port that MDD is to drive.
- o On an I2 IOU, when MDD is initiated at deadstart for standalone NOS/VE, the F7 key may not correctly initiate the NOS/VE deadstart. When this problem occurs, the operator sees only the MDD banner on the MDD console (or a garbled MDD banner). The operator should enter an F7 followed by a lower case w to continue deadstart.
- o When using dual state, if you deadstart NOS/BE on a dual CPU CYBER 995, a false (218) FATAL CPU1 ERROR is received in the CERFILE which is also displayed on the NOS/VE console when that system is deadstarted. This error message does not prevent NOS/VE from using the CPU, thus the message can be ignored. To avoid having the error message appear at all, obtain PSR NBOE611 from SOLVER and install it in your NOS/BE system.
- o When switching from using dual state to standalone NOS, CIP V10 L727 must be reinstalled with an initial installation to ensure the proper level of SCI is installed.
- o When installing the NOS/VE boot programs for NOS/VE 1.4.1 L716 or NOS/VE 1.4.2 L727, the NOS/VE deadstart tape must be used.
- o At NOS/VE 1.4.1 or later, NOS/VE supports the capability of disabling CPU elements in a dual CPU environment, while the system is executing on line. CIP currently does not provide a user interface to clear the CPU down status via CTI. The action required to clear this status is to clear the MRT on the CIP disk. See previous note in this section for a description on how to clear the MRT.
- o The Maintenance Display Driver (MDD) has a parameter name changed in the display memory and enter memory commands. The AD parameter has been changed to MA for the commands DB, DC, DH, EB, and EC. For example, DB MA=3FF WC=10 should now be used in place of DB AD=3FF WC=10.
- o On CYBER 960/962/992/994 after installing/replacing the NOS/VE boot programs a deadstart is required before initiating an operating system load. This is necessary to correct a problem caused by the loss of the system configuration status during the CIP Install NOS/VE Programs Utility.
- o CIP does not support tapes configured on channels 0 or 1.

CIP V10 L727 Installation Procedure

CIP V10 L727 and Operating System Compatibility

CIP V10 L727 may be installed as released if your site is running any of the following operating system release levels on a non dual IOU system. Operating systems released prior are outside the support window and may not work. Sites that wish to use a previously released operating system may do so at their own risk.

| | | |
|--------|-----------------|----------------------|
| NOS | 2.7.1 L716 | |
| | 2.6.1 L710/L688 | (CYBER 960/994 only) |
| | 2.6.1 L700/L688 | |
| | 2.5.3 L688 | |
| NOS/BE | 1.5 L712 | |
| | 1.5 L682 | |
| | 1.5 L664 | |
| NOS/VE | 1.4.2 L727 | |
| | 1.4.1 L716 | |
| | 1.3.1 L700 | |
| | 1.2.3 L688 | |

CIP V10 L727 on Systems with Dual IOU's

When using CIP V10 L727 on a dual IOU system, the operating system(s) used must be at the following (or later) levels:

| | |
|--------|------------|
| NOS | 2.7.1 L716 |
| NOS/VE | 1.4.2 L727 |

At the present time dual IOU's cannot be used on a dual state system running NOS/BE.

(Note: The second IOU is only used be NOS/VE)

CIP V10 L727 Backlevel Support on Systems Without Dual IOUs

Customers may upgrade to CIP V10 L727 and continue to use an operating system that is not at the latest release level. No CIP tape modification is necessary unless your site is running dual state with NOS 2.6.1 L700/688 or NOS 2.7.1 L716 and NOS/VE 1.2.3 L688 (or a prior level).

Beginning with CIP V9 L700, CIP no longer supports NOS/VE systems that were released prior to NOS/VE 1.2.2 L678.

CC598 Installation

To install the console software, refer to the CC598 Support Package SRB. To install CIP V10 L727, refer to the CYBER Initialization Package (CIP) User's Handbook, revision N (60457180).

CIP Installation

- o Do not install CIP when the CIP disk is in use. Installation of CIP should be accomplished only when CIP has sole access to the disk to avoid conflicts with operating system access and possible file corruption.

In dual state, the CIP device must be defined to the host operating system (NOS or NOS/BE). The CIP disk may either be defined in the NOS/VE configuration as state=OFF or must be omitted entirely from the NOS/VE configuration. NOS/VE does not use a device with state=OFF unless it is a CIP disk, and then only for DFT access.

For NOS/VE standalone, the CIP device must be state=ON. It is also recommended that the CIP disk also be the system disk.

You may alternate between dual state and standalone, using the same PHYSICAL_CONFIG and configuration prolog files by changing the state of the CIP disk to state=OFF when running dual state.

- o Perform the following steps to install CIP V10 L727 to the CIP disk:
 1. If you plan to run dual state with NOS 2.6.1 L700/688 or NOS 2.7.1 L716 and intend to use NOS/VE 1.2.3 L688 or a prior level, you must create a modified CIP tape based on the CIP currently in use by replacing SCI with the version from the CIP V10 L727 tape. You must use this tape when installing the NOS/VE boot components.

If this situation does not apply to you, skip to step 2.

Perform the following steps to create the modified CIP tape:

- a. Obtain the following:

- o The CIP tape which matches the level of NOS/VE you are currently running.
- o The CIP V10 L727 tape.
- o A scratch tape for the modified CIP tape that you will create.

- b. To replace SCI, have the site analyst perform the following steps at the system console or from an interactive terminal:

REQUEST,CIP,VSN=CIP,D=PE,F=SI,LB=KU.

assign the CIP V10 L727 tape

GTR,CIP,SCI.OVL/SCI

UNLOAD,CIP.

REQUEST,OLD,VSN=OLD,D=PE,F=SI,LB=KU.

assign the CIP tape matching the NOS/VE level to be used:

| <u>for NOS/VE Level</u> | <u>use CIP Level</u> |
|-------------------------|----------------------|
| 1.2.3 L688 | V8 L688 |
| 1.2.2 L678 | V7 L678 |

LIBEDIT,P=OLD,N=NEW,B=SCI.
UNLOAD,OLD.
REQUEST,SCR,VSN=SCR,D=PE,F=SI,LB=KU.
 assign the scratch tape
REWIND,NEW,SCR.
COPYBF,NEW,SCR.
UNLOAD,SCR,NEW.

Use this modified CIP tape when installing the NOS/VE boot programs, described in step 6.

2. The update option may be used to install CIP V10 L727 and permanent files do not require dumping and reloading. Use of the update or initial installation option is documented in the CYBER Initialization Package (CIP) User's Handbook, revision N (60457180). After identifying the type of CIP installation and, if necessary dumping permanent files, deadstart from the CIP V10 L727 tape and perform either the update or the initial installation.
3. If your site does not use NOS/VE, skip to step 8; otherwise, deadstart from the CIP V10 L727 disk.
4. Select the U (Utilities) option.
5. Select the V (Install NOS/VE Boot Programs) option.
6. Mount one of the following based on the descriptions given:
 - a. If you created a modified CIP tape in step 1, mount this tape.
 - b. If you plan to run NOS/VE 1.4.2 L727, mount the NOS/VE 1.4.2 L727 or if you plan to run NOS/VE 1.4.1 L716, mount the NOS/VE 1.4.1 L716 deadstart tape. (Note that the CIP V10 L716/L727 tapes do not contain the required NOS/VE boot programs.)
 - c. In any other case, mount the CIP tape that matches the level of NOS/VE that you plan to run.
7. Describe the path to the tape drive containing the tape identified in step 6 and install the NOS/VE boot programs.
8. The CIP V10 L727 installation process is complete. You may proceed to the peripheral microcode and operating system installation.

If you wish to alternate between the two levels of NOS/VE for any reason, you may do this using the same CIP disk by following steps 3-7 to install the NOS/VE boot components matching the NOS/VE system level you are deadstarting. Steps 3-7 must be repeated immediately before each deadstart of a NOS/VE system that is at a different release level than the NOS/VE system most recently executed on that mainframe.

Peripheral Microcode Installation

New levels of peripheral microcode for NOS and NOS/BE are distributed via CIP. The NOS/VE operating system obtains peripheral microcode from the common disk area, which is installed with CIP V10 L727, and does not require the operating system deadstart tape to be modified.

Acquiring the peripheral microcode from the CIP V10 L727 tape for installation onto the operating system is an operation separate from CIP V10 L727 installation. NOS peripheral microcode is contained on file 4 of the CIP tape, and NOS/BE peripheral microcode is on file 5. File 6 is a procedure to aid in the installation of peripheral microcode onto the NOS/BE operating system. The steps in the NOS and NOS/BE sections describe how to install peripheral microcode onto an operating system deadstart tape.

Enhancements

The peripheral microcode MH426 for 9853 has added two functional changes plus other various features. These changes are transparent to the user and improve performance. Field tests show a 12-13% performance improvement from these enhancements. To install MH426 the utility LEEP is used. The documentation for LEEP is contained in the CYBER Systems Peripheral Diagnostic Reference Manual, publication number 60000144 revision F.

The utility LEEP, which loads the EEPROM in the CM3 may not terminate correctly. LEEP normally terminates with the following message: MICROCODE XX SUCCESSFULLY LOADED, where XX is the level number. If LEEP halts with a DISK SUBSYSTEM ERROR, DRIVE STATUS=8004H, and a LOW LEVEL ERROR = 0063H, the EEPROM has been properly loaded. This can be verified by rerunning LEEP. Enter an R on the keyboard, followed by a space bar. The initial warning message is display. Note the currently loaded portion of the message, which should reflect level 09, which was just loaded.

The features are described as follows:

- o Dual process: This feature provides two processes under the kernel for each drive on the string. If there are two more commands in the command buffer (IPI-3 buffer) for the same drive, the first command is parsed and executed and the second command is parsed and readied for execution during the seek for the first command. However, other drive commands could be parsed and put into execution prior to the second or subsequent commands for that drive. In other words, a second command for each drive could be parsed and readied for execution during the execution of commands for that drive to be complete before beginning the next command on that drive.
- o Split buffer: This feature allows for another drive's data to be loaded into the buffer and transferred to the host prior to completion of the command for the drive currently transferring data. The following conditions must be met for this feature to work:
 - the last burst for the current transfer is in the buffer
 - the next drive's RPS interrupt occurs
 - the next drive has the same sector size as the current drive.

When these conditions are satisfied the data transfer for the next drive occurs before the command completes class 1 transfer packet for the current command is transferred.

- o Defect list error recovery: Error recovery was added to all data sets on the defect management cylinder. It prevents a catastrophic failure if one of the replicated sectors is unreadable. This error recovery allows the operation in progress to continue in the event of a data error.
- o Defect list sector length: The length field in the defect list was changed to 3FE (1024) instead of the actual length of the data to comply with the ANSI standard.
- o Unformatted status: Drives that fail diagnostics or are removed from the CM-3 drive tables due to a hardware status were being reported as unformatted. This was changed to reflect a more accurate description of the drive condition.

NOS Installation

NOS sites must update the operating system deadstart tape if it is not at NOS 2.7.1 L716. The following procedure installs peripheral microcode onto an operating system tape and directs its installation.

1. Deadstart NOS.
2. Mount the CIP V10 L727 tape.
3. Enter the following commands at the system console under DIS or from an interactive terminal:

```
REQUEST,CIP,VSN=CIP,D=PE,F=SI,LB=KU,PO=RF.  
SKIPF,CIP,3.  
COPYBF,CIP,LGO.  
RETURN,CIP.  
COMMON,SYSTEM.  
SYSGEN,DST,SYSTEM,LGO,NEW,USERD,density.  where density is the density  
                                              of the new deadstart tape  
                                              (PE or GE)
```

These steps create a new deadstart tape containing the new peripheral microcode. The new tape is requested with a VSN of NDT. It should be assigned with the VSN,est,NDT command from the system console, where est is the EST ordinal of the tape drive where the operating system tape is written.

4. If CIP V10 L727 has not been installed to disk yet, use the process documented in the CIP V10 L727 Installation section, mentioned previously.
5. Perform a level 0 (zero) NOS deadstart with the new tape.

NOS/BE Installation

To incorporate the latest peripheral microcode from the CIP V10 L727 tape onto NOS/BE, follow the steps below:

1. Deadstart NOS/BE.
2. Mount the CIP V10 L727 tape.
3. Enter the following commands at the system console:

```
n.DIS.  
REQUEST,CIP,VSN=CIP,NT,PE,NORING.  
SKIPF,CIP,5,17.  
BEGIN,,NOSBE,CIP.
```

When this procedure terminates, all peripheral microcode used by NOS/BE is CATALOGed with ID=CWARE. The deadstart tape must now be rebuilt using the appropriate NOS/BE build job (DST1 or DST3) as described in the NOS/BE Installation Handbook.

4. If CIP V10 L727 has not been installed to disk yet, use the process documented in the CIP V10 L727 Installation section, mentioned previously.
5. Deadstart NOS/BE with the new tape.

NOS/BE UEM Requirements

CIP allocates Central Memory (CM) space on the system mainframes for EI, page tables and required CM resident binaries. In addition, DFT requires CM space for its tables. These requirements change depending on the type of mainframe, the amount of memory and the number of CPUs. The CM remaining for User Extended Memory (UEM) is summarized in the following table:

| Mainframe Type | CM Size times 1000B | | | NOS/BE Level |
|--|---------------------|-------|-------|---------------|
| | 8 MB | 16 MB | 32 MB | |
| 810/810A/815/825/830/830A/835 | 2737 | 6735 | 6777 | L682 or prior |
| | 2736 | 6734 | 6776 | L712 |
| 840/840A/845/850/850A/855/860 860A/870/870A | 2735 | 6733 | 6777 | L682 or prior |
| | 2733 | 6731 | 6775 | L712 |
| 960 | N/A | N/A | N/A | L682 or prior |
| | 2706 | 6704 | 6774 | L712 |
| 990/990E/994/995E | 2665* | 6663* | 6775* | L682 or prior |
| | 2662* | 6660* | 6772* | L712 |

* If the mainframe has a second CPU, subtract another 1000B.

All values should be multiplied by 1000B. The first line gives the values for NOS/BE systems at level 682 or prior and the second gives values for level 712. The 32 MB size includes all systems greater than 32 MB.

Chapter 3

Maintenance Software Library

Enhancements

Enhancements

The enhancements to the Maintenance Software Library (MSL) are as follows:

- o Modifications to SMT3, LMT3, BPT3, EXCH, TRAP, FCT1, FCT5, CMEM, and EME for CYBER 960/962 for the redesigned LMA module (JS arrays).
- o Modifications to MCT3, CMSE and the command buffers on CYBER 960/962 for dual CPUs.
- o Support for I4C as a secondary IOU on CYBER 960/962/992/994.
- o Modification to MDT3 to correct MDT3 margin failures on CYBER 960/962.
- o Modification to command buffers FII40 and FII44 to add CX,I (master clear IOU) and CE,I (clear IOU fault register) CMSE commands for CYBER 96x/99x.

Notes and Cautions

- o Microfiche program listings of CTI, microcode, SCI, SCD, MDD, DFT, and EI are available at the discretion of the District Technical Operational Support (TOS) managers or the Country Central Office.
- o Deleting DEMOT's OUTPUT files (*DP,fn command), or any other file created without a 77 table (such as the flaw map from FMU), results in the error message PRFX TABLE MISMATCH appearing in the keyboard area error/message line. Although the file was deleted and the error message can be cleared with no need to retry the command, the disk space used by such a file is not released by CMSE. If a SRT FULL situation is encountered, CIP V10 L727 requires reinstallation using the update installation option.
- o The memory tests generally do not execute properly if CMSE is using central memory for communication.
- o To run the I4 (CIO) PP based diagnostics, central memory has to be enabled at the initial CMSE display by entering 8.3 (parameter change). The diagnostics do not run without CM enabled. Refer to Service Bulletin 6945. The diagnostics that are affected are:
 - o CCA4 - 170 DMA (CIO) channels
 - o ISI4 - Intelligent Subsystem Interface (ISI) channels
 - o IPI4 - Intelligent Peripheral Interface (IPI) channels
 - o HYDR - DMA enhanced ISI channel adapter to 887 disk test
 - o UESM - ESM/STORNET monitor
 - o UHYD - ISI channel off line monitor of 887 disk in line test
 - o DEMOT diagnostics (CIO)

Note: The 170 DMA IOU diagnostic CCA4 leaves the CIO IOU in a state that the DEMOT diagnostics can't use. A deadstart followed by a U-I-M sequence corrects the problem.

- o The PSR MSLB092 documents a problem with the diagnostic CMEM testing central memory in excess of 128 mega bytes on a CYBER 960/962. The diagnostic displays PAGE UNAVAILABLE FOR RMA if an attempt is made to test memory with addresses greater than FFF,FFF (HEX). Testing of the full memory can be accomplished using MAT3. This problem will be corrected in a future release.
- o The diagnostic CMEM has been modified to execute with a 16K byte page size on CYBER models 960, 962, 990, 992, 994 and 995. This has caused the diagnostic to move in memory. The control words and parameters that were at 500xx are now at 2E0xx. Second CPU parameters are at 2E820. Information that was at 4E2xx/4F2xx is now at 2D2xx/2DAxx. Refer to the MSL15x Model Independent Tests and Maintenance Software Reference Manual, publication number 60469390 revision x, for a description of the control words and parameters.
- o The PSR MSLB089 documents a problem with BYTE on CYBER 960/962, which reports PIT loses during execution. This should not be of concern. Checking of PIT interrupts by the test has been turned off. The problem will be resolved in a future release.
- o On CYBER 960/962 problems have been reported in MCT3 section 29. For the present time, errors reported by this section should be ignored. This test section can be deleted with a parameter entry. This problem will be resolved in a future CIP release.

Chapter 4

Configuration Management

Mainframe Microcode Levels

| <u>Mainframe System Type</u> | <u>Release Level</u> | <u>Mainframe System Type</u> | <u>Release Level</u> |
|----------------------------------|--------------------------|----------------------------------|--------------------------|
| CYBER 180-810 810A | M14AA15 | CYBER 170-815 | M11AA15 |
| CYBER 180-830 830A | M13AA15 | CYBER 170-825 | M12AA15 |
| CYBER 180-840 840A | M340x09 | CYBER 170-835 | M20AA16 |
| CYBER 180-850 850A | M330x12 | CYBER 170/180-845 | M310x11 |
| CYBER 180-860 860A | M320x11 | CYBER 170/180-855 | M300x10 |
| CYBER 960/962-11 | M3A0x06* | CYBER 180-990/995 | M40Ax22* |
| CYBER 960/962-31 | M3B0x06* | CYBER 180-990/995 | M41Ax22* |
| CYBER 992 | M43Ax22* | | |
| CYBER 994 | M44Ax22* | | |

* Changed with the CIP V10 L727 release when compared to CIP V10 L716.

Peripheral Microcode Levels

These are the versions of peripheral microcode furnished on the CIP V10 L727 tape and the current versions with which CIP was tested.

| <u>Name</u> | <u>Version</u> | <u>Description</u> |
|-------------|----------------|---|
| MA401 | 08 | 844FT disk peripheral microcode |
| MA454 | 04 | FSC disk peripheral microcode |
| MA462 | 06 | ISD disk adapter peripheral microcode |
| MA464 | 10 | 895 disk peripheral microcode |
| MA466 | 03 | 5870 NIP peripheral microcode |
| MA710 | 13 | 844HT disk peripheral microcode |
| MA721 | 12 | 885/FMD disk peripheral microcode |
| MA722 | 03 | 885/FMD DEMA disk peripheral microcode |
| MB301 | 012 | IPI tape peripheral microcode |
| MB401 | 04 | FSC tape peripheral microcode |
| MB434 | 14 | 66X tape peripheral microcode |
| MB465/CW63X | 04 | 639 ISMT tape control module peripheral microcode |
| MB466 | 03 | 7990 mass storage subsystem peripheral microcode |
| MB467 | 02 | 698 CMTS tape peripheral microcode |
| MD422 | 07 | 834 disk diagnostics |
| MD424 | 03 | 836 disk diagnostics |
| MH422 | 07 | 834 disk COS |
| MH424 | 03 | 836 disk COS |
| *MH426 | 09 | 9853 disk COS |

* = Modified for this release.

Field Change Announcement (FCA) Index Levels

FCA plug and play index levels are documented on the FCA sheet distributed with CIP V10 L727.

Chapter 5

Seldom Used or Obsolete Diagnostic Instructions

Notes and Cautions

This section contains information on file 7 for CIP V10 L727 tapes with MSL. The following programs, which are seldom used or obsolete diagnostics, can be installed at the option of the local site maintenance personnel for all systems except a CYBER 962 or CYBER 992.

FFU01-FFU99A
 FLM00-FLM99C
 FSM00-FSM99A
 F4401-F4499A
 F7X00-F7X99A
 F8801-F8899A
 PDP01-PDP99B
 BCX-9X6
 MY8-9VJ
 MY9-9VT
 LDC-9V5
 MTC-9UP
 S2C-8JU
 SCX
 CID-7AZ
 MYP-9VX

| | |
|--------------|--|
| PAGE2 | CYBER 960/990/994/995 only |
| STAT2 | CYBER 960/990/994/995 only |
| TASE2 | CYBER 960/990/994/995 only |
| TIVE2 | CYBER 960/990/994/995 only |
| PAGE065 | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| STAT065 | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| TASE065 | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| TIVE065 | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| GENM | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| CACHE-CACHEB | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| TRPEM-TRPEB | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |
| VAUTO-VAUTOB | CYBER 845/855/840/840A/850/850A/860/860A/870/870A only |

Installation Instructions

To copy file 7 to another tape for installation by TDX, refer to the NOS or NOS/BE instructions below.

NOS Instructions

JOB.
USER,user,pw,family.
CHARGE,charge,project.
REQUEST,CIP,VSN=CIP,NT,PE,F=SI,LB=KU,PO=R.
REQUEST,COPY,VSN=COPY,NT,PE,F=SI,LB=KU,PO=W.
SKIPF,CIP,6.
COPYBF,CIP,COPY.

NOS/BE Instructions

JOB/account
REQUEST,CIP,VSN=CIP,NT,PE,NORING.
REQUEST,COPY,VSN=COPY,NT,PE,RING.
SKIPF,CIP,6,17.
COPYBF,CIP,COPY.

Refer to the MSL15X Reference Manual for a description of TDX, which is used to install the diagnostics to the CIP disk from the tape created.