

Micro Fiche Scan

Name of device(s) tested:

MSV11-DD/LF/PK/ED/LK/PF/PL/R/QA/QB

Test description:

0-2 MEG MEM EXER

MAINDEC Number or Package Identifier (after SEP 1977):

CVMSAB0

Fiche Document Part Number:

AH-S437B-MC

Fiche preparation date unknown, using copyright year:

1985

Image resolution:

1-bit black&white, compressed for minimal file size

COPYRIGHT (C) 1981-85 by d|i|g|i|t|a|l

## IDENTIFICATION

=====

PRODUCT CODE: AC-S435B-MC  
PRODUCT NAME: CVMSABO 0-2 MEG MEM EXER  
PRODUCT DATE: DECEMBER 1985  
MAINTAINER: ESD DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1981, 1985 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DEC TAPE	

REVISION HISTORY  
\*\*\*\*\*

REVISION A:	APRIL 1981	COMMENT
REVISION B:	DECEMBER 1985	11/53 PIPE-LINEING SUPPORT XXDP V2.2 COMPATIBILITY DEPO INCORPORATED UPDATED DOCUMENTATION

## TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION.
1.1	PROGRAM PURPOSE (ABSTRACT)
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE SUPPORTED
1.2.1.1	HARDWARE RESTRICTIONS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	LOADING AND STARTING PROCEDURE
2.2	SPECIAL ENVIRONMENTS
2.3	PROGRAM OPTIONS
2.4	EXECUTION TIMES
3.0	ERROR INFORMATION
3.1	ERROR REPORTING
3.2	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
5.2	MOS PARITY REGISTER
6.0	SUB-TEST SUMMARIES
6.1	SECTION 1: ADDRESS TESTS
6.2	SECTION 2: WORST CASE NOISE TESTS
6.3	SECTION 3: INSTRUCTION EXECUTION TESTS
6.4	SECTION 4: MOS TESTS
6.5	SPECIAL TOGGLE IN TESTS
7.0	PROGRAM LISTING

## 1.0 GENERAL PROGRAM INFORMATION.

## 1.1 PROGRAM PURPOSE (ABSTRACT)

THIS PROGRAM HAS THE ABILITY TO TEST MEMORY FROM ADDRESS 000000 TO ADDRESS 17757777. IT DOES SO USING:

- A. UNIQUE ADDRESSING TECHNIQUES
- B. WORSE CASE NOISE PATTERNS, AND
- C. INSTRUCTION EXECUTION THROUGH MEMORY.

THE INTENT OF THIS PROGRAM IS TO TEST AS COMPREHENSIVELY AS POSSIBLE ALL MOS MEMORIES USED ON THE LSI 11 BUS WITHOUT CONCENTRATING ON ANY ONE SYSTEM. ALTHOUGH THE TESTS RELATE TO GENERAL DESIGNS THEY MAY BE COMPLETE FOR CERTAIN SYSTEMS. THIS TEST IS ALSO NOT INTENDED TO BE A TOTAL 100% TEST OF THE MEMORY. OTHER TESTS THAT DO I/O MAY FIND MEMORY PROBLEMS THAT THIS TEST IS UNABLE TO.

## 1.2 SYSTEM REQUIREMENTS

## A. HARDWARE REQUIREMENTS

LSI-11/2, LSI 11/23, LSI-11/53, LSI-11/73 BUS FAMILY PROCESSORS.  
MINIMUM OF 16KW OF MEMORY.

OPTIONAL:  
ANY PARITY MEMORY CONTROL MODULE.  
KTF11 MEMORY MANAGEMENT.

## B. SOFTWARE REQUIREMENTS

THE SMALLEST UNIT OF MEMORY THIS PROGRAM WILL RECOGNIZE IS 8K. IF ANY ADDRESS IN A 8K BANK CAUSES A TIME OUT TRAP, THAT ENTIRE BANK OF MEMORY IS IGNORED BY THE PROGRAM. PROGRAM TESTS IN 8KW BANKS, UNLESS IT IS THE LAST 4KW BEFORE THE I/O PAGE OR LAST 6KW IF 30KW SYSTEM.

THE PROGRAM IS DESIGNED TO EXERCISE THE VECTOR PORTION OF MEMORY (LOCATIONS 0-776) IN EXACTLY THE SAME MANNER AS THE REST OF MEMORY. TO MAKE THIS POSSIBLE, WITHOUT REQUIRING MEMORY MANAGEMENT, NO SOFTWARE TRAPS ARE USED IN THE PROGRAM. THIS MEANS THAT IF MEMORY MANAGEMENT IS NOT AVAILABLE OR IS DISABLED (SW12=1), IF THE PROGRAM IS RELOCATED OUT OF BANK 0, IF LOCATION 0-776 ARE SELECTED FOR TEST, AND IF AN UNEXPECTED HARDWARE TRAP OCCURS, THE RESULTS WILL BE UNPREDICTABLE.

THE PROGRAM HAS THE PROPER INTERFACE CODE TO ALLOW RUNNING UNDER THE AUTOMATED MANUFACTURING TEST LINE SYSTEM - ACT11 AND APT.

## 1.2.1 HARDWARE SUPPORTED

THE FOLLOWING MEMORIES ARE SUPPORTED BY THIS SOFTWARE:  
MSV11-DD, MSV11-LF, MSV11-PK, MSV11-ED, MSV11-LK, MSV11 PF,  
MSV11 PL, MSV11-R, MSV11-Q/A/B/C, MSV11-S.

## 1.2.1.1 HARDWARE RESTRICTIONS

IF THE SYSTEM HAS MIXED MSV11-D (18 BIT) MEMORIES WITH  
MSV11-L OR MSV11-P (22 BIT) MEMORIES, IT IS RECOMMENDED  
TO SET UP THE MSV11-L OR MSV11-P TO 18 BIT MODE.  
AS THE PROGRAM AUTOSIZES FOR NONCONTIGUOUS MEMORY,  
IT IS POSSIBLE TO RECEIVE RESPONSES FROM THE "MSV11-D"  
MEMORY WHEN SIZING ABOVE 18 BITS. THIS CAN CAUSE  
INCORRECT MEMORY SIZING AND FALSE ERRORS. ADDITIONALLY,  
THE MSV11-R, MSV11-Q/A/B/C, AND THE MSV11-S ARE SUBJECT  
TO THE SAME LIMITATIONS. IT IS RECOMMENDED THAT THESE  
MEMORIES NOT BE MIXED WITH MSV11-D.

## 1.3 RELATED DOCUMENTS AND STANDARDS

- A. PROGRAMMING PRACTICES - DOCUMENT NO. 175-003-009-01
- B. PDP-11 MAINDEC SYSMAC PACKAGE - MAINDEC 11-DZQAC-C7-D
- C. THE APPLICABLE MEMORY SYSTEM MAINTENANCE MANUAL
- D. THE APPLICABLE CIRCUIT SCHEMATICS

## 1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

BEFORE RUNNING THIS PROGRAM, A CPU DIAGNOSTIC SHOULD BE RUN  
TO VERIFY THE FUNCTIONALITY OF THE PROCESSOR AND PDP-11  
INSTRUCTION SET. FOR LSI 11/23: CJKDB DIAG  
FOR LSI-11/2 : CVKAA\_ DIAG

IF MEMORY MANAGEMENT IS TO BE USED, THEN THE KTF11 DIAGNOSTIC  
CJKDA\_ SHOULD ALSO BE RUN BEFORE THIS PROGRAM.

## 1.5 ASSUMPTIONS

THIS PROGRAM ASSUMES THE CORRECT OPERATION OF THE CPU AND, IF  
USED, THE MEMORY MANAGEMENT OPTION.

## 2.0 OPERATING INSTRUCTIONS

## 2.1 LOADING AND STARTING PROCEDURES

2.1.1 LOAD THE PROGRAM USING XXDP OR ANY STANDARD ABSOLUTE LOADER.

2.1.2 STARTING ADDRESS 200:  
NORMAL PROGRAM EXECUTION.

2.1.3 STARTING ADDRESS 204:  
RESTART PROGRAM USING PREVIOUSLY SELECTED PARAMETERS.

## 2.2 SPECIAL ENVIRONMENTS

SEQ 0006

IF THE PROGRAM IS RUN IN AUTOMATIC MODE UNDER ACT11 OR APT11 THE PROGRAM IS DONE AFTER THE FIRST PASS. ALSO, THE PROGRAM DOES NOT RELOCATE TO TEST THE LOWER 8K OF MEMORY AFTER THE FIRST PASS.

## 2.3 PROGRAM OPTIONS

THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED FOR ALL OPERATIONAL SWITCH SETTINGS.  
THE USER CAN TYPE CTRL G (+G) TO ALLOW SWR CHANGES DURING PROGRAM EXECUTION.

SW15 = 1 OR UP....	HALT ON ERROR
SW14 = 1 OR UP....	LOOP ON TEST
SW13 = 1 OR UP....	INHIBIT ERROR TYPEOUT
SW12 = 1 OR UP....	INHIBIT MEMORY MANAGEMENT (INITIAL START ONLY)
SW11 = 1 OR UP....	INHIBIT SUBTEST ITERATION (NOT USED)
SW10 = 1 OR UP....	RING BELL ON ERROR
SW9 = 1 OR UP....	LOOP ON ERROR
SW8 = 1 OR UP....	LOOP ON TEST IN SWR<4:0>
SW7 = 1 OR UP....	INHIBIT PROGRAM RELOCATION
SW6 = 1 OR UP....	INHIBIT PARITY ERROR DETECTION
SW5 = 1 OR UP....	INHIBIT EXERCISING VECTOR AREA (LOCATIONS 0-1000).

## 2.4 EXECUTION TIMES

EXECUTION TIME IS DEPENDENT ON TYPE OF MEMORY, AND AMOUNT OF MEMORY. WORSE CASE RUN TIMES WITH MC. MEMORY\$ ARE:

## A. FOR NON-PARITY MEMORY

FULL PASS:	< 5 MINUTES FOR 64KW
	30 MINUTES FOR 1280 KW

## B. FOR PARITY MEMORY

FULL PASS:	5 MINUTES FOR 64KW
	20 MINUTES FOR 256KW
	117 MINUTES FOR 1280KW

APT TIME IS SETUP FOR 256Kw (APPROX. 20 MIN).

SEQ 000

\*PLEASE MAKE CHANGES TO APT TIMES AS MEMORY INCREASES OR DECREASES IN SIZE.

### 3.0 ERROR INFORMATION

#### 3.1 ERROR REPORTING

THERE ARE A TOTAL OF 31(8) TYPES OF ERROR REPORTS GENERATED BY THE PROGRAM. SOME OF THE KEY COLUMN HEADING MNEMONICS ARE DESCRIBED BELOW FOR CLARITY:

PC = PROGRAM COUNTER OF ERROR DETECTION CODE.  
(V/PC=P/PC)

V/PC = VIRTUAL PROGRAM COUNTER. THIS IS WHERE THE ERROR DETECTION CODE CAN BE FOUND IN THE PROGRAM LISTING.

P/PC = PHYSICAL PROGRAM COUNTER. THIS IS WHERE THE ERROR DETECTION CODE IS ACTUALLY LOCATED IN MEMORY.

TRP/PC = PHYSICAL PROGRAM COUNTER OF THE CODE WHICH CAUSED A TRAP.

MA = MEMORY ADDRESS

REG = PARITY REGISTER ADDRESS.

PS = PROCESSOR STATUS WORD.

IUT = INSTRUCTION UNDER TEST.

S/B = WHAT CONTENTS SHOULD BE.

WAS = WHAT CONTENTS WAS.

#### 3.2 ERROR HALTS

WITH THE 'HALT ON ERROR' SWITCH (SW15) NOT SET THERE ARE SEVERAL PROGRAMMED 'HALTS' IN THE PROGRAM:

A. IN THE ERROR TRAP SERVICE ROUTINE FOR UNEXPECTED TRAPS TO VECTOR 4. THIS ONE WILL OCCUR IF A 2ND TRAP TO 4 OCCURS BEFORE THE ERROR REPORT FOR THE FIRST HAS HAD A CHANCE TO BE PRINTED OUT.

B. IN THE RELOCATION ROUTINE IF THE PROGRAM IS BEING RELOCATED BACK TO THE FIRST 8K OF MEMORY AND THE PROGRAM CODE WAS NOT ABLE TO BE TRANSFERRED PROPERLY.

C. IN THE CASE OF ERROR REPORTING AND THERE IS NO TERMINAL TO ALLOW THE INFORMATION TRANSFER.




- D. IN THE POWER FAIL ROUTINE IF THE POWER UP SEQUENCE WAS STARTED BEFORE THE POWER DOWN SEQUENCE HAD A CHANCE TO COMPLETE ITSELF.
- E. IN THE MEMORY MAPPING ROUTINE OR ANY OF THE ADDRESS CONTROL ROUTINES, FAILURES TO FIND A MEANINGFUL MAP.

4.0 PERFORMANCE AND PROGRESS REPORTS  
NOT APPLICABLE

5.0 DEVICE INFORMATION TABLES

THE FOLLOWING IS A PICTURE VIEW OF A PARITY CONTROL STATUS REGISTERS, WHICH WILL SHOW BIT ASSIGNMENTS AND DEFINITIONS, TO PROVIDE A HANDY REFERENCE:

5.2 MOS PARITY REGISTER



BIT ASSIGNMENTS ARE DEFINED AS FOLLOWS:

BIT15 PARITY ERROR

BIT02 WRITE WRONG  
PARITY NORMAL PARITY  
(ODD) WHEN CLEAR;  
OTHER PARITY (EVEN)  
WHEN SET

BIT00 ACTION ENABLE NO  
ACTION WHEN CLEAR. TRAP  
TO VECTOR 114 WHEN SET.

BITS 5-11 ADDRESS BITS FOR A11-A17  
OR ADDRESS BITS 18-21, IF BIT 14=1  
LOCATES PARITY ERROR TO A 1K  
SEGMENT OF MEMORY.

BIT 14...ALWAYS READ AS A ZERO  
ON 128KW. IN A 2044 MACHINE, R/W  
AND IS THE EXTENDED CSR READ  
ENABLE BIT FOR A18-A21 IN BITS 5-8.

## 6.0 SUB-TEST SUMMARIES

SEQ 0009

## 6.1 SECTION 1: ADDRESS TESTS.

THESE TESTS VERIFY THE UNIQUENESS OF EVERY MEMORY ADDRESS.

TEST 1 WRITES AND READS THE VALUE OF EACH MEMORY WORD ADDRESS INTO THAT MEMORY LOCATION. AFTER ALL MEMORY HAS BEEN WRITTEN, ALL LOCATIONS ARE CHECKED AGAIN.

TEST 2 WRITES THE BYTE VALUE OF EACH ADDRESS INTO THAT BYTE LOCATION AND CHECKS IT.

TEST 3 WRITES THE COMPLEMENT OF EACH WORD ADDRESS INTO THAT LOCATION AND CHECKS IT.

TEST 4 WRITES THE 8K BANK NUMBER INTO EACH BYTE OF THAT BANK AND CHECKS IT.

TEST 5 WRITES THE COMPLEMENT OF THE BANK NUMBER INTO EACH BYTE OF THAT BANK AND CHECKS IT.

## 6.2 SECTION 2: WORST CASE NOISE TESTS.

THESE ARE INTENDED TO APPLY MAXIMUM STRESS TO THE VARIOUS TYPES OF PDP-11 MOS MEMORIES.

TEST 6 AND TEST 7 ARE SUPPLIED TO ALLOW THE OPERATOR TO SELECT A SINGLE WORD DATA PATTERN (SA=204) AND SCOPE ON EITHER THE WRITING (DATO) IN TEST 6 OR THE READING (DATI) IN TEST 7 OF THAT DATA.  
LOCATION .CONST:0 SHOULD BE CHANGED IF A DIFFERENT SINGLE WORD DATA PATTERN IS CONSIDERED.

TEST 10 WRITES AND THEN CHECKS A SERIES OF SINGLE WORD PATTERNS WHICH ARE DESIGNED TO STRESS PARITY MEMORY.

TEST 11 WRITES ALL MEMORY WITH 1'S IN EVERY BIT AND THEN "RIPPLES" A '0' THROUGH IT.

TEST 12 WRITES ALL MEMORY WITH 0'S IN EVERY BIT AND THEN "RIPPLES" A "1" THROUGH IT.

TEST 13 WRITES WRONG PARITY IN EACH BYTE OF MEMORY AND CHECKS THAT THE PARITY DETECTION LOGIC WORKS. THIS TEST IS SKIPPED FOR NON-PARITY MEMORY.

TEST 14 WRITE "RANDOM" PROGRAM CODE THROUGH MEMORY AND CHECKS IT.

## 6.3 SECTION 3: INSTRUCTION EXECUTION TESTS.

THIS GROUP OF TESTS PLACE INSTRUCTIONS IN THE MEMORY UNDER TEST, THEN EXECUTES THE INSTRUCTIONS, AND FINALLY, CHECKS

THAT THEY EXECUTED CORRECTLY.

SEQ 0010

TEST 15 EXECUTES AN INSTRUCTION WHICH DOES A DATI AND A DATO ON THE MEMORY UNDER TEST.

TEST 16 EXECUTES AN INSTRUCTION WHICH DOES A DATI AND A DATOB ON THE LOW BYTE OF MEMORY UNDER TEST.

TEST 17 EXECUTES AN INSTRUCTION WHICH DOES A DATI AND A DATOB ON THE HIGH BYTE.

TEST 20 EXECUTES AN INSTRUCTION WHICH DOES A DATIO AND A DATO.

TEST 21 EXECUTES AN INSTRUCTION WHICH DOES A DATIO AND A DATOB ON THE LOW BYTE.

TEST 22 EXECUTES AN INSTRUCTION WHICH DOES A DATIO AND A DATOB ON THE HIGH BYTE.

#### 6.4 SECTION 4: MOS TESTS

TEST 23 -WRITES A PATTERN OF 000377 THROUGH MEMORY, THEN COMPLEMENTS IT ADDRESSING DOWNWARD, COMPLEMENTS THE NEW PATTERN ADDRESSING UPWARD, COMPLEMENTS THE THIRD PATTERN ADDRESSING UPWARD AND FINALLY COMPLEMENTS THIS NEW AB PATTERNS ADDRESSING DOWNWARD.

TEST 24-25 WRITE A CHECKERBOARD THROUGH MEMORY THEN STALLS FOR 2 SECONDS AND THEN VERIFIES NO DATA HAS CHANGED.

#### 6.5 SPECIAL TOGGLE IN TESTS

##### 6.5.1 TOGGLE-IN-PROGRAM #1

THE FOLLOWING IS A TOGGLE IN MEMORY ADDRESS TEST. THIS TEST IS USEFUL WHEN AN ADDRESS SELECTION FAILURE IS SUSPECTED INVOLVING THE FIRST 8K OF MEMORY. THIS PROGRAM WRITES THE VALUE OF EACH ADDRESS INTO ITSELF STARTING WITH THE LOWER LIMIT (200) AND CONTINUING TO THE UPPER LIMIT. AFTER ALL ADDRESSES HAVE BEEN WRITTEN EACH ADDRESS IS CHECKED FOR THE CORRECT CONTENTS STARTING WITH THE UPPER LIMIT AND CONTINUING TO THE LOWER LIMIT.

LOCATION	CONTENTS	MNEMONIC	COMMENT
10	012700	MOV #200,R0	;GET FIRST ADDRESS
12	000200		;TO TEST ;(EXAMPLE START ADDRESS)
14	010001	MOV R0,R1	;SAVE IN R1
16	020037	1\$: CMP R0,@#SWR	;CHECK UPPER LIMIT ;(IN SOFTWARE SWITCH REGISTER)
20	000176		
22	001403	BEQ 2\$	;BRANCH IF AT UPPER LIMIT
24	010010	MOV R0,(R0)	;LOAD VALUE INTO ADDRESS
26	005720	TST (R0)+	;STEP TO NEXT ADDRESS
30	000772	BR 1\$	;LOOP UNTIL DONE
32	010004	2\$: MOV R0,R4	;SAVE UPPER LIMIT
34	020001	3\$: CMP R0,R1	;CHECK IF AT LOWER LIMIT

```

* 36 001767 BEQ 1$ ;BRANCH IF DONE
40 024000 CMP -(R0),R0 ;CHECK DATA WRITTEN
42 001774 BEQ 3$ ;BRANCH IF OK
44 000000 HALT ;ERROR
46 000772 BR 3$ ;LOOP BACK

```

SEQ 0011

### 6.5.2 TOGGLE-IN-PROGRAM #2

THE FOLLOWING IS ALSO A TOGGLE IN PROGRAM TO BE USED WITH TOGGLE-IN-PROGRAM #1 FOR MORE COMPLETE ADDRESS TESTING. THIS PROGRAM WRITES THE COMPLEMENT VALUE OF EACH ADDRESS INTO ITSELF STARTING WITH THE UPPER LIMIT AND CONTINUING TO THE LOWER LIMIT. AFTER ALL ADDRESSES HAVE BEEN WRITTEN EACH ADDRESS IS CHECKED FOR THE CORRECT CONTENTS STARTING WITH THE LOWER LIMIT ADDRESS AND CONTINUING TO THE UPPER LIMIT. TOGGLE IN THE FOLLOWING PATCHES TO THE PROGRAM ABOVE.

THIS IS THE PATCH TO TOGGLE-IN-PROGRAM #1:

```

LOCATION CONTENTS      MNEMONIC  COMMENT
36      001404      BEQ 4$    ;BRANCH TO PROGRAM #2

```

THESE ARE THE ADDITIONS TO TOGGLE-IN-PROGRAM #1:

```

LOCATION  CONTENTS      MNEMONIC  COMMENT
50      010402      4$: MOV R4,R2 ;GET UPPER LIMIT
52      005142      5$: COM -(R2) ;COMPLEMENT ADDRESS
54      020201      CMP R2,R1  ;CHECK IF AT LOWER LIMIT
56      001375      BNE 5$     ;LOOP UNTIL DONE
60      020204      6$: CMP R2,R4 ;CHECK IF AT UPPER LIMIT
62      001755      BEQ 1$     ;GO TO PROGRAM 1 IF DONE
64      010203      MOV R2,R3  ;GET VALUE OF ADDRESS
66      005103      COM R3     ;COMPLEMENT VALUE
70      020322      CMP R3,(R2)+ ;CHECK ADDRESS
72      001772      BEQ 6$     ;BRANCH IF OK
74      000000      HALT      ;ERROR
76      000770      BR 6$     ;GO CHECK NEXT ADDRESS

```

7.0 PROGRAM LISTING  
ATTACHED

```

.TITLE CVMSAB 0-2 MEGAWORD MEMORY EXERCISER, 16K VER
;*COPYRIGHT (C) 1985
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY SAM/BARRY BILL
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C7), JUL, 1982.
;*

```

```

637 .SBTTL OPERATIONAL SWITCH SETTINGS
;*
;* SWITCH USE
;* -----
;* 15 HALT ON ERROR
;* 14 LOOP ON TEST
;* 13 INHIBIT ERROR TYPEOUTS
;* 12 INHIBIT KT11 (AT START TIME ONLY)
;* 11 INHIBIT ITERATIONS
;* 10 BELL ON ERROR
;* 9 LOOP ON ERROR
638 .* 8 LOOP ON TEST IN SWR<4:0>
;* 7 INHIBIT PROGRAM RELOCATION
639 .* 6 INHIBIT PARITY ERROR DETECTION
;* 5 INHIBIT EXERCISING VECTOR AREA.

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100 STACK= 1100
104000 ERROR= EMT ;;BASIC DEFINITION OF ERROR CALL
000004 SCOPE= IOT ;;BASIC DEFINITION OF SCOPE CALL
;*MISCELLANEOUS DEFINITIONS
000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
000012 LF= 12 ;;CODE FOR LINE FEED
000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776 PS= 177776 ;;PROCESSOR STATUS WORD
177776 PSW= PS
177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
;*GENERAL PURPOSE REGISTER DEFINITIONS
000000 R0= *0 ;;GENERAL REGISTER
000001 R1= *1 ;;GENERAL REGISTER
000002 R2= *2 ;;GENERAL REGISTER
000003 R3= *3 ;;GENERAL REGISTER
000004 R4= *4 ;;GENERAL REGISTER
000005 R5= *5 ;;GENERAL REGISTER
000006 R6= *6 ;;GENERAL REGISTER
000007 R7= *7 ;;GENERAL REGISTER
000006 SP= *6 ;;STACK POINTER
000007 PC= *7 ;;PROGRAM COUNTER
;*PRIORITY LEVEL DEFINITIONS
000000 PR0= 0 ;;PRIORITY LEVEL 0
000040 PR1= 40 ;;PRIORITY LEVEL 1
000100 PR2= 100 ;;PRIORITY LEVEL 2
000140 PR3= 140 ;;PRIORITY LEVEL 3

```

N1

BASIC DEFINITIONS

SEQ 0013

```

000200 PR4= 200 ;;PRIORITY LEVEL 4
000240 PR5= 240 ;;PRIORITY LEVEL 5
000300 PR6= 300 ;;PRIORITY LEVEL 6
000340 PR7= 340 ;;PRIORITY LEVEL 7
;* "SWITCH REGISTER" SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
001000 SW9= SW09
000400 SW8= SW08
000200 SW7= SW07
000100 SW6= SW06
000040 SW5= SW05
000020 SW4= SW04
000010 SW3= SW03
000004 SW2= SW02
000002 SW1= SW01
000001 SW0= SW00
;* DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
001000 BIT9= BIT09
000400 BIT8= BIT08
000200 BIT7= BIT07
000100 BIT6= BIT06
000040 BIT5= BIT05
000020 BIT4= BIT04
000010 BIT3= BIT03
000004 BIT2= BIT02
000002 BIT1= BIT01

```

```

000001      BIT0= BIT00
              ;*BASIC "CPU" TRAP VECTOR ADDRESSES
000004      ERRVEC= 4          ;; TIME OUT AND OTHER ERRORS
000010      RESVEC= 10         ;; RESERVED AND ILLEGAL INSTRUCTIONS
000014      TBITVEC= 14        ;; "T" BIT
000014      TRTVEC= 14         ;; TRACE TRAP
000014      BPTVEC= 14         ;; BREAKPOINT TRAP (BPT)
000020      IOTVEC= 20         ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024      PWRVEC= 24         ;; POWER FAIL
000030      EMTVEC= 30         ;; EMULATOR TRAP (EMT) **ERROR**
000034      TRAPVEC= 34        ;; "TRAP" TRAP
000060      TKVEC= 60          ;; TTY KEYBOARD VECTOR
000064      TPVEC= 64          ;; TTY PRINTER VECTOR
000240      PIRQVEC= 240       ;; PROGRAM INTERRUPT REQUEST VECTOR

640
641
642
              .SBTTL MEMORY MANAGEMENT DEFINITIONS
              ;*KT11 VECTOR ADDRESS
000250      MMVEC= 250
              ;*KT11 STATUS REGISTER ADDRESSES
177572      SR0= 177572
177574      SR1= 177574
177576      SR2= 177576
172516      SR3= 172516
              ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300      KIPDR0= 172300
172302      KIPDR1= 172302
172304      KIPDR2= 172304
172306      KIPDR3= 172306
172310      KIPDR4= 172310
172312      KIPDR5= 172312
172314      KIPDR6= 172314
172316      KIPDR7= 172316
              ;*KERNEL "I" PAGE ADDRESS REGISTERS
172340      KIPAR0= 172340
172342      KIPAR1= 172342
172344      KIPAR2= 172344
172346      KIPAR3= 172346
172350      KIPAR4= 172350
172352      KIPAR5= 172352
172354      KIPAR6= 172354
172356      KIPAR7= 172356
643      000000      UP = 0          ;CODE FOR UPWARDS MAP IN MEM MGMT PDR'S
644      000006      RW = 6          ;CODE FOR READ/WRITE IN MEM MGMT PDR S
645
646
647      000001      ;* PARITY MEMORY DEFINITIONS.
648      000114      AE=1          ;PARITY ACTION ENABLE
649
650
651      017777      ;* MISCELLANEOUS ASSIGNMENTS
652      037777      MASK4K= 17777 ;MASK FOR 4K ADDRESS BANK BOUNDARY.
653      000007      MASK8K= 37777 ;MASK FOR 8K ADDRESS BANK BOUNDARY
654
655      MFPT= 7          ;MOVE FROM PROCESSOR TYPE TO RO
657
              .SBTTL TRAP CATCHER
              .-0
  
```

```

; *ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT'
; *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
; *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
                                .=174
000174 000174 000000  DISPREG: .WORD 0                ;; SOFTWARE DISPLAY REGISTER
000176 000000  SWREG: .WORD 0                ;; SOFTWARE SWITCH REGISTER
                                .SBTTL STARTING ADDRESS(ES)
658 000200 000137 003744  JMP @#START ;; JUMP TO STARTING ADDRESS OF PROGRAM
659 000204 000167 000070  JMP RESTAR  ;; RESTART ADDRESS, USING PREVIOUS PARAMETERS.
660                                     .=ERRVEC
661 000004 023430  .WORD ERRTRP
662 000006 000000  .WORD 0
663
664 .SBTTL ACT11 HOOKS
; *****
; HOOKS REQUIRED BY ACT11
                                $SVPC=.                ;SAVE PC
                                .=46
000046 012722  $ENDAD                ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
                                .=52
000052 040000  .WORD BIT14           ;;2)SET LOC.52 TO BIT14
                                .=$SVPC                 ;; RESTORE PC
  
```



```

666      000100 000100      . =100
667      000100 000104 000340 000002 .WORD 104,340,2      ;IF BEVENT IS ENABLED
668
669
670      000300      . =300
671      ;*****
672      ;* THE FOLLOWING ROUTINES ARE LOCATED IN THE VECTOR AREA (0-1000) SO THAT
673      ;* THEY CAN BE PROTECTED BY SELECTING SW05 (SEE DOCUMENT FOR USE OF SW05).
674      ;*****
675      000300 005005      RESTAR: CLR      R5      ;CLEAR FLAG TO INDICATE RESTART.
676      000302 000401      BR      REST1      ;GO RESTORE PROGRAM BEFORE RESTARTING.
677      000304 010705      RESTOR: MOV      PC,      R5      ;PUT DATA INTO FLAG FOR RESTORE.
678      000306 012706 001070 REST1: MOV      #$CMTAG,SP ;SET UP THE STACK POINTER.
679      000312 005767 000216      TST      PRGMAP      ;CHECK IF THE MEMORY HAS BEEN MAPPED.
680      000316 001002      BNE      REST2      ;BR IF MEMORY MAPPED.
681      000320 000167 003434      JMP      STARTA      ;GO START, IF NOT MAPPED
682      000324 005767 000206      REST2: TST      MMAVA      ;CHECK IF MEM MGMT AVAILABLE.
683      000330 001454      BEQ      10$      ;BR IF NO MEM MGMT.
684      000332 032737 000001 177572 BIT      #BIT0, @#SRO ;CHECK IF MEM MGMT ACTIVE.
685      000340 001027      BNE      2$      ;BR IF MEM MGMT ALREADY SET UP.
686      000342 012700 172300      MOV      #KIPDR0,R0 ;POINT TO FIRST MEM MGMT DDATA REG.
687      000346 012701 000010      MOV      #8,      R1      ;SET UP COUNTER.
688      000352 012720 077406      1$: MOV      #077406,(R0)+ ;MAP FIRST 28K 1-FOR 1.
689      000356 005301      DEC      R1      ;COUNT REGISTERS.
690      000360 001374      BNE      1$      ;BR IF MORE REG.
691      000362 012700 172340      MOV      #KIPAR0,R0 ;POINT TO FIRST MEM MGMT ADDRESS REG.
692      000366 005020      CLR      (R0)+      ;PAR0 MAPPED INTO BANK0.
693      000370 012720 000200      MOV      #200, (R0)+ ;PAR1 MAPPED INTO BANK1.
694      000374 005020      CLR      (R0)+      ;PAR2 CLEARED
695      000376 005020      CLR      (R0)+      ;PAR3 CLEARED
696      000400 005020      CLR      (R0)+      ;PAR4 CLEARED
697      000402 005020      CLR      (R0)+      ;PAR5 CLEARED
698      000404 005020      CLR      (R0)+      ;PAR6 CLEARED
699      000406 012720 177600      MOV      #177600,(R0)+ ;PAR7 MAPPED INTO LAST BANK.
700      000412 012737 000001 177572 MOV      #BIT0, @#SRO ;ENABLE MEM MGMT.
701      000420 005000      CLR      R0      ;INIT TEMP PAR REG.
702      000422 016701 000106      MOV      PRGMAP, R1 ;GET THE PROGRAM MAP...LO 64K.
703      000426 006201      3$: ASR      R1      ;SHIFT THE MAP POINTER.
704      000430 103403      BCS      4$      ;BR WHEN FIRST 8K BANK FOUND.
705      000432 062700 000400      ADD      #400, R0 ;UPDATE TMP PAR TO NEXT 8K BANK.
706      000436 000773      BR      3$      ;NEXT 8K BANK
707      000440 010037 172340      4$: MOV      R0, @#KIPAR0 ;PUT TEMP PAR INTO FIRST PAR.
708      000444 000137 000450      JMP      @#5$      ;JUMP INTO PROGRAM IF NOT THERE ALREADY.
709      000450 062700 000200      5$: ADD      #200, R0 ;KEEP UPDATING TEMP PAR REG.
710      000454 010037 172342      MOV      R0, @#KIPAR1 ;SET UP SECOND PROGRAM BANK POINTER.
711      000460 000410      BR      20$      ;BR TO RELOCATE SECTION.
712      000462 016700 000044      10$: MOV      RELOCF, R0 ;GET RELOCATION FACTOR.
713      000466 062700 001070      ADD      #$CMTAG,R0 ;SET UP STACK POINTER.
714      000472 010006      MOV      R0, SP ;SET STACK TO RELOCATE PROGRAM.
715      000474 062700 177412      ADD      #20$-$CMTAG,R0 ;ADJUST R0 TO RELOCATED "20$" ADDRESS.
716      000500 000110      JMP      (R0) ;GO TO "20$" (RELOCATED).
717      000502 022767 000001 000024 20$: CMP      #1, PRGMAP ;CHECK IF PROGRAM IS IN 8K BANK 0.
718      000510 001402      BEQ      21$      ;BR IF IN 8K BANK 0.
719      000512 004767 014546      JSR      PC, RELO ;RELOCATE THE PROGRAM BACK TO BANK 0.
720      000516 005067 000436      21$: CLR      $TIMES ;CLEAN UP BEFORE STARTING.
721      000522 105067 000344      CLRB   $TSTNM
722      000526 000167 006254      JMP      START1 ;RESTART WITH PREVIOUSLY SELECTED PARAMETERS.

```

E2

723  
724  
725  
726  
727  
728  
729  
730  
731

000532 000000  
000534 000000  
000536 000000

;\* THE FOLLOWING LOCATIONS ARE USED BY THE ABOVE ROUTINE AND MUST BE LOCATED  
;\* BELOW 1000 TO INSURE CORRECT OPERATION UNDER THE WIDEST VARIETY OF  
;\* CIRCUMSTANCES.  
RELOCF: .WORD 0 ;CONTAINS RELOCATION FACTOR (NO MEM MGMT)  
PRGMAP: .WORD 0 ;PROGRAM MAP WHERE THE PROGRAM IS LOCATED  
MMAVA: .WORD 0 ;MEMORY MANAGEMENT AVAIL ABLE FLAG.  
;BIT 0 = 1 MMU AVAILABLE  
;BIT 15 = 1 22 BIT ADDRESSING AVAILABLE

733

```

.SBTTL POWER DOWN AND UP ROUTINES
;*****
;POWER DOWN ROUTINE
000540 012737 000706 000024 $PWRDN: MOV    #ILLUP,@PWRVEC ;;SET FOR FAST UP
000546 012737 000340 000026      MOV    #340,@PWRVEC+2 ;;PRIO:7
000554 010046      MOV    R0,-(SP) ;;PUSH R0 ON STACK
000556 010146      MOV    R1,(SP)  ;;PUSH R1 ON STACK
000560 010246      MOV    R2,(SP)  ;;PUSH R2 ON STACK
000562 010346      MOV    R3,(SP)  ;;PUSH R3 ON STACK
000564 010446      MOV    R4,-(SP) ;;PUSH R4 ON STACK
000566 010546      MOV    R5,-(SP) ;;PUSH R5 ON STACK
000570 017746 000334      MOV    @SWR,-(SP) ;;PUSH @SWR ON STACK
000574 010667 000112      MOV    SP,$SAVR6 ;;SAVE SP
000600 012737 000612 000024      MOV    #PWRUP,@PWRVEC ;;SET UP VECTOR
000606 000000      HALT
000610 000776      BR     .-2 ;;HANG UP
;*****
;POWER UP ROUTINE
000612 012737 000706 000024 $PWRUP: MOV    #ILLUP,@PWRVEC ;;SET FOR FAST DOWN
000620 016706 000066      MOV    $SAVR6,SP ;;GET SP
000624 005067 000062      CLR    $SAVR6 ;;WAIT LOOP FOR THE TTY
000630 005267 000056 1$: INC    $SAVR6 ;;WAIT FOR THE INC
000634 001375      BNE    1$ ;;OF WORD
000636 012677 000266      MOV    (SP)+,@SWR ;;POP STACK INTO @SWR
000642 012605      MOV    (SP)+,R5 ;;POP STACK INTO R5
000644 012604      MOV    (SP)+,R4 ;;POP STACK INTO R4
000646 012603      MOV    (SP)+,R3 ;;POP STACK INTO R3
000650 012602      MOV    (SP)+,R2 ;;POP STACK INTO R2
000652 012601      MOV    (SP)+,R1 ;;POP STACK INTO R1
000654 012600      MOV    (SP)+,R0 ;;POP STACK INTO R0
000656 012737 000540 000024      MOV    #PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
000664 012737 000340 000026      MOV    #340,@PWRVEC+2 ;;PRIO:7
000672 004567 021054      JSR    R5,$PRINT ;;GO PRINT OUT THE FOLLOWING MESSAGE.
000676 024137 $PWRMG: .WORD PWRMSG ;;POWER FAIL MESSAGE POINTER
000700 012716      MOV    (PC)+,(SP) ;;RESTART AT RESTART
000702 000300 $PWRAD: .WORD RESTART ;;RESTART ADDRESS
000704 000002      RTI
000706 000000 $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
000710 000776      BR     .-2 ;;BEFORE THE POWER DOWN WAS COMPLETE
000712 000000 $SAVR6: 0 ;;PUT THE SP HERE
    
```

1231

```
.SBTTL COMMON TAGS
;*****
;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;USED IN THE PROGRAM.
.=1070
001070 001070 $CMTAG: .WORD 0 ;; START OF COMMON TAGS
001070 000000 $TSTNM: .BYTE 0 ;; CONTAINS THE TEST NUMBER
001072 000 $ERFLG: .BYTE 0 ;; CONTAINS ERROR FLAG
001073 000 $ICNT: .WORD 0 ;; CONTAINS SUBTEST ITERATION COUNT
001074 000000 $LPADR: .WORD 0 ;; CONTAINS SCOPE LOOP ADDRESS
001076 000000 $LPERR: .WORD 0 ;; CONTAINS SCOPE RETURN FOR ERRORS
001100 000000 $ERTTL: .WORD 0 ;; CONTAINS TOTAL ERRORS DETECTED
001102 000000 $ITEMB: .BYTE 0 ;; CONTAINS ITEM CONTROL BYTE
001104 000 $ERMAX: .BYTE 1 ;; CONTAINS MAX. ERRORS PER TEST
001105 001 $ERRPC: .WORD 0 ;; CONTAINS PC OF LAST ERROR INSTRUCTION
001106 000000 $GDADR: .WORD 0 ;; CONTAINS ADDRESS OF 'GOOD' DATA
001110 000000 $BDADR: .WORD 0 ;; CONTAINS ADDRESS OF 'BAD' DATA
001112 000000 $GDDAT: .WORD 0 ;; CONTAINS 'GOOD' DATA
001114 000000 $BDDAT: .WORD 0 ;; CONTAINS 'BAD' DATA
001116 000000 .WORD 0 ;; RESERVED--NOT TO BE USED
001120 000000 .WORD 0
001122 000000 .WORD 0
001124 000 $AUTOB: .BYTE 0 ;; AUTOMATIC MODE INDICATOR
001125 000 $INTAG: .BYTE 0 ;; INTERRUPT MODE INDICATOR
001126 000000 .WORD 0
001130 177570 SWR: .WORD DSWR ;; ADDRESS OF SWITCH REGISTER
001132 177570 DISPLAY: .WORD DDISP ;; ADDRESS OF DISPLAY REGISTER
001134 177560 $TKS: 177560 ;; TTY KBD STATUS
001136 177562 $TKB: 177562 ;; TTY KBD BUFFER
001140 177564 $TPS: 177564 ;; TTY PRINTER STATUS REG. ADDRESS
001142 177566 $TPB: 177566 ;; TTY PRINTER BUFFER REG. ADDRESS
001144 000 $NULL: .BYTE 0 ;; CONTAINS NULL CHARACTER FOR FILLS
001145 002 $FILLS: .BYTE 2 ;; CONTAINS # OF FILLER CHARACTERS REQUIRED
001146 012 $FILLC: .BYTE 12 ;; INSERT FILL CHARS. AFTER A "LINE FEED"
001147 000 $TPFLG: .BYTE 0 ;; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
001150 000004 .REPT 4
001152 000000 $TMP0: .WORD 0 ;; USER DEFINED
001154 000000 $TMP1: .WORD 0 ;; USER DEFINED
001156 000000 $TMP2: .WORD 0 ;; USER DEFINED
001160 000000 $TMP3: .WORD 0 ;; USER DEFINED
001162 000000 $TIMES: 0 ;; MAX. NUMBER OF ITERATIONS
001164 207 377 377 $ESCAPE: 0 ;; ESCAPE ON ERROR ADDRESS
001167 000 $BELL: .ASCIZ <207><377><377> ;; CODE FOR BELL
001170 077 $QUES: .ASCII /?/ ;; QUESTION MARK
001171 015 $CRLF: .ASCII <15> ;; CARRIAGE RETURN
001172 012 000 $LF: .ASCIZ <12> ;; LINE FEED
;*****
.SBTTL APT MAILBOX-ETABLE
;*****
.EVEN
001174 $MAIL: ;; APT MAILBOX
001174 000000 $MSGTY: .WORD AMSGTY ;; MESSAGE TYPE CODE
001176 000000 $FATAL: .WORD AFATAL ;; FATAL ERROR NUMBER
001200 000000 $TESTN: .WORD ATESTN ;; TEST NUMBER
001202 000000 $PASS: .WORD APASS ;; PASS COUNT
001204 000000 $DEVCT: .WORD ADEVCT ;; DEVICE COUNT
```

```

001206 000000 $UNIT: .WORD AUNIT ;; I/O UNIT NUMBER
001210 000000 $MSGAD: .WORD AMSGAD ;; MESSAGE ADDRESS
001212 000000 $MSGLG: .WORD AMSGLG ;; MESSAGE LENGTH
001214 $ETABLE: ;; APT ENVIRONMENT TABLE
001214 000 $ENV: .BYTE AENV ;; ENVIRONMENT BYTE
001215 000 $ENVM: .BYTE AENVM ;; ENVIRONMENT MODE BITS
001216 000000 $SWREG: .WORD ASWREG ;; APT SWITCH REGISTER
001220 000000 $USWR: .WORD AUSWR ;; USER SWITCHES
001222 000000 $CPUCP: .WORD ACPUOP ;; CPU TYPE, OPTIONS
; * BITS 15-11=CPU TYPE
; * 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
; * 11/70=06,PDQ=07,Q=10
; * BIT 10=REAL TIME CLOCK
; * BIT 9=FLOATING POINT PROCESSOR
; * BIT 8=MEMORY MANAGEMENT
001224 000 $MAMS1: .BYTE AMAMS1 ;; HIGH ADDRESS, M.S. BYTE
001225 000 $MTYP1: .BYTE AMTYP1 ;; MEM. TYPE, BLK#1
; * MEM. TYPE BYTE -- (HIGH BYTE)
; * 900 NSEC CORE=001
; * 300 NSEC BIPOLAR=002
; * 500 NSEC MOS=003
001226 000000 $MADR1: .WORD AMADR1 ;; HIGH ADDRESS, BLK#1
; * MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
001230 000 $MAMS2: .BYTE AMAMS2 ;; HIGH ADDRESS, M.S. BYTE
001231 000 $MTYP2: .BYTE AMTYP2 ;; MEM. TYPE, BLK#2
001232 000000 $MADR2: .WORD AMADR2 ;; MEM. LAST ADDRESS, BLK#2
001234 000 $MAMS3: .BYTE AMAMS3 ;; HIGH ADDRESS, M.S. BYTE
001235 000 $MTYP3: .BYTE AMTYP3 ;; MEM. TYPE, BLK#3
001236 000000 $MADR3: .WORD AMADR3 ;; MEM. LAST ADDRESS, BLK#3
001240 000 $MAMS4: .BYTE AMAMS4 ;; HIGH ADDRESS, M.S. BYTE
001241 000 $MTYP4: .BYTE AMTYP4 ;; MEM. TYPE, BLK#4
001242 000000 $MADR4: .WORD AMADR4 ;; MEM. LAST ADDRESS, BLK#4
001244 000000 $VECT1: .WORD AVECT1 ;; INTERRUPT VECTOR#1, BUS PRIORITY#1
001246 000000 $VECT2: .WORD AVECT2 ;; INTERRUPT VECTOR#2, BUS PRIORITY#2
001250 000000 $BASE: .WORD ABASE ;; BASE ADDRESS OF EQUIPMENT UNDER TEST
001252 000000 $DEVM: .WORD ADEVM ;; DEVICE MAP
001254 000000 $CDW1: .WORD ACDW1 ;; CONTROLLER DESCRIPTION WORD#1
001256 000000 $CDW2: .WORD ACDW2 ;; CONTROLLER DESCRIPTION WORD#2
001260 000000 $DDW0: .WORD ADDW0 ;; DEVICE DESCRIPTOR WORD#0
001262 000000 $DDW1: .WORD ADDW1 ;; DEVICE DESCRIPTOR WORD#1
001264 000000 $DDW2: .WORD ADDW2 ;; DEVICE DESCRIPTOR WORD#2
001266 000000 $DDW3: .WORD ADDW3 ;; DEVICE DESCRIPTOR WORD#3
001270 000000 $DDW4: .WORD ADDW4 ;; DEVICE DESCRIPTOR WORD#4
001272 000000 $DDW5: .WORD ADDW5 ;; DEVICE DESCRIPTOR WORD#5
001274 000000 $DDW6: .WORD ADDW6 ;; DEVICE DESCRIPTOR WORD#6
001276 000000 $DDW7: .WORD ADDW7 ;; DEVICE DESCRIPTOR WORD#7
001300 000000 $DDW8: .WORD ADDW8 ;; DEVICE DESCRIPTOR WORD#8
001302 000000 $DDW9: .WORD ADDW9 ;; DEVICE DESCRIPTOR WORD#9
001304 000000 $DDW10: .WORD ADDW10 ;; DEVICE DESCRIPTOR WORD#10
001306 000000 $DDW11: .WORD ADDW11 ;; DEVICE DESCRIPTOR WORD#11
001310 000000 $DDW12: .WORD ADDW12 ;; DEVICE DESCRIPTOR WORD#12
001312 000000 $DDW13: .WORD ADDW13 ;; DEVICE DESCRIPTOR WORD#13
001314 000000 $DDW14: .WORD ADDW14 ;; DEVICE DESCRIPTOR WORD#14
001316 000000 $DDW15: .WORD ADDW15 ;; DEVICE DESCRIPTOR WORD#15
001320 $ETEND:
; MEXIT
; SBTTL APT PARAMETER BLOCK
    
```

```

;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
;*****
000024 001320 . $X= . ;:SAVE CURRENT LOCATION
000044 000024 . =24 ;:SET POWER FAIL TO POINT TO START OF PROGRAM
000044 000200 200 ;:FOR APT START UP
000044 000044 . =44 ;:POINT TO APT INDIRECT ADDRESS PNTR.
000044 001320 $APTHDR ;:POINT TO APT HEADER BLOCK
000044 001320 . = $X ;:RESET LOCATION COUNTER
;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.
001320 $APTHD:
001320 000000 $HIBTS: .WORD 0 ;:TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
001322 001174 $MBADR: .WORD $MAIL ;:ADDRESS OF APT MAILBOX (BITS 0-15)
001324 001604 $TSTM: .WORD 900. ;:RUN TIM OF LONGEST TEST
001326 002260 $PASTM: .WORD 1200. ;:RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
001330 000000 $UNITM: .WORD 0. ;:ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
001332 000052 .WORD $ETEND-$MAIL/2 ;:LENGTH MAILBOX-ETABLE(WORDS)
.SBTTL APT STATISTICS TABLE
;*****
001334 $ASTAT:
001334 000031 .REPT 31
001334 177777 .WORD -1,0
001340 177777 .WORD -1,0
001344 177777 .WORD -1,0
001350 177777 .WORD -1,0
001354 177777 .WORD -1,0
001360 177777 .WORD 1,0
001364 177777 .WORD -1,0
001370 177777 .WORD -1,0
001374 177777 .WORD -1,0
001400 177777 .WORD -1,0
001404 177777 .WORD -1,0
001410 177777 .WORD 1,0
001414 177777 .WORD -1,0
001420 177777 .WORD -1,0
001424 177777 .WORD -1,0
001430 177777 .WORD -1,0
001434 177777 .WORD -1,0
001440 177777 .WORD -1,0
001444 177777 .WORD -1,0
001450 177777 .WORD -1,0
001454 177777 .WORD -1,0
001460 177777 .WORD -1,0
001464 177777 .WORD -1,0
001470 177777 .WORD -1,0
001474 177777 .WORD -1,0
001500 177777 .WORD -1,0
001502 001334 $ASTEND: -1
$APTR: $ASTAT
;*****
;*THE FOLLOWING TAGS ARE USER DEFINED
;*****
001504 000000 $VERPC: .WORD 0 ;:VIRTUAL PC LOCATION FOR ERROR TYPEOUT ROUTINE ($ERTYP).
001506 070032 RESRVD: .WORD 070032 ;:CORE PARITY REG BITS RESERVED FOR FUTURE USE.
;NOTE: FOR MS11 MEMORY WITH PARITY, CHANGE TO 077772.

```

```

001510 000000      LMAD: .WORD 0      ;LAST CONTIGUOUS MEMORY ADDRESS (+2)
001512 000000      LDDISP: .WORD 0     ;CONTAINS DISPLAY REGISTER IMAGE

001514              MEMMAP:          ;MEMORY MAP - EACH BIT CORRESPONDS TO 8K

001514 000000      .WORD 0          ;1ST WORD MAP...128KW
001516 000000      .WORD 0          ;2ND WORD MAP...256KW
001520 000000      .WORD 0          ;3RD WORD MAP...384KW
001522 000000      .WORD 0          ;4TH WORD MAP...512KW
001524 000000      .WORD 0          ;5TH WORD MAP...640KW
001526 000000      .WORD 0          ;6TH WORD MAP...768KW
001530 000000      .WORD 0          ;7TH WORD MAP...896KW
001532 000000      .WORD 0          ;8TH WORD MAP...1024KW
001534 000000      .WORD 0          ;9TH WORD MAP...1152KW
001536 000000      .WORD 0          ;10TH WORD MAP...1280KW
001540 000000      .WORD 0          ;11TH WORD MAP...1408KW
001542 000000      .WORD 0          ;12TH WORD MAP...1536KW
001544 000000      .WORD 0          ;13TH WORD MAP...1664KW
001546 000000      .WORD 0          ;14TH WORD MAP...1792KW
001550 000000      .WORD 0          ;15TH WORD MAP...1920KW
001552 000000      .WORD 0          ;16TH WORD MAP...2048KW

001554              TSTMAP:         ;TEST MAP - WHICH BANKS ARE SELECTED FOR TEST.

001554 000000      .WORD 0          ;1ST WORD MAP...128KW
001556 000000      .WORD 0          ;2ND WORD MAP...256KW
001560 000000      .WORD 0          ;3RD WORD MAP...384KW
001562 000000      .WORD 0          ;4TH WORD MAP...512KW
001564 000000      .WORD 0          ;5TH WORD MAP...640KW
001566 000000      .WORD 0          ;6TH WORD MAP...768KW
001570 000000      .WORD 0          ;7TH WORD MAP...896KW
001572 000000      .WORD 0          ;8TH WORD MAP...1024KW
001574 000000      .WORD 0          ;9TH WORD MAP...1152KW
001576 000000      .WORD 0          ;10TH WORD MAP...1280KW
001600 000000      .WORD 0          ;11TH WORD MAP...1408KW
001602 000000      .WORD 0          ;12TH WORD MAP...1536KW
001604 000000      .WORD 0          ;13TH WORD MAP...1664KW
001606 000000      .WORD 0          ;14TH WORD MAP...1792KW
001610 000000      .WORD 0          ;15TH WORD MAP...1920KW
001612 000000      .WORD 0          ;16TH WORD MAP...2048KW

001614              SAVTST:         ;SAVED TEST MAP - USED DURING FIRST PASS TO ONLY
                                ; TEST EACH BANK ONCE.

001614 000000      .WORD 0          ;1ST WORD MAP...128KW
001616 000000      .WORD 0          ;2ND WORD MAP...256KW
001620 000000      .WORD 0          ;3RD WORD MAP...384KW
001622 000000      .WORD 0          ;4TH WORD MAP...512KW
001624 000000      .WORD 0          ;5TH WORD MAP...640KW
001626 000000      .WORD 0          ;6TH WORD MAP...768KW
001630 000000      .WORD 0          ;7TH WORD MAP...896KW
001632 000000      .WORD 0          ;8TH WORD MAP...1024KW
001634 000000      .WORD 0          ;9TH WORD MAP...1152KW
001636 000000      .WORD 0          ;10TH WORD MAP...1280KW
001640 000000      .WORD 0          ;11TH WORD MAP...1408KW
001642 000000      .WORD 0          ;12TH WORD MAP...1536KW
001644 000000      .WORD 0          ;13TH WORD MAP...1664KW
  
```

APT STATISTICS TABLE

SEQ 0023

001646	000000	.WORD	0	;14TH WORD MAP..1792KW
001650	000000	.WORD	0	;15TH WORD MAP..1920KW
001652	000000	.WORD	0	;16TH WORD MAP..2048KW
001654		PMEMAP:		;PARITY MAP - WHICH BANKS HAVE MEMORY PARITY
001654	000000	.WORD	0	;1ST WORD MAP...128KW
001656	000000	.WORD	0	;2ND WORD MAP...256KW
001660	000000	.WORD	0	;3RD WORD MAP...384KW
001662	000000	.WORD	0	;4TH WORD MAP...512KW
001664	000000	.WORD	0	;5TH WORD MAP...640KW
001666	000000	.WORD	0	;6TH WORD MAP...768KW
001670	000000	.WORD	0	;7TH WORD MAP...896KW
001672	000000	.WORD	0	;8TH WORD MAP...1024KW
001674	000000	.WORD	0	;9TH WORD MAP...1152KW
001676	000000	.WORD	0	;10TH WORD MAP...1280KW
001700	000000	.WORD	0	;11TH WORD MAP...1408KW
001702	000000	.WORD	0	;12TH WORD MAP...1536KW
001704	000000	.WORD	0	;13TH WORD MAP...1664KW
001706	000000	.WORD	0	;14TH WORD MAP...1792KW
001710	000000	.WORD	0	;15TH WORD MAP...1920KW
001712	000000	.WORD	0	;16TH WORD MAP...2048KW
001714		BITPT:		;POINTER TO CURRENT 8K BANK OF MEMORY
001714	000000	.WORD	0	;1ST WORD MAP...128KW
001716	000000	.WORD	0	;2ND WORD MAP...256KW
001720	000000	.WORD	0	;3RD WORD MAP...384KW
001722	000000	.WORD	0	;4TH WORD MAP...512KW
001724	000000	.WORD	0	;5TH WORD MAP...640KW
001726	000000	.WORD	0	;6TH WORD MAP...768KW
001730	000000	.WORD	0	;7TH WORD MAP...896KW
001732	000000	.WORD	0	;8TH WORD MAP...1024KW
001734	000000	.WORD	0	;9TH WORD MAP...1152KW
001736	000000	.WORD	0	;10TH WORD MAP...1280KW
001740	000000	.WORD	0	;11TH WORD MAP...1408KW
001742	000000	.WORD	0	;12TH WORD MAP...1536KW
001744	000000	.WORD	0	;13TH WORD MAP...1664KW
001746	000000	.WORD	0	;14TH WORD MAP...1792KW
001750	000000	.WORD	0	;15TH WORD MAP...1920KW
001752	000000	.WORD	0	;16TH WORD MAP...2048KW
001754	000000	MMORE: .WORD	0	;LOOP ADDRESS FOR MULTIPLE BLOCK TESTING. ;SET UP BY "INITMM" AND "INITDN" ROUTINES. ;USED BY "MMUP" AND "MMDOWN" ROUTINES.
001756	000	SELFLG: .BYTE	0	;OPERATOR SELECTED PARAMETERS FLAG. (SA=204)
001757	000	FLAG8K: .BYTE	0	;8K BLOCK INDICATOR. USED IN "INITMM" AND "MMUP"
001760	000	OEFLG: .BYTE	0	;ODD/EVEN FLAG USED IN PARITY MEMORY BYTE TEST.
001762	000000	FSTADR: .WORD	0	;FIRST VIRTUAL ADDRESS TO BE TESTED. ;FIRST ADDRESS IS USER SELECTABLE. ; TO BREAK TO "MMUP" TO FIND LAST ADDRESS.
001764	000000	.CONST: .WORD	0	;USER SELECTABLE CONSTANT DATA.
001766	000004	WWP: .WORD	4	;WRITE WRONG PARITY COMMAND
001770	000000	TEMP: .WORD	0	;TEMPORARY STORAGE



L2

001772	000000	TEMP1:	.WORD	0	;TEMPORARY STORAGE
001774	000000	FLG30K:	.WORD	0	;30K MEMORY FLAG
001776	000000	LSIFLG:	.WORD	0	;LSI-11 PROCESSOR FLAG
002000	000000	KDJDA:	.WORD	0	;VK KDJ11-DA (11/53) CPU FLAG
002002	000000	PLUS1:	.WORD	0	;DATA BIT USED FOR FIRST ENTRY INTO ;MMUP AND MMDOWN ROUTINES.

```

;*****
;* RELATIVE ADDRESSING TABLE.
;* THE FOLLOWING LOCATIONS ARE MODIFIED AT RELOCATION TIME TO ALLOW
;* RELATIVE ADDRESSING TO GET THE RELOCATED VALUE OF THE ARGUMENT TAGS.
;*****

```

002004		RADTAB:			
002004	001070	.STACK:	\$CMTAG		;STACK POINTER INITIAL ADDRESS.
002006	001514	.MEMMAP:		MEMMAP	;AUTO. MEMORY SIZING MAP
002010	001614	.SAVTST:		SAVTST	;SIZED MEMORY MAP FROM AUTO. OR USER
002012	001554	.TSTMAP:		TSTMAP	;MEMORY MAP OF 8K BANKS TO TEST
002014	001654	.PMEMAP:		PMEMAP	;PARITY MAP OF 8K BANKS
002016	001714	.BITPT:	BITPT		;BIT POINTER FOR BLOCK UNDER TEST
002020	001506	.RESRV:	RESRVD		;PARITY REGISTER RESERVED BIT MASK ADDRESS.
002022	002272	.MPRO:	MPRO		;MEMORY PARITY REGISTER TABLE ADDRESS.
002024	003372	.MPRX:	MPRX		;MEMORY PARITY REGISTER EXIST TABLE ADDRESS.
002026	010520	.PBTRP:	PBTRP		;PARITY BYTE TEST TRAP ROUTINE ADDRESS
002030	002244	.MPPAT:	MPPATS		;MEMORY PARITY PATTERN TABLE ADDRESS.
002032	015632	.PESRV:	PESRV		;MEMORY PARITY ERROR TRAP ROUTINE ADDRESS.
002034	003434	.ERRTB:	\$ERRTB		;ERROR TIMEOUT TABLE PONTER.
002036	000010	.EIGHT:	8		;DECIMAL TYPE ROUTINE COUNT DESIGNATOR.
002040	012506	.TST32:	TST32		;SCOPE ABORT ADR FOR WHEN NO MEM AVA FOR TEST.

```

;*****
;* DATA CONTAINERS FOR ERROR PRINTOUT.
;*****

```

002042	001106	001110	001114	DT1:	\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT,0
002050	001116	000000			
002054	001504	001106	001110	DT2:	\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT,0
002062	001114	001116	000000		
002070	001504	001106	001110	DT12:	\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,0
002076	001114	000000			
002102	001504	001106	001150	DT14:	\$VERPC,\$ERRPC,\$TMPO,\$GDADR,0
002110	001110	000000			
002114	001504	001106	001110	DT15:	\$VERPC,\$ERRPC,\$GDADR,\$TMPO,\$GDDAT,\$BDDAT,0
002122	001150	001114	001116		
002130	000000				
002132	001504	001106	001150	DT21:	\$VERPC,\$ERRPC,\$TMPO,\$GDADR,\$GDDAT,\$BDDAT,0
002140	001110	001114	001116		
002146	000000				
002150	001504	001106	001110	DT23:	\$VERPC,\$ERRPC,\$GDADR,\$BDADR,\$GDDAT,\$BDDAT,0
002156	001112	001114	001116		
002164	000000				
002166	001504	001106	001112	DT24:	\$VERPC,\$ERRPC,\$BDADR,0
002174	000000				
002176	001504	001106	001112	DT25:	\$VERPC,\$ERRPC,\$BDADR,\$TMPO,\$TMP1,0
002204	001150	001152	000000		
002212	001504	001106	001150	DT26:	\$VERPC,\$ERRPC,\$TMPO,\$TMP1,0
002220	001152	000000			
002224	001150	001152	001110	DT30:	\$TMPO,\$TMP1,\$GDADR,\$BDDAT,0
002232	001116	000000			
002236	001156	000000		DT31:	\$TMP3,0

002242 177777

.WORD 1 ;TABLE TERMINATOR.

.SBTTL MEMORY PARITY PATTERNS TABLE

\*\*\*\*\*  
 ;THE FOLLOWING ARE THE PARITY PATTERNS EXERCISED THRUOUT MEMORY  
 ;\*\*\*\*\*

002244 125325  
 002246 152652  
 002250 052452  
 002252 025125  
 002254 102070  
 002256 072527  
 002260 177777  
 002262 107030  
 002264 152525  
 002266 000000

MPPATS: 125325 ;EVEN, ODD  
 152652 ;ODD, EVEN  
 052452 ;EVEN, ODD  
 025125 ;ODD, EVEN  
 102070 ;EVEN, EVEN  
 072527 ;ODD, ODD  
 177777 ;EVEN, EVEN  
 107030 ;ODD, ODD  
 152525 ;ODD, EVEN  
 0 ;EXTRA PATTERN HOLDER FOR  
 ;FUTURE USE

002270 000000

MPEND: 0 ;TABLE TERMINATOR

.SBTTL MEMORY PARITY REGISTER ADDRESS TABLE

////////////////////////////////////  
 ; THE FOLLOWING REPRESENTS THE MEMORY PARITY REGISTER ADDRESS TABLE  
 ; FROM WHICH PARITY MEMORY IS ADDRESSED & CONTROLLED:  
 ;  
 ; THE LEAST SIGNIFICANT BIT IN THE DEVICE ADDRESS IS SET TO A ONE (1)  
 ; IF THE CONTROL IS FOUND NOT TO BE PRESENT. THE MEMORY PRESENT UNDER  
 ; THE CONTROL OF EACH CONTROLLER IS REPRESENTED BY 16 WORDS FOLLOWING  
 ; THE DEVICE ADDRESS. FOR NON-22BIT MEMORY ONLY 1 WORD IS USED  
 ; (EACH BIT REPRESENTING A 8K BLOCK, I.E. FIRST WORD BIT0 = 0 - 8K,  
 ; BIT 3 = 24-28KW 16 BIT ADDRESSING  
 ; BIT 15 = 120-124KW 18 BIT ADDRESSING  
 ;////////////////////////////////////

002272 172101  
 002274 000000  
 002276 000000  
 002300 000000  
 002302 000000  
 002304 000000  
 002306 000000  
 002310 000000  
 002312 000000  
 002314 000000  
 002316 000000  
 002320 000000  
 002322 000000  
 002324 000000  
 002326 000000  
 002330 000000  
 002332 000000  
 002334 000000  
 002336 172103  
 002340 000000  
 002342 000000  
 002344 000000  
 002346 000000  
 002350 000000

MPRO: 172100 +1 ;PARITY STATUS REGISTER  
 .WORD 0 ;1ST WORD CONTROL MAP...128KW  
 .WORD 0 ;2ND WORD CONTROL MAP...256KW  
 .WORD 0 ;3RD WORD CONTROL MAP...384KW  
 .WORD 0 ;4TH WORD CONTROL MAP...512KW  
 .WORD 0 ;5TH WORD CONTROL MAP...640KW  
 .WORD 0 ;6TH WORD CONTROL MAP...768KW  
 .WORD 0 ;7TH WORD CONTROL MAP...896KW  
 .WORD 0 ;8TH WORD CONTROL MAP...1024KW  
 .WORD 0 ;9TH WORD CONTROL MAP...1152KW  
 .WORD 0 ;10TH WORD CONTROL MAP...1280KW  
 .WORD 0 ;11TH WORD CONTROL MAP...1408KW  
 .WORD 0 ;12TH WORD CONTROL MAP...1536KW  
 .WORD 0 ;13TH WORD CONTROL MAP...1664KW  
 .WORD 0 ;14TH WORD CONTROL MAP...1792KW  
 .WORD 0 ;15TH WORD CONTROL MAP...1920KW  
 .WORD 0 ;16TH WORD CONTROL MAP...2048KW  
 ;MASK FOR UNUSED PARITY CSR BITS  
 MPR1: 172102 +1 ;PARITY STATUS REGISTER  
 .WORD 0 ;1ST WORD CONTROL MAP...128KW  
 .WORD 0 ;2ND WORD CONTROL MAP...256KW  
 .WORD 0 ;3RD WORD CONTROL MAP...384KW  
 .WORD 0 ;4TH WORD CONTROL MAP...512KW  
 .WORD 0 ;5TH WORD CONTROL MAP...640KW

N2

002352	000000	.WORD	0	:6TH	WORD CONTROL MAP...	768KW
002354	000000	.WORD	0	:7TH	WORD CONTROL MAP...	896KW
002356	000000	.WORD	0	:8TH	WORD CONTROL MAP...	1024KW
002360	000000	.WORD	0	:9TH	WORD CONTROL MAP...	1152KW
002362	000000	.WORD	0	:10TH	WORD CONTROL MAP...	1280KW
002364	000000	.WORD	0	:11TH	WORD CONTROL MAP...	1408KW
002366	000000	.WORD	0	:12TH	WORD CONTROL MAP...	1536KW
002370	000000	.WORD	0	:13TH	WORD CONTROL MAP...	1664KW
002372	000000	.WORD	0	:14TH	WORD CONTROL MAP...	1792KW
002374	000000	.WORD	0	:15TH	WORD CONTROL MAP...	1920KW
002376	000000	.WORD	0	:16TH	WORD CONTROL MAP...	2048KW
002400	000000	.WORD	0	;MASK FOR UNUSED PARITY CSR BITS		
002402	172105	MPR2:	172104 +1	;PARITY STATUS REGISTER		
002404	000000	.WORD	0	:1ST	WORD CONTROL MAP...	128KW
002406	000000	.WORD	0	:2ND	WORD CONTROL MAP...	256KW
002410	000000	.WORD	0	:3RD	WORD CONTROL MAP...	384KW
002412	000000	.WORD	0	:4TH	WORD CONTROL MAP...	512KW
002414	000000	.WORD	0	:5TH	WORD CONTROL MAP...	640KW
002416	000000	.WORD	0	:6TH	WORD CONTROL MAP...	768KW
002420	000000	.WORD	0	:7TH	WORD CONTROL MAP...	896KW
002422	000000	.WORD	0	:8TH	WORD CONTROL MAP...	1024KW
002424	000000	.WORD	0	:9TH	WORD CONTROL MAP...	1152KW
002426	000000	.WORD	0	:10TH	WORD CONTROL MAP...	1280KW
002430	000000	.WORD	0	:11TH	WORD CONTROL MAP...	1408KW
002432	000000	.WORD	0	:12TH	WORD CONTROL MAP...	1536KW
002434	000000	.WORD	0	:13TH	WORD CONTROL MAP...	1664KW
002436	000000	.WORD	0	:14TH	WORD CONTROL MAP...	1792KW
002440	000000	.WORD	0	:15TH	WORD CONTROL MAP...	1920KW
002442	000000	.WORD	0	:16TH	WORD CONTROL MAP...	2048KW
002444	000000	.WORD	0	;MASK FOR UNUSED PARITY CSR BITS		
002446	172107	MPR3:	172106 +1	;PARITY STATUS REGISTER		
002450	000000	.WORD	0	:1ST	WORD CONTROL MAP...	128KW
002452	000000	.WORD	0	:2ND	WORD CONTROL MAP...	256KW
002454	000000	.WORD	0	:3RD	WORD CONTROL MAP...	384KW
002456	000000	.WORD	0	:4TH	WORD CONTROL MAP...	512KW
002460	000000	.WORD	0	:5TH	WORD CONTROL MAP...	640KW
002462	000000	.WORD	0	:6TH	WORD CONTROL MAP...	768KW
002464	000000	.WORD	0	:7TH	WORD CONTROL MAP...	896KW
002466	000000	.WORD	0	:8TH	WORD CONTROL MAP...	1024KW
002470	000000	.WORD	0	:9TH	WORD CONTROL MAP...	1152KW
002472	000000	.WORD	0	:10TH	WORD CONTROL MAP...	1280KW
002474	000000	.WORD	0	:11TH	WORD CONTROL MAP...	1408KW
002476	000000	.WORD	0	:12TH	WORD CONTROL MAP...	1536KW
002500	000000	.WORD	0	:13TH	WORD CONTROL MAP...	1664KW
002502	000000	.WORD	0	:14TH	WORD CONTROL MAP...	1792KW
002504	000000	.WORD	0	:15TH	WORD CONTROL MAP...	1920KW
002506	000000	.WORD	0	:16TH	WORD CONTROL MAP...	2048KW
002510	000000	.WORD	0	;MASK FOR UNUSED PARITY CSR BITS		
002512	172111	MPR4:	172110 +1	;PARITY STATUS REGISTER		
002514	000000	.WORD	0	:1ST	WORD CONTROL MAP...	128KW
002516	000000	.WORD	0	:2ND	WORD CONTROL MAP...	256KW
002520	000000	.WORD	0	:3RD	WORD CONTROL MAP...	384KW
002522	000000	.WORD	0	:4TH	WORD CONTROL MAP...	512KW
002524	000000	.WORD	0	:5TH	WORD CONTROL MAP...	640KW
002526	000000	.WORD	0	:6TH	WORD CONTROL MAP...	768KW
002530	000000	.WORD	0	:7TH	WORD CONTROL MAP...	896KW
002532	000000	.WORD	0	:8TH	WORD CONTROL MAP...	1024KW

002534	000000	.WORD	0	:9TH	WORD CONTROL MAP	..1152KW
002536	000000	.WORD	0	:10TH	WORD CONTROL MAP	..1280KW
002540	000000	.WORD	0	:11TH	WORD CONTROL MAP	..1408KW
002542	000000	.WORD	0	:12TH	WORD CONTROL MAP	..1536KW
002544	000000	.WORD	0	:13TH	WORD CONTROL MAP	..1664KW
002546	000000	.WORD	0	:14TH	WORD CONTROL MAP	..1792KW
002550	000000	.WORD	0	:15TH	WORD CONTROL MAP	..1920KW
002552	000000	.WORD	0	:16TH	WORD CONTROL MAP	..2048KW
002554	000000	.WORD	0		MASK FOR UNUSED PARITY CSR BITS	
002556	172113	MPR5:	172112 +1		PARITY STATUS REGISTER	
002560	000000	.WORD	0	:1ST	WORD CONTROL MAP	..128KW
002562	000000	.WORD	0	:2ND	WORD CONTROL MAP	..256KW
002564	000000	.WORD	0	:3RD	WORD CONTROL MAP	..384KW
002566	000000	.WORD	0	:4TH	WORD CONTROL MAP	..512KW
002570	000000	.WORD	0	:5TH	WORD CONTROL MAP	..640KW
002572	000000	.WORD	0	:6TH	WORD CONTROL MAP	..768KW
002574	000000	.WORD	0	:7TH	WORD CONTROL MAP	..896KW
002576	000000	.WORD	0	:8TH	WORD CONTROL MAP	..1024KW
002600	000000	.WORD	0	:9TH	WORD CONTROL MAP	..1152KW
002602	000000	.WORD	0	:10TH	WORD CONTROL MAP	..1280KW
002604	000000	.WORD	0	:11TH	WORD CONTROL MAP	..1408KW
002606	000000	.WORD	0	:12TH	WORD CONTROL MAP	..1536KW
002610	000000	.WORD	0	:13TH	WORD CONTROL MAP	..1664KW
002612	000000	.WORD	0	:14TH	WORD CONTROL MAP	..1792KW
002614	000000	.WORD	0	:15TH	WORD CONTROL MAP	..1920KW
002616	000000	.WORD	0	:16TH	WORD CONTROL MAP	..2048KW
002620	000000	.WORD	0		MASK FOR UNUSED PARITY CSR BITS	
002622	172115	MPR6:	172114 +1		PARITY STATUS REGISTER	
002624	000000	.WORD	0	:1ST	WORD CONTROL MAP	..128KW
002626	000000	.WORD	0	:2ND	WORD CONTROL MAP	..256KW
002630	000000	.WORD	0	:3RD	WORD CONTROL MAP	..384KW
002632	000000	.WORD	0	:4TH	WORD CONTROL MAP	..512KW
002634	000000	.WORD	0	:5TH	WORD CONTROL MAP	..640KW
002636	000000	.WORD	0	:6TH	WORD CONTROL MAP	..768KW
002640	000000	.WORD	0	:7TH	WORD CONTROL MAP	..896KW
002642	000000	.WORD	0	:8TH	WORD CONTROL MAP	..1024KW
002644	000000	.WORD	0	:9TH	WORD CONTROL MAP	..1152KW
002646	000000	.WORD	0	:10TH	WORD CONTROL MAP	..1280KW
002650	000000	.WORD	0	:11TH	WORD CONTROL MAP	..1408KW
002652	000000	.WORD	0	:12TH	WORD CONTROL MAP	..1536KW
002654	000000	.WORD	C	:13TH	WORD CONTROL MAP	..1664KW
002656	000000	.WORD	0	:14TH	WORD CONTROL MAP	..1792KW
002660	000000	.WORD	0	:15TH	WORD CONTROL MAP	..1920KW
002662	000000	.WORD	0	:16TH	WORD CONTROL MAP	..2048KW
002664	000000	.WORD	0		MASK FOR UNUSED PARITY CSR BITS	
002666	172117	MPR7:	172116 +1		PARITY STATUS REGISTER	
002670	000000	.WORD	0	:1ST	WORD CONTROL MAP	..128KW
002672	000000	.WORD	0	:2ND	WORD CONTROL MAP	..256KW
002674	000000	.WORD	0	:3RD	WORD CONTROL MAP	..384KW
002676	000000	.WORD	0	:4TH	WORD CONTROL MAP	..512KW
002700	000000	.WORD	0	:5TH	WORD CONTROL MAP	..640KW
002702	000000	.WORD	0	:6TH	WORD CONTROL MAP	..768KW
002704	000000	.WORD	0	:7TH	WORD CONTROL MAP	..896KW
002706	000000	.WORD	0	:8TH	WORD CONTROL MAP	..1024KW
002710	000000	.WORD	0	:9TH	WORD CONTROL MAP	..1152KW
002712	000000	.WORD	0	:10TH	WORD CONTROL MAP	..1280KW
002714	000000	.WORD	0	:11TH	WORD CONTROL MAP	..1408KW

002716	000000	.WORD	0	:12TH WORD CONTROL MAP..1536KW
002720	000000	.WORD	0	:13TH WORD CONTROL MAP..1664KW
002722	000000	.WORD	0	:14TH WORD CONTROL MAP..1792KW
002724	000000	.WORD	0	:15TH WORD CONTROL MAP..1920KW
002726	000000	.WORD	0	:16TH WORD CONTROL MAP..2048KW
002730	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS
002732	172121	MPR8: 172120	+1	:PARITY STATUS REGISTER
002734	000000	.WORD	0	:1ST WORD CONTROL MAP...128KW
002736	000000	.WORD	0	:2ND WORD CONTROL MAP...256KW
002740	000000	.WORD	0	:3RD WORD CONTROL MAP...384KW
002742	000000	.WORD	0	:4TH WORD CONTROL MAP...512KW
002744	000000	.WORD	0	:5TH WORD CONTROL MAP...640KW
002746	000000	.WORD	0	:6TH WORD CONTROL MAP...768KW
002750	000000	.WORD	0	:7TH WORD CONTROL MAP...896KW
002752	000000	.WORD	0	:8TH WORD CONTROL MAP..1024KW
002754	000000	.WORD	0	:9TH WORD CONTROL MAP..1152KW
002756	000000	.WORD	0	:10TH WORD CONTROL MAP..1280KW
002760	000000	.WORD	0	:11TH WORD CONTROL MAP..1408KW
002762	000000	.WORD	0	:12TH WORD CONTROL MAP..1536KW
002764	000000	.WORD	0	:13TH WORD CONTROL MAP..1664KW
002766	000000	.WORD	0	:14TH WORD CONTROL MAP..1792KW
002770	000000	.WORD	0	:15TH WORD CONTROL MAP..1920KW
002772	000000	.WORD	0	:16TH WORD CONTROL MAP..2048KW
002774	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS
002776	172123	MPR9: 172122	+1	:PARITY STATUS REGISTER
003000	000000	.WORD	0	:1ST WORD CONTROL MAP...128KW
003002	000000	.WORD	0	:2ND WORD CONTROL MAP...256KW
003004	000000	.WORD	0	:3RD WORD CONTROL MAP...384KW
003006	000000	.WORD	0	:4TH WORD CONTROL MAP...512KW
003010	000000	.WORD	0	:5TH WORD CONTROL MAP...640KW
003012	000000	.WORD	0	:6TH WORD CONTROL MAP...768KW
003014	000000	.WORD	0	:7TH WORD CONTROL MAP...896KW
003016	000000	.WORD	0	:8TH WORD CONTROL MAP..1024KW
003020	000000	.WORD	0	:9TH WORD CONTROL MAP..1152KW
003022	000000	.WORD	0	:10TH WORD CONTROL MAP..1280KW
003024	000000	.WORD	0	:11TH WORD CONTROL MAP..1408KW
003026	000000	.WORD	0	:12TH WORD CONTROL MAP..1536KW
003030	000000	.WORD	0	:13TH WORD CONTROL MAP..1664KW
003032	000000	.WORD	0	:14TH WORD CONTROL MAP..1792KW
003034	000000	.WORD	0	:15TH WORD CONTROL MAP..1920KW
003036	000000	.WORD	0	:16TH WORD CONTROL MAP..2048KW
003040	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS
003042	172125	MPR10: 172124	+1	:PARITY STATUS REGISTER
003044	000000	.WORD	0	:1ST WORD CONTROL MAP...128KW
003046	000000	.WORD	0	:2ND WORD CONTROL MAP...256KW
003050	000000	.WORD	0	:3RD WORD CONTROL MAP...384KW
003052	000000	.WORD	0	:4TH WORD CONTROL MAP...512KW
003054	000000	.WORD	0	:5TH WORD CONTROL MAP...640KW
003056	000000	.WORD	0	:6TH WORD CONTROL MAP...768KW
003060	000000	.WORD	0	:7TH WORD CONTROL MAP...896KW
003062	000000	.WORD	0	:8TH WORD CONTROL MAP..1024KW
003064	000000	.WORD	0	:9TH WORD CONTROL MAP..1152KW
003066	000000	.WORD	0	:10TH WORD CONTROL MAP..1280KW
003070	000000	.WORD	0	:11TH WORD CONTROL MAP..1408KW
003072	000000	.WORD	0	:12TH WORD CONTROL MAP..1536KW
003074	000000	.WORD	0	:13TH WORD CONTROL MAP..1664KW
003076	000000	.WORD	0	:14TH WORD CONTROL MAP..1792KW

003100	000000	.WORD	0	:15TH WORD CONTROL MAP..1920KW
003102	000000	.WORD	0	:16TH WORD CONTROL MAP..2048KW
003104	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS
003106	172127	MPR11: .WORD	+1	:PARITY STATUS REGISTER
003110	000000	.WORD	0	:1ST WORD CONTROL MAP...128KW
003112	000000	.WORD	0	:2ND WORD CONTROL MAP...256KW
003114	000000	.WORD	0	:3RD WORD CONTROL MAP...384KW
003116	000000	.WORD	0	:4TH WORD CONTROL MAP...512KW
003120	000000	.WORD	0	:5TH WORD CONTROL MAP...640KW
003122	000000	.WORD	0	:6TH WORD CONTROL MAP...768KW
003124	000000	.WORD	0	:7TH WORD CONTROL MAP...896KW
003126	000000	.WORD	0	:8TH WORD CONTROL MAP...1024KW
003130	000000	.WORD	0	:9TH WORD CONTROL MAP...1152KW
003132	000000	.WORD	0	:10TH WORD CONTROL MAP...1280KW
003134	000000	.WORD	0	:11TH WORD CONTROL MAP...1408KW
003136	000000	.WORD	0	:12TH WORD CONTROL MAP...1536KW
003140	000000	.WORD	0	:13TH WORD CONTROL MAP...1664KW
003142	000000	.WORD	0	:14TH WORD CONTROL MAP...1792KW
003144	000000	.WORD	0	:15TH WORD CONTROL MAP...1920KW
003146	000000	.WORD	0	:16TH WORD CONTROL MAP...2048KW
003150	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS
003152	172131	MPR12: .WORD	+1	:PARITY STATUS REGISTER
003154	000000	.WORD	0	:1ST WORD CONTROL MAP...128KW
003156	000000	.WORD	0	:2ND WORD CONTROL MAP...256KW
003160	000000	.WORD	0	:3RD WORD CONTROL MAP...384KW
003162	000000	.WORD	0	:4TH WORD CONTROL MAP...512KW
003164	000000	.WORD	0	:5TH WORD CONTROL MAP...640KW
003166	000000	.WORD	0	:6TH WORD CONTROL MAP...768KW
003170	000000	.WORD	0	:7TH WORD CONTROL MAP...896KW
003172	000000	.WORD	0	:8TH WORD CONTROL MAP...1024KW
003174	000000	.WORD	0	:9TH WORD CONTROL MAP...1152KW
003176	000000	.WORD	0	:10TH WORD CONTROL MAP...1280KW
003200	000000	.WORD	0	:11TH WORD CONTROL MAP...1408KW
003202	000000	.WORD	0	:12TH WORD CONTROL MAP...1536KW
003204	000000	.WORD	0	:13TH WORD CONTROL MAP...1664KW
003206	000000	.WORD	0	:14TH WORD CONTROL MAP...1792KW
003210	000000	.WORD	0	:15TH WORD CONTROL MAP...1920KW
003212	000000	.WORD	0	:16TH WORD CONTROL MAP...2048KW
003214	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS
003216	172133	MPR13: .WORD	+1	:PARITY STATUS REGISTER
003220	000000	.WORD	0	:1ST WORD CONTROL MAP...128KW
003222	000000	.WORD	0	:2ND WORD CONTROL MAP...256KW
003224	000000	.WORD	0	:3RD WORD CONTROL MAP...384KW
003226	000000	.WORD	0	:4TH WORD CONTROL MAP...512KW
003230	000000	.WORD	0	:5TH WORD CONTROL MAP...640KW
003232	000000	.WORD	0	:6TH WORD CONTROL MAP...768KW
003234	000000	.WORD	0	:7TH WORD CONTROL MAP...896KW
003236	000000	.WORD	0	:8TH WORD CONTROL MAP...1024KW
003240	000000	.WORD	0	:9TH WORD CONTROL MAP...1152KW
003242	000000	.WORD	0	:10TH WORD CONTROL MAP...1280KW
003244	000000	.WORD	0	:11TH WORD CONTROL MAP...1408KW
003246	000000	.WORD	0	:12TH WORD CONTROL MAP...1536KW
003250	000000	.WORD	0	:13TH WORD CONTROL MAP...1664KW
003252	000000	.WORD	0	:14TH WORD CONTROL MAP...1792KW
003254	000000	.WORD	0	:15TH WORD CONTROL MAP...1920KW
003256	000000	.WORD	0	:16TH WORD CONTROL MAP...2048KW
003260	000000	.WORD	0	:MASK FOR UNUSED PARITY CSR BITS



```

.SBTTL ERROR POINTER TABLE
;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC)
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
;*      EM      ;;POINTS TO THE ERROR MESSAGE
;*      DH      ;;POINTS TO THE DATA HEADER
;*      DT      ;;POINTS TO THE DATA
;*      DF      ;;POINTS TO THE DATA FORMAT
$ERRTB:
CHGG1:
;* ITEM 1
DM1      ;PARITY REGISTER DATA ERROR.
DH1      ;PC REG,S/B,WAS
DT1      ;$ERRPC,$GDADR,$GDDAT,$BDDAT
DF1      ;16,22,16,16
;* ITEM 2
DM2      ;ADDRESS TEST ERROR(TST1-5).
DH2      ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT
DF2      ;16,22,22,16,16
;* ITEM 3
DM2      ;ADDRESS TEST ERROR(TST1-5).
DH31     ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT
DF3      ;16,22,22,8,8
;* ITEM 4
DM4      ;CONSTANT DATA ERROR(TST6-10).
DH2      ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT
DF2      ;16,22,22,16,16
;* ITEM 5
DM5      ;ROTATING BIT ERROR(TST11-12).
DH2      ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT
DF2      ;16,22,22,16,16
;* ITEM 6
DM6      ;MOS REFRESH TEST ERROR (TST24-25).
DH2      ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT
DF2      ;16,22,22,16,16
;* ITEM 7
DM7      ;FATAL ERROR HALT
0
0
0
;* ITEM 10
DM10     ;MARCHING 1'S AND 0'S ERROR(TST23).
DH2      ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT
DF2      ;16,22,22,16,16
;* ITEM 11
DM11     ;PARITY MEMORY ADDRESS ERROR(TST13).
DH31     ;V/PC,P/PC,MA,S/B,WAS
DT2      ;$VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT

```

```

003434
1232 003434
1233
1234 003434 025152
1235 003436 026512
1236 003440 002042
1237 003442 027250
1238
1239 003444 025206
1240 003446 026535
1241
1242 003450 002054
1243 003452 027254
1244
1245 003454 025206
1246 003456 027214
1247 003460 002054
1248 003462 027261
1249
1250 003464 025242
1251 003466 026535
1252 003470 002054
1253 003472 027254
1254
1255 003474 025300
1256 003476 026535
1257 003500 002054
1258 003502 027254
1259
1260 003504 025336
1261 003506 026535
1262 003510 002054
1263 003512 027254
1264
1265 003514 025402
1266 003516 000000
1267 003520 000000
1268 003522 000000
1269
1270 003524 025423
1271 003526 026535
1272 003530 002054
1273 003532 027254
1274
1275 003534 025467
1276 003536 027214
1277 003540 002054

```



1278	003542	027261	DF3	:16,22,22,8,8
1279			;* ITEM 12	
1280	003544	025533	DM12	:DATIO WITH WRONG PARITY DIDN'T TRAP(TST13).
1281	003546	026574	DH12	:V/PC,P/PC,MA,S/B
1282	003550	002070	DT12	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT
1283	003552	027261	DF3	:16,22,22,8
1284			;* ITEM 13	
1285	003554	025607	DM13	:WRONG PARITY DETECTED, BUT NO REGISTER SHOWS ERROR FLAG.
1286	003556	026574	DH12	:V/PC,P/PC,MA,S/B
1287	003560	002070	DT12	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT
1288	003562	027261	DF3	:16,22,22,8
1289			;* ITEM 14	
1290	003564	025700	DM14	:PARITY REGISTER NOT MAPPED AS CONTROLLING THIS ADDRESS(TST13).
1291	003566	026623	DH14	:V/PC,P/PC,REG,MA
1292	003570	002102	DT14	:\$VERPC,\$ERRPC,\$TMPO,\$GDADR
1293				
1294	003572	027266	DF14	:16,22,22,22
1295			;* ITEM 15	
1296	003574	025152	DM1	:PARITY REGISTER DATA ERROR.
1297	003576	026652	DH15	:V/PC,P/PC,MAUT,REG,S/B,WAS
1298	003600	002114	DT15	:\$VERPC,\$ERRPC,\$GDADR,\$TMPO,\$GDDAT,\$BDDAT
1299	003602	027266	DF14	:16,22,22,22,16,16
1300			;* ITEM 16	
1301	003604	025777	DM16	:MORE THAN ONE REGISTER INDICATED PARITY ERROR.
1302	003606	026623	DH14	:V/PC,P/PC,REG,MA
1303	003610	002102	DT14	:\$VERPC,\$ERRPC,\$TMPO,\$GDADR
1304	003612	027266	DF14	:16,22,22,22
1305			;* ITEM 17	
1306	003614	026056	DM17	:DATA SHOULDN'T HAVE CHANGED WHEN PARITY ERROR
1307				: TRAPPED(TST13).
1308	003616	027214	DH31	:V/PC,P/PC,MA,S/B,WAS
1309	003620	002054	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT
1310	003622	027261	DF3	:16,22,22,8,8
1311			;* ITEM 20	
1312	003624	026154	DM20	:RANDOM DATA ERROR(TST14).
1313	003626	026535	DH2	:V/PC,P/PC,MA,S/B,WAS
1314	003630	002054	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT
1315	003632	027254	DF2	:16,22,22,16,16
1316			;* ITEM 21	
1317	003634	026206	DM21	:INSTRUCTION EXECUTION ERROR(TST15 22).
1318	003636	026725	DH21	:V/PC,P/PC,IUT,MA,S/B,WAS
1319	003640	002132	DT21	:\$VERPC,\$ERRPC,\$TMPO,\$GDADR,\$GDDAT,\$BDDAT
1320	003642	027274	DF21	:16,22,16,22,16,16
1321			;* ITEM 22	
1322	003644	000000	0	:NOT USED
1323	003646	000000	0	:CHGG1
1324	003650	000000	0	
1325	003652	000000	0	
1326			;* ITEM 23	
1327	003654	026255	DM23	:PROGRAM CODE CHANGED WHEN RELOCATED.
1328	003656	026772	DH23	:V/PC,P/PC, SRC MA, DST MA, S/B, WAS
1329	003660	002150	DT23	:\$VERPC,\$ERRPC,\$GDADR,\$BDADR,\$GDDAT,\$BDDAT
1330	003662	027266	DF14	:16,22,22,22,16,16
1331			;* ITEM 24	
1332	003664	026322	DM24	:TRAPPED, BUT NO REGISTER HAD ERROR BIT SET.
1333	003666	027046	DH24	:V/PC,P/PC,TRP/PC
1334	003670	002166	DT24	:\$VERPC,\$ERRPC,\$BDADR

```

1335 003672 027266          DF14          :16,22,22
1336          :* ITEM 25
1337 003674 026376          DM25          ;TRAPPED TO 114.
1338 003676 027071          DH25          ;V/PC,P/PC,TRP/PC,REG,WAS
1339 003700 002176          DT25          ;$VERPC,$ERRPC,$BDADR,$TMPO,$TMP1
1340 003702 027266          DF14          :16,22,22,22,16
1341          :* ITEM 26
1342 003704 026416          DM26          ;FAILED TO TRAP.
1343 003706 027135          DH26          ;V/PC,P/PC,REG,WAS
1344 003710 002212          DT26          ;$VERPC,$ERRPC,$TMPO,$TMP1
1345 003712 027254          DF2           :16,22,22,16
1346          :* ITEM 27
1347 003714 026436          DM27          ;(ACTION ENABLE WASN'T SET).
1348 003716 027135          DH26          ;V/PC,P/PC,REG,WAS
1349 003720 002212          DT26          ;$VERPC,$ERRPC,$TMPO,$TMP1
1350 003722 027254          DF2           :16,22,22,16
1351          :* ITEM 30
1352 003724 000000          0             ;NO MESSAGE.
1353 003726 027165          DH30          ;REG,WAS,MA,WAS
1354 003730 002224          DT30          ;$TMPO,$TMP1,$GDADR,$BDDAT
1355 003732 027302          DF30          :22,16,22,8
1356          :* ITEM 31
1357 003734 026472          DM31          ;TRAPPED TO 4
1358 003736 000000          0             ;NO HEADER
1359 003740 002236          DT31          ;$TMP3
1360 003742 027302          DF30          ;22

```

.SBTTL START: SETUP AND MAP MEMORY

```

1361 .REPT 1
1362 :/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:
;* THIS IS THE NORMAL (SA = 200) BEGINNING OF THE PROGRAM.
;* NOTE: THIS CODE IS NOT POSITION INDEPENDENT.

```

```

1367 003744 105067 176006 START: CLR B SELFLG ;CLEAR SELECT PARAMETER FLAG.
1368 003750 000403 BR STARTA ;GO DO SETUP AND MEMORY MAP.
1369 003752 112767 177777 175776 SELECT: MOV B #-1, SELFLG ;SET THE SELECT PARAMETERS FLAG.
1370 003760 STARTA:
.SBTTL INITIALIZE THE COMMON TAGS
;;CLEAR THE COMMON TAGS ($CMTAG) AREA
003760 012706 001070 MOV #$CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
003764 005026 CLR (R6)+ ;;CLEAR MEMORY LOCATION
003766 022706 001130 CMP #SWR,R6 ;;DONE?
003772 001374 BNE -6 ;;LOOP BACK IF NO
003774 012706 001100 MOV #STACK,SP ;;SETUP THE STACK POINTER
;;INITIALIZE A FEW VECTORS
004000 012737 000540 000024 MOV #$PWRDN,@#PWRVEC ;;POWER FAILURE VECTOR
004006 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;LEVEL 7
004014 016767 006634 006624 MOV $ENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
004022 013746 000004 MOV @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
004026 012737 004062 000004 MOV #30000$,@#ERRVEC ;;SET UP ERROR VECTOR
004034 012767 177570 175066 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
004042 012767 177570 175062 MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
004050 022777 177777 175052 CMP #-1,@SWR ;;TRY TO REFERENCE HARDWARE SWR
004056 001012 BNE 30002$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED

```

```

004060 000403          BR      30001$          ;;AND THE HARDWARE SWR IS NOT = -1
004062 012716 004070 30000$: MOV    #30001$, (SP)      ;;BRANCH IF NO TIMEOUT
004066 000002          RTI                          ;;SET UP FOR TRAP RETURN
004070 012767 000176 175032 30001$: MOV    #SWREG, SWR          ;;POINT TO SOFTWARE SWR
004076 012767 000174 175026          MOV    #DISPREG, DISPLAY
004104 012637 000004          30002$: MOV    (SP)+, @#ERRVEC      ;;RESTORE ERROR VECTOR
004110 005067 175066          CLR    $PASS          ;;CLEAR PASS COUNT
004114 132767 000200 175073          BITB   #APTSIZE, $ENVM  ;;TEST USER SIZE UNDER APT
004122 001403          BEQ    30003$          ;;YES, USE NON-APT SWITCH
004124 012767 001216 174776          MOV    #SWREG, SWR          ;;NO, USE APT SWITCH REGISTER
004132          30003$:
1371          ;;*****
1372          ;;V DISABLE CACHE ELSE SIZING IS AFFECTED
1373          ;;V*****
1374 004132 016746 173646          MOV    4, -(SP)          ;;V SAVE TIME OUT VECTOR
1375 004136 016746 173644          MOV    6, -(SP)          ;;V SAVE THE STATUS
1376 004142 012767 004164 173634          MOV    #30$, 4          ;;V SET UP TIME OUT VECTOR
1377 004150 005067 173632          CLR    6          ;;V CLEAR T.O. STATUS LOC
1378 004154 052737 001414 177746          BIS    #1414, @#177746  ;;V DISABLE CACHE
1379 004162 000402          BR     31$          ;;V CACHE IS PRESENT
1380 004164 062706 000004          30$:  ADD    #4, SP          ;;V RESET STACK POINTER
1381 004170 012667 173612          31$:  MOV    (SP)+, 6      ;;V RESTORE T.O. STATUS
1382 004174 012667 173604          MOV    (SP)+, 4          ;;V RESTORE T.O. VECTOR
1383          ;;VK*****
1384          ;;VK SIZE FOR KDJ11-DA (11/53) PROCESSOR
1385          ;;VK*****
1386 004200 005067 175574          CLR    KDJDA
1387 004204 013746 000004          MOV    @#4, -(SP)
1388 004210 012737 004244 000004          MOV    #1$, @#4
1389 004216 013700 177750          MOV    @#177750, R0
1390 004222 042700 177417          BIC    #177417, R0
1391 004226 022700 000100          CMP    #100, R0
1392 004232 001004          BNE    1$
1393 004234 012767 177777 175536          MOV    #-1, KDJDA
1394 004242 000402          BR     2$
1395 004244 062706 000004          1$:  ADD    #4, SP
1396 004250 012637 000004          2$:  MOV    (SP)+, @#4
1397          ;;VK*****END KDJ11-DA SIZING*****
1398 004254 005067 175232          CLR    LDDISP          ;;CLEAR DISPLAY REGISTER STORAGE LOCN
1399 004260 005077 174646          CLR    @DISPLAY        ;;CLEAR DISPLAY REGISTER
1400          .SBTTL  TYPE PROGRAM NAME
          ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
004264 005227 177777          INC    #-1          ;;FIRST TIME?
004270 001041          BNE    30004$          ;;BRANCH IF NO
004272 022737 012722 000042          CMP    #ENDAD, @#42    ;;ACT-11?
004300 001435          BEQ    30004$          ;;BRANCH IF YES
004302 004567 015444          JSR    R5, $PRINT      ;;GO PRINT OUT THE FOLLOWING MESSAGE.
004306 004362          .WORD  30005$          ;;ADDRESS OF MESSAGE TO BE TYPED
          .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
004310 005737 000042          TST    @#42          ;;ARE WE RUNNING UNDER XXDP/ACT?
004314 001016          BNE    30006$          ;;BRANCH IF YES
004316 126727 174672 000001          CMPB   $ENV, #1        ;;ARE WE RUNNING UNDER APT?
004324 001412          BEQ    30006$          ;;BRANCH IF YES
004326 026727 174576 000176          CMP    SWR, #SWREG     ;;SOFTWARE SWITCH REG SELECTED?
004334 001011          BNE    30007$          ;;BRANCH IF NO
; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $GTSWR ROUTINE

```

```

    004336 106746
    004340 105066 000001
    004344 004767 014310
    004350 000403
    004352 112767 000001 174544 30006$: MOVB #1,$AUTOB ;;SET AUTO-MODE INDICATOR
    004360 000405 30007$:
    004360 000405 30004$ BR 30004$ ;;GET OVER THE ASCIZ
    004374 30005$: .ASCIZ <CRLF>'CVMSAB'<CRLF>
    1401 004374 010700
    1402 004376 022700 004376 9$: MOV PC, RO ;GET CURRENT PROGRAM COUNTER.
    1403 004402 001402 CMP #9$, RO ;CHECK IF THE PROGRAM IS RELOCATED.
    1404 004404 000167 173670 BEQ 10$ ;BR IF PROGRAM NOT RELOCATED.
    1405 004410 012767 000001 174116 10$: JMP RESTAR ;GO TRY TO RELOCTED BEFORE CONTINUING.
    1406 004416 005067 174110 12$: MOV #1, PRGMAP ;INITIALIZE PROGRAM MAP.
    1407 004422 105737 001214 CLR RELOCF ;INIT THE RELOCATION FACTOR.
    1408 004426 001011 TSTB @#$ENV ;CHECK FOR APT11
    1409 004430 005737 000042 BNE 13$ ;BR IF APT11
    1410 004434 001406 TST @#42 ;CHECK FOR STANDALONE
    1411 004436 023737 000042 000046 BEQ 13$ ;BR IF STANDALONE
    1412 004444 001402 CMP @#42,@#46 ;CHECK FOR ACT11
    1413 BEQ 13$ ;BR IF ACT11
    1414 004446 004767 011100 JSR PC,SAVLDR ;MUST BE XXDP
    1415 ;GO SAVE LOADERS
    1416
    1417 ;* CHECK IF MEMORY MANAGEMENT IS AVAILABLE, AND SET IT UP IF IT IS.
    1418 004452 012700 001514 ;* INITIALIZE THE MEMMAP TABLE
    1419 004456 012701 000020 13$: MOV #MEMMAP,RO ;LOAD RO WITH MEMMAP TABLE ADDRESS
    1420 004462 005020 14$: MOV #16,R1 ;LOAD COUNTER
    1421 004464 077102 CLR (R0)+ ;CLEAR MEMMAP TABLE ENTRY
    1422 SOB R1,14$ ;DECREMENT COUNTER 16. TIMES
    1423 ;IF COUNTER NOT = 0 THEN CLEAR NEXT ENTRY
    1424 004466 005067 175304 CLR LSIFLG ;INIT LSI-11 /2/QUAD PROCESSOR FLAG
    1425 004472 012767 004504 173310 MOV #15$,RESVEC ;FIND OUT IF LSI-11/2/QUAD
    1426 004500 000007 MFPT ;MFPT INSTRUCTION WILL CAUSE TRAP
    1427 ;ON LSI-11/2
    1428 004502 000404 BR 16$ ;11/23 OR LATER WILL BRANCH
    1429 004504 062706 000004 15$: ADD #4,SP ;LSI-11 RETURN CORRECT STACK
    1430 004510 005267 175262 INC LSIFLG ;AND SET LSI-11/2 FLAG
    1431
    1432 ;* CHECK IF MEMORY MANAGEMENT IS AVAILABLE, AND SET IT UP IF IT IS
    1433 004514 005067 174016 16$: CLR MMAVA ;CLEAR KT AND 22 BIT ADDRESSING FLAG
    1434 004520 032777 010000 174402 BIT #SW12,@SWR ;CHECK FOR INHIBIT KT11 SWITCH
    1435 004526 001047 BNE NONKT ;BRANCH IF SET
    1436 004530 012737 004646 000004 MOV #NONKT,@#ERRVEC ;SET UP TIMEOUT TRAP VECTOR
    1437 004536 005037 177572 CLR @#SRO ;CLEAR MEM MGMT STATUS REGISTER
    1438 004542 004767 006232 JSR PC,MMINIT ;MEM MGMT INITIALIZATION ROUTINE
    1439 004546 005267 173764 INC MMAVA ;SET MEM MGMT AVAILABLE FLAG
    1440 004552 004567 015174 JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
    004556 023650 .WORD MMAMES ;ADDRESS OF MESSAGE TO BE TYPED
    ;"KT11 AVAILABLE"
    1441
    1442
    1443
    1444 004560 012737 004630 000004 ;* CHECK IF 22 BIT SYSTEM AVAILABLE AND SET IT UP IF IT IS
    MOV #22$,@#ERRVEC ;SET UP FOR TIME OUT VECTOR
  
```

```

1445 004566 005037 000000 CLR @#0 ;CLEAR LOCATION 0
1446 004572 012737 010000 172344 MOV #10000,@#KIPAR2 ;SET PAR2 TO LOC 128K + 2
1447 004600 052737 000020 172516 BIS #BIT4,@#SR3 ;TURN ON 22 BIT ADDRESSING
1448 004606 012737 177777 040000 MOV #-1,@#40000 ;NOW WRITE TO LOC 128K + 2
1449 004614 005737 000000 TST @#0 ;IF LOC 0 = 0
1450 004620 001403 BEQ 22$ ; THEN 22 BIT SYSTEM
1451 004622 005037 172516 CLR @#SR3 ; ELSE 18 BIT SYSTEM, DISABLE 22 BIT ADR
1452 004626 000454 BR KTSIZ ; AND GO SIZE MEMORY
1453
1454 ;* TIME OUT TRAP TO HERE OR MEMORY EXISTS AT 128K + 2
1455 004630 052767 100000 173700 22$: BIS #BIT15,MMAVA ; ELSE SET 22 BIT FLAG
1456 004636 004567 015110 JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
004642 023715 .WORD AVAL22 ;ADDRESS OF MESSAGE TO BE TYPED
; "22 BIT ADR AVAILABLE"
1457 004644 000445 BR KTSIZ ;GO SIZE MEMORY
1458
1459
1460 ;*****
1461 ;* THIS ROUTINE WILL MAP MEMORY IN 8K SEGMENTS. SUPPORTS ONLY THE SIZING
1462 ;* OF 16 BIT ADDRESSING WITHOUT MEM MGMT SUPPORT.
1463 ;* STORAGE USED:
1464 ;* R0 = MEMMAP POINTER ... LO 128K
1465 ;* R2 = ADDRESS POINTER
1466 ;* R3 = BANK POINTER ... LO 128K
1467 ;* FLG30K = 30K MEMORY FLAG
1468 ;* LITERALS:
1469 ;* MASK8K = 37777
1470 ;*****
1471 004646 012706 001100 NONKT: MOV #STACK,SP ;SET-UP THE STACK
1472 004652 012700 001514 MOV #MEMMAP,R0 ;SET UP MEMORY MAP PTR TO LO 128K
1473 004656 005002 CLR R2 ;SET ADDRESS PTR TO 0
1474 004660 012703 000001 MOV #1,R3 ;SET UP 8K BANK POINTER
1475 004664 012737 004706 000004 MOV #2$,@#ERRVEC ;SET UP TIME OUT VECTOR
1476 004672 011222 1$: MOV (R2),(R2)+ ;READ AND WRITE ALL MEMORY
1477 004674 032702 037777 BIT #MASK8K,R2 ;IF NOT 8K BOUNDARY
1478 004700 001374 BNE 1$ ; THEN CHECK NEXT LOCATION
1479 004702 050310 BIS R3,(R0) ; ELSE SET BANK FLAG IN MEMMAP
1480 004704 000420 BR 3$ ; AND DO SOME MORE
1481
1482 ;* TIMEOUT TRAPS TO HERE
1483 004706 062706 000004 2$: ADD #4,SP ;RESTORE STACK POINTER
1484 004712 022702 160000 CMP #160000,R2 ;IF NOT 28K BOUNDARY
1485 004716 001001 BNE 20$ ; THEN BRANCH
1486 004720 000405 BR 21$ ; ELSE SET UP POINTERS
1487 004722 022702 170000 20$: CMP #170000,R2 ;IF NOT 30K BOUNDARY
1488 004726 001004 BNE 22$ ; THEN BRANCH
1489 004730 005267 175040 INC FLG30K ; ELSE SET 30K MEMORY FLAG
1490 004734 050310 21$: BIS R3,(R0) ;SET BANK FLAG IN MEMMAP
1491 004736 000407 BR 4$ ;BRANCH ALL DONE
1492 004740 052702 037777 22$: BIS #MASK8K,R2 ;POINT TO LAST ADDRESS OF 8K BANK
1493 004744 005202 INC R2 ;POINT TO 1ST ADDRESS OF NEXT BANK
1494
1495 004746 106303 3$: ASLB R3 ;UPDATE BANK POINTER
1496 004750 032703 000020 BIT #BIT4,R3 ;IF NOT DONE WITH 32K
1497 004754 001746 BEQ 1$ ; THEN TRY SOME MORE
1498 004756 000500 4$: BR DISMAP ;GO TYPE OUT MAP
1499

```

```

1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515 004760 012706 001100
1516 004764 012700 001514
1517 004770 012702 040000
1518 004774 005037 172344
1519 005000 012737 000200 172346
1520 005006 012737 005034 000004
1521
1522 005014 012703 000001 1$: MOV #BIT0,R3 ;SET-UP 8K BANK POINTER
1523
1524 005020 011222 2$: MOV (R2),(R2)+ ;READ AND WRITE ALL MEMORY
1525 005022 032702 037777 BIT #MASK8K,R2 ;IF NOT 8K BOUNDARY
1526 005026 001374 BNE 2$ ; THEN TRY SOMEMORE
1527 005030 050310 BIS R3,(R0) ; ELSE SET BANK FLAG IN MEMMAP
1528 005032 000424 BR 5$ ;AND GO UPDATE VARIABLES AND CONTINUE
1529
1530
1531 005034 062706 000004 3$: ADD #4,SP ;RESTORE STACK POINTER
1532 005040 022702 060000 CMP #60000,R2 ;IF NOT POSSIBLY THE I/O PAGE
1533 005044 001017 BNE 5$ ; THEN GO TEST SOMEMORE
1534 005046 005767 173464 TST MAVA ; ELSE IF 22 BIT ADDRESSING
1535 005052 100406 BMI 4$ ; THEN GO SEE IF 2M I/O PAGE
1536 005054 022737 007600 172346 CMP #7600,@#KIPAR3 ; ELSE IF NOT I/O BOUNDARY FOR 18 BITS
1537 005062 001010 BNE 5$ ; THEN GO UPDATE VARIABLES AND TRY SOMEMORE
1538 005064 050310 BIS R3,(R0) ; ELSE SET BANK EXISTS IN MEMMAP
1539 005066 000433 BR 7$ ;AND GO TYPE MEMORY MAP
1540
1541 005070 022737 177600 172346 4$: CMP #177600,@#KIPAR3 ;IF NOT 2M I/O BOUNDARY
1542 005076 001002 BNE 5$ ; THEN GO TRY SOMEMORE SIZING
1543 005100 050310 BIS R3,(R0) ; ELSE SET BANK IN MEMMAP
1544 005102 000425 BR 7$ ;AND GO TYPE MEMORY MAP
1545
1546 005104 062737 000400 172344 5$: ADD #400,@#KIPAR2 ;UPDATE MAP TO NEXT
1547 005112 062737 000400 172346 ADD #400,@#KIPAR3 ; 8K BANK
1548 005120 012702 040000 MOV #40000,R2 ;RESTORE ADDRESS POINTER TO 1ST ADDRESS OF THIS BANK
1549 005124 005767 173406 TST MAVA ;IF NOT 18 BIT ADDR
1550 005130 100403 BMI 6$ ;THEN GO TEST SOMEMORE
1551 005132 006303 ASL R3 ;18 BIT ADDR. = 1 WORD
1552 005134 001331 BNE 2$ ;IF NOT END OF 18 BIT ADDR
1553
1554 005136 000407 BR 7$ ; THEN GO SIZE SOMEMORE
1555 005140 006303 6$: ASL R3 ; ELSE ALL DONE 18 BIT SIZING.
1556 005142 001326 BNE 2$ ;UPDATE BANK POINTER
;IF NOT END OF THIS MEMMAP ENTRY, THEN CONTINUE

```

```

1557 005144 062700 000002      ADD    #2,R0      ; ELSE UPDATE TO NEX MEMMAP ENTRY
1558 005150 022700 001554      CMP    #MEMMAP+40,R0 ; IF NOT END OF MEMMAP TABLE
1559 005154 001317              BNE    1$        ; THEN GO SIZE SOMEMORE
1560                               ; ELSE ALL DONE SIZING
1561 005156 000400      7$: BR    DISMAP ; GO TYPE OUT MEMORY MAP
1562
1563
1564                               ;*****
1565                               ;* ROUTINE WILL TYPE OUT MEMMAP, LOAD TEST MAP (SAVTST) AND CHECKS
1566                               ;* TO INSURE LOWEST 16K OF MEMORY IS AVAILABLE FOR TEST TO RUN
1567                               ;* STORAGE LOCATIONS:
1568                               ;* R0 = MEMMAP POINTER ... LO 128K
1569                               ;* R1 = COUNTER
1570                               ;* R2 = SAVTST POINTER ... LO 128K
1571                               ;*****
1572 005160 012700 001514      DISMAP: MOV #MEMMAP,R0 ; LOAD R0 WITH MEMMAP ADR
1573 005164 012737 023430 000004 MOV #ERRTRP,@#ERRVEC ; SET UP TIME OUT VECTOR
1574 005172 004567 014554      JSR    R5,$PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
1575 005176 023742              .WORD  MEMMES ; ADDRESS OF MESSAGE TO BE TYPED
1576                               ; "MEMORY MAP:"
1577                               ; GO TYPE THE MAP
1578 005200 004767 011622      JSR    PC,TYPMAP ; GO PRINT OUT THE FOLLOWING MESSAGE.
1579 005204 004567 014542      JSP    R5,$PRINT ; ADDRESS OF MESSAGE TO BE TYPED
1580 005210 001171              .WORD  $CRLF ; LOAD ADR OF SAVTST TABLE TO BE CLEARED
1581 005212 012702 001614      MOV    #SAVTST,R2 ; LOAD ADR OF MEMMAP TABLE
1582 005216 012700 001514      MOV    #MEMMAP,R0 ; LOAD COUNTER
1583 005222 012701 000020      MOV    #16.,R1 ; CLEAR SAVTST TABLE ENTRY
1584 005226 005012      1$: CLR    (R2) ; LOAD SAVTST FROM MEMMAP
1585 005230 012022      MOV    (R0)+,(R2)+ ; DECREMENT CTR 16 TIMES
1586 005232 077103      SOB    R1,1$ ; LOAD R0 WITH MAP OF 1ST 128K
1587 005234 016700 174254      MOV    MEMMAP,R0 ; MASK ALL BUT BOTTOM 16K
1588 005240 042700 177774      BIC    #177774,R0 ; IF BOTTOM 16K IS ALL THERE
1589 005244 022700 000003      CMP    #3,R0 ; THEN GO RUN
1590 005250 001404      BEQ    GMPR ; GO PRINT OUT THE FOLLOWING MESSAGE.
1591 005252 004567 014474      JSR    R5,$PRINT ; ADDRESS OF MESSAGE TO BE TYPED
1592 005256 024022              .WORD  INSUFF ; "FIRST 16K OF MEMORY NOT ALL THERE!"
1593                               ; FATAL ERROR HALT
1594                               ; MEMORY IS NOT CONFIGURED TO RUN THIS PROGRAM
1595
1596                               ;SBTTL MAP PARITY REGISTERS
1597                               ;*****
1598                               ;* SEARCH FOR PARITY REGISTERS PRESENT AND TYPE ADDRESSES OF THOSE FOUND
1599                               ;* THAT ARE FUNCTIONAL AND HAVE CORRESPONDING PARITY MEMORY
1600                               ;*****
1601 005262 012704 003372      GMPR:  MOV    #MPRX, R4 ; SET UP POINTER TO PARITY REG EXIST TABLE.
1602 005266 032777 000100 173634 BIT    #SW06,@SWR ; CHECK FOR INHIBIT PARITY SWITCH.
1603 005274 001040              BNE    GMPRO ; BR IF INHIBIT PARITY.
1604 005276 012703 002272      MOV    #MPRO, R3 ; SET UP TABLE POINTER
1605 005302 012737 005324 000004 MOV    #GMPRB,@#ERRVEC ; SET UP TIMEOUT TRAP SERVICE
1606 005310 042713 000001      GMPRA: BIC    #1,(R3) ; CLEAR FLAG BIT IN TABLE
1607 005314 005773 000000      TST    @#(R3) ; DOES THIS MEMORY PARITY REGISTER EXIST.
1608                               ;* IF IT DOESN'T EXIST, A TIMEOUT TRAP WILL GO TO "GMPRB".
1609                               ; SAVE IT IN THE PARITY REG EXIST TABLE.
1610                               ; SKIP TIMEOUT SERVICE CODE
1611                               ;* TIMEOUT COMES HERF

```

N3

MAP PARITY REGISTERS

SEQ 0039

```

1609 005324 062706 000004      GMPRB:  ADD    #4,SP      ;RESTORE STACK POINTER
1610 005330 052723 000001      BIS    #1, (R3)+      ;SET FLAG TO INDICATE REGISTER NOT PRESENT
1611 005334 012701 000021      GMPRBA: MOV    #17,R1    ;LOAD COUNTER
1612 005340 005023      GMPRC:  CLR    (R3)+    ;CLEAR ENTRY IN THIS GPR TABLE
1613 005342 077102      SOB    R1,GMPRC      ;DECREMENT COUNTER AND CONTINUE
1614      ;CLEARING COUNTER UNTIL COMPLETED.
1615 005344 020327 003372      CMP    R3, #MPRX     ;HAVE WE CHECKED ALL REGISTERS?
1616      ;NO GO BACK TO CHECK NEXT ONE
1617 005350 103757      BLO   GMPRA          ;NO GO BACK TO CHECK NEXT ONE
1618 005352 005014      CLR    (R4)          ;SET TERMINATOR IN PARITY REG EXIST TABLE.
1619 005354 012737 023430 000004      MOV    #ERRTRP,@#ERRVEC ; RESTORE TRAPCATCHER
1620 005362 005767 176004      TST   MPRX          ;ANY PARITY REGISTERS PRESENT?
1621 005366 001006      BNE   MPAMEM        ;YES - GO TEST CONTROLS PRESENT
1622 005370 004567 014356      JSR   R5, $PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
      005374 024103      .WORD MTR           ;ADDRESS OF MESSAGE TO BE TYPED
      ;"NO MEMORY PARITY REGISTERS FOUND"
1623 005376 005014      GMPRD:  CLR    (R4)    ;MAKE SURE TABLE IS CLEAR.
1624 005400 000167 000744      JMP    MANUAL        ;AND SKIP ALL CONTROLS TESTING
1625

```



```

1627 .SBTTL MAP PARITY MEMORY
1628 ;*****
1629 ;* MAP CORRESPONDENCE BETWEEN PARITY REGISTERS AND MEMORY,
1630 ;* AND TYPE RESULTS. SET WRITE WRONG PARITY IN ALL
1631 ;* REGISTERS PRESENT, THEN WRITE TEST LOCATION VIA DAT0 & READ TEST
1632 ;* LOCATION VIA DAT1, THEN CLEAR WRITE WRONG PARITY IN ALL REGISTERS.
1633 ;* NOTE: THAT IF PARITY MEMORY IS NOT LOCATED CORRECTLY THAT
1634 ;* IT IS IN ALL PROBABILITY DUE TO ONE OF THE FOLLOWING
1635 ;* FAILURES:
1636 ;* - SETTING WRITE WRONG PARITY DIDN'T CAUSE BAD PARITY TO BE WRITTEN
1637 ;* - PARITY GENERATE OR DETECT LOGIC FAILED
1638 ;* - PARITY ERROR BIT FAILED TO SET
1639 ;* - PARITY BITS IN MEMORY LOCATION FAILED
1640 ;* - I.E. BIT STUCK AT GOOD PARITY VALUE
1641 ;* STORAGE USED:
1642 ;* R0 = MEMMAP & PMEMAP TABLE INDEX
1643 ;* R1 = BANK POINTER
1644 ;* R2 = ADDRESS TO WRITE WRONG PARITY TO
1645 ;* R3 = MPR TABLE POINTER
1646 ;* R4 = ADDRESS OF PRESENT MPR TABLE ENTRY
1647 ;* R5 = MPR TABLES INDEX
1648 ;*****
1649 005404 004767 011262 MPAMEM: JSR PC,CLRPAR ;INITIALIZE ALL PARITY REGISTERS
1650 005410 012702 014000 MOV #14000,R2 ;SET ADDRESS TO 14000 TO WRITE WRONG PARITY
1651 005414 005767 173116 TST MMAVA ;IF NO MEM MGMT
1652 005420 001404 BEQ MAPRB ; THEN GO MAP PARITY MEMORY
1653 005422 012702 054000 MOV #54000,R2 ; ELSE SET ADDRESS POINTER TO MAP THRU PAR2
1654 005426 004767 005346 JSR PC,MMINIT ;SET UP MEM MGMT REGISTERS
1655
1656 005432 012703 001654 MAPRB: MOV #PMEMAP,R3 ;LOAD PMEMAP TABLE ADR
1657 005436 012704 000020 MOV #16.,R4 ;LOAD COUNTER
1658 005442 005023 1$: CLR (R3)+ ;CLEAR ALL OF TABLE
1659 005444 077402 SOB R4,1$ ;IF NOT DONE CLEARING THEN TRY SOMEMORE
1660
1661 005446 004767 011220 JSR PC,CLRPAR ;GO INITIALIZE ALL PARITY REGISTERS
1662 005452 005000 CLR R0 ;INIT INDEX FOR MEMMAP AND PMEMAP TABLES
1663 005454 012705 000002 MOV #2,R5 ;INIT INDEX FOR MPR TABLES
1664 005460 012701 000001 MOV #BIT0,R1 ;INIT BANK POINTER
1665
1666 005464 012703 002272 2$: MOV #MPRO,R3 ;INIT MPR TABLE ADDRESS POINTER
1667 005470 010304 3$: MOV R3,R4 ;UPDATE TO NEW TABLE
1668 005472 060504 ADD R5,R4 ;UPDATE INDEX THRU NEW TABLE
1669
1670 005474 032713 000001 BIT #BIT0,(R3) ;IF CSR IS NOT PRESENT
1671 005500 001021 BNE 4$ ; THEN GO TRY AGAIN
1672 005502 013773 001766 000000 MOV @#WWP,@(R3) ; ELSE SET WRITE WRONG PARITY BIT
1673 005510 011212 MOV (R2),(R2) ;WRITE WRONG PARITY
1674 005512 005712 TST (R2) ;READ WRONG PARITY
1675 005514 043773 001766 000000 BIC @#WWP,@(R3) ;CLEAR WRITE WRONG PARITY BIT
1676 005522 005773 000000 TST @ (R3) ;IF NO PARITY ERROR
1677 005526 100006 BPL 4$ ; THEN REGISTER DOES NOT CONTROL THIS MEMORY
1678 005530 012763 070032 000042 MOV #70032,42(R3) ; ELSE SAVE THE PARITY MASK IN TABLE
1679 005536 050160 001654 BIS R1,PMEMAP(R0) ;SET BANK IN PMEMAP
1680 005542 050114 BIS R1,(R4) ;SET BANK IN MPR TABLES
1681 005544 062703 000044 4$: ADD #44,R3 ;UPDATE TO NEXT MPR TABLE
1682 005550 022703 003372 CMP #MPRX,R3 ; IF NOT END OF TABLE
1683 005554 101345 BHI 3$ ; THEN TRY SOMEMORE

```

```

1684 005556 011212      MOV      (R2),(R2)      ; ELSE CLEAR BAD PARITY
1685
1686 005560 005767 172752 5$:  TST      MAVA          ;IF NO MEM MGMT
1687 005564 001417      BEQ      6$            ; THEN GO UPDATE FOR 16 BIT SYSTEM
1688 005566 062737 000400 172344  ADD      #400, @#KIPAR2 ; ELSE UPDATE PAR2 TO NEXT 8K BANK
1689 005574 006301      ASL      R1            ;UPDATE BANK POINTER TO NEXT BANK
1690 005576 001020      BNE      7$            ;IF STILL SOME TO CHECK IN THIS 128K BANK THEN DO IT
1691 005600 062700 000002      ADD      #2,R0         ; ELSE UPDATE INDEX FOR MEMMAP AND PMEMAP TABLES
1692 005604 062705 000002      ADD      #2,R5         ;UPDATE INDEX FOR GPR TABLES
1693 005610 012701 000001      MOV      #BIT0,R1     ;INIT BANK POINTER
1694 005614 022700 000040      CMP      #40,R0       ;IF END OF MEMMAP
1695 005620 001413      BEQ      9$            ; THEN GO TYPE MEM PARITY MAPS
1696 005622 000406      BR       7$            ;GO TRY SOMEMORE
1697
1698 005624 062702 040000 6$:  ADD      #40000,R2     ;UPDATE ADDRESS TO NEXT 8K BANK
1699 005630 106301      ASLB     R1            ;UPDATE BANK POINTR
1700 005632 032701 000020      BIT      #BIT4,R1     ;IF DONE WITH 16 BITS
1701 005636 001004      BNE      9$            ; THEN FINISHED
1702
1703 005640 036001 001514 7$:  BIT      MEMMAP(R0),R1 ;IF BANK DOES NOT EXIST
1704 005644 001745      BEQ      5$            ; THEN GET ANOTHER BANK
1705
1706 005646 000706      BR       2$            ; THEN GO DO SOMEMORE
1707
1708 005650 000167 000000 9$:  JMP      TMAP          ;GO TYPE PARITY MAPS
1709
1710      .SBTTL  DISPLAY PARITY MEMORY MAP
1711      ;*****
1712      ;* ROUTINE TO TYPE MAP OF WHERE PARITY MEMORY IS PRESENT AND WHICH
1713      ;* CONTROL REGISTERS CONTROL WHICH MEMORY.
1714      ;* STORAGE USED:
1715      ;* R0 = FIRST ADDRESS OF MAP TO BE TYPED
1716      ;* R1 = PARITY REGISTER ADDRESS ... BITS 14-0
1717      ;* R2 = PARITY REGISTER ADDRESS ... BITS 21-15
1718      ;* R3 = MPR TABLE ENTRY
1719      ;*****
1720 005654 004767 011012 TMAP: JSR      PC,CLRPAR  ;INITIALIZE ALL PARITY REGISTERS PRESENT
1721 005660 004567 014066 JSR      R5,$PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
1722 005664 023760      .WORD   MMAP         ;ADDRESS OF MESSAGE TO BE TYPED
1723      ;"PARITY MEMORY MAP:"
1724 005666 012703 002272      MOV      #MPRO,R3    ;INIT MPR TABLE POINTER
1725
1726 005672 032713 000001 1$:  BIT      #BIT0,(R3)   ;IF THIS REGISTER IS NOT PRESENT
1727 005676 001050      BNE      6$            ; THEN GO TRY AGAIN
1728
1729 005700 004567 014046 2$:  JSR      R5,$PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
1730 005704 024367      .WORD   MX1          ;ADDRESS OF MESSAGE TO BE TYPED
1731      ;"PARITY REGISTER AT"
1732 005706 011301      MOV      (R3),R1     ;SAVE PARITY REGISTER ADDRESS
1733 005710 042701 100000      BIC      #100000,R1  ;DEVELOP BITS 14-0 OF REGISTER ADDRESS
1734 005714 005767 172616      TST      MAVA        ;IF TYPE OF MEMORY MANAGEMENT
1735 005720 100404      BMI      3$            ; THEN 22 BIT BRANCH
1736 005722 001006      BNE      4$            ; OR 18 BIT BRANCH
1737 005724 012702 000001      MOV      #1,R2       ; ELSE 16 BIT SET BITS 21-15 FOR PRINT OUT
1738 005730 000405      BR       5$            ;AND GO TYPE OUT
1739

```

```

1736 005732 012702 000177 3$: MOV #177,R2 ;LOAD BITS 21-15 FOR PRINT OUT
1737 005736 000402 BR 5$ ;AND GO TYPE OUT
1738
1739 005740 012702 000007 4$: MOV #7,R2 ;LOAD BITS 21-15 FOR PRINT OUT
1740
1741 005744 010246 5$: MOV R2,-(SP) ;;SAVE R2 FOR TYPEOUT
;;TYPE ADDRESS BITS 21-15
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
005746 106746 MFPS -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
005750 105066 000001 CLR 1(SP) ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
005754 004767 015220 JSR PC,$TYPOS ;GO TO THE SUBROUTINE
005760 003 .BYTE 3 ;;TYPE 3 DIGIT(S)
005761 000 .BYTE 0 ;;SUPPRESS LEADING ZEROS
1742 005762 010146 MOV R1,-(SP) ;;SAVE R1 FOR TYPEOUT
;;TYPE ADDRESS BITS 14-0
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
005764 106746 MFPS -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
005766 105066 000001 CLR 1(SP) ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
005772 004767 015202 JSR PC,$TYPOS ;GO TO THE SUBROUTINE
005776 005 .BYTE 5 ;;TYPE 5 DIGIT(S)
005777 001 .BYTE 1 ;;TYPE LEADING ZEROS
1743 006000 004567 013746 JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
006004 024415 .WORD MX2 ;ADDRESS OF MESSAGE TO BE TYPED
;"CONTROLS"
1744 006006 010300 MOV R3,R0 ;SET UP R0 FOR TYPMAP ROUTINE
1745 006010 062700 000002 ADD #2,R0 ;POINT TO MAP ENTRY FOR MPR TABLE
1746 006014 004767 011006 JSR PC,TYPMAP ;GO TYPE MEMORY COVERED BY THIS REGISTER
1747
1748 006020 062703 000044 6$: ADD #44,R3 ;UPDATE TO NEXT REGISTER IN TABLE
1749 006024 022703 003372 CMP #MPRX,R3 ;IF NOT END OF MPR TABLE
1750 006030 101320 BHI 1$ ; THEN DO SOMEMORE
1751
1752 006032 012700 000010 MOV #10,R0 ;LOAD DELAY
1753 006036 012701 177777 7$: MOV #-1,R1 ;LOAD DELAY
1754 006042 077101 8$: SOB R1,8$ ;ALLOW DELAY TO INSURE PRINT OUT IS
1755 006044 077004 SOB R0,7$ ;COMPLETED BEFORE RESET OCCURS
1756
1757 006046 005737 003372 TST @#MPRX ;IF PARITY REGISTERS TO TEST
1758 006052 001002 BNE CTRLS ; THEN GO TEST
1759 006054 000167 000270 JMP MANUAL ; ELSE JUMP OVER TESTS
1760
1761
1762
1763 .SBTTL TEST PARITY REGISTERS
1764 ;;*****
1765 ;* SHOW THAT BITS 0, 2, 5 - 11 AND 15 OF EACH PARITY REGISTER PRESENT
1766 ;* CAN BE SET AND CLEARED.
1767 ;* THIS IS A ONCE ONLY TEST.
1768 ;;*****
1769
1770 006060 012703 002272 CTRLS: MOV #MPRO, R3 ;LOAD INITIAL TABLE ADDRESS FOR A POINTER
1771 006064 011302 1$: MOV (R3),R2 ;GET CSR ADDRESS INTO R2
    
```

TEST PARITY REGISTERS

```

1772 006066 032702 000001      BIT      #BIT0,R2      ; ELSE IF CSR DOES NOT EXIST
1773 006072 001052              BNE      105$         ; THEN BRANCH
1774 006074 016367 000042 173404  MOV      42(R3),RESRVD ; ELSE LOAD MASK, IF EQ TO 0
1775 006102 001446              BEQ      105$         ; THEN DO NOT TEST
1776 006104 012700 000001      MOV      #1,R0        ; LOAD R0 WITH 1ST BIT TO BE TESTED
1777 006110 005012              CLR      (R2)         ; INITIALIZE THE PARITY REGISTER
1778 006112 011201              MOV      (R2),R1      ; READ THE CONTENTS OF THE PARITY REGISTER
1779 006114 046701 173366      BIC      #_SRVD,R1    ; CLEAR RESERVED BITS, IF EQ 0
1780 006120 001405              BEQ      2$          ; THEN BRANCH
1781 006122 004767 010566      30008$: JSR      PC,        SPRNT ; SET UP VALUES FOR ERROR PRINTING.
          006126 004767 011712      JSR      PC,        $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
          006132 000001              .WORD    1           ; ERROR TYPE CODE.
1782 006134 030067 173346      2$:     BIT      R0,RESRVD ; IF THIS BIT IS RESERVED
1783 006140 001025              BNE      3$          ; THEN BRANCH AND DON'T TEST
1784 006142 010012              MOV      R0,(R2)     ; ELSE SET THIS BIT IN CSR
1785 006144 011201              MOV      (R2),R1    ; READ AND SAVE CONTENTS OF CSR
1786 006146 005012              CLR      (R2)         ; CLEAR THE CSR
1787 006150 046701 173332      106$:   BIC      RESRVD,R1  ; CLEAR RESERVED BITS
1788 006154 020001              CMP      R0,        R1 ; COMPARE THE CHECK WORD WITH THE DATA READ.
          006156 001405              BEQ      30010$     ; BRANCH OVER ERROR CALL IF GOOD DATA.
          006160 004767 010572      30009$: JSR      PC,        SPRNT0 ; SET UP VALUES FOR ERROR PRINTING.
          006164 004767 011654      JSR      PC,        $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
          006170 000001              .WORD    1           ; ERROR TYPE CODE.
          006172              30010$:
1789                                ; MAKE SURE BIT WAS CLEARED OUT OF CSR
1790 006172 011201              MOV      (R2),R1    ; READ THE CONTENTS OF THE PARITY REGISTER
1791 006174 046701 173306      BIC      RESRVD, R1  ; CLEAR BITS WHICH ARE RESERVED
1792 006200 001405              BEQ      3$          ; CHECK OTHER BITS - BRANCH IF OK
1793 006202 004767 010506      30011$: JSR      PC,        SPRNT ; SET UP VALUES FOR ERROR PRINTING.
          006206 004767 011632      JSR      PC,        $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
          006212 000001              .WORD    1           ; ERROR TYPE CODE.
1794 006214 006300      3$:     ASL      R0          ; ROTATE TO GET NEXT BIT TO BE TESTED
1795 006216 001346              BNE      2$          ; BRANCH IF NOT DONE WITH ALL BITS
1796 006220 062703 000044      105$:   ADD      #44,R3     ; UPDATE PTR TO NEXT ENTRY
1797 006224 022703 003372      CMP      #MPRX,R3   ; IF NOT DONE WITH TABLE
1798 006230 003315              BGT      1$          ; THEN TRY AGAIN
1799
1800                                ; *****
1801                                ; * SHOW THAT RESET CLEARS BITS 0,2 AND 15 OF EACH PARITY REGISTER PRESENT.
1802                                ; * ALSO BIT 14 IN PARITY CSR IF MEMORY IS SET FOR 22 BIT ADDRESSING
1803                                ; * THIS IS A ONCE ONLY TEST.
1804                                ; *****
1805
1806 006232 012704 002272      RESCHK: MOV      #MPRO, R4 ; LOAD INITIAL TABLE ADDRESS FOR A POINTER
1807 006236 022704 003372      1$:     CMP      #MPRX,R4   ; IF END OF TABLE
          006242 003411              BLE      100$        ; THEN BRANCH
1809 006244 032714 000001      BIT      #BIT0,(R4)  ; ELSE IF CSR DOES NOT EXIST
1910 006250 001003              BNE      101$        ; THEN BRANCH
1811 006252 012774 177777 000000  MOV      #-1,@(R4)   ; ELSE LOAD CSR WITH ALL 1 S
1812 006260 062704 000044      101$:   ADD      #44,R4    ; UPDATE POINTER
1813 006264 000764              BR       1$          ; TRY AGAIN
1814 006266 000005      100$:   RESET      ; RESET THE WORLD
1815 006270 012702 002272      MOV      #MPRO,R2   ; LOAD INITIAL ADDRESS FOR POINTER
1816 006274 022702 003372      2$:     CMP      #MPRX,R2 ; IF END OF TABLE
          006300 003423              BLE      MANUAL     ; THEN BRANCH
1818 006302 032712 000001      BIT      #BIT0,(R2) ; ELSE IF CSR DOES NOT EXIST
1819 006306 001015              BNE      30013$     ; ;V THEN BRANCH

```

TEST PARITY REGISTERS

```

1820 006310 017201 000000      MOV      @R2),R1      ; ELSE SAVE CONTENTS OF CSR
1821 006314 005072 000000      CLR      @R2)        ; CLEAR THE CSR
1822 006320 042701 037772      BIC      #37772,R1   ; TEST FOR BIT14 TOO
1823                                     ; 18 BIT MODE = BIT14 ALWAYS READ AS ZERO
1824                                     ; 22 BIT MODE - BIT14 R/W CLEARED BY RESET
1825 006324 005701      4$:      TST      R1      ; CHECK IF REST WERE CLEARED BY RESET
1826 006326 001405      BEQ      30013$     ; BRANCH OVER ERROR CALL IF GOOD DATA.
      006330 004767 010360      30012$: JSR      PC,      $SPRNT ; SET UP VALUES FOR ERROR PRINTING.
      006334 004767 011504      JSR      PC,      $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
      006340 000001      .WORD    1          ; ERROR TYPE CODE.
      006342      30013$:      ADD      #44,R2      ; UPDATE POINTER
1827 006342 062702 000044      BR       2$        ; BRANCH BACK TO CHECK NEXT REGISTER
1828 006346 000752
1829
1830
1831 006350 005067 173406      MANUAL: CLR      FSTADR ; INIT FIRST ADDRESS
1832 006354 105767 173376      TSTB    SELFLG     ; CHECK FOR SELECT PARAMETER SETUP
1833 006360 001002      BNE     MANUL1    ; IF FLAG SET GET USERS PARAMETERS
1834 006362 000167 000402      JMP     MANUL2    ; ELSE USE DEFAULT DATA
1835 006366      MANUL1: JSR      R5,      $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
      006366 004567 013360      .WORD    FADMES     ; ADDRESS OF MESSAGE TO BE TYPED
      006372 024453      ; "FIRST ADDRESS:"
      ; FIRST ADDRESS 8K BOUNDARY
1836                                     ; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDOCT ROUTINE
1837                                     ; * WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
      006374 106746      MFPS    -(SP)      ; PUT THE PROCESSOR STATUS ON THE STACK
      006376 105066 000001      CLRB    1(SP)     ; HIGH BYTE CLEARED TO INSURE KERNEL MODE
      ; ON PSW RETURN.
      ; GO TO THE SUBROUTINE
1838 006402 004767 013170      JSR      PC,      $RDOCT ; ON 8K BOUNDARY?
1839 006406 032716 037777      BIT     #37777,(SP) ; IF NO REASK
1840 006412 001365      BNE     MANUL1    ; SAVE ORIGINAL HIGH BITS
1841 006414 016703 013330      MOV     $HI OCT,R3 ; AND LOW BITS
1842 006420 011604      MOV     (SP),R4   ; DIVIDE HIGH ADDRESS INTO
1843 006422 006267 013322      ASR     $HI OCT   ; NUMBER OF 128K BANKS AND
1844 006426 006016      ROR     (SP)      ; NUMBER OF 8K BANK WITHIN
1845 006430 006267 013314      ASR     $HI OCT   ; 128K BANK
1846 006434 006016      ROR     (SP)      ; MAKE NUMBER OF 128K BANKS INDEX
1847 006436 006367 013306      ASL     $HI OCT   ; GET START OF TEST TABLE
1848 006442 012700 001714      MOV     #BITPT,R0 ; ADD INDEX
1849 006446 066700 013276      ADD     $HI OCT,R0 ; SET UP TO ALIGN 8K BANK COUNT
1850 006452 012701 000012      MOV     #12,R1   ; ALIGN COUNT
1851 006456 006016      1$:     ROR     (SP)   ; LOOP UNTIL DONE
1852 006460 077102      SOB     R1,1$    ; INIT 8K BANK POINTER IN 128K WORD
1853 006462 052710 000001      BIS     #BIT0,(R0) ; SHIFT BIT UNTIL COUNT = 0
1854 006466 005716      2$:     TST     (SP)   ; WHEN ZERO DONE
1855 006470 001403      BEQ     3$      ; SHIFT BIT
1856 006472 006310      ASL     (R0)     ; SUBTRACT FROM COUNT
1857 006474 005316      DEC     (SP)     ; LOOP BACK
1858 006476 000773      BR      2$      ; GET FIRST ADDRESS OF MEMORY TABLE
1859 006500 012702 001514      3$:     MOV     #MEMMAP,R2 ; ADD INDEX
1860 006504 066702 013240      ADD     $HI OCT,R2 ; IS BIT JUST LOCATED, SET IN MEM. TABLE
1861 006510 031012      BIT     (R0),(R2) ; IF NO BANK EXISTS...REASK
1862 006512 001725      BEQ     MANUL1
      006514 004567 013232      4$:     JSR      R5,      $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
      006520 024540      .WORD    LADMES     ; ADDRESS OF MESSAGE TO BE TYPED

```

```

1863      006522 106746
          006524 105066 000001
          006530 004767 013042
1864 006534 005716
1865 006536 001010
1866 006540 005767 013204
1867 006544 001005
1868 006546 016716 172402
1869 006552 016767 172400 013170
1870 006560 020467 013164 5$:
1871 006564 101353
1872 006566 103402
1873 006570 020316
1874 006572 101350
1875 006574 012700 000020 6$:
1876 006600 012701 001714
1877 006604 012702 001614
1878 006610 052122 7$:
1879 006612 077002
1880 006614 020367 013130
1881 006620 103403
1882 006622 101027
1883 006624 020116
1884 006626 101025
1885 006630 062704 040000 8$:
1886
1887 006634 005503
1888 006636 012700 000017
1889 006642 012701 001714
1890 006646 006321
1891 006650 006121 9$:
1892 006652 077002
1893 006654 103423
1894 006656 012700 000020
1895 006662 012701 001714
1896 006666 012702 001514
1897 006672 032122 10$:
1898 006674 001337
1899 006676 077003
1900 006700 000753
1901 006702 012700 000020 11$:
1902 006706 012701 001714
1903 006712 012702 001514
1904 006716 032122 12$:
1905 006720 001007
1906 006722 077003
1907 006724 012706 001100 13$:
1908 006730 004567 013016
          006734 024563
          006736 000604
1909 006736 000604
1910 006740 012706 001100 14$:
1911 006744 004567 013002
    
```

```

; "LAST ADDRESS:"
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDOCT ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
MFPS (SP) ;PUT THE PROCESSOR STATUS ON THE STACK
CLRFB 1(SP) ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
JSR PC, $RDOCT ;GO TO THE SUBROUTINE
TST (SP) ;CHECK IF LOW BITS ZERO
BNE 5$ ;IF NOT, NO DEFAULT
TST $HIOCT ;CHECK IF HIGH BITS ZERO
BNE 5$ ;IF NOT, NO DEFAULT
MOV $TMP2,(SP) ;IF BOTH ZERO, FILL IN DEFAULT
MOV $TMP3,$HIOCT ;FOR LOW AND HIGH BITS
5$: CMP R4,$HIOCT ;CHECK FOR LAST ADDR. BELOW FIRST
BHI 4$ ;IF YES...REASK
BLO 6$ ;IF LAST HIGHER GO ON
CMP R3,(SP) ;IF EQUAL CHECK LOW BITS
BHI 4$ ;IF LOW BITS LOWER...REASK
6$: MOV #20,R0 ;TABLE COUNTER
MOV #BITPT,R1
MOV #SAVTST,R2
7$: BIS (R1)+,(R2)+ ;STORE BITPT IN SAVTST MAP
SOB R0,7$ ;DO 16 TIMES
CMP R3,$HIOCT ;COMPARE HIGH BITS OF FIRST TO LAST
BLO 8$ ;IF LOWER SEE IF NEXT BANK EXISTS
BHI 11$ ;IF HIGHER MUST BE LAST BANK
CMP R4,(SP) ;IF EQUAL CHECK LOW BITS
BHI 11$ ;IF LOW BITS FIRST HIGHER LAST BANK
8$: ADD #40000,R4 ;UPDATE TO NEXT BANK
ADC R3
MOV #17,R0 ;SET UP TO UPDATE POINTER
MOV #BITPT,R1 ;GET START ADDRESS OF TABLE
ASL (R1)+ ;ROTATE POINTER WITHIN
9$: ROL (R1)+ ;TABLE
SOB R0,9$ ;UNTIL ALL LOCATIONS DONE
BCS 13$ ;BANK DOESN'T MAP
MOV #20,R0 ;SET UP TO SEE IF ONE EXISTS
MOV #BITPT,R1 ;GET START ADDRESS OF POINTER TABLE
MOV #MEMMAP,R2 ;GET START ADDRESS OF MEMORY TABLE
10$: BIT (R1)+,(R2)+ ;TEST IF BANK EXISTS
BNE 6$ ;IF MATCH UPDATE
SOB R0,10$ ;DO ALL OF TABLE
BR 8$
11$: MOV #20,R0 ;MAKE SURE LAST BANK
MOV #BITPT,R1 ;WAS MAPPED BY MEMORY
MOV #MEMMAP,R2 ;SIZING ROUTINE
12$: BIT (R1)+,(R2)+ ;
BNE 14$
SOB R0,12$
13$: MOV #STACK,SP ;RESET STACK
JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
;ADDRESS OF MESSAGE TO BE TYPED
;"?ADDRESS IN UNMAPPED BANK?"
BR MANUAL ;LOOP BACK AND START OVER
14$: MOV #STACK,SP ;RESET STACK
JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
    
```



```
007134 004767 010704      JSR   PC,   $ERROR   ;*** ERROR *** (GO TYPE A MESSAGE)
007140 000002              .WORD   2           ;ERROR TYPE CODE.
007142              30015$:
1955 007142 062700 000002      ADD   #2,   R0       ;ADD #2 TO PHYSICAL ADDRESS
1956 007146 077514              SOB   R5,   2$      ;BRANCH IF MORE IN CURRENT BLOCK.
007150 004767 004214      JSR   PC,   MMUP    ;FIND NEXT BLOCK AND LOOP TO 1$.

1957
1958
1959      ;* CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY
      ;* DOWNWARDS WORD ADDRESSING.
1960 007154 004467 004074      JSR   R4,   INITDN  ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1961 007160 010200 3$:      MOV   R2,   R0       ;SET UP TO CALCULATE PHYSICAL ADDRESS
1962 007162 162700 000002      SUB   #2,   R0       ;GET LAST ADDRESS OF BLOCK
1963 007166 004767 005104      JSR   PC,   PHYADR  ;GET PHYSICAL ADDRESS INTO R0
1964 007172 014201 4$:      MOV   -(R2), R1     ;GET THE DATA FROM MEMORY
1965 007174 020001      CMP   R0,   R1     ;COMPARE THE CHECK WORD WITH THE DATA READ.
007176 001405      BEQ   30017$      ;BRANCH OVER ERROR CALL IF GOOD DATA.
007200 004767 007552 30016$: JSR   PC,   SPRNT0  ;SET UP VALUES FOR ERROR PRINTING.
007204 004767 010634      JSR   PC,   $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
007210 000002              .WORD   2           ;ERROR TYPE CODE.
007212              30017$:
1966 007212 162700 000002      SUB   #2,   R0       ;DEC DATA BY 2
1967 007216 077513              SOB   R5,   4$      ;BRANCH IF MORE IN CURRENT BLOCK.
007220 004767 004510      JSR   PC,   MMDOWN ;FIND NEXT BLOCK AND LOOP TO 3$.
```



1969

007224  
007224 004567 010302  
1970  
1971 007230 004467 003722  
1972 007234 010200  
1973 007236 004767 005034  
1974 007242 006305  
1975 007244 110022  
1976 007246 005200  
1977 007250 077503  
007252 004767 004112  
1978  
1979  
1980  
1981 007256 004467 003772  
1982 007262 010200  
1983 007264 005300  
1984 007266 004767 005004  
1985 007272 006305  
1986 007274 114201  
1987 007276 120001  
1988 007300 001405  
007302 004767 007450  
007306 004767 010532  
007312 000003  
007314  
1989 007314 005300  
1990 007316 077512  
007320 004767 004410  
1991  
1992

```

*****
; *TEST 2 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY
; * R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
; * R1 = DATA READ FROM MEMORY (WAS)
; * R2 = VIRTUAL ADDRESS
; * R3 = NOT USED
; * R4 = NOT USED
; * R5 = BLOCK BOUNDARY BIT MASK.
*****
TST2:
      JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
; * UPWARDS BYTE ADDRESSING.
      JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:   MOV R2, R0 ;SET UP TO CALCULATE PHYSICAL ADDRESS
      JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
      ASL R5 ;MAKE TEST COUNTER BYTE VALUE
2$:   MOVB R0, (R2)+ ;WRITE VALUE OF ADDRESS INTO ADDRESS
      INC R0 ;ADD ONE TO PHYSICAL ADDRESS
      SOB R5, 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

; * CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY
; * DOWNWARDS BYTE ADDRESSING.
      JSR R4, INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
3$:   MOV R2, R0 ;SET UP TO CALCULATE PHYSICAL ADDRESS
      DEC R0 ;GET LAST BYTE ADDRESS OF BLOCK
      JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
      ASL R5 ;MAKE TEST COUNTER BYTE VALUE
4$:   MOVB -(R2), R1 ;GET THE DATA FROM MEMORY
      CMPB R0, R1 ;CHECK THE DATA...LC BYTE ONLY VALID.
      BEQ 30019$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30018$: JSR PC, SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
      JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD 3 ;ERROR TYPE CODE.
30019$: DEC R0 ;DEC DATA BY 1
      SOB R5, 4$ ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR PC, MMDOWN ;FIND NEXT BLOCK AND LOOP TO 3$.

```

007324  
007324 004567 010202  
1993  
1994 007330 004467 003720  
1995 007334 010200  
1996 007336 162700 000002  
1997 007342 004767 004730  
1998 007346 005100  
1999 007350 010042

```

*****
; *TEST 3 WRITE 1'S COMPLEMENT VALUE OF ADDRESS INTO ADDRESS.
; * R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
; * R1 = DATA READ FROM MEMORY (WAS)
; * R2 = VIRTUAL ADDRESS
; * R3 = NOT USED
; * R4 = NOT USED
; * R5 = BLOCK BOUNDARY BIT MASK.
*****
TST3:
      JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
; * DOWNWARDS WORD ADDRESSING.
      JSR R4, INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:   MOV R2, R0 ;SET UP TO CALCULATE PHYSICAL ADDRESS
      SUB #2, R0 ;GET LAST ADDRESS OF BLOCK
      JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
      COM R0 ;COMPLEMENT THE ADR
2$:   MOV R0, (R2) ;PUT DATA INTO MEMORY

```

```

2000 007352 062700 000002      ADD    #2,    R0    ;+2 TO DATA--ADR GOES DOWN SO COM GOES UP
2001 007356 077504             SOB    R5,    2$   ;BRANCH IF MORE IN CURRENT BLOCK.
      007360 004767 004350      JSR    PC,    MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

2002
2003
2004      ;* CHECK COMPLEMENT DATA WRITTEN DOWN
      ;* UPWARDS WORD ADDRESSING.
2005 007364 004467 003566      JSR    R4,    INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2006 007370 010200             3$:   MOV    R2,    RO    ;SET UP TO CALCULATE PHYSICAL ADDRESS
2007 007372 004767 004700      JSR    PC,    PHYADR ;GET PHYSICAL ADDRESS INTO RO
2008 007376 005100             COM    RO        ;COMPLEMENT IT
2009 007400             4$:   MOV    (R2)+, R1    ;GET THE DATA FROM MEMORY UNDER TEST.
      007400 012201             CMP    RO,    R1    ;COMPARE THE CHECK WORD WITH THE DATA READ.
      007402 020001             BEQ    30021$,   ;BRANCH OVER ERROR CALL IF GOOD DATA.
      007404 001405             30020$: JSR    PC,    SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
      007406 004767 007370      JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      007412 004767 010426      .WORD 2          ;ERROR TYPE CODE.
      007416 000002
      007420
2010 007420 162700 000002      SUB    #2,    R0    ;COUNT DOWN WITH ADDRESS
2011 007424 077513             SOB    R5,    4$   ;BRANCH IF MORE IN CURRENT BLOCK
      007426 004767 003736      JSR    PC,    MMUP ;FIND NEXT BLOCK AND LOOP TO 3$.

2012
2013

```

```

;*****
;*TEST 4      WRITE BANK # INTO ALL ADDRESSES IN A 8K BANK
;*      RO = DATA WRITTEN INTO MEMORY (SHOULD BE)
;*      R1 = DATA READ FROM MEMORY (WAS)
;*      R2 = VIRTUAL ADDRESS
;*      R3 = NOT USED
;*      R4 = NOT USED
;*      R5 = BLOCK BOUNDARY BIT MASK.
;*****

```

```

      007432
      007432 004567 010074      TST4: JSR    R5,    $SCOPE ;GO TO SCOPE ROUTINE.
2014
2015 007436 004467 003514      ;* UPWARDS BYTE ADDRESSING.
2016 007442 004767 004726      JSR    R4,    INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2017 007446 006305             1$:   JSR    PC,    BANKNO ;GET THE BANK NUMBER INTO RO
2018 007450 110022             ASL    R5,    ;MAKE TEST COUNTER BYTE VALUE
2019 007452 077502             2$:   MOVB   RO,    (R2)+ ;WRITE BANK # INTO ALL ADDRESSES
      007454 004767 003710      SOB    R5,    2$   ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR    PC,    MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

2020
2021
2022      ;* CHECK THAT DATA WRITTEN ABOVE CAN BE READ
      ;* UPWARDS BYTE ADDRESSING.
2023 007460 004467 003472      JSR    R4,    INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2024 007464 004767 004704      3$:   JSR    PC,    BANKNO ;GET THE BANK NUMBER INTO RO
2025 007470 006305             ASL    R5,    ;MAKE TEST COUNTER BYTE VALUE
2026 007472 112201             4$:   MOVB   (R2)+, R1    ;READ THE DATA OUT OF MEMORY
2027 007474 120001             CMPB   RO,    R1    ;CHECK DATA...LOW BYTE ONLY VALID
2028 007476 001405             BEQ    30023$,   ;BRANCH OVER ERROR CALL IF GOOD DATA.
      007500 004767 007260      30022$: JSR    PC,    SPRNT1 ;SET UP VALUES FOR ERROR PRINTING.
      007504 004767 010334      JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      007510 000003             .WORD 3          ;ERROR TYPE CODE.
      007512
2029 007512 077511             SOB    R5,    4$   ;BRANCH IF MORE IN CURRENT BLOCK
      007514 004767 003650      JSR    PC,    MMUP ;FIND NEXT BLOCK AND LOOP TO 3$.

2030
2031

```

```

;*****

```

```

; *TEST 5      WRITE 1'S COMPLEMENT OF BANK #.
; *          R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
; *          R1 = DATA READ FROM MEMORY (WAS)
; *          R2 = VIRTUAL ADDRESS
; *          R3 = NOT USED
; *          R4 = NOT USED
; *          R5 = BLOCK BOUNDARY BIT MASK.
; *****
TST5:
007520 007520 004567 010006      JSR    R5,    $SCOPE ;GO TO SCOPE ROUTINE.
2032 007524 004467 003524      ; * DOWNWARDS BYTE ADDRESSING.
2033 007530 004767 004640      JSR    R4,    INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2034 007534 006305                1$: JSR    PC,    BANKNO ;GET THE BANK NUMBER INTO R0
2035 007536 005100                ASL    R5     ;MAKE TEST COUNTER BYTE VALUE
2036 007540 110042                COM    R0     ;1'S COMPLEMENT OF BANK #
2037 007542 077502                MOVB   R0,    -(R2) ;PUT 1'S COM OF BANK # INTO MEMORY
2038 007544 004767 004164      SOB    R5,    2$     ;BRANCH IF MORE IN CURRENT BLOCK.
;                               JSR    PC,    MMDOWN ;FIND NEXT BLOCK AND LOOP TO 1$.

; * CHECK THAT DATA WRITTEN CAN BE READ.
; * DOWNWARDS BYTE ADDRESSING.
2042 007550 004467 003500      3$: JSR    R4,    INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2043 007554 004767 004614      JSR    PC,    BANKNO ;GET THE BANK # INTO R0
2044 007560 006305                ASL    R5     ;MAKE TEST COUNTER BYTE VALUE
2045 007562 005100                COM    R0     ;SET 1'S COMPLEMENT OF BANK #
2046 007564 114201                MOVB   -(R2), R1    ;READ DATA OUT OF MEMORY
2047 007566 120001                CMPB   R0,    R1    ;CHECK DATA...LOW BYTE ONLY VALID
2048 007570 001405                BEQ    30025$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
;                               JSR    PC,    SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
;                               JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
;                               .WORD 3 ;ERROR TYPE CODE.
007572 004767 007160      30024$: JSR    PC,    SPRNTO
007576 004767 010242      JSR    PC,    $ERROR
007602 000003                .WORD 3
007604                30025$: SOB    R5,    4$     ;BRANCH IF MORE IN CURRENT BLOCK.
2049 007604 077511 004122      JSR    PC,    MMDOWN ;FIND NEXT BLOCK AND LOOP TO 3$.

; * IF PROGRAM HAS RELOCATED TO UPPER BOUNDARY, THE ADDRESSING
; * TESTS WILL BE EXECUTED FOR ALL BANKS AND WORST CASE NOISE TESTING
; * WILL BE LIMITED TO BANKS 0,1.
; * ALL OTHER BANKS WILL BE EXERCISED FOR WORST CASE NOISE TESTING
; * WHEN THE PROGRAM OCCUPIES BANKS 0,1.
2058 007612 032767 000001 170714 SECT2: BIT    #BIT0,PRGMAP ;IS PROGRAM RELOCATED
2059 007620 001014                BNE    2$     ;IF NO,CONTINUE TESTING ALL BANKS
2060 007622 012700 000020      MOV    #20,R0 ;CLEAR ALL LOCATIONS OF TEST MAP
2061 007626 016701 172160      MOV    .TSTMAP,R1 ;TEST MAP TABLE
2062 007632 005021                1$: CLR    (R1)+
2063 007634 077002                SOB    R0,1$  ;LOOP UNTIL DONE
2064 007636 016700 171752      MOV    SAVTST,R0 ;GET LOWER 128K MAP
2065 007642 042700 177776      BIC    #177776,R0 ;DO ONLY FIRST BANK
2066 007646 010067 171702      MOV    R0,TSTMAP ;FOR DATA TESTS
2067 007652                2$: ;CONTINUE TESTING

.SBTTL SECTION 2:      WORST CASE NOISE TESTS
; *****
; * THESE TESTS WRITE MEMORY WORST CASE NOISE TEST PATTERNS THROUGHOUT

```

2073  
 2074  
 2075

```

;* MEMORY AND CHECK THAT THEY CAN BE WRITTEN AND READ.
;*****
;*****
;*TEST 6      WRITE A CONSTANT INTO MEMORY.
;*           THE CONSTANT IS USER SELECTABLE (DEFAULT = 0).
;*           R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
;*           R1 = DATA READ FROM MEMORY (WAS)
;*           R2 = VIRTUAL ADDRESS
;*           R3 = NOT USED
;*           R4 = NOT USED
;*           R5 = BLOCK BOUNDARY BIT MASK.
;*****
    
```

007652  
 007652 004567 007654  
 2076 007656 016700 172102  
 2077 007662 004467 003270  
 2078 007666 010022  
 2079 007670 077502  
 007672 004767 003472  
 2080  
 2084

```

†TST6:
TST6A: JSR    R5,    $SCOPE ;GO TO SCOPE ROUTINE.
        MOV    .CONST, R0 ;GET USER CONSTANT
        JSR    R4,    INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:     MOV    R0,    (R2)+ ;WRITE CONSTANT INTO MEMORY.
        SOB   R5,    1$ ;BRANCH IF MORE IN CURRENT BLOCK
        JSR   PC,    MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
    
```

```

;*****
;*TEST 7      READ MEMORY AND COMPARE TO CONSTANT.
;* IMPORTANT: THIS TEST SHOULD NOT BE RUN WITHOUT FIRST RUNNING TEST $TN.
;*****
    
```

007676  
 007676 004567 007630  
 2085 007702 016700 172056  
 2086 007706 004467 003244  
 2087 007712  
 007712 012201  
 007714 020001  
 007716 001405  
 007720 004767 007056  
 007724 004767 010114  
 007730 000004  
 007732  
 2088 007732 077511  
 007734 004767 003430

```

†TST7:
        JSR    R5,    $SCOPE ;GO TO SCOPE ROUTINE.
        MOV    .CONST, R0 ;GET USER CONSTANT
        JSR    R4,    INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:     MOV    (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
        CMP    R0,    R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
        BEQ   30027$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30026$: JSR    PC,    SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
        JSR   PC,    $ERROR ;*** ERRJR *** (GO TYPE A MESSAGE)
        .WORD 4 ;ERROR TYPE CODE.
30027$: SOB   R5,    1$ ;BRANCH IF MORE IN CURRENT BLOCK
        JSR   PC,    MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
    
```

2090  
 2091  
 2092  
 2093 007740 032777 000400 171162  
 2094 007746 001416  
 2095 007750 017746 171154  
 2096 007754 042716 177740  
 2097 007760 022726 000006  
 2098 007764 001007  
 2099 007766 162767 000001 171076  
 2100 007774 162767 000024 171074  
 2101 010002 000725  
 2103  
 2104

```

;* SPECIAL CHECK TO SEE IF TEST 6 IS SELECTED THRU THE SWR.
;* ALLOWS THE OPERATOR TO SWITCH BACK AND FORTH BETWEEN TESTS 6 AND 7
;* BY SIMPLY "TOGGLING" SW00 WHEN SW01, SW02, AND SW08 ARE SET.
        BIT    $SW08, @SWR ;CHECK THAT LOOP ON TEST BIT SET
        BEQ   TST10 ;BRANCH IF NOT LOOP ON TEST
        MOV   @SWR, -(SP) ;GET SWITCH REGISTER DATA.
        BIC   #177740,(SP) ;CLEAR NON-TEST-NUMBER SWITCHES.
        CMP   #6, (SP)+ ;CHECK IF TEST 6 IN SWITCHES.
        BNE   TST10 ;BRANCH IF NOT TEST 6
        SUB   #1, $TSTNM ;RESET TEST NUM
        SUB   #TST7-TST6,$LPADR ;RESET LOOP ADR
        BR    TST6A ;GO TO TEST 6
    
```

```

;*****
;*TEST 10     WORSE CASE NOISE (PARITY) WORD TESTING
;*           CHECK MEMORY WITH A SERIES OF PATTERNS
;*****
    
```

010004  
 010004 004567 007522

```

†TST10: JSR    R5,    $SCOPE ;GO TO SCOPE ROUTINE.
    
```

N4

```

2105 010010 016704 172014      MOV      .MPPAT, R4      ;INITIALIZE PATTERN TABLE POINTER
2106 010014 004767 006020      JSR      PC,          CKPMER ;CHECK FOR NON-TRAP PARITY MEMORY ERORS.
2107 010020 012400              MOV      (R4)+,      RO      ;GET THE DATA PATTERN.
2108 010022 001417              BEQ      TST11        ;BR IF END OF TABLE.
2109 010024 004467 003126      JSR      R4,          INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2110 010030 010012              MOV      RO,          (R2)   ;PUT DATA PATTERN INTO MEMORY.
2111 010032 012201              MOV      (R2)+,      R1      ;GET THE DATA FROM MEMORY UNDER TEST.
      010034 020001              CMP      RO,          R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
      010036 001405              BEQ      30029$       ;BRANCH OVER ERROR CALL IF GOOD DATA.
      010040 004767 006736      JSR      PC,          SPRINT2 ;SET UP VALUES FOR ERROR PRINTING.
      010044 004767 007774      JSR      PC,          $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
      010050 000004              .WORD                    ;ERROR TYPE CODE.
      010052              30029$:
2112 010052 077512              SOB      R5,          2$     ;BRANCH IF MORE IN CURRENT BLOCK
      010054 004767 003310      JSR      PC,          MMUP   ;FIND NEXT BLOCK AND LOOP TO 2$.
2113 010060 000755              BR       1$              ;BR BACK TO DO NEXT PATTERN

```

2115

```

*****
;*TEST 11 ROTATE A "0" BIT THROUGH A FIELD OF ONES.
*****

```

```

010062
010062 004567 007444
2116 010066 012700 177777
2117 010072 004767 004364
2118 010076 004467 003054
2119 010102 000241
2120 010104 004767 004370
2121 010110 016201 177776
2122 010114 103402
2123 010116 020001
010120 001405
010122 004767 006654
010126 004767 007712
010132 000005
010134
2124 010134 077516
010136 004767 003226

```

```

†ST11:
      JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
      MOV      #1,     RO      ;SET CHECK WORD
      JSR      PC,     SETCON ;PUT THE CONTENTS OF RO IN ALL MEMORY.
      JSR      R4,     INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:   CLC
      JSR      PC,     ROTATE ;CLEAR CARRY BIT IN PSW
      MOV      -2(R2), R1      ;GET RESULT
      BCS      63$,    ;BRANCH IF 'C' BIT WAS SET
      CMP      RO,     R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ      30030$, ;BRANCH OVER ERROR CALL IF GOOD DATA.
63$:  JSR      PC,     SPRT2  ;SET UP VALUES FOR ERROR PRINTING.
      JSR      PC,     $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD    5           ;ERROR TYPE CODE.
30030$: SOB      R5,     1$    ;BRANCH IF MORE IN CURRENT BLOCK
      JSR      PC,     MMUP   ;FIND NEXT BLOCK AND LOOP TO 1$.

```

2125  
2126

```

*****
;*TEST 12 ROTATE A "1" BIT THROUGH A FIELD OF ZEROS
*****

```

```

010142
010142 004567 007364
2127 010146 005000
2128 010150 004767 004306
2129 010154 004467 002776
2130 010160 000261
2131 010162 004767 004312
2132 010166 016201 177776
2133 010172 103002
2134 010174 020001
010176 001405
010200 004767 006576
010204 004767 007634
010210 000005
010212
2135 010212 077516
010214 004767 003150
2136

```

```

†ST12:
      JSR      R5,     $SCOPE ;GO TO SCOPE ROUTINE.
      CLR      RO      ;SET CHECK WORD
      JSR      PC,     SETCON ;PUT THE CONTENTS OF RO IN ALL MEMORY
      JSR      R4,     INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:   SEC
      JSR      PC,     ROTATE ;SET 'C' BIT IN PSW
      MOV      -2(R2), R1      ;GO ROTATE '1' BIT
      BCC      63$,    ;GET RESULT
      CMP      RO,     R1      ;BRANCH IF 'C' IS CLEAR
      BEQ      30031$, ;COMPARE THE CHECK WORD WITH THE DATA READ.
63$:  JSR      PC,     SPRT2  ;BRANCH OVER ERROR CALL IF GOOD DATA.
      JSR      PC,     $ERROR ;SET UP VALUES FOR ERROR PRINTING.
      .WORD    5           ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD    5           ;ERROR TYPE CODE.
30031$: SOB      R5,     1$    ;BRANCH IF MORE IN CURRENT BLOCK
      JSR      PC,     MMUP   ;FIND NEXT BLOCK AND LOOP TO 1$.

```

2147

```

*****
*TEST 13      WORSE CASE NOISE PARITY BYTE TESTING
* CHECK PARITY MEMORY WITH A SERIES OF BYTE PATTERNS
* 1) FORCE WRONG PARITY IN EACH BYTE OF PARITY MEMORY
* 2) READ IT BACK WITH ACTION ENABLE SET, MAKING SURE THAT A TRAP OCCURS
* 3) WRITE GOOD PARITY AND MAKE SURE NO TRAP OCCURS WHEN IT IS READ
* 4) MAKE SURE THE ERROR ADDRESS BITS (CSR BITS <11-5>) ARE CORRECT
* 5) IF MMU ENABLED AND ABOVE 128KW,CHECK BIT14 AND BITS <11-5>
*      ON PARITY CSR.
*****

```

```

010220
2148 010220 004567 007306
2149 010224 005767 173142
2150 010230 001404
2151 010232 032777 000100 170670
2152 010240 001402
2153 010242 000167 000760
2154 010246 005000
2155 010250 004767 004206
2156 010254 004467 002676
2157
2158 010260 006305
2159 010262 012700 000020
2160 010266 016701 171524
2161 010272 016703 171516
2162 010276 032123
2163 010300 001004
2164 010302 077003
2165 010304 060502
2166
2167 010306 000167 000704
2168 010312 004767 005466
2169 010316 004767 005516
2170 010322 020227 000114
2171 010326 001004
2172 010330 062702 000004
2173 010334 162705 000004
2174
2175 010340 111201
2176 010342 001405
      010344 004767 006344
      010350 004767 007470
      010354 000011
      010356
2177 010356 105067 171376
2178 010362 112700 000252
2179 010366 110012
2180 010370 016703 171430
2181 010374 056773 171366 000000
2182 010402 052733 000001
2183 010406 005713
2184 010410 001371
2185
2186 010412 110012
2187 010414 016703 171404
2188 010420 046733 171342

```

```

†ST13:
WWPBO: JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
        TST      MPRX    ;CHECK FOR ANY PARITY MEMORY.
        BEQ      1$,     ;BR IF NO PARITY MEMORY.
        BIT      #SW06, @SWR ;CHECK FORINHIBIT PARITY SWITCH.
        BEQ      2$,     ;BR IF NOT SET.
1$:     JMP      TST14    ;SKIP THIS TEST IF NO PARITY MEMORY PRESENT.
2$:     CLR      R0      ;ZERO TO BE PUT IN ALL MEMORY.
        JSR      PC,     SETCON ;ROUTINE TO LOAD ALL MEMORY.
        JSR      R4,     INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.

;RETURN FOR MMUP
WWPBYT: ASL      R5      ;MAKE TEST COUNTER BYTE VALUE
        MOV      #20,   R0 ;TABLE COUNT
        MOV      .BITPT, R1 ;BANK POINTER TABLE
        MOV      .PMEAP, R3 ;PARITY TABLE
1$:     BIT      (R1)+, (R3)+ ;CHECK IF CURRENT BANK HAS PARITY MEMORY
        BNE      2$,     ;BRANCH IF PARITY MEMORY
        SOB      R0,     1$ ;CHECK TILL END OF TABLE
        ADD      R5,     R2 ;IF NONE FOUND POINT R2 TO
        ;FIRST ADDR OF NEXT BANK.
        JMP      WWPB6   ;FIND NEX, BLOCK
2$:     JSR      PC,     SETAE ;SET ACTION ENABLE (EVEN IF BANK0.)
        JSR      PC,     CKPMER ;CHECK FOR ANY NON TRAP PARITY ERRORS.
WWPB1:  CMP      R2,     #114 ;CHECK IF POINTING TO PARITY ERROR VECTOR.
        BNE      3$,     ;BR IF NOT AT VECTOR.
        ADD      #4,     R2 ;SKIP PARITY VECTOR.
        SUB      #4,     R5 ;SKIP PARITY VECTOR
        ;SUBTACT 4 FROM TEST COUNTER
3$:     MOVB     (R2),   R1 ;CHECK IF BYTE STILL CLEARED.
        BEQ      30033$, ;BRANCH OVER ERROR CALL IF GOOD DATA.
        JSR      PC,     SPRNT ;SET UP VALUES FOR ERROR PRINTING.
        JSR      PC,     $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD    11 ;ERROR TYPE CODE.
30033$:
        CLRB     OEFLG   ;CLEAR ODD/EVEN FLAG.
        MOVB     #252,   R0 ;SET UP DATA...EVEN, SETS PARITY BIT.
WWPB2:  MOVB     R0,     (R2) ;MOV DATA INTO TEST LOCATION.
        MOV      .MPRX,  R3 ;GET PARITY REGISTER TABLE POINTER.
10$:    BIS      WWP, @ (R3) ;SET WRITE WRONG PARITY.
        BIS      #AE, @ (R3)+
        TST      (R3)
        BNE      10$,
;* SET WRONG PARITY IN LOCATION UNDER TEST.
        MOVB     R0,     (R2) ;WRITE SAME DATA (EXCEPT PARITY) VIA DATOB.
        MOV      .MPRX,  R3 ;GET PARITY REG TABLE POINTER.
11$:    BIC      WWP,   @ (R3)+ ;CLEAR WRITE WRONG PARITY.

```

```

2189 010424 005713          TST      (R3)          ;CHECK FOR TABLE TERMINATOR.
2190 010426 001374          BNE      11$          ;BR IF MORE PARITY REGISTERS.
2191 010430 005767 171342   TST      LSIFLG       ;CHECK IF RUNNING ON EARLIER LSI-11/2
2192 010434 001402          BEQ      12$          ;BR IF 11/23 OR LATER PROCESSOR
2193 010436 105712          TSTB     (R2)         ;PARITY TRAP LOGIC NOT AVAILABLE ON LSI11/2
2194 010440 000433          BR       PBTRP1      ;SET PARITY ERROR WITH READ AND BYPASS
2195                                ;PARITY TRAP AND TEST PARITY CSR.
2196 010442 016737 171360 000114 12$:  MOV     .PBTRP, @#PARVEC ;SET UP VECTOR FOR EXPECTED TRAP.
2197                                ;* DETECT WRONG PARITY VIA DATIO; DATOB SHOULDN'T EXECUTE.
2198                                ;;VK*****
2199                                ;;VK CHECK FOR KDJ11-DA (11/53) PROCESSOR
2200                                ;;VK*****
2201 010450 005767 171324          TST      KDJDA
2202 010454 001404          BEQ      14$
2203 010456 105712          TSTB     (R2)
2204 010460 005767 173260          TST      START
2205 010464 000401          BR       16$
2206                                ;;VK*****END OF KDJDA CHECK*****
2207 010466 105412          14$:  NEGB     (R2)          ;DATIO (DATOB AND COM PARITY BIT.)
2208                                ;* SHOULD HAVE TRAPPED TO PBTRP.
2209 010470 016737 171336 000114 16$:  MOV     .PESRV, @#PARVEC ;RESET VECTOR FOR UNEXPECTED TRAPS.
2210 010476 004767 006254          30034$: JSR     PC,      SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
2211 010502 004767 007336          JSR     PC,      $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
2212 010506 000012          .WORD   12           ;ERROR TYPE CODE.
2213 010510 004767 006156          JSR     PC, CLRPAR   ;CLEAR ALL PARITY CSRS BEFORE NEXT BYTE
2214 010514 000167 000442          JMP     WWPB4        ;SKIP TRAP SERVICE.
2215
2216                                ;* EXPECTED PARITY MEMORY TRAPS COME HERE.
2217 010520 016737 171306 000114 PBTRP: MOV     .PESRV, @#PARVEC ;RESET PARITY VECTOR FOR UNEXPECTED TRAPS.
2218 010526 022626          CMP     (SP)+, (SP)+ ;RESET THE STACK POINTER AFTER TRAP.
2219 010530 016703 171266          PBTRP1: MOV    .MPRO, R3 ;GET PARITY REG AND MAP TABLE POINTER.
2220 010534 032713 000001          21$:  BIT     #BIT0, (R3) ;CHECK IF THIS REGISTER EXISTS.
2221 010540 001003          BNE     22$          ;BR IF IT DOESN'T EXIST.
2222 010542 017301 000000          MOV     @ (R3), R1   ;GET THE CONTENTS.
2223 010546 100413          BMI     23$          ;BR IF ERROR FLAG SET.
2224 010550 062703 000044          22$:  ADD     #44, R3   ;MOVE POINTER TO NEXT REG.
2225 010554 020367 171244          CMP     R3, .MPRX   ;CHECK FOR END OF TABLE.
2226 010560 103765          BLO     21$          ;BR IF MORE REGISTERS.
2227 010562 004767 006170          30035$: JSR     PC,      SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
2228 010566 004767 007252          JSR     PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2229 010572 000013          .WORD   13           ;ERRGR TYPE CODE.
2230 010574 000572          BR      WWPB4        ;EXIT AFTER ERROR.
2231 010576 004567 005344          23$:  JSR     R5,      PARMAT ;CHECK FOR MAP OF THIS REGISTER
2232 010602 000405          BR      24$          ;BRANCH IF THIS PARITY REGISTER
2233                                ;CONTROLS THIS BANK.
2234                                ;RETURN +2, ERROR, CANNOT FIND MEM BANK
2235                                ;IN PARITY MAP TABLE.
2236 010604 004767 006142          30036$: JSR     PC,      SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
2237 010610 004767 007230          JSR     PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2238 010614 000014          .WORD   14           ;ERROR TYPE CODE.
2239 010616 010046          24$:  MOV     R0, -(SP)   ;; PUSH R0 ON STACK
2240 010620 010200          MOV     R2, R0       ;GET THE ADDRESS POINTER.
2241 010622 042700 003777          BIC     #3777, R0    ;CLEAR LOW ADDRESS BITS.
2242 010626 000300          SWAB   R0            ;SHIFT 6 PLACES RIGHT.

```



```

2239 010630 006300 ASL R0
2240 010632 006300 ASL R0
2241 010634 005767 167676 TST MMAVA ;CHECK FOR MEM MGMT.
2242 010640 001411 BEQ 25$ ;BR IF NO MEM MGMT.
2243 010642 042700 177600 BIC #177600,R0 ;CLEAR BANK BITS
2244 010646 063700 172344 ADD @#KIPAR2,R0 ;ADD MEM MGMT OFFSET.
2245 010652 032702 020000 BIT #BIT13,R2 ;CHECK FOR PAR3 REF. ADDRESSING
2246 010656 001402 BEQ 25$ ;BR IF R2 IS ADDRESSING PAR2
2247 010660 062700 000200 ADD #200,R0 ;SET UP EXPECTED WITH PAR3
2248 010664 052700 100001 25$: BIS #BIT15+BIT0,R0 ;SET ERROR AND AE BIT IN CHECK WORD.
2249 010670 016367 000042 170610 MOV 42(R3),RESRVD ;GET APPROPRIATE MASK.
2250 010676 046700 170604 BIC RESRVD,R0 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
2251 010702 046701 170600 BIC RESRVD,R1 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
2252 ;NOTE: THE ABOVE INSTRUCTION (2 WORDS) CAN BE NOP'ED FOR UNMIXED MEMORY TYPES.
2253 010706 020001 CMP R0,R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
010710 001405 BEQ 30038$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
010712 004767 006034 30037$: JSR PC,SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
010716 004767 007122 JSR PC,$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
010722 000015 .WORD 15 ;ERROR TYPE CODE.
010724 30038$:
2254 010724 005767 167606 TST MMAVA ;CHECK FOR 22 BIT ADDRESSING
2255 010730 100034 BPL 100$ ;BR IF 22 BIT ADDR NOT ENABLED
2256 010732 022737 010000 172344 CMP #10000,@#KIPAR2 ;CHECK IF ABOVE 128KW
2257 010740 101030 BHI 100$ ;BR IF KIPAR2 LESS THAN 128KW
2258 010742 010046 MOV R0,-(SP) ;PUSH R0 ON STACK
2259 010744 052773 040000 000000 BIS #BIT14,@(R3) ;SET BIT14 TO ENABLE BITS 18 21
2260 INTO BITS 8-5 OF PARITY CSR
2261 010752 013700 172344 MOV @#KIPAR2,R0 ;SETUP EXPECTED FOR PARITY CSR
2262 010756 042700 007777 BIC #7777,R0 ;BITS 18-21 STORED IN
2263 010762 000300 SWAB R0 ;BITS 5-8.
2264 010764 006300 ASL R0 ;A18-21 IN BITS 5-8
2265 010766 052700 140001 BIS #BIT15!BIT14!AE,R0 ;SAVE EXPECTED PARITY CSR
2266 010772 017301 000000 MOV @(R3),R1 ;GET CONTENTS OF PARITY CSR
2267 010776 042701 030032 BIC #30032,R1 ;CLEAR MASKED BITS
2268 011002 020001 CMP R0,R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
011004 001405 BEQ 30040$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
011006 004767 005740 30039$: JSR PC,SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
011012 004767 007026 JSR PC,$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
011016 000015 .WORD 15 ;ERROR TYPE CODE.
011020 30040$:
2269 011020 012600 MOV (SP)+,R0 ;POP STACK INTO R0
2270 011022 005073 000000 100$: CLR @(R3) ;CLEAR REG INCLUDING ACTION ENABLE.
2271 011026 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
2272 011030 062703 000044 26$: ADD #44,R3 ;UPDATE POINTER TO NEXT PARITY REG + MAP.
2273 011034 020367 170764 CMP R3,.MPRX ;CHECK FOR END OF TABLE.
2274 011040 101014 BHI WWPB3 ;BR IF END OF TABLE REACHED.
2275 011042 032713 000001 BIT #BIT0,(R3) ;CHECK IF NEXT REG EXISTS.
2276 011046 001370 BNE 26$ ;BR IF THIS PARITY REG DOESN'T EXIST.
2277 011050 017301 000000 MOV @(R3),R1 ;SAVE AND CHECK FOR ERROR FLAG.
2278 011054 100365 BPL 26$ ;BR IF NO ERROR FLAG.
2279 011056 004767 005670 30041$: JSR PC,SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
011062 004767 006756 JSR PC,$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
011066 000016 .WORD 16 ;ERROR TYPE CODE.
2280 011070 000757 BR 26$ ;BR AFTER ERROR.
2281 011072 111204 WWPB3: MOVB (R2),R4 ;GET THE DATA FOR CHECKING.
2282 ;* READING THE DATA VIA DAT1 TO CHECK IT SHOULD CAUSE PARITY ERROR, BUT
2283 ;* ACTION ENABLE IS NOT SET IN CONTROLLING REG, SO NO TRAP SHOULD OCCUR.

```

```

2284 011074 111212          MOVB   (R2), (R2) ;RESTORE RIGHT PARITY
2285 ;NOTE: THE ABOVE INSTRUCTION CAN BE NOP'ED FOR PROCESSORS
2286 ; WHICH DO ONLY DATOB TO DESTINATION OF MOVB INSTRUCTIONS.
2287 011076 012603          MOV    (SP)+,R3 ;;POP STACK INTO R3
2288 011100 017301 000000    MOV    @R3, R1 ;READ THE PARITY REGISTER TO CHECK IT AGAIN.
2289 011104 046701 170376    BIC    RESRVD, R1 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
2290 ;NOTE: THE ABOVE INSTRUCTION (2 WORDS) CAN BE NOP'ED FOR UNMIXED MEMORY TYPES.
2291 011110 042700 000001    BIC    #AE, R0 ;CLEAR THE ACTION ENABLE BIT IN TEST DATA.
2292 011114 020001           CMP    R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
      011116 001405           BEQ    30043$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
      011120 004767 005626    30042$: JSR   PC, SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
      011124 004767 006714    JSR   PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      011130 000015           .WORD  15 ;ERROR TYPE CODE.
      011132           30043$:
2293 011132 012773 000001 000000 MOV    #1, @R3 ;CLEAR ALL BUT ACTION ENABLE.
2294 011140 010401           MOV    R4, R1 ;GET DATA READ FROM MEMORY FOR TESTING.
2295 011142 012600           MOV    (SP)+,R0 ;;POP STACK INTO R0
2296 011144 120001           CMPB  R0, R1 ;CHECK THE DATA.
2297 011146 001405           BEQ    30045$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
      011150 004767 005602    30044$: JSR   PC, SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
      011154 004767 006664    JSR   PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      011160 000017           .WORD  17 ;ERROR TYPE CODE.
      011162           30045$:
2298 011162 110012          WWPB4: MOVB  R0, (R2) ;RESTORE DATA.
2299 011164 105712          TSTB  (R2) ;DO A DATI TO BE SURE RIGHT PARITY.
2300 011166 012700 000253    MOV    #253, R0 ;SET ODD PARITY DATA.
2301 011172 105167 170562    COMB  OEFLG ;CHECK IF DONE BOTH ODD AND EVEN PARITY.
2302 011176 100002          BPL   27$ ;BR IF DONE BOTH EVEN AND ODD.
2303 011200 000167 177162    JMP   WWPB2 ;LOOP BACK AND DO ODD(PARITY BIT CLR).
2304 011204 005202          27$: INC  R2 ;MOVE POINTER TO NEXT MEMORY BYTE.
2305 011206 005305          WWPB5: DEC  R5 ;CHECK FOR END OF BLOCK
      306 011210 001402          BEQ   WWPB6 ;BR IF END OF BLOCK FOUND.
2307 011212 000167 177104    JMP   WWPB1 ;LOOP BACK TO TEST NEXT BYTE.
2308 011216 004767 002146    WWPB6: JSR   PC, MMUP ;FIND NEXT BLOCK AND LOOP TO WWPBYT
2309 011222 004767 004512    JSR   PC, MAMF ;GO RESET PARITY REGISTERS.

```

2311

011226  
2312 011232 004567 006300  
2313 011234 010703  
2314 011240 042703 007777  
2315 011244 004467 001712  
2316 011246 010246  
2317 011250 010346 170516  
2318 011254 010567  
2319 011256 012322  
2320 011262 032703 007777  
2321 011264 001002 010000  
2322 011270 162703  
2323 011272 077507  
2324 011274 012603  
2325 011276 012602 170470  
2326 011302 016705  
2327 011304 012300 012201  
011306 020001  
011310 001405  
011312 004767 005464  
011316 004767 006522  
011322 000020  
011324  
2328 011324 032703 007777  
2329 011330 001002  
2330 011332 162703 010000  
2331 011336 077517  
011336 004767 002024  
011340

```

*****
*TEST 14 RANDOM DATA TESTING THRU PROGRAM CODE RELOCATION.
*****
†ST14:
RANTST: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
MOV PC, R3 ;GET CURRENT PROGRAM COUNTER.
BIC #7777, R3 ;POINT TO BEGINNING OF CURRENT 2K BLOCK.
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: MOV R2, (SP) ;SAVE MEMORY POINTER.
MOV R3, -(SP) ;SAVE "DATA" POINTER.
MOV R5, TEMP1 ;SAVE ADDRESS COUNTER
2$: MOV (R3)+, (R2)+ ;MOV CODE INTO TEST MEMORY.
BIT #7777, R3 ;CHECK FOR END OF "DATA TABLE"
BNE 3$ ;BRANCH IF MORE
SUB #10000, R3 ;RESET POINTER TO START OF "RANDOM DATA"
3$: SOB R5, 2$ ;IF NOT END OF BLOCK, BRANCH TO 2$
MOV (SP)+, R3 ;RESET "DATA" POINTER.
MOV (SP)+, R2 ;RESET MEMORY POINTER.
MOV TEMP1, R5 ;RESET ADDRESS COUNTER
4$: MOV (R3)+, R0 ;GET S/B DATA.
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 30047$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30046$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
WORD 20 ;ERROR TYPE CODE.
30047$: BIT #7777, R3 ;CHECK FOR END OF "DATA TABLE"
BNE 5$ ;BR IF MORE.
SUB #10000, R3 ;RESET POINTER TO TOP OF "DATA TABLE".
5$: SOB R5, 4$ ;BRANCH IF MORE IN CURRENT BLOCK
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```

2332  
2333  
2358

```

.SBTTL SECTION 3: INSTRUCTION EXECUTION TESTS.
*****
*TEST 15 EXECUTE DATI, DATO THRU MEMORY.
* EXECUTES THE INSTRUCTION 'MOV R4,(R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOV' INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
*
* MEMORY LOCATION INSTRUCTION CONTENTS OF MEMORY LOCATION
* LOCATION PLACED THERE AFTER INSTRUCTION EXECUTION
*
* 1ST PASS / 40000 010412 000205
* THRU TEST / 40002 000205 000205
*
* 2ND PASS / 40002 010412 000205
* THRU TEST / 40004 000205 000205
*
* ETC., ETC., ETC.
*
* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
* R1 = DATA READ FROM MEMORY (WAS).
* R2 = ADDRESS OF IUT/DATA.
* R3 - INSTRUCTION UNDER TEST (IUT).

```

```

;* R4 = RTS R5 (CODE 205).
;* R5 = BLOCK BOUNDARY BIT MASK.
;*****
TST15:
011344
011344 004567 006162
2359 011350 012703 010412
2360 011354 012704 000205
2361 011360 010400
2362 011362 004467 001570
2363 011366 005305
2364 011370 010322
2365 011372 010412
2366 011374 004542
2367 011376 012201
2368 011400 020001
011402 001405
011404 004767 005366
011410 004767 006430
011414 000021
011416
2369 011416 010322
2370 011420 077514
011422 004767 001742

DIDO: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
MOV #010412,R3 ;GET 'MOV R4,(R2)' INSTRUCTION (IUT).
MOV #205, R4 ;GET 'RTS R5'
MOV R4, R0 ;SET UP S/B DATA AFTER EXECUTION.
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: DEC R5 ;DO ALL ADDRESSES -1
MOV R3, (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2$: MOV R4, (R2) ;PUT 'RTS R5' FOLLOWING IUT.
JSR R5, -(R2) ;GO EXECUTE THE IUT.
MOV (R2)+, R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 30049$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30048$: JSR PC, SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 21 ;ERROR TYPE CODE.
30049$: MOV R3, (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
SOB R5, 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```

2396

\*\*\*\*\*

\*TEST 16 EXECUTE DATI, DATOB (LOW BYTE) THRU MEMORY.  
\* EXECUTES THE INSTRUCTION 'MOVB R4,(R2)' THROUGHOUT MEMORY.  
\* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOVB' INSTRUCTION TO RETURN  
\* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.  
\* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:

\*  
\* MEMORY LOCATION INSTRUCTION CONTENTS OF MEMORY LOCATION  
\* LOCATION PLACED THERE AFTER INSTRUCTION EXECUTION

\* 1ST PASS / 40000 110412 110605  
\* THRU TEST / 40002 000205 000205

\* 2ND PASS / 40002 110412 110605  
\* THRU TEST / 40004 000205 000205

\* ETC., ETC., ETC.

\* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).  
\* R1 = DATA READ FROM MEMORY (WAS).  
\* R2 = ADDRESS OF IUT/DATA.  
\* R3 = INSTRUCTION UNDER TEST (IUT).  
\* R4 = RTS R5 (CODE 205).  
\* R5 = BLOCK BOUNDARY BIT MASK.

\*\*\*\*\*

011426  
011426 004567 006100  
2397 011432 012703 110412  
2398 011436 012704 000205  
2399 011442 012700 110605  
2400 011446 004467 001504  
2401 011452 005305  
2402 011454 010322  
2403 011456 010412  
2404 011460 004542  
2405 011462 012201  
2406 011464 020001  
011466 001405  
011470 004767 005302  
011474 004767 006344  
011500 000021  
011502  
2407 011502 010322  
2408 011504 077514  
011506 004767 001656

†ST16:  
DIDBL: JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.  
MOV #110412,R3 ;GET 'MOVB R4,(R2)' INSTRUCTION (IUT).  
MOV #205,R4 ;GET 'RTS R5'  
MOV #110605,R0 ;SET UP S/B DATA AFTER EXECUTION.  
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.  
1\$: DEC R5 ;DO ALL ADDRESSES -1  
MOV R3, (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.  
2\$: MOV R4, (R2) ;PUT 'RTS R5' FOLLOWING IUT.  
JSR R5, -(R2) ;GO EXECUTE THE IUT.  
MOV (R2)+, R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.  
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.  
BEQ 30051\$ ;BRANCH OVER ERROR CALL IF GOOD DATA.  
30050\$: JSR PC, SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.  
JSR PC, \$ERROR ;\*\*\* ERROR \*\*\* (GO TYPE A MESSAGE)  
.WORD 21 ;ERROR TYPE CODE.  
30051\$:  
MOV R3, (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.  
SOB R5, 2\$ ;BRANCH IF MORE IN CURRENT BLOCK.  
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.

2434

```

*****
*TEST 17 EXECUTE DATI, DATOB (HIGH BYTE) THRU MEMORY.
* EXECUTES THE INSTRUCTION 'MOVB R3,-(R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOVB' INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
*
*          MEMORY          INSTRUCTION          CONTENTS OF MEMORY LOCATION
*          LOCATION        PLACED THERE        AFTER INSTRUCTION EXECUTION
*
* 1ST PASS / 40000        110342            161342
* THRU TEST / 40002        000205            000205
*
* 2ND PASS / 40002        110342            161342
* THRU TEST / 40004        000205            000205
*
*          ETC., ETC., ETC.
*
* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
* R1 = DATA READ FROM MEMORY (WAS).
* R2 = ADDRESS OF IUT/DATA.
* R3 = INSTRUCTION UNDER TEST (IUT).
* R4 = RTS R5 (CODE 205).
* R5 = BLOCK BOUNDARY BIT MASK.

```

```

011512
2435 011512 004567 006014
2436 011516 012703 110342
2437 011522 012704 000205
2438 011526 012700 161342
2439 011532 004467 001420
2440 011536 005305
2441 011540 010322
2442 011542 010412
2443 011544 004562 177776
2444 011550 005302
2445 011552 012201
011554 020001
011556 001405
011560 004767 005212
011564 004767 006254
011570 000021
011572
2446 011572 010322
2447 011574 077516
011576 004767 001566

```

```

*****
*ST17:
DIDBH: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
        MOV #110342,R3 ;GET 'MOVB R3,-(R2)' INSTRUCTION (IUT).
        MOV #205,R4 ;GET 'RTS R5'
        MOV #161342,R0 ;SET UP S/B DATA AFTER EXECUTION.
        JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: DEC R5 ;DO ALL ADDRESSES -1
    MOV R3, (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2$: MOV R4, (R2) ;PUT 'RTS R5' FOLLOWING IUT.
    JSR R5, -2(R2) ;GO EXECUTE THE IUT.
    DEC R2 ;ADJUST R2 TO POINT TO MAUT.
    MOV (R2)+, R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 30053$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30052$: JSR PC, SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.
        JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD 21 ;ERROR TYPE CODE.
30053$: MOV R3, (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
        SOB R5, 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
        JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```

2475

```

*****
*TEST 20 EXECUTE DATI, DATIO, DATO THRU MEMORY.
* EXECUTES THE INSTRUCTION 'NEG (R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'NEG' INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:

```

```

*
*          MEMORY          INSTRUCTION          CONTENTS OF MEMORY LOCATION
*          LOCATION        PLACED THERE        AFTER INSTRUCTION EXECUTION
*
* 1ST PASS / 40000        005412             172366
* THRU TEST / 40002        000205             000205
*
* 2ND PASS / 40002        005412             172366
* THRU TEST / 40004        000205             000205
*
*          ETC., ETC., ETC.

```

```

* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
* R1 = DATA READ FROM MEMORY (WAS).
* R2 = ADDRESS OF IUT/DATA.

* R3 = INSTRUCTION UNDER TEST (IUT).
* R4 = RTS R5 (CODE 205).
* R5 = BLOCK BOUNDARY BIT MASK.

```

```

011602
011602 004567 005724
2476 011606 012703 005412
2477 011612 012704 000205
2478 011616 012700 172366
2479 011622 004467 001330
2480 011626 005305
2481 011630 010322
2482 011632 010412
2483 011634 004542
2484 011636 012201
2485 011640 020001
011642 001405
011644 004767 005126
011650 004767 006170
011654 000021
011656
2486 011656 010322
2487 011660 077514
011662 004767 001502

```

```

*****
†ST20:
DIPD0· JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
MOV #005412,R3 ;GET 'NEG (R2)' INSTRUCTION (IUT).
MOV #205,R4 ;GET 'RTS R5'
MOV #172366,R0 ;SET UP S/B DATA AFTER EXECUTION.
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: DEC R5 ;DO ALL ADDRESSES -1
MOV R3, (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2$: MOV R4, (R2) ;PUT 'RTS R5' FOLLOWING IUT.
JSR R5, -(R2) ;GO EXECUTE THE IUT.
MOV (R2)+, R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 30055$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30054$: JSR PC, SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 21 ;ERROR TYPE CODE.
30055$: MOV R3, (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
SOB R5, 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```

2513

```

*****
*TEST 21 EXECUTE DATI, DATI, DATIO, DATOB (LOW BYTE) THRU MEMORY.
* EXECUTES THE INSTRUCTION BICB (R2)+, -(R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE BICB INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
*
*          MEMORY          INSTRUCTION          CONTENTS OF MEMORY LOCATION
*          LOCATION        PLACED THERE          AFTER INSTRUCTION EXECUTION
*
* 1ST PASS / 40000        142242          142000
* THRU TEST / 40002        000205          000205
*
* 2ND PASS / 40002        142242          142000
* THRU TEST / 40004        000205          000205
*
*          ETC., ETC., ETC.
*
* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
* R1 = DATA READ FROM MEMORY (WAS).
* R2 = ADDRESS OF IUT/DATA.
* R3 = INSTRUCTION UNDER TEST (IUT).
* R4 = RTS R5 (CODE 205).
* R5 = BLOCK BOUNDARY BIT MASK.
*****

```

```

011666
2514 011672 012703 142242
2515 011676 012704 000205
2516 011702 012700 142000
2517 011706 004467 001244
2518 011712 005305
2519 011714 010322
2520 011716 010412
2521 011720 004542
2522 011722 012201
2523 011724 020001
011726 001405
011730 004767 005042
011734 004767 006104
011740 000021
011742
2524 011742 010322
2525 011744 077514
011746 004767 001416

```

```

†ST21:
DPDBL: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
        MOV #142242,R3 ;GET BICB (R2)+, -(R2)' INSTRUCTION (IUT).
        MOV #205, R4 ;GET 'RTS R5'
        MOV #142000,R0 ;SET UP S/B DATA AFTER EXECUTION.
        JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: DEC R5 ;DO ALL ADDRESSES -1
    MOV R3, (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2$: MOV R4, (R2) ;PUT 'RTS R5' FOLLOWING IUT.
    JSR R5, -(R2) ;GO EXECUTE THE IUT.
    MOV (R2)+, R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 30057$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30056$: JSR PC, SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.
        JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD 21 ;ERROR TYPE CODE.
30057$:
        MOV R3, (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
        SOB R5, 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
        JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```



2551

\*\*\*\*\*  
: \*TEST 22 EXECUTE DATI, DATI, DATIO, DATOB (HIGH BYTE) THRU MEMORY.  
: \* EXECUTES THE INSTRUCTION 'BISB (R2)+,(R2)' THROUGHOUT MEMORY.  
: \* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'BISB' INSTRUCTION TO RETURN  
: \* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.  
: \* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:  
: \*  
: \*

	MEMORY LOCATION	INSTRUCTION PLACED THERE	CONTENTS OF MEMORY LOCATION AFTER INSTRUCTION EXECUTION
: *	1ST PASS / 40000	152212	157212
: *	THRU TEST / 40002	000205	000205
: *	2ND PASS / 40002	152212	157212
: *	THRU TEST / 40004	000205	000205
: *	ETC., ETC., ETC.		

: \* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).  
: \* R1 = DATA READ FROM MEMORY (WAS).  
: \* R2 = ADDRESS OF IUT/DATA.  
: \* R3 = INSTRUCTION UNDER TEST (IUT).  
: \* R4 = RTS R5 (CODE 205).  
: \* R5 = BLOCK BOUNDARY BIT MASK.  
: \*

\*\*\*\*\*  
†ST22:

011752	004567	005554						
2552 011752	012703	152212		DPDBH:	MOV	R5,	\$SCOPE	:GO TO SCOPE ROUTINE.
2553 011762	012704	000205			MOV	#152212,R3		:GET 'BISB (R2)+,(R2)' INSTRUCTION (IUT).
2554 011766	012700	157212			MOV	#205,R4		:GET 'RTS R5'
2555 011772	004467	001160			MOV	#157212,R0		:SET UP S/B DATA AFTER EXECUTION.
2556 011776	005305			1\$:	JSR	R4,	INITMM	:INITIALIZE THE MEMORY ADDRESS POINTERS.
2557 012000	010322				DEC	R5,		:DO ALL ADDRESSES -1
2558 012002	010412			2\$:	MOV	R3,	(R2)+	:PUT IUT INTO FIRST LOC OF BLOCK.
2559 012004	004542				MOV	R4,	(R2)	:PUT 'RTS R5' FOLLOWING IUT.
2560 012006	005302				JSR	R5,	-(R2)	:GO EXECUTE THE IUT.
2561 012010	012201				DEC	R2,		:RESET R2 TO POINT TO IUT.
2562 012012	020001				MOV	(R2)+,	R1	:GET THE DATA FROM THE MEM ADR UNDER TEST.
012014	001405				CMP	R0,	R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
012016	004767	004754		30058\$:	BEQ	30059\$		:BRANCH OVER ERROR CALL IF GOOD DATA.
012022	004767	006016			JSR	PC,	SPRNT3	:SET UP VALUES FOR ERROR PRINTING.
012026	000011				JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
012030				30059\$:	.WORD	21		:ERROR TYPE CODE.
2563 012030	010322				MOV	R3,	(R2)+	:PUT THE IUT INTO THE NEXT LOCATION.
2564 012032	077515				SOB	R5,	2\$	:BRANCH IF MORE IN CURRENT BLOCK.
012034	004767	001330			JSR	PC,	MMUP	:FIND NEXT BLOCK AND LOOP TO 1\$.

2566  
2590

.SBTTL SECTION 4:MOS TESTS

```

*****
*TEST 23      MARCHING 1'S AND 0'S.
* THIS TEST IS DESIGNED TO STRESS MOS MEMORIES.
* STARTING AT THE BOTTOM ADDRESS AND ADDRESSING UPWARDS A 8K BANK IS
* WRITTEN WITH 000377. THEN STARTING AT THE TOP ADDRESS OF THE BANK THE
* 000377 IS READ, THE BYTES ARE SWAPPED TO 177400 AND THE LOCATION
* REREAD TO CONFIRM THE WRITE. THIS IS REPEATED FOR EVERY LOCATION
* ADDRESSED DOWNWARD UNTIL THE BOTTOM IS REACHED. STARTING AT THE
* BOTTOM EACH LOCATION IS READ FOR 177400, THE BYTES ARE SWAPPED TO
* 000377 AND REREAD TO CONFIRM THE WRITE UNTIL THE TOP ADDRESS OF THE
* BANK IS REACHED. AGAIN STARTING AT THE BOTTOM EACH LOCATION IS READ
* FOR 000377, THE BYTES SWAPPED TO 177400 AND THE LOCATION REREAD TO
* CONFIRM THE WRITE. LASTLY STARTING FROM THE TOP AND ADDRESSING DOWN-
* WARD EACH LOCATION IS READ, THE BYTES SWAPPED TO 000377 AND THE
* LOCATION IS REREAD TO CONFIRM THE WRITE. THIS IS REPEATED FOR EVERY
* 8K BANK UNDER TEST.
*
*      R0=DATA WRITTEN INTO MEMORY(SHOULD BE)
*      R1=DATA READ FROM MEMORY(WAS)
*      R2=VIRTUAL ADDRESS
*      R3=TIMES THROUGH COUNTER
*      R4=NOT USED
*      R5=BLOCK BOUNDARY BIT MASK.
*****

```

```

012040
2591 012044 004567 005466
2592 012050 010567 167716
2593 012054 010267 167710
2594 012060 005003
2595 012062 012700 000377
2596 012066 010022
2597 012070 077502
2598 012072 016705 167674
2599 012076 014201
2600 012100 020001
      012102 001405
      012104 004767 004672
      012110 004767 005730
      012114 000010
      012116
2601 012116 000300
2602 012120 010012
2603 012122 011201
2604 012124 020001
      012126 001405
      012130 004767 004646
      012134 004767 005704
      012140 000010
      012142
2605 012142 000300
2606 012144 005703
2607 012146 001403
2608 012150 020327 000003
2609 012154 001011
2610 012156 077531

```

```

*****
†ST23:
      JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
      JSR      R4,      INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
100$:  MOV      R5,TEMP1 ;STORE TEST WORD COUNTER
      MOV      R2,TEMP ;SAVE BANK STARTING ADDRESS
1$:    CLR      R3 ;CLEAR PASS COUNTER
      MOV      #000377,R0 ;SETUP TO WRITE PATTERN
2$:    MOV      R0,(R2)+ ;WRITE PATTERN
      SOB     R5,2$ ;END OF 8K?
      MOV     TEMP1,R5 ;RESTORE TEST WORD COUNTER FOR NEXT PASS
3$:    MOV      -(R2),R1 ;GET DATA WRITEN
      CMP     R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ     30061$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30060$: JSR     PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
      JSR     PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD  10 ;ERROR TYPE CODE.
30061$:
4$:    SWAB    R0 ;SWAP BYTES OF DATA
      MOV     R0,(R2) ;WRITE SWAPPED WORD
      MOV     (R2),R1 ;GET DATA WRITEN
      CMP     R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ     30063$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
30062$: JSR     PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
      JSR     PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD  10 ;ERROR TYPE CODE.
30063$:
      SWAB    R0 ;PUT DATA BACK TO ORIGINAL
      TST     R3 ;IF ON PASS 0 OR PASS 3
      BEQ     5$ ;WE ARE ADDRESSING DOWN
      CMP     R3,#3 ;IF ON PASS 1 OR 2 GO TO
      BNE     6$ ;UPWARD
5$:    SOB     R5,3$ ;DONE A PASS? ,IF NOT THEN 3$

```

```

2611 012160 005203          INC      R3          ;IF YES INCREMENT PASS COUNTER
2612 012162 022703 000004  CMP      #4,R3      ;ARE WE DONE ALL PASSES FOR THIS 8K?
2613 012166 001403          BEQ      9$          ;IF YES BRANCH
2614 012170 016705 167576  MOV      TEMP1,R5   ;RESTORE TEST COUNTER FOR NEXT PASS.
2615 012174 000300          SWAB     R0          ;ELSE SET UP NEW READ WORD
2616 012176 000404          BR       7$          ;GO TO START OF ADDRESS UP
2617 012200 062702 000002  6$:    ADD      #2,R2   ;UPDATE TO NEXT ADDRESS
2618 012204 005305          DEC      R5          ;DONE A PASS?
2619 012206 001411          BEQ      8$          ;IF YES BRANCH
2620 012210 011201 7$:    MOV      (R2),R1   ;GET DATA WRITTEN
2621 012212 020001          CMP      R0, R1     ;COMPARE THE CHECK WORD WITH THE DATA READ.
      012214 001405          BEQ      30065$     ;BRANCH OVER ERROR CALL IF GOOD DATA.
      012216 004767 004560 30064.: JSR      PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
      012222 004767 005616  JSR      PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      012226 000010          .WORD   10         ;ERROR TYPE CODE.
      012230          30065$:
2622 012230 000732          BR       4$          ;RESTORE TEST WORD COUNTER FOR NEXT PASS.
2623 012232 016705 167534  8$:    MOV      TEMP1,R5   ;RESTORE TEST WORD COUNTER FOR NEXT PASS.
2624 012236 005203          INC      R3          ;INCREMENT PASS COUNTER
2625 012240 000300          SWAB     R0          ;SET UP NEW READ WORD
2626 012242 020327 000002  CMP      R3,#2      ;ADDRESSING UP?
2627 012246 001313          BNE     3$          ;IF NO GO TO DOWN SEQUENCE
2628 012250 016702 167514  MOV      TEMP,R2    ;IF YES RESET ADDRESS TO START
2629 012254 000755          BR       7$          ;GO TO UP SEQUENCE
2630 012256 062702 040000  9$:    ADD      #40000,R2 ;TESTING ENDS WITH R2 = BOTTOM OF BANK
2631          ;ADD 8K FOR TEST START OF NEXT BANK
2632 012262 042702 001000  BIC      #1000,R2  ;CLEAR POSSIBLE FIRST STARTING
2633          ;ADDRESS OF 1000 WHEN VECTOR AREA IS
2634          ;PROTECTED.
2635 012266 004767 001076  JSR      PC,MMUP    ;UPDATE TO NEW BANK IF EXISTS
2636          ;RETURN TO 100$
2637
2650

```

```

;*****
;*TEST 24 WRITE CHECKERBOARD STARTING WITH '125252' DATA.
;* THESE TESTS WRITE A CHECKERBOARD THROUGHOUT MEMORY, STALL
;* FOR 2 SECONDS THEN CHECK PATTERN TO VERIFY DATA DID NOT
;* DETERIORATE BETWEEN REFRESH CYCLES.
;*
;* R0=DATA WRITTEN INTO MEMORY(SHOULD BE)
;* R1=DATA READ FROM MEMORY(WAS)
;* R2=VIRTUAL ADDRESS
;* R3=SMALL LOOP COUNTER FOR STALL
;* R4=NUMBER OF TIMES SMALL LOOP DONE
;* R5=BLOCK BOUNDARY BIT MASK.
;*****

```

```

      012272          TST24:
2651 012272 004567 005234  JSR      R5, $SCOPE ;GO TO SCOPE ROUTINE.
2652 012276 004467 000654  JSR      R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2653 012302 012700 125252  MOV      #125252,R0 ;SETUP DATA PATTERN
2654 012306 010022 1$:    MOV      R0, (R2)+ ;WRITE A WORD
2655 012310 005100          COM      R0          ;COMPLEMENT DATA
2656 012312 077503          SOB     R5, 1$      ;BRANCH IF MORE IN CURRENT BLOCK
2657 012314 004767 001050  JSR      PC, MMUP   ;FIND NEXT BLOCK AND LOOP TO 1$.
2658 012320 005003          C_R     R3          ;SET UP COUNTER FOR STALL
2659 012322 012704 000046  MOV      #46, R4    ;DO LOOP 46 TIMES OR 2 SEC. TOTAL.
2659 012326 005303  2$:    DEC      R3
2659 012330 001376          BNE     2$

```

```

2660 012332 005304          DEC    R4
2661 012334 001374          BNE   2$
2662 012336 004467 000614    JSR   R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2663 012342 012700 125252    MOV   #125252,R0 ;INIT DATA FOR CHECKING
2664 012346          3$:
    012346 012201          MOV   (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    012350 020001          CMP   R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    012352 001405          BEQ   30067$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
    012354 004767 004422    30066$: JSR   PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
    012360 004767 005460    JSR   PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    012364 000006          .WORD 6 ;ERROR TYPE CODE.
    012366          30067$:
2665 012366 005100          COM   R0
2666 012370 077512          SOB   R5, 3$ ;BRANCH IF MORE IN CURRENT BLOCK
    012372 004767 000772    JSR   PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
2667          ;:*****
          ;*TEST 25 WRITE CHECKERBOARD STARTING WITH 052525 DATA
          ;:*****
          †ST25:
    012376          JSR   R5, $SCOPE ;GO TO SCOPE ROUTINE.
2668 012402 004467 005130    JSR   R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2669 012406 012700 052525    MOV   #052525,R0 ;SETUP DATA PATTERN
2670 012412 010022          1$: MOV   R0, (R2)+ ;WRITE A WORD
2671 012414 005100          COM   R0
2672 012416 077503          SOB   R5, 1$ ;BRANCH IF MORE IN CURRENT BLOCK
    012420 004767 000744    JSR   PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
2673 012424 005003          CLR   R3 ;SET COUNTER FOR LOOP
2674 012426 012704 000046    MOV   #46, R4 ;DO LOOP 46 TIMES OR 2 SEC. TOTAL
2675 012432 005303          2$: DEC   R3
2676 012434 001376          BNE   2$
2677 012436 005304          DEC   R4
2678 012440 001374          BNE   2$
2679 012442 004467 000510    JSR   R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2680 012446 012700 052525    MOV   #052525,R0 ;INIT PATTERN FOR CHECKING
2681 012452          3$:
    012452 012201          MOV   (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    012454 020001          CMP   R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    012456 001405          BEQ   30069$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
    012460 004767 004316    30068$: JSR   PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
    012464 004767 005354    JSR   PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    012470 000006          .WORD 6 ;ERROR TYPE CODE.
    012472          30069$:
2682 012472 005100          COM   R0
2683 012474 077512          SOB   R5, 3$ ;BRANCH IF MORE IN CURRENT BLOCK
    012476 004767 000666    JSR   PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```

D6

```

2685 .SBTTL DONE: RELOCATE PROGRAM AND REPEAT ALL TESTS.
2686 012502 004567 005024 DONE:
2687 012506 005067 166446 TST32: JSR R5 $SCOPE ;GO TO SCOPE ROUTINE.
2688 012512 105067 166354 CLR $TIMES ;RESET ITERATION COUNTER FOR RESTARTING TEST.
2689 012516 032777 000200 166404 CLR $TSTNM ;RESET TEST NUMBER.
2690 012524 001037 BNE $SW07, @SWR ;CHECK FOR INHIBIT RELOCATION SWITCH.
2691 012526 105767 166462 TSTB $EOP ;SKIP RELOCATION IF SWITCH SET.
2692 012532 001403 BEQ $ENV ;CHECK FOR APT11
2693 012534 005767 166442 TST $PASS ;BRANCH IF NOT APT11
2694 012540 001026 BNE 6$ ;CHECK FOR 1ST PASS
2695 012542 026767 165274 165276 1$: CMP 42,46 ;IF APT, DO NOT RELOCATE AFTER FIRST PASS
2696 012550 001003 BNE 2$ ;CHECK FOR ACT11
2697 012552 005767 166424 TST $PASS ;BRANCH IF NOT ACT11
2698 012556 001417 BEQ 6$ ;CHECK FOR FIRST PASS
2699 012560 032767 000001 165746 2$: BIT #BIT0,PRGMAP ;IF ACT, DO NOT RELOCATE ON FIRST PASS
2700 012566 001404 BEQ 4$ ;CHECK IF PROGRAM IN FIRST 8K
2701 ;IF NOT IN FIRST 8K, RELOC TOP TO BOTTOM
2702 012570 004767 002154 JSR PC, RELTOP ;MUST BE XXDP OR STANDALONE
2703 012574 000167 174206 3$: JMP START1 ;RELOCATE PROGRAM TO TOP OF MEMORY.
2704 ;LOOP BACK AND RUN ALL TESTS AGAIN.
2705 012600 004767 002460 4$: JSR PC, RELO ;RELOCATE PROGRAM BACK TO FIRST 8K.
2706 012604 005767 165232 TST 42 ;TEST FOR XXDP
2707 012610 001402 BEQ 6$ ;IF NOT RUNNING UNDER MON. DONT
2708 012612 004767 002646 5$: JSR PC, RESLDR ;RESTORE LOADERS.
2709 012616 004567 007130 6$: JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
012622 001171 .WORD $CRLF ;ADDRESS OF MESSAGE TO BE TYPED

```

CVMSAB  
DONE:

2711

012624  
012624 000240  
012626 005067 166326  
012632 005267 166344  
012636 042767 100000 166336  
012644 005327  
012646 000001  
012650 003041  
012652 012737  
012654 000001  
012656 012646  
012660 004567 007066  
012664 012760  
012666 016746 166310  
  
012672 106746  
012674 105066 000001  
  
012700 004767 010042  
012704 004567 007042  
012710 012775  
012712  
  
012712 016700 165124  
012716 001416  
012720 000005  
012722 004710  
012724 000240  
012726 000240  
012730 000240  
012732 023737 000042 000046  
012740 001405  
012742 105737 001214  
012746 001002  
012750 004767 002576  
012754  
012754 000167 174026  
012760 015 012 105  
012763 116 104 040  
012766 120 101 123  
012771 123 040 043  
012774 000  
012775 377 377 000

```
*****  
.SBTTL END OF PASS ROUTINE  
;*INCREMENT THE PASS NUMBER ($PASS)  
;*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)  
;TF THERES A MONITOR GO TO IT  
;*IF THERE ISN'T JUMP TO START1  
$EOP:  
NOP  
CLR $TIMES ;;ZERO THE NUMBER OF ITERATIONS  
INC $PASS ;;INCREMENT THE PASS NUMBER  
BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER  
DEC (PC)+ ;;LOOP?  
$EOPCT: .WORD 1  
BGT $DOAGN ;;YES  
MOV (PC)+,@(PC)+ ;;RESTORE COUNTER  
$ENDCT: .WORD 1  
JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.  
;ADDRESS OF MESSAGE TO BE TYPED  
;SAVE $PASS FOR TYPEOUT  
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPDS ROUTINE  
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**  
MFPS -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK  
CLRB 1(SP) ;HIGH BYTE CLEARED TO INSURE KERNEL MODE  
;ON PSW RETURN.  
JSR PC,$TYPDS ;GO TO THE SUBROUTINE  
JSR R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.  
;ADDRESS OF MESSAGE TO BE TYPED  
$GET42:  
MOV 42,R0 ;GET MONITOR ADDRESS  
BEQ $DOAGN ;;BRANCH IF NO MONITOR  
RESET ;;CLEAR THE WORLD  
$ENDAD: JSR PC,(R0) ;GO TO MONITOR  
NOP ;;SAVE ROOM  
NOP ;;FOR  
NOP ;;ACT11  
CMP @#42,@#46 ;ARE WE UNDER ACT11 OR XXDP  
BEQ $DOAGN ;IF ACT11 THEN RESTART  
TSTB @#$ENV ;CHECK FOR APT11  
BNE $DOAGN ;IF APT11 THEN RESTART  
JSR PC,SAVLDR ;IF XXDP FIRST SAVE MONITOR  
$DOAGN:  
JMP START1 ;RETURN*****  
$ENDMG: .ASCIZ <15><12>/END PASS #/  
$ENULL: .BYTE -1,-1,0 ;NULL CHARACTER STRING  
.SBTTL SUBROUTINE AND TRAP ROUTINE SECTION.  
.SBTTL MEMORY MANAGEMENT AND ADDRESSING SUBROUTINES.  
*****  
;* SET UP ALL THE MEM MGMT REGISTERS FOR NORMAL OPERATION.
```

2712  
2713  
2714  
2715

```

2716 ;* THE PROGRAM IS POINTED TO BY PARS 0 AND 1.
2717 ;* THE MEMORY UNDER TEST IS POINTED TO BY PARS 2 AND 3.
2718 ;* THE DEVICE ADDRESS AREA IS POINTED TO BY PAR 7.
2719 ;* PARS 4, 5, AND 6 ARE UNUSED.
2720 ;*****
2721 013000 MMINIT:
      013000 012737 077406 172300 MOV #200 1*400+UP+RW,@#KIPDR0 ;SET KIPDR0 = RW UP 200 BLOCKS
2722 013006 012737 077406 172302 MOV #200-1*400+UP+RW,@#KIPDR1 ;SET KIPDR1 = RW UP 200 BLOCKS
2723 013014 012737 077406 172304 MOV #200 1*400+UP+RW,@#KIPDR2 ;SET KIPDR2 = RW UP 200 BLOCKS
2724 013022 012737 077406 172306 MOV #200-1*400+UP+RW,@#KIPDR3 ;SET KIPDR3 = RW UP 200 BLOCKS
2725 013030 005037 172310 CLR @#KIPDR4
2726 013034 005037 172312 CLR @#KIPDR5
2727 013040 105767 166060 TSTB $AUTOB ;;V IF TRUE XXDP CHAIN MODE
2728 013044 001005 BNE VMK ;;V DO NOT TOUCH KIPDR6 OR KIPDR7
2729 013046 005037 172314 CLR @#KIPDR6
2730 013052 012737 077406 172316 MOV #200-1*400+UP+RW,@#KIPDR7 ;SET KIPDR7 = RW UP 200 BLOCKS
2731 013060 005037 172340 VMK: CLR @#KIPAR0 ;MAP PAR0 INTO BANK0
2732 013064 012737 000200 172342 MOV #200,@#KIPAR1 ;MAP PAR1 INTO BANK1
2733 013072 005037 172344 CLR @#KIPAR2 ;MAP PAR2 INTO BANK0
2734 013076 005037 172346 CLR @#KIPAR3
2735 013102 005037 172350 CLR @#KIPAR4
2736 013106 005037 172352 CLR @#KIPAR5
2737 013112 105767 166006 TSTB $AUTOB ;;V IF TRUE XXDP CHAIN MODE
2738 013116 001005 BNE VMK1 ;;V DO NOT TOUCH KIPAR6 OR KIPAR7
2739 013120 005037 172354 CLR @#KIPAR6
2740 013124 012737 177600 172356 MOV #177600,@#KIPAR7 ;MAP PAR7 INTO I/O BANK
2741 013132 005767 165400 VMK1: TST MAVA ;IF 22 BIT ADR NOT AVAILABLE
2742 013136 100003 BPL 1$ ; THEN BRANCH
2743 013140 052737 000020 172516 BIS #BIT4,@#SR3 ; ELSE ENABLE 22 BIT ADDRESSING
2744 013146 012737 000001 177572 1$: MOV #1,@#SRO ;ENABLE MEMORY MANAGEMENT
2745 013154 000207 RTS ;RETURN
2746
2747
2748 ;*****
2749 ;* MEMORY ADDRESS POINTER INITIALIZATION ROUTINES.
2750 ;*****
2751
2752 INITMM:
      013156 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
      013160 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
2753 013162 012767 100000 166612 MOV #BIT15,PLUS1
2754 013170 005002 CLR R2 ;INITIALIZE ADDRESS
2755 013172 005767 165340 TST MAVA
2756 013176 001410 BEQ 2$
2757 013200 012700 000020 MOV #20,R0
2758 013204 016701 166606 MOV .BITPT,R1
2759 013210 005021 1$: CLR (R1)+
2760 013212 077002 SOB R0,1$
2761 013214 005037 172344 CLR @#KIPAR2
2762 013220 012767 013362 166526 2$: MOV #INITEX,MMORE
2763 013226 066767 165300 166520 ADD RELOC,MMORE
2764 013234 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
      013236 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
2765 013240 004767 000124 JSR PC,MMUP
2766 013244 004767 004574 JSR PC,$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      013250 000007 ;FATAL ERROR
      .WORD 7 ;ERROR TYPE CODE.
    
```

```

2767 013252 000000          HALT          ;FATAL ERROR!!! NO MEM INDICATED IN MEMMAP ABOVE 8K!
2768
2769
2770 013254          INITDN:
      013254 010046          MOV      R0,-(SP)          ;;PUSH R0 ON STACK
      013256 010146          MOV      R1,-(SP)          ;;PUSH R1 ON STACK
2771 013260 005002          CLR      R2
2772 013262 005767 165250          TST      MMAVA
2773 013266 001414          BEQ      2$
2774 013270 012700 000020          MOV      #20,R0
2775 013274 016701 166516          MOV      .BITPT,R1
2776 013300 005021          1$:    CLR      (R1)+
2777 013302 077002          SOB      R0,1$
2778 013304 012767 000001 166470          MOV      #BIT0,PLUS1
2779 013312 005037 172344          CLR      @#KIPAR2
2780 013316 000403          BR      3$
2781 013320 012767 000020 166366          2$:    MOV      #BIT4,BITPT
2782 013326 012767 013362 166420          3$:    MOV      #INITEX,MMORE
2783 013334 066767 165172 166412          ADD      RELOC,MMORE
2784 013342 012601          MOV      (SP)+,R1          ;;POP STACK INTO R1
      013344 012600          MOV      (SP)+,R0          ;;POP STACK INTO R0
2785 013346 004767 000362          JSR      PC,MMDOWN
2786 013352 004767 004466          JSR      PC,$ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
      ;FATAL ERROR
      .WORD      7          ;ERROR TYPE CODE
2787 013360 000000          HALT          ;FATAL ERROR!!! NO MEM INDICATED IN MEMMAP ABOVE 8K!
2788 013362 010467 166366          INITEX: MOV      R4,MMORE
2789 013366 000204          RTS      R4
2790
2791          ;*****
2792          ;* COMMON UPWARDS ADDRESSING ROUTINE
2793          ;* FINDS NEXT EXISTING 8K BANK AND UPDATES POINTERS.
2794          ;* GOES TO ADDRESS IN "MMORE" IF MORE BANKS.
2795          ;* DOES STRAIGHT EXIT WHEN ALL MEMORY HAS BEEN DONE.
2796          ;*****
2797
2798 013370 012705 020000          MMUP:  MOV      #20000,R5          ;SET UP 8K TEST COUNTER
2799          ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
          ;* WITHOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
      013374 106746          MFPS      -(SP)          ;PUT THE PROCESSOR STATUS ON THE STACK
      013376 105066 000001          CLR      1(SP)          ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
          ;ON PSW RETURN.
2800 013402 004767 005200          JSR      PC,$CKSWR      ;GO TO THE SUBROUTINE
2801 013406 005767 165124          TST      MMAVA          ;CHECK FOR MEMORY MANAGEMENT
2802 013412 001475          BEQ      7$          ;IF MMAVA = 0, BRANCH TO NON <T MODE
      013414 010046          MOV      R0,-(SP)          ;;PUSH R0 ON STACK
      013416 010146          MOV      R1,-(SP)          ;;PUSH R1 ON STACK
      013420 010346          MOV      R3,(SP)          ;;PUSH R3 ON STACK
      013422 010446          MOV      R4,-(SP)          ;;PUSH R4 ON STACK
2803 013424 012702 040000          MOV      #40000,R2          ;MMU AVAIL. SET UP VA = 0,PAR2
2804 013430 005767 166346          TST      PLUS1          ;CHECK IF FIRST TIME ENTRY
2805 013434 001003          BNE      100$          ;DO NOT ADD 8K TO PAR2
2806          ;UPON FIRST ENTRY
2807 013436 062737 000400 172344          1$:    ADD      #400,@#KIPAR2          ;ADD 8K TO PAR2
2808 013444 016701 166346          100$:  MOV      .BITPT,R1
2809 013450 012700 000020          MOV      #20,R0
2810 013454 006367 166322          ASL      PLUS1

```



```

2811 013460 006121      2$:  ROL      (R1)+      ;ROTATE TOTAL TABLE TO INSURE
2812 013462 077002      SOB      R0,2$      ;ROTATION OF ONE BIT
2813 013464 103005      BCC      101$      ;TESTING IS DONE WHEN CARRY BIT IS SET
2814 013466 012604      MOV      (SP)+,R4   ;POP STACK INTO R4
      013470 012603      MOV      (SP)+,R3   ;POP STACK INTO R3
      013472 012601      MOV      (SP)+,R1   ;POP STACK INTO R1
      013474 012600      MOV      (SP)+,R0   ;POP STACK INTO R0
2815 013476 000510      BR       12$      ;DONE,READY TO EXIT
2816 013500 016703 166312 101$: MOV      .BITPT,R3
2817 013504 016704 166302      MOV      .TSTMAP,R4
2818 013510 012700 000020      MOV      #20,R0
2819 013514 032324      3$:  BIT      (R3)+,(R4)+
2820 013516 001002      BNE      4$
2821 013520 077003      SOB      R0,3$
2822 013522 000745      BR       1$
2823 013524 013737 172344 172346 4$:  MOV      @#KIPAR2,@#KIPAR3
2824 013532 062737 000200 172346      ADD      #200,@#KIPAR3
2825 013540 012604      MOV      (SP)+,R4   ;POP STACK INTO R4
      013542 012603      MOV      (SP)+,R3   ;POP STACK INTO R3
      013544 012601      MOV      (SP)+,R1   ;POP STACK INTO R1
      013546 012600      MOV      (SP)+,R0   ;POP STACK INTO R0
2826 013550 005767 164762      TST      MMAVA
2827 013554 100005      BPL      5$
2828 013556 032767 100000 166166      BIT      #BIT15,BITPT+36
2829 013564 001005      BNE      6$
2830 013566 000436      BR       9$
2831 013570 032767 100000 166116 5$:  BIT      #BIT15,BITPT
2832 013576 001432      BEQ      9$
2833 013600 012705 010000      6$:  MOV      #10000,R5
2834 013604 000427      BR       9$
2835 013606 006367 166170      7$:  ASL      PLUS1
2836 013612 006167 166076      ROL      BITPT
2837 013616 103440      BCS      12$
2838 013620 036767 166070 165726      BIT      BITPT,TSTMAP
2839 013626 001003      BNE      8$
2840 013630 062702 040000      ADD      #40000,R2
2841 013634 000764      BR       7$
2842 013636 032767 000010 166050 8$:  BIT      #BIT3,BITPT
2843 013644 001407      BEQ      9$
2844 013646 012705 010000      MOV      #10000,R5
2845 013652 005767 166116      TST      FLG30K
2846 013656 001402      BEQ      9$
2847 013660 062705 004000      ADD      #4000,R5
2848 013664 032767 000001 166022 9$:  BIT      #BIT0,BITPT
2849 013672 001407      BEQ      10$
2850 013674 066702 166062      ADD      FSTADR,R2
2851 013700 005767 166056      TST      FSTADR      ;FSTADR = STARTING ADDRESS
2852      ;          0 OR 1000 IF VECTOR AREA IS
2853      ;          PROTECTED.
2854 013704 001402      BEQ      10$
2855 013706 162705 000400      SUB      #400,R5      ;ADJUST ADDR COUNTER TO PROTECT 0-1000
2856 013712 016716 166036      10$: MOV      MMORE,(SP)
2857 013716 000207      11$: RTS      PC
2858      ;* BEFORE FINAL EXIT, CHECK FOR ANY NON TRAP PARITY ERRORS.
2859 013720 005767 167446      12$: TST      MPRX      ;CHECK FOR ANY PARITY REGISTERS PRESENT.
2860 013724 001402      BEQ      13$      ;BR IF NONE.
2861 013726 004767 002106      JSR      PC,CKPMER  ;CHECK FOR PARITY MEMORY ERRORS.
    
```

```

2862 013732 000207      13$:   RTS      PC          ;STRAIGHT RETURN.
2863
2864                    ;:*****
2865                    ;* MEMORY DOWNWARD; ADDRESSING SUBROUTINE.
2866                    ;* FINDS NEXT LOWER 8K BANK AND UPDATES POINTERS.
2867                    ;* GOES TO ADDRESS IN "MMORE" IF MORE BANKS.
2868                    ;* DOES STRAIGHT EXIT WHEN ALL MEMORY HAS BEEN DONE.
2869                    ;:*****
2870
2871 013734 012705 020000 MM IN: MOV    #20000,R5      ;SET UP 8K TEST COUNTER
2872                    ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
                    ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
                    MFPS    -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
                    CLR B    1(SP)     ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                    ;ON PSW RETURN.
                    JSR     PC      $CKSWR ;GO TO THE SUBROUTINE
2873 013746 004767 004634      TST     MMAVA      ;CHECK FOR MEMORY MANAGEMENT
2874 013752 005767 164560      BEQ     7$         ;IF MMAVA = 0 THEN BR TO NON KT MODE
2875 013756 001502              MOV     R0,-(SP)   ;:PUSH R0 ON STACK
                    MOV     R1,-(SP)   ;:PUSH R1 ON STACK
                    MOV     R3,-(SP)   ;:PUSH R3 ON STACK
                    MOV     R4,-(SP)   ;:PUSH R4 ON STACK
2876 013760 010046              MOV     R4,-(SP)
2877 013762 010146              MOV     R4,-(SP)
2878 013764 010346              MOV     R4,-(SP)
2879 013766 010446              MOV     R4,-(SP)
2880 013770 162737 000400 172344 1$: SUB     #400,@#KIPAR2 ;DOWN DATE TO NEXT 8K BANK
2881 013776 016700 166014      MOV     .BITPT,R0
2882 014002 052700 000040      ADD     #40,R0     ;SET UP TO MOVE POINTER
2883 014006 012703 000020      MOV     #20,R3    ;ONE POSITION THRU 20 WORD TABLE
2884 014012 006267 165764      ASR     PLUS1     ;GET INITIAL VALUE OF BIT
2885 014016 006040              ROR     -(R0)     ;MOVE THE POINTER
2886 014020 077302              SOB     R3,2$
2887 014022 103005              BCC     100$      ;CONTINUE TESTING UNTIL CARRY BIT SET
2888 014024 012604              MOV     (SP)+,R4  ;:POP STACK INTO R4
2889 014026 012603              MOV     (SP)+,R3  ;:POP STACK INTO R3
2890 014030 012601              MOV     (SP)+,R1  ;:POP STACK INTO R1
2891 014032 012600              MOV     (SP)+,R0  ;:POP STACK INTO R0
2892 014034 000517              BR      11$      ;TESTING DONE,READY TO EXIT
2893 014036 016700 165754 100$: MOV     .BITPT,R0 ;THEN WE HAVE TESTED LAST BANK
2894 014042 062700 000040      ADD     #40,R0   ;IF NO UNDERFLOW SET UP TO
2895 014046 016701 165740      MOV     .TSTMAP,R1 ;SEE IF BANK SHOULD BE TESTED
2896 014052 062701 000040      ADD     #40,R1
2897 014056 012703 000020      MOV     #20,R3
2898 014062 034041 3$: BIT     -(R0),-(R1) ;CHECK IF BANK IS UNDER TEST
2899 014064 001002              BNE     4$       ;IF YES GO SET UP PARS
2900 014066 077303              SOB     R3,3$   ;IF NO CHECK ALL POSSIBLES
2901 014070 000737              BR      1$       ;IF NOT GO CHECK NEXT LOWER 8K
2902 014072 013737 172344 172346 4$: MOV     @#KIPAR2,@#KIPAR3 ;MAKE PAR2 AND PAR3 POINT TO SAME
2903 014100 062737 000200 172346 ADD     #200,@#KIPAR3 ;MAKE KIPAR3 UPPER 4K
2904 014106 012702 100000      MOV     #100000,R2 ;SET UP FIRST ADDRESS + 2
2905 014112 012604              MOV     (SP)+,R4 ;:POP STACK INTO R4
2906 014114 012603              MOV     (SP)+,R3 ;:POP STACK INTO R3
2907 014116 012601              MOV     (SP)+,R1 ;:POP STACK INTO R1
2908 014120 012600              MOV     (SP)+,R0 ;:POP STACK INTO R0
2909 014122 055767 164410      TST     MMAVA    ;CHECK FOR 22 BIT ADDRESSING
2910 014126 100005              BPL     5$       ;IF NO,CHECK 18 BIT MODE
2911 014130 032767 100000 165614 BIT     #BIT15,BITPT+36 ;TESTING HIGHEST 22 BIT SEG.?
2912 014136 001005              BNE     6$       ;IF YES,DO ONLY 4K SEGMENT
2913 014140 000442              BR      9$       ;IF NO,DO 8K SEGMENT
2914 014142 032767 100000 165544 5$: BIT     #BIT15,BITPT ;TESTING HIGHEST 18 BIT SEGMENT
    
```

J6

```

2905 014150 001436          BEQ      9$          ;IF NO ,DO 8K SEGMENT
2906 014152 012702 060000    6$:    MOV      #60000,R2    ;DO ONLY 4K SEGMENT
2907 014156 012705 010000    MOV      #10000,R5   ;SET UP 4K WORD COUNTER
2908 014162 000431          BR       9$          ;GET OVER NON KT ROUTINE
2909 014164 006267 165524    7$:    ASR      BITPT      ;POINT TO NEXT LOWEST BANK
2910 014170 103441          BCS     11$         ;IF CARRY FOR LSB THEN DONE TESTING
2911 014172 036767 165516 1653c4 BIT      BITPT,TSTMAP ;IS THIS BANK UNDER TEST?
2912 014200 001003          BNE     8$
2913 014202 162702 040000    SUB      #40000,R2
2914 014206 000766          BR       7$
2915 014210 032767 000010 165476 8$:    BIT      #BIT3,BITPT
2916 014216 001413          BEQ     9$
2917 014220 162702 020000    SUB      #20000,R2
2918 014224 012705 010000    MOV      #10000,R5
2919 014230 005767 165540    TST     FLG30K
2920 014234 001404          BEQ     9$
2921 014236 062702 010000    ADD      #10000,R2
2922 014242 062705 004000    ADD      #4000,R5
2923 014246 032767 000001 165440 9$:    BIT      #BIT0,BITPT
2924 014254 001405          BEQ     10$
2925 014256 005767 165500    TST     FSTADR      ;CHECK FIRST ADDRESS = 0 OR 1000
2926 014262 001402          BEQ     10$
2927 014264 162705 000400    SUB      #400,R5     ;PROTECT VECTOR AREA 0-1000 FROM
2928                                ;BEING TESTED IF FSTADR =1000
2929 014270 016716 165460    10$:    MOV      MMORE,(SP)  ;SETUP RETURN FOR MORE TESTING
2930 014274 000207          11$:    RTS      PC        ;RETURN
2931

```

```

2933 .SBTTL SUBROUTINES FOR ADDRESS AND WORSE CASE NOISE TESTS.
2934 ;;*****
2935 ;* SUBROUTINE TO CALCULATE PHYSICAL ADDRESS AND PUT IT IN R0 (BOTTOM 16 BITS).
2936 ;;*****
2937 014276 005767 164234 PHYADR: TST MAVA ;CHECK FOR MEM MGMT AVAILABLE
2938 014302 001433 BEQ 4$ ;BRANCH IF NO MEM MGMT
2939 014304 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
    014306 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
    014310 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
    014312 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
2940 014314 010005 1$: MOV R0,R5 ;SAVE FOR PHYSICAL ADDR. ADDITION
2941 014316 042700 017777 BIC #17777,R0 ;CLEAR VIRTUAL ADDR BITS
2942 014322 012701 000014 MOV #12.,R1 ;SET UP ROTATE COUNTER
2943 014326 006200 2$: ASR R0 ;TO SHIFT PAR POINTER
2944 014330 077102 SOB R1,2$ ;INTO BITS 0-3
2945 014332 012704 172340 MOV #KIPAR0,R4 ;STORE START OF PARS
2946 014336 060004 ADD R0,R4 ;USE PAR POINTER IN 0-3 AS INDEX
2947 014340 011403 MOV (R4),R3 ;STORE CONTENTS OF PROPER PAR
2948 014342 012701 000006 MOV #6,R1 ;SET UP COUNTER TO
2949 014346 006303 3$: ASL R3 ;CONVERT PAR CONTENTS
2950 014350 077102 SOB R1,3$ ;TO A PHYSICAL "K" ADDRESS
2951 014352 010500 MOV R5,R0 ;STORE VIRTUAL ADDRESS
2952 014354 042700 160000 BIC #160000,R0 ;CLEAR PAR POINTER
2953 014360 060300 ADD R3,R0 ;ADD PHYSICAL "K" ADDRESS
2954 ;TO OBTAIN 16 BIT PHYSICAL ADDRESS
2955 014362 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
    014364 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
    014366 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
    014370 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
2956 014372 000207 4$: RTS PC ;EXIT WITH PHYSICAL ADDR IN R0
2957
2958 ;;*****
2959 ;* SUBROUTINE TO PUT BANK NUMBER INTO R0.
2960 ;;*****
2961 014374 005000 BANKNO: CLR R0 ;INIT R0
2962 014376 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
    014400 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
    014402 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
    014404 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
2963 014406 016701 165404 MOV .BITPT,R1 ;START OF BIT POINTER TABLE
2964 014412 012703 000020 MOV #20.,R3 ;SET UP BITPT TABLE COUNTER
2965 014416 012702 000020 1$: MOV #20.,R2 ;SET UP ROTATE COUNTER FOR 1 WORD
2966 014422 012104 MOV (R1)+,R4 ;GET WORD TO ROTATE BIT
2967 014424 006204 2$: ASR R4 ;ROTATE BITPT WORD TO FIND BANK
2968 014426 103410 BCS 4$ ;IF CARRY SET ,THEN BANK FOUND
2969 014430 105200 INCB RC ;COUNT BANKS.
2970 014432 001004 BNE 3$ ;BR IF NOT OVERFLOW.
2971 014434 004767 003404 JSR PC,$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    ;FATAL ERROR
    .WORD 7 ;ERROR TYPE CODE.
2972 014440 000007 HALT ;FATAL ERROR!!! NO POINTER FOUND.
2973 014442 000000 3$: SOB R2,2$ ;IF NOT FINISHED ROTATING WORD
2974 014444 077211 SOB R3,1$ ;GO BACK AND ROTATE AGAIN
2975 014446 077315 ;IF NOT FINISHED BITPT TABLE
2976 ;THEN ROTATE THROUGH NEXT WORD.
2977 014450 012604 4$: MOV (SP)+,R4 ;;POP STACK INTO R4
    
```

```

014452 012603      MOV      (SP)+,R3      ;;POP STACK INTO R3
014454 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
014456 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
2978 014451 000207      RTS      PC              ;RETURN
2979
2980      ;;*****
2981      ;* SUBROUTINE TO WRITE THE CONSTANT IN R0 INTO ALL OF MEMORY.
2982      ;;*****
2983 014462          SETCON:
014462 004467 176470      JSR      R4,      INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2984 014466 010022      1$:      MOV      R0,      (R2)+ ;MOV CONSTANT INTO MEMORY
2985 014470 077502      SOB      R5,      1$ ;BRANCH IF MORE IN CURRENT BLOCK
014472 004767 176672      JSR      PC,      MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
2986 014476 000207      RTS      PC              ;RETURN
2987
2988      ;;*****
2989      ;* ROUTINE TO ROTATE 'C' BIT THROUGH A MEMORY LOCATION.
2990      ;;*****
2991 014500 106112      ROTATE:  ROLB      (R2)      ;(R2)=177776 OR 000001
2992 014502 106112      ROLB      (R2)      ;(R2)=177775 OR 000002
2993 014504 106112      ROLB      (R2)      ;(R2)=177773 OR 000004
2994 014506 106112      ROLB      (R2)      ;(R2)=177767 OR 000010
2995 014510 106112      ROLB      (R2)      ;(R2)=177757 OR 000020
2996 014512 106112      ROLB      (R2)      ;(R2)=177737 OR 000040
2997 014514 106112      ROLB      (R2)      ;(R2)=177677 OR 000100
2998 014516 106112      ROLB      (R2)      ;(R2)=177777 OR 000000
2999 014520 106122      ROLB      (R2)+     ;(R2)=177577 OR 000200
3000 014522 106112      ROLB      (R2)      ;(R2)=177377 OR 000400
3001 014524 106112      ROLB      (R2)      ;(R2)=176777 OR 001000
3002 014526 106112      ROLB      (R2)      ;(R2)=175777 OR 002000
3003 014530 106112      ROLB      (R2)      ;(R2)=173777 OR 004000
3004 014532 106112      ROLB      (R2)      ;(R2)=167777 OR 010000
3005 014534 106112      ROLB      (R2)      ;(R2)=157777 OR 020000
3006 014536 106112      ROLB      (R2)      ;(R2)=137777 OR 040000
3007 014540 106112      ROLB      (R2)      ;(R2)=077777 OR 100000
3008 014542 106122      ROLB      (R2)+     ;(R2)=177777 OR 000000
3009 014544 000207      RTS      PC              ;RETURN
3010
3011      ;;*****
3012      ;* SUBROUTINE TO WRITE 3 XOR 9 PATTERN INTO 256. WORD BLOCK.
3013      ;;*****
3014 014546 012704 000020      W3X9:  MOV      #16.,R4      ;EACH LOOP WRITES 256. WORDS
3015
3016 014552 010022      2$:      MOV      R0,(R2)+
3017 014554 010022      MOV      R0,(R2)+
3018 014556 010022      MOV      R0,(R2)+
3019 014560 010022      MOV      R0,(R2)+
3020
3021 014562 010322      MOV      R3,(R2)+
3022 014564 010322      MOV      R3,(R2)+
3023 014566 010322      MOV      R3,(R2)+
3024 014570 010322      MOV      R3,(R2)+
3025
3026 014572 010022      MOV      R0,(R2)+
3027 014574 010022      MOV      R0,(R2)+
3028 014576 010022      MOV      R0,(R2)+
3029 014580 010022      MOV      R0,(R2)+

```

M6

```
3030
3031 014602 010322      MOV      R3,(R2)+
3032 014604 010322      MOV      R3,(R2)+
3033 014606 010322      MOV      R3,(R2)+
3034 014610 010322      MOV      R3,(R2)+
3035
3036 014612 005304      DEC      R4
3037 014614 001356      BNE     2$
3038 014616 010046      MOV      R0,-(SP) ;SAVE R0
      014620 010300      MOV      R3,R0 ;PUT R3 INTO R0
      014622 012603      MOV      (SP)+,R3 ;PUT SAVED R0 INTO R3
3039 014624 000207      RTS     PC ;RETURN
```

```

3041 .SBTTL RELOCATION SUBROUTINES.
3042 ;;*****
3043 ;* ROUTINE TO RELOCATE PROGRAM CODE
3044 ;;*****
3045 RELOC:
        MOV     R2,-(SP)      ;;PUSH R2 ON STACK
        MOV     R3,-(SP)      ;;PUSH R3 ON STACK
        MOV     R4,-(SP)      ;;PUSH R4 ON STACK
3046 4$:   MOV     (R5)+, R2     ;GET FIRST LOCATION.
3047       MOV     (R5)+, R3     ;GET FIRST LOCATION OF DESTINATION.
3048       MOV     #20000, R4    ;SET UP 8K COUNTER.
3049 1$:   MOV     (R2)+, (R3)+ ;MOV THE DATA.
3050       DEC     R4           ;COUNT THE WORDS.
3051       BNE    1$           ;BR IF MORE.
3052       MOV     #20000, R4    ;RESET THE COUNTER.
3053 2$:   CMP     -(R2), -(R3) ;CHECK THE DATA JUST MOVED.
3054       BEQ    3$           ;BR IF DATA OK.
3055       MOV     (R2), $GDDAT ;GET SOURCE DATA.
3056       MOV     (R3), $BDDAT ;GET DESTINATION DATA.
3057       MOV     R2, $GDADR   ;GET SOURCE ADDRESS.
3058       MOV     R3, $BDADR   ;GET DESTINATION ADDRESS.
3059       JSR    PC, $ERROR    ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD   23            ;ERROR TYPE CODE.
3060       HALT   ;FATAL ERROR!!! RELOCATION FAILED.
3061       SUB    #4, R5        ;ADJUST RETURN POINTER.
3062       BR    4$           ;GO BACK AND TRY AGAIN.
3063 3$:   DEC     R4           ;COUNT WORDS.
3064       BNE    2$           ;BR IF MORE.
3065       JSR    R5, $PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
        .WORD   PRELOC       ;ADDRESS OF MESSAGE TO BE TYPED
        .WORD   "PROGRAM RELOCATED TO " ;"PROGRAM RELOCATED TO "
3066       MOV     R3, -(SP)    ;PUT THE DATA ON THE STACK.
3067       JSR    PC, $TYPAD    ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
        MOV     (SP)+, R4      ;;POP STACK INTO R4
        MOV     (SP)+, R3      ;;POP STACK INTO R3
        MOV     (SP)+, R2      ;;POP STACK INTO R2
3068       RTS     R5          ;RETURN
3069 ;;*****
3070 ;* SUBROUTINE TO MOVE PROGRAM FROM BOTTOM TO TOP 8K BANK OF 128KW MEMORY.
3071 ;* HIGHEST AVAILABLE BANK WITH KT WILL BE 700000 - 737776
3072 ;* HIGHEST AVAILABLE BANK NON-KT WILL BE 100000 - 137776
3073 ;;*****
3074 1$:   RELTOP: CMP     #1, PRGMAP ;CHECK THAT THE PROGRAM IS NOW IN BANKS 0 AND 1.
3075       BEQ    1$           ;BR IF OK
3076       JSR    PC, $ERROR    ;*** ERROR *** (GO TYPE A MESSAGE)
        ;FATAL ERROR
        .WORD   7            ;ERROR TYPE CODE.
3077       HALT   ;FATAL ERROR!!! PROG SHOULD BE IN BANKS 0 AND 1
3078 1$:   MOV     R0,-(SP)      ;;PUSH R0 ON STACK
        MOV     R1,-(SP)      ;;PUSH R1 ON STACK
3079       TST    MAVA         ;
3080       BEQ    10$          ;
3081       MOV     #7600, @#KIPAR3 ;SET PAR TO TOP OF MEM
3082       MOV     #BIT15, R0    ;...HI 128K.
3083 2$:   SUB    #400, @#KIPAR3 ;BACK DOWN ONE BANK.
3084       ROR    R0           ;...LO 64K.
    
```

```

3085 015024 103445          BCS      90$
3086 015026 030067 164462  BIT      R0,      MEMMAP ;CHECK FOR BANK EXISTS.
3087 015032 001770          BEQ      2$        ;BR IF NO BANK FOUND.
3088 015034 013737 172346 172344 3$:  MOV     @*KIPAR3,@*KIPAR2 ;COPY PAR
3089 015042 162737 000200 172344 4$:  SUB     #200, @*IPAR2 ;BACK DOWN WITH LOW PAR.
3090 015050 030067 163460          BIT      R0,      PRGMAP ;CHECK FOR CONFLICT.
3091 015054 001031          BNE     90$        ;ABORT IF DESTINATION OVERLAYS SOURCE.
3092 015056 004567 177544          JSR     R5,      RELOC  ;GO RELOCATE PROGRAM.
3093 015062 000000          .WORD   0         ;SOURCE FIRST ADDRESS.
3094 015064 040000          .WORD   40000      ;DESTINATION FIRST ADDRESS.
3095 015066 013737 172344 172340  MOV     @*KIPAR2,@*KIPAR0 ;RELOCATE LO BANK
3096 015074 013737 172346 172342  MOV     @*KIPAR3,@*KIPAR1 ;RELOCATE HI BANK.
3097          ;* PROGRAM SHOULD NOW BE EXECUTING OUT OF LAST TWO BANKS OF MEMORY.
3098 015102 000461          BR      30$        ;BR TO COMMON EXIT.
3099
3100 015104 012700 000010 10$:  MOV     #BIT3, R0    ;SET BANK POINTER TO TOP OF MEM.
3101 015110 012701 140000          MOV     #140000,R1  ;SET ADDRESS POINTER TO TOP
3102 015114 162701 040000 11$:  SUB     #40000, R1  ;BACK DOWN ONE BANK.
3103 015120 006200          ASR     R0         ;MOVE POINTER DOWN ONE BANK.
3104 015122 103406          BCS     90$        ;BR IF OVERFLOW.
3105 015124 030067 164364  BIT      R0,      MEMMAP ;CHECK IF THIS BANK EXISTS.
3106 015130 001771          BEQ     11$        ;BR IF NON-EXISTANT BANK.
3107 015132 030067 163376  BIT      R0,      PRGMAP ;CHECK FOR A PROGRAM CONFLICT.
3108 015136 001404          BEQ     12$        ;BR IF NO CONFLICT.
3109 015140 004767 002700 90$:  JSR     PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
          ;FATAL ERROR
          .WORD   7         ;ERROR TYPE CODE.
3110 015144 000007          HALT    ;FATAL ERROR!!! NOT ENOUGH MEMORY??
3111 015146 000000          MOV     R1,      13$   ;SET DATA FOR RELOCATION SUBROUTINE.
3112 015150 010167 000006 12$:  JSR     R5,      RELOC  ;GO RELOCATE THE PROGRAM TO TOP OF MEM.
3113 015154 004567 177446          .WORD   0         ;SOURCE STARTING ADDRESS.
3114 015162 000000 13$:  .WORD   0         ;DESTINATION STARTING ADDRESS.
3115 015164 010167 163342  MOV     R1,      RELOCF ;SET RELOCATION FACTOR IN UNRELOCATED CODE.
3116 015170 060107          ADD     R1,      PC    ;JUMP TO RELOCATED PROGRAM
3117          ;* PROGRAM NOW EXECUTING OUT OF TOP OF MEMORY.
3118 015172 060106          ADD     R1,      SP    ;ADJUST THE STACK POINTER TO TOP OF MEMORY.
3119 015174 010167 163332  MOV     R1,      RELOCF ;SET THE RELOCATION FACTOR.
3120 015200 060137 000004          ADD     R1,      @*ERRVEC ;ADJUST ERROR VECTOR.
3121 015204 060137 000024          ADD     R1,      @*PWRVEC ;ADJUST POWER FAIL VECTOR.
3122 015210 060137 000114          ADD     R1,      @*PARVEC ;ADJUST PARITY ERROR VECTOR.
3123 015214 060167 163710          ADD     R1,      SWR   ;ADJUST SOFTWARE SWITCH REGISTER.
3124 015220 060167 163706          ADD     R1,      DISPLAY ;ADJUST SOFTWARE DISPLAY REGISTER.
3125 015224 062701 002004 14$:  ADD     #RADTAB,R1  ;POINT TO THE RELATIVE RELOCATION TABLE.
3126 015230 066721 163276 15$:  ADD     RELOCF,(R1)+ ;ADD RELOCATION FACTOR TO ADDRESSES IN TABLE.
3127 015234 005721 16$:  TST     (R1)+       ;CHECK FOR INTERUM TERMINATOR.
3128 015236 001776          BEQ     16$        ;BR SO AS TO NOT MODIFY ZERO.
3129 015240 024127 177777          CMP     -(R1), #-1  ;CHECK FOR END OF TABLE.
3130 015244 001371          BNE     15$        ;BR IF MORE IN TABLE.
3131 015246 010067 163262 30$:  MOV     R0,      PRGMAP ;SET NEW PROGRAM MAP...LO 64K.
3132 015252 012601          MOV     (SP)+,R1   ;POP STACK INTO R1
          MOV     (SP)+,R0 ;POP STACK INTO R0
3133 015256 066716 163250          ADD     RELOCF,(SP) ;ADJUST RETURN ADDRESS.
3134 015262 000207          RTS     PC        ;RETURN
3135
3136          ;*****
3137          ;* SUBROUTINE TO RELOCATE PROGRAM BACK TO BANKS 0 AND 1.
    
```



```

3138
3139 015264 032767 000001 163242 ;*****
3140 015272 001404 ;RELO: BIT #1, PRGMAP ;CHECK FOR PROGRAM ALREADY IN BANKS 0 OR 1.
3141 015274 004767 002544 ; BEQ 1$, ;BR IF NO CONFLICT.
; JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
;FATAL ERROR
; .WORD 7 ;ERROR TYPE CODE.
3142 015300 000007 ;HALT ;FATAL ERROR!!! PROGRAM ALREADY IN BANKS 0 OR 1!!!!
3143 015302 000000 163226 1$: TST MMAVA ;CHECK FOR MEM MGMT.
3144 015310 001417 ; BEQ 10$ ;BR IF NO MEMMGMT.
3145 015312 005037 172344 ; CLR @#KIPAR2 ;SET PAR 2 TO BANK 0.
3146 015316 012737 000200 172346 ; MOV #200, @#KIPAR3 ;SET PAR 3 TO BANK 1.
3147 015324 004567 177276 ; JSR R5, RELOC ;GO MOVE 8K INTO BANKS 0 AND 1.
3148 015330 000000 ; .WORD 0 ;SOURCE STARTING ADDRESS.
3149 015332 040000 ; .WORD 40000 ;DESTINATION SIAF ING ADDRESS.
3150 015334 005037 172340 ; CLR @#KIPARO ;RESTORE PAR 0 TO BANK0.
3151 015340 012737 000200 172342 ; MOV #200, @#KIPAR1 ;RESTORE PAR 1 TO BANK 1.
3152 ;* PROGRAM IS NOW EXECUTING OUT OF BANKS 0 AND 1.
3153 015346 000440 ; BR 30$ ;BR TO COMMON EXIT.
3154
3155 015350 016746 163156 10$: MOV RELOCF, -(SP) ;PUT RELOCATION FACTOR ONTO THE STACK.
3156 015354 011667 000004 ; MOV (SP), 20$ ;SET DATA FOR RELOC SUBROUTINE.
3157 015360 004567 177242 ; JSR R5, RELOC ;GO MOVE THE PROGRAM BACK TO BANKS 0 AND 1.
3158 015364 000000 20$: ; .WORD 0 ;SOURCE STARTING ADDRESS.
3159 015366 000000 ; .WORD 0 ;DESTINATION STARTING ADDRESS.
3160 015370 161607 ; SUB (SP), PC ;JUMP TO RELOCATED PROGRAM.
3161 ;* THE PROGRAM IS NOW EXECUTING OUT OF BANKS 0 AND 1.
3162 015372 161606 ; SUB (SP), SP ;RESET THE STACK POINTER.
3163 015374 010046 ; MOV RO, -(SP) ;PUSH RO ON STACK
3164 015376 012700 002004 ; MOV #RADTAB,RO ;SET UP POINTER TO RELATIVE ADDRESS TABLE.
3165
3166 015402 166620 000002 21$: SUB 2(SP), (RO)+ ;RESET ADDRESSES TO UNRELOCATED VALUES.
3167 015406 005720 22$: TST (RO)+ ;CHECK FOR TERMINATORS.
3168 015410 001776 ; BEQ 22$ ;BR OVER TERMINATORS.
3169 015412 024027 177777 ; CMP -(RO), #-1 ;CHECK FOR END OF TABLE INDICATOR.
3170 015416 001371 ; BNE 21$ ;BR IF MORE ADDRESSES IN TABLE.
3171 015420 012600 ; MOV (SP)+,RO ;POP STACK INTO RO
3172 015422 161637 000004 ; SUB (SP), @#ERRVEC ;ADJUST ERROR VECTOR.
3173 015426 161637 000024 ; SUB (SP), @#PWRVEC ;ADJUST POWER FAIL VECTOR.
3174 015432 161637 000114 ; SUB (SP), @#PARVEC ;ADJUST PARITY ERROR VECTOR.
3175 015436 161667 163466 ; SUB (SP), SWR ;ADJUST SOFTWARE SWITCH REGISTER.
3176 015442 161667 163464 ; SUB (SP), DISPLAY ;ADJUST SOFTWARE DISPLAY REGISTER.
3177 015446 162616 23$: SUB (SP)+, (SP) ;ADJUST RETURN ADDRESS.
3178 015450 005067 163056 30$: CLR RELOCF ;RESET RELOCATION FACTOR.
3179 015454 012767 000001 163052 ; MOV #1, PRGMAP ;SET PROGRAM MAP TO POINT TO BANKS 0 AND 1.
3180 015462 000207 ; RTS PC ;RETURN.
3181
3182 ;*****
3183 ;* THIS SUBROUTINE MOVES THE LOADER AREA BACK TO THE "TOP" OF MEMORY FROM
3184 ;* WHENCE IT CAME. THE LOADER AREA IS SAVED AT THE END OF THE 8K OF
3185 ;* PROGRAM CODE WHEN THE PROGRAM IS INITIALLY RUN.
3186 ;*****
3187 015464 016700 164020 ;RESLDR: MOV LMAD, RO ;CHECK IF THE LOADERS WERE SAVED.
3188 015470 001004 ; BNE 1$ ;BR IF LOADER AREA WAS SAVED.
3189 015472 004767 002346 ; JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
;FATAL ERROR
; .WORD 7 ;ERROR TYPE CODE.
3190 015476 000007 ;HALT ;FATAL ERROR!!! CAN'T RESTORE LOADER AREA IF IT WASN'T SAVED.
3190 015500 000000
    
```

```

3191 015502 005767 163030      1$:  TST      MMAVA      ;CHECK FOR MEM MGMT.
3192 015506 001402              BEQ      2$          ;SKIP IF NO MEM MGMT.
3193 015510 005037 177572      CLR      @#SRO      ;DISABLE MEM MGMT.
3194 015514 012701 040000      2$:  MOV      #40000, R1  ;GET END OF 8K, ASSUME PROG NOT RELOCATED.
3195 015520 012702 003000      MOV      #1536., R2  ;GET COUNTER.
3196 015524 014140              3$:  MOV      (R1), -(R0) ;MOVE THE LOADER AREA.
3197 015526 005302              DEC      R2         ;COUNT HOW LONG THE AREA IS.
3198 015530 001375              BNE      3$        ;BR IF NOT MORE TO MOVE.
3199 015532 005067 163752      CLR      LMAD      ;CLEAR MONITOR SAVED FLAG
3200 015536 005767 162774      TST      MMAVA      ;CHECK FOR MEM MGMT.
3201 015542 001402              BEQ      4$        ;BR IF NO MEM MGMT.
3202 015544 005237 177572      INC      @#SRO      ;ENABLE MEM MGMT.
3203 015550 000207              4$:  RTS      PC      ;RETURN.
3204
3205      ;* ROUTINE TO SAVE THE LOADERS AT THE END OF 8K.
3206 015552 005767 163732      SAVLDR: TST      LMAD      ;CHECK IF LOADERS HAVE BEEN SAVED ALREADY.
3207 015556 001024              BNE      4$        ;BRANCH IF ALREADY SAVED
3208 015560 012700 040000      MOV      #40000, R0  ;GET END OF 8K
3209 015564 010001              MOV      R0, R1     ;GET END OF 8K
3210 015566 012737 015600 000004  MOV      #2$, @#ERRVEC ;SET UP TIMEOUT VECTOR
3211 015574 011020              1$:  MOV      (R0), (R0)+ ;SEARCH FOR END OF MEMORY
3212 015576 000776              BR       1$        ;KEEP SEARCHING
3213 015600 022626              2$:  CMP      (SP)+, (SP)+ ;RESTORE STACK POINTER
3214 015602 012737 023430 000004  MOV      #ERRTRP, @#ERRVEC ;RESET TIMEOUT VECTOR.
3215 015610 010046              MOV      R0, -(SP)  ;SAVE LAST MEMORY ADDRESS (CONTIGUOUS)
3216 015612 012702 003000      MOV      #1536., R2  ;SET UP WORD COUNTER
3217 015616 014041              3$:  MOV      -(R0), -(R1) ;SAVE THE LOADERS
3218 015620 005302              DEC      R2         ;COUNT THE WORDS
3219 015622 001375              BNE      3$        ;BRANCH IF MORE WORDS
3220 015624 012667 163660      MOV      (SP)+, LMAD ;SAVE LAST MEMORY ADDRESS
3221 015630 000207              4$:  RTS      PC      ;RETURN
    
```

```

3223 .SBTTL PARITY MEMORY TRAP SERVICE AND SUBROUTINES.
3224 ;:*****
3225 ;* PARITY MEMORY UNEXPECTED ERROR TRAP SERVICE ROUTINE.
3226 ;* FIND OUT WHICH REGISTER DETECTED THE ERROR.
3227 ;* THEN SCAN MEMORY TO SEE IF PARITY ERROR STILL SET AND REPORT LOCATION.
3228 ;:*****
3229 015632 011667 163254 PESRV: MOV (SP), $BDADR ;GET PC OF INSTRUCTION WHICH CAUSED ERROR.
3230 015636 004567 004110 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
    015642 024643 .WORD UNEXPT ;ADDRESS OF MESSAGE TO BE TYPED
    ;"UNEXPECTED MEMORY PARITY TRAP."
3231 015644 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
    015646 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
3232 015650 016703 164150 MOV MPRX, R3 ;GET POINTER TO PARITY REGISTERS.
3233 015654 005733 1$: TST @R3+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
3234 015656 100415 SMI 3$ ;BR IF THIS REGISTER SHOWS THE ERROR.
3235 015660 005713 TST (R3) ;CHECK FOR TABLE TERMINATOR.
3236 015662 001374 BNE 1$ ;BR IF MORE REGISTERS.
3237 015664 004767 002154 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    ;***ERROR*** NO REGISTER INDICATED ERROR
    .WORD 24 ;ERROR TYPE CODE.
    BR 4$ ;EXIT
3238 015672 000417 2$: TST (R3) ;CHECK FOR TABLE TERMINATOR.
3239 015674 005713 BEQ 4$ ;BR IF NO MORE PARITY REGISTERS.
3240 015676 001415 TST @R3+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
3241 015700 005733 BPL 2$ ;BR IF NO ERROR FLAG.
3242 015702 100374 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
3243 015704 004567 004042 .WORD MTOE ;ADDRESS OF MESSAGE TO BE TYPED
    ;"MORE THAN ONE ERROR FOUND."
3244 015712 3$:
    015712 004767 001010 30070$: JSR PC, SPRNTQ ;SET UP VALUES FOR ERROR PRINTING.
    015716 004767 002122 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    015722 000025 .WORD 25 ;ERROR TYPE CODE.
3245 015724 004767 000262 JSR PC, PSCAN ;GO SCAN MEMORY FOR BAD PARITY.
3246 015730 000761 BR 2$ ;GO LOOK FOR MORE ERRORS.
3247 015732 4$:
    015732 012603 MOV (SP)+,R3 ;POP STACK INTO R3
    015734 012601 MOV (SP)+,R1 ;POP STACK INTO R1
3248 015736 000002 RTI ;RETURN.
3249
3250 ;:*****
3251 ;ROUTINE TO ENABLE PARITY ERROR ACTION ON MA/MF PARITY MEMORIES
3252 ;THIS ROUTINE IS MEANT TO CATCH UNEXPECTEDS
3253 ;:*****
3254 015740 005767 165426 MAMF: TST MPRX ;CHECK IF ANY PARITY REGISTERS EXIST.
3255 015744 001434 BEQ MAMF2 ;EXIT IF NO PARITY REGISTERS.
3256 015746 032777 000100 163154 BIT #SW6, @SWR ;CHECK FOR INHIBIT PARITY ERROR DETECTION.
3257 015754 001030 BNE MAMF2 ;EXIT IF NO PARITY ERROR DETECTION.
3258 015756 005767 162550 TST RELOCF ;CHECK IF PROGRAM RELOCATED OUT OF BANK 0.
3259 015762 001410 BEQ SETAE ;BR IF PROG IN BANK 0.
3260 015764 032777 000040 163136 BIT #SW5, @SWR ;CHECK IF VECTORS PROTECTED.
3261 015772 001004 BNE SETAF ;BR IF VECTOR AREA PROTECTED.
3262 015774 026727 163762 001000 CMP FSTADR, #1000 ;CHECK FOR STARTING ADDRESS ABOVE THE VECTORS.
3263 016002 103415 BLO MAMF2 ;EXIT IF VECTORS EXPOSED TO TESTING.
3264
3265 016004 016737 164022 000114 SETAE: MOV .PESRV, @#PARVEC ;SET PARITY ERROR TRAP VECTOR
3266 016012 005037 000116 CLR @#PARVEC+2 ;PRIORITY LEVEL 0 ON TRAP
3267 016016 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
    
```

```

3268 016020 016703 164000      MOV      .MPRX, R3      ;GET PARITY REGISTER TABLE POINTER.
3269 016024 052733 000001 MAMF1:  BIS      #AE, @R3+  ;SET ACTION ENABLE BIT IN PARITY REG
3270 016030 005713          TST      (R3)         ;CHECK FOR END OF TABLE.
3271 016032 001374          BNE     MAMF1         ;BR IF MORE PARITY REGISTERS.
3272 016034 012603          MOV     (SP)+,R3     ;POP STACK INTO R3
3273 016036 000207 MAMF2:  RTS      PC      ;RETURN.
3274
3275
3276      ;*****
3277      ;* SUBROUTINE TO CHECK PARITY REGISTERS FOR ERRORS THAT DIDN'T TRAP.
3278      ;*****
3278 016040          CHGG2:
3279 016040 005767 165326 CKPMER: TST      MPRX      ;CHECK IF ANY PARITY REGISTERS EXIST.
3280 016044 001437          BEQ     4$           ;BR IF NO PARITY REGISTERS.
3281 016046 032777 000100 163054 BIT      #SW6, @SWR    ;CHECK FOR INHIBIT PARITY ERROR CHECKING.
3282 016054 001033          BNE     4$           ;BR IF PARITY ERROR CHECKING INHIBITED.
3283 016056 010346          MOV     R3,-(SP)     ;PUSH R3 ON STACK
3284 016060 016703 163740          MOV     .MPRX, R3    ;GET PARITY REG TABLE POINTER.
3285 016064 005733 1$:      TST      @R3+      ;CHECK THE PARITY REG FOR AN ERROR FLAG.
3286 016066 100023          BPL     3$           ;BR IF NO ERROR
3287 016070 032773 000001 177776 BIT      #BIT0, @-2(R3) ;CHECK IF A TRAP SHOULD HAVE OCCURRED.
3288 016076 001410          BEQ     2$           ;BR IF NO ACTION ENABLE. CHGG2
3289 016100 004767 000622 30071$: JSR     PC, SPRNTQ   ;SET UP VALUES FOR ERROR PRINTING.
3290 016104 004767 001734          JSR     PC, $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
3291 016110 000026          .WORD  26          ;ERROR TYPE CODE.
3292 016112 000411          BR      3$           ;
3293 016114 004767 000072          JSR     PC, PSCAN   ;GO SCAN ALL MEMORY FOR PARITY ERRORS.
3294 016120 2$:
3295 016120 004767 000602 30072$: JSR     PC, SPRNTQ   ;SET UP VALUES FOR ERROR PRINTING.
3296 016124 004767 001714          JSR     PC, $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
3297 016130 000027          .WORD  27          ;ERROR TYPE CODE.
3298 016132 004767 000054          JSR     PC, PSCAN   ;GO SCAN ALL MEMORY FOR PARITY ERRORS.
3299 016136 005713 3$:      TST      (R3)         ;CHECK FOR TABLE TERMINATOR.
3300 016140 001351          BNE     1$           ;BR IF MORE.
3301 016142 012603          MOV     (SP)+,R3     ;POP STACK INTO R3
3302 016144 000207 4$:      RTS      PC      ;RETURN.
3303
3304      ;*****
3305      ;* SUBROUTINE TO VERIFY THAT THE PARITY CSR DOES CONTROL THE BANK
3306      ;* UNDER TEST. MATCH THE BANK UNDER TEST WITH THE PARITY MAP TABLE.
3307      ;* RETURN IF MEM BANK HAS BEEN MAPPED IN PARITY MAP TABLE.
3308      ;* RETURN+2 IF ERROR, MEM BANK HAS NOT BEEN MAPPED.
3309      ;*****
3309 016146          PARMAT:
3310 016146 010046          MOV     R0,-(SP)    ;PUSH R0 ON STACK
3311 016150 010146          MOV     R1,-(SP)    ;PUSH R1 ON STACK
3312 016152 010446          MOV     R4,-(SP)    ;PUSH R4 ON STACK
3313 016154 012700 000020          MOV     #20,R0      ;COUNT OF PARITY MAP TABLE
3314 016160 016701 163632          MOV     .BITPT,R1  ;MEM BANK UNDER TEST POINTER
3315 016164 010304          MOV     R3,R4       ;STORE PARITY MAP TABLE
3316 016166 005724          TST     (R4)+       ;MOVE PAST CSR ADDRESS TO MAP TABLE
3317 016170 032124 1$:      BIT      (R1)+,(R4)+ ;CHECK FOR TABLE MATCH
3318 016172 001003          BNE     2$           ;BR IF MATCH MADE IN TABLES
3319 016174 005300          DEC     R0          ;DO NEXT WORD IN TABLE
3320 016176 001374          BNE     1$           ;BR TO NEXT WORD IN TABLE
3321 016200 005725          TST     (R5)+       ;NO MATCH MADE, RETURN +2
3322 016202 2$:

```

```

016202 012604      MOV      (SP)+,R4      ;;POP STACK INTO R4
016204 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
016206 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
3317 016210 000205  RTS      R5
3318
3319
3320
3321
3322
3323
3324
3325
3326
3327
3328
3329
3330
3331
3332
3333
016212 010046
016212 010146
016214 010246
016216 010346
016220 010446
016222 010446
3334 016224 004567 003522
016230 025000

3335 016232 004767 000434
3336 016236 013746 000114
016242 013746 000116
3337 016246 012737 000116 000114
3338 016254 005037 000116
3339 016260 005004
3340 016262 005002
3341 016264 012700 000001
3342 016270 016701 163520
3343 016274 005767 162236
3344 016300 001413
3345 016302 013746 172344
016306 013746 172346
3346 016312 005037 172344
3347 016316 012737 000200 172346
3348 016324 012702 040000
3349
3350 016330 030011 1$: BIT      R0,(R1)      ;IF 8K BANK DOES EXIST
3351 016332 001003 2$: BNE      2$          ; THEN BRANCH
3352 016334 062702 C40000 ADD      #40000,R2      ; ELSE UPDATE ADDRESS TO NEXT 8K BANK
3353 016340 000475 BR        10$          ; AND BRANCH TO SEE IF SHOULD CONTINUE TESTING
3354
3355 016342 111267 163422 2$: MOV      (R2),TEMP    ;READ THE BYTE LOCATION
3356 016346 016703 163452 MOV      .MPRX,R3      ;POINT TO PARITY CSR TABLE
3357
3358 016352 005733 3$: TST      @R3+        ;IF NO ERROR FLAG SET IN CSR
3359 016354 100024 BPL      5$            ; THEN BRANCH
3360 016356 005704 TST      R4            ; ELSE IF NOT FIRST ERROR
3361 016360 001003 BNE      4$            ; THEN BRANCH
    
```

```

*****
* AFTER A PARITY ERROR IS ENCOUNTERED THIS SUBROUTINE IS USED
* TO SCAN ALL PARITY MEMORY PER THE PMEMAP TABLE LOOKING FOR BYTE LOCATIONS
* CAUSING THE PARITY ERROR. UPON FINDING THE LOCATION(S) A MESSAGE
* WILL BE TYPED AND THE LOCATION WILL BE REWRITTEN IN ORDER TO RESTORE GOOD PARITY.
* STORAGE USED:
* R0 = BANK POINTER
* R1 = PARITY CSR TABLE POINTER (MPRX)
* R2 = ADDRESS POINTER
* R3 = PMEMAP TABLE ENTRY
* R4 = ERROR DETECT FLAG
* TEMP = TEMPORARY STORAGE
*****
PSCAN:
    
```

```

3362 016362 005367 162514          DEC      $ERTTL      ; ELSE ADJUST ERROR COUNT
3363 016366 005204                INC      R4          ; AND SET ERROR DETECT FLAG
3364
3365 016370                4$:
016370 004767 000332          30073$: JSR      PC,      SPRNTQ ; SET UP VALUES FOR ERROR PRINTING.
016374 004767 001444          JSR      PC,      $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
016400 000030                .WORD    30          ; ERROR TYPE CODE.
3366 016402 111212          MOVWB   (R2), (R2) ; REWRITE LOCATION TO CLEAR BAD PARITY
3367 016404 005053          CLR     @-(R3)    ; CLEAR ERROR FLAG IN PARITY CSR
3368 016406 105712          TSTB   (R2)      ; REREAD LOCATION TO SEE IF ERROR CLEARED
3369 016410 005733          TST    @-(R3)+   ; IF ERROR CLEARED
3370 016412 001405          BEQ    5$        ; THEN BRANCH
3371 016414 004567 003332          JSR    R5,      $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
016420 025042                .WORD    PEWNC      ; ADDRESS OF MESSAGE TO BE TYPED
; "PARITY ERROR WILL NOT CLEAR"
; CLEAR PARITY CSR
3372 016422 005073 177776          CLR     @-2(R3)
3373
3374 016426 005713                5$: TST     (R3)      ; IF NOT DONE WITH TABLE
3375 016430 001350                BNE    3$        ; THEN TRY NEXT CSR FOR ERROR
3376 016432 005202                INC     R2        ; ELSE UPDATE ADDRESS POINTER
3377 016434 005767 162076          TST    MMAVA     ; IF MEMORY MANAGEMENT AVAILABLE
3378 016440 001013                BNE    7$        ; THEN BRANCH
3379 016442 005767 163326          TST    FLG30K    ; ELSE IF NOT 30K SYSTEM
3380 016446 001404                BEQ    6$        ; THEN BRANCH
3381 016450 022702 170000          CMP    #170000, R2 ; ELSE IF 30K I/O PAGE
3382 016454 001467                BEQ    14$       ; THEN ALL DONE CHECKING MEMORY
3383 016456 000423                BR     9$        ; ELSE TRY SOMEMORE
3384
3385 016460 022702 160000                6$: CMP    #160000, R2 ; IF 28K I/O PAGE
3386 016464 001463                BEQ    14$       ; THEN ALL DONE CHECKING MEMORY
3387 016466 000417                BR     9$        ; ELSE TRY SOMEMORE
3388
3389 016470 022702 060000                7$: CMP    #60000, R2 ; IF NOT POSSIBLY THE I/O PAGE
3390 016474 001014                BNE    9$        ; THEN BRANCH AND TRY SOMEMORE
3391 016476 005767 162034          TST    MMAVA     ; ELSE IF 22 BIT ADDRESSING AVAILABLE
3392 016502 100405                BMI    8$        ; THEN BRANCH
3393 016504 022737 007600 172346          CMP    #7600, @#KIPAR3 ; ELSE IF 128K I/O PAGE
3394 016512 001444                BEQ    13$       ; THEN ALL DONE
3395 016514 000404                BR     9$        ; ELSE TRY SOMEMORE
3396
3397 016516 022737 177600 172346          8$: CMP    #177600, @#KIPAR3 ; IF 2M I/O PAGE
3398 016524 001437                BEQ    13$       ; THEN ALL DONE CHECKING
3399
3400 016526 032702 037777                9$: BIT    #MASK8K, R2 ; IF NOT DONE WITH THIS 8K BANK
3401 016532 001303                BNE    2$        ; THEN TRY ANOTHER ADDRESS
3402
3403 016534 006300                10$: ASL    R0          ; IF NOT DONE WITH 128K BANK
3404 016536 001012                BNE    11$       ; THEN BRANCH
3405 016540 062701 000002          ADD    #2, R1    ; ELSE POINT TO NEXT PMEMAP ENTRY
3406 016544 016700 163244          MOV    .PMEMAP, R0 ; START OF TABLE
3407 016550 062700 000040          ADD    #40, R0   ; END OF TABLE
3408 016554 020001                CMP    R0, R1    ; IF DONE WITH TABLE
3409 016556 001422                BEQ    13$       ; THEN ALL DONE
3410 016560 012700 000001          MOV    #BIT0, R0 ; ELSE REINIT BANK POINTER
3411
3412 016564 005767 161746                11$: TST    MMAVA     ; IF KT AVAILABLE
3413 016570 001004                BNE    12$       ; THEN BRANCH

```

```

3414 016572 032700 000020          BIT    #BIT4,R0          ; ELSE IF AT 32K LIMIT
3415 016576 001016          BNE    14$              ; THEN ALL DONE CHECKING
3416 016600 000653          BR     1$              ; ELSE TRY SOMEMORE
3417
3418 016602 062737 000400 172344 12$:  ADD    #400,@#KIPAR2    ;UPDATE PARS TO MAP TO NEXT
3419 016610 062737 000400 172346      ADD    #400,@#KIPAR3    ; 8K BANK
3420 016616 012702 040000          MOV    #40000,R2       ;REINIT ADDRESS
3421 016622 000642          BR     1$              ;AND TRY SOMEMORE
3422
3423 016624          13$:  MOV    (SP)+,@#KIPAR3    ;;POP STACK INTO @#KIPAR3
      016624 012637 172346          MOV    (SP)+,@#KIPAR2    ;;POP STACK INTO @#KIPAR2
      016630 012637 172344
3424
3425 016634 005704          14$:  TST    R4              ;IF ERROR FOUND
3426 016636 001003          BNE    15$              ; THEN BRANCH
3427 016640 004567 003106          JSR    R5,$PRINT       ;GO PRINT OUT THE FOLLOWING MESSAGE.
      016644 024204          .WORD  NOPE$          ;ADDRESS OF MESSAGE TO BE TYPED
3428
3429 016646          15$:  MOV    (SP)+,@#116      ;;POP STACK INTO @#116
      016646 012637 000116          MOV    (SP)+,@#114      ;;POP STACK INTO @#114
      016652 012637 000114          MOV    (SP)+,R4         ;;POP STACK INTO R4
      016656 012604          MOV    (SP)+,R3         ;;POP STACK INTO R3
      016660 012603          MOV    (SP)+,R2         ;;POP STACK INTO R2
      016662 012602          MOV    (SP)+,R1         ;;POP STACK INTO R1
      016664 012601          MOV    (SP)+,R0         ;;POP STACK INTO R0
      016666 012600
3430
3431 016670 000207          16$:  RTS     PC              ;RETURN
3432
3433
3434
3435
3436
3437 016672          CLRPAR:
      016672 010346          MOV    R3,-(SP)        ;;PUSH R3 ON STACK
      016674 016703 163124          MOV    MPRX,R3         ;GET PARITY REGISTER TABLE POINTER.
3438 016674 016703 163124          1$:  TST    (R3)            ;CHECK FOR THE TABLE TERMINATOR.
3439 016700 005713          BEQ    2$              ;BR IF DONE ALL PARITY REGISTERS.
3440 016702 001402          CLR    @ (R3)+         ;CLEAR THE PARITY REGISTER.
3441 016704 005033          BR     1$              ;BR FOR MORE
3442 016706 000774          2$:  MOV    (SP)+,R3        ;;POP STACK INTO R3
3443 016710          RTS     PC              ;RETURN.
      016710 012603
3444 016712 000207
3445
3446
3447
3448
3449
3450
3451
3452 016714 010267 162170          .SBTTL SUBROUTINES TO SET UP DATA FOR ERROR PRINTOUT ROUTINE.
3453 016720 005067 162170          ;;*****
3454 016724 000435          ;* THESE ROUTINES ARE USED TO TRANSFER DATA TO COMMON TAG AREA (. $CMTAG)
3455
3456 016726 014367 162216          ;* FOR ERROR PRINTOUT BY .$ERROR & .$ERRTYP ROUTINES FROM **SYSMAC**.
3457 016732 013367 162214          ;;*****
3458 016736 016767 163026 162152  SPRNT:  MOV    R2,$GDADR    ;SAVE THE ADDRESS UNDER TEST.
      016736 000435          CLR    $GDDAT          ;SHOULD BE DATA IS "0".
      016767 163026 162152          BR     SPRNTB
3456 016726 014367 162216          SPRNTQ: MOV    -(R3), $TMP0 ;GET THE PARITY REGISTER ADDRESS.
3457 016732 013367 162214          MOV    @ (R3)+, $TMP1  ;GET THE CONTENTS OF THE PARITY REG.
3458 016736 016767 163026 162152          MOV    TEMP,$DDAT
    
```

```

3459 016744 010267 162140      MOV    R2,$GDADR
3460 016750 000425      BR     SPREND
3461
3462 016752 011367 162172      SPRNTP: MOV   (R3), $TMPO ;GET THE PARITY REGISTER ADDRESS.
3463 016756 010267 162126      SPRNTO: MOV   R2,   $GDADR ;GET THE MEMORY ADDRESS BEING TESTED
3464 016762 000414      BR     SPNTA ;BR TO COMMON SECTION.
3465
3466 016764 010267 162120      SPRNT1: MOV   R2,   $GDADR ;GET THE MEMORY ADDRESS BEING TESTED
3467 016770 005367 162114      DEC   $GDADR ;ADJUST IT FOR PRINTOUT.
3468 016774 000407      BR     SPRNTA ;BR TO COMMON SECTION.
3469
3470 016776 010367 162146      SPRNT3: MOV   R3,   $TMPO ;GET THE DATA IN R3.
3471 017002 010267 162102      SPRNT2: MOV   R2,   $GDADR ;GET THE MEMORY ADDRESS BEING TESTED
3472 017006 162767 000002 162074      SUB   #2,   $GDADR ;ADJUST IT FOR PRINTOUT.
3473 017014 010067 162074      SPRNTA: MOV   R0,   $GDDAT ;GET WHAT THE DATA SHOULD BE
3474 017020 010167 162072      SPRNTB: MOV   R1,   $BDDAT ;GET WHAT THE DATA WAS
3475 017024 000207      SPREND: RTS   PC ;RETURN TO ENTER ERROR ROUTINES
3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494

```

```

*****
;* THIS ROUTINE WILL TYPE OUT A MAP OF MEMORY BANKS.
;* UPON ENTERING THIS ROUTINE R0 WILL CONTAIN THE ADDRESS
;* OF THE TABLE TO BE TYPED OUT. THE ROUTINE REQUIRES THAT THE
;* TABLE CONTAIN 16 DECIMAL WORDS.
;* STORAGE USED:
;* R0 = MAP TABLE ADDRESS
;* R1 = BANK POINTER
;* R2 = CONSECUTIVE ZERO BANK FLAG
;* R3 = HIGH MEMORY ADR ... LO 16 BITS
;* R4 = HIGH MEMORY ADR ... HI 6 BITS
;* LMEMLO = LOW MEMORY ADR ... LO 16 BITS
;* LMEMHI = LOW MEMORY ADR ... HI 6 BITS
;* BNKTAB = ADDRESS OF TABLE TO BE PROCESSED
;* ENDBKT = LAST ADDRESS + 2 OF TABLE TO BE PROCESSED
;* FLG30K = 30K MEMORY FLAG
*****

```

```

3495 017026 010037 017526      TYPMAP: MOV   R0,@#BNKTAB ;SAVE ADDRESS OF TABLE
3496 017032 012737 000040 017530      MOV   #40,@#ENDBKT ;LOAD END BANK TABLE WITH 40
3497 017040 060037 017530      ADD   R0,@#ENDBKT ;GET LAST ADR + 2 INTO ENDBKT
3498 017044 005710      1$: TST   (R0) ;ANY MEMORY IN THIS TABLE ENTRY
3499 017046 001011      BNE   2$ ; THEN GO PRINT OUT LOCATIONS
3500 017050 005720      TST   (R0)+ ; ELSE POINT TO NEXT TABLE ENTRY
3501 017052 023700 017530      CMP   @#ENDBKT,R0 ;IF NOT END OF TABLE
3502 017056 001372      BNE   1$ ; THEN TRY AGAIN
3503 017060 004567 002666      JSR   R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
;ADDRESS OF MESSAGE TO BE TYPED
; "NO MEMORY FOUND."
;EXIT
3504 017066 000167 000426      JMP   13$
3505
3506 017072 013700 017526      2$: MOV   @#BNKTAB,R0 ;RESTORE MAP TABLE ADDRESS
3507 017076 010146      MOV   R1,-(SP) ;:PUSH R1 ON STACK
;:PUSH R2 ON STACK
;:PUSH R3 ON STACK
;:PUSH R4 ON STACK
;INIT LOW MEM ADR ... LO 16 BITS
;INIT LOW MEM ADR ... HI 6 BITS
;INIT LAST BANK IN MAP FLAG
017100 010246      MOV   R2,-(SP)
017102 010346      MOV   R3,-(SP)
017104 010446      MOV   R4,-(SP)
3508 017106 005067 000410      CLR   LMEMLO
3509 017112 005067 000406      CLR   LMEMHI
3510 017116 005067 162646      CLR   TEMP

```



```

3511 017122 012703 177777      MOV    #-1,R3      ;INIT HIGH MEM ADR ... LO 16 BITS
3512 017126 010304             MOV    R3,R4      ;INIT HIGH MEM ADR ... HI 6 BITS
3513 017130 012702 000001      MOV    #1,R2      ;INIT CONSECUTIVE ZERO BANK FLAG
3514
3515 017134 012701 000001      3$:   MOV    #BIT0,R1  ;INIT BANK POINTER
3516
3517 017140 030110             4$:   BIT    R1,(R0)  ;IF THIS 8K BANK IS NOT PRESENT
3518 017142 001405             BEQ    5$          ; THEN GO PRINTOUT MAP
3519 017144 062703 040000      ADD    #40000,R3  ; ELSE UPDATE HIGH MEM TO TOP OF THIS BANK
3520 017150 005504             ADC    R4
3521 017152 005002             CLR    R2
3522 017154 000541             BR     11$        ;CLEAR CONSECUTIVE ZERO BANK FLAG
3523
3524 017156 005702             5$:   TST    R2        ;IF CONSECUTIVE ZERO BANK
3525 017160 001123             BNE   10$        ; THEN DO NOT PRINT MESSAGE
3526 017162 005202             INC    R2        ; ELSE UPDATE CONSECUTIVE ZERO BANK FLAG
3527 017164 022703 177777      CMP    #177777,R3 ;IF NOT 32K, 128K OR 2M BOUNDARY
3528 017170 001023             BNE   9$        ; THEN GO PRINT MESSAGE
3529 017172 005767 161340      TST   MMAVA     ; ELSE IF 22BIT ADDRESSING
3530 017176 100413             BMI   7$        ; THEN GO WORK ON 22 BIT ADDRESSING
3531 017200 001006             BNE   6$        ; OR GO WORK ON 18 BIT ADDRESSING
3532 017202 005767 162566      TST   FLG30K    ; ELSE IF NOT 30K SYSTEM
3533 017206 001412             BEQ   8$        ; THEN GO ADJ TO 28K BOUNDARY
3534 017210 162703 010000      SUB    #10000,R3 ; ELSE ADJ TO 30K BOUNDARY
3535 017214 000411             BR     9$        ;AND GO PRINT
3536
3537 017216 022704 000003      6$:   CMP    #3,R4    ;IF NOT 128K BOUNDARY
3538 017222 001006             BNE   9$        ; THEN GO PRINT
3539 017224 000403             BR     8$        ; ELSE GO ADJ TO 124K BOUNDARY
3540
3541 017226 022704 000077      7$:   CMP    #77,R4   ;IF NOT 2M BOUNDARY
3542 017232 001002             BNE   9$        ; THEN GO PRINT
3543
3544 017234 162703 020000      8$:   SUB    #20000,R3 ;ADJ HIGH MEMORY TO BELOW I/O PAGE
3545
3546 017240             9$:
017240 010346             MOV    R3,-(SP)  ;; PUSH R3 ON STACK
017242 010446             MOV    R4,-(SP)  ;; PUSH R4 ON STACK
017244 016746 000252      MOV    LMEMLO,-(SP) ;; PUSH LMEMLO ON STACK
017250 016746 000250      MOV    LMEMHI,-(SP) ;; PUSH LMEMHI ON STACK
3547 017254 004567 002472      JSR    R5,$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
017260 024005             .WORD FROM      ;ADDRESS OF MESSAGE TO BE TYPED
3548 017262 006303             ASL   R3         ;SHIFT BIT 15 INTO CARRY
3549 017264 006104             ROL   R4         ;SHIFT BIT 15 TO ALIGN WITH BITS 17-16
3550 017266 006003             ROR   R3         ;RESTORE BITS 14-0
3551 017270 006367 000226      ASL   LMEMLO    ;SHIFT BIT 15 INTO CARRY
3552 017274 006167 000224      ROL   LMEMHI    ;SHIFT BIT 15 TO ALIGN WITH BITS 17 16
3553 017300 006067 000216      ROR   LMEMLO    ;RESTORE BITS 14-0
3554 017304 016746 000214      MOV    LMEMHI,-(SP) ;; SAVE LMEMHI FOR TYPEOUT
                                ;; TYPE ADDRESS BITS 21-15
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
017310 106746             MFPS  -(SP)     ;PUT THE PROCESSOR STATUS ON THE STACK
017312 105066 000001      CLRB  1(SP)    ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
017316 004767 003656      JSR   PC,$TYPOS ;GO TO THE SUBROUTINE
017322 003             .BYTE 3      ;;TYPE 3 DIGIT(S)

```

```

3555 017323 000          .BYTE 0          ;; SUPPRESS LEADING ZEROS
      017324 016746 000172 MOV    LMEMLO, (SP) ;; SAVE LMEMLO FOR TYPEOUT
                                      ;; TYPE ADDRESS BITS 14-0
; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
; * WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
      017330 106746          MFPS  -(SP)      ;; PUT THE PROCESSOR STATUS ON THE STACK
      017332 105066 000001 CLR   1(SP)      ;; HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                      ;; ON PSW RETURN.
      017336 004767 003636 JSR   PC,    $TYPOS ;; GO TO THE SUBROUTINE
      017342 005          .BYTE 5          ;; TYPE 5 DIGIT(S)
      017343 001          .BYTE 1          ;; TYPE LEADING ZEROS
3556 017344 004567 002402 JSR   R5,    $PRINT ;; GO PRINT OUT THE FOLLOWING MESSAGE.
      017350 024015          .WORD TO      ;; ADDRESS OF MESSAGE TO BE TYPED
3557 017352 010446          MOV    R4, -(SP)  ;; SAVE R4 FOR TYPEOUT
                                      ;; TYPE ADDRESS BITS 21-15
; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
; * WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
      017354 106746          MFPS  -(SP)      ;; PUT THE PROCESSOR STATUS ON THE STACK
      017356 105066 000001 CLR   1(SP)      ;; HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                      ;; ON PSW RETURN.
      017362 004767 003612 JSR   PC,    $TYPOS ;; GO TO THE SUBROUTINE
      017366 003          .BYTE 3          ;; TYPE 3 DIGIT(S)
      017367 000          .BYTE 0          ;; SUPPRESS LEADING ZEROS
3558 017370 010346          MOV    R3, -(SP)  ;; SAVE R3 FOR TYPEOUT
                                      ;; TYPE ADDRESS BITS 14-0
; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
; * WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
      017372 106746          MFPS  -(SP)      ;; PUT THE PROCESSOR STATUS ON THE STACK
      017374 105066 000001 CLR   1(SP)      ;; HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                      ;; ON PSW RETURN.
      017400 004767 003574 JSR   PC,    $TYPOS ;; GO TO THE SUBROUTINE
      017404 005          .BYTE 5          ;; TYPE 5 DIGIT(S)
      017405 001          .BYTE 1          ;; TYPE LEADING ZEROS
3559 017406 012667 000112 MOV    (SP)+, LMEMHI ;; POP STACK INTO LMEMHI
      017412 012667 000104 MOV    (SP)+, LMEMLO ;; POP STACK INTO LMEMLO
      017416 012604          MOV    (SP)+, R4  ;; POP STACK INTO R4
      017420 012603          MOV    (SP)+, R3  ;; POP STACK INTO R3
3560 017422 005767 162342 TST   TEMP      ;; HAS LAST BIT IN MAP PRINTED?
3561 017426 001030          BNE   14$      ;; YES, EXIT TO STACK CLEANUP
3562
3563 017430 062703 040000 10$: ADD    #40000, R3  ;; UPGRADE TO TOP OF THIS BANK
3564 017434 005504          ADC    R4          ;;
3565 017436 010367 000060 MOV    R3, LMEMLO ;; UPDATE LMEM TO THIS BANK
3566 017442 010467 000056 MOV    R4, LMEMHI ;;
3567 017446 062767 000001 000046 ADD    #1, LMEMLO ;; GET TO NEW LOW ADDRESS OF NEXT BANK
3568 017454 005567 000044 ADC    LMEMHI    ;;
3569
3570 017460 006301          11$: ASL   R1          ;; POINT TO NEXT 8K BANK
3571 017462 001226          BNE   4$          ;; BRANCH IF MORE TO TEST IN THIS MAP ENTRY
3572
3573 017464 005720          12$: TST   (R0)+      ;; UPDATE POINTER TO NEXT TABLE ENTRY
3574 017466 023700 017530 CMP    @#ENDBKT, R0 ;; IF NOT DONE WITH TABLE
3575 017472 001220          SNE   3$          ;; THEN TRY AGAIN
3576 017474 005760 177776 TST   -2(R0)     ;; CHECK IF LAST BANK AVAILABLE
3577 017500 100003          BPL   14$      ;; IF ZERO, TYPMAP PRINT COMPLETED
3578 017502 005267 162262 INC    TEMP      ;; ELSE SET LAST BANK PRINT FLAG
3579 017506 000623          BR    5$          ;; PRINT FOR LAST BANK
    
```

```

3580 017510          14$:      MOV      (SP)+,R4      ;;POP STACK INTO R4
      017510 012604      MOV      (SP)+,R3      ;;POP STACK INTO R3
      017512 012603      MOV      (SP)+,R2      ;;POP STACK INTO R2
      017514 012602      MOV      (SP)+,R1      ;;POP STACK INTO R1
      017516 012601
3581
3582 017520 000207      13$:      RTS      PC          ;RETURN TO CALLER
3583
3584 017522 000000      LMEMLO: .WORD 0      ; LOW MEMORY ADR ... LO 16 BITS
3585 017524 000000      LMEMHI: .WORD 0      ; LOW MEMORY ADR ... HI 6 BITS
3586 017526 000000      BNKTAB: .WORD 0     ; ADDRESS OF TABLE TO BE PROCESSED
3587 017530 000000      ENDBKT: .WORD 0    ; LAST ADDRESS + 2 0" TABLE
3588
3589
3596
      .SBTTL SCOPE HANDLER ROUTINE
      ;*****
      ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
      ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
      ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
      ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
      ;*SW14=1      LOOP ON TEST
      ;*SW11=1      INHIBIT ITERATIONS
      ;*SW09=1      LOOP ON ERROR
      ;*SW08=1      LOOP ON TEST IN SWR<4:0>
      ;*CALL
      ;*      SCOPE          ;;SCOPE=IOT
017532 $SCOPE:
      ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
      ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
017532 106746      MFPS      -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
017534 105066 000001      CLR      1(SP)      ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
017540 004767 001042      JSR      PC, $CKSWR ;GO TO THE SUBROUTINE
017544 010516      MOV      R5, (SP)   ;PUT RETURN PC ONTO STACK. SIMULATE JSR PC.
017546 032777 040000 161354 1$:      BIT      #BIT14,@SWR  ;;LOOP ON PRESENT TEST?
017554 001117      BNE      $OVER      ;;YES IF SW14=1
      ;*****START OF CODE FOR THE XOR TESTER*****
017556 000416      $XTSTR: BR      6$   ;;IF RUNNING ON THE "XOR" TESTER CHANGE
                                ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
017560 013746 000004      MOV      @#ERRVEC, -(SP) ;;SAVE THE CONTENTS OF THE ERROR VECTOR
017564 012737 017604 000004      MOV      #5$, @#ERRVEC ;;SET FOR TIMEOUT
017572 005737 177060      TST      @#177060      ;;TIME OUT ON XOR?
017576 012637 000004      MOV      (SP)+, @#ERRVEC ;;RESTORE THE ERROR VECTOR
017602 000466      BR      $SVLAD      ;;GO TO THE NEXT TEST
017604 022626      5$:      CMP      (SP)+, (SP)+  ;;CLEAR THE STACK AFTER A TIME OUT
017606 012637 000004      MOV      (SP)+, @#ERRVEC ;;RESTORE THE ERROR VECTOR
017612 000426      BR      7$          ;;LOOP ON THE PRESENT TEST
017614      6$: ;*****END OF CODE FOR THE XOR TESTER*****
017614 032777 000400 161306      BIT      #BIT08,@SWR  ;;LOOP ON SPEC. TEST?
017622 001407      BEQ      2$          ;;BR IF NO
017624 017746 161300      MOV      @SWR, -(SP)  ;;SET DESIRED TEST NUM. FROM SWR
017630 042716 000340      BIC      #SWR&MK, (SP) ;;STRIP AWAY UNDESIRED BITS
017634 122667 161232      CMPB    (SP)+, $TSTNM ;;ON THE RIGHT TEST?
017640 001465      BEQ      $OVER      ;;BR IF YES
017642 105767 161225      2$:      TSTB    $ERFLG      ;;HAS AN ERROR OCCURRED?
017646 001421      BEQ      3$          ;;BR IF NO
017650 126767 161231 161215      CMPB    $ERMAX, $ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?

```

SCOPE HANDLER ROUTINE

```

017656 101015          BHI      3$          ;;BR IF NO
017660 032777 001000 161242 BIT      #BIT09,@SWR  ;;LOOP ON ERROR?
017666 001404          BEQ      4$          ;;BR IF NO
017670 016767 161204 161200 7$: MOV     $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
017676 000446          BR       $OVER
017700 105067 161167          4$: CLRB   $ERFLG      ;;ZERO THE ERROR FLAG
017704 005067 161250          CLR     $TIMES     ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
017710 000415          BR       1$          ;;ESCAPE TO THE NEXT TEST
017712 032777 004000 161210 3$: BIT     #BIT11,@SWR  ;;INHIBIT ITERATIONS?
017720 001011          BNE     1$          ;;BR IF YES
017722 005767 161254          TST     $PASS      ;;IF FIRST PASS OF PROGRAM
017726 001406          BEQ     1$          ;;INHIBIT ITERATIONS
017730 005267 161140          INC     $JCNT      ;;INCREMENT ITERATION COUNT
017734 026767  51220 161132 CMP     $TIMES,$JCNT ;;CHECK THE NUMBER OF ITERATIONS MADE
017742 002024          BGE     $OVER      ;;BR IF MORE ITERATION REQUIRED
017744 012767 000001 161122 1$: MOV     #1,$ICNT   ;;REINITIALIZE THE ITERATION COUNTER
017752 016767 000052 161200 MOV     $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
017760 105267 151106          $SVLAD: INCB  $TSTNM   ;;COUNT TEST NUMBERS
017764 116767 161102 161206 MOVB   $TSTNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
017772 011667 161100          MOV    (SP),$LPADR  ;;SAVE SCOPE LOOP ADDRESS
017776 011667 161076          MOV    (SP),$LPERR  ;;SAVE ERROR LOOP ADDRESS
020002 005067 161154          CLR    $ESCAPE     ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
020006 112767 000001 161071 MOVB   #1,$ERMAX    ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
020014 016777 161052 161110 $OVER: MOV    $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
020022 016716 161050          MOV    $LPADR,(SP) ;;FUDGE RETURN ADDRESS
020026 000207          ENDINS: RTS     PC  ;;EXIT SCOPE ROUTINE BACK TO TEST.
020030 000001          $MXCNT: 1      ;;MAX. NUMBER OF ITERATIONS
3597  ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **S.SMAC**
020032 106746          MFPS   -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
020034 105066 000001          CLRB  1(SP)     ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
3598 020040 004767 000542          JSR   PC, $CKSWR ;GO TO THE SUBROUTINE
.SBTTL ERROR HANDLER ROUTINE
;*****
;THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
;SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
;AND GO TO $ERRTYP ON ERROR
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW15=1 HALT ON ERROR
;SW13=1 INHIBIT ERROR TYPEOUTS
;SW10=1 BELL ON ERROR
;SW09=1 LOOP ON ERROR
;CALL
;ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER
020044 $ERROR:
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
020044 106746          MFPS   -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
020046 105066 000001          CLRB  1(SP)     ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
020052 004767 000530          JSR   PC, $CKSWR ;GO TO THE SUBROUTINE
020056 062716 000002          ADD   #2,(SP)   ;ADJUST POINTER PAST CODE WORD.
020062 105267 161005          7$: INCB  $ERFLG  ;;SET THE ERROR FLAG
020066 001775          BEQ   7$        ;;DON'T LET THE FLAG GO TO ZERO
020070 016777 160776 161034 MOV    $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
020076 032777 002000 161024 BIT     #BIT10,@SWR  ;;BELL ON ERROR?

```

```

020104 001403      BEQ      1$      ;;NO - SKIP
020106 004567 001640 JSR      R5      $PRINT  ;;GO PRINT OUT THE FOLLOWING MESSAGE.
020112 001164      .WORD    $BELL    ;;ADDRESS OF MESSAGE TO BE TYPED
020114 005267 160762 1$: INC      $ERTTL  ;;COUNT THE NUMBER OF ERRORS
020120 011667 160762      MOV      (SP), $ERRPC  ;;GET ADDRESS OF ERROR INSTRUCTION
020124 162767 000002 160754 SUB      #2, $ERRPC
020132 117767 160750 160744 MOV      @($ERRPC, $ITEMB) ;;STRIP AND SAVE THE ERROR ITEM CODE
020140 032777 020000 160762 BIT      #BIT13, @SWR    ;;SKIP TYPEOUT IF SET
020146 001005      BNE      20$      ;;SKIP TYPEOUTS
020150 004767 000120 JSR      PC, $ERRTYP    ;;GO TO USER ERROR ROUTINE
020154 004567 001572 JSR      R5      $PRINT  ;;GO PRINT OUT THE FOLLOWING MESSAGE.
020160 001171      .WORD    $CRLF    ;;ADDRESS OF MESSAGE TO BE TYPED
020162
020162 122767 000001 161024 20$: CMP      #APTENV, $ENV  ;;RUNNING IN APT MODE
020170 001007      BNE      2$      ;;NO SKIP APT ERROR REPORT
020172 116767 160706 000004 MOV      $ITEMB, 21$   ;;SET ITEM NUMBER AS ERROR NUMBER
020200 004767 002152 JSR      PC, $ATY4    ;;REPORT FATAL ERROR TO APT
020204 000
020205 000
020206 000777      RR      22$      ;;APT ERROR LOOP
020210 005777 160714 2$: TST      @SWR      ;;HALT ON ERROR
020214 100006      BPL      3$      ;;SKIP IF CONTINUE
020216 000000      HALT     ;;HALT ON ERROR!
; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
; * WITHOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
020220 106746      MFPS    -(SP)    ;;PUT THE PROCESSOR STATUS ON THE STACK
020222 105066 000001 CLR      1(SP)      ;;HIGH BYTE CLEARED TO INSURE KERNEL MODE
; ON PSW RETURN,
020226 004767 000354 JSR      PC, $CKSWR  ;;GO TO THE SUBROUTINE
020232 032777 001000 160670 3$: BIT      #BIT09, @SWR  ;;LOOP ON ERROR SWITCH SET?
020240 001402      BEQ      4$      ;;BR IF NO
020242 016716 160632 MOV      $LPERR, (SP) ;;FUDGE RETURN FOR LOOPING
020246 005767 160710 4$: TST      $ESCAPE  ;;CHECK FOR AN ESCAPE ADDRESS
020252 001402      BEQ      5$      ;;BR IF NONE
020254 016716 160702 MOV      $ESCAPE, (SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
020260
020260 022737 012722 000042 5$: CMP      #ENDAD, @#42 ;;ACT-11 AUTO-ACCEPT?
020266 001001      BNE      6$      ;;BRANCH IF NO
020270 000000      HALT     ;;YES
020272
020272 000207      RTS     PC

```

3599

;;\*\*\*\*\*

.SBTTL ERROR MESSAGE TIMEOUT ROUTINE

; \*THIS ROUTINE USES THE "ITEM CONTROL BYTE" (\$ITEMB) TO DETERMINE WHICH  
; \*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" (\$ERRTB),  
; \*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

```

020274
020274 004567 001452 $ERRTYP: JSR      R5      $PRINT  ;;GO PRINT OUT THE FOLLOWING MESSAGE.
020300 001171      .WORD    $CRLF    ;;ADDRESS OF MESSAGE TO BE TYPED
020302 010046      MOV      R0, -(SP)  ;;SAVE R0
020304 005000      CLR      R0      ;;PICKUP THE ITEM INDEX
020306 156700 160572 BIS      $ITEMB, R0

```

```

020312 001010          BNE      1$          ;IF ITEM NUMBER IS ZERO, JUST
                                ;TYPE THE PC OF THE ERROR
020314 016746 160566   MOV      $ERRPC,-(SP)  ;;SAVE $ERRPC FOR TYPEOUT
                                ;;ERROR ADDRESS
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
020320 106746          MFPS      -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
020322 105066 000001   CLRFB   1(SP)      ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
020326 004767 002672   JSR      PC,      $TYPOC ;GO TO THE SUBROUTINE
020332 000516          BR       10$          ;GET OUT
020334 016767 160546 161142 1$:  MOV      $ERRPC, $VERPC ;SET UP VIRTUAL PC FOR TYPEOUT.
020342 166767 160164 161134   SUB      RELOCF, $VERPC ;MAKE VIRTUAL IF NOT ALREADY.
020350 005300          DEC      RO          ;ADJUST THE INDEX SO THAT IT WILL
020352 006300          ASL      RO          ;
020354 006300          ASL      RO          ;
020356 006300          ASL      RO          ;
020360 066700 161450   ADD      .ERRTB, RO      ;FORM TABLE POINTER
020364 012067 000006   MOV      (RO)+,2$      ;PICKUP "ERROR MESSAGE" POINTER
020370 001406          BEQ      3$          ;SKIP TYPEOUT IF NO POINTER
020372 004567 001354   JSR      R5,      $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020376 000000          .WORD   0          ;"ERROR MESSAGE" POINTER GOES HERE
020400 004567 001346   JSR      R5,      $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020404 001171          .WORD   $CRLF      ;ADDRESS OF MESSAGE TO BE TYPED
020406 012067 000006   MOV      (RO)+,4$      ;PICKUP "DATA HEADER" POINTER
020412 001406          BEQ      5$          ;SKIP TYPEOUT IF 0
020414 004567 001332   JSR      R5,      $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020420 000000          .WORD   0          ;"DATA HEADER" POINTER GOES HERE
020422 004567 001324   JSR      R5,      $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020426 001171          .WORD   $CRLF      ;ADDRESS OF MESSAGE TO BE TYPED
020430 010146          5$:  MOV      R1, -(SP)      ;SAVE R1
020432 012001          MOV      (R0)+,R1      ;PICKUP "DATA TABLE" POINTER
020434 001454          BEQ      9$          ;BR IF NO DATA TO BE TYPED
020436 066701 160070   ADD      RELOCF, R1      ;ADJUST POINTER
020442 012000          MOV      (R0)+,RO      ;PICKUP "DATA FORMAT" POINTER
020444 066700 160062   ADD      RELOCF, RO      ;ADJUST POINTER.
020450 105720          6$:  TSTB   (RO)+          ;CHECK THE FORMAT
020452 001007          BNE      7$          ;BR IF NOT 16-BIT OCTAL
020454 013146          MOV      @ (R1)+,-(SP)  ;;SAVE @ (R1)+ FOR TYPEOUT
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
020456 106746          MFPS      -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
020460 105066 000001   CLRFB   1(SP)      ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
020464 004767 002534   JSR      PC,      $TYPOC ;GO TO THE SUBROUTINE
020470 000430          BR       8$          ;
020472 100407          7$:  BMI     17$          ;BRANCH IF NOT DECIMAL
020474 013146          MOV      @ (R1)+,-(SP)  ;;SAVE @ (R1)+ FOR TYPEOUT
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPDS ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
020476 106746          MFPS      -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
020500 105066 000001   CLRFB   1(SP)      ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
020504 004767 002236   JSR      PC,      $TYPDS ;GO TO THE SUBROUTINE
020510 000420          BR       8$          ;SKIP
020512 122760 177777 177777 17$: CMPB   # 1, -1(RO) ;CHECK FOR 22-BIT ADDRESS FORMAT.
020520 001004          BNE     18$          ;BR IF NOT 22-BIT ADDRESS FORMAT.

```

ERROR MESSAGE TIMEOUT ROUTINE

```

020522 013146          MOV    @R1)+, (SP) ;PUT THE DATA ON THE STACK.
020524 004767 002736 JSR    PC,    $TYPAD ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
020530 000410          BR     8$      ;SKIP
020532 005046          CLR    -(SP)   ;CLEAR THE WORD ON THE STACK.
020534 113116          MOVB  @R1)+, (SP) ;PUT THE DATA ON THE STACK.
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
020536 106746          MFPS  -(SP)   ;PUT THE PROCESSOR STATUS ON THE STACK
020540 105066 000001  CLRB  1(SP)   ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
020544 004767 002430  JSR    PC,    $TYPOS ;GO TO THE SUBROUTINE
020550          .BYTE 3      ;TYPE 3 DIGITS.
020551          .BYTE 1      ;TYPE LEADING ZEROS.
020552 005711          TST   (R1)     ;IS THERE ANOTHER NUMBER?
020554 001404          BEQ   9$      ;BR IF NO
020556 004567 001170  JSR    R5,    $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020562 020602          .WORD 11$   ;ADDRESS OF MESSAGE TO BE TYPED
020564 000731          BR     6$      ;LOOP
020566 012601          9$: MOV    (SP)+,R1   ;RESTORE R1
020570 012600          10$: MOV   (SP)+,R0  ;RESTJRE R0
020572 004567 001154  JSR    R5,    $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020576 001171          .WORD $CRLF ;ADDRESS OF MESSAGE TO BE TYPED
020600 000207          RTS   PC     ;RETURN
020602          040      040      000 11$: .ASCIZ / / ;DOUBLE SPACE

```

3600

```

.SBTTL TTY INPUT ROUTINE
;*****
;ENABL LSB
;*****
;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
;*WHEN OPERATING IN TTY FLAG MODE.

```

```

020606 022767 000176 160314 $CKSWR: CMP    #SWREG,SWR ;:IS THE SOFT-SWR SELECTED?
020614 001105          BNE   15$      ;:BRANCH IF NO
020616 105777 160312  TSTB  @TKS     ;:CHAR THERE?
020622 100102          BPL   15$      ;:IF NO, DON'T WAIT AROUND
020624 117746 160306  MOVB  @TKB,-(SP) ;:SAVE THE CHAR
020630 042716 177600  BIC   #+C177,(SP) ;:STRIP-OFF THE ASCII
020634 022726 000007  CMP   #7,(SP)+ ;:IS IT A CONTROL G?
020640 001073          BNE   15$      ;:NO, RETURN TO USER
020642 126727 160256 000001  CMPB  $AUTOB,#1 ;:ARE WE RUNNING IN AUTO-MODE?
020650 001467          BEQ   15$      ;:BRANCH IF YES
020652 004567 001074  JSR    R5,    $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020656 021547          .WORD $CNTLG ;ADDRESS OF MESSAGE TO BE TYPED
020660          $GTSWR: JSR    R5,    $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020660 004567 001066  .WORD $MSWR   ;ADDRESS OF MESSAGE TO BE TYPED
020664 021554          MOV   SWREG,-(SP) ;:SAVE SWREG FOR TIMEOUT
020666 016746 157304  ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
020672 106746          MFPS  -(SP)   ;PUT THE PROCESSOR STATUS ON THE STACK
020674 105066 000001  CLRB  1(SP)   ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
020700 004767 002320  JSR    PC,    $TYPOC ;GO TO THE SUBROUTINE

```

TTY INPUT ROUTINE

```

020704 004567 001042 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020710 021565 .WORD $MNEW ;ADDRESS OF MESSAGE TO BE TYPED
020712 005046 19$: CLR (SP) ;:CLEAR COUNTER
020714 005046 CLR -(SP) ;:THE NEW SWR
020716 105777 160212 7$: TSTB @TKS ;:CHAR THERE?
020722 100375 BFL 7$ ;:IF NOT TRY AGAIN
020724 117746 160206 MOVB @TKB, (SP) ;:PICK UP CHAR
020730 042716 177600 BIC #C177, (SP) ;:MAKE IT 7-BIT ASCII
020734 021627 000025 9$: CMP (SP), #25 ;:IS IT A CONTROL-U?
020740 001006 BNE 10$ ;:BRANCH IF NOT
020742 004567 001004 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
020746 021542 .WORD $CNTLU ;ADDRESS OF MESSAGE TO BE TYPED
020750 062706 000006 20$: ADD #6, SP ;:IGNORE PREVIOUS INPUT
020754 000756 BR 19$ ;:LET'S TRY IT AGAIN
020756 021627 000015 10$: CMP (SP), #15 ;:IS IT A <CR>?
020762 001023 BNE 16$ ;:BRANCH IF NO
020764 005766 000004 TST 4(SP) ;:YES, IS IT THE FIRST CHAR?
020770 001403 BEQ 11$ ;:BRANCH IF YES
020772 016677 000002 160130 MOV 2(SP), @SWR ;:SAVE NEW SWR
021000 062706 000006 11$: ADD #6, SP ;:CLEAR UP STACK
021004 14$: JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
021004 004567 000742 .WORD $CRLF ;ADDRESS OF MESSAGE TO BE TYPED
021010 001171 CMPB $INTAG, #1 ;:RE-ENABLE TTY KBD INTERRUPTS?
021012 126727 160107 000001 BNE 15$ ;:BRANCH IF NOT
021020 001003 MOV #100, @TKS ;:RE-ENABLE TTY KBD INTERRUPTS
021022 012777 000100 160104 15$: RTI ;:RETURN
021030 000002 JSR PC, $TYPEC ;:ECHO CHAR
021032 004767 001160 16$: CMP (SP), #60 ;:CHAR < 0?
021036 021627 000060 BLT 18$ ;:BRANCH IF YES
021042 002420 CMP (SP), #67 ;:CHAR > 7?
021044 021627 000067 BGT 18$ ;:BRANCH IF YES
021050 003015 BIC #60, (SP)+ ;:STRIP-OFF ASCII
021052 042726 000060 TST 2(SP) ;:IS THIS THE FIRST CHAR
021056 005766 000002 BEQ 17$ ;:BRANCH IF YES
021062 001403 ASL (SP) ;:NO, SHIFT PRESENT
021064 006316 ASL (SP) ;: CHAR OVER TO MAKE
021066 006316 ASL (SP) ;: ROOM FOR NEW ONE.
021070 006316 INC 2(SP) ;:KEEP COUNT OF CHAR
021072 005266 000002 17$: BIS -2(SP), (SP) ;:SET IN NEW CHAR
021076 056616 177776 BR 7$ ;:GET THE NEXT ONE
021102 000705 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
021104 004567 000642 .WORD $QUES ;ADDRESS OF MESSAGE TO BE TYPED
021110 001170 BR 20$ ;:SIMULATE CONTROL-U
021112 000716 .DSABL LSB
;*****
;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
;CALL:
;* RDCHR ;:INPUT A SINGLE CHARACTER FROM THE TTY
;* RETURN HERE ;:CHARACTER IS ON THE STACK
;* ;:WITH PARITY BIT STRIPPED OFF
;RDCHR: MOV (SP), (SP) ;:PUSH DOWN THE PC
021114 011646 MOV 4(SP), 2(SP) ;:SAVE THE PS
021116 016666 000004 000002 1$: TSTB @TKS ;:WAIT FOR
021124 105777 160004 BPL 1$ ;:A CHARACTER
021130 100375

```



```

021132 117766 160000 000004      MOVB    @TKB,4(SP)      ;;READ THE TTY
021140 042766 177600 000004      BIC     #C<177>,4(SP) ;;GET RID OF JUNK IF ANY
021146 026627 000004 000023      CMP     4(SP),#23     ;;IS IT A CONTROL-5?
021154 001013                BNE     3$            ;;BRANCH IF NO
021156 105777 157752          2$:    TSTB    @TKS          ;;WAIT FOR A CHARACTER
021162 100375                BPL     2$            ;;LOOP UNTIL ITS THERE
021164 117746 157746      MOVB    @TKB,-(SP)     ;;GET CHARACTER
021170 042716 177600      BIC     #C177,(SP)   ;;MAKE IT 7-BIT ASCII
021174 022627 000021      CMP     (SP)+,#21    ;;IS IT A CONTROL-Q?
021200 001366                BNE     2$            ;;IF NOT DISCARD IT
021202 000750                BR      1$            ;;YES, RESUME
021204 026627 000004 000021  3$:    CMP     4(SP),#$XON  ;;IS IT A RANDOM XON?      ;RAN001
021212 001744                BEQ     1$            ;;BRANCH IF YES           ;RAN001
021214 026627 000004 000140      CMP     4(SP),#140   ;;IS IT UPPER CASE?
021222 002407                BLT     4$            ;;BRANCH IF YES
021224 026627 000004 000175      CMP     4(SP),#175   ;;IS IT A SPECIAL CHAR?
021232 003003                BGT     4$            ;;BRANCH IF YES
021234 042766 000040 000004      BIC     #40,4(SP)    ;;MAKE IT UPPER CASE
021242 000002          4$:    RTI      ;;GO BACK TO USER

;*****
;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
;CALL:
;*
;*      RDLIN          ;;INPUT A STRING FROM THE TTY
;*      RETURN HERE   ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
;*                  ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
021244 010346      $RDLIN. MOV    R3,-(SP)      ;;SAVE R3
021246 005046      CLR     -(SP)        ;;CLEAR THE RUBOUT KEY
021250 012703 021532  1$:    MOV     #$TTYIN,R3    ;;GET ADDRESS
021254 022703 021542  2$:    CMP     #$TTYIN+8.,R3 ;;BUFFER FULL?
021260 101470      BLOS   4$            ;;BR IF YES
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDCHR ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
021262 106746      MFPS   -(SP)        ;;PUT THE PROCESSOR STATUS ON THE STACK
021264 105066 000001      CLRB  1(SP)        ;;HIGH BYTE CLEARED TO INSURE KERNEL MODE
;ON PSW RETURN.
021270 004767 177620      JSR    PC,$RDCHR    ;;GO TO THE SUBROUTINE
021274 112613      MOVB   (SP)+,(R3)   ;;GET CHARACTER
021276 122713 000177  10$:   CMPB   #177,(R3)     ;;IS IT A RUBOUT
021302 001024      BNE    5$            ;;BR IF NO
021304 005716      TST   (SP)          ;;IS THIS THE FIRST RUBOUT?
021306 001010      BNE    6$            ;;BR IF NO
021310 112767 000134 000212  MOVB   #' \,9$      ;;TYPE A BACK SLASH
021316 004567 000430      JSR    R5,$PRINT    ;;GO PRINT OUT THE FOLLOWING MESSAGE.
021322 021530      .WORD 9$          ;;ADDRESS OF MESSAGE TO BE TYPED
021324 012716 177777      MOV   #-1,(SP)     ;;SET THE RUBOUT KEY
021330 005303          6$:    DEC    R3           ;;BACKUP BY ONE
021332 020327 021532      CMP   R3,$TTYIN    ;;STACK EMPTY?
021336 103441          BLO   4$            ;;BR IF YES
021340 111367 000164      MOVB  (R3),9$      ;;SETUP TO TYPEOUT THE DELETED CHAR.
021344 004567 000402      JSR   R5,$PRINT    ;;GO PRINT OUT THE FOLLOWING MESSAGE.
021350 021530      .WORD 9$          ;;ADDRESS OF MESSAGE TO BE TYPED
021352 000740          BR    2$            ;;GO READ ANOTHER CHAR.
021354 005716          5$:    TST   (SP)          ;;RUBOUT KEY SET?
021356 001407          BEQ   7$            ;;BR IF NO
021360 112767 000134 000142  MOVB   #' \,9$      ;;TYPE A BACK SLASH
021366 004567 000360      JSR   R5,$PRINT    ;;GO PRINT OUT THE FOLLOWING MESSAGE.
021372 021530      .WORD 9$          ;;ADDRESS OF MESSAGE TO BE TYPED

```



```

021576 011646          $RDOCT: MOV      (SP), -(SP)      ;; PROVIDE SPACE FOR THE
021600 016666 000004 000002  MOV      4(SP), 2(SP)      ;; INPUT NUMBER
021606 010046          MOV      R0, (SP)          ;; PUSH R0 ON STACK
021610 010146          MOV      R1, (SP)          ;; PUSH R1 ON STACK
021612 010246          MOV      R2, -(SP)         ;; PUSH R2 ON STACK
021614

1$:
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDLIN ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
021614 106746          MFPS      -(SP)          ;PUT THE PROCESSOR STATUS ON THE STACK
021616 105066 000001  CLR      1(SP)          ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
021622 004767 177416  JSR      PC, $RDLIN      ;GO TO THE SUBROUTINE
021626 012600          MOV      (SP)+, R0      ;; GET ADDRESS OF 1ST CHARACTER
021630 010067 000102  MOV      R0, 5$        ;; AND SAVE IT
021634 005001          CLR      R1          ;; CLEAR DATA WORD
021636 005002          CLR      R2
021640 112046          MOV      (R0)+, (SP)    ;; PICKUP THIS CHARACTER
021642 001420          BEQ      3$          ;; IF ZERO GET OUT
021644 122716 000060  CMP      #'0, (SP)     ;; MAKE SURE THIS CHARACTER
021650 003026          BGT      4$          ;; IS AN OCTAL DIGIT
021652 122716 000067  CMP      #'7, (SP)
021656 002423          BLT      4$
021660 006301          ASL      R1          ;; *2
021662 006102          ROL      R2
021664 006301          ASL      R1          ;; *4
021666 006102          ROL      R2
021670 006301          ASL      R1          ;; *8
021672 006102          ROL      R2
021674 042716 177770  BIC      #'C7, (SP)    ;; STRIP THE ASCII JUNK
021700 062601          ADD      (SP)+, R1    ;; ADD IN THIS DIGIT
021702 000756          BR       2$          ;; LOOP
021704 005726          TST      (SP)+      ;; CLEAN TERMINATOR FROM STACK
021706 010166 000012  MOV      R1, 12(SP)   ;; SAVE THE RESULT
021712 010267 000032  MOV      R2, $HIOCT
021716 012602          MOV      (SP)+, R2    ;; POP STACK INTO R2
021720 012601          MOV      (SP)+, R1    ;; POP STACK INTO R1
021722 012600          MOV      (SP)+, R0    ;; POP STACK INTO R0
021724 000002          RTI
021726 005726          TST      (SP)+      ;; CLEAN PARTIAL FROM STACK
021730 105010          CLR      (R0)        ;; SET A TERMINATOR
021732 004567 000014  JSR      R5, $PRINT   ;GO PRINT OUT THE FOLLOWING MESSAGE.
021736 000000          .WORD  0
021740 004567 000006  JSR      R5, $PRINT   ;GO PRINT OUT THE FOLLOWING MESSAGE.
021744 001170          .WORD  $QUES      ;ADDRESS OF MESSAGE TO BE TYPED
021746 000722          BR       1$          ;; TRY AGAIN
021750 000000          $HIOCT: .WORD  0   ;; HIGH ORDER BITS GO HERE

3602
3603
3604
3605
3606
3607
3608 021752 012567 000020 *****
3609 021756 066767 156550 000012 ;* SUBROUTINE TO PASS RELOCATED MESSAGE ADDRESSES TO THE $TYPE ROUTINE.
3610
;* CALL: JSR      R5, $PRINT
;* <MESSAGE VIRTUAL ADDRESS>
*****
$PRINT: MOV      (R5)+, 1$    ;GET THE MESSAGE VIRTUAL ADDRESS.
        ADD      RELOC, 1$    ;MAKE IT PHYSICAL.
;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPE ROUTINE
;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
021764 106746          MFPS      -(SP)          ;PUT THE PROCESSOR STATUS ON THE STAC<
    
```

```

021766 105066 000001          CLRB    1(SP)          ;HIGH BYTE CLEARED TO INSURE KERNEL MODE
                                ;ON PSW RETURN.
021772 004767 0C0004          JSR     PC,    $TYPE    ;GO TO THE SUBROUTINE
3611 021776 000000          1$:    .WORD   0        ;CONTAINS THE PHYSICAL MESSAGE ADDRESS.
3612 022000 000205          RTS     R5          ;RETURN.
3613
3614

.SBTTL  TYPE ROUTINE
;*****
;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;*NOTE1:      $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;*NOTE2:      $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;*NOTE3:      $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;*
;*CALL:
;*1) USING A TRAP INSTRUCTION
;*      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;*OR
;*      TYPE
;*      MESADR
;*
022002 105767 157141          $TYPE:  TSTB    $TPFLG      ;;IS THERE A TERMINAL?
022006 100002          BPL     1$              ;;BR IF YES
022010 000000          HALT                    ;;HALT HERE IF NO TERMINAL
022012 000430          BR     3$              ;;LEAVE
022014 010046          1$:    MOV     RO,-(SP)      ;;SAVE RO
022016 017600 000002          MOV     @2(SP),RO      ;;GET ADDRESS OF ASCIZ STRING
022022 122767 000001 157164          CMPB   #APTENV,$ENV    ;;RUNNING IN APT MODE
022030 001011          BNE    62$            ;;NO,GO CHECK FOR APT CONSOLE
022032 132767 000100 157155          BITB   #APTSPOOL,$ENVM ;;SPOOL MESSAGE TO APT
022040 001405          BEQ   62$            ;;NO,GO CHECK FOR CONSOLE
022042 010067 000004          MOV     RO,61$        ;;SETUP MESSAGE ADDRESS FOR APT
022046 004767 000274          JSR    PC,$ATY3       ;;SPOOL MESSAGE TO APT
022052 000000          61$:    .WORD   0        ;;MESSAGE ADDRESS
022054 132767 000040 157133          62$:    BITB   #APTCSUP,$ENVM ;;APT CONSOLE SUPPRESSED
022062 001003          BNE    60$            ;;YES,SKIP TYPE OUT
022064 112046          2$:    MOVB   (RO)+,-(SP)  ;;PUSH CHARACTER TO BE TYPED ONTO STACK
022066 001005          BNE    4$              ;;BR IF IT ISN'T THE TERMINATOR
022070 005726          TST   (SP)+           ;;IF TERMINATOR POP IT OFF THE STACK
022072 012600          60$:    MOV     (SP)+,RO    ;;RESTORE RO
022074 062716 000002          3$:    ADD     #2,(SP)     ;;ADJUST RETURN PC
022100 000002          RTI                    ;;RETURN
022102 122716 000011          4$:    CMPB   #HT,(SP)    ;;BRANCH IF <HT>
022106 001431          BEQ   8$              ;;BRANCH IF NOT <CRLF>
022110 122716 000200          CMPB   #CRLF,(SP)
022114 001007          BNE    5$              ;;BRANCH IF NOT <CRLF>
022116 005726          TST   (SP)+           ;;POP <CR><LF> EQUIV
022120 004567 177626          JSR    R5,    $PRINT   ;GO PRINT OUT THE FOLLOWING MESSAGE.
022124 001171          $CRLF
022126 105067 000202          CLRB   $CHARCNT      ;;CLEAR CHARACTER COUNT
022132 000754          BR     2$              ;;GET NEXT CHARACTER
022134 004767 000056          5$:    JSR    PC,$TYPEC    ;;GO TYPE THIS CHARACTER
022140 126726 157002          6$:    CMPB   $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
022144 001347          BNE    2$              ;;IF NO GO GET NEXT CHAR.
022146 016746 156772          MOV     $NULL,(SP)   ;;GET # OF FILLER CHARS. NEEDED
                                ;;AND THE NULL CHAR.
022152 105366 000001          7$:    DECB   1(SP)      ;;DOES A NULL NEED TO BE TYPED?

```

TYPE ROUTINE

```

022156 002770          BLT      6$          ;;BR IF NO -GO POP THE NULL OFF OF STACK
022160 004767 000032  JSR      PC,$TYPEC  ;;GO TYPE A NULL
022164 105367 000144  DECB    $CHARCNT    ;;DO NOT COUNT AS A COUNT
022170 000770          BR       7$          ;;LOOP

:HORIZONTAL TAB PROCESSOR
022172 112716 000040  8$:    MOVB    #'(SP)  ;;REPLACE TAB WITH SPACE
022176 004767 000014  9$:    JSR      PC,$TYPEC  ;;TYPE A SPACE
022202 132767 000007 000124 BITB    #7,$CHARCNT  ;;BRANCH IF NOT AT
022210 001372          BNE     9$          ;;TAB STOP
022212 005726          TST     (SP)+       ;;POP SPACE OFF STACK
022214 000723          BR       2$          ;;GET NEXT CHARACTER
022216          $TYPEC:
022216 105777 156712  TSTB   @TKS         ;;CHAR IN KYBD BUFFER?
022222 100022          BPL     10$         ;;BR IF NOT
022224 017746 156706  MOV     @TKB,-(SP)  ;;GET CHAR
022230 042716 177600  BIC    #177600,(SP) ;;STRIP EXTRANEIOUS BITS
022234 122716 000023  CMPB   #XOFF,(SP)  ;;WAS CHAR XOFF
022240 001012          BNE     102$        ;;BR IF NOT
022242          101$:
022242 105777 156666  TSTB   @TKS         ;;WAIT FOR CHAR
022246 100375          BPL     101$        ;;
022250 117716 156662  MOVB   @TKB,(SP)   ;;GET CHAR
022254 042716 177600  BIC    #177600,(SP) ;;STRIP IT
022260 122716 000021  CMPB   #XON,(SP)   ;;WAS IT XON?
022264 001366          BNE     101$        ;;BR IF NOT
022266          102$:
022266 005726          TST     (SP)+       ;;FIX STACK
022270          10$:
022270 105777 156644  TSTB   @TPS         ;;WAIT UNTIL PRINTER IS READY
022274 100375          BPL     10$         ;;
022276 116677 000002 156636 MOVB   2(SP),@TPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
022304 122766 000015 000002 CMPB   #CR,2(SP)   ;;IS CHARACTER A CARRIAGE RETURN?
022312 001003          BNE     1$          ;;BRANCH IF NO
022314 105067 000014  CLRB   $CHARCNT    ;;YES--CLEAR CHARACTER COUNT
022320 000406          BR       $TYPEX    ;;EXIT
022322 122766 000012 000002 1$:    CMPB   #LF,2(SP)   ;;IS CHARACTER A LINE FEED?
022330 001402          BEQ     $TYPEX    ;;BRANCH IF YES
022332 105227          INCB   (PC)+     ;;COUNT THE CHARACTER
022334 000000          $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
022336 000207          $TYPEX: RTS      PC

3615 .SBTTL APT COMMUNICATIONS ROUTINE
*****
022340 112767 000001 000376 $ATY1: MOVB   #1,$FFLG  ;;TO REPORT FATAL ERROR
022346 112767 000001 000366 $ATY3: MOVB   #1,$MFLG  ;;TO TYPE A MESSAGE
022354 000403          BR       $ATYC
022356 112767 000001 000360 $ATY4: MOVB   #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
022364          $ATYC:
022364 010046          MOV     R0,-(SP)   ;;PUSH R0 ON STACK
022366 010146          MOV     R1,-(SP)   ;;PUSH R1 ON STACK
022370 105767 000346  TSTB   $MFLG       ;;SHOULD TYPE A MESSAGE?
022374 001450          BEQ     5$          ;;IF NOT: BR
022376 122767 000001 156610  CMPB   #APTENV,$ENV ;;OPERATING UNDER APT?
022404 001031          BNE     3$          ;;IF NOT: BR
022406 132767 000100 156601  BITB   #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
022414 001425          BEQ     3$          ;;IF NOT: BR
022416 017600 000004          MOV     @4(SP),R0  ;;GET MESSAGE ADDR.
022422 062766 000002 000004  ADD     #2,4(SP)    ;;BUMP RETURN ADDR.

```

```

022430 005767 156540 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
022434 001375 BNE 1$ ;;IF NOT: WAIT
022436 010067 156546 MOV RO,$MSGAD ;;PUT ADDR IN MAILBOX
022442 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
022444 001376 BNE 2$
022446 166700 156536 SUB $MSGAD,RO ;;SUB START OF MESSAGE
022452 006200 ASR RO ;;GET MESSAGE LNGTH IN WORDS
022454 010067 156532 MOV RO,$MSGGLT ;;PUT LENGTH IN MAILBOX
022460 012767 000004 156506 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
022466 000413 BR 5$
022470 017667 000004 000016 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
022476 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
022504 016746 155266 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
022510 004767 177266 JSR PC,$TYPE ;;CALL TYPE MACRO
022514 000000 4$: .WORD 0
022516 5$:
022516 105767 000221 TSTB $LFLG ;;SHOULD LOG AN ERROR?
022522 001422 BEQ 10$ ;;IF NOT: BR
022524 017600 000004 MOV @4(SP),RO ;;GET ERROR #
022530 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
022536 012701 001334 MOV #,$ASTAT,R1 ;;POINT TO TABLE START
022542 005711 6$: TST (R1) ;;END OF TABLE?
022544 100404 BMI 8$ ;;IF SO: BR
022546 020021 CMP RO,(R1)+ ;;PROPER ENTRY?
022550 001406 BEQ 9$ ;;IF SO: BR
022552 005721 TST (R1)+ ;;MOVE PAST COUNTER WORD
022554 000772 BR 6$ ;;KEEP LOOKING
022556 026701 156720 8$: CMP $APTR,R1 ;;TABLE FULL?
022562 001402 BEQ 10$ ;;IF SO: BR -- NO MORE ROOM
022564 013021 MOV RO,(R1)+ ;;SET UP NEW ENTRY
022566 005211 9$: INC (R1) ;;BUMP ERROR COUNT
022570 105767 000150 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
022574 001416 BEQ 12$ ;;IF NOT: BR
022576 005767 156412 TST $ENV ;;RUNNING UNDER APT?
022602 001413 BEQ 12$ ;;IF NOT: BR
022604 005767 156364 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
022610 001375 BNE 11$ ;;IF NOT: WAIT
022612 017667 000004 156356 MOV @4(SP),$FATAL ;;GET ERROR #
022620 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
022626 005267 156342 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
022632 105067 000106 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
022636 105067 000101 CLRB $LFLG ;;CLEAR LOG FLAG
022642 105067 000074 CLRB $MFLG ;;CLEAR MESSAGE FLAG
022646 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
022650 012600 MOV (SP)+,RO ;;POP STACK INTO RO
022652 000207 RTS PC ;;RETURN
022654 $ATY6:
022654 010046 MOV RO,-(SP) ;;PUSH RO ON STACK
022656 016700 156620 MOV $APTR,RO
022662 162700 001334 SUB #,$ASTAT,RO ;;GET SIZE OF STAT TABLE
022666 005767 156302 1$: TST $MSGTY ;;SEE IF DONE LAST COMMUNICATION
022672 001375 BNE 1$ ;;IF NOT: WAIT
022674 010067 156312 MOV RO,$MSGGLG ;;SET MESSAGE LENGTH
022700 012767 001334 156302 MOV #,$ASTAT,$MSGAD ;;SET MESSAGE ADDR.
022706 012767 000002 156260 MOV #2,$MSGTY ;;TELL APT TO TAKE STATS.
022714 012600 MOV (SP)+,RO ;;POP STACK INTO RO
022716 000207 RTS PC ;;RETURN
  
```

```

022720          $ATY7:
022720 010046          MOV     R0, -(SP)          ;; PUSH R0 ON STACK
022722 012701 001334  MOV     # $STAT, R1        ;; GET START OF TABLE
022726 005721          1$:  TST     (R1)+          ;; END OF TABLE?
022730 100402          BMI     2$          ;; IF SO: BR
022732 005021          CLR     (R1)+          ;; CLEAR ERROR COUNT
022734 000774          BR      1$          ;; KEEP CLEARING
022736          2$:
022736 012600          MOV     (SP)+, R0        ;; POP STACK INTO R0
022740 000207          RTS     PC          ;; RETURN
022742          000          $MFLG: .BYTE 0          ;; MESSG. FLAG
022743          000          $LFLG: .BYTE 0          ;; LOG FLAG
022744          000          $FFLG: .BYTE 0          ;; FATAL FLAG

```

```

00020^
000001
000100
000040

```

3616

```

APTSIZE=200
APTENV=001
APTSPOOL=100
APTCSUP=040
;*****

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
; *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
; *REPLACED WITH SPACES.
; *CALL:
; *

```

```

; * MOV     NUM, -(SP)          ;; PUT THE BINARY NUMBER ON THE STACK
; * TYPDS          ;; GO TO THE ROUTINE

```

```

022746          $TYPDS:
022746 010046          MOV     R0, -(SP)          ;; PUSH R0 ON STACK
022750 010146          MOV     R1, -(SP)          ;; PUSH R1 ON STACK
022752 010246          MOV     R2, -(SP)          ;; PUSH R2 ON STACK
022754 010346          MOV     R3, -(SP)          ;; PUSH R3 ON STACK
022756 010546          MOV     R5, -(SP)          ;; PUSH R5 ON STACK
022760 012746 020200  MOV     #20200, -(SP)        ;; SET BLANK SWITCH AND SIGN
022764 016605 000020  MOV     20(SP), R5          ;; GET THE INPUT NUMBER
022770 100004          BPL     1$          ;; BR IF INPUT IS POS.
022772 005405          NEG     R5          ;; MAKE THE BINARY NUMBER POS.
022774 112766 000055 000001  MOVB   #' - 1(SP)          ;; MAKE THE ASCII NUMBER NEG.
023002 016700 155524  1$:  MOV     RELOC, R0          ;; GET RELOCATION FACTOR.
023006 012703 023170  MOV     # $DBLK, R3        ;; SETUP THE OUTPUT POINTER
023012 060003          ADD     R0, R3          ;; ADD IN RELOCATION FACTOR.
023014 112723 000040  MOVB   #' , (R3)+          ;; SET THE FIRST CHARACTER TO A BLANK
023020 005002          2$:  CLR     R2          ;; CLEAR THE BCD NUMBER
023022 016001 023160  MOV     $DTBL(R0), R1      ;; GET THE CONSTANT
023026 160105          3$:  SUB     R1, R5          ;; FORM THIS BCD DIGIT
023030 002402          BLT     4$          ;; BR IF DONE
023032 005202          INC     R2          ;; INCREASE THE BCD DIGIT BY 1
023034 000774          BR      3$
023036 060105          4$:  ADD     R1, R5          ;; ADD BACK THE CONSTANT
023040 005702          TST     R2          ;; CHECK IF BCD DIGIT=0
023042 001002          BNE     5$          ;; FALL THROUGH IF 0
023044 105716          TSTB   (SP)          ;; STILL DOING LEADING 0'S?
023046 100407          BMI     7$          ;; BR IF YES

```

```

023050 106316      5$: ASLB (SP)      ;;MSD?
023052 103003      BCC 6$      ;;BR IF NO
023054 116663 000001 177777  MOVB 1(SP), 1(R3) ;;YES--SET THE SIGN
023062 052702 000060      6$: BIS #'0,R2    ;;MAKE THE BCD DIGIT ASCII
023066 052702 000040      7$: BIS #' R2     ;;MAKE IT A SPACE IF NOT ALREADY A 'GIT
023072 110223      MOVB R2,(R3)+  ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
023074 005720      TST (R0)+    ;;JUST INCREMENTING
023076 020067 156734      CMP R0, .EIGHT ;;CHECK THE TABLE INDEX
023102 103746      BLO 2$      ;;GO DO THE NEXT DIGIT
023104 101002      BHI 8$      ;;GO TO EXIT
023106 010502      MOV R5,R2    ;;GET THE LSD
023110 000764      BR 6$      ;;GO CHANGE TO ASCII
023112 105726      8$: TSTB (SP)+  ;;WAS THE LSD THE FIRST NON-ZERO?
023114 100003      BPL 9$      ;;BR IF NO
023116 116063 177777 177776  MOVB -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
023124 105013      9$: CLRB (R3)  ;;SET THE TERMINATOR
023126 012605      MOV (SP)+,R5  ;;POP STACK INTO R5
023130 012603      MOV (SP)+,R3  ;;POP STACK INTO R3
023132 012602      MOV (SP)+,R2  ;;POP STACK INTO R2
023134 012601      MOV (SP)+,R1  ;;POP STACK INTO R1
023136 012600      MOV (SP)+,R0  ;;POP STACK INTO R0
023140 004567 176606      JSR R5, $PRINT ;;GO PRINT OUT THE FOLLOWING MESSAGE.
023144 023170      .WORD $DBLK  ;;ADDRESS OF MESSAGE TO BE TYPED
023146 016666 000002 000004  MOV 2(SP),4(SP) ;;ADJUST THE STACK
023154 012616      MOV (SP)+,(SP)
023156 000002      RTI      ;;RETURN TO USER
023160 023420      $DTBL: 10000.
023162 001750      1000.
023164 000144      100.
023166 000012      10.
023170      $DBLK: .BLKW 4

```

3617

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
;OCTAL (ASCII) NUMBER AND TYPE IT.
;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
;CALL:
;*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
;*   TYPOS      ;;CALL FOR TYPEOUT
;*   .BYTE  N           ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
;*   .BYTE  M           ;;M=1 OR 0
;*                               ;;1=TYPE LEADING ZEROS
;*                               ;;0=SUPPRESS LEADING ZEROS
;*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
;*$TYPOS OR $TYPOC
;CALL:
;*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
;*   TYPON      ;;CALL FOR TYPEOUT
;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
;CALL:
;*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
;*   TYPOC      ;;CALL FOR TYPEOUT
;$TYPOS: MOV 2(SP),-(SP)  ;;PICKUP THE MODE
MOV 1(SP), $OFILL  ;;LOAD ZERO FILL SWITCH
MOV (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE

```

```

023200 017646 000000
023204 116667 000001 000213
023212 112667 000211

```



```

023216 062716 000002      ADD      #2,(SP)      ;;ADJUST RETURN ADDRESS
023222 000406      BR      $TYPON
023224 112767 000001 000173 $TYPON: MOV      #1,$OFILL      ;;SET THE ZERO FILL SWITCH
023232 112767 000006 000167 $TYPON: MOV      #6,$OMODE+1      ;;SET FOR SIX(6) DIGITS
023240 112767 000005 000156 $TYPON: MOV      #5,$OCNT      ;;SET THE ITERATION COUNT
023246 010346      MOV      R3,-(SP)      ;;SAVE R3
023250 010446      MOV      R4,-(SP)      ;;SAVE R4
023252 010546      MOV      R5,-(SP)      ;;SAVE R5
023254 116704 000147      MOV      $OMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
023260 005404      NEG      R4
023262 062704 000006      ADD      #6,R4      ;;SUBTRACT IT FOR MAX. ALLOWED
023266 110467 000134      MOV      R4,$OMODE      ;;SAVE IT FOR USE
023272 116704 000127      MOV      $OFILL,R4      ;;GET THE ZERO FILL SWITCH
023276 016605 000012      MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
023302 005003      CLR      R3      ;;CLEAR THE OUTPUT WORD
023304 006105      1$:    ROL      R5      ;;ROTATE MSB INTO "C"
023306 000404      BR      3$      ;;GO DO MSB
023310 006105      2$:    ROL      R5      ;;FORM THIS DIGIT
023312 006105      ROL      R5
023314 006105      ROL      R5
023316 010503      MOV      R5,R3
023320 006103      3$:    ROL      R3      ;;GET LSB OF THIS DIGIT
023322 105367 000100      DEC      $OMODE      ;;TYPE THIS DIGIT?
023326 100017      BPL      7$      ;;BR IF NO
023330 042703 177770      BIC      #177770,R3      ;;GET RID OF JUNK
023334 001002      BNE      4$      ;;TEST FOR 0
023336 005704      TST      R4      ;;SUPPRESS THIS 0?
023340 001403      BEQ      5$      ;;BR IF YES
023342 005204      4$:    INC      R4      ;;DON'T SUPPRESS ANYMORE 0'S
023344 052703 000060      BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
023350 052703 000040      5$:    BIS      #' ,R3      ;;MAKE ASCII IF NOT ALREADY
023354 110367 000042      MOV      R3,8$      ;;SAVE FOR TYPING
023360 004567 176366      JSR      R5, $PRINT      ;;GO PRINT OUT THE FOLLOWING MESSAGE.
023364 023422      .WORD      8$      ;;ADDRESS OF MESSAGE TO BE TYPED
023366 105367 000032      7$:    DEC      $OCNT      ;;COUNT BY 1
023372 003346      BGT      2$      ;;BR IF MORE TO DO
023374 002402      BLT      6$      ;;BR IF DONE
023376 005204      INC      R4      ;;INSURE LAST DIGIT ISN'T A BLANK
023400 000743      BR      2$      ;;GO DO THE LAST DIGIT
023402 012605      6$:    MOV      (SP)+,R5      ;;RESTORE R5
023404 012604      MOV      (SP)+,R4      ;;RESTORE R4
023406 012603      MOV      (SP)+,R3      ;;RESTORE R3
023410 016666 000002 000004      MOV      2(SP),4(SP)      ;;SET THE STACK FOR RETURNING
023416 012616      MOV      (SP)+,(SP)
023420 000002      RTI
023422 000      8$:    .BYTE      0      ;;RETURN
023423 000      .BYTE      0      ;;STORAGE FOR ASCII DIGIT
023424 000      .BYTE      0      ;;TERMINATOR FOR TYPE ROUTINE
023425 000      $OCNT: .BYTE      0      ;;OCTAL DIGIT COUNTER
023426 000000      $OFILL: .BYTE      0      ;;ZERO FILL SWITCH
023426 000000      $OMODE: .WORD      0      ;;NUMBER OF DIGITS TO TYPE
3618      .ERROR TRAP SERVICE ROUTINE
3619 023430 005727      ERRTRP: TST      (PC)      ;;CHECK IF PREV TRAP TO 4 REPORTED
3620 023432 000000      1$:    .WORD      0      ;;CONTAINS ERROR REPORTED FLAG
3621 023434 001010      BNE      2$      ;;BRANCH IF NOT REPORTED
3622 023436 005267 177770      INC      1$      ;;SET DOUBLE TRAP FLAG.
3623 023442 011667 155510      MOV      (SP), $TMP3      ;;SAVE THE BAD PC FOR TYPING.
3624 023446 004767 174372      JSR      PC, $ERROR      ;;- * ERROR * (GO TYPE A MESSAGE)

```

```

3625 023452 000031          .WORD 31          ;ERROR TYPE CODE.
3626 023454 000401          BR 3$          ;SKIP HALT
3627 023456 000000          2$: HALT      ;ERROR! SECOND TRAP TO 4 OCCURRED
3628 023460 005067 177746  3$: CLR 1$     ;BEFORE FIRST WAS PRINTED
3629 023464 000002          RTI          ;RETURN TO PROGRAM AND TRY TO RECOVER
3630
3631          .SBTTL PHYSICAL ADDRESS TYPE ROUTINE
3632          ;* ROUTINE TO TYPE A PHYSICAL ADDRESS (22 BITS).
3633          $TYPAD:
3634 023466 010046          MOV R0,-(SP)   ;;PUSH R0 ON STACK
3635 023470 010146          MOV R1,-(SP)   ;;PUSH R1 ON STACK
3636 023472 010246          MOV R2,-(SP)   ;;PUSH R2 ON STACK
3637 023474 010346          MOV R3,-(SP)   ;;PUSH R3 ON STACK
3638 023476 016602 000012  MOV 12(SP),R2  ;;GET BASE ADDRESS
3639 023502 005003          CLR R3        ;;WORKING & INDEX REGISTER
3640 023504 005767 155026  TST MMAVA     ;;CHECK FOR MEM MGMT AVAILABLE
3641 023510 001430          BEQ 1$       ;;BRANCH IF NO MEM MGMT
3642 023512 032737 000001 177572 BIT #1, @#SRO ;;CHECK IF MEM MGMT ENABLED
3643 023520 001424          BEQ 1$       ;;BRANCH IF MEM MGMT NOT ENABLED
3644 023522 010201          MOV R2, R1    ;;COPY VIRTUAL ADR
3645 023524 006101          ROL R1        ;;SHUFFLE BITS 13,14,15 INTO 1,2,3
3646 023526 006101          ROL R1
3647 023530 006101          ROL R1
3648 023532 006101          ROL R1
3649 023534 006101          ROL R1
3650 023536 042701 177761  BIC #177761, R1 ;CLR ALL EXCEPT BITS 1,2,3
3651 023542 062701 172340  ADD #KIPARO, R1 ;SET TO APPROPRIATE PAR
3652 023546 011101          MOV (R1), R1  ;;GET CONTENTS OF PAR
3653 023550 012700 000006  MOV #6, R0    ;;SET UP COUNTER
3654 023554 006301          4$: ASL R1    ;;SHIFT PAR
3655 023556 006103          ROL R3        ;;SAVE OVERFLOW BITS
3656 023560 077003          SOB R0, 4$   ;;COUNT SIX SHIFTS
3657 023562 042702 160000  BIC #160000, R2 ;SAVE BANK BITS
3658 023566 0f.0102          ADD R1, R2   ;;COMPUTE PHYSICAL ADDRESS
3659 023570 005503          ADC R3      ;;MAKE SURE CARRY ISN'T LOST!
3660 023572 006302          1$: ASL R2   ;;FIRST DIGIT TO R3
3661 023574 006103          ROL R3
3662 023576 006002          ROR R2      ;;RESTORE R2 FOR BITS 14-0
3663 023600 010346          MOV R3,-(SP) ;;SAVE R3 FOR TYPEOUT
3664          ;;TYPE ADDRESS BITS 21-15
3665          ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
3666          ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
3667 023602 106746          MFPS -(SP)   ;;PUT THE PROCESSOR STATUS ON THE STACK
3668 023604 105066 000001  CLR B1(SP)   ;;HIGH BYTE CLEARED TO INSURE KERNEL MODE
3669          ;;ON PSW RETURN.
3670 023610 004767 177364  JSR PC, $TYPOS ;GO TO THE SUBROUTINE
3671 023614 003          .BYTE 3    ;;TYPE 3 DIGIT(S)
3672 023615 001          .BYTE 1    ;;TYPE LEADING ZEROS
3673 3660 023616 010246          MOV R2,-(SP) ;;SAVE R2 FOR TYPEOUT
3674          ;;TYPE ADDRESS BITS 14-0
3675          ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
3676          ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
3677 023620 106746          MFPS -(SP)   ;;PUT THE PROCESSOR STATUS ON THE STACK
3678 023622 105066 000001  CLR B1(SP)   ;;HIGH BYTE CLEARED TO INSURE KERNEL MODE
3679          ;;ON PSW RETURN.
3680 023626 004767 177346  JSR PC, $TYPOS ;GO TO THE SUBROUTINE
    
```

```

023632      005      .BYTE      5      ;;TYPE 5 DIGIT(S)
023633      001      .BYTE      1      ;;TYPE LEADING ZEROS
3661 023634 012603  MOV      (SP)+,R3  ;;POP STACK INTO R3
023636 012602  MOV      (SP)+,R2  ;;POP STACK INTO R2
023640 012601  MOV      (SP)+,R1  ;;POP STACK INTO R1
023642 012600  MOV      (SP)+,R0  ;;POP STACK INTO R0
3662 023644 012616  MOV      (SP)+, (SP) ;;ADJUST THE STACK TO CLEAR DATA
3663 023646 000207  RTS      PC      ;;RETURN
3664
3665      .SBTTL  STANDARD PROGRAM MESSAGES
3666      ;;*****
3667      ;;VARIOUS MESSAGE PRINTOUTS USED THRUOUT
3668      ;;THE PROGRAM
3669      ;;*****
3670 023650      015      012      113      MMAMES: .ASCIZ  <15><12>'KT11 (MEMORY MANAGEMENT) AVAILABLE'
023653      124      061      061
023656      040      050      115
023661      105      115      117
023664      122      131      040
023667      115      101      116
023672      101      107      105
023675      115      105      116
023700      124      051      040
023703      101      126      101
023706      111      114      101
023711      102      114      105
023714      000
3671 023715      015      012      062      AVAL22: .ASCIZ  <15><12>'22 BIT ADR AVAIL' <15><12>
023720      062      040      102
023723      111      124      040
023726      101      104      122
023731      040      101      126
023734      101      111      111
023737      015      012      000
3672 023742      015      012      115      MEMMES: .ASCIZ  <15><12>'MEMORY MAP:'
023745      105      115      117
023750      122      131      040
023753      115      101      120
023756      072      000
3673 023760      015      012      120      MTMAP: .ASCIZ  <15><12>'PARITY MEMORY MAP:'
023763      101      122      111
023766      124      131      040
023771      115      105      115
023774      117      122      131
023777      040      115      101
024002      120      072      000
3674 024005      015      012      106      FROM: .ASCIZ  <15><12>'FROM '
024010      122      117      115
024013      040      000
3675 024015      040      124      117      TO: .ASCIZ  ' TO '
024020      040      000
3676 024022      015      012      111      INSUFF: .ASCIZ  <15><12>'INSUFFICIENT MEMORY...FIRST 16K NOT ALL THERE!'
024025      116      123      125
024030      106      106      111
024033      103      111      105
024036      116      124      040
024041      115      105      115
    
```

	024044	117	122	131	
	024047	056	056	056	
	024052	106	111	122	
	024055	123	124	040	
	024060	061	066	113	
	024063	040	116	117	
	024066	124	040	101	
	024071	114	114	040	
	024074	124	110	105	
	024077	122	105	041	
3677	024102	000			
	024103	015	012	116	MTR: .ASCIZ <15><12>'NO PARITY REGISTERS FOUND'
	024106	117	040	120	
	024111	101	122	111	
	024114	124	131	040	
	024117	122	105	107	
	024122	111	123	124	
	024125	105	122	123	
	024130	040	106	117	
	024133	125	116	104	
3678	024136	000			
	024137	015	012	122	PWRMSG: .ASCIZ <15><12>'RESTARTING AFTER A POWER FAILURE'<15><12>
	024142	105	123	124	
	024145	101	122	124	
	024150	111	116	107	
	024153	040	101	106	
	024156	124	105	122	
	024161	040	101	040	
	024164	120	117	127	
	024167	105	122	040	
	024172	106	101	111	
	024175	114	125	122	
	024200	105	015	012	
3679	024203	000			
	024204	015	012	116	NOPE: .ASCIZ <15><12>'NO PARITY ERRORS FOUND ON MEMORY SCAN'<15><12>
	024207	117	040	120	
	024212	101	122	111	
	024215	124	131	040	
	024220	105	122	122	
	024223	117	122	123	
	024226	040	106	117	
	024231	125	116	104	
	024234	040	117	116	
	024237	040	115	105	
	024242	115	117	122	
	024245	131	040	123	
	024250	103	101	116	
3680	024253	015	012	000	
	024256	015	012	120	PROREL: .ASCII <15><12>'PROGRAM NOW RESIDES BACK AT 0 TO 8K'
	024261	122	117	107	
	024264	122	101	115	
	024267	040	116	117	
	024272	127	040	122	
	024275	105	123	111	
	024300	104	105	123	
	024303	040	102	101	
	024306	103	113	040	

	024311	101	124	040	
	024314	060	040	124	
	024317	117	040	070	
	024322	113			
3681	024323	015	012	110	.ASCIZ <15><12>'HIT CONTINUE FOR NORMAL RUNNING'<15><12>
	024326	111	124	040	
	024331	103	117	116	
	024334	124	111	116	
	024337	125	105	040	
	024342	106	117	122	
	024345	040	116	117	
	024350	122	115	101	
	024353	114	040	122	
	024356	125	116	116	
	024361	111	116	107	
	024364	015	012	000	
3682	024367	015	012	120	MX1: .ASCIZ <15><12>'PARITY REGISTER AT '
	024372	101	122	111	
	024375	124	131	040	
	024400	122	105	107	
	024403	111	123	124	
	024406	105	122	040	
	024411	101	124	040	
	024414	000			
3683	024415	040	103	117	MX2: .ASCIZ ' CONTROLS '
	024420	116	124	122	
	024423	117	114	123	
	024426	040	000		
3684	024430	015	012	116	NOMEM: .ASCIZ <15><12>'NO MEMORY FOUND.'
	024433	117	040	115	
	024436	105	115	117	
	024441	122	131	040	
	024444	106	117	125	
	024447	116	104	056	
	024452	000			
3685	024453	015	012	012	FADMES: .ASCII <15><12><12><12>'INPUT ALL PARAMETERS IN OCTAL.'
	024456	012	111	116	
	024461	120	125	124	
	024464	040	101	114	
	024467	114	040	120	
	024472	101	122	101	
	024475	115	105	124	
	024500	105	122	123	
	024503	040	111	116	
	024506	040	117	103	
	024511	124	101	114	
	024514	056			
3686	024515	015	012	106	.ASCIZ <15><12>'FIRST ADDRESS: '
	024520	111	122	123	
	024523	124	040	101	
	024526	104	104	122	
	024531	105	123	123	
	024534	072	040	040	
	024537	000			
3687	024540	015	012	114	LADMES: .ASCIZ <15><12>'LAST ADDRESS: '
	024543	101	123	124	
	024546	040	101	104	

	024551	104	122	105	
	024554	123	123	072	
	024557	040	040	040	
	024562	000			
3688	024563	015	012	077	BADADR: .ASCIZ <15><12>'?ADDRESS IN UNMAPPED BANK?'
	024566	101	104	104	
	024571	122	105	123	
	024574	123	040	111	
	024577	116	040	125	
	024602	116	115	101	
	024605	120	120	105	
	024610	104	040	102	
	024613	101	116	113	
	024616	077	000		
3689	024620	015	012	123	CONST: .ASCIZ <15><12>'SELECT CONSTANT:'
	024623	105	114	105	
	024626	103	124	040	
	024631	103	117	116	
	024634	123	124	101	
	024637	116	124	072	
	024642	000			
3690	024643	015	012	125	UNEXPT: .ASCIZ <15><12>'UNEXPECTED MEMORY PARITY ERROR'
	024646	116	105	130	
	024651	120	105	103	
	024654	124	105	104	
	024657	040	115	105	
	024662	115	117	122	
	024665	131	040	120	
	024670	101	122	111	
	024673	124	131	040	
	024676	105	122	122	
	024701	117	122	000	
3691	024704	015	012	120	PRELOC: .ASCIZ <15><12>'PROGRAM RELOCATED TO '
	024707	122	117	107	
	024712	122	101	115	
	024715	040	122	105	
	024720	114	117	103	
	024723	101	124	105	
	024726	104	040	124	
	024731	117	040	000	
3692	024734	015	012	115	MTOE: .ASCIZ <15><12>'MORE THAN ONE PARITY ERROR FOUND.'
	024737	117	122	105	
	024742	040	124	110	
	024745	101	116	040	
	024750	117	116	105	
	024753	040	120	101	
	024756	122	111	124	
	024761	131	040	105	
	024764	122	122	117	
	024767	122	040	106	
	024772	117	125	116	
	024775	104	056	000	
3693	025000	015	012	123	SCANM: .ASCIZ <15><12>'SCANNING MEMORY FOR BAD PARITY.'
	025003	103	101	116	
	025006	116	111	116	
	025011	107	040	115	
	025014	105	115	117	

	025017	122	131	040	
	025022	106	117	122	
	025025	040	102	101	
	025030	104	040	120	
	025033	101	122	111	
	025036	124	131	056	
	025041	000			
3694	025042	015	012	120	PEWNC: .ASCIZ <15><12>'PARITY ERROR WILL NOT CLEAR.'
	025045	101	122	111	
	025050	124	131	040	
	025053	105	122	122	
	025056	117	122	040	
	025061	127	111	114	
	025064	114	040	116	
	025067	117	124	040	
	025072	103	114	105	
	025075	101	122	056	
	025100	000			
3695	025101	015	012	116	NOMTST: .ASCIZ <15><12>'NO MEMORY TESTED.'
	025104	117	040	115	
	025107	105	115	117	
	025112	122	131	040	
	025115	124	105	123	
	025120	124	105	104	
	025123	056	000		
3696	025125	015	012	123	SKPMES: .ASCIZ <15><12>'SKIPPING TEST #'
	025130	113	111	120	
	025133	120	111	116	
	025136	107	040	124	
	025141	105	123	124	
	025144	040	043	000	
3697	025147	377	377	000	FILL2: .ASCIZ <377><377>
3698					
3699					.SBTTL ERROR REPORTING MESSAGES AND TABLES.
3700					::*****
3701					::* MESSAGE BLOCK FOR ERROR TABLE TYPEOUTS
3702					::*****
3703	025152	120	101	122	DM1: .ASCIZ 'PARITY REGISTER DATA ERROR.'
	025155	111	124	131	
	025160	040	122	105	
	025163	107	111	123	
	025166	124	105	122	
	025171	040	104	101	
	025174	124	101	040	
	025177	105	122	122	
	025202	117	122	056	
	025205	000			
3704	025206	101	104	104	DM2: .ASCIZ 'ADDRESS TEST ERROR(TST1-5).'
	025211	122	105	123	
	025214	123	040	124	
	025217	105	123	124	
	025222	040	105	122	
	025225	122	117	122	
	025230	050	124	123	
	025233	124	061	055	
	025236	065	051	056	
	025241	000			

3705	025242	103	117	116	DM4:	.ASCIZ 'CONSTANT DATA ERROR(TST6-10).'
	025245	123	124	101		
	025250	116	124	040		
	025253	104	101	124		
	025256	101	040	105		
	025261	122	122	117		
	025264	122	050	124		
	025267	123	124	066		
	025272	055	061	060		
	025275	051	056	000		
3706	025300	122	117	124	DM5:	.ASCIZ 'ROTATING BIT ERROR(TST11-12).'
	025303	101	124	111		
	025306	116	107	040		
	025311	102	111	124		
	025314	040	105	122		
	025317	122	117	122		
	025322	050	124	123		
	025325	124	061	061		
	025330	055	061	062		
	025333	051	056	000		
3707	025336	115	117	123	DM6:	.ASCIZ 'MOS REFRESH TEST ERROR (TST 24-25).'
	025341	040	122	105		
	025344	106	122	105		
	025347	123	110	040		
	025352	124	105	123		
	025355	124	040	105		
	025360	122	122	117		
	025363	122	040	050		
	025366	124	123	124		
	025371	040	062	064		
	025374	055	062	065		
	025377	051	056	000		
3708	025402	106	101	124	DM7:	.ASCIZ 'FATAL ERROR HALT'
	025405	101	114	040		
	025410	105	122	122		
	025413	117	122	040		
	025416	110	101	114		
	025421	124	000			
3709	025423	115	101	122	DM10:	.ASCIZ "MARCHING 1'S AND 0'S ERROR(TST 23)."
	025426	103	110	111		
	025431	116	107	040		
	025434	061	047	123		
	025437	040	101	1'6		
	025442	104	040	060		
	025445	047	123	040		
	025450	105	122	122		
	025453	117	122	050		
	025456	124	123	124		
	025461	040	062	063		
	025464	051	056	000		
3710	025467	120	101	122	DM11:	.ASCIZ 'PARITY MEMORY ADDRESS ERROR(TST13).'
	025472	111	124	131		
	025475	040	115	105		
	025500	115	117	122		
	025503	131	040	101		
	025506	104	104	122		
	025511	105	123	123		



	025514	040	105	122	
	025517	122	117	122	
	025522	050	124	123	
	025525	124	061	063	
	025530	051	056	000	
3711	025533	104	101	124	DM12: .ASCIZ 'DATIO WITH WRONG PARITY DIDN'T TRAP(TST13).'
	025536	111	117	040	
	025541	127	111	124	
	025544	110	040	127	
	025547	122	117	116	
	025552	107	040	120	
	025555	101	122	111	
	025560	124	131	040	
	025563	104	111	104	
	025566	116	047	124	
	025571	040	124	122	
	025574	101	120	050	
	025577	124	123	124	
	025602	061	063	051	
	025605	056	000		
3712	025607	127	122	117	DM13: .ASCIZ 'WRONG PARITY DETECTED, BUT NO REGISTER SHOWS ERROR FLAG.'
	025612	116	107	040	
	025615	120	101	122	
	025620	111	124	131	
	025623	040	104	105	
	025626	124	105	103	
	025631	124	105	104	
	025634	054	040	102	
	025637	125	124	040	
	025642	116	117	040	
	025645	122	105	107	
	025650	111	123	124	
	025653	105	122	040	
	025656	123	110	117	
	025661	127	123	040	
	025664	105	122	122	
	025667	117	122	040	
	025672	106	114	101	
	025675	107	056	000	
3713	025700	120	101	122	DM14: .ASCIZ 'PARITY REGISTER NOT MAPPED AS CONTROLLING THIS ADDRESS(TST13).'
	025703	111	124	131	
	025706	040	122	105	
	025711	107	111	123	
	025714	124	105	122	
	025717	040	116	117	
	025722	124	040	115	
	025725	101	120	120	
	025730	105	104	040	
	025733	101	123	040	
	025736	103	117	116	
	025741	124	122	117	
	025744	114	114	111	
	025747	116	107	040	
	025752	124	110	111	
	025755	123	040	101	
	025760	104	104	122	
	025763	105	123	123	

	025766	050	124	123	
	025771	124	061	063	
	025774	051	056	000	
3714	025777	115	117	122	DM16: .ASCIZ 'MORE THAN ONE REGISTER INDICATED PARITY ERROR.'
	026002	105	040	124	
	026005	110	101	116	
	026010	040	117	116	
	026013	105	040	122	
	026016	105	107	111	
	026021	123	124	105	
	026024	122	040	111	
	026027	116	104	111	
	026032	103	101	124	
	026035	105	104	040	
	026040	120	101	122	
	026043	111	124	131	
	026046	040	105	122	
	026051	122	117	122	
	026054	056	000		
3715	026056	104	101	124	DM17: .ASCIZ 'DATA SHOULDN'T HAVE CHANGED WHEN PARITY ERROR TRAPPED(TST13).'
	026061	101	040	123	
	026064	110	117	125	
	026067	114	104	116	
	026072	047	124	040	
	026075	110	101	126	
	026100	105	040	103	
	026103	110	101	116	
	026106	107	105	104	
	026111	040	127	110	
	026114	105	116	040	
	026117	120	101	122	
	026122	111	124	131	
	026125	040	105	122	
	026130	122	117	122	
	026133	040	124	122	
	026136	101	120	120	
	026141	105	104	050	
	026144	124	123	124	
	026147	061	063	051	
	026152	056	000		
3716	026154	122	101	116	DM20: .ASCIZ 'RANDOM DATA ERROR(TST14).'
	026157	104	117	115	
	026162	040	104	101	
	026165	124	101	040	
	026170	105	122	122	
	026173	117	122	050	
	026176	124	123	124	
	026201	061	064	051	
	026204	056	000		
3717	026206	111	116	123	DM21: .ASCIZ 'INSTRUCTION EXECUTION ERROR(TST15-22).'
	026211	124	122	125	
	026214	103	124	111	
	026217	117	116	040	
	026222	105	130	105	
	026225	103	125	124	
	026230	111	117	116	
	026233	040	105	122	

	026236	122	117	122	
	026241	050	124	123	
	026244	124	061	065	
	026247	055	062	062	
	026252	051	056	000	
3718	026255	120	122	117	DM23: .ASCIZ 'PROGRAM CODE CHANGED WHEN RELOCATED.'
	026260	107	122	101	
	026263	115	040	103	
	026266	117	104	105	
	026271	040	103	110	
	026274	101	116	107	
	026277	105	104	040	
	026302	127	110	105	
	026305	116	040	122	
	026310	105	114	117	
	026313	103	101	124	
	026316	105	104	056	
	026321	000			
3719	026322	124	122	101	DM24: .ASCIZ 'TRAPPED, BUT NO REGISTER HAD ERROR BIT SET.'
	026325	120	120	105	
	026330	104	054	040	
	026333	102	125	124	
	026336	040	116	117	
	026341	040	122	105	
	026344	107	111	123	
	026347	124	105	122	
	026352	040	110	101	
	026355	104	040	105	
	026360	122	122	117	
	026363	122	040	102	
	026366	111	124	040	
	026371	123	105	124	
	026374	056	000		
3720	026376	124	122	101	DM25: .ASCIZ 'TRAPPED TO 114.'
	026401	120	120	105	
	026404	104	040	124	
	026407	117	040	061	
	026412	061	064	056	
	026415	000			
3721	026416	106	101	111	DM26: .ASCIZ 'FAILED TO TRAP.'
	026421	114	105	104	
	026424	040	124	117	
	026427	040	124	122	
	026432	101	120	056	
	026435	000			
3722	026436	050	101	103	DM27: .ASCIZ "(ACTION ENABLE WASN'T SET)."
	026441	124	111	117	
	026444	116	040	105	
	026447	116	101	102	
	026452	114	105	040	
	026455	127	101	123	
	026460	116	047	124	
	026463	040	123	105	
	026466	124	051	056	
	026471	000			
3723	026472	015	012	124	DM31: .ASCIZ '<15><12>' TRAPPED TO 4
	026475	122	101	120	



3734	026724	000											
	026725	126	057	120	DH21:	.ASCIZ	'V/PC	P/PC	IUT	MA	S/B	WAS'	
	026730	103	011	120									
	026733	057	120	103									
	026736	011	040	040									
	026741	111	125	124									
	026744	011	040	040									
	026747	115	101	011									
	026752	040	040	040									
	026755	040	123	057									
	026760	102	011	040									
	026763	040	040	040									
	026766	127	101	123									
	026771	000											
3735	026772	126	057	120	DH23:	.ASCIZ	'V/PC	P/PC	SRC MA	DST MA	S/B	WAS'	
	026775	103	011	120									
	027000	057	120	103									
	027003	011	040	040									
	027006	123	122	103									
	027011	040	115	101									
	027014	040	040	040									
	027017	040	104	123									
	027022	124	040	115									
	027025	101	040	040									
	027030	040	040	123									
	027033	057	102	040									
	027036	040	040	040									
	027041	040	127	101									
	027044	123	000										
3736	027046	126	057	120	DH24:	.ASCIZ	'V/PC	P/PC	TRP/PC'				
	027051	103	011	120									
	027054	057	120	103									
	027057	011	040	040									
	027062	124	122	120									
	027065	057	120	103									
	027070	000											
3737	027071	126	057	120	DH25:	.ASCIZ	'V/PC	P/PC	TRP/PC	REG	WAS'		
	027074	103	011	120									
	027077	057	120	103									
	027102	011	040	040									
	027105	124	122	120									
	027110	057	120	103									
	027113	040	040	040									
	027116	040	122	105									
	027121	107	040	040									
	027124	040	040	040									
	027127	040	040	127									
	027132	101	123	000									
3738	027135	126	057	120	DH26:	.ASCIZ	'V/PC	P/PC	REG	WAS'			
	027140	103	011	120									
	027143	057	120	103									
	027146	011	040	040									
	027151	122	105	107									
	027154	011	040	040									
	027157	040	040	127									
	027162	101	123	000									
3739	027165	122	105	107	DH30:	.ASCIZ	'REG	WAS	MA	WAS'			

	027170	011	040	040					
	027173	127	101	123					
	027176	011	040	040					
	027201	115	101	011					
	027204	040	040	040					
	027207	040	127	101					
	027212	123	000						
3740	027214	126	057	120	DH31:	.ASCIZ	'V/PC	P/PC	MA S/B WAS'
	027217	103	011	120					
	027222	057	120	103					
	027225	011	040	040					
	027230	115	101	011					
	027233	040	040	040					
	027236	040	123	057					
	027241	102	040	040					
	027244	127	101	123					
	027247	000							

3741  
 3742  
 3743  
 3744

```

;*****
;* DATA FORMAT TABLE FOR ERROR PRINTOUT.
;*****
  
```

3745	027250	000	377	000	DF1:	.BYTE	0,-1,0,0
	027253	000					
3746	027254	000	377	377	DF2:	.BYTE	0,-1,-1,0,0
	027257	000	000				
3747	027261	000	377	377	DF3:	.BYTE	0,-1,-1,-2,-2
	027264	376	376				
3748	027266	000	377	377	DF14:	.BYTE	0,-1,-1,-1,0,0
	027271	377	000	000			
3749	027274	000	377	000	DF21:	.BYTE	0,-1,0,-1,0,0
	027277	377	000	000			
3750	027302	377	000	377	DF30:	.BYTE	-1,0,-1,-2
	027305	376					

3751  
 3752  
 3753  
 3754  
 3755  
 3756

```

.EVEN
. = 32000
;THE LOADERS ARE SAVE HERE TO END OF 8K
;1536. WORDS
.END
  
```

Symbol table

AGASE	=	000000	BIT0	=	000001	DIDO	=	011350	GMPRBA	=	005334	MPRO	=	002272
ACDW1	=	000000	BIT00	=	000001	DIPDO	=	011606	GMPRC	=	005340	MPR1	=	002336
ACDW2	=	000000	BIT01	=	000002	DISMAP	=	005160	GMPRD	=	005376	MPR10	=	003042
ACPUOP	=	000000	BIT02	=	000004	DISPLA	=	001132	HT	=	000011	MPR11	=	003106
ADDW0	=	000000	BIT03	=	000010	DISPRE	=	000174	INITDN	=	013254	MPR12	=	003152
ADDW1	=	000000	BIT04	=	000020	DM1	=	025152	INITEX	=	013362	MPR13	=	003216
ADDW10	=	000000	BIT05	=	000040	DM10	=	025423	INITMM	=	013156	MPR14	=	003262
ADDW11	=	000000	BIT06	=	000100	DM11	=	025467	INSUFF	=	024022	MPR15	=	003326
ADDW12	=	000000	BIT07	=	000200	DM12	=	025533	IOTVEC	=	000020	MPR2	=	002402
ADDW13	=	000000	BIT08	=	000400	DM13	=	025607	KDJDA	=	002000	MPR3	=	002446
ADDW14	=	000000	BIT09	=	001000	DM14	=	025700	KIPAR0	=	172340	MPR4	=	002512
ADDW15	=	000000	BIT1	=	000002	DM16	=	025777	KIPAR1	=	172342	MPR5	=	002556
ADDW2	=	000000	BIT10	=	002000	DM17	=	026056	KIPAR2	=	172344	MPR6	=	002622
ADDW3	=	000000	BIT11	=	004000	DM2	=	025206	KIPAR3	=	172346	MPR7	=	002666
ADDW4	=	000000	BIT12	=	010000	DM20	=	026154	KIPAR4	=	172350	MPR8	=	002732
ADDW5	=	000000	BIT13	=	020000	DM21	=	026206	KIPAR5	=	172352	MPR9	=	002776
ADDW6	=	000000	BIT14	=	040000	DM23	=	026255	KIPAR6	=	172354	MTMAP	=	023760
ADDW7	=	000000	BIT15	=	100000	DM24	=	026322	KIPAR7	=	172356	MTOE	=	024734
ADDW8	=	000000	BIT2	=	000004	DM25	=	026376	KIPDR0	=	172300	MTR	=	024103
ADDW9	=	000000	BIT3	=	000010	DM26	=	026416	KIPDR1	=	172302	MX1	=	024367
ADEVCT	=	000000	BIT4	=	000020	DM27	=	026436	KIPDR2	=	172304	MX2	=	024415
ADEVM	=	000000	BIT5	=	000040	DM31	=	026472	KIPDR3	=	172306	NOMEM	=	024430
AE	=	000001	BIT6	=	000100	DM4	=	025242	KIPDR4	=	172310	NOMTST	=	025101
AENV	=	000000	BIT7	=	000200	DM5	=	025300	KIPDR5	=	172312	NONKT	=	004646
AENVM	=	000000	BIT8	=	000400	DM6	=	025336	KIPDR6	=	172314	NOPE5	=	024204
AFATAL	=	000000	BIT9	=	001000	DM7	=	025402	KIPDR7	=	172316	OEFLG	=	001760
AMADR1	=	000000	BNKTAB	=	017526	DONE	=	012502	KTSIZ	=	004760	PARMAT	=	016146
AMADR2	=	000000	BPTVEC	=	000014	DPDBH	=	011756	LADMES	=	024540	PARVEC	=	000114
AMADR3	=	000000	CHGG1	=	003434	DPDBL	=	011672	LDDISP	=	001512	PBTRP	=	010520
AMADR4	=	000000	CHGG2	=	016040	DSWR	=	177570	LF	=	000012	PBTRP1	=	010530
AMAMS1	=	000000	CKPMER	=	016040	DT1	=	002042	LMAD	=	001510	PESRV	=	015632
AMAMS2	=	000000	CLRPAR	=	016672	DT12	=	002070	LMEMHI	=	017524	PEWNC	=	025042
AMAMS3	=	000000	CONST	=	024620	DT14	=	002102	LMEMLO	=	017522	PHYADR	=	014276
AMAMS4	=	000000	CR	=	000015	DT15	=	002114	LSIFLG	=	001776	PIRQ	=	177772
AMSGAD	=	000000	CRLF	=	000200	DT2	=	002054	MAMF	=	015740	PIRQVE	=	000240
AMSGLG	=	000000	CTRLS	=	006060	DT21	=	002132	MAMF1	=	016024	PLUS1	=	002002
AMSGTY	=	000000	DDISP	=	177570	DT23	=	002150	MAMF2	=	016036	PMEMAP	=	001654
AMTYP1	=	000000	DF1	=	027250	DT24	=	002166	MANUAL	=	006350	PRELOC	=	024704
AMTYP2	=	000000	DF14	=	027266	DT25	=	002176	MANUL1	=	006366	PRGMAP	=	000534
AMTYP3	=	000000	DF2	=	027254	DT26	=	002212	MANUL2	=	006770	PROREL	=	024256
AMTYP4	=	000000	DF21	=	027274	DT30	=	002224	MAPRB	=	005432	PRO	=	000000
APASS	=	000000	DF3	=	027261	DT31	=	002236	MASK4K	=	017777	PR1	=	000040
APRIOR	=	000000	DF30	=	027302	EMTVEC	=	000030	MASK8K	=	037777	PR2	=	000100
APTC5U	=	000040	DH1	=	026512	ENDBKT	=	017530	MEMMAP	=	001514	PR3	=	000140
APTENV	=	000001	DH12	=	026574	ENDINS	=	020026	MEMMES	=	023742	PR4	=	000200
APTSIZ	=	000200	DH14	=	026623	ERROR	=	104000	MFPT	=	000007	PR5	=	000240
APTSPO	=	000100	DH15	=	026652	ERRTRP	=	023430	MMAMES	=	023650	PR6	=	000300
ASWREG	=	000000	DH2	=	026535	ERRVEC	=	000004	MMAVA	=	000536	PR7	=	000340
ATESTN	=	000000	DH21	=	026725	FADMES	=	024453	MMDOWN	=	013734	PS	=	177776
AUNIT	=	000000	DH23	=	026772	FILL2	=	025147	MMINIT	=	013000	PSCAN	=	016212
AUSWR	=	000000	DH24	=	027046	FLAG8K	=	001757	MMORE	=	001754	PSW	=	177776
AVAL22	=	023715	DH25	=	027071	FLG30K	=	001774	MMUP	=	013370	PWRMSG	=	024137
AVECT1	=	000000	DH26	=	027135	FROM	=	024005	MMVEC	=	000250	PWRVEC	=	000024
AVECT2	=	000000	DH30	=	027165	FSTADR	=	001762	MPAMEM	=	005404	RADTAB	=	002004
BADADR	=	024563	DH31	=	027214	GMPR	=	005262	MPEND	=	002270	RANTST	=	011232
BANKNJ	=	014374	DIDBH	=	011516	GMPRA	=	005310	MPPATS	=	002244	RELOC	=	014626
BITP	=	001714	DIDBL	=	011432	GMPRB	=	005324	MPRX	=	003372	RELOCF	=	000532

## Symbol table

SEQ 0119

RFLTOP	014750	SW10	002000	WWPB3	011072	\$ENVM	001215	\$OVER	020014
RELO	015264	SW11	= 004000	WWPB4	011162	\$EOP	012624	\$PASS	001202
RESCHK	006232	SW12	= 010000	WWPB5	011206	\$EOPCT	012646	\$PASTM	001326
RESLDR	015464	SW13	= 020000	WWPB6	011216	\$ERFLG	001073	\$PRINT	021752
RESRVD	001506	SW14	= 040000	W3X9	014546	\$ERMAX	001105	\$PWRAD	000702
RESTAR	000300	SW15	= 100000	\$APTHD	001320	\$ERROR	020044	\$PWRDN	000540
RESTOR	000304	SW2	= 000004	\$APTR	001502	\$ERRPC	001106	\$PWRMG	000676
REST1	000306	SW3	= 000010	\$ASTAT	001334	\$ERRTB	003434	\$PWRUP	000612
REST2	000324	SW4	= 000020	\$ASTEN	001500	\$ERRTY	020274	\$QUES	001170
RESVEC	000010	SW5	= 000040	\$ATYC	022364	\$ERTTL	001102	\$RDCHR	021114
ROTATE	014500	SW6	= 000100	\$ATY1	022340	\$ESCAP	001162	\$RDLIN	021244
RW	000006	SW7	= 000200	\$ATY3	022346	\$ETABL	001214	\$RDOCT	021576
R6	*000006	SW8	= 000400	\$ATY4	022356	\$ETEND	001320	\$RDSZ	= 000010
R7	*000007	SW9	= 001000	\$ATY6	022654	\$FATAL	001176	\$SAVR6	000712
SAVLDR	015552	TBITVE	= 000014	\$ATY7	022720	\$FFLG	022744	\$SCOPE	017532
SAVTST	001614	TEMP	001770	\$AUTOB	001124	\$FILLC	001146	\$SETUP	= 000130
SCAP	025000	TEMP1	001772	\$BASE	001250	\$FILLS	001145	\$STUP	= 177777
SCOPE	000004	TKVEC	= 000060	\$BDADR	001112	\$GDADR	001110	\$SVLAD	017760
SECT2	007612	TMAP	005654	\$BDDAT	001116	\$GDDAT	001114	\$SVPC	= 000010
SELECT	003752	TO	024015	\$BELL	001164	\$GET42	012712	\$SWR	= 167400
SEL_FLG	001756	TPVEC	= 000064	\$CDW1	001254	\$GTSWR	020660	\$SWREG	001216
SETAE	016004	TRAPVE	= 000034	\$CDW2	001256	\$HD	= 000000	\$SWRMK	= 000340
SETCON	014462	TRTVEC	= 000014	\$CHARC	022334	\$HIBTS	001320	\$TESTN	001200
SKPMES	025125	TSTMAP	001554	\$CKSWR	020606	\$HIOC	021750	\$TIMES	001160
SPREND	017024	TST1	007102	\$CMTAG	001070	\$ICNT	001074	\$TKB	001136
SPRNT	016714	TST10	010004	\$CM3	= 000000	\$ILLUP	000706	\$TKS	001134
SPRNTA	017014	TST11	010062	\$CM4	= 000004	\$INTAG	001125	\$TMP0	001150
SPRNTB	017020	TST12	010142	\$CNTLG	021547	\$ITEMB	001104	\$TMP1	001152
SPRNTP	016752	TST13	010220	\$CNTLU	021542	\$LF	001172	\$TMP2	001154
SPRNTQ	016726	TST14	011226	\$CPUOP	001222	\$LFLG	022743	\$TMP3	001156
SPRNT0	016756	TST15	011344	\$CRLF	001171	\$LPADR	001076	\$TN	= 000026
SPRNT1	016764	TST16	011426	\$DBLK	023170	\$LPERR	001100	\$TPB	001142
SPRNT2	017002	TST17	011512	\$DDW0	001260	\$MADR1	001226	\$TPFLG	001147
SPRNT3	016776	TST2	007224	\$DDW1	001262	\$MADR2	001232	\$TPS	001140
SRO	= 177572	TST20	011602	\$DDW10	001304	\$MADR3	001236	\$TSTM	001324
SR1	= 177574	TST21	011666	\$DDW11	001306	\$MADR4	001242	\$TSTNM	001072
SR2	= 177576	TST22	011752	\$DDW12	001310	\$MAIL	001174	\$TTYIN	021532
SR3	= 172516	TST23	012040	\$DDW13	001312	\$MAMS1	001224	\$TYPAD	023466
STACK	= 001100	TST24	012272	\$DDW14	001314	\$MAMS2	001230	\$TYPDS	022746
START	003744	TST25	012376	\$DDW15	001316	\$MAMS3	001234	\$TYPE	022002
STARTA	003760	TST3	007324	\$DDW2	001264	\$MAMS4	001240	\$TYPEC	022216
START1	007006	TST32	012506	\$DDW3	001266	\$MBADR	001322	\$TYPEX	022336
STKLMT	= 177774	TST4	007432	\$DDW4	001270	\$MFLG	022742	\$TYPC	023224
SWR	001130	TST5	007520	\$DDW5	001272	\$MNEW	021565	\$TYPON	023240
SWREG	000176	TST6	007652	\$DDW6	001274	\$MSGAD	001210	\$TYPQS	023200
SW0	= 000001	TST6A	007656	\$DDW7	001276	\$MSGLG	001212	\$UNIT	001206
SW00	= 000001	TST7	007676	\$DDW8	001300	\$MSGTY	001174	\$UNITM	001330
SW01	= 000002	TYPMAP	017026	\$DDW9	001302	\$MSWR	021554	\$USWR	001220
SW02	= 000004	UNEXPT	024643	\$DEVCT	001204	\$MTYP1	001225	\$VECT1	001244
SW03	= 000010	UP	= 000000	\$DEVM	001252	\$MTYP2	001231	\$VECT2	001246
SW04	= 000020	VMK	013060	\$DOAGN	012754	\$MTYP3	001235	\$VERPC	001504
SW05	= 000040	VMK1	013132	\$DTBL	023160	\$MTYP4	001241	\$XOFF	= 000023
SW06	= 000100	WWP	001766	\$ENDAD	012722	\$MXCNT	020030	\$XON	= 000021
SW07	= 000200	WWPBYT	010262	\$ENDCT	012654	\$NULL	001144	\$XTSTR	017556
SW08	= 000400	WWPB0	010224	\$ENDMG	012760	\$NWTST	= 000001	\$OFILL	023425
SW09	= 001000	WWPB1	010322	\$ENULL	012775	\$OCNT	023424	.BITPT	002016
SW1	= 000002	WWPB2	010366	\$ENV	001214	\$OMODE	023426	.CONST	001764



Symbol table

.EIGHT	002036	.MPPAT	002030	.PBTRP	002026	.RESRV	002020	.TSTMA	002012
.ERRTB	002034	.MPRX	002024	.PESRV	002032	.SAVTS	002010	.TST32	002040
.MEMMA	002006	.MPRO	002022	.PMEMA	002014	.STACK	002004	.\$X	= 001320

. ABS. 032000 000 (RW,I,GBL,ABS,GvR)  
000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 655  
Work file writes: 514  
Size of work file: 65336 Words ( 0 Pages)  
Size of core pool: 19714 Words ( 75 Pages)  
Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:03:03.04  
CVMSAB.BIN,CVMSAB.LST=SYSMAC.MLB/ML,CVMSAB.P11