

FEPOM

CTAL BRIDGE INTFC
CZFPAAO

COPYRIGHT (c) 1982-84
AH-T859A-MC
FICHE 1 OF 1

APR 1984

digital

Made In USA

This microfiche card contains a grid of frames, each displaying technical data. The data is organized into columns and rows, with some frames containing diagrams or tables. The text is small and difficult to read, but it appears to be technical specifications or data points related to the system described in the header. The frames are arranged in a regular grid pattern across the card.

.REM 6

IDENTIFICATION

PRODUCT CODE: AC-T858A-MC
PRODUCT NAME: CZFPAAO CTRL BRIDGE INTFC
PRODUCT DATE: MAY 1982
MAINTAINER: CSS GNG DIAGNOSTIC ENGINEERING
AUTHOR: DALE F. PROCTOR

COPYRIGHT (C) 1982,1984
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS 01754

THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY TRANSFERED.

THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	Q-BUS
LSI	VAX		

REVISION HISTORY

- A.0 DALE PROCTOR 22-DEC-1983
CHANGED THE NAME TO CZFPA-A0 AND RELEASED TO
SDC. ALSO UPDATED ALL THE DOCUMENTATION, AND
REMOVED THE HELP FILE QUESTIONS FROM THE
INITIALIZATION SECTION.
- D.2 DALE PROCTOR 4-NOV-1983
CHANGED THE INSTRUCTION MOV #PATCH, @QBA TO
MOV @#PATCH, @QBA IN Z0791D5.MAC IN TEST 41.
- D.1 DALE PROCTOR 30-SEP-1983
ADDED TO THE CLEANUP CODE TO ALWAYS
DISABLE MIDDIS.
- D.0 DALE PROCTOR 15-JUNE-1983
RENAMED PROGRAM TO Z0791DX.MAC AND ARCHEVED.
- C.1 DALE PROCTOR 10-JUNE-1983
ADDED STATST AND CKPNT MACROS TO PRINT
OUT THE TEST SBTTL IF THE FLA:PNT FLAG
IS SET.
- C.0 MODIFIER- JOHN M. MARTIN 31-MAR-83
DISABLED UMR IN INITIALIZE.
CORRECTED ERRORS IN TESTS 3,36.
- B.0 MODIFIER- PAUL HOLSINGER
ADDED 11/24 (UNIBUS) COMPATIBILITY.
- A.0 INITIAL RELEASE

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC CONTAINS REPAIR LEVEL TESTS FOR THE FRONT END PROCESSOR BRIDGE MODULE ON THE PDP-11 SIDE. IT CAN BE RUN EITHER WITH INTERNAL LOOPBACK LOGIC OR WITH A LOOPBACK CABLE INSTALLED.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

PDP-11/23 OR /24 CPU WITH AT LEAST 16K WORDS OF MEMORY, CONSOLE DEVICE AND TU-58 TAPE DRIVE. NORMAL CONFIGURATION FOR THE CONSOLE DEVICE IS THROUGH THE VAX SIDE OF THE FEP.

1.3 RELATED DOCUMENTS AND STANDARDS

FEPCH TECHNICAL MANUAL
AC-T860A-MC CZFPBAO CTRL BRIDGE LINK
AC-T866AS-MC CXFPCAO CTRL BRIDGE DEC/X11
EVDTE COMMAND BRIDGE INTERFACE DIAGNOSTIC. (VAX DIAGNOSTIC)
EVDTC COMMAND BRIDGE LINK DIAGNOSTIC. (VAX DIAGNOSTIC)
XXDP+ USERS MANUAL - CHQUS??.

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE CPU, MEMORY, CONSOLE DEVICE AND THE TU-58 TAPE DRIVE ARE ASSUMED TO BE FUNCTIONING PRIOR TO RUNNING THIS TEST. NO RUNNING ORDER IS REQUIRED ON THE TESTS.

1.5 ASSUMPTIONS

EITHER A LOOPBACK CABLE IS INSTALLED OR THE DEFAULT IN THE HARDWARE QUESTION REFERING TO THE LOOPBACK CABLE IS ANSWERED.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ↑C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBE*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

LSI BRIDGE MODULE BASE ADDRESS ADDRESS OF Q-COMMAND REGISTER	DEFAULT=160500
LSI BRIDGE MODULE VECTOR ADDRESS OF INTERRUPT VECTOR	DEFAULT=500
LOOPBACK CABLE INSTALLED INTERNAL LOOPBACK OR PHYSICAL CABLE USED	DEFAULT=NO
BR LEVEL INTERRUPT PRIORITY LEVEL	DEFAULT=4

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THERE ARE NO SOFTWARE QUESTIONS IN THIS DIAGNOSTIC.

2.6 EXTENDED P-TABLE DIALOGUE

NOT APPLICABLE.

2.7 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM

4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE

.WHERE; NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBE" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

MOST OF THE ERROR MESSAGES ARE SELF EXPLANATORY. THE GENERAL FORMAT IS THE BASIC ERROR LINE, FOLLOWED BY A DESCRIPTIVE LINE, FOLLOWED BY A LINE THAT CONTAINS A REGISTER NAME, IT'S ADDRESS, IT'S CONTENTS, AND WHAT WAS EXPECTED. UNDETERMINED BITS AND UNTESTED BITS ARE ZEROED OUT PRIOR TO TESTING AND DISPLAYING. IF THERE IS A BIT RANGE (EX., BIT 1-5 ONLY ARE TESTED,) THAT IS INCLUDED IN THE ERROR MESSAGE.

THREE OF THE TESTS, 28 - 30 DEAL WITH THE THE VIEW RAM. THERE IS A POSSIBILITY OF 1K OR 2K OF RAM INSALLED. IF THERE IS AN ERROR IN THIS RAM, YOU WILL GET A MAXIMUM OF 20 LINES OF ERROR MESSAGES. THIS IS TO PREVENT 1K OR 2K LINES OF MESSAGES PRODUCED.

HOWEVER, A TOTAL ERROR COUNT IS PROVIDED AT THE END OF EACH TEST. ALSO, TEST 29 AND 30 TELL THE OPERATOR THE RAM SIZE. THE THREE POSSIBILITIES ARE 1K, 2K OR UNDETERMINED RAM SIZE. THE 1K OR 2K RAM SIZE MESSAGE WILL OCCUR ONLY ONCE FROM THE POINT OF RUNNING THE DIAGNOSTIC, BUT UNDETERMINED RAM SIZE WILL PRINT EACH TIME TEST 29 OR 30 IS ENCOUNTERED IF NEEDED.

THERE IS A WATCH DOG TIMER CIRCUIT ON THE FEPCM, AND THE TESTING OF IT USES THE BELL ON THE CONSOLE. TEST 36 TESTS EACH TIME PATTERN 5 TIMES, AND WITH 4 TIMES PATTERNS THAT MEANS 20 BELLS ON THE CONSOLE. THE BELL'S RINGS SHOULD BE CLOSE TO THE TIMING OF THE WDT CIRCUIT. A MAXIMUM TIME OF 4 SECONDS IS PROVIDED BY THE CIRCUIT, BUT THE TEST ALLOWS APPROXIMATELY 8 SECONDS.

SEVERAL OF THE TESTS TEST THE INTERRUPTS. THEIR ERROR MESSAGES ARE SELF EXPLANATORY.

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

5.0 DEVICE INFORMATION TABLES

P-TABLE DEFINITION-

WORD 1- CSR ADDRESS
WORD 2- VECTOR ADDRESS
WORD 3- LOOKBACK CABLE INSTALLED (Y/N)
WORD 4- BR INTERRUPT PRIORITY LEVEL

6.0 TEST SUMMARIES

TEST1:
RESET

TEST2:
CHECK QMT1 REGISTER

TEST3:
CHECK QCLR RESET

TEST4:
CHECK QCMD LO BITS (MOVING 1)

TEST5:
CHECK QCMD LOW BITS (MOVING 0)

TEST6:
CHECK QCMD HI BITS (MOVING 1)

TEST7:
CHECK QCMD HI BITS (MOVING 0)

TEST8:
CHECK QVNT LO BITS (MOVING 1)

TEST9:
CHECK QVNT LOW BITS (MOVING 0)

TEST10:
CHECK QVNT HI BITS (MOVING 1)

TEST11:
CHECK QVNT HI BITS (MOVING 0)

TEST12:
CHECK ACK - PRS LINK

TEST13:
CHECK QBA (MOVING 1)

TEST14:
CHECK QBA (MOVING 0)

TEST15:
CHECK QDMA HI BITS (8-13) (MOVING 1)

TEST16:
CHECK QDMA HI BITS (8-13) (MOVING 0)

TEST17:
CHECK QDMA UXAD BITS

TEST18:
CHECK QUBA (MOVING 1)

TEST19:
CHECK QUBA (MOVING 0)

TEST20:
CHECK QWC (MOVING 1)

TEST21:
CHECK QWC (MOVING 0)

TEST22:
CHECK QVAD (Q-REGISTER) (MOVING 1)

TEST23:
CHECK QVAD (Q-REGISTER) (MOVING 0)

TEST24:
CHECK QVAD (U-REGISTER) (MOVING 1)

TEST25:
CHECK QVAD (U-REGISTER) (MOVING 0)

TEST26:
CHECK QVAD INCREMENT (Q-REGISTER)

TEST27:
CHECK QVAD INCREMENT (U-REGISTER)

TEST28:
CHECK VIEW REGISTER RAM

TEST29:
CHECK RAM ADDRESSING (ADDRESS VALUE)

TEST30:
CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)

TEST31:
CHECK QBA INCREMENT

TEST32:
CHECK QWC OVERFLOW (READ)

TEST33:
CHECK QWC OVERFLOW (WRITE)

TEST34:
DMA 1 WORD (WRITE)

TEST35:
DMA 1 WORD (READ)

TEST36:
DMA 1 WORD (WRITE)

TEST37:
CHECK WDTO TIME

TEST38:
CHECK WDTO RESET

TEST39:
CHECK VNTACK INTERRUPT

TEST40:
CHECK CMDPRS INTERRUPT

TEST41:
CHECK RDY INTERRUPT

TEST42:
CHECK ERR INTERRUPT (UNEX)

TEST43:
CHECK ERR INTERRUPT (QNEX)

TEST44:
CHECK ERR INTERRUPT (UPWRFL)

TEST45:
CHECK BR LEVEL

```

12      .TITLE CZFPA-AO CTRL BRIDGE INTFC DIAGNOSTIC
13      .SBITL PROGRAM HEADER
39
41 000000      .ENABL ABS,AMA
42      002000      = 2000
47
48 002000      BGNMOD
49
50
51      ;**
52      ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
53      ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
54      ;--
55 002000      POINTER BGNSETUP,BGNRPT
56
73
74 002000      HEADER CZFPA,A,0,8,,1
002000      L$NAME::      ;DIAGNOSTIC NAME
002000      103      .ASCII /C/
002001      132      .ASCII /Z/
002002      106      .ASCII /F/
002003      120      .ASCII /P/
002004      101      .ASCII /A/
002005      000      .BYTE 0
002006      000      .BYTE 0
002007      000      .BYTE 0
002010      L$REV::      ;REVISION LEVEL
002010      101      .ASCII /A/
002011      L$DEPO::      ;0
002011      060      .ASCII /O/
002012      L$UNIT::      ;NUMBER OF UNITS
002012      000001      .WORD T$PTHV
002014      L$TIML::      ;LONGEST TEST TIME
002014      000010      .WORD 8.
002016      L$HPCP::      ;PTR. TO H.W. QUES.
002016      041444      .WORD L$HARD
002020      L$SPCP::      ;PTR. TO S.W. QUES.
002020      000000      .WORD 0
002022      L$HPTP::      ;PTR. TO DEF. H.W. PTABLE
002022      002260      .WORD L$HW
002024      L$SPTP::      ;PTR. TO S.W. PTABLE
002024      000000      .WORD 0
002026      L$LADP::      ;DIAG. END ADDRESS
002026      042064      .WORD L$LAST
002030      L$STA::      ;RESERVED FOR APT STATS
002030      000000      .WORD 0
002032      L$CO::      .WORD 0
002032      000000      .WORD 0
002034      L$DTYP::      ;DIAGNOSTIC TYPE
002034      000001      .WORD 1
002036      L$APT::      ;APT EXPANSION
002036      000000      .WORD 0
002040      L$DTP::      ;PTR. TO DISPATCH TABLE
002040      002124      .WORD L$DISPATCH
002042      L$PRIO::      ;DIAGNOSTIC RUN PRIORITY
002042      000000      .WORD 0
002044      L$ENVI::      ;FLAGS DESCRIBE HOW IT WAS SETUP

```

PROGRAM HEADER

002044	000000			
002046		L\$EXP1::	.WORD 0	;EXPANSION WORD
002046	000000			
002050		L\$MREV::	.WORD 0	;SVC REV AND EDIT #
002050	003			
002051	003			
002052		L\$EF::	.BYTE C\$REVISION	
002052	000000			
002054	000000			
002056		L\$SPC::	.WORD 0	
002056	000000			
002060		L\$DEVP::	.WORD 0	;DIAG. EVENT FLAGS
002060	002554			
002062		L\$REPP::	.WORD 0	
002062	014446			
002064		L\$EXP4::	.WORD 0	
002064	000000			
002066		L\$EXP5::	.WORD 0	
002066	000000			
002070		L\$AUT::	.WORD 0	;PTR. TO ADD UNIT CODE
002070	000000			
002072		L\$DUT::	.WORD 0	;PTR. TO DROP UNIT CODE
002072	000000			
002074		L\$LUN::	.WORD 0	;LUN FOR EXERCISERS TO FILL
002074	000000			
002076		L\$DESP::	.WORD 0	;PTR. TO REPORT CODE
002076	002560			
002100		L\$LOAD::	.WORD 0	;PTR. TO REPORT CODE
002100	104035			
002102		L\$ETP::	.WORD 0	
002102	000000			
002104		L\$ICP::	.WORD 0	
002104	014466			
002106		L\$CCP::	.WORD 0	
002106	015044			
002110		L\$ACP::	.WORD 0	
002110	015040			
002112		L\$PRT::	.WORD 0	
002112	014460			
002114		L\$TEST::	.WORD 0	
002114	000000			
002116		L\$DLY::	.WORD 0	
002116	000000			
002120		L\$HIME::	.WORD 0	
002120	000000			

DISPATCH TABLE

87
88
89
90
91
92
93
94

002122	
002122	000055
002124	
002124	015152
002126	016050
002130	016302
002132	017012
002134	017320
002136	017644
002140	020140
002142	020456
002144	020760
002146	021304
002150	021600
002152	022104
002154	022502
002156	022756
002160	023266
002162	023616
002164	024174
002166	024576
002170	025062
002172	025360
002174	025634
002176	026142
002200	026444
002202	027006
002204	027322
002206	027652
002210	030064
002212	030334
002214	031570
002216	032452
002220	033306
002222	033620
002224	034062
002226	034362
002230	034674
002232	035226
002234	035702
002236	036420
002240	036646
002242	037126
002244	037404
002246	037704
002250	040260
002252	040620
002254	041152

95

.SBTTL DISPATCH TABLE

```

; **
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
; --

```

	DISPATCH 45
	.WORD 45
L#DISPATCH::	
	.WORD T1
	.WORD T2
	.WORD T3
	.WORD T4
	.WORD T5
	.WORD T6
	.WORD T7
	.WORD T8
	.WORD T9
	.WORD T10
	.WORD T11
	.WORD T12
	.WORD T13
	.WORD T14
	.WORD T15
	.WORD T16
	.WORD T17
	.WORD T18
	.WORD T19
	.WORD T20
	.WORD T21
	.WORD T22
	.WORD T23
	.WORD T24
	.WORD T25
	.WORD T26
	.WORD T27
	.WORD T28
	.WORD T29
	.WORD T30
	.WORD T31
	.WORD T32
	.WORD T33
	.WORD T34
	.WORD T35
	.WORD T36
	.WORD T37
	.WORD T38
	.WORD T39
	.WORD T40
	.WORD T41
	.WORD T42
	.WORD T43
	.WORD T44
	.WORD T45

DEFAULT HARDWARE P-TABLE

```

103          .SBTTL  DEFAULT HARDWARE P-TABLE
104
105          ;**
106          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
107          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
108          ; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES.
109          ; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
110          ;--
111
112 002256          BGNHW  DFPTBL
      002256 000004  .WORD  L10000-L$HW/2
      002260          L$HW::
      002260          DFPTBL::
113
114 002260 160500  .WORD  QCMDAD          ;HARDWARE UNIT 0 DEFAULT BASE ADDRESS
115 002262 000500  .WORD  VEC          ;HARDWARE UNIT 0 DEFAULT VECTOR
116 002264 000000  .WORD  NO          ;LOOPBACK CABLE INSTALLED DEFAULT
117 002266 000200  .WORD  †B00000000010000000 ;DEFAULT BR INTERRUPT LEVEL 4
127
128 002270          ENDHW
      002270          L10000:

```


SOFTWARE P-TABLE

131
132
133
134
135
136
137
138
139
140
148
149
150 002270

```
.SBTTL SOFTWARE P-TABLE  
; **  
; THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE  
; PROGRAM AS OPERATIONAL PARAMETERS. THESE PARAMETERS ARE  
; SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR  
; AT RUN TIME.  
; --  
; SOFTWARE TABLE NOT USED  
  
ENDMOD
```

E2

SOFTWARE P-TABLE

11
12
40
50
51 002270

.ENABL AMA
.SBTTL GLOBAL EQUATES SECTION

BGNMOD

MACRO DEFINITIONS

53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109

```
.SBTTL MACRO DEFINITIONS
;*****
;**
;          MACRO DEFINITION SECTION
;--
;*****

.MACRO INIT
.LIST
;INITIALIZE DEVICE
        MOV     @M0HALT,@QMT1           ;INITIALIZE Q-BRIDGE
        MOV     INITWORD,@QMT1        ;SET UP LOOPBACK OPTION
        CLR     @QINT                   ;CLEAR QINT AFTER LOOPBACK ENABLED
        CLR     ERROR1                 ;CLEAR ERROR FLAG

.NLIST
.ENDM

;
;          MACROS TO CALL BITS SUBROUTINE
;
;          MACRO SETBITS
;          USED TO CALL ROUTINE TO PRINT OUT REGISTER BIT NAMES
;
.MACRO SETBITS NAME, POINTER, VALUE
.NARG  TE#                               ;GET NUMBER OF ARGUMENTS PASSED
.IF NE TE#-3                             ;SEE IF RIGHT NUMBER
.ERROR ;SETBITS MACRO REQUIRES 3 PARAMETERS
.ENDC
.NCHR  $L1 NAME                          ;GET NUMBER OF CHARACTERS IN NAME PARAMETER
$L1 = $L1+1                               ;ALLOW FOR ZERO BYTE IN ASCIZ
$TEMP = $L1 & 1                           ;CHECK FOR ODD OR EVEN
.IF EQ $TEMP                              ;IF EVEN LENGTH OF NAME
$LEN = 4+$L1
.ENDC
.IF NE $TEMP                              ;IF ODD LENGTH OF NME
$LEN = 5+$L1
.ENDC
        MOV     VALUE,R1                 ;GET VALUE REGISTER TO READ
        JSR     R5,BIT$                 ;SUBROUTINE TO OUTPUT VALUES
        .WORD  $LEN
        .WORD  POINTER
        .ASCIZ /NAME/
        .EVEN

.ENDM

;
;          MACRO S$BITS
;          USED TO CALL ROUTINE TO FORMAT PRINT BUFFER OF REGISTER BIT NAMES
;
.MACRO S$BITS POINTER, VALUE
.NARG  TE#                               ;GET NUMBER OF ARGUMENTS PASSED
.IF NE TE#-2                             ;SEE IF RIGHT NUMBER
.ERROR ;S$BITS MACRO REQUIRES 2 PARAMETERS
.ENDC
        MOV     VALUE,R1                 ;GET VALUE REGISTER TO READ
        JSR     R5,BIT$                 ;SUBROUTINE TO OUTPUT VALUES
        .WORD  POINTER
        .EVEN

.ENDM
```

MACRO DEFINITIONS

```

111      ;
112      ; MACROS USED TO PRINT OUT THE TEST'S TITLE IF THE PNT FLAG IS SET
113      ;
114      .MACRO STATST P1
115      .MCALL PASTST
116      .IF EQ F$
117      .ERROR ;2 STATST MACRO'S WITHOUT CKPNT MACRO CALL IN BETWEEN
118      .MEXIT
119      .ENDC
120      F$ = 0
121      .RADIX 10
122      T$NUM = T$NUM+1
123      PASTST \T$NUM,<P1>
124      .RADIX 8
125      .ENDM
126      .MACRO PASTST Z,P2
127      .LIST
128      T'Z'MSG: .ASCIZ / P2/
129      .NLIST
130      .LIST MEB
131      .EVEN
132      .ENDM
133      .MACRO CKPNT
134      .MCALL PTPNT
135      .IF NE F$
136      .ERROR ;CKPNT MACRO MUST FOLLOW STATST MACRO, NOT ANOTHER CKPNT CALL
137      .MEXIT
138      .ENDC
139      .RADIX 10
140      F$ = 1
141      PTPNT \T$NUM
142      .RADIX 8
143      .ENDM
144      .MACRO PTPNT N,?A
145      RFLAGS RO ; READ CURRENT FLAGS
146      CMP #PNT,RO ; IS PNT FLAG SET?
147      BNE A ; BRANCH IF NOT SET
148      PRINTF #PNTMSG,#T'N'MSG ; PRINT MESSAGE IF PNT SET
149      CLR ERROR1 ; CLEAR ERROR COUNTER
150      .ENDM
151      .ENDM PNTMSG: .ASCIZ /#T/
152      T$NUM = 0
153      F$ = 1

```

```

002270      045      124      000
000000
000001

```

MACRO DEFINITIONS

155
156
157
158
159
160
161
162
163
164
165
166
167
168
169 002273

170
171
172
173 002273

174
175 002273

```

;
;MACRO TO INTERFACE WITH $HLP DUMP HELP FILE SUBROUTINE
;
.MACRO HLPMAC N
.LIST MEB
.NCHR $SYM,N
      JSR      R5,$HLP          ;JUMP TO SUBROUTINE
      .ASCII  /N/              ;NAME OF FILE
      $TEMP = 10.-$SYM
      .REPT  $TEMP
      .BYTE  0
      .ENDR
.ENDM

STARS
;*****
;*
;*          GLOBAL EQUATE SECTION
;*
STARS
;*****

EQUALS
;
; BIT DIFINITIONS
;
100000 BIT15-- 100000
040000 BIT14-- 40000
020000 BIT13-- 20000
010000 BIT12-- 10000
004000 BIT11-- 4000
002000 BIT10-- 2000
001000 BIT09-- 1000
000400 BIT08-- 400
000200 BIT07-- 200
000100 BIT06-- 100
000040 BIT05-- 40
000020 BIT04-- 20
000010 BIT03-- 10
000004 BIT02-- 4
000002 BIT01-- 2
000001 BIT00-- 1

001000 BIT9-- BIT09
000400 BIT8-- BIT08
000200 BIT7-- BIT07
000100 BIT6-- BIT06
000040 BIT5-- BIT05
000020 BIT4-- BIT04
000010 BIT3-- BIT03
000004 BIT2-- BIT02
000002 BIT1-- BIT01
000001 BIT0-- BIT00

;
; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;

```

MACRO DEFINITIONS

```

000040 EF.START== 32. ; START COMMAND WAS ISSUED
000037 EF.RESTART== 31. ; RESTART COMMAND WAS ISSUED
000036 EF.CONTINUE== 30. ; CONTINUE COMMAND WAS ISSUED
000035 EF.NEW== 29. ; A NEW PASS HAS BEEN STARTED
000034 EF.PWR== 28. ; A POWER-FAIL/POWER-UP OCCURRED
;
;
; PRIORITY LEVEL DEFINITIONS
;
000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0
;
; OPERATOR FLAG BITS
;
000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
000040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000
020000 IER== 20000
040000 LOE== 40000
100000 HOE== 100000
;
; STANDARD REGISTER BASE ADDRESS CONFIGURATION
;
160500 QCMDAD == 160500 ; STANDARD BASE ADDRESS FOR UNIT 0
000500 VEC == 500 ; STANDARD VECTOR ADDRESS FOR UNIT 0
;
; BIT DEFINITIONS
;
; QCMD - Q-BUS COMMAND REGISTER
;
000001 CMDACK == BIT00 ; NO COMMAND ACKNOWLEDGE
000100 PRSIE == BIT06 ; R/W INTERRUPT ENABLE
;
; QVNT - Q-BUS EVENT REGISTER
;
000001 VNTPRS == BIT00 ; NO EVENT PRESENT
000100 ACKIE == BIT06 ; R/W INTERRUPT ENABLE
;
; QINT - Q-BUS INTERRUPT SUMMARY REGISTER
;
000100 ERRIE == BIT06 ; R/W INTERRUPT ENABLE
001000 MRDY == BIT09 ; RO MIRROR OF QDMA-07, READY

```

176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198

MACRO DEFINITIONS

```

199      002000      VNTACK  -- BIT10      ; RO EVENT ACKNOWLEDGE
200      004000      CMDPRS  -- BIT11      ; RO COMMAND PRESENT
201      010000      UPWRFL  -- BIT12      ; RO UNIBUS POWER FAIL
202      020000      QNEX    -- BIT13      ; RO Q-BUS NON EXISTENT MEMORY ADDRESS
203      040000      UNEX    -- BIT14      ; RO UNIBUS NON EXISTENT MEMORY ADDRESS
204      100000      ERR      -- BIT15      ; RO ERROR
205      ;
206      ;          QCTL - Q-BUS CONTROL REGISTER
207      ;
208      000001      WDTRST  -- BIT00      ; WO WATCHDOG TIMER RESET
209      000002      TMRENB  -- BIT01      ; R/W TIMER ENABLE
210      000004      WDT0    -- BIT02      ; WO WATCHDOG TIMER TIME-OUT BIT (1 OF 2)
211      000010      WDT1    -- BIT03      ; WO WATCHDOG TIMER TIME-OUT BIT (2 OF 2)
212      000020      QVREN  -- BIT04      ; Q-VIEW READ ENABLE
213      000000      TIME.5  -- 0          ; 1/2 SEC TIME CODE
214      000004      TIME1   -- WDT0      ; 1 SEC TIME CODE
215      000010      TIME2   -- WDT1      ; 2 SEC TIME CODE
216      000014      TIME4   -- WDT0!WDT1 ; 4 SEC TIME CODE
217      ;
218      ;
219      ;          QDMA - Q-BUS DMA CONTROL AND STATUS REGISTER
220      ;
221      000001      GO       -- BIT00      ; WO INITIATES DMA TRANSFER
222      000002      DMAWT   -- BIT01      ; R/W DIRECTION FLOW OF DMA
223      000020      UXAD16  -- BIT04      ; R/W UNIBUS EXTENDED ADDRESS BIT 16
224      000040      UXAD17  -- BIT05      ; R/W UNIBUS EXTENDED ADDRESS BIT 17
225      000100      RDYIE   -- BIT06      ; R/W INTERRUPT ENABLE
226      000200      RDY     -- BIT07      ; RO READY (CLEARED BY GO)
227      000400      QXAD16  -- BIT08      ; R/W Q-BUS EXTENDED ADDRESS BIT 16
228      001000      QXAD17  -- BIT09      ; R/W Q-BUS EXTENDED ADDRESS BIT 17
229      002000      QXAD18  -- BIT10      ; R/W Q-BUS EXTENDED ADDRESS BIT 18
230      004000      QXAD19  -- BIT11      ; R/W Q-BUS EXTENDED ADDRESS BIT 19
231      010000      QXAD20  -- BIT12      ; R/W Q-BUS EXTENDED ADDRESS BIT 20
232      020000      QXAD21  -- BIT13      ; R/W Q-BUS EXTENDED ADDRESS BIT 21
233      ;
234      ;          QUBA - Q-BUS - UNIBUS BUS ADDRESS REGISTER
235      ;
236      000001      QUBA00  -- BIT00      ; WO UNIBUS TRANSFER ADDRESS BIT 00
237      000002      QUBA01  -- BIT01      ; WO UNIBUS TRANSFER ADDRESS BIT 01
238      000004      QUBA02  -- BIT02      ; WO UNIBUS TRANSFER ADDRESS BIT 02
239      000010      QUBA03  -- BIT03      ; WO UNIBUS TRANSFER ADDRESS BIT 03
240      000020      QUBA04  -- BIT04      ; WO UNIBUS TRANSFER ADDRESS BIT 04
241      000040      QUBA05  -- BIT05      ; WO UNIBUS TRANSFER ADDRESS BIT 05
242      000100      QUBA06  -- BIT06      ; WO UNIBUS TRANSFER ADDRESS BIT 06
243      000200      QUBA07  -- BIT07      ; WO UNIBUS TRANSFER ADDRESS BIT 07
244      000400      QUBA08  -- BIT08      ; WO UNIBUS TRANSFER ADDRESS BIT 08
245      001000      QUBA09  -- BIT09      ; WO UNIBUS TRANSFER ADDRESS BIT 09
246      002000      QUBA10  -- BIT10      ; WO UNIBUS TRANSFER ADDRESS BIT 10
247      004000      QUBA11  -- BIT11      ; WO UNIBUS TRANSFER ADDRESS BIT 11
248      010000      QUBA12  -- BIT12      ; WO UNIBUS TRANSFER ADDRESS BIT 12
249      020000      QUBA13  -- BIT13      ; WO UNIBUS TRANSFER ADDRESS BIT 13
250      040000      QUBA14  -- BIT14      ; WO UNIBUS TRANSFER ADDRESS BIT 14
251      100000      QUBA15  -- BIT15      ; WO UNIBUS TRANSFER ADDRESS BIT 15
252      ;
253      ;          QBA - BUS ADDRESS REGISTER
254      ;
255      000001      QBA00   -- BIT00      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 00
    
```

MACRO DEFINITIONS

```

256      000002      QBA01      -- BIT01      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 01
257      000004      QBA02      -- BIT02      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 02
258      000010      QBA03      -- BIT03      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 03
259      000020      QBA04      -- BIT04      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 04
260      000040      QBA05      -- BIT05      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 05
261      000100      QBA06      -- BIT06      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 06
262      000200      QBA07      -- BIT07      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 07
263      000400      QBA08      -- BIT08      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 08
264      001000      QBA09      -- BIT09      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 09
265      002000      QBA10      -- BIT10      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 10
266      004000      QBA11      -- BIT11      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 11
267      010000      QBA12      -- BIT12      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 12
268      020000      QBA13      -- BIT13      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 13
269      040000      QBA14      -- BIT14      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 14
270      100000      QBA15      -- BIT15      ; R/W Q-BUS BUS ADDRESS REGISTER BIT 15
271      ;
272      ;
273      ;
274      000001      QWC00      -- BIT00      ; R/W DMA WORD COUNT REGISTER BIT00
275      000002      QWC01      -- BIT01      ; R/W DMA WORD COUNT REGISTER BIT01
276      000004      QWC02      -- BIT02      ; R/W DMA WORD COUNT REGISTER BIT02
277      000010      QWC03      -- BIT03      ; R/W DMA WORD COUNT REGISTER BIT03
278      000020      QWC04      -- BIT04      ; R/W DMA WORD COUNT REGISTER BIT04
279      000040      QWC05      -- BIT05      ; R/W DMA WORD COUNT REGISTER BIT05
280      000100      QWC06      -- BIT06      ; R/W DMA WORD COUNT REGISTER BIT06
281      000200      QWC07      -- BIT07      ; R/W DMA WORD COUNT REGISTER BIT07
282      000400      QWC08      -- BIT08      ; R/W DMA WORD COUNT REGISTER BIT08
283      001000      QWC09      -- BIT09      ; R/W DMA WORD COUNT REGISTER BIT09
284      002000      QWC10      -- BIT10      ; R/W DMA WORD COUNT REGISTER BIT10
285      004000      QWC11      -- BIT11      ; R/W DMA WORD COUNT REGISTER BIT11
286      010000      QWC12      -- BIT12      ; R/W DMA WORD COUNT REGISTER BIT12
287      020000      QWC13      -- BIT13      ; R/W DMA WORD COUNT REGISTER BIT13
288      040000      QWC14      -- BIT14      ; R/W DMA WORD COUNT REGISTER BIT14
289      100000      QWC15      -- BIT15      ; R/W DMA WORD COUNT REGISTER BIT15
290      ;
291      ;
292      ;
293      000002      MVADR      -- BIT01      ; R/W MAINTENANCE VIEW ADDRESS
294      000004      FUNC0      -- BIT02      ; R/W SELECT MAINTENANCE MODE BIT 02 FOR QMTO
295      000010      FUNC1      -- BIT03      ; R/W SELECT MAINTENANCE MODE BIT 03 FOR QMTO
296      000020      FUNC2      -- BIT04      ; R/W SELECT MAINTENANCE MODE BIT 04 FOR QMTO
297      000040      MQPFL      -- BIT05      ; R/W MAINTENANCE Q-BUS POWER FAIL
298      000100      MQHALT     -- BIT06      ; WO MAINTENANCE Q-BUS HALT
299      000200      MIODIS     -- BIT07      ; R/W MAINTENANCE I/O DISABLE
300      ;
301      ;
302      ;
303      000001      QVAD00     -- BIT00      ; R/W Q-BUS VIEW ADDRESS REG. BIT 00
304      000002      QVAD01     -- BIT01      ; R/W Q-BUS VIEW ADDRESS REG. BIT 01
305      000004      QVAD02     -- BIT02      ; R/W Q-BUS VIEW ADDRESS REG. BIT 02
306      000010      QVAD03     -- BIT03      ; R/W Q-BUS VIEW ADDRESS REG. BIT 03
307      000020      QVAD04     -- BIT04      ; R/W Q-BUS VIEW ADDRESS REG. BIT 04
308      000040      QVAD05     -- BIT05      ; R/W Q-BUS VIEW ADDRESS REG. BIT 05
309      000100      QVAD06     -- BIT06      ; R/W Q-BUS VIEW ADDRESS REG. BIT 06
310      000200      QVAD07     -- BIT07      ; R/W Q-BUS VIEW ADDRESS REG. BIT 07
311      000400      QVAD08     -- BIT08      ; R/W Q-BUS VIEW ADDRESS REG. BIT 08
312      001000      QVAD09     -- BIT09      ; R/W Q-BUS VIEW ADDRESS REG. BIT 09

```


MACRO DEFINITIONS

```

313      002000      QVAD10  == BIT10      ; R/W Q-BUS VIEW ADDRESS REG. BIT 10
314      ;
315      ;          QVDA - Q-BUS VIEW DATA REGISTER
316      ;
317      000001      QVDA00  == BIT00      ; R/W Q-BUS VIEW DATA REG. BIT00
318      000002      QVDA01  == BIT01      ; R/W Q-BUS VIEW DATA REG. BIT01
319      000004      QVDA02  == BIT02      ; R/W Q-BUS VIEW DATA REG. BIT02
320      000010      QVDA03  == BIT03      ; R/W Q-BUS VIEW DATA REG. BIT03
321      000020      QVDA04  == BIT04      ; R/W Q-BUS VIEW DATA REG. BIT04
322      000040      QVDA05  == BIT05      ; R/W Q-BUS VIEW DATA REG. BIT05
323      000100      QVDA06  == BIT06      ; R/W Q-BUS VIEW DATA REG. BIT06
324      000200      QVDA07  == BIT07      ; R/W Q-BUS VIEW DATA REG. BIT07
325      000400      QVDA08  == BIT08      ; R/W Q-BUS VIEW DATA REG. BIT08
326      001000      QVDA09  == BIT09      ; R/W Q-BUS VIEW DATA REG. BIT09
327      002000      QVDA10  == BIT10      ; R/W Q-BUS VIEW DATA REG. BIT10
328      004000      QVDA11  == BIT11      ; R/W Q-BUS VIEW DATA REG. BIT11
329      010000      QVDA12  == BIT12      ; R/W Q-BUS VIEW DATA REG. BIT12
330      020000      QVDA13  == BIT13      ; R/W Q-BUS VIEW DATA REG. BIT13
331      040000      QVDA14  == BIT14      ; R/W Q-BUS VIEW DATA REG. BIT14
332      100000      QVDA15  == BIT15      ; R/W Q-BUS VIEW DATA REG. BIT15
333      ;
334      ;          MAINTENANCE FUNCTION, BIT IN QMT1 TO DEFINE USE OF QMTO
335      ;
336      ;
337      000004      SELQEVT  == 000004      ; SELECT QEVENT
338      000010      SELQCMD  == 000010      ; SELECT QCMD
339      000014      SELUVADR  == 000014      ; SELECT UVADR
340      000020      SELUBAR  == 000020      ; SELECT UBAR
341      000024      SELDMADAT == 000024      ; SELECT DMADAT
342      000030      SELUVDAT  == 000030      ; SELECT UVDAT
343      000034      SELRDDMA  == 000034      ; SELECT DMA READ
344      ;
345      ;          MEMORY MANAGEMENT MAPPING ADDRESSES
346      ;
347      ;
348      177572      MMR0      == 177572
349      172516      MMR3      == 172516
350      172300      KISDRO    == 172300
351      172340      KISARO    == 172340
352      170370      HIUBM     == 170370
353      ;
354      ;          MISC. EQUATES
355      ;
356      ;
357      000010      MAXUNITS  == 8.          ; MAXIMUM NUMBER OF UNITS ALLOWED
358      000000      NO        == 0          ; LOGICAL VALUE FOR NO
359      000001      YES       == 1          ; LOGICAL VALUE FOR YES
360      020040      WSPACE    == 20040      ; WORD OF ASCII SPACES
361
362
377
    
```

GLOBAL DATA SECTION

```

379          .SBTTL  GLOBAL DATA SECTION
380
381 002273    STARS
              ;*****
382          ;*
383          ;*   GLOBAL DATA SECTION
384          ;*
385 002273    STARS
              ;*****
386
387          ;
388          ; CURRENT UNIT Q-BUS BRIDGE INTERFACE REGISTERS ADDRESSES ARE STORED HERE
389          ;
390          .EVEN
391 002274    ADDRESSES::
392 002274    000000    QCMD::          .WORD  0          ; Q-BUS COMMAND REGISTER
393 002276    000000    QVNT::          .WORD  0          ; Q-BUS EVENT REGISTER
394 002300    000000    QINT::          .WORD  0          ; Q-BUS INTERRUPT SUMMARY REGISTER
395 002302    000000    QCTL::          .WORD  0          ; Q-BUS CONTROL REGISTER
396 002304    000000    QDMA::          .WORD  0          ; Q-BUS DMA CONTROL & STATUS REGISTER
397 002306    000000    QUBA::          .WORD  0          ; Q-BUS BUS ADDRESS UNIBUS REGISTER
398 002310    000000    QBA::          .WORD  0          ; Q-BUS BUS ADDRESS Q-BUS REGISTER
399 002312    000000    QWC::          .WORD  0          ; Q-BUS WORD COUNT REGISTER
400 002314    000000    QMT0::          .WORD  0          ; Q-BUS MAINTENANCE REGISTER 0
401 002316    000000    QMT1::          .WORD  0          ; Q-BUS MAINTENANCE REGISTER 1
402 002320    000000    QVAD::          .WORD  0          ; Q-BUS VIEW ADDRESS REGISTER
403 002322    000000    QVDA::          .WORD  0          ; Q-BUS DATA REGISTER
404
405          ;
406          ; CURRENT UNIT Q-BUS BRIDGE INTERFACE REGISTERS VALUES ARE STORED HERE
407          ;
408 002324    VALUES::
409 002324    000000    SQCMD::          .WORD  0          ; COMMAND REGISTER
410 002326    000000    SQVNT::          .WORD  0          ; EVENT REGISTER
411 002330    000000    SQINT::          .WORD  0          ; INTERRUPT SUMMARY REGISTER
412 002332    000000    SQCTL::          .WORD  0          ; CONTROL REGISTER
413 002334    000000    SQDMA::          .WORD  0          ; DMA CONTROL & STATUS REGISTER
414 002336    000000    SQUBA::          .WORD  0          ; BUS ADDRESS UNIBUS REGISTER
415 002340    000000    SQBA::          .WORD  0          ; BUS ADDRESS REGISTER
416 002342    000000    SQWC::          .WORD  0          ; WORD COUNT REGISTER
417 002344    000000    SQMT0::          .WORD  0          ; MAINTENANCE REGISTER 0
418 002346    000000    SQMT1::          .WORD  0          ; MAINTENANCE REGISTER 1
419 002350    000000    SQVAD::          .WORD  0          ; VIEW ADDRESS REGISTER
420 002352    000000    SQVDA::          .WORD  0          ; DATA REGISTER
421
422 002354    EXPECTED::
423 002354    000000    EXQCMD::          .WORD  0          ; USED FOR TABLE PROCESSING OF EXPECTED RESULTS
424 002356    000000    EXQVNT::          .WORD  0          ; COMMAND REGISTER
425 002360    000000    EXQINT::          .WORD  0          ; EVENT REGISTER
426 002362    000000    EXQCTL::          .WORD  0          ; INTERRUPT SUMMARY REGISTER
427 002364    000000    EXQDMA::          .WORD  0          ; CONTROL REGISTER
428 002366    000000    EXQUBA::          .WORD  0          ; DMA CONTROL & STATUS REGISTER
429 002370    000000    EXQBA::          .WORD  0          ; BUS ADDRESS UNIBUS REGISTER
430 002372    000000    EXQWC::          .WORD  0          ; BUS ADDRESS REGISTER
431 002374    000000    EXQMT0::          .WORD  0          ; WORD COUNT REGISTER
432 002376    000000    EXQMT1::          .WORD  0          ; MAINTENANCE REGISTER 0
433 002400    000000    EXQVAD::          .WORD  0          ; MAINTENANCE REGISTER 1
              ; VIEW ADDRESS REGISTER

```

GLOBAL DATA SECTION

```

434 002402 000000          EXQVDA::          .WORD 0          ; DATA REGISTER
435
436
437          ;
438          ;Q-BRIDGE REGISTER NAMES ARE STORED HERE. ACCESS IS INDEXED, EACH TAKING 2 WORDS
439          ;
440 002404      121      103      115 NAMES:: .EVEN .ASCIZ /QCMD/
         002407      104      000
441 002411      121      126      116          .ASCIZ /QVNT/
         002414      124      000
442 002416      121      111      116          .ASCIZ /QINT/
         002421      124      000
443 002423      121      103      124          .ASCIZ /QCTL/
         002426      114      000
444 002430      121      104      115          .ASCIZ /QDMA/
         002433      101      000
445 002435      121      125      102          .ASCIZ /QUBA/
         002440      101      000
446 002442      121      102      101          .ASCIZ /QBA /
         002445      040      000
447 002447      121      127      103          .ASCIZ /QWC /
         002452      040      000
448 002454      121      115      124          .ASCIZ /QMT0/
         002457      060      000
449 002461      121      115      124          .ASCIZ /QMT1/
         002464      061      000
450 002466      121      126      101          .ASCIZ /QVAD/
         002471      104      000
451 002473      121      126      104          .ASCIZ /QVDA/
         002476      101      000
452          .EVEN
453
454          ;
455          ; MISC STORAGE AREAS
456          ;
457
458 002500 000000 BRIDGETYPE:: .WORD 0 ;BRIDGE TYPE (0=Q-BRIDGE 1=U-BRIDGE)
459 002502 000000 BRDGFLG:: .WORD 0 ;BRIDGE CONFIGURED FLAG
460 002504 000000 LOGUNIT:: .WORD 0 ;USED TO STORE CURRENT LOGICAL UNIT
461 002506 000000 PLOC:: .WORD 0 ;POINTER TO CURRENT HARDWARE P-TABLE
462 002510 000000 BASEADD:: .WORD 0 ;STORES BASE ADDRESS
463 002512 000000 VECTOR:: .WORD 0 ;STORES VECTOR ADDRESS
464 002514 000000 LOOPBK:: .WORD 0 ;STORES SOFTWARE LOOPBACK QUES. VALUE FOR CURRENT UNIT
465 002516 000000 BRLEVEL:: .WORD 0 ;STORES BR LEVEL
466 002520 000000 INITWORD:: .WORD 0 ;STORES INITIALIZE WORD SENT TO QMT1
467 002522 000000 TRPFLG:: .WORD 0 ;TRAP FLAG INDICATOR
468 002524 000000 ADD:: .WORD 0 ;STORES ADDRESS OF REGISTER FOR MESSAGES
469 002526 000000 VAL:: .WORD 0 ;STORES VALUE OF REGISTER FOR MESSAGES
470 002530 000000 EXP:: .WORD 0 ;STORES EXPECTED VALUE OF TEST FOR MESSAGES
471 002532 000000 ERROR1:: .WORD 0 ;STORES ERROR COUNTS
472 002534 000000 ERROR2:: .WORD 0 ;STORES ERROR COUNTS
473 002536 000000 RAM:: .WORD 0 ;TELLS WHETHER RAM MESSAGE WAS PRINTED OUT
474 002540 000000 VALUE:: .WORD 0 ;STORES CURRENT CPU PRIORITY LEVEL
475 002542 000000 INTFLG:: .WORD 0 ;INTERRUPT FLAG
476 002544 000000 HP1:: .WORD 0 ;TELLS WHETHER DRS HELP MESSAGE ALREADY PRINTED
477 002546 000000 HP2:: .WORD 0 ;TELLS WHETHER DIA HELP MESSAGE ALREADY PRINTED
478 002550 000000 MEMSIZ:: .WORD 0 ;STORE FREE MEMORY SIZE IN WORDS ABOVE DIAGNOSTIC

```

B3

CZFPA-A0 CTRL BRIDGE INTFC DIAG MACRO M1200 09 JAN-84 12:33 PAGE 19-2

SEQ 0027

GLOBAL DATA SECTION

479 002552 000000
480

FREMEM:: .WORD 0 ;POINTS TO STARTING ADDRESS OF FREE MEMORY

GLOBAL TEXT SECTION

```

482          .SBTTL GLOBAL TEXT SECTION
483
484          ;**
485          ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
486          ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
487          ; MORE THAN ONE TEST.
488          ;--
489
490          ;
491          ; NAMES OF DEVICES SUPPORTED BY PROGRAM
492          ;
493 002554          DEVTYP <FEP>
002554          L$DVTYP::
002554          106    105    120    .ASCIZ /FEP/
002557          .EVEN
494
495          ; TEST DESCRIPTION
496          ;
497          ;
498 002560          DESCRIPT    <COMMAND BRIDGE INTERFACE DIAGNOSTIC>
002560          L$DESC::
002560          103    117    115    .ASCIZ /COMMAND BRIDGE INTERFACE DIAGNOSTIC/
002563          115    101    116
002566          104    040    102
002571          122    111    104
002574          107    105    040
002577          111    116    124
002602          105    122    106
002605          101    103    105
002610          040    104    111
002613          101    107    116
002616          117    123    124
002621          111    103    000
499          .EVEN
          .EVEN

```

GLOBAL TEXT SECTION

```

501      .NLIST BEX
502      ;
503      ; BIT NAMES IN THE REGISTERS
504      ;
505 002624 054 054 054 CMDBIT:: .ASCIZ /.....PRsie,.....CMDACK/
506 002657 054 054 054 VNTBIT:: .ASCIZ /.....ACKIE,.....VNTPRS/
507 002712 105 122 122 INTBIT:: .ASCIZ /ERR,UNEX,QNEX,UPWRFL,CMDPRS,VNTACK,RDY,,,ERRIE/
508 002771 054 054 054 CTLBIT:: .ASCIZ /.....QVREN,WDT1,WDT0,THRENB,WDRST/
509 003042 054 054 121 DMABIT:: .ASCII /,,QXAD21,QXAD20,QXAD19,QXAD18,QXAD17,QXAD16,RDY,RDYIE/
510 003127 054 125 130 .ASCIZ /,UXAD17,UXAD16,,,DMAWT,GO/
511 003161 054 054 054 MT1BIT:: .ASCIZ /.....MIODIS,MQHLT,MQPFL,FUNC2,FUNC1,FUNCO,MVADR/
512
513 003244 STARS
;*****
;
; FORMAT STATEMENTS USED IN PRINT CALLS
;
; STARS
;*****
514
515
516
517 003244 STARS
;*****
518
519      ;.IF NDF ONEFILE
520      .NLIST BEX
521      ;.ENDC
522
523 003244 045 116 061 CONFIG:: .ASCIZ /#N1#CONFIGURED FOR #T#A BRIDGE MODULE#N1/
524 003316 121 055 102 QBUS:: .ASCIZ /Q-BUS/
525 003324 125 116 111 UBUS:: .ASCIZ /UNIBUS/
526
527 003333 045 116 061 FOR0:: .ASCIZ /#N1/ ;LINE FEED CARRIAGE RETURN ONLY
528 003337 045 116 061 FOR1:: .ASCIZ /#N1#ANAME#S4#ADDRESS#S4#CONTENTS#S4#EXPECTED (UNDETERMINED BITS ARE ZERO
) /
529 003454 045 116 061 FOR2:: .ASCIZ /#N1#T#S5#O6#S5#O6#S6#O6/
530 003504 045 124 045 FOR3:: .ASCIZ /#T#A REGISTER AT #O6#A CANNOT BE READ/
531 003552 045 116 061 FOR4:: .ASCIZ /#N1#S4#O4#S9#O6#S7#O6/
532 003600 FOR4.5::
533 003600 045 116 061 .ASCIZ /#N1#UNKNOWN VIEW RAM SIZE, 1K ASSUMED FOR REST OF TEST/
534 003670 045 116 061 FOR5:: .ASCIZ /#N1#AQVAD Q RAM ADDRESS INCREMENT SHOULD BE #O4#A WAS #O4/
535 003762 FOR5.5::
536 003762 045 116 061 .ASCIZ /#N1#AQVAD U RAM ADDRESS INCREMENT SHOULD BE #O4#A WAS #O4/
537 004054 045 116 061 FOR6:: .ASCIZ /#N1#TOTAL RAM CHECK ERRORS #D5/
538 004114 045 116 061 FOR7:: .ASCIZ /#N1#TOTAL INCREMENT ERRORS #D5/
539 004154 045 116 061 FOR8:: .ASCIZ /#N1#ARAM ADDRESS CONTENTS EXPECTED/
540 004227 045 116 061 FOR9:: .ASCIZ /#N1#AVIEW RAM SIZE #D1#AK/
541 004261 045 116 061 FOR10:: .ASCIZ /#N1#ASHOULD BE #O6#A, WAS #O6#A LOOP #D3#A OUT OF 100#N1/
542 004353 045 116 061 FOR11:: .ASCIZ /#N1#ATEST 37: BELL WILL RING EACH TIME WDT0 OCCURS (20 TIMES /
543 004450 124 117 124 .ASCIZ /TOTAL)#N1/
544 004462 045 101 007 FOR12:: .ASCIZ /#A/<7>
545 004466 045 116 045 FOR13:: .ASCIZ /#N#ABR LEVEL #O1#A CPU PRIORITY LEVEL #O1#N1/
546      .EVEN

```

GLOBAL TEXT SECTION

```

548 004544 STARS
549          ;:*****
550          ;
551          ; ASCII MESSAGES USED IN ERROR REPORTING
552 004544 STARS
553          ;:*****
554
555 004544 102 122 111 MSG1:: .ASCIZ /BRIDGE REGISTER DUMP/
556 004571 102 101 104 MSG2:: .ASCIZ /BAD ADDRESS ERROR - PASS ABORTED/
557 004632 122 105 107 MSG3:: .ASCIZ /REGISTER READ AFTER RESET ERROR/
558 004672 114 117 101 MSG4:: .ASCIZ /LOAD WITH ONE'S AND READ ERROR/
559 004731 114 117 101 MSG5:: .ASCIZ /LOAD WITH ZERO'S AND READ ERROR/
560 004771 121 103 114 MSG6:: .ASCIZ /QCLR RESET ERROR/
561 005012 121 103 115 MSG7:: .ASCIZ /QCMD ROTATING 1 IN BITS 1-5 ERROR/
562 005054 121 103 115 MSG8:: .ASCIZ /QCMD ROTATING 0 IN BITS 1-5 ERROR/
563 005116 121 103 115 MSG9:: .ASCIZ /QCMD ROTATING 1 IN BITS 8-15 ERROR/
564 005161 121 103 115 MSG10:: .ASCIZ /QCMD ROTATING 0 IN BITS 8-15 ERROR/
565 005224 121 126 116 MSG11:: .ASCIZ /QVNT ROTATING 1 IN BITS 1-5 ERROR/
566 005266 121 126 116 MSG12:: .ASCIZ /QVNT ROTATING 0 IN BITS 1-5 ERROR/
567 005330 121 126 116 MSG13:: .ASCIZ /QVNT ROTATING 1 IN BITS 8-15 ERROR/
568 005373 121 126 116 MSG14:: .ASCIZ /QVNT ROTATING 0 IN BITS 8-15 ERROR/
569 005436 121 111 116 MSG15:: .ASCIZ /QINT BIT 11 (CMDPRS) SHOULD BE CLEAR AFTER SET QCMD CMDACK/
570 005531 121 111 116 MSG16:: .ASCIZ /QINT BIT 10 (VNTACK) SHOULD BE SET AFTER SET QCMD CMDACK/
571 005622 121 111 116 MSG17:: .ASCIZ /QINT BIT 10 (VNTACK) SHOULD BE CLEAR AFTER SET QVNT VNTPRS/
572 005715 121 111 116 MSG18:: .ASCIZ /QINT BIT 11 (CMDPRS) SHOULD BE SET AFTER SET QVNT VNTPRS/
573 006006 121 102 101 MSG19:: .ASCIZ /QBA ROTATING 1 ERROR/
574 006033 121 102 101 MSG20:: .ASCIZ /QBA ROTATING 0 ERROR/
575 006060 121 104 115 MSG21:: .ASCIZ /QDMA HI BITS (8-13) ROTATING 1 ERROR/
576 006125 121 104 115 MSG22:: .ASCIZ /QDMA HI BITS (8-13) ROTATING 0 ERROR/
577 006172 121 104 115 MSG23:: .ASCIZ /QDMA EXTENDED ADDRESS BITS 4 & 5 ERROR/
578 006241 121 125 102 MSG24:: .ASCIZ /QUBA ROTATING 1 ERROR/
579 006267 121 125 102 MSG25:: .ASCIZ /QUBA ROTATING 0 ERROR/
580 006315 121 127 103 MSG26:: .ASCIZ /QMC ROTATING 1 ERROR/
581 006342 121 127 103 MSG27:: .ASCIZ /QMC ROTATING 0 ERROR/
582 006367 121 126 101 MSG28:: .ASCIZ /QVAD Q-REGISTER ROTATING 1 ERROR/
583 006430 121 126 101 MSG29:: .ASCIZ /QVAD Q-REGISTER ROTATING 0 ERROR/
584 006471 121 126 101 MSG30:: .ASCIZ /QVAD U-REGISTER ROTATING 1 ERROR/
585 006532 121 126 101 MSG31:: .ASCIZ /QVAD U-REGISTER ROTATING 0 ERROR/
586 006573 121 126 101 MSG32:: .ASCIZ /QVAD Q-REGISTER INCREMENT ERROR/
587 006633 121 126 101 MSG33:: .ASCIZ /QVAD U-REGISTER INCREMENT ERROR/
588 006673 121 126 104 MSG34:: .ASCIZ /QVDA VIEW REGISTER RAM CHECK ERROR/
589 006736 121 126 101 MSG35:: .ASCIZ /QVAD RAM ADDRESS INCREMENT ERROR/
590 006777 121 102 101 MSG36:: .ASCIZ /QBA INCREMENT ERROR/
591 007023 MSG36.5::
592 007023 121 104 115 .ASCIZ /QDMA INCREMENT BITS 8-13 EXTENDED ADDRESS ERROR/
593 007103 121 104 115 MSG37:: .ASCIZ /QDMA RDY BIT 7 SHOULD BE CLEARED AFTER SET QDMA GO BIT/
594 007172 121 127 103 MSG38:: .ASCIZ /QMC SHOULD HAVE INCREMENTED AFTER SET QDMA GO BIT/
595 007254 121 104 115 MSG39:: .ASCIZ /QDMA RDY BIT 7 SHOULD BE SET AFTER SET QDMA GO BIT/
596 007337 121 127 103 MSG40:: .ASCIZ /QMC INCREMENT AFTER QDMA DMAWT AND GO BIT SET ERROR/
597 007423 121 104 115 MSG41:: .ASCIZ /QDMA RDY BIT 7 SHOULD BE SET AFTER QDMA DMAWA AND GO BIT SET/
598 007520 104 115 101 MSG42:: .ASCIZ /DMA WRITE DATA TRANSFER ERROR/
599 007556 104 115 101 MSG42.5:: .ASCIZ /DMA WRITE HI MEMORY DATA TRANSFER ERROR/
600 007626 104 115 101 MSG43:: .ASCIZ /DMA READ DATA TRANSFER ERROR/
601 007663 127 101 124 MSG44:: .ASCIZ /WATCH DOG TIMER READ AFTER WRITE TIME CODE BITS 2 & 3 ERROR/
602 007756 015 012 124 .ASCIZ <15><12>/TEST ABORTED/

```

GLOBAL TEXT SECTION

603	007775	127	101	124	MSG45::	.ASCII	/WATCH DOG TIMER READ AFTER WRITE TMREN8 BIT 1 ERROR/
604	010060	015	012	124		.ASCIZ	<15><12>/TEST ABORTED/
605	010077	127	101	124	MSG46::	.ASCIZ	/WATCH DOG TIMER DID NOT TIME OUT/
606	010140	127	101	124	MSG47::	.ASCIZ	/WATCH DOG TIMO OUT RESET ERROR/
607	010177	121	126	116	MSG48::	.ASCIZ	/QVNT ACKIE BIT 6 SET TO 1 AND READ AS 0/
608	010247	111	116	124	MSG49::	.ASCIZ	/INTERRUPT DID NOT OCCUR AFTER SETTING QCMD CMDACK BIT 0/
609	010337	121	103	115	MSG50::	.ASCIZ	/QCMD PRSIE BIT 6 SET TO 1 AND READ AS 0/
610	010407	111	116	124	MSG51::	.ASCIZ	/INTERRUPT DID NOT OCCUR AFTER SETTING QVNT VNTPRS BIT 0/
611	010477	121	104	115	MSG52::	.ASCIZ	/QDMA RDYIE BIT 6 SET TO 1 AND READ AS 0/
612	010547	111	116	124	MSG53::	.ASCII	/INTERRUPT DID NOT OCCUR AFTER SETTING QDMA GO BIT 0 AND /
613	010637	104	115	101		.ASCIZ	/DMAWT BIT 1/
614	010653	121	111	116	MSG54::	.ASCIZ	/QINT ERRIE BIT 6 SET TO 1 AND READ AS 0/
615	010723	111	116	124	MSG55::	.ASCIZ	/INTERRUPT DID NOT OCCUR AFTER SETTING QMT1 MQPFL BIT 5/
616	011012	121	111	116	MSG56::	.ASCIZ	/QINT UNEX BIT 14 OR ERR BIT 15 NOT SET AFTER INTERRUPT/
617	011101	111	116	124	MSG57::	.ASCII	/INTERRUPT DID NOT OCCUR AFTER SETTING QDMA DMAWT BIT 1 /
618	011170	101	116	104		.ASCIZ	/AND GO BIT 0/
619	011205	121	111	116	MSG58::	.ASCIZ	/QINT QNEX BIT 13 OR ERR BIT 15 NOT SET AFTER INTERRUPT/
620	011274	127	104	124	MSG59::	.ASCIZ	/WDTO INTERRUPT DID NOT OCCUR AFTER 8 SECONDS/
621	011351	121	111	116	MSG60::	.ASCIZ	/QINT UPWRFL, ERR BITS NOT SET AFTER WDTO INTERRUPT/
622	011434	116	117	040	MSG61::	.ASCIZ	/NO INTERRUPT OCCURRED WITH BR LEVEL > THAN CPU LEVEL/
623	011521	111	116	124	MSG62::	.ASCIZ	/INTERRUPT OCCURED WITH BR LEVEL <= CPU LEVEL/
624	011576	120	122	111	HELP1::	.ASCIZ	/PRINT DIAGNOSTIC SUPERVISOR HELP FILE?/
625	011645	120	122	111	HELP2::	.ASCIZ	/PRINT DIAGNOSTIC HELP FILE?/
626						.EVEN	
627							

GLOBAL ERROR REPORT SECTION

632
633
634
635
636
637
638
639
640
641
642
643
644 011702
011702
645 011702 010246
646 011704 005002
647 011706 060102
648 011710 060102
649 011712 060102
650 011714 060102
651 011716 060102
652 011720 062702 002404
653 011724
011724 013746 002524
011730 010246
011732 012746 003504
011736 012746 000003
011742 010600
011744 104414
011746 062706 000010
654 011752
011752 012746 003333
011756 012746 000001
011762 010600
011764 104414
011766 062706 000004
655 011772 012602
656 011774
011774
011774 104423

```
.SBTTL GLOBAL ERROR REPORT SECTION
; **
; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
; USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
; --

; BAD ADDRESS ERROR
; REGISTER NUMBER (0-11.) EXPECTED TO BE IN R1

ERR2:: BGNMSG ERR2
MOV R2, -(SP)
CLR R2 ;CLEAR ACCUMULATOR
ADD R1,R2 ;MULTIPLY REGISTER POINTER TIMES 5
ADD R1,R2
ADD R1,R2
ADD R1,R2
ADD R1,R2
ADD #NAMES,R2 ;POINT R2 TO REGISTER NAME
PRINTB #FOR3,R2,ADD ;TELL OPERATOR BAD ADDRESS
MOV ADD, -(SP)
MOV R2, -(SP)
MOV #FOR3, -(SP)
MOV #3, -(SP)
MOV SP,R0
TRAP C#PNTB
ADD #10, SP
PRINTB #FOR0 ;INSERT LINE FEED CARRIAGE RETURN
MOV #FOR0, -(SP)
MOV #1, -(SP)
MOV SP,R0
TRAP C#PNTB
ADD #4, SP
MOV (SP)+,R2 ;RESTORE REGISTERS
ENDMSG
L10001: TRAP C#MSG
```

657
658
659
660
661
662
663
664
665 011776
011776
666 011776 010146
667 012000 010246
668 012002 005002
669 012004 060102
670 012006 060102
671 012010 060102
672 012012 060102

```
; BAD REGISTER VALUE ERROR (SINGLE REGISTER TEST)
; REGISTER NUMBER (0-11.) EXPECTED TO BE IN R1
; REGISTER ADDRESS EXPECTED TO BE IN LOCATION ADD
; REGISTER VALUE EXPECTED TO BE IN LOCATION VAL
; REGISTER EXPECTED VALUE EXPECTED TO BE IN LOCATION EXP

ERR4:: BGNMSG ERR4
MOV R1, -(SP) ;SAVE REGISTERS USED IN ROUTINES
MOV R2, -(SP)
CLR R2 ;CLEAR ACCUMULATOR
ADD R1,R2 ;MULTIPLY REGISTER POINTER TIMES 5
ADD R1,R2
ADD R1,R2
```

GLOBAL ERROR REPORT SECTION

```

673 012014 060102          ADD      R1,R2
674 012016 062702 002404  ADD      #NAMES,R2          ;POINT R2 TO REGISTER NAME
675 012022 006301          ASL      R1                  ;REGISTER POINTER TIMES 2
676 012024 016137 002274 002524  MOV     ADDRESSES(R1),ADD   ;MOVE CURRENT ADDRESS TO MESSAGE AREA
677 012032          PRINTX  #FOR1                ;PRINT HEADER LINE
    012032 012746 003337  MOV     #FOR1,-(SP)
    012036 012746 000001  MOV     #1,-(SP)
    012042 010600          MOV     SP,R0
    012044 104415          TRAP   C#PNTX
    012046 062706 000004  ADD     #4,SP
678 012052          PRINTX  #FOR2,R2,ADD,VAL,EXP ;PRINT FULL ERROR DETAILS
    012052 013746 002530  MOV     EXP,-(SP)
    012056 013746 002526  MOV     VAL,-(SP)
    012062 013746 002524  MOV     ADD,-(SP)
    012066 010246          MOV     R2,-(SP)
    012070 012746 003454  MOV     #FOR2,-(SP)
    012074 012746 000005  MOV     #5,-(SP)
    012100 010600          MOV     SP,R0
    012102 104415          TRAP   C#PNTX
    012104 062706 000014  ADD     #14,SP
679 012110          PRINTX  #FOR0                ;INSERT LINE FEED CARRIAGE RETURN
    012110 012746 003333  MOV     #FOR0,-(SP)
    012114 012746 000001  MOV     #1,-(SP)
    012120 010600          MOV     SP,R0
    012122 104415          TRAP   C#PNTX
    012124 062706 000004  ADD     #4,SP
680 012130 012602          MOV     (SP)+,R2          ;RESTORE REGISTERS
681 012132 012601          MOV     (SP)+,R1
682 012134          ENDMSG
    012134          L10002: TRAP   C#MSG
    012134 104423
683
684          ;BAD VIEW REGISTER RAM ERROR
685          ;PRINTS HEADER ONLY
686
687 012136          BGNMSG  ERR5
688 012136          ERR5:: PRINTX  #FOR8                ;PRINT HEADER
    012136 012746 004154  MOV     #FOR8,-(SP)
    012142 012746 000001  MOV     #1,-(SP)
    012146 010600          MOV     SP,R0
    012150 104415          TRAP   C#PNTX
    012152 062706 000004  ADD     #4,SP
689 012156          ENDMSG
    012156          L10003: TRAP   C#MSG
    012156 104423
690
691          ;BR LEVEL INTERRUPT LEVEL TEST ERROR ROUTINE
692
693 012160          BGNMSG  ERR6
694 012160          ERR6:: MOV     R1,-(SP)          ;SAVE REGISTERS USED IN ROUTINES
695 012162 010146          MOV     R2,-(SP)
696 012164 010346          MOV     R3,-(SP)
697 012166 013701 002516  MOV     BRLEVEL,R1        ;DEVICE PRIORITY TO R1
698 012172 013702 002540  MOV     VALUE,R2         ;CPU PRIORITY TO R2
699 012176 012703 000005  MOV     #5,R3            ;LOOP COUNTER TO R3
    
```

GLOBAL ERROR REPORT SECTION

```

700 ;SHIFT PRIORITY RIGHT 5 BITS FOR MESSAGE
701 012202 006201 10$: ASR R1 ;SHIFT R1 RIGHT
702 012204 006202 ASR R2 ;SHIFT R2 RIGHT
703 012206 005303 DEC R3 ;DECREMENT COUNTER
704 012210 001374 BNE 10$ ;IF NOT DONE, BRANCH
705 ;PRINT ERROR MESSAGE
706 012212 PRINTB #FOR13,R1,R2 ;TELL OPERATOR DETAILS
    012212 010246 MOV R2,-(SP)
    012214 010146 MOV R1,-(SP)
    012216 012746 004466 MOV #FOR13,-(SP)
    012222 012746 000003 MOV #3,-(SP)
    012226 010600 MOV SP,R0
    012230 104414 TRAP C#PNTB
    012232 062706 000010 ADD #10,SP
707 012236 012603 MOV (SP)+,R3
708 012240 012602 MOV (SP)+,R2 ;RESTORE REGISTERS
709 012242 012601 MOV (SP)+,R1
710 012244 ENDMSG
    012244
    012244 104423 L10004: TRAP C#MSG
711 ; BAD REGISTER VALUE ERROR (SINGLE REGISTER TEST)
712 ; USED WITH ROTATING BITS TESTS
713 ;REGISTER NUMBER (0-11.) EXPECTED TO BE IN R1
714 ;REGISTER ADDRESS EXPECTED TO BE IN LOCATION ADD
715 ;REGISTER VALUE EXPECTED TO BE IN LOCATION VAL
716 ;REGISTER EXPECTED VALUE EXPECTED TO BE IN LOCATION EXP
717
718 012246 BGNMSG ERR7
    012246
719 012246 010146 ERR7:: MOV R1,-(SP) ;SAVE REGISTERS USED IN ROUTINES
720 012250 010246 MOV R2,-(SP)
721 012252 005002 CLR R2 ;CLEAR ACCUMULATOR
722 012254 060102 ADD R1,R2 ;MULTIPLY REGISTER POINTER TIMES 5
723 012256 060102 ADD R1,R2
724 012260 060102 ADD R1,R2
725 012262 060102 ADD R1,R2
726 012264 060102 ADD R1,R2
727 012266 062702 002404 ADD #NAMES,R2 ;POINT R2 TO REGISTER NAME
728 012272 006301 ASL R1 ;REGISTER POINTER TIMES 2
729 012274 016137 002274 002524 MOV ADDRESSES(R1),ADD ;MOVE CURRENT ADDRESS TO MESSAGE AREA
730 012302 PRINTX #FOR1 ;PRINT HEADER LINE
    012302 012746 003337 MOV #FOR1,-(SP)
    012306 012746 000001 MOV #1,-(SP)
    012312 010600 MOV SP,R0
    012314 104415 TRAP C#PNTX
    012316 062706 000004 ADD #4,SP
731 012322 PRINTX #FOR2,R2,ADD,VAL,EXP ;PRINT FULL ERROR DETAILS
    012322 013746 002530 MOV EXP,-(SP)
    012326 013746 002526 MOV VAL,-(SP)
    012332 013746 002524 MOV ADD,-(SP)
    012336 010246 MOV R2,-(SP)
    012340 012746 003454 MOV #FOR2,-(SP)
    012344 012746 000005 MOV #5,-(SP)
    012350 010600 MOV SP,R0
    012352 104415 TRAP C#PNTX
    012354 062706 000014 ADD #14,SP
732 012360 012602 MOV (SP)+,R2 ;RESTORE REGISTERS
    
```

J3

GLOBAL ERROR REPORT SECTION

733 012362 012601
734 012364
012364
012364 104423

MOV (SP)+,R1
ENDMSG
L10005:
TRAP C\$MSG

GLOBAL SUBROUTINES SECTION

736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757 012366
758 012366 010146
759 012370 010246
760 012372 005002
761 012374 060102
762 012376 060102
763 012400 060102
764 012402 060102
765 012404 060102
766 012406 062702 002404
767 012412 006301
768 012414 016137 002274 002524
769 012422
012422 013746 002530
012426 013746 002526
012432 013746 002524
012436 010246
012440 012746 003454
012444 012746 000005
012450 010600
012452 104415
012454 062706 000014
770 012460 012602
771 012462 012601
772 012464 000207

```

.SBTTL GLOBAL SUBROUTINES SECTION
; **
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
; --
;
; THIS SUBROUTINE PRINTS A ONE LINE DETAIL LINE WITHOUT THE
; THE PRIMARY REGISTER ERROR HEADER LINE.
;
; INPUTS:
; REGISTER NUMBER (0-11.) EXPECTED TO BE IN R1
; REGISTER ADDRESS EXPECTED TO BE IN LOCATION ADD
; REGISTER VALUE EXPECTED TO BE IN LOCATION VAL
; REGISTER EXPECTED VALUE EXPECTED TO BE IN LOCATION EXP
;
; CALLING SEQUENCE:
; JSR PC.DETAIL
;
DETAIL:
MOV R1,-(SP) ;SAVE REGISTERS USED IN ROUTINES
MOV R2,-(SP)
CLR R2 ;CLEAR ACCUMULATOR
ADD R1,R2 ;MULTIPLY REGISTER POINTER TIMES 5
ADD R1,R2
ADD R1,R2
ADD R1,R2
ADD R1,R2
ADD #NAMES,R2 ;POINT R2 TO REGISTER NAME
ASL R1 ;REGISTER POINTER TIMES 2
MOV ADDRESSES(R1),ADD ;MOVE CURRENT ADDRESS TO MESSAGE AREA
PRINTX #FOR2,R2,ADD,VAL,EXP ;PRINT FULL ERROR DETAILS
MOV EXP,-(SP)
MOV VAL,-(SP)
MOV ADD,-(SP)
MOV R2,-(SP)
MOV #FOR2,-(SP)
MOV #5,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #14,SP
MOV (SP)+,R2 ;RESTORE REGISTERS
MOV (SP)+,R1
RETURN

```

GLOBAL SUBROUTINES SECTION

```

774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808 012466
809
810 012466 010246
811 012470 010346
812 012472 010446
813 012474 012503
814 012476 012737 177777 013226
815 012504 000411
816
817 012506
818 012506 005037 013226
819
820 012512 010246
821 012514 010346
822 012516 010446
823 012520 010502
824 012522 061505
825 012524 005722
826 012526 012203
827
828
829
830

```

```

*****
; **
;           BITS.MAC
; PROVIDES CODE FOR A SUBROUTINE TO INTERPRET THE BITS SET
; IN A WORD (OR REGISTER), AND OPTIONALLY FOR EVERY BIT SET PRINT OUT
; THE NAME OF THAT BIT IF DEFINED IN AN ASCIZ STATEMENT, AND ALWAYS
; PUT THE NAMES IN A BUFFER.
;
; AUTHOR: DALE PROCTOR
; DATE: 12/23/81
; VERSION: 1.00
;
; ASCIZ STATEMENT FORMAT -
; LABEL: .ASCIZ /BIT15,BIT14,...,BIT10...BIT7/
; MAXIMUM NUMBER OF DEFINITIONS IS 16
;
; TO USE THE FULL ROUTINE, CALL BY USING THE MACRO SETBITS.
; SETBITS IS IN THE FORMAT-
; SETBITS NAME, POINTER, VALUE
; WHERE NAME IS AN ASCII NAME THAT WILL BE PRINTED IN THE
; MESSAGE LINE, POINTER IS AN ADDRESS THAT POINTS TO THE
; ASCIZ FORMAT STATEMENT THAT CONTAINS THE BIT NAMES, AND
; VALUE IS THE WORD TO INTERPRET AND CONVERT TO BIT NAMES.
;
; TO CREATE ONLY A PRINT BUFFER WITH THE SET BIT NAMES CALL
; THIS ROUTINE WITH THE MACRO S$BITS.
; S$BITS IS IN THE FORMAT-
; S$BITS POINTER, VALUE
; ON RETURN FROM S$BITS ROUTINE R0 CONTAINS THE ADDRESS
; OF THE BUFFER.
; --
*****
; CALL BY S$BITS MACRO, NO PRINTING
BIT$:
; SAVE SOME REGISTERS
MOV R2, -(SP)
MOV R3, -(SP)
MOV R4, -(SP)
MOV (R5)+, R3 ;GET POINTER OF FORMAT IN R3
MOV @-1, STATU$ ;TELL ROUTINE THAT THE S$BITS MACRO CALLED
BR BUILD$ ;BRANCH OVER SETBITS STUFF
; CALL BY SETBITS MACRO, PRINT LINE IF SOMETHING TO PRINT
BITS$:
CLR STATU$ ;TELL ROUTINE THAT THE SETBITS MACRO CALLED
; SAVE SOME REGISTERS
MOV R2, -(SP)
MOV R3, -(SP)
MOV R4, -(SP)
MOV R5, R2 ;GET ADDRESS IN R2
ADD (R5), R5 ;ADD LENGTH OF DATA TO RETURN PC
TST (R2)+ ;SKIP PAST LENGTH
MOV (R2)+, R3 ;GET POINTER OF FORMAT IN R3
; REGISTER USAGE
; R0 = LOOP COUNTER
; R1 = CONTAINS REGISTER CONTENTS
; R2 = POINTS TOWARD REGISTER NAME

```

GLOBAL SUBROUTINES SECTION

```

831                                     ; R3 = POINTS TO DEFINITION FORMAT
832                                     ; R4 = POINTS TO BUFFER
833                                     ; R5 = CONTAINS RETURN ADDRESS
834 ;NOW BUILD BIT NAME BUFFER
835 012530                               BUILD$:
836 012530 012704 013015                 MOV    #MES2$,R4           ;POINT R4 TO BUFFER
837 012534 012700 000204                 MOV    #MES2$L,R0        ;LENGTH OF BUFFER TO CLEAR
838                                     ;ZERO OUT THE BUFFER
839 012540 105024                         1$: CLRB   (R4)+           ;CLEAR BYTE
840 012542 005300                         DEC    R0
841 012544 001375                         BNE   1$
842 012546 012704 013015                 MOV    #MES2$,R4           ;POINT R4 TO BUFFER
843 012552 012700 000020                 MOV    #16.,R0           ;NUMBER OF LOOPS TO LOOP COUNTER R1
844 012556 010137 013222                 MOV    R1,STORE$         ;SAVE ORIGINAL BIT PATTERN
845 012562 005037 013224                 CLR    NO$CHAR           ;CLEAR CHARACTER MOVED FLAG
846 012566 105037 013225                 10$: CLRB   NO$CHAR+1     ;CLEAR BIT DEFINED AND MOVED FLAG
847 012572 006101                         ROL    R1                 ;CHECK BIT
848 012574 103410                         BCS   20$               ;IF BITS SET, GO MOVE BIT NAME
849                                     ;BIT WAS NOT SET, FIND NEXT COMMA
850 012576 122713 000000                 5$:  CMPB   #0,(R3)        ;END OF DEFINITION?
851 012602 001433                         BEQ   40$               ;IF END, GO PRINT MESSAGE
852 012604 122713 000054                 CMPB   #'',(R3)         ;IS IT A COMMA?
853 012610 001425                         BEQ   35$              ;IF COMMA, CONTINUE TO PROCESS
854 012612 005203                         INC    R3                ;POINT TO NEXT CHARACTER IN DEFINITION
855 012614 000770                         BR    5$                ;CHECK NEXT CHARACTER IF NOT A COMMA
856                                     ;BIT WAS SET, MOVE BIT NAME IF THERE
857 012616                               20$:
858 012616 122713 000000                 CMPB   #0,(R3)          ;IS IT END OF FORMAT?
859 012622 001425                         BEQ   45$              ;IF END, GO PRINT MESSAGE
860 012624 122713 000054                 CMPB   #'',(R3)         ;IS IT A COMMA?
861 012630 001406                         BEQ   30$              ;IF IT WAS A COMMA, GO
862                                     ;SHOULD BE A VALID CHARACTER, MOVE TO PRINT BUFFER
863 012632 112324                         MOVB   (R3)+,(R4)+       ;MOVE CHARACTER
864 012634 105237 013224                 INCB   NO$CHAR          ;INCREMENT CHARACTER FLAG
865 012640 105237 013225                 INCB   NO$CHAR+1        ;INCREMENT BIT DEFINED AND MOVED FLAG
866 012644 000764                         BR    20$              ;GO PROCESS NEXT CHAR
867                                     ;END OF CHARACTER MOVE, ADVANCE POINTER TO PUT COMMA AFTER NAME
868 012646                               30$:
869 012646 105737 013225                 TSTB   NO$CHAR+1        ;WAS THE LAST BIT DEFINED
870 012652 001404                         BEQ   35$              ;IF LAST BIT NOT DEFINED, BRANCH
871 012654 112724 000054                 MOVB   #'',(R4)+        ;PUT COMMA AFTER BIT NAME
872 012660 112724 000040                 MOVB   #40,(R4)+       ;PUT SPACE AFTER COMMA
873 012664 005203                         35$: INC    R3           ;POINT TO NEXT CHARACTER IN DEFINITION
874 012666 005300                         DEC    R0               ;DECREMENT LOOP COUNTER
875 012670 001336                         BNE   10$              ;IF NOT DONE, GO PROCESS NEXT BIT
876                                     ;NOW SET UP TO PRINT THE MESSAGE
877 012672                               40$:
878 012672 005304                         DEC    R4               ;POINT BACK TO LAST COMMA AND SPACE
879 012674 005304                         DEC    R4
880 012676 112714 000000                 45$: MOVB   #0,(R4)       ;PUT ZERO AS TERMINATOR IN BUFFER
881 012702 005000                         CLR    R0               ;DEFAULT RETURN CODE = NOTHING PRINTED
882 012704 005737 013226                 TST    STATU$          ;SEE WHICH MACRO CALLED ROUTINE
883 012710 001020                         BNE   50$              ;BRANCH IF S$BITS MACRO CALLED
884 012712 005737 013224                 TST    NO$CHAR         ;SEE IF NOTHING PUT IN PRINT BUFFER
885 012716 001415                         BEQ   50$              ;IF NOTHING THERE, DON'T PRINT IT
886 012720                               PRINTB #MES1$,R2,STORE$,#MES2$ ;PRINT LINE
      012720 012746 013015                 MOV    #MES2$,-(SP)

```

GLOBAL SUBROUTINES SECTION

```

012724 013746 013222      MOV      STORE$, -(SP)
012730 010246             MOV      R2, -(SP)
012732 012746 012766      MOV      #MES1$, -(SP)
012736 012746 000004      MOV      #4, -(SP)
012742 010600             MOV      SP, R0
012744 104414             TRAP     C$PNTB
012746 062706 000012      ADD      #12, SP
887                                     ;RESTORE AND GO BACK
888 012752 50$:
889 012752 012700 013015      MOV      #MES2$, R0      ;RETURN WITH R0 POINTING TO BUFFER
890 012756 012604             MOV      (SP)+, R4
891 012760 012603             MOV      (SP)+, R3
892 012762 012602             MOV      (SP)+, R2
893 012764 000205             RTS      R5
894
895 012766      045      116 061 MES1$:: .ASCIZ /#N1#T#A = #06#A; #T#N1/
896 013015      MES2$:: .BLKB 132.      ;SAVE ALL KINDS OF SPACE FOR MESSAGE LINE
897      000204      MES2$L = .-MES2$
898      .EVEN
899 013222 000000      STORE$: .WORD 0      ;STORES ORIGINAL BIT PATTERN
900 013224 000000      NO$CHAR: .WORD 0      ;FLAG IF CHARACTERS WERE MOVED TO BUFFER
901 013226 000000      STATU$: .WORD 0      ;STORE WHICH MACRO CALLED

```


GLOBAL SUBROUTINES SECTION

903 013230

STARS
;*****

904

;**

905

; SUBROUTINE DUMP -

906

; FUNCTIONAL DESCRIPTION:

907

; SUBROUTINE TO PRINT THE CONTENTS OF ALL THE REGISTERS

908

; IT USES THE PRINTX PRINT EXTENDED FORMAT AND CAN BE DISABLED

909

; BY THE OPERATOR BY /FLAG:IXE, INHIBIT EXTENDED ERROR REPORTS

910

; INPUTS:

911

; NONE

912

; OUTPUT:

913

; DEVICE REGISTER DUMP PRINTED IF EXTENDED ERROR REPORTS ENABLED

914

; CALLING SEQUENCE:

915

; JSR PC,DUMP

916 013230

STARS
;*****

917

DUMP::

918 013230

;FIRST CHECK FOR INHIBIT EXTENDED ERROR REPORTS FLAG SET

919

920 013230

RFLAGS FLAG

013230 104421

TRAP C0RFLA

013232 010037 014170

MOV R0,FLAG

921 013236 032737 004000 014170

BIT @BIT11,FLAG

; IS INHIBIT FLAGS SET?

922 013244 001144

BNE EDUMP

; EXIT ROUTINE IF SET

923 013246 010146

MOV R1,-(SP)

; SAVE CPU REGISTERS

924 013250 010246

MOV R2,-(SP)

925 013252 010346

MOV R3,-(SP)

926 013254 010446

MOV R4,-(SP)

927 013256 010546

MOV R5,-(SP)

928 013260 017746 167016

MOV @QCTL,-(SP)

929

;FIRST READ THE REGISTERS

930 013264 052777 000020 167010

BIS @QVREN,@QCTL

; ENABLE Q-VIEW READ

931 013272 012701 000014

MOV @12.,R1

; NUMBER OF REGISTERS TO READ

932 013276 013702 002274

MOV @CMD,R2

; BASE REGISTER ADDRESS TO R2

933 013302 012703 002324

MOV @VALUES,R3

; RECEIVING STORAGE

934 013306 022701 000007

E100: CMP @7,R1

; IS IT QUBA REGISTER?

935 013312 001002

BNE 110

936 013314 000137 013720

JMP P1

; BRANCH IF QUBA

937 013320 022701 000002

110: CMP @2,R1

; IS IT QVAD REGISTER?

938 013324 001002

BNE 120

; BRANCH IF QVAD

939 013326 000137 013772

JMP P2

940 013332 012223

120: MOV (R2)+,(R3)+

; STORE REGISTER VALUE

941 013334 005301

E50: DEC R1

; DECREMENT LOOP COUNTER

942 013336 001363

BNE E100

; IF NOT DONE, LOOP

943

;END READ, NOW PRINT THE RESULTS

944 013340

PRINTX @RP1

; PRINT FIRST LINE OF MESSAGE

013340 012746 014050

MOV @RP1,-(SP)

013344 012746 000001

MOV @1,-(SP)

013350 010600

MOV SP,R0

013352 104415

TRAP C0PNTX

013354 062706 000004

ADD @4,SP

945 013360 012704 002377

MOV @NAMES-5,R4

; POINT R4 TO REGISTER NAMES TABLE

946 013364 005002

CLR R2

; CLEAR POINTER REGISTER

947 013366 012703 000014

MOV @12.,R3

; LOAD R3 AS LOOP COUNTER

948 013372 062704 000005

E60: ADD @5,R4

; POINT R4 TO NEXT REGISTER NAME

949 013376 016237 002274 002524

MOV ADDRESSES(R2),ADD

; GET ADDRESS OF REGISTER READY TO PRINT

950 013404 016237 002324 002526

MOV VALUES(R2),VAL

; GET VALUE OF REGISTER READY TO PRINT

GLOBAL SUBROUTINES SECTION

```

951 013412          PRINTX  @RP2,R4,ADD,VAL          ;PRINT REGISTER NAME, ADDRESS, VALUE
      013412 013746 002526
      013416 013746 002524
      013422 010446
      013424 012746 014140
      013430 012746 000004
      013434 010600
      013436 104415
      013440 062706 000012
952          ;CHECK TO SEE IF ONE OF THE BIT DEFINED REGISTERS, IF YES, BRANCH
953 013444 022703 000014
954 013450 001443
955 013452 022703 000013
956 013456 001446
957 013460 022703 000012
958 013464 001451
959 013466 022703 000011
960 013472 001454
961 013474 022703 000010
962 013500 001457
963 013502 022703 000003
964 013506 001462
965 013510 062702 000002
966 013514 005303
967 013516 001325
968 013520
      013520 012746 014044
      013524 012746 000001
      013530 010600
      013532 104415
      013534 062706 000004
969 013540 012677 166536
970 013544 012605
971 013546 012604
972 013550 012603
973 013552 012602
974 013554 012601
975 013556 000207
976
977
978 013560
979 013572 000435
980
981 013574
982 013606 000427
983
984 013610
985 013622 000421
986
987 013624
988 013636 000413
989
990 013640
991 013652 000405
992
993 013654
994
      MOV      VAL,-(SP)
      MOV      ADD,-(SP)
      MOV      R4,-(SP)
      MOV      @RP2,-(SP)
      MOV      @4,-(SP)
      MOV      SP,R0
      TRAP     C@PNTX
      ADD      @12,SP
      CMP      @12.,R3          ;IS IT CMD REG
      BEQ      CMDB
      CMP      @11.,R3          ;IS IT VNT REG
      BEQ      VNTB
      CMP      @10.,R3          ;IS IT INT REG
      BEQ      INTB
      CMP      @9.,R3           ;IS IT CTL REG
      BEQ      CTLB
      CMP      @8.,R3           ;IS IT DMA REG
      BEQ      DMAB
      CMP      @3.,R3           ;IS IT MT1 REG
      BEQ      MT1B
      X1:      ADD      @2,R2          ;POINT R2 TO NEXT REGISTER DATA
      DEC      R3                ;DECREMENT LOOP COUNTER
      BNE     E64                ;GO DO NEXT REGISTER IF NOT DONE
      PRINTX  @RPO
      MOV      @RPO,-(SP)
      MOV      @1,-(SP)
      MOV      SP,R0
      TRAP     C@PNTX
      ADD      @4,SP
      MOV      (SP)+,@QCTL
      MOV      (SP)+,R5
      MOV      (SP)+,R4
      MOV      (SP)+,R3          ;RESTORE REGISTERS
      MOV      (SP)+,R2
      MOV      (SP)+,R1
      EDUMP:  RTS      PC          ;RETURN

      ;PROCESS PRINTING SET BIT DEFINITIONS
      CMDB:   S@BITS  CMDBIT,VAL
      BR      PRINTIT
      VNTB:   S@BITS  VNTBIT,VAL
      BR      PRINTIT
      INTB:   S@BITS  INTBIT,VAL
      BR      PRINTIT
      CTLB:   S@BITS  CTLBIT,VAL
      BR      PRINTIT
      DMAB:   S@BITS  DMABIT,VAL
      BR      PRINTIT
      MT1B:   S@BITS  MT1BIT,VAL

```

GLOBAL SUBROUTINES SECTION

```

995                                     ;PRINT BIT DEFINITION LINE
996 013666                               PRINTIT:
997 013666 010005                       MOV     R0,R5                ;MOVE ADDRESS TO R5
998 013670 105715                       TSTB   (R5)                ;IS IT A BLANK
999 013672 001706                       BEQ    X#                   ;BRANCH IF NOTHING TO PRINT
1000 013674                               PRINTB @RP4,R5              ;PRINT LINE
      013674 010546                       MOV     R5,-(SP)
      013676 012746 014165               MOV     @RP4,-(SP)
      013702 012746 000002               MOV     @2,-(SP)
      013706 010600                       MOV     SP,R0
      013710 104414                       TRAP   C#PNTB
      013712 062706 000006               ADD     @6,SP
1001 013716 000674                       BR     X#                   ;RETURN TO MAINLINE
1002
1003
1004                                     ;PROCESS QUBA REGISTER (NOT NORMAL REGISTER READ
1005 013720 017746 166372               P1:   MOV     @QMT1,-(SP)    ;SAVE CURRENT QMT1
1006 013724 052777 000200 166364       BIS     @MIODIS,@QMT1      ;ENABLE INTERNAL LOOPBACK
1007 013732 052777 000020 166356       BIS     @BIT4,@QMT1       ;SELECT UBAR FUNCTION
1008 013740 017723 166350               MOV     @QMT0,(R3)+       ;READ QUBA
1009 013744 005722                       TST    (R2)+              ;CORRECT R2
1010 013746 042777 000200 166342       BIC     @MIODIS,@QMT1     ;DISABLE INTERNAL LOOPBACK
1011 013754 042777 000020 166334       BIC     @BIT4,@QMT1       ;DESELECT UBAR FUNCTION
1012 013762 012677 166330               MOV     (SP)+,@QMT1       ;RESTORE QMT1
1013 013766 000137 013334               JMP     E$                 ;BRANCH BACK
1014
1015                                     ;PROCESS QVAD REGISTER READ (NOT NORMAL REGISTER READ)
1016 013772 017746 166320               P2:   MOV     @QMT1,-(SP)    ;SAVE CURRENT QMT1
1017 013776 052777 000200 166312       BIS     @MIODIS,@QMT1     ;ENABLE INTERNAL LOOPBACK
1018 014004 052777 000002 166304       BIS     @MVADR,@QMT1      ;ENABLE ADDRESS REGISTER READ
1019 014012 017723 166302               MOV     @QVAD,(R3)+       ;READ ADDRESS REGISTER
1020 014016 005722                       TST    (R2)+              ;CORRECT R2
1021 014020 042777 000200 166270       BIC     @MIODIS,@QMT1     ;DISABLE INTERNAL LOOPBACK
1022 014026 042777 000002 166262       BIC     @MVADR,@QMT1      ;DISABLE ADDRESS REGISTER READ
1023 014034 012677 166256               MOV     (SP)+,@QMT1       ;RESTORE QMT1
1024 014040 000137 013334               JMP     E$                 ;BRANCH BACK
1025
1026                                     ;FORMATS USED IN REGISTER DUMP PRINTING
1027
1028 014044 045 116 061 RP0:: .ASCIZ /#N1/ ;LINE FEED CARRIAGE RETURN ONLY
1029 014050 045 116 061 RP1:: .ASCIZ /#N1#S7#AREGISTER DUMP#N1#ANAME#S4#ADDRESS#S4#ACONTENTS/
1030                                     .EVEN
1031 014140 045 116 061 RP2:: .ASCIZ /#N1#T#S5#06#S5#06#S3/
1032 014165 045 124 000 RP4:: .ASCIZ /#T/
1033                                     .EVEN
1034 014170 000000 FLAG: .WORD 0 ;STORES RETURNED FLAG SETTINGS

```

GLOBAL SUBROUTINES SECTION

```

1036 014172
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051 014172
1052
1053 014172
1054 014172 010537 014366
1055 014176
      014176 010500
      014200 104434
1056
1057 014202 012702 000015
1058 014206 004537 014270
1059 014212 012702 000012
1060 014216 004537 014270
1061 014222 005001
1062 014224
      014224 104426
      014226 110002
1063 014230
      014230 103011
1064 014232 022702 000000
1065 014236 001406
1066 014240 022702 000011
1067 014244 001437
1068 014246 004537 014270
1069 014252 000764
1070
1071 014254
1072 014254
      014254 104435
1073 014256 013705 014366
1074 014262 062705 000012
1075 014266 000205
1076
1077 014270 010237 014364
1078 014274
      014274 012746 014362
      014300 012746 000001
      014304 010600
      014306 104414
      014310 062706 000004
1079 014314 005201

```

```

STARS
;*****
;
; FUNCTIONAL DESCRIPTION:
; SUBROUTINE TO PRINT OUT A TEXT OR HELP FILE
; INPUTS:
; NONE
; OUTPUTS:
; CONTENTS OF EITHER DRS.HLP OR DIAGNOSTIC DEVICE HELP FILE
; PRINTED ON CONSOLE.
; CONTENTS OF R1 AND R2 ARE DESTROYED.
; CALLING SEQUENCE:
; USES MACRO HLPMAC; FORMAT IS HLPMAC 'FILENAME.EXT'
; MACRO IS DEFINED AT END OF SUBROUTINE.
; MACRO USES FORMAT JSR R5,HLP.
;--
STARS
;*****

;HLP::
      MOV     R5,#STORE          ;SAVE RETURN ADDRESS
      OPEN   R5                  ;OPEN FILE NAME
      MOV     R5,R0
      TRAP   C#OPEN
;FIRST PRINT CR/LF
      MOV     #15,R2             ;CARRIAGE RETURN TO R2
      JSR    R5,60#              ;GO PRINT IT
      MOV     #12,R2             ;LINE FEED TO R2
      JSR    R5,60#              ;GO PRINT IT
      CLR    R1                  ;CLEAR POSITION COUNTER
10# : GETBYTE R2                 ;GET BYTE COUNT OF RECORD
      TRAP   C#GETB
      MOVB  R0,R2
      BNCOMPLETE 50#            ;BRANCH IF END OF FILE
      BCC   50#
      CMP   #0,R2                ;END OF RECORDS?
      BEQ   50#                  ;BRANCH IF END
30# : CMP   #11,R2              ;IS IT TAB CHARACTER?
      BEQ   80#                  ;IF YES HANDLE TAB
40# : JSR   R5,60#              ;GO PRINT IT
      BR    10#                  ;GO PROCESS NEXT CHARACTER
;END OF FILE OR LAST RECORD
50# :
      CLOSE
      TRAP   C#CLOS              ;CLOSE FILE
      MOV     #STORE,R5          ;RESTORE RETURN ADDRESS
      ADD    #10.,R5             ;SKIP PAST FILE NAME
      RTS    R5
;PRINT AND COUNT ROUTINE
60# : MOV     R2,#MESLNE         ;GET CHARACTER TO PRINT IN R2
      PRINTB #HLPFOR            ;GO PRINT LINE
      MOV     #HLPFOR,-(SP)
      MOV     #1,-(SP)
      MOV     SP,R0
      TRAP   C#PNTB
      ADD    #4,SP
      INC    R1                  ;INCREMENT POSITION COUNTER

```

GLOBAL SUBROUTINES SECTION

1080	014316	022701	000010		CMP	#8.,R1				
1081	014322	001406			BEQ	65#				; IS IT MAXIMUM?
1082	014324	022702	000012		CMP	#12,R2				; IF MAXIMUM, BRANCH
1083	014330	001403			BEQ	65#				; IS IT A LINE FEED?
1084	014332	022702	000015		CMP	#15,R2				; IF LINE FEED, BRANCH
1085	014336	001001			BNE	70#				; IS IT A CARRIAGE RETURN?
1086	014340	005001		65#:	CLR	R1				; IF NOT, BRANCH
1087	014342	000205		70#:	RTS	R5				; CLEAR POSITION COUNTER
1088										; FROM PRINT AND COUNT ROUTINE
1089	014344									
1090	014344	012702	000040		MOV	#40,R2				; MOVE SPACE CHARACTERS
1091	014350	004537	014270		JSR	R5,60#				; GO PRINT SPACE
1092	014354	005701			TST	R1				; DONE YET?
1093	014356	001372			BNE	80#				; IF NOT DONE, AGAIN
1094	014360	000721			BR	10#				; RETURN FROM TAB ROUTINE
1095										
1096										
1097										
1098	014362									
1099	014362	045	101							
1100	014364									
1101	014364	000								
1102	014365	000								
1103										
1104	014366	000000								

65#:

70#:

;TAB ROUTINE

80#:

; STORAGE, FORMAT AND MESSAGE LINE

; \$HLPFOR::

.ASCII /#A/

; \$MESLNE:

.BYTE 0

.BYTE 0

.EVEN

; \$STORE: .WORD 0

; RESERVED FOR MESSAGE LINE

; STORES MAIN SUBROUTINE RETURN ADDRESS

GLOBAL SUBROUTINES SECTION

1106 014370

1107

1108

1109

1110

1111

1112

1113

1114

1115

1116

1117

1118

1119 014370

1120

1121 014370

1122 014370 005001

1123 014372 012702 172300

1124 014376 012703 000007

1125 014402 012712 077406

1126 014406 010162 000040

1127 014412 005722

1128 014414 062701 000200

1129 014420 005303

1130 014422 001367

1131 014424 012712 077406

1132 014430 012762 177600 000040

1133 014436 000207

STARS

;;*****

;;**

;; MMINIT

;; FUNCTIONAL DESCRIPTION-

;; SUBROUTINE TO INITIALIZE MEMORY MANAGEMENT REGISTERS

;; INPUTS-

;; NONE

;; OUTPUT-

;; NONE

;; CALLING SEQUENCE-

;; JSR PC,MMINIT

;;

;;--

STARS

;;*****

MMINIT::

CLR R1

MOV #KISDR0,R2

MOV #7,R3

1\$: MOV #77406,(R2)

MOV R1,40(R2)

TST (R2)+

ADD #200,R1

DEC R3

BNE 1\$

MOV #77406,(R2)

MOV #177600,40(R2)

RTS PC

;GET DESCRIPTOR REGISTER ADDRESS

;DO 7 REGISTERS

;SET 4K, R/W UP

;SET ADDRESS REGISTER

;SET TO NEXT REGISTER ADDRESS

;DONE?

;IF NOT DONE

;SET I/O PAGE

GLOBAL SUBROUTINES SECTION

1135 014440

STARS

1136

;;*****

1137

;;

1138

;

INTERRUPT SERVICE ROUTINE
ADDRESS TRAP SERVICE ROUTINE

1139

;

1140 014440

;;

STARS

;;*****

1141

1142 014440

TRAP4:: BGNSRV TRAP4

014440

1143 014440 005237 002522

TRAP4:: INC TRPFLG ;SET TRAP FLAG

1144 014444

ENDSRV

014444

L10006:

014444 000002

RTI

1145

1146 014446

ENDMOD

1147

1148

GLOBAL SUBROUTINES SECTION

```

11
12
40
41 014446
42
43
44
45
46
47
48 014446
014446
49 014446 004737 013230
61
62 014452
014452 000167
014454 000000
74
75
76
77 014456
014456
014456 104425

.ENABL AMA
.SBTTL REPORT CODING SECTION

BGNMOD

; **
; THE REPORT CODING SECTION CONTAINS THE
; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
; --

BGNRPT
L#RPT:: CALL DUMP ;GO PRINT THE DUMP ROUTINE

EXIT RPT
.WORD J#JMP
.WORD L10007-2-.

.EVEN

ENDRPT
L10007: TRAP C#RPT

```


PROTECTION TABLE

79
80
81
82
83
84
85
86
87
88
89
90
91
92
93

014460
014460
014460 177777
014462 177777
014464 177777

.SBTTL PROTECTION TABLE

; THIS TABLE IS USED BY THE RUNTIME SERVICES
; TO PROTECT THE LOAD MEDIA.
;--

BGNPROT
L\$PROT::

-1
-1
-1

;OFFSET INTO P-TABLE FOR CSR ADDRESS
;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
;OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

INITIALIZE SECTION

```

108      .SBTTL  INITIALIZE SECTION
109
110      ;**
111      ; THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
112      ; AT THE BEGINNING OF EACH PASS.
113      ;--
114
115 014466      BGNINIT
116 014466      L$INIT::
117 014466      SETPRI  #PRI00          ;INITIALIZE WITH CPU ZERO PRIORITY
118 014466 012700 000000      MOV      #PRI00,R0
119 014472 104441      TRAP    C$SPRI
120
121 014474      INIT0:  READEF  #EF.CONTINUE      ; WAS THERE A CONTINUE COMMAND
122 014474 012700 000036      MOV      #EF.CONTINUE,R0
123 014500 104447      TRAP    C$REFG
124 014502      BNCOMPLETE INIT1      ;IF NO, CONTINUE
125 014502 103002      BCC     INIT1
126 014504 000137 015032      JMP     ENDI      ;YES, SKIP INITIALIZATION
127
128 014510      INIT1:  READEF  #EF.NEW          ;NEW PASS OR SUB PASS?
129 014510 012700 000035      MOV      #EF.NEW,R0
130 014514 104447      TRAP    C$REFG
131 014516      BNCOMPLETE NEXT      ;IF NOT NEW PASS, SKIP SETUP
132 014516 103036      BCC     NEXT
133
134 014520      INIT2:  TST     BRDGLF          ;HAS BRIDGE TYPE BEEN DETERMINED?
135 014524 001030      BNE     INIT3      ;IF NE YES
136 014526 005237 002502      INC     BRDGLF      ;SET FLAG
137 014532 005037 002500      CLR     BRIDGETYPE ;CLEAR BRIDGE TYPE FLAG (Q-BRIDGE)
138 014536 012702 003316      MOV     #QBUS,R2   ;LOAD BRIDGE TYPE PTR (Q-BRIDGE)
139 014542      READBUS      ;DETERMINE BRIDGE TYPE
140 014542 104407      TRAP    C$RDBU
141 014544      BCOMPLETE 10$      ;IF COMPLETE THEN Q-BRIDGE
142 014544 103407      BCS     10$
143 014546 012737 177777 002500      MOV     #-1,BRIDGETYPE ;SET BRIDGE TYPE FLAG (U-BRIDGE)
144 014554 012702 003324      MOV     #UBUS,R2   ;LOAD BRIDGE TYPE PTR (U-BRIDGE)
145 014560 005037 172516      CLR     MMR3      ;DISABLE UNIBUS MAPPING ;V C.O
146 014564      10$:  PRINTB  #CONFIG,R2      ;IDENTIFY BRIDGE TYPE
147 014564 010246      MOV     R2,-(SP)
148 014566 012746 003244      MOV     #CONFIG,-(SP)
149 014572 012746 000002      MOV     #2,-(SP)
150 014576 010600      MOV     SP,R0
151 014600 104414      TRAP    C$PNTB
152 014602 062706 000006      ADD     #6,SP
153
154      ; !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
155      ; HELP FILE SECTION REMOVED. TO REINSTALL, REMOVED COMMENTS
156      ; !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
157
158      INITS:
159      ; TST     HP1          ;WAS HELP FILE PRINTED
160      ; BNE     1$          ;BRANCH IF ALREADY PRINTED
161      ; INC     HP1          ;SET HELP FILE QUESTION FLAG
162      ; GMANIL  HELP1,VAL,1,YES ;ASK IF HELP FILE WANTED
163      ; CMP     #NO,VAL      ;DO WE WANT TO PRINT HELP FILE?
164      ; BEQ     1$          ;IF NO, BRANCH

```

INITIALIZE SECTION

```

148      :      HLPMAC  DRS.HLP      ;PRINT OUT SUPERVISOR HELP FILE
149      :18:    TST      HP2        ;WAS HELP FILE PRINTED
150      :      BNE      SETUP      ;BRANCH IF ALREADY PRINTED
151      :      INC      HP2        ;SET HELP FILE QUESTION FLAG
152      :24:    GMANIL  HELP2,VAL,1,YES ;ASK IF DIAGNOSTIC HELP FILE WANTED
153      :      CMP      @NO,VAL     ;DO WE WANT TO PRINT HELP FILE
154      :      BEQ      SETUP      ;IF NO, BRANCH
155      :      HLPMAC  Z0791.HLP    ;PRINT OUT DIAGNOSTIC HELP FILE
156
157 014606 012737 177777 002504 SETUP: MOV  @-1,LOGUNIT ;INITIALIZE LOGICAL UNIT COUNTER
158

```

INITIALIZE SECTION

```

160
161 014614 005237 002504      NEXT:  INC      LOGUNIT      ;POINT TO NEXT LOGICAL UNIT
162 014620 023737 002504 002012  CMP      LOGUNIT,L#UNIT ;HAVE WE PASSED MAXIMUM
163 014626 001500          BEQ      ABORT          ;GO IF MAXIMUM PASSED
164 014630          GPHARD  LOGUNIT,PLOC ;GET P-TABLE ADDRESS
      014630 013700 002504      MOV      LOGUNIT,R0
      014634 104442          TRAP     C#GPHRD
      014636 010037 002506      MOV      R0,PLOC
165 014642          BNCOMPLETE NEXT ;IF NOT AVAILABLE, GET NEXT UNIT
      014642 103364          BCC     NEXT
166 014644 013737 002504 002074  MOV      LOGUNIT,L#LUN ;STORE CURRENT LOGICAL UNIT IN HEADER
167          ;GET ALL HARDWARE TABLE ENTRIES IN STORAGE
168 014652 013700 002506      MOV      PLOC,R0 ;PLACE HEADER POINTER IN R0
169 014656 016037 000000 002510  MOV      0(R0),BASEADD ;BASE ADDRESS OF BOARD
170 014664 016037 000002 002512  MOV      2(R0),VECTOR  ;VECTOR ADDRESS OF BOARD
171 014672 016037 000004 002514  MOV      4(R0),LOOPBK  ;LOOPBACK OPTION INSTALLED?
172 014700 016037 000006 002516  MOV      6(R0),BRLEVEL ;BR INTERRUPT LEVEL ON THE BOARD
173          ;FILL IN BRIDGE INTERFACE REGISTER TABLE
174 014706 013701 002510      MOV      BASEADD,R1 ;GET BASE ADDRESS IN R1
175 014712 012702 002274          MOV      #QCMD,R2 ;POINT TO REGISTER TABLE ADDRESS
176 014716 012703 000014          MOV      #12,,R3 ;# OF REGISTERS IN TABLE
177 014722 010122          10$: MOV      R1,(R2)+ ;PLACE REGISTER ADDRESS IN TABLE
178 014724 062701 000002          ADD      #2,R1 ;ADJUST R1 TO NEXT REGISTER ADDRESS
179 014730 005303          DEC      R3 ;ARE WE DONE?
180 014732 001373          BNE     10$ ;IF NOT DONE, GO AGAIN
181          ;TABLE BUILT, NOW ESTABLISH INITIALIZE WORD FOR TEST (LOOPBACK YES OR NO INSTALLED)
182 014734 005037 002520      CLR      INITWORD ;CLEAR STORAGE
183 014740 005737 002514          TST     LOOPBK ;IS LOOPBACK CABLE INSTALLED
184 014744 001003          BNE     20$ ;IF LOOPBACK CABLE INSTALLED, BRANCH
185 014746 052737 000200 002520  BIS      #MIODIS,INITWORD ;SET LOOPBACK ENABLED (NO CABLE INSTALLED)
186 014754
187          20$: ;GET FREE MEMORY ADDRESS AND SIZE
188 014754          MEMORY FREMEM ;GET MEMORY ADDRESS
      014754 104431          TRAP     C#MEM
189 014756 010037 002552          MOV      R0,FREMEM
190 014762 017737 165564 002550  MOV      #FREMEM,MEMSIZ ;GET FREE MEMORY SIZE
191          ;CHECK MEMORY SIZE
191 014770 022737 002000 002120  CMP      #2000,L#HIME ;> 32K WORD MEMORY? ;V C.0
192 014776 003004          BGT     22$ ;IF NOT ;V C.0
193 015000 005037 177572          CLR      M#R0 ;DISABLE MEM. MGT. ;V C.0
194 015004 005037 172516          CLR      M#R3 ;DISABLE UMR ;V C.0
195 015010 022737 007577 002120  22$: CMP      #7577,L#HIME ;COMPARE 128K TO MEMORY SIZE
196 015016 100003          BPL     25$ ;OK IF SIZE <= 128K
197 015020 012737 007577 002120  MOV      #7577,L#HIME ;RESET MEMORY SIZE TO 128K
198 015026 000401          BR      ENDI ;SKIP ABORT INSTRUCTION
199 015030          ABORT: DOCLN ;DO CLEANUP AND ABORT THE PASS
      015030 104444          TRAP     C#DCLN
200 015032          ENDI: EXIT  INIT ;THAT'S ALL TO INITIALIZE PASS
      015032 104432          TRAP     C#EXIT
      015034 000002          .WORD  L10011-.
201
225
226          ; EXIT  INIT
227
239
240          .EVEN
241

```

INITIALIZE SECTION

242 015036
015036
015036 104411

ENDINIT
L10011: TRAP C#INIT

AUTODROP SECTION

244
 245
 246
 247
 248
 249
 250
 251
 252
 253 015040
 015040
 254
 255 015040 000240
 256
 263
 264 015042
 015042
 015042 104461

```
.SBTTL AUTODROP SECTION
; **
; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
; DROPPED FROM TESTING.
; **
          BGNAUTO
L$AUTO::
          NOP          ; NO ON-LINE SIGNAL PROVIDED TO USER FOR AUTODROP

          ENDAUTO
L10012:  TRAP  C$AUTO
```

CLEANUP CODING SECTION

```

266
267
268
269
270
271
272
273
274
275
276 015044
    015044
277
278 015044
    015044 012746 000340
    015050 012746 015112
    015054 012746 000004
    015060 012746 000003
    015064 104437
    015066 062706 000010
279 015072 042777 000200 165216
280 015100
    015100 012700 000004
    015104 104436
281 015106
    015106 104432
    015110 000010
282
283 015112 000002
284
293
294 015114
    015114 104432
    015116 000002
295
307
308
309
310 015120
    015120
    015120 104412
    
```

.SBTTL CLEANUP CODING SECTION

```

; **
; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
;
; THE CLEANUP CODE WILL SET THE TRAP CATCHER, CLEAR MIODIS,
; RESET THE TRAP CATCHER, AND EXIT.
; --
    
```

```

                BGNCLN
L10013:
                SETVEC  #4,#BAD,#PRI07           ; SET FOR BAD ADDRESS TRAP
                MOV     #PRI07,-(SP)
                MOV     #BAD,-(SP)
                MOV     #4,-(SP)
                MOV     #3,-(SP)
                TRAP    C#SVEC
                ADD     #10,SP
                BIC     #MIODIS,#QMT1           ; CLEAR MAINTENANCE LOOP-BACK BIT
                CLRVEC  #4                       ; RESET VECTOR
                MOV     #4,R0
                TRAP    C#CVEC
                EXIT    CLN
                TRAP    C#EXIT
                .WORD   L10013-

BAD:            RTI

                EXIT    CLN
                TRAP    C#EXIT
                .WORD   L10013-

                .EVEN

                ENDCLN
L10013:        TRAP    C#CLEAN
    
```

DROP UNIT SECTION

312
 313
 314
 315
 316
 317
 318
 319 015122
 015122
 320
 321 015122 000240
 322
 331
 332 015124
 015124 000167
 015126 000000
 333
 345
 346
 347
 348 015130
 015130
 015130 104453

```
.SBTTL DROP UNIT SECTION
; **
; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO NO LONGER BE TESTED.
; --

          BGNDU
L#DU::

          NOP          ;NO SPECIAL DROP UNIT CODING NEEDED

          EXIT        DU
          .WORD       J#JMP
          .WORD       L10014-2-.

          .EVEN

          ENDDU
L10014:  TRAP        C#DU
```


ADD UNIT SECTION

```

350          .SBTTL  ADD UNIT SECTION
351
352          ;**
353          ; THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
354          ; TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
355          ; TO THE TEST CYCLE.
356          ;--
357
358 015132    BGNAU
359          L#AU::
360 015132    000240      NOP          ;NO SPECIAL ADD UNIT CODING NEEDED
361
362
363
364
365
366
367 015134    000167      EXIT        AU
368 015134    000000      .WORD      J#JMP
369 015136    000000      .WORD      L10015-2-.
370
371
372
373
374
375
376          .EVEN
377
378
379
380
381
382
383
384
385
386
387 015140    104452      ENDAU
388          L10015:
389 015140    104452      TRAP        C#AU
390          ENDMOD

```

F5

ADD UNIT SECTION

11
13
15
44

.ENABL AMA
.DSABL GBL

ADD UNIT SECTION

```

46 015142          BGNMOD
47          .SBTTL TEST1: RESET
48 015142          STATST <RESET>
   015142          040      122      105  T1MSG:: .ASCIZ / RESET/
49
50          ;*****
51          ;**
52          ;TEST DESCRIPTION-
53          ; CHECKS REGISTER ADDRESSING
54          ; CHECKS REGISTER BITS FOR RESET
55          ;TEST STEPS-
56          ; EXECUTE RESET INSTRUCTION
57          ; READ ALL REGISTERS
58          ; CHECK ALL VALUES
59          ;
60          ;--
61          ;*****
62
63 015152          BGNTST
   015152          T1::
64 015152          CKPNT          ; PRINT OUT TEST TITLE IF PNT SET
   015152          104421        TRAP          C0RFLA
   015154          022700        CMP          @PNT,R0          ; IS PNT FLAG SET?
   015160          001012        BNE          640             ; BRANCH IF NOT SET
   015162          012746        MOV          @T1MSG,-(SP)
   015166          012746        MOV          @PNTMSG,-(SP)
   015172          012746        MOV          @2,-(SP)
   015176          010600        MOV          SP,R0
   015200          104417        TRAP          C0PNTF
   015202          062706        ADD          @6,SP
   015206          005037        002532      640:  CLR          ERROR1          ; CLEAR ERROR COUNTER
65 015212          SETVEC        @4,@TRAP4,@PRI07          ; SET FOR BAD ADDRESS TRAP
   015212          012746        MOV          @PRI07,-(SP)
   015216          012746        MOV          @TRAP4,-(SP)
   015222          012746        MOV          @4,-(SP)
   015226          012746        MOV          @3,-(SP)
   015232          104437        TRAP          C0SVEC
   015234          062706        ADD          @10,SP
66 015240          50:  BREAK          ; ALLOW CONTROL C
   015240          104422        TRAP          C0BRK
67 015242          DEC          R1          ; DECREMENT DELAY COUNTER
68 015244          BNE          50         ; LOOP IF NOT DONE
69 015246          004537        016002      60:  JSR          R5,BRESET          ; GO DO BUS RESET
70
71          ; CHECK REGISTER ADDRESSING
72          ;
73 015252          005037        002522      CLR          TRPFLG          ; CLEAR TRAP FLAG
74 015256          012701        177777      MOV          @-1,R1          ; COUNTER IN R1
75 015262          013702        002274      MOV          QCMD,R2          ; REGISTER TABLE BASE TO R2
76 015266          005201        INC          R1          ; INCREMENT COUNTER
77 015270          022701        000014      CMP          @12.,R1          ; DONE YES?
78 015274          001423        BEQ          CONT          ; BRANCH IF DONE WITH CHECK
79 015276          012203        MOV          (R2)+,R3          ; READ REGISTER
80 015300          005737        002522      TST          TRPFLG          ; ANY TRAPS?
81 015304          001770        BEQ          100           ; BRANCH IF NO TRAPS
82
83          ; MUST HAVE BEEN BAD ADDRESS

```

TEST1: RESET

```

84
85 015306 005037 002522      ; CLR TRPFLG      ; CLEAR TRAP INDICATOR
86 015312 010237 002524      ; MOV R2,ADD     ; PUT OFFENDING ADDRESS IN MEM
87 015316 162737 000002 002524 ; SUB #2,ADD     ; CORRECT FOR AUTO INCREMENT
88 015324      ; ERRDF 1,MSG2,ERR2 ; DEVICE FATAL ERROR MESSAGE
   015324 104455      ; TRAP C#ERDF
   015326 000001      ; .WORD 1
   015330 004571      ; .WORD MSG2
   015332 011702      ; .WORD ERR2
89 015334      ; CLRVEC #4      ; RESET VECTOR
   015334 012700 000004      ; MOV #4,R0
   015340 104436      ; TRAP C#CVEC
90 015342      ; DOCLN          ; EXIT PASS IF BAD ADDRESS
   015342 104444      ; TRAP C#DCLN
91
92
93      ; NOW TEST ALL THE REGISTERS
94
95 015344      ; CONT:
96 015344      ; T1.1: BGNSUB
   015344 104402      ; TRAP C#BSUB
97 015346      ; INLOOP        ; CHECK FOR ERROR LOOP
   015346 104420      ; TRAP C#INLP
98 015350      ; BNCOMPLETE 11# ; BRANCH IF NOT ERROR LOOP
   015350 103002      ; BCC 11#
99 015352 004537 016002      ; JSR R5,BRESET ; IF ERROR LOOP, BRANCH
100 015356
101
102      ; TEST QCMD FOR EXPECTED RESULTS
103
104 015356 017737 164712 002526 ; MOV QCMD,VAL  ; READ QCMD REGISTER
105 015364 042737 177476 002526 ; BIC #177476,VAL ; MASK OUT UNDETERMINED BITS
106 015372 012737 000000 002530 ; MOV #0,EXP    ; ALL ZEROS TO EXPECTED
107 015400 023737 002530 002526 ; CMP EXP,VAL   ; COMPARE EXPECTED WITH VALUE
108 015406 001406      ; BEQ 30#      ; BRANCH IF OK
109
110      ; ERROR CONDITION 1
111
112 015410 012701 000000      ; MOV #0,R1    ; LOAD R1 WITH REGISTER NUMBER
113 015414      ; ERHRD 1,MSG3,ERR4 ; UNEXPECTED RESULT, TELL OPERATOR
   015414 104456      ; TRAP C#ERHRD
   015416 000001      ; .WORD 1
   015420 004632      ; .WORD MSG3
   015422 011776      ; .WORD ERR4
114 015424
115 015424      ; 30#: ENDSUB
   015424 104403      ; L10017: TRAP C#ESUB
116 015426      ; BGNSUB
   015426      ; T1.2:
   015426 104402      ; TRAP C#BSUB
117 015430      ; INLOOP        ; CHECK FOR ERROR LOOP
   015430 104420      ; TRAP C#INLP
118 015432      ; BNCOMPLETE 31# ; BRANCH IF NOT ERROR LOOP
   015432 103002      ; BCC 31#
119 015434 004537 016002      ; JSR R5,BRESET ; IF ERROR LOOP, BRANCH

```

TEST1: RESET

```

120 015440      310:
121             ;
122             ; TEST QVNT REGISTER
123             ;
124 015440 017737 164632 002526      MOV      @QVNT,VAL      ; READ QVNT REGISTER
125 015446 042737 177476 002526      BIC      @177476,VAL    ; MASK OUT UNDETERMINED BITS
126 015454 012737 000000 002530      MOV      @0,EXP        ; ALL ZEROS TO EXPECTED
127 015462 023737 002530 002526      CMP      EXP,VAL       ; COMPARE EXPECTED WITH VALUE
128 015470 001406                      BEQ      400           ; BRANCH IF OK
129
130             ; ERROR CONDITION 2
131             ;
132 015472 012701 000001      MOV      @1,R1         ; LOAD R1 WITH REGISTER NUMBER
133 015476      ERRHRD 2,MSG3,ERR4    ; UNEXPECTED RESULT, TELL OPERATOR
      015476 104456      TRAP      C@ERRHRD
      015500 000002      .WORD    2
      015502 004632      .WORD    MSG3
      015504 011776      .WORD    ERR4
134 015506      400:
135 015506      ENDSUB
      015506 104403      L10020: TRAP      C@ESUB
136 015510      BGNSUB
      015510      T1.3: TRAP      C@BSUB
137 015512 104402      INLOOP   ; CHECK FOR ERROR LOOP
      015512 104420      TRAP      C@INLP
138 015514      BNCOMPLETE 410      ; BRANCH IF NOT ERROR LOOP
      015514 103002      BCC      410
139 015516 004537 016002      JSR      R5,BRESET    ; IF ERROR LOOP, BRANCH
140 015522      410:
141             ;
142             ; TEST QINT REGISTER
143             ;
144 015522 017737 164552 002526      MOV      @QINT,VAL     ; READ QINT REGISTER
145 015530 012737 001000 002530      MOV      @1000,EXP     ; EXPECTED VALUE TO EXP
146 015536 023737 002530 002526      CMP      EXP,VAL       ; COMPARE EXPECTED WITH VALUE
147 015544 001406                      BEQ      500           ; BRANCH IF OK
148
149             ; ERROR CONDITION 3
150             ;
151 015546 012701 000002      MOV      @2,R1         ; LOAD R1 WITH REGISTER NUMBER
152 015552      ERRHRD 3,MSG3,ERR4    ; UNEXPECTED RESULT, TELL OPERATOR
      015552 104456      TRAP      C@ERRHRD
      015554 000003      .WORD    3
      015556 004632      .WORD    MSG3
      015560 011776      .WORD    ERR4
153 015562      500:
154 015562      ENDSUB
      015562 104403      L10021: TRAP      C@ESUB
155 015564      BGNSUB
      015564      T1.4: TRAP      C@BSUB
156 015566 104402      INLOOP   ; CHECK FOR ERROR LOOP
      015566 104420      TRAP      C@INLP
157 015570      BNCOMPLETE 510      ; BRANCH IF NOT ERROR LOOP

```

TEST1: RESET

```

158 015570 103002 016002      BCC 51#
159 015572 004537 016002      JSR R5,BRESET      ; IF ERROR LOOP, BRANCH
160
161      ; TEST QCTL REGISTER
162
163 015576 017737 164500 002526      MOV 8QCTL,VAL      ; READ QCTL REGISTER
164 015604 012737 000000 002530      MOV #0,EXP        ; ALL ZEROS TO EXP
165 015612 023737 002530 002526      CMP EXP,VAL       ; COMPARE EXPECTED WITH VALUE
166 015620 001406                BEQ 60#           ; BRANCH IF OK
167
168      ; ERROR CONDITION 4
169
170 015622 012701 000003      MOV #3,R1         ; LOAD R1 WITH REGISTER NUMBER
171 015626                ERRHRD 4,MSG3,ERR4 ; UNEXPECTED RESULT, TELL OPERATOR
    015626 104456                TRAP C#ERRHRD
    015630 000004                .WORD 4
    015632 004632                .WORD MSG3
    015634 011776                .WORD ERR4
172 015636
173 015636                L10022:
    015636 104403                TRAP C#ESUB
174 015640                BGNSUB
    015640 104402                T1.5:
175 015642                TRAP C#BSUB
    015642 104420                INLOOP
176 015644                TRAP C#INLP
    015644 103002 016002      BNCOMPLETE 61#    ; CHECK FOR ERROR LOOP
177 015646 004537 016002      BCC 61#           ; BRANCH IF NOT ERROR LOOP
178 015652                JSR R5,BRESET     ; IF ERROR LOOP, BRANCH
179
180      ; TEST QDMA REGISTER
181
182 015652 017737 164426 002526      MOV 8QDMA,VAL     ; READ QDMA REGISTER
183 015660 012737 000200 002530      MOV #200,EXP     ; EXPECTED VALUE TO EXP
184 015666 023737 002530 002526      CMP EXP,VAL      ; COMPARE EXPECTED WITH VALUE
185 015674 001406                BEQ 70#           ; BRANCH IF OK
186
187      ; ERROR CONDITION 5
188
189 015676 012701 000004      MOV #4,R1         ; LOAD R1 WITH REGISTER NUMBER
190 015702                ERRHRD 5,MSG3,ERR4 ; UNEXPECTED RESULT, TELL OPERATOR
    015702 104456                TRAP C#ERRHRD
    015704 000005                .WORD 5
    015706 004632                .WORD MSG3
    015710 011776                .WORD ERR4
191 015712
192 015712                L10023:
    015712 104403                TRAP C#ESUB
193
194      ; QBA REGISTER NOT CHECKED
195
196
197      ; QWC REGISTER NOT CHECKED

```

TEST1: RESET

```

198
199
200      ; QMTO REGISTER NOT CHECKED (TRI-STATE)
201      ;
202
203      015714      BGNSUB
204      015714      104402      T1.6:      TRAP      C#BSUB      ; CHECK FOR ERROR LOOP
205      015716      104420      INLOOP      ;
206      015720      103002      TRAP      C#INLP      ; BRANCH IF NOT ERROR LOOP
207      015722      004537      016002      BNCOMPLETE      71#      ; IF ERROR LOOP, BRANCH
208      015726      004537      016002      BCC      71#
209      015726      004537      016002      JSR      R5,BRESET
210      ;
211      015726      017737      164364      002526      ; TEST QMT1 REGISTER
212      015734      012737      000000      002530      ;
213      015742      023737      002530      002526      MOV      @QMT1,VAL      ; READ QMT1 REGISTER
214      015750      001406      ;
215      ;
216      ; ERROR CONDITION 6
217      ;
218      015752      012701      000011      ;
219      015756      104456      ERRHRD      6,MSG3,ERR4      ; LOAD R1 WITH REGISTER NUMBER
220      015760      000006      TRAP      C#ERRHRD      ; UNEXPECTED RESULT, TELL OPERATOR
221      015762      004632      .WORD      6
222      015764      011776      .WORD      MSG3
223      015766      104403      .WORD      ERR4
224      ;
225      ;
226      ;
227      015776      104432      016000      000020      80#:      CLRVEC      #4      ; CLEAR BAD ADDRESS TRAP
228      015776      104432      016000      000020      MOV      #4,R0
229      016000      000020      TRAP      C#CVEC
230      ;
231      ;
232      ;
233      016002      012701      003000      L10024:      ENDSUB
234      016002      012701      003000      TRAP      C#ESUB
235      016006      104422      ;
236      016010      005301      ; QVAD AND QVDA REGISTERS ARE NOT CHECKED
237      016012      001375      ;
238      016014      000005      ;
239      016016      000205      ;
240      ;
241      ;
242      ;
243      ;
244      ;
245      ;
246      ;
247      ;
248      ;
249      ;
250      ;
251      ;
252      ;
253      ;
254      ;
255      ;
256      ;
257      ;
258      ;
259      ;
260      ;
261      ;
262      ;
263      ;
264      ;
265      ;
266      ;
267      ;
268      ;
269      ;
270      ;
271      ;
272      ;
273      ;
274      ;
275      ;
276      ;
277      ;
278      ;
279      ;
280      ;
281      ;
282      ;
283      ;
284      ;
285      ;
286      ;
287      ;
288      ;
289      ;
290      ;
291      ;
292      ;
293      ;
294      ;
295      ;
296      ;
297      ;
298      ;
299      ;
300      ;
301      ;
302      ;
303      ;
304      ;
305      ;
306      ;
307      ;
308      ;
309      ;
310      ;
311      ;
312      ;
313      ;
314      ;
315      ;
316      ;
317      ;
318      ;
319      ;
320      ;
321      ;
322      ;
323      ;
324      ;
325      ;
326      ;
327      ;
328      ;
329      ;
330      ;
331      ;
332      ;
333      ;
334      ;
335      ;
336      ;
337      ;
338      ;
339      ;
340      ;
341      ;
342      ;
343      ;
344      ;
345      ;
346      ;
347      ;
348      ;
349      ;
350      ;
351      ;
352      ;
353      ;
354      ;
355      ;
356      ;
357      ;
358      ;
359      ;
360      ;
361      ;
362      ;
363      ;
364      ;
365      ;
366      ;
367      ;
368      ;
369      ;
370      ;
371      ;
372      ;
373      ;
374      ;
375      ;
376      ;
377      ;
378      ;
379      ;
380      ;
381      ;
382      ;
383      ;
384      ;
385      ;
386      ;
387      ;
388      ;
389      ;
390      ;
391      ;
392      ;
393      ;
394      ;
395      ;
396      ;
397      ;
398      ;
399      ;
400      ;
401      ;
402      ;
403      ;
404      ;
405      ;
406      ;
407      ;
408      ;
409      ;
410      ;
411      ;
412      ;
413      ;
414      ;
415      ;
416      ;
417      ;
418      ;
419      ;
420      ;
421      ;
422      ;
423      ;
424      ;
425      ;
426      ;
427      ;
428      ;
429      ;
430      ;
431      ;
432      ;
433      ;
434      ;
435      ;
436      ;
437      ;
438      ;
439      ;
440      ;
441      ;
442      ;
443      ;
444      ;
445      ;
446      ;
447      ;
448      ;
449      ;
450      ;
451      ;
452      ;
453      ;
454      ;
455      ;
456      ;
457      ;
458      ;
459      ;
460      ;
461      ;
462      ;
463      ;
464      ;
465      ;
466      ;
467      ;
468      ;
469      ;
470      ;
471      ;
472      ;
473      ;
474      ;
475      ;
476      ;
477      ;
478      ;
479      ;
480      ;
481      ;
482      ;
483      ;
484      ;
485      ;
486      ;
487      ;
488      ;
489      ;
490      ;
491      ;
492      ;
493      ;
494      ;
495      ;
496      ;
497      ;
498      ;
499      ;
500      ;
501      ;
502      ;
503      ;
504      ;
505      ;
506      ;
507      ;
508      ;
509      ;
510      ;
511      ;
512      ;
513      ;
514      ;
515      ;
516      ;
517      ;
518      ;
519      ;
520      ;
521      ;
522      ;
523      ;
524      ;
525      ;
526      ;
527      ;
528      ;
529      ;
530      ;
531      ;
532      ;
533      ;
534      ;
535      ;
536      ;
537      ;
538      ;
539      ;
540      ;
541      ;
542      ;
543      ;
544      ;
545      ;
546      ;
547      ;
548      ;
549      ;
550      ;
551      ;
552      ;
553      ;
554      ;
555      ;
556      ;
557      ;
558      ;
559      ;
560      ;
561      ;
562      ;
563      ;
564      ;
565      ;
566      ;
567      ;
568      ;
569      ;
570      ;
571      ;
572      ;
573      ;
574      ;
575      ;
576      ;
577      ;
578      ;
579      ;
580      ;
581      ;
582      ;
583      ;
584      ;
585      ;
586      ;
587      ;
588      ;
589      ;
590      ;
591      ;
592      ;
593      ;
594      ;
595      ;
596      ;
597      ;
598      ;
599      ;
600      ;
601      ;
602      ;
603      ;
604      ;
605      ;
606      ;
607      ;
608      ;
609      ;
610      ;
611      ;
612      ;
613      ;
614      ;
615      ;
616      ;
617      ;
618      ;
619      ;
620      ;
621      ;
622      ;
623      ;
624      ;
625      ;
626      ;
627      ;
628      ;
629      ;
630      ;
631      ;
632      ;
633      ;
634      ;
635      ;
636      ;
637      ;
638      ;
639      ;
640      ;
641      ;
642      ;
643      ;
644      ;
645      ;
646      ;
647      ;
648      ;
649      ;
650      ;
651      ;
652      ;
653      ;
654      ;
655      ;
656      ;
657      ;
658      ;
659      ;
660      ;
661      ;
662      ;
663      ;
664      ;
665      ;
666      ;
667      ;
668      ;
669      ;
670      ;
671      ;
672      ;
673      ;
674      ;
675      ;
676      ;
677      ;
678      ;
679      ;
680      ;
681      ;
682      ;
683      ;
684      ;
685      ;
686      ;
687      ;
688      ;
689      ;
690      ;
691      ;
692      ;
693      ;
694      ;
695      ;
696      ;
697      ;
698      ;
699      ;
700      ;
701      ;
702      ;
703      ;
704      ;
705      ;
706      ;
707      ;
708      ;
709      ;
710      ;
711      ;
712      ;
713      ;
714      ;
715      ;
716      ;
717      ;
718      ;
719      ;
720      ;
721      ;
722      ;
723      ;
724      ;
725      ;
726      ;
727      ;
728      ;
729      ;
730      ;
731      ;
732      ;
733      ;
734      ;
735      ;
736      ;
737      ;
738      ;
739      ;
740      ;
741      ;
742      ;
743      ;
744      ;
745      ;
746      ;
747      ;
748      ;
749      ;
750      ;
751      ;
752      ;
753      ;
754      ;
755      ;
756      ;
757      ;
758      ;
759      ;
760      ;
761      ;
762      ;
763      ;
764      ;
765      ;
766      ;
767      ;
768      ;
769      ;
770      ;
771      ;
772      ;
773      ;
774      ;
775      ;
776      ;
777      ;
778      ;
779      ;
780      ;
781      ;
782      ;
783      ;
784      ;
785      ;
786      ;
787      ;
788      ;
789      ;
790      ;
791      ;
792      ;
793      ;
794      ;
795      ;
796      ;
797      ;
798      ;
799      ;
800      ;
801      ;
802      ;
803      ;
804      ;
805      ;
806      ;
807      ;
808      ;
809      ;
810      ;
811      ;
812      ;
813      ;
814      ;
815      ;
816      ;
817      ;
818      ;
819      ;
820      ;
821      ;
822      ;
823      ;
824      ;
825      ;
826      ;
827      ;
828      ;
829      ;
830      ;
831      ;
832      ;
833      ;
834      ;
835      ;
836      ;
837      ;
838      ;
839      ;
840      ;
841      ;
842      ;
843      ;
844      ;
845      ;
846      ;
847      ;
848      ;
849      ;
850      ;
851      ;
852      ;
853      ;
854      ;
855      ;
856      ;
857      ;
858      ;
859      ;
860      ;
861      ;
862      ;
863      ;
864      ;
865      ;
866      ;
867      ;
868      ;
869      ;
870      ;
871      ;
872      ;
873      ;
874      ;
875      ;
876      ;
877      ;
878      ;
879      ;
880      ;
881      ;
882      ;
883      ;
884      ;
885      ;
886      ;
887      ;
888      ;
889      ;
890      ;
891      ;
892      ;
893      ;
894      ;
895      ;
896      ;
897      ;
898      ;
899      ;
900      ;
901      ;
902      ;
903      ;
904      ;
905      ;
906      ;
907      ;
908      ;
909      ;
910      ;
911      ;
912      ;
913      ;
914      ;
915      ;
916      ;
917      ;
918      ;
919      ;
920      ;
921      ;
922      ;
923      ;
924      ;
925      ;
926      ;
927      ;
928      ;
929      ;
930      ;
931      ;
932      ;
933      ;
934      ;
935      ;
936      ;
937      ;
938      ;
939      ;
940      ;
941      ;
942      ;
943      ;
944      ;
945      ;
946      ;
947      ;
948      ;
949      ;
950      ;
951      ;
952      ;
953      ;
954      ;
955      ;
956      ;
957      ;
958      ;
959      ;
960      ;
961      ;
962      ;
963      ;
964      ;
965      ;
966      ;
967      ;
968      ;
969      ;
970      ;
971      ;
972      ;
973      ;
974      ;
975      ;
976      ;
977      ;
978      ;
979      ;
980      ;
981      ;
982      ;
983      ;
984      ;
985      ;
986      ;
987      ;
988      ;
989      ;
990      ;
991      ;
992      ;
993      ;
994      ;
995      ;
996      ;
997      ;
998      ;
999      ;
1000      ;

```

L5

TEST1: RESET

240
241 016020
016020
016020 104401

ENDTST
L10016: TRAP C#ETST

TEST2: CHECK QMT1 REGISTER

```

243 .SBTTL TEST2: CHECK QMT1 REGISTER
244 016022 STATST <CHECK QMT1 REGISTER>
    016022 040 103 110 T2MSG:: .ASCIZ / CHECK QMT1 REGISTER/
245
246 ;*****
247 ;**
248 ;TEST DESCRIPTION-
249 ; CHECKS R/W BITS
250 ;TEST STEPS-
251 ; LOAD 1'S IN QMT1
252 ; READ AND CHECK
253 ; LOAD 0'S
254 ; READ AND CHECK
255 ;
256 ;--
257 ;*****
258
259 016050 BGNTST
    016050
260 016050 T2:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
    016050 104421 TRAP C#RFLA
    016052 022700 001000 CMP #PNT,RO ; IS PNT FLAG SET?
    016056 001012 BNE 64$ ; BRANCH IF NOT SET
    016060 012746 016022 MOV #T2MSG,-(SP)
    016064 012746 002270 MOV #PNTMSG,-(SP)
    016070 012746 000002 MOV #2,-(SP)
    016074 010600 MOV SP,RO
    016076 104417 TRAP C#PNTF
    016100 062706 000006 ADD #6,SP
    016104 005037 002532 64$: CLR ERROR1 ; CLEAR ERROR COUNTER
261 016110
    016110
    016110 104402 T2.1: TRAP C#BSUB
262 ;
263 ; FIRST CHECK WITH ONE'S
264 ;
265 016112 012737 000236 002530 MOV #236,EXP ; MOVE ALL 1'S TO EXPECTED
266 016120 013777 002530 164170 MOV EXP,BQMT1 ; MOVE EXPECTED TO QMT1
267 016126 017737 164164 002526 MOV BQMT1,VAL ; MOVE RESULT TO VALUE STORAGE
268 016134 042737 177541 002526 BIC #C236,VAL ; CLEAR UNDETERMINED BITS
269 016142 023737 002526 002530 CMP VAL,EXP ; IS THAT WHAT IS REALLY THERE?
270 016150 001406 BEQ 1$ ; BRANCH IF OK
271 ;
272 ; ERROR CONDITION 1
273 ;
274 016152 012701 000011 MOV #9,R1 ; REGISTER NUMBER FOR MESSAGE
275 016156 ERRHRD 1,MSG4,ERR4 ; GO REPORT ERROR TO OPERATOR
    016156 104456 TRAP C#ERRRD
    016160 000001 .WORD 1
    016162 004672 .WORD MSG4
    016164 011776 .WORD ERR4
276 016166
277 016166
    016166
    016166 104403 1$: ENDSUB
    016166 L10026: TRAP C#ESUB
278 016170
    016170 T2.2:

```

TEST2: CHECK QMT1 REGISTER

279	016170	104402			TRAP	C#BSUB	
280					:		
281					:	NOW CHECK WITH ZERO'S	
282	016172	012737	000000	002530	MOV	#0,EXP	: MOVE ALL 0'S TO EXPECTED
283	016200	013777	002530	164110	MOV	EXP,@QMT1	: MOVE EXPECTED TO QMT1
284	016206	017737	164104	002526	MOV	@QMT1,VAL	: MOVE RESULT TO VALUE STORAGE
285	016214	042737	177541	002526	BIC	@C236,VAL	: CLEAR UNDETERMINED BITS
286	016222	023737	002526	002530	CMP	VAL,EXP	: IS THAT WHAT IS REALLY THERE?
287	016230	001411			BEQ	2#	: BRANCH IF OK
288					:		
289					:	ERROR CONDITION 2	
290					:		
291	016232	012701	000011		MOV	#9,R1	: REGISTER # FOR MESSAGE
292	016236	012737	000000	002530	MOV	#0,EXP	: EXPECTED RESULT FOR MESSAGE
293	016244				ERRHRD	2,MSG5,ERR4	: GO REPORT ERROR TO OPERATOR
	016244	104456			TRAP	C#ERRHRD	
	016246	000002			.WORD	2	
	016250	004731			.WORD	MSG5	
	016252	011776			.WORD	ERR4	
294	016254				2#:		
295	016254				ENDSUB		
	016254				L10027:		
	016254	104403			TRAP	C#ESUB	
296	016256				ENDTST		
	016256				L10025:		
	016256	104401			TRAP	C#ETST	
297							

TEST3: CHECK QCLR RESET

```

299 .SBTTL TEST3: CHECK QCLR RESET
300 016260 STATST <CHECK QCLR RESET>
016260 040 103 110 T3MSG:: .ASCIZ / CHECK QCLR RESET/
301
302 ;.....
303 ;**
304 ;TEST DESCRIPTION-
305 ; CHECKS QCLR REGISTER BIT RESET
306 ; USES QHALT - QCLR LOOP-BACK
307 ;TEST STEPS-
308 ; LOAD ALL R/W BITS THAT ARE CLEARABLE (EXCEPT THREN8)
309 ; SET QMT1 QHALT BIT
310 ; READ ALL REGISTERS THAT WERE LOADED
311 ; CHECK FOR CLEAR (SEE EXPECTED VALUES IN TABLE EXP3)
312 ;
313 ;--
314 ;.....
315
316 016302 BGNTST
016302 T3::
317 016302 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
016302 104421 TRAP C1RFLA
016304 022700 001000 CMP @PNT,RO ; IS PNT FLAG SET?
016310 001012 BNE 648 ; BRANCH IF NOT SET
016312 012746 016260 MOV @T3MSG,-(SP)
016316 012746 002270 MOV @PNTMSG,-(SP)
016322 012746 000002 MOV @2,-(SP)
016326 010600 MOV SP,RO
016330 104417 TRAP C1PNTF
016332 062706 000006 ADD @6,SP
016336 005037 002532 648: CLR ERROR1 ; CLEAR ERROR COUNTER
016342 005077 163732 CLR @QINT ; CLEAR UPWRFL BIT FROM PREVIOUS ; V C.O ; V C.O
; TEST TO PREVENT UNEXPECTED ; V C.O
; INTERRUPT. ; V C.O
318
319 ;
320 ; LOAD ALL R/W BITS THAT ARE CLEARABLE
321 ;
322 ;
323 ;
324 016346 012777 177401 163720 MOV @177401,@QCMD ; SET ALL R/W BITS IN QCMD(NO IE);V C.O
325 016354 012777 177401 163714 MOV @177401,@QVNT ; SET ALL R/W BITS IN QVNT(NO IE);V C.O
326 016362 012777 000014 163712 MOV @000014,@QCTL ; SET ALL R/W BITS IN QCTL
327 016370 012777 037562 163706 MOV @037562,@QDMA ; SET ALL R/W BITS IN QDMA
328 016376 012777 000100 163674 MOV @000100,@QINT ; SET ALL R/W BITS IN QINT
329 016404 052777 000100 163662 BIS @PRSI,@QCMD ; NOW ENABLE INTERRUPTS ; V C.O
330 016412 052777 000100 163656 BIS @ACKIE,@QVNT ; ; V C.O
331 016420 012777 000236 163670 MOV @000236,@QMT1 ; ; V C.O
332 016426 052777 000100 163662 BIS @QHALT,@QMT1 ; RESET REGISTERS
333 ;
334 ; TEST QCMD REGISTER
335 ;
336 016434 017737 163634 002526 MOV @QCMD,VAL ; GET VALUE IN VAL
337 016442 042737 177477 002526 BIC @C300,VAL ; CLEAR UNTESTED BITS
338 016450 012737 000000 002530 MOV @0,EXP ; EXPECTED IN EXP
339 016456 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
340 016464 001406 BEQ 18 ; BRANCH IF OK
341 ;
342 ; ERROR CONDITION 1
343 ;

```

C6

TEST3: CHECK QCLR RESET

344	016466	012701	000000		MOV	#0,R1		; LOAD R1 WITH REGISTER NUMBER
345	016472				ERRHRD	1,MSG6,ERR4		; REPORT ERROR TO OPERATOR
	016472	104456			TRAP	C1ERRHRD		
	016474	000001			.WORD	1		
	016476	004771			.WORD	MSG6		
	016500	011776			.WORD	ERR4		
346	016502							
347								
348								
349								
350	016502	017737	163570	002526	MOV	QVNT,VAL		; GET VALUE IN VAL
351	016510	042737	177477	002526	BIC	#1C300,VAL		; CLEAR UNTESTED BITS
352	016516	012737	000000	002530	MOV	#0,EXP		; EXPECTED IN EXP
353	016524	023737	002530	002526	CMF	EXP,VAL		; GET EXPECTED IN VAL
354	016532	001406			BEQ	20		; IF OK, BRANCH
355								
356								
357								
358	016534	012701	000001		MOV	#1,R1		; LOAD R1 WITH REGISTER NUMBER
359	016540				ERRHRD	2,MSG6,ERR4		; REPORT ERROR TO OPERATOR
	016540	104456			TRAP	C1ERRHRD		
	016542	000002			.WORD	2		
	016544	004771			.WORD	MSG6		
	016546	011776			.WORD	ERR4		
360	016550							
361								
362								
363								
364	016550	017737	163524	002526	MOV	QINT,VAL		; GET VALUE IN VAL
365	016556	012737	001000	002530	MOV	#1000,EXP		; EXPECTED VALUE TO EXP
366	016564	023737	002530	002526	CMF	EXP,VAL		; COMPARE EXPECTED WITH VALUE
367	016572	001406			BEQ	30		; IF OK, BRANCH
368								
369								
370								
371	016574	012701	000002		MOV	#2,R1		; LOAD R1 WITH REGISTER NUMBER
372	016600				ERRHRD	3,MSG6,ERR4		; REPORT ERROR TO OPERATOR
	016600	104456			TRAP	C1ERRHRD		
	016602	000003			.WORD	3		
	016604	004771			.WORD	MSG6		
	016606	011776			.WORD	ERR4		
373	016610							
374								
375								
376								
377	016610	017737	163466	002526	MOV	QCTL,VAL		; GET VALUE IN VAL
378	016616	012737	000000	002530	MOV	#0,EXP		; ALL ZEROS TO EXPECTED
379	016624	023737	002530	002526	CMF	EXP,VAL		; COMPARE EXPECTED WITH VALUE
380	016632	001406			BEQ	40		; IF OK, BRANCH
381								
382								
383								
384	016634	012701	000003		MOV	#3,R1		; LOAD R1 WITH REGISTER NUMBER
385	016640				ERRHRD	4,MSG6,ERR4		; REPORT ERROR TO OPERATOR
	016640	104456			TRAP	C1ERRHRD		
	016642	000004			.WORD	4		
	016644	004771			.WORD	MSG6		

TEST3: CHECK QCLR RESET

```

016646 011776
386 016650
387
388
389
390 016650 017737 163430 002526
391 016656 012737 000200 002530
392 016664 023737 002530 002526
393 016672 001406
394
395
396
397 016674 012701 000004
398 016700
    016700 104456
    016702 000005
    016704 004771
    016706 011776
399 016710
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415 016710 017737 163402 002526
416 016716 012737 000000 002530
417 016724 023737 002530 002526
418 016732 001406
419
420
421
422 016734 012701 000011
423 016740
    016740 104456
    016742 000006
    016744 004771
    016746 011776
424 016750
425
426
427
428
429
430 016750
    016750
    016750 104401

```

```

        .WORD  ERR4
40:
;
; TEST QDMA REGISTER
;
        MOV     @QDMA,VAL           ; GET VALUE IN VAL
        MOV     @200,EXP           ; EXPECTED VALUE TO EXP
        CMP     EXP,VAL            ; COMPARE EXPECTED WITH VALUE
        BEQ     50                 ; IF OK, BRANCH
;
; ERROR CONDITION 5
;
        MOV     @4,R1              ; LOAD R1 WITH REGISTER NUMBER
        ERHRD   5,MSG6,ERR4       ; REPORT ERROR TO OPERATOR
        TRAP    C1ERHRD
        .WORD   5
        .WORD   MSG6
        .WORD   ERR4
50:
;
; QUBA REGISTER NOT TESTED
;
; QBA REGISTER NOT TESTED
;
; QMC REGISTER NOT TESTED
;
; QMT0 REGISTER NOT TESTED
;
; TEST QMT1 REGISTER
;
        MOV     @QMT1,VAL          ; GET VALUE IN VAL
        MOV     @0,EXP             ; ALL ZEROS TO EXPECTED
        CMP     EXP,VAL            ; COMPARE EXPECTED WITH VALUE
        BEQ     60                 ; IF OK, BRANCH
;
; ERROR CONDITION 6
;
        MOV     @9,R1              ; LOAD R1 WITH REGISTER NUMBER
        ERHRD   6,MSG6,ERR4       ; REPORT ERROR TO OPERATOR
        TRAP    C1ERHRD
        .WORD   6
        .WORD   MSG6
        .WORD   ERR4
60:
;
; QVAD AND QVDA REGISTERS ARE NOT CHECKED
;
        ENDTST
L10030: TRAP    C1ETST

```

TEST4: CHECK QCMD LO BITS (MOVING 1)

```

432 .SBTTL TEST4: CHECK QCMD LO BITS (MOVING 1)
433 016752 STATST <CHECK QCMD LO BITS (MOVING 1)>
016752 040 103 110 T4MSG:: .ASCIZ / CHECK QCMD LO BITS (MOVING 1)/
434
435 ;*****
436 ;**
437 ;TEST DESCRIPTION-
438 ; CHECKS THAT BITS 1-5 CAN BE LOADED
439 ; USES LDUCMD - LDGEVENT LOOP-BACK
440 ;TEST STEPS-
441 ; SET QMT1 FUNC = 2 (SELQCMD)
442 ; LOAD MOVING BIT WORD IN QMTO
443 ; READ QCMD, CHECK BITS 1-5
444 ; REPEAT FOR ALL 5 BITS
445 ;
446 ;--
447 ;*****
448
449 017012 BGNTST
017012
450 017012 T4:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
017012 104421 TRAP C#RFLA
017014 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
017020 001012 BNE 64# ; BRANCH IF NOT SET
017022 012746 016752 MOV #T4MSG,-(SP)
017026 012746 002270 MOV #PNTMSG,-(SP)
017032 012746 000002 MOV #2,-(SP)
017036 010600 MOV SP,R0
017040 104417 TRAP C#PNTF
017042 062706 000006 ADD #6,SP
017046 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
451 017052 INIT
017052 012777 000100 163236 ; INITIALIZE DEVICE
017060 013777 002520 163230 MOV #MHALT,@QMT1 ; INITIALIZE Q-BRIDGE
017066 005077 163206 MOV INITWORD,@QMT1 ; SET UP LOOPBACK OPTION
017072 005037 002532 CLR @QINT ; CLEAR QINT AFTER LOOPBACK ENABLED
452 017076 005037 002532 CLR ERROR1 ; CLEAR ERROR FLAG
453 017102 012701 000000 CLR ERROR1
454 017106 012702 000005 MOV #0,R1 ; REGISTER NUMBER TO R1
455 017112 012737 000002 002530 MOV #5,R2 ; NUMBER OF BITS TO CHECK
456 017120 052777 000010 163170 MOV #BIT1,EXP ; FIRST DATA PATTERN TO CHECK
457 ; BIS #SELQCMD,@QMT1 ; SELECT QCMD MODE IN QMT1
458 ;
459 ; TEST BITS 1-5 WITH MOVING ONE
460 ;
460 017126 BGNSUB
017126
461 017126 104402 T4.1: TRAP C#BSUB
017130 104404 10#: BGNSEG
017130 104404 TRAP C#BSEG
462 017132 013777 002530 163154 MOV EXP,@QMT0 ; MOVE EXPECTED TO REGISTER QMTO
463 017140 017737 163130 002526 MOV @QCMD,VAL ; READ QCMD AND MOVE TO VALUE
464 017146 042737 177701 002526 BIC #177701,VAL ; MASK OUT UNWANTED BITS
465 017154 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
466 017162 001414 BEQ 20# ; IF OK, BRANCH
467
468 ; ERROR CONDITION

```

TEST4: CHECK QCMD LO BITS (MOVING 1)

469									
470	017164	005737	002532		TST	ERROR1			; SEE IF FIRST ERROR
471	017170	001005			BNE	15:			; SKIP HEADER IF ALREADY PRINTED
472	017172				ERRHRD	1,MSG7,ERR7			; TELL OPERATOR ERROR
	017172	104456			TRAP	C:ERRHRD			
	017174	000001			.WORD	1			
	017176	005012			.WORD	MSG7			
	017200	012246			.WORD	ERR7			
473	017202	000402			BR	18:			; SKIP DETAIL LINE IF HEADER PRINTED
474	017204	004737	012366	15:	CALL	DETAIL			; PRINT DETAIL LINE
475	017210	005237	002532	18:	INC	ERROR1			; INCREMENT ERROR COUNT
476									
477									
478									
479	017214								
	017214			20:	ENDSEG				
	017214	104405		10000:					
480	017216	006337	002530		TRAP	C:ESUB			
481	017222	005302			ASL	EXP			; SHIFT BIT FOR NEXT TEST
482	017224	001341			DEC	R2			; DECREMENT LOOP COUNTER
483	017226				BNE	10:			; IF NOT DONE, BRANCH BACK
	017226				ENDSUB				
	017226	104403		L10032:					
484	017230	005737	002532		TRAP	C:ESUB			
485	017234	001410			TST	ERROR1			; ANY ERRORS
486	017236				BEQ	500:			; BRANCH IF NO ERRORS
	017236	012746	003333		PRINTX	#FORO			; LINE FEED
	017242	012746	000001		MOV	#FORO, -(SP)			
	017246	010600			MOV	#1, -(SP)			
	017250	104415			MOV	SP, R0			
	017252	062706	000004		TRAP	C:PNTX			
487	017256				ADD	#4, SP			
488	017256			500:					
	017256				ENDTST				
	017256	104401		L10031:					
					TRAP	C:ETST			

TESTS: CHECK QCMD LOW BITS (MOVING 0)

```

490 .SBTTL TESTS: CHECK QCMD LOW BITS (MOVING 0)
491 017260 STATST <CHECK QCMD LOW BITS (MOVING 0)>
    017260 040 103 110 TSMMSG:: .ASCIZ / CHECK QCMD LOW BITS (MOVING 0)/
492 ;*****
493 ;**
494 ;TEST DESCRIPTION-
495 ; CHECKS THAT BITS 1-5 CAN BE LOADED
496 ; USES LDUCMD - LDQEVENT LOOP-BACK
497 ;TEST STEPS-
498 ; SET QMT1 FUNC = 2 (SELQCMD)
499 ; LOAD MOVING BIT WORD IN QMTO
500 ; READ QCMD, CHECK BITS 1-5
501 ; REPEAT FOR ALL 5 BITS
502 ;
503 ;
504 ;--
505 ;*****
506
507 017320 BGNTST
    017320 TS::
508 017320 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
    017320 TRAP C#RFLA
    017322 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
    017326 001012 BNE 64# ; BRANCH IF NOT SET
    017330 012746 017260 MOV #TSMMSG,-(SP)
    017334 012746 002270 MOV #PNTMSG,-(SP)
    017340 012746 000002 MOV #2,-(SP)
    017344 010600 MOV SP,R0
    017346 104417 TRAP C#PNTF
    017350 062706 000006 ADD #6,SP
    017354 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
509 017360 INIT
    017360 012777 000100 162730 ;INITIALIZE DEVICE
    017366 013777 002520 162722 MOV #MHALT,QMNT1 ;INITIALIZE Q-BRIDGE
    017374 005077 162700 MOV INITWORD,QMNT1 ;SET UP LOOPBACK OPTION
    017400 005037 002532 CLR QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
    017404 012701 000000 CLR ERROR1 ;CLEAR ERROR FLAG
510 017410 012702 000005 MOV #0,R1 ; REGISTER NUMBER TO R1
511 017414 012703 000002 MOV #5,R2 ; NUMBER OF BITS TO CHECK
512 017420 010337 002530 MOV #BIT1,R3 ; INITIAL DATA PATTERN TO R3
513 017424 005137 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
514 017430 052777 000010 162660 COM EXP ; COMPLEMENT FOR MOVING 0
515 017436 014402 002530 BIS #SELQCMD,QMNT1 ; SELECT QCMD MODE IN QMT1
516 ;
517 ; TEST BITS 1-5 WITH MOVING ZERO
518 ;
519 017436 BGNSUB
    017436 TS.1:
    017440 104402 104:
    017440 104404 TRAP C#BSUB
520 017442 042737 177701 002530 TRAP C#BSEG
    017444 013777 002530 162636 BIC #177701,EXP ; CLEAR UNTESTED BITS
    017446 017737 162612 002526 MOV EXP,QMTO ; MOVE EXPECTED TO REGISTER QMTO
    017448 042737 177701 002526 MOV QCMD,VAL ; READ QCMD AND MOVE TO VALUE
    017450 023737 002530 002526 BIC #177701,VAL ; MASK OUT UNDETERMINED BITS
    017452 001414 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
521 017500 BEQ 20# ; IF OK, BRANCH

```


TESTS: CHECK QCMD LOW BITS (MOVING 0)

```

527
528
529
530 017502 005737 002532
531 017506 001005
532 017510
    017510 104456
    017512 000001
    017514 005054
    017516 012246
533 017520 000402
534 017522 004737 012366
535 017526 005237 002532
536
537
538
539 017532
    017532
    017532 104405
540 017534 006303
541 017536 010337 002530
542 017542 005137 002530
543 017546 005302
544 017550 001333
545 017552
    017552
    017552 104403
546 017554 005737 002532
547 017560 001410
548 017562
    017562 012746 003333
    017566 012746 000001
    017572 010600
    017574 104415
    017576 062706 000004
549 017602
550 017602
    017602
    017602 104401

```

```

; ERROR CONDITION
;
; TST ERROR1 ; SEE IF FIRST ERROR
; BNE 15; ; SKIP HEADER IF ALREADY PRINTED
; ERRMRD 1,MSG8,ERR7 ; TELL OPERATOR ERROR
; TRAP C#ERRMRD
; .WORD 1
; .WORD MSG8
; .WORD ERR7
; BR 18; ; SKIP DETAIL LINE IF HEADER PRINTED
15;: CALL DETAIL ; PRINT DETAIL LINE
18;: INC ERROR1 ; INCREMENT ERROR COUNT
;
; END ERROR CONDITION
;
20;: ENDSEG
10000;:
; TRAP C#ESEG
; ASL R3 ; SHIFT BIT FOR NEXT TEST
; MOV R3,EXP ; PLACE PATTERN IN EXPECTED
; COM EXP ; COMPLIMENT FOR MOVING 0
; DEC R2 ; DECREMENT LOOP COUNTER
; BNE 10; ; IF NOT DONE, BRANCH BACK
; ENDSUB
L10034:
; TRAP C#ESUB
; TST ERROR1 ; ANY ERRORS
; BEQ 500; ; BRANCH IF NO ERRORS
; PRINTX #FORO ; LINE FEED
; MOV #FORO,-(SP)
; MOV #1,-(SP)
; MOV SP,R0
; TRAP C#PNTX
; ADD #4,SP
500;:
L10033:
; TRAP C#ETST

```

TEST6: CHECK QCMD HI BITS (MOVING 1)

```

552 .SBTTL TEST6: CHECK QCMD HI BITS (MOVING 1)
553 017604 STATST <CHECK QCMD HI BITS (MOVING 1)>
    017604 040 103 110 T6MSG:: .ASCIZ / CHECK QCMD HI BITS (MOVING 1)/
554
555 ;*****
556 ;**
557 ;TEST DESCRIPTION-
558 ; CHECKS THAT BITS 8-15 CAN BE LOADED
559 ;TEST STEPS-
560 ; LOAD MOVING BIT WORD IN QCMD
561 ; READ QCMD, CHECK BITS 8-15
562 ; REPEAT FOR ALL 8 BITS
563 ;
564 ;-
565 ;*****
566
567 017644 BGNTST
    017644
568 017644 T6:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
    017644 104421 TRAP C#RFLA
    017646 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
    017652 001012 BNE 64# ; BRANCH IF NOT SET
    017654 012746 017604 MOV #T6MSG,-(SP)
    017660 012746 002270 MOV #PNTMSG,-(SP)
    017664 012746 000002 MOV #2,-(SP)
    017670 010600 MOV SP,R0
    017672 104417 TRAP C#PNTF
    017674 062706 000006 ADD #6,SP
    017700 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
569 017704 INIT
    017704 012777 000100 162404 ;INITIALIZE DEVICE
    017712 013777 002520 162376 MOV #MHALT,BQMT1 ;INITIALIZE Q-BRIDGE
    017720 005077 162354 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
    017724 005037 002532 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
    017730 012701 000000 CLR ERROR1 ;CLEAR ERROR FLAG
    017734 012702 000010 MOV #0,R1 ; REGISTER NUMBER TO R1
    017740 012737 000400 002530 MOV #8,R2 ; NUMBER OF BITS TO CHECK
    017740 012737 000400 002530 MOV #BIT#EXP ; FIRST DATA PATTERN TO CHECK
573
574 ; TEST BITS 8-15 WITH MOVING ONE
575 ;
576 017746 BGNSUB
    017746
    017746 104402 T6.1: TRAP C#BSUB
577 017750 104404 10#: BGNSEG TRAP C#BSEG
    017750 104404 TRAP C#BSEG
578 017752 013777 002530 162314 MOV EXP,BQCMD ; MOVE EXPECTED TO REGISTER QCMD
579 017760 017737 162310 002526 MOV BQCMD,VAL ; READ QCMD AND MOVE TO VALUE
580 017766 042737 000377 002526 BIC #377,VAL ; MASK OUT UNTESTED BITS
581 017774 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
582 020002 001414 BEQ 20# ; IF OK, BRANCH
583
584 ; ERROR CONDITION
585 ;
586 020004 005737 002532 TST ERROR1 ; SEE IF FIRST ERROR
587 020010 001005 BNE 15# ; SKIP HEADER IF ALREADY PRINTED
588 020012 ERRHRD 1,MSG9,ERR7 ; TELL OPERATOR ERROR

```

TEST6: CHECK QCMD HI BITS (MOVING 1)

```

020012 104456          TRAP  C#ERHRD
020014 000001          .WORD 1
020016 005116          .WORD MSG9
020020 012246          .WORD ERR7
589 020022 000402          BR 18#
590 020024 004737 012366 15#: CALL  DETAIL
591 020030 005237 002532 18#: INC  ERROR1
592
593
594
595 020034
020034
020034 104405          TRAP  C#ESEG
596 020036 006337 002530  ASL  EXP
597 020042 005302          DEC  R2
598 020044 001341          BNE 10#
599 020046          ENDSUB
                                ; SKIP DETAIL LINE IF HEADER PRINTED
                                ; PRINT DETAIL LINE
                                ; INCREMENT ERROR COUNT
                                ;
                                ; END ERROR CONDITION
                                ;
20#: ENDSEG
10000#:
L10036: TRAP  C#ESUB
        TST  ERROR1
        BEQ  500#
        PRINTX #FORO
        MOV  #FORO, -(SP)
        MOV  #1, -(SP)
        MOV  SP, R0
        TRAP C#PNTX
        ADD  #4, SP
                                ; SHIFT BIT FOR NEXT TEST
                                ; DECREMENT LOOP COUNTER
                                ; IF NOT DONE, BRANCH BACK
                                ;
                                ; ANY ERRORS
                                ; BRANCH IF NO ERRORS
                                ; LINE FEED
500#:
L10035: TRAP  C#ETST
600 020050 005737 002532
601 020054 001410
602 020056
020056 012746 003333
020062 012746 000001
020066 010600
020070 104415
020072 062706 000004
603 020076
604 020076
020076
020076 104401

```

TEST7: CHECK QCMD HI BITS (MOVING 0)

```

606 .SBTTL TEST7: CHECK QCMD HI BITS (MOVING 0)
607 020100 STATST <CHECK QCMD HI BITS (MOVING 0)>
020100 040 103 110 T7MSG:: .ASCIZ / CHECK QCMD HI BITS (MOVING 0)/
608 ;*****
609 ;**
610 ;TEST DESCRIPTION-
611 ; CHECKS THAT BITS 8-15 CAN BE LOADED
612 ;TEST STEPS-
613 ; LOAD MOVING BIT WORD IN QCMD
614 ; READ QCMD, CHECK BITS 8-15
615 ; REPEAT FOR ALL 8 BITS
616 ;
617 ;
618 ;--
619 ;*****
620
621 020140 BGNTST
020140
622 020140 T7:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
020140 104421 TRAP C#RFLA
020142 022700 001000 CMP #PNT,RO ; IS PNT FLAG SET?
020146 001012 BNE 64# ; BRANCH IF NOT SET
020150 012746 020100 MOV #T7MSG,-(SP)
020154 012746 002270 MOV #PNTMSG,-(SP)
020160 012746 000002 MOV #2,-(SP)
020164 010600 MOV SP,RO
020166 104417 TRAP C#PNTF
020170 062706 000006 ADD #6,SP
020174 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
623 020200 INIT
020200 012777 000100 162110 ;INITIALIZE DEVICE
020206 013777 002520 162102 MOV #MHALT,BQMT1 ;INITIALIZE Q-BRIDGE
020214 005077 162060 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
020220 005037 002532 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
624 020224 012701 000000 CLR ERROR1 ;CLEAR ERROR FLAG
625 020230 012702 000010 MOV #0,R1 ; REGISTER NUMBER TO R1
626 020234 012703 000400 MOV #8,R2 ; NUMBER OF BITS TO CHECK
627 020240 010337 002530 MOV #BIT8,R3 ; INITIAL DATA PATTERN TO R3
628 020244 005137 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
629 COM EXP ; COMPLEMENT FOR MOVING 0
630 ;
631 ; TEST BITS 8-15 WITH MOVING ZERO
632 ;
633 020250 BGNSUB
020250
020250 104402 T7.1: TRAP C#BSUB
634 020252 104404 10#: BGNSEG TRAP C#BSEG
020254 042737 000377 002530 BIC #377,EXP ; MASK OUT UNTESTED BITS
635 020262 013777 002530 162004 MOV EXP,BQCMD ; MOVE EXPECTED TO REGISTER QCMD
636 020270 017737 162000 002526 MOV BQCMD,VAL ; READ QCMD AND MOVE TO VALUE
637 020276 042737 000377 002526 BIC #377,VAL ; MASK OUT UNTESTED BITS
638 020304 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
639 020312 001414 BEQ 20# ; IF OK, BRANCH
640 ;
641 ; ERROR CONDITION
642 ;

```

TEST7: CHECK QCMD HI BITS (MOVING 0)

```

643 020314 005737 002532      TST      ERROR1      ; SEE IF FIRST ERROR
644 020320 001005              BNE      15$         ; SKIP HEADER IF ALREADY PRINTED
645 020322 104456              ERRHRD   1,MSG10,ERR7 ; TELL OPERATOR ERROR
      020322 104456              TRAP    C$ERRHRD
      020324 000001              .WORD   1
      020326 005161              .WORD   MSG10
      020330 012246              .WORD   ERR7
646 020332 000402              BR       18$         ; SKIP DETAIL LINE IF HEADER PRINTED
647 020334 004737 012366      15$:    CALL    DETAIL ; PRINT DETAIL LINE
648 020340 005237 002532      18$:    INC     ERROR1 ; INCREMENT ERROR COUNT
649
650                          ; END ERROR CONDITION
651
652 020344 104405              20$:    ENDSEG
      020344 006303              10000$: TRAP    C$ESEG
653 020346 010337 002530      ASL     R3
654 020350 005137 002530      MOV     R3,EXP      ; SHIFT BIT FOR NEXT TEST
655 020354 005302              COM     EXP         ; PLACE PATTERN IN EXPECTED
656 020360 001333              DEC     R2         ; COMPLIMENT FOR MOVING 0
657 020362 001333              BNE     10$         ; DECREMENT LOOP COUNTER
658 020364 104403              ENDSUB             ; IF NOT DONE, BRANCH BACK
      020364 104403              L10040: TRAP    C$ESUB
659 020366 005737 002532      TST     ERROR1      ; ANY ERRORS
660 020372 001410              BEQ     500$        ; BRANCH IF NO ERRORS
661 020374 012746 003333      PRINTX #FORO,-(SP) ; LINE FEED
      020374 012746 000001      MOV     #1,-(SP)
      020400 010600              MOV     SP,R0
      020404 104415              TRAP    C$PNTX
      020410 062706 000004      ADD     #4,SP
662 020414 500$:
663 020414 104401              ENDTST
      020414 104401              L10037: TRAP    C$ETST

```

TEST8: CHECK QVNT LO BITS (MOVING 1)

```

665 .SBTTL TEST8: CHECK QVNT LO BITS (MOVING 1)
666 020416 STATST <CHECK QVNT LO BITS (MOVING 1)>
667 020416 040 103 110 T8MSG:: .ASCIZ / CHECK QVNT LO BITS (MOVING 1)/
668 ;*****
669 ;**
670 ;TEST DESCRIPTION-
671 ; CHECKS THAT BITS 1-5 CAN BE LOADED
672 ; USES LDUCMD - LDQEVENT LOOP-BACK
673 ;TEST STEPS-
674 ; SET QMT1 FUNC = 1 (SELQVNT)
675 ; LOAD MOVING BIT WORD IN QMTO
676 ; READ QVNT, CHECK BITS 1-5
677 ; REPEAT FOR ALL 5 BITS
678 ;
679 ;--
680 ;*****
681
682 020456 BGNTST
683 020456 T8:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
020456 104421 TRAP C#RFLA ; IS PNT FLAG SET?
020460 022700 001000 CMP #PNT,R0 ; BRANCH IF NOT SET
020464 001012 BNE 64#
020466 012746 020416 MOV #T8MSG,-(SP)
020472 012746 002270 MOV #PNTMSG,-(SP)
020476 012746 000002 MOV #2,-(SP)
020502 010600 MOV SP,R0
020504 104417 TRAP C#PNTF
020506 062706 000006 ADD #6,SP
684 020512 005037 002532 64# CLR ERROR1 ; CLEAR ERROR COUNTER
020516 INIT
020516 012777 000100 161572 ;INITIALIZE DEVICE
020524 013777 002520 161564 MOV #MQHALT,@QMT1 ;INITIALIZE Q-BRIDGE
020532 005077 161542 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
020536 005037 002532 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
685 020542 012701 000001 CLR ERROR1 ;CLEAR ERROR FLAG
686 020546 012702 000005 MOV #1,R1 ; REGISTER NUMBER TO R1
687 020552 012737 000002 002530 MOV #5,R2 ; NUMBER OF BITS TO CHECK
688 020560 052777 000004 161530 MOV #BIT1,EXP ; FIRST DATA PATTERN TO CHECK
689 BIS #SELQEVENT,@QMT1 ; SELECT QVNT MODE IN QMT1
690 ;
691 ; TEST BITS 1-5 WITH MOVING ONE
692 ;
692 020566 BGNSUB
693 020566 104402 T8.1: TRAP C#BSUB
020570 104404 10# BGNSEG
020572 013777 002530 161514 TRAP C#BSEG
694 020600 017737 161472 002526 MOV EXP,@QMT0 ; MOVE EXPECTED TO REGISTER QMTO
695 020606 042737 177701 002526 MOV @QVNT,VAL ; READ QVNT AND MOVE TO VALUE
696 020614 023737 002530 002526 BIC #177701,VAL ; MASK OUT UNTESTED BITS
697 020622 001414 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
698 BEQ 20# ; IF OK, BRANCH
699 ;
700 ; ERROR CONDITION
701 ;

```

TEST8: CHECK QVNT LO BITS (MOVING 1)

```

702 020624 005737 002532          TST      ERROR1          ; SEE IF FIRST ERROR
703 020630 001005                   BNE      15$             ; SKIP HEADER IF ALREADY PRINTED
704 020632                   ERRHRD   1,MSG11,ERR7    ; TELL OPERATOR ERROR
      020632 104456                   TRAP    C$ERHRD
      020634 000001                   .WORD   1
      020636 005224                   .WORD   MSG11
      020640 012246                   .WORD   ERR7
705 020642 000402                   BR       18$             ; SKIP DETAIL LINE IF HEADER PRINTED
706 020644 004737 012366          15$:   CALL    DETAIL    ; PRINT DETAIL LINE
707 020650 005237 002532          18$:   INC     ERROR1    ; INCREMENT ERROR COUNT
708
709                               ; END ERROR CONDITION
710
711 020654                   20$:   ENDSEG
      020654                   10000$:
      020654 104405                   TRAP    C$ESEG
712 020656 006337 002530                   ASL     EXP
713 020662 005302                   DEC     R2
714 020664 001341                   BNE     10$             ; SHIFT BIT FOR NEXT TEST
715 020666                   ENDSUB                   ; DECREMENT LOOP COUNTER
      020666 104403                   L10042:                   ; IF NOT DONE, BRANCH BACK
716 020670 005737 002532          TRAP    C$ESUB
717 020674 001410                   TST     ERROR1          ; ANY ERRORS
718 020676                   BEQ     500$            ; BRANCH IF NO ERRORS
      020676 012746 003333          PRINTX  #FORO
      020702 012746 000001          MOV     #FORO, -(SP)
      020706 010600                   MOV     #1, -(SP)
      020710 104415                   MOV     SP, R0
      020712 062706 000004          TRAP    C$PNTX
719 020716                   ADD     #4, SP
720 020716                   500$:   ENDTST
      020716 104401                   L10041:                   TRAP    C$ETST

```

TEST9: CHECK QVNT LOW BITS (MOVING 0)

```

722 .SBTTL TEST9: CHECK QVNT LOW BITS (MOVING 0)
723 020720 STATST <CHECK QVNT LOW BITS (MOVING 0)>
020720 040 103 110 T9MSG:: .ASCIZ / CHECK QVNT LOW BITS (MOVING 0)/
724
725 ;*****
726 ;**
727 ;TEST DESCRIPTION-
728 ; CHECKS THAT BITS 1-5 CAN BE LOADED
729 ; USES LDUCMD - LDQEVENT LOOP-BACK
730 ;TEST STEPS-
731 ; SET QMT1 FUNC = 1 (SELQVNT)
732 ; LOAD MOVING BIT WORD IN QMTO
733 ; READ QVNT, CHECK BITS 1-5
734 ; REPEAT FOR ALL 5 BITS
735 ;
736 ;--
737 ;*****
738
739 020760          BGNTST
020760          T9::
740 020760          CKPNT          ; PRINT OUT TEST TITLE IF PNT SET
020760 104421          TRAP          C#RFLA
020762 022700 001000      CMP          @PNT,RO          ; IS PNT FLAG SET?
020766 001012          BNE          648          ; BRANCH IF NOT SET
020770 012746 020720      MOV          @T9MSG,-(SP)
020774 012746 002270      MOV          @PNTMSG,-(SP)
021000 012746 000002      MOV          @2,-(SP)
021004 010600          MOV          SP,RO
021006 104417          TRAP          C#PNTF
021010 062706 000006      ADD          @6,SP
021014 005037 002532      648: CLR          ERROR1          ; CLEAR ERROR COUNTER
741 021020          INIT
          ;INITIALIZE DEVICE
021020 012777 000100 161270      MOV          @QMHALT,@QMT1          ; INITIALIZE Q-BRIDGE
021026 013777 002520 161262      MOV          INITWORD,@QMT1          ; SET UP LOOPBACK OPTION
021034 005077 161240          CLR          @QINT          ; CLEAR QINT AFTER LOOPBACK ENABLED
021040 005037 002532          CLR          ERROR1          ; CLEAR ERROR FLAG
742
743 021044 012701 000001          MOV          @1,R1          ; REGISTER NUMBER TO R1
744
745 021050          MOV          @5,R2          ; NUMBER OF BITS TO CHECK
746 021054 012703 000002          MOV          @BIT1,R3          ; INITIAL DATA PATTERN TO R3
747 021060 010337 002530          MOV          R3,EXP          ; MOVE BIT PATTERN TO EXPECTED
748 021064 005137 002530          COM          EXP          ; COMPLEMENT FOR MOVING 0
749 021070 052777 000004 161220      BIS          @SELQEVENT,@QMT1          ; SELECT QVNT MODE IN QMT1
750
751 ; TEST BITS 1-5 WITH MOVING ZERO
752 ;
753 021076          BGNSUB
021076          T9.1:
021076 104402          TRAP          C#BSUB
754 021100          108:
021100 104404          TRAP          C#BSEG
755 021102 042737 177701 002530      BIC          @177701,EXP          ; MASK OUT UNTESTED BITS
756 021110 013777 002530 161176      MOV          EXP,@QMT0          ; MOVE EXPECTED TO REGISTER QMTO
757 021116 017737 161154 002526      MOV          @QVNT,VAL          ; READ QVNT AND MOVE TO VALUE
758 021124 042737 177701 002526      BIC          @177701,VAL          ; MASK OUT UNTESTED BITS

```


TEST9: CHECK QVNT LOW BITS (MOVING 0)

```

759 021132 023737 002530 002526      CMP      EXP,VAL      ; COMPARE EXPECTED WITH VALUE
760 021140 001414                      BEQ      200          ; IF OK, BRANCH
761                                     ;
762                                     ; ERROR CONDITION
763                                     ;
764 021142 005737 002532      TST      ERROR1      ; SEE IF FIRST ERROR
765 021146 001005      BNE      150          ; SKIP HEADER IF ALREADY PRINTED
766 021150                      ERRHRD  1,MSG12,ERR7  ; TELL OPERATOR ERROR
      021150 104456      TRAP     C0ERHRD
      021152 000001      .WORD   1
      021154 005266      .WORD   MSG12
      021156 012246      .WORD   ERR7
767 021160 000402      BR       180          ; SKIP DETAIL LINE IF HEADER PRINTED
768 021162 004737 012366      150:    CALL    DETAIL  ; PRINT DETAIL LINE
769 021166 005237 002532      180:    INC     ERROR1  ; INCREMENT ERROR COUNT
770                                     ;
771                                     ; END ERROR CONDITION
772                                     ;
773 021172                      200:    ENDSEG
      021172                      100000:
      021172 104405      TRAP     C0ESEG
774 021174 006303      ASL     R3
775 021176 010337 002530      MOV     R3,EXP
776 021202 005137 002530      COM    EXP
777 021206 005302      DEC    R2
778 021210 001333      BNE    100
779 021212                      ENDSUB
      021212                      L10044:
      021212 104403      TRAP     C0ESUB
780 021214 005737 002532      TST    ERROR1
781 021220 001410      BEQ    500
782 021222                      PRINTX #FORO
      021222 012746 003333      MOV    #FORO,-(SP)
      021226 012746 000001      MOV    #1,-(SP)
      021232 010600      MOV    SP,R0
      021234 104415      TRAP   C0PNTX
      021236 062706 000004      ADD    #4,SP
783 021242                      500:
784 021242                      ENDTST
      021242                      L10043:
      021242 104401      TRAP    C0ETST

```

TEST10: CHECK QVNT MI BITS (MOVING 1)

```

786 .SBTTL TEST10: CHECK QVNT MI BITS (MOVING 1)
787 021244 STATST <CHECK QVNT MI BITS (MOVING 1)>
021244 040 103 110 T10MSG:: .ASCIZ / CHECK QVNT MI BITS (MOVING 1)/
788
789 ;*****
790 ;**
791 ;TEST DESCRIPTION-
792 ; CHECKS THAT BITS 8-15 CAN BE LOADED
793 ;TEST STEPS-
794 ; LOAD MOVING BIT WORD IN QVNT
795 ; READ QVNT, CHECK BITS 8-15
796 ; REPEAT FOR ALL 8 BITS
797 ;
798 ;--
799 ;*****
800
801 021304 BGNTST
021304
802 021304 T10:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
021304 104421 TRAP C#RFLA
021306 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
021312 001012 BNE 64# ; BRANCH IF NOT SET
021314 012746 021244 MOV #T10MSG,-(SP)
021320 012746 002270 MOV #PNTMSG,-(SP)
021324 012746 000002 MOV #2,-(SP)
021330 010600 MOV SP,R0
021332 104417 TRAP C#PNTF
021334 062706 000006 ADD #6,SP
021340 005037 002532 64# : CLR ERROR1 ; CLEAR ERROR COUNTER
803 021344 INIT
;INITIALIZE DEVICE
021344 012777 000100 160744 MOV #MHALT,BQMT1 ;INITIALIZE Q-BRIDGE
021352 013777 002520 160736 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
021360 005077 160714 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
021364 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
804 021370 012701 000001 MOV #1,R1 ; REGISTER NUMBER TO R1
805 021374 012702 000010 MOV #8,R2 ; NUMBER OF BITS TO CHECK
806 021400 012737 000400 002530 MOV #BIT8,EXP ; FIRST DATA PATTERN TO CHECK
807
808 ; TEST BITS 8-15 WITH MOVING ONE
809 ;
810 021406 BGNSUB
021406
811 021406 104402 T10.1: TRAP C#BSUB
021410 104404 10# : BGNSEG TRAP C#BSEG
812 021412 013777 002530 160656 MOV EXP,BQVNT ; MOVE EXPECTED TO REGISTER QVNT
813 021420 017737 160652 002526 MOV BQVNT,VAL ; READ QVNT AND MOVE TO VALUE
814 021426 042737 000377 002526 BIC #377,VAL ; MASK OUT UNTESTED BITS
815 021434 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
816 021442 001414 BEQ 20# ; IF OK, BRANCH
817
818 ; ERROR CONDITION
819 ;
820 021444 005737 002532 TST ERROR1 ; SEE IF FIRST ERROR
821 021450 001005 BNE 15# ; SKIP HEADER IF ALREADY PRINTED
822 021452 ERRHRD 1,MSG13,ERR7 ; TELL OPERATOR ERROR

```

TEST10: CHECK QVNT MI BITS (MOVING 1)

021452	104456		TRAP	C0ERHRD	
021454	000001		.WORD	1	
021456	005330		.WORD	MSG13	
021460	012246		.WORD	ERR7	
823	021462	000402	BR	180	: SKIP DETAIL LINE IF HEADER PRINTED
824	021464	004737	CALL	DETAIL	: PRINT DETAIL LINE
825	021470	005237	INC	ERROR1	: INCREMENT ERROR COUNT
826					
827					
828					
829	021474		200:	ENDSEG	
	021474		100000:		
	021474	104405	TRAP	C0ESEG	
830	021476	006337	ASL	EXP	: SHIFT BIT FOR NEXT TEST
831	021502	005302	DEC	R2	: DECREMENT LOOP COUNTER
832	021504	001341	BNE	100	: IF NOT DONE, BRANCH BACK
833	021506		ENDSUB		
	021506		L10046:		
	021506	104403	TRAP	C0ESUB	
834	021510	005737	TST	ERROR1	: ANY ERRORS
835	021514	001410	BEG	5000	: BRANCH IF NO ERRORS
836	021516		PRINTX	#FORO	: LINE FEED
	021516	012746	MOV	#FORO, -(SP)	
	021522	012746	MOV	#1, -(SP)	
	021526	010600	MOV	SP, R0	
	021530	104415	TRAP	C0PNTX	
	021532	062706	ADD	#4, SP	
837	021536		5000:		
838	021536		ENDTST		
	021536		L10045:		
	021536	104401	TRAP	C0ETST	

TEST11: CHECK QVNT HI BITS (MOVING 0)

```

840 .SBTTL TEST11: CHECK QVNT HI BITS (MOVING 0)
841 021540 STATST <CHECK QVNT HI BITS (MOVING 0)>
      021540 040 103 110 T11MSG:: .ASCIZ / CHECK QVNT HI BITS (MOVING 0)/
842
843 ;*****
844 ;**
845 ;TEST DESCRIPTION-
846 ; CHECKS THAT BITS 8-15 CAN BE LOADED
847 ;TEST STEPS-
848 ; LOAD MOVING BIT WORD IN QVNT
849 ; READ QVNT, CHECK BITS 8-15
850 ; REPEAT FOR ALL 8 BITS
851 ;
852 ;--
853 ;*****
854
855 021600 BGNTST
      021600 T11::
856 021600 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      021600 104421 TRAP C#RFLA
      021602 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
      021606 001012 BNE 64# ; BRANCH IF NOT SET
      021610 012746 021540 MOV #T11MSG,-(SP)
      021614 012746 002270 MOV #PNTMSG,-(SP)
      021620 012746 000002 MOV #2,-(SP)
      021624 010600 MOV SP,R0
      021626 104417 TRAP C#PNTF
      021630 062706 000006 ADD #6,SP
      021634 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
857 021640 INIT
      ;INITIALIZE DEVICE
      021640 012777 000100 160450 MOV #MCHALT,BQMT1 ;INITIALIZE Q-BRIDGE
      021646 013777 002520 160442 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
      021654 005077 160420 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
      021660 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
858 021664 012701 000001 MOV #1,R1 ; REGISTER NUMBER TO R1
859 021670 012702 000010 MOV #8,R2 ; NUMBER OF BITS TO CHECK
860 021674 012703 000400 MOV #BIT8,R3 ; INITIAL DATA PATTERN TO R3
861 021700 010337 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
862 021704 005137 002530 COM EXP ; COMPLEMENT FOR MOVING 0
863
864 ;
865 ; TEST BITS 8-15 WITH MOVING ZERO
866 ;
      021710 BGNSUB
      021710 T11.1:
      021710 104402 TRAP C#BSUB
867 021712 104404 10#: BGNSEG
      021712 104404 TRAP C#BSEG
868 021714 042737 000377 002530 BIC #377,EXP ; MASK OUT UNTESTED BITS
869 021722 013777 002530 160346 MOV EXP,BQVNT ; MOVE EXPECTED TO REGISTER QVNT
870 021730 017737 160342 002526 MOV BQVNT,VAL ; READ QVNT AND MOVE TO VALUE
871 021736 042737 000377 002526 BIC #377,VAL ; MASK OUT UNTESTED BITS
872 021744 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
873 021752 001414 BEQ 20# ; IF OK, BRANCH
874
875 ;
876 ; ERROR CONDITION

```

TEST11: CHECK QVNT MI BITS (MOVING 0)

```

877 021754 005737 002532      TST      ERROR1      ; SEE IF FIRST ERROR
878 021760 001005              BNE      150         ; SKIP HEADER IF ALREADY PRINTED
879 021762              ERRHRD  1,MSG14,ERR7 ; TELL OPERATOR ERROR
      021762 104456              TRAP    C0ERHRD
      021764 000001              .WORD   1
      021766 005373              .WORD   MSG14
      021770 012246              .WORD   ERR7
880 021772 000402              BR       180         ; SKIP DETAIL LINE IF HEADER PRINTED
881 021774 004737 012366      150:    CALL    DETAIL ; PRINT DETAIL LINE
882 022000 005237 002532      180:    INC     ERROR1 ; INCREMENT ERROR COUNT
883
884      ; END ERROR CONDITION
885
886 022004              200:    ENDSEG
      022004              100000:
887 022006 006303              TRAP    C0ESEG
888 022010 010337 002530      ASL     R3           ; SHIFT BIT FOR NEXT TEST
889 022014 005137 002530      MOV     R3,EXP      ; PLACE PATTERN IN EXPECTED
890 022020 005302              COM     EXP         ; COMPLIMENT FOR MOVING 0
891 022022 001333              DEC     R2         ; DECREMENT LOOP COUNTER
892 022024              BNE     100         ; IF NOT DONE, BRANCH BACK
      022024
      022024 104403              L10050: TRAP    C0ESUB
893 022026 005737 002532      TST     ERROR1     ; ANY ERRORS
894 022032 001410              BEQ     500         ; BRANCH IF NO ERRORS
895 022034              PRINTX 0FORO       ; LINE FEED
      022034 012746 003333      MOV     0FORO, -(SP)
      022040 012746 000001      MOV     01, -(SP)
      022044 010600              MOV     SP, R0
      022046 104415              TRAP    C0PNTX
      022050 062706 000004      ADD     04, SP
896 022054              500:
897 022054              L10047: ENDTST
      022054 104401              TRAP    C0ETST

```

TEST12: CHECK ACK - PRS LINK

```

899 .SBTTL TEST12: CHECK ACK - PRS LINK
900 022056 STATST <CHECK ACK - PRS LINK>
022056 040 103 110 T12MSG:: .ASCIZ / CHECK ACK - PRS LINK/
901 ;*****
902 ;**
903 ;TEST DESCRIPTION
904 ; CHECKS THAT CMDACK SETS VNTACK AND CLEARS CMDPRS
905 ; CHECKS THAT VNTPRS SETS CMDPRS AND CLEARS VNTACK
906 ; USES QCMDACK - UEVENTACK LOOP-BACK
907 ; USES QEVNTPRSNT - UCMDPRSNT LOOP-LOOPBACK
908 ;TEST STEPS-
909 ; SET QCMD CMDACK
910 ; CHECK FOR CMDPRS CLEAR
911 ; READ QVNT VNTACK, CHECK FOR SET
912 ; SET VNTPRS
913 ; READ VNTACK, CHECK FOR CLEAR
914 ; READ QCMD CMDPRS, CHECK FOR SET
915 ; LOOPS 100 TIMES OR COMPLETES CURRENT PASS WITH ERROR AND EXITS
916 ;
917 ;
918 ;--
919 ;*****
920
921 022104 BGNTST
022104 T12::
922 022104 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
022104 104421 TRAP C#RFLA
022106 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
022112 001012 BNE 64# ; BRANCH IF NOT SET
022114 012746 022056 MOV #T12MSG,-(SP)
022120 012746 002270 MOV #PNTMSG,-(SP)
022124 012746 000002 MOV #2,-(SP)
022130 010600 MOV SP,R0
022132 104417 TRAP C#PNTF
022134 062706 000006 ADD #6,SP
022140 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
923 022144 INIT
;INITIALIZE DEVICE
022144 012777 000100 160144 MOV #QHALT,QGMT1 ;INITIALIZE Q-BRIDGE
022152 013777 002520 160136 MOV INITWORD,QGMT1 ;SET UP LOOPBACK OPTION
022160 005077 160114 CLR QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
022164 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
924 ;
925 ; LOOP THROUGH TEST 100 TIMES
926 ;
927 022170 012702 000144 MOV #100.,R2 ; # OF LOOPS TO R2
928 022174 1#:
929 022174 BGNSEG
022174 104404 TRAP C#BSEG
930 022176 012777 000001 160070 MOV #CMDACK,QCMD ; SET BIT 0 (CMDACK) IN QCMD
931 022204 017737 160070 002526 MOV QINT,VAL ; READ AND STORE QINT REGISTER
932 022212 032737 004000 002526 BIT #CMDPRS,VAL ; IS CMDPRS CLEAR
933 022220 001413 BEQ 2# ; BRANCH IF OK
934 ;
935 ; ERROR CONDITION 1
936 ;
937 022222 005237 002532 INC ERROR1 ; SET ERROR FLAG

```

TEST12: CHECK ACK - PRS LINK

```

938 022226 012701 000002          MOV    #2,R1          ; REGISTER # FOR MESSAGE
939 022232 012737 000000 002530  MOV    #0,EXP        ; VALUE OF EXPECTED FOR MESSAGE
940 022240          ERRHRD 1,MSG15       ; GO REPORT ERROR TO OPERATOR
      022240 104456      TRAP   C#ERRHRD
      022242 000001      .WORD 1
      022244 005436      .WORD MSG15
      022246 000000      .WORD 0
941 022250          2#:
942          ;
943          ; CHECK TO SEE IF VNTACK WAS SET
944          ;
945 022250 017737 160024 002526  MOV    @QINT,VAL     ; READ AND STORE QINT REGISTER
946 022256 032737 002000 002526  BIT    @VNTACK,VAL  ; TEST VNTACK BIT
947 022264 001013          BNE    3#           ; BRANCH IF OK
948          ;
949          ; ERROR CONDITION 2
950          ;
951 022266 005237 002532          INC    ERROR1        ; SET ERROR FLAG
952 022272 012701 000002          MOV    #2,R1        ; REGISTER # FOR MESSAGE
953 022276 012737 002000 002530  MOV    @VNTACK,EXP  ; VALUE OF EXPECTED FOR MESSAGE
954 022304          ERRHRD 2,MSG16       ; GO REPORT ERROR TO OPERATOR
      022304 104456      TRAP   C#ERRHRD
      022306 000002      .WORD 2
      022310 005531      .WORD MSG16
      022312 000000      .WORD 0
955 022314          3#:
956 022314          ENDSEG
      022314 10000#      10000#: TRAP   C#ESEG
957          ;
958 022316          BGNSEG
      022316 104404      TRAP   C#BSEG
959 022320 012777 000001 157750  MOV    @VNTPRS,@QVNT ; SET BIT 0 (VNTPRS) IN QVNT
960 022326 017737 157746 002526  MOV    @QINT,VAL    ; READ AND STORE QINT REGISTER
961 022334 032737 002000 002526  BIT    @VNTACK,VAL  ; IS VNTACK CLEAR
962 022342 001413          BEQ    4#           ; BRANCH IF OK
963          ;
964          ; ERROR CONDITION 3
965          ;
966 022344 005237 002532          INC    ERROR1        ; SET ERROR FLAG
967 022350 012701 000002          MOV    #2,R1        ; REGISTER # FOR MESSAGE
968 022354 012737 000000 002530  MOV    #0,EXP        ; VALUE OF EXPECTED FOR MESSAGE
969 022362          ERRHRD 3,MSG17       ; GO REPORT ERROR TO OPERATOR
      022362 104456      TRAP   C#ERRHRD
      022364 000003      .WORD 3
      022366 005622      .WORD MSG17
      022370 000000      .WORD 0
970 022372          4#:
971          ;
972          ; CHECK TO SEE IF QINT CMDPRS WAS SET
973          ;
974 022372 017737 157702 002526  MOV    @QINT,VAL    ; READ AND STORE QINT REGISTER
975 022400 032737 004000 002526  BIT    @CMDPRS,VAL  ; TEST CMDPRS BIT
976 022406 001013          BNE    5#           ; BRANCH IF OK
977          ;
978          ; ERROR CONDITION 4
979          ;

```

TEST12: CHECK ACK - PRS LINK

```

980 022410 005237 002532      INC      ERROR1      ; SET ERROR FLAG
981 022414 012701 000002      MOV      #2,R1      ; REGISTER # FOR MESSAGE
982 022420 012737 004000 002530  MOV      @CMDPRS,EXP ; VALUE OF EXPECTED FOR MESSAGE
983 022426      ERRHRD 4,MSG18 ; GO REPORT ERROR TO OPERATOR
      022426 104456      TRAP  C#ERRHRD
      022430 000004      .WORD 4
      022432 005715      .WORD MSG18
      022434 000000      .WORD 0
984 022436      5#:
985 022436      10001#:
      022436 104405      TRAP  C#ESEG
986 022440 005737 002532      TST      ERROR1      ; TEST ERROR FLAG
987 022444 001002      BNE      6#
988 022446 005302      DEC      R2          ; DECREMENT LOOP COUNTER
989 022450 001251      BNE      1#          ; LOOP IF NOT DONE
990 022452      6#:
991 022452      L10051:
      022452 104401      TRAP  C#ETST
      022452 104401

```


TEST13: CHECK QBA (MOVING 1)

```

993 .SBTTL TEST13: CHECK QBA (MOVING 1)
994 022454 STATST <CHECK QBA (MOVING 1)>
022454 040 103 110 T13MSG:: .ASCIZ / CHECK QBA (MOVING 1)/
995
996 ;*****
997 ;**
998 ;TEST DESCRIPTION
999 ; CHECKS ALL REGISTER BITS
1000 ;TEST STEPS-
1001 ; LOAD WORD IN QBA
1002 ; READ QBA, CHECK
1003 ; MOVE BIT
1004 ; REPEAT FOR ALL BITS
1005 ;
1006 ;--
1007 ;*****
1008
1009 022502 BGNTST
022502
1010 022502 T13:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
022502 104421 TRAP C#RFLA ;
022504 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
022510 001012 BNE 64# ; BRANCH IF NOT SET
022512 012746 022454 MOV #T13MSG,-(SP)
022516 012746 002270 MOV #PNTMSG,-(SP)
022522 012746 000002 MOV #2,-(SP)
022526 010600 MOV SP,R0
022530 104417 TRAP C#PNTF
022532 062706 000006 ADD #6,SP
022536 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1011 022542 INIT
022542 012777 000100 157546 ;INITIALIZE DEVICE
022550 013777 002520 157540 MOV #MHALT,BQMT1 ;INITIALIZE Q-BRIDGE
022556 005077 157516 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
022562 005037 002532 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
1012 022566 012701 000006 CLR ERROR1 ;CLEAR ERROR FLAG
1013 022572 012702 000020 MOV #6,R1 ; REGISTER NUMBER TO R1
1014 022576 012737 000001 002530 MOV #16,R2 ; NUMBER OF BITS TO CHECK
1015 MOV #BIT0,EXP ; FIRST DATA PATTERN TO CHECK
1016 ;
1017 ; TEST BITS 0-15 WITH MOVING ONE
1018 022604 ;
022604 BGNSUB
022604 104402 T13.1:
1019 022606 104404 10# : TRAP C#BSUB
022606 104404 10# : BGNSEG
1020 022610 013777 002530 157472 TRAP C#BSEG
1021 022616 017737 157466 002526 MOV EXP,BQBA ; MOVE EXPECTED TO REGISTER QBA
1022 022624 023737 002530 002526 MOV BQBA,VAL ; READ QBA AND MOVE TO VALUE
1023 022632 001414 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1024 BEQ 20# ; IF OK, BRANCH
1025 ;
1026 ; ERROR CONDITION
1027 022634 005737 002532 TST ERROR1 ; SEE IF FIRST ERROR
1028 022640 001005 BNE 15# ; SKIP HEADER IF ALREADY PRINTED
1029 022642 ERRHRD 1,MSG19,ERR7 ; TELL OPERATOR ERROR

```

TEST13: CHECK QBA (MOVING 1)

022642	104456		TRAP	C#ERHRD	
022644	000001		.WORD	1	
022646	006006		.WORD	MSG19	
022650	012246		.WORD	ERR7	
1030	022652	000402	BR	18#	: SKIP DETAIL LINE IF HEADER PRINTED
1031	022654	004737	CALL	DETAIL	: PRINT DETAIL LINE
1032	022660	005237	INC	ERROR1	: INCREMENT ERROR COUNT
1033					
1034					
1035					
1036	022664		20#:	ENDSEG	
	022664		10000#:		
	022664	104405	TRAP	C#ESEG	
1037	022666	006337	ASL	EXP	: SHIFT BIT FOR NEXT TEST
1038	022672	005302	DEC	R2	: DECREMENT LOOP COUNTER
1039	022674	001344	BNE	10#	: IF NOT DONE, BRANCH BACK
1040	022676		ENDSUB		
	022676		L10053:		
	022676	104403	TRAP	C#ESUB	
1041	022700	005737	TST	ERROR1	: ANY ERRORS
1042	022704	001410	BEG	500#	: BRANCH IF NO ERRORS
1043	022706		PRINTX	#FORO	: LINE FEED
	022706	012746	MOV	#FORO, -(SP)	
	022712	012746	MOV	#1, -(SP)	
	022716	010600	MOV	SP, R0	
	022720	104415	TRAP	C#PNTX	
	022722	062706	ADD	#4, SP	
1044	022726		500#:		
1045	022726		ENDTST		
	022726		L10052:		
	022726	104401	TRAP	C#ETST	

TEST14: CHECK QBA (MOVING 0)

```

1047 .SBTTL TEST14: CHECK QBA (MOVING 0)
1048 022730 STATST <CHECK QBA (MOVING 0)>
1049 022730 040 103 110 T14MSG:: .ASCIZ / CHECK QBA (MOVING 0)/
1050 ;*****
1051 ;**
1052 ;TEST DESCRIPTION
1053 ; CHECKS ALL REGISTER BITS
1054 ;TEST STEPS-
1055 ; LOAD WORD IN QBA
1056 ; READ QBA, CHECK
1057 ; MOVE BIT
1058 ; REPEAT FOR ALL BITS
1059 ;
1060 ;--
1061 ;*****
1062
1063 022756 BGNTST
1064 022756 T14:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1065 022756 104421 TRAP C#RFLA ; IS PNT FLAG SET?
1066 022760 022700 001000 CMP #PNT,R0 ; BRANCH IF NOT SET
1067 022764 001012 BNE 64#
1068 022766 012746 022730 MOV #T14MSG,-(SP)
1069 022772 012746 002270 MOV #PNTMSG,-(SP)
1070 022776 012746 000002 MOV #2,-(SP)
1071 023002 010600 MOV SP,R0
1072 023004 104417 TRAP C#PNTF
1073 023006 062706 000006 ADD #6,SP
1074 023012 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1075 023016 INIT
1076 023016 012777 000100 157272 ;INITIALIZE DEVICE
1077 023024 013777 002520 157264 MOV #MHALT,@QMT1 ; INITIALIZE Q-BRIDGE
1078 023032 005077 157242 MOV INITWORD,@QMT1 ; SET UP LOOPBACK OPTION
1079 023036 005037 002532 CLR @QINT ; CLEAR QINT AFTER LOOPBACK ENABLED
1080 023042 012701 000006 CLR ERROR1 ; CLEAR ERROR FLAG
1081 023046 012702 000020 MOV #6,R1 ; REGISTER NUMBER TO R1
1082 023052 012703 000001 MOV #16,R2 ; NUMBER OF BITS TO CHECK
1083 023056 010337 002530 MOV #BIT0,R3 ; INITIAL DATA PATTERN TO R3
1084 023062 005137 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
1085 ; COMPLEMENT FOR MOVING 0
1086 ;
1087 ; TEST BITS 0-15 WITH MOVING ZERO
1088 ;
1089 ;
1090 023066 BGNSUB
1091 023066 104402 T14.1: TRAP C#BSUB
1092 023070 104404 10#: BGNSEG TRAP C#BSEG
1093 023072 013777 002530 157210 MOV EXP,@QBA ; MOVE EXPECTED TO REGISTER QBA
1094 023100 017737 157204 002526 MOV @QBA,VAL ; READ QBA AND MOVE TO VALUE
1095 023106 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1096 023114 001414 BEQ 20# ; IF OK, BRANCH
1097 ;
1098 ; ERROR CONDITION
1099 ;
1100 023116 005737 002532 TST ERROR1 ; SEE IF FIRST ERROR

```

TEST14: CHECK QBA (MOVING 0)

```

1084 023122 001005      BNE      15$      ; SKIP HEADER IF ALREADY PRINTED
1085 023124      ERRHRD  1,MSG20,ERR7 ; TELL OPERATOR ERROR
      023124 104456      TRAP      C$ERHRD
      023126 000001      .WORD     1
      023130 006033      .WORD     MSG20
      023132 012246      .WORD     ERR7
1086 023134 000402      BR        18$      ; SKIP DETAIL LINE IF HEADER PRINTED
1087 023136 004737 012366 15$:      CALL     DETAIL ; PRINT DETAIL LINE
1088 023142 005237 002532 18$:      INC      ERROR1 ; INCREMENT ERROR COUNT
1089
1090      ;
1091      ; END ERROR CONDITION
1092 023146      20$:      ENDSEG
      023146      10000$:
1093 023146 104405      TRAP      C$ESEG
1094 023150 006303      ASL      R3
1095 023152 010337 002530  MOV     R3,EXP ; SHIFT BIT FOR NEXT TEST
1096 023156 005137 002530  COM     EXP ; PLACE PATTERN IN EXPECTED
1097 023162 005302      DEC     R2 ; COMPLIMENT FOR MOVING 0
1098 023164 001341      BNE     10$      ; DECREMENT LOOP COUNTER
      023166      ENDSUB ; IF NOT DONE, BRANCH BACK
1099 023166 104403      L10055: TRAP     C$ESUB
1100 023170 005737 002532  TST     ERROR1 ; ANY ERRORS
1101 023174 001410      BEQ     500$    ; BRANCH IF NO ERRORS
      023176 012746 003333  PRINTX #FORO ; LINE FEED
      023202 012746 000001  MOV     #FORO,-(SP)
      023206 010600      MOV     #1,-(SP)
      023210 104415      MOV     SP,R0
      023212 062706 000004  TRAP     C$PNTX
1102 023216      ADD     #4,SP
1103 023216      500$:      ENDTST
      023216 104401      L10054: TRAP     C$ETST

```

TEST15: CHECK QDMA HI BITS (8-13) (MOVING 1)

```

1105 .SBTTL TEST15: CHECK QDMA HI BITS (8-13) (MOVING 1)
1106 023220 STATST <CHECK QDMA HI BITS (8-13) (MOVING 1)>
1107 023220 040 103 110 T15MSG:: .ASCIZ / CHECK QDMA HI BITS (8-13) (MOVING 1)/
1108 ;.....
1109 ;..
1110 ;TEST DESCRIPTION-
1111 ; CHECKS HI Q-BUS ADDRESS BITS
1112 ;TEST STEPS-
1113 ; LOAD QDMA BITS 8-13
1114 ; IF U-BRIDGE THEN LOAD BITS 8,9
1115 ; READ QDMA, CHECK BITS
1116 ; MOVE BIT
1117 ; REPEAT FOR ALL BITS
1118 ;
1119 ;..
1120 ;.....
1121
1122 023266 BGNTST
023266 T15::
:123 023266 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
023266 104421 TRAP C@RFLA
023270 022700 001000 CMP @PNT,R0 ; IS PNT FLAG SET?
023274 001012 BNE 641 ; BRANCH IF NOT SET
023276 012746 023220 MOV @T15MSG,-(SP)
023302 012746 002270 MOV @PNTMSG,-(SP)
023306 012746 000002 MOV @2,-(SP)
023312 010600 MOV SP,R0
023314 104417 TRAP C@PNTF
023316 062706 000006 ADD @6,SP
1124 023322 005037 002532 641: CLR ERROR1 ; CLEAR ERROR COUNTER
023326 INIT
;INITIALIZE DEVICE
023326 012777 000100 156762 MOV @M@H@L@T,@Q@M@T@1 ;INITIALIZE Q-BRIDGE
023334 013777 002520 156754 MOV INITWORD,@Q@M@T@1 ;SET UP LOOPBACK OPTION
023342 005077 156732 CLR @Q@I@N@T ;CLEAR QINT AFTER LOOPBACK ENABLED
023346 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
1125 023352 012701 000004 MOV @4,R1 ; REGISTER NUMBER TO R1
1126 023356 012702 000006 MOV @6,R2 ; NUMBER OF BITS TO CHECK
1127 023362 005737 002500 TST BRIDGETYPE ; TEST BRIDGE TYPE
1128 023366 001402 BEQ 11 ; IF EQ THEN Q-BRIDGE
1129 023370 012702 000002 MOV @2,R2 ; NUMBER OF BITS TO CHECK (U-BRIDGE)
1130 023374 012737 000400 002530 11: MOV @BIT8,EXP ; FIRST DATA PATTERN TO CHECK
1131 ;
1132 ; TEST BITS 8-13 WITH MOVING ONE
1133 ;
1134 023402 BGNSUB
023402 T15.1:
023402 104402 TRAP C@BSUB
1135 023404 104404 104: BGNSEG
023404 104404 TRAP C@BSEG
1136 023406 013777 002530 156670 MOV EXP,@QDMA ; MOVE EXPECTED TO REGISTER QDMA
1137 023414 017737 156664 002526 MOV @QDMA,VAL ; READ QDMA AND MOVE TO VALUE
1138 023422 042737 140377 002526 BIC @140377,VAL ; CLEAR UNTESTED BITS
1139 023430 005737 002500 TST BRIDGETYPE ; TEST BRIDGE TYPE
1140 023434 001403 BEQ 121 ; IF EQ THEN Q-BRIDGE
1141 023436 042737 176377 002526 BIC @176377,VAL ; CLEAR UNTESTED BITS (U-BRIDGE)

```

TEST15: CHECK QDMA HI BITS (8-13) (MOVING 1)

```

1142 023444 023737 002530 002526 120:  CMP      EXP,VAL      ; COMPARE EXPECTED WITH VALUE
1143 023452 001414                BEQ      200          ; IF OK, BRANCH
1144                                ;
1145                                ; ERROR CONDITION
1146                                ;
1147 023454 005737 002532                TST      ERROR1      ; SEE IF FIRST ERROR
1148 023460 001005                BNE      150          ; SKIP HEADER IF ALREADY PRINTED
1149 023462                ERRHRD  1,MSG21,ERR7 ; TELL OPERATOR ERROR
      023462 104456                TRAP    C0ERRRD
      023464 000001                .WORD   1
      023466 006060                .WORD   MSG21
      023470 012246                .WORD   ERR7
1150 023472 000402                BR       180          ; SKIP DETAIL LINE IF HEADER PRINTED
1151 023474 004737 012366 150:  CALL    DETAIL      ; PRINT DETAIL LINE
1152 023500 005237 002532 180:  INC     ERROR1     ; INCREMENT ERROR COUNT
1153                                ;
1154                                ; END ERROR CONDITION
1155                                ;
1156 023504                200:  ENDSEG
      023504                100000:
1157 023506 006337 002530                TRAP    C0ESEG
1158 023512 005302                ASL     EXP          ; SHIFT BIT FOR NEXT TEST
1159 023514 001333                DEC     R2           ; DECREMENT LOOP COUNTER
1160 023516                BNE     100          ; IF NOT DONE, BRANCH BACK
      023516                ENDSUB
      L10057:
1161 023520 005737 002532                TRAP    C0ESUB
      023524 001410                TST     ERROR1
1162 023526                BEQ     5000
      023526 012746 003333                PRINTX #FORO
      023532 012746 000001                MOV     #FORO,-(SP)
      023536 010600                MOV     #1,-(SP)
      023540 104415                MOV     SP,R0
      023542 062706 000004                TRAP   C0PNTX
1164 023546                5000:
1165 023546                ENDTST
      023546                L10056:
      023546 104401                TRAP   C0ETST

```

TEST16: CHECK QDMA HI BITS (8-13) (MOVING 0)

```

1167 .SBTTL TEST16: CHECK QDMA HI BITS (8-13) (MOVING 0)
1168 023550 STATST <CHECK QDMA HI BITS (8-13) (MOVING 0)>
023550 040 103 110 T16MSG:: .ASCIZ / CHECK QDMA HI BITS (8-13) (MOVING 0)/

1169 ;*****
1170 ;**
1171 ;TEST DESCRIPTION-
1172 ; CHECKS HI Q-BUS ADDRESS BITS
1173 ;TEST STEPS-
1174 ; LOAD QDMA BITS 8-13
1175 ; IF U-BRIDGE THEN LOAD BITS 8,9
1176 ; READ QDMA, CHECK BITS
1177 ; MOVE BIT
1178 ; REPEAT FOR ALL BITS
1179 ;
1180 ;
1181 ;--
1182 ;*****
1183
1184 023616 BGNTST
023616 T16::
1185 023616 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
023616 104421 TRAP C#RFLA
023620 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
023624 001012 BNE 64# ; BRANCH IF NOT SET
023626 012746 023550 MOV #T16MSG,-(SP)
023632 012746 002270 MOV #PNTMSG,-(SP)
023636 012746 000002 MOV #2,-(SP)
023642 010600 MOV SP,R0
023644 104417 TRAP C#PNTF
023646 062706 000006 ADD #6,SP
023652 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1186 023656 INIT
;INITIALIZE DEVICE
023656 012777 000100 156432 MOV #MHALT,BQMT1 ;INITIALIZE Q-BRIDGE
023664 013777 002520 156424 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
023672 005077 156402 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
023676 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
1187 023702 012701 000004 MOV #4,R1 ; REGISTER NUMBER TO R1
1188 023706 012702 000006 MOV #6,R2 ; NUMBER OF BITS TO CHECK
1189 023712 005737 002500 TST BRIDGETYPE ; TEST BRIDGE TYPE
1190 023716 001402 BEQ 1# ; IF EQ THEN Q-BRIDGE
1191 023720 012702 000002 MOV #2,R2 ; NUMBER OF BITS (U-BRIDGE)
1192 023724 012703 000400 1#: MOV #BIT8,R3 ; INITIAL DATA PATTERN TO R3
1193 023730 010337 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
1194 023734 005137 002530 COM EXP ; COMPLEMENT FOR MOVING 0
1195 ;
1196 ; TEST BITS 8-13 WITH MOVING ZERO
1197 ;
1198 023740 BGNSUB
023740 T16.1:
023740 104402 TRAP C#BSUB
1199 023742 104404 10#: BGNSEG
023742 104404 TRAP C#BSEG
1200 023744 005737 002500 TST BRIDGETYPE ; TEST BRIDGE TYPE
1201 023750 001015 BNE 11# ; IF NE THEN U-BRIDGE
1202 023752 042737 140377 002530 BIC #140377,EXP ; CLEAR UNTESTED BITS
1203 023760 013777 002530 156316 MOV EXP,BQDMA ; MOVE EXPECTED TO REGISTER QDMA

```

TEST16: CHECK QDMA HI BITS (8-13) (MOVING 0)

1204	023766	017737	156312	002526		MOV	QDMA,VAL		; READ QDMA AND MOVE TO VALUE
1205	023774	042737	140377	002526		BIC	#140377,VAL		; CLEAR UNTESTED BITS
1206	024002	000414				BR	12#		; COMPARE VALUES
1207	024004	042737	176377	002530	11#:	BIC	#176377,EXP		; CLEAR UNTESTED BITS
1208	024012	013777	002530	156264		MOV	EXP,QDMA		; MOVE EXPECTED TO REGISTER QDMA
1209	024020	017737	156260	002526		MOV	QDMA,VAL		; READ QDMA AND MOVE TO VALUE
1210	024026	042737	176377	002526		BIC	#176377,VAL		; CLEAR UNTESTED BITS
1211	024034	023737	002530	002526	12#:	CMP	EXP,VAL		; COMPARE EXPECTED WITH VALUE
1212	024042	001414				BEQ	20#		; IF OK, BRANCH
1213									
1214									
1215									
1216	024044	005737	002532			TST	ERROR1		; SEE IF FIRST ERROR
1217	024050	001005				BNE	15#		; SKIP HEADER IF ALREADY PRINTED
1218	024052					ERRHRD	1,MSG22,ERR7		; TELL OPERATOR ERROR
	024052	104456				TRAP	C#ERRHRD		
	024054	000001				.WORD	1		
	024056	006125				.WORD	MSG22		
	024060	012246				.WORD	ERR7		
1219	024062	000402				BR	18#		; SKIP DETAIL LINE IF HEADER PRINTED
1220	024064	004737	012366		15#:	CALL	DETAIL		; PRINT DETAIL LINE
1221	024070	005237	002532		18#:	INC	ERROR1		; INCREMENT ERROR COUNT
1222									
1223									
1224									
1225	024074								
	024074				20#:	ENDSEG			
	024074	104405			10000#:				
1226	024076	006303				TRAP	C#ESEG		
1227	024100	010337	002530			ASL	R3		; SHIFT BIT FOR NEXT TEST
1228	024104	005137	002530			MOV	R3,EXP		; PLACE PATTERN IN EXPECTED
1229	024110	005302				COM	EXP		; COMPLIMENT FOR MOVING 0
1230	024112	001313				DEC	R2		; DECREMENT LOOP COUNTER
1231	024114					BNE	10#		; IF NOT DONE, BRANCH BACK
	024114					ENDSUB			
	024114	104403			L10061:				
1232	024116	005737	002532			TRAP	C#ESUB		
1233	024122	001410				TST	ERROR1		; ANY ERRORS
1234	024124					BEQ	500#		; BRANCH IF NO ERRORS
	024124	012746	003333			PRINTX	#FORO		; LINE FEED
	024130	012746	000001			MOV	#FORO,-(SP)		
	024134	010600				MOV	#1,-(SP)		
	024136	104415				MOV	SP,R0		
	024140	062706	000004			TRAP	C#PNTX		
1235	024144				500#:	ADD	#4,SP		
1236	024144					ENDTST			
	024144	104401			L10060:				
	024144					TRAP	C#ETST		

TEST17: CHECK QDMA UXAD BITS

```

1238
1239 024146          040    103    110
1240 024146
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255 024174
1256 024174          104421   001000
1257 024234          012777   000100   156054
      024242          013777   002520   156046
      024250          005077   156024
      024254          005037   002532
1258 024260          012701   000004
1259 024264
      024264          104402
1260
1261
1262
1263 024266          012737   000060   002530
1264 024274          013777   002530   156002
1265 024302          017737   155776   002526
1266 024310          042737   177717   002526
1267 024316          023737   002530   002526
1268 024324          001404
1269
1270
1271
1272 024326          104456
      024326          000001
      024330          006172

```

```

.SBTTL TEST17: CHECK QDMA UXAD BITS
STATST <CHECK QDMA UXAD BITS>
T17MSG:: .ASCIZ / CHECK QDMA UXAD BITS/

;*****
;..
;TEST DESCRIPTION-
; CHECKS UNIBUS EXTENDED ADDRESS BITS
; LDUXAD DRIVER AND I21 ARE NOT CHECKED
;TEST STEPS-
; LOAD QDMA BITS 4,5
; READ QDMA, CHECK BITS
; INCREMENT PATTERN
; REPEAT FOR ALL PATTERNS
;
;--
;*****

T17:: BGNTST
      CKPNT
      TRAP C0RFLA ; PRINT OUT TEST TITLE IF PNT SET
      CMP #PNT,R0 ; IS PNT FLAG SET?
      BNE 640 ; BRANCH IF NOT SET
      MOV #T17MSG,-(SP)
      MOV #PNTMSG,-(SP)
      MOV #2,-(SP)
      MOV SP,R0
      TRAP C0PNTF
      ADD #6,SP
640: CLR ERROR1 ; CLEAR ERROR COUNTER
      INIT
;INITIALIZE DEVICE
      MOV #M0HALT,BQMT1 ;INITIALIZE Q-BRIDGE
      MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
      CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
      CLR ERROR1 ;CLEAR ERROR FLAG
      MOV #4,R1 ; REGISTER NUMBER TO R1
      BGNSUB
T17.1: TRAP C0BSUB
;
; TEST WITH BOTH BITS HIGH
;
      MOV #60,EXP ; BIT PATTERN IN EXPECTED
      MOV EXP,BQDMA ; MOVE PATTERN TO QDMA REGISTER
      MOV BQDMA,VAL ; GET VALUE OF REGISTER
      BIC #177717,VAL ; MASK OUT UNDETERMINED BITS
      CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
      BEQ 10 ; IF OK, BRANCH
;
; ERROR CONDITION 1
;
ERRHRD 1,MSG23,ERR4 ; TELL OPERATOR ERROR
      TRAP C0ERHRD
      .WORD 1
      .WORD MSG23

```

TEST17: CHECK QDMA UXAD BITS

```

1273 024334 011776
1274 024336
      024336
1275 024336 104403
      024340
      024340
1276 024340 104402
1277
1278
1279 024342 012737 000040 002530
1280 024350 013777 002530 155726
1281 024356 017737 155722 002526
1282 024364 042737 177717 002526
1283 024372 023737 002530 002526
1284 024400 001404
1285
1286
1287
1288 024402
      024402 104456
      024404 000002
      024406 006172
      024410 011776
1289 024412
1290 024412
      024412
      024412 104403
1291 024414
      024414
      024414 104402
1292
1293
1294
1295 024416 012737 000020 002530
1296 024424 013777 002530 155652
1297 024432 017737 155646 002526
1298 024440 042737 177717 002526
1299 024446 023737 002530 002526
1300 024454 001404
1301
1302
1303
1304 024456
      024456 104456
      024460 000003
      024462 006172
      024464 011776
1305 024466
1306 024466
      024466
      024466 104403
1307 024470
      024470
      024470 104402
1308

```

```

      .WORD ERR4
16:
      ENDSUB
L10063:
      TRAP C#ESUB
      BGNSUB
T17.2:
      TRAP C#BSUB
;
; TEST WITH BIT 5 HIGH
;
      MOV #40,EXP
      MOV EXP,QDMA
      MOV QDMA,VAL
      BIC #177717,VAL
      CMP EXP,VAL
      BEQ 26
;
; ERROR CONDITION 2
;
      ERRHRD 2,MSG23,ERR4
      TRAP C#ERHRD
      .WORD 2
      .WORD MSG23
      .WORD ERR4
26:
      ENDSUB
L10064:
      TRAP C#ESUB
      BGNSUB
T17.3:
      TRAP C#BSUB
;
; TEST WITH BIT 4 HIGH
;
      MOV #20,EXP
      MOV EXP,QDMA
      MOV QDMA,VAL
      BIC #177717,VAL
      CMP EXP,VAL
      BEQ 36
;
; ERROR CONDITION 3
;
      ERRHRD 3,MSG23,ERR4
      TRAP C#ERHRD
      .WORD 3
      .WORD MSG23
      .WORD ERR4
36:
      ENDSUB
L10065:
      TRAP C#ESUB
      BGNSUB
T17.4:
      TRAP C#BSUB
;
; BIT PATTERN IN EXPECTED
; MOVE PATTERN TO QDMA REGISTER
; GET VALUE OF REGISTER
; MASK OUT UNDETERMINED BITS
; COMPARE EXPECTED WITH VALUE
; IF OK, BRANCH
; TELL OPERATOR ERROR
; BIT PATTERN IN EXPECTED
; MOVE PATTERN TO QDMA REGISTER
; GET VALUE OF REGISTER
; MASK OUT UNDETERMINED BITS
; COMPARE EXPECTED WITH VALUE
; IF OK, BRANCH
; TELL OPERATOR ERROR

```

TEST17: CHECK QDMA UXAD BITS

```

1309 ; TEST WITH BOTH BITS LOW
1310 ;
1311 024472 012737 000000 002530 ; MOV @00,EXP ; BIT PATTERN IN EXPECTED
1312 024500 013777 002530 155576 ; MOV EXP,@QDMA ; MOVE PATTERN TO QDMA REGISTER
1313 024506 017737 155572 002526 ; MOV @QDMA,VAL ; GET VALUE OF REGISTER
1314 024514 042737 177717 002526 ; BIC @177717,VAL ; MASK OUT UNDETERMINED BITS
1315 024522 023737 002530 002526 ; CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1316 024530 001404 ; BEQ 46 ; IF OK, BRANCH
1317 ;
1318 ; ERROR CONDITION 4
1319 ;
1320 024532 ; ERRHRD 4,MSG23,ERR4 ; TELL OPERATOR ERROR
    024532 104456 ; TRAP C#ERR4
    024534 000004 ; .WORD 4
    024536 006172 ; .WORD MSG23
    024540 011776 ; .WORD ERR4
1321 024542 ; 46:
1322 024542 ; ENDSUB
    024542 ; L10066:
    024542 104403 ; TRAP C#ESUB
1323 024544 ; ENDTST
    024544 ; L10062:
    024544 104401 ; TRAP C#ETST

```

TEST18: CHECK QUBA (MOVING 1)

```

1325 .SBTTL TEST18: CHECK QUBA (MOVING 1)
1326 024546 STATST <CHECK QUBA (MOVING 1)>
1327 024546 040 103 110 T18MSG:: .ASCIZ / CHECK QUBA (MOVING 1)/
1328 ;*****
1329 ;**
1330 ;TEST DESCRIPTION
1331 ; CHECKS ALL REGISTER BITS
1332 ; USES QTSOUT - QTSIN LOOP-BACK
1333 ;TEST STEPS-
1334 ; SET QMT1 FUNC = 4 (SELUBAR)
1335 ; LOAD WORD IN QUBA
1336 ; READ QMTO, CHECK
1337 ; MOVE BIT
1338 ; REPEAT FOR ALL BITS
1339 ;
1340 ;--
1341 ;*****
1342
1343 024576 BGNTST
1344 024576 T18::
1345 024576 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1346 024576 TRAP C#RFLA ; IS PNT FLAG SET?
1347 024600 104421 001000 CMP #PNT,RO ; BRANCH IF NOT SET
1348 024604 001012 BNE 64#
1349 024606 012746 024546 MOV #T18MSG,-(SP)
1350 024612 012746 002270 MOV #PNTMSG,-(SP)
1351 024616 012746 000002 MOV #2,-(SP)
1352 024622 010600 MOV SP,RO
1353 024624 104417 TRAP C#PNTF
1354 024626 062706 000006 ADD #6,SP
1355 024632 005037 002532 64# CLR ERROR1 ; CLEAR ERROR COUNTER
1356 024636 INIT
1357 024636 ;INITIALIZE DEVICE
1358 024636 MOV #MHALT,@QMT1 ;INITIALIZE Q-BRIDGE
1359 024644 013777 002520 155452 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
1360 024652 005077 155422 155444 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
1361 024656 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
1362 1346 024662 012701 000005 MOV #5,R1 ; REGISTER NUMBER TO R1
1363 1347 024666 012702 000020 MOV #16,R2 ; NUMBER OF BITS TO CHECK
1364 1348 024672 012737 000001 002530 MOV #BIT0,EXP ; FIRST DATA PATTERN TO CHECK
1365 1349 024700 052777 000020 155410 BIS #SELUBAR,@QMT1 ; SELECT QMT1 FUNC = 4
1366 ;
1367 ; TEST BITS 0-15 WITH MOVING ONE
1368 ;
1369 ;
1370 1353 024706 BGNSUB
1371 024706 T18.1:
1372 024706 104402 TRAP C#BSUB
1373 1354 024710 104404 10# BGNSEG
1374 024710 TRAP C#BSEG
1375 1355 024712 013777 002530 155366 MOV EXP,@QUBA ; MOVE EXPECTED TO REGISTER QUBA
1376 1356 024720 017737 155370 002526 MOV @QMT0,VAL ; READ QMTO AND MOVE TO VALUE
1377 1357 024726 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1378 1358 024734 001414 BEQ 20# ; IF OK, BRANCH
1379 1359 ;
1380 1360 ; ERROR CONDITION
1381 1361 ;

```

TEST18: CHECK QUBA (MOVING 1)

1362	024736	005737	002532	TST	ERROR1				
1363	024742	001005		BNE	150				: SEE IF FIRST ERROR
1364	024744			ERRHRD	1,MSG24,ERR7				: SKIP HEADER IF ALREADY PRINTED
	024744	104456		TRAP	C#ERRHRD				: TELL OPERATOR ERROR
	024746	000001		.WORD	1				
	024750	006241		.WORD	MSG24				
	024752	012246		.WORD	ERR7				
1365	024754	000402		BR	180				: SKIP DETAIL LINE IF HEADER PRINTED
1366	024756	004737	012366	150:	CALL	DETAIL			: PRINT DETAIL LINE
1367	024762	005237	002532	180:	INC	ERROR1			: INCREMENT ERROR COUNT
1368									
1369									
1370									
1371	024766								
	024766			200:	ENDSEG				
	024766	104405		100000:					
1372	024770	006337	002530		TRAP	C#ESEG			
1373	024774	005302			ASL	EXP			: SHIFT BIT FOR NEXT TEST
1374	024776	001344			DEC	R2			: DECREMENT LOOP COUNTER
1375	025000				BNE	100			: IF NOT DONE, BRANCH BACK
	025000				ENDSUB				
	025000	104403		L10070:					
1376	025002	005737	002532		TRAP	C#ESUB			
1377	025006	001410			TST	ERROR1			: ANY ERRORS
1378	025010				BEQ	5000			: BRANCH IF NO ERRORS
	025010	012746	003333		PRINTX	#FORO			: LINE FEED
	025014	012746	000001		MOV	#FORO, -(SP)			
	025020	010600			MOV	#1, -(SP)			
	025022	104415			MOV	SP, R0			
	025024	062706	000004		TRAP	C#PNTX			
1379	025030				ADD	#4, SP			
1380	025030			5000:					
	025030				ENDTST				
	025030	104401		L10067:					
					TRAP	C#ETST			

TEST19: CHECK QUBA (MOVING 0)

```

1382 .SBTTL TEST19: CHECK QUBA (MOVING 0)
1383 025032 STATST <CHECK QUBA (MOVING 0)>
1384 025032 040 103 110 T19MSG:: .ASCIZ / CHECK QUBA (MOVING 0)/
1385 ;*****
1386 ;**
1387 ;TEST DESCRIPTION
1388 ; CHECKS ALL REGISTER BITS
1389 ; USES QTSOUT - QTSIN LOOP-BACK
1390 ;TEST STEPS-
1391 ; SET QMT1 FUNC = 4 (SELUBAR)
1392 ; LOAD WORD IN QUBA
1393 ; READ QMT0, CHECK
1394 ; MOVE BIT
1395 ; REPEAT FOR ALL BITS
1396 ;
1397 ;--
1398 ;*****
1400 025062 BGNTST
1401 025062 T19:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1402 025062 104421 TRAP C#RFLA ; IS PNT FLAG SET?
1403 025064 022700 001000 CMP #PNT,R0 ; BRANCH IF NOT SET
1404 025070 001012 BNE 64#
1405 025072 012746 025032 MOV #T19MSG,-(SP)
1406 025076 012746 002270 MOV #PNTMSG,-(SP)
1407 025102 012746 000002 MOV #2,-(SP)
1408 025106 010600 MOV SP,R0
1409 025110 104417 TRAP C#PNTF
1410 025112 062706 000006 ADD #6,SP
1411 025116 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1412 025122 INIT
1413 ;INITIALIZE DEVICE
1414 025122 012777 000100 155166 MOV #MHALT,@QMT1 ;INITIALIZE Q-BRIDGE
1415 025130 013777 002520 155160 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
1416 025136 005077 155136 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
1417 025142 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
1418 1403 025146 012701 000005 MOV #5,R1 ; REGISTER NUMBER TO R1
1419 1404 025152 012702 000020 MOV #16.,R2 ; NUMBER OF BITS TO CHECK
1420 1405 025156 012703 000001 MOV #BIT0,R3 ; INITIAL DATA PATTERN TO R3
1421 1406 025162 010337 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
1422 1407 025166 005137 002530 COM EXP ; COMPLEMENT FOR MOVING 0
1423 1408 025172 052777 000020 155116 BIS #SELUBAR,@QMT1 ; SELECT QMT1 FUNC = 4
1424 1409 ;
1425 1410 ; TEST BITS 0-15 WITH MOVING ZERO
1426 1411 ;
1427 1412 025200 BGNSUB
1428 025200 T19.1: TRAP C#BSUB
1429 025200 104402 10# : BGNSEG
1430 1413 025202 TRAP C#BSEG
1431 025202 104404 10# :
1432 1414 025204 013777 002530 155074 MOV EXP,@QUBA ; MOVE EXPECTED TO REGISTER QUBA
1433 1415 025212 017737 155076 002526 MOV @QMT0,VAL ; READ QMT0 AND MOVE TO VALUE
1434 1416 025220 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1435 1417 025226 001414 BEQ 20# ; IF OK, BRANCH
1418 ;

```

TEST19: CHECK QUBA (MOVING 0)

```

1419                                     ; ERROR CONDITION
1420                                     ;
1421 025230 005737 002532               TST      ERROR1
1422 025234 001005                       BNE     15$
1423 025236                               ERRHRD  1,MSG25,ERR7
      025236 104456                       TRAP   C$ERHRD
      025240 000001                       .WORD  1
      025242 006267                       .WORD  MSG25
      025244 012246                       .WORD  ERR7
1424 025246 000402                       BR      18$
1425 025250 004737 012366             15$:   CALL  DETAIL
1426 025254 005237 002532             18$:   INC   ERROR1
1427                                     ;
1428                                     ; END ERROR CONDITION
1429                                     ;
1430 025260                               20$:   ENDSEG
      025260                               10000$:
1431 025262 104405                       TRAP   C$ESEG
1432 025264 010337 002530               ASL    R3
1433 025270 005137 002530               MOV    R3,EXP
1434 025274 005302                       COM    EXP
1435 025276 001341                       DEC    R2
1436 025300                               BNE    10$
      025300                               ENDSUB
1437 025302 005737 002532               L10072: TRAP  C$ESUB
1438 025306 001410                       TST   ERROR1
1439 025310                               BEQ   500$
      025310 012746 003333               PRINTX #FORO
      025314 012746 000001               MOV   #FORO,-(SP)
      025320 010600                       MOV   #1,-(SP)
      025322 104415                       MOV   SP,R0
      025324 062706 000004               TRAP  C$PNTX
1440 025330                               ADD   #4,SP
1441 025330                               500$:
      025330                               ENDTST
      025330 104401                               L10071:
      025330                               TRAP  C$ETST

```

```

; SEE IF FIRST ERROR
; SKIP HEADER IF ALREADY PRINTED
; TELL OPERATOR ERROR

; SKIP DETAIL LINE IF HEADER PRINTED
; PRINT DETAIL LINE
; INCREMENT ERROR COUNT

; SHIFT BIT FOR NEXT TEST
; PLACE PATTERN IN EXPECTED
; COMPLIMENT FOR MOVING 0
; DECREMENT LOOP COUNTER
; IF NOT DONE, BRANCH BACK

; ANY ERRORS
; BRANCH IF NO ERRORS
; LINE FEED

```

TEST20: CHECK QWC (MOVING 1)

```

1443 .SBTTL TEST20: CHECK QWC (MOVING 1)
1444 025332 STATST <CHECK QWC (MOVING 1)>
1445 025332 040 103 110 T20MSG:: .ASCIZ / CHECK QWC (MOVING 1)/
1446 ;*****
1447 ;**
1448 ;TEST DESCRIPTION
1449 ; CHECKS ALL REGISTER BITS
1450 ;TEST STEPS-
1451 ; LOAD WORD IN QWC
1452 ; READ QWC, CHECK
1453 ; MOVE BIT
1454 ; REPEAT FOR ALL BITS
1455 ;
1456 ;--
1457 ;*****
1458
1459 025360 BGNTST
1460 025360 T20::
1461 025360 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1462 025360 104421 TRAP C#RFLA
1463 025362 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
1464 025366 001012 BNE 64# ; BRANCH IF NOT SET
1465 025370 012746 025332 MOV #T20MSG,-(SP)
1466 025374 012746 002270 MOV #PNTMSG,-(SP)
1467 025400 012746 000002 MOV #2,-(SP)
1468 025404 010600 MOV SP,R0
1469 025406 104417 TRAP C#PNTF
1470 025410 062706 000006 ADD #6,SP
1471 025414 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1472 025420 INIT
1473 ;INITIALIZE DEVICE
1474 025420 012777 000100 154670 MOV #MQHALT,@QMT1 ;INITIALIZE Q-BRIDGE
1475 025426 013777 002520 154662 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
1476 025434 005077 154640 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
1477 025440 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
1478 1462 025444 012701 000007 MOV #7,R1 ; REGISTER NUMBER TO R1
1479 1463 025450 012702 000020 MOV #16,R2 ; NUMBER OF BITS TO CHECK
1480 1464 025454 012737 000001 002530 MOV #BIT0,EXP ; FIRST DATA PATTERN TO CHECK
1481 1465 ;
1482 1466 ; TEST BITS 0-15 WITH MOVING ONE
1483 1467 ;
1484 1468 025462 BGNSUB
1485 025462 T20.1:
1486 025462 104402 10#: TRAP C#BSUB
1487 1469 025464 BGNSEG
1488 025464 104404 TRAP C#BSEG
1489 1470 025466 013777 002530 154616 MOV EXP,@QWC ; MOVE EXPECTED TO REGISTER QWC
1490 1471 025474 017737 154612 002526 MOV @QWC,VAL ; READ QWC AND MOVE TO VALUE
1491 1472 025502 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1492 1473 025510 001414 BEQ 20# ; IF OK, BRANCH
1493 1474 ;
1494 1475 ; ERROR CONDITION
1495 1476 ;
1496 1477 025512 005737 002532 TST ERROR1 ; SEE IF FIRST ERROR
1497 1478 025516 001005 BNE 15# ; SKIP HEADER IF ALREADY PRINTED
1498 1479 025520 ERRHRD 1,MSG26,ERR7 ; TELL OPERATOR ERROR

```


TEST20: CHECK QWC (MOVING 1)

025520	104456		TRAP	C#ERHRD	
025522	000001		.WORD	1	
025524	006315		.WORD	MSG26	
025526	012246		.WORD	ERR7	
1480	025530	000402	BR	18#	: SKIP DETAIL LINE IF HEADER PRINTED
1481	025532	004737	CALL	DETAIL	: PRINT DETAIL LINE
1482	025536	005237	INC	ERROR1	: INCREMENT ERROR COUNT
1483					
1484					
1485					
1486	025542				
	025542				
	025542	104405			
1487	025544	006337	TRAP	C#ESEG	
1488	025550	005302	ASL	EXP	: SHIFT BIT FOR NEXT TEST
1489	025552	001344	DEC	R2	: DECREMENT LOOP COUNTER
1490	025554		BNE	10#	: IF NOT DONE, BRANCH BACK
	025554		ENDSUB		
	025554	104403	L10074:		
1491	025556	005737	TRAP	C#ESUB	
1492	025562	001410	TST	ERROR1	: ANY ERRORS
1493	025564		BEQ	500#	: BRANCH IF NO ERRORS
	025564	012746	PRINTX	#FORO	: LINE FEED
	025564	012746	MOV	#FORO, -(SP)	
	025570	012746	MOV	#1, -(SP)	
	025574	010600	MOV	SP, R0	
	025576	104415	TRAP	C#PNTX	
	025600	062706	ADD	#4, SP	
1494	025604		500#:		
1495	025604		ENDTST		
	025604		L10073:		
	025604	104401	TRAP	C#ETST	

TEST21: CHECK QWC (MOVING 0)

```

1497 .SBTTL TEST21: CHECK QWC (MOVING 0)
1498 025606 STATST <CHECK QWC (MOVING 0)>
      025606 040 103 110 T21MSG:: .ASCIZ / CHECK QWC (MOVING 0)/
1499
1500 ;.....
1501 ;..
1502 ; TEST DESCRIPTION
1503 ; CHECKS ALL REGISTER BITS
1504 ; TEST STEPS-
1505 ; LOAD WORD IN QWC
1506 ; READ QWC, CHECK
1507 ; MOVE BIT
1508 ; REPEAT FOR ALL BITS
1509 ;
1510 ;..
1511 ;.....
1512
1513 025634 BGNTST
      025634 T21::
1514 025634 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      025634 104421 TRAP C1RFLA ; IS PNT FLAG SET?
      025636 022700 001000 CMP #PNT,R0 ; BRANCH IF NOT SET
      025642 001012 BNE 640
      025644 012746 025606 MOV #T21MSG,-(SP)
      025650 012746 002270 MOV #PNTMSG,-(SP)
      025654 012746 000002 MOV #2,-(SP)
      025660 010600 MOV SP,R0
      025662 104417 TRAP C1PNTF
      025664 062706 000006 ADD #6,SP
      025670 005037 002532 640: CLR ERROR1 ; CLEAR ERROR COUNTER
1515 025674 INIT
      025674 012777 000100 154414 ; INITIALIZE DEVICE
      025702 013777 002520 154406 MOV #MOMALT,BQMT1 ; INITIALIZE Q-BRIDGE
      025710 005077 154364 MOV INITWORD,BQMT1 ; SET UP LOOPBACK OPTION
      025714 005037 002532 CLR BQINT ; CLEAR QINT AFTER LOOPBACK ENABLED
      025720 012701 000007 CLR ERROR1 ; CLEAR ERROR FLAG
1516 025724 012702 000020 MOV #7,R1 ; REGISTER NUMBER TO R1
1517 025724 012702 000020 MOV #16,R2 ; NUMBER OF BITS TO CHECK
1518 025730 012703 000001 MOV #BIT0,R3 ; INITIAL DATA PATTERN TO R3
1519 025734 010337 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
1520 025740 005137 002530 COM EXP ; COMPLEMENT FOR MOVING 0
1521
1522 ; TEST BITS 0-15 WITH MOVING ZERO
1523
1524 025744 BGNSUB
      025744 T21.1:
      025744 104402 TRAP C1BSUB
1525 025746 BGNSEG 100:
      025746 104404 TRAP C1BSEG
1526 025750 013777 002530 154334 MOV EXP,BQWC ; MOVE EXPECTED TO REGISTER QWC
1527 025756 017737 154330 002526 MOV BQWC,VAL ; READ QWC AND MOVE TO VALUE
1528 025764 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1529 025772 001414 BEQ 200 ; IF OK, BRANCH
1530
1531 ; ERROR CONDITION
1532
1533 025774 005737 002532 TST ERROR1 ; SEE IF FIRST ERROR

```

09

TEST21: CHECK QMC (MOVING 0)

1534	026000	001005		BNE	150			: SKIP HEADER IF ALREADY PRINTED
1535	026002			ERRHRD	1,MSG27,ERR7			: TELL OPERATOR ERROR
	026002	104456		TRAP	C#ERRHRD			
	026004	000001		.WORD	1			
	026006	006342		.WORD	MSG27			
	026010	012246		.WORD	ERR7			
1536	026012	000402		BR	180			: SKIP DETAIL LINE IF HEADER PRINTED
1537	026014	004737	012366	150:	CALL	DETAIL		: PRINT DETAIL LINE
1538	026020	005237	002532	180:	INC	ERROR1		: INCREMENT ERROR COUNT
1539				:				
1540				:	END ERROR CONDITION			
1541				:				
1542	026024			200:	ENDSEG			
	026024			100000:				
	026024	104405		TRAP	C#ESEG			
1543	026026	006303		ASL	R3			: SHIFT BIT FOR NEXT TEST
1544	026030	010337	002530	MOV	R3,EXP			: PLACE PATTERN IN EXPECTED
1545	026034	005137	002530	COM	EXP			: COMPLIMENT FOR MOVING 0
1546	026040	005302		DEC	R2			: DECREMENT LOOP COUNTER
1547	026042	001341		BNE	100			: IF NOT DONE, BRANCH BACK
1548	026044			ENDSUB				
	026044			L10076:				
	026044	104403		TRAP	C#ESUB			
1549	026046	005737	002532	TST	ERROR1			: ANY ERRORS
1550	026052	001410		BEQ	5000			: BRANCH IF NO ERRORS
1551	026054			PRINTX	#FOR0			: LINE FEED
	026054	012746	003333	MOV	#FOR0,-(SP)			
	026060	012746	000001	MOV	#1,-(SP)			
	026064	010600		MOV	SP,R0			
	026066	104415		TRAP	C#PNTX			
	026070	062706	000004	ADD	#4,SP			
1552	026074			5000:				
1553	026074			ENDTST				
	026074			L10075:				
	026074	104401		TRAP	C#ETST			

TEST22: CHECK QVAD (Q-REGISTER) (MOVING 1)

```

1555 .SBTTL TEST22: CHECK QVAD (Q-REGISTER) (MOVING 1)
1556 026076 STATST <CHECK QVAD (Q-REGISTER) (MOVING 1)>
1557 026076 040 103 110 T22MSG:: .ASCIZ / CHECK QVAD (Q-REGISTER) (MOVING 1)/
1558 ;*****
1559 ;**
1560 ;TEST DESCRIPTION
1561 ; CHECKS THAT QVAD (A-COUNTER) CAN BE LOADED AND READ
1562 ;TEST STEPS-
1563 ; LOAD WORD IN QVAD
1564 ; SET QMT1 MVADR BIT
1565 ; READ QVAD, CHECK
1566 ; CLEAR QMT1 MVADR BIT
1567 ; MOVE BIT
1568 ; REPEAT FOR ALL BITS
1569 ;
1570 ;--
1571 ;*****
1572
1573 026142 BGNTST
1574 026142 T22::
1575 026142 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1576 026142 TRAP C0RFLA
1577 026144 104421 CMP @PNT,R0 ; IS PNT FLAG SET?
1578 026150 001012 BNE 640 ; BRANCH IF NOT SET
1579 026152 012746 026076 MOV @T22MSG,-(SP)
1580 026156 012746 002270 MOV @PNTMSG,-(SP)
1581 026162 012746 000002 MOV @2,-(SP)
1582 026166 010600 MOV SP,R0
1583 026170 104417 TRAP C0PNTF
1584 026172 062706 000006 ADD @6,SP
1585 026176 005037 002532 640: CLR ERROR1 ; CLEAR ERROR COUNTER
1586 ;
1587 ; INITIALIZE DEVICE
1588 ;
1589 026202 012777 000100 154106 MOV @MQHALT,@QMT1 ; INITIALIZE Q-BRIDGE
1590 026210 005037 002532 CLR ERROR1 ; CLEAR ERROR COUNTER
1591 026214 012701 000012 MOV @10.,R1 ; REGISTER NUMBER TO R1
1592 026220 012702 000020 MOV @16.,R2 ; NUMBER OF BITS TO CHECK
1593 026224 012737 000001 002530 MOV @BIT0,EXP ; FIRST DATA PATTERN TO CHECK
1594 ;
1595 ; TEST BITS 0-15 WITH MOVING ONE
1596 ;
1597 026232 BGNSUB
1598 026232 T22.1:
1599 026232 104402 TRAP C0BSUB
1600 026234 104404 100: BGNSEG
1601 026236 052777 000020 154036 TRAP C0BSEG
1602 026244 013777 002530 154046 BIS @QVREN,@QCTL ; READ ENABLE
1603 026252 052777 000002 154036 MOV EXP,@QVAD ; MOVE EXPECTED TO REGISTER QVAD
1604 026260 017737 154034 002526 BIS @MVADR,@QMT1 ; SET MVADR BIT IN QMT1
1605 026266 042777 000002 154022 MOV @QVAD,VAL ; READ QVAD AND MOVE TO VALUE
1606 026274 023737 002530 002526 BIC @MVADR,@QMT1 ; CLEAR MVADR BIT IN QMT1
1607 026302 001414 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1608 ;
1609 ; ERROR CONDITION

```

TEST22: CHECK QVAD (Q-REGISTER) (MOVING 1)

```

1597
1598 026304 005737 002532      ;
1599 026310 001005              TST      ERROR1      ; SEE IF FIRST ERROR
1600 026312      104456          BNE      150         ; SKIP HEADER IF ALREADY PRINTED
                                ERRHRD  1,MSG28,ERR7      ; TELL OPERATOR ERROR
                                TRAP    C0ERRHRD
                                .WORD   1
                                .WORD   MSG28
                                .WORD   ERR7
1601 026322 000402              BR       180         ; SKIP DETAIL LINE IF HEADER PRINTED
1602 026324 004737 012366      150:    CALL    DETAIL ; PRINT DETAIL LINE
1603 026330 005237 002532      180:    INC     ERROR1 ; INCREMENT ERROR COUNT
1604
1605      ; END ERROR CONDITION
1606
1607 026334      104405          200:    ENDSEG
                                100000:
                                TRAP    C0ESEG
                                ASL     EXP
                                DEC     R2
                                BNE     100
                                ENDSUB
1608 026336 006337 002530      L10100: TRAP    C0ESUB
1609 026342 005302              TST     ERROR1      ; ANY ERRORS
1610 026344 001333              BEQ     500         ; BRANCH IF NO ERRORS
1611 026346      104403          PRINTX  #FORO      ; LINE FEED
                                026346 104403
                                TRAP    C0ESUB
1612 026350 005737 002532      TST     ERROR1
1613 026354 001410              BEQ     500
1614 026356 012746 003333      MOV     #FORO, -(SP)
                                026362 012746 000001      MOV     #1, -(SP)
                                026366 010600              MOV     SP, R0
                                026370 104415              TRAP    C0PNTX
                                026372 062706 000004      ADD     #4, SP
1615 026376      104401          500:
1616 026376      104401          L10077: ENDTST
                                TRAP    C0ETST

```

TEST23: CHECK QVAD (Q-REGISTER) (MOVING 0)

```

1618 .SBTTL TEST23: CHECK QVAD (Q-REGISTER) (MOVING 0)
1619 026400 STATST <CHECK QVAD (Q-REGISTER) (MOVING 0)>
1620 026400 T23MSG:: .ASCIZ / CHECK QVAD (Q-REGISTER) (MOVING 0)/
1621 ;*****
1622 ;**
1623 ;TEST DESCRIPTION
1624 ; CHECKS THAT QVAD (A-COUNTER) CAN BE LOADED AND READ
1625 ;TEST STEPS-
1626 ; LOAD WORD IN QVAD
1627 ; SET QMT1 MVADR BIT
1628 ; READ QVAD, CHECK
1629 ; CLEAR QMT1 MVADR BIT
1630 ; MOVE BIT
1631 ; REPEAT FOR ALL BITS
1632 ;
1633 ;--
1634 ;*****
1635
1636 026444 BGNTST
1637 026444 T23::
1638 026444 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1639 026444 TRAP C0RFLA ; IS PNT FLAG SET?
1640 026446 104421 001000 CMP #PNT,R0 ; BRANCH IF NOT SET
1641 026452 001012 BNE 640
1642 026454 012746 026400 MOV #T23MSG,-(SP)
1643 026460 012746 002270 MOV #PNTMSG,-(SP)
1644 026464 012746 000002 MOV #2,-(SP)
1645 026470 010600 MOV SP,R0
1646 026472 104417 TRAP C0PNTF
1647 026474 062706 000006 ADD #6,SP
1648 026500 005037 002532 640: CLR ERROR1 ; CLEAR ERROR COUNTER
1649 ;
1650 ; INITIALIZE DEVICE
1651 ;
1652 026504 012777 000100 153604 MOV #QHALT,QMT1 ; INITIALIZE Q-BRIDGE
1653 026512 005037 002532 CLR ERROR1 ; CLEAR ERROR FLAG
1654 026516 012701 000012 MOV #10.,R1 ; REGISTER NUMBER TO R1
1655 026522 012702 000020 MOV #16.,R2 ; NUMBER OF BITS TO CHECK
1656 026526 012703 000001 MOV #BIT0,R3 ; INITIAL DATA PATTERN TO R3
1657 026532 010337 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
1658 026536 005137 002530 COM EXP ; COMPLEMENT FOR MOVING 0
1659 ;
1660 ; TEST BITS 0-15 WITH MOVING ZERO
1661 ;
1662 026542 BGNSUB
1663 026542 T23.1:
1664 026542 104402 TRAP C0BSUB
1665 026544 104404 100: BGNSEG
1666 026546 052777 000020 153526 TRAP C0BSEG
1667 026554 013777 002530 153536 BIS #QVREN,QCTL ; READ ENABLE
1668 026562 052777 000002 153526 MOV EXP,QVAD ; MOVE EXPECTED TO REGISTER QVAD
1669 026570 017737 153524 002526 BIS #MVADR,QMT1 ; SET MVADR BIT IN QMT1
1670 026576 042777 000002 153512 MOV QVAD,VAL ; READ QVAD AND MOVE TO VALUE
1671 026604 023737 002530 002526 BIC #MVADR,QMT1 ; CLEAR MVADR BIT IN QMT1
1672 026612 001414 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1673 BEQ 200 ; IF OK, BRANCH

```

TEST23: CHECK QVAD (Q-REGISTER) (MOVING 0)

```

1660
1661
1662
1663 026614 005737 002532
1664 026620 001005
1665 026622
      026622 104456
      026624 000001
      026626 006430
      026630 012246
1666 026632 000402
1667 026634 004737 012366
1668 026640 005237 002532
1669
1670
1671
1672 026644
      026644
      026644 104405
1673 026646 006303
1674 026650 010337 002530
1675 026654 005137 002530
1676 026660 005302
1677 026662 001330
1678 026664
      026664
      026664 104403
1679 026666 005737 002532
1680 026672 001410
1681 026674
      026674 012746 003333
      026700 012746 000001
      026704 010600
      026706 104415
      026710 062706 000004
1682 026714
1683 026714
      026714
      026714 104401
1684 026716
      026716 012777 000100 153372
      026724 013777 002520 153364
      026732 005077 153342
      026736 005037 002532
;
; ERROR CONDITION
;
      TST      ERROR1
      BNE      150
      ERRHRD  1,MSG29,ERR7
      TRAP     C0ERRHRD
      .WORD    1
      .WORD    MSG29
      .WORD    ERR7
      BR       180
150:  CALL     DETAIL
180:  INC      ERROR1
; SEE IF FIRST ERROR
; SKIP HEADER IF ALREADY PRINTED
; TELL OPERATOR ERROR
;
; SKIP DETAIL LINE IF HEADER PRINTED
; PRINT DETAIL LINE
; INCREMENT ERROR COUNT
;
; END ERROR CONDITION
;
200:  ENDSEG
100000:
      TRAP     C0ESEG
      ASL      R3
      MOV      R3,EXP
      COM      EXP
      DEC      R2
      BNE      100
      ENDSUB
L10102:
      TRAP     C0ESUB
      TST      ERROR1
      BEQ      5000
      PRINTX   #FORO
      MOV      #FORO,-(SP)
      MOV      #1,-(SP)
      MOV      SP,R0
      TRAP     C0PNTX
      ADD      #4,SP
; SHIFT BIT FOR NEXT TEST
; PLACE PATTERN IN EXPECTED
; COMPLIMENT FOR MOVING 0
; DECREMENT LOOP COUNTER
; IF NOT DONE, BRANCH BACK
;
; ANY ERRORS
; BRANCH IF NO ERRORS
; LINE FEED
;
5000:
      ENDTST
L10101:
      TRAP     C0ETST
      INIT
; INITIALIZE DEVICE
      MOV      #MQHALT,BQMT1
      MOV      INITWORD,BQMT1
      CLR      BQINT
      CLR      ERROR1
; INITIALIZE Q-BRIDGE
; SET UP LOOPBACK OPTION
; CLEAR QINT AFTER LOOPBACK ENABLED
; CLEAR ERROR FLAG

```

TEST24: CHECK QVAD (U-REGISTER) (MOVING 1)

```

1686 .SBTTL TEST24: CHECK QVAD (U-REGISTER) (MOVING 1)
1687 026742 STATST <CHECK QVAD (U-REGISTER) (MOVING 1)>
1688 026742 040 103 110 T24MSG: .ASCIZ / CHECK QVAD (U-REGISTER) (MOVING 1)/
1689 ;*****
1690 ;**
1691 ;TEST DESCRIPTION
1692 ; CHECKS THAT QVAD (C-COUNTER) CAN BE LOADED AND READ
1693 ; USES LDQVADR - LDUVADR LOOP-BACK
1694 ; USES QTSOUT - QTSIN LOOP-BACK
1695 ;TEST STEPS-
1696 ; SET QMT1 FUNC = 3 (SELUVADR)
1697 ; LOAD WORD IN QMTO
1698 ; SET QMT1 MVADR BIT
1699 ; READ QMTO, CHECK
1700 ; CLEAR QMT1 MVADR BIT
1701 ; MOVE BIT
1702 ; REPEAT FOR ALL BITS
1703 ;
1704 ;--
1705 ;*****
1706
1707 027006 BGNTST
1708 027006 T24::
1709 027006 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1710 027010 TRAP C@RFLA ; IS PNT FLAG SET?
1711 027014 CMP #PNT,R0 ; BRANCH IF NOT SET
1712 027016 BNE 64$
1713 027016 MOV #T24MSG,-(SP)
1714 027022 MOV #PNTMSG,-(SP)
1715 027026 MOV #2,-(SP)
1716 027032 MOV SP,R0
1717 027034 TRAP C@PNTF
1718 027036 ADD #6,SP
1719 027042 CLR ERROR1 ; CLEAR ERROR COUNTER
1720 027046 INIT
1721 027046 ;INITIALIZE DEVICE
1722 027054 MOV #QHALT,@QMT1 ;INITIALIZE Q-BRIDGE
1723 027062 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
1724 027066 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
1725 027072 CLR ERROR1 ;CLEAR ERROR FLAG
1726 027076 MOV #10,,R1 ; REGISTER NUMBER TO R1
1727 027104 BIS #SELUVADR,@QMT1 ; SELECT QMT1 FUNCTION = 3
1728 027110 MOV #16,,R2 ; NUMBER OF BITS TO CHECK
1729 027116 MOV #BIT0,EXP ; FIRST DATA PATTERN TO CHECK
1730 ;
1731 ; TEST BITS 0-15 WITH MOVING ONE
1732 ;
1733 027116 BGNSUB
1734 027116 T24.1:
1735 027120 TRAP C@BSUB
1736 027122 BGNSUB
1737 027126 TRAP C@BSEG
1738 027130 MOV EXP,@QMTO ; MOVE EXPECTED TO REGISTER QVAD
1739 027136 BIS #MVADR,@QMT1 ; SET MVADR BIT IN QMT1
1740 027142 MOV @QMTO,VAL ; READ QVAD AND MOVE TO VALUE
1741 027144 BIC #MVADR,@QMT1 ; CLEAR MVADR BIT IN QMT1

```


TEST24: CHECK QVAD (U-REGISTER) (MOVING 1)

```

1723 027152 023737 002530 002526      CMP      EXP,VAL      ; COMPARE EXPECTED WITH VALUE
1724 027160 001414                      BEQ      20$          ; IF OK, BRANCH
1725                                     ;
1726                                     ; ERROR CONDITION
1727                                     ;
1728 027162 005737 002532      TST      ERROR1      ; SEE IF FIRST ERROR
1729 027166 001005                      BNE      15$          ; SKIP HEADER IF ALREADY PRINTED
1730 027170                      ERRMRD   1,MSG30,ERR7 ; TELL OPERATOR ERROR
      027170 104456                      TRAP    C$ERRMRD
      027172 000001                      .WORD   1
      027174 006471                      .WORD   MSG30
      027176 012246                      .WORD   ERR7
1731 027200 000402                      BR       18$          ; SKIP DETAIL LINE IF HEADER PRINTED
1732 027202 004737 012366      15$:    CALL    DETAIL ; PRINT DETAIL LINE
1733 027206 005237 002532      18$:    INC     ERROR1 ; INCREMENT ERROR COUNT
1734                                     ;
1735                                     ; END ERROR CONDITION
1736                                     ;
1737 027212                      20$:    ENDSEG
      027212                      10000$:
1738 027214 006337 002530      TRAP    C$ESEG
1739 027220 005302                      ASL     EXP
1740 027222 001336                      DEC     R2            ; SHIFT BIT FOR NEXT TEST
1741 027224                      BNE     10$          ; DECREMENT LOOP COUNTER
      027224                      ENDSUB              ; IF NOT DONE, BRANCH BACK
1742 027226 005737 002532      L10104: TRAP    C$ESUB
1743 027232 001410                      TST     ERROR1      ; ANY ERRORS
1744 027234                      BEQ     500$         ; BRANCH IF NO ERRORS
      027234 012746 003333      PRINTX #FORO        ; LINE FEED
      027240 012746 000001      MOV     #FORO,-(SP)
      027244 010600                      MOV     #1,-(SP)
      027246 104415                      MOV     SP,R0
      027250 062706 000004      TRAP    C$PNTX
1745 027254                      ADD     #4,SP
1746 027254                      500$:    ENDTST
      027254 104401                      L10103: TRAP    C$ETST

```

TEST25: CHECK QVAD (U-REGISTER) (MOVING 0)

```

1748 .SBTTL TEST25: CHECK QVAD (U-REGISTER) (MOVING 0)
1749 027256 STATST <CHECK QVAD (U-REGISTER) (MOVING 0)>
1750 027256 040 103 110 T25MSG:: .ASCIZ / CHECK QVAD (U-REGISTER) (MOVING 0)/
1751 ;*****
1752 ;**
1753 ;TEST DESCRIPTION
1754 ; CHECKS THAT QVAD (C-COUNTER) CAN BE LOADED AND READ
1755 ; USES LDQVADR - LDUVADR LOOP-BACK
1756 ; USES QTSOUT - QTSIN LOOP-BACK
1757 ;TEST STEPS-
1758 ; SET QMT1 FUNC = 3 (SELUVADR)
1759 ; LOAD WORD IN QMTO
1760 ; SET QMT1 MVADR BIT
1761 ; READ QMTO, CHECK
1762 ; CLEAR QMT1 MVADR BIT
1763 ; MOVE BIT
1764 ; REPEAT FOR ALL BITS
1765 ;
1766 ;--
1767 ;*****
1768
1769 027322 BGNTST
1770 027322 T25:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1771 027322 TRAP C#RFLA ; IS PNT FLAG SET?
1772 027324 104421 001000 CMP #PNT,RO ; BRANCH IF NOT SET
1773 027330 001012 BNE 64#
1774 027332 012746 027256 MOV #T25MSG,-(SP)
1775 027336 012746 002270 MOV #PNTMSG,-(SP)
1776 027342 012746 000002 MOV #2,-(SP)
1777 027346 010600 MOV SP,RO
1778 027350 104417 TRAP C#PNTF
1779 027352 062706 000006 ADD #6,SP
1780 027356 005037 002532 64# CLR ERROR1 ; CLEAR ERROR COUNTER
1781 027362 INIT
1782 ;INITIALIZE DEVICE
1783 027362 012777 000100 152726 MOV #QHALT,QMT1 ; INITIALIZE Q-BRIDGE
1784 027370 013777 002520 152720 MOV INITWORD,QMT1 ; SET UP LOOPBACK OPTION
1785 027376 005077 152676 CLR #QINT ; CLEAR QINT AFTER LOOPBACK ENABLED
1786 027402 005037 002532 CLR ERROR1 ; CLEAR ERROR FLAG
1787 1772 027406 012701 000012 MOV #10,R1 ; REGISTER NUMBER TO R1
1788 1773 027412 012702 000020 MOV #16,R2 ; NUMBER OF BITS TO CHECK
1789 1774 027416 012703 000001 MOV #BIT0,R3 ; INITIAL DATA PATTERN TO R3
1790 1775 027422 010337 002530 MOV R3,EXP ; MOVE BIT PATTERN TO EXPECTED
1791 1776 027426 005137 002530 COM EXP ; COMPLEMENT FOR MOVING 0
1792 1777 027432 052777 000014 152656 BIS #SELUVADR,QMT1 ; SELECT FUNCTION 3 IN QMT1
1793 1778 ;
1794 1779 ; TEST BITS 0-15 WITH MOVING ZERO
1795 1780 ;
1796 1781 027440 BGNSUB
1797 027440 T25.1: TRAP C#BSUB
1798 1782 027440 104402 10# BGNSEG
1799 027442 TRAP C#BSEG
1800 1783 027444 013777 002530 152642 MOV EXP,QMTO ; MOVE EXPECTED TO REGISTER QVAD
1801 1784 027452 052777 000002 152636 BIS #MVADR,QMT1 ; SET MVADR BIT IN QMT1

```

TEST25: CHECK QVAD (U-REGISTER) (MOVING 0)

```

1785 027460 017737 152630 002526      MOV      @QMT0,VAL      ; MOVE CONTENTS OF QVAD TO VALUE
1786 027466 042777 000002 152622      BIC      @MVADR,@QMT1  ; CLEAR MVADR BIT IN QMT1
1787 027474 023737 002530 002526      CMP      EXP,VAL      ; COMPARE EXPECTED WITH VALUE
1788 027502 001414                BEQ      20$          ; IF OK, BRANCH
1789
1790                ; ERROR CONDITION
1791
1792 027504 005737 002532                TST      ERROR1      ; SEE IF FIRST ERROR
1793 027510 001005                BNE      15$          ; SKIP HEADER IF ALREADY PRINTED
1794 027512                ERRHRD  1,MSG31,ERR7 ; TELL OPERATOR ERROR
      027512 104456                TRAP    C#ERRHRD
      027514 000001                .WORD   1
      027516 006532                .WORD  MSG31
      027520 012246                .WORD  ERR7
1795 027522 000402                BR       18$          ; SKIP DETAIL LINE IF HEADER PRINTED
1796 027524 004737 012366      15$: CALL    DETAIL    ; PRINT DETAIL LINE
1797 027530 005237 002532      18$: INC    ERROR1   ; INCREMENT ERROR COUNT
1798
1799                ; END ERROR CONDITION
1800
1801 027534                ;
      027534                20$: ENDSEG
      027534 104405      10000$:
1802 027536 006303                TRAP    C#ESEG
1803 027540 010337 002530      ASL     R3            ; SHIFT BIT FOR NEXT TEST
1804 027544 005137 002530      MOV     R3,EXP       ; PLACE PATTERN IN EXPECTED
1805 027550 005302                COM     EXP           ; COMPLIMENT FOR MOVING 0
1806 027552 001333                DEC     R2            ; DECREMENT LOOP COUNTER
1807 027554                BNE     10$          ; IF NOT DONE, BRANCH BACK
      027554                ENDSUB
      027554 104403      L10106:
1808 027556 005737 002532      TRAP    C#ESUB
1809 027562 001410                TST     ERROR1      ; ANY ERRORS
1810 027564                BEQ     500$         ; BRANCH IF NO ERRORS
      027564 012746 003333      PRINTX @FORO         ; LINE FEED
      027570 012746 000001      MOV     @FORO,-(SP)
      027574 010600                MOV     @1,-(SP)
      027576 104415                MOV     SP,R0
1811 027600 062706 000004      TRAP    C#PNTX
1812 027604                ADD     @4,SP
      027604 104401      500$:
      027604                ENDTST
      027604                L10105:
      027604 104401                TRAP    C#ETST

```

TEST26: CHECK QVAD INCREMENT (Q-REGISTER)

```

1814 .SBTTL TEST26: CHECK QVAD INCREMENT (Q-REGISTER)
1815 027606 STATST <CHECK QVAD INCREMENT (Q-REGISTER)>
1816 027606 040 103 110 T26MSG:: .ASCIZ / CHECK QVAD INCREMENT (Q-REGISTER)/
1817 ;*****
1818 ;**
1819 ;TEST DESCRIPTION
1820 ; CHECKS THAT QVAD (A-COUNTER) INCREMENT ON READ QVDA
1821 ;TEST STEPS-
1822 ; LOAD QVAD WITH 1'S
1823 ; READ QVDA
1824 ; READ QVAD, CHECK FOR 0
1825 ;
1826 ;--
1827 ;*****
1828
1829 027652 BGNTST
1830 027652 T26::
1831 027652 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
1832 027652 104421 TRAP C#RFLA
1833 027654 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
1834 027660 001012 BNE 64# ; BRANCH IF NOT SET
1835 027662 012746 027606 MOV #T26MSG,-(SP)
1836 027666 012746 002270 MOV #PNTMSG,-(SP)
1837 027672 012746 000002 MOV #2,-(SP)
1838 027676 010600 MOV SP,R0
1839 027700 104417 TRAP C#PNTF
1840 027702 062706 000006 ADD #6,SP
1841 027706 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1842 ;
1843 ; INITIALIZE DEVICE
1844 ;
1845 1834 027712 012777 000100 152376 MOV #MHALT,BQMT1 ; INITIALIZE Q-BRIDGE
1846 1835 027720 012701 000012 MOV #10.,R1 ; REGISTER NUMBER TO R1
1847 ;
1848 ; TEST FOR INCREMENT
1849 ;
1850 1839 027724 BGNSUB
1851 027724 T26.1:
1852 1840 027726 104402 TRAP C#BSUB
1853 1841 027734 052777 000020 152346 BIS #QVREN,BQCTL ; READ ENABLE
1854 1842 027742 017702 152354 MOV #-1,BQVAD ; MOVE ALL ONE'S TO QVAD
1855 1843 027746 012737 000000 002530 MOV BQVDA,R2 ; DUMMY READ TO QVDA
1856 1844 027754 052777 000002 152334 MOV #0,EXP ; CLEAR EXPECTED FIELD
1857 1845 027762 017737 152332 002526 BIS #MVADR,BQMT1 ; ENABLE TO READ QVAD
1858 1846 027770 023737 002530 002526 MOV BQVAD,VAL ; MOVE CURRENT VALUE OF QVAD TO VAL
1859 1847 027776 001406 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
1860 1848 ; BEQ 1# ; IF OK, BRANCH
1861 ;
1862 ; ERROR CONDITION
1863 ;
1864 1851 030000 ERRHRD 1,MSG32,ERR4 ; TELL OPERATOR ERROR
1865 030000 104456 TRAP C#ERRHD
1866 030002 000001 .WORD 1
1867 030004 006573 .WORD MSG32
1868 030006 011776 .WORD ERR4
1869 1852 030010 004737 013230 JSR PC,DUMP ; DO OPTIONAL REGISTER DUMP

```

TEST26: CHECK QVAD INCREMENT (Q-REGISTER)

1853 030014
1854 030014
030014 104403
1855 030016
030016 104401
030016

18:
L10110: ENDSUB
TRAP C#ESUB
ENDTST
L10107:
TRAP C#ETST

TEST27: CHECK QVAD INCREMENT (U-REGISTER)

```

1857 .SBTTL TEST27: CHECK QVAD INCREMENT (U-REGISTER)
1858 030020 STATST <CHECK QVAD INCREMENT (U-REGISTER)>
      030020 040 103 110 T27MSG:: .ASCIZ / CHECK QVAD INCREMENT (U-REGISTER)/
1859
1860 ;*****
1861 ;**
1862 ;TEST DESCRIPTION-
1863 ; CHECKS THAT QVAD (C-COUNTER) INCREMENT ON LDUVDAT
1864 ; USES LDQVADR - LDUVADR LOOP-BACK
1865 ; USES QTSOUT - QTSIN LOOP-BACK
1866 ;TEST STEPS-
1867 ; SET QMT1 FUNC = 3 (SELUVADR)
1868 ; LOAD QMTO WITH 1'S
1869 ; SET QMT1 FUNC = 6 (SEL UV DAT)
1870 ; LOAD QMTO (ANY VALUE)
1871 ; SET QMT1 MVADR BIT
1872 ; SET QMT1 FUNC = 3 (SELUVADR)
1873 ; READ QMTO, CHECK FOR 0
1874 ;
1875 ;--
1876 ;*****
1877
1878 030064 BGNTST
      030064
1879 030064 T27:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      030064 104421 TRAP C#RFLA
      030066 022700 001000 CMP #PNT,RO ; IS PNT FLAG SET?
      030072 001012 BNE 64# ; BRANCH IF NOT SET
      030074 012746 030020 MOV #T27MSG,-(SP)
      030100 012746 002270 MOV #PNTMSG,-(SP)
      030104 012746 000002 MOV #2,-(SP)
      030110 010600 MOV SP,RO
      030112 104417 TRAP C#PNTF
      030114 062706 000006 ADD #6,SP
      030120 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
1880 030124 INIT
      030124 012777 000100 152164 ;INITIALIZE DEVICE
      030132 013777 002520 152156 MOV #MHALT,@QMT1 ;INITIALIZE Q-BRIDGE
      030140 005077 152134 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
      030144 005037 002532 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
1881 030150 012701 000012 CLR ERROR1 ;CLEAR ERROR FLAG
1882 MOV #10,,R1 ; REGISTER NUMBER TO R1
1883 ;
1884 ; CHECK QVAD INCREMENT
1885 ;
1885 030154 BGNSUB
      030154
1885 030154 104402 T27.1: TRAP C#BSUB
1886 030156 052777 000014 152132 BIS #SELUVADR,@QMT1 ; SELECT QMT1 FUNC = 3 (SELUVADR)
1887 030164 012777 177777 152122 MOV #-1,@QMTO ; LOAD QMTO WITH ALL ZERO'S
1888 030172 042777 000014 152116 BIC #SELUVADR,@QMT1 ; DESELECT QMT1 FUNC = 3 (SELUVADR)
1889 030200 052777 000030 152110 BIS #SELUVDAT,@QMT1 ; SELECT QMT1 FUNC = 6 (SELUVDAT)
1890 030206 012777 177777 152100 MOV #-1,@QMTO ; LOAD QMTO (ANY VALUE)
1891 030214 042777 000030 152074 BIC #SELUVDAT,@QMT1 ; DESELECT QMT1 FUNC = 6 (SELUVDAT)
1892 030222 052777 000016 152066 BIS #SELUADR!MVADR,@QMT1 ; SET QMT1 = FUNC 3 (SELUVADR) & MVADR BIT
1893 030230 012737 000000 002530 MOV #0,EXP ; LOAD EXP WITH EXPECTED VALUE
1894 030236 017737 152052 002526 MOV @QMTO,VAL ; READ QMTO, LOAD INTO VALUE

```

TEST27: CHECK QVAD INCREMENT (U-REGISTER)

```

1895 030244 042777 000016 152044      BIC  @SELUVADR!MVADR,@QMT1  ; Deselect QMT1 = FUNC 3 (SELUVADR) & MVARD BIT
1896 030252 023737 002530 002526      CMP  EXP,VAL                ; COMPARE EXPECTED WITH VALUE
1897 030260 001406                      BEQ  18                      ; IF OK, BRANCH
1898
1899      ;
1900      ; ERROR CONDITION
1901      ;
1901 030262                      ERRMRD 1,MSG33,ERR4          ; TELL OPERATOR ERROR
      030262 104456              TRAP  C@ERRMRD
      030264 000001              .WORD 1
      030266 006633              .WORD MSG33
      030270 011776              .WORD ERR4
1902 030272 004737 013230          JSR  PC,DUMP                ; DO OPTIONAL REGISTER DUMP
1903 030276
1904 030276
      030276
      030276 104403
1905 030300
      030300
      030300 104401

18:
L10112: ENDSUB
      TRAP  C@ESUB
L10111: ENDTST
      TRAP  C@ETST
    
```

TEST28: CHECK VIEW REGISTER RAM

```

1907 .SBTTL TEST28: CHECK VIEW REGISTER RAM
1908 030302 STATST <CHECK VIEW REGISTER RAM>
      030302 040 103 110 T28MSG:: .ASCIZ / CHECK VIEW REGISTER RAM/
1909
1910 ;*****
1911 ;**
1912 ;TEST DESCRIPTION-
1913 ; CHECKS EACH VIEW DATA RAM LOCATION WITH 1'S AND 0'S
1914 ; CHECKS ALL LOCATIONS FOR NO CHANGE
1915 ; USES QVAD (Q-REGISTER) FOR READ ADDRESS
1916 ; USED QVAD (U-REGISTER) FOR WRITE ADDRESS
1917 ; USES LUQVAD - LDUVDAT LOOP-BACK
1918 ; USES QTSOUT - QTSIN LOOP-BACK
1919 ;TEST STEPS-
1920
1921 ; SET MIODIS (LOOPBACK ENABLE BIT)
1922 ; SELECT FUNCTION = 3 UVADR
1923 ; LOAD QVAD (UVADR) WITH ADDRESS (START AT 0)
1924 ; Deselect FUNCTION 3
1925 ; SELECT FUNCTION = 6 UVDAT
1926 ; LOAD QMTO WITH 1'S (QVDA WRITE)
1927 ; CLEAR MIODIS (LOOPBACK ENABLE BIT) AND FUNCTION 6
1928 ; LOAD QVAD (QVADR) WITH ADDRESS
1929 ; READ QVDA, CHECK FOR ALL 1'S
1930
1931 ; SET MIODIS (LOOPBACK ENABLE BIT)
1932 ; SELECT FUNCTION = 3 UVADR
1933 ; LOAD QVAD (UVADR) WITH ADDRESS
1934 ; Deselect FUNCTION 3
1935 ; SELECT FUNCTION = 6 UVDAT
1936 ; LOAD QMTO WITH 0'S (QVDA WRITE)
1937 ; SELECT FUNCTION = 3 UVADR
1938 ; SET MVADR BIT (QVAD DIRECTION BIT) IN QMT1
1939 ; READ QMTO (UVADR) ADDRESS, CHECK FOR INCREMENT
1940 ; CLEAR MVADR BIT IN QMT1
1941 ; CLEAR MIODIS (LOOPBACK ENABLE BIT) AND FUNCTION 6
1942 ; LOAD QVAD (QVADR) WITH ADDRESS
1943 ; READ QVDA, CHECK FOR ALL 0'S
1944 ; SET MVADR BIT (QVAD DIRECTION BIT) IN QMT1
1945 ; READ QVAD, CHECK FOR ADDRESS INCREMENTS
1946 ; CLEAR QMT1 MVADR BIT
1947 ; REPEAT FOR 2K ADDRESSES (RAM ADDRESS SHOULD BE 0 AT END)
1948 ;
1949 ;--
1950 ;*****
1951
1952 030334 BGNTST
      030334
1953 030334 T28:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      030334 104421 TRAP C@RFLA
      030336 022700 001000 CMP @PNT,RO ; IS PNT FLAG SET?
      030342 001012 BNE 64@ ; BRANCH IF NOT SET
      030344 012746 030302 MOV @T28MSG, -(SP)
      030350 012746 002270 MOV @PNTMSG, -(SP)
      030354 012746 000002 MOV @2, -(SP)
      030360 010600 MOV SP,RO
      030362 104417 TRAP C@PNTF

```


TEST28: CHECK VIEW REGISTER RAM

1954	030364	062706	000006		648:	ADD	#6,SP		
1955	030370	005037	002532			CLR	ERROR1		; CLEAR ERROR COUNTER
1956									
1957	030374	012777	000100	151714		MOV	#MGMALT, @QMT1		; INITIALIZE Q-BRIDGE
1958	030402	012701	004000			MOV	#4000, R1		; ALLOW FOR 2K RAM IN LOOP
1959	030406	005037	002532			CLR	ERROR1		; CLEAR ERROR OCCURED COUNTER
1960	030412	005037	002534			CLR	ERROR2		; CLEAR ERROR OCCURED COUNTER
1961	030416	012737	000000	002524		MOV	#0, ADD		; START AT RAM ADDRESS ZERO
1962									
1963									
1964									
1965	030424								
	030424								
	030424	104402			T28.1:	TRAP	C#BSUB		
1966	030426				L28:				; START LOOPS HERE
1967	030426					BGNSEG			
	030426	104404				TRAP	C#BSEG		
1968									
1969									
1970									
1971									
1972	030430	013777	002520	151660		MOV	INITWORD, @QMT1		; SET UP LOOPBACK OPTION
1973	030436	005077	151636			CLR	@QINT		; CLEAR QINT AFTER LOOPBACK ENABLED
1974	030442	042777	000020	151632		BIC	@QVREN, @QCTL		; CLEAR READ ENABLE
1975	030450	052777	000014	151640		BIS	@SELUVADR, @QMT1		; SELECT UVADR
1976	030456	013777	002524	151630		MOV	ADD, @QMT0		; LOAD U SIDE OF QVAD WITH RAM ADDRESS
1977									
1978									
1979									
1980	030464	042777	000014	151624		BIC	@SELUVADR, @QMT1		; DESELECT UVADR
1981	030472	052777	000030	151616		BIS	@SELUVDAT, @QMT1		; SELECT UVDAT TO WRITE TO RAM
1982									
1983									
1984									
1985	030500	012737	177777	002530		MOV	#-1, EXP		; EXPECTED PATTEN TO EXP
1986	030506	013777	002530	151600		MOV	EXP, @QMT0		; MOVE ALL 1'S TO QVDA THROUGH QMT0
1987									
1988									
1989									
1990	030514	052777	000020	151560		BIS	@QVREN, @QCTL		; READ ENABLE
1991	030522	012777	000000	151566		MOV	#0, @QMT1		; CLEAR MAINTENANCE LOOP-BACK BIT
1992	030530	013777	002524	151562		MOV	ADD, @QVAD		; LOAD QVAD WITH RAM ADDRESS
1993									
1994									
1995									
1996	030536	017737	151560	002526		MOV	@QVDA, VAL		; READ QVDA
1997	030544	023737	002530	002526		CMP	EXP, VAL		; COMPARE EXPECTED WITH VALUE
1998	030552	001433				BEQ	204		; IF OK, BRANCH
1999									
2000									
2001									
2002	030554	005737	002532			TST	ERROR1		; CHECK FOR PREVIOUS ERRORS
2003	030560	001004				BNE	104		; BRANCH IF PREVIOUS ERRORS
2004	030562					ERRHRD	1, MSG34, ERR5		; PRINT ERROR HEADER
	030562	104456				TRAP	C#ERHRD		

TEST28: CHECK VIEW REGISTER RAM

```

030564 000001      .WORD 1
030566 006673      .WORD MSG34
030570 012136      .WORD ERR5
2005 030572 022737 000023 002532 100:  CMP    #19.,ERROR1      ; SEE IF TOO MANY TO PRINT
2006 030600 100416      BMI    150              ; BRANCH IF MORE THAN 10 PRINTED
2007 030602      PRINTB #FOR4,ADD,VAL,EXP ; PRINT ERROR LINE
      030602 013746 002530      MOV    EXP,-(SP)
      030606 013746 002526      MOV    VAL,-(SP)
      030612 013746 002524      MOV    ADD,-(SP)
      030616 012746 003552      MOV    #FOR4,-(SP)
      030622 012746 000004      MOV    #4,-(SP)
      030626 010600      MOV    SP,R0
      030630 104414      TRAP  C#PNTB
      030632 062706 000012      ADD    #12,SP
2008 030636 005237 002532 150:  INC    ERROR1          ; INCREMENT ERROR OCCURRED COUNTER
2009 030642      200:
2010      ;
2011      ; NOW CHECK WITH ALL 0'S
2012      ; RESTORE U SIDE RAM ADDRESS AFTER INCREMENT
2013      ;
2014 030642 013777 002520 151446      MOV    INITWORD,@QMT1 ; SET UP LOOPBACK OPTION
2015 030650 005077 151424      CLR    @QINT           ; CLEAR QINT AFTER LOOPBACK ENABLED
2016 030654 042777 000020 151420      BIC    @QVREN,@QCTL   ; CLEAR READ ENABLE
2017 030662 052777 000014 151426      BIS    @SELUVADR,@QMT1 ; SELECT UVADR
2018 030670 013777 002524 151416      MOV    ADD,@QMT0      ; LOAD U SIDE OF QVAD WITH RAM ADDRESS
2019      ;
2020      ; SET UP FOR WRITE TO RAM
2021      ;
2022 030676 042777 000014 151412      BIC    @SELUVADR,@QMT1 ; DESELECT UVADR
2023 030704 052777 000030 151404      BIS    @SELUVDAT,@QMT1 ; SELECT UVDAT TO WRITE TO RAM
2024      ;
2025      ; WRITE DATA
2026      ;
2027 030712 012737 000000 002530      MOV    #0,EXP         ; LOAD ALL 0'S TO EXP
2028 030720 013777 002530 151366      MOV    EXP,@QMT0      ; MOVE ALL 0'S TO QVDA THROUGH QMT0
2029      ;
2030      ; NOW CHECK TO SEE IF QVAD U SIDE REALLY DID INCREMENT
2031      ;
2032 030726 042777 000030 151362      BIC    @SELUVDAT,@QMT1 ; DESELECT UVDAT
2033 030734 052777 000014 151354      BIS    @SELUVADR,@QMT1 ; SELECT UVADR
2034 030742 052777 000002 151346      BIS    @MVADR,@QMT1   ; SET MVADR BIT IN QMT1
2035 030750 017737 151340 002526      MOV    @QMT0,VAL      ; READ U ADDRESS IN QVAD FROM QMT0
2036 030756 042777 000002 151332      BIC    @MVADR,@QMT1   ; CLEAR MVADR BIT IN QMT1
2037 030764 042777 000014 151324      BIC    @SELUVADR,@QMT1 ; DESELECT UVADR
2038 030772 013737 002524 002530      MOV    ADD,EXP        ; MOVE CURRENT ADDRESS TO EXPECTED
2039 031000 005237 002530      INC    EXP            ; INCREMENT EXPECTED
2040 031004 023737 002530 002526      CMP    EXP,VAL        ; COMPARE EXPECTED WITH VALUE
2041 031012 001434      BEQ    1700          ; IF OK, BRANCH
2042      ;
2043      ; ERROR CONDITION 2
2044      ;
2045 031014 005737 002532      TST    ERROR1         ; CHECK FOR PREVIOUS ERROR FROM ABOVE
2046 031020 001007      BNE    1500          ; IF ERROR FROM ABOVE, BRANCH
2047 031022 005737 002534      TST    ERROR2         ; CHECK FOR PREVIOUS ERROR
2048 031026 001004      BNE    1500          ; BRANCH IF PREVIOUS ERRORS
2049 031030      ERHRD 2,MSG35
      031030 104456      TRAP  C#ERHRD

```

TEST28: CHECK VIEW REGISTER RAM

```

031032 000002          .WORD 2
031034 006736          .WORD MSG35
031036 000000          .WORD 0
2050 031040 022737 000011 002534 150:  CMP    #9,.ERROR2          ; SEE IF TOO MANY TO PRINT
2051 031046 100414          BMI    160:                ; BRANCH IF MORE THAN 10 PRINTED
2052 031050          PRINTB #FOR5.5,EXP,VAL        ; PRINT ERROR LINE
      031050 013746 002526  MOV    VAL,-(SP)
      031054 013746 002530  MOV    EXP,-(SP)
      031060 012746 003762  MOV    #FOR5.5,-(SP)
      031064 012746 000003  MOV    #3,-(SP)
      031070 010600          MOV    SP,R0
      031072 104414          TRAP  C#PNTB
      031074 062706 000010  ADD    #10,SP
2053 031100 005237 002534 160:  INC    ERROR2              ; INCREMENT ERROR COUNTER
2054
2055 031104          170:
2056
2057          ; RESTORE Q SIDE RAM ADDRESS AFTER INCREMENT
2058
2059 031104 052777 000020 151170  BIS    #QVREN,#QCTL        ; READ ENABLE
2060 031112 012777 000000 151176  MOV    #0,#QMT1           ; CLEAR MAINTENANCE LOOP-BACK BIT
2061 031120 013777 002524 151172  MOV    ADD,#QVAD          ; LOAD QVAD WITH RAM ADDRESS
2062 031126 012737 000000 002530  MOV    #0,EXP            ; RESTORE EXPECTED VALUE
2063
2064          ; READ DATA
2065
2066 031134 017737 151162 002526  MOV    QVDA,VAL          ; READ QVDA
2067 031142 023737 002530 002526  CMP    EXP,VAL           ; COMPARE EXPECTED WITH VALUE
2068 031150 001433          BEQ    40:                ; IF OK, BRANCH
2069
2070          ; ERROR CONDITION 3
2071
2072 031152 005737 002532          TST    ERROR1             ; CHECK FOR PREVIOUS ERRORS
2073 031156 001004          BNE    30:                ; BRANCH IF PREVIOUS ERRORS
2074 031160          ERRHRD 3,MSG34,ERR5    ; PRINT ERROR HEADER
      031160 104456          TRAP  C#ERRRD
      031162 000003          .WORD 3
      031164 006673          .WORD MSG34
      031166 012136          .WORD ERR5
2075 031170 022737 000023 002532 30:  CMP    #19,.ERROR1        ; SEE IF TOO MANY TO PRINT
2076 031176 100416          BMI    35:                ; BRANCH IF MORE THAN 10 PRINTED
2077 031200          PRINTB #FOR4,ADD,VAL,EXP  ; PRINT ERROR LINE
      031200 013746 002530  MOV    EXP,-(SP)
      031204 013746 002526  MOV    VAL,-(SP)
      031210 013746 002524  MOV    ADD,-(SP)
      031214 012746 003552  MOV    #FOR4,-(SP)
      031220 012746 000004  MOV    #4,-(SP)
      031224 010600          MOV    SP,R0
      031226 104414          TRAP  C#PNTB
      031230 062706 000012  ADD    #12,SP
2078 031234 005237 002532 35:  INC    ERROR1              ; INCREMENT ERROR OCCURRED COUNTER
2079
2080 031240          40:
2081
2082          ; NOW CHECK TO SEE IF QVAD Q SIDE REALLY DID INCREMENT
2083
2084 031240 052777 000002 151050  BIS    #MVADR,#QMT1        ; SET MVADR BIT IN QMT1

```

TEST28: CHECK VIEW REGISTER RAM

```

2085 031246 017737 151046 002526      MOV      @QVAD,VAL      ; READ ADDRESS
2086 031254 042777 000002 151034      BIC      @MVADR,@QMT1  ; CLEAR MVADR BIT IN QMT1
2087 031262 013737 002524 002530      MOV      ADD,EXP      ; MOVE CURRENT ADDRESS TO EXPECTED
2088 031270 005237 002530      INC      EXP          ; INCREMENT EXPECTED
2089 031274 023737 002530 002526      CMP      EXP,VAL      ; COMPARE EXPECTED WITH VALUE
2090 031302 001434      BEQ      610          ; IF OK, BRANCH
2091
2092      ; ERROR CONDITION 4
2093
2094 031304 005737 002532      TST      ERROR1      ; CHECK FOR PREVIOUS ERROR FROM ABOVE
2095 031310 001007      BNE      500          ; IF ERROR FROM ABOVE, BRANCH
2096 031312 005737 002534      TST      ERROR2      ; CHECK FOR PREVIOUS ERROR
2097 031316 001004      BNE      500          ; BRANCH IF PREVIOUS ERRORS
2098 031320      ERRHRD  4,MSG35
      031320 104456      TRAP    C@ERRHRD
      031322 000004      .WORD  4
      031324 006736      .WORD  MSG35
      031326 000000      .WORD  0
2099 031330 022737 000011 002534 500:    CMP      @9,ERROR2    ; SEE IF TOO MANY TO PRINT
2100 031336 100414      RMI      600          ; BRANCH IF MORE THAN 10 PRINTED
2101 031340      PRINTB  @FOR5,EXP,VAL ; PRINT ERROR LINE
      031340 013746 002526      MOV      VAL,-(SP)
      031344 013746 002530      MOV      EXP,-(SP)
      031350 012746 003670      MOV      @FOR5,-(SP)
      031354 012746 000003      MOV      @3,-(SP)
      031360 010600      MOV      SP,R0
      031362 104414      TRAP    C@PNTB
      031364 062706 000010      ADD      @10,SP
2102 031370 005237 002534      600:    INC      ERROR2      ; INCREMENT ERROR COUNTER
2103
2104 031374      610:
2105 031374      ENDSEG
      031374      100000:
      031374 104405      TRAP    C@ESEG
2106
2107      ; SET UP FOR NEXT LOOP
2108
2109 031376 005237 002524      INC      ADD          ; INCREMENT TO NEXT RAM ADDRESS
2110 031402 005301      DEC      R1           ; DECREMENT LOOP COUNTER
2111 031404 001402      BEQ      750          ; IF DONE, BRANCH
2112 031406 000137 030426      JMP      L28         ; NOT FINISHED WITH LOOP, JUMP
2113
2114      ; LOOP MUST BE COMPLETED, PRINT FINAL ERROR TOTALS IF ANY
2115
2116 031412      750:
2117 031412 013701 002532      MOV      ERROR1,R1   ; MOVE ERROR1 COUNT TO R1
2118 031416 063701 002534      ADD      ERROR2,R1  ; ADD ERROR2 COUNT TO R1
2119 031422 005701      TST      R1          ; TEST FOR NO ERRORS
2120 031424 001434      BEQ      800          ; BRANCH IF NO ERRORS
2121
2122      ; PRINT FINAL ERROR TOTALS
2123
2124 031426      PRINTB  @FOR6,ERROR1 ; ERROR ONE ERROR COUNT
      031426 013746 002532      MOV      ERROR1,-(SP)
      031432 012746 004054      MOV      @FOR6,-(SP)
      031436 012746 000002      MOV      @2,-(SP)
      031442 010600      MOV      SP,R0

```

TEST28: CHECK VIEW REGISTER RAM

	031444	104414	
	031446	062706	000006
2125	031452		
	031452	013746	002534
	031456	012746	004114
	031462	012746	000002
	031466	010600	
	031470	104414	
	031472	062706	000006
2126	031476		
	031476	012746	003333
	031502	012746	000001
	031506	010600	
	031510	104414	
	031512	062706	000004
2127	031516		
	031516		
	031516	104403	
2128	031520		
	031520		
	031520	104401	

	TRAP	C#PNTB	
	ADD	#6, SP	
	PRINTB	#FOR7, ERROR2	
	MOV	ERROR2, -(SP)	
	MOV	#FOR7, -(SP)	
	MOV	#2, -(SP)	
	MOV	SP, RO	
	TRAP	C#PNTB	
	ADD	#6, SP	
	PRINTB	#FOR0	
	MOV	#FOR0, -(SP)	
	MOV	#1, -(SP)	
	MOV	SP, RO	
	TRAP	C#PNTB	
	ADD	#4, SP	
	ENDSUB		
80#:			
L10114:	TRAP	C#ESUB	
	ENDTST		
L10113:	TRAP	C#ETST	

; ERROR TWO ERROR COUNT

; LINE FEED CARRIAGE RETURN

TEST29: CHECK RAM ADDRESSING (ADDRESS VALUE)

```

2130 .SBTTL TEST29: CHECK RAM ADDRESSING (ADDRESS VALUE)
2131 031522 STATST <CHECK RAM ADDRESSING (ADDRESS VALUE)>
      031522 040 103 110 T29MSG:: .ASCIZ / CHECK RAM ADDRESSING (ADDRESS VALUE)/
2132 ;*****
2133 ;**
2134 ;TEST DESCRIPTION-
2135 ; CHECKS VIEW DATA RAM ADDRESSING
2136 ; LOADS ALL RAM LOCATIONS WITH ADDRESS
2137 ; CHECKS ALL RAM LOCATIONS
2138 ; USES QVAD (Q-REGISTER) FOR ADDRESS
2139 ; USES LDQV DAT - LDUVDAT LOOP-BACK
2140 ; USES QTSOUT - QTSIN LOOP-BACK
2141 ;TEST STEPS-
2142 ; SELECT FUNCTION UVADR
2143 ; LOAD QVAD WITH ZERO'S THROUGH QMTO
2144 ; Deselect FUNCTION UVADR
2145 ; SELECT FUNCTION UVDAT
2146 ; LOAD QVDA WITH ADDRESS VALUE THROUGH QMTO
2147 ; REPEAT LOAD QVDA THROUGH QMTO FOR 2K ADDRESSES
2148 ; CLEAR MIODIS MAINTENANCE LOOP-BACK BIT
2149 ; LOAD QVAD WITH ZERO
2150 ; READ QVDA, CHECK FOR ZERO OR 2000 (CONFIRMS 1K OR 2K)
2151 ; TELL OPERATOR 1K RAM, 2K RAM OR UNKNOWN SIZE RAM
2152 ; READ QVDA, CHECK DATA
2153 ; REPEAT READ QVDA FOR ALL RAM
2154 ;
2155 ;
2156 ;--
2157 ;*****
2158
2159 031570 BGNTST
2160 031570 T29::
      031570 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      031572 TRAP C:RFLA ; IS PNT FLAG SET?
      031576 CMP #PNT,R0 ; BRANCH IF NOT SET
      031577 BNE 64:
      031600 MOV #T29MSG,-(SP)
      031604 MOV #PNTMSG,-(SP)
      031610 MOV #2,-(SP)
      031614 MOV SP,R0
      031616 TRAP C:PNTF
      031620 ADD #6,SP
      031624 CLR ERROR1 ; CLEAR ERROR COUNTER
2161 031630 64:
      031630 INIT
      031630 ;INITIALIZE DEVICE
      031630 MOV #MGMHALT,@QMT1 ;INITIALIZE Q-BRIDGE
      031636 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
      031644 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
      031650 CLR ERROR1 ;CLEAR ERROR FLAG
      031654 MOV #0,R1 ; CLEAR R1 AS COUNTER
2162
2163 ;
2164 ; SET ADDRESS
2165 ;
2166 031660 BIC #QVREN,@QCTL ; CLEAR READ ENABLE
2167 031666 BIS #SELUVADR,@QMT1 ; SELECT UVADR
2168 031674 MOV #0,@QMT0 ; LOAD U SIDE OF QVAD WITH RAM ADDRESS
2169

```

TEST29: CHECK RAM ADDRESSING (ADDRESS VALUE)

```

2170 ; SET UP FOR WRITE TO RAM
2171 ;
2172 031702 042777 000014 150406 BIC #SELUVADR,@QMT1 ; DESELECT UVADR
2173 031710 052777 000030 150400 BIS #SELUVDAT,@QMT1 ; SELECT UVDAT TO WRITE TO RAM
2174 ;
2175 ; LOAD RAM WITH ADDRESSES
2176 ;
2177 031716 100:
2178 031716 010177 150372 MOV R1,@QMT0 ; LOAD QVDA WITH ADDRESS DATA THROUGH QMT0
2179 031722 005201 INC R1 ; INCREMENT COUNTER
2180 031724 020127 004000 CMP R1,#4000 ; HAS IT LOOPED 2K YET?
2181 031730 001372 BNE 100 ; IF NOT DONE, GO AGAIN
2182 ;
2183 ; ALL RAM LOADED, NOW CHECK FOR 1K OR 2K PRESENT
2184 ;
2185 031732 042777 000200 150356 BIC #MIDDIS,@QMT1 ; CLEAR MAINTENANCE LOOP-BACK BIT
2186 031740 012737 000002 002530 MOV #2,EXP ; AMOUNT OF RAM TO EXP FOR MESSAGE
2187 031746 012701 000000 MOV #0,R1 ; SET COUNTER FOR 2K RAM
2188 031752 012737 000000 002524 MOV #0,ADD ; POINT ADD TO FIRST RAM ADDRESS
2189 ;
2190 ; SET ADDRESS
2191 ;
2192 031760 052777 000020 150314 BIS #QVREN,@QCTL ; READ ENABLE
2193 031766 012777 000000 150324 MOV #0,@QVAD ; LOAD QVAD WITH RAM ADDRESS
2194 031774 017737 150322 002526 MOV @QVDA,VAL ; READ FIRST RAM ADDRESS
2195 032002 022737 000000 002526 CMP #0,VAL ; IS IT 2K RAM
2196 032010 001450 BEQ 200 ; BRANCH IF 2K RAM
2197 032012 012737 000001 002530 MOV #1,EXP ; ASSUME 1K RAM FOR MESSAGES
2198 032020 012701 002000 MOV #2000,R1 ; LOAD R1 COUNTER WITH 1K
2199 032024 022737 002000 002526 CMP #2000,VAL ; IS IT 1K RAM
2200 032032 001437 BEQ 200 ; BRANCH IF 1K RAM
2201 ;
2202 ; ERROR CONDITION, UNKNOWN RAM SIZE
2203 ; ASSUME 1K FOR REST OF TEST
2204 ;
2205 032034 005237 002532 INC ERROR1 ; INCREMENT ERROR COUNTER
2206 032040 ERRHRD 1,MSG34,ERR5 ; PRINT ERROR HEADER
2207 032040 104456 TRAP C@ERRHRD
2208 032042 000001 .WORD 1
2209 032044 006673 .WORD MSG34
2210 032046 012136 .WORD ERR5
2211 ;
2212 ; TELL OPERATOR UNKNOWN RAM SIZE
2213 ;
2214 032050 PRINTB #FOR4.5 ; PRINT UNKNOWN RAM SIZE MESSAGE
2215 032050 012746 003600 MOV #FOR4.5,-(SP)
2216 032054 012746 000001 MOV #1,-(SP)
2217 032060 010600 MOV SP,R0
2218 032062 104414 TRAP C@PNTB
2219 032064 062706 000004 ADD #4,SP
2220 032070 010137 002530 MOV R1,EXP ; EXPECTED VALUE FROM R1
2221 032074 PRINTB #FOR4,ADD,VAL,EXP ; PRINT ERROR LINE
2222 032074 013746 002530 MOV EXP,-(SP)
2223 032100 013746 002526 MOV VAL,-(SP)
2224 032104 013746 002524 MOV ADD,-(SP)
2225 032110 012746 003552 MOV #FOR4,-(SP)
2226 032114 012746 000004 MOV #4,-(SP)

```

TEST29: CHECK RAM ADDRESSING (ADDRESS VALUE)

```

032120 010600
032122 104414
032124 062706 000012
2213 032130 000417
2214
2215
2216
2217
2218 032132 005737 002536
2219 032136 001014
2220 032140
    032140 013746 002530
    032144 012746 004227
    032150 012746 000002
    032154 010600
    032156 104414
    032160 062706 000006
2221 032164 005237 002536
2222
2223
2224
2225 032170
2226 032170 005201
2227 032172 005237 002524
2228 032176 017737 150120 002526
2229 032204 010137 002530
2230 032210 023737 002530 002526
2231 032216 001433
2232
2233
2234
2235 032220 005737 002532
2236 032224 001004
2237
2238
2239
2240 032226
    032226 104456
    032230 000002
    032232 006673
    032234 012136
2241 032236 022737 000023 002532 45:
2242 032244 100416
2243 032246
    032246 013746 002530
    032252 013746 002526
    032256 013746 002524
    032262 012746 003552
    032266 012746 000004
    032272 010600
    032274 104414
    032276 062706 000012
2244 032302 005237 002532
2245
2246
2247
2248 032306

```

```

MOV SP,R0
TRAP C:PNTB
ADD #12,SP
BR 40:
; END ERROR CONDITION
; PRINT RAM SIZE IF DETERMINED AND NOT PREVIOUSLY PRINTED
20: TST RAM ; SEE IF RAM SIZE ALREADY PRINTED
BNE 40: ; IF RAM SIZE PRINTED, BRANCH
PRINTB #FOR9,EXP ; TELL OPERATOR HOW MUCH RAM PRESENT
MOV EXP,-(SP)
MOV #FOR9,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTB
ADD #6,SP
INC RAM ; SET RAM FLAG MESSAGE PRINTED
; NOW LOOP THROUGH AND CHECK REST OF RAM
40:
INC R1 ; INCREMENT COUNTER
INC ADD ; INCREMENT RAM ADDRESS POINTER
MOV @QVDA,VAL ; READ NEXT RAM ADDRESS
MOV R1,EXP ; GET EXPECTED IN EXP
CMP EXP,VAL ; COMPARE EXPECTED TO VALUE
BEQ 50: ; IF OK, BRANCH
; ERROR CONDITION
TST ERROR1 ; HAVE ANY ERRORS OCCURED YET?
BNE 45: ; IF PREVIOUS ERROR, BRANCH
; NO PREVIOUS ERRORS
ERRHRD 2,MSG34,ERR5 ; PRINT ERROR HEADER
TRAP C:ERHRD
.WORD 2
.WORD MSG34
.WORD ERR5
45: CMP #19,ERROR1 ; SEE IF TOO MANY ERRORS TO PRINT
BMI 48: ; BRANCH IF MORE THEN 20 PRINTED
PRINTB #FOR4,ADD,VAL,EXP ; PRINT ERROR LINE
MOV EXP,-(SP)
MOV VAL,-(SP)
MOV ADD,-(SP)
MOV #FOR4,-(SP)
MOV #4,-(SP)
MOV SP,R0
TRAP C:PNTB
ADD #12,SP
48: INC ERROR1 ; INCREMENT ERROR COUNTER
; END OF ERROR ROUTINE, CHECK FOR END OF TEST
50:

```


TEST29: CHECK RAM ADDRESSING (ADDRESS VALUE)

```

2249 032306 020127 003777          CMP      R1,#3777          ; END OF TEST
2250 032312 001326                   BNE      40$              ; BRANCH IF TEST NOT DONE
2251                                     ;
2252                                     ; TEST DONE, PRINT FINAL ERROR TOTALS IF ANY
2253                                     ;
2254 032314 005737 002532          TST      ERROR1          ; ANY ERRORS?
2255 032320 001422                   BEQ      60$              ; IF NO, BRANCH
2256                                     ;
2257                                     ; PRINT FINAL ERROR TOTALS
2258                                     ;
2259 032322                   PRINTB   #FOR6,ERROR1     ; PRINT NUMBER OF ERRORS
      032322 013746 002532          MOV      ERROR1,-(SP)
      032326 012746 004054          MOV      #FOR6,-(SP)
      032332 012746 000002          MOV      #2,-(SP)
      032336 010600                   MOV      SP,R0
      032340 104414                   TRAP     C#PNTB
2260 032342 062706 000006          ADD      #6,SP
      032346 012746 003333          PRINTB   #FOR0          ; LINE FEED CARRIAGE RETURN
      032352 012746 000001          MOV      #FOR0,-(SP)
      032356 010600                   MOV      #1,-(SP)
      032360 104414                   MOV      SP,R0
      032362 062706 000004          TRAP     C#PNTB
2261 032366                   ADD      #4,SP
2262 032366                   60$:
      032366 104401                   L10115:
      032366                   ENDTST
      032366                   TRAP     C#ETST

```

TEST30: CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)

```

2264 .SBTTL TEST30: CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)
2265 032370 STATST <CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)>
032370 040 103 110 T30MSG:: .ASCIZ / CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)/
2266
2267 ;*****
2268 ;**
2269 ;TEST DESCRIPTION-
2270 ; CHECKS VIEW DATA RAM ADDRESSING
2271 ; LOADS ALL RAM LOCATIONS WITH ADDRESS
2272 ; CHECKS ALL RAM LOCATIONS
2273 ; USES QVAD (Q-REGISTER) FOR ADDRESS
2274 ; USES LDQVDAT - LDUVDAT LOOP-BACK
2275 ; USES QTSOUT - QTSIN LOOP-BACK
2276 ;TEST STEPS-
2277 ; SELECT FUNCTION UVADR
2278 ; LOAD QVAD WITH ZERO'S THROUGH QMTO
2279 ; DESELECT FUNCTION UVADR
2280 ; SELECT FUNCTION UVDAT
2281 ; LOAD QVDA WITH COMPLIMENTED ADDRESS VALUE THROUGH QMTO
2282 ; REPEAT LOAD QVDA THROUGH QMTO FOR 2K ADDRESSES
2283 ; CLEAR MIODIS MAINTENANCE LOOP-BACK BIT
2284 ; LOAD QVAD WITH ZERO
2285 ; READ QVDA, CHECK FOR ZERO OR 2000 (CONFIRMS 1K OR 2K)
2286 ; TELL OPERATOR 1K RAM, 2K RAM OR UNKNOWN SIZE RAM
2287 ; READ QVDA, CHECK DATA
2288 ; REPEAT READ QVDA FOR ALL RAM
2289 ;
2290 ;--
2291 ;*****
2292
2293 032452 BGNTST
032452
2294 032452 T30::
032452 104421 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
032454 022700 001000 TRAP C#RFLA
032460 001012 CMP #PNT,R0 ; IS PNT FLAG SET?
032462 012746 032370 BNE 644 ; BRANCH IF NOT SET
032466 012746 002270 MOV #T30MSG,-(SP)
032472 012746 000002 MOV #PNTMSG,-(SP)
032476 010600 MOV #2,-(SP)
032500 104417 TRAP SP,R0
032502 062706 000006 ADD C#PNTF
032506 005037 002532 644: CLR ERROR1 ; CLEAR ERROR COUNTER
2295 032512 INIT
;INITIALIZE DEVICE
032512 012777 000100 147576 MOV #MGMHALT,%QMT1 ;INITIALIZE Q-BRIDGE
032520 013777 002520 147570 MOV INITWORD,%QMT1 ;SET UP LOOPBACK OPTION
032526 005077 147546 CLR %QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
032532 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2296 032536 012701 177777 MOV #-1,R1 ; FIRST 1'S COMPLEMENT TO R1
2297
2298 ;
2299 ; SET ADDRESS
;
2300 032542 042777 000020 147532 BIC #QVREN,%QCTL ; CLEAR READ ENABLE
2301 032550 052777 000014 147540 BIS #SELUVADR,%QMT1 ; SELECT UVADR
2302 032556 012777 000000 147530 MOV #0,%QMTO ; LOAD U SIDE OF QVAD WITH RAM ADDRESS
2303 ;

```

TEST30: CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)

```

2304 ; SET UP FOR WRITE TO RAM
2305 ;
2306 032564 042777 000014 147524 ; BIC #SELUVADR,@QMT1 ; DESELECT UVADR
2307 032572 052777 000030 147516 ; BIS #SELUVDAT,@QMT1 ; SELECT UVDAT TO WRITE TO RAM
2308 ;
2309 ; LOAD RAM WITH ADDRESSES
2310 ;
2311 10#:
2312 032600 010177 147510 ; MOV R1,@QMT0 ; LOAD QVDA WITH ADDRESS DATA THROUGH QMT0
2313 032604 005301 ; DEC R1 ; DECREMENT COUNTER
2314 032606 020127 173777 ; CMP R1,@+C4000 ; HAS IT LOOPED 2K YET?
2315 032612 001372 ; BNE 10# ; IF NOT DONE, GO AGAIN
2316 ;
2317 ; ALL RAM LOADED, NOW CHECK FOR 1K OR 2K PRESENT
2318 ;
2319 032614 052777 000020 147460 ; BIS #QVREN,@QCTL ; READ ENABLE
2320 032622 042777 000200 147466 ; BIC #MIODIS,@QMT1 ; CLEAR MAINTENANCE LOOP-BACK BIT
2321 032630 012737 000002 002530 ; MOV #2,EXP ; ASSUME 2K RAM FOR MESSAGES
2322 032636 012701 000000 ; MOV #0,R1 ; SET COUNTER FOR 2K RAM
2323 032642 012737 000000 002524 ; MOV #0,ADD ; POINT ADD TO FIRST RAM ADDRESS
2324 ;
2325 ; SET ADDRESS
2326 ;
2327 032650 012777 000000 147442 ; MOV #0,@QVAD ; LOAD QVAD WITH RAM ADDRESS
2328 032656 017737 147440 002526 ; MOV @QVDA,VAL ; READ FIRST RAM ADDRESS
2329 032664 022737 177777 002526 ; CMP @+CO,VAL ; IS IT 2K RAM
2330 032672 001452 ; BEQ 20# ; BRANCH IF 2K RAM
2331 032674 012737 000001 002530 ; MOV #1,EXP ; AMOUNT OF RAM TO EXP FOR MESSAGE
2332 032702 012701 002000 ; MOV #2000,R1 ; LOAD R1 COUNTER WITH 1K
2333 032706 022737 175777 002526 ; CMP @+C2000,VAL ; IS IT 1K RAM
2334 032714 001441 ; BEQ 20# ; IF 1K RAM, BRANCH
2335 ;
2336 ; ERROR CONDITION, UNKNOWN RAM SIZE
2337 ; ASSUME 1K FOR REST OF TEST
2338 ;
2339 032716 005237 002532 ; INC ERROR1 ; INCREMENT ERROR COUNTER
2340 032722 ; ERRHRD 1,MSG34,ERR5 ; PRINT ERROR HEADER
2341 032722 104456 ; TRAP C#ERRHRD
2342 032724 000001 ; .WORD 1
2343 032726 006673 ; .WORD MSG34
2344 032730 012136 ; .WORD ERR5
2345 ;
2346 ; TELL OPERATOR UNKNOWN RAM SIZE
2347 ;
2348 032732 ; PRINTB #FOR4.5 ; PRINT UNKNOWN RAM SIZE MESSAGE
2349 032732 012746 003600 ; MOV #FOR4.5,-(SP)
2350 032736 012746 000001 ; MOV #1,-(SP)
2351 032742 010600 ; MOV SP,R0
2352 032744 104414 ; TRAP C#PNTB
2353 032746 062706 000004 ; ADD #4,SP
2354 032752 010137 002530 ; MOV R1,EXP ; EXPECTED VALUE FROM R1
2355 032756 005137 002530 ; COM EXP ; COMPLEMENT EXPRESSION
2356 032762 ; PRINTB #FOR4,ADD,VAL,EXP ; PRINT ERROR LINE
2357 032762 013746 002530 ; MOV EXP,-(SP)
2358 032766 013746 002526 ; MOV VAL,-(SP)
2359 032772 013746 002524 ; MOV ADD,-(SP)
2360 032776 012746 003552 ; MOV #FOR4,-(SP)

```

TEST30: CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)

```

033002 012746 000004      MOV      #4,-(SP)
033006 010600      MOV      SP,R0
033010 104414      TRAP     C:PNTB
033012 062706 000012      ADD      #12,SP
2348 033016 000417      BR       400
2349
2350      ; END ERROR CONDITION
2351      ; PRINT RAM SIZE IF DETERMINED AND NOT PREVIOUSLY PRINTED
2352
2353 033020 005737 002536      200:    TST      RAM      ; SEE IF RAM SIZE ALREADY PRINTED
2354 033024 001014      BNE     400          ; IF RAM SIZE PRINTED, BRANCH
2355 033026      PRINTB  #FOR9,EXP   ; TELL OPERATOR HOW MUCH RAM PRESENT
      033026 013746 002530      MOV      EXP,-(SP)
      033032 012746 004227      MOV      #FOR9,-(SP)
      033036 012746 000002      MOV      #2,-(SP)
      033042 010600      MOV      SP,R0
      033044 104414      TRAP     C:PNTB
      033046 062706 000006      ADD      #6,SP
2356 033052 005237 002536      INC      RAM      ; SET RAM FLAG MESSAGE PRINTED
2357
2358      ; NOW LOOP THROUGH AND CHECK REST OF RAM
2359
2360 033056      400:
2361 033056 005201      INC      R1      ; INCREMENT COUNTER
2362 033060 005237 002524      INC      ADD     ; INCREMENT RAM ADDRESS POINTER
2363 033064 017737 147232 002526      MOV      @QVDA,VAL ; READ NEXT RAM ADDRESS
2364 033072 010137 002530      MOV      R1,EXP  ; GET EXPECTED IN EXP
2365 033076 005137 002530      COM     EXP     ; COMPLEMENT EXPRESSION
2366 033102 023737 002530 002526      CMP     EXP,VAL  ; COMPARE EXPECTED TO VALUE
2367 033110 001432      BEQ     500      ; IF OK, BRANCH
2368
2369      ; ERROR CONDITION
2370
2371 033112 005737 002532      TST     ERROR1   ; HAVE ANY ERRORS OCCURED YET?
2372
2373      ; NO PREVIOUS ERRORS
2374
2375 033116      ERRHRD  2,MSG34,ERR5 ; PRINT ERROR HEADER
      033116 104456      TRAP     C:ERRHD
      033120 000002      .WORD   2
      033122 006673      .WORD   MSG34
      033124 012136      .WORD   ERR5
2376 033126 022737 000023 002532 450:    CMP     #19,,ERROR1 ; SEE IF TOO MANY ERRORS TO PRINT
2377 033134 100416      BHI     480      ; BRANCH IF MORE THEN 20 PRINTED
2378 033136      PRINTB  #FOR4,ADD,VAL,EXP ; PRINT ERROR LINE
      033136 013746 002530      MOV      EXP,-(SP)
      033142 013746 002526      MOV      VAL,-(SP)
      033146 013746 002524      MOV      ADD,-(SP)
      033152 012746 003552      MOV      #FOR4,-(SP)
      033156 012746 000004      MOV      #4,-(SP)
      033162 010600      MOV      SP,R0
      033164 104414      TRAP     C:PNTB
      033166 062706 000012      ADD      #12,SP
2379 033172 005237 002532      480:    INC      ERROR1   ; INCREMENT ERROR COUNTER
2380
2381      ; END OF ERROR ROUTINE, CHECK FOR END OF TEST
2382

```

TEST30: CHECK RAM ADDRESSING (COMPLEMENT ADDRESS VALUE)

```

2383 033176
2384 033176 020127 003777
2385 033202 001325
2386
2387
2388
2389 033204 005737 002532
2390 033210 001422
2391
2392
2393
2394 033212
      033212 013746 002532
      033216 012746 004054
      033222 012746 000002
      033226 010600
      033230 104414
      033232 062706 000006
2395 033236
      033236 012746 003333
      033242 012746 000001
      033246 010600
      033250 104414
      033252 062706 000004
2396 033256
2397 033256
      033256
      033256 104401

```

```

504:
      CMP      R1,03777          ; END OF TEST
      BNE      404              ; BRANCH IF TEST NOT DONE
;
; TEST DONE, PRINT FINAL ERROR TOTALS IF ANY
;
      TST      ERROR1          ; ANY ERRORS?
      BEQ      604              ; IF NO, BRANCH
;
; PRINT FINAL ERROR TOTALS
;
      PRINTB   #FOR6,ERROR1    ; PRINT NUMBER OF ERRORS
      MOV      ERROR1,-(SP)
      MOV      #FOR6,-(SP)
      MOV      #2,-(SP)
      MOV      SP,R0
      TRAP    C:PNTB
      ADD     #6,SP
;
; LINE FEED CARRIAGE RETURN
      PRINTB   #FOR0
      MOV      #FOR0,-(SP)
      MOV      #1,-(SP)
      MOV      SP,R0
      TRAP    C:PNTB
      ADD     #4,SP
604:
      ENDTST
L10116:
      TRAP    C:ETST

```

TEST31: CHECK QBA INCREMENT

```

2399 .SBTTL TEST31: CHECK QBA INCREMENT
2400 033260 STATST <CHECK QBA INCREMENT>
      033260 040 103 110 T31MSG:: .ASCIZ / CHECK QBA INCREMENT/
2401
2402 ;*****
2403 ;**
2404 ;TEST DESCRIPTION
2405 ; CHECKS BUS ADDRESS COUNTER INCREMENT
2406 ;TEST STEPS-
2407 ; LOAD 177776 IN QBA
2408 ; LOAD 1'S IN QDMA BITS 8-13
2409 ; IF U-BRIDGE THEN LOAD BITS 8,9
2410 ; SET QDMA GO AND DMAWT BITS
2411 ; READ QBA, CHECK FOR 0
2412 ; READ QDMA, CHECK BITS 8-13 FOR 0
2413 ; IF U-BRIDGE THEN CHECK BITS 8,9
2414 ;
2415 ;--
2416 ;*****
2417
2418 033306 BGNTST
      033306 T31::
2419 033306 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      033306 104421 TRAP C@RFLA
      033310 022700 001000 CMP #PNT,RO ; IS PNT FLAG SET?
      033314 001012 BNE 64@ ; BRANCH IF NOT SET
      033316 012746 033260 MOV #T31MSG,-(SP)
      033322 012746 002270 MOV #PNTMSG,-(SP)
      033326 012746 000002 MOV #2,-(SP)
      033332 010600 MOV SP,RO
      033334 104417 TRAP C@PNTF
      033336 062706 000006 ADD #6,SP
      033342 005037 002532 64@: CLR ERROR1 ; CLEAR ERROR COUNTER
2420 033346 INIT
      033346 012777 000100 146742 ;INITIALIZE DEVICE
      033354 013777 002520 146734 MOV #M@H@LT,@QMT1 ;INITIALIZE Q-BRIDGE
      033362 005077 146712 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
      033366 005037 002532 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
      033366 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2421 ;
2422 ; CHECK QBA INCREMENT
2423 ;
2424 033372 012777 177776 146710 MOV #177776,@QBA ; ALL ONES TO QBA
2425 033400 012777 037400 146676 MOV #37400,@QDMA ; SET BITS 8-13 IN QDMA
2426 033406 005737 002500 TST BRIDGETYPE ; TEST BRIDGE TYPE
2427 033412 001403 BEQ 10@ ; IF EQ THEN Q-BRIDGE
2428 033414 012777 001400 146662 MOV #01400,@QDMA ; SET BITS 8,9 IN QDMA (U-BRIDGE)
2429 033422 052777 000003 146654 10@: BIS #DMAWT!GO,@QDMA ; INITIATE DMA TRANSFER
2430 033430 017737 146654 002526 MOV @QBA,VAL ; MOVE QBA TO VALUE
2431 033436 012737 000000 002530 MOV #0,EXP ; MOVE EXPECTED TO EXP
2432 033444 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
2433 033452 001410 BEQ 1@ ; IF OK, BRANCH
2434 ;
2435 ; ERROR CONDITION
2436 ;
2437 033454 012701 000006 MOV #6,R1 ; REGISTER NUMBER TO R1
2438 033460 ERRHRD 1,MSG36,ERR4 ; TELL OPERATOR ERROR

```

TEST31: CHECK QBA INCREMENT

```

033460 104456          TRAP  C0ERHRD
033462 000001        .WORD  1
033464 006777        .WORD  MSG36
033466 011776        .WORD  ERR4
2439 033470 004737 013230 JSR   PC,DUMP          ; DO OPTIONAL REGISTER DUMP
2440
2441
2442
2443 033474          ; NOW CHECK QDMA BITS 8-13 FOR 0
2444 033474 017737 146604 002526 10:  MOV   QDMA,VAL          ; READ QDMA INTO VAL
2445 033502 042737 140377 002526      BIC   #140377,VAL       ; CLEAR UNTESTED BITS
2446 033510 005737 002500      TST   BRIDGETYPE      ; TEST BRIDGE TYPE
2447 033514 001403      BEQ   110
2448 033516 042737 176377 002526      BIC   #176377,VAL       ; CLEAR UNTESTED BITS (U-BRIDGE)
2449 033524 012737 000000 002530 110: MOV   #0,EXP           ; MOVE EXPECTED TO EXP
2450 033532 023737 002530 002526      CMP   EXP,VAL          ; COMPARE EXPECTED WITH VALUE
2451 033540 001410      BEQ   20
2452
2453          ; ERROR CONDITION
2454
2455 033542 012701 000004      MOV   #4,R1            ; REGISTER NUMBER TO R1
2456 033546          ERRHRD 2,MSG36.5,ERR4      ; TELL OPERATOR ERROR
033546 104456          TRAP  C0ERHRD
033550 000002        .WORD  2
033552 007023        .WORD  MSG36.5
033554 011776        .WORD  ERR4
2457 033556 004737 013230 JSR   PC,DUMP          ; DO OPTIONAL REGISTER DUMP
2458 033562
2459 033562
033562
033562 104401          20:  ENDTST
L10117: TRAP  C0ETST

```

TEST32: CHECK QWC OVERFLOW (READ)

```

2461 .SBTTL TEST32: CHECK QWC OVERFLOW (READ)
2462 033564 STATST <CHECK QWC OVERFLOW (READ)>
033564 040 103 110 T32MSG:: .ASCIZ / CHECK QWC OVERFLOW (READ)/
2463
2464 ;*****
2465 ;**
2466 ;TEST DESCRIPTION-
2467 ; CHECKS THAT GO WITH DMAWT CAUSES IMMEDIATE DMA REQ
2468 ; CHECKS WC INCREMENT, OVERFLOW
2469 ;TEST STEPS-
2470 ; LOAD QWC WITH 1'S
2471 ; LOAD QBA WITH VALID ADDRESS
2472 ; SET QDMA AND GO BIT
2473 ; READ QWC, CHECK FOR 0
2474 ; CHECK QDMA RDY SET
2475 ;
2476 ;--
2477 ;*****
2478
2479 033620 BGNTST
033620 T32::
2480 033620 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
033620 104421 TRAP C0RFLA
033622 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
033626 001012 BNE 640 ; BRANCH IF NOT SET
033630 012746 033564 MOV #T32MSG,-(SP)
033634 012746 002270 MOV #PNTMSG,-(SP)
033640 012746 000002 MOV #2,-(SP)
033644 010600 MOV SP,R0
033646 104417 TRAP C0PNTF
033650 062706 000006 ADD #6,SP
033654 005037 002532 640: CLR ERROR1 ; CLEAR ERROR COUNTER
2481 033660 INIT
;INITIALIZE DEVICE
033660 012777 000100 146430 MOV #M0HALT,BQMT1 ;INITIALIZE Q-BRIDGE
033666 013777 002520 146422 MOV INITWORD,BQMT1 ;SET UP LOOPBACK OPTION
033674 005077 146400 CLR BQINT ;CLEAR QINT AFTER LOOPBACK ENABLED
033700 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2482 033704 012777 177777 146400 MOV #1,BQWC ; LOAD QWC WITH 1'S
2483 033712 012777 041660 146370 MOV #PATCH,BQBA ; LOAD QBA WITH VALID ADDRESS
2484 033720 052777 000001 146356 BIS #GO,BQDMA ; SET QDMA AND GO BIT
2485 033726 017737 146360 002526 MOV BQWC,VAL ; READ QWC
2486 033734 012737 000000 002530 MOV #0,EXP ; EXPECTED VALUE IN EXP
2487 033742 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
2488 033750 001410 BEQ 100 ; BRANCH IF OK
2489
2490 ; ERROR CONDITION
2491
2492 033752 012701 000007 MOV #7,R1 ; REGISTER NUMBER TO R1
2493 033756 ERRHRD 1,MSG40,ERR4 ; TELL OPERATOR ERROR
033756 104456 TRAP C0ERRRD
033760 000001 .WORD 1
033762 007337 .WORD MSG40
033764 011776 .WORD ERR4
2494 033766 004737 013230 JSR PC,DUMP ; DO OPTIONAL REGISTER DUMP
2495
2496 ; END ERROR CONDITION, CHECK FOR RDY SET

```


TEST32: CHECK QMC OVERFLOW (READ)

```

2497
2498 033772
2499 033772 017737 146306 002526
2500 034000 032737 000200 002526
2501 034006 001006
2502
2503
2504
2505 034010
      034010 104456
      034012 000002
      034014 007423
      034016 000000
2506 034020 004737 013230
2507
2508
2509
2510 034024
2511 034024
      034024
      034024 104401

```

```

;
100:
      MOV      QDMA,VAL
      BIT      @RDY,VAL
      BNE      200
; READ QDMA REGISTER
; CHECK FOR RDY SET
; BRANCH IF OK
;
; ERROR CONDITION
;
      ERRHRD   2,MSG41
      TRAP     C@ERHRD
      .WORD    2
      .WORD    MSG41
      .WORD    0
      JSR      PC,DUMP
; TELL OPERATOR ERROR
; DO OPTIONAL REGISTER DUMP
;
; END ERROR CONDITION
;
200:
      ENDTST
L10120:
      TRAP     C@ETST

```

TEST33: CHECK QWC OVERFLOW (WRITE)

```

2513 .SBTTL TEST33: CHECK QWC OVERFLOW (WRITE)
2514 034026 STATST <CHECK QWC OVERFLOW (WRITE)>
      034026 040 103 110 T33MSG:: .ASCIZ / CHECK QWC OVERFLOW (WRITE)/
2515
2516 ;*****
2517 ;**
2518 ;TEST DESCRIPTION-
2519 ; CHECKS THAT GO CLEARS RDY BIT
2520 ; CHECKS THAT GO CAUSES DMA REQ
2521 ; CHECKS THAT DMA REQ CAUSES WC INCREMENT
2522 ; CHECKS THAT WC OVERFLOW SETS RDY BIT
2523 ;TEST STEPS
2524 ; LOAD QWC WITH 177776
2525 ; LOAD QBA WITH ANY VALID ADDRESS
2526 ; SET QMT1 FUNC = 5 (SELDMAT)
2527 ; SET QDMA GO AND DMAWT BITS
2528 ; CHECK QDMA RDY CLEARED
2529 ; SET QDMA GO AND DMAWT BITS
2530 ; READ QWC, CHECK FOR 0
2531 ; CHECK QDMA RDY SET
2532 ;
2533 ;--
2534 ;*****
2535
2536 034062 BGNTST
      034062 T33::
2537 034062 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      034062 104421 TRAP C%RFLA
      034064 022700 001000 CMP #PNT,RO ; IS PNT FLAG SET?
      034070 001012 BNE 648 ; BRANCH IF NOT SET
      034072 012746 034026 MOV #T33MSG,-(SP)
      034076 012746 002270 MOV #PNTMSG,-(SP)
      034102 012746 000002 MOV #2,-(SP)
      034106 010600 MOV SP,RO
      034110 104417 TRAP C%PNTF
      034112 062706 000006 ADD #6,SP
      034116 005037 002532 648: CLR ERROR1 ; CLEAR ERROR COUNTER
2538 034122 INIT
      034122 012777 000100 146166 ;INITIALIZE DEVICE
      034130 013777 002520 146160 MOV #M%HALT,%QMT1 ;INITIALIZE Q-BRIDGE
      034136 005077 146136 MOV INITWORD,%QMT1 ;SET UP LOOPBACK OPTION
      034142 005037 002532 CLR %QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
2539 034146 012777 177776 146136 CLR ERROR1 ;CLEAR ERROR FLAG
2540 034154 012777 041660 146126 MOV #177776,%QWC ; LOAD QWC WITH ALL 1'S
2541 034162 052777 000024 146126 MOV #%PATCH,%QBA ; LOAD QBA WITH VALID ADDRESS
2542 034170 052777 000003 146106 BIS #SELDMAT,%QMT1 ; SEL QMT1 FUNC = 5
2543 034176 017737 146102 002526 BIS #GO!DMAWT,%QDMA ; SET QDMA GO BIT
2544 034204 032737 000200 002526 MOV %QDMA,VAL ; READ QDMA REGISTER
2545 034212 001406 BIT #RDY,VAL ; CHECK FOR RDY BIT CLEARED
2546 ; BRANCH IF OK
2547 ;
2548 ; ERROR CONDITION
2549 034214 ERRHRD 1,MSG37 ; TELL OPERATOR ERROR
      034214 104456 TRAP C%ERRHRD
      034216 000001 .WORD 1
      034220 007103 .WORD MSG37

```

TEST33: CHECK QWC OVERFLOW (WRITE)

```

034222 000000 .WORD 0
2550 034224 004737 013230 JSR PC,DUMP ; DO OPTIONAL REGISTER DUMP
2551 ;
2552 ; END ERROR CONDITION, CHECK FOR QWC INCREMENT
2553 ;
2554 034230 100:
2555 034230 052777 000003 146046 BIS @GO!DMAWT,@QDMA ; SET QDMA GO BIT
2556 034236 017737 146050 002526 MOV @QWC,VAL ; READ QWC REGISTER
2557 034244 012737 000000 002530 MOV @0,EXP ; ALL ZEROS FOR EXPECTED
2558 034252 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
2559 034260 001410 BEQ 200 ; BRANCH IF OK
2560 ;
2561 ; ERROR CONDITION
2562 ;
2563 034262 012701 000007 MOV @7,R1 ; REGISTER NUMBER TO R1
2564 034266 ERRHRD 2,MSG38,ERR4 ; TELL OPERATOR ERROR
034266 104456 TRAP C#ERRHRD
034270 000002 .WORD 2
034272 007172 .WORD MSG38
034274 011776 .WORD ERR4
2565 034276 004737 013230 JSR PC,DUMP ; DO OPTIONAL REGISTER DUMP
2566 ;
2567 ; END ERROR CONDITION, CHECK FOR QDMA RDY SET
2568 ;
2569 034302 200:
2570 034302 017737 145776 002526 MOV @QDMA,VAL ; READ QDMA REGISTER
2571 034310 032737 000200 002526 BIT @RDY,VAL ; CHECK RDY BIT FOR SET
2572 034316 001006 BNE 300 ; BRANCH IF OK
2573 ;
2574 ; ERROR CONDITION
2575 ;
2576 034320 ERRHRD 3,MSG39 ; TELL OPERATOR ERROR
034320 104456 TRAP C#ERRHRD
034322 000003 .WORD 3
034324 007254 .WORD MSG39
034326 000000 .WORD 0
2577 034330 004737 013230 JSR PC,DUMP ; DO OPTIONAL REGISTER DUMP
2578 034334 300:
2579 034334 ENDTST
034334 L10121:
034334 104401 TRAP C#ETST

```

TEST34: DMA 1 WORD (WRITE)

```

2581 .SBTTL TEST34: DMA 1 WORD (WRITE)
2582 034336 STATST <DMA 1 WORD (WRITE)>
034336 040 104 115 T34MSG:: .ASCIZ / DMA 1 WORD (WRITE)/
2583 ;*****
2584 ;**
2585 ;TEST DESCRIPTION-
2586 ; CHECKS DMA FROM MEMORY FROM Q-BUS TO UNIBUS
2587 ; USES QTSOUT - QTSIN LOOP-BACK
2588 ;TEST STEPS-
2589 ; LOAD DATA WORD IN BUFFER
2590 ; LOAD QMC WITH -1
2591 ; LOAD QBA WITH BUFFER ADDRESS
2592 ; SET QDMA DMAWT AND GO BITS
2593 ; SET QMT1 FUNC = 5 (SELDMADAT)
2594 ; READ QMT0, CHECK DATA WORD
2595 ; CLEAR QMT1 FUNC = 5 (SELDMADAT)
2596 ; REPEAT WITH COMPLEMENT DATA PATTERN
2597 ; LOOP 100 TIMES
2598 ;
2599 ;
2600 ;--
2601 ;*****
2602
2603 034362 BGNTST
034362 T34::
2604 034362 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
034362 104421 TRAP C#RFLA
034364 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
034370 001012 BNE 64# ; BRANCH IF NOT SET
034372 012746 034336 MOV #T34MSG,-(SP)
034376 012746 002270 MOV #PNTMSG,-(SP)
034402 012746 000002 MOV #2,-(SP)
034406 010600 MOV SP,R0
034410 104417 TRAP C#PNTF
034412 062706 000006 ADD #6,SP
034416 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
2605 034422 INIT
;INITIALIZE DEVICE
034422 012777 000100 145666 MOV #QHALT,QMT1 ;INITIALIZE Q-BRIDGE
034430 013777 002520 145660 MOV INITWORD,QMT1 ;SET UP LOOPBACK OPTION
034436 005077 145636 CLR QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
034442 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2606 034446 012705 000144 MOV #100,,R5 ; NUMBER OF LOOPS
2607 034452 012737 125252 002530 MOV #125252,EXP ; STARTING DATA PATTERN TO DMA
2608 034460 BGNSUB
034460 104402 T34.1:
2609 034462 L34: TRAP C#BSUB
034462 104404 TRAP C#BSEG
2610 034464 012777 177777 145620 MOV #-1,QMC ; -1 TO QMC
2611 034472 012777 002530 145610 MOV #EXP,QBA ; RECEIVING BUFFER TO QBA
2612 034500 052777 000003 145576 BIS #DMAWT!GO,QDMA ; INITIATE DMA
2613 034506 052777 000024 145602 BIS #SELDMADAT,QMT1 ; SET QMT1 FUNC = 5
2614 034514 017737 145574 002526 MOV QMT0,VAL ; READ QMT0 (RECEIVED DMA DATA)
2615 034522 042777 000024 145566 BIC #SELDMADAT,QMT1 ; CLEAR QMT1 FUNC = 5
2616 034530 023737 002530 002526 CMP EXP,VAL ; COMPARE EXPECTED WITH VALUE
2617 034536 001430 BEQ 20# ; BRANCH IF OK

```

TEST34: DMA 1 WORD (WRITE)

```

2618
2619
2620
2621 034540
      034540 104456
      034542 000001
      034544 007520
      034546 000000
2622 034550 012704 000145
2623 034554 160504
2624 034556
      034556 010446
      034560 013746 002526
      034564 013746 002530
      034570 012746 004261
      034574 012746 000004
      034600 010600
      034602 104414
      034604 062706 000012
2625 034610 004737 013230
2626 034614 005237 002532
2627 034620
2628 034620
      034620
      034620 104405
2629 034622 005137 002530
2630 034626 005305
2631 034630 001405
2632 034632 005737 002532
2633 034636 001002
2634 034640 000137 034462
2635 034644
2636 034644
      034644
      034644 104403
2637 034646
      034646
      034646 104401

```

```

:
: ERROR CONDITION
:
ERRHRD 1,MSG42
TRAP C#ERHRD
.WORD 1
.WORD MSG42
.WORD 0
MOV #101.,R4
SUB R5,R4
PRINTB #FOR10,EXP,VAL,R4
MOV R4,-(SP)
MOV VAL,-(SP)
MOV EXP,-(SP)
MOV #FOR10,-(SP)
MOV #4,-(SP)
MOV SP,R0
TRAP C#PNTB
ADD #12,SP
JSR PC,DUMP
INC ERROR1
20:
ENDSEG
10000:
TRAP C#ESEG
COM EXP
DEC R5
BEQ 30:
TST ERROR1
BNE 30:
JMP L34
30:
ENDSUB
L10123:
TRAP C#ESUB
ENDTST
L10122:
TRAP C#ETST

```

```

: TELL OPERATOR ERROR
:
: CALCULATE LOOP NUMBER
: PRINT OUT RESULTS
:
: DO OPTIONAL REGISTER DUMP
: SET ERROR FLAG
:
: COMPLEMENT DATA PATTERN
: DECREMENT LOOP COUNTER
: BRANCH IF DONE WITH LOOPS
: CHECK FOR ERRORS
: IF ANY ERRORS, END TEST
: PERFORM TEST AGAIN

```

TEST35: DMA 1 WORD (READ)

```

2639 .SBTTL TEST35: DMA 1 WORD (READ)
2640 034650 STATST <DMA 1 WORD (READ)>
034650 040 104 115 T35MSG:: .ASCIZ / DMA 1 WORD (READ)/
2641 ;*****
2642 ;**
2643 ;TEST DESCRIPTION-
2644 ; CHECKS DMA TO MEMORY FROM UNIBUS TO Q-BUS
2645 ; USES UDMAENB - QDMAENB LOOP-BACK
2646 ; USES QTSOUT - QTSIN LOOP-BACK
2647 ;TEST STEPS-
2648 ; SET QMT1 FUNC = 7 (SEL DMA READ)
2649 ; CLEAR BUFFER
2650 ; LOAD QMTO WITH DATA PATTERN
2651 ; LOAD QMC WITH -1
2652 ; LOAD QBA WITH BUFFER ADDRESS
2653 ; SET QDMA GO BITS
2654 ; READ DATA IN BUFFER, CHECK
2655 ; REPEAT WITH COMPLEMENT DATA PATTERN
2656 ; LOOP 100 TIMES
2657 ;
2658 ;
2659 ;--
2660 ;*****
2661
2662 034674 BGNTST
034674
2663 034674 T35:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
034674 104421 TRAP C#RFLA ;
034676 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
034702 001012 BNE 64# ; BRANCH IF NOT SET
034704 012746 034650 MOV #T35MSG,-(SP)
034710 012746 002270 MOV #PNTMSG,-(SP)
034714 012746 000002 MOV #2,-(SP)
034720 010600 MOV SP,R0
034722 104417 TRAP C#PNTF
034724 062706 000006 ADD #6,SP
034730 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
2664 034734 INIT
;INITIALIZE DEVICE
034734 012777 000100 145354 MOV #QMHALT,@QMT1 ;INITIALIZE Q-BRIDGE
034742 013777 002520 145346 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
034750 005077 145324 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
034754 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2665 034760 012705 000144 MOV #100.,R5 ; NUMBER OF LOOPS
2666 034764 012737 125252 002530 MOV #125252,EXP ; STARTING DATA PATTERN TO DMA
2667 034772 BGNSUB
034772
2668 034774 T35.1: TRAP C#BSUB
034774 104402 L35: BGNSEG
034774 104404 TRAP C#BSEG
2669 034776 052777 000034 145312 BIS #SELRDDMA,@QMT1 ; SET QMT1 FUNC = 7
2670 035004 012737 000000 041660 MOV #0,@PATCH ; CLEAR BUFFER
2671 035012 013777 002530 145274 MOV EXP,@QMT0 ; LOAD DATA PATTERN INTO QMTO
2672 035020 012777 177777 145264 MOV #-1,@QMC ; -1 TO QMC
2673 035026 012777 041660 145254 MOV #PATCH,@QBA ; RECEIVING BUFFER TO QBA
2674 035034 052777 000001 145242 BIS #GO,@QDMA ; INITIATE DMA
2675 035042 013737 041660 002526 MOV #PATCH,VAL ; MOVE BUFFER TO VALUE

```

TEST35: DMA 1 WORD (READ)

2676	035050	023737	002530	002526		CMP	EXP,VAL		: COMPARE EXPECTED WITH VALUE
2677	035056	001430				BEQ	20:		: BRANCH IF OK
2678									
2679									
2680									
2681	035060					ERRHRD	1,MSG43		: TELL OPERATOR ERROR
	035060	104456				TRAP	C#ERHRD		
	035062	000001				.WORD	1		
	035064	007626				.WORD	MSG43		
	035066	000000				.WORD	0		
2682	035070	012704	000145			MOV	#101.,R4		: CALCULATE LOOP NUMBER
2683	035074	160504				SUB	R5,R4		
2684	035076					PRINTB	#FOR10,EXP,VAL,R4		: PRINT OUT RESULTS
	035076	010446				MOV	R4,-(SP)		
	035100	013746	002526			MOV	VAL,-(SP)		
	035104	013746	002530			MOV	EXP,-(SP)		
	035110	012746	004261			MOV	#FOR10,-(SP)		
	035114	012746	000004			MOV	#4,-(SP)		
	035120	010600				MOV	SP,R0		
	035122	104414				TRAP	C#PNTB		
	035124	062706	000012			ADD	#12,SP		
2685	035130	004737	013230			JSR	PC,DUMP		: DO OPTIONAL REGISTER DUMP
2686	035134	005237	002532			INC	ERROR1		: SET ERROR FLAG
2687	035140								
2688	035140								
	035140					ENDSEG			
	035140	104405							
2689	035142	005137	002530			TRAP	C#ESEG		
2690	035146	005305				COM	EXP		: COMPLEMENT DATA PATTERN
2691	035150	001405				DEC	R5		: DECREMENT LOOP COUNTER
2692	035152	005737	002532			BEQ	30:		: BRANCH IF DONE WITH LOOPS
2693	035156	001002				TST	ERROR1		: CHECK FOR ERRORS
2694	035160	000137	034774			BNE	30:		: IF ANY ERRORS, END TEST
2695	035164					JMP	L35		: PREFORM TEST AGAIN
2696	035164								
	035164					ENDSUB			
	035164	104403							
2697	035166					TRAP	C#ESUB		
	035166					ENDTST			
	035166	104401							
						L10124:	TRAP	C#ETST	

TEST36: DMA 1 WORD HI MEMORY (WRITE)

```

2699 .SBTTL TEST36: DMA 1 WORD HI MEMORY (WRITE)
2700 035170 STATST <DMA 1 WORD HI MEMORY (WRITE)>
      035170 040 104 115 T36MSG:: .ASCIZ / DMA 1 WORD HI MEMORY (WRITE)/
2701
2702 ;*****
2703 ;**
2704 ;TEST DESCRIPTION-
2705 ; CHECKS DMA FROM MEMORY FROM Q-BUS HIGHEST AVAILABLE
2706 ; MEMORY TO UNIBUS
2707 ; USES QTSOUT - QTSIN LOOP-BACK
2708 ;TEST STEPS-
2709 ; CHECK IF > 32K WORD MEMORY
2710 ; IF YES-
2711 ; SET UP MEMORY MANAGEMENT REGISTERS
2712 ; GET TOP OF PROGRAM ADDRESS, CALCULATE NEXT 4KW BLOCK
2713 ; GET TOP THREE BITS OF BLOCK, USE THAT FOR INDEX TO MM REGISTER
2714 ; THIS ADDRESS STORED (TRANSFER ADDRESS)
2715 ; GET HIGHEST AVAILABLE ADDRESS
2716 ; SET EXTENDED ADDRESS BITS 16 AND 17 FROM HIGHEST ADDRESS
2717 ; CONVERT HIGHEST AVAILABLE ADDRESS TO 16 BIT ADDRESS
2718 ; ENABLE MAPPING
2719 ; WRITE EXPECTED DATA PATTERN TO MEMORY AT TRANSFER ADDRESS
2720
2721 ; ELSE TRANSFER AT TOP OF BUFFER
2722
2723 ; LOAD QMC WITH -1
2724 ; LOAD QBA WITH BUFFER ADDRESS
2725 ; SET QDMA DMAWT AND GO BITS
2726 ; SET QMT1 FUNC = 5 (SELDMADAT)
2727 ; READ QMT0, CHECK DATA WORD
2728 ; CLEAR QMT1 FUNC = 5 (SELDMADAT)
2729 ; REPEAT WITH COMPLEMENT DATA PATTERN
2730 ; LOOP 100 TIMES
2731 ;--
2732 ;*****
2733
2734 035226 BGNTST
2735 035226 T36::
      035226 104421 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
      035230 022700 001000 TRAP C#RFLA ; IS PNT FLAG SET?
      035234 001012 CMP #PNT,RO ; BRANCH IF NOT SET
      035236 012746 035170 BNE 64#
      035242 012746 002270 MOV #T36MSG,-(SP)
      035246 012746 000002 MOV #PNTMSG,-(SP)
      035252 010600 MOV #2,-(SP)
      035254 104417 TRAP SP,RO
      035256 062706 000006 ADD #6,SP
      035262 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
2736 035266 INIT
      035266 012777 000100 145022 ;INITIALIZE DEVICE
      035274 013777 002520 145014 MOV #MGMHALT,%QMT1 ;INITIALIZE Q-BRIDGE
      035302 005077 144772 CLR %QINT ;SET UP LOOPBACK OPTION
      035306 005037 002532 CLR ERROR1 ;CLEAR QINT AFTER LOOPBACK ENABLED
2737 035312 012705 000144 MOV #100,,R5 ;CLEAR ERROR FLAG
2738 035316 012737 125252 002530 MOV #125252,EXP ; NUMBER OF LOOPS
      ; STARTING DATA PATTERN TO DMA

```


TEST36: DMA 1 WORD HI MEMORY (WRITE)

```

2739 035324 005002          CLR      R2
2740 035326          BGNSUB
      035326          T36.1:
2741 035330 022737 002000 002120 TRAP     C#BSUB
2742 035336 002404          CMP      @2000,L#HIME      ; > 32K WORD MEMORY?
2743          BLT      2#          ; IF YES BRANCH
2744          ; MEMORY LESS THEN 32KW, NO MEMORY MANAGEMENT SET UP
2745          ;
2746 035340 013701 002552          MOV      FREMEM,R1          ; READ BUFFER ADDRESS
2747 035344 010103          MOV      R1,R3
2748 035346 000451          BR      L36          ; GO DO DMA          ; V C.O
2749
2750          ; MEMORY MANAGEMENT IN USE, SET UP TEST
2751          ;
2752 035350          2#:
2753 035350 004737 014370          JSR      PC,MMINIT          ; SET UP MM REGISTERS
2754 035354 013700 002552          MOV      FREMEM,R0          ; GET TO TOP OF PROGRAM
2755 035360 062700 020000          ADD      @20000,R0          ; NEXT 4KW BLOCK
2756 035364 042700 017777          BIC      @17777,R0
2757 035370 010003          MOV      R0,R3          ; SAVE FOR BUFFER ADDRESS
2758 035372 000241          CLC
2759 035374 006100          ROL      R0          ; CLEAR CARRY FLAG
2760 035376 006100          ROL      R0          ; GET TOP 3 BITS
2761 035400 006100          ROL      R0
2762 035402 006100          ROL      R0
2763 035404 006100          ROL      R0
2764 035406 013760 002120 172340 MOV      L#HIME,KISARO(R0) ; TIMES 2 FOR INDEX USE
2765 035414 005002          CLR      R2          ; INDEX TO MM REGISTER TO USE
2766 035416 032737 004000 002120 BIT      @BIT11,L#HIME      ; BIT 11 OF HIGHEST AVAILABLE MEMORY
2767 035424 001402          BEQ      3#          ; IF NOT ON
2768 035426 052702 001000          BIS      @QXAD17,R2          ; SET BIT 17
2769 035432 032737 002000 002120 3#: BIT      @BIT10,L#HIME      ; BIT 10 OF HIGHEST AVAILABLE MEMORY
2770 035440 001402          BEQ      4#          ; IF NOT ON
2771 035442 052702 000400          BIS      @QXAD16,R2          ; SET BIT 16
2772 035446 012700 000006          4#: MOV      @6,R0
2773 035452 013701 002120          5#: MOV      L#HIME,R1          ; GET BUS ADDRESS
2774 035456 006301          ASL      R1          ; CHANGE TO 16 BIT ADDRESS
2775 035460 005300          DEC      R0
2776 035462 001375          BNE      5#
2777 035464 012737 000001 177572 MOV      @BIT0,MMRO          ; ENABLE MAPPING
2778 035472 013713 002530          L36: MOV      EXP,(R3)          ; WRITE DATA TO MEMORY          ; V C.O
2779 035476 012777 177777 144606 MOV      @-1,@QMC          ; -1 TO QMC
2780 035504 010177 144600          MOV      R1,@QBA          ; XMITTING BUFFER ADDR TO QBA
2781 035510 052702 000003          MOV      R2,@QDMA          ; SET UP INITIATE DMA WORD
2782 035514 010277 144564          BIS      @DMAWT!GO,R2          ; INITIATE DMA
2783 035520 052777 000024 144570 BIS      @SELDADAT,@QMT1          ; SET QMT1 FUNC = 5
2784 035526 017737 144562 002526 MOV      @QMT0,VAL          ; READ QMT0 (RECEIVED DMA DATA)
2785 035534 042777 000024 144554 BIC      @SELDADAT,@QMT1          ; CLEAR QMT1 FUNC = 5
2786 035542 023737 002530 002526 CMP      EXP,VAL          ; COMPARE EXPECTED WITH VALUE
2787 035550 001430          BEQ      20#          ; BRANCH IF OK
2788
2789          ; ERROR CONDITION
2790          ;
2791 035552          ERRHRD 1,MSG42.5          ; TELL OPERATOR ERROR
      035552 104456          TRAP     C#ERRRD
      035554 000001          .WORD   1

```

TEST36: DMA 1 WORD HI MEMORY (WRITE)

	035556	007556			.WORD	MSG42.5			
	035560	000000			.WORD	0			
2792	035562	012704	000145		MOV	#101.,R4		:	CALCULATE LOOP NUMBER
2793	035566	160504			SUB	R5,R4			
2794	035570				PRINTB	#FOR10,EXP,VAL,R4		:	PRINT OUT RESULTS
	035570	010446			MOV	R4,-(SP)			
	035572	013746	002526		MOV	VAL,-(SP)			
	035576	013746	002530		MOV	EXP,-(S^)			
	035602	012746	004261		MOV	#FOR10,-(SP)			
	035606	012746	000004		MOV	#4,-(SP)			
	035612	010600			MOV	SP,R0			
	035614	104414			TRAP	C#PNTB			
	035616	062706	000012		ADD	#12,SP			
2795	035622	004737	013230		JSR	PC,DUMP		:	DO OPTIONAL REGISTER DUMP
2796	035626				EXIT	TST			
	035626	104432			TRAP	C#EXIT			
	035630	000026			.WORD	L10126-			
2797	035632			20:					
2798	035632			L10127:	ENDSUB				
	035632	104403			TRAP	C#ESUB			
2799	035634	005137	002530		COM	EXP		:	COMPLEMENT DATA PATTERN ; V C.O
2800	035640	005305			DEC	R5		:	DECREMENT LOOP COUNTER ; V C.O
2801	035642	001405			BEQ	30:		:	BRANCH IF DONE WITH LOOPS ; V C.O
2802	035644	000137	035472		JMP	L36		:	PERFORM TEST AGAIN ; V C.O
2803	035650	012737	000000	177572	MOV	#0,MMRO		:	DISABLE MAPPING ; V C.O
2804									
2805	035656			30:					
2806	035656			L10126:	ENDTST				
	035656				TRAP	C#ETST			
	035656	104401							

TEST37: CHECK WDTO TIME

```

2808 .SBTTL TEST37: CHECK WDTO TIME
2809 035660 STATST <CHECK WDTO TIME>
035660 040 103 110 T37MSG:: .ASCIZ / CHECK WDTO TIME/

2810 ;*****
2811 ;**
2812 ;TEST DESCRIPTION-
2813 ; CHECKS QCTL BITS
2814 ; CHECKS THAT TIMER IS OPERATING
2815 ; ALLOWS OPERATOR TO CHECK TIMES
2816 ; USES UPWRFAIL - QMOTO LOOP-BACK
2817 ;TEST STEPS-
2818 ; SET TIME CODE IN QCTL
2819 ; READ QCTL TIME CODE BITS, CHECK
2820 ; SET QCTL TMRENB
2821 ; READ QCTL TMRENB, CHECK
2822 ; WAIT FOR QINT WPRFL BIT SET ON TIME-OUT
2823 ; RING BELL
2824 ; REPEAT 5 TIMES
2825 ; REPEAT WITH ALL TIMES CODES
2826 ;
2827 ;
2828 ;--
2829 ;*****
2830
2831 035702 BGNTST
035702
2832 035702 T37:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
035702 104421 TRAP C:RFLA
035704 022700 001000 CMP @PNT,RO ; IS PNT FLAG SET?
035710 001012 BNE 648 ; BRANCH IF NOT SET
035712 012746 035660 MOV @T37MSG, -(SP)
035716 012746 002270 MOV @PNTMSG, -(SP)
035722 012746 000002 MOV @2, -(SP)
035726 010600 MOV SP,RO
035730 104417 TRAP C:PNTF
035732 062706 000006 ADD @6,SP
035736 005037 002532 648: CLR ERROR1 ; CLEAR ERROR COUNTER
2833 035742 INIT
;INITIALIZE DEVICE
035742 012777 000100 144346 MOV @MOMHALT, @QMT1 ;INITIALIZE Q-BRIDGE
035750 013777 002520 144340 MOV INITWORD, @QMT1 ;SET UP LOOPBACK OPTION
035756 005077 144316 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
035762 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2834 035766 012701 000004 MOV @4, R1 ; R1 WITH NUMBER OF TIME CODES
2835 035772 012702 000005 MOV @5, R2 ; R2 WITH NUMBER OF LOOPS PER CODE
2836 035776 012703 036362 MOV @TABLE36, R3 ; R3 WITH TIME CODE TABLE ADDRESS
2837 036002 005737 036372 TST P37 ; HAS MESSAGE ALREADY BEEN PRINTED
2838 036006 001012 BNE L37 ; IF ALREADY PRINTED, SKIP PRINTING
2839 036010 PRINTB @FOR11 ; PRINT ABOUT USING BELLS IN TESTS
036010 012746 004353 MOV @FOR11, -(SP)
036014 012746 000001 MOV @1, -(SP)
036020 010600 MOV SP,RO
036022 104414 TRAP C:PNTB
036024 062706 000004 ADD @4,SP
2840 036030 005237 036372 L37: INC P37 ; INCREMENT PRINTED ABOVE MESSAGE FLAG
2841 036034
2842 036034 012777 000000 144236 MOV @0, @QINT ; MAKE SURE UPWRFL IS CLEAR

```

TEST37: CHECK WDTO TIME

```

2843 036042 012777 000000 144232      MOV      #0,BQCTL      ; MAKE SURE TIMER ENABLE IS CLEAR
2844 036050 051377 144226      BIS      (R3),BQCTL    ; SET TIME CODE BITS IN QCTL
2845 036054 017737 144222 002526      MOV      BQCTL,VAL     ; READ QCTL
2846 036062 011337 002530      MOV      (R3),EXP     ; MOVE EXPECTED TO EXP
2847 036066 005137 002530      COM      EXP          ; COMPLEMENT EXP FOR MASK
2848 036072 043737 002530 002526      BIC      EXP,VAL      ; MASK OUT UNTESTED BITS
2849 036100 005137 002530      COM      EXP          ; RESTORE EXPECTED VALUE
2850 036104 023737 002530 002526      CMP      EXP,VAL      ; COMPARE EXPECTED WITH VALUE
2851 036112 001410      BEQ      100          ; BRANCH IF OK
2852
2853      ; ERROR CONDITION
2854
2855 036114 012701 000003      MOV      #3,R1        ; REGISTER NUMBER TO R1
2856 036120      ERRHRD 1,MSG44,ERR4    ; TELL OPERATOR ERROR AND ABORT
      036120 104456      TRAP    C#ERRHRD
      036122 000001      .WORD  1
      036124 007663      .WORD  MSG44
      036126 011776      .WORD  ERR4
2857 036130      EXIT    TST          ; ABORT TEST
      036130 104432      TRAP    C#EXIT
      036132 000242      .WORD  L10130-.
2858
2859      ; END ERROR CONDITION
2860
2861 036134      100:
2862 036134 052777 000002 144140      BIS      #TMRENB,BQCTL ; ENABLE TIMER
2863 036142 017737 144134 002526      MOV      BQCTL,VAL     ; READ QCTL
2864 036150 032737 000002 002526      BIT      #TMRENB,VAL   ; TEST FOR TMRENB BIT SET
2865 036156 001016      BNE      200          ; BRANCH IF OK
2866
2867      ; ERROR CONDITION
2868
2869 036160 012701 000003      MOV      #3,R1        ; REGISTER NUMBER TO R1
2870 036164 012737 000002 002530      MOV      #TMRENB,EXP   ; EXPECTED VALUE TO EXP
2871 036172 042737 177775 002526      BIC      #+CTMRENB,VAL ; CLEAR UNTESTED BIT FOR MESSAGE
2872 036200      ERRHRD 2,MSG45,ERR4    ; TELL OPERATOR ERROR AND ABORT
      036200 104456      TRAP    C#ERRHRD
      036202 000002      .WORD  2
      036204 007775      .WORD  MSG45
      036206 011776      .WORD  ERR4
2873 036210      EXIT    TST          ; ABORT TEST
      036210 104432      TRAP    C#EXIT
      036212 000162      .WORD  L10130-.
2874
2875      ; END ERROR CONDITION
2876      ; NOW WAIT FOR MAXIMUM OF 8 SECONDS IN .025 SEC INCREMENTS FOR WDTO COMPLETE
2877
2878 036214      200:
2879 036214 012704 000360      MOV      #240.,R4     ; NUMBER OF .025 SEC TO LOOP
2880 036220      300:
2881 036220      DELAY  25.           ; .025 SEC DELAY
      036220 012727 000031      MOV      #25.,(PC)+
      036224 000000      .WORD  0
      036226 013727 002116      MOV      L#DLY,(PC)+
      036232 000000      .WORD  0
      036234 005367 177772      DEC      -6(PC)
      036240 001375      BNE      .-4

```

TEST37: CHECK WDTO TIME

```

036242 005367 177756      DEC      -22(PC)
036246 001367      BNE      .-20
2882 036250      BREAK
036250 104422      TRAP     C#BRK      ; CHECK FOR OPERATOR INPUT
2883 036252 032777 010000 144020  BIT      @UPWRFL,@QINT ; TEST FOR WDTO COMPLETE (BIT SET)
2884 036260 001012      BNE      40#      ; IF TIMER COMPLETE, BRANCH
2885 036262 005304      DEC      R4      ; DECREMENT R4 COUNTER
2886 036264 001355      BNE      30#      ; BRANCH IF 6 SECONDS NOT UP
2887
2888      ; ERROR CONDITION, 8 SECONDS UP WITH NO WDTO COMPLETE
2889
2890 036266      ERRHRD   3,MSG46      ; TELL OPERATOR ERROR AND ABORT
036266 104456      TRAP     C#ERHRD
036270 000003      .WORD   3
036272 010077      .WORD   MSG46
036274 000000      .WORD   0
2891 036276 004737 013230  JSR      PC,DUMP      ; DO OPTIONAL REGISTER DUMP
2892 036302      EXIT     TST      ; ABORT TEST
036302 104432      TRAP     C#EXIT
036304 000070      .WORD   L10130-.

2893      ;
2894      ; END ERROR CONDITION
2895      ; WATCH DOG TIMER ENDED PROPERLY, RING BELL AND SET UP FOR LOOPING
2896
2897 036306
2898 036306      40#:
036306 012746 004462  PRINTB   #FOR12      ; RING BELL
036312 012746 000001  MOV      #FOR12,-(SP)
036316 010600  MOV      #1,-(SP)
036320 104414  MOV      SP,R0
036322 062706 000004  TRAP     C#PNTB
2899 036326 005302  ADD      #4,SP
2900 036330 001402  DEC      R2      ; DECREMENT LOOP COUNTER
2901 036332 000137 036034  BEQ      50#      ; IF DONE, BRANCH
2902      JMP      L37      ; IF NOT DONE, JUMP BACK
2903
2904      ; SET UP FOR NEXT TIME CODE AND CHECK FOR DONE
2905
2906 036336      50#:
2906 036336 062703 000002  ADD      #2,R3      ; POINT R3 TO NEXT TIME CODE VALUE
2907 036342 012702 000005  MOV      #5,R2      ; R2 WITH NUMBER OF LOOPS PER CODE
2908 036346 005301  DEC      R1      ; DECREMENT CODE COUNTER
2909 036350 001402  BEQ      60#      ; BRANCH IF DONE
2910 036352 000137 036034  JMP      L37      ; GO TEST NEXT TIME CODE
2911 036356
2912 036356 104432  EXIT     TST
036356 000014  TRAP     C#EXIT
036360      .WORD   L10130-.

2913
2914      ; TABLE OF TIME CODES
2915
2916 036362      TABLE36:
2917 036362 000000  .WORD   TIME.5      ; 1/2 SECOND TIME CODE
2918 036364 000004  .WORD   TIME1      ; 1 SECOND TIME CODE
2919 036366 000010  .WORD   TIME2      ; 2 SECONDS TIME CODE
2920 036370 000014  .WORD   TIME4      ; 4 SECONDS TIME CODE
2921 036372 000000  P37: .WORD   0      ; FLAG FOR MESSAGE ABOUT BELL
2922 036374  ENDTST

```

G12

TEST37: CHECK WDTO TIME

036374
036374 104401

L10130: TRAP C#ETST

TEST38: CHECK WDTO RESET

```

2924 .SBTTL TEST38: CHECK WDTO RESET
2925 036376 STATST <CHECK WDTO RESET>
036376 040 103 110 T38MSG:: .ASCIZ / CHECK WDTO RESET/

2926 ;*****
2927 ;**
2928 ;TEST DESCRIPTION-
2929 ; CHECKS THAT TIMER CAN BE RESET
2930 ; USES UPWRFAIL - QWDTO LOOP-BACK
2931 ;TEST STEPS-
2932 ; SET QCTL THRENB
2933 ; WAIT < 10 MILLISECONDS
2934 ; CHECK QINT UPWRFL FOR 0
2935 ; SET QCTL WDTRST BIT
2936 ; REPEAT 1000 TIMES
2937 ;
2938 ;
2939 ;--
2940 ;*****
2941
2942 036420 BGNTST
036420 T38::
2943 036420 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
036420 TRAP C#RFLA
036422 104421 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
036426 001012 BNE 64# ; BRANCH IF NOT SET
036430 012746 036376 MOV #T38MSG,-(SP)
036434 012746 002270 MOV #PNTMSG,-(SP)
036440 012746 000002 MOV #2,-(SP)
036444 010600 MOV SP,R0
036446 104417 TRAP C#PNTF
036450 062706 000006 ADD #6,SP
036454 005037 002532 64# : CLR ERROR1 ; CLEAR ERROR COUNTER
2944 036460 INIT
; INITIALIZE DEVICE
036460 012777 000100 143630 MOV #MHALT,@QMT1 ; INITIALIZE Q-BRIDGE
036466 013777 002520 143622 MOV INITWORD,@QMT1 ; SET UP LOOPBACK OPTION
036474 005077 143600 CLR @QINT ; CLEAR QINT AFTER LOOPBACK ENABLED
036500 005037 002532 CLR ERROR1 ; CLEAR ERROR FLAG
2945 036504 012701 001750 MOV #1000.,R1 ; NUMBER OF LOOPS IN TEST
2946 036510 BGNSUB
T38.1:
2947 036512 104402 000002 143562 L38: TRAP C#SUB
036510 052777 000002 143562 BIS #THRENB,@QCTL ; SET THRENB BIT IN QCTL
2948 036520 012727 000003 DELAY 3 ; WAIT ABOUT 7.5 MS
036520 012727 000003 MOV #3,(PC)+
036524 000000 .WORD 0
036526 013727 002116 MOV L#DLY,(PC)+
036532 000000 .WORD 0
036534 005367 177772 DEC -6(PC)
036540 001375 BNE .-4
036542 005367 177756 DEC -22(PC)
036546 001367 BNE .-20
2949 036550 032777 010000 143522 BIT #UPWRFL,@QINT ; CHECK UPWRFL FOR CLEAR
2950 036556 001410 BEQ 10# ; BRANCH IF OK
2951 ;
2952 ; ERROR CONDITION
2953 ;

```

TEST38: CHECK WDTO RESET

```

2954 036560          ERRHRD 1,MSG47          ; TELL OPERATOR ERROR
      036560 104456  TRAP   C#ERHRD
      036562 000001  .WORD  1
      036564 010140  .WORD  MSG47
      036566 000000  .WORD  0
2955 036570 004737 013230 JSR   PC,DUMP          ; DO OPTIONAL REGISTER DUMP
2956 036574          EXIT   TST              ; ABORT TEST IF ERROR
      036574 104432  TRAP   C#EXIT
      036576 000016  .WORD  L10131-.
2957
2958
2959
2960 036600          ; END ERROR CONDITION
2961 036600 052777 000001 143474 101:  BIS   #WDTRST,0QCTL          ; SET WDTRST BIT
2962 036606          ENDSUB
      036606          L10132:
      036606 104403  TRAP   C#ESUB
2963 036610 005301  DEC   R1              ; DECREMENT LOOP COUNTER
2964 036612 001337  BNE   L38              ; IF NOT DONE, LOOP
2965 036614          ENDTST
      036614 104401  L10131: TRAP   C#ETST

```


TEST39: CHECK VNTACK INTERRUPT

```

2967 .SBTTL TEST39: CHECK VNTACK INTERRUPT
2968 036616 STATST <CHECK VNTACK INTERRUPT>
036616 040 103 110 T39MSG:: .ASCIZ / CHECK VNTACK INTERRUPT/

2969 ;*****
2970 ;**
2971 ;TEST DESCRIPTION-
2972 ; CHECKS THAT VNTACK SETTING CAN CAUSE INTERRUPT
2973 ; USES QCMDACK - UEVENTACK LOOP-BACK
2974 ;TEST STEPS-
2975 ; SET INTERRUPT VECTOR
2976 ; SET QVNT ACKIE BIT
2977 ; CHECK FOR BIT SET
2978 ; SET QCMD CMDACK BIT
2979 ; CHECK FOR IMMEDIATE INTERRUPT
2980 ; RESTORE INTERRUPT VECTOR
2981 ;
2982 ;--
2983 ;*****
2984
2985
2986 036646 BGNTST
036646 T39::
2987 036646 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
036646 104421 TRAP C@RFLA
036650 022700 001000 CMP @PNT,R0 ; IS PNT FLAG SET?
036654 001012 BNE 64@ ; BRANCH IF NOT SET
036656 012746 036616 MOV @T39MSG,-(SP)
036662 012746 002270 MOV @PNTMSG,-(SP)
036666 012746 000002 MOV @2,-(SP)
036672 010600 MOV SP,R0
036674 104417 TRAP C@PNTF
036676 062706 000006 ADD @6,SP
036702 005037 002532 64@: CLR ERROR1 ; CLEAR ERROR COUNTER
2988 036706 INIT
;INITIALIZE DEVICE
036706 012777 000100 143402 MOV @M@HALT,@QMT1 ;INITIALIZE Q-BRIDGE
036714 013777 002520 143374 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
036722 005077 143352 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
036726 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
2989 036732 SETVEC VECTOR,@L39,@PRI07 ; SET INTERRUPT VECTOR
036732 012746 000340 MOV @PRI07,-(SP)
036736 012746 037060 MOV @L39,-(SP)
036742 013746 002512 MOV VECTOR,-(SP)
036746 012746 000003 MOV @3,-(SP)
036752 104437 TRAP C@SVEC
036754 062706 000010 ADD @10,SP
2990 036760 052777 000100 143310 BIS @ACKIE,@QVNT ; SET ACKIE BIT
2991 036766 017737 143304 002526 MOV @QVNT,VAL ; READ QVNT
2992 036774 032737 000100 002526 BIT @ACKIE,VAL ; IS ACKIE BIT REALLY SET
2993 037002 001012 BNE 10@ ; BRANCH IF OK
2994
2995 ; ERROR CONDITION
2996 ;
2997 037004 012701 000001 MOV @1,R1 ; REGISTER NUMBER TO R1
2998 037010 012737 000100 002530 MOV @ACKIE,EXP ; EXPECTED PATTERN TO EXP
2999 037016 037016 104456 ERRHRD 1,MSG48,ERR4 ; TELL OPERATOR ERROR
TRAP C@ERRHD

```

TEST39: CHECK VNTACK INTERRUPT

```

037020 000001           .WORD  1
037022 010177           .WORD  MSG48
037024 011776           .WORD  ERR4
3000 037026 000417      BR      E39           ; BRANCH TO END
3001
3002           ;
3003           ; END ERROR CONDITION
3004 037030
3005 037030 052777 000001 143236 100:    BIS      #CMDACK,@QCMD       ; SET QMDACK BIT, SHOULD INTERRUPT NOW
3006 037036 000240           NOP             ; ALLOW SMALL AMOUNT OF TIME
3007 037040 000240           NOP
3008
3009           ;
3010           ; ERROR CONDITION, INTERRUPT DID NOT WORK IF HERE
3011 037042
3012 037042 104456           ERRHRD  2,MSG49           ; TELL OPERATOR ERROR
3013 037044 000002           TRAP   C#ERRHRD
3014 037046 010247           .WORD  2
3015 037050 000000           .WORD  MSG49
3016 037052 004737 013230           .WORD  0
3017 037056 000403           JSR    PC,DUMP       ; DO OPTIONAL REGISTER DUMP
3018
3019           BR      E39           ; SKIP INTERRUPT SERVICE ROUTINE
3020
3021           ;
3022           ; END ERROR CONDITION
3023           ; INTERRUPT SERVICE ROUTINE
3024
3025           ;
3026 037060           BGNSRV  L39
3027 037060 012716 037066  L39::    MOV     #E39,(SP)
3028 037064           ENDSRV
3029 037064
3030 037064 000002  L10134:  RTI
3031
3032           ;
3033           ; END INTERRUPT SERVICE ROUTINE
3034
3035           ;
3036 037066           E39:
3037 037066 013700 002512           CLRVEC VECTOR       ; CLEAR VECTOR
3038 037072 104436           MOV    VECTOR,R0
3039 037074
3040 037074           TRAP  C#CVEC
3041 037074 104401  L10133:  ENDTST
3042           TRAP  C#ETST

```

TEST40: CHECK CMDPRS INTERRUPT

```

3028 .SBTTL TEST40: CHECK CMDPRS INTERRUPT
3029 037076 STATST <CHECK CMDPRS INTERRUPT>
      037076 040 103 110 T40MSG:: .ASCIZ / CHECK CMDPRS INTERRUPT/
3030
3031 ;*****
3032 ;**
3033 ;TEST DESCRIPTION-
3034 ; CHECKS THAT CMDPRS SETTING CAN CAUSE INTERRUPT
3035 ; USES QEVENTPRS - UCMDPRS LOOP-BACK
3036 ;TEST STEPS-
3037 ; SET INTERRUPT VECTOR
3038 ; SET QCMD PRSIE BIT
3039 ; CHECK FOR BIT SET
3040 ; SET QVNT VNTPRS BIT
3041 ; CHECK FOR IMMEDIATE INTERRUPT
3042 ; RESTORE INTERRUPT VECTOR
3043 ;
3044 ;--
3045 ;*****
3046
3047 037126 BGNTST
      037126
3048 037126 T40::
      037126 CKPNT
      037126 TRAP C#RFLA ; PRINT OUT TEST TITLE IF PNT SET
      037126 104421 CMP #PNT,R0 ; IS PNT FLAG SET?
      037130 022700 001000 BNE 64# ; BRANCH IF NOT SET
      037134 001012 MOV #T40MSG,-(SP)
      037136 012746 037076 MOV #PNTMSG,-(SP)
      037142 012746 002270 MOV #2,-(SP)
      037146 012746 000002 MOV SP,R0
      037152 010600 TRAP C#PNTF
      037154 104417 ADD #6,SP
      037156 062706 000006 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
      037162 005037 002532 INIT
3049 037166 ;INITIALIZE DEVICE
      037166 012777 000100 143122 MOV #MHALT,#QMT1 ;INITIALIZE Q-BRIDGE
      037174 013777 002520 143114 MOV INITWORD,#QMT1 ;SET UP LOOPBACK OPTION
      037202 005077 143072 CLR #QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
      037206 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
3050 037212 SETVEC VECTOR,#L40,#PRI07 ; SET INTERRUPT VECTOR
      037212 012746 000340 MOV #PRI07,-(SP)
      037216 012746 037340 MOV #L40,-(SP)
      037222 013746 002512 MOV VECTOR,-(SP)
      037226 012746 000003 MOV #3,-(SP)
      037232 104437 TRAP C#SVEC
      037234 062706 000010 ADD #10,SP
3051 037240 012777 000100 143026 MOV #PRSIE,#QCMD ; SET QCMD PRSIE BIT
3052 037246 017737 143022 002526 MOV #QCMD,VAL ; READ QCMD
3053 037254 032737 000100 002526 BIT #PRSIE,VAL ; IS PRSIE BIT SET
3054 037262 001012 BNE 10# ; BRANCH IF OK
3055
3056 ; ERROR CONDITION
3057 ;
3058 037264 012701 000000 MOV #0,R1 ; REGISTER NUMBER TO R1
3059 037270 012737 000100 002530 MOV #PRSIE,EXP ; EXPECTED PATTERN TO EXP
3060 037276 104456 ERRHRD 1,MSG50,ERR4 ; TELL OPERATOR ERROR
      037276 TRAP C#ERRHD

```

TEST40: CHECK CMDPRS INTERRUPT

```

037300 000001          .WORD 1
037302 010337          .WORD MSG50
037304 011776          .WORD ERR4
3061 037306 000417     BR E40          ; BRANCH TO END
3062
3063                   ; END ERROR CONDITION
3064
3065 037310          100:
3066 037310 052777 000001 142760     BIS #VNTPRS,@QVNT      ; SET VNTPRS BIT, SHOULD INTERRUPT NOW
3067 037316 000240     NOP          ; ALLOW SMALL AMOUNT OF TIME
3068 037320 000240     NOP
3069
3070                   ; ERROR CONDITION, INTERRUPT DID NOT WORK IF HERE
3071
3072 037322          ;
037322 104456     ERRHRD 2,MSG51      ; TELL OPERATOR ERROR
037324 000002     TRAP C#ERHRD
037326 010407     .WORD 2
037330 000000     .WORD MSG51
3073 037332 004737 013230     .WORD 0
3074 037336 000403     JSR PC,DUMP      ; DO OPTIONAL REGISTER DUMP
037336 000403     BR E40          ; SKIP INTERRUPT SERVICE ROUTINE
3075
3076                   ; END ERROR CONDITION
3077                   ; INTERRUPT SERVICE ROUTINE
3078
3079 037340          ;
037340          L40: BGNSRV L40
3080 037340 012716 037346     MOV #E40,(SP)
3081 037344          ENDSRV
037344          L10136: RTI
037344 000002
3082
3083                   ; END INTERRUPT SERVICE ROUTINE
3084
3085 037346          ;
3086 037346          E40: CLRVEC VECTOR      ; CLEAR VECTOR
037346 013700 002512     MOV VECTOR,R0
037352 104436     TRAP C#CVEC
3087 037354          ENDTST
037354          L10135: TRAP C#ETST
037354 104401

```

TEST41: CHECK RDY INTERRUPT

```

3089 .SBTTL TEST41: CHECK RDY INTERRUPT
3090 037356 STATST <CHECK RDY INTERRUPT>
037356 040 103 110 T41MSG:: .ASCIZ / CHECK RDY INTERRUPT/
3091
3092 ;*****
3093 ;**
3094 ;TEST DESCRIPTION-
3095 ; CHECKS THAT RDY BIT SET CAUSES INTERRUPT
3096 ;TEST STEPS-
3097 ; SET INTERRUPT VECTOR
3098 ; SET QDMA RDYIE BIT
3099 ; CHECK FOR BIT SET
3100 ; SET QWC = -1
3101 ; SET QBA = (ANY LEGAL ADDRESS)
3102 ; SET QDMA DMAWT, GO BITS
3103 ; CHECK FOR IMMEDIATE INTERRUPT
3104 ; RESTORE INTERRUPT VECTOR
3105 ;
3106 ;--
3107 ;*****
3108
3109 037404 BGNTST
037404
3110 037404 T41:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
037404 104421 TRAP C#RFLA
037406 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
037412 001012 BNE 64# ; BRANCH IF NOT SET
037414 012746 037356 MOV #T41MSG,-(SP)
037420 012746 002270 MOV #PNTMSG,-(SP)
037424 012746 000002 MOV #2,-(SP)
037430 010600 MOV SP,R0
037432 104417 TRAP C#PNTF
037434 062706 000006 ADD #6,SP
037440 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
3111 037444 INIT
;INITIALIZE DEVICE
037444 012777 000100 142644 MOV #QHALT,QGMT1 ;INITIALIZE Q-BRIDGE
037452 013777 002520 142636 MOV INITWORD,QGMT1 ;SET UP LOOPBACK OPTION
037460 005077 142614 CLR QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
037464 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
3112 037470 SETVEC VECTOR,#L41,#PRI07 ; SET INTERRUPT VECTOR
037470 012746 000340 MOV #PRI07,-(SP)
037474 012746 037632 MOV #L41,-(SP)
037500 013746 002512 MOV VECTOR,-(SP)
037504 012746 000003 MOV #3,-(SP)
037510 104437 TRAP C#SVEC
037512 062706 000010 ADD #10,SP
3113 037516 052777 000100 142560 BIS #RDYIE,QDMA ; SET QDMA RDYIE BIT
3114 037524 017737 142554 002526 MOV QDMA,VAL ; READ QDMA INTO VAL
3115 037532 032737 000100 002526 BIT #RDYIE,VAL ; IS RDYIE BIT REALLY SET
3116 037540 001012 BNE 10# ; BRANCH IF OK
3117
3118 ; ERROR CONDITION
3119 ;
3120 037542 012701 000004 MOV #4,R1 ; REGISTER NUMBER TO R1
3121 037546 012737 000100 002530 MOV #RDYIE,EXP ; EXPECTED PATTERN TO EXP
3122 037554 ERRHRD 1,MSG52,ERR4 ; TELL OPERATOR ERROR

```

TEST41: CHECK RDY INTERRUPT

037554	104456				TRAP	C0ERHRD		
037556	000001				.WORD	1		
037560	010477				.WORD	MSG52		
037562	011776				.WORD	ERR4		
3123	037564	000425			BR	E41		; BRANCH TO END
3124								
3125								
3126								
3127	037566							
3128	037566	012777	177777	142516				
3129	037574	012777	041660	142506	100:	MOV	#-1,BQWC	; SET QWC = -1
3130	037602	052777	000003	142474		MOV	#PATCH,@QBA	; LOAD QBA WITH ANY ADDRESS ;VD.2
3131	037610	000240				BIS	@GO!DMAWT,@QDMA	; CAUSE INTERRUPT
3132	037612	000240				NOP		; TIME DELAY
3133						NOP		
3134								
3135								
3136	037614							
	037614	104456				ERRHRD	2,MSG53	; TELL OPERATOR ERROR
	037616	000002				TRAP	C0ERHRD	
	037620	010547				.WORD	2	
	037622	000000				.WORD	MSG53	
3137	037624	004737	013230			.WORD	0	
3138	037630	000403				JSR	PC,DUMP	; DO OPTIONAL REGISTER DUMP
3139						BR	E41	; BRANCH OVER INTERRUPT AREA
3140								
3141								
3142								
3143	037632							
	037632							
3144	037632	012716	037640		L41::	BGNSRV	L41	
3145	037636					MOV	#E41,(SP)	; ADJUST STACK
	037636					ENDSRV		
	037636	000002			L10140:	RTI		
3146	037640				E41:			
3147	037640					CLRVEC	VECTOR	; CLEAR VECTOR
	037640	013700	002512			MOV	VECTOR,R0	
	037644	104436				TRAP	C0CVEC	
3148	037646					ENDTST		
	037646				L10137:			
	037646	104401				TRAP	C0ETST	

TEST42: CHECK ERR INTERRUPT (UNEX)

```

3150 .SBTTL TEST42: CHECK ERR INTERRUPT (UNEX)
3151 037650 STATST <CHECK ERR INTERRUPT (UNEX)>
037650 040 103 110 T42MSG:: .ASCIZ / CHECK ERR INTERRUPT (UNEX)/
3152 ;*****
3153 ;**
3154 ;TEST DESCRIPTION-
3155 ; CHECKS THAT UNEX CAN CAUSE INTERRUPT
3156 ; USES QPWRFL - UNEX LOOP-BACK
3157 ;TEST STEPS-
3158 ; SET INTERRUPT VECTOR
3159 ; SET QINT ERRIE BIT, CHECK
3160 ; SET QMT1 MOPFL BIT
3161 ; CHECK FOR IMMEDIATE INTERRUPT
3162 ; CHECK QINT ERR, UNEX BITS
3163 ; CLEAR QMT1 MOPFL BIT
3164 ; RESTORE INTERRUPT VECTOR
3165 ;
3166 ;
3167 ;--
3168 ;*****
3169
3170 037704 BGNTST
037704
3171 037704 T42:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
037704 104421 TRAP C@RFLA
037706 022700 001000 CMP @PNT,R0 ; IS PNT FLAG SET?
037712 001012 BNE 64@ ; BRANCH IF NOT SET
037714 012746 037650 MOV @T42MSG,-(SP)
037720 012746 002270 MOV @PNTMSG,-(SP)
037724 012746 000002 MOV @2,-(SP)
037730 010600 MOV SP,R0
037732 104417 TRAP C@PNTF
037734 062706 000006 ADD @6,SP
037740 005037 002532 64@: CLR ERROR1 ; CLEAR ERROR COUNTER
3172 037744 INIT
;INITIALIZE DEVICE
037744 012777 000100 142344 MOV @M@HALT,@QMT1 ;INITIALIZE Q-BRIDGE
037752 013777 002520 142336 MOV INITWORD,@QMT1 ;SET UP LOOPBACK OPTION
037760 005077 142314 CLR @QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
037764 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
3173 037770 SETVEC VECTOR,@L42,@PRI07 ; SET INTERRUPT VECTOR
037770 012746 000340 MOV @PRI07,-(SP)
037774 012746 040116 MOV @L42,-(SP)
040000 013746 002512 MOV VECTOR,-(SP)
040004 012746 000003 MOV @3,-(SP)
040010 104437 TRAP C@SVEC
040012 062706 000010 ADD @10,SP
3174 040016 052777 000100 142254 BIS @ERRIE,@QINT ; SET QINT ERRIE BIT
3175 040024 017737 142250 002526 MOV @QINT,VAL ; READ QINT INTO VAL
3176 040032 032737 000100 002526 BIT @ERRIE,VAL ; IS ERRIE BIT REALLY SET
3177 040040 001012 BNE 10@ ; BRANCH IF OK
3178 ;
3179 ; ERROR CONDITION
3180 ;
3181 040042 012701 000002 MOV @2,R1 ; REGISTER NUMBER TO R1
3182 040046 012737 000100 002530 MOV @ERRIE,EXP ; EXPECTED PATTERN TO EXP
3183 040054 ERRHRD 1,MSG54,ERR4 ; TELL OPERATOR ERROR

```

TEST42: CHECK ERR INTERRUPT (UNEX)

```

040054 104456          TRAP  C0ERHRD
040056 000001         .WORD  1
040060 010653         .WORD  MSG54
040062 011776         .WORD  ERR4
3184 040064 000450     BR      E42                ; BRANCH TO END
3185
3186                   ; END ERROR CONDITION
3187
3188 040066
3189 040066 052777 000040 142222 100:    BIS      #MQPFL,BQMT1        ; ENABLE INTERRUPT
3190 040074 000240     NOP
3191 040076 000240     NOP                ; TIME DELAY
3192
3193                   ; ERROR CONDITION, INTERRUPT DID NOT WORK IF HERE
3194
3195 040100
040100 104456          ERRHRD  2,MSG55                ; TELL OPERATOR ERROR
040102 000002          TRAP  C0ERHRD
040104 010723         .WORD  2
040106 000000         .WORD  MSG55
3196 040110 004737 013230  JSR     PC,DUMP                ; DO OPTIONAL REGISTER DUMP
3197 040114 000434     BR      E42                ; BRANCH OVER INTERRUPT AREA
3198
3199                   ; END ERROR CONDITION
3200                   ; INTERRUPT SERVICE ROUTINE
3201
3202 040116          BGNSRV  L42
040116
3203 040116 017737 142156 002526 L42::  MOV     BQINT,VAL                ; READ QINT REGISTER
3204 040124 012737 140000 002530  MOV     #UNEX!ERR,EXP          ; EXPECTED PATTERN TO EXP
3205 040132 005137 002530         COM     EXP                    ; COMPLEMENT EXP FOR CLEARING
3206 040136 043737 002530 002526  BIC     EXP,VAL                ; CLEAR UNTESTED BITS
3207 040144 005137 002530         COM     EXP                    ; RESTORE EXPECTED PATTERN
3208 040150 023737 002530 002526  CMP     EXP,VAL                ; COMPARE EXPECTED WITH VALUE
3209 040156 001410     BEQ     200                    ; BRANCH IF OK
3210
3211                   ; ERROR CONDITION
3212
3213 040160 012701 000002         MOV     #2,R1                    ; REGISTER NUMBER TO R1
3214 040164          ERRHRD  3,MSG56,ERR4          ; TELL OPERATOR ERROR
040164 104456          TRAP  C0ERHRD
040166 000003         .WORD  3
040170 011012         .WORD  MSG56
040172 011776         .WORD  ERR4
3215 040174 004737 013230  JSR     PC,DUMP                ; DO OPTIONAL REGISTER DUMP
3216
3217                   ; END ERROR CONDITION
3218
3219 040200 012716 040206 200:    MOV     #E42,(SP)                ; ADJUST STACK
3220 040204          ENDSRV
040204
040204 000002
3221 040206          RTI
3222 040206 042777 000040 142102 E42:    BIC     #MQPFL,BQMT1          ; CLEAR MQPFL BIT IN QMT1
3223 040214          CLRVEC  VECTOR                ; CLEAR VECTOR
040214 013700 002512     MOV     VECTOR,RO
040220 104436          TRAP  C0CVEC

```


TEST42: CHECK ERR INTERRUPT (UNEX)

3224 040222
040222
040222 104401

L10141: ENDTST
TRAP C#ETST

TEST43: CHECK ERR INTERRUPT (QNEX)

```

3226 .SBTTL TEST43: CHECK ERR INTERRUPT (QNEX)
3227 040224 STATST <CHECK ERR INTERRUPT (QNEX)>
040224 040 103 110 T43MSG:: .ASCIZ / CHECK ERR INTERRUPT (QNEX)/
3228 ;*****
3229 ;**
3230 ;
3231 ;TEST DESCRIPTION-
3232 ; CHECKS THAT QNEX CAN CAUSE INTERRUPT
3233 ;TEST STEPS-
3234 ; SET INTERRUPT VECTOR
3235 ; SET QINT ERRIE BIT
3236 ; SET QMC = -1
3237 ; SET QBA = 160000 (ILLEGAL ADDRESS)
3238 ; SET QDMA = 37400
3239 ; SET QDMA DMAWT, GO BITS
3240 ; CHECK FOR IMMEDIATE INTERRUPT (CAN BE 10 MICROSEC.)
3241 ; CHECK QINT ERR, QNEX BITS
3242 ; RESTORE INTERRUPT VECTOR
3243 ;
3244 ;--
3245 ;*****
3246
3247 040260 BGNTST
040260 T43::
3248 040260 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
040260 104421 TRAP C:RFLA
040262 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
040266 001012 BNE 64: ; BRANCH IF NOT SET
040270 012746 040224 MOV #T43MSG,-(SP)
040274 012746 002270 MOV #PNTMSG,-(SP)
040300 012746 000002 MOV #2,-(SP)
040304 010600 MOV SP,R0
040306 104417 TRAP C:PNTF
040310 062706 000006 ADD #6,SP
040314 005037 002532 64: CLR ERROR1 ; CLEAR ERROR COUNTER
3249 040320 INIT
;INITIALIZE DEVICE
040320 012777 000100 141770 MOV #QHALT,QMNT1 ;INITIALIZE Q-BRIDGE
040326 013777 002520 141762 MOV INITWORD,QMNT1 ;SET UP LOOPBACK OPTION
040334 005077 141740 CLR QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
040340 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
3250 040344 SETVEC VECTOR,#L43,#PRI07 ; SET INTERRUPT VECTOR
040344 012746 000340 MOV #PRI07,-(SP)
040350 012746 040454 MOV #L43,-(SP)
040354 013746 002512 MOV VECTOR,-(SP)
040360 012746 000003 MOV #3,-(SP)
040364 104437 TRAP C:SVEC
040366 062706 000010 ADD #10,SP
3251 040372 052777 000100 141700 BIS #ERRIE,QINT ; SET ERRIE BIT IN QINT
3252 040400 012777 177777 141704 MOV #-1,QMC ; ALL 1'S TO QMC
3253 040406 012777 160000 141674 MOV #160000,QBA ; ILLEGAL ADDRESS 160000 TO QBA
3254 040414 012777 037400 141662 MOV #37400,QDMA ; 37400 TO QDMA
3255 040422 052777 000003 141654 BIS #DMAWT!GO,QDMA ; INITIATE INTERRUPT
3256 040430 000240 NOP ; SMALL TIME DELAY
3257 040432 000240 NOP
3258 040434 000240 NOP
3259

```

TEST43: CHECK ERR INTERRUPT (GNEX)

```

3260                                     ; ERROR CONDITION, INTERRUPT DID NOT WORK IF HERE
3261                                     ;
3262 040436                               ; ERRHRD 1,MSG57                               ; TELL OPERATOR ERROR
      040436 104456                       TRAP C#ERRHRD
      040440 000001                       .WORD 1
      040442 011101                       .WORD MSG57
      040444 000000                       .WORD 0
3263 040446 004737 013230                JSR PC,DUMP                               ; DO OPTIONAL REGISTER DUMP
3264 040452 000434                       BR E43                                    ; BRANCH OVER INTERRUPT AREA
3265                                     ;
3266                                     ; END ERROR CONDITION
3267                                     ; INTERRUPT SERVICE ROUTINE
3268                                     ;
3269 040454                               ; BGNSRV L43
      040454                               L43::
3270 040454 017737 141620 002526         MOV BQINT,VAL                               ; READ QINT REGISTER
3271 040462 012737 120000 002530         MOV #GNEX!ERR,EXP                          ; EXPECTED PATTERN TO EXP
3272 040470 005137 002530                COM EXP                                     ; COMPLEMENT EXP FOR CLEARING
3273 040474 043737 002530 002526         BIC EXP,VAL                                ; CLEAR UNTESTED BITS
3274 040502 005137 002530                COM EXP                                     ; RESTORE EXPECTED PATTERN
3275 040506 023737 002530 002526         CMP EXP,VAL                                ; COMPARE EXPECTED WITH VALUE
3276 040514 001410                       BEQ 20#                                     ; BRANCH IF OK
3277                                     ;
3278                                     ; ERROR CONDITION
3279                                     ;
3280 040516 012701 000002                 MOV #2,R1                                  ; REGISTER NUMBER TO R1
3281 040522                               ERRHRD 2,MSG58,ERR4                          ; TELL OPERATOR ERROR
      040522 104456                       TRAP C#ERRHRD
      040524 000002                       .WORD 2
      040526 011205                       .WORD MSG58
      040530 011776                       .WORD ERR4
3282 040532 004737 013230                JSR PC,DUMP                               ; DO OPTIONAL REGISTER DUMP
3283                                     ;
3284                                     ; END ERROR CONDITION
3285                                     ;
3286 040536 012716 040544                 20#: MOV #E43,(SP)                          ; ADJUST STACK
3287 040542                               ENDSRV
      040542                               L10144:
      040542 000002                       RTI
3288 040544                               E43:
3289 040544 042777 000040 141544         BIC #MQPFL,BQMT1                          ; CLEAR MQPFL BIT IN QMT1
3290 040552 013700 002512               CLRVEC VECTOR                             ; CLEAR VECTOR
      040552 013700 002512               MOV VECTOR,RO
      040556 104436                       TRAP C#CVEC
3291 040560                               L10143:
      040560 104401                       TRAP C#ETST
  
```

TEST44: CHECK ERR INTERRUPT (UPWRFL)

```

3293 .SBTTL TEST44: CHECK ERR INTERRUPT (UPWRFL)
3294 040562 STATST <CHECK ERR INTERRUPT (UPWRFL)>
040562 040 103 110 T44MSG:: .ASCIZ / CHECK ERR INTERRUPT (UPWRFL)/
3295 ;*****
3296 ;**
3297 ;TEST DESCRIPTION-
3298 ; CHECKS THAT UPWRFL CAN CAUSE INTERRUPT
3299 ; USED WDTO - UPWRFL LOOP-BACK
3300 ;TEST STEPS
3301 ; SET INTERRUPT VECTOR
3302 ; SET QINT ERRIE BIT
3303 ; SET QCTL TMRENB
3304 ; WAIT FOR INTERRUPT ON TIME-OUT
3305 ; CHECKS QINT UPWRFL, ERR BITS
3306 ; RESTORE INTERRUPT VECTOR
3307 ;
3308 ;
3309 ;--
3310 ;*****
3311
3312 040620 BGNTST
040620
3313 040620 T44:: CKPNT ; PRINT OUT TEST TITLE IF PNT SET
040620 104421 TRAP C#RFLA
040622 022700 001000 CMP #PNT,R0 ; IS PNT FLAG SET?
040626 001012 BNE 64# ; BRANCH IF NOT SET
040630 012746 040562 MOV #T44MSG,-(SP)
040634 012746 002270 MOV #PNTMSG,-(SP)
040640 012746 000002 MOV #2,-(SP)
040644 010600 MOV SP,R0
040646 104417 TRAP C#PNTF
040650 062706 000006 ADD #6,SP
040654 005037 002532 64#: CLR ERROR1 ; CLEAR ERROR COUNTER
3314 040660 INIT
;INITIALIZE DEVICE
040660 012777 000100 141430 MOV #MHALT,#QMT1 ;INITIALIZE Q-BRIDGE
040666 013777 002520 141422 MOV INITWORD,#QMT1 ;SET UP LOOPBACK OPTION
040674 005077 141400 CLR #QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
040700 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
3315 040704 SETVEC VECTOR,#L44,#PRI07 ; SET INTERRUPT VECTOR
040704 012746 000340 MOV #PRI07,-(SP)
040710 012746 041032 MOV #L44,-(SP)
040714 013746 002512 MOV VECTOR,-(SP)
040720 012746 000003 MOV #3,-(SP)
040724 104437 TRAP C#SVEC
040726 062706 000010 ADD #10,SP
3316 040732 052777 000100 141340 BIS #ERRIE,#QINT ; SET ERRIE BIT IN QINT
3317 040740 052777 000002 141334 BIS #TMRENB,#QCTL ; SET TMRENB IN QCTL
3318 ;
3319 ; NOW WAIT FOR MAXIMUM OF 8 SECONDS FOR WDTO INTERRUPT
3320 ;
3321 040746 012704 000360 MOV #240.,R4 ; NUMBER OF .025 SEC TO LOOP
3322 040752
3323 040752 10#: DELAY 25. ; .025 SEC DELAY
040752 012727 000031 MOV #25.,(PC)+
040756 000000 .WORD 0
040760 013727 002116 MOV L#DLY,(PC)+

```

TEST44: CHECK ERR INTERRUPT (UPWRFL)

```

040764 000000          .WORD 0
040766 005367 177772  DEC -6(PC)
040772 001375          BNE .-4
040774 005367 177756  DEC -22(PC)
041000 001367          BNE .-20
3324 041002          BREAK          ; CHECK FOR OPERATOR INPUT
      041002 104422    TRAP C#BRK
3325 041004 001002    BNE 20$          ; IF TIMER COMPLETE, BRANCH
3326 041006 005304    DEC R4          ; DECREMENT R4 COUNTER
3327 041010 001360    BNE 10$          ; BRANCH IF 6 SECONDS NOT UP
3328
3329          ; ERROR CONDITION, 8 SECONDS UP WITH NO WDTO INTERRUPT
3330
3331 041012          ;
3332 041012          20$:
      041012 104456    ERRHRD 1,MSG59          ; TELL OPERATOR ERROR AND ABORT
      041014 000001    TRAP C#ERHRD
      041016 011274    .WORD 1
      041020 000000    .WORD MSG59
3333 041022 004737 013230 .WORD 0
      041026 104432    JSR PC,DUMP          ; DO OPTIONAL REGISTER DUMP
3334 041026          EXIT TST          ; ABORT TEST
      041030 000100    TRAP C#EXIT
      041030 000100    .WORD L10145-.
3335
3336          ;
3337          ; END ERROR CONDITION
3338          ; INTERRUPT SERVICE ROUTINE
3339 041032          ;
      041032          BGNSRV L44
3340 041032 017737 141242 002526 L44::
3341 041040 012737 110000 002530 MOV BQINT,VAL          ; READ QINT REGISTER
3342 041046 005137 002530 MOV #UPWRFL!ERR,EXP    ; EXPECTED PATTERN TO EXP
3343 041052 043737 002530 002526 COM EXP          ; COMPLEMENT EXP FOR CLEARING
3344 041060 005137 002530 BIC EXP,VAL          ; CLEAR UNTESTED BITS
3345 041064 023737 002530 002526 COM EXP          ; RESTORE EXPECTED PATTERN
3346 041072 001410    CMP EXP,VAL          ; COMPARE EXPECTED WITH VALUE
3347          BEQ 30$          ; BRANCH IF OK
3348
3349          ;
3350 041074 012701 000002    MOV #2,R1          ; REGISTER NUMBER TO R1
3351 041100          ERRHRD 2,MSG60,ERR4          ; TELL OPERATOR ERROR
      041100 104456    TRAP C#ERHRD
      041102 000002    .WORD 2
      041104 011351    .WORD MSG60
      041106 011776    .WORD ERR4
3352 041110 004737 013230 JSR PC,DUMP          ; DO OPTIONAL REGISTER DUMP
3353
3354          ;
3355          ; END ERROR CONDITION
3356 041114 012716 041122    30$: MOV #E44,(SP)          ; ADJUST STACK
3357 041120          ENDSRV
      041120 000002    L10146: RTI
3358 041122          E44:
3359 041122 013700 002512 CLRVEC VECTOR          ; CLEAR VECTOR
      041122 104436    MOV VECTOR,R0
      041126          TRAP C#CVEC

```

J13

TEST44: CHECK ERR INTERRUPT (UPWRFL)

3360 041130
041130
041130 104401

L10145: ENDTST
TRAP C:ETST

TEST45: CHECK BR LEVEL

```

3362 .SBTTL TEST45: CHECK BR LEVEL
3363 041132 STATST <CHECK BR LEVEL>
3364 041132 040 103 110 T45MSG:: .ASCIZ / CHECK BR LEVEL/
3365 ;*****
3366 ;**
3367 ;TEST DESCRIPTION-
3368 ; CHECKS FOR INTERRUPT WHEN PS IS BELOW DEVICE BR LEVEL
3369 ; CHECKS FOR NO INTERRUPT WHEN PS IS EQUAL OR ABOVE DEVICE LEVEL
3370 ;TEST STEPS-
3371 ; SET INTERRUPT VECTOR
3372 ; SET CPU PRIORITY = 7
3373 ; SET QVNT ACKIE BIT
3374 ; SET QCMD CMDACK BIT TO CAUSE INTERRUPT
3375 ; IF NOT INTERRUPT:
3376 ; CHECK FOR DEVICE LEVEL < OR = CPU LEVEL
3377 ; IF INTERRUPT:
3378 ; CHECK FOR DEVICE LEVEL > CPU LEVEL
3379 ; DROP CPU LEVEL AND REPEAT
3380 ; RESTORE INTERRUPT VECTOR
3381 ;
3382 ;--
3383 ;*****
3384
3385 041152 BGNTST
3386 041152 T45::
3387 041152 CKPNT ; PRINT OUT TEST TITLE IF PNT SET
3388 041152 TRAP C:RFLA
3389 041154 022700 001000 CMP #PNT,RO ; IS PNT FLAG SET?
3390 041160 001012 BNE 644 ; BRANCH IF NOT SET
3391 041162 012746 041132 MOV #T45MSG,-(SP)
3392 041166 012746 002270 MOV #PNTMSG,-(SP)
3393 041172 012746 000002 MOV #2,-(SP)
3394 041176 010600 MOV SP,RO
3395 041200 104417 TRAP C:PNTF
3396 041202 062706 000006 ADD #6,SP
3397 041206 005037 002532 644: CLR ERROR1 ; CLEAR ERROR COUNTER
3398 041212 INIT
3399 ;INITIALIZE DEVICE
3400 041212 012777 000100 141076 MOV #QHALT,%QMT1 ;INITIALIZE Q-BRIDGE
3401 041220 013777 002520 141070 MOV INITWORD,%QMT1 ;SET UP LOOPBACK OPTION
3402 041226 005077 141046 CLR %QINT ;CLEAR QINT AFTER LOOPBACK ENABLED
3403 041232 005037 002532 CLR ERROR1 ;CLEAR ERROR FLAG
3404 3388 041236 SETVEC VECTOR,%L45,BRLEVEL ; SET INTERRUPT VECTOR
3405 041236 013746 002516 MOV BRLEVEL,-(SP)
3406 041242 012746 041432 MOV #L45,-(SP)
3407 041246 013746 002512 MOV VECTOR,-(SP)
3408 041252 012746 000003 MOV #3,-(SP)
3409 041256 104437 TRAP C:SVEC
3410 041260 062706 000010 ADD #10,SP
3411 3389 041264 012737 000340 002540 MOV #PRI07,VALUE ; STORE CURRENT CPU LEVEL
3412 3390 041272
3413 3391 041272 SETPRI VALUE ; SET UP CURRENT CPU PRIORITY LEVEL
3414 041272 013700 002540 MOV VALUE,RO
3415 041276 104441 TRAP C:SPRI
3416 3392 041300 005037 002542 CLR INTFLG ; CLEAR INTRRRUPT FLAG
3417 3393 041304 052777 000100 140764 BIS #ACKIE,%QVNT ; SET ACKIE BIT IN QVNT

```

TEST45: CHECK BR LEVEL

```

3394 041312 052777 000001 140754      BIS      #CMDACK,8QCMD      ; CAUSE INTERRUPT
3395 041320 000240                      NOP                      ; LITTLE BIT OF TIME
3396 041322 005737 002542      TST      INTFLG          ; DID WE GET INTERRUPT
3397 041326 001011      BNE      20$            ; BRANCH IF WE GOT INTERRUPT
3398
3399      ; NO INTERRUPT, SEE CHECK CPU LEVEL VS. BR LEVEL
3400
3401 041330 023737 002540 002516      CMP      VALUE,BRLEVEL   ; COMPARE CPU LEVEL VS. BR
3402 041336 002015      BGE      30$            ; IF CPU >=BR, OK
3403
3404      ; ERROR CONDITION, NO INTERRUPT
3405
3406      ERRHRD 1,MSG61,ERR6      ; TELL OPERATOR ERROR
      041340 104456      TRAP     C#ERRHRD
      041342 000001      .WORD   1
      041344 011434      .WORD   MSG61
      041346 012160      .WORD   ERR6
3407 041350 000410      BR       30$            ; BRANCH OVER NEXT SECTION
3408
3409      ; INTERRUPT OCCURRED-CHECK CPU LEVEL VS. BR LEVEL
3410
3411 041352 023737 002540 002516 20$:  CMP      VALUE,BRLEVEL   ; COMPARE CPU LEVEL VS. BR
3412 041360 002404      BLT     30$            ; IF CPU<BR, OK; BRANCH
3413
3414      ; ERROR CONDITION, INTERRUPT OCCURED WHEN IT SHOULDN'T
3415
3416      ERRHRD 2,MSG62,ERR6      ; TELL OPERATOR ERROR
      041362 104456      TRAP     C#ERRHRD
      041364 000002      .WORD   2
      041366 011521      .WORD   MSG62
      041370 012160      .WORD   ERR6
3417
3418      ; END ERROR CONDITION, TRY NEXT LOWER CPU LEVEL
3419
3420      ;
3421 041372 012777 000001 140676 30$:  MOV      #VNTPRS,8QVNT    ; RESET VNTACK FOR NEXT LOOP
3422 041400 162737 000040 002540      SUB      #PRI01,VALUE    ; TRY NEXT CPU LEVEL
3423 041406 100401                      BMI      40$            ; IF DONE, BRANCH
3424 041410 000730      BR       10$            ; GO DO NEXT TEST
3425
3426      ; END OF TEST, RESTORE
3427
3428      ;
3429 041412 013700 002512 40$:  CLRVEC  VECTOR          ; CLEAR VECTOR
      041412 104436      MOV      VECTOR,R0
      041416 104436      TRAP     C#CVEC
3430 041420 012700 000000      SETPRI  #PRI00          ; LOWER CPU PRIORITY
      041420 104441      MOV      #PRI00,R0
      041424 104441      TRAP     C#SPRI
3431 041426 104432      EXIT   TST
      041426 000010      TRAP     C#EXIT
      041430 000010      .WORD   L10147-.
3432
3433      ; INTERRUPT SERVICE ROUTINE
3434
3435 041432      BGNSRV  L45
      041432
L45::

```


TEST45: CHECK BR LEVEL

3436 041432 005237 002542
 3437 041436
 041436
 041436 000002
 3438
 3439
 3440
 3441 041440
 041440
 041440 104401
 3442
 3443 041442
 3444

INC INTFLG ; INCREMENT INTERRUPT FLG
 ENDSRV
 L10150: RTI
 ;
 ; END INTERRUPT SERVICE ROUTINE
 ;
 ENDTST
 L10147: TRAP C#ETST
 ENDMOD

TEST45: CHECK BR LEVEL

1
13
14
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
69
70
71
72
73
74
75
76
77
84

041442
041442 000020
041444
041444 000031
041446 041504
041450 000000
041452 177776
041454
041454 001031
041456 041537
041460 000000
041462 001000
041464
041464 002130
041466 041572
041470 000001
041472
041472 003032
041474 041625
041476 000340
041500 000000
041502 000007

```
.ENABL AMA
.SBTTL HARDWARE PARAMETER CODING SECTION
BGNMOD
; **
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; --
BGNHRD
.WORD L10151-L#HARD/2
L#HARD:
GPRMA G1,0,0,0,177776,YES ;BASE ADDRESS
.WORD T#CODE
G1
.WORD T#LOLIM
.WORD T#HILIM
GPRMA G2,2,0,0,1000,YES ;VECTOR
.WORD T#CODE
G2
.WORD T#LOLIM
.WORD T#HILIM
GPRML G3,4,1,YES ;LOOPBACK CABLE INSTALLED?
.WORD T#CODE
G3
.WORD 1
GPRMD G4,6,0,340,0,7,YES ;BR LEVEL
.WORD T#CODE
G4
.WORD 340
.WORD T#LOLIM
.WORD T#HILIM
```

```
ENDHRD
.EVEN
L10151:
G1: .ASCIZ /BRIDGE MODULE BASE ADDRESS/
G2: .ASCIZ /BRIDGE MODULE VECTOR /
G3: .ASCIZ /LOOPBACK CABLE INSTALLED? /
G4: .ASCIZ /BR LEVEL /
.EVEN
```

SOFTWARE PARAMETER CODING SECTION

```

87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102 041660
103 041660
104
111
112 042060
      042060 042100
      042062 000006
      042064
113
114 042064
115 042064
      042064 000000
      042066 000004
      042070
116 042070 160500
117 042072 000500
118 042074 000000
119 042076 000200
120 042100
      042100
121 042100
122      000001
    
```

.SBTTL SOFTWARE PARAMETER CODING SECTION

```

; **
; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; **
    
```

; SOFTWARE PARAMETER SECTION NOT NEEDED
.EVEN

%PATCH::
.BLKW 100

```

      LASTAD
      .EVEN
      .WORD T%FREE
      .WORD T%SIZE
    
```

```

L%LAST::
;HARDCODED P-TABLE
  BGNSETUP 1
  BGNPTAB
  .WORD 0
  .WORD L10154-./2-1
    
```

```

L10152:
  .WORD QCMDAD
  .WORD VEC
  .WORD NO
  .WORD %B10000000
  ENDP TAB
    
```

```

L10154:
  ENDSETUP
.END
    
```

```

;HARDWARE UNIT 0 DEFAULT BASE ADDRESS
;HARDWARE UNIT 0 DEFAULT VECTOR
;LOOPBACK CABLE INSTALLED DEFAULT
;DEFAULT BR INTERRUPT LEVEL 4
    
```

SYMBOL TABLE

ABORT	015030	C#CLEA	= 000012	EF.RES	= 000037 G	FUNC1	= 000010 G	IER	= 020000 G
ACKIE	= 000100 G	C#CLOS	= 000035	EF.STA	= 000040 G	FUNC2	= 000020 G	INITWO	002520 G
ADD	002524 G	C#CLP1	= 000006	ENDI	015032	F#	= 000001	INITO	014474
ADDRESS	002274 G	C#CVEC	= 000036	ERR	= 100000 G	F#AU	= 000015	INIT1	014510
ADR	= 000020 G	C#DCLN	= 000044	ERRIE	= 000100 G	F#AUTO	= 000020	INIT2	014520
ASSEMB	= 000010	C#DODU	= 000051	ERROR1	002532 G	F#BGN	= 000040	INIT3	014606
BAD	015112	C#DRPT	= 000024	ERROR2	002534 G	F#CLEA	= 000007	INTB	013610
BASEAD	002510 G	C#DU	= 000053	ERR2	011702 G	F#DU	= 000016	INTBIT	002712 G
BITS#	012506 G	C#EDIT	= 000003	ERR4	011776 G	F#END	= 000041	INTFLG	002542 G
BIT#	012466 G	C#ERDF	= 000055	ERR5	012136 G	F#HARD	= 000004	ISR	= 000100 G
BIT0	= 000001 G	C#ERHR	= 000056	ERR6	012160 G	F#HM	= 000013	IXE	= 004000 G
BIT00	= 000001 G	C#ERRO	= 000060	ERR7	012246 G	F#INIT	= 000006	I#AU	= 000041
BIT01	= 000002 G	C#ERSF	= 000054	EVL	= 000004 G	F#JMP	= 000050	I#AUTO	= 000041
BIT02	= 000004 G	C#ERSO	= 000057	EXP	002530 G	F#MOD	= 000000	I#CLN	= 000041
BIT03	= 000010 G	C#ESCA	= 000010	EXPECT	002354 G	F#MSG	= 000011	I#DU	= 000041
BIT04	= 000020 G	C#ESEG	= 000005	EXQBA	002370 G	F#PROT	= 000021	I#HRD	= 000041
BIT05	= 000040 G	C#ESUB	= 000003	EXQCMD	002354 G	F#PWR	= 000017	I#INIT	= 000041
BIT06	= 000100 G	C#ETST	= 000001	EXQCTL	002362 G	F#RPT	= 000012	I#MOD	= 000040
BIT07	= 000200 G	C#EXIT	= 000032	EXQDMA	002364 G	F#SEG	= 000003	I#MSG	= 000041
BIT08	= 000400 G	C#GETB	= 000026	EXQINT	002360 G	F#SOFT	= 000005	I#PROT	= 000040
BIT09	= 001000 G	C#GETW	= 000027	EXQINT0	002374 G	F#SRV	= 000010	I#PTAB	= 000041
BIT1	= 000002 G	C#GMAN	= 000043	EXQMT1	002376 G	F#SUB	= 000002	I#PWR	= 000041
BIT10	= 002000 G	C#GPHR	= 000042	EXQUBA	002366 G	F#SW	= 000014	I#RPT	= 000041
BIT11	= 004000 G	C#GPLD	= 000030	EXQVAD	002400 G	F#TEST	= 000001	I#SEG	= 000041
BIT12	= 010000 G	C#GPRI	= 000040	EXQVDA	002402 G	GO	= 000001 G	I#SETU	= 000041
BIT13	= 020000 G	C#INIT	= 000011	EXQVNT	002356 G	G#CNT0	= 000200	I#SRV	= 000041
BIT14	= 040000 G	C#INLP	= 000020	EXQMC	002372 G	G#DELH	= 000372	I#SUB	= 000041
BIT15	= 100000 G	C#MANI	= 000050	E#END	= 002100	G#DISP	= 000003	I#TST	= 000041
BIT2	= 000004 G	C#MEM	= 000031	E#LOAD	= 000035	G#EXCP	= 000400	J#JMP	= 000167
BIT3	= 000010 G	C#MSG	= 000023	E10#	013306	G#HILI	= 000002	KISARO	= 172340 G
BIT4	= 000020 G	C#OPEN	= 000034	E39	037066	G#LOLI	= 000001	KISARO	= 172300 G
BIT5	= 000040 G	C#PNTB	= 000014	E40	037346	G#NO	= 000000	LOE	= 040000 G
BIT6	= 000100 G	C#PNTF	= 000017	E41	037640	G#OFFS	= 000400	LOGUNI	002504 G
BIT7	= 000200 G	C#PNTS	= 000016	E42	040206	G#OFSI	= 000376	LOOPBK	002514 G
BIT8	= 000400 G	C#PNTX	= 000015	E43	040544	G#PRMA	= 000001	LOT	= 000010 G
BIT9	= 001000 G	C#QIO	= 000377	E44	041122	G#PRMD	= 000002	L#ACP	002110 G
BOE	= 000400 G	C#RDBU	= 000007	E5#	013334	G#PRML	= 000000	L#APT	002036 G
BRDGFL	002502 G	C#REFG	= 000047	E6#	013372	G#RADA	= 000140	L#AU	015132 G
BRESET	016002	C#RESE	= 000033	FLAG	014170	G#RADB	= 000000	L#AUT	002070 G
BRIDGE	002500 G	C#REVI	= 000003	FOR0	003333 G	G#RADD	= 000040	L#AUTO	015040 G
BRLEVE	002516 G	C#RFLA	= 000021	FOR1	003337 G	G#RADL	= 000120	L#CCP	002106 G
BUILD#	012530	C#RPT	= 000025	FOR10	004261 G	G#RADO	= 000020	L#CLEA	015044 G
CHDACK	= 000001 G	C#SEFG	= 000046	FOR11	004353 G	G#XFER	= 000004	L#CO	002032 G
CHDB	013560	C#SPRI	= 000041	FOR12	004462 G	G#YES	= 000010	L#DEPO	002011 G
CHDBIT	002624 G	C#SVEC	= 000037	FOR13	004466 G	G1	041504	L#DESC	002560 G
CHDPRS	= 004000 G	C#TPRI	= 000013	FOR2	003454 G	G2	041537	L#DESP	002076 G
CONFIG	003244 G	DETAIL	012366	FOR3	003504 G	G3	041572	L#DEVP	002060 G
CONT	015344	DFPTBL	002260 G	FOR4	003552 G	G4	041625	L#DISP	002124 G
CTLB	013624	DIAGMC	= 000000	FOR4.5	003600 G	HELP	= 000000	L#DLY	002116 G
CTLBIT	002771 G	DHAB	013640	FOR5	003670 G	HELP1	011576 G	L#DTP	002040 G
C#AU	= 000052	DHABIT	= 003042 G	FOR5.5	003762 G	HELP2	011645 G	L#DTP	002034 G
C#AUTO	= 000061	DHAWT	= 000002 G	FOR6	004054 G	HIUBM	= 170370 G	L#DU	015122 G
C#BRK	= 000022	DUMP	013230 G	FOR7	004114 G	HOE	= 100000 G	L#DUT	002072 G
C#BSEG	= 000004	EDUMP	013556	FOR8	004154 G	HP1	002544 G	L#DVTY	002554 G
C#BSUB	= 000002	EF.CON	= 000036 G	FOR9	004227 G	HP2	002546 G	L#EF	002052 G
C#CEFG	= 000045	EF.NEW	= 000035 G	FREMEM	002552 G	IBE	= 010000 G	L#ENVI	002044 G
C#CLCK	= 000062	EF.PWR	= 000034 G	FUNC0	= 000004 G	IDU	= 000040 G	L#ETP	002102 G

SYMBOL TABLE

L\$EXP1	002046	G	L10035	020076	G	L10126	035656	MSG19	006006	G	NAMES	002404	G
L\$EXP4	002064	G	L10036	020046	G	L10127	035632	MSG2	004571	G	NEXT	014614	
L\$EXP5	002066	G	L10037	020414	G	L10130	036374	MSG20	006033	G	NO	= 000000	G
L\$HARD	041444	G	L10040	020364	G	L10131	036614	MSG21	006060	G	NO\$CHA	013224	
L\$HIME	002120	G	L10041	020716	G	L10132	036606	MSG22	006125	G	ONEFIL	= 000000	
L\$HPCP	002016	G	L10042	020666	G	L10133	037074	MSG23	006172	G	O\$APTS	= 000000	
L\$HPTP	002022	G	L10043	021242	G	L10134	037064	MSG24	006241	G	O\$AU	= 000000	
L\$HM	002260	G	L10044	021212	G	L10135	037354	MSG25	006267	G	O\$BGNR	= 000001	
L\$ICP	002104	G	L10045	021536	G	L10136	037344	MSG26	006315	G	O\$BGNS	= 000000	
L\$INIT	014466	G	L10046	021506	G	L10137	037646	MSG27	006342	G	O\$DU	= 000000	
L\$LADP	002026	G	L10047	022054	G	L10140	037636	MSG28	006367	G	O\$ERRT	= 000000	
L\$LAST	042064	G	L10050	022024	G	L10141	040222	MSG29	006430	G	O\$GNSW	= 000000	
L\$LOAD	002100	G	L10051	022452	G	L10142	040204	MSG3	004632	G	O\$POIN	= 000001	
L\$LUN	002074	G	L10052	022726	G	L10143	040560	MSG30	006471	G	O\$SETU	= 000001	
L\$MREV	002050	G	L10053	022676	G	L10144	040542	MSG31	006532	G	PLOC	002506	G
L\$NAME	002000	G	L10054	023216	G	L10145	041130	MSG32	006573	G	PNT	= 001000	G
L\$PRIO	002042	G	L10055	023166	G	L10146	041120	MSG33	006633	G	PNTMSG	002270	G
L\$PROT	014460	G	L10056	023546	G	L10147	041440	MSG34	006673	G	PRI	= 002000	G
L\$PRT	002112	G	L10057	023516	G	L10150	041436	MSG35	006736	G	PRINTI	013666	
L\$REPP	002062	G	L10060	024144	G	L10151	041504	MSG35	006777	G	PRI00	= 000000	G
L\$REV	002010	G	L10061	024114	G	L10152	042070	MSG36	007023	G	PRI01	= 000040	G
L\$RPT	014446	G	L10062	024544	G	L10154	042100	MSG37	007103	G	PRI02	= 000100	G
L\$SPC	002056	G	L10063	024336	G	L28	030426	MSG38	007172	G	PRI03	= 000140	G
L\$SPCP	002020	G	L10064	024412	G	L34	034462	MSG39	007254	G	PRI04	= 000200	G
L\$SPTP	002024	G	L10065	024466	G	L35	034774	MSG4	004672	G	PRI05	= 000240	G
L\$STA	002030	G	L10066	024542	G	L36	035472	MSG40	007537	G	PRI06	= 000300	G
L\$TEST	002114	G	L10067	025030	G	L37	036034	MSG41	007423	G	PRI07	= 000340	G
L\$TIML	002014	G	L10070	025000	G	L38	036512	MSG42	007520	G	PR\$IE	= 000100	G
L\$UNIT	002012	G	L10071	025330	G	L39	037060	MSG42	007556	G	P1	013720	
L10000	002270		L10072	025300	G	L40	037340	MSG43	007626	G	P2	013772	
L10001	011774		L10073	025604	G	L41	037632	MSG44	007663	G	P37	036372	
L10002	012134		L10074	025554	G	L42	040116	MSG45	007775	G	QBA	002310	G
L10003	012156		L10075	026074	G	L43	040454	MSG46	010077	G	QBA00	= 000001	G
L10004	012244		L10076	026044	G	L44	041032	MSG47	010140	G	QBA01	= 000002	G
L10005	012364		L10077	026376	G	L45	041432	MSG48	010177	G	QBA02	= 000004	G
L10006	014444		L10100	026346	G	MAXUNI	= 000010	MSG49	010247	G	QBA03	= 000010	G
L10007	014456		L10101	026714	G	MEMSIZ	= 002550	MSG5	004731	G	QBA04	= 000020	G
L10011	015036		L10102	026664	G	MES10	012766	MSG50	010337	G	QBA05	= 000040	G
L10012	015042		L10103	027254	G	MES20	013015	MSG51	010407	G	QBA06	= 000100	G
L10013	015120		L10104	027224	G	MES20L	= 000204	MSG52	010477	G	QBA07	= 000200	G
L10014	015130		L10105	027604	G	MIODIS	= 000200	MSG53	010547	G	QBA08	= 000400	G
L10015	015140		L10106	027554	G	M\$INIT	014370	MSG54	010653	G	QBA09	= 001000	G
L10016	016020		L10107	030016	G	M\$RO	= 177572	MSG55	010723	G	QBA10	= 002000	G
L10017	015424		L10110	030014	G	M\$R3	= 172516	MSG56	011012	G	QBA11	= 004000	G
L10020	015506		L10111	030300	G	M\$HALT	= 000100	MSG57	011101	G	QBA12	= 010000	G
L10021	015562		L10112	030276	G	M\$PFL	= 000040	MSG58	011205	G	QBA13	= 020000	G
L10022	015636		L10113	031520	G	M\$RDY	= 001000	MSG59	011274	G	QBA14	= 040000	G
L10023	015712		L10114	031516	G	MSG1	004544	MSG6	004771	G	QBA15	= 100000	G
L10024	015774		L10115	032366	G	MSG10	005161	MSG60	011351	G	CSUS	003316	G
L10025	016256		L10116	033256	G	MSG11	005224	MSG61	011434	G	QCMD	002274	G
L10026	016166		L10117	033562	G	MSG12	005266	MSG62	011521	G	QCMDAD	= 160500	G
L10027	016254		L10120	034024	G	MSG13	005330	MSG7	005012	G	QCTL	002302	G
L10030	016750		L10121	034334	G	MSG14	005373	MSG8	005054	G	QDMA	002304	G
L10031	017256		L10122	034646	G	MSG15	005436	MSG9	005116	G	QINT	002300	G
L10032	017226		L10123	034644	G	MSG16	005531	MT18	013654		QMT0	002314	G
L10033	017602		L10124	035166	G	MSG17	005622	MT18BIT	003161	G	QMT1	002316	G
L10034	017552		L10125	035164	G	MSG18	005715	MVADR	= 000002	G	QNE\$	= 020000	G

SYMBOL TABLE

QUBA	002306	G	QWC08	=	000400	G	TRPFLG	002522	G	T1.5	015640	T26MSG	027606	G					
QUBA00	=	000001	G	QWC09	=	001000	G	T#ARGC	=	000002	T1.6	015714	T26.1	027724					
QUBA01	=	000002	G	QWC10	=	002000	G	T#CODE	=	003032	T10	021304	G	T27	030064	G			
QUBA02	=	000004	G	QWC11	=	004000	G	T#ERRN	=	000002	T10MSG	021244	G	T27MSG	030020	G			
QUBA03	=	000010	G	QWC12	=	010000	G	T#EXCP	=	000000	T10.1	021406	T27.1	030154					
QUBA04	=	000020	G	QWC13	=	020000	G	T#FLAG	=	000040	T11	021600	G	T28	030334	G			
QUBA05	=	000040	G	QWC14	=	040000	G	T#FREE	=	042100	T11MSG	021540	G	T28MSG	030302	G			
QUBA06	=	000100	G	QWC15	=	100000	G	T#GMAN	=	000000	T11.1	021710	T28.1	030424					
QUBA07	=	000200	G	QXAD16	=	000400	G	T#HILI	=	000007	T12	022104	G	T29	031570	G			
QUBA08	=	000400	G	QXAD17	=	001000	G	T#LAST	=	000001	T12MSG	022056	G	T29MSG	031522	G			
QUBA09	=	001000	G	QXAD18	=	002000	G	T#LOLI	=	000000	T13	022502	G	T3	016302	G			
QUBA10	=	002000	G	QXAD19	=	004000	G	T#LSYM	=	010000	T13MSG	022454	G	T3MSG	016260	G			
QUBA11	=	004000	G	QXAD20	=	010000	G	T#LTNO	=	000055	T13.1	022604	T30	032452	G				
QUBA12	=	010000	G	QXAD21	=	020000	G	T#NEST	=	000000	T14	022756	G	T30MSG	032370	G			
QUBA13	=	020000	G	RAM	=	002536	G	T#NSO	=	000000	T14MSG	022730	G	T31	033306	G			
QUBA14	=	040000	G	RDY	=	000200	G	T#NS1	=	000004	T14.1	023066	T31MSG	033260	G				
QUBA15	=	100000	G	RDYIE	=	000100	G	T#NS2	=	000010	T15	023266	G	T32	033620	G			
QVAD	002320	G	RPO	014044	G	RP1	014050	G	T#NS3	=	000003	T15MSG	023220	G	T32MSG	033564	G		
QVAD00	=	000001	G	RP2	014140	G	RP4	014165	G	T#NUM	=	000055	T15.1	023402	T33	034062	G		
QVAD01	=	000002	G	SELDMA	=	000024	G	T#PCNT	=	000000	T16	023616	G	T33MSG	034026	G			
QVAD02	=	000004	G	SELQCM	=	000010	G	T#PTAB	=	010153	T16MSG	023550	G	T34	034362	G			
QVAD03	=	000010	G	SELQCH	=	000004	G	T#PTHV	=	000001	T16.1	023740	T34MSG	034336	G				
QVAD04	=	000020	G	SELQEV	=	000004	G	T#PTNU	=	000001	T17	024174	G	T34.1	034460				
QVAD05	=	000040	G	SELRDD	=	000034	G	T#SAVL	=	177777	T17MSG	024146	G	T35	034674	G			
QVAD06	=	000100	G	SELUBA	=	000020	G	T#SEGL	=	177777	T17.1	024264	T35MSG	034650	G				
QVAD07	=	000200	G	SELUVA	=	000014	G	T#SEKO	=	010000	T17.2	024340	T35.1	034772					
QVAD08	=	000400	G	SELUVD	=	000030	G	T#SIZE	=	000006	T17.3	024414	T36	035226	G				
QVAD09	=	001000	G	SETUP	014606	SQBA	002340	G	T#SUBN	=	000000	T17.4	024470	T36MSG	035170	G			
QVAD10	=	002000	G	SQBA	002340	G	SQCHD	002324	G	T#TAGL	=	177777	T18	024576	G	T36.1	035326		
QVDA	002322	G	SQCTL	002332	G	SQDMA	002334	G	T#TAGN	=	010155	T18MSG	024546	G	T37	035702	G		
QVDA00	=	000001	G	SQINT	002330	G	SQMT0	002344	G	T#TEMP	=	000004	T18.1	024706	T37MSG	035660	G		
QVDA01	=	000002	G	SQMT1	002346	G	SQUBA	002336	G	T#TEST	=	000055	T19	025062	G	T38	036420	G	
QVDA02	=	000004	G	SQVAD	002350	G	SQVDA	002352	G	T#TSTM	=	177777	T19MSG	025032	G	T38MSG	036376	G	
QVDA03	=	000010	G	SQVDA	002352	G	SQVNT	002326	G	T#TSTS	=	000001	T19.1	025200	T38.1	036510			
QVDA04	=	000020	G	SQMC	002342	G	STATU#	013226		T#AU	=	010015	T2	016050	G	T39	036646	G	
QVDA05	=	000040	G	STORE#	013222	SVCGBL	=	000000	T#AUT	=	010012	T2MSG	016022	G	T39MSG	036616	G		
QVDA06	=	000100	G	SVCINS	=	000000	SVCINS	=	000000	T#CLE	=	010013	T2.1	016110	T4	017012	G		
QVDA07	=	000200	G	SVCSUB	=	000000	SVCINS	=	000000	T#DAT	=	010154	T2.2	016170	T4MSG	016752	G		
QVDA08	=	000400	G	SVCTAG	=	000000	SVCTAG	=	000000	T#DU	=	010014	T20	025360	G	T4.1	017126		
QVDA09	=	001000	G	SVCTST	=	000000	SVCTST	=	000000	T#HAR	=	010151	T20MSG	025332	G	T40	037126	G	
QVDA10	=	002000	G	S#LSYM	=	010000	TABLE3	036362	T#HM	=	010000	T20.1	025462	T40MSG	037076	G			
QVDA11	=	004000	G	TE#	=	000002	TIME.5	=	000000	T#INI	=	010011	T21	025634	G	T41	037404	G	
QVDA12	=	010000	G	TIME.5	=	000000	G	T#MSG	=	010005	T#PC	=	000001	T21MSG	025606	G	T41MSG	037356	G
QVDA13	=	020000	G	TIME1	=	000004	G	T#PRO	=	010010	T#PTA	=	010153	T21.1	025744	T42	037704	G	
QVDA14	=	040000	G	TIME2	=	000010	G	T#RPT	=	010007	T#RPT	=	010007	T22	026142	G	T42MSG	037650	G
QVDA15	=	100000	G	TIME4	=	000014	G	T#SEG	=	010000	T#SEG	=	010000	T22MSG	026076	G	T43	040260	G
QVNT	002276	G	THRENB	=	000002	G	TRAP4	014440	G	T#SRV	=	010150	T22.1	026232	T43MSG	040224	G		
QVREN	=	000020	G	TRAP4	014440	G				T#SUB	=	010132	T23	026444	G	T44	040620	G	
QWC	002312	G								T#TES	=	010147	T23MSG	026400	G	T44MSG	040562	G	
QWC00	=	000001	G							T1	015152	G	T23.1	026542	T45	041152	G		
QWC01	=	000002	G							T1MSG	015142	G	T24	027006	G	T45MSG	041132	G	
QWC02	=	000004	G							T1.1	015344	G	T24MSG	026742	G	T5	017320	G	
QWC03	=	000010	G							T1.2	015426	G	T24.1	027116	T5MSG	017260	G		
QWC04	=	000020	G							T1.3	015510	G	T25	027322	G	T5.1	017436		
QWC05	=	000040	G							T1.4	015564	G	T25MSG	027256	G	T6	017644	G	
QWC06	=	000100	G										T25.1	027440	T6MSG	017604	G		
QWC07	=	000200	G										T26	027652	G	T6.1	017746		

SYMBOL TABLE

T7	020140 G	T9.1	021076	VALUE	002540 G	WDTRST=	000001 G	X\$TRUE=	000020
T7MSG	020100 G	UAM	= 000200 G	VALUES	002324 G	WDT0	= 000004 G	YES	= 000001 G
T7.1	020250	UBUS	= 003324 G	VEC	= 000500 G	WDT1	= 000010 G	\$HLP	014172 G
T8	020456 G	UNEX	= 040000 G	VECTOR	002512 G	WSPACE=	020040 G	\$HLPFO	014362 G
T8MSG	020416 G	UPWRFL=	010000 G	VNTACK=	002000 G	X\$	013510	\$MESLN	014364
T8.1	020566	UXAD16=	000020 G	VNTB	013574	X\$ALWA=	000000	\$PATCH	041660 G
T9	020760 G	UXAD17=	000040 G	VNTBIT	002657 G	X\$FALS=	000040	\$STORE	014366
T9MSG	020720 G	VAL	002526 G	VNTPRS=	000001 G	X\$OFFS=	000400		

. ABS. 042100 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 29816 WORDS (117 PAGES)

DYNAMIC MEMORY: 20060 WORDS (77 PAGES)

ELAPSED TIME: 00:12:57

ZFPAA0.BIC.CZFPAA0/-SP=SVC/ML,ZFPAA01,ZFPAA02,ZFPAA03,ZFPAA04,ZFPAA05,ZFPAA06