

KDJ11-A

KDJ11 FPP DIAG
CZKDLB0

COPYRIGHT (c) 1983-84

AH-T709B-MC

FICHE 01 OF 01

JUL 1984

digital

Made In USA

This microfiche card contains a grid of 14 columns and 16 rows of frames. Each frame contains a small, illegible image or document snippet. The frames are arranged in a regular grid pattern across the card.

14 15 16

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38

.REM &

IDENTIFICATION

PRODUCT CODE: AC-T708B-MC
PRODUCT NAME: CZKDLBO KDJ11 FLOATING POINT DIAGNOSTIC
PRODUCT DATE: 15-MAR-84
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHORS: HENRY ENMAN, JIM PITTMAN, BARRY IRRGANG

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1983, 1984 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

&

39
40
41
42
43
44
45
46
47
48
49
50
51

HISTORY

.REM &

OCT-83 REV. A
FEB-84 REV. B

- FIRST RELEASE
CORRECTIONS MADE TO:
1. CORRECT VECTOR AREA MAINTENANCE PROBLEM
2. TURN CACHE MEMORY SYSTEM OFF DURING NON-CACHE TESTS.
3. ENSURE THAT CPU ERROR REGISTER IS CLEARED AFTER
COMPLETION OF TEST THAT MIGHT CAUSE IT TO BE SET.
4. SAVE PC AND CONTENTS OF R6 ON UNEXPECTED INTERRUPTS

&

52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70

.REM E

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
3.0	ERROR INFORMATION

E

.REM E

71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS IS AN APT COMPATIBLE VERSION OF THE KDJ11 FLOATING POINT INSTRUCTION TESTS. IT FOCUSES ON TESTING THE KDJ11 FLOATING POINT INSTRUCTION FUNCTIONALITY.

1.2 SYSTEM REQUIREMENTS

KDJ11-A PROCESSOR MODULE
ENSURE THAT HALT TRAP OPTION IS DISABLED (JUMPER W9 INSTALLED)
32KW MEMORY
Q-22 BACKPLANE (18 BIT QBUS MAY BE USED WITH REDUCED TEST COVERAGE)
SERIAL LINE UNIT AND CONSOLE TERMINAL (CONSOLE TERMINAL NOT REQUIRED FOR APT)

1.3 RELATED DOCUMENTS AND STANDARDS

KDJ11-A MODULE SPECIFICATION REV 2.2
PDP11 MAINDEC SYSMAC PACKAGE
J11 CONTROL CHIP SPECIFICATION 21-17679-00
J11 DATA CHIP SPECIFICATION 21-17677-00

1.4 DIAGNOSTIC HIERARCY PREREQUISITES

THE KDJ11 CPU AND MEMORY MANAGEMENT DIAGNOSTICS MUST RUN SUCCESSFULLY PRIOR TO RUNNING THE FLOATING POINT TESTS.

1.5 ASSUMPTIONS

IT IS ASSUMED THAT THE DIAGNOSTIC OPERATOR IS FAMILIAR WITH THE XXDP+ OPERATING SYSTEM AND THE J11 MICRO-ODT.

2.0 OPERATING INSTRUCTIONS

2.1 LOADING AND STARTING PROCEEDURE

LOAD PROGRAM INTO MEMORY USING STANDARD XXDP+ PROCEEDURES. THE PROGRAM IS STARTED BY LOADING ADDRESS 200 AND USING THE J11 MICRO-ODT G COMMAND TO START. THE PROGRAM IDENTIFICATION MESSAGE WILL BE TYPED AFTER THE FIRST PASS OF THE COMPLETE PROGRAM.

2.2 PROGRAM OPTIONS

THE FOLLOWING ASSIGNMENTS HAVE BEEN MADE FOR THE KDJ11-A DIAGNOSTIC SWITCH REGISTER BITS:

BIT#15	14	13	12	11	10	9	8
-----*							*
					DON'T	18 BIT	EXTENDED
					TEST	ADDRESS	CACHE
					BEVENT	ONLY	TESTS

127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155

THE SOFTWARE SWITCH REGISTER HAS NO EFFECT ON THE OPERATION OF THIS DIAGNOSTIC.

2.3 OPERATION UNDER APT

THERE ARE NO ABNORMALITIES IN THE EXECUTION OF THIS DIAGNOSTIC WHEN OPERATING IN AN APT ENVIRONMENT. PROBLEMS CAUSED BY THE ASYNCHRONOUS HALTS OF THE DIAGNOSTIC BY THE APT MONITOR HAVE NOT BEEN NOTED.

3.0 ERROR INFORMATION

ERRORS WILL CAUSE THE FOLLOWING ERROR MESSAGE TO BE PRINTED:

ERROR DURING FPP TESTING
ERROR # = (UNIQUE ERROR NUMBER)
ERROR PC = (PC AT TIME OF ERROR)

THE ERROR WILL THEN BE REPORTED TO APT AND THE PROGRAM WILL HALT.

4.0 PROGRESS REPORT

AT THE END OF EACH PASS THE DIAGNOSTIC NAME AND PASS COUNT ARE PRINTED.

156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176

```
.TITLE PROGRAM HEADER AND TABLES  
.SBTTL PROGRAM HEADER  
  
.MCALL NEWTST,ERRDEF,,EQUAT,,KT11,,$40CAT,,$EOP,,$APTBL$ SETUP  
.MCALL .$TYPE,,$TYPDEC,ERRDF,BGNTST,ENDTST,BGNMOD,ENDMOD,CKLOOP  
.MCALL .HEADER,,SETUP,,$TRAP,BGNSUB,ENDSUB,,$ACT11,,$APTHDR  
.MCALL .$ATYPE,,$ERROR,,$TYPOCT,,$READ
```

```
.TITLE KDJ11-A FLOATING POINT DIAGNOSTIC  
:*COPYRIGHT (C) OCTOBER,1983  
:*DIGITAL EQUIPMENT CORP.  
:*MAYNARD, MASS. 01754  
:*  
:*  
:*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC  
:*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.  
:*  
$TN=1  
$SWR=160000 ;;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
```

000001
160000

```

177 .TITLE GLOBAL AREAS
178 .SBTTL GLOBAL EQUATES SECTION
179
180 ***
181 ; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
182 ; ARE USED IN MORE THAN ONE TEST.
183 ;--
184 .SBTTL BASIC DEFINITIONS
185
186 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1000 ***
187 001000 STACK= 1000
188 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
189 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
190
191 ;*MISCELLANEOUS DEFINITIONS
192 000011 MT= 11 ;;CODE FOR HORIZONTAL TAB
193 000012 LF= 12 ;;CODE FOR LINE FEED
194 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
195 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
196 177776 PS= 177776 ;;PROCESSOR STATUS WORD
197 .EQUIV PS,PSW
198 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
199 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
200 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
201 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
202
203 ;*GENERAL PURPOSE REGISTER DEFINITIONS
204 000000 R0= %0 ;;GENERAL REGISTER
205 000001 R1= %1 ;;GENERAL REGISTER
206 000002 R2= %2 ;;GENERAL REGISTER
207 000003 R3= %3 ;;GENERAL REGISTER
208 000004 R4= %4 ;;GENERAL REGISTER
209 000005 R5= %5 ;;GENERAL REGISTER
210 000006 R6= %6 ;;GENERAL REGISTER
211 000007 R7= %7 ;;GENERAL REGISTER
212 000006 SP= %6 ;;STACK POINTER
213 000007 PC= %7 ;;PROGRAM COUNTER
214
215 ;*PRIORITY LEVEL DEFINITIONS
216 000000 PRO= 0 ;;PRIORITY LEVEL 0
217 000040 PR1= 40 ;;PRIORITY LEVEL 1
218 000100 PR2= 100 ;;PRIORITY LEVEL 2
219 000140 PR3= 140 ;;PRIORITY LEVEL 3
220 000200 PR4= 200 ;;PRIORITY LEVEL 4
221 000240 PR5= 240 ;;PRIORITY LEVEL 5
222 000300 PR6= 300 ;;PRIORITY LEVEL 6
223 000340 PR7= 340 ;;PRIORITY LEVEL 7
224
225 ;*"SWITCH REGISTER" SWITCH DEFINITIONS
226 100000 SW15= 100000
227 040000 SW14= 40000
228 020000 SW13= 20000
229 010000 SW12= 10000
230 004000 SW11= 4000
231 002000 SW10= 2000
232 001000 SW09= 1000

```



```

233      000400      SW08= 400
234      000200      SW07= 200
235      000100      SW06= 100
236      000040      SW05= 40
237      000020      SW04= 20
238      000010      SW03= 10
239      000004      SW02= 4
240      000002      SW01= 2
241      000001      SW00= 1
242      .EQUIV      SW09,SW9
243      .EQUIV      SW08,SW8
244      .EQUIV      SW07,SW7
245      .EQUIV      SW06,SW6
246      .EQUIV      SW05,SW5
247      .EQUIV      SW04,SW4
248      .EQUIV      SW03,SW3
249      .EQUIV      SW02,SW2
250      .EQUIV      SW01,SW1
251      .EQUIV      SW00,SW0
252
253      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
254      100000      BIT15= 100000
255      040000      BIT14= 40000
256      020000      BIT13= 20000
257      010000      BIT12= 10000
258      004000      BIT11= 4000
259      002000      BIT10= 2000
260      001000      BIT09= 1000
261      000400      BIT08= 400
262      000200      BIT07= 200
263      000100      BIT06= 100
264      000040      BIT05= 40
265      000020      BIT04= 20
266      000010      BIT03= 10
267      000004      BIT02= 4
268      000002      BIT01= 2
269      000001      BIT00= 1
270      .EQUIV      BIT09,BIT9
271      .EQUIV      BIT08,BIT8
272      .EQUIV      BIT07,BIT7
273      .EQUIV      BIT06,BIT6
274      .EQUIV      BIT05,BIT5
275      .EQUIV      BIT04,BIT4
276      .EQUIV      BIT03,BIT3
277      .EQUIV      BIT02,BIT2
278      .EQUIV      BIT01,BIT1
279      .EQUIV      BIT00,BIT0
280
281      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
282      000004      ERRVEC= 4          ;;TIME OUT AND OTHER ERRORS
283      000010      RESVEC= 10         ;;RESERVED AND ILLEGAL INSTRUCTIONS
284      000014      TBITVEC= 14        ;; "T" BIT
285      000014      TRTVEC= 14         ;;TRACE TRAP
286      000014      BPTVEC= 14         ;;BREAKPOINT TRAP (BPT)
287      000020      IOTVEC= 20         ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
288      000024      PWRVEC= 24         ;;POWER FAIL

```

```

289      000030      EMTVEC= 30      ;;EMULATOR TRAP (EMT) **ERROR**
290      000034      TRAPVEC=34      ;;"TRAP" TRAP
291      000060      TKVEC= 60      ;;TTY KEYBOARD VECTOR
292      000064      TPVEC= 64      ;;TTY PRINTER VECTOR
293      000240      PIRQVEC=240      ;;PROGRAM INTERRUPT REQUEST VECTOR
294      .SBTTL      MEMORY MANAGEMENT DEFINITIONS
295
296      ;*KT11 VECTOR ADDRESS
297
298      000250      MMVEC= 250
299
300      ;*KT11 STATUS REGISTER ADDRESSES
301
302      177572      SR0= 177572
303      177574      SR1= 177574
304      177576      SR2= 177576
305      172516      SR3= 172516
306
307      ;*USER "I" PAGE DESCRIPTOR REGISTERS
308
309      177600      UIPDR0= 177600
310      177602      UIPDR1= 177602
311      177604      UIPDR2= 177604
312      177606      UIPDR3= 177606
313      177610      UIPDR4= 177610
314      177612      UIPDR5= 177612
315      177614      UIPDR6= 177614
316      177616      UIPDR7= 177616
317
318      ;*USER "D" PAGE DESCRIPTOR REGISTORS
319
320      177620      UDPDR0= 177620
321      177622      UDPDR1= 177622
322      177624      UDPDR2= 177624
323      177626      UDPDR3= 177626
324      177630      UDPDR4= 177630
325      177632      UDPDR5= 177632
326      177634      UDPDR6= 177634
327      177636      UDPDR7= 177636
328
329      ;*USER "I" PAGE ADDRESS REGISTERS
330
331      177640      UIPAR0= 177640
332      177642      UIPAR1= 177642
333      177644      UIPAR2= 177644
334      177646      UIPAR3= 177646
335      177650      UIPAR4= 177650
336      177652      UIPAR5= 177652
337      177654      UIPAR6= 177654
338      177656      UIPAR7= 177656
339
340      ;*USER "D" PAGE ADDRESS REGISTERS
341
342      177660      UDPAR0= 177660
343      177662      UDPAR1= 177662
344      177664      UDPAR2= 177664

```

345	177666	UDPAR3= 177666
346	177670	UDPAR4= 177670
347	177672	UDPAR5= 177672
348	177674	UDPAR6= 177674
349	177676	UDPAR7= 177676
350		
351		;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
352		
353	172200	SIPDR0= 172200
354	172202	SIPDR1= 172202
355	172204	SIPDR2= 172204
356	172206	SIPDR3= 172206
357	172210	SIPDR4= 172210
358	172212	SIPDR5= 172212
359	172214	SIPDR6= 172214
360	172216	SIPDR7= 172216
361		
362		;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
363		
364	172220	SDPDR0= 172220
365	172222	SDPDR1= 172222
366	172224	SDPDR2= 172224
367	172226	SDPDR3= 172226
368	172230	SDPDR4= 172230
369	172232	SDPDR5= 172232
370	172234	SDPDR6= 172234
371	172236	SDPDR7= 172236
372		
373		;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
374		
375	172240	SIPAR0= 172240
376	172242	SIPAR1= 172242
377	172244	SIPAR2= 172244
378	172246	SIPAR3= 172246
379	172250	SIPAR4= 172250
380	172252	SIPAR5= 172252
381	172254	SIPAR6= 172254
382	172256	SIPAR7= 172256
383		
384		;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
385		
386	172260	SDPAR0= 172260
387	172262	SDPAR1= 172262
388	172264	SDPAR2= 172264
389	172266	SDPAR3= 172266
390	172270	SDPAR4= 172270
391	172272	SDPAR5= 172272
392	172274	SDPAR6= 172274
393	172276	SDPAR7= 172276
394		
395		;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
396		
397	172300	KIPDR0= 172300
398	172302	KIPDR1= 172302
399	172304	KIPDR2= 172304
400	172306	KIPDR3= 172306

```

401      172310      KIPDR4= 172310
402      172312      KIPDR5= 172312
403      172314      KIPDR6= 172314
404      172316      KIPDR7= 172316
405
406      ;*KERNEL "D" PAGE DESCRIPTOR REGISTERS
407
408      172320      KDPDR0= 172320
409      172322      KDPDR1= 172322
410      172324      KDPDR2= 172324
411      172326      KDPDR3= 172326
412      172330      KDPDR4= 172330
413      172332      KDPDR5= 172332
414      172334      KDPDR6= 172334
415      172336      KDPDR7= 172336
416
417      ;*KERNEL "I" PAGE ADDRESS REGISTERS
418
419      172340      KIPAR0= 172340
420      172342      KIPAR1= 172342
421      172344      KIPAR2= 172344
422      172346      KIPAR3= 172346
423      172350      KIPAR4= 172350
424      172352      KIPAR5= 172352
425      172354      KIPAR6= 172354
426      172356      KIPAR7= 172356
427
428      ;*KERNEL "D" PAGE ADDRESS REGISTERS
429
430      172360      KDPAR0= 172360
431      172362      KDPAR1= 172362
432      172364      KDPAR2= 172364
433      172366      KDPAR3= 172366
434      172370      KDPAR4= 172370
435      172372      KDPAR5= 172372
436      172374      KDPAR6= 172374
437      172376      KDPAR7= 172376
438
439      ;THESE ARE FLOATING POINT ACCUMULATOR EQUATES
440      000000      AC0= #0
441      000001      AC1= #1
442      000002      AC2= #2
443      000003      AC3= #3
444      000004      AC4= #4
445      000005      AC5= #5
446      000006      AC6= #6
447      000007      AC7= #7
448
449      000244      FPVEC= 244
450
451      ;THESE ARE CACHE REGISTER EQUATES
452      177746      CCR= 177746 ;CACHE CONTROL REGISTER
453      177744      MSER= 177744 ;MEMORY SYSTEM ERROR REGISTER
454      177752      HITMIS= 177752 ;HIT/MISS REGISTER
455      177766      CPereg= 177766 ;CPU ERROR REGISTER
456

```

```

457                                     ;MISCELLANEOUS DEFINITIONS
458      177546      BEVENT= 177546      ;BEVENT CONTROL REGISTER
459      177560      RCSR= 177560
460      177562      RBUF= 177562
461      177564      XCSR= 177564
462      177566      XBUF= 177566
463      000000      ERRTN= HALT
464      000001      $TSTNU=1
465      000001      ERRNUM= 1      ;INITIALIZE ERROR NUMBER COUNTER
466      002000      AUSWR= 2000      ;SWR FOR APT--NO BEVENT TESTING
467
468
469                                     ;THIS EQUATE DEFINES THE BOTTOM OF THE PROGRAM STACK POINTER
470      001000      STBOT= 1000
471      000000      .ASECT
472      .SBTTL TRAP CATCHER
473
474      000000      .=0
475                                     ;*ALL UNUSED LOCATIONS OF THE VECTOR AREA CONTAIN
476                                     ;*A ".+2, IOT" SEQUENCE TO CATCH AND PROCESS ILLEGAL
477                                     ;*TRAPS AND INTERRUPTS THAT MIGHT OCCUR.
478                                     ;*THE IOT TRAP WHICH IS TAKEN ON THE ILLEGAL TRAP/INT
479                                     ;*TRAPS TO THE $SCOPE ROUTINE WHICH (IF THE RETURN PC IS
480                                     ;*LESS THAN 1002) JUMPS TO THE $ERROR ROUTINE.
481                                     ;*THE $ERROR ROUTINE WILL REPORT THE ERROR AS FOLLOWS:
482                                     ;*
483                                     ;* PC=YYYYYY UNEXPECTED TRAP TO XXX
484                                     ;*AND RETURN TO THE PROGRAM AT PC=YYYYYY+2
485                                     ;*WHERE XXX=LOCATION OF ILLEGAL TRAP
486                                     ;* YYYYYY=PC AT TIME OF TRAP
487                                     ;*NOTE: IF THE PROCESSOR IS NOT AN 11/05 THE PROGRAM
488                                     ;* CAN BE STARTED AT ADDRESS 0 AS WELL AS ADDRESS 200.
489      000000      000000      $40CAT: HALT      ;;HALT
490      000002      000737      BR      .-100      ;;BRANCH TO 177700 & TIME OUT (NOT ON
491                                     ;;11/05)
492      000004      002200      .WORD START      ;;VECTOR TO STARTING ADDRESS
493      000006      000340      .WORD 340      ;;WITH PRIORITY LEVEL 7
494      000174      000174      .=174
495      000174      000000      DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
496      000176      000000      SWREG: .WORD 0      ;;SOFTWARE SWITCH REGISTER
497      .SBTTL STARTING ADDRESS)
498      000200      000137      002200      JMP @START ;;GO TO START OF PROGRAM
499      .SBTTL ACT11 HOOKS
500
501                                     ;*****
502                                     ;HOOKS REQUIRED BY ACT11
503      000204      $SVPC=.      ;SAVE PC
504      000046      .=46
505      000046      036362      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
506      000052      .=52
507      000052      000000      .WORD 0      ;;2)SET LOC.52 TO ZERO
508      000204      .=$SVPC      ;; RESTORE PC
509      .SBTTL APT PARAMETER BLOCK
510
511                                     ;*****
512                                     ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT

```

```

513
514      000204      ;;*****
515      000024      . $X= .      ;;SAVE CURRENT LOCATION
516 000024 000200    . =24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
517      000044      200      ;;FOR APT START UP
518 000044 000204    . =44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
519      000204      $APTHDR ;;POINT TO APT HEADER BLOCK
520      000204      . = $X      ;;RESET LOCATION COUNTER
521      ;;*****
522      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
523      ;INTERFACE SPEC.
524 000204      $APTHD:
525 000204 000000    $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
526 000206 001000    $MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
527 000210 000001    $TSTM: .WORD 1      ;;RUN TIM OF LONGEST TEST
528 000212 000002    $PASTM: .WORD 2      ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
529 000214 000000    $UNITM: .WORD 0      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
530 000216 000014    .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
531      000204      . = $X      ;SAVE CURRENT LOCATION COUNT
532      000002      . =2
533 000002 000000    0
534 000004 000006    6
535 000006 000004    4      ;SET UP SOME VECTORS
536      000204      . = $X      ;RESTORE LOCATION COUNT
537      001000      . =1000

```

538
539
540
541
542
543
544
545
546
547
548 001000
549 001000 000000
550 001002 000000
551 001004 000000
552 001006 000000
553 001010 000000
554 001012 000000
555 001014 000000
556 001016 000000
557 001020
558 001020 000
559 001021 000
560 001022 000000
561 001024 002000
562 001026 000000
563
564
565
566
567
568
569 001030
570
571
572
573
574
575 001030 000000
576 001032 000000
577
578
579 001034 000000
580 001036 000000
581 001040 000000
582 001042 000000
583 001044 000000
584 001046 177570
585 001050 177570
586 001052 000000
587
588 001054 000000
589 001056 000000
590 001060 000000
591 001062 000000
592 001064 000000
593

.SBTTL GLOBAL DATA SECTION

; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.

.SBTTL APT MAILBOX-ETABLE

```

;*****
.EVEN
$MAIL:                ;; APT MAILBOX
$MSGTY: .WORD  MSGTY  ;; MESSAGE TYPE CODE
$FATAL: .WORD  AFATAL ;; FATAL ERROR NUMBER
$TESTN: .WORD  ATESTN ;; TEST NUMBER
$PASS:  .WORD  APASS  ;; PASS COUNT
$DEVCT: .WORD  ADEVCT ;; DEVICE COUNT
$UNIT:  .WORD  AUNIT  ;; I/O UNIT NUMBER
$MSGAD: .WORD  AMSGAD ;; MESSAGE ADDRESS
$MSGLG: .WORD  AMSGLG ;; MESSAGE LENGTH
$ETABLE:                ;; APT ENVIRONMENT TABLE
$ENV:   .BYTE  AENV   ;; ENVIRONMENT BYTE
$ENVM:  .BYTE  AENVM  ;; ENVIRONMENT MODE BITS
$SWREG: .WORD  ASWREG ;; APT SWITCH REGISTER
$USWR:  .WORD  AUSWR  ;; USER SWITCHES
$CPUOP: .WORD  ACPUOP ;; CPU TYPE, OPTIONS
; *
; *                               11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
; *                               11/70=06,PDQ=07,Q=10
; *                               BIT 10-REAL TIME CLOCK
; *                               BIT  9-FLOATING POINT PROCESSOR
; *                               BIT  8-MEMORY MANAGEMENT
$ETEND:
.MEXIT

```

; THESE LOCATIONS ARE USED IN MORE THAN ONE TEST TO STORE VECTOR DATA
; WHEN THE TEST NEEDS TO HAVE AN ERROR CONDITION RESPOND DIFFERENTLY
; FROM THE DEFAULT RESPONSE.

SLOC00: .WORD 0
SLOC01: .WORD 0

```

; THESE LOCATIONS ARE USED IN MORE THAN ONE TEST TO STORE WORKING DATA.
EXPDAT: .WORD  0                ; STORES EXPECTED (GOOD) DATA FOR COMPARISONS
RECDAT: .WORD  0                ; STORES RECIEVED DATA TO BE VERIFIED
COUNT: .WORD  0                ; ERROR INDICATOR FOR FLOATING POINT TESTS
FLAG:   .WORD  0                ; USED TO STORE "FLAG" CONDITIONS
ERRCNT: .WORD  0                ; STORAGE FOR ERROR COUNT
SWR:    .WORD  DSWR             ; STORAGE FOR SWITCH REGISTER ADDRESS
DISPLAY: .WORD  DDISP           ; STORAGE FOR DISPLAY REGISTER ADDRESS
$ERFLG: .WORD  0                ; ERROR FLAG

```

; THESE LOCATIONS ARE USED BY MORE THAN ONE TEST AS LOOP COUNTERS

DCOUNT: .WORD 0
ALLCTR: .WORD 0
LOOPIN: .WORD 0
SAVSP1: .WORD 0
SAVSP2: .WORD 0

; STORAGE FOR UNEXPECTED TRAP DATA
; " " " " " "

594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609

001066 000004
001076 000004
001106 000004
001116 000004
001126 000004

001136
001136 000020

BTEXP: .BLKW 4
BTRES: .BLKW 4
RECFEC: .BLKW 4
RECST: .BLKW 4
RECDST: .BLKW 4

; STORES EXPONENT DURING BIT TESTS
; STORES RECIEVED DATA FOR BIT TESTS
; RECIEVED FLOATING POINT EXCEPTION CODE
; RECIEVED FLOATING POINT STATUS
; DESTINATION ADDRESS FOR FLOATING POINT TESTS

!!!!!!THIS IS IT. THE PROGRAM TEST LOCATION AND WRITE BUFFER!!!!!!!!!!!!!!!!!!!!!!
TSTLOC: .BLKW 20

610	001176	123456			TAB1:	.WORD	123456
611	001200	000000				.WORD	000000
612	001202	000000				.WORD	0
613	001204	000001				.WORD	1
614	001206	055555			TAB2:	.WORD	055555
615	001210	177777				.WORD	177777
616	001212	145671				.WORD	145671
617	001214	100000				.WORD	100000
618	001216	003000			TAB3:	.WORD	003000
619	001220	123456				.WORD	123456
620	001222	000000				.WORD	0
621	001224	000000				.WORD	0
622	001226	055555			TAB4:	.WORD	55555
623	001230	177777				.WORD	-1
624	001232	000000				.WORD	0
625	001234	000000				.WORD	0
626	001236	043243			TAB5:	.WORD	43243
627	001240	000000				.WORD	0
628	001242	000000				.WORD	0
629	001244	000000				.WORD	0
630	001246	162400			TAB5A:	.WORD	162400
631	001250	000000				.WORD	0
632	001252	000000				.WORD	0
633	001254	000000				.WORD	0
634	001256	000000			TAB6:	.WORD	0
635	001260	000000				.WORD	0
636	001262	000000				.WORD	0
637	001264	000000				.WORD	0
638	001266	047050			TAB6A:	.WORD	47050
639	001270	010000				.WORD	10000
640	001272	000000				.WORD	0
641	001274	000000				.WORD	0
642	001276	000200			TAB7:	.WORD	200
643	001300	000000				.WORD	0
644	001302	000000				.WORD	0
645	001304	000000				.WORD	0
646	001306	000200			TAB8:	.WORD	200
647	001310	000000				.WORD	0
648	001312	000000				.WORD	0
649	001314	000001				.WORD	1
650	001316	000400	000000	000000	TAB9:	.WORD	400.0.0.0
651	001324	000000					
652	001326	030000			TAB10:	.WORD	30000
653	001330	003000				.WORD	3000
654	001332	000000				.WORD	0
655	001334	000000				.WORD	0
656	001336	016400			TAB11:	.WORD	16400
657	001340	000000				.WORD	0
658	001342	000000				.WORD	0
659	001344	000000				.WORD	0
660	001346	030000	003000	000002	TAB11A:	.WORD	30000.3000.2.0
661	001354	000000					
662	001356	016100	000000	000000	TAB12:	.WORD	16100.0.0.1
663	001364	000001					
664	001366	016200			TAB13:	.WORD	16200
665	001370	000000				.WORD	0

666	001372	000000				.WORD	0
667	001374	000001				.WORD	1
668	001376	030000	003000	000000	TAB13B:	.WORD	30000,3000,0,140000
669	001404	140000					
670	001406	030000			TAB14:	.WORD	30000
671	001410	000000				.WORD	0
672	001412	000000				.WORD	0
673	001414	000000				.WORD	0
674	001416	024700			TAB15:	.WORD	24700
675	001420	000000				.WORD	0
676	001422	000000				.WORD	0
677	001424	000000				.WORD	0
678	001426	025000			TAB16:	.WORD	25000
679	001430	175363				.WORD	175363
680	001432	123456				.WORD	123456
681	001434	123456				.WORD	123456
682	001436	030000			TAB17:	.WORD	30000
683	001440	007020				.WORD	7020
684	001442	000000	000000			.WORD	0,0
685	001446	023456			TAB18:	.WORD	23456
686	001450	000000				.WORD	0
687	001452	000000				.WORD	0
688	001454	000001				.WORD	1
689	001456	100200	000000	000000	TAB21:	.WORD	100200,0,0,0
690	001464	000000					
691	001466	100400	000000	000000	TAB22:	.WORD	100400,0,0,0
692	001474	000000					
693	001476	000200	000000	000000	TAB23:	.WORD	200,0,0,1
694	001504	000001					
695	001506	062400	000000	000000	TAB24:	.WORD	62400,0,0,0
696	001514	000000					
697	001516	001100	000000	000000	TAB25:	.WORD	1100,0,0,0
698	001524	000000					
699	001526	100600	000000	000000	TAB26:	.WORD	100600,0,0,0
700	001534	000000					
701	001536	001000	000000	000000	TAB27:	.WORD	1000,0,0,0
702	001544	000000					
703	001546	000600	000000	000000	TAB28:	.WORD	600,0,0,0
704	001554	000000					
705	001556	010100	000000	000000	TAB29:	.WORD	10100,0,0,0
706	001564	000000					
707	001566	010100	000000	002000	TAB29A:	.WORD	10100,0,2000,0
708	001574	000000					
709							
710	001576	000500	000000	000000	TAB30:	.WORD	500,0,0,0
711	001604	000000					
712	001606	100400	000000	000000	TAB31:	.WORD	100400,0,0,0
713	001614	000000					
714	001616	016000	000000	000000	TAB32:	.WORD	16000,0,0,0
715	001624	000000					
716	001626	011600	000000	000000	TAB33:	.WORD	11600,0,0,0
717	001634	000000					
718	001636	000640	000000	000000	TAB34:	.WORD	640,0,0,0
719	001644	000000					
720	001646	077600	000000	000000	TAB40:	.WORD	77600,0,0,0
721	001654	000000					

GLOBAL AREAS MACY11 30A(1052) 15-MAR-84 16:58 PAGE 18
KDJ11A.MAC 15-MAR-84 15:51 APT MAILBOX-ETABLE

SEQ 0018

722	001656	100200	000000	000000	TAB41: .WORD	100200,0,0,1
723	001664	000001				
724	001666	000340	000000	000000	TAB42: .WORD	340,0,0,0
725	001674	000000				
726	001676	000077	177777	177777	TAB43: .WORD	77,177777,177777,177776
727	001704	177776				
728	001706	000577	177777	177777	TAB45: .WORD	577,-1,-1,-1
729	001714	177777				
730	001716	000577	177777	000000	TAB46: .WORD	577,-1,0,0
731	001724	000000				
732	001726	173737	124242	052525	TAB47: .WORD	173737,124242,052525,12346
733	001734	012346				
734	001736	000000	000000	052525	TAB47A: .WORD	0,0,052525,12346
735	001744	012346				
736	001746	173737	124242	000000	TAB48: .WORD	173737,124242,0,0
737	001754	000000				
738	001756	000600	000000	000000	TAB49: .WORD	600,0,0,0
739	001764	000000				

```

740 .SBTTL GLOBAL TEXT SECTION
741
742 ;++
743 ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
744 ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
745 ; MORE THAN ONE TEST.
746 ;--
747
748 ;
749 ; FORMAT STATEMENTS USED IN PRINT CALLS
750 ;
751
752 001766 005015 040503 044103 ERRMSG: .ASCIZ <CR><LF>/CACHE SYSTEM ERROR/
753 001774 020105 054523 052123
754 002002 046505 042440 051122
755 002010 051117 000
756 002013 015 042412 051122 FPPERR: .ASCIZ <CR><LF>/ERROR DURING FPP TESTING/
757 002020 051117 042040 051125
758 002026 047111 020107 050106
759 002034 020120 042524 052123
760 002042 047111 000107
761 002046 005015 051105 047522 ERR1: .ASCIZ <CR><LF>/ERROR # =/
762 002054 020122 020043 000075
763 002062 005015 051105 047522 ERR2: .ASCIZ <CR><LF>/ERROR PC =/
764 002070 020122 041520 036440
765 002076 000
766 002077 015 020012 020040 $CRLF: .ASCIZ <CR><LF>/ /
767 002104 000
768 002106 .EVEN

```

GLOBAL ERROR REPORT SECTION

769
770
771
772
773
774
775

.SBTTL GLOBAL ERROR REPORT SECTION

;++
: THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
: USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION.
:--

```

776      .SBTTL GLOBAL SUBROUTINES SECTION
777
778      ;++
779      ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
780      ; THAT ARE USED IN MORE THAN ONE TEST.
781      ;--
782      ;FPP COMMON SUBROUTINES
783      002106 012600 WLDTRP: MOV      (SP)+,R0      ;SAVE PC
784      002110 012605      MOV      (SP)+,R5      ;SAVE STATUS AND RESTORE STACK
785      002112 104000      ERROR      ;ALL ERRORS TO TRAP TO EMT VECTOR
786      002114 000001      .WORD    1          ;UNIQUE ERROR NUMBER
787      002116 002013      .WORD    FPPERR      ;ADDRESS OF ERROR MESSAGE
788      002120 000110      JMP      (R0)        ;GO BACK INLINE
789
790      ;
791      ;
792      002122 000000 TRPFLG: .WORD    0
793      002124 000207 ERRFP:  RTS      R7
794      002126 000207 ERR:   RTS      R7
795      ;
796      ;
797      ;
798      ;
799      ;
800      ;SUBROUTINE DATA VERIFICATION -
801      ;
802      ; CALLED BY      JSR      R7,DATVER
803      ;
804      ;INPUT:          (R4)=EXPECTED DATA
805      ;                (R1)=RECEIVED DATA
806      ;
807      ; THIS ROUTINE VERIFIES THAT THE 4 CONSECUTIVE WORDS STARTING WITH (R4) ARE
808      ; EQUAL TO THE FOUR WORDS ADDRESSED BY (R1). THE CONTENTS OF R4, AND R1 ARE NOT
809      ; DISTURBED.
810      ; LOCATION "COUNT" . IF NOT EQUAL TO 0 SIGNIFIES DATA ERROR
811      ; IF THE STATUS IS FLOATING MODE, THE LAST TWO BYTES OF RECEIVED
812      ; ARE SIMPLY CHECKED FOR ZEROS
813      ;
814      ;
815      002130 010446 DATVFR: MOV      R4,-(SP)      ;SAVE R4
816      002132 010146      MOV      R1,-(SP)      ;SAVE R1
817      002134 012767 000003 176676      MOV      #3,COUNT      ;SET UP ITERATION COUNT
818      002142 000167 000012      JMP      DAT1
819      ;
820      ;
821      002146 010446 DATVER: MOV      R4,-(SP)      ;SAVE R4
822      002150 010146      MOV      R1,-(SP)      ;SAVE R1
823      002152 012767 000005 176660      MOV      #5,COUNT      ;SET UP ITERATION COUNT
824      002160 005367 176654 DAT1:  DEC      COUNT
825      002164 001402      BEQ      2$
826      002166 022421      CMP      (R4)+,(R1)+
827      002170 001773      BEQ      DAT1
828      002172 012601      2$:  MOV      (SP)+,R1
829      002174 012604      MOV      (SP)+,R4
830      002176 000207      RTS      R7
      ;RESTORE R1
      ;RESTORE R4
      ;GO BACK TO CALLING ROUTINE
      ;IF DATA ERROR, COUNT NE 0

```

```

831 002200 START:
832 002200 012737 000014 177746 MOV #14,#CCR ;SET CACHE TO FORCE MISS
833 .SBTTL INITIALIZE THE COMMON TAGS
834 002206 012706 001000 MOV #STACK,SP ;;SETUP THE STACK POINTER
835 ;;INITIALIZE A FEW VECTORS
836 002212 012737 040046 000030 MOV #ERROR,#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
837 002220 012737 000340 000032 MOV #340,#EMTVEC+2 ;;LEVEL 7
838 002226 012737 037530 000034 MOV #TRAP,#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
839 002234 012737 000340 000036 MOV #340,#TRAPVEC+2;LEVEL 7
840 002242 005067 176540 CLR $PASS ;;CLEAR THE PASS COUNT
841 002246 016767 034056 034046 MOV $ENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
842 002254 105067 176572 CLRB $ERFLG ;;CLEAR THE ERROR FLAG
843 ;;SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
844 ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
845 002260 013746 000004 MOV #ERRVEC,-(SP) ;;SAVE ERROR VECTOR
846 002264 012737 002320 000004 MOV #64,#ERRVEC ;;SET UP ERROR VECTOR
847 002272 012767 177570 176546 MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
848 002300 012767 177570 176542 MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
849 002306 022777 177777 176532 CMP #-1,#SWR ;;TRY TO REFERENCE HARDWARE SWR
850 002314 001012 BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
851 ;;AND THE HARDWARE SWR IS NOT = -1
852 002316 000403 BR 65$ ;;BRANCH IF NO TIMEOUT
853 002320 012716 002326 64$: MOV #65#,(SP) ;;SET UP FOR TRAP RETURN
854 002324 000002 RTI
855 002326 012767 000176 176512 65$: MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
856 002334 012767 000174 176506 MOV #DISPREG,DISPLAY
857 002342 012637 000004 66$: MOV (SP)+,#ERRVEC ;;RESTORE ERROR VECTOR
858
859 .MACRO $$SETMAIL ?$ARG1
860 CLR $PASS ;;CLEAR PASS COUNT
861 BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
862 BEQ $ARG1 ;;YES,USE NON-APT SWITCH
863 MOV #SWREG,SWR ;;NO,USE APT SWITCH REGISTER
864
865 $ARG1:
866 .ENDM $$SETMAIL
867 002346 005067 176434 CLR $PASS ;;CLEAR PASS COUNT
868 002352 132767 000200 176441 BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
869 002362 012767 001022 176456 BEQ 67$ ;;YES,USE NON-APT SWITCH
870 002370 MOV #SWREG,SWR ;;NO,USE APT SWITCH REGISTER
871 002370 012737 040046 000020 67$: MOV #ERROR,#IOTVEC ;;SET UP IOT VECTORS
872 002376 012737 000340 000022 MOV #340,#IOTVEC+2 ;;TO GO TO ERROR ROUTINE
873 002404 005037 177766 CLR #177766 ;;CLEAR CPU ERROR REGISTER
874 002410 005067 176370 RESTART: CLR $TESTN ;;RESET $TESTN TO ZERO
875 002414 012737 000014 177746 MOV #14,#CCR ;;SET CACHE TO FORCE MISS
876
877 ;*****
878 .SBTTL FLOATING POINT TESTS
879 ;*****
880 ; BEGIN FLOATING POINT TESTING
881 ;*****
882 ;*****
883 002422 MBT1:
884 ;*****
885 ;*TEST 1 FPP REGISTER BIT TESTS
886 ;*****

```

```

887
888
889
890
891
892
893 002422
894 002422 005267 176356
895 002426 170011
896 002430 005005
897 002432 012702 001066
898 002436 012703 001076
899 002442 170400
900 002444 174012
901 002446 005004
902 002450 170400
903 002452 170401
904 002454 170402
905 002456 170403
906 002460 170404
907 002462 170405
908
909 002464 010501
910 002466 070127 000014
911 002472 062701 002500
912 002476 000111
913 002500 172467 176362
914 002504 174067 176366
915 002510 000167 000074
916 002514 172567 176346
917 002520 174167 176352
918 002524 000167 000060
919 002530 172667 176332
920 002534 174267 176336
921 002540 000167 000044
922 002544 172767 176316
923 002550 174367 176322
924 002554 000167 000030
925 002560 172467 176302
926 002564 174004
927 002566 172404
928 002570 000167 177710
929 002574 172467 176266
930 002600 174005
931 002602 172405
932 002604 000167 177674
933 002610 026767 176252 176260
934 002616 001014
935 002620 026767 176244 176252
936 002626 001010
937 002630 026767 176236 176244
938 002636 001004
939 002640 026767 176230 176236
940 002646 001403
941 002650
942 002650 104000

```

```

;R5=FPP POINTER
;R1=TEMPORARY COUNTER
;R2=POINTER TO EXPECTED DATA
;R3=POINTER TO RECEIVED DATA
;R4=ODD/EVEN COUNTER
;*****
TST1:
      INC      $TESTN          ;INCREMENT TEST NUMBER
      SETD
MBT2:  CLR      R5              ;SETUP FPP ACC POINTER
      MOV      @BTEXP,R2      ;POINT TO TEST DATA
      MOV      @BTRES,R3     ;POINT TO RECEIVED DATA
MBT2A: CLRD     ACO            ;SETUP FPP REGISTER VALUES
      STD     ACO,(R2)       ;CLEAR EXPECTED VALUE
      CLR      R4
BTGO:  CLRD     ACO            ;SETUP FPP REGISTER VALUES
      CLRD     AC1
      CLRD     AC2
      CLRD     AC3
      CLRD     AC4
      CLRD     AC5
      MOV      R5,R1          ;GET FPP AC NUMBER INTO R1
      MUL      @14,R1        ;ALLOW 10 LOCATIONS FOR OPERATION
      ADD      @MACO,R1      ;SETUP JMP LOCATION
      JMP      (R1)
MACO:  LDD      BTEXP,ACO     ;LOAD TEST DATA INTO TEST REGISTER
MACOA: STD      ACO,BTRES    ;SAVE TEST RESULT
      JMP
MAC1:  LDD      BTEXP,AC1    ;LOAD TEST DATA INTO TEST REGISTER
      STD      AC1,BTRES    ;SAVE TEST RESULT
      JMP
MAC2:  LDD      BTEXP,AC2    ;LOAD TEST DATA INTO TEST REGISTER
      STD      AC2,BTRES    ;SAVE TEST RESULT
      JMP
MAC3:  LDD      BTEXP,AC3    ;LOAD TEST DATA INTO TEST REGISTER
      STD      AC3,BTRES    ;SAVE TEST RESULT
      JMP
MAC4:  LDD      BTEXP,ACO     ;LOAD TEST DATA INTO TEST REGISTER
      STD      ACO,AC4     ;SAVE TEST RESULT
      LDD      AC4,ACO
      JMP      MACOA        ;GET OUT
MAC5:  LDD      BTEXP,ACO     ;LOAD TEST DATA INTO TEST XFER REGISTER
      STD      ACO,AC5     ;LOAD TEST REGISTER
      LDD      AC5,ACO     ;STORE RESULT INTO XFER FPP REGISTER
      JMP      MACOA        ;GET OUT
MACE:  CMP      BTEXP,BTRES  ;BRANCH IF REGISTER ERROR
      BNE
      CMP      BTEXP+2,BTRES+2
      BNE
      CMP      BTEXP+4,BTRES+4
      BNE
      CMP      BTEXP+6,BTRES+6
      BEQ      MBT8
BTER:  ERROR

```

```

;GOOD RESULT
;ALL ERRORS TO TRAP TO EMT VECTOR

```



```

943 002652 000002          .WORD 2          ;UNIQUE ERROR NUMBER
944 002654 002013          .WORD FPPERR     ;ADDRESS OF ERROR MESSAGE
945                                     ;FPP AC LOADED INCORRECTLY
946                                     ;NOW VERIFY THE OTHER REGISTERS REMAINED ZERO
947 002656                                     MBT8:
948 002656 005001          CLR R1           ;CLEAR TEMPORARY COUNTER
949 002660 005705          TST R5          ;SEE IF R0 UNDER TEST
950 002662 001413          BEQ MBT8A       ;BRANCH IF TEST ING R0
951 002664 020527 000004   CMP R5,#4       ;SEE IF TESTING FPP REGISTER >R4
952 002670 100010          BPL MBT8A       ;SKIP R0 TESTING
953 002672 174067 176200   STD AC0,BTRES   ;SAVE AC TEST RESULT
954 002676 004767 000246   JSR R7,BTTST    ;VERIFY THAT CONTENTS REMAINED ZERO
955 002702 001403          BEQ MBT8A       ;BRANCH IF EXPECTED RESULT
956 002704 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
957 002706 000003          .WORD 3         ;UNIQUE ERROR NUMBER
958 002710 002013          .WORD FPPERR     ;ADDRESS OF ERROR MESSAGE
959
960 002712 020527 000001   MBT8A: CMP R5,#1     ;SEE IF R1 UNDER TEST
961 002716 001410          BEQ MBT8B       ;BRANCH IF R1 UNDER TEST
962 002720 174167 176152   STD AC1,BTRES   ;SAVE AC TEST RESULT
963 002724 004767 000220   JSR R7,BTTST    ;VERIFY THAT CONTENTS REMAINED ZERO
964 002730 001403          BEQ MBT8B       ;BRANCH IF GOOD
965 002732 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
966 002734 000004          .WORD 4         ;UNIQUE ERROR NUMBER
967 002736 002013          .WORD FPPERR     ;ADDRESS OF ERROR MESSAGE
968
969 002740 020527 000002   MBT8B: CMP R5,#2     ;SEE IF TESTING FPP REGISTER AC2
970 002744 001410          BEQ MBT8C       ;BRANCH IF R2 UNDER TEST
971 002746 174267 176124   STD AC2,BTRES   ;SAVE AC TEST RESULT
972 002752 004767 000172   JSR R7,BTTST    ;VERIFY THAT CONTENTS REMAINED ZERO
973 002756 001403          BEQ MBT8C       ;BRANCH IF GOOD
974 002760 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
975 002762 000005          .WORD 5         ;UNIQUE ERROR NUMBER
976 002764 002013          .WORD FPPERR     ;ADDRESS OF ERROR MESSAGE
977
978 002766 020527 000003   MBT8C: CMP R5,#3     ;SEE IF R3 UNDER TEST
979 002772 001410          BEQ MBT8D       ;BRANCH IF R3 UNDER TEST
980 002774 174367 176076   STD AC3,BTRES   ;SAVE AC TEST RESULT
981 003000 004767 000144   JSR R7,BTTST    ;VERIFY THAT CONTENTS REMAINED ZERO
982 003004 001403          BEQ MBT8D       ;BRANCH IF GOOD
983 003006 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
984 003010 000006          .WORD 6         ;UNIQUE ERROR NUMBER
985 003012 002013          .WORD FPPERR     ;ADDRESS OF ERROR MESSAGE
986
987 003014 020527 000004   MBT8D: CMP R5,#4     ;SEE IF R4 UNDER TEST
988 003020 001411          BEQ MBT8E       ;BRANCH IF R4 UNDER TEST
989 003022 172404          LDD AC4,AC0     ;MOVE REGISTER CONTENT
990 003024 174067 176046   STD AC0,BTRES   ;SAVE AC TEST RESULT
991 003030 004767 000114   JSR R7,BTTST    ;VERIFY THAT CONTENTS REMAINED ZERO
992 003034 001403          BEQ MBT8E       ;BRANCH IF GOOD
993 003036 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
994 003040 000007          .WORD 7         ;UNIQUE ERROR NUMBER
995 003042 002013          .WORD FPPERR     ;ADDRESS OF ERROR MESSAGE
996
997 003044 020527 000005   MBT8E: CMP R5,#5     ;SEE IF R0 UNDER TEST
998 003050 001411          BEQ MBT8F       ;BRANCH IF R0 UNDER TEST
    
```

```

999 003052 172405          LDD    AC5,AC0          ;MOVE REGISTER CONTENTS
1000 003054 174067 176016  STD    AC0,BTRES       ;SAVE AC TEST RESULT
1001 003060 004767 000064  JSR    R7,BTTST       ;VERIFY THAT CONTENTS REMAINED ZERO
1002 003064 001403          BEQ    MBT8F          ;BRANCH IF GOOD
1003 003066 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
1004 003070 000010          .WORD 10            ;UNIQUE ERROR NUMBER
1005 003072 002013          .WORD FPPERR        ;ADDRESS OF ERROR MESSAGE
1006
1007 003074 005204          MBT8F: INC    R4          ;BAD AC5
1008 003076 000241          CLC
1009 003100 042704 177776  BIC    #177776,R4     ;INCREMENT PATTERN COUNTER
1010 003104 001401          BEQ    MBT8FG        ; TEST FOR ODD /EVEN
1011 003106 000261          SEC
1012 003110 006112          MBT8FG: ROL    (R2)    ;BRANCH IF EVEN
1013 003112 006162 000002  ROL    2(R2)         ;SET CARRY FOR TEST PATTERN SHIFT
1014 003116 006162 000004  ROL    4(R2)         ;ROTATE LSW OF TEST PATTERN
1015 003122 006162 000006  ROL    6(R2)         ;ROTATE 2 WORD OF TEST PATTERN
1016 003126 103402          BCS    MBT8I        ;ROTATE 3 WORD OF TEST PATTERN
1017 003130 000167 177314  JMP    BTGO          ;ROTATE 4 WORD OF TEST PATTERN
1018
1019 003134 005205          MBT8I: INC    R5          ;JUMP IF THROUGH WITH TEST PATTERN
1020 003136 020527 000006  CMP    R5,#6         ;CONTINUE WITH NEW TEST PATTERN
1021 003142 100016          BPL    MBTE
1022 003144 000167 177272  JMP    MBT2A
1023
1024
1025 003150 005767 175722  ;
1026 003154 001010          ;BTTST: TST    BTRES   ;VERIFY CONTENTS AS ZERO
1027 003156 005767 175716  BNE    BTTSTE        ;EXIT IF NOT ZERO
1028 003162 001005          TST    BTRES+2       ;VERIFY CONTENTS AS ZERO
1029 003164 005767 175712  BNE    BTTSTE        ;EXIT IF NOT ZERO
1030 003170 001002          TST    BTRES+4       ;VERIFY CONTENTS AS ZERO
1031 003172 005767 175706  BNE    BTTSTE        ;EXIT IF NOT ZERO
1032 003176 000207          BTTSTE: TST    BTRES+6 ;VERIFY CONTENTS AS ZERO
1033
1034
1035
1036
1037 003200          ;
1038
1039
1040 003200          ;
1041
1042
1043
1044
1045
1046
1047
1048 003200          ;
1049 003200 005267 175600  TST2: INC    $TESTN   ;INCREMENT TEST NUMBER
1050
1051
1052
1053 003204 170011          ;
1054 003206 005000          MFA:  SETD   R0          ;SETUP FPP ACC POINTER
        CLR    R0
    
```

1055	003210	005004		CLR	R4	
1056	003212	012702	001066	MOV	#BTEXP,R2	;POINT TO TEST DATA
1057	003216	012703	001076	MOV	#BTRES,R3	;POINT TO RECEIVED DATA
1058	003222	012767	000051	MOV	#51,BTEXP	;SETUP EXPECTED DATA
1059	003230	012767	000052	MOV	#52,BTEXP+2	;
1060	003236	012767	000053	MOV	#53,BTEXP+4	;
1061	003244	012767	000054	MOV	#54,BTEXP+6	;
1062	003252	172467	175610	LDD	BTEXP,ACO	;MOVE DATA TEMPORARILY
1063	003256	174005		STD	ACO,AC5	;PUT DATA INTO TEST REGISTER
1064	003260	004567	000240	JSR	R5,SUBT	;SUBTRACT TEN FROM EACH EXPECTED DATA
1065	003264	172467	175576	LDD	BTEXP,ACO	;MOVE DATA TEMPORARILY
1066	003270	174004		STD	ACO,AC4	;MOVE DATA INTO TEST REGISTER
1067	003272	004567	000226	JSR	R5,SUBT	;SUBTRACT 10 FROM TEST DATA WORDS
1068	003276	172767	175564	LDD	BTEXP,AC3	;STORE INTO TEST REGISTER
1069	003302	004567	000216	JSR	R5,SUBT	;GET NEXT SET OF UNIQUE DATA WORDS
1070	003306	172667	175554	LDD	BTEXP,AC2	;STORE INTO TEST REGISTER
1071	003312	004567	000206	JSR	R5,SUBT	;GET NEXT SET OF TEST DATAS
1072	003316	172567	175544	LDD	BTEXP,AC1	;LOAD TEST REGISTER
1073	003322	004567	000176	JSR	R5,SUBT	;GET NEXT SET OF TEST WORDS
1074	003326	172467	175534	LDD	BTEXP,ACO	;LOAD FINAL TEST REGISTER
1075						;ALL REGISTER CONTAIN UNIQUE TEST WORDS
1076	003332	174067	175540	STD	ACO,BTRES	;STORE ACO,RESULT
1077	003336	004567	000246	JSR	R5,BFA	;CHECK RESULT
1078	003342	001403		BEQ	BFAC1	;BRANCH IF GOOD
1079	003344	104000		ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
1080	003346	000011		.WORD	11	;UNIQUE ERROR NUMBER
1081	003350	002013		.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
1082						;BAD ACO
1083	003352	004567	000200	JSR	R5,ADDT	;UPDATE EXPECTED RESULT
1084	003356	174167	175514	STD	AC1,BTRES	;STORE AC1 RESULT
1085	003362	004567	000222	JSR	R5,BFA	;CHECK RESULT
1086	003366	001403		BEQ	BFAC2	;BRANCH IF GOOD
1087	003370	104000		ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
1088	003372	000012		.WORD	12	;UNIQUE ERROR NUMBER
1089	003374	002013		.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
1090						;BAD RESULT AC1
1091	003376	004567	000154	JSR	R5,ADDT	;UPDATE EXPECTED RESULT
1092	003402	174267	175470	STD	AC2,BTRES	;STORE AC2 RESULT
1093	003406	004567	000176	JSR	R5,BFA	;CHECK RESULT
1094	003412	001403		BEQ	BFAC3	;BRANCH IF GOOD
1095	003414	104000		ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
1096	003416	000013		.WORD	13	;UNIQUE ERROR NUMBER
1097	003420	002013		.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
1098						;BAD AC2 RESULT
1099	003422	004567	000130	JSR	R5,ADDT	;UPDATE EXPECTED RESULT
1100	003426	174367	175444	STD	AC3,BTRES	;SAVE TEST RESULT
1101	003432	004567	000152	JSR	R5,BFA	;CHECK RESULT
1102	003436	001403		BEQ	BFAC4	;BRANCH IF GOOD
1103	003440	104000		ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
1104	003442	000014		.WORD	14	;UNIQUE ERROR NUMBER
1105	003444	002013		.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
1106						;BAD AC3 RESULT
1107	003446	004567	000104	JSR	R5,ADDT	;UPDATE EXPECTED RESULT
1108	003452	172704		LDD	AC4,AC3	;SAVE TEMPORARY
1109	003454	174367	175416	STD	AC3,BTRES	;STORE AC4 RESULT
1110	003460	004567	000124	JSR	R5,BFA	;CHECK RESULT

```

1111 003464 001403          BEQ      BFAC5          ;BRANCH IF GOOD
1112 003466 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
1113 003470 000015          .WORD      15          ;UNIQUE ERROR NUMBER
1114 003472 002013          .WORD      FPPERR      ;ADDRESS OF ERROR MESSAGE
1115                                     ;BAD AC4 RESULT
1116 003474 004567 000056    BFAC5: JSR      R5,ADDT    ;UPDATE EXPECTED RESULT
1117 003500 172605          LDD      AC5,AC2      ;SAVE TEMPORARY COPY
1118 003502 174267 175370    STD      AC2,BTRES    ;MOVE AC5 RESULT
1119 003506 004567 000076    JSR      R5,BFA       ;CHECK RESULT
1120 003512 001456          BEQ      BFAE         ;BRANCH IF GOOD
1121 003514 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
1122 003516 000016          .WORD      16          ;UNIQUE ERROR NUMBER
1123 003520 002013          .WORD      FPPERR      ;ADDRESS OF ERROR MESSAGE
1124                                     ;BAD AC5 RESULT
1125 003522 000452          BR       BFAE         ;EXIT MODULE
1126
1127 003524 162767 000010 175334  SUBT:  SUB      @10,BTEXP      ;UPDATE EXPECTED CONTENTS
1128 003532 162767 000010 175330  SUB      @10,BTEXP.2      ;UPDATE EXPECTED CONTENTS
1129 003540 162767 000010 175324  SUB      @10,BTEXP.4      ;UPDATE EXPECTED CONTENTS
1130 003546 162767 000010 175320  SUB      @10,BTEXP.6      ;UPDATE EXPECTED CONTENTS
1131 003554 000205          RTS
1132 003556 062767 000010 175302  ADDT:  ADD      @10,BTEXP      ;UPDATE EXPECTED CONTENTS
1133 003564 062767 000010 175276  ADD      @10,BTEXP.2      ;UPDATE EXPECTED CONTENTS
1134 003572 062767 000010 175272  ADD      @10,BTEXP.4      ;UPDATE EXPECTED CONTENTS
1135 003600 062767 000010 175266  ADD      @10,BTEXP.6      ;UPDATE EXPECTED CONTENTS
1136 003606 000205          RTS
1137
1138 003610 026767 175252 175260  BFA:   CMP      BTEXP,BTRES    ;VERIFY CONTENTS
1139 003616 001013          BNE      BFB          ;EXIT IF NOT ZERO
1140 003620 026767 175244 175252  CMP      BTEXP.2,BTRES.2  ;VERIFY CONTENTS
1141 003626 001007          BNE      BFB          ;EXIT IF NOT ZERO
1142 003630 026767 175236 175244  CMP      BTEXP.4,BTRES.4  ;VERIFY CONTENTS
1143 003636 001003          BNE      BFB          ;EXIT IF NOT ZERO
1144 003640 026767 175230 175236  CMP      BTEXP.6,BTRES.6  ;VERIFY CONTENTS
1145 003646 000205          BFB:   RTS           ;GO BACK TO CALLING ROUTINE
1146
1147
1148 003650          BFAE:
1149
1150
1151
1152 003650          TSFP1:
1153          ;*****
1154          ;*TEST 3          TEST LDFPS AND STFPS MODE 0
1155          ;*****
1156          TST3:
1157 003650 005267 175130          INC      @TESTN          ;INCREMENT TEST NUMBER
1158 003654 005037 002122          CLR      @TRPFLG        ;CLEAR TRAP FLAG
1159 003660 012704 147757          MOV      @147757,R4     ;SETUP DATA TO BE LOADED
1160 003664 004767 000032          JSR      PC,LOST        ;LOAD AND STORE FPS WITH DATA
1161 003670 012704 105252          MOV      @105252,R4     ;SETUP DATA TO BE LOADED
1162 003674 004767 000022          JSR      PC,LOST        ;LOAD AND STORE FPS WITH DATA
1163 003700 012704 042505          MOV      @42505,R4     ;SETUP DATA TO BE LOADED
1164 003704 004767 000012          JSR      PC,LOST        ;LOAD AND STORE FPS WITH DATA
1165 003710 005004          CLR      R4             ;SETUP DATA TO BE LOADED
1166 003712 004767 000004          JSR      PC,LOST        ;LOAD AND STORE FPS WITH DATA

```

```

1167
1168
1169 003716 000167 000020      ;      JMP      FIN1
1170
1171 003722 170104      ; LOST:  LDFPS  R4      ;LOAD FPS WITH DATA
1172 003724 170201      ;      STFPS  R1      ;LOAD R1 WITH (FPS)
1173 003726 020401      ;      CMP    R4,R1    ;DID THE INSTRUCTIONS WORK
1174 003730 001403      ;      BEQ   1#      ;YES GO ON
1175 003732 104000      ;      ERROR      ;ALL ERRORS TO TRAP TO EMT VECTOR
1176 003734 000017      ;      .WORD  17     ;UNIQUE ERROR NUMBER
1177 003736 002013      ;      .WORD  FPPERR ;ADDRESS OF ERROR MESSAGE
1178
1179 003740 000207      ;      RTS    PC      ;NO GO TO ERROR
1180 003742
1181
1182 003742      ;      FIN1:
1183
1184      ;      TSFP2:
1185      ;*****
1186      ;*TEST 4      TEST CFCC
1187      ;*****
1188 003742 005267 175036      ;      TST4:
1189 003746 005037 002122      ;      INC    $TESTN ;INCREMENT TEST NUMBER
1190 003752 012704 000017      ;      CLR    @TRPFLG ;CLEAR TRAP FLAG
1191 003756 004767 000032      ;      MOV    @17,R4  ;SETUP DATA TO BE LOADED
1192 003762 012704 000012      ;      JSR   PC,TSF2 ;LOAD FPS AND COPY CONDITION CODES TO PS
1193 003766 004767 000022      ;      MOV    @12,R4  ;SETUP DATA TO BE LOADED
1194 003772 012704 000005      ;      JSR   PC,TSF2 ;LOAD FPS AND COPY CONDITION CODES TO PS
1195 003776 004767 000012      ;      MOV    @5,R4   ;SETUP DATA TO BE LOADED
1196 004002 005004      ;      JSR   PC,TSF2 ;LOAD FPS AND COPY CONDITION CODES TO PS
1197 004004 004767 000004      ;      CLR    R4      ;SETUP DATA TO BE LOADED
1198
1199 004010 000167 000030      ;      JSR   PC,TSF2 ;LOAD FPS AND COPY CONDITION CODES TO PS
1200
1201 004014 170104      ;      JMP      FIN2
1202 004016 170000      ;      TSF2:  LDFPS  R4      ;LOAD FPS
1203 004020 013701 177776      ;      CFCC      ;COPY CONDITION CODES TO PS
1204 004024 042701 177760      ;      MOV    @177776,R1 ;SAVE PS TO R1
1205 004030 020401      ;      BIC    @177760,R1 ;MASK OUT UNWANTED BITS
1206
1207 004032 001403      ;      CMP    R4,R1    ;WAS CONDITION CODE BITS TRANSFERRED
1208 004034 104000      ;      BEQ   1#      ;CORRECTLY
1209 004036 000020      ;      ERROR      ;YES GO ON
1210 004040 002013      ;      .WORD  20     ;ALL ERRORS TO TRAP TO EMT VECTOR
1211
1212 004042 000207      ;      .WORD  FPPERR ;UNIQUE ERROR NUMBER
1213 004044      ;      ;ADDRESS OF ERROR MESSAGE
1214
1215 004044      ;      RTS    PC      ;NO GO TO ERROR
1216
1217      ;      FIN2:
1218      ;      TSFP3:
1219      ;*****
1220      ;*TEST 5      TEST SETF, SETD, SETI, SETL
1221      ;*****
1222 004044 005267 174734      ;      TST5:
1223 004050 005037 002122      ;      INC    $TESTN ;INCREMENT TEST NUMBER
1224 004054 012704 000200      ;      CLR    @TRPFLG ;CLEAR TRAP FLAG
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500

```

```

1223 004060 170104 LDFPS R4 ;LOAD FPS
1224 004062 170001 SETF ;MAKE FD=0
1225 004064 170201 STFPS R1 ;STORE FPS
1226 004066 020127 000000 CMP R1,#0 ;IS FD=0
1227 004072 001403 BEQ 1# ;YES GO ON
1228 004074 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1229 004076 000021 .WORD 21 ;UNIQUE ERROR NUMBER
1230 004100 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1231 ;NO GO TO ERROR
1232 004102 170011 1# : SETD ;MAKE FD=1
1233 004104 170201 STFPS R1 ;STORE FPS
1234 004106 020104 CMP R1,R4 ;IS FD=1
1235 004110 001403 BEQ 2# ;YES GO ON
1236 004112 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1237 004114 000022 .WORD 22 ;UNIQUE ERROR NUMBER
1238 004116 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1239 ;NO GO TO ERROR
1240 004120 012704 000100 2# : MOV #100,R4 ;SETUP DATA TO BE LOADED
1241 004124 170104 LDFPS R4 ;LOAD FPS
1242 004126 170002 SETI ;MAKE FL=0
1243 004130 170201 STFPS R1 ;STORE FPS
1244 004132 020127 000000 CMP R1,#0 ;IS FL=0
1245 004136 001403 BEQ 3# ;YES GO ON
1246 004140 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1247 004142 000023 .WORD 23 ;UNIQUE ERROR NUMBER
1248 004144 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1249 ;NO GO TO ERROR
1250 004146 170012 3# : SETL ;MAKE FL=1
1251 004150 170201 STFPS R1 ;STORE FPS
1252 004152 020104 CMP R1,R4 ;IS FL=1
1253 004154 001403 BEQ 4# ;YES GO ON
1254 004156 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1255 004160 000024 .WORD 24 ;UNIQUE ERROR NUMBER
1256 004162 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1257 ;NO GO TO ERROR
1258 004164 4# :
1259 ;
1260 ;
1261 004164 ;TSFP4:
1262 ;*****
1263 ;*TEST 6 TEST ILLEGAL OP CODES AND STST
1264 ;*****
1265 004164 TST6:
1266 004164 005267 174614 INC #TESTN ;INCREMENT TEST NUMBER
1267 004170 005037 002122 CLR #TRPFLG ;CLEAR TRAP FLAG
1268 004174 012705 170003 MOV #170003,R5 ;INIT OP CODE
1269 004200 013746 000244 MOV #0244,-(SP) ;SAVE FP VECTOR
1270 004204 012737 004340 000244 MOV #ILLOP1,#0244 ;SETUP NEW VECTOR
1271 004212 013746 000004 MOV #04,-(SP) ;SAVE TIME OUT VECTOR
1272 004216 012737 004424 000004 MOV #TIMEOU,#04 ;SETUP NEW VECTOR
1273 004224 013746 000010 MOV #010,-(SP) ;SAVE ILLEGAL VECTOR
1274 004230 012737 004434 000010 MOV #ILLOP2,#010 ;SETUP NEW VECTOR
1275 004236 005003 D1: CLR R3 ;
1276 004240 170103 LDFPS R3 ;CLEAR FPS
1277 004242 005002 CLR R2 ;
1278 004244 010537 004250 MOV R5,#0D2 ;SETUP THE ILLEGAL INST

```

```

1279 004250 000000      D2:  .WORD  0
1280 004252 170000      D3:  CFCC
1281 004254 005202      INC   R2
1282 004256 005202      INC   R2
1283 004260 170201      STFPS R1
1284 004262 104000      ERROR
1285 004264 000025      .WORD 25
1286 004266 002013      .WORD FPPERR
1287
1288 004270 022705 170010  D4:  CMP    #170010,R5
1289 004274 001003      BNE   D5
1290 004276 012705 170013  MOV   #170013,R5
1291 004302 000755      BR    D1
1292 004304 022705 170077  D5:  CMP    #170077,R5
1293 004310 001001      BNE   D6
1294 004312 000402      BR    D7
1295 004314 005205      D6:  INC   R5
1296 004316 000747      BR    D1
1297 004320 012637 000010  D7:  MOV   (SP)+,R#10
1298 004324 012637 000004      MOV   (SP)+,R#4
1299 004330 012637 000244      MOV   (SP)+,R#244
1300
1301
1302 004334 000167 000104      ; JMP    FIN4
1303
1304 004340 022716 004252      ; ILL0P1: CMP   #D3,(SP)
1305 004344 001403      BEQ   1#
1306 004346 104000      ERROR
1307 004350 000026      .WORD 26
1308 004352 002013      .WORD FPPERR
1309
1310 004354 022626      1#:  CMP   (SP)+,(SP)+
1311 004356 170201      STFPS R1
1312 004360 022701 100000  CMP   #100000,R1
1313 004364 001403      BEQ   2#
1314 004366 104000      ERROR
1315 004370 000027      .WORD 27
1316 004372 002013      .WORD FPPERR
1317
1318 004374 005004      2#:  CLR   R4
1319 004376 170304      STST  R4
1320
1321
1322
1323 004400 022704 000002      CMP   #2,R4
1324 004404 001002      BNE   3#
1325 004406 000167 177656      JMP   D4
1326 004412
1327 004412 104000      3#:  ERROR
1328 004414 000030      .WORD 30
1329 004416 002013      .WORD FPPERR
1330
1331 004420 000167 177644      JMP   D4
1332
1333 004424
1334 004424 104000      ; TIMEOU: ERROR

```

```

; MEMORY WORDS TO BE USED WITH
; EXECUTION OF ILLEGAL OP CODE
;
; SAVE FPS
; ALL ERRORS TO TRAP TO EMT VECTOR
; UNIQUE ERROR NUMBER
; ADDRESS OF ERROR MESSAGE
;GO TO ERROR
; COMPUTE NEXT OP CODE
;
;
;
;
; RESTORE VECTORS
;
;
; DID TRAP OCCUR ON TEST INST
; YES GO ON
; ALL ERRORS TO TRAP TO EMT VECTOR
; UNIQUE ERROR NUMBER
; ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
; CLEAN UP STACK
; STORE FPS
; IS FPS CORRECT
; YES GO ON
; ALL ERRORS TO TRAP TO EMT VECTOR
; UNIQUE ERROR NUMBER
; ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
; INT R4 TO A KNOWN STATE
; STORE FEC AT R4
; IF THE DESTINATION MODE IS IMPROPERLY
; DECODED AN ODD ADDRESS TRAP TO 4
; SHOULD OCCUR
; IS FEC CORRECT
;NO GO TO ERROR
; YES GO ON
; ALL ERRORS TO TRAP TO EMT VECTOR
; UNIQUE ERROR NUMBER
; ADDRESS OF ERROR MESSAGE
;GO TO ERROR
; THEN GO ON
; ALL ERRORS TO TRAP TO EMT VECTOR

```

```

1335 004426 000031          .WORD 31          ;UNIQUE ERROR NUMBER
1336 004430 002013          .WORD FPPERR      ;ADDRESS OF ERROR MESSAGE
1337                                     ;ERROR BECAUSE OF TRAP TO 4
1338 004432 000006          RTT                ;RETURN
1339
1340                                     ;ILLOP2:
1341 004434 104000          ERROR              ;ALL ERRORS TO TRAP TO EMT VECTOR
1342 004436 000032          .WORD 32          ;UNIQUE ERROR NUMBER
1343 004440 002013          .WORD FPPERR      ;ADDRESS OF ERROR MESSAGE
1344                                     ;ERROR BECAUSE OF TRAP TO 10
1345 004442 000006          RTT                ;RETURN
1346 004444
1347
1348 004444          FIN4:
1349                                     ;TSFP5:
1350                                     ;*****
1351                                     ;*TEST 7          TEST FID (INTERRUPT DISABLE BIT)
1352                                     ;*****
1353 004444          TST7:
1354 004450 005267 174334      INC $TESTN         ;INCREMENT TEST NUMBER
1355 004454 013746 002122      CLR @TRPFLG       ;CLEAR TRAP FLAG
1356 004460 012737 004544      MOV @244,-(SP)    ;SAVE FP VECTOR
1357 004466 012703 040000      MOV @ILL,@244     ;SETUP NEW VECTOR
1358 004472 170103          MOV @40000,R3     ;SETUP DATA TO BE LOADED
1359 004474 170020          LDFPS R3          ;LOAD FPS, FID=1
1360 004476 170000          .WORD 170020     ;ILLEGAL FP INSTRUCTION
1361 004500 170201          CFCC              ;
1362 004502 022701 140000      STFPS R1          ;SEE IF ERROR WAS RECORDED IN FPS
1363 004506 001403          CMP @140000,R1   ;
1364 004510 104000          BEQ 1$           ;YES GO ON
1365 004512 000033          ERROR            ;ALL ERRORS TO TRAP TO EMT VECTOR
1366 004514 002013          .WORD 33         ;UNIQUE ERROR NUMBER
1367                                     .WORD FPPERR      ;ADDRESS OF ERROR MESSAGE
1368 004516 170304          1$: STST R4         ;NO GO TO ERROR
1369 004520 022704 000002      CMP @2,R4        ;SEE IF FEC=2
1370 004524 001403          BEQ 2$           ;
1371 004526 104000          ERROR            ;YES GO ON
1372 004530 000034          .WORD 34         ;ALL ERRORS TO TRAP TO EMT VECTOR
1373 004532 002013          .WORD FPPERR      ;UNIQUE ERROR NUMBER
1374                                     .WORD FPPERR      ;ADDRESS OF ERROR MESSAGE
1375 004534 012637 000244      2$: MOV (SP)+,@244 ;NO GO TO ERROR
1376                                     ;RESTORE VECTOR
1377
1378 004540 000167 000010      ; JMP FIN5
1379
1380                                     ;ILL:
1381 004544 104000          ERROR            ;ALL ERRORS TO TRAP TO EMT VECTOR
1382 004546 000035          .WORD 35         ;UNIQUE ERROR NUMBER
1383 004550 002013          .WORD FPPERR      ;ADDRESS OF ERROR MESSAGE
1384                                     ;FID ERROR
1385 004552 000006          RTT                ;RETURN
1386 004554
1387
1388 004554          FIN5:
1389                                     ;TSFP6:
1390                                     ;*****
                                     ;*TEST 10          TEST LOD, STD FSRC AND FDST MODE 1

```



```

1447
1448 004750          †SF6:
1449 004750 104000      ERROR                                ;ALL ERRORS TO TRAP TO EMT VECTOR
1450 004752 000042      .WORD 42                            ;UNIQUE ERROR NUMBER
1451 004754 002013      .WORD FPPERR                                ;ADDRESS OF ERROR MESSAGE
1452
1453 004756 000006      RTT                                ;ODD ADDRESS TRAP
1454 004760
1455
1456 004760          FIN6:
1457
1458
1459
1460 004760          †TSFP7:
1461 004760 005267 174020      ;*****
1462 004764 005037 002122      ;*TEST 11          TEST LDD, LDF FSRC MODE 0
1463 004770 012704 000200      ;*****
1464 004774 170104
1465 004776 013746 000004      TST11:
1466 005002 012737 005154 000004      INC          $TESTN          ;INCREMENT TEST NUMBER
1467 005010 012704 005164      CLR          @TRPFLG         ;CLEAR TRAP FLAG
1468 005014 172414      MOV          @200,R4         ;SETUP TO LOAD FPS
1469 005016 012701 005174      LDFPS       R4              ;LOAD FPS, FD=1
1470 005022 172511      MOV          @4,-(SP)        ;SAVE TIMEOUT VECTOR
1471 005024 172401      MOV          @TSF7,@4        ;SETUP NEW VECTOR
1472 005026 012704 001136      MOV          @TS7DA1,R4      ;SETUP POINTER TO DATA
1473 005032 174114      LDD          (R4),ACO        ;CLEAR ACO
1474 005034 004767 000072      MOV          @TS7DA2,R1      ;SETUP POINTER TO DATA
1475 005040 012704 001136      LDD          (R1),AC1        ;LOAD AC1 WITH DATA
1476 005044 012701 005174      LDD          AC1,ACO         ; TEST INSTRUCTION
1477 005050 174014      MOV          @TSTLOC,R4      ;
1478 005052 004767 000054      STD          AC1,(R4)        ;CHECK IF AC1 HAS BEEN ALTERED
1479 005056 012701 005164      JSR          PC,CHECK7       ;
1480 005062 172511      MOV          @TSTLOC,R4      ;          ;SETUP POINTERS FOR DATA
1481 005064 170001      LDD          @TS7DA2,R1      ;
1482 005066 172401      STD          ACO,(R4)        ;CHECK IF ACO RECEIVED CORRECT DATA
1483 005070 170011      JSR          PC,CHECK7       ;
1484 005072 012704 001136      MOV          @TS7DA1,R1      ;SETUP POINTER TO DATA
1485 005076 174114      LDD          (R1),AC1        ;CLEAR AC1
1486 005100 004767 000026      SETF        AC1,ACO         ;SET FD=0
1487 005104 012704 005204      LDF         AC1,ACO         ; TEST INSTRUCTION
1488 005110 012701 001136      SETD        AC1,ACO         ;SET FD=1
1489 005114 174011      MOV          @TSTLOC,R4      ;SETUP POINTER TO DATA
1490 005116 004767 000010      STD          AC0,(R1)        ;CHECK IF ACO HAS CORRECT DATA
1491 005122 012637 000004      JSR          PC,CHECK7       ;
1492
1493
1494 005126 000167 000062      MOV          (SP),@4         ;RESTORE VECTOR
1495
1496 005132 012703 000004      JMP          FIN7
1497 005136 022421      ;CHECK7: MOV          @4,R3          ;INIT COUNTER
1498 005140 001403      CHEK7:  CMP          (R4),,(R1) ;IS DATA OK
1499 005142 104000      BEQ          CHK7           ;YES GO ON
1500 005144 000043      ERROR                                ;ALL ERRORS TO TRAP TO EMT VECTOR
1501 005146 002013      .WORD 43                            ;UNIQUE ERROR NUMBER
1502
                                .WORD FPPERR                                ;ADDRESS OF ERROR MESSAGE
                                ;NO GO TO ERROR
    
```

1503 005150 077306
 1504 005152 000207
 1505
 1506 005154
 1507 005154 104000
 1508 005156 000044
 1509 005160 002013
 1510
 1511 005162 000006
 1512
 1513 005164 000000
 1514 005166 000000
 1515 005170 000000
 1516 005172 000000
 1517 005174 037641
 1518 005176 065121
 1519 005200 037373
 1520 005202 022265
 1521 005204 000000
 1522 005206 000000
 1523 005210 037373
 1524 005212 022265
 1525 005214
 1526
 1527 005214
 1528
 1529
 1530
 1531 005214
 1532 005214 005267 173564
 1533 005220 005037 002122
 1534 005224 012704 000200
 1535 005230 170104
 1536 005232 013746 000004
 1537 005236 012737 005410 000004
 1538 005244 012704 005420
 1539 005250 172414
 1540 005252 012701 005430
 1541 005256 172511
 1542 005260 174100
 1543 005262 012704 001136
 1544 005266 174114
 1545 005270 004767 000072
 1546 005274 012704 001136
 1547 005300 012701 005430
 1548 005304 174014
 1549 005306 004767 000054
 1550 005312 012701 005420
 1551 005316 172511
 1552 005320 170001
 1553 005322 174100
 1554 005324 170011
 1555 005326 012704 001136
 1556 005332 174114
 1557 005334 004767 000026
 1558 005340 012704 005440

```

CHK7: SOB R3,CHK7 ;ARE WE DONE
      RTS PC ;YES RETURN

;
;TSF7:
      ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD 44 ;UNIQUE ERROR NUMBER
      .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;ODD ADDRESS TRAP
      RTT ;RETURN

;
;TS7DA1: .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
TS7DA2: .WORD 37641
        .WORD 65121
        .WORD 37373
        .WORD 22265
TS7DA4: .WORD 0
        .WORD 0
        .WORD 37373
        .WORD 22265

FIN7:
;
;TSFP10:
;*****
; *TEST 12 TEST STD, STF FDST MODE 0
;*****
TST12:
      INC #TESTN ;INCREMENT TEST NUMBER
      CLR #TRPFLG ;CLEAR TRAP FLAG
      MOV #200,R4 ;SETUP TO LOAD FPS
      LDFPS R4 ;LOAD FPS, FD=1
      MOV #04,-(SP) ;SAVE TIMEOUT VECTOR
      MOV #TSF10,#04 ;SETUP NEW VECTOR
      MOV #TS10D1,R4 ;SETUP POINTER TO DATA
      LDD (R4),ACO ;CLEAR ACO
      MOV #TS10D2,R1 ;SETUP POINTER TO DATA
      LDD (R1),AC1 ;LOAD AC1 WITH DATA
      STD AC1,ACO ; TEST INSTRUCTION
      ;
      ;CHECK IF AC1 HAS BEEN ALTERED
      ;
      ;SETUP POINTERS FOR DATA
      ;
      ;CHECK IF ACO RECEIVED CORRECT DATA
      ;
      ;SETUP POINTER TO DATA
      LDD (R1),AC1 ;CLEAR AC1
      SETF ;SET FD=0
      STF AC1,ACO ; TEST INSTRUCTION
      SETD ;SET FD=1
      MOV #TSTLOC,R4 ;SETUP POINTER TO DATA
      STD AC1,(R4) ;CHECK IF AC1 HAS BEEN ALTERED
      JSR PC,CHEC10
      ;
      ;SETUP POINTERS FOR DATA
      MOV #TS10D4,R4

```

```

1559 005344 012701 001136      MOV      #TSTLOC,R1
1560 005350 174011              STD      ACO,(R1)
1561 005352 004767 000010      JSR      PC,CHC10
1562 005356 012637 000004      MOV      (SP)+,#04
1563
1564
1565 005362 000167 000062      ;
1566
1567 005366 012703 000004      ;
CHC10: MOV      #4,R3
CH10:  CMP      (R4)+,(R1)+
      BEQ      CHK10
      ERROR
      .WORD   45
      .WORD   FPPERR
      ;NO GO TO ERROR
      ;ARE WE DONE
      ;YES RETURN
1570 005376 104000
1571 005400 000045
1572 005402 002013
1573
1574 005404 077306      CHK10:  SOB      R3,CH10
1575 005406 000207      RTS
1576
1577 005410
1578 005410 104000      ;TSF10:
1579 005412 000046      ERROR
1580 005414 002013      .WORD   46
1581
1582 005416 000006      .WORD   FPPERR
1583
1584 005420 000000      RTT
1585 005422 000000      ;
1586 005424 000000      ;TS10D1: .WORD   0
1587 005426 000000      .WORD   0
1588 005430 177777      .WORD   0
1589 005432 111236      TS10D2: .WORD   177777
1590 005434 100045      .WORD   111236
1591 005436 003651      .WORD   100045
1592 005440 000000      TS10D4: .WORD   3651
1593 005442 000000      .WORD   0
1594 005444 100045      .WORD   0
1595 005446 003651      .WORD   100045
1596 005450
1597
1598 005450
1599
1600
1601
1602 005450
1603 005450 005267 173330
1604 005454 005037 002122
1605 005460 012704 000200
1606 005464 170104
1607 005466 012704 005550
1608 005472 172414
1609 005474 170400
1610 005476 170203
1611 005500 012704 001136
1612 005504 174014
1613 005506 012701 000004
1614 005512 022427 000000

;*****
;*TEST 13      TEST FDST SINGLE OPERAND MODE 0
;*****
TST13:
      INC      #TESTN
      CLR      #TRPFLG
      MOV      #200,R4
      LDFPS   R4
      MOV      #TS11D1,R4
      LDD      (R4),ACO
      CLRD    ACO
      STFPS   R3
      MOV      #TSTLOC,R4
      STD      ACO,(R4)
      MOV      #4,R1
      1$:  CMP      (R4)+,#0
      ;INCREMENT TEST NUMBER
      ;CLEAR TRAP FLAG
      ;SETUP TO LOAD FPS
      ;SET FD=1
      ;SETUP POINTER TO DATA
      ;LOAD ALL ONES TO ACO
      ;TEST INSTRUCTION
      ;GET FPS
      ;
      ;CHECK ACO FOR ALL ZEROES
      ;INIT COUNTER
      ;

```

```

1615 005516 001403      BEQ      2#          ;OK GO ON
1616 005520 104000      ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
1617 005522 000047      .WORD   47          ;UNIQUE ERROR NUMBER
1618 005524 002013      .WORD   FPPERR      ;ADDRESS OF ERROR MESSAGE
1619                                     ;NO GO TO ERROR
1620 005526 077107      2#:   SOB      R1,1#   ;ARE WE DONE
1621 005530 020327 000204  CMP      R3,#204    ;CHECK FPS
1622 005534 001403      BEQ      3#          ;OK GO ON
1623 005536 104000      ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
1624 005540 000050      .WORD   50          ;UNIQUE ERROR NUMBER
1625 005542 002013      .WORD   FPPERR      ;ADDRESS OF ERROR MESSAGE
1626                                     ;NO GO TO ERROR
1627 005544      3#:
1628
1629
1630 005544 000167 000010      ;
1631                                     ;
1632                                     ;TS11D1: .WORD   177777
1633                                     ;.WORD   177777
1634                                     ;.WORD   177777
1635                                     ;.WORD   177777
1636 005560      FIN11:
1637                                     ;
1638 005560      TSFP12:
1639                                     ;*****
1640                                     ;*TEST 14      TEST FDST SOP MODE 0 WITH ILLEGAL AC7
1641                                     ;*****
1642 005560      TST14:
1643 005560 005267 173220      INC      #TESTN      ;INCREMENT TEST NUMBER
1644 005564 005037 002122      CLR      @TRPFLG     ;CLEAR TRAP FLAG
1645 005570 012703 040200      MOV      @40200,R3   ;SETUP TO LOAD FPS
1646 005574 170103      LDFPS   R3           ;SET FID=1, AND FD=1
1647 005576 170407      CLAD    AC7          ; TEST INSTRUCTION
1648 005600 170204      STFPS   R4           ;GET FPS
1649 005602 170305      STST    R5           ;GET FEC
1650 005604 022704 140200      CMP      @140200,R4  ;IS FPS CORRECT
1651 005610 001403      BEQ      1#          ;YES GO ON
1652 005612 104000      ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
1653 005614 000051      .WORD   51          ;UNIQUE ERROR NUMBER
1654 005616 002013      .WORD   FPPERR      ;ADDRESS OF ERROR MESSAGE
1655                                     ;NO GO TO ERROR
1656 005620 022705 000002      1#:   CMP      @2,R5   ;IS FEC CORRECT
1657 005624 001403      BEQ      2#          ;YES GO ON
1658 005626 104000      ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
1659 005630 000052      .WORD   52          ;UNIQUE ERROR NUMBER
1660 005632 002013      .WORD   FPPERR      ;ADDRESS OF ERROR MESSAGE
1661                                     ;NO GO TO ERROR
1662 005634      2#:
1663
1664
1665 005634      ;
1666                                     ;TSFP13:
1667                                     ;*****
1668                                     ;*TEST 15      TEST FDST SOP MODE 1
1669                                     ;*****
1670 005634 005267 173144      TST15:
1671                                     ;
1672                                     ;INC      #TESTN      ;INCREMENT TEST NUMBER

```

```

1671 005640 013746 000004      MOV      @#4,-(SP)          ;SAVE TIMEOUT VECTOR
1672 005644 012737 005774 000004  MOV      @TSF13,@#4      ;SETUP NEW VECTOR
1673 005652 005037 002122      CLR      @#TRPFLG        ;CLEAR TRAP FLAG
1674 005656 012702 000200      MOV      @200,R2        ;SETUP TO LOAD FPS
1675 005662 170102                LDFPS   R2                ;SET FD=1
1676 005664 012705 000004      MOV      @4,R5           ;INIT COUNTER
1677 005670 012704 001136      MOV      @TSTLOC,R4      ;SETUP POINTER TO TEST LOCATION
1678 005674 012724 177777 100$:  MOV      @177777,(R4)+   ;MOVE ALL ONES TO TEST LOCATION
1679 005700 077503                SOB     R5,100$         ;ARE WE DONE
1680 005702 012702 001136      MOV      @TSTLOC,R2      ;SETUP POINTER TO DATA
1681 005706 170412                CLRD   (R2)             ; TEST INSTRUCTION
1682 005710 170203                STFPS  R3                ;GET FPS
1683 005712 020227 001136      CMP      R2,@TSTLOC      ;WAS R2 ALTERED
1684 005716 001403                BEQ    1$               ;NO GO ON
1685 005720 104000                ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
1686 005722 000053                .WORD 53                ;UNIQUE ERROR NUMBER
1687 005724 002013                .WORD FPPERR           ;ADDRESS OF ERROR MESSAGE
1688                                ;YES GO TO ERROR
1689 005726 012701 000004 1$:  MOV      @4,R1           ;INIT COUNTER
1690 005732 022227 000000 2$:  CMP      (R2)+,@0        ;CHECK LOCATION FOR 0
1691 005736 001403                BEQ    3$               ;OK GO ON
1692 005740 104000                ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
1693 005742 000054                .WORD 54                ;UNIQUE ERROR NUMBER
1694 005744 002013                .WORD FPPERR           ;ADDRESS OF ERROR MESSAGE
1695                                ;NO GO TO ERROR
1696 005746 077107                SOB     R1,2$          ;ARE WE DONE
1697 005750 020327 000204      CMP      R3,@204        ;CHECK FPS
1698 005754 001403                BEQ    4$               ;OK GO ON
1699 005756 104000                ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
1700 005760 000055                .WORD 55                ;UNIQUE ERROR NUMBER
1701 005762 002013                .WORD FPPERR           ;ADDRESS OF ERROR MESSAGE
1702                                ;NO GO TO ERROR
1703 005764 012637 000004 4$:  MOV      (SP)+,@#4      ;RESTORE VECTOR
1704                                ;
1705                                ;
1706 005770 000167 000010      JMP     FIN13
1707                                ;
1708                                ;TSF13:
1709 005774 104000                ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
1710 005776 000056                .WORD 56                ;UNIQUE ERROR NUMBER
1711 006000 002013                .WORD FPPERR           ;ADDRESS OF ERROR MESSAGE
1712                                ;ODD ADDRESS TRAP
1713 006002 000006                RTT      ;RETURN
1714                                ;
1715                                ;FIN13:
1716                                ;
1717 006004                ;TSFP14:
1718                                ;*****
1719                                ;*TEST 16      TEST FDST SOP MODE 2
1720                                ;*****
1721 006004                TST16:
1722 006004 005267 172774                INC     @TESTN          ;INCREMENT TEST NUMBER
1723 006010 013746 000004      MOV      @#4,-(SP)      ;SAVE TIMEOUT VECTOR
1724 006014 012737 006150 000004  MOV      @TSF14,@#4      ;SETUP NEW VECTOR
1725 006022 005037 002122      CLR      @#TRPFLG        ;CLEAR TRAP FLAG
1726 006026 012702 000200      MOV      @200,R2        ;SETUP TO LOAD FPS

```

```

1727 006032 170102          LDFPS R2          ;SET FD=1
1728 006034 012705 000004  MOV #4,R5        ;INIT COUNTER
1729 006040 012704 001136  MOV #TSTLOC,R4   ;SETUP POINTER TO TEST LOCATION
1730 006044 012724 177777 100$: MOV #177777,(R4)+ ;MOVE ALL ONES TO TEST LOCATION
1731 006050 077503          SOB R5,100$      ;ARE WE DONE
1732 006052 012702 001136  MOV #TSTLOC,R2   ;SETUP POINTER TO DATA
1733 006056 170422          CLRD (R2)+       ; TEST INSTRUCTION
1734 006060 170203          STFPS R3        ;GET FPS
1735 006062 020227 001146  CMP R2,#TSTLOC+10 ;IS R2 CORRECT
1736 006066 001403          BEQ 1$          ;YES GO ON
1737 006070 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
1738 006072 000057          .WORD 57       ;UNIQUE ERROR NUMBER
1739 006074 002013          .WORD FPPERR    ;ADDRESS OF ERROR MESSAGE
1740
1741 006076 012702 001136 1$: MOV #TSTLOC,R2  ;NO GO TO ERROR
1742 006102 012701 000004  MOV #4,R1        ;SETUP POINTER TO DATA
1743 006106 022227 000000 2$: CMP (R2)+,#0   ;INIT COUNTER
1744 006112 001403          BEQ 3$          ;CHECK LOCATION FOR 0
1745 006114 104000          ERROR          ;YES GO ON
1746 006116 000060          .WORD 60       ;ALL ERRORS TO TRAP TO EMT VECTOR
1747 006120 002013          .WORD FPPERR    ;UNIQUE ERROR NUMBER
1748
1749 006122 077107          SOB R1,2$       ;ADDRESS OF ERROR MESSAGE
1750 006124 020327 000204  CMP R3,#204     ;NO GO TO ERROR
1751 006130 001403          BEQ 4$          ;ARE WE DONE
1752 006132 104000          ERROR          ;CHECK FPS
1753 006134 000061          .WORD 61       ;OK GO ON
1754 006136 002013          .WORD FPPERR    ;ALL ERRORS TO TRAP TO EMT VECTOR
1755
1756 006140 012637 000004 4$: MOV (SP)+,#04  ;UNIQUE ERROR NUMBER
1757
1758
1759 006144 000167 000010  ; JMP FIN14      ;ADDRESS OF ERROR MESSAGE
1760
1761 006150          ;TSF14:
1762 006150 104000          ERROR          ;NO GO TO ERROR
1763 006152 000062          .WORD 62       ;ARE WE DONE
1764 006154 002013          .WORD FPPERR    ;CHECK FPS
1765
1766 006156 000006          RTT           ;OK GO ON
1767
1768 006160          ;FIN14:
1769
1770 006160          ;TSFP15:
1771
1772          ;*****
1773          ;*TEST 17 TEST FDST SOP MODE 3
1774          ;*****
1775 006160 005267 172620  TST17: INC #TESTN      ;INCREMENT TEST NUMBER
1776 006164 013746 000004  MOV #04,-(SP)   ;SAVE TIMEOUT VECTOR
1777 006170 012737 006370 000004 MOV #TSF15,#04  ;SETUP NEW VECTOR
1778 006176 005037 002122  CLR #TRPFLG     ;CLEAR TRAP FLAG
1779 006202 012702 000200  MOV #200,R2     ;SETUP TO LOAD FPS
1780 006206 170102          LDFPS R2        ;SET FD=1
1781 006210 012705 000011  MOV #9,R5       ;INIT COUNTER
1782 006214 012704 001136  MOV #TSTLOC,R4  ;SETUP POINTER TO TEST LOCATION
    
```

```

1783 006220 012724 177777      100$: MOV      #177777,(R4)+      ;INIT TEST LOCATION
1784 006224 077503              SOB      R5,100$          ;ARE WE DONE
1785 006226 012737 001150 001136 MOV      #TSTLOC+12,#TSTLOC ;INIT TEST LOCATION
1786 006234 012702 001136      MOV      #TSTLOC,R2      ;SETUP POINTER TO DATA
1787 006240 170432              CLRD    @R2)+            ; TEST INSTRUCTION
1788 006242 170203              STFPS   R3              ;GET FPS
1789 006244 020227 001140      CMP     R2,#TSTLOC+2    ;IS R2 CORRECT
1790 006250 001403              BEQ     1$              ;YES GO ON
1791 006252 104000              ERKOR   ;ALL ERRORS TO TRAP TO EMT VECTOR
1792 006254 000063              .WORD  63              ;UNIQUE ERROR NUMBER
1793 006256 002013              .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
1794                                     ;NO GO TO ERROR
1795 006260 012702 001136      1$:  MOV      #TSTLOC,R2      ;SETUP POINTER TO DATA
1796 006264 022227 001150      CMP     (R2)+,#TSTLOC+12 ;IS DATA CORRECT
1797 006270 001403              BEQ     2$              ;YES GO ON
1798 006272 104000              ERKOR   ;ALL ERRORS TO TRAP TO EMT VECTOR
1799 006274 000064              .WORD  64              ;UNIQUE ERROR NUMBER
1800 006276 002013              .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
1801                                     ;NO GO TO ERROR
1802 006300 012701 000004      2$:  MOV      #4,R1          ;INIT COUNTER
1803 006304 022227 177777      3$:  CMP     (R2)+,#177777  ;IS LOCATION ALL ONES
1804 006310 001403              BEQ     4$              ;YES GO ON
1805 006312 104000              ERKOR   ;ALL ERRORS TO TRAP TO EMT VECTOR
1806 006314 000065              .WORD  65              ;UNIQUE ERROR NUMBER
1807 006316 002013              .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
1808                                     ;NO GO TO ERROR
1809 006320 077107              4$:  SOB      R1,3$          ;ARE WE DONE
1810 006322 012701 000004      MOV      #4,R1          ;INIT COUNTER
1811 006326 022227 000000      5$:  CMP     (R2)+,#0       ;IS LOCATION 0
1812 006332 001403              BEQ     6$              ;YES GO ON
1813 006334 104000              ERKOR   ;ALL ERRORS TO TRAP TO EMT VECTOR
1814 006336 000066              .WORD  66              ;UNIQUE ERROR NUMBER
1815 006340 002013              .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
1816                                     ;NO GO TO ERROR
1817 006342 077107              6$:  SOB      R1,5$          ;ARE WE DONE
1818 006344 020327 000204      CMP     R3,#204        ;CHECK FPS
1819 006350 001403              BEQ     7$              ;OK GO ON
1820 006352 104000              ERKOR   ;ALL ERRORS TO TRAP TO EMT VECTOR
1821 006354 000067              .WORD  67              ;UNIQUE ERROR NUMBER
1822 006356 002013              .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
1823                                     ;NO GO TO ERROR
1824 006360 012637 000004      7$:  MOV      (SP)+,#0$     ;RESTORE VECTOR
1825
1826
1827 006364 000167 000010      ;
1828                                     ;
1829                                     ;TSF15:
1830 006370 104000              ERKOR   ;ALL ERRORS TO TRAP TO EMT VECTOR
1831 006372 000070              .WORD  70              ;UNIQUE ERROR NUMBER
1832 006374 002013              .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
1833                                     ;ODD ADDRESS TRAP
1834 006376 000006              RTT                    ;RETURN
1835
1836                                     ;
1837                                     ;FIN15:
1838 006400                                     ;TSFP16:

```



```

1839
1840
1841
1842 006400
1843 006400 005267 172400
1844 006404 013746 000004
1845 006410 012737 006562 000004
1846 006416 005037 002122
1847 006422 012702 000200
1848 006426 170102
1849 006430 012705 000010
1850 006434 012704 001136
1851 006440 012724 177777
1852 006444 077503
1853 006446 012702 001146
1854 006452 170442
1855 006454 170203
1856 006456 020227 001136
1857 006462 001403
1858 006464 104000
1859 006466 000071
1860 006470 002013
1861
1862 006472 012701 000004
1863 006476 022227 000000
1864 006502 001403
1865 006504 104000
1866 006506 000072
1867 006510 002013
1868
1869 006512 077107
1870 006514 012701 000004
1871 006520 022227 177777
1872 006524 001403
1873 006526 104000
1874 006530 000073
1875 006532 002013
1876
1877 006534 077107
1878 006536 020327 000204
1879 006542 001403
1880 006544 104000
1881 006546 000074
1882 006550 002013
1883
1884 006552 012637 000004
1885
1886
1887 006556 000167 000010
1888
1889 006562
1890 006562 104000
1891 006564 000075
1892 006566 002013
1893
1894 006570 000006

```

```

*****
; *TEST 20 TEST FDST SOP MODE 4
*****
TST20:
INC $TESTN ; INCREMENT TEST NUMBER
MOV $04,-(SP) ; SAVE TIMEOUT VECTOR
MOV $TSF16,$04 ; SETUP NEW VECTOR
CLR $TRPFLG ; CLEAR TRAP FLAG
MOV $200,R2 ; SETUP TO LOAD FPS
LDFPS R2 ; SET FD=1
MOV $8,R5 ; INIT COUNTER
MOV $TSTLOC,R4 ; SETUP POINTER TO TEST LOCATION
100$: MOV $177777,(R4) ; INIT TEST LOCATION
SOB R5,100$ ; ARE WE DONE
MOV $TSTLOC+10,R2 ; SETUP POINTER TO DATA
CLRD -(R2) ; TEST INSTRUCTION
STFPS R3 ; GET FPS
CMP R2,$TSTLOC ; IS R2 CORRECT
BEQ 1$ ; YES GO ON
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 71 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
MOV $4,R1 ; INIT COUNTER
2$: CMP (R2)+,$0 ; IS LOCATION 0
BEQ 3$ ; YES GO ON
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 72 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
3$: SOB R1,2$ ; ARE WE DONE
MOV $4,R1 ; INIT COUNTER
4$: CMP (R2)+,$177777 ; IS LOCATION UNCHANGED
BEQ 5$ ; YES GO ON
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 73 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
5$: SOB R1,4$ ; ARE WE DONE
CMP R3,$204 ; CHECK FPS
BEQ 6$ ; OK GO ON
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 74 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
6$: MOV (SP)+,$04 ; RESTORE VECTOR
;
JMP FIN16
;
;TSF16:
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 75 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
;ODD ADDRESS TRAP
RTT ; RETURN

```

```

1895
1896 006572
1897
1898 006572
1899
1900
1901
1902 006572
1903 006572 005267 172206
1904 006576 013746 000004
1905 006602 012737 006776 000004
1906 006610 005037 002122
1907 006614 012702 000200
1908 006620 170102
1909 006622 012705 000011
1910 006626 012704 001136
1911 006632 012724 177777
1912 006636 077503
1913 006640 012737 001150 001136
1914 006646 012702 001140
1915 006652 170452
1916 006654 170203
1917 006656 020227 001136
1918 006662 001403
1919 006664 104000
1920 006666 000076
1921 006670 002013
1922
1923 006672 022227 001150
1924 006676 001403
1925 006700 104000
1926 006702 000077
1927 006704 002013
1928
1929 006706 012701 000004
1930 006712 022227 177777
1931 006716 001403
1932 006720 104000
1933 006722 000100
1934 006724 002013
1935
1936 006726 077107
1937 006730 012701 000004
1938 006734 022227 000000
1939 006740 001403
1940 006742 104000
1941 006744 000101
1942 006746 002013
1943
1944 006750 077107
1945 006752 020327 000204
1946 006756 001403
1947 006760 104000
1948 006762 000102
1949 006764 002013
1950

;
FIN16:
;
;TSFP17:
;*****
;TEST 21 TEST FDST SOP MODE 5
;*****
TST21:
INC $TESTN ;INCREMENT TEST NUMBER
MOV $04,-(SP) ;SAVE TIMEOUT VECTOR
MOV $TSF17,$04 ;SETUP NEW VECTOR
CLR $TRPFLG ;CLEAR TRAP FLAG
MOV $200,R2 ;SETUP TO LOAD FPS
LDFPS R2 ;SET FD=1
MOV $9,R5 ;INIT COUNTER
MOV $TSTLOC,R4 ;SETUP POINTER TO TEST LOCATION
100$: MOV $177777,(R4) ;INIT TEST LOCATION
SOB R5,100$ ;ARE WE DONE
MOV $TSTLOC+12,$TSTLOC ;INIT TEST LOCATION
MOV $TSTLOC+2,R2 ;SETUP POINTER TO DATA
CLRD $-(R2) ;TEST INSTRUCTION
STFPS R3 ;GET FPS
CMP R2,$TSTLOC ;IS R2 CORRECT
BEQ 1$ ;YES GO ON
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 76 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
1$: CMP (R2)+,$TSTLOC+12 ;IS DATA CORRECT
BEQ 2$ ;YES GO ON
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 77 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
2$: MOV $4,R1 ;INIT COUNTER
3$: CMP (R2)+,$177777 ;IS LOCATION ALL ONES
BEQ 4$ ;YES GO ON
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 100 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
4$: SOB R1,3$ ;ARE WE DONE
MOV $4,R1 ;INIT COUNTER
5$: CMP (R2)+,$0 ;IS LOCATION 0
BEQ 6$ ;YES GO ON
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 101 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR
6$: SOB R1,5$ ;ARE WE DONE
CMP R3,$204 ;CHECK FPS
BEQ 7$ ;OK GO ON
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 102 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;NO GO TO ERROR

```

```

1951 006766 012637 000004 7$: MOV (SP),@04 ;RESTORE VECTOR
1952
1953 ;
1954 006772 000167 000010 ; JMP FIN17
1955 ;
1956 006776 ;TSF17:
1957 006776 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1958 007000 000103 .WORD 103 ;UNIQUE ERROR NUMBER
1959 007002 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1960 ;
1961 007004 000006 RTT ;ODD ADDRESS TRAP
1962 ;
1963 007006 ;FIN17:
1964 ;
1965 007006 ;TSFP20:
1966 ;*****
1967 ;+TEST 22 TEST FDST SOP MODE 6
1968 ;*****
1969 007006 TST22:
1970 007006 005267 171772 INC #TESTN ;INCREMENT TEST NUMBER
1971 007012 005037 002122 CLR @TRPFLG ;CLEAR TRAP FLAG
1972 007016 013746 000004 MOV @4,-(SP) ;SAVE TIMEOUT VECTOR
1973 007022 012737 007176 000004 MOV @TSF20,@04 ;SETUP NEW VECTOR
1974 007030 012702 000200 MOV @200,R2 ;SETUP TO LOAD FPS
1975 007034 170102 LDFPS R2 ;SET FD=1
1976 007036 012705 000010 MOV @8,R5 ;INIT COUNTER
1977 007042 012704 001136 MOV @TSTLOC,R4 ;SETUP POINTER TO TEST LOCATION
1978 007046 012724 177777 100$: MOV @177777,(R4) ;INIT TEST LOCATION
1979 007052 077503 SOB R5,100$ ;ARE WE DONE
1980 007054 012702 001137 MOV @TSTLOC+1,R2 ;SETUP POINTER TO DATA
1981 007060 170462 000007 CLRD 7(R2) ;TEST INSTRUCTION
1982 007064 170203 STFPS R3 ;GET FPS
1983 007066 020227 001137 CMP R2,@TSTLOC+1 ;IS R2 CORRECT
1984 007072 001403 BEQ 1$ ;YES GO ON
1985 007074 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1986 007076 000104 .WORD 104 ;UNIQUE ERROR NUMBER
1987 007100 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1988 ;NO GO TO ERROR
1989 007102 012702 001136 1$: MOV @TSTLOC,R2 ;SETUP POINTER TO DATA
1990 007106 012701 000004 MOV @4,R1 ;INIT COUNTER
1991 007112 022227 177777 2$: CMP (R2),@177777 ;IS DATA CORRECT
1992 007116 001403 BEQ 3$ ;YES GO ON
1993 007120 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
1994 007122 000105 .WORD 105 ;UNIQUE ERROR NUMBER
1995 007124 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
1996 ;NO GO TO ERROR
1997 007126 077107 3$: SOB R1,2$ ;ARE WE DONE
1998 007130 012701 000004 MOV @4,R1 ;INIT COUNTER
1999 007134 022227 000000 4$: CMP (R2),@0 ;IS DATA CORRECT
2000 007140 001403 BEQ 5$ ;YES GO ON
2001 007142 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
2002 007144 000106 .WORD 106 ;UNIQUE ERROR NUMBER
2003 007146 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
2004 ;NO GO TO ERROR
2005 007150 077107 5$: SOB R1,4$ ;ARE WE DONE
2006 007152 020327 000204 CMP R3,@204 ;IS FPS CORRECT

```

```

2007 007156 001403          BEQ      6$          ;YES GO ON
2008 007160 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2009 007162 000107          .WORD    107        ;UNIQUE ERROR NUMBER
2010 007164 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2011                                     ;NO GO TO ERROR
2012 007166 012637 000004    6$:      MOV      (SP)+,0$4 ;RESTORE VECTOR
2013
2014
2015 007172 000167 000010    ;
2016                                     ;
2017                                     ;TSF20:
2018 007176 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2019 007200 000110          .WORD    110        ;UNIQUE ERROR NUMBER
2020 007202 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2021                                     ;ODD ADDRESS TRAP
2022 007204 000006          RTT        ;RETURN
2023
2024 007206          ;
2025                                     ;
2026 007206          ;TSFP21:
2027                                     ;*****
2028                                     ;*TEST 23      TEST FDST SOP MODE 7
2029                                     ;*****
2030 007206          ;TST23:
2031 007206 005267 171572          INC      $TESTN     ;INCREMENT TEST NUMBER
2032 007212 005037 002122          CLR      @TRPFLG    ;CLEAR TRAP FLAG
2033 007216 013746 000004          MOV      @4,-(SP)   ;SAVE TIMEOUT VECTOR
2034 007222 012737 007420 000004    MOV      @TSF21,0$4 ;SETUP NEW VECTOR
2035 007230 012702 000200          MOV      @200,R2    ;SETUP TO LOAD FPS
2036 007234 170102          LDFPS    R2         ;SET FD=1
2037 007236 012705 000010          MOV      @8.,R5     ;INIT COUNTER
2038 007242 012704 001136          MOV      @TSTLOC,R4 ;SETUP POINTER TO TEST LOCATION
2039 007246 012724 177777          100$:    MOV      @177777,(R4). ;INIT TEST LOCATION
2040 007252 077503          SOB      R5,100$    ;ARE WE DONE
2041 007254 012737 001136 001146    MOV      @TSTLOC,@TSTLOC+10 ;INIT TEST LOCATION
2042 007262 012702 001141          MOV      @TSTLOC+3,R2 ;SETUP POINTER TO DATA
2043 007266 170472 000005          CLRD    @5(R2)     ;***TEST INSTRUCTION***
2044 007272 170203          STFPS   R3         ;GET FPS
2045 007274 020227 001141          CMP      R2,@TSTLOC+3 ;IS R2 CORRECT
2046 007300 001403          BEQ      1$        ;YES GO ON
2047                                     ;NO GO TO ERROR
2048 007302 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2049 007304 000111          .WORD    111        ;UNIQUE ERROR NUMBER
2050 007306 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2051 007310 012702 001136          1$:      MOV      @TSTLOC,R2  ;SETUP POINTER TO DATA
2052 007314 012701 000004          MOV      @4,R1      ;INIT COUNTER
2053 007320 022227 000000          2$:      CMP      (R2)+,0$0 ;IS DATA CORRECT
2054 007324 001403          BEQ      3$        ;YES GO ON
2055 007326 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2056 007330 000112          .WORD    112        ;UNIQUE ERROR NUMBER
2057 007332 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2058                                     ;NO GO TO ERROR
2059 007334 077107          3$:      SOB      R1,2$    ;ARE WE DONE
2060 007336 022227 001136          CMP      (R2)+,@TSTLOC ;IS DATA CORRECT
2061 007342 001403          BEQ      4$        ;YES GO ON
2062 007344 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR

```



```

2119 007536 077107          2$: SOB      R1,1$          ;ARE WE DONE
2120 007540 012701 000004   MOV      #4,R1          ;INIT COUNTER
2121 007544 022227 177777   3$: CMP      (R2)+,#177777 ;IS DATA CORRECT
2122 007550 001403          BEQ      4$             ;YES GO ON
2123 007552 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
2124 007554 000120          .WORD   120            ;UNIQUE ERROR NUMBER
2125 007556 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
2126                                     ;NO GO TO ERROR
2127 007560 077107          4$: SOB      R1,3$          ;ARE WE DONE
2128 007562 020327 000204   CMP      R3,#204        ;CHECK FPS
2129 007566 001403          BEQ      5$             ;OK GO ON
2130 007570 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
2131 007572 000121          .WORD   121            ;UNIQUE ERROR NUMBER
2132 007574 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
2133                                     ;NO GO TO ERROR
2134 007576 012637 000004   5$: MOV      (SP)+,#04    ;RESTORE VECTOR
2135
2136 ;
2137 007602 000167 000010   ; JMP      FIN22
2138 ;
2139 ;TSF22:
2140 007606 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
2141 007610 000122          .WORD   122            ;UNIQUE ERROR NUMBER
2142 007612 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
2143                                     ;ODD ADDRESS TRAP
2144 007614 000006          RTT                    ;RETURN
2145
2146 ;FIN22:
2147 ;
2148 ;TSFP23:
2149 ;
2150 ;*****
2151 ;*TEST 25          TEST FDST SOP MODE 6 GR7
2152 ;*****
2153 007616 005267 171162   TST25: INC      $TESTN          ;INCREMENT TEST NUMBER
2154 007622 005037 002122   CLR      @TRPFLG        ;CLEAR TRAP FLAG
2155 007626 013746 000004   MOV      @4,-(SP)        ;SAVE TIMEOUT VECTOR
2156 007632 012737 007744 000004   MOV      @TSF23,@4       ;SETUP NEW VECTOR
2157 007640 012702 000200   MOV      @200,R2         ;SETUP TO LOAD FPS
2158 007644 170102          LDFPS   R2               ;SET FD=1
2159 007646 012705 000004   MOV      #4,R5           ;INIT COUNTER
2160 007652 012704 001136   MOV      @TSTLOC,R4      ;SETUP POINTER TO TEST LOCATION
2161 007656 012724 177777   100$: MOV      @177777,(R4)+ ;INIT TEST LOCATION
2162 007662 077503          SOB      R5,100$        ;ARE WE DONE
2163 007664 170467 171246   CLRD    TSTLOC          ; TEST INSTRUCTION
2164 007670 170203          STFPS   R3               ;GET FPS
2165 007672 012701 000004   MOV      #4,R1           ;INIT COUNTER
2166 007676 012702 001136   MOV      @TSTLOC,R2      ;SETUP POINTER TO DATA
2167 007702 022227 000000   1$: CMP      (R2)+,#0    ;IS DATA CORRECT
2168 007706 001403          BEQ      2$             ;YES GO ON
2169 007710 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
2170 007712 000123          .WORD   123            ;UNIQUE ERROR NUMBER
2171 007714 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
2172                                     ;NO GO TO ERROR
2173 007716 077107          2$: SOB      R1,1$          ;ARE WE DONE
2174 007720 020327 000204   CMP      R3,#204        ;CHECK FPS

```

```

2175 007724 001403          BEQ      3$          ;OK GO ON
2176 007726 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2177 007730 000124          .WORD    124        ;UNIQUE ERROR NUMBER
2178 007732 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2179                                ;NO GO TO ERROR
2180 007734 012637 000004    3$:      MOV      (SP)+,0#4 ;RESTORE VECTOR
2181
2182                                ;
2183 007740 000167 000010    ;        JMP      FIN23
2184                                ;
2185                                ;TSF23:
2186 007744 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2187 007746 000125          .WORD    125        ;UNIQUE ERROR NUMBER
2188 007750 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2189                                ;ODD ADDRESS TRAP
2190 007752 000006          RTT
2191 007754
2192                                ;
2193 007754          FIN23:
2194                                ;
2195                                ;TSFP24:
2196                                ;*****
2197                                ;*TEST 26      TEST FDST SOP MODE 7 GR7
2198                                ;*****
2199                                ;TST26:
2198 007754 005267 171024          INC      $TESTN     ;INCREMENT TEST NUMBER
2199 007760 005037 002122          CLR      @TRPFLG   ;CLEAR TRAP FLAG
2200 007764 013746 000004          MOV      @#4,-(SP) ;SAVE TIMEOUT VECTOR
2201 007770 012737 010146 000004    MOV      @TSF24,@#4 ;SETUP NEW VECTOR
2202 007776 012702 000200          MOV      @200,R2   ;SETUP TO LOAD FPS
2203 010002 170102          LDFPS   R2         ;SET FD=1
2204 010004 012705 000010          MOV      @8,R5     ;INIT COUNTER
2205 010010 012704 001136          MOV      @TSTLOC,R4 ;SETUP TEST LOCATION POINTER
2206 010014 012724 177777          100$:   MOV      @177777,(R4)+ ;INIT TEST LOCATION
2207 010020 077503          SOB      R5,100$   ;ARE WE DONE
2208 010022 012737 001136 001146    MOV      @TSTLOC,@TSTLOC+10 ;INIT TEST LOCATION
2209 010030 170477 171112          CLRD    @TSTLOC+10 ;***TEST INSTRUCTION***
2210 010034 170203          STFPS   R3         ;GET FPS
2211 010036 012702 001136          MOV      @TSTLOC,R2 ;SETUP POINTER TO DATA
2212 010042 012701 000004          MOV      @4,R1     ;INIT COUNTER
2213 010046 022227 000000          1$:     CMP      (R2)+,0#0 ;IS DATA CORRECT
2214 010052 001403          BEQ      2$        ;YES GO ON
2215                                ;NO, GO TO ERROR
2216 010054 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2217 010056 000126          .WORD    126        ;UNIQUE ERROR NUMBER
2218 010060 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2219 010062 077107          SOB      R1,1$     ;ARE WE DONE
2220 010064 022227 001136          2$:     CMP      (R2)+,@TSTLOC ;IS DATA CORRECT
2221 010070 001403          BEQ      3$        ;YES GO ON
2222                                ;NO, GO TO ERROR
2223 010072 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2224 010074 000127          .WORD    127        ;UNIQUE ERROR NUMBER
2225 010076 002013          .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2226 010100 012701 000003          3$:     MOV      @3,R1     ;INIT COUNTER
2227 010104 022227 177777          4$:     CMP      (R2)+,@177777 ;IS DATA CORRECT
2228 010110 001403          BEQ      5$        ;YES GO ON
2229 010112 104000          ERROR     ;ALL ERRORS TO TRAP TO EMT VECTOR
2230 010114 000130          .WORD    130        ;UNIQUE ERROR NUMBER

```

```

2231 010116 002013          .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
2232                                     ;NO GO TO ERROR
2233 010120 077107          SOB    R1,4$           ;ARE WE DONE
2234 010122 020327 000204   CMP    R3,#204        ;CHECK FPS
2235 010126 001403          BEQ    6$              ;OK GO ON
2236 010130 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
2237 010132 000131          .WORD  131            ;UNIQUE ERROR NUMBER
2238 010134 002013          .WORD  FPPERR        ;ADDRESS OF ERROR MESSAGE
2239                                     ;NO GO TO ERROR
2240 010136 012637 000004   MOV    (SP),#0#4     ;RESTORE VECTOR
2241                                     ;
2242                                     ;
2243 010142 000167 000010   JMP    FIN24
2244                                     ;
2245 010146          TSF24:
2246 010146 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
2247 010150 000132          .WORD  132            ;UNIQUE ERROR NUMBER
2248 010152 002013          .WORD  FPPERR        ;ADDRESS OF ERROR MESSAGE
2249                                     ;ODD ADDRESS TRAP
2250 010154 000006          RTT
2251                                     ;
2252 010156          ;FIN24:
2253                                     ;
2254 010156          ;TSFP25:
2255                                     ;*****
2256                                     ;*TEST 27          TEST CLRF
2257                                     ;*****
2258 010156          TST27:
2259 010156 005267 170622   INC    #TESTN        ;INCREMENT TEST NUMBER
2260 010162 005037 002122   CLR    @TRPFLG      ;CLEAR TRAP FLAG
2261 010166 005002          CLR    R2            ;SETUP TO LOAD FPS
2262 010170 170102          LDFPS R2            ;SET FD=0
2263 010172 012705 000004   MOV    #4,R5        ;INIT COUNTER
2264 010176 012704 001136   MOV    #TSTLOC,R4   ;SETUP POINTER TO TEST LOCATION
2265 010202 012724 177777   MOV    #177777,(R4) ;INIT TEST LOCATION
2266 010206 077503          SOB    R5,100$      ;ARE WE DONE
2267 010210 012702 001136   MOV    #TSTLOC,R2   ;SETUP POINTER TO DATA
2268 010214 170422          CLRF  (R2),         ; TEST INSTRUCTION
2269 010216 170203          STFPS R3            ;GET FPS
2270 010220 020227 001142   CMP    R2,#TSTLOC+4 ;IS R2 CORRECT
2271 010224 001403          BEQ    1$           ;YES GO ON
2272                                     ;NO, GO TO ERROR
2273 010226 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
2274 010230 000133          .WORD  133            ;UNIQUE ERROR NUMBER
2275 010232 002013          .WORD  FPPERR        ;ADDRESS OF ERROR MESSAGE
2276 010234 012702 001136   MOV    #TS1LOC,R2   ;SETUP POINTER TO DATA
2277 010240 012701 000002   MOV    #2,R1        ;INIT COUNTER
2278 010244 022227 000000   CMP    (R2),#0      ;IS DATA CORRECT
2279 010250 001403          BEQ    3$           ;YES GO ON
2280                                     ;NO, GO TO ERROR
2281 010252 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
2282 010254 000134          .WORD  134            ;UNIQUE ERROR NUMBER
2283 010256 002013          .WORD  FPPERR        ;ADDRESS OF ERROR MESSAGE
2284 010260 077107          SOB    R1,2$        ;ARE WE DONE
2285 010262 012701 000002   MOV    #2,R1        ;INIT COUNTER
2286 010266 022227 177777   CMP    (R2),#177777 ;IS DATA CORRECT

```



```

2287 010272 001403          BEQ      5$          ;YES GO ON
2288                                ;NO GO TO ERROR
2289 010274 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
2290 010276 000135          .WORD      135          ;UNIQUE ERROR NUMBER
2291 010300 002013          .WORD          ;ADDRESS OF ERROR MESSAGE
2292 010302 077107          SOB      R1,4$          ;ARE WE DONE
2293 010304 020327 000004 5$:      CMP      R3,#4          ;CHECK FPS
2294 010310 001403          BEQ      6$          ;OK GO ON
2295                                ;NO, GO TO ERROR
2296 010312 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
2297 010314 000136          .WORD      136          ;UNIQUE ERROR NUMBER
2298 010316 002013          .WORD          ;ADDRESS OF ERROR MESSAGE
2299 010320
2300
2301
2302 010320          ;
2303          ;TSFP26:
2304          ;:*****
2305          ;*TEST 30      TEST TSTF AND TSTD
2306          ;:*****
2307 010320 005267 170460          TST30:
2308 010324 005037 002122          INC      $TESTN          ;INCREMENT TEST NUMBER
2309 010330 005004          CLR      @TRPFLG          ;CLEAR TRAP FLAG
2310 010332 170104          CLR      R4          ;SETUP TO LOAD FPS
2311 010334 170567 000300          LDFPS   R4          ;SET FD=0
2312 010340 170203          TSTF    TS26D0          ;***TEST INSTRUCTION***
2313 010342 020327 000004          STFPS   R3          ;GET FPS
2314 010346 001403          CMP      R3,#4          ;CHECK FPS
2315                                BEQ      1$          ;OK GO ON
2316 010350 104000          ERROR          ;NO, GO TO ERROR
2317 010352 000137          .WORD      137          ;ALL ERRORS TO TRAP TO EMT VECTOR
2318 010354 002013          .WORD          ;UNIQUE ERROR NUMBER
2319 010356 012704 010640          .WORD          ;ADDRESS OF ERROR MESSAGE
2320 010362 012702 010670          1$:      MOV      @TS26D0,R4          ;SETUP POINTERS TO DATA
2321 010366 004767 000224          MOV      @TS26D3,R2
2322 010372 170537 010650          JSR     PC,CHEC26
2323 010376 170203          TSTF    @TS26D1
2324 010400 020327 000010          STFPS   R3          ;CHECK IF DATA IS CORRECT
2325 010404 001403          CMP      R3,#10          ;***TEST INSTRUCTION***
2326                                BEQ      2$          ;GET FPS
2327 010406 104000          ERROR          ;CHECK FPS
2328 010410 000140          .WORD      140          ;OK GO ON
2329 010412 002013          .WORD          ;NO, GO TO ERROR
2330 010414 012704 010650          .WORD          ;ALL ERRORS TO TRAP TO EMT VECTOR
2331 010420 012702 010700          2$:      MOV      @TS26D1,R4          ;UNIQUE ERROR NUMBER
2332 010424 004767 000166          MOV      @TS26D4,R2          ;ADDRESS OF ERROR MESSAGE
2333 010430 170567 000224          JSR     PC,CHEC26          ;SETUP POINTERS TO DATA
2334 010434 170203          TSTF    TS26D2
2335 010436 020327 000000          STFPS   R3          ;CHECK IF DATA IS CORRECT
2336 010442 001403          CMP      R3,#0          ;***TEST INSTRUCTION***
2337                                BEQ      3$          ;GET FPS
2338 010444 104000          ERROR          ;CHECK FPS
2339 010446 000141          .WORD      141          ;OK GO ON
2340 010450 002013          .WORD          ;NO, GO TO ERROR
2341 010452 012704 010660          .WORD          ;ALL ERRORS TO TRAP TO EMT VECTOR
2342 010456 012702 010710          3$:      MOV      @TS26D2,R4          ;UNIQUE ERROR NUMBER
          MOV      @TS26D5,R2          ;ADDRESS OF ERROR MESSAGE
          ;SETUP POINTERS TO DATA
          ;

```


2399 010660 077777
 2400 010662 000000
 2401 010664 000000
 2402 010666 000000
 2403 010670 000177
 2404 010672 177777
 2405 010674 177777
 2406 010676 177777
 2407 010700 177777
 2408 010702 000000
 2409 010704 000000
 2410 010706 000000
 2411 010710 077777
 2412 010712 000000
 2413 010714 000000
 2414 010716 000000
 2415 010720
 2416
 2417 010720
 2418
 2419
 2420
 2421 010720
 2422 010720 005267 170060
 2423 010724 005037 002122
 2424 010730 005005
 2425 010732 170105
 2426 010734 012701 000014
 2427 010740 012704 001136
 2428 010744 012703 011204
 2429 010750 012324
 2430 010752 077102
 2431 010754 012705 001136
 2432 010760 170615
 2433 010762 170203
 2434 010764 020527 001136
 2435 010770 001403
 2436
 2437 010772 104000
 2438 010774 000146
 2439 010776 002013
 2440 011000 012702 011234
 2441 011004 004767 000152
 2442 011010 020327 000000
 2443 011014 001403
 2444
 2445 011016 104000
 2446 011020 000147
 2447 011022 002013
 2448 011024 012705 001146
 2449 011030 170625
 2450 011032 170203
 2451 011034 020527 001152
 2452 011040 001403
 2453
 2454 011042 104000

TS26D2: .WORD 77777
 .WORD 0
 .WORD 0
 .WORD 0
 TS26D3: .WORD 177
 .WORD 177777
 .WORD 177777
 .WORD 177777
 TS26D4: .WORD 177777
 .WORD 0
 .WORD 0
 .WORD 0
 TS26D5: .WORD 77777
 .WORD 0
 .WORD 0
 .WORD 0

FIN26:

TSFP27:

```

:*****
:*TEST 31      TEST ABSF
:*****

```

TST31:

```

      INC      #TESTN      ;INCREMENT TEST NUMBER
      CLR      @TRPFLG     ;CLEAR TRAP FLAG
      CLR      R5          ;SETUP TO LOAD FPS
      LDFPS    R5          ;SET FD=0
      MOV      @12.,R1     ;INIT COUNTER
      MOV      @TSTLOC,R4  ;SETUP POINTER TO TEST LOCATION
      MOV      @TS27D0,R3  ;SETUP POINTER TO TEST VALUE
100$: MOV      (R3), (R4)   ;INIT TEST LOCATION
      SOB      R1,100$     ;ARE WE DONE
      MOV      @TSTLOC,R5  ;SETUP POINTER TO DATA
      ABSF     (R5)        ;***TEST INSTRUCTION***
      STFPS    R3          ;GET FPS
      CMP      R5,@TSTLOC  ;IS R5 CORRECT
      BEQ      1$         ;YES GO ON
                          ;NO, GO TO ERROR
                          ;ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD    146        ;UNIQUE ERROR NUMBER
      .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
1$:  MOV      @TS27D3,R2   ;SETUP POINTER TO DATA
      JSR      PC,CHEC27   ;CHECK IF DATA IS CORRECT
      CMP      R3,#0      ;CHECK FPS
      BEQ      2$         ;OK GO ON
                          ;NO, GO TO ERROR
                          ;ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD    147        ;UNIQUE ERROR NUMBER
      .WORD    FPPERR     ;ADDRESS OF ERROR MESSAGE
2$:  MOV      @TSTLOC+10,R5 ;SETUP POINTER TO DATA
      ABSF     (R5)        ;***TEST INSTRUCTION***
      STFPS    R3          ;GET FPS
      CMP      R5,@TSTLOC+14 ;IS R5 CORRECT
      BEQ      3$         ;YES GO ON
                          ;NO, GO TO ERROR
                          ;ALL ERRORS TO TRAP TO EMT VECTOR
      ERROR

```

2455	011044	000150			.WORD	150					
2456	011046	002013			.WORD	FPPERR					
2457	011050	012705	001146	3\$:	MOV	#TSTLOC+10,R5					
2458	011054	012702	011244		MOV	#TS27D4,R2					
2459	011060	004767	000076		JSR	PC,CHEC27					
2460	011064	020327	000000		CMP	R3,#0					
2461	011070	001403			BEQ	4\$					
2462											
2463	011072	104000			ERROR						
2464	011074	000151			.WORD	151					
2465	011076	002013			.WORD	FPPERR					
2466	011100	012705	001136	4\$:	MOV	#TSTLOC,R5					
2467	011104	170665	000020		ABSF	20(R5)					
2468	011110	170203			STFPS	R3					
2469	011112	020527	001136		CMP	R5,#TSTLOC					
2470	011116	001403			BEQ	5\$					
2471											
2472	011120	104000			ERROR						
2473	011122	000152			.WORD	152					
2474	011124	002013			.WORD	FPPERR					
2475	011126	012705	001156	5\$:	MOV	#TSTLOC+20,R5					
2476	011132	012702	011254		MOV	#TS27D5,R2					
2477	011136	004767	000020		JSR	PC,CHEC27					
2478	011142	020327	000004		CMP	R3,#4					
2479	011146	001403			BEQ	6\$					
2480											
2481	011150	104000			ERROR						
2482	011152	000153			.WORD	153					
2483	011154	002013			.WORD	FPPERR					
2484	011156			6\$:							
2485											
2486											
2487	011156	000167	000102		JMP	FIN27					
2488											
2489	011162	012701	000004		CHEC27: MOV	#4,R1					
2490	011166	022522		1\$:	CMP	(R5),.(R2),					
2491	011170	001403			BEQ	2\$					
2492											
2493	011172	104000			ERROR						
2494	011174	000154			.WORD	154					
2495	011176	002013			.WORD	FPPERR					
2496	011200	077106		2\$:	SOB	R1,1\$					
2497	011202	000207			RTS	PC					
2498											
2499	011204	177777			TS27D0: .WORD	177777					
2500	011206	177777			.WORD	177777					
2501	011210	177777			.WORD	177777					
2502	011212	177777			.WORD	177777					
2503	011214	000377			TS27D1: .WORD	377					
2504	011216	175436			.WORD	175436					
2505	011220	136477			.WORD	136477					
2506	011222	000001			.WORD	1					
2507	011224	000177			TS27D2: .WORD	177					
2508	011226	175436			.WORD	175436					
2509	011230	136477			.WORD	136477					
2510	011232	000001			.WORD	1					

```

;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;SETUP POINTER TO DATA
;
;CHECK IF DATA IS CORRECT
;CHECK FPS
;OK GO ON
;NO, GO TO ERROR
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;SETUP POINTER TO DATA
;***TEST INSTRUCTION***
;GET FPS
;IS R5 CORRECT
;YES GO ON
;NO, GO TO ERROR
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;SETUP POINTERS TO DATA
;
;CHECK IF DATA IS CORRECT
;CHECK FPS
;OK GO ON
;NO, GO TO ERROR
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;
;INIT COUNTER
;IS DATA CORRECT
;YES GO ON
;NO, GO TO ERROR
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;ARE WE DONE
;RETURN
    
```

2511 011234 077777
 2512 011236 177777
 2513 011240 177777
 2514 011242 177777
 2515 011244 000377
 2516 011246 175436
 2517 011250 136477
 2518 011252 000001
 2519 011254 000000
 2520 011256 000000
 2521 011260 136477
 2522 011262 000001
 2523 011264
 2524
 2525 011264
 2526
 2527
 2528
 2529 011264
 2530 011264 005267 167514
 2531 011270 005037 002122
 2532 011274 012705 000200
 2533 011300 170105
 2534 011302 012701 000014
 2535 011306 012704 001136
 2536 011312 012703 011552
 2537 011316 012324
 2538 011320 077102
 2539 011322 012705 001136
 2540 011326 170615
 2541 011330 170203
 2542 011332 020527 001136
 2543 011336 001403
 2544
 2545 011340 104000
 2546 011342 000155
 2547 011344 002013
 2548 011346 012702 011602
 2549 011352 004767 000152
 2550 011356 020327 000200
 2551 011362 001403
 2552
 2553 011364 104000
 2554 011366 000156
 2555 011370 002013
 2556 011372 012705 001146
 2557 011376 170625
 2558 011400 170203
 2559 011402 020527 001156
 2560 011406 001403
 2561
 2562 011410 104000
 2563 011412 000157
 2564 011414 002013
 2565 011416 012705 001146
 2566 011422 012702 011612

TS27D3: .WORD 77777
 .WORD 177777
 .WORD 177777
 .WORD 177777
 TS27D4: .WORD 377
 .WORD 175436
 .WORD 136477
 .WORD 1
 TS27D5: .WORD 0
 .WORD 0
 .WORD 136477
 .WORD 1
 FIN27:
 ;
 TSFP30:
 ;:*****
 ;*TEST 32 TEST ABSD
 ;:*****
 TST32:
 INC #TESTN ;INCREMENT TEST NUMBER
 CLR #TRPFLG ;CLEAR TRAP FLAG
 MOV #200,R5 ;SETUP TO LOAD FPS
 LDFPS R5 ;SET FD=1
 MOV #12.,R1 ;INIT COUNTER
 MOV #TSTLOC,R4 ;SETUP POINTER TO TEST LOCATION
 MOV #TS30D0,R3 ;SETUP POINTER TO TEST VALUE
 100\$: MOV (R3)+,(R4)+ ;INIT TEST LOCATION
 SOB R1,100\$;ARE WE DONE
 MOV #TSTLOC,R5 ;SETUP POINTER TO DATA
 ABSD (R5) ;***TEST INSTRUCTION***
 STFPS R3 ;GET FPS
 CMP R5,#TSTLOC ;IS R5 CORRECT
 BEQ 1\$;YES GO ON
 ;NO, GO TO ERROR
 ;ALL ERRORS TO TRAP TO EMT VECTOR
 .WORD 155 ;UNIQUE ERROR NUMBER
 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
 1\$: MOV #TS30D3,R2 ;SETUP POINTER TO DATA
 JSR PC,CHEC30 ;CHECK IF DATA IS CORRECT
 CMP R3,#200 ;CHECK FPS
 BEQ 2\$;OK GO ON
 ;NO, GO TO ERROR
 ;ALL ERRORS TO TRAP TO EMT VECTOR
 .WORD 156 ;UNIQUE ERROR NUMBER
 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
 2\$: MOV #TSTLOC+10,R5 ;SETUP POINTER TO DATA
 ABSD (R5)+ ;***TEST INSTRUCTION***
 STFPS R3 ;GET FPS
 CMP R5,#TSTLOC+20 ;IS R5 CORRECT
 BEQ 3\$;YES GO ON
 ;NO, GO TO ERROR
 ;ALL ERRORS TO TRAP TO EMT VECTOR
 .WORD 157 ;UNIQUE ERROR NUMBER
 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
 3\$: MOV #TSTLOC+10,R5 ;SETUP POINTERS TO DATA
 MOV #TS30D4,R2 ;

2567	011426	004767	000076		JSR	PC,CHEC30		;CHECK IF DATA IS CORRECT
2568	011432	020327	000200		CMP	R3,#200		;CHECK FPS
2569	011436	001403			BEQ	4:		;OK GO ON
2570								;NO, GO TO ERROR
2571	011440	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2572	011442	000160			.WORD	160		;UNIQUE ERROR NUMBER
2573	011444	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2574	011446	012705	001136	4:	MOV	@TSTLOC,R5		;SETUP POINTER TO DATA
2575	011452	170665	000020		ABSD	20(R5)		;***TEST INSTRUCTION***
2576	011456	170203			STFPS	R3		;GET FPS
2577	011460	020527	001136		CMP	R5,@TSTLOC		;IS R5 CORRECT
2578	011464	001403			BEQ	5:		;YES GO ON
2579								;NO, GO TO ERROR
2580	011466	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2581	011470	000161			.WORD	161		;UNIQUE ERROR NUMBER
2582	011472	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2583	011474	012705	001156	5:	MOV	@TSTLOC+20,R5		;SETUP POINTERS TO DATA
2584	011500	012702	011622		MOV	@TS30D5,R2		
2585	011504	004767	000020		JSR	PC,CHEC30		;CHECK IF DATA IS CORRECT
2586	011510	020327	000204		CMP	R3,#204		;CHECK FPS
2587	011514	001403			BEQ	6:		;OK GO ON
2588								;NO, GO TO ERROR
2589	011516	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2590	011520	000162			.WORD	162		;UNIQUE ERROR NUMBER
2591	011522	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2592	011524			6:				
2593								
2594	011524	000167	000102		JMP	FIN30		
2595								
2596	011530	012701	000004		;			;INIT COUNTER
2597	011534	022522		CHEC30:	MOV	#4,R1		;IS DATA CORRECT
2598	011536	001403		1:	CMP	(R5),.(R2).		;YES GO ON
2599					BEQ	2:		;NO, GO TO ERROR
2600	011540	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2601	011542	000163			.WORD	163		;UNIQUE ERROR NUMBER
2602	011544	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2603	011546	077106		2:	SOB	R1,1:		;ARE WE DONE
2604	011550	000207			RTS	PC		;RETURN
2605								
2606	011552	177777		TS30D0:	.WORD	177777		
2607	011554	177777			.WORD	177777		
2608	011556	177777			.WORD	177777		
2609	011560	177777			.WORD	177777		
2610	011562	000377		TS30D1:	.WORD	377		
2611	011564	175436			.WORD	175436		
2612	011566	136477			.WORD	136477		
2613	011570	000001			.WORD	1		
2614	011572	000177		TS30D2:	.WORD	177		
2615	011574	175436			.WORD	175436		
2616	011576	136477			.WORD	136477		
2617	011600	000001			.WORD	1		
2618	011602	077777		TS30D3:	.WORD	77777		
2619	011604	177777			.WORD	177777		
2620	011606	177777			.WORD	177777		
2621	011610	177777			.WORD	177777		
2622	011612	000377		TS30D4:	.WORD	377		

2679	011772	000006							
2680									
2681	011774								
2682									
2683	011774								
2684									
2685									
2686									
2687	011774								
2688	011774	005267	167004						
2689	012000	005037	002122						
2690	012004	005005							
2691	012006	170105							
2692	012010	012701	000014						
2693	012014	012704	001136						
2694	012020	012703	012210						
2695	012024	012324							
2696	012026	077102							
2697	012030	170767	167102						
2698	012034	170203							
2699	012036	012705	001136						
2700	012042	012702	012240						
2701	012046	004767	000114						
2702	012052	020327	000000						
2703	012056	001403							
2704									
2705	012060	104000							
2706	012062	000170							
2707	012064	002013							
2708	012066	170767	167054						
2709	012072	170203							
2710	012074	012705	001146						
2711	012100	012702	012250						
2712	012104	004767	000056						
2713	012110	020327	000010						
2714	012114	001403							
2715									
2716	012116	104000							
2717	012120	000171							
2718	012122	002013							
2719	012124	170767	167026						
2720	012130	170203							
2721	012132	012705	001156						
2722	012136	012702	012260						
2723	012142	004767	000020						
2724	012146	020327	000004						
2725	012152	001403							
2726									
2727	012154	104000							
2728	012156	000172							
2729	012160	002013							
2730	012162								
2731									
2732	012162	000167	000102						
2733									
2734	012166	012701	000004						

```

RTT
;RETURN
;
; FIN31:
;
; SFP32:
;*****
; *TEST 34      TEST NEGF
;*****
TST34:
    INC      $TESTN      ; INCREMENT TEST NUMBER
    CLR      @TRPFLG     ; CLEAR TRAP FLAG
    CLR      R5          ; SETUP TO LOAD FPS
    LDFPS   R5          ; SET FD=0
    MOV      @12.,R1     ; INIT COUNTER
    MOV      @TSTLOC,R4  ; SETUP POINTER TO TEST LOCATION
    MOV      @TS32D0,R3  ; SETUP POINTER TO TEST VALUE
1000:  MOV      (R3), (R4) ; INIT TEST LOCATION
    SOB     R1,1000     ; ARE WE DONE
    NEGF    TSTLOC      ; ***TEST INSTRUCTION***
    STFPS  R3          ; GET FPS
    MOV     @TSTLOC,R5  ; SETUP POINTERS TO DATA
    MOV     @TS32D3,R2
    JSR    PC,CHEC32
    CMP   R3,#0
    BEQ   1#
;
; ERROR
; .WORD 170
; .WORD FPPERR
; .WORD TSTLOC*10
1#:  NEGF    TSTLOC*10
    STFPS  R3
    MOV     @TSTLOC*10,R5
    MOV     @TS32D4,R2
    JSR    PC,CHEC32
    CMP   R3,#10
    BEQ   2#
;
; ERROR
; .WORD 171
; .WORD FPPERR
; .WORD TSTLOC*20
2#:  NEGF    TSTLOC*20
    STFPS  R3
    MOV     @TSTLOC*20,R5
    MOV     @TS32D5,R2
    JSR    PC,CHEC32
    CMP   R3,#4
    BEQ   3#
;
; ERROR
; .WORD 172
; .WORD FPPERR
3#:
;
; JMP FIN32
;
; CHEC32: MOV     @4,R1      ; INIT COUNTER

```


2735 012172 022522
 2736 012174 001403
 2737
 2738 012176 104000
 2739 012200 000173
 2740 012202 002013
 2741 012204 077106
 2742 012206 000207
 2743
 2744 012210 170000
 2745 012212 003541
 2746 012214 177777
 2747 012216 172710
 2748 012220 070000
 2749 012222 003541
 2750 012224 177777
 2751 012226 172710
 2752 012230 000177
 2753 012232 100000
 2754 012234 177777
 2755 012236 177007
 2756 012240 070000
 2757 012242 003541
 2758 012244 177777
 2759 012246 172710
 2760 012250 170000
 2761 012252 003541
 2762 012254 177777
 2763 012256 172710
 2764 012260 000000
 2765 012262 000000
 2766 012264 177777
 2767 012266 177007
 2768 012270
 2769
 2770 012270
 2771
 2772
 2773
 2774 012270
 2775 012270 005267 166510
 2776 012274 005037 002122
 2777 012300 012705 000200
 2778 012304 170105
 2779 012306 012701 000014
 2780 012312 012704 001136
 2781 012316 012703 012506
 2782 012322 012324
 2783 012324 077102
 2784 012326 170767 166604
 2785 012332 170203
 2786 012334 012705 001136
 2787 012340 012702 012536
 2788 012344 004767 000114
 2789 012350 020327 000200
 2790 012354 001403

1\$: CMP (R5), (R2),
 BEQ 2\$
 ERROR
 .WORD 173
 .WORD FPPERR
 2\$: SOB R1, 1\$
 RTS PC
 TS32D0: .WORD 170000
 .WORD 3541
 .WORD 177777
 .WORD 172710
 TS32D1: .WORD 70000
 .WORD 3541
 .WORD 177777
 .WORD 172710
 .WORD 177
 .WORD 100000
 .WORD 177777
 .WORD 177007
 TS32D3: .WORD 70000
 .WORD 3541
 .WORD 177777
 .WORD 172710
 TS32D4: .WORD 170000
 .WORD 3541
 .WORD 177777
 .WORD 172710
 TS32D5: .WORD 0
 .WORD 0
 .WORD 177777
 .WORD 177007
 FIN32:
 TSFP33:
 ;*****
 ;*TEST 35 TEST NEGD
 ;*****
 TST35:
 INC \$TESTN ; INCREMENT TEST NUMBER
 CLR \$TRAPFLG ; CLEAR TRAP FLAG
 MOV \$200, R5 ; SETUP TO LOAD FPS
 LDFPS R5 ; SET FD=1
 MOV \$12, R1 ; INIT COUNTER
 MOV \$TSTLOC, R4 ; SETUP POINTER TO TEST LOCATION
 MOV \$TS33D0, R3 ; SETUP POINTER TO TEST VALUE
 100\$: MOV (R3), (R4), ; INIT TEST LOCATION
 SOB R1, 100\$; ARE WE DONE
 NEGD TSTLOC ; ***TEST INSTRUCTION***
 STFPS R3 ; GET FPS
 MOV \$TSTLOC, R5 ; SETUP POINTERS TO DATA
 MOV \$TS33D3, R2 ;
 JSR PC, CHEC33 ; CHECK IF DATA IS CORRECT
 CMP R3, \$200 ; CHECK FPS
 BEQ 1\$; OK GO ON

; IS DATA CORRECT
 ; YES GO ON
 ; NO, GO TO ERROR
 ; ALL ERRORS TO TRAP TO EMT VECTOR
 ; UNIQUE ERROR NUMBER
 ; ADDRESS OF ERROR MESSAGE
 ; ARE WE DONE
 ; RETURN


```

2847 012546 170000
2848 012550 003541
2849 012552 177777
2850 012554 172710
2851 012556 000000
2852 012560 000000
2853 012562 000000
2854 012564 000000
2855 012566
2856
2857 012566
2858
2859
2860
2861 012566
2862 012566 005267 166212
2863 012572 012704 047600
2864 012576 170104
2865 012600 012702 001106
2866 012604 172407
2867
2868 012606 170201
2869 012610 022701 147600
2870 012614 001403
2871 012616 104000
2872 012620 000200
2873 012622 002013
2874
2875 012624 170312
2876 012626 022722 000002
2877 012632 001403
2878 012634 104000
2879 012636 000201
2880 012640 002013
2881
2882 012642 022722 012604
2883 012646 001403
2884 012650 104000
2885 012652 000202
2886 012654 002013
2887
2888 012656
2889
2890
2891 012656
2892
2893
2894
2895 012656
2896 012656 005267 166122
2897 012662 012701 001126
2898 012666 012704 001176
2899 012672 012702 047750
2900 012676 170102
2901 012700 172424
2902 012702 170203
    
```

```

TS33D4: .WORD 170000
        .WORD 3541
        .WORD 177777
        .WORD 172710
TS33D5: .WORD 0
        .WORD 0
        .WORD 0
        .WORD 0
    
```

FIN33:

MFSRCMO:

```

;*****
;*TEST 36 TEST LDD MODE 0, ILLEGAL AC7
;*****
TST36:
    
```

```

        INC      $TESTN          ;INCREMENT TEST NUMBER
        MOV      #47600,R4       ;SETUP FPP STATUS
        LDFPS   R4              ;LOAD FP STATUS
        MOV      @RECFEC,R2     ;POINT TO RECEIVED FEC MEMORY
1$:     LDD      R7,ACO          ;*TEST INSTRUCTION
        STFPS   R1              ;LOAD ACO FROM ILLEGAL AC7
        CMP     #147600,R1      ;SAVE FPP STATUS
        BEQ     2$              ;VERIFY FER BIT SET
        ERROR   200             ;BRANCH IF GOOD ERROR CONDITION
        .WORD   FPPERR         ;ALL ERRORS TO TRAP TO EMT VECTOR
        .WORD   FPPERR         ;UNIQUE ERROR NUMBER
        .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
        ;THE FER BIT DIDNT SET
        STST    (R2)            ;SAVE FEC AND FEA
        CMP     #2,(R2)+        ;VERIFY FEC CONTENTS
        BEQ     3$              ;BRANCH IF GOOD
        ERROR   201             ;ALL ERRORS TO TRAP TO EMT VECTOR
        .WORD   FPPERR         ;UNIQUE ERROR NUMBER
        .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
        ;FEC NE 2 (OPCODE ERROR)
        CMP     #1$(R2)+        ;VERIFY FEA CONTENTS
        BEQ     4$              ;BRANCH FI GOOD
        ERROR   202             ;ALL ERRORS TO TRAP TO EMT VECTOR
        .WORD   FPPERR         ;UNIQUE ERROR NUMBER
        .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
        ;FEA NOT CORRECT ERROR ADDRESS
    
```

MLDDM2:

```

;*****
;*TEST 37 TEST LDD MODE2
;*****
TST37:
    
```

```

        INC      $TESTN          ;INCREMENT TEST NUMBER
        MOV      @RECDST,R1     ;POINT TO RECEIVED DATA LOCATION
        MOV      #TAB1,R4       ;POINT TO GOOD DATA
        MOV      #47750,R2     ;LOAD GOOD STATUS
        LDFPS   R2              ;LOAD FPP STATUS - DOUBLE, ID
        LDD     (R4)+,ACO       ;***TEST INSTRUCTION - MODE 2***
        STFPS   R3              ;SAVE TEST FPP STATUS
    
```

2903	012704	174021			STD	AC0,(R1),		;SAVE TEST RESULT MODE 2
2904	012706	020203			CMP	R2,R3		;VERIFY FPP STATUS
2905	012710	001403			BEQ	1#		;BRANCH IF GOOD
2906	012712	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2907	012714	000203			.WORD	203		;UNIQUE ERROR NUMBER
2908	012716	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2909								;BAD FPP STSTUS
2910	012720	022704	001206	1#:	CMP	#TAB1+10,R4		;VERFIY AUTO-INCR
2911	012724	001403			BEQ	2#		;BRANCH IF GOOD
2912	012726	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2913	012730	000204			.WORD	204		;UNIQUE ERROR NUMBER
2914	012732	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2915								;BAD AUTO-INCR
2916	012734	012704	001176	2#:	MOV	#TAB1,R4		;POINT TO RECEIVED DATA
2917	012740	162701	000010		SUB	#10,R1		;RETURN R1 TO PROPER VALUE
2918	012744	004767	167176		JSR	R7,DATVER		;VERFIY DATA FROM FPP
2919	012750	005767	166064		TST	COUNT		;SEE IF COUNTER=0
2920	012754	001403			BEQ	3#		;BRANCH IF GOOD COMPARE
2921								;BAD DATA FROM FPP
2922	012756	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2923	012760	000205			.WORD	205		;UNIQUE ERROR NUMBER
2924	012762	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2925	012764			3#:				
2926								
2927								
2928	012764							
2929								
2930								
2931								
2932	012764							
2933	012764	005267	166014					
2934	012770	012737	001126	001140	INC	#TESTN		;INCREMENT TEST NUMBER
2935	012776	012701	001140		MOV	#RECDST,#@TSTLOC+2		;POINT TO RECEIVED DATA LOCATION
2936	013002	012737	001206	001136	MOV	#TSTLOC+2,R1		;SETUP STD IN MODE 3
2937	013010	012704	001136		MOV	#TAB2,#@TSTLOC		;POINT TO DATA TABLE
2938	013014	012702	047750		MOV	#TSTLOC,R4		;POINT TO GOOD DATA
2939	013020	170102			MOV	#47750,R2		;LOAD GOOD STATUS
2940	013022	172434			LDFPS	R2		;LOAD FPP STATUS - DOUBLE.ID
2941	013024	170203			LDD	#(R4),AC0		;***TEST INSTRUCTION - MODE 2***
2942	013026	174031			STFPS	R3		;SAVE TEST FPP STATUS
2943	013030	022703	047740		STD	AC0,#(R1),		;SAVE TEST RESULT IN MODE 3
2944	013034	001403			CMP	#47740,R3		;VERIFY FPP STATUS
2945	013036	104000			BEQ	1#		;BRANCH IF GOOD
2946	013040	000206			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
2947	013042	002013			.WORD	206		;UNIQUE ERROR NUMBER
2948					.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
2949	013044	022704	001140	1#:	CMP	#TSTLOC+2,R4		;BAD FPP STATUS
2950	013050	001403			BEQ	2#		;VERFIY AUTO-INCR
2951	013052	104000			ERROR			;BAD AUTO-DEC ON LDD
2952	013054	000207			.WORD	207		;ALL ERRORS TO TRAP TO EMT VECTOR
2953	013056	002013			.WORD	FPPERR		;UNIQUE ERROR NUMBER
2954								;ADDRESS OF ERROR MESSAGE
2955	013060	022701	001142	2#:	CMP	#TSTLOC+4,R1		;BAD AUTO-INC
2956	013064	001403			BEQ	3#		;TEST STD AUTO-INCR
2957	013066	104000			ERROR			;BRANCH IF GOOD
2958	013070	000210			.WORD	210		;ALL ERRORS TO TRAP TO EMT VECTOR
								;UNIQUE ERROR NUMBER

MLDDM3:

 ;TEST 40 TEST LDD MODE 3

TST40:

```

2959 013072 002013          .WORD  FPPERR          ; ADDRESS OF ERROR MESSAGE
2960                                     ; BAD AUTO-INCR
2961 013074 012704 001206   3$:  MOV     @TAB2,R4      ; POINT TO RECEIVED DATA
2962 013100 012701 001126   MOV     @RECDST,R1     ; POINT TO RECEIVED DATA
2963 013104 004767 167036   JSR     R7,DATVER      ; VERIFY DATA FROM FPP
2964 013110 005767 165724   TST     COUNT          ; SEE IF COUNTER=0
2965 013114 001403          BEQ     4$             ; BRANCH IF GOOD COMPARE
2966 013116 104000          ERROR                    ; ALL ERRORS TO TRAP TO EMT VECTOR
2967 013120 000211          .WORD  211            ; UNIQUE ERROR NUMBER
2968 013122 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
2969                                     ; BAD DATA FROM FPP
2970 013124          4$:
2971
2972 013124          MLDDM4:
2973          ;*****
2974          ;*TEST 41          TEST LDF, STD MODE 4
2975          ;*****
2976 013124          TST41:
2977 013124 005267 165654   INC     $TESTN         ; INCREMENT TEST NUMBER
2978 013130 012701 001132   MOV     @RECDST+4,R1   ; POINT TO RECEIVED DATA LOCATION
2979 013134 012704 001222   MOV     @TAB3+4,R4     ; POINT TO GOOD DATA
2980 013140 012705 001256   MOV     @TAB6,R5       ; CLEAR OUT ACO
2981 013144 170127 000200   LDFPS  @200            ; SET TO DOUBLE
2982 013150 172415          LDD     (R5),ACO       ; ACO=0
2983 013152 012702 047550   MOV     @47550,R2      ; LOAD GOOD STATUS FLOATING
2984 013156 170102          LDFPS  R2              ; LOAD FPP STATUS - DOUBLE, ID
2985 013160 172444          LDF     -(R4),ACO      ; *TEST INSTRUCTION - MODE 4
2986 013162 170203          STFPS  R3              ; SAVE TEST FPP STATUS
2987 013164 012702 047750   MOV     @47750,R2      ; SET TO DOUBLE MODE
2988 013170 170102          LDFPS  R2              ; SET FPP TO DOUBLE
2989 013172 174041          STD     ACO, -(R1)     ; SAVE TEST RESULT
2990 013174 022703 047540   CMP     @47540,R3      ; VERIFY FPP STATUS
2991 013200 001403          BEQ     1$             ; BRANCH IF GOOD
2992 013202 104000          ERROR                    ; ALL ERRORS TO TRAP TO EMT VECTOR
2993 013204 000212          .WORD  212            ; UNIQUE ERROR NUMBER
2994 013206 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
2995                                     ; BAD FPP STATUS
2996 013210 022704 001216   1$:  CMP     @TAB3,R4      ; VERIFY AUTO-DEC
2997 013214 001403          BEQ     2$             ; BRANCH IF GOOD
2998 013216 104000          ERROR                    ; ALL ERRORS TO TRAP TO EMT VECTOR
2999 013220 000213          .WORD  213            ; UNIQUE ERROR NUMBER
3000 013222 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
3001                                     ; BAD AUTO-INCR
3002 013224 012704 001216   2$:  MOV     @TAB3,R4      ; POINT TO RECEIVED DATA
3003 013230 004767 166712   JSR     R7,DATVER      ; VERIFY DATA FROM FPP
3004 013234 005767 165600   TST     COUNT          ; SEE IF COUNTER=0
3005 013240 001403          BEQ     3$             ; BRANCH IF GOOD COMPARE
3006 013242 104000          ERROR                    ; ALL ERRORS TO TRAP TO EMT VECTOR
3007 013244 000214          .WORD  214            ; UNIQUE ERROR NUMBER
3008 013246 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
3009                                     ; BAD DATA FROM FPP
3010 013250          3$:
3011
3012 013250          MLDDM5:
3013          ;*****
3014          ;*TEST 42          TEST LDD MODE 5
    
```

```

3015
3016 013250
3017 013250 005267 165530
3018 013254 012701 001126
3019 013260 012704 001140
3020 013264 012737 001176 001136
3021 013272 012702 047750
3022 013276 170102
3023 013300 172454
3024 013302 170203
3025 013304 174011
3026 013306 020203
3027 013310 001403
3028 013312 104000
3029 013314 000215
3030 013316 002013
3031
3032 013320 022704 001136 1$:
3033 013324 001403
3034 013326 104000
3035 013330 000216
3036 013332 002013
3037
3038 013334 012704 001176 2$:
3039 013340 004767 166602
3040 013344 005767 165470
3041 013350 001403
3042 013352 104000
3043 013354 000217
3044 013356 002013
3045
3046 013360 3$:
3047
3048 013360
3049
3050
3051
3052 013360
3053 013360 005267 165420
3054 013364 012701 001326
3055 013370 012704 001006
3056 013374 012702 047750
3057 013400 170102
3058 013402 172464 000200
3059 013406 170203
3060 013410 174061 177600
3061 013414 022703 047740
3062 013420 001403
3063 013422 104000
3064 013424 000220
3065 013426 002013
3066
3067 013430 162701 000200 1$:
3068 013434 062704 000200 2$:
3069 013440 004767 166502
3070 013444 005767 165370

```

```

;*****
TST42:
INC $TESTN ;INCREMENT TEST NUMBER
MOV @RECDST,R1 ;POINT TO RECEIVED DATA LOCATION
MOV @TSTLOC+2,R4 ;POINT TO GOOD DATA
MOV @TAB1,@TSTLOC ;SET UP MODE 5 POINTER TO DATA
MOV @47750,R2 ;LOAD GOOD STATUS
LDFPS R2 ;LOAD FPP STATUS - DOUBLE.ID
LDD @-(R4),ACO ;*TEST INSTRUCTION - MODE 5
STFPS R3 ;SAVE TEST FPP STATUS
STD ACO,(R1) ;SAVE TEST RESULT
CMP R2,R3 ;VERIFY FPP STATUS
BEQ 1$ ;BRANCH IF GOOD
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 215 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;BAD FPP STATUS
1$:
CMP @TSTLOC,R4 ;VERFIY AUTO-DEC
BEQ 2$ ;BRANCH IF GOOD
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 216 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;BAD AUTO-DEC
2$:
MOV @TAB1,R4 ;POINT TO EXPECTED DATA
JSR R7,DATVER ;VERFIY DATA FROM FPP
TST COUNT ;SEE IF COUNTER=0
BEQ 3$ ;BRANCH IF GOOD COMPARE
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 217 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;BAD DATA FROM FPP
3$:

```

```

MLDDM6:
;*****
;*TEST 43 TEST LDD MODE 6
;*****
TST43:
INC $TESTN ;INCREMENT TEST NUMBER
MOV @RECDST+200,R1 ;POINT TO RECEIVED DATA LOCATION
MOV @TAB2-200,R4 ;SETUP R4 FOR MODE 6
MOV @47750,R2 ;LOAD GOOD STATUS
LDFPS R2 ;LOAD FPP STATUS - DOUBLE.ID
LDD 200(R4),ACO ;LDD MODE 6
STFPS R3 ;SAVE TEST FPP STATUS
STD ACO,-200(R1) ;SAVE TEST RESULT
CMP @47740,R3 ;VERIFY FPP STATUS
BEQ 1$ ;BRANCH IF GOOD
ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 220 ;UNIQUE ERROR NUMBER
.WORD FPPERR ;ADDRESS OF ERROR MESSAGE
;BAD FPP STATUS
1$:
SUB @200,R1 ;R1=RECDST
2$:
ADD @200,R4 ;POINT TO EXPECTED DATA
JSR R7,DATVER ;VERFIY DATA FROM FPP
TST COUNT ;SEE IF COUNTER=0

```


3127	013620	005205		INC	R5				
3128	013622	005205		INC	R5				
3129	013624	022705	000003	CMP	#3,R5				; TEST PROPER PC PATH
3130	013630	001403		BEQ	1#				; VERIFY ONLY 3 PC INCREMENT
3131	013632	104000		ERROR					; BRANCH IF PROPER PC ACTION
3132	013634	000225		.WORD	225				; ALL ERRORS TO TRAP TO EMT VECTOR
3133	013636	002013		.WORD	FPPERR				; UNIQUE ERROR NUMBER
3134									; ADDRESS OF ERROR MESSAGE
3135	013640	170203							; BAD MODE 27 LOAD
3136	013642	174011		1#:	STFPS	R3			; SAVE TEST FPP STATUS
3137	013644	022703	047740		STD	ACO,(R1)			; SAVE TEST RESULT
3138	013650	001403			CMP	#47740,R3			; VERIFY FPP STATUS
3139	013652	104000			BEQ	2#			; BRANCH IF GOOD
3140	013654	000226			ERROR				; ALL ERRORS TO TRAP TO EMT VECTOR
3141	013656	002013			.WORD	226			; UNIQUE ERROR NUMBER
3142					.WORD	FPPERR			; ADDRESS OF ERROR MESSAGE
3143	013660	004767	166262						; BAD FPP STATUS
3144	013664	005767	165150	2#:	JSR	R7,DATVER			; VERIFY DATA FROM FPP
3145	013670	001403			TST	COUNT			; SEE IF COUNTER=0
3146	013672	104000			BEQ	3#			; BRANCH IF GOOD COMPARE
3147	013674	000227			ERROR				; ALL ERRORS TO TRAP TO EMT VECTOR
3148	013676	002013			.WORD	227			; UNIQUE ERROR NUMBER
3149					.WORD	FPPERR			; ADDRESS OF ERROR MESSAGE
3150	013700			3#:					; BAD DATA FROM FPP
3151									
3152	013700								
3153									
3154									
3155									
3156	013700								
3157	013700	005267	165100						
3158	013704	012704	001256						
3159	013710	005067	165216						
3160	013714	005067	165214						
3161	013720	012702	040000						
3162	013724	170102							
3163	013726	172414							
3164	013730	172014							
3165	013732	170203							
3166	013734	022703	040004						
3167	013740	001403							
3168	013742	104000							
3169	013744	000230							
3170	013746	002013							
3171									
3172	013750	012701	001126						
3173	013754	174011		1#:	MOV	#RECDST,R1			; BAD FPP STATUS
3174	013756	004767	166164		STF	ACO,(R1)			; POINT TO RECEIVERD DATA
3175	013762	005767	165052		JSR	R7,DATVER			; SAVE DATA
3176	013766	001403			TST	COUNT			; VERIFY DATA
3177	013770	104000			BEQ	2#			; BRANCH IF GOOD
3178	013772	000231			ERROR				; ALL ERRORS TO TRAP TO EMT VECTOR
3179	013774	002013			.WORD	231			; UNIQUE ERROR NUMBER
3180					.WORD	FPPERR			; ADDRESS OF ERROR MESSAGE
3181	013776	012702	040200	2#:	MOV	#40200,R2			; BAD DATA IN ACO
3182	014002	170102			LDFPS	R2			; LOAD FLOATING STATUS

MNNRM1:

```

;*****
;+TEST 46      TEST ADDF, ADDD, SUBF, SUBD - ACO=0 FSRC=0;
;*****

```

TST46:

```

INC      #TESTN      ;INCREMENT TEST NUMBER
MOV      #TAB6,R4    ;POINT TO FSRC TEST DATA
CLR      RECDST+4    ;CLEAR OUT RECEIVED DATA TABLE
CLR      RECDST+6
MOV      #40000,R2   ;SET UP GOOD STATUS
LDFPS   R2           ;LOAD FPP STATUS, FLOATING
LDF      (R4),ACO    ;LOAD ACO WITH 0
ADDF    (R4),ACO    ;0+0
STFPS   R3           ;SAVE STATUS
CMP      #40004,R3   ;VERIFY STATUS
BEQ      1#          ;BRANCH IF GOOD
ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD   230          ;UNIQUE ERROR NUMBER
.WORD   FPPERR       ;ADDRESS OF ERROR MESSAGE
;BAD FPP STATUS
MOV      #RECDST,R1 ;POINT TO RECEIVERD DATA
STF     ACO,(R1)    ;SAVE DATA
JSR     R7,DATVER   ;VERIFY DATA
TST     COUNT
BEQ     2#          ;BRANCH IF GOOD
ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
.WORD  231          ;UNIQUE ERROR NUMBER
.WORD  FPPERR       ;ADDRESS OF ERROR MESSAGE
;BAD DATA IN ACO
MOV     #40200,R2   ;LOAD FLOATING STATUS
LDFPS  R2

```


Line	AREAS	MAC	Address	Instruction	Comments	Labels
3183	014004	172414		LDD (R4),ACO		
3184	014006	172014		ADDD (R4),ACO		
3185	014010	174011		STD ACO,(R1)		
3186	014012	170203		STFPS R3		
3187	014014	022703	040204	CMP #40204,R3		
3188	014020	001403		BEQ 3#		
3189	014022	104000		ERROR		
3190	014024	000232		.WORD 232		
3191	014026	002013		.WORD FPPERR		
3192						
3193	014030	004767	166112	3#:	JSR R7,DATVER	
3194	014034	005737	001040		TST #COUNT	
3195	014040	001403			BEQ 44#	
3196	014042	104000			ERROR	
3197	014044	000233			.WORD 233	
3198	014046	002013			.WORD FPPERR	
3199						
3200	014050	172414		44#:	LDD (R4),ACO	
3201	014052	173014			SUBD (R4),ACO	
3202	014054	170203			STFPS R3	
3203	014056	022703	040204		CMP #40204,R3	
3204	014062	001403			BEQ 4#	
3205	014064	104000			ERROR	
3206	014066	000234			.WORD 234	
3207	014070	002013			.WORD FPPERR	
3208						
3209	014072	174011		4#:	STD ACO,(R1)	
3210	014074	004767	166046		JSR R7,DATVER	
3211	014100	005767	164734		TST COUNT	
3212	014104	001403			BEQ 5#	
3213	014106	104000			ERROR	
3214	014110	000235			.WORD 235	
3215	014112	002013			.WORD FPPERR	
3216						
3217	014114	170127	000000	5#:	LDFPS #0	
3218	014120	172414			LDD (R4),ACO	
3219	014122	173014			SUBF (R4),ACO	
3220	014124	170203			STFPS R3	
3221	014126	174011			STD ACO,(R1)	
3222	014130	022703	000004		CMP #4,R3	
3223	014134	001403			BEQ 6#	
3224	014136	104000			ERROR	
3225	014140	000236			.WORD 236	
3226	014142	002013			.WORD FPPERR	
3227						
3228	014144	004767	165776	6#:	JSR R7,DATVER	
3229	014150	005767	164664		TST COUNT	
3230	014154	001403			BEQ 7#	
3231	014156	104000			ERROR	
3232	014160	000237			.WORD 237	
3233	014162	002013			.WORD FPPERR	
3234						
3235	014164			7#:		
3236						
3237						
3238	014164			MNNRM2:		

```

;LOAD ACO WITH 0
;*TEST INSTRUCTION
;SAVE DATA
;SAVE FPS
;VERIFY STATUS
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD FPS
;VERIFY DATA
;VERIFY RESULT
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD ACO
;SETUP DATA
;*TEST INSTRUCTION
;SAVE STATUS
;VERIFY STATUS
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD FPS
;SAVE ACO DATA
;VERIFY DATA
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD ACO
;STORE FPP STATUS
;LOAD ACO
;O-0
;SAVE STATUS
;SAVE ACO
;VERIFY STATUS
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD FPS
;VERIFY DATAT
;BRANC IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD ACO

```

```

3239
3240
3241
3242 014164
3243 014164 005267 164614
3244 014170 012701 001126
3245 014174 012705 071256
3246 014200 012704 001206
3247 014204 170127 000200
3248 014210 172415
3249 014212 005002
3250 014214 170102
3251 014216 172414
3252 014220 172015
3253 014222 170203
3254 014224 174011
3255 014226 022703 000000
3256 014232 001403
3257 014234 104000
3258 014236 000240
3259 014240 002013
3260
3261 014242 012704 001226
3262 014246 004767 165674
3263 014252 005767 164562
3264 014256 001403
3265 014260 104000
3266 014262 000241
3267 014264 002013
3268
3269 014266 170127 000200
3270 014272 172414
3271 014274 173015
3272 014276 170203
3273 014300 174011
3274 014302 022703 000200
3275 014306 001403
3276 014310 104000
3277 014312 000242
3278 014314 002013
3279
3280 014316 012704 001226
3281 014322 004767 165620
3282 014326 005767 164506
3283 014332 001403
3284 014334 104000
3285 014336 000243
3286 014340 002013
3287
3288 014342
3289
3290
3291 014342
3292
3293
3294

```

```

*****
; *TEST 47          TEST ADDF,SUBD - FSRC=0, ACO NE 0
*****
TST47:
      INC          $TESTN          ; INCREMENT TEST NUMBER
      MOV          #RECDST,R1      ; POINT TO RECEIVED DATA TABLE
      MOV          #TAB6,R5        ; POINT TO SOURCE DATA TABLE
      MOV          #TAB2,R4        ; POINT TO ACO DATA
      LDFPS        #200            ; SET TO DOUBLE FOR CLEAR
      LDD          (R5),ACO        ;
      CLR          R2              ; SETUP FPP STATUS
      LDFPS        R2              ; LOAD FPP
      LDF          (R4),ACO        ; LOAD ACO
      ADDF         (R5),ACO        ; *TEST INSTRUCTION
      STFPS        R3              ; SAVE STATUS
      STF          ACO,(R1)        ; SAVE ACO
      CMP          #0,R3           ; VERIFY NEGATIVE RESULT
      BEQ          1$              ; BRANCH IF GOOD
      ERROR        240             ; ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD        FPPERR         ; UNIQUE ERROR NUMBER
      .WORD        FPPERR         ; ADDRESS OF ERROR MESSAGE
;BAD FPS
      MOV          #TAB4,R4        ; POINT TO EXPECTED DATA
      JSR          R7,DATVER       ; VERIFY ACO
      TST          COUNT          ; CHECK RESULT
      BEQ          2$              ; BRANCH IF GOOD
      ERROR        241             ; ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD        FPPERR         ; UNIQUE ERROR NUMBER
      .WORD        FPPERR         ; ADDRESS OF ERROR MESSAGE
;BAD ACO
      LDFPS        #200            ; SET STATUS TO DOUBLE NODE
      LDD          (R4),ACO        ; LOAD ACO WITH A VALUE
      SUBD         (R5),ACO        ; *TEST INSTRUCTION
      STFPS        R3              ; SAVE FPP STATUS
      STD          ACO,(R1)        ; SAVE ACO
      CMP          #200,R3         ; VERIFY RESULT
      BEQ          3$              ; BRANCH IF GOOD
      ERROR        242             ; ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD        FPPERR         ; UNIQUE ERROR NUMBER
      .WORD        FPPERR         ; ADDRESS OF ERROR MESSAGE
;BAD SUBD
      MOV          #TAB4,R4        ; POINT TO EXPECTED
      JSR          R7,DATVER       ; VERIFY ACO
      TST          COUNT          ;
      BEQ          4$              ; BRANCH IF GOOD ACO
      ERROR        243             ; ALL ERRORS TO TRAP TO EMT VECTOR
      .WORD        FPPERR         ; UNIQUE ERROR NUMBER
      .WORD        FPPERR         ; ADDRESS OF ERROR MESSAGE
;BAD ACO
      MNNRM3:
*****
; *TEST 50          TEST ADDD, SUBF - FSRC NE 0, ACO=0
*****

```

3295	014342			TST50:			
3296	014342	005267	164436		INC	#TESTN	; INCREMENT TEST NUMBER
3297	014346	012701	001126		MOV	#RECDST,R1	; POINT TO RECEIVED DATA TABLE
3298	014352	012705	001256		MOV	#TAB6,R5	; POINT TO ACO DATA TABLE
3299	014356	012704	001176		MOV	#TAB1,R4	; POINT TO FSRC DATA
3300	014362	012702	000200		MOV	#200,R2	; SETUP FPP STATUS
3301	014366	170102			LDFPS	R2	; LOAD FPS
3302	014370	172415			LDD	(R5),ACO	; LOAD ACO
3303	014372	172014			ADD	(R4),ACO	; *TEST INSTRUCTION
3304	014374	170203			STFPS	R3	; SAVE STATUS
3305	014376	174011			STD	ACO,(R1)	; SAVE ACO
3306	014400	022703	000210		CMP	#210,R3	; VERIFY NEGATIVE RESULT
3307	014404	001403			BEQ	1#	; BRANCH IF GOOD
3308	014406	104000			ERROR		; ALL ERRORS TO TRAP TO EMT VECTOR
3309	014410	000244			.WORD	244	; UNIQUE ERROR NUMBER
3310	014412	002013			.WORD	FPPERR	; ADDRESS OF ERROR MESSAGE
3311							
3312	014414	004767	165526	1#:	JSR	R7,DATVER	; BAD FPS
3313	014420	005767	164414		TST	COUNT	; VERIFY ACO
3314	014424	001403			BEQ	2#	; CHECK RESULT
3315	014426	104000			ERROR		; BRANCH IF GOOD
3316	014430	000245			.WORD	245	; ALL ERRORS TO TRAP TO EMT VECTOR
3317	014432	002013			.WORD	FPPERR	; UNIQUE ERROR NUMBER
3318							; ADDRESS OF ERROR MESSAGE
3319	014434	170127	000200	2#:	LDFPS	#200	; BAD ACO
3320	014440	172415			LDF	(R5),ACO	; SET STATUS TO DOUBLE NODE
3321	014442	173014			SUBD	(R4),ACO	; LOAD ACO WITH A VALUE
3322	014444	170203			STFPS	R3	; *TEST INSTRUCTION
3323	014446	174011			STF	ACO,(R1)	; SAVE FPP STATUS
3324	014450	022703	000200		CMP	#200,R3	; SAVE ACO
3325	014454	001403			BEQ	3#	; VERIFY RESULT
3326	014456	104000			ERROR		; BRANCH IF GOOD
3327	014460	000246			.WORD	246	; ALL ERRORS TO TRAP TO EMT VECTOR
3328	014462	002013			.WORD	FPPERR	; UNIQUE ERROR NUMBER
3329							; ADDRESS OF ERROR MESSAGE
3330	014464	012704	001446	3#:	MOV	#TAB18,R4	; BAD SUBD
3331	014470	004767	165452		JSR	R7,DATVER	; POINT TO EXPECTED DATA
3332	014474	005767	164340		TST	COUNT	; VERIFY ACO
3333	014500	001403			BEQ	4#	; BRANCH IF GOOD ACO
3334	014502	104000			ERROR		; ALL ERRORS TO TRAP TO EMT VECTOR
3335	014504	000247			.WORD	247	; UNIQUE ERROR NUMBER
3336	014506	002013			.WORD	FPPERR	; ADDRESS OF ERROR MESSAGE
3337							
3338	014510			4#:			; BAD ACO
3339							
3340							
3341	014510			MINRMA:			
3342							
3343							
3344							
3345	014510						
3346	014510	005267	164270	TST51:	INC	#TESTN	; INCREMENT TEST NUMBER
3347	014514	012702	003240		MOV	#3240,R2	; SET FIU,FD,FT
3348	014520	170102			LDFPS	R2	
3349	014522	012704	001276		MOV	#TAB7,R4	; SET FSRC
3350	014526	012705	001306		MOV	#TAB8,R5	; SETUP ACO


```

3407 014730 002013          .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
3408                                     ;BAD ACO, SHOULD = FSRC
3409 014732 012704 001356  2$:  MOV    #TAB12,R4      ;POINT TO FSRC DATA
3410 014736 172415          LDD    (R5),ACO      ;ACO
3411 014740 172014          ADDD   (R4),ACO      ;*TEST INSTRUCTION
3412 014742 012704 001376  MOV    #TAB13B,R4    ;POINT TO EXPECTED RESULT
3413 014746 174011          STD    ACO,(R1)      ;SAVE ACO DATA INTO RECDAT
3414 014750 004767 165172  JSR    R7,DATVER     ;VERIFY DATA
3415 014754 005767 164060  TST    COUNT
3416 014760 001403          BEQ    3$           ;BRANCH IF GOOD DATA
3417 014762 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
3418 014764 000254          .WORD  254          ;UNIQUE ERROR NUMBER
3419 014766 002013          .WORD  FPPERR       ;ADDRESS OF ERROR MESSAGE
3420                                     ;BAD ACO DATA
3421 014770 012702 003000  3$:  MOV    #3000,R2     ;GET FPP STATUS DATA
3422 014774 012704 001406  MOV    #TAB14,R4     ;POINT TO FSRC DATA
3423 015000 012705 001416  MOV    #TAB15,R5     ;POINT TO ACO DATA
3424 015004 172415          LDD    (R5),ACO      ;LOAD ACO
3425 015006 170102          LDFPS  R2           ;FPP STATUS = FLOAT, INTERRUPTS ENABLE
3426 015010 172014          ADDF   (R4),ACO      ;*TEST INSTRUCTION
3427 015012 170127 000200  LDFPS  #200         ;RESET TO DOUBLE
3428 015016 174011          STD    ACO,(R1)     ;RECDST=ACO
3429 015020 012704 001326  MOV    #TAB10,R4    ;POINT TO GOOD DATA
3430 015024 004767 165116  JSR    R7,DATVER     ;VERIFY CONTENTS OF ACO
3431 015030 005767 164004  TST    COUNT
3432 015034 001403          BEQ    4$           ;BRANCH IF GOOD
3433 015036 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
3434 015040 000255          .WORD  255          ;UNIQUE ERROR NUMBER
3435 015042 002013          .WORD  FPPERR       ;ADDRESS OF ERROR MESSAGE
3436                                     ;BAD FLOATING ADD
3437 015044 012705 001426  4$:  MOV    #TAB16,R5     ;POINT TO ACO DATA
3438 015050 170102          LDFPS  R2           ;FPP STATUS = FLOAT
3439 015052 172415          LDF    (R5),ACO      ;LOAD ACO
3440 015054 172014          ADDF   (R4),ACO      ;*TEST INSTRUCTION
3441 015056 174011          STD    ACO,(R1)     ;SAVE ACO DATA
3442 015060 012704 001436  MOV    #TAB17,R4    ;POINT TO GOOD DATA
3443 015064 004767 165056  JSR    R7,DATVER
3444 015070 005767 163744  TST    COUNT
3445 015074 001403          BEQ    5$           ;BRANCH IF GOOD
3446 015076 104000          ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
3447 015100 000256          .WORD  256          ;UNIQUE ERROR NUMBER
3448 015102 002013          .WORD  FPPERR       ;ADDRESS OF ERROR MESSAGE
3449                                     ;BAD FLOATING ADD
3450 015104          5$:
3451
3452
3453
3454 015104          MNGOP:
3455          ;*****
3456          ;*TEST 53      TEST ADD WITH NEGATIVE OPERANDS
3457          ;*****
3458          TST53:
3459 015104 005267 163674  INC    #TESTN        ;INCREMENT TEST NUMBER
3460 015110 012702 003200  MOV    #3200,R2     ;LOAD FPS VALUE
3461 015114 170102          LDFPS  R2           ;
3462 015116 012704 001456  MOV    #TAB21,R4    ;DATA ADDRESS FOR ACO AND FSR

```

3463	015122	172414			LDD	(R4),ACO		;ACO=100200 0 0 0
3464	015124	172014			ADD	(R4),ACO		;*TEST INSTRUCTION
3465	015126	170203			STFPS	R3		;SAVE STATUS
3466	015130	012701	001126		MOV	@RECDST,R1		;POINT TO RECEIVED DATA TABLE
3467	015134	174011			STD	ACO,(R1)		;SAVE ACO DATA
3468	015136	022703	003210		CMP	@3210,R3		;VERIFY STATUS
3469	015142	001403			BEQ	1*		;BRANCH IF GOOD
3470	015144	104000			ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
3471	015146	000257			.WORD	257		;UNIQUE ERROR NUMBER
3472	015150	002013			.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
3473								
3474	015152	012704	001466		1*:	MOV	@TAB22,R4	;POINT TO EXPECTED DATA
3475	015156	004767	164764			JSR	R7,DATVER	
3476	015162	005767	163652			TST	COUNT	
3477	015166	001403				BEQ	2*	;VERIFY DATA
3478	015170	104000				ERROR		;BRANCH IF GOOD
3479	015172	000260				.WORD	260	;ALL ERRORS TO TRAP TO EMT VECTOR
3480	015174	002013				.WORD	FPPERR	;UNIQUE ERROR NUMBER
3481								;ADDRESS OF ERROR MESSAGE
3482								
3483	015176	012704	001456		2*:	;	!-FSRC! = !ACO!	
3484	015202	012701	001476			MOV	@TAB21,R4	;POINT TO FSRC DATA
3485	015206	012737	015230	000244		MOV	@TAB23,R1	;POINT TO ACO DATA
3486	015214	172411				MOV	@101*,@FPVEC	;SETUP FP VECTOR
3487	015216	172014				LDD	(R1),ACO	;LOAD ACO
3488	015220	170000				ADD	(R4),ACO	;*TEST INSTRUCTION
3489	015222	104000			100*:	CFCC		;COPY FPP CC
3490	015224	000261				ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
3491	015226	002013				.WORD	261	;UNIQUE ERROR NUMBER
3492						.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
3493	015230	170203						;GO TO ERROR
3494	015232	012701	001126		101*:	STFPS	R3	;SAVE FPP STATUS
3495	015236	174011				MOV	@RECDST,R1	;POINT TO RECEIVED DATA TABLE
3496	015240	022703	103200			STD	ACO,(R1)	;SAVE ACO DATA
3497	015244	001403				CMP	@103200,R3	;VERIFY STATUS
3498	015246	104000				BEQ	3*	;BRANCH IF GOOD
3499	015250	000262				ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
3500	015252	002013				.WORD	262	;UNIQUE ERROR NUMBER
3501						.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
3502	015254	012605						;BAD STATUS
3503	015256	020527	015220		3*:	MOV	(SP)+,R5	;GET ERROR PC
3504	015262	001403				CMP	R5,@100*	;VERIFY ERROR ADDRESS ON STACK
3505	015264	104000				BEQ	102*	;BRANCH IF GOOD
3506	015266	000263				ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
3507	015270	002013				.WORD	263	;UNIQUE ERROR NUMBER
3508						.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
3509	015272	005726						;BAD ERROR RETURN ON STACK
3510	015274	012704	001506		102*:	TST	(SP)+	;RESTORE STACK
3511	015300	004767	164642			MOV	@TAB24,R4	;POINT TO EXPECTED DATA TABLE
3512	015304	005767	163530			JSR	R7,DATVER	;VERIFY DATA
3513	015310	001403				TST	COUNT	
3514	015312	104000				BEQ	4*	;BRANC IF GOOD
3515	015314	000264				ERROR		;ALL ERRORS TO TRAP TO EMT VECTOR
3516	015316	002013				.WORD	264	;UNIQUE ERROR NUMBER
3517						.WORD	FPPERR	;ADDRESS OF ERROR MESSAGE
3518								;BAD ACO DATA
							!-ACO! = !FSRC!	

3519	015320	012704	001476		4#:	MOV	#TAB23,R4		;POINT TO FSRC DATA
3520	015324	012701	001456			MOV	#TAB21,R1		;POINT TO ACO DATA
3521	015330	012737	015360	000244		MOV	#104#,B#FPVEC		;SETUP FP VECTOR
3522	015336	012702	003200			MOV	#3200,R2		;LOAD FPS VALUE
3523	015342	170102				LDFPS	R2		
3524	015344	172411				LDD	(R1),ACO		;LOAD ACO DATA
3525	015346	172014				ADD	(R4),ACO		;*TEST INSTRUCTION
3526	015350	170000			103#:	CFCC			;COPY FPP CC
3527	015352	104000				ERROR			;ALL ERRORS TO TRAP TO EMT VECTOR
3528	015354	000265				.WORD	265		;UNIQUE ERROR NUMBER
3529	015356	002013				.WORD	FPPERR		;ADDRESS OF ERROR MESSAGE
3530									
3531	015360	170203			104#:	STFPS	R3		;GO TO ERROR
3532	015362	012701	001126			MOV	#RECDST,R1		;SAVE FPS
3533	015366	174011				STD	ACO,(R1)		;SAVE ACO
3534	015370	022703	103200			CMP	#103200,R3		
3535	015374	001403				BEQ	5#		;VERFIY STATUS
3536	015376	104000				ERROR			;BRANCH IF GOOD
3537	015400	000266				.WORD	266		;ALL ERRORS TO TRAP TO EMT VECTOR
3538	015402	002013				.WORD	FPPERR		;UNIQUE ERROR NUMBER
3539									;ADDRESS OF ERROR MESSAGE
3540	015404	012605			5#:	MOV	(SP),R5		;BAD FPS STATUS
3541	015406	020527	015350			CMP	R5,#103#		;GET ERROR PC
3542	015412	001403				BEQ	105#		;VERIFY ERROR ADDRESS ON STACK
3543	015414	104000				ERROR			;BRANCH IF GOOD
3544	015416	000267				.WORD	267		;ALL ERRORS TO TRAP TO EMT VECTOR
3545	015420	002013				.WORD	FPPERR		;UNIQUE ERROR NUMBER
3546									;ADDRESS OF ERROR MESSAGE
3547	015422	005726			105#:	TST	(SP),		;BAD ERROR RETURN ON STACK
3548	015424	012704	001506			MOV	#TAB24,R4		;RESTORE STACK
3549	015430	004767	164512			JSR	R7,DATVER		;POINT TO EXPECTED DATA
3550	015434	005767	163400			TST	COUNT		
3551	015440	001403				BEQ	6#		
3552	015442	104000				ERROR			;BRANCH IF GOOD
3553	015444	000270				.WORD	270		;ALL ERRORS TO TRAP TO EMT VECTOR
3554	015446	002013				.WORD	FPPERR		;UNIQUE ERROR NUMBER
3555									;ADDRESS OF ERROR MESSAGE
3556									
3557	015450	012704	001526		6#:	;	!-FSRC! <		;BAD ACO
3558	015454	012701	001516			MOV	#TAB26,R4		!ACO!
3559	015460	012702	003200			MOV	#TAB25,R1		;POINT TO FSRC DATA
3560	015464	170102				MOV	#3200,R2		;POINT TO ACO DATA
3561	015466	012737	000246	000244		LDFPS	R2		;LOAD FPS VALUE
3562	015474	172411				MOV	#246,B#FPVEC		
3563	015476	172014				LDD	(R1),ACO		;SETUP FP VECTOR
3564	015500	170203				ADD	(R4),ACO		;LOAD ACO DATA
3565	015502	012701	001126			STFPS	R3		;*TEST INSTRUCTION
3566	015506	174011				MOV	#RECDST,R1		;SAVE STATUS
3567	015510	020327	003200			STD	ACO,(R1)		;POINT TO RECEIVED DATA TABLE
3568	015514	001403				CMP	R3,#3200		;SAVE ACO
3569	015516	104000				BEQ	7#		;VERIFY STATUS
3570	015520	000271				ERROR			;BRANCH IF GOOD
3571	015522	002013				.WORD	271		;ALL ERRORS TO TRAP TO EMT VECTOR
3572						.WORD	FPPERR		;UNIQUE ERROR NUMBER
3573	015524	012704	001536		7#:	MOV	#TAB27,R4		;ADDRESS OF ERROR MESSAGE
3574	015530	004767	164412			JSR	R7,DATVER		;BAD FPS

;POINT TO EXPECTED DSATA
;VERIFY DATA

G6

```

3575 015534 005767 163300      TST      COUNT
3576 015540 001403              BEQ      8#
3577 015542 104000              ERROR
3578 015544 000272              .WORD   272
3579 015546 002013              .WORD   FPPERR
3580
3581                               ;
3582 015550 012704 001516      8#:     MOV      !FSRC! >
3583 015554 012701 001526      MOV      @TAB25,R4
3584 015560 172411              LDD     @TAB26,R1
3585 015562 172014              ADD     (R1),ACO
3586 015564 170203              ADD     (R4),ACO
3587 015566 012701 001126      STFPS   R3
3588 015572 174011              MOV     @RECDST,R1
3589 015574 020327 003200      STD     ACO,(R1)
3590 015600 001403              CMP     R3,#3200
3591 015602 104000              BEQ     9#
3592 015604 000273              ERROR
3593 015606 002013              .WORD   273
3594                               .WORD   FPPERR
3595 015610 012704 001536      9#:     MOV     @TAB27,R4
3596 015614 004767 164326      JSR     R7,DATVER
3597 015620 005767 163214      TST     COUNT
3598 015624 001403              BEQ     10#
3599 015626 104000              ERROR
3600 015630 000274              .WORD   274
3601 015632 002013              .WORD   FPPERR
3602
3603                               ;
3604 015634 012704 001556      10#:    MOV     !-FSRC! <
3605 015640 012701 001546      MOV     @TAB29,R4
3606 015644 172411              MOV     @TAB28,R1
3607 015646 172014              LDD     (R1),ACO
3608 015650 170203              ADD     (R4),ACO
3609 015652 012701 001126      STFPS   R3
3610 015656 174011              MOV     @RECDST,R1
3611 015660 020327 003200      STD     ACO,(R1)
3612 015664 001403              CMP     R3,#3200
3613 015666 104000              BEQ     11#
3614 015670 000275              ERROR
3615 015672 002013              .WORD   275
3616                               .WORD   FPPERR
3617 015674 012704 001566      11#:    MOV     @TAB29A,R4
3618 015700 004767 164242      JSR     R7,DATVER
3619 015704 005767 163130      TST     COUNT
3620 015710 001403              BEQ     12#
3621 015712 104000              ERROR
3622 015714 000276              .WORD   276
3623 015716 002013              .WORD   FPPERR
3624
3625 015720                      12#:
3626
3627                               ;
3628                               ;
3629 015720                      MSB:
3630                               ;
;*****

```

```

;
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;
;BAD FPS
;POINT TO EXPECTED DSATA
;VERIFY DATA
;
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;
;BAD ACO
!ACO!
;POINT TO FSRC DATA
;POINT TO ACO DATA
;LOAD ACO DATA
;TEST INSTRUCTION
;SAVE STATUS
;POINT TO RECEIVED DATA TABLE
;SAVE ACO
;VERIFY STATUS
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;
;BAD FPS
;POINT TO EXPECTED DATA
;VERIFY DATA
;
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;

```



```

3631                                     ;*TEST 54      TEST SUB WITH EXP[ACO]=EXP[FSRC]
3632                                     ;:*****
3633 015720                               TST54:
3634 015720 005267 163060                 INC      $TESTN      ; INCREMENT TEST NUMBER
3635 015724 012702 003200                 MOV      #3200,R2    ; LOAD FPS DATA
3636 015730 170102                         LDFPS   R2           ; LOAD FPS
3637 015732 012704 001456                 MOV      #TAB21,R4   ; POINT TO FSRC DATA
3638 015736 012701 001126                 MOV      #RECDST,R1 ; POINT TO ACO RECEIVED DATA TABLE
3639 015742 172414                         LDD     (R4),ACO    ; LOAD ACO
3640 015744 173014                         SUBD    (R4),ACO    ;*TEST INSTRUCTION
3641 015746 170203                         STFPS   R3           ; SAVE STATUS
3642 015750 174011                         STD     ACO,(R1)    ; SAVE ACO INTO RECDST
3643 015752 022703 003204                 CMP      #3204,R3   ; VERIFY STATUS
3644 015756 001403                         BEQ     1$          ; BRANCH IF GOOD
3645 015760 104000                         ERROR   277         ; ALL ERRORS TO TRAP TO EMT VECTOR
3646 015762 000277                         .WORD  FPPERR      ; UNIQUE ERROR NUMBER
3647 015764 002013                         .WORD  FPPERR      ; ADDRESS OF ERROR MESSAGE
3648
3649 015766 012704 001256                 1$:  MOV      #TAB6,R4 ; BAD FPS STATUS
3650 015772 004767 164150                 JSR     R7,DATVER  ; POINT TO EXPECTED DATA
3651 015776 005767 163036                 TST     COUNT      ; VERIFY ACO
3652 016002 001403                         BEQ     2$          ;
3653 016004 104000                         ERROR   300         ; BRANCH IF GOOD
3654 016006 000300                         .WORD  FPPERR      ; ALL ERRORS TO TRAP TO EMT VECTOR
3655 016010 002013                         .WORD  FPPERR      ; UNIQUE ERROR NUMBER
3656
3657 016012 012704 001406                 2$:  MOV      #TAB14,R4 ; BAD ACO
3658 016016 172414                         LDD     (R4),ACO   ; POINT TO FSRC AND ACO DATA
3659 016020 173014                         SUBD    (R4),ACO   ; LOAD ACO DATA
3660 016022 170203                         STFPS   R3         ;*TEST INSTRUCTION
3661 016024 174011                         STD     ACO,(R1)   ; SAVE FPS
3662 016026 022703 003204                 CMP      #3204,R3 ; SAVE ACO INTO RECDST
3663 016032 001403                         BEQ     3$          ; VERIFY FPS
3664 016034 104000                         ERROR   301         ; BRANCH IF GOOD
3665 016036 000301                         .WORD  FPPERR      ; ALL ERRORS TO TRAP TO EMT VECTOR
3666 016040 002013                         .WORD  FPPERR      ; UNIQUE ERROR NUMBER
3667
3668 016042 012704 001256                 3$:  MOV      #TAB6,R4 ; BAD ACO
3669 016046 004767 164074                 JSR     R7,DATVER  ; POINT TO EXPECTED DATA
3670 016052 005767 162762                 TST     COUNT      ; VERIFY ACO
3671 016056 001403                         BEQ     4$          ;
3672 016060 104000                         ERROR   302         ; BRANCH IF GOOD
3673 016062 000302                         .WORD  FPPERR      ; ALL ERRORS TO TRAP TO EMT VECTOR
3674 016064 002013                         .WORD  FPPERR      ; UNIQUE ERROR NUMBER
3675
3676 016066                               4$:
3677
3678
3679 016066                               ;
3680 MNRM:
3681 ;:*****
3682 ;*TEST 55      TEST NORMALIZE
3683 ;:*****
3684 016066 005267 162712                 TST55:
3685 016072 012702 003200                 INC      $TESTN      ; INCREMENT TEST NUMBER
3686 016076 170102                         MOV      #3200,R2    ; LOAD FPS
3686 016076 170102                         LDFPS   R2           ;

```

```

3687 016100 012705 001606      MOV      #TAB31,R5      ;POINT TO FSRC DATA
3688 016104 012701 001576      MOV      #TAB30,R1      ;POINT TO ACO DATA
3689 016110 172411                LDD      (R1),ACO       ;LOAD ACO
3690 016112 173015                SUBD     (R5),ACO       ;*TEST INSTRUCTION
3691                                ;1 LEFT SHIFT
3692 016114 170203                STFPS   R3              ;SAVE STATUS
3693 016116 012704 001126      MOV      #RECDST,R4     ;POINT TO RECDATA
3694 016122 174014                STD     ACO,(R4)        ;SAVE ACO
3695 016124 012701 001636      MOV      #TAB34,R1     ;POINT TO EXPECTED DATA
3696 016130 004767 164012      JSR     R7,DATVER      ;VERIFY DATA
3697 016134 005767 162700      TST     COUNT
3698 016140 001403                BEQ     1#              ;BRANCH IF GOOD
3699 016142 104000                ERROR
3700 016144 000303                .WORD  303              ;ALL ERRORS TO TRAP TO EMT VECTOR
3701 016146 002013                .WORD  FPPERR          ;UNIQUE ERROR NUMBER
3702                                ;ADDRESS OF ERROR MESSAGE
3703 016150 012701 001616      1#:    MOV      #TAB32,R1      ;ACO DATA
3704 016154 012705 001626      MOV      #TAB33,R5     ;FSRC DATA
3705 016160 172411                LDD      (R1),ACO       ;LOAD ACO
3706 016162 173015                SUBD     (R5),ACO       ;*TST INSTRUCTION
3707                                ;56 LEFT SHIFTS
3708 016164 012701 001126      MOV      #RECDST,R1     ;SAVE DATA
3709 016170 174011                STD     ACO,(R1)
3710 016172 004767 163750      JSR     R7,DATVER
3711 016176 005767 162636      TST     COUNT
3712 016202 001403                BEQ     2#              ;
3713 016204 104000                ERROR                  ;ALL ERRORS TO TRAP TO EMT VECTOR
3714 016206 000304                .WORD  304              ;UNIQUE ERROR NUMBER
3715 016210 002013                .WORD  FPPERR          ;ADDRESS OF ERROR MESSAGE
3716
3717 016212      2#:
3718
3719 016212      MUVAD:
3720      ;:*****
3721      ;*TEST 56      TEST ADD WITH OVERFLOW AND UNDERFLOW
3722      ;:*****
3723 016212      TST56:
3724 016212 005267 162566      INC     #TESTN          ;INCREMENT TEST NUMBER
3725 016216 012702 000200      MOV     #200,R2        ;SETUP FLOATING POINT STATUS
3726 016222 170102                LDFPS  R2              ;LOAD FPS
3727 016224 012704 001646      MOV     #TAB40,R4      ;POINT TO FSRC DATA
3728 016230 012701 001646      MOV     #TAB40,R1      ;POINT TO ACO DATA
3729 016234 172411                LDD     (R1),ACO       ;LOAD ACO WITH TEST DATA
3730 016236 172014                ADDD   (R4),ACO
3731 016240 170203                STFPS  R3              ;*TEST INSTRUCTION
3732 016242 012701 001126      MOV     #RECDST,R1     ;SAVE FPS
3733 016246 174011                STD     ACO,(R1)       ;POINT TO RECEIVED DATA TABLE
3734 016250 022703 000206      CMP     #206,R3        ;SAVE ACO RESULT
3735 016254 001403                BEQ     1#              ;VERIFY STATUS
3736 016256 104000                ERROR                  ;BRANCH IF GOOD
3737 016260 000305                .WORD  305              ;ALL ERRORS TO TRAP TO EMT VECTOR
3738 016262 002013                .WORD  FPPERR          ;UNIQUE ERROR NUMBER
3739                                ;ADDRESS OF ERROR MESSAGE
3740 016264 012704 001256      1#:    MOV     #TAB6,R4        ;BAD FPS
3741 016270 004767 163652      JSR     R7,DATVER      ;POINT TO EXPECTED DATA
3742 016274 005767 162540      TST     COUNT          ;VERIFY DATA
    
```


3967	017300	004767	162642	JSR	R7,DATVER				
3968	017304	005767	161530	TST	COUNT				;VERIFY DATA
3969	017310	001403		BEQ	5#				;BRANCH IF GOOD
3970	017312	104000		ERROR					;ALL ERRORS TO TRAP TO EMT VECTOR
3971	017314	000333		.WORD	333				;UNIQUE ERROR NUMBER
3972	017316	002013		.WORD	FPPERR				;ADDRESS OF ERROR MESSAGE
3973									;BAD ACO
3974									
3975	017320	012702	000200	;LDCFD GR7					
3976	017324	170102		5#:	MOV #200,R2				;SETUP FLOATING POINT STATUS
3977	017326	005003			LDFPS R2				;LOAD FPS
3978	017330	177427	043243		CLR R3				
3979	017334	005203			LDCFD #5203,ACO				;*TEST INSTRUCTION
3980	017336	005203			INC R3				
3981	017340	005203			INC R3				
3982	017342	022703	000003		INC R3				;IF LDCFD WORKED, R3 SHOULD=3
3983	017346	001403			CMP #3,R3				;VERIFY CORRECT PROGRAM FLOW
3984	017350	104000			BEQ 6#				;BRANCH IF GOOD
3985	017352	000334			ERROR				;ALL ERRORS TO TRAP TO EMT VECTOR
3986	017354	002013			.WORD 334				;UNIQUE ERROR NUMBER
3987					.WORD FPPERR				;ADDRESS OF ERROR MESSAGE
3988									;BAD PROGRAM FLOW
3989	017356	012702	000200	;NEGATIVE OPERANDS					
3990	017362	170102		6#:	MOV #200,R2				;SETUP FLOATING POINT STATUS
3991	017364	012704	001726		LDFPS R2				;LOAD FPS
3992	017370	012701	001706		MOV #TAB47,R4				;POINT TO FSRC DATA
3993	017374	172411			MOV #TAB45,R1				;POINT TO ACO DATA
3994	017376	177414			LDD (R1),ACO				;LOAD ACO WITH TEST DATA
3995	017400	170203			LDCFD (R4),ACO				;*TEST INSTRUCTION
3996	017402	012701	001126		STFPS R3				;SAVE FPS
3997	017406	174011			MOV #RECDST,R1				;POINT TO RECEIVED DATA TABLE
3998	017410	022703	000210		STD ACO,(R1)				;SAVE ACO RESULT
3999	017414	001403			CMP #210,R3				;VERIFY STATUS
4000	017416	104000			BEQ 7#				;BRANCH IF GOOD
4001	017420	000335			ERROR				;ALL ERRORS TO TRAP TO EMT VECTOR
4002	017422	002013			.WORD 335				;UNIQUE ERROR NUMBER
4003					.WORD FPPERR				;ADDRESS OF ERROR MESSAGE
4004	017424	012704	001746						;BAD FPS
4005	017430	004767	162512	7#:	MOV #TAB48,R4				;POINT TO EXPECTED DATA
4006	017434	005767	161400		JSR R7,DATVER				;VERIFY DATA
4007	017440	001403			TST COUNT				
4008	017442	104000			BEQ 8#				;BRANCH IF GOOD
4009	017444	000336			ERROR				;ALL ERRORS TO TRAP TO EMT VECTOR
4010	017446	002013			.WORD 336				;UNIQUE ERROR NUMBER
4011					.WORD FPPERR				;ADDRESS OF ERROR MESSAGE
4012									;BAD ACO
4013	017450	012702	000200	;LOAD A ZERO					
4014	017454	170102		8#:	MOV #200,R2				;SETUP FLOATING POINT STATUS
4015	017456	012704	001256		LDFPS R2				;LOAD FPS
4016	017462	012701	001746		MOV #TAB6,R4				;POINT TO FSRC DATA
4017	017466	172411			MOV #TAB48,R1				;POINT TO ACO DATA
4018	017470	177414			LDD (R1),ACO				;LOAD ACO WITH TEST DATA
4019	017472	170203			LDCFD (R4),ACO				;*TEST INSTRUCTION
4020	017474	012701	001126		STFPS R3				;SAVE FPS
4021	017500	174011			MOV #RECDST,R1				;POINT TO RECEIVED DATA TABLE
4022	017502	022703	000204		STD ACO,(R1)				;SAVE ACO RESULT
					CMP #204,R3				;VERIFY STATUS


```

4135      ;*TEST 61      TEST DIVF
4136      ;:*****
4137      020056      005267      160722      001042      TST61:
4138      020056      005267      160722      INC      $TESTN      ;INCREMENT TEST NUMBER
4139      ;1/EXP[AC]=FSRC=0      MOV      #2,$#FLAG      ;NO INTERRUPT, BUT FEC
4140      020062      012737      000002      JSR      R7,DVFSUB      ;DO TEST
4141      020070      004767      000706      .WORD   100,27      ;ACO
4142      020074      000100      000027      .WORD   0,0      ;FSRC
4143      020100      000000      000000      .WORD   100,27      ;RESULT
4144      020104      000100      000027      .WORD   40000      ; TEST FPS
4145      020110      040000      .WORD   140000      ;RESULT FPS
4146      020112      140000      .WORD   4      ;FEC
4147      020114      000004      ;2/AC=EXP[FSRC]=0
4148      ;TRAPS ENABLED
4149      ;
4150      020116      012737      000001      001042      MOV      #1,$#FLAG      ;INTERRUPT
4151      020124      004767      000652      JSR      R7,DVFSUB      ;DO TEST
4152      020130      000000      000000      .WORD   0,0      ;ACO
4153      020134      000100      000000      .WORD   100,0      ;FSRC
4154      020140      000000      000000      .WORD   0,0      ;RESULT
4155      020144      000000      .WORD   0      ; TEST FPS
4156      020146      100000      .WORD   100000      ;RESULT FPS
4157      020150      000004      .WORD   4      ;FEC
4158      ;3/FSRC>ACO=0
4159      020152      005037      001042      CLR      $#FLAG      ;NO INTERRUPT
4160      020156      004767      000620      JSR      R7,DVFSUB      ;DO TEST
4161      020162      000177      000234      .WORD   177,234      ;ACO
4162      020166      004100      000000      .WORD   4100,0      ;FSRC
4163      020172      000000      000000      .WORD   0,0      ;RESULT
4164      020176      007400      .WORD   7400      ; TEST FPS
4165      020200      007404      .WORD   7404      ;RESULT FPS
4166      ;4/ACO>EXP[FSRC]=0
4167      020202      012737      000001      001042      MOV      #1,$#FLAG      ;INTERRUPT
4168      020210      004767      000566      JSR      R7,DVFSUB      ;DO TEST
4169      020214      040200      104210      .WORD   40200,104210      ;ACO
4170      020220      000125      025252      .WORD   125,25252      ;FSRC
4171      020224      040200      104210      .WORD   40200,104210      ;RESULT
4172      020230      007557      .WORD   7557      ; TEST FPS
4173      020232      107557      .WORD   107557      ;RESULT FPS
4174      020234      000004      .WORD   4      ;FEC
4175      ;5/EXP[AC]=EXP[FSRC]
4176      020236      005037      001042      CLR      $#FLAG      ;NO INTERRUPT
4177      020242      004767      000534      JSR      R7,DVFSUB      ;DO TEST
4178      020246      077760      177777      .WORD   77760,-1      ;ACO
4179      020252      077760      000000      .WORD   77760,0      ;FSRC
4180      020256      040200      104210      .WORD   40200,104210      ;RESULT
4181      020262      007414      .WORD   7414      ; TEST FPS
4182      020264      007400      .WORD   7400      ;RESULT FPS
4183      ;6/AC=FSRC
4184      020266      005037      001042      CLR      $#FLAG      ;NO INTERRUPT
4185      020272      004767      000504      JSR      R7,DVFSUB      ;DO TEST
4186      020276      052525      052525      .WORD   52525,52525      ;ACO
4187      020302      052525      052525      .WORD   52525,52525      ;FSRC
4188      020306      040200      000000      .WORD   40200,0      ;RESULT
4189      020312      007400      .WORD   7400      ; TEST FPS
4190      020314      007400      .WORD   7400      ;RESULT FPS
    
```

4191				;7/FSRC>0<ACO, ROUND		
4192	020316	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4193	020322	004767	000454	JSR	R7,DVFSUB	;DO TEST
4194	020326	077777	125252	.WORD	77777,125252	;ACO
4195	020332	040300	000000	.WORD	40300,0	;FSRC
4196	020336	077652	070707	.WORD	77652,070707	;RESULT
4197	020342	007400		.WORD	7400	; TEST FPS
4198	020344	007400		.WORD	7400	;RESULT FPS
4199				;8/AC>0<FSRC		
4200	020346	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4201	020352	004767	000424	JSR	R7,DVFSUB	;DO TEST
4202	020356	055377	177777	.WORD	55377,-1	;ACO
4203	020362	055300	000000	.WORD	55300,0	;FSRC
4204	020366	040252	125252	.WORD	40252,125252	;RESULT
4205	020372	000000		.WORD	0	; TEST FPS
4206	020374	000000		.WORD	0	;RESULT FPS
4207				;9/FSRC>AC>0		
4208	020376	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4209	020402	004767	000374	JSR	R7,DVFSUB	;DO TEST
4210	020406	064600	000001	.WORD	64600,1	;ACO
4211	020412	066600	000000	.WORD	66600,0	;FSRC
4212	020416	036200	000001	.WORD	36200,1	;RESULT
4213	020422	000000		.WORD	0	; TEST FPS
4214	020424	000000		.WORD	0	;RESULT FPS
4215				;10/AC>FSRC>0		
4216	020426	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4217	020432	004767	000344	JSR	R7,DVFSUB	;DO TEST
4218	020436	012345	156024	.WORD	12345,156024	;ACO
4219	020442	005600	000000	.WORD	05600,0	;FSRC
4220	020446	044745	156024	.WORD	44745,156024	;RESULT
4221	020452	000017		.WORD	17	; TEST FPS
4222	020454	000000		.WORD	0	;RESULT FPS
4223				;11/FSRC<0		
4224	020456	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4225	020462	004767	000314	JSR	R7,DVFSUB	;DO TEST
4226	020466	040422	101010	.WORD	40422,101010	;ACO
4227	020472	140511	101010	.WORD	140511,101010	;FSRC
4228	020476	140072	020167	.WORD	140072,20167	;RESULT
4229	020502	000057		.WORD	57	; TEST FPS
4230	020504	000050		.WORD	50	;RESULT FPS
4231				;12/AC<0		
4232	020506	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4233	020512	004767	000264	JSR	R7,DVFSUB	;DO TEST
4234	020516	160077	000101	.WORD	160077,101	;ACO
4235	020522	040417	177777	.WORD	40417,-1	;FSRC
4236	020526	157651	143527	.WORD	157651,143527	;RESULT
4237	020532	000007		.WORD	7	; TEST FPS
4238	020534	000010		.WORD	10	;RESULT FPS
4239				;13/TRUNCATE TEST		
4240	020536	005037	001042	CLR	B#FLAG	;NO INTERRUPT
4241	020542	004767	000234	JSR	R7,DVFSUB	;DO TEST
4242	020546	060100	000177	.WORD	60100,177	;ACO
4243	020552	040300	000000	.WORD	40300,0	;FSRC
4244	020556	060000	000124	.WORD	60000,124	;RESULT
4245	020562	000040		.WORD	40	; TEST FPS
4246	020564	000040		.WORD	40	;RESULT FPS

```
4247 ;14/ROUND TEST
4248
4249 020566 005037 001042 CLR B#FLAG ;NO INTERRUPT
4250 020572 004767 000204 JSR R7,DVFSUB ;DO TEST
4251 020576 060100 000177 .WORD 60100,177 ;ACO
4252 020602 040300 000000 .WORD 40300,0 ;FSRC
4253 020606 060000 000125 .WORD 60000,125 ;RESULT
4254 020612 000000 .WORD 0 ;TEST FPS
4255 020614 000000 .WORD 0 ;RESULT FPS
4256
4257 020616 012737 000001 001042 ;15/OVERFLOW, INTERRUPTS ENABLED
4258 020624 004767 000152 MOV #1,B#FLAG ;INTERRUPT
4259 020630 177700 000000 JSR R7,DVFSUB ;DO TEST
4260 020634 000200 000000 .WORD 177700,0 ;ACO
4261 020640 137700 000000 .WORD 200,0 ;FSRC
4262 020644 001100 .WORD 137700,0 ;RESULT
4263 020646 101112 .WORD 1100 ;TEST FPS
4264 020650 000010 .WORD 101112 ;RESULT FPS
4265 .WORD 10 ;FEC
4266 020652 012737 000002 001042 ;16/OVERFLOW, TRAPS DISABLED
4267 020660 004767 000116 MOV #2,B#FLAG ;NO INTERRUPT
4268 020664 000200 000000 JSR R7,DVFSUB ;DO TEST
4269 020670 177700 000000 .WORD 200,0 ;ACO
4270 020674 000000 000000 .WORD 177700,0 ;FSRC
4271 020700 041100 .WORD 0,0 ;RESULT
4272 020702 041104 .WORD 41100 ;TEST FPS
4273 020704 000010 .WORD 41104 ;RESULT FPS
4274 .WORD 10 ;FEC OVERFLOW
4275 020706 012737 000001 001042 ;17/UNDERFLOW, TRAPS ENABLED, UV RESULT
4276 020714 004767 000062 MOV #1,B#FLAG ;INTERRUPT
4277 020720 100200 000000 JSR R7,DVFSUB ;DO TEST
4278 020724 040377 177777 .WORD 100200,0 ;ACO
4279 020730 100000 000001 .WORD 40377,-1 ;FSRC
4280 020734 002000 .WORD 100000,1 ;RESULT
4281 020736 102014 .WORD 2000 ;TEST FPS
4282 020740 000012 .WORD 102014 ;RESULT FPS
4283 .WORD 12 ;FEC
4284 020742 012737 000001 001042 ;18/UNDERFLOW, TRAPS ENABLED, ROUND
4285 020750 004767 000026 MOV #1,B#FLAG ;INTERRUPT
4286 020754 030325 025252 JSR R7,DVFSUB ;DO TEST
4287 020760 076777 023456 .WORD 30325,25252 ;ACO
4288 020764 071525 157716 .WORD 76777,23456 ;FSRC
4289 020770 002537 .WORD 71525,157716 ;RESULT
4290 020772 102500 .WORD 2537 ;TEST FPS
4291 020774 000012 .WORD 102500 ;RESULT FPS
4292 .WORD 12 ;FEC
4293 ;
4294 020776 000167 000242 JMP HOP10 ;GO TO NEXT TEST
4295 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4296 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4297 ;DIVF SUBROUTINE:
4298 ; ACO
4299 ; FSRC
4300 ; FPS BEFORE EXECUTION
4301 ; FPS AFTER EXECUTION
4302 ; (FEC)
```

```

4303
4304
4305
4306
4307 021002 012605
4308 021004 012737 021064 000244
4309 021012 012702 000200
4310 021016 170102
4311 021020 010504
4312 021022 062704 000004
4313 021026 172415
4314 021030 016502 000014
4315 021034 170102
4316
4317 021036 174414
4318 021040 170001
4319
4320
4321 021042 032737 000001 001042
4322 021050 001426
4323 021052 104000
4324 021054 000343
4325 021056 002013
4326
4327 021060 000167 000042
4328
4329
4330 021064 032737 000001 001042
4331 021072 001005
4332 021074 104000
4333 021076 000344
4334 021100 002013
4335
4336 021102 000167 000020
4337 021106 012604
4338 021110 005726
4339 021112 022704 021040
4340 021116 001403
4341 021120 104000
4342 021122 000345
4343 021124 002013
4344
4345
4346
4347 021126 170203
4348 021130 012702 000200
4349 021134 170102
4350 021136 012701 001126
4351 021142 174011
4352 021144 026503 000016
4353 021150 001403
4354 021152 104000
4355 021154 000346
4356 021156 002013
4357
4358 021160 010504

```

```

;
;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
;
DVFSUB: MOV (SP),R5 ; RETURN ADDRESS TO USE AS POINTER
MOV @50@,@FPVEC ; REDIRECT TRAP VECTOR
MOV @200,R2 ; SET TO DOUBLE MODE FOR LOAD
LDFPS R2 ; LOAD FPS
MOV R5,R4 ; POINT TO FSRC DATA
ADD @4,R4
LDD (R5),ACO ; LOAD ACO WITH TEST DATA
MOV 14(R5),R2 ; GET TEST FPS
LDFPS R2 ; LOAD TEST FPS
;
; DIVF (R4),ACO ; *TEST INSTRUCTION
1@: SETF ; WAIT FOR POSSIBLE FPA TRAP.
;
; INSTRUCTION DIDNT TRAP
BIT @1,@FLAG ; VERIFY A NO TRAP CONDITION
BEQ 2@ ; BRANCH IF GOOD
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 343 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
; INSTRUCTION SHOULD HAVE TRAPPED
JMP 2@ ; REJOIN CODE
;
; INSTRUCTION TRAPPED
50@: BIT @1,@FLAG ; SEE IF EXPECTING A TRAP
BNE 51@ ; BRANCH IF EXPECTING A TRAP
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 344 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
; INSTRUCTION WASNT SUPPOSE TO TRAP
JMP 2@ ; REJOIN CODE
51@: MOV (SP),R4 ; SEE IF PC = INSTRUCTION
TST (SP); ; CLEAN UP STACK
CMP @1@,R4 ;
BEQ 2@ ; BRANCH IF GOOD COMPARE
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 345 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
; PC WAS INCORRECT
;
; COMMON CODE FOR TRAP AND NO TRAP
2@: STFPS R3 ; SAVE FPS
MOV @200,R2 ; SET FPP TO DOUBLE
LDFPS R2
MOV @RECDST,R1 ; POINT TO RECEIVED DATA TABLE
STD ACO,(R1) ; SAVE ACO RESULT
CMP 16(R5),R3 ; VERIFY STATUS
BEQ 3@ ; BRANCH IF GOOD
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 346 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
; BAD FPS
3@: MOV R5,R4 ; POINT TO EXPECTED DATA

```

```

4359 021162 062704 000010      ADD    #10,R4
4360 021166 004767 160736      JSR    R7,DATVFR
4361 021172 005767 157642      TST    COUNT
4362 021176 001403              BEQ    5$
4363 021200 104000              ERROR
4364 021202 000347              .WORD 347
4365 021204 002013              .WORD FPPERR
4366
4367 021206 005737 001042      5$:   TST    @#FLAG
4368 021212 001002              BNE    6$
4369 021214 000165 000020      JMP    20(R5)
4370 021220 170301              6$:   STST   R1
4371 021222 016504 000020      MOV    20(R5),R4
4372 021226 020401              CMP    R4,R1
4373 021230 001403              BEQ    7$
4374 021232 104000              ERROR
4375 021234 000350              .WORD 350
4376 021236 002013              .WORD FPPEPR
4377
4378 021240 000165 000022      7$:   JMP    22(R5)
4379
4380 021244      ;
4381 021244      MOP10:
4382
4383      ;*****
4384      ;*TEST 62      TEST DIVD -
4385      ;*****
4385 021244      TST62:
4386 021244 005267 157534      INC    #TESTN
4387
4388 021250 012737 000002 001042  ;1/AC=FSRC=0 TRAPS DISABLED
4389 021256 004767 000516      MOV    #2,@#FLAG
4390 021262 000000 000000 000000  JSR    R7,DVDSUB
4391 021270 000001              .WORD 0,0,0,1
4392 021272 000100 000000 000000  ;AC0
4393 021300 000000              .WORD 100,0,0,0
4394 021302 000000 000000 000000  ;FSRC
4395 021310 000001              .WORD 0,0,0,1
4396 021312 040000              ;RESULT
4397 021314 140000              .WORD 40000
4398 021316 000004              .WORD 140000
4399
4400 021320 012737 000001 001042  ;2/FSRC=0, TRAPS ENABLED
4401 021326 004767 000446      MOV    #1,@#FLAG
4402 021332 000402 000000 000000  JSR    R7,DVDSUB
4403 021340 000000              .WORD 402,0,0,0
4404 021342 000000 000000 000000  ;AC0
4405 021350 000000              .WORD 0,0,0,0
4406 021352 000402 000000 000000  ;FSRC
4407 021360 000000              .WORD 402,0,0,0
4408 021362 000200              ;RESULT
4409 021364 100200              .WORD 200
4410 021366 000004              .WORD 100200
4411
4412 021370 005037 001042      ;3/ROUND
4413 021374 004767 000400      CLR    @#FLAG
4414 021400 034300 000000 000000  JSR    R7,DVDSUB
                                .WORD 34300,0,0,1

```

```

;VERIFY DATA
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD ACO
;SEE IF NEED TO CHECK FEC
;BRANCH IF NEED TO CHECK
;RETURN FROM TEST
;SAVE FEC
;GET FEC
;VERIFY FEC
;BRANCH IF GOOD
;ALL ERRORS TO TRAP TO EMT VECTOR
;UNIQUE ERROR NUMBER
;ADDRESS OF ERROR MESSAGE
;BAD FEC
;RETURN FROM TEST

```

```

4415 021406 000001
4416 021410 140300 000000 000000 .WORD 140300,0,0,0 ;FSRC
4417 021416 000000
4418 021420 134200 000000 000000 .WORD 134200,0,0,1 ;RESULT
4419 021426 000001
4420 021430 000200 .WORD 200 ; TEST FPS
4421 021432 000210 .WORD 210 ;RESULT FPS
4422
;4/TRUNCATE
4423 021434 005037 001042 CLR B#FLAG ;NO INTERRUPT
4424 021440 004767 000334 JSR R7,DVDSUB ;DO TEST
4425 021444 034300 000000 000000 .WORD 34300,0,0,1 ;ACO
4426 021452 000001
4427 021454 140300 000000 000000 .WORD 140300,0,0,0 ;FSRC
4428 021462 000000
4429 021464 134200 000000 000000 .WORD 134200,0,0,0 ;RESULT
4430 021472 000000
4431 021474 000240 .WORD 240 ; TEST FPS
4432 021476 000250 .WORD 250 ;RESULT FPS
4433
;5/ROUND NEGATIVE AC, FSRC
4434 021500 005037 001042 CLR B#FLAG ;NO INTERRUPT
4435 021504 004767 000270 JSR R7,DVDSUB ;DO TEST
4436 021510 177642 000000 000000 .WORD 177642,0,0,151 ;ACO
4437 021516 000151
4438 021520 166600 000000 000000 .WORD 166600,0,0,123 ;FSRC
4439 021526 000123
4440 021530 051242 000000 000000 .WORD 51242,0,0,0 ;RESULT
4441 021536 000000
4442 021540 000200 .WORD 200 ; TEST FPS
4443 021542 000200 .WORD 200 ;RESULT FPS
4444
;6/TRUNCATE NEAGTIVE AC, FSRC
4445 021544 005037 001042 CLR B#FLAG ;NO INTERRUPT
4446 021550 004767 000224 JSR R7,DVDSUB ;DO TEST
4447 021554 177642 000000 000000 .WORD 177642,0,0,151 ;ACO
4448 021562 000151
4449 021564 166600 000000 000000 .WORD 166600,0,0,123 ;FSRC
4450 021572 000123
4451 021574 051241 177777 177777 .WORD 51241,-1,-1,-1 ;RESULT
4452 021602 177777
4453 021604 000240 .WORD 240 ; TEST FPS
4454 021606 000240 .WORD 240 ;RESULT FPS
4455
;7/AC=FSRC
4456 021610 005037 001042 CLR B#FLAG ;NO INTERRUPT
4457 021614 004767 000160 JSR R7,DVDSUB ;DO TEST
4458 021620 055521 047621 100333 .WORD 55521,47621,100333,-1 ;ACO
4459 021626 177777
4460 021630 055521 047621 100333 .WORD 55521,47621,100333,-1 ;FSRC
4461 021636 177777
4462 021640 040200 000000 000000 .WORD 40200,0,0,0 ;RESULT
4463 021646 000000
4464 021650 007717 .WORD 7717 ; TEST FPS
4465 021652 007700 .WORD 7700 ;RESULT FPS
4466
;8/UNDERFLOW TRAPS ENABLED, UV RESULT
4467 021654 012737 000001 001042 MOV #1,B#FLAG ;INTERRUPT
4468 021662 004767 000112 JSR R7,DVDSUB ;DO TEST
4469 021666 100200 000000 000000 .WORD 100200,0,0,0 ;ACO
4470 021674 000000
    
```

```

4471 021676 077777 000000 000000 .WORD 77777,0,0,0 ;FSRC
4472 021704 000000
4473 021706 140400 100200 100200 .WORD 140400,100200,100200,100201 ;RESULT
4474 021714 100201
4475 021716 002200 .WORD 2200 ; TEST FPS
4476 021720 102210 .WORD 102210 ;RESULT FPS
4477 021722 000012 .WORD 12 ;FEC
4478
4479 021724 012737 000001 001042 ;9/OVERFLOW TRAPS ENABLED
4480 021732 004767 000042 MOV #1,B#FLAG ; INTERRUPT
4481 021736 077000 123465 012346 JSR R7,DVDSUB ;DO TEST
4482 021744 000525 .WORD 77000,123465,12346,525 ;ACO
4483 021746 000303 000001 140000 .WORD 303,1,140000,140001 ;FSRC
4484 021754 140001
4485 021756 036650 163002 103645 .WORD 36650,163002,103645,64003 ;RESULT
4486 021764 064003
4487 021766 001700 .WORD 1700 ; TEST FPS
4488 021770 101702 .WORD 101702 ;RESULT FPS
4489 021772 000010 .WORD 10 ;FEC
4490
4491
4492 021774 000167 000242 JMP HOP11 ;HOP OVER SUBROUTINE
4493 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4494 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4495
4496 ;
4497 ;DIVD SUBROUTINE:
4498 ; ACO
4499 ; FSRC
4500 ; FPS BEFORE EXECUTION
4501 ; FPS AFTER EXECUTION
4502 ; (FEC)
4503 ;
4504 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4505 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4506 022000 012605 DVDSUB: MOV (SP),R5 ; RETURN ADDRESS TO USE AS POINTER
4507 022002 012737 022062 000244 MOV #501,B#FPVEC ;REDIRECT TRAP VECTOR
4508 022010 012702 000200 MOV #200,R2 ;SET TO DOUBLE MODE FOR LOAD
4509 022014 170102 LDFPS R2 ;LOAD FPS
4510 022016 010504 MOV R5,R4 ;POINT TO FSRC DATA
4511 022020 062704 000010 ADD #10,R4
4512 022024 172415 LDD (R5),ACO ;LOAD ACO WITH TEST DATA
4513 022026 016502 000030 MOV 30(R5),R2 ;GET TEST FPS
4514 022032 170102 LDFPS R2 ;LOAD TEST FPS
4515
4516 022034 174414 ;
4517 022036 170000 1$: DIVD (R4),ACO ;*TEST INSTRUCTION
4518 ; CFCC ;WAIT FOR POSSIBLE FPA TRAP.
4519 ;
4520 022040 032737 000001 001042 ;INSTRUCTION DIDNT TRAP
4521 022046 001426 BIT #1,B#FLAG ;VERIFY A NO TRAP CONDITION
4522 022050 104000 BEQ 2$ ;BRANCH IF GOOD
4523 022052 000351 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4524 022054 002013 .WORD 351 ;UNIQUE ERROR NUMBER
4525 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4526 022056 000167 000042 JMP 2$ ;INSTRUCTION SHOULD HAVE TRAPPED
;REJOIN CODE

```



```

4527
4528
4529 022062 032737 000001 001042 50: INSTRUCTION TRAPPED
4530 022070 001005 BIT #1,0#FLAG ;SEE IF EXPECTING A TRAP
4531 022072 104000 BNE 51# ;BRANCH IF EXPECTING A TRAP
4532 022074 000352 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4533 022076 002013 .WORD 352 ;UNIQUE ERROR NUMBER
4534 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4535 022100 000167 000020 ;INSTRUCTION WASNT SUPPOSE TO TRAP
4536 022104 012604 51: JMP 2# ;REJOIN CODE
4537 022106 005726 MOV (SP)+,R4 ;SEE IF PC = INSTRUCTION
4538 022110 022704 022036 TST (SP)+ ;CLEAN UP STACK
4539 022114 001403 CMP #1#,R4
4540 022116 104000 BEQ 2# ;BRANCH IF GOOD COMPARE
4541 022120 000353 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4542 022122 002013 .WORD 353 ;UNIQUE ERROR NUMBER
4543 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4544 ;PC WAS INCORRECT
4545 ;COMMON CODE FOR TRAP AND NO TRAP
4546 022124 170203 2: STFPS R3 ;SAVE FPS
4547 022126 012702 000200 MOV #200,R2 ;SET FPP TO DOUBLE
4548 022132 170102 LDFPS R2
4549 022134 012701 001126 MOV #RECDST,R1 ;POINT TO RECEIVED DATA TABLE
4550 022140 174011 STD ACO,(R1) ;SAVE ACO RESULT
4551 022142 026503 000032 CMP 32(R5),R3 ;VERIFY STATUS
4552 022146 001403 BEQ 3# ;BRANCH IF GOOD
4553 022150 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4554 022152 000354 .WORD 354 ;UNIQUE ERROR NUMBER
4555 022154 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4556 ;BAD FPS
4557 022156 010504 3: MOV R5,R4 ;POINT TO EXPECTED DATA
4558 022160 062704 000020 ADD #20,R4
4559 022164 004767 157756 4: JSR R7,DATVER ;VERIFY DATA
4560 022170 005767 156644 TST COUNT
4561 022174 001403 BEQ 5# ;BRANCH IF GOOD
4562 022176 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4563 022200 000355 .WORD 355 ;UNIQUE ERROR NUMBER
4564 022202 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4565 ;BAD ACO
4566 022204 005737 001042 5: TST 0#FLAG ;SEE IF NEED TO CHECK FEC
4567 022210 001002 BNE 6# ;BRANCH IF NEED TO CHECK
4568 022212 000165 000034 JMP 34(R5) ;RETURN FROM TEST
4569 022216 170301 6: STST R1 ;SAVE FEC
4570 022220 016504 000034 MOV 34(R5),R4 ;GET FEC
4571 022224 020401 CMP R4,R1 ;VERIFY FEC
4572 022226 001403 BEQ 7# ;BRANCH IF GOOD
4573 022230 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4574 022232 000356 .WORD 356 ;UNIQUE ERROR NUMBER
4575 022234 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4576 ;BAD FEC
4577 022236 000165 000036 7: JMP 36(R5) ;RETURN FROM TEST
4578
4579 022242 ;
4580 022242 ;MOP11:
4581 ;MMULF:
4582 ;*****
;*TEST 63 TEST MULF
    
```

```

4583
4584 022242
4585 022242 005267 156536
4586
4587 022246 005037 001042
4588 022252 004767 000564
4589 022256 000000 000000
4590 022262 000000 000000
4591 022266 000000 000000
4592 022272 007517
4593 022274 007504
4594
4595 022276 005037 001042
4596 022302 004767 000534
4597 022306 000200 000000
4598 022312 000000 000000
4599 022316 000000 000000
4600 022322 000013
4601 022324 000004
4602
4603 022326 005037 001042
4604 022332 004767 000504
4605 022336 000100 000000
4606 022342 000300 000000
4607 022346 000000 000000
4608 022352 007500
4609 022354 007504
4610
4611 022356 005037 001042
4612 022362 004767 000454
4613 022366 040200 000000
4614 022372 040177 177777
4615 022376 040177 177777
4616 022402 000000
4617 022404 000000
4618
4619 022406 005037 001042
4620 022412 004767 000424
4621 022416 040177 177777
4622 022422 040200 000000
4623 022426 040177 177777
4624 022432 000040
4625 022434 000040
4626
4627 022436 005037 001042
4628 022442 004767 000374
4629 022446 040100 000000
4630 022452 040100 000000
4631 022456 040020 000000
4632 022462 000012
4633 022464 000000
4634
4635 022466 005037 001042
4636 022472 004767 000344
4637 022476 017500 000000
4638 022502 023652 125252

```

```

*****
TST63:
      INC      $TESTN      ;INCREMENT TEST NUMBER
;1/ACO=FSRC=0 - INTERRUPTS DISABLED
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   0,0        ;ACO
      .WORD   0,0        ;FSRC
      .WORD   0,0
      .WORD   7517      ;RESULT
      .WORD   7504      ;TEST FPS
      .WORD   7504      ;RESULTANT FPS
;2/AC>FSRC=0 - INTERRUPTS ON
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   200,0     ;ACO
      .WORD   0,0      ;FSRC
      .WORD   0,0
      .WORD   13       ;RESULT
      .WORD   4        ;TEST FPS
      .WORD   4        ;RESULTANT FPS
;3/AC=0 FSRC>0 -
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   100,0    ;ACO
      .WORD   300,0    ;FSRC
      .WORD   0,0
      .WORD   7500     ;RESULT
      .WORD   7504     ;TEST FPS
      .WORD   7504     ;RESULTANT FPS
;4/AC=1 >FSRC - ROUND
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   40200,0  ;ACO
      .WORD   40177,-1 ;FSRC
      .WORD   40177,-1 ;RESULT
      .WORD   0        ;TEST FPS
      .WORD   0        ;RESULTANT FPS
;5/TRUNCATE
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   40177,-1 ;ACO
      .WORD   40200,0  ;FSRC
      .WORD   40177,-1 ;RESULT
      .WORD   40        ;TEST FPS
      .WORD   40        ;RESULTANT FPS
;6/NORMALIZE
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   40100,0  ;ACO
      .WORD   40100,0  ;FSRC
      .WORD   40020,0  ;RESULT
      .WORD   12       ;TEST FPS
      .WORD   0        ;RESULTANT FPS
;7/ROUND
      CLR      @FLAG      ;NO INTERRUPT
      JSR      R7,MLFSUB   ;DO TEST
      .WORD   17500,0  ;ACO
      .WORD   23652,125252 ;FSRC

```

4639	022506	003177	177777		.WORD	3177,-1		;RESULT
4640	022512	007417			.WORD	7417		;TEST FPS
4641	022514	007400			.WORD	7400		;RESULTANT FPS
4642								
4643	022516	005037	001042		:8/AC>0>FSRC ROUND			
4644	022522	004767	000314		CLR	@FLAG		;NO INTERRUPT
4645	022526	040342	177777		JSR	R7,MLFSUB		;DO TEST
4646	022532	176543	025252		.WORD	40342,-1		;ACO
4647	022536	176711	067324		.WORD	176543,025252		;FSRC
4648	022542	007500			.WORD	176711,67324		;RESULT
4649	022544	007510			.WORD	7500		;TEST FPS
4650					.WORD	7510		;RESULTANT FPS
4651	022546	005037	001042		:9/IAC<FSRC<0, ROUND			
4652	022552	004767	000264		CLR	@FLAG		;NO INTERRUPT
4653	022556	144600	000000		JSR	R7,MLFSUB		;DO TEST
4654	022562	154000	000000		.WORD	144600,0		;ACO
4655	022566	060400	000000		.WORD	154000,0		;FSRC
4656	022572	000017			.WORD	60400,0		;RESULT
4657	022574	000000			.WORD	17		;TEST FPS
4658					.WORD	0		;RESULT FPS
4659	022576	005037	001042		:10/AC<FSRC, ROUND			
4660	022602	004767	000234		CLR	@FLAG		;NO INTERRUPT
4661	022606	060000	000000		JSR	R7,MLFSUB		;DO TEST
4662	022612	140377	177776		.WORD	60000,0		;ACO
4663	022616	160177	177776		.WORD	140377,177776		;FSRC
4664	022622	000017			.WORD	160177,177776		;RESULT
4665	022624	000010			.WORD	17		;TEST FPS
4666					.WORD	10		;RESULT FPS
4667	022626	005037	001042		:11/AC>0>FSRC, TRUNCATE			
4668	022632	004767	000204		CLR	@FLAG		;NO INTERRUPT
4669	022636	060000	000000		JSR	R7,MLFSUB		;DO TEST
4670	022642	140377	177776		.WORD	60000,0		;ACO
4671	022646	160177	177776		.WORD	140377,177776		;FSRC
4672	022652	007547			.WORD	160177,177776		;RESULT
4673	022654	007550			.WORD	7547		;TEST FPS
4674					.WORD	7550		;RESULT FPS
4675	022656	012737	000002	001042	:12/UNDERFLOW, NO INTERRUPTS			
4676	022664	004767	000152		MOV	@2,@FLAG		;NO INTERRUPT
4677	022670	000200	000001		JSR	R7,MLFSUB		;DO TEST
4678	022674	000200	000001		.WORD	200,1		;ACO
4679	022700	040200	000002		.WORD	200,1		;FSRC
4680	022704	042117			.WORD	40200,2		;RESULT
4681	022706	142100			.WORD	42117		;TEST FPS
4682	022710	000012			.WORD	142100		;RESULT FPS
4683					.WORD	12		;FEC
4684	022712	012737	000001	001042	:13/OVERFLOW, TRAP			
4685	022720	004767	000116		MOV	@1,@FLAG		;INTERRUPT
4686	022724	177777	177777		JSR	R7,MLFSUB		;DO TEST
4687	022730	040300	000000		.WORD	177777,-1		;ACO
4688	022734	100077	177777		.WORD	40300,0		;FSRC
4689	022740	001117			.WORD	100077,-1		;RESULT
4690	022742	101116			.WORD	1117		;TEST FPS
4691	022744	000010			.WORD	101116		;RESULT FPS
4692					.WORD	10		;FEC
4693	022746	012737	000002	001042	:14/OVERFLOW NO TRAP			
4694	022754	004767	000062		MOV	@2,@FLAG		;NO INTERRUPT
					JSR	R7,MLFSUB		;DO TEST

```

4695 022760 077700 000000 .WORD 77700,0 ;ACO
4696 022764 077700 000000 .WORD 77700,0 ;FSRC
4697 022770 000000 000000 .WORD 0,0 ;RESULT
4698 022774 040117 .WORD 40117 ; TEST FPS
4699 022776 040106 .WORD 40106 ;RESULT FPS
4700 023000 000010 .WORD 10 ;FEC
4701 ;15/UNDEFINED VARIABLE IN FSRC, TRAP ENABLED
4702 023002 012737 000001 001042 MOV #1,0#FLAG ;INTERRUPT
4703 023010 004767 000026 JSR R7,MLFSUB ;DO TEST
4704 023014 123465 000000 .WORD 123465,0 ;ACO
4705 023020 100022 000000 .WORD 100022,0 ;FSRC
4706 023024 123465 000000 .WORD 123465,0 ;RESULT
4707 023030 004000 .WORD 4000 ; TEST FPS
4708 023032 104000 .WORD 104000 ;RESULT FPS
4709 023034 000014 .WORD 14 ;FEC
4710 ;
4711 ;
4712 023036 000167 000242 JMP HOP12
4713 ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
4714 ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
4715 ;
4716 ; ACO
4717 ; FSRC
4718 ; FPS BEFORE EXECUTION
4719 ; FPS AFTER EXECUTION
4720 ; (FEC)
4721 ;
4722 ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
4723 ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
4724 ;
4725 023042 012605 MLFSUB: MOV (SP)+,R5 ; RETURN ADDRESS TO USE AS POINTER
4726 023044 012737 023124 000244 MOV #50,0#FPVEC ;REDIRECT TRAP VECTOR
4727 023052 012702 000200 MOV #200,R2 ;SET TO DOUBLE MODE FOR LOAD
4728 023056 170102 LDFPS R2 ;LOAD FPS
4729 023060 172415 LDD (R5),ACO ;LOAD ACO WITH TEST DATA
4730 023062 010504 MOV R5,R4 ;POINT TO FSRC DATA
4731 023064 062704 000004 ADD #4,R4
4732 023070 016502 000014 MOV 14(R5),R2 ;GET TEST FPS
4733 023074 170102 LDFPS R2 ;LOAD TEST FPS
4734 ;
4735 023076 171014 MULF (R4),ACO ;*TEST INSTRUCTION
4736 023100 170001 1$: SETF ;WAIT FOR POSSIBLE FPA TRAP.
4737 ;
4738 ; INSTRUCTION DIDNT TRAP
4739 023102 032737 000001 001042 BIT #1,0#FLAG ;VERIFY A NO TRAP CONDITION
4740 023110 001426 BEQ 2$ ;BRANCH IF GOOD
4741 023112 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
4742 023114 000357 .WORD 357 ;UNIQUE ERROR NUMBER
4743 023116 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
4744 ; INSTRUCTION SHOULD HAVE TRAPPED
4745 023120 000167 000042 JMP 2$ ;REJOIN CODE
4746 ;
4747 ; INSTRUCTION TRAPPED
4748 023124 032737 000001 001042 50$: BIT #1,0#FLAG ;SEE IF EXPECTING A TRAP
4749 023132 001005 BNE 51$ ;BRANCH IF EXPECTING A TRAP
4750 023134 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
    
```


4863	023604	017500	000000	000000	.WORD	17500,0,0,0	;ACO
4864	023612	000000					
4865	023614	123652	125252	125252	.WORD	123652,125252,125252,125252	;FSRC
4866	023622	125252					
4867	023624	103177	177777	177777	.WORD	103177,-1,-1,-1	;RESULT
4868	023632	177777					
4869	023634	000200			.WORD	200	; TEST FPS
4870	023636	000210			.WORD	210	;RESULTANT FPS
4871							
4872	023640	005037	001042		;7/UNDERFLOW, TRAPS DISABLED		
4873	023644	004767	000224		CLR	#0FLAG	;NO INTERRUPT
4874	023650	000300	000000	000000	JSR	R7,MLDSUB	;DO TEST
4875	023656	000252			.WORD	300,0,0,252	;ACO
4876	023660	000377	000001	000002	.WORD	377,1,2,3	;FSRC
4877	023666	000003					
4878	023670	000000	000000	000000	.WORD	0,0,0,0	;RESULT
4879	023676	000000					
4880	023700	005740			.WORD	5740	; TEST FPS
4881	023702	005744			.WORD	5744	;RESULT FPS
4882							
4883	023704	012737	000001	001042	;8/UNDERFLOW, TRAP ENABLED		
4884	023712	004767	000156		MOV	#1,#0FLAG	; INTERRUPT
4885	023716	100277	000001	000002	JSR	R7,MLDSUB	;DO TEST
4886	023724	177777			.WORD	100277,1,2,-1	;ACO
4887	023726	100300	000001	000001	.WORD	100300,1,1,1	;FSRC
4888	023734	000001					
4889	023736	040417	040001	077403	.WORD	40417,40001,77403,0	;RESULT
4890	023744	000000					
4891	023746	002217			.WORD	2217	; TEST FPS
4892	023750	102200			.WORD	102200	;RESULT FPS
4893	023752	000012			.WORD	12	;FEC
4894							
4895	023754	005037	001042		;9/OVERFLOW, TRAPS DISABLED		
4896	023760	004767	000110		CLR	#0FLAG	;NO INTERRUPT
4897	023764	177777	177777	177777	JSR	R7,MLDSUB	;DO TEST
4898	023772	177777			.WORD	-1,-1,-1,-1	;ACO
4899	023774	040200	177777	177777	.WORD	40200,-1,-1,-1	;FSRC
4900	024002	177777					
4901	024004	000000	000000	000000	.WORD	0,0,0,0	;RESULT
4902	024012	000000					
4903	024014	006740			.WORD	6740	; TEST FPS
4904	024016	006746			.WORD	6746	;RESULT FPS
4905							
4906	024020	012737	000001	001042	;10/OVERFLOW, TRAPS ENABLED		
4907	024026	004767	000042		MOV	#1,#0FLAG	; INTERRUPT
4908	024032	157700	025252	025252	JSR	R7,MLDSUB	;DO TEST
4909	024040	025252			.WORD	157700,25252,25252,25252	;ACO
4910	024042	167700	000000	000000	.WORD	167700,0,0,0	;FSRC
4911	024050	000000					
4912	024052	007420	017777	117777	.WORD	7420,017777,117777,117777	;RESULT
4913	024060	117777					
4914	024062	001240			.WORD	1240	; TEST FPS
4915	024064	101242			.WORD	101242	;RESULT FPS
4916	024066	000010			.WORD	10	;FEC
4917							
4918							

```

4919 024070 000167 000242          JMP      HOP13
4920
4921          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4922          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4923          ;
4924          ;          ACO
4925          ;          FSRC
4926          ;          FPS BEFORE EXECUTION
4927          ;          FPS AFTER EXECUTION
4928          ;          (FEC)
4929          ;
4930          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4931          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4932          ;
4933 024074 012605          MLDSUB: MOV      (SP),R5          ; RETURN ADDRESS TO USE AS POINTER
4934 024076 012737 024156 000244      MOV      @50@,RFPVEC      ; REDIRECT TRAP VECTOR
4935 024104 012702 000200          MOV      @200,R2         ; SET TO DOUBLE MODE FOR LOAD
4936 024110 170102          LDFPS   R2              ; LOAD FPS
4937 024112 172415          LDD     (R5),ACO        ; LOAD ACO WITH TEST DATA
4938 024114 010501          MOV     R5,R1           ; POINT TO FSRC DATA
4939 024116 062701 000010          ADD     @10,R1
4940 024122 016502 000030          MOV     30(R5),R2
4941 024126 170102          LDFPS   R2              ; GET TEST FPS
4942          ;
4943 024130 171011          ;
4944 024132 170011          1$:     MULD   (R1),ACO    ; *TEST INSTRUCTION
4945          ;
4946          ;          SETD
4947          ;          INSTRUCTION DIDNT TRAP
4948 024134 032737 000001 001042      BIT     @1,@FLAG        ; VERIFY A NO TRAP CONDITION
4949 024142 001426          BEQ     2$              ; BRANCH IF GOOD
4950 024144 104000          ERROR
4951 024146 000365          .WORD  365              ; ALL ERRORS TO TRAP TO EMT VECTOR
4952 024150 002013          .WORD  FPPERR           ; UNIQUE ERROR NUMBER
4953 024152 000167 000042          JMP     2$              ; ADDRESS OF ERROR MESSAGE
4954          ;
4955          ;          INSTRUCTION TRAPPED
4956 024156 032737 000001 001042      50$:   BIT     @1,@FLAG        ; INSTRUCTION SHOULD HAVE TRAPPED
4957 024164 001005          BNE     51$              ; REJOIN CODE
4958 024166 104000          ERROR
4959 024170 000366          .WORD  366              ; SEE IF EXPECTING A TRAP
4960 024172 002013          .WORD  FPPERR           ; BRANCH IF EXPECTING A TRAP
4961          ;
4962 024174 000167 000020          JMP     2$              ; ALL ERRORS TO TRAP TO EMT VECTOR
4963 024200 012604          51$:   MOV     (SP),R4        ; UNIQUE ERROR NUMBER
4964 024202 005726          TST     (SP)             ; ADDRESS OF ERROR MESSAGE
4965 024204 022704 024132          CMP     @1@,R4          ; INSTRUCTION WASNT SUPPOSE TO TRAP
4966 024210 001403          BEQ     2$              ; REJOIN CODE
4967 024212 104000          ERROR
4968 024214 000367          .WORD  367              ; SEE IF PC = INSTRUCTION
4969 024216 002013          .WORD  FPPERR           ; CLEAN UP STACK
4970          ;
4971          ;          PC WAS INCORRECT
4972          ;
4973 024220 170203          ; COMMON CODE FOR TRAP AND NO TRAP
4974 024222 012702 000200          2$:   STFPS   R3          ; SAVE FPS
          ;          MOV     @200,R2          ; SET FPP TO DOUBLE

```



```

4975 024226 170102          LDFPS  R2
4976 024230 012701 001126  MOV    #RECDST,R1          ;POINT TO RECEIVED DATA TABLE
4977 024234 174011          STD    ACO,(R1)           ;SAVE ACO RESULT
4978 024236 026503 000032  CMP    32(R5),R3         ;VERIFY STATUS
4979 024242 001403          BEQ    3#                ;BRANCH IF GOOD
4980 024244 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
4981 024246 000370          .WORD  370              ;UNIQUE ERROR NUMBER
4982 024250 002013          .WORD  FPPERR           ;ADDRESS OF ERROR MESSAGE
4983
4984 024252 010504          3#:   MOV    R5,R4          ;BAD FPS
4985 024254 062704 000020  ADD    #20,R4            ;POINT TO EXPECTED DATA
4986 024260 004767 155662  4#:   JSR    R7,DATVER       ;VERIFY DATA
4987 024264 005767 154550  TST    COUNT
4988 024270 001403          BEQ    5#                ;BRANCH IF GOOD
4989 024272 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
4990 024274 000371          .WORD  371              ;UNIQUE ERROR NUMBER
4991 024276 002013          .WORD  FPPERR           ;ADDRESS OF ERROR MESSAGE
4992
4993 024300 005737 001042  5#:   TST    @#FLAG          ;BAD ACO
4994 024304 001002          BNE    6#                ;SEE IF NEED TO CHECK FEC
4995 024306 000165 000034  JMP    34(R5)            ;BRANCH IF NEED TO CHECK
4996
4997 024312 170301          ;VERIFY ERROR STATUS
4998 024314 016504 000034  6#:   STST   R1
4999 024320 020401          MOV    34(R5),R4        ;SAVE FEC
5000 024322 001403          CMP    R4,R1            ;GET FEC
5001 024324 104000          BEQ    7#                ;VERIFY FEC
5002 024326 000372          ERROR          ;BRANCH IF GOOD
5003 024330 002013          .WORD  372              ;ALL ERRORS TO TRAP TO EMT VECTOR
5004
5005 024332 000165 000036  7#:   .WORD  FPPERR           ;UNIQUE ERROR NUMBER
5006 024336
5007 024336
5008
5009
5010
5011 024336
5012 024336 005267 154442  HOP13:
5013
5014 024342 005037 001042  HMODF:
5015 024346 004767 000554  ;*****
5016 024352 000100 000000  ;*TEST 65          TEST MODF
5017 024356 012346 177777  ;*****
5018 024362 000000 000000  TST65:
5019 024366 000000 000000  INC    #TESTN           ;INCREMENT TEST NUMBER
5020 024372 000013          ;1/AC=0  FSRC=0
5021 024374 000004          CLR    @#FLAG          ;NO INTERRUPT
5022
5023 024376 005037 001042  JSR    R7,MDFSUB       ;DO TEST
5024 024402 004767 000520  .WORD  100,0           ;ACO
5025 024406 012356 177777  .WORD  12346,-1
5026 024412 000000 000000  .WORD  0,0             ;FSRC
5027 024416 000000 000000  .WORD  0,0             ;FRACTIONAL RESULT
5028 024422 000000 000000  .WORD  0,0             ;INTEGER RESULT
5029 024426 000003          .WORD  13              ;TEST FPS
5030 024430 000004          .WORD  4                ;RESULTANT FPS

```

5031							
5032	024432	005037	001042	:3/AC=0	CLR	B#FLAG	;NO INTERRUPT
5033	024436	004767	000464		JSR	R7,MDFSUB	;DO TEST
5034	024442	000000	000000		.WORD	0,0	;ACO
5035	024446	177777	177777		.WORD	1,-1	;FSRC
5036	024452	000000	000000		.WORD	0,0	;FRACTIONAL RESULT
5037	024456	000000	000000		.WORD	0,0	;INTEGER RESULT
5038	024462	007500			.WORD	7500	;TEST FPS
5039	024464	007504			.WORD	7504	;RESULT FPS
5040							
5041	024466	005037	001042	:4/AC>FSRC>0	CLR	B#FLAG	;NO INTERRUPT
5042	024472	004767	000430		JSR	R7,MDFSUB	;DO TEST
5043	024476	046252	125252		.WORD	46252,125252	;ACO
5044	024502	040300	000000		.WORD	40300,0 ;FSRC	
5045	024506	000000	000000		.WORD	0,0	;FRACTIONAL RESULT
5046	024512	046377	177777		.WORD	46377,-1	;INTEGER RESULT
5047	024516	000013			.WORD	13	;TEST FPS
5048	024520	000004			.WORD	4	;RESULTANT FPS
5049							
5050	024522	005037	001042	:5/AC>FSRC>0	CLR	B#FLAG	;NO INTERRUPT
5051	024526	004767	000374		JSR	R7,MDFSUB	;DO TEST
5052	024532	077652	125252		.WORD	77652,125252	;ACO
5053	024536	040300	000000		.WORD	40300,0 ;FSRC	
5054	024542	000000	000000		.WORD	0,0	;FRACTIONAL RESULT
5055	024546	077777	177777		.WORD	77777,-1	;INTEGER RESULT
5056	024552	000000			.WORD	0	;TEST FPS
5057	024554	000004			.WORD	4	;RESULTANT FPS
5058							
5059							
5060	024556	005037	001042	:6/AC>0<FSRC, INTEGERS	CLR	B#FLAG	;NO INTERRUPT
5061	024562	004767	000340		JSR	R7,MDFSUB	;DO TEST
5062	024566	060600	000000		.WORD	60600,0	;ACO
5063	024572	147400	025700		.WORD	147400,25700	;FSRC
5064	024576	000000	000000		.WORD	0,0	;FRACTIONAL RESULT
5065	024602	170000	025700		.WORD	170000,25700	;INTEGER RESULT
5066	024606	007400			.WORD	7400	;TEST FPS
5067	024610	007404			.WORD	7404	;RESULT FPS
5068							
5069	024612	005037	001042	:7/AC<0<FSRC, FRACTIONAL	CLR	B#FLAG	;NO INTERRUPT
5070	024616	004767	000304		JSR	R7,MDFSUB	;DO TEST
5071	024622	100227	177777		.WORD	100227,-1	;ACO
5072	024626	044025	025252		.WORD	44025,25252	;FSRC
5073	024632	104061	021251		.WORD	104061,21251	;FRACTIONAL RESULT
5074	024636	000000	000000		.WORD	0,0	;INTEGER RESULT
5075	024642	000000			.WORD	0	;TEST FPS
5076	024644	000010			.WORD	10	;RESULT FPS
5077							
5078	024646	005037	001042	:8/AC<0>FSRC, TRUNCATE	CLR	B#FLAG	;NO INTERRUPT
5079	024652	004767	000250		JSR	R7,MDFSUB	;DO TEST
5080	024656	046252	125252		.WORD	46252,125252	;ACO
5081	024662	040300	000000		.WORD	40300,0	;FSRC
5082	024666	000000	000000		.WORD	0,0	;FRACTIONAL RESULT
5083	024672	046377	177777		.WORD	46377,-1	;INTEGER RESULT
5084	024676	000053			.WORD	53	;TEST FPS
5085	024700	000044			.WORD	44	;RESULT FPS
5086				:9/ROUND INTEGER			

```
5087 024702 005037 001042 CLR B#FLAG ;NO INTERRUPT
5088 024706 004767 000214 JSR R7,MDFSUB ;DO TEST
5089 024712 046252 125252 .WORD 46252,125252 ;ACO
5090 024716 040300 000000 .WORD 40300,0 ;FSRC
5091 024722 000000 000000 .WORD 0,0 ;FRACTIONAL RESULT
5092 024726 046377 177777 .WORD 46377,-1 ;INTEGER RESULT
5093 024732 000013 .WORD 13 ;TEST FPS
5094 024734 000004 .WORD 4 ;RESULT FPS
5095 ;10/TRUNCATE FRACTION
5096 024736 005037 001042 CLR B#FLAG ;NO INTERRUPT
5097 024742 004767 000160 JSR R7,MDFSUB ;DO TEST
5098 024746 040777 177777 .WORD 40777,-1 ;ACO
5099 024752 040200 000000 .WORD 40200,0 ;FSRC
5100 024756 040177 177770 .WORD 40177,177770 ;FRACTIONAL RESULT
5101 024762 040740 000000 .WORD 40740,0 ;INTEGER RESULT
5102 024766 000000 .WORD 0 ;TEST FPS
5103 024770 000000 .WORD 0 ;RESULT FPS
5104 ;11/ROUND INTEGER
5105 024772 005037 001042 CLR B#FLAG ;NO INTERRUPT
5106 024776 004767 000124 JSR R7,MDFSUB ;DO TEST
5107 025002 000000 000000 .WORD 0,0 ;ACO
5108 025006 000000 000000 .WORD 0,0 ;FSRC
5109 025012 000000 000000 .WORD 0,0 ;FRACTIONAL RESULT
5110 025016 000000 000000 .WORD 0,0 ;INTEGER RESULT
5111 025022 000000 .WORD 0 ;TEST FPS
5112 025024 000004 .WORD 4 ;RESULT FPS
5113 ;12/ROUND FRACTION
5114 025026 005037 001042 CLR B#FLAG ;NO INTERRUPT
5115 025032 004767 000070 JSR R7,MDFSUB ;DO TEST
5116 025036 040225 125252 .WORD 40225,125252 ;ACO
5117 025042 066652 052525 .WORD 66652,52525 ;FSRC
5118 025046 000000 000000 .WORD 0,0 ;FRACTIONAL RESULT
5119 025052 066707 025160 .WORD 66707,25160 ;INTEGER RESULT
5120 025056 007027 .WORD 7027 ;TEST FPS
5121 025060 007004 .WORD 7004 ;RESULT FPS
5122 ;/OVERFLOW
5123 025062 012737 000001 001042 MOV #1,B#FLAG ;INTERRUPT
5124 025070 004767 000032 JSR R7,MDFSUB ;DO TEST
5125 025074 076000 000000 .WORD 76000,0 ;ACO
5126 025100 076000 000000 .WORD 76000,0 ;FSRC
5127 025104 000000 000000 .WORD 0,0 ;FRACTIONAL RESULT
5128 025110 033600 000000 .WORD 33600,0 ;INTEGER RESULT
5129 025114 001000 .WORD 1000 ;TEST FPS
5130 025116 101006 .WORD 101006 ;RESULT FPS
5131 025120 000010 .WORD 10 ;FEC
5132 ;
5133 025122 000167 000310 JMP HOP14
5134 ;
5135 ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
5136 ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
5137 ;
5138 ;
5139 ; ACO
5140 ; FSRC
5141 ; FRACTIONAL RESULT
5142 ; INTEGER RESULT
; FPS BEFORE EXECUTION
```

```

5143                                     :           FPS AFTER EXECUTION
5144                                     :           (FEC)
5145                                     :
5146                                     : *X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
5147                                     : *X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
5148                                     :
5149 025126 012605                          :MDFSUB: MOV      (SP)+,R5                ; RETURN ADDRESS TO USE AS POINTER
5150 025130 012737 025216 000244          :      MOV      #50#,B#FPVEC            ; REDIRECT TRAP VECTOR
5151 025136 012702 000200                  :      MOV      #200,R2                 ; SET TO DOUBLE MODE FOR LOAD
5152 025142 170102                          :      LDFPS   R2                       ; LOAD FPS
5153 025144 172415                          :      LDD     (R5),AC0                  ; LOAD AC0 WITH TEST DATA
5154 025146 012701 025426                  :      MOV      #MODGAR,R1              ; LOAD KNOWN INTO AC1
5155 025152 172511                          :      LDD     (R1),AC1                  ;
5156 025154 010501                          :      MOV      R5,R1                    ; POINT TO FSRC DATA
5157 025156 062701 000004                  :      ADD     #4,R1                      ;
5158 025162 016502 000020                  :      MOV      20(R5),R2                ; GET TEST FPS
5159 025166 170102                          :      LDFPS   R2                       ; LOAD TEST FPS
5160                                     :
5161 025170 171411                          :      MODF   (R1),AC0                  ; *TEST INSTRUCTION
5162 025172 170001                          :1$:   SETF                                ; WAIT FOR POSSIBLE FPA TRAP.
5163                                     :
5164                                     : INSTRUCTION DIDNT TRAP
5165 025174 032737 000001 001042          :      BIT     #1,B#FLAG                ; VERIFY A NO TRAP CONDITION
5166 025202 001426                          :      BEQ    2$                         ; BRANCH IF GOOD
5167 025204 104000                          :      ERROR  ; ALL ERRORS TO TRAP TO EMT VECTOR
5168 025206 000373                          :      .WORD  373                        ; UNIQUE ERROR NUMBER
5169 025210 002013                          :      .WORD  FPPERR                     ; ADDRESS OF ERROR MESSAGE
5170                                     :
5171 025212 000167 000042                  :      JMP     2$                         ; INSTRUCTION SHOULD HAVE TRAPPED
5172                                     :
5173                                     : INSTRUCTION TRAPPED
5174 025216 032737 000001 001042          :50$:  BIT     #1,B#FLAG                ; SEE IF EXPECTING A TRAP
5175 025224 001005                          :      BNE    51$                        ; BRANCH IF EXPECTING A TRAP
5176 025226 104000                          :      ERROR  ; ALL ERRORS TO TRAP TO EMT VECTOR
5177 025230 000374                          :      .WORD  374                        ; UNIQUE ERROR NUMBER
5178 025232 002013                          :      .WORD  FPPERR                     ; ADDRESS OF ERROR MESSAGE
5179                                     :
5180 025234 000167 000020                  :      JMP     2$                         ; INSTRUCTION WASNT SUPPOSE TO TRAP
5181 025240 012604                          :
5182 025242 005726                          :51$:  MOV      (SP)+,R4                ; REJOIN CODE
5183 025244 022704 025172                  :      TST    (SP)+                      ; SEE IF PC = INSTRUCTION
5184 025250 001403                          :      CMP    #1$,R4                    ; CLEAN UP STACK
5185 025252 104000                          :      BEQ    2$                         ;
5186 025254 000375                          :      ERROR  ; BRANCH IF GOOD COMPARE
5187 025256 002013                          :      .WORD  375                        ; ALL ERRORS TO TRAP TO EMT VECTOR
5188                                     :      .WORD  FPPERR                     ; UNIQUE ERROR NUMBER
5189                                     :      ; ADDRESS OF ERROR MESSAGE
5190                                     :      ; PC WAS INCORRECT
5191 025260 170203                          : ;COMMON CODE FOR TRAP AND NO TRAP
5192 025262 012702 000200                  :2$:  STFPS   R3                         ; SAVE FPS
5193 025266 170102                          :      MOV      #200,R2                 ; SET FPP TO DOUBLE
5194 025270 012701 001126                  :      LDFPS   R2                       ;
5195                                     :      MOV      #RECDST,R1              ; POINT TO RECEIVED DATA TABLE
5196 025274 174011                          : ;SAVE FRACTIONAL RESULT
5197 025276 026503 000022                  :      STD     AC0,(R1)                  ; SAVE AC0 RESULT
5198 025302 001403                          :      CMP    22(R5),R3                 ; VERIFY STATUS
5199                                     :      BEQ    3$                         ; BRANCH IF GOOD

```


5255	025502	000000	000000	000000	.WORD	0,0,0,0	; INTEGER RESULT
5256	025510	000000					
5257	025512	000200			.WORD	200	; TEST FPS
5258	025514	000204			.WORD	204	; RESULTANT FPS
5259							
5260	025516	005037	001042				
5261	025522	004767	001110		CLR	B#FLAG	; NO INTERRUPT
5262	025526	000000	000000	000000	JSR	R7,MDDSUB	; DO TEST
5263	025534	000000			.WORD	0,0,0,0	; ACO
5264	025536	001234	177777	000000	.WORD	1234,-1,0,0	; FSRC
5265	025544	000000					
5266	025546	000000	000000	000000	.WORD	0,0,0,0	; FRACTIONAL RESULT
5267	025554	000000					
5268	025556	000000	000000	000000	.WORD	0,0,0,0	; INTEGER RESULT
5269	025564	000000					
5270	025566	007717			.WORD	7717	; TEST FPS
5271	025570	007704			.WORD	7704	; RESULTANT FPS
5272							
5273	025572	005037	001042				
5274	025576	004767	001034		CLR	B#FLAG	; NO INTERRUPT
5275	025602	056252	125252	125252	JSR	R7,MDDSUB	; DO TEST
5276	025610	125250			.WORD	56252,125252,125252,125250	; ACO
5277	025612	040300	000000	000000	.WORD	40300,0,0,0	; FSRC
5278	025620	000000					
5279	025622	000000	000000	000000	.WORD	0,0,0,0	; FRACTIONAL RESULT
5280	025630	000000					
5281	025632	056377	177777	177777	.WORD	56377,-1,-1,-4	; INTEGER RESULT
5282	025640	177774					
5283	025642	000213			.WORD	213	; TEST FPS
5284	025644	000204			.WORD	204	; RESULTANT FPS
5285							
5286	025646	005037	001042				
5287	025652	004767	000760		CLR	B#FLAG	; NO INTERRUPT
5288	025656	140240	000000	000000	JSR	R7,MDDSUB	; DO TEST
5289	025664	000000			.WORD	140240,0,0,0	; ACO
5290	025666	063714	146314	133572	.WORD	63714,146314,133572,167737	; FSRC
5291	025674	167737					
5292	025676	000000	000000	000000	.WORD	0,0,0,0	; FRACTIONAL RESULT
5293	025704	000000					
5294	025706	163777	177777	162531	.WORD	163777,-1,162531,125726	; INTEGER RESULT
5295	025714	125726					
5296	025716	000210			.WORD	210	; TEST FPS
5297	025720	000204			.WORD	204	; RESULTANT FPS
5298							
5299	025722	005037	001042				
5300	025726	004767	000704		CLR	B#FLAG	; NO INTERRUPT
5301	025732	056200	000000	000000	JSR	R7,MDDSUB	; DO TEST
5302	025740	000001			.WORD	56200,0,0,1	; ACO
5303	025742	040340	000000	000000	.WORD	40340,0,0,0	; FSRC
5304	025750	000000					
5305	025752	000000	000000	000000	.WORD	0,0,0,0	; FRACTIONAL RESULT
5306	025760	000000					
5307	025762	056340	000000	000000	.WORD	56340,0,0,1	; INTEGER RESULT
5308	025770	000001					
5309	025772	000213			.WORD	213	; TEST FPS
5310	025774	000204			.WORD	204	; RESULTANT FPS

```

5311
5312 025776 005037 001042 ;6/TRUNCATE
5313 026002 004767 000630 CLR @#FLAG ;NO INTERRUPT
5314 026006 056252 125252 125252 JSR R7,MDDSUB ;DO TEST
5315 026014 125252 .WORD 56252,125252,125252,125252 ;ACO
5316 026016 040300 000000 000000 .WORD 40300,0,0,0 ;FSRC
5317 026024 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5318 026026 000000 000000 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5319 026034 000000 .WORD 56377,-1,-1,-1 ;INTEGER RESULT
5320 026036 056377 177777 177777 .WORD 56377,-1,-1,-1 ;INTEGER RESULT
5321 026044 177777 .WORD 253 ;TEST FPS
5322 026046 000253 .WORD 244 ;RESULT FPS
5323 026050 000244
5324 ;7/TRUNCATE FRACTION
5325 026052 005037 001042 CLR @#FLAG ;NO INTERRUPT
5326 026056 004767 000554 JSR R7,MDDSUB ;DO TEST
5327 026062 023252 125252 125252 .WORD 23252,125252,125252,125252 ;ACO
5328 026070 125252 .WORD 40300,0,0,0 ;FSRC
5329 026072 040300 000000 000000 .WORD 40300,0,0,0 ;FSRC
5330 026100 000000 .WORD 23377,-1,-1,-1 ;FRACTIONAL RESULT
5331 026102 023377 177777 177777 .WORD 23377,-1,-1,-1 ;FRACTIONAL RESULT
5332 026110 177777 .WORD 0,0,0,0 ;INTEGER RESULT
5333 026112 000000 000000 000000 .WORD 0,0,0,0 ;INTEGER RESULT
5334 026120 000000 .WORD 253 ;TEST FPS
5335 026122 000253 .WORD 240 ;RESULT FPS
5336 026124 000240
5337 ;8/ROUND INTEGER
5338 026126 005037 001042 CLR @#FLAG ;NO INTERRUPT
5339 026132 004767 000500 JSR R7,MDDSUB ;DO TEST
5340 026136 076600 000000 000000 .WORD 76600,0,0,125252 ;ACO
5341 026144 125252 .WORD 40300,0,0,0 ;FSRC
5342 026146 040300 000000 000000 .WORD 40300,0,0,0 ;FSRC
5343 026154 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5344 026156 000000 000000 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5345 026164 000000 .WORD 76700,0,0,-1 ;INTEGER RESULT
5346 026166 076700 000000 000000 .WORD 76700,0,0,-1 ;INTEGER RESULT
5347 026174 177777 .WORD 200 ;TEST FPS
5348 026176 000200 .WORD 204 ;RESULT FPS
5349 026200 000204
5350 ;9/ROUND THROUGH FRACTION
5351 026202 005037 001042 CLR @#FLAG ;NO INTERRUPT
5352 026206 004767 000424 JSR R7,MDDSUB ;DO TEST
5353 026212 041525 052525 052525 .WORD 41525,052525,52525,52525 ;ACO
5354 026220 052525 .WORD 40300,0,0,0 ;FSRC
5355 026222 040300 000000 000000 .WORD 40300,0,0,0 ;FSRC
5356 026230 000000 .WORD 40177,-1,-1,177740 ;FRACTIONAL RESULT
5357 026232 040177 177777 177777 .WORD 40177,-1,-1,177740 ;FRACTIONAL RESULT
5358 026240 177740 .WORD 41636,0,0,0 ;INTEGER RESULT
5359 026242 041636 000000 000000 .WORD 41636,0,0,0 ;INTEGER RESULT
5360 026250 000000 .WORD 7700 ;TEST FPS
5361 026252 007700 .WORD 7700 ;RESULT FPS
5362 026254 007700
5363 ;/OVERFLOW, TRAPS ENABLED
5364 026256 012737 000001 001042 MOV @1,@#FLAG ;INTERRUPT
5365 026264 004767 000346 JSR R7,MDDSUB ;DO TEST
5366 026270 177777 177777 177777 .WORD -1,-1,-1,-1 ;ACO
    
```

```

5367 026276 177777
5368 026300 040400 000000 000000 .WORD 40400,0,0,0 ;FSRC
5369 026306 000000
5370 026310 000000 000000 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5371 026316 000000
5372 026320 100177 177777 177777 .WORD 100177,-1,-1,-1 ;INTEGER RESULT
5373 026326 177777
5374 026330 007700 .WORD 7700 ; TEST FPS
5375 026332 107706 .WORD 107706 ;RESULT FPS
5376 026334 000010 .WORD 10 ;FEC
5377 ;/INTEGER CHOPPED TO 56 BITS
5378 026336 005037 001042 CLR #0,0 ;NO INTERRUPT
5379 026342 004767 000270 JSR R7,MDDSUB ;DO TEST
5380 026346 056700 000000 000000 .WORD 56700,0,0,-1 ;ACO
5381 026354 177777
5382 026356 044440 177777 177777 .WORD 44440,-1,-1,-1 ;FSRC
5383 026364 177777
5384 026366 000000 000000 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5385 026374 000000
5386 026376 063161 100000 000001 .WORD 63161,100000,1,40775 ;INTEGER RESULT
5387 026404 040775
5388 026406 000200 .WORD 200 ; TEST FPS
5389 026410 000204 .WORD 204 ;RESULT FPS
5390 ;/OVERFLOW, TRAPS DISABLED
5391 026412 012737 000002 001042 MOV #2,0 ;NO INTERRUPT
5392 026420 004767 000212 JSR R7,MDDSUB ;DO TEST
5393 026424 066600 000000 000000 .WORD 66600,0,0,0 ;ACO
5394 026432 000000
5395 026434 066600 000000 000000 .WORD 66600,0,0,0 ;FSRC
5396 026442 000000
5397 026444 000000 000000 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5398 026452 000000
5399 026454 015200 000000 000000 .WORD 15200,0,0,0 ;INTEGER RESULT
5400 026462 000000
5401 026464 047700 .WORD 47700 ; TEST FPS
5402 026466 147706 .WORD 147706 ;RESULT FPS
5403 026470 000010 .WORD 10 ;FEC
5404 ;/UNDERFLOW, TRAPS DISABLED
5405 026472 012737 000002 001042 MOV #2,0 ;NO INTERRUPT
5406 026500 004767 000132 JSR R7,MDDSUB ;DO TEST
5407 026504 100277 000001 000002 .WORD 100277,1,2,-1 ;ACO
5408 026512 177777
5409 026514 100300 000001 000001 .WORD 100300,1,1,1 ;FSRC
5410 026522 000001
5411 026524 000000 000000 000000 .WORD 0,0,0,0 ;FRACTIONAL RESULT
5412 026532 000000
5413 026534 000000 000000 000000 .WORD 0,0,0,0 ;INTEGER RESULT
5414 026542 000000
5415 026544 005200 .WORD 5200 ; TEST FPS
5416 026546 005204 .WORD 5204 ;RESULT FPS
5417 026550 000010 .WORD 10 ;FEC
5418 ;/UNDERFLOW TRAPS ENABLED, UV AS RESULT
5419 026552 012737 000001 001042 MOV #1,0 ;INTERRUPT
5420 026560 004767 000052 JSR R7,MDDSUB ;DO TEST
5421 026564 100277 000001 000002 .WORD 100277,1,2,-1 ;ACO
5422 026572 177777

```


B9

5479									
5480	026744	000167	000020						
5481	026750	012604		51:	JMP	2:			
5482	026752	005726			MOV	(SP),R4			
5483	026754	022704	026702		TST	(SP),			
5484	026760	001403			CMP	#1,R4			
5485	026762	104000			BEQ	2:			
5486	026764	000404			ERROR				
5487	026766	002013			.WORD	404			
5488					.WORD	FPPERR			
5489									
5490									
5491	026770	170203							
5492	026772	012702	000200						
5493	026776	170102							
5494	027000	012701	001126						
5495									
5496	027004	174011							
5497	027006	026503	000042						
5498	027012	001403							
5499	027014	104000							
5500	027016	000405							
5501	027020	002013							
5502									
5503	027022	010504							
5504	027024	062704	000020						
5505	027030	004767	153112						
5506	027034	005767	152000						
5507	027040	001403							
5508	027042	104000							
5509	027044	000406							
5510	027046	002013							
5511									
5512									
5513	027050	174111							
5514	027052	010504							
5515	027054	062704	000030						
5516	027060	004767	153062						
5517	027064	005767	151750						
5518	027070	001403							
5519	027072	104000							
5520	027074	000407							
5521	027076	002013							
5522									
5523	027100	005737	001042						
5524	027104	001002							
5525	027106	000165	000044						
5526	027112	170301							
5527	027114	016504	000044						
5528	027120	020401							
5529	027122	001403							
5530	027124	104000							
5531	027126	000410							
5532	027130	002013							
5533									
5534	027132	000165	000046						

```

; INSTRUCTION WASNT SUPPOSE TO TRAP
; REJOIN CODE
; SEE IF PC = INSTRUCTION
; CLEAN UP STACK
;
; BRANCH IF GOOD COMPARE
; ALL ERRORS TO TRAP TO EMT VECTOR
; UNIQUE ERROR NUMBER
; ADDRESS OF ERROR MESSAGE
; PC WAS INCORRECT

; COMMON CODE FOR TRAP AND NO TRAP
2:
STFPS R3 ; SAVE FPS
MOV #200,R2 ; SET FPP TO DOUBLE
LDFPS R2
MOV #RECDST,R1 ; POINT TO RECEIVED DATA TABLE
; SAVE FRACTIONAL RESULT
STD AC0,(R1) ; SAVE AC0 RESULT
CMP #42(R5),R3 ; VERIFY STATUS
BEQ 3: ; BRANCH IF GOOD
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 405 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE

; BAD FPS
3:
MOV R5,R4 ; POINT TO EXPECTED DATA
ADD #20,R4
4:
JSR R7,DATVER ; VERIFY DATA
TST COUNT
BEQ 5: ; BRANCH IF GOOD
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 406 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE

; BAD AC0
5:
STD AC1,(R1) ; SAVE AC1 RESULT
MOV R5,R4 ; POINT TO EXPECTED
ADD #30,R4
JSR R7,DATVER
TST COUNT
BEQ 6: ; VERIFY DATA
;
; BRANCH IF GOOD
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 407 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE

; BAD AC1
6:
TST #FLAG
BNE 7: ; SEE IF NEED TO CHECK FEC
JMP #44(R5) ; BRANCH IF NEED TO CHECK
; RETURN FROM TEST
7:
STST R1 ; SAVE FEC
MOV #44(R5),R4 ; GET FEC
CMP R4,R1 ; VERIFY FEC
BEQ 8: ; BRANCH IF GOOD
ERROR ; ALL ERRORS TO TRAP TO EMT VECTOR
.WORD 410 ; UNIQUE ERROR NUMBER
.WORD FPPERR ; ADDRESS OF ERROR MESSAGE
; BAD FEC
8:
JMP #46(R5) ; RETURN FROM TEST
    
```

09

```

5535
5536 027136
5537 027136
5538
5539
5540
5541 027136
5542 027136 005267 151642
5543
5544 027142 004767 000170
5545 027146 000177 000000 000000
5546 027154 000001
5547 027156 000000 000000 000000
5548 027164 000000
5549 027166 047557
5550 027170 047544
5551
5552 027172 004767 000140
5553 027176 077577 177777 177777
5554 027204 177777
5555 027206 077577 177777 000000
5556 027214 000000
5557 027216 007540
5558 027220 007540
5559
5560 027222 004767 000110
5561 027226 100377 177777 100000
5562 027234 000000
5563 027236 100377 177777 000000
5564 027244 000000
5565 027246 007517
5566 027250 007510
5567
5568 027252 004767 000060
5569 027256 100000 000000 000000
5570 027264 000000
5571 027266 000000 000000 000000
5572 027274 000000
5573 027276 007757
5574 027300 007744
5575
5576 027302 004767 000030
5577 027306 125252 125252 125252
5578 027314 125252
5579 027316 125252 125252 000000
5580 027324 000000
5581 027326 000000
5582 027330 000010
5583
5584
5585 027332 000167 000120
5586
5587
5588
5589
5590
    ;
    HOP15:
    MSFD:
    ;*****
    ;*TEST 67 TEST STCFD
    ;*****
    TST67:
    INC $TESTN ;INCREMENT TEST NUMBER
    ;1/AC=0
    JSR R7,SFDSUB ;DO TEST
    .WORD 0177,0,0,1 ;ACO
    .WORD 0,0,0,0 ;RESULT
    .WORD 47557 ;TEST FPS
    .WORD 47544 ;RESULT FPS
    ;2/AC>0, TRUNCATE
    JSR R7,SFDSUB ;DO TEST
    .WORD 77577,-1,-1,-1 ;ACO
    .WORD 77577,-1,0,0 ;RESULT
    .WORD 7540 ;TEST FPS
    .WORD 7540 ;RESULT FPS
    ;3/AC<0, ROUND
    JSR R7,SFDSUB ;DO TEST
    .WORD 100377,-1,100000,0 ;ACO
    .WORD 100377,-1,0,0 ;RESULT
    .WORD 7517 ;TEST FPS
    .WORD 7510 ;RESULT FPS
    ;4/AC=-0
    JSR R7,SFDSUB ;DO TEST
    .WORD 100000,0,0,0 ;ACO
    .WORD 0,0,0,0 ;RESULT
    .WORD 7757 ;TEST FPS
    .WORD 7744 ;RESULT FPS
    ;5/AC<0
    JSR R7,SFDSUB ;DO TEST
    .WORD 125252,125252,125252,125252 ;ACO
    .WORD 125252,125252,0,0 ;RESULT
    .WORD 0 ;TEST FPS
    .WORD 10 ;RESULT FPS
    ;
    JMP HOP16 ;GET OVER SUBROUTINE
    ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
    ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
    ;STCFD
    ;
    ACO
    RESULT
    ;
    
```

D9

```

5591      ;
5592      ;           FPS BEFORE EXECUTION
5593      ;           FPS AFTER EXECUTION
5594      ;
5595      ;THERE CAN BE NO TRAPS WITH THE STCFD INSTRUCTION
5596      ;*XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
5597      ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
5598 027336 012605 SFDSUB: MOV      (SP),R5           ; RETURN ADDRESS TO USE AS POINTER
5599 027340 012737 027444 000244 MOV      @50,@FPVEC       ; REDIRECT TRAP VECTOR
5600 027346 012702 000200          MOV      @200,R2          ; SET TO DOUBLE MODE FOR LOAD
5601 027352 170102          LDFPS   R2              ; LOAD FPS
5602 027354 172415          LDD     (R5),ACO         ; LOAD ACO WITH TEST DATA
5603 027356 012701 001126          MOV      @RECDST,R1       ; POINT TO RESULT AREA
5604 027362 016502 000020          MOV      20(R5),R2      ; GET TEST FPS
5605 027366 170102          LDFPS   R2              ; LOAD TEST FPS
5606      ;
5607 027370 176011 40$: STCFD   ACO,(R1)          ; *TEST INSTRUCTION
5608      ;
5609      ; INSTRUCTION DIDNT TRAP
5610      ; VERIFY STATUS
5611 027372 170203 2$: STFPS   R3              ; SAVE FPS
5612 027374 016502 000022          MOV      22(R5),R2       ; GET EXPECTED STATUS
5613 027400 020203          CMP     R2,R3          ; VERIFY STATUS
5614 027402 001403          BEQ    3$              ; BRANCH IF GOOD
5615 027404 104000          ERROR  ; ALL ERRORS TO TRAP TO EMT VECTOR
5616 027406 000411          .WORD  411           ; UNIQUE ERROR NUMBER
5617 027410 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
5618      ;
5619 027412 010504 3$: MOV     R5,R4           ;BAD FPS
5620 027414 062704 000010          ADD    @10,R4          ; POINT TO EXPECTED DATA
5621 027420 004767 152522 4$: JSR    R7,DATVER         ; VERIFY DATA
5622 027424 005767 151410          TST   COUNT
5623 027430 001403          BEQ    5$              ; BRANCH IF GOOD
5624 027432 104000          ERROR  ; ALL ERRORS TO TRAP TO EMT VECTOR
5625 027434 000412          .WORD  412           ; UNIQUE ERROR NUMBER
5626 027436 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
5627      ;
5628 027440 000165 000024 5$: JMP     24(R5)         ;BAD ACO
5629      ; INSTRUCTION TRAPPED
5630      ;
5631 027444 104000 50$: ERROR  ; ALL ERRORS TO TRAP TO EMT VECTOR
5632 027446 000413          .WORD  413           ; UNIQUE ERROR NUMBER
5633 027450 002013          .WORD  FPPERR         ; ADDRESS OF ERROR MESSAGE
5634      ;
5635 027452 000165 000024          JMP     24(R5)         ; INSTRUCTION WASNT SUPPOSE TO TRAP
5636      ;
5637 027456          ; RETURN FROM TEST
5638      ;
5639 027456          ;
5640      ;
5641      ; *****
5642      ; *TEST 70 TEST STCFD
5643      ; *****
5644 027456 005267 151322 TST70:
5645      ;
5646 027462 005037 001042          INC    $TESTN         ; INCREMENT TEST NUMBER
                    CLR    @FLAG           ; NO INTERRUPT
    
```



```

5703      ;
5704      ;           FPS BEFORE EXECUTION
5705      ;           FPS AFTER EXECUTION
5706      ;
5707      ;A TRAP CAN ONLY OCCUR IF ROUNDING CAUSES OVERFLOW
5708      ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
5709      ;*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X*X
5710      ;
5710 027712 012605      SDFSUB: MOV      (SP)+,R5           ; RETURN ADDRESS TO USE AS POINTER
5711 027714 012737 027774 000244  MOV      #50#,R5           ; REDIRECT TRAP VECTOR
5712 027722 012702 000200      MOV      #200,R2          ; SET TO DOUBLE MODE FOR LOAD
5713 027726 170102      LDFPS   R2                ; LOAD FPS
5714 027730 172415      LDD     (R5),ACO          ; LOAD ACO WITH TEST DATA
5715 027732 012701 001126      MOV      @RECDST,R1       ; POINT TO RESULT AREA
5716 027736 016502 000014      MOV      14(R5),R2        ; GET TEST FPS
5717 027742 170102      LDFPS   R2                ; LOAD TEST FPS
5718      ;
5719 027744 176011      40$:   STCDF   ACO,(R1)    ; *TEST INSTRUCTION
5720 027746 170327      1$:   STST   (PC)+        ; WAIT FOR POSSIBLE FPA TRAP.
5721 027750 000000      .WORD   0                ; STORE STATUS HERE.
5722      ;
5723      ; INSTRUCTION DIDNT TRAP
5724 027752 032737 000001 001042  BIT      #1,@FLAG        ; VERIFY A NO TRAP CONDITION
5725 027760 001426      BEQ      2$              ; BRANCH IF GOOD
5726 027762 104000      ERROR   ; ALL ERRORS TO TRAP TO EMT VECTOR
5727 027764 000414      .WORD   414             ; UNIQUE ERROR NUMBER
5728 027766 002013      .WORD   FPPERR          ; ADDRESS OF ERROR MESSAGE
5729      ; INSTRUCTION SHOULD HAVE TRAPPED
5730 027770 000167 000042      JMP      2$              ; REJOIN CODE
5731      ;
5732      ; INSTRUCTION TRAPPED
5733 027774 032737 000001 001042  50$:   BIT      #1,@FLAG        ; SEE IF EXPECTING A TRAP
5734 030002 001005      BNE     51$             ; BRANCH IF EXPECTING A TRAP
5735 030004 104000      ERROR   ; ALL ERRORS TO TRAP TO EMT VECTOR
5736 030006 000415      .WORD   415             ; UNIQUE ERROR NUMBER
5737 030010 002013      .WORD   FPPERR          ; ADDRESS OF ERROR MESSAGE
5738      ; INSTRUCTION WASNT SUPPOSE TO TRAP
5739 030012 000167 000020      JMP      2$              ; REJOIN CODE
5740 030016 012604      51$:   MOV      (SP)+,R4        ; SEE IF PC = INSTRUCTION
5741 030020 005726      TST     (SP)+          ; CLEAN UP STACK
5742 030022 022704 027746      CMP     #1#,R4          ;
5743 030026 001403      BEQ     2$              ; BRANCH IF GOOD COMPARE
5744 030030 104000      ERROR   ; ALL ERRORS TO TRAP TO EMT VECTOR
5745 030032 000416      .WORD   416             ; UNIQUE ERROR NUMBER
5746 030034 002013      .WORD   FPPERR          ; ADDRESS OF ERROR MESSAGE
5747      ; PC WAS INCORRECT
5748      ;
5749      ; COMMON CODE FOR TRAP AND NO TRAP
5750      ; VERIFY STATUS
5751 030036 170203      2$:   STFPS   R3                ; SAVE FPS
5752 030040 016502 000016      MOV     16(R5),R2        ; GET EXPECTED STATUS
5753 030044 020203      CMP     R2,R3           ; VERIFY STATUS
5754 030046 001403      BEQ     3$              ; BRANCH IF GOOD
5755 030050 104000      ERROR   ; ALL ERRORS TO TRAP TO EMT VECTOR
5756 030052 000417      .WORD   417             ; UNIQUE ERROR NUMBER
5757 030054 002013      .WORD   FPPERR          ; ADDRESS OF ERROR MESSAGE
5758      ; BAD FPS

```

G9

```

5759 030056 010504      3$:  MOV    R5,R4          ;POINT TO EXPECTED DATA
5760 030060 062704 000010      ADD    #10,R4
5761 030064 004767 152040      4$:  JSR    R7,DATVFR      ;VERIFY DATA
5762 030070 005767 150744      TST    COUNT
5763 030074 001403      BEQ    5$              ;BRANCH IF GOOD
5764 030076 104000      ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
5765 030100 000420      .WORD 420             ;UNIQUE ERROR NUMBER
5766 030102 002013      .WORD FPPERR         ;ADDRESS OF ERROR MESSAGE
5767                                     ;BAD ACO
5768 030104 005737 001042      5$:  TST    @#FLAG
5769 030110 001002      BNE    7$              ;SEE IF NEED TO CHECK FEC
5770 030112 000165 000020      JMP    20(R5)         ;BRANCH IF NEED TO CHECK
5771                                     ;RETURN FROM TEST
5772 030116 012704 001106      ;VERIFY FEC
5773 030122 170314      7$:  MOV    @RECFEC,R4    ;POINT TO FEC AREA
5774 030124 021427 000010      STST   (R4)           ;SAVE FEC
5775 030130 001403      CMP    (R4),#10      ;VERIFY FEC FOR OVERFLOW
5776 030132 104000      BEQ    8$              ;BRANCH IF GOOD
5777 030134 000421      ERROR  ;ALL ERRORS TO TRAP TO EMT VECTOR
5778 030136 002013      .WORD 421             ;UNIQUE ERROR NUMBER
5779                                     .WORD FPPERR         ;ADDRESS OF ERROR MESSAGE
5780 030140 000165 000020      8$:  JMP    20(R5)         ;RETURN FROM TEST
5781                                     ;
5782 030144      ;HOP17:
5783 030144      ;MSFDI:
5784                                     ;
5785      ;*****
5786      ;*TEST 71      TEST STCFD - USING ILLEGAL ACCUMULATOR
5787      ;*****
5787 030144      TST71:
5788 030144 005267 150634      INC    $TESTN         ;INCREMENT TEST NUMBER
5789 030150 012701 040000      MOV    @40000,R1     ;DISABLE INTERRUPTS
5790 030154 170101      LDFPS  R1
5791 030156 176006      STCFD  ACO,AC6      ;*TEST ILLEGAL INSTRUCTION
5792 030160 170202      STFPS  R2
5793 030162 170303      STST   R3           ;SAVE STATUS
5794 030164 022702 140000      CMP    @140000,R2    ;SAVE FEC
5795 030170 001403      BEQ    1$              ;VERIFY FER SET
5796 030172 104000      ERROR  ;BRANCH IF ERROR RECEIVED
5797 030174 000422      .WORD 422             ;ALL ERRORS TO TRAP TO EMT VECTOR
5798 030176 002013      .WORD FPPERR         ;UNIQUE ERROR NUMBER
5799                                     .WORD FPPERR         ;ADDRESS OF ERROR MESSAGE
5800 030200 022703 000002      1$:  CMP    #2,R3          ;FER BIT NOT SET ON ILLEGAL INST.
5801 030204 001403      BEQ    2$              ;VERIFY FEC = FLOATING OPDOE ERROR
5802 030206 104000      ERROR  ;BRANCH IF GOOD
5803 030210 000423      .WORD 423             ;ALL ERRORS TO TRAP TO EMT VECTOR
5804 030212 002013      .WORD FPPERR         ;UNIQUE ERROR NUMBER
5805                                     .WORD FPPERR         ;ADDRESS OF ERROR MESSAGE
5806 030214      2$:  ;FEC INCORRECT
5807                                     ;
5808                                     ;
5809 030214      ;MCLRD:
5810      ;*****
5811      ;*TEST 72      TEST CLRD
5812      ;*****
5813 030214      TST72:
5814 030214 005267 150564      INC    $TESTN         ;INCREMENT TEST NUMBER
    
```

```

5815 030220 012701 001726      MOV      #TAB47,R1      ;POINT TO DATA
5816 030224 012704 000200      MOV      #200,R4      ;SET FPP STATUS TO DOUBLE
5817 030230 170104              LDFPS   R4
5818 030232 172411              LDD     (R1),ACO
5819 030234 012701 001126      MOV      #RECDST,R1   ;
5820 030240 174011              STD     ACO,(R1)      ;POINT TO DATA BUFFER
5821 030242 170411              CLRD   (R1)          ;STORE GARBAGE
5822 030244 012704 001256      MOV      #TAB6,R4     ;CLEAR DATA BUFFER
5823 030250 004767 151672      JSR     R7,DATVER     ;VERIFY BUFFER =0
5824 030254 005767 150560      TST     COUNT
5825 030260 001403              BEQ     1#           ;
5826 030262 104000              ERROR   1#           ;BRANCH I RECDST = 0
5827 030264 000424              .WORD  424          ;ALL ERRORS TO TRAP TO EMT VECTOR
5828 030266 002013              .WORD  FPPERR       ;UNIQUE ERROR NUMBER
5829                               ;RECDST NOT CLEARED ;ADDRESS OF ERROR MESSAGE
5830 030270 170202              1#:   STFPS  R2
5831 030272 020227 000204      CMP     R2,#204
5832 030276 001403              BEQ     2#           ;SAVE STATUS
5833 030300 104000              ERROR   2#           ;VERIFY STATUS
5834 030302 000425              .WORD  425          ;BRANCH IF GOOD
5835 030304 002013              .WORD  FPPERR       ;ALL ERRORS TO TRAP TO EMT VECTOR
5836                               ;UNIQUE ERROR NUMBER
5837 030306              2#:   ;ADDRESS OF ERROR MESSAGE
5838                               ;BAD STATUS
5839
5840 030306      MCLRI:
5841      ;*****
5842      ;*TEST 73      TEST CLRD, ILLEGAL ACCUMULATOR
5843      ;*****
5844 030306      TST73:
5845 030306 005267 150472      INC     #TESTN      ;INCREMENT TEST NUMBER
5846 030312 012704 040200      MOV     #40200,R4   ;DISABLE INTERRUPTS
5847 030316 170104              LDFPS  R4           ;LOAD STATUS
5848 030320 170406              CLRD   R6           ;*TEST INSTRUCTION WITH ILLEGAL ACC
5849 030322 170203              STFPS  R3           ;SAVE STATUS
5850 030324 170305              STST   R5           ;SAVE FEC
5851 030326 022703 140200      CMP     #140200,R3  ;VERIFY ERROR
5852 030332 001403              BEQ     1#           ;BRANCH IF FER SET
5853 030334 104000              ERROR   1#           ;ALL ERRORS TO TRAP TO EMT VECTOR
5854 030336 000426              .WORD  426          ;UNIQUE ERROR NUMBER
5855 030340 002013              .WORD  FPPERR       ;ADDRESS OF ERROR MESSAGE
5856                               ;ERROR IN FPS
5857 030342 022705 000002      1#:   CMP     #2,R5    ;VERIFY FEC =2 OPCODE ERROR
5858 030346 001403              BEQ     2#           ;BRANCH IF GOOD
5859 030350 104000              ERROR   2#           ;ALL ERRORS TO TRAP TO EMT VECTOR
5860 030352 000427              .WORD  427          ;UNIQUE ERROR NUMBER
5861 030354 002013              .WORD  FPPERR       ;ADDRESS OF ERROR MESSAGE
5862                               ;BAD FEC
5863 030356      2#:
5864
5865
5866 030356      MLS1:
5867      ;*****
5868      ;*TEST 74      TEST LDFPS, STFPS MODE 1
5869      ;*****
5870 030356      TST74:
    
```



```

5871 030356 005267 150422      INC      $TESTN      ;INCREMENT TEST NUMBER
5872 030362 012704 001136      MOV      @TSTLOC,R4  ;POINT R4 TO RAM
5873 030366 012714 147757      MOV      @147757,(R4) ;SETUP EXPECTED STATUS
5874 030372 012701 001116      MOV      @RECST,R1   ;SET BUFFER FOR RECEIVED STATUS
5875 030376 012737 030462 000244 MOV      @10$,@FPVEC ;SETUP TRAP VECTOR
5876 030404 170114      LDFPS   (R4)        ;*TEST INSTRUCTION
5877 030406 170211      STFPS   (R1)        ;*TEST INSTRUCTION
5878 030410 020427 001136      CMP      R4,@TSTLOC  ;VERIFY R4
5879 030414 001403      BEQ     1$          ;BRANCH IF GOOD
5880 030416 104000      ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
5881 030420 000430      .WORD  430         ;UNIQUE ERROR NUMBER
5882 030422 002013      .WORD  FPPERR      ;ADDRESS OF ERROR MESSAGE
5883
5884 030424 020127 001116      1$:      CMP      R1,@RECST  ;VERIFY R1
5885 030430 001403      BEQ     2$          ;BRANCH IF GOOD
5886 030432 104000      ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
5887 030434 000431      .WORD  431         ;UNIQUE ERROR NUMBER
5888 030436 002013      .WORD  FPPERR      ;ADDRESS OF ERROR MESSAGE
5889
5890 030440 023727 001116 147757 2$:      CMP      @@RECST,@147757 ;BAD R1
5891 030446 001412      BEQ     3$          ;VERIFY STATUS
5892 030450 104000      ERROR   ;BRANCH F GOOD
5893 030452 000432      .WORD  432         ;ALL ERRORS TO TRAP TO EMT VECTOR
5894 030454 002013      .WORD  FPPERR      ;UNIQUE ERROR NUMBER
5895
5896 030456 000167 000012      JMP     3$          ;BAD STATUS\
5897
5898 030462 012600      ;UNEXPECTED TRAP  ;GET OVER TRAP
5899 030464 012605      10$:     MOV      (SP),R0   ;SAVE PC
5900 030466 104000      MOV      (SP),R5   ;SAVE PS
5901 030470 000433      ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
5902 030472 002013      .WORD  433         ;UNIQUE ERROR NUMBER
5903
5904 030474      .WORD  FPPERR      ;ADDRESS OF ERROR MESSAGE
5905
5906
5907 030474      ;UNEXPECTED TRAP
5908
5909
5910
5911 030474      ;UNEXPECTED TRAP
5912 030474 005267 150304      MLS2:
5913 030500 012704 001136      ;:*****
5914 030504 012714 145557      ;*TEST 75      TEST LDFPS, STFPS MODE 2
5915 030510 012701 001116      ;:*****
5916 030514 012737 030600 000244 TST75:
5917 030522 170124      INC      $TESTN      ;INCREMENT TEST NUMBER
5918 030524 170221      MOV      @TSTLOC,R4  ;POINT R4 TO RAM
5919 030526 020427 001140      MOV      @145557,(R4) ;SETUP EXPECTED STATUS
5920 030532 001403      MOV      @RECST,R1   ;SET BUFFER FOR RECEIVED STATUS
5921 030534 104000      MOV      @10$,@FPVEC ;SETUP TRAP VECTOR
5922 030536 000434      LDFPS   (R4)        ;*TEST INSTRUCTION
5923 030540 002013      STFPS   (R1)        ;*TEST INSTRUCTION
5924
5925 030542 020127 001120      CMP      R4,@TSTLOC*2 ;VERIFY R4
5926 030546 001403      BEQ     1$          ;BRANCH IF GOOD

```

J9

```

5927 030550 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
5928 030552 000435          .WORD      435          ;UNIQUE ERROR NUMBER
5929 030554 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
5930
5931 030556 023727 001116 145557 2$: CMP      @@RECST,@145557 ;BAD R1 ;VERIFY STATUS
5932 030564 001412          BEQ        3$           ;BRANCH F GOOD
5933 030566 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
5934 030570 000436          .WORD      436          ;UNIQUE ERROR NUMBER
5935 030572 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
5936
5937 030574 000167 000012          JMP        3$           ;BAD STATUS\ ;GET OVER TRAP
5938          ;UNEXPECTED TRAP
5939 030600 012600          10$: MOV      (SP),R0          ;SAVE PC
5940 030602 012605          MOV      (SP),R5          ;SAVE PS
5941 030604 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
5942 030606 000437          .WORD      437          ;UNIQUE ERROR NUMBER
5943 030610 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
5944
5945 030612          3$:          ;UNEXPECTED TRAP
5946
5947
5948 030612          MLS3:
5949          ;*****
5950          ;*TEST 76          TEST LDFPS, STFPS MODE 3
5951          ;*****
5952          TST76:
5953 030612 005267 150166          INC      @TESTN          ;INCREMENT TEST NUMBER
5954 030616 012704 001136          MOV      @TSTLOC,R4      ;POINT R4 TO RAM
5955 030622 012737 001142 001136          MOV      @TSTLOC+4,@TSTLOC ;TSTLOC= DEFERRED ADDRESS
5956 030630 012737 147501 001142          MOV      @147501,@TSTLOC+4 ;SETUP EXPECTED STATUS
5957 030636 012701 001146          MOV      @TSTLOC+10,R1   ;R1 POINTS TO TSTLOC+10
5958 030642 012737 001116 001146          MOV      @RECST,@TSTLOC+10 ;SET DEFERRED BUFFER FOR RECEIVED STATUS
5959 030650 012737 030734 000244          MOV      @10$,@FPVcC     ;SETUP TRAP VECTOR
5960 030656 170134          LDFPS     @R4)          ;*TEST INSTRUCTION
5961 030660 170231          STFPS     @R1)          ;*TEST INSTRUCTION
5962 030662 020427 001140          CMP      R4,@TSTLOC+2    ;VERIFY R4
5963 030666 001403          BEQ        1$           ;BRANCH IF GOOD
5964 030670 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
5965 030672 000440          .WORD      440          ;UNIQUE ERROR NUMBER
5966 030674 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
5967
5968 030676 020127 001150          1$: CMP      R1,@TSTLOC+12 ; ;VERIFY R1
5969 030702 001403          BEQ        2$           ;BRANCH IF GOOD
5970 030704 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
5971 030706 000441          .WORD      441          ;UNIQUE ERROR NUMBER
5972 030710 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
5973
5974 030712 023727 001116 147501 2$: CMP      @@RECST,@147501 ;BAD R1 ;VERIFY STATUS
5975 030720 001412          BEQ        3$           ;BRANCH F GOOD
5976 030722 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
5977 030724 000442          .WORD      442          ;UNIQUE ERROR NUMBER
5978 030726 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
5979
5980 030730 000167 000012          JMP        3$           ;BAD STATUS\ ;GET OVER TRAP
5981          ;UNEXPECTED TRAP
5982 030734 012600          10$: MOV      (SP),R0          ;SAVE PC
    
```

K9

```
5983 030736 012605          MOV      (SP)+,R5          ;SAVE PS
5984 030740 104000          ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
5985 030742 000443          .WORD    443              ;UNIQUE ERROR NUMBER
5986 030744 002013          .WORD    FPPERR          ;ADDRESS OF ERROR MESSAGE
5987                                     ;UNEXPECTED TRAP
5988 030746          3$:
5989
5990
5991 030746          MLS4:
5992          ;*****
5993          ;*TEST 77          TEST LDFPS, STFPS MODE 4
5994          ;*****
5995          TST77:
5996 030746 005267 150032          INC      $TESTN          ;INCREMENT TEST NUMBER
5997 030752 012704 001140          MOV      @TSTLOC+2,R4    ;POINT R4 TO RAM
5998 030756 012737 147757 001136          MOV      @147757,@TSTLOC ;TSTLOC= STATUS ADDRESS
5999 030764 012701 001120          MOV      @RECST+2,R1     ;SET BUFFER FOR RECEIVED STATUS
6000 030770 012737 031054 000244          MOV      @10$,@FPVEC     ;SETUP TRAP VECTOR
6001 030776 170144          LDFPS   -(R4)            ;*TEST INSTRUCTION
6002 031000 170241          STFPS   -(R1)            ;*TEST INSTRUCTION
6003 031002 020427 001136          CMP      R4,@TSTLOC      ;VERIFY R4
6004 031006 001403          BEQ     1$              ;BRANCH IF GOOD
6005 031010 104000          ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
6006 031012 000444          .WORD    444              ;UNIQUE ERROR NUMBER
6007 031014 002013          .WORD    FPPERR          ;ADDRESS OF ERROR MESSAGE
6008
6009 031016 020127 001116          1$:  CMP      R1,@RECST    ;VERIFY R1
6010 031022 001403          BEQ     2$              ;BRANCH IF GOOD
6011 031024 104000          ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
6012 031026 000445          .WORD    445              ;UNIQUE ERROR NUMBER
6013 031030 002013          .WORD    FPPERR          ;ADDRESS OF ERROR MESSAGE
6014
6015 031032 023727 001116 147757 2$:  CMP      @@RECST,@147757 ;BAD R1 ;VERIFY STATUS
6016 031040 001412          BEQ     3$              ;BRANCH F GOOD
6017 031042 104000          ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
6018 031044 000446          .WORD    446              ;UNIQUE ERROR NUMBER
6019 031046 002013          .WORD    FPPERR          ;ADDRESS OF ERROR MESSAGE
6020
6021 031050 000167 000012          JMP     3$              ;BAD STATUS\ ;GET OVER TRAP
6022          ;UNEXPECTED TRAP
6023 031054 012600          10$: MOV      (SP)+,R0          ;SAVE PC
6024 031056 012605          MOV      (SP)+,R5          ;SAVE PS
6025 031060 104000          ERROR                      ;ALL ERRORS TO TRAP TO EMT VECTOR
6026 031062 000447          .WORD    447              ;UNIQUE ERROR NUMBER
6027 031064 002013          .WORD    FPPERR          ;ADDRESS OF ERROR MESSAGE
6028                                     ;UNEXPECTED TRAP
6029 031066          3$:
6030
6031
6032 031066          MLS5:
6033          ;*****
6034          ;*TEST 100         TEST LDFPS, STFPS MODE 5
6035          ;*****
6036          TST100:
6037 031066 005267 147712          INC      $TESTN          ;INCREMENT TEST NUMBER
6038 031072 012704 001140          MOV      @TSTLOC+2,R4    ;POINT R4 TO RAM
```

```

6039 031076 012737 001142 001136      MOV      @TSTLOC+4,@TSTLOC      ;TSTLOC= DEFERRED ADDRESS
6040 031104 012737 147501 001142      MOV      @147501,@TSTLOC+4    ;SETUP EXPECTED STATUS
6041 031112 012701 001150              MOV      @TSTLOC+12,R1        ;R1 POINTS TO 412
6042 031116 012737 001116 001146      MOV      @RECST,@TSTLOC+10    ;SET DEFERRED BUFFER FOR RECEIVED STATUS
6043 031124 012737 031210 000244      MOV      @10@,@FPVEC          ;SETUP TRAP VECTOR
6044 031132 170154              LDFPS   @-(R4)                ;*TEST INSTRUCTION
6045 031134 170251              STFPS   @-(R1)                ;*TEST INSTRUCTION
6046 031136 020427 001136      CMP      R4,@TSTLOC           ;VERIFY R4
6047 031142 001403              BEQ     1@                    ;BRANCH IF GOOD
6048 031144 104000              ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
6049 031146 000450              .WORD   450                   ;UNIQUE ERROR NUMBER
6050 031150 002013              .WORD   FPPERR                ;ADDRESS OF ERROR MESSAGE
6051
6052 031152 020127 001146      1@:    CMP      R1,@TSTLOC+10    ;VERIFY R1
6053 031156 001403              BEQ     2@                    ;BRANCH IF GOOD
6054 031160 104000              ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
6055 031162 000451              .WORD   451                   ;UNIQUE ERROR NUMBER
6056 031164 002013              .WORD   FPPERR                ;ADDRESS OF ERROR MESSAGE
6057
6058 031166 023727 001116 147501 2@:    CMP      @@RECST,@147501      ;BAD R1
6059 031174 001412              BEQ     3@                    ;VERIFY STATUS
6060 031176 104000              ERROR   ;BRANCH F GOOD
6061 031200 000452              .WORD   452                   ;ALL ERRORS TO TRAP TO EMT VECTOR
6062 031202 002013              .WORD   FPPERR                ;UNIQUE ERROR NUMBER
6063
6064 031204 000167 000012              JMP     3@                    ;BAD STATUS\
6065
6066 031210 012600              ;UNEXPECTED TRAP
6067 031212 012605      10@:   MOV      (SP)+,R0            ;SAVE PC
6068 031214 104000              MOV      (SP)+,R5            ;SAVE PS
6069 031216 000453              ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
6070 031220 002013              .WORD   453                   ;UNIQUE ERROR NUMBER
6071
6072 031222              .WORD   FPPERR                ;ADDRESS OF ERROR MESSAGE
6073
6074
6075 031222              ;UNEXPECTED TRAP
6076
6077
6078
6079 031222      MLS6:
        ;*****
        ;*TEST 101      TEST LDFPS, STFPS MODE 6
        ;*****
        TST101:
6080 031222 005267 147556      INC      @TESTN              ;INCREMENT TEST NUMBER
6081 031226 012704 001136      MOV      @TSTLOC,R4          ;POINT R4 TO RAM
6082 031232 012737 140001 001142      MOV      @140001,@TSTLOC+4    ;SETUP EXPECTED STATUS
6083 031240 012701 001246      MOV      @TSTLOC+110,R1      ;R1 WILL POINT TO TESTLOC+10
6084 031244 012737 031334 000244      MOV      @10@,@FPVEC          ;SETUP TRAP VECTOR
6085 031252 170164 000004              LDFPS   4(R4)                ;*TEST INSTRUCTION
6086 031256 170261 177700              STFPS   -100(R1)             ;*TEST INSTRUCTION
6087 031262 020427 001136      CMP      R4,@TSTLOC           ;VERIFY R4
6088 031266 001403              BEQ     1@                    ;BRANCH IF GOOD
6089 031270 104000              ERROR   ;ALL ERRORS TO TRAP TO EMT VECTOR
6090 031272 000454              .WORD   454                   ;UNIQUE ERROR NUMBER
6091 031274 002013              .WORD   FPPERR                ;ADDRESS OF ERROR MESSAGE
6092
6093 031276 020127 001246      1@:    CMP      R1,@TSTLOC+110    ;VERIFY R1
6094 031302 001403              BEQ     2@                    ;BRANCH IF GOOD

```

```

6095 031304 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6096 031306 000455          .WORD      455          ;UNIQUE ERROR NUMBER
6097 031310 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
6098                                     ;BAD R1
6099 031312 023727 001146 140001 2$:  CMP      @TSTLOC+10,@140001 ;VERIFY STATUS
6100 031320 001412          BEQ      3$             ;BRANCH F GOOD
6101 031322 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6102 031324 000456          .WORD      456          ;UNIQUE ERROR NUMBER
6103 031326 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
6104                                     ;BAD STATUS\
6105 031330 000167 000012          JMP      3$             ;GET OVER TRAP
6106                                     ;UNEXPECTED TRAP
6107 031334 012600          10$:  MOV      (SP)+,R0          ;SAVE PC
6108 031336 012605          MOV      (SP)+,R5          ;SAVE PS
6109 031340 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6110 031342 000457          .WORD      457          ;UNIQUE ERROR NUMBER
6111 031344 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
6112                                     ;UNEXPECTED TRAP
6113 031346          3$:
6114
6115
6116 031346          MLS7:
6117          ;*****
6118          ;*TEST 102      TEST LDFPS, STFPS MODE 7
6119          ;*****
6120          TST102:
6121 031346 005267 147432          INC      $TESTN          ;INCREMENT TEST NUMBER
6122 031352 012704 001236          MOV      @TSTLOC+100,R4  ;POINT R4 TO RAM
6123 031356 012737 001142 001136  MOV      @TSTLOC+4,@TSTLC ;TSTLOC= DEFERRED ADDRESS
6124 031364 012737 145501 001142  MOV      @145501,@TSTLOC+4 ;SETUP EXPECTED STATUS
6125 031372 012701 001046          MOV      @TSTLOC-70,R1   ;R1 POINTS TO TSTLOC+10
6126 031376 012737 001146 001140  MOV      @TSTLOC+10,@TSTLOC+2 ;
6127 031404 012737 031474 000244  MOV      @10$,@FPVEC     ;SETUP TRAP VECTOR
6128 031412 170174 177700          LDFPS   @-100(R4)        ;*TEST INSTRUCTION
6129 031416 170271 000072          STFPS   @72(R1)         ;*TEST INSTRUCTION
6130 031422 020427 001236          CMP      R4,@TSTLOC+100  ;VERIFY R4
6131 031426 001403          BEQ      1$             ;BRANCH IF GOOD
6132 031430 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6133 031432 000460          .WORD      460          ;UNIQUE ERROR NUMBER
6134 031434 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
6135
6136 031436 020127 001046          1$:  CMP      R1,@TSTLOC-70  ;VERIFY R1
6137 031442 001403          BEQ      2$             ;BRANCH IF GOOD
6138 031444 104000          ERROR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6139 031446 000461          .WORD      461          ;UNIQUE ERROR NUMBER
6140 031450 002013          .WORD      FPPERR       ;ADDRESS OF ERROR MESSAGE
6141
6142 031452 023727 001146 145501 2$:  CMP      @TSTLOC+10,@145501 ;BAD R1
6143 031460 001412          BEQ      3$             ;VERIFY STATUS
6144 031462 104000          ERROR          ;BRANCH F GOOD
6145 031464 000462          .WORD      462          ;ALL ERRORS TO TRAP TO EMT VECTOR
6146 031466 002013          .WORD      FPPERR       ;UNIQUE ERROR NUMBER
6147                                     ;ADDRESS OF ERROR MESSAGE
6148 031470 000167 000012          JMP      3$             ;BAD STATUS\
6149                                     ;GET OVER TRAP
6150 031474 012600          10$:  MOV      (SP)+,R0          ;SAVE PC

```

```

6151 031476 012605          MOV      (SP)+,R5          ;SAVE PS
6152 031500 104000          ERROR                     ;ALL ERRORS TO TRAP TO EMT VECTOR
6153 031502 000463          .WORD    463              ;UNIQUE ERROR NUMBER
6154 031504 002013          .WORD    FPPERR          ;ADDRESS OF ERROR MESSAGE
6155                                     ;UNEXPECTED TRAP
6156 031506          3$:
6157
6158
6159 031506          MLDC2:
6160          ;:*****
6161          ;*TEST 103      TEST LDCLD MODE 27
6162          ;:*****
6163 031506          TST103:
6164 031506 005267 147272          INC      $TESTN          ;INCREMENT TEST NUMBER
6165 031512 005001          CLR      R1              ;INIT R1
6166 031514 012704 007700          MOV      @7700,R4        ;FPS=DOUBLE, LONG
6167 031520 170104          LDFPS   R4
6168 031522 012737 031562 000244          MOV      @10$,@FPVEC    ;SETUP WILD TRAP
6169 031530 177027          LDCLD   (R7)+,ACO       ;*TEST INSTRUCTION
6170 031532 005201          INC      R1
6171 031534 005201          INC      R1
6172 031536 005201          INC      R1
6173 031540 005201          INC      R1
6174 031542 020127 000003          CMP      R1,#3
6175 031546 001412          BEQ     1$
6176 031550 104000          ERROR                     ;VERIFY
6177 031552 000464          .WORD    464              ;BRANCH IF GOOD
6178 031554 002013          .WORD    FPPERR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6179                                     ;UNIQUE ERROR NUMBER
6180 031556 000167 000012          JMP     1$                ;ADDRESS OF ERROR MESSAGE
6181 031562 012600          10$: MOV      (SP)+,R0        ;INSTRUCTION FAILED
6182 031564 012605          MOV      (SP)+,R5        ;JUMP OVER WILD TRAP
6183 031566 104000          ERROR                     ;SAVE PC
6184 031570 000465          .WORD    465              ;SAVE PS
6185 031572 002013          .WORD    FPPERR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6186                                     ;UNIQUE ERROR NUMBER
6187 031574 012704 001266          1$: MOV      @TAB6A,R4    ;ADDRESS OF ERROR MESSAGE
6188 031600 012701 001126          MOV      @RECDST,R1      ;WILD TRAP ON INSTRUCTION
6189 031604 174011          STD     ACO,(R1)         ;POINT TO EXPECTED DATA
6190 031606 004767 150334          JSR     R7,DATVER        ;POINT TO DATA BUFFER
6191 031612 005767 147222          TST     COUNT
6192 031616 001403          BEQ     2$
6193 031620 104000          ERROR                     ;VERIFY DATA
6194 031622 000466          .WORD    466              ;BRANCH IF GOOD DATA
6195 031624 002013          .WORD    FPPERR          ;ALL ERRORS TO TRAP TO EMT VECTOR
6196                                     ;UNIQUE ERROR NUMBER
6197 031626          2$:                                     ;ADDRESS OF ERROR MESSAGE
6198                                     ;BAD DATA
6199
6200
6201 031626          MLCF:
6202          ;:*****
6203          ;*TEST 104      TEST LDCIF, LDCLF
6204          ;:*****
6205 031626          TST104:
6206 031626 005267 147152          INC      $TESTN          ;INCREMENT TEST NUMBER
    
```

B10

6207				:1/INT=0			
6208	031632	004767	000500	JSR	R7,LCFSUB		:DO TEST
6209	031636	000000	000100	.WORD	0,0	:FSRC	
6210	031642	000000	000000	.WORD	0,0	:RESULT	
6211	031646	000000		.WORD	0	: TEST FPS	
6212	031650	000004		.WORD	4	:RESULT FPS	
6213				:2/INT=0,-1			
6214	031652	004767	000460	JSR	R7,LCFSUB		:DO TEST
6215	031656	000000	177777	.WORD	0,-1	:FSRC	
6216	031662	000000	000000	.WORD	0,0	:RESULT	
6217	031666	007440		.WORD	7440	: TEST FPS	
6218	031670	007444		.WORD	7444	:RESULT FPS	
6219				:3/LONG=0			
6220	031672	004767	000440	JSR	R7,LCFSUB		:DO TEST
6221	031676	000000	000000	.WORD	0,0	:FSRC	
6222	031702	000000	000000	.WORD	0,0	:RESULT	
6223	031706	000100		.WORD	100	: TEST FPS	
6224	031710	000104		.WORD	104	:RESULT FPS	
6225				:4/INT=40000			
6226	031712	004767	000420	JSR	R7,LCFSUB		:DO TEST
6227	031716	040000	000000	.WORD	40000,0	:FSRC	
6228	031722	043600	000000	.WORD	43600,0	:RESULT	
6229	031726	000017		.WORD	17	: TEST FPS	
6230	031730	000000		.WORD	0	:RESULT FPS	
6231				:5/LONG=1			
6232	031732	004767	000400	JSR	R7,LCFSUB		:DO TEST
6233	031736	000000	000001	.WORD	0,1	:FSRC	
6234	031742	040200	000000	.WORD	40200,0	:RESULT	
6235	031746	000117		.WORD	117	: TEST FPS	
6236	031750	000100		.WORD	100	:RESULT FPS	
6237				:6/INT=PATTERN			
6238	031752	004767	000360	JSR	R7,LCFSUB		:DO TEST
6239	031756	000252	025252	.WORD	252,25252	:FSRC	
6240	031762	042052	000000	.WORD	42052,0	:RESULT	
6241	031766	000000		.WORD	0	: TEST FPS	
6242	031770	000000		.WORD	0	:RESULT FPS	
6243				:7/INT=-40000			
6244	031772	004767	000340	JSR	R7,LCFSUB		:DO TEST
6245	031776	140000	000000	.WORD	-40000,0	:FSRC	
6246	032002	143600	000000	.WORD	143600,0	:RESULT	
6247	032006	000007		.WORD	7	: TEST FPS	
6248	032010	000010		.WORD	10	:RESULT FPS	
6249				:8/INT=-1			
6250	032012	004767	000320	JSR	R7,LCFSUB		:DO TEST
6251	032016	177777	000000	.WORD	-1,0	:FSRC	
6252	032022	140200	000000	.WORD	140200,0	:RESULT	
6253	032026	000007		.WORD	7	: TEST FPS	
6254	032030	000010		.WORD	10	:RESULT FPS	
6255				:9/INT=PATTERN			
6256	032032	004767	000300	JSR	R7,LCFSUB		:DO TEST
6257	032036	125252	125252	.WORD	125252,125252	:FSRC	
6258	032042	143652	126000	.WORD	143652,126000	:RESULT	
6259	032046	000007		.WORD	7	: TEST FPS	
6260	032050	000010		.WORD	10	:RESULT FPS	
6261				:10/LONG=40000			
6262	032052	004767	000260	JSR	R7,LCFSUB		:DO TEST

6263	032056	040000	000000	.WORD	40000,0	FSRC	
6264	032062	047600	000000	.WORD	47600,0	RESULT	
6265	032066	000117		.WORD	117	TEST FPS	
6266	032070	000100		.WORD	100	RESULT FPS	
6267							
6268	032072	004767	000240	:11/LONG=1	JSR	R7,LCFSUB	DO TEST
6269	032076	000000	000001	.WORD	0,1	FSRC	
6270	032102	040200	000000	.WORD	40200,0	RESULT	
6271	032106	007557		.WORD	7557	TEST FPS	
6272	032110	007540		.WORD	7540	RESULT FPS	
6273							
6274	032112	004767	000220	:12/LONG=PATTERN	JSR	R7,LCFSUB	DO TEST
6275	032116	000000	000252	.WORD	0,252	FSRC	
6276	032122	042052	000000	.WORD	42052,0	RESULT	
6277	032126	007557		.WORD	7557	TEST FPS	
6278	032130	007540		.WORD	7540	RESULT FPS	
6279							
6280	032132	004767	000200	:13/LONG = -40000	JSR	R7,LCFSUB	DO TEST
6281	032136	140000	000000	.WORD	-40000,0	FSRC	
6282	032142	147600	000000	.WORD	147600,0	RESULT	
6283	032146	000107		.WORD	107	TEST FPS	
6284	032150	000110		.WORD	110	RESULT FPS	
6285							
6286	032152	004767	000160	:14/LONG=-1	JSR	R7,LCFSUB	DO TEST
6287	032156	177777	177777	.WORD	-1,-1	FSRC	
6288	032162	140200	000000	.WORD	140200,0	RESULT	
6289	032166	007500		.WORD	7500	TEST FPS	
6290	032170	007510		.WORD	7510	RESULT FPS	
6291							
6292	032172	004767	000140	:15/LONG=PATTERN	JSR	R7,LCFSUB	DO TEST
6293	032176	125252	125252	.WORD	125252,125252	FSRC	
6294	032202	147652	125253	.WORD	147652,125253	RESULT	
6295	032206	000105		.WORD	105	TEST FPS	
6296	032210	000110		.WORD	110	RESULT FPS	
6297							
6298	032212	004767	000120	:16/LONG=77777,177500	JSR	R7,LCFSUB	DO TEST
6299	032216	077777	177500	.WORD	77777,177500	FSRC	
6300	032222	047777	177777	.WORD	47777,177777	RESULT	
6301	032226	000117		.WORD	117	TEST FPS	
6302	032230	000100		.WORD	100	RESULT FPS	
6303							
6304	032232	004767	000100	:17/LONG=40000,100	JSR	R7,LCFSUB	DO TEST
6305	032236	040000	000100	.WORD	40000,100	FSRC	
6306	032242	047600	000001	.WORD	47600,1	RESULT	
6307	032246	007502		.WORD	7502	TEST FPS	
6308	032250	007500		.WORD	7500	RESULT FPS	
6309							
6310	032252	004767	000060	:18/LONG=40000,100 - TRUNCATE	JSR	R7,LCFSUB	DO TEST
6311	032256	040000	000100	.WORD	40000,100	FSRC	
6312	032262	047600	000000	.WORD	47600,0	RESULT	
6313	032266	007557		.WORD	7557	TEST FPS	
6314	032270	007540		.WORD	7540	RESULT FPS	
6315							
6316	032272	004767	000040	:19/INT= MOST NEGATIVE	JSR	R7,LCFSUB	DO TEST
6317	032276	100000	000000	.WORD	100000,0	FSRC	
6318	032302	144000	000000	.WORD	144000,0	RESULT	


```

6319 032306 000007          .WORD 7          ; TEST FPS
6320 032310 000010          .WORD 10         ; RESULT FPS
6321          ;20/LONG= MOST NEGATIVE
6322 032312 004767 000020  JSR R7,LCFSUB    ; DO TEST
6323 032316 100000 000000    .WORD 10000,0    ; FSRC
6324 032322 150000 000000    .WORD 15000,0    ; RESULT
6325 032326 000107          .WORD 107        ; TEST FPS
6326 032330 000110          .WORD 110        ; RESULT FPS
6327          ;
6328          ;
6329 032332 000167 000126    JMP HOP18         ; GET OVER SUBROUTINE
6330          ;
6331          ;
6332          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6333          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6334          ;LDCIF, LDCLF
6335          ;
6336          ;
6337          ;          FSRC
6338          ;          RESULT
6339          ;          FPS BEFORE EXECUTION
6340          ;          FPS AFTER EXECUTION
6341          ;
6342          ;NO TRAP CAN OCCUR
6343          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6344          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6345 032336 012602          LCFSUB: MOV (SP),R2    ; RETURN ADDRESS TO USE AS POINTER
6346 032340 012737 032446 000244  MOV #50,0#FPVEC  ; REDIRECT TRAP VECTOR
6347 032346 012701 001126    MOV #RECDST,R1   ; POINT TO RESULT AREA
6348 032352 016200 000010    MOV 10(R2),R0    ; GET TEST FPS
6349 032356 170100          LDFPS R0         ; LOAD TEST FPS
6350 032360 010204          MOV R2,R4        ; POINT TO TEST DATA
6351          ;
6352 032362 177014          40: LDCIF (R4),AC0 ; *TEST INSTRUCTION (ACCORDING TO MODE)
6353          ;
6354          ;VERIFY STATUS
6355 032364 170203          2: STFPS R3      ; SAVE FPS
6356 032366 012700 000200    MOV #200,R0      ; SET FPP STATUS TO DOUBLE
6357 032372 170100          LDFPS R0
6358 032374 174011          STD AC0,(R1)     ; SAVE TEST RESULT INTO RECDST
6359 032376 016200 000012    MOV 12(R2),R0    ; GET EXPECTED STATUS
6360 032402 020003          CMP R0,R3        ; VERIFY STATUS
6361 032404 001403          BEQ 3:           ; BRANCH IF GOOD
6362 032406 104000          ERROR           ; ALL ERRORS TO TRAP TO EMT VECTOR
6363 032410 000467          .WORD 467        ; UNIQUE ERROR NUMBER
6364 032412 002013          .WORD FPPERR    ; ADDRESS OF ERROR MESSAGE
6365          ;
6366 032414 010204          3: MOV R2,R4      ; BAD FPS
6367 032416 062704 000004    ADD #4,R4        ; POINT TO EXPECTED DATA
6368 032422 004767 147502    4: JSR R7,DATVFR ; VERIFY DATA
6369 032426 005767 146406    TST COUNT
6370 032432 001403          BEQ 5:           ; BRANCH IF GOOD
6371 032434 104000          ERROR           ; ALL ERRORS TO TRAP TO EMT VECTOR
6372 032436 000470          .WORD 470        ; UNIQUE ERROR NUMBER
6373 032440 002013          .WORD FPPERR    ; ADDRESS OF ERROR MESSAGE
6374          ;
    
```

```

6375 032442 000162 000014 5: JMP 14(R2) ;RETURN FROM TEST
6376
6377 ;INSTRUCTION TRAPPED
6378 032446 012600 50: MOV (SP),R0 ;SAVE PC
6379 032450 012605 MOV (SP),R5 ;SAVE PS
6380 032452 104000 ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
6381 032454 000471 .WORD 471 ;UNIQUE ERROR NUMBER
6382 032456 002013 .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
6383 ;INSTRUCTION WASNT SUPPOSE TO TRAP
6384 032460 000167 177756 JMP 5: ;CONTINUE
6385 032464
6386
6387 032464
6388
6389
6390
6391 032464
6392 032464 005267 146314
6393
6394 032470 004767 000264
6395 032474 000000 000000 ;1/LONG=0 INC #TESTN ;INCREMENT TEST NUMBER
6396 032500 000000 000000 000000 JSR R7,LCDSUB ;DO TEST
6397 032506 000000 .WORD 0,0 .FSRC
6398 032510 007313 .WORD 0,0,0,0 ;RESULT
6399 032512 007304 .WORD 7313 ;TEST FPS
6400 .WORD 7304 ;RESULT FPS
6401 032514 004767 000240 ;2/INT=0 JSR R7,LCDSUB ;DO TEST
6402 032520 000000 000001 .WORD 0,1 .FSRC
6403 032524 040200 000000 000000 .WORD 40200,0,0,0 ;RESULT
6404 032532 000000 .WORD 7757 ;TEST FPS
6405 032534 007757 .WORD 7740 ;RESULT FPS
6406 032536 007740
6407
6408 032540 004767 000214 ;3/INT=40000 JSR R7,LCDSUB ;DO TEST
6409 032544 040000 177777 .WORD 40000,-1 .FSRC
6410 032550 043600 000000 000000 .WORD 43600,0,0,0 ;RESULT
6411 032556 000000 .WORD 7617 ;TEST FPS
6412 032560 007617 .WORD 7600 ;RESULT FPS
6413 032562 007600
6414
6415 032564 004767 000170 ;4/INT=-40000 JSR R7,LCDSUB ;DO TEST
6416 032570 140000 177777 .WORD -40000,-1 .FSRC
6417 032574 143600 000000 000000 .WORD 143600,0,0,0 ;RESULT
6418 032602 000000 .WORD 7600 ;TEST FPS
6419 032604 007600 .WORD 7610 ;RESULT FPS
6420 032606 007610
6421
6422 032610 004767 000144 ;5/LONG=40000 JSR R7,LCDSUB ;DO TEST
6423 032614 040000 000000 .WORD 40000,0 .FSRC
6424 032620 047600 000000 000000 .WORD 47600,0,0,0 ;RESULT
6425 032626 000000 .WORD 7757 ;TEST FPS
6426 032630 007757 .WORD 7740 ;RESULT FPS
6427 032632 007740
6428
6429 032634 004767 000120 ;6/LONG=1 JSR R7,LCDSUB ;DO TEST
6430 032640 000000 000001 .WORD 0,1 .FSRC

```

```

6431 032644 040200 000000 000000 .WORD 40200,0,0,0 ;RESULT
6432 032652 000000 .WORD 300 ; TEST FPS
6433 032654 000300 .WORD 300 ;RESULT FPS
6434 032656 000300 ;7/LONG=-2
6435 .WORD 300 ;RESULT FPS
6436 032660 004767 000074 JSR R7,LCDSUB ;DO TEST
6437 032664 177777 177776 .WORD -1,-2 ;FSRC
6438 032670 140400 000000 000000 .WORD 140400,0,0,0 ;RESULT
6439 032676 000000 .WORD 7300 ; TEST FPS
6440 032700 007300 .WORD 7310 ;RESULT FPS
6441 032702 007310 ;8/INT=PATTERN
6442 JSR R7,LCDSUB ;DO TEST
6443 032704 004767 000050 .WORD 123456,176543 ;FSRC
6444 032710 123456 176543 .WORD 143661,122000,0,0 ;RESULT
6445 032714 143661 122000 000000 .WORD 143661,122000,0,0 ;RESULT
6446 032722 000000 .WORD 200 ; TEST FPS
6447 032724 000200 .WORD 210 ;RESULT FPS
6448 032726 000210 ;9/LONG=PATTERN
6449 JSR R7,LCDSUB ;DO TEST
6450 032730 004767 000024 .WORD 125252,125252 ;FSRC
6451 032734 125252 125252 126000 .WORD 147652,125252,126000,0 ;RESULT
6452 032740 147652 125252 126000 .WORD 300 ; TEST FPS
6453 032746 000000 .WORD 310 ;RESULT FPS
6454 032750 000300 ;
6455 032752 000310 ;
6456 ;
6457 ;
6458 ;
6459 032754 000167 000126 JMP HOP19 ;GET OVER SUBROUTINE
6460 ;
6461 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6462 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6463 ;LDCID, LDCLD
6464 ;
6465 ;
6466 ; FSRC
6467 ; RESULT
6468 ; FPS BEFORE EXECUTION
6469 ; FPS AFTER EXECUTION
6470 ;
6471 ;NO TRAP CAN OCCUR
6472 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6473 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6474 ;
6475 LCDSUB: MOV (SP),R2 ; RETURN ADDRESS TO USE AS POINTER
6476 MOV #508,0@FPVEC ;REDIRECT TRAP VECTOR
6477 MOV @RECDST,R1 ;POINT TO RESULT AREA
6478 LDFPS R0 ;GET TEST FPS
6479 MOV R2,R4 ;LOAD TEST FPS
6480 ;POINT TO TEST DATA
6481 ;
6482 406: LDCID (R4),ACO ;*TEST INSTRUCTION (ACCORDING TO MODE)
6483 ;
6484 ;VERIFY STATUS
6485 29: STFPS R3 ;SAVE FPS
6486 MOV #200,R0 ;SET FPP STATUS TO DOUBLE
        LDFPS R0 ;
    
```

```

6487 033016 174011          STD      ACO,(R1)          ;SAVE TEST RESULT INTO RECDST
6488 033020 016200 000016  MOV      16(R2),R0        ;GET EXPECTED STATUS
6489 033024 020003          CMP      R0,R3           ;VERIFY STATUS
6490 033026 001403          BEQ      3$              ;BRANCH IF GOOD
6491 033030 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
6492 033032 000472          .WORD   472             ;UNIQUE ERROR NUMBER
6493 033034 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
6494
6495 033036 010204          3$:     MOV      R2,R4      ;BAD FPS
6496 033040 062704 000004  ADD      4,R4           ;POINT TO EXPECTED DATA
6497 033044 004767 147076  4$:     JSR      R7,DATVER ;VERIFY DATA
6498 033050 005767 145764  TST      COUNT
6499 033054 001403          BEQ      5$              ;BRANCH IF GOOD
6500 033056 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
6501 033060 000473          .WORD   473             ;UNIQUE ERROR NUMBER
6502 033062 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
6503
6504 033064 000162 000020  5$:     JMP      20(R2)       ;BAD ACO
6505
6506          ;INSTRUCTION TRAPPED
6507 033070 012600          50$:   MOV      (SP)+,R0    ;SAVE PC
6508 033072 012605          MOV      (SP)+,R5    ;SAVE PS
6509 033074 104000          ERROR    ;ALL ERRORS TO TRAP TO EMT VECTOR
6510 033076 000474          .WORD   474             ;UNIQUE ERROR NUMBER
6511 033100 002013          .WORD   FPPERR         ;ADDRESS OF ERROR MESSAGE
6512
6513 033102 000167 177756  JMP      5$              ;INSTRUCTION WASNT SUPPOSE TO TRAP
6514
6515 033106          ; HOP19:
6516
6517 033106          ; MLXP:
6518          ;:*****
6519          ;:TEST 106      EST LDEXP DOUBLE
6520          ;:*****
6521 033106          TST106:
6522 033106 005267 145672  INC      $TESTN        ;INCREMENT TEST NUMBER
6523          ;1/EXP=10 - AC=NEG
6524 033112 005037 001042  CLR      @FLAG         ;NO INTERRUPTS
6525 033116 004767 001140  JSR      R7,LXPSUB    ;DO TEST
6526 033122 123456 067012 025252  .WORD   123456,67012,25252,171717 ;AC0
6527 033130 171717
6528 033132 000010          .WORD   10             ;EXP
6529 033134 142056 067012 025252  .WORD   142056,67012,25252,171717 ;RESULT
6530 033142 171717
6531 033144 007757          .WORD   7757          ; TEST FPS
6532 033146 007750          .WORD   7750          ;RESULT FPS
6533          ;2/EXP=177 - ACO=POS
6534 033150 005037 001042  CLR      @FLAG         ;NO INTERRUPTS
6535 033154 004767 001102  JSR      R7,LXPSUB    ;DO TEST
6536 033160 023456 070123 100000  .WORD   23456,70123,100000,1 ;AC0
6537 033166 000001
6538 033170 000177          .WORD   177           ;EXP
6539 033172 077656 070123 100000  .WORD   77656,70123,100000,1 ;RESULT
6540 033200 000001
6541 033202 007700          .WORD   7700          ; TEST FPS
6542 033204 007700          .WORD   7700          ;RESULT FPS
    
```

```

6543
6544 033206 005037 001042 ;3/EXP=56
6545 033212 004767 001044 CLR @#FLAG ;NO INTERRUPTS
6546 033216 055555 044444 033333 JSR R7,LXPSUB ;DO TEST
6547 033224 022222 .WORD 55555,44444,33333,22222 ;ACO
6548 033226 000056 .WORD 56 ;EXP
6549 033230 053555 044444 033333 .WORD 53555,44444,33333,22222 ;RESULT
6550 033236 022222
6551 033240 007757 .WORD 7757 ; TEST FPS
6552 033242 007740 .WORD 7740 ;RESULT FPS
6553
6554 033244 005037 001042 ;4/EXP=-151, ACO=UV
6555 033250 004767 001006 CLR @#FLAG ;NO INTERRUPTS
6556 033254 100077 177777 177777 JSR R7,LXPSUB ;DO TEST
6557 033262 177776 .WORD 100077,-1,-1,-2 ;ACO
6558 033264 177623 .WORD -155 ;EXP
6559 033266 104677 177777 177777 .WORD 104677,-1,-1,-2 ;RESULT
6560 033274 177776
6561 033276 007757 .WORD 7757 ; TEST FPS
6562 033300 007750 .WORD 7750 ;RESULT FPS
6563
6564 033302 005037 001042 ;5/EXP=-177
6565 033306 004767 000750 CLR @#FLAG ;NO INTERRUPTS
6566 033312 000177 177777 177777 JSR R7,LXPSUB ;DO TEST
6567 033320 177776 .WORD 177,-1,-1,-2 ;ACO
6568 033322 177601 .WORD -177 ;EXP
6569 033324 000377 177777 177777 .WORD 377,-1,-1,-2 ;RESULT
6570 033332 177776
6571 033334 007700 .WORD 7700 ; TEST FPS
6572 033336 007700 .WORD 7700 ;RESULT FPS
6573
6574 033340 012737 000001 001042 ;6/EXP=-200, UNDERFLOW
6575 033346 004767 000710 MOV #1,@#FLAG ; INTERRUPTS
6576 033352 030131 032334 035363 JSR R7,LXPSUB ;DO TEST
6577 033360 073031 .WORD 30131,32334,35363,73031 ;ACO
6578 033362 177600 .WORD -200 ;EXP
6579 033364 000131 032334 035363 .WORD 131,32334,35363,73031 ;RESULT
6580 033372 073031
6581 033374 007740 .WORD 7740 ; TEST FPS
6582 033376 107744 .WORD 107744 ;RESULT FPS
6583 033400 000012 .WORD 12 ;FEC
6584
6585 033402 012737 000001 001042 ;7/EXP=LARGEST NEGATIVE
6586 033410 004767 000646 MOV #1,@#FLAG ;EXPECT INTERRUPTS
6587 033414 000000 000123 000456 JSR R7,LXPSUB ;DO TEST
6588 033422 000001 .WORD 0,123,456,1 ;ACO
6589 033424 100000 .WORD 100000 ;EXP
6590 033426 040000 000123 000456 .WORD 40000,123,456,1 ;RESULT
6591 033434 000001
6592 033436 002200 .WORD 2200 ; TEST FPS
6593 033440 102200 .WORD 102200 ;RESULT FPS
6594 033442 000012 .WORD 12 ;FEC
6595
6596 033444 012737 000001 001042 ;8/EXP=-200, NEG. ACO
6597 033452 004767 000604 MOV #1,@#FLAG ; INTERRUPTS
6598 033456 111111 100000 100000 JSR R7,LXPSUB ;DO TEST
        .WORD 111111,100000,100000,-1 ;ACO
    
```

```

6599 033464 177777
6600 033466 177600
6601 033470 100111 100000 100000 .WORD -200 ;EXP
6602 033476 177777 100000 100000 .WORD 100111,100000,100000,-1 ;RESULT
6603 033500 002217 .WORD 2217 ; TEST FPS
6604 033502 102214 .WORD 102214 ;RESULT FPS
6605 033504 000012 .WORD 12 ;FEC
6606 ;9/EXP=-1743, FIU=0
6607 033506 012737 000002 001042 MOV #2,B#FLAG ;NO INTERRUPTS
6608 033514 004767 000542 JSR R7,LXPSUB ;DO TEST
6609 033520 123456 012346 012346 .WORD 123456,12346,12346,123 ;ACO
6610 033526 000123
6611 033530 176035 .WORD -1743 ;EXP
6612 033532 000000 000000 000000 .WORD 0,0,0,0 ;RESULT
6613 033540 000000
6614 033542 005700 .WORD 5700 ; TEST FPS
6615 033544 005704 .WORD 5704 ;RESULT FPS
6616 033546 000012 .WORD 12 ;FEC
6617 ;10/EXP = -16616, FID=1
6618 033550 012737 000002 001042 MOV #2,B#FLAG ;NO INTERRUPTS
6619 033556 004767 000500 JSR R7,LXPSUB ;DO TEST
6620 033562 000377 123456 065432 .WORD 377,123456,65432,1 ;ACO
6621 033570 000001
6622 033572 161162 .WORD -16616 ;EXP
6623 033574 074577 123456 065432 .WORD 74577,123456,65432,1 ;RESULT
6624 033602 000001
6625 033604 047700 .WORD 47700 ; TEST FPS
6626 033606 147700 .WORD 147700 ;RESULT FPS
6627 033610 000012 .WORD 12 ;FEC
6628 ;11/EXP=177, ACO=UNDEFINED VARIABLE
6629 033612 005037 001042 CLR B#FLAG ;NO INTERRUPTS
6630 033616 004767 000440 JSR R7,LXPSUB ;DO TEST
6631 033622 100177 177777 177777 .WORD 100177,-1,-1,-1 ;ACO
6632 033630 177777
6633 033632 000177 .WORD 177 ;EXP
6634 033634 177777 177777 177777 .WORD -1,-1,-1,-1 ;RESULT
6635 033642 177777
6636 033644 007700 .WORD 7700 ; TEST FPS
6637 033646 007710 .WORD 7710 ;RESULT FPS
6638 ;12/EXP=150 ACO=POS
6639 033650 005037 001042 CLR B#FLAG ;NO INTERRUPT
6640 033654 004767 000402 JSR R7,LXPSUB ;DO TEST
6641 033660 000200 000100 000200 .WORD 200,100,200,300 ;ACO
6642 033666 000300
6643 033670 000150 .WORD 150 ;EXP
6644 033672 072000 000100 000200 .WORD 72000,100,200,300 ;RESULT
6645 033700 000300
6646 033702 007717 .WORD 7717 ; TEST FPS
6647 033704 007700 .WORD 7700 ;RESULT FPS
6648 ;13/EXP=200, ACO=NEG
6649 033706 012737 000001 001042 MOV #1,B#FLAG
6650 033714 004767 000342 JSR R7,LXPSUB ;DO TEST
6651 033720 177777 177777 177777 .WORD -1,-1,-1,-1 ;ACO
6652 033726 177777
6653 033730 000200 .WORD 200 ;EXP
6654 033732 100177 177777 177777 .WORD 100177,-1,-1,-1 ;RESULT
    
```

```

6655 033740 177777
6656 033742 007705
6657 033744 107716
6658 033746 000010
6659
:14/EXP=400, FID
6660 033750 012737 000002 001042 MOV #2, B#FLAG ; INTERRUPT
6661 033756 004767 000300 JSR R7, LXPSUB ; DO TEST
6662 033762 000555 177777 177776 .WORD 555, -1, -2, -3 ; ACO
6663 033770 177775
6664 033772 000400 .WORD 400 ; EXP
6665 033774 040155 177777 177776 .WORD 40155, -1, -2, -3 ; RESULT
6666 034002 177775
6667 034004 047700 .WORD 47700 ; TEST FPS
6668 034006 147702 .WORD 147702 ; RESULT FPS
6669 034010 000010 .WORD 10 ; FEC
6670
:15/EXP=11011 FIU=0
6671 034012 012737 000000 001042 MOV #0, B#FLAG ; NO INTERRUPT
6672 034020 004767 000236 JSR R7, LXPSUB ; DO TEST
6673 034024 177773 177777 177776 .WORD 177773, -1, -2, -3 ; ACO
6674 034032 177775
6675 034034 011011 .WORD 11011 ; EXP
6676 034036 000000 000000 000000 .WORD 0,0,0,0 ; RESULT
6677 034044 000000
6678 034046 006700 .WORD 6700 ; TEST FPS
6679 034050 006706 .WORD 6706 ; RESULT FPS
6680
:16/EXP=LARGEST POSITIVE
6681 034052 012737 000001 001042 MOV #1, B#FLAG ; INTERRUPT
6682 034060 004767 000176 JSR R7, LXPSUB ; DO TEST
6683 034064 123456 000100 000100 .WORD 123456, 100, 100, 200 ; ACO
6684 034072 000200
6685 034074 077777 .WORD 77777 ; EXP
6686 034076 137656 000100 000100 .WORD 137656, 100, 100, 200 ; RESULT
6687 034104 000200
6688 034106 007740 .WORD 7740 ; TEST FPS
6689 034110 107752 .WORD 107752 ; RESULT FPS
6690 034112 000010 .WORD 10 ; FEC
6691
:17/FLOATING
6692 034114 005037 001042 CLR B#FLAG ; NO INTERRUPT
6693 034120 004767 000136 JSR R7, LXPSUB ; DO TEST
6694 034124 123456 023465 000555 .WORD 123456, 23465, 555, 444 ; ACO
6695 034132 000444
6696 034134 000050 .WORD 50 ; EXP
6697 034136 152056 023465 000555 .WORD 152056, 23465, 555, 444 ; RESULT
6698 034144 000444
6699 034146 007500 .WORD 7500 ; TEST FPS
6700 034150 007510 .WORD 7510 ; RESULT FPS
6701
:18/FLOATING UNDERFLOW
6702 034152 012737 000001 001042 MOV #1, B#FLAG ; INTERRUPT
6703 034160 004767 000076 JSR R7, LXPSUB ; DO TEST
6704 034164 000333 000444 000555 .WORD 333, 444, 555, 666 ; ACO
6705 034172 000666
6706 034174 177600 .WORD -200 ; EXP
6707 034176 000133 000444 000555 .WORD 133, 444, 555, 666 ; RESULT
6708 034204 000666
6709 034206 007500 .WORD 7500 ; TEST FPS
6710 034210 107504 .WORD 107504 ; RESULT FPS

```

```

6711 034212 000012          .WORD 12          ;FEC
6712          ;19/FLOATING OVERFLOW
6713 034214 012737 000001 001042  MOV #1,0#FLAG ;INTERRUPT
6714 034222 004767 000034          JSR R7,LXPSUB ;DO TEST
6715 034226 012346 000123 000345  .WORD 12346,123,345,456 ;ACO
6716 034234 000456
6717 034236 000400          .WORD 400          ;EXP
6718 034240 040146 000123 000345  .WORD 40146,123,345,456 ;RESULT
6719 034246 000456
6720 034250 007400          .WORD 7400          ; TEST FPS
6721 034252 107402          .WORD 107402        ;RESULT FPS
6722 034254 000010          .WORD 10           ;FEC
6723
6724
6725 034256 000167 000250          JMP HOP20          ;GET OVER SUBROUTINE
6726          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6727          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6728          ;LDEXP
6729          ;
6730          ; ACO
6731          ; EXPONENT
6732          ; RESULT
6733          ; FPS BEFORE EXECUTION
6734          ; FPS AFTER EXECUTION
6735          ; (FEC)
6736          ;
6737          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6738          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6739 034262 012602          LXPSUB: MOV (SP)+,R2 ; RETURN ADDRESS TO USE AS POINTER
6740 034264 012737 034352 000244  MOV #50#,0#FPVEC ;REDIRECT TRAP VECTOR
6741 034272 012701 001126          MOV #RECDST,R1 ;POINT TO RESULT AREA
6742 034276 012700 000200          MOV #200,R0 ;SET FPS TO DOUBLE
6743 034302 170100          LDFPS R0 ;
6744 034304 010204          MOV R2,R4 ;POINT TO ACO DATA
6745 034306 172414          LDD (R4),ACO ;LOAD ACO
6746 034310 016200 000022          MOV 22(R2),R0 ;GET TEST FPS
6747 034314 170100          LDFPS R0 ;LOAD TEST FPS
6748 034316 016204 000010          MOV 10(R2),R4 ;POINT TO TEST DATA
6749
6750 034322 176404          40#: LDEXP R4,ACO ;*TEST INSTRUCTION (ACCORDING TO MODE)
6751 034324 170327          1#: STST (PC)+ ;WAIT FOR POSSIBLE FPA TRAP.
6752 034326 000000          .WORD 0 ;STORE STATUS HERE
6753
6754
6755          ;
6756 034330 032737 000001 001042  ;INSTRUCTION DIDNT TRAP
6757 034336 001426          BIT #1,0#FLAG ;VERIFY A NO TRAP CONDITION
6758 034340 104000          BEQ 2# ;BRANCH IF GOOD
6759 034342 000475          ERROR ;ALL ERRORS TO TRAP TO EMT VECTOR
6760 034344 002013          .WORD 475 ;UNIQUE ERROR NUMBER
6761          .WORD FPPERR ;ADDRESS OF ERROR MESSAGE
6762 034346 000167 000042          JMP 2# ;INSTRUCTION SHOULD HAVE TRAPPED
6763          ;REJOIN CODE
6764
6765 034352 032737 000001 001042  ;INSTRUCTION TRAPPED
6766 034360 001005          50#: BIT #1,0#FLAG ;SEE IF EXPECTING A TRAP
          BNE 51# ;BRANCH IF EXPECTING A TRAP

```



```

6767 034362 104000          ERROR          ; ALL ERRORS TO TRAP TO EMT VECTOR
6768 034364 000476          .WORD      476          ; UNIQUE ERROR NUMBER
6769 034366 002013          .WORD      FPPERR       ; ADDRESS OF ERROR MESSAGE
6770                                     ; INSTRUCTION WASNT SUPPOSE TO TRAP
6771 034370 000167 000020    JMP        2$           ; REJOIN CODE
6772 034374 012604          51$: MOV      (SP)+,R4    ; SEE IF PC = INSTRUCTION
6773 034376 005726          TST      (SP)+        ; CLEAN UP STACK
6774 034400 022704 034324    CMP      #1$,R4       ;
6775 034404 001403          BEQ      2$           ; BRANCH IF GOOD COMPARE
6776 034406 104000          ERROR          ; ALL ERRORS TO TRAP TO EMT VECTOR
6777 034410 000477          .WORD      477          ; UNIQUE ERROR NUMBER
6778 034412 002013          .WORD      FPPERR       ; ADDRESS OF ERROR MESSAGE
6779                                     ; PC WAS INCORRECT
6780
6781                                     ;
6782                                     ; COMMON CODE FOR TRAP AND NO TRAP
6783 034414 170203          ; VERIFY STATUS
6784 034416 012700 000200    2$: STFPS   R3          ; SAVE FPS
6785 034422 170100          MOV      #200,R0      ; SETUP FPS
6786 034424 174011          LDFPS   R0            ; FPS=200
6787 034426 016200 000024    STD     ACO,(R1)      ; GET RESULT
6788 034432 020003          MOV      24(R2),R0    ; GET EXPECTED STATUS
6789 034434 001403          CMP     R0,R3         ; VERIFY STATUS
6790 034436 104000          BEQ     3$           ; BRANCH IF GOOD
6791 034440 000500          ERROR          ; ALL ERRORS TO TRAP TO EMT VECTOR
6792 034442 002013          .WORD    500          ; UNIQUE ERROR NUMBER
6793                                     .WORD    FPPERR       ; ADDRESS OF ERROR MESSAGE
6794 034444 010204          ; BAD FPS
6795 034446 062704 000012    3$: MOV     R2,R4      ; POINT TO EXPECTED DATA
6796 034452 004767 145470    4$: ADD     #12,R4     ;
6797 034456 005767 144356    JSR     R7,DATVER     ; VERIFY DATA
6798 034462 001403          TST     COUNT         ;
6799 034464 104000          BEQ     5$           ; BRANCH IF GOOD
6800 034466 000501          ERROR          ; ALL ERRORS TO TRAP TO EMT VECTOR
6801 034470 002013          .WORD    501          ; UNIQUE ERROR NUMBER
6802                                     .WORD    FPPERR       ; ADDRESS OF ERROR MESSAGE
6803 034472 005737 001042    ; BAD ACO
6804 034476 001002          5$: TST     #0,FLAG    ; SEE IF NEED TO CHECK FEC
6805 034500 000162 000026    BNE     7$           ; BRANCH IF NEED TO CHECK
6806                                     JMP     26(R2)        ; RETURN FROM TEST
6807 034504 012704 001106    ; VERIFY FEC
6808 034510 170314          7$: MOV     #REC FEC, R4 ; POINT TO FEC AREA
6809 034512 021462 000026    STST   (R4)          ; SAVE FEC
6810 034516 001403          CMP     (R4),26(R2)   ; VERIFY FEC FOR OVERFLOW
6811 034520 104000          BEQ     8$           ; BRANCH IF GOOD
6812 034522 000502          ERROR          ; ALL ERRORS TO TRAP TO EMT VECTOR
6813 034524 002013          .WORD    502          ; UNIQUE ERROR NUMBER
6814                                     .WORD    FPPERR       ; ADDRESS OF ERROR MESSAGE
6815 034526 000162 000030    8$: JMP     30(R2)     ; BAD FEC
6816                                     ; RETURN FROM TEST
6817 034532          ;
6818                                     ; HOP20:
6819 034532          MSCD:
6820                                     ; *****
6821                                     ; *TEST 107      TEST STCDI, STCDL
6822                                     ; *****

```


6879	035004	007700			.WORD	7700		; TEST FPS
6880	035006	107705			.WORD	107705		; RESULT FPS
6881					:8/INT, EXP=2**15			
6882	035010	005037	001042		CLR	B#FLAG		; NO INTERRUPTS
6883	035014	004767	000336		JSR	R7, SCDSUB		; DO TEST
6884	035020	043200	000000	000000	.WORD	43200,0,0,0		; ACO
6885	035026	000000						
6886	035030	010000	177777		.WORD	10000,-1		; RESULT
6887	035034	007600			.WORD	7600		; TEST FPS
6888	035036	007600			.WORD	7600		; RESULT FPS
6889					:9/INT, EXP>2**15			
6890	035040	012737	000001	001042	MOV	#1, B#FLAG		; INTERRUPT
6891	035046	004767	000304		JSR	R7, SCDSUB		; DO TEST
6892	035052	077777	177777	177777	.WORD	77777,-1,-1,-1		; ACO
6893	035060	177777						
6894	035062	000000	177777		.WORD	0,-1		; RESULT
6895	035066	007600			.WORD	7600		; TEST FPS
6896	035070	107605			.WORD	107605		; RESULT FPS
6897					:10/INT, EXP>2**15, FID			
6898	035072	012737	000000	001042	MOV	#0, B#FLAG		; NO INTERRUPT
6899	035100	004767	000252		JSR	R7, SCDSUB		; DO TEST
6900	035104	043300	000000	000000	.WORD	43300,0,0,0		; ACO
6901	035112	000000						
6902	035114	000000	014000		.WORD	0,14000		; RESULT
6903	035120	047700			.WORD	47700		; TEST FPS
6904	035122	047700			.WORD	47700		; RESULT FPS
6905					:11/INT, EXP>2**15, FIC=0			
6906	035124	012737	000000	001042	MOV	#0, B#FLAG		; NO INTERRUPT
6907	035132	004767	000220		JSR	R7, SCDSUB		; DO TEST
6908	035136	143300	177777	177777	.WORD	143300,-1,-1,-1		; ACO
6909	035144	177777						
6910	035146	177777	163741		.WORD	-1,163741		; RESULT
6911	035152	007300			.WORD	7300		; TEST FPS
6912	035154	007310			.WORD	7310		; RESULT FPS
6913					:12/LONG, EXP>2**32, FID			
6914	035156	012737	000002	001042	MOV	#2, B#FLAG		; INTERRUPT
6915	035164	004767	000166		JSR	R7, SCDSUB		; DO TEST
6916	035170	050100	000000	000000	.WORD	50100,0,0,0		; ACO
6917	035176	000000						
6918	035200	000000	000000		.WORD	0,0		; RESULT
6919	035204	047700			.WORD	47700		; TEST FPS
6920	035206	147705			.WORD	147705		; RESULT FPS
6921					:13/LONG, EXP>2**32, FIC=0			
6922	035210	012737	000000	001042	MOV	#0, B#FLAG		; NO INTERRUPT
6923	035216	004767	000134		JSR	R7, SCDSUB		; DO TEST
6924	035222	050377	177777	177777	.WORD	50377,-1,-1,-1		; ACO
6925	035230	177777						
6926	035232	000000	000000		.WORD	0,0		; RESULT
6927	035236	007300			.WORD	7300		; TEST FPS
6928	035240	007305			.WORD	7305		; RESULT FPS
6929					:14/LONG, EXP<0			
6930	035242	005037	001042		CLR	B#FLAG		; NO INTERRUPTS
6931	035246	004767	000104		JSR	R7, SCDSUB		; DO TEST
6932	035252	100200	177777	177777	.WORD	100200,-1,-1,-1		; ACO
6933	035260	177777						
6934	035262	000000	000000		.WORD	0,0		; RESULT

```

6935 035266 007757 .WORD 7757 ; TEST FPS
6936 035270 007744 .WORD 7744 ; RESULT FPS
6937 ;15/INT, EXP<0
6938 035272 005037 001042 CLR @FLAG ; NO INTERRUPTS
6939 035276 004767 000054 JSR R7,SCDSUB ; DO TEST
6940 035302 037700 177777 177777 .WORD 37700,-1,-1,-2 ; ACO
6941 035310 177776
6942 035312 000000 177777 .WORD 0,-1 ; RESULT
6943 035316 007600 .WORD 7600 ; TEST FPS
6944 035320 007604 .WORD 7604 ; RESULT FPS
6945 ;16/INT, EXP-10
6946 035322 005037 001042 CLR @FLAG ; NO INTERRUPTS
6947 035326 004767 000024 JSR R7,SCDSUB ; DO TEST
6948 035332 004377 177777 177777 .WORD 4377,-1,-1,-1 ; ACO
6949 035340 177777
6950 035342 000000 177777 .WORD 0,-1 ; RESULT
6951 035346 007600 .WORD 7600 ; TEST FPS
6952 035350 007604 .WORD 7604 ; RESULT FPS
6953 ;
6954 ;
6955 035352 000167 000244 JMP HOP21 ; GET OVER SUBROUTINE
6956 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6957 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6958 ;STCDI, STCDL, STCFI, STCFL
6959 ;
6960 ;
6961 ; ACO
6962 ; RESULT
6963 ; FPS BEFORE EXECUTION
6964 ; FPS AFTER EXECUTION
6965 ; (FEC)
6966 ;
6967 ; TRAP ON CONVERSION FAILURE
6968 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6969 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
6970 035356 012602 SCDSUB: MOV (SP),R2 ; RETURN ADDRESS TO USE AS POINTER
6971 035360 012737 035452 000244 MOV @50,@FPVEC ; REDIRECT TRAP VECTOR
6972 035366 012701 001130 MOV @RECDST-2,R1 ; POINT TO RESULT AREA
6973 035372 012711 177777 MOV @-1,(R1) ; PRELOAD RECEIVE DATA BUFFER
6974 035376 012741 177777 MOV @-1,-(R1) ;
6975 035402 012700 000200 MOV @200,R0 ; SET FPS TO DOUBLE
6976 035406 170100 LDFPS R0 ;
6977 035410 010204 MOV R2,R4 ; POINT TO ACO DATA
6978 035412 172414 LDD (R4),ACO ; LOAD ACO
6979 035414 016200 000014 MOV 14(R2),R0 ; GET TEST FPS
6980 035420 170100 LDFPS R0 ; LOAD TEST FPS
6981 ;
6982 035422 175411 40#: STCDI ACO,(R1) ; TEST INSTRUCTION (ACCORDING TO MODE)
6983 035424 170327 1#: STST (PC), ; WAIT FOR POSSIBLE FPA TRAP.
6984 035426 000000 .WORD 0 ; STORE STATUS HERE.
6985 ;
6986 ;
6987 ; INSTRUCTION DIDNT TRAP
6988 035430 032737 000001 001042 BIT @1,@FLAG ; VERIFY A NO TRAP CONDITION
6989 035436 001426 BEQ 2# ; BRANCH IF GOOD
6990 035440 104000 ERROR ; ALL ERRORS TO TRAP TO ENT VECTOR
    
```



```
7047
7048 035622
7049
7050
7051
7052 035622
7053 035622 005267 143156
7054
7055 035626 005037 001042
7056 035632 004767 177520
7057 035636 044541 052525 177777
7058 035644 177777
7059 035646 000003 102525
7060 035652 007517
7061 035654 007500
7062
7063 035656 005037 001042
7064 035662 004767 177470
7065 035666 002300 177777 177777
7066 035674 177777
7067 035676 000000 177777
7068 035702 007400
7069 035704 007404
7070
7071 035706 012737 000001 001042
7072 035714 004767 177436
7073 035720 070000 177777 177777
7074 035726 177777
7075 035730 000000 000000
7076 035734 007540
7077 035736 107545
7078
7079 035740 005037 001042
7080 035744 004767 177406
7081 035750 052000 000000 177777
7082 035756 177777
7083 035760 000000 177777
7084 035764 047000
7085 035766 047005
7086
7087
7088
7089 J35770
7090
7091
7092
7093 035770
7094 035770 005267 143010
7095
7096 035774 004767 000154
7097 036000 020000 000000 000000
7098 036006 000000
7099 036010 177700
7100 036012 007740
7101 036014 007750
7102
```

```
MSCF:
*****
*TEST 110 TEST STCFI, STCFL
*****
TST110:
;1/LONG INC #TESTN ;INCREMENT TEST NUMBER
EXP =30
CLR #FLAG ;NO INTERRUPTS
JSR R7,SCDSUB ;DO TEST
.WORD 44541,52525,-1,-1 ;ACO
;RESULT
.WORD 3,102525 ;TEST FPS
.WORD 7517 ;RESULT FPS
.WORD 7500 ;RESULT FPS
;2/INT, EXP<0
CLR #FLAG ;NO INTERRUPTS
JSR R7,SCDSUB ;DO TEST
.WORD 2300,-1,-1,-1 ;ACO
;RESULT
.WORD 0,-1 ;TEST FPS
.WORD 7400 ;RESULT FPS
.WORD 7404 ;RESULT FPS
;3/LONG, EXP>>2**32
MOV #1,#FLAG ;INTERRUPT
JSR R7,SCDSUB ;DO TEST
.WORD 7000,-1,-1,-1 ;ACO
;RESULT
.WORD 0,0 ;TEST FPS
.WORD 7540 ;RESULT FPS
.WORD 107545 ;RESULT FPS
;4/INT,EXP=5, FIC=0, FID=1
CLR #FLAG ;NO INTERRUPTS
JSR R7,SCDSUB ;DO TEST
.WORD 52000,0,-1,-1 ;ACO
;RESULT
.WORD 0,-1 ;TEST FPS
.WORD 47000 ;RESULT FPS
.WORD 47005 ;RESULT FPS
;
MSXP:
*****
*TEST 111 TEST STEXP
*****
TST111:
;1/EXP=100 INC #TESTN ;INCREMENT TEST NUMBER
JSR R7,SXPSUB ;DO TEST
.WORD 20000,0,0,0 ;ACO
;RESULT
.WORD -100 ;TEST FPS
.WORD 7740 ;RESULT FPS
.WORD 7750 ;RESULT FPS
;2/EXP=201 FLOAT, NEG
```

E 1 1

```
7103 036016 004767 000132 JSR R7,SXPSUB ;DO TEST
7104 036022 140377 177777 177777 .WORD 140377,-1,-1,0 ;ACO
7105 036030 000000 .WORD 1 ;RESULT
7106 036032 000001 .WORD 7500 ;TEST FPS
7107 036034 007500 .WORD 7500 ;RESULT FPS
7108 036036 007500 ;3/EXP=-177
7109 ;
7110 036040 004767 000110 JSR R7,SXPSUB ;DO TEST
7111 036044 000177 177777 177777 .WORD 177,-1,-1,-1 ;ACO
7112 036052 177777 .WORD 177600 ;RESULT
7113 036054 177600 .WORD 7700 ;TEST FPS
7114 036056 007700 .WORD 7710 ;RESULT FPS
7115 036060 007710 ;4/EXP=-100
7116 ;
7117 036062 004767 000066 JSR R7,SXPSUB ;DO TEST
7118 036066 020000 000000 177777 .WORD 20000,0,-1,-1 ;ACO
7119 036074 177777 .WORD -100 ;RESULT
7120 036076 177700 .WORD 40200 ;TEST FPS
7121 036100 040200 .WORD 40210 ;RESULT FPS
7122 036102 040210 ;5/EXP=200
7123 ;
7124 036104 004767 000044 JSR R7,SXPSUB ;DO TEST
7125 036110 040000 000000 000000 .WORD 40000,0,0,0 ;ACO
7126 036116 000000 .WORD 0 ;RESULT
7127 036120 000000 .WORD 7700 ;TEST FPS
7128 036122 007700 .WORD 7704 ;RESULT FPS
7129 036124 007704 ;6/EXP=0
7130 ;
7131 036126 004767 000022 JSR R7,SXPSUB ;DO TEST
7132 036132 000177 177777 177777 .WORD 177,-1,-1,-1 ;ACO
7133 036140 177777 .WORD 177600 ;RESULT
7134 036142 177600 .WORD 0 ;TEST FPS
7135 036144 000000 .WORD 10 ;RESULT FPS
7136 036146 000010 ;
7137 ;
7138 ;
7139 036150 000167 000120 JMP HOP22 ;GET OVER SUBROUTINE
7140 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
7141 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
7142 ;STEXP
7143 ;
7144 ; ACO
7145 ; EXPONENT RESULT
7146 ; FPS BEFORE EXECUTION
7147 ; FPS AFTER EXECUTION
7148 ;
7149 ;NO TRAPS CAN OCCUR
7150 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
7151 ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
7152 ;
7152 036154 012602 SXPSUB: MOV (SP),R2 ; RETURN ADDRESS TO USE AS POINTER
7153 036156 012737 036256 000244 MOV #508,#FPVEC ;REDIRECT TRAP VECTOR
7154 036164 012701 001126 MOV #RECDST,R1 ;POINT TO RESULT AREA
7155 036170 012700 000200 MOV #200,R0 ;SET FPS TO DOUBLE
7156 036174 170100 LDFPS R0 ;
7157 036176 010204 MOV R2,R4 ;POINT TO ACO DATA
7158 036200 172414 LDD (R4),ACO ;LOAD ACO
```

```

7159 036202 016200 000012          MOV    12(R2),R0          ;GET TEST FPS
7160 036206 170100                   LDFPS  R0                ;LOAD TEST FPS
7161                                     ;
7162 036210 175011                   40$:  STEXP  ACO,(R1)    ;*TEST INSTRUCTION(ACCORDING TO MODE)
7163                                     ;
7164                                     ;VERIFY STATUS
7165 036212 170203                   2$:  STFPS  R3                ;SAVE FPS
7166 036214 016200 000014          MOV    14(R2),R0          ;GET EXPECTED STATUS
7167 036220 020003                   CMP    R0,R3              ;VERIFY STATUS
7168 036222 001403                   BEQ    3$                  ;BRANCH IF GOOD
7169 036224 104000                   ERROR  3$                  ;ALL ERRORS TO TRAP TO EMT VECTOR
7170 036226 000511                   .WORD 511                  ;UNIQUE ERROR NUMBER
7171 036230 002013                   .WORD FPPERR              ;ADDRESS OF ERROR MESSAGE
7172                                     ;BAD FPS
7173 036232 016204 000010          3$:  MOV    10(R2),R4      ;POINT TO EXPECTED EXPONENT
7174 036236 020437 001126          CMP    R4,B@RECDST       ;VERIFY EXPONENT
7175 036242 001403                   BEQ    5$                  ;BRANCH IF GOOD
7176 036244 104000                   ERROR  5$                  ;ALL ERRORS TO TRAP TO EMT VECTOR
7177 036246 000512                   .WORD 512                  ;UNIQUE ERROR NUMBER
7178 036250 002013                   .WORD FPPERR              ;ADDRESS OF ERROR MESSAGE
7179                                     ;BAD ACO
7180 036252 000162 000016          5$:  JMP    16(R2)        ;RETURN FROM TEST
7181                                     ;
7182                                     ;INSTRUCTION TRAPPED
7183 036256 012600                   50$: MOV    (SP),R0        ;SAVE PC
7184 036260 012605                   MOV    (SP),R5            ;SAVE OLD PS
7185 036262 104000                   ERROR  5$                  ;ALL ERRORS TO TRAP TO EMT VECTOR
7186 036264 000513                   .WORD 513                  ;UNIQUE ERROR NUMBER
7187 036266 002013                   .WORD FPPERR              ;ADDRESS OF ERROR MESSAGE
7188                                     ;WILD TRAP DURING STEXP
7189 036270 000167 177756          JMP    5$                  ;REJOIN CODE
7190                                     ;
7191                                     ;
7192 036274                   HOP22:
7193
7194
    
```



```

7195 .MCALL IDMSG,ENDPAS
7196 .SBTTL END OF PASS ROUTINE
7197
7198 ;*****
7199 ;*INCREMENT THE PASS NUMBER ($PASS)
7200 ;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
7201 ;*IF THERES A MONITOR GO TO IT
7202 ;*IF THERE ISN'T JUMP TO RESTART
7203
7204 036274 $EOP:
7205 036274 005767 142506 TST $PASS ;ONLY TYPE MESSAGE AT END OF FIRST PASS
7206 036300 001002 BNE SKIPID ;IF >0 THEN SKIP THE ID MESSAGE
7207 036302 104401 036402 TYPE ,MSG1 ;ELSE TYPE THE ID MESSAGE
7208 036306
7209 036306 005267 142474 SKIPID: INC $PASS ;;INCREMENT THE PASS NUMBER
7210 036312 042767 100000 142466 BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
7211 036320 005327 DEC (PC), ;LOOP?
7212 036322 000001 $EOPCT: .WORD 1
7213 036324 003022 BGT $DOAGN ;;YES
7214 036326 012737 MOV (PC)+,$(PC), ;RESTORE COUNTER
7215 036330 000001 $ENDCT: .WORD 1
7216 036332 036322 $EOPCT
7217 036334 104401 036456 TYPE ,MSG2
7218 036340 016746 142442 MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
7219 036344 104405 TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
7220 036346 104401 036376 TYPE , $ENULL
7221 036352 013700 000042 $GET42: MOV $#42,RO ;;GET MONITOR ADDRESS
7222 036356 001405 BEQ $DOAGN ;;BRANCH IF NO MONITOR
7223 036360 000005 RESET ;;CLEAR THE WORLD
7224 036362 004710 $ENDAD: JSR PC,(RO) ;;GO TO MONITOR
7225 036364 000240 NOP ;;SAVE ROOM
7226 036366 000240 NOP ;;FOR
7227 036370 000240 NOP ;;ACT11
7228 036372
7229 036372 000137 $DOAGN: JMP $$(PC), ;RETURN
7230 036374 002410 $RTNAD: .WORD RESTART
7231 036376 377 377 000 $ENULL: .BYTE -1,-1,0 ;NULL CHARACTER STRING
7232 036402 .EVEN
7233 036402 005015 055103 042113 MSG1: .ASCIZ <CR><LF>/CZKDL-B-0 KDJ11 FLOATING POINT DIAGNOSTIC/
7234 036410 026514 026502 020060
7235 036416 042113 030512 020061
7236 036424 046106 040517 044524
7237 036432 043516 050040 044517
7238 036440 052116 042040 040511
7239 036446 047107 051517 044524
7240 036454 000103
7241 036456 005015 055103 042113 MSG2: .ASCIZ <CR><LF>/CZKDLB END PASS #/
7242 036464 041114 042440 042116
7243 036472 050040 051501 020123
7244 036500 000043
7245 .EVEN
7246 .SBTTL TYPE ROUTINE
7247
7248 ;*****
7249 ;*ROUTINE TO TYPE ASCIZ MESSAGE, MESSAGE MUST TERMINATE WITH A 0 BYTE.
7250 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
    
```

```

7251 ;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
7252 ;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
7253 ;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
7254 ;*
7255 ;*CALL:
7256 ;*1) USING A TRAP INSTRUCTION
7257 ;*      TYPE      ,MESADR          ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
7258 ;*OR
7259 ;*      TYPE
7260 ;*      MESADR
7261 ;*
7262 ;*
7263 036502 105767 000343 $TYPE: TSTB $TPFLG          ;; IS THERE A TERMINAL?
7264 036506 100002      BPL 1$          ;; BR IF YES
7265 036510 000000      HALT          ;; HALT HERE IF NO TERMINAL
7266 036512 000430      BR 3$          ;; LEAVE
7267 036514 010046      1$: MOV RO,-(SP)          ;; SAVE RO
7268 036516 017600 000002      MOV @2(SP),RO          ;; GET ADDRESS OF ASCIZ STRING
7269 036522 122767 000001 142270      CMPB @APTENV,$ENV          ;; RUNNING IN APT MODE
7270 036530 001011      BNE 62$          ;; NO,GO CHECK FOR APT CONSOLE
7271 036532 132767 000100 142261      BITB @APTSPOOL,$ENVM          ;; SPOOL MESSAGE TO APT
7272 036540 001405      BEQ 62$          ;; NO,GO CHECK FOR CONSOLE
7273 036542 010067 000004      MOV RO,61$          ;; SETUP MESSAGE ADDRESS FOR APT
7274 036546 004767 001034      JSR PC,$ATY3          ;; SPOOL MESSAGE TO APT
7275 036552 000000      61$: .WORD 0          ;; MESSAGE ADDRESS
7276 036554 132767 000040 142237 62$: BITB @APTCSUP,$ENVM          ;; APT CONSOLE SUPPRESSED
7277 036562 001003      BNE 60$          ;; YES,SKIP TYPE OUT
7278 036564 112046      2$: MOVB (RO),-(SP)          ;; PUSH CHARACTER TO BE TYPED ONTO STACK
7279 036566 001005      BNE 4$          ;; BR IF IT ISN'T THE TERMINATOR
7280 036570 005726      TST (SP),          ;; IF TERMINATOR POP IT OFF THE STACK
7281 036572 012600      60$: MOV (SP),RO          ;; RESTORE RO
7282 036574 062716 000002      3$: ADD @2,(SP)          ;; ADJUST RETURN PC
7283 036600 000002      RTI          ;; RETURN
7284 036602 122716 000011      4$: CMPB @HT,(SP)          ;; BRANCH IF <HT>
7285 036606 001430      BEQ 8$          ;;
7286 036610 122716 000200      CMPB @CRLF,(SP)          ;; BRANCH IF NOT <CRLF>
7287 036614 001006      BNE 5$          ;;
7288 036616 005726      TST (SP),          ;; POP <CR><LF> EQUIV
7289 036620 104401      TYPE          ;; TYPE A CR AND LF
7290 036622 002077      @CRLF
7291 036624 105067 000202      CLRB $CHARCNT          ;; CLEAR CHARACTER COUNT
7292 036630 000755      BR 2$          ;; GET NEXT CHARACTER
7293 036632 004767 000056      5$: JSR PC,$TYPEC          ;; GO TYPE THIS CHARACTER
7294 036636 126726 000206      6$: CMPB $FILLC,(SP),          ;; IS IT TIME FOR FILLER CHARS.?
7295 036642 001350      BNE 2$          ;; IF NO GO GET NEXT CHAR.
7296 036644 016746 000176      MOV $NULL,-(SP)          ;; GET # OF FILLER CHARS. NEEDED
7297 ;*AND THE NULL CHAR.
7298 036650 105366 000001      7$: DECB 1(SP)          ;; DOES A NULL NEED TO BE TYPED?
7299 036654 002770      BLT 6$          ;; BR IF NO--GO POP THE NULL OFF OF STACK
7300 036656 004767 000032      JSR PC,$TYPEC          ;; GO TYPE A NULL
7301 036662 105367 000144      DECB $CHARCNT          ;; DO NOT COUNT AS A COUNT
7302 036666 000770      BR 7$          ;; LOOP
7303 ;*
7304 ;*HORIZONTAL TAB PROCESSOR
7305 ;*
7306 036670 112716 000040      8$: MOVB @' ,(SP)          ;; REPLACE TAB WITH SPACE
    
```

```

7307 036674 004767 000014 9$: JSR PC,$TYPEC ;;TYPE A SPACE
7308 036700 132767 000007 000124 BITB 47,$CHARCNT ;;BRANCH IF NOT AT
7309 036706 001372 BNE 9$ ;;TAB STOP
7310 036710 005726 TST (SP), ;;POP SPACE OFF STACK
7311 036712 000724 BR 2$ ;;GET NEXT CHARACTER
7312 036714 $TYPEC:
7313 036714 105777 000116 TSTB 0$TKS ;;CHAR IN KYBD BUFFER? ;MJD001
7314 036720 100022 BPL 10$ ;;BR IF NOT ;MJD001
7315 036722 017746 000112 MOV 0$TKB,-(SP) ;;GET CHAR ;MJD001
7316 036726 042716 177600 BIC 0177600,(SP) ;;STRIP EXTRANEIOUS BITS ;MJD001
7317 036732 122716 000023 CMPB 0$XOFF,(SP) ;;WAS CHAR XOFF ;MJD001
7318 036736 001012 BNE 102$ ;;BR IF NOT ;MJD001
7319 036740 101$:
7320 036740 105777 000072 TSTB 0$TKS ;;WAIT FOR CHAR ;MJD001
7321 036744 100375 BPL 101$ ;MJD001
7322 036746 117716 000066 MOVB 0$TKB,(SP) ;;GET CHAR ;MJD001
7323 036752 042716 177600 BIC 0177600,(SP) ;;STRIP IT ;MJD001
7324 036756 122716 000021 CMPB 0$XON,(SP) ;;WAS IT XON? ;MJD001
7325 036762 001366 BNE 101$ ;;BR IF NOT ;MJD001
7326 036764 102$:
7327 036764 005726 TST (SP), ;;FIX STACK ;MJD001
7328 036766 10$:
7329 036766 105777 000050 TSTB 0$TPS ;;WAIT UNTIL PRINTER IS READY ;MJD001
7330 036772 100375 BPL 10$ ;MJD001
7331 036774 116677 000002 000042 MOVB 2(SP),0$TPB ;;LOAD CHAR TO BE TYPED INTO DATA REG. ;MJD001
7332 037002 122766 000015 000002 CMPB 0$CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
7333 037010 001003 BNE 1$ ;;BRANCH IF NO
7334 037012 105067 000014 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
7335 037016 000406 BR $TYPEX ;;EXIT
7336 037020 122766 000012 000002 1$: CMPB 0$LF,2(SP) ;;IS CHARACTER A LINE FEED?
7337 037026 001402 BZQ $TYPEX ;;BRANCH IF YES
7338 037030 105227 INCB (PC), ;;COUNT THE CHARACTER
7339 037032 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
7340 037034 000207 $TYPEX: RTS PC
7341
7342 037036 177560 $TKS: .WORD 177560 ;;TTY KDB STATUS ;MJD001
7343 037040 177562 $TKB: .WORD 177562 ;;TTY KDB BUFFER ;MJD001
7344 037042 177564 $TPS: .WORD 177564 ;;TTY PRINTER STATUS REG. ADDRESS
7345 037044 177566 $TPB: .WORD 177566 ;;TTY PRINTER BUFFER REG. ADDRESS
7346 037046 000 $NULL: .BYTE 0 ;;CONTAINS NULL CHARACTER FOR FILLS
7347 037047 002 $FILLS: .BYTE 2 ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
7348 037050 012 $FILLC: .BYTE 12 ;;INSERT FILL CHARS. AFTER A "LINE FEED"
7349 037051 000 $TPFLG: .BYTE 0 ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
7350 037052 077 $QUES: .ASCII "?" ;;QUESTION MARK
7351 037053 012 000 $LF: .ASCIZ <12> ;;LINEFEED
7352 037056 .EVEN
7353 .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
7354
7355 ;;*****
7356 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
7357 ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
7358 ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
7359 ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
7360 ;*REPLACED WITH SPACES.
7361 ;*CALL:
7362 ;* MOV NUM,-(SP) ;;PUT THE BINARY NUMBER ON THE STACK
    
```

```

7363 ;* TYPDS ;:GO TO THE ROUTINE
7364
7365 037056 $TYPDS:
7366 037056 010046 MOV R0,-(SP) ;:PUSH R0 ON STACK
7367 037060 010146 MOV R1,-(SP) ;:PUSH R1 ON STACK
7368 037062 010246 MOV R2,-(SP) ;:PUSH R2 ON STACK
7369 037064 010346 MOV R3,-(SP) ;:PUSH R3 ON STACK
7370 037066 010546 MOV R5,-(SP) ;:PUSH R5 ON STACK
7371 037070 012746 020200 MOV #20200,-(SP) ;:SET BLANK SWITCH AND SIGN
7372 037074 016605 000020 MOV 20(SP),R5 ;:GET THE INPUT NUMBER
7373 037100 100004 BPL 1# ;:BR IF INPUT IS POS.
7374 037102 005405 NEG R5 ;:MAKE THE BINARY NUMBER POS.
7375 037104 112766 000055 000001 MOVB #'-.1(SP) ;:MAKE THE ASCII NUMBER NEG.
7376 037112 005000 1#: CLR R0 ;:ZERO THE CONSTANTS INDEX
7377 037114 012703 037272 MOV #DBLK,R3 ;:SETUP THE OUTPUT POINTER
7378 037120 112723 000040 MOVB #' ,(R3)+ ;:SET THE FIRST CHARACTER TO A BLANK
7379 037124 005002 2#: CLR R2 ;:CLEAR THE BCD NUMBER
7380 037126 016001 037262 MOV $DTBL(R0),R1 ;:GET THE CONSTANT
7381 037132 160105 3#: SUB R1,R5 ;:FORM THIS BCD DIGIT
7382 037134 002402 BLT 4# ;:BR IF DONE
7383 037136 005202 INC R2 ;:INCREASE THE BCD DIGIT BY 1
7384 037140 000774 BR 3#
7385 037142 060105 4#: ADD R1,R5 ;:ADD BACK THE CONSTANT
7386 037144 005702 TST R2 ;:CHECK IF BCD DIGIT=0
7387 037146 001002 BNE 5# ;:FALL THROUGH IF 0
7388 037150 105716 TSTB (SP) ;:STILL DOING LEADING 0'S?
7389 037152 100407 BMI 7# ;:BR IF YES
7390 037154 106316 5#: ASLB (SP) ;:MSD?
7391 037156 103003 BCC 6# ;:BR IF NO
7392 037160 116663 000001 177777 MOVB 1(SP),-1(R3) ;:YES--SET THE SIGN
7393 037166 052702 000060 6#: BIS #'0,R2 ;:MAKE THE BCD DIGIT ASCII
7394 037172 052702 000040 7#: BIS #' ,R2 ;:MAKE IT A SPACE IF NOT ALREADY A DIGIT
7395 037176 110223 MOVB R2,(R3)+ ;:PUT THIS CHARACTER IN THE OUTPUT BUFFER
7396 037200 005720 TST (R0)+ ;:JUST INCREMENTING
7397 037202 020027 000010 CMP R0,#10 ;:CHECK THE TABLE INDEX
7398 037206 002746 BLT 2# ;:GO DO THE NEXT DIGIT
7399 037210 003002 BGT 8# ;:GO TO EXIT
7400 037212 010502 MOV R5,R2 ;:GET THE LSD
7401 037214 000764 BR 6# ;:GO CHANGE TO ASCII
7402 037216 105726 8#: TSTB (SP)+ ;:WAS THE LSD THE FIRST NON-ZERO?
7403 037220 100003 BPL 9# ;:BR IF NO
7404 037222 116663 177777 177776 MOVB -1(SP),-2(R3) ;:YES--SET THE SIGN FOR TYPING
7405 037230 105013 9#: CLRB (R3) ;:SET THE TERMINATOR
7406 037232 012605 MOV (SP)+,R5 ;:POP STACK INTO R5
7407 037234 012603 MOV (SP)+,R3 ;:POP STACK INTO R3
7408 037236 012602 MOV (SP)+,R2 ;:POP STACK INTO R2
7409 037240 012601 MOV (SP)+,R1 ;:POP STACK INTO R1
7410 037242 012600 MOV (SP)+,R0 ;:POP STACK INTO R0
7411 037244 104401 037272 TYPE ,#DBLK ;:NOW TYPE THE NUMBER
7412 037250 016666 000002 000004 MOV 2(SP),4(SP) ;:ADJUST THE STACK
7413 037256 012616 MOV (SP)+,(SP)
7414 037260 000002 RTI ;:RETURN TO USER
7415 037262 023420 $DTBL: 10000.
7416 037264 001750 1000.
7417 037266 000144 100.
7418 037270 000012 10.

```

```

7419 037272 000004      $DBLK: .BLKW 4
7420                      .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
7421
7422                      ;;*****
7423                      ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
7424                      ;*OCTAL (ASCII) NUMBER AND TYPE IT.
7425                      ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
7426                      ;*CALL:
7427                      ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
7428                      ;*      TYPOS      ;;CALL FOR TYPEOUT
7429                      ;*      .BYTE  N      ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
7430                      ;*      .BYTE  M      ;;M=1 OR 0
7431                      ;*
7432                      ;*      ;;1=TYPE LEADING ZEROS
7433                      ;*      ;;0=SUPPRESS LEADING ZEROS
7434                      ;*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
7435                      ;*$TYPOS OR $TYPOC
7436                      ;*CALL:
7437                      ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
7438                      ;*      TYPON      ;;CALL FOR TYPEOUT
7439                      ;*
7440                      ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
7441                      ;*CALL:
7442                      ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
7443                      ;*      TYPOC      ;;CALL FOR TYPEOUT
7444
7445 037302 017646 000000  $TYPOS: MOV      @(SP),-(SP)      ;;PICKUP THE MODE
7446 037306 116667 000001 000211  MOVB     1(SP),#OFILL  ;;LOAD ZERO FILL SWITCH
7447 037314 112667 000207      MOVB     (SP),#OMODE+1  ;;NUMBER OF DIGITS TO TYPE
7448 037320 062716 000002      ADD      #2,(SP)      ;;ADJUST RETURN ADDRESS
7449 037324 000406      BR       $TYPON
7450 037326 112767 000001 000171  $TYPOC: MOVB     #1,#OFILL  ;;SET THE ZERO FILL SWITCH
7451 037334 112767 000006 000165  MOVB     #6,#OMODE+1  ;;SET FOR SIX(6) DIGITS
7452 037342 112767 000005 000154  $TYPON: MOVB     #5,#OCNT  ;;SET THE ITERATION COUNT
7453 037350 010346      MOV      R3,-(SP)      ;;SAVE R3
7454 037352 010446      MOV      R4,-(SP)      ;;SAVE R4
7455 037354 010546      MOV      R5,-(SP)      ;;SAVE R5
7456 037356 116704 000145      MOVB     #OMODE+1,R4  ;;GET THE NUMBER OF DIGITS TO TYPE
7457 037362 005404      NEG      R4
7458 037364 062704 000006      ADD      #6,R4      ;;SUBTRACT IT FOR MAX. ALLOWED
7459 037370 110467 000132      MOVB     R4,#OMODE  ;;SAVE IT FOR USE
7460 037374 116704 000125      MOVB     #OFILL,R4  ;;GET THE ZERO FILL SWITCH
7461 037400 016605 000012      MOV      12(SP),R5  ;;PICKUP THE INPUT NUMBER
7462 037404 005003      CLR      R3      ;;CLEAR THE OUTPUT WORD
7463 037406 006105      1#:     ROL      R5      ;;ROTATE MSB INTO "C"
7464 037410 000404      BR       3#
7465 037412 006105      2#:     ROL      R5      ;;GO DO MSB
7466 037414 006105      ROL      R5      ;;FORM THIS DIGIT
7467 037416 006105      ROL      R5
7468 037420 010503      MOV      R5,R3
7469 037422 006103      3#:     ROL      R3      ;;GET LSR OF THIS DIGIT
7470 037424 105367 000076      DECB     #OMODE      ;;TYPE THIS DIGIT?
7471 037430 100016      BPL      7#      ;;BR IF NO
7472 037432 042703 177770      BIC      #177770,R3  ;;GET RID OF JUNK
7473 037436 001002      BNE      4#      ;;TEST FOR 0
7474 037440 005704      TST     R4      ;;SUPPRESS THIS 0?
    
```

111

```

7475 037442 001403          BEQ      5$          ;;BR IF YES
7476 037444 005204          4$: INC      R4          ;;DON'T SUPPRESS ANYMORE 0'S
7477 037446 052703 000060   BIS      #'0,R3      ;;MAKE THIS DIGIT ASCII
7478 037452 052703 000040   5$: BIS      #' ,R3    ;;MAKE ASCII IF NOT ALREADY
7479 037456 110367 000040   MOVB     R3,8$       ;;SAVE FOR TYPING
7480 037462 104401 037522   TYPE     .8$        ;;GO TYPE THIS DIGIT
7481 037466 105367 000032   7$: DECB    $OCNT    ;;COUNT BY 1
7482 037472 003347          BGT      2$          ;;BR IF MORE TO DO
7483 037474 002402          BLT      6$          ;;BR IF DONE
7484 037476 005204          INC      R4          ;;INSURE LAST DIGIT ISN'T A BLANK
7485 037500 000744          BR       2$          ;;GO DO THE LAST DIGIT
7486 037502 012605          6$: MOV     (SP)+,R5  ;;RESTORE R5
7487 037504 012604          MOV     (SP)+,R4    ;;RESTORE R4
7488 037506 012603          MOV     (SP)+,R3    ;;RESTORE R3
7489 037510 016666 000002 000004  MOV     2(SP),4(SP)  ;;SET THE STACK FOR RETURNING
7490 037516 012616          MOV     (SP)+,(SP)
7491 037520 000002          RTI          ;;RETURN
7492 037522 000          8$: .BYTE   0          ;;STORAGE FOR ASCII DIGIT
7493 037523 000          .BYTE   0          ;;TERMINATOR FOR TYPE ROUTINE
7494 037524 000          $OCNT: .BYTE   0          ;;OCTAL DIGIT COUNTER
7495 037525 000          $OFILL: .BYTE  0          ;;ZERO FILL SWITCH
7496 037526 000000          $OMODE: .WORD  0          ;;NUMBER OF DIGITS TO TYPE
7497          .SBTTL TRAP DECODER
7498
7499
7500          ;;*****
7501          ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7502          ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7503          ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7504          ;*GO TO THAT ROUTINE.
7505 037530 010046          $TRAP: MOV     RO,-(SP)  ;;SAVE RO
7506 037532 016600 000002   MOV     2(SP),RO     ;;GET TRAP ADDRESS
7507 037536 005740          TST     -(RO)        ;;BACKUP BY 2
7508 037540 111000          MOVB    (RO),RO     ;;GET RIGHT BYTE OF TRAP
7509 037542 006300          ASL     RO          ;;POSITION FOR INDEXING
7510 037544 016000 037564   MOV     $TRPAD(RO),RO ;;INDEX TO TABLE
7511 037550 000200          RTS      RO          ;;GO TO ROUTINE
7512
7513
7514          ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
7515
7516 037552 011646          $TRAP2: MOV    (SP),-(SP) ;;MOVE THE PC DOWN
7517 037554 016666 000004 000002  MOV    4(SP),2(SP)    ;;MOVE THE PSW DOWN
7518 037562 000002          RTI          ;;RESTORE THE PSW
7519
7520          .MACRO SETTRAP A,B,MSG
7521          ;;SET A,B,\<TRAP>,$TRP>,\$TRP,<MSG>
7522          .NLIST
7523          $TRP=$TRP+1
7524          .LIST
7525          .ENDM SETTRAP
7526          .MACRO $$SET A,B,C,D,COMNT
7527          .IF EQ $TRP-1
7528          .SBTTL TRAP TABLE
7529
7530          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED

```

```

7531      ;*BY THE "TRAP" INSTRUCTION.
7532
7533      :      ROUTINE
7534      :      -----
7535      $TRPAD: .WORD      $TRAP2
7536      .ENDC
7537      .IIF NDF GNS,.NLIST
7538      A=      C
7539      .IIF NDF GNS,.LIST
7540      B      ;:CALL=A      TRAP+D(C)      COMNT
7541      .ENDM $$SET
7542      .MACRO TRMTRP
7543      $TERM=.-$TRPAD
7544      .ENDM TRMTRP
7545      .SBTTL TRAP TABLE
7546
7547      ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
7548      ;*BY THE "TRAP" INSTRUCTION.
7549
7550      :      ROUTINE
7551      :      -----
7552      $TRPAD: .WORD      $TRAP2
7553      $TYPE   ;:CALL=TYPE      TRAP+1(104401) TTY TYPEOUT ROUTINE
7554      $TYPOC  ;:CALL=TYPOC     TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
7555      $TYPOS  ;:CALL=TYPOS     TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
7556      $TYPON  ;:CALL=TYPON     TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
7557      $TYPDS  ;:CALL=TYPDS     TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
7558
7559
7560      .SBTTL APT COMMUNICATIONS ROUTINE
7561
7562      ;:*****
7563      037600 112767 000001 000236 $ATY1: MOVB #1,$FFLG ;:TO REPORT FATAL ERROR
7564      037606 112767 000001 000226 $ATY3: MOVB #1,$MFLG ;:TO TYPE A MESSAGE
7565      037614 000403
7566      037616 112767 000001 000220 $ATY4: MOVB #1,$FFLG ;:TO ONLY REPORT FATAL ERROR
7567      037624
7568      037624 010046
7569      037626 010146
7570      037630 105767 000206
7571      037634 001450
7572      037636 122767 000001 141154
7573      037644 001031
7574      037646 132767 000100 141145
7575      037654 001425
7576      037656 017600 000004
7577      037662 062766 000002 000004
7578      037670 005767 141104 1$: TST $MSGTYPE ;:SEE IF DONE W/ LAST XMISSION?
7579      037674 001375
7580      037676 010067 141112
7581      037702 105720
7582      037704 001376 2$: TSTB (RO), ;:FIND END OF MESSAGE
7583      037706 166700 141102
7584      037712 006200
7585      037714 010067 141076
7586      037720 012767 000004 141052

```

```

7587 037726 000413          BR          5$
7588 037730 017667 000004 000016 3$:  MOV      @4(SP),4$      ;;PUT MSG ADDR IN JSR LINKAGE
7589 037736 062766 000002 000004      ADD      @2,4(SP)      ;;BUMP RETURN ADDRESS
7590 037744 016746 140026      MOV      177776,-(SP)  ;;PUSH 177776 ON STACK
7591 037750 004767 176526      JSR      PC,$TYPE     ;;CALL TYPE MACRO
7592 037754 000000          .WORD    0
7593 037756          4$:
7594 037756 105767 000062          5$:
7595 037762 001416          10$:  TSTB     $FFLG      ;;SHOULD REPORT FATAL ERROR?
7596 037764 005767 141030      BEQ      12$        ;;IF NOT: BR
7597 037770 001413          TST      $ENV       ;;RUNNING UNDER APT?
7598 037772 005767 141002      BEQ      12$        ;;IF NOT: BR
7599 037776 001375          11$:  TST      $MSGTYPE   ;;FINISHED LAST MESSAGE?
7600 040000 017667 000004 140774      BNE      11$        ;;IF NOT: WAIT
7601 040006 062766 000002 000004      MOV      @4(SP),$FATAL ;;GET ERROR #
7602 040014 005267 140760      ADD      @2,4(SP)      ;;BUMP RETURN ADDR.
7603 040020 105067 000020          INC      $MSGTYPE   ;;TELL APT TO TAKE ERROR
7604 040024 105067 000013          12$:  CLRB     $FFLG      ;;CLEAR FATAL FLAG
7605 040030 105067 000006      CLRB     $LFLG      ;;CLEAR LOG FLAG
7606 040034 012601          CLRB     $MFLG      ;;CLEAR MESSAGE FLAG
7607 040036 012600          MOV      (SP)+,R1    ;;POP STACK INTO R1
7608 040040 000207          MOV      (SP)+,R0    ;;POP STACK INTO R0
7609 040042 000          RTS      PC         ;;RETURN
7610 040043 000          $MFLG: .BYTE 0      ;;MESSG. FLAG
7611 040044 000          $LFLG: .BYTE 0      ;;LOG FLAG
7612          040046          $FFLG: .BYTE 0      ;;FATAL FLAG
7613          000200          .EVEN
7614          000001  APTSIZE=200
7615          000100  APTENV=001
7616          000040  APTSPool=100
7617          APTCSUP=040
7618          ;;*****
7619          ;THIS ROUTINE WILL INCREMENT THE ERROR COUNT AND THEN PASS THE UNIQUE
7620          ;ERROR NUMBER TO THE APT ERROR ROUTINE TO BE REPORTED TO THE APT SYSTEM.
7621 040046 005267 141000          $ERROR: INC      $ERFLG      ;;INCREMENT ERROR FLAG
7622 040052 001775          BEQ      $ERROR      ;;DON'T LET IT GO TO ZERO
7623 040054 005267 140764          INC      ERRCNT     ;;INCREMENT THE ERROR COUNT
7624 040060 021627 001002          CMP      (SP), @1002 ;;IS ERROR FROM VECTOR AREA
7625 040064 101010          BHI      1$         ;;IF YES THEN
7626 040066 012767 007777 000106      MOV      @7777, 3$   ;;REPORT AN UNEXPECTED TRAP
7627 040074 012637 001062          MOV      (SP)+,@$SAVSP1 ;;SAVE UNEXPECTED TRAP DATA
7628 040100 012637 001064          MOV      (SP)+,@$SAVSP2 ;;AND RESTORE SP
7629 040104 000430          BR       2$         ;;ELSE
7630 040106 017667 000000 000066 1$:  MOV      @4(SP), 3$   ;;REPORT UNIQUE ERROR NUMBER TO APT
7631 040114 011667 000072          MOV      (SP),101$  ;;SAVE ERROR PC
7632 040120 062716 000002          ADD      @2,(SP)    ;;GET OVER UNIQUE ERROR NUMBER FOR RETURN
7633 040124 017637 000000 040134 100$: MOV      @4(SP),@102$
7634 040132 104401          TYPE
7635 040134 000000          102$: .WORD 0      ;;TYPE ERROR MESSAGE
7636 040136 062716 000002          ADD      @2,(SP)    ;;GET OVER ERROR MESSAGE
7637 040142 104401 002046          TYPE      ,ERR1    ;;
7638 040146 016746 000030          MOV      3$,-(SP)  ;;PUSH UNIQUE ERROR NUMBER ON THE STACK
7639 040152 104402          TYPOC
7640 040154 104401 002062          TYPE      ,ERR2    ;;TYPE OCTAL ERROR NUMBER
7641 040160 016746 000026          MOV      101$,-(SP) ;;PUSH ERROR PC ON THE STACK
7642 040164 104402          TYPOC
    
```



```
7643 040166 122767 000001 140624 2: CMPB @APTENV,%ENV
7644 040174 001004 BNE 5:
7645 040176 004767 177414 JSR PC,%ATY4
7646 040202 000000 3: .WORD 0
7647 040204 000777 4: BR 4:
7648 040206 000000 5: HALT
7649 040210 000002 RTI
7650 040212 000000 101: .WORD 0
7651 040214 $PATCH:
7652 040214 000010 .BLKW 10
7653 000001 .END
```

```
;CHECK TO MAKE SURE WE'RE IN APT MODE
;IF YES THEN
;GO REPORT ERROR TO APT
;STORAGE FOR ERROR NUMBER
;LOOP HERE AFTER REPORTING ERROR TO APT
;IF NOT APT THEN HALT
;ALLOW RECOVERY FROM HALT
```

ABASE = 000000	547					
ACDW1 = 000000	547					
ACDW2 = 000000	547					
ACPUOP = 000000	547	562				
ADDT 003556	1083	1091	1099	1107	1116	11320
ADDW0 = 000000	547					
ADDW1 = 000000	547					
ADDW10 = 000000	547					
ADDW11 = 000000	547					
ADDW12 = 000000	547					
ADDW13 = 000000	547					
ADDW14 = 000000	547					
ADDW15 = 000000	547					
ADDW2 = 000000	547					
ADDW3 = 000000	547					
ADDW4 = 000000	547					
ADDW5 = 000000	547					
ADDW6 = 000000	547					
ADDW7 = 000000	547					
ADDW8 = 000000	547					
ADDW9 = 000000	547					
ADEVCT = 000000	547	553				
ADEVN = 000000	547					
AENV = 000000	547	558				
AENVN = 000000	547	559				
AFATAL = 000000	547	550				
ALLCTR 001056	5890					
AMADR1 = 000000	547					
AMADR2 = 000000	547					
AMADR3 = 000000	547					
AMADR4 = 000000	547					
AMAMS1 = 000000	547					
AMAMS2 = 000000	547					
AMAMS3 = 000000	547					
AMAMS4 = 000000	547					
AMSGAD = 000000	547	555				
AMSGLG = 000000	547	556				
AMSGTY = 000000	547	549				
AMTYP1 = 000000	547					
AMTYP2 = 000000	547					
AMTYP3 = 000000	547					
AMTYP4 = 000000	547					
APASS = 000000	547	552				
APRIOR = 000000	547					
APTCSU = 000040	7276	76160				
APTENV = 000001	7269	7572	76140	7643		
APTSIZ = 000200	867	76130				
APTSP0 = 000100	7271	7574	76150			
ASWREG = 000000	547	560				
ATESTN = 000000	547	551				
AUNIT = 000000	547	554				
AUSWR = 002000	4660	547	561			
AVECT1 = 000000	547					
AVECT2 = 000000	547					
BEVENT = 177546	4580					
BFA 003610	1077	1085	1093	1101	1110	1119 11380

CHEK7	005136	1497	1503											
CHK10	005404	1569	1574											
CHK7	005150	1498	1503											
CH10	005372	1568	1574											
CLRD =	***** U	5809												
CLRI =	***** U	5840												
CMPD =	***** U	4039												
CMPRTN	017730	4047	4056	4065	4073	4095								
COUNT	001040	581	817	822	823	2919	2964	3004	3040	3070	3106	3144	3175	3194
		3211	3229	3263	3282	3313	3332	3357	3371	3403	3415	3431	3444	3476
		3512	3550	3575	3597	3619	3651	3670	3697	3711	3742	3780	3805	3843
		3868	3906	3938	3968	4006	4030	4122	4361	4560	4779	4987	5206	5217
		5506	5517	5622	5762	5824	6191	6369	6498	6797	7026			
CPEREG=	177766	455												
CPUTST=	000001	1	166	509	603	756	877	7233						
CR =	000015	194	752	756	761	763	766	7233	7241	7332	7344			
CRLF =	000200	195	7286	7344										
DATRAM=	000001	1	874											
DATVER	002146	820	2918	2963	3003	3039	3069	3105	3143	3174	3193	3210	3228	3262
		3281	3312	3331	3356	3370	3402	3414	3430	3443	3475	3511	3549	3574
		3596	3618	3650	3669	3696	3710	3741	3779	3804	3842	3867	3905	3937
		3967	4005	4029	4121	4559	4986	5505	5516	5621	5823	6190	6497	6796
DATVFR	002130	815	4360	4778	5205	5216	5761	6368	7025					
DAT1	002160	818	823	826										
DCOUNT	001054	588												
DDISP =	177570	201	585	848										
DISPLA	001050	585	848	856										
DISPRE	000174	495	856											
DIVD =	***** U	4381												
DIVF =	***** U	4133												
DSWR =	177570	200	584	847										
DVDSUB	022000	4389	4401	4413	4424	4435	4446	4457	4468	4480	4506			
DVFSUB	021002	4141	4151	4160	4168	4177	4185	4193	4201	4209	4217	4225	4233	4241
		4250	4258	4267	4276	4285	4307							
D1	004236	1275	1291	1296										
D2	004250	1278	1279											
D3	004252	1280	1304											
D4	004270	1288	1325	1331										
D5	004304	1289	1292											
D6	004314	1293	1295											
D7	004320	1294	1297											
EMTVEC=	000030	289	836	837										
ERR	002126	794												
ERRCNT	001044	583	7623											
ERRFP	002124	793												
ERRMSG	001766 G	752												
ERRNUM=	000514	465	785	788	941	945	956	959	965	968	974	977	983	986
		993	996	1003	1006	1079	1082	1087	1090	1095	1098	1103	1106	1112
		1115	1121	1124	1175	1178	1208	1211	1228	1231	1236	1239	1246	1249
		1254	1257	1284	1287	1306	1309	1314	1317	1326	1330	1333	1337	1340
		1344	1364	1367	1371	1374	1380	1384	1404	1407	1412	1415	1421	1424
		1429	1432	1448	1452	1499	1502	1506	1510	1570	1573	1577	1581	1616
		1619	1623	1626	1652	1655	1658	1661	1685	1688	1692	1695	1699	1702
		1708	1712	1737	1740	1745	1748	1752	1755	1761	1765	1791	1794	1798
		1801	1805	1808	1813	1816	1820	1823	1829	1833	1858	1861	1865	1868
		1873	1876	1880	1883	1889	1893	1919	1922	1925	1928	1932	1935	1940

STACK = 001000	187#	834							
START 002200	492	498	831#						
STBOT = 001000	470#								
STKLMT = 177774	198#								
SUBT 003524	1064	1067	1069	1071	1073	1127#			
SWR 001046	584#	847*	849	855*	869*				
SWREG 000176	496#	855							
SW0 = 000001	251#								
SW00 = 000001	241#	251							
SW01 = 000002	240#	250							
SW02 = 000004	239#	249							
SW03 = 000010	238#	248							
SW04 = 000020	237#	247							
SW05 = 000040	236#	246							
SW06 = 000100	235#	245							
SW07 = 000200	234#	244							
SW08 = 000400	233#	243							
SW09 = 001000	232#	242							
SW1 = 000002	250#								
SW10 = 002000	231#								
SW11 = 004000	230#								
SW12 = 010000	229#								
SW13 = 020000	228#								
SW14 = 040000	227#								
SW15 = 100000	226#								
SW2 = 000004	249#								
SW3 = 000010	248#								
SW4 = 000020	247#								
SW5 = 000040	246#								
SW6 = 000100	245#								
SW7 = 000200	244#								
SW8 = 000400	243#								
SW9 = 001000	242#								
SXP = ***** U	7089								
SXPSUB 036154	7096	7103	7110	7117	7124	7131	7152#		
TAB1 001176	610#	2898	2910	2916	3020	3038	3086	3104	3299
TAB10 001326	652#	3390	3429						
TAB11 001336	656#	3388							
TAB11A 001346	660#	3401							
TAB12 001356	662#	3409							
TAB13 001366	664#								
TAB13B 001376	668#	3412							
TAB14 001406	670#	3422	3657						
TAB15 001416	674#	3423							
TAB16 001426	678#	3437	3948						
TAB17 001436	682#	3442							
TAB18 001446	685#	3330							
TAB2 001206	614#	2936	2961	3055	3246				
TAB21 001456	689#	3462	3483	3520	3637				
TAB22 001466	691#	3474							
TAB23 001476	693#	3484	3519						
TAB24 001506	695#	3510	3548						
TAB25 001516	697#	3558	3582						
TAB26 001526	699#	3557	3583						
TAB27 001536	701#	3573	3595						
TAB28 001546	703#	3605							

TST21	006572	19020		
TST22	007006	19690		
TST23	007206	20300		
TST24	007430	20970		
TST25	007616	21520		
TST26	007754	21970		
TST27	010156	22580		
TST3	003650	11560		
TST30	010320	23060		
TST31	010720	24210		
TST32	011264	25290		
TST33	011632	26360		
TST34	011774	26870		
TST35	012270	27740		
TST36	012566	28610		
TST37	012656	28950		
TST4	003742	11860		
TST40	012764	29320		
TST41	013124	29760		
TST42	013250	30160		
TST43	013360	30520		
TST44	013460	30820		
TST45	013566	31180		
TST46	013700	31560		
TST47	014164	32420		
TST5	004044	12190		
TST50	014342	32950		
TST51	014510	33450		
TST52	014634	33840		
TST53	015104	34580		
TST54	015720	36330		
TST55	016066	36830		
TST56	016212	37230		
TST57	017120	39190		
TST6	004164	12650		
TST60	017542	40430		
TST61	020056	41370		
TST62	021244	43850		
TST63	022242	45840		
TST64	023304	48030		
TST65	024336	50110		
TST66	025436	52440		
TST67	027136	55410		
TST7	004444	13520		
TST70	027456	56430		
TST71	030144	57870		
TST72	030214	58130		
TST73	030306	58440		
TST74	030356	58700		
TST75	030474	59110		
TST76	030612	59520		
TST77	030746	59950		
TS10D1	005420	1538	1550	15840
TS10D2	005430	1540	1547	15880
TS10D4	005440	1558	15920	
TS11D1	005550	1607	16320	

UIPAR1= 177642	332#				
UIPAR2= 177644	333#				
UIPAR3= 177646	334#				
UIPAR4= 177650	335#				
UIPAR5= 177652	336#				
UIPAR6= 177654	337#				
UIPAR7= 177656	338#				
UIPDR0= 177600	309#				
UIPDR1= 177602	310#				
UIPDR2= 177604	311#				
UIPDR3= 177606	312#				
UIPDR4= 177610	313#				
UIPDR5= 177612	314#				
UIPDR6= 177614	315#				
UIPDR7= 177616	316#				
UVAD = ***** U	3719				
WLDTRP 002106	783#	3789	3852		
XBUF = 177566	462#				
XCSR = 177564	461#				
XDF1 = ***** U	3380				
\$APTHD 000204	518	524#			
\$ASTAT= ***** U	7594	7609			
\$ATYC 037624	7565	7567#			
\$ATY1 037600	7563#				
\$ATY3 037606	7274	7564#			
\$ATY4 037616	7566#	7645			
\$CHARC 037032	7291*	7301*	7308	7334*	7339#
\$CKSWR= ***** U	7560				
\$CMTAG= ***** U	834	840	842		
\$CPUOP 001026	562#				
\$CRLF 002077	766#	7290	7351		
\$DBLK 037272	7377	7411	7419#		
\$DEVCT 001010	553#				
\$DOAGN 036372	7213	7222	7228#		
\$DTBL 037262	7380	7415#			
\$ENDAD 036362	505	7224#			
\$ENDCT 036330	841	7215#			
\$ENULL 036376	7220	7231#			
\$ENV 001020	558#	7269	7572	7596	7643
\$ENVM 001021	559#	867	7271	7276	7574
\$EOP 036274	7204#				
\$EOPCT 036322	841*	7212#	7216		
\$ERFLG 001052	586#	842*	7621*		
\$ERROR 040046	836	871	7621#	7622	
\$ETABL 001020	557#				
\$ETEND 001030	530	569#			
\$FATAL 001002	550#	7600*			
\$FFLG 040044	7563*	7566*	7594	7603*	7611#
\$FILLC 037050	7294	7348#			
\$FILLS 037047	7347#				
\$GET42 036352	7221#				
\$GTSWR= ***** U	7559				
\$HD = 000003	175	176			
\$HIBTS 000204	525#				
\$LF 037053	7351#				
\$LFLG 040043	7604*	7610#			

\$MAIL	001000	526	530	548#	859	7269												
\$MBADR	000206	526#																
\$MFLG	040042	7564*	7570	7605*	7609#													
\$MSGAD	001014	555#	7580*	7583														
\$MSGLG	001016	556#	7585-															
\$MSGTY	001000	549#	7578	7586*	7598	7602*												
\$NULL	037046	7296	7346#															
\$NWTST =	000001	884#	886	1041#	1043	1153#	1183#	1216#	1262#	1349#	1389#	1457#	1528#	1599#				
		1639#	1666#	1718#	1771#	1839#	1899#	1966#	2027#	2094#	2149#	2194#	2255#	2303#				
		2418#	2526#	2633#	2684#	2771#	2858#	2892#	2929#	2973#	3013#	3049#	3079#	3115#				
		3153#	3239#	3292#	3342#	3381#	3455#	3630#	3680#	3720#	3916#	4040#	4134#	4382#				
		4581#	4800#	5008#	5241#	5538#	5640#	5784#	5810#	5841#	5867#	5908#	5949#	5992#				
		6033#	6076#	6117#	6160#	6202#	6388#	6518#	6820#	7049#	7090#							
		7452*	7481*	7494#														
\$OCNT	037524	7447*	7451*	7456	7459*	7470*	7496#											
\$OMODE	037526	552#	840*	866*	7205	7209*	7210*	7218	7231									
\$PASS	001006	528#																
\$PASTM	000212	7651#																
\$PATCH	040214	7350#																
\$QUES	037052	7560																
\$RDCHR =	*****	7560																
\$RDDEC =	*****	7560																
\$RDLIN =	*****	7560																
\$RDOCT =	*****	7560																
\$RTNAD	036374	7230#																
\$R2A =	*****	7560																
\$SAVRE =	*****	7560																
\$SETUP =	000126	471#	835	836	838	840	842	843	7209									
\$STUP =	177777	471#																
\$SVPC =	000204	503#	508															
\$SWR =	160000	175	176#	843	895	1050	1158	1188	1221	1267	1354	1394	1462	1533				
		1604	1644	1671	1723	1776	1844	1904	1971	2032	2099	2154	2199	2260				
		2308	2423	2531	2638	2689	2776	2863	2897	2934	2978	3018	3054	3084				
		3120	3158	3244	3297	3347	3386	3460	3635	3685	3725	3921	4045	4139				
		4387	4586	4805	5013	5246	5543	5645	5789	5815	5846	5872	5913	5954				
		5997	6038	6081	6122	6165	6207	6393	6523	6825	7054	7095	7201	7209				
		7223	7229	7231														
\$SWREG	001022	560#	869															
\$TESTN	001004	551#	874*	894*	1049*	1157*	1187*	1220*	1266*	1353*	1393*	1461*	1532*	1603*				
		1643*	1670*	1722*	1775*	1843*	1903*	1970*	2031*	2098*	2153*	2198*	2259*	2307*				
		2422*	2530*	2637*	2688*	2775*	2862*	2896*	2933*	2977*	3017*	3053*	3083*	3119*				
		3157*	3243*	3296*	3346*	3385*	3459*	3634*	3684*	3724*	3920*	4044*	4138*	4386*				
		4585*	4804*	5012*	5245*	5542*	5644*	5788*	5814*	5845*	5871*	5912*	5953*	5996*				
		6037*	6080*	6121*	6164*	6206*	6392*	6522*	6824*	7053*	7094*							
\$TKB	037040	7315	7322	7343#														
\$TKS	037036	7313	7320	7342#														
\$TN =	000112	175#	884	895#	1041	1050#	1153	1158#	1183	1188#	1216	1221#	1262	1267#				
		1349	1354#	1389	1394#	1457	1462#	1528	1533#	1599	1604#	163#	1644#	1666				
		1671#	1718	1723#	1771	1776#	1839	1844#	1899	1904#	1966	1971#	2027	2032#				
		2094	2099#	2149	2154#	2194	2199#	2255	2260#	2303	2308#	2418	2423#	2526				
		2531#	2633	2638#	2684	2689#	2771	2776#	2858	2863#	2892	2897#	2929	2934#				
		2973	2978#	3013	3018#	3049	3054#	3079	3084#	3115	3120#	3153	3158#	3239				
		3244#	3292	3297#	3342	3347#	3381	3386#	3455	3460#	3630	3635#	3680	3685#				
		3720	3725#	3916	3921#	4040	4045#	4134	4139#	4382	4387#	4581	4586#	4800				
		4805#	5008	5013#	5241	5246#	5538	5543#	5640	5645#	5784	5789#	5810	5815#				
		5841	5846#	5867	5872#	5908	5913#	5949	5954#	5992	5997#	6033	6038#	6076				
		6081#	6117	6122#	6160	6165#	6202	6207#	6388	6393#	6518	6523#	6820	6825#				

BGNMOD	160#	876														
BGNSUB	161#															
BGNTST	160#	893	1048	1156	1186	1219	1265	1352	1392	1460	1531	1602	1642	1669	1721	
	1774	1842	1902	1969	2030	2097	2152	2197	2258	2306	2421	2529	2636	2687	2774	
	2861	2895	2932	2976	3016	3052	3082	3118	3156	3242	3295	3345	3384	3458	3633	
	3683	3723	3919	4043	4137	4385	4584	4803	5011	5244	5541	5643	5787	5813	5844	
	5870	5911	5952	5995	6036	6079	6120	6163	6205	6391	6521	6823	7052	7093		
CKLOOP	160#															
COMMEN	294#															
DEFPRG	1#															
ENDCOM	294#															
ENDMOD	160#	7194														
ENDPAS	7195#	7217														
ENDSUB	161#															
ENDTST	160#	1038	1150	1167	1197	1258	1300	1376	1435	1492	1563	1627	1662	1704	1757	
	1825	1885	1952	2013	2081	2135	2181	2241	2299	2376	2484	2592	2670	2730	2817	
	2889	2926	2971	3011	3047	3077	3113	3151	3236	3289	3339	3378	3452	3626	3677	
	3718	3913	4037	4131	4293	4491	4711	4918	5058	5433	5584	5694	5807	5838	5864	
	5905	5946	5989	6030	6073	6114	6157	6199	6328	6457	6724	6954	7087	7138		
ERRDEF	159#															
ERRDF	160#	785	941	956	965	974	983	993	1003	1079	1087	1095	1103	1112	1121	
	1175	1208	1228	1236	1246	1254	1284	1306	1314	1326	1333	1340	1364	1371	1380	
	1404	1412	1421	1429	1448	1499	1506	1570	1577	1616	1623	1652	1658	1685	1692	
	1699	1708	1737	1745	1752	1761	1791	1798	1805	1813	1820	1829	1858	1865	1873	
	1880	1889	1919	1925	1932	1940	1947	1956	1985	1993	2001	2008	2017	2048	2055	
	2062	2069	2076	2085	2115	2123	2130	2139	2169	2176	2185	2216	2223	2229	2236	
	2245	2273	2281	2289	2296	2316	2327	2338	2351	2362	2372	2384	2437	2445	2454	
	2463	2472	2481	2493	2545	2553	2562	2571	2580	2589	2600	2650	2657	2664	2674	
	2705	2716	2727	2738	2792	2803	2814	2825	2871	2878	2884	2906	2912	2922	2945	
	2951	2957	2966	2992	2998	3006	3028	3034	3042	3063	3072	3094	3100	3108	3131	
	3139	3146	3168	3177	3189	3196	3205	3213	3224	3231	3257	3265	3276	3284	3308	
	3315	3326	3334	3359	3373	3397	3405	3417	3433	3446	3470	3478	3489	3498	3505	
	3514	3527	3536	3543	3552	3569	3577	3591	3599	3613	3621	3645	3653	3664	3672	
	3699	3713	3736	3744	3757	3766	3773	3782	3799	3807	3820	3829	3836	3845	3862	
	3870	3883	3894	3900	3908	3932	3940	3953	3962	3970	3984	4000	4008	4024	4032	
	4112	4124	4323	4332	4341	4354	4363	4374	4522	4531	4540	4553	4562	4573	4741	
	4750	4759	4772	4781	4793	4949	4958	4967	4980	4989	5001	5167	5176	5185	5199	
	5208	5219	5230	5467	5476	5485	5499	5508	5519	5530	5615	5624	5630	5726	5735	
	5744	5755	5764	5776	5796	5802	5826	5833	5853	5859	5880	5886	5892	5900	5921	
	5927	5933	5941	5964	5970	5976	5984	6005	6011	6017	6025	6048	6054	6060	6068	
	6089	6095	6101	6109	6132	6138	6144	6152	6176	6183	6193	6362	6371	6380	6491	
	6500	6509	6758	6767	6776	6790	6799	6811	6990	6999	7008	7019	7028	7040	7169	
	7176	7185														
ERROR	188#	785	942	956	965	974	983	993	1003	1079	1087	1095	1103	1112	1121	
	1175	1208	1228	1236	1246	1254	1284	1306	1314	1327	1334	1341	1364	1371	1381	
	1404	1412	1421	1429	1449	1499	1507	1570	1578	1616	1623	1652	1658	1685	1692	
	1699	1709	1737	1745	1752	1762	1791	1798	1805	1813	1820	1830	1858	1865	1873	
	1880	1890	1919	1925	1932	1940	1947	1957	1985	1993	2001	2008	2018	2048	2055	
	2062	2069	2076	2086	2115	2123	2130	2140	2169	2176	2186	2216	2223	2229	2236	
	2246	2273	2281	2289	2296	2316	2327	2338	2351	2362	2372	2384	2437	2445	2454	
	2463	2472	2481	2493	2545	2553	2562	2571	2580	2589	2600	2650	2657	2664	2675	
	2705	2716	2727	2738	2792	2803	2814	2825	2871	2878	2884	2906	2912	2922	2945	
	2951	2957	2966	2992	2998	3006	3028	3034	3042	3063	3072	3094	3100	3108	3131	
	3139	3146	3168	3177	3189	3196	3205	3213	3224	3231	3257	3265	3276	3284	3308	
	3315	3326	3334	3359	3373	3397	3405	3417	3433	3446	3470	3478	3489	3498	3505	
	3514	3527	3536	3543	3552	3569	3577	3591	3599	3613	3621	3645	3653	3664	3672	

\$\$NEWT	294#	884	1041	1153	1183	1216	1262	1349	1389	1457	1528	1599	1639	1666	1718
	1771	1839	1899	1966	2027	2094	2149	2194	2255	2303	2418	2526	2633	2684	2771
	2858	2892	2929	2973	3013	3049	3079	3115	3153	3239	3292	3342	3381	3455	3630
	3680	3720	3916	4040	4134	4382	4581	4800	5008	5241	5538	5640	5784	5810	5841
	5867	5908	5949	5992	6033	6076	6117	6160	6202	6388	6518	6820	7049	7090	
\$\$SET	7526#	7545	7554	7555	7556	7557									
\$\$SETM	859#	866													
\$\$SKIP	294#														
.EQUAT	159#	184													
.HEADE	161#	166													
.KT11	159#	294													
.SETUP	161#	471													
.\$ACT1	161#	499													
.\$APT8	159#	544													
.\$APTH	161#	509													
.\$APTY	162#	7560													
.\$EOP	159#	7196													
.\$ERRO	162#														
.\$READ	162#														
.\$TRAP	161#	7497													
.\$TYPD	160#	7353													
.\$TYPE	160#	7246													
.\$TYPO	162#	7420													
.\$40CA	159#	472													

. ABS. 040234 000

ERRORS DETECTED: 0

CZKDLB/EN:ABS,CZKDLB.SEQ/CRF/DOC/SOL/NL:TOC=SYSMAC.SML/ML,CZKDLB.MAC/ML,KDJ11A.MAC

RUN-TIME: 249 141 10 SECONDS

RUN-TIME RATIO: 539/400=1.3

CORE USED: 52K (103 PAGES)

DOCUMENT PAGES: 165