

RM03,02

EXTENDED DRIVE TEST
CZRMFB0

AH-B007B-MC

JAN 1978

COPYRIGHT © 1977

digital

FICHE 1 OF 2

MADE IN USA

This microfiche card contains a grid of frames. Each frame contains a small, high-contrast image of a document page, likely a technical report or test log. The frames are arranged in approximately 15 rows and 15 columns. The text within the frames is too small to be legible, but the layout suggests a structured document with multiple pages of information.

801

ESF10ZRA88580411

00010000

780105

POP10 81E N T I F IP80A1CZRM888EG

00010000

780105
SEQ 0001

PRODUCT CODE: AC-80068-MC
PRODUCT NAME: CZRMFBO RMO3/RMO2 EXTENDED DRIVE TEST
DATE CREATED: AUGUST 1977
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: H. BLACKSTONE

COPYRIGHT (C) 1977 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

CONTENTS

1.	ABSTRACT
2.	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	MEDIA
3.	LOADING PROCEDURE
4.	STARTING PROCEDURE
4.1	STARTING ADDRESSES
4.2	OPERATOR ACTION
4.3	PROGRAM ACTION
	4.3.1 CONTROL SWITCH SELECTION
	4.3.2 RM70 ADDRESS SELECTION
	4.3.3 DRIVE AND PARAMETER SELECTION
5.	OPERATING PROCEDURE
5.1	OPERATIONAL SWITCH SETTINGS
5.2	CONTROL SWITCH SETTINGS
6.	ERRORS
6.1	ERROR TYPES
6.2	ERROR RECOVERY
7.	RESTRICTIONS
8.	MISCELLANEOUS
8.1	EXECUTION TIME
8.2	STACK POINTER
8.3	TIMING TEST (TESTS 12 - 15) PRINTOUTS
8.4	END OF TEST
9.	PROGRAM DESCRIPTION
10.	RM70/RM03 DRIVER MODULE
11.	PROGRAM LISTING

1. ABSTRACT

THIS PROGRAM CONTAINS A SERIES OF TESTS THAT WILL VERIFY THAT THE DISK IS CAPABLE OF PERFORMING SEEKS, THAT THE ACCESS TIMES ARE WITHIN TOLERANCE, THAT THE TRACK AND SECTOR ADDRESSING CIRCUITRY OPERATES PROPERLY, AND THAT THE DATA STORAGE AND RETRIEVAL CAPABILITIES ARE FUNCTIONING.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 PROCESSOR
16K MEMORY
TELETYPE
PROGRAM LOADING DEVICE
KW11-L OR KW11-P (THE KW11-P IS REQUIRED FOR THE TIMING TESTS)
RH70 WITH 1 - 8 RM03 DISK DRIVES

2.2 PRELIMINARY PROGRAMS

RM03, RM02 DISKLESS CONTROLLER TEST	CZRMJB
RM03, RM02 FUNCTIONAL TEST I	CZRMCB
RM03, RM02 FUNCTIONAL TEST II	CZRMDB
RM03, RM02 FUNCTIONAL TEST III	CZRMEB

2.3 MEDIA

THE PROGRAM REQUIRES THAT EACH DRIVE TO BE TESTED HAS A FORMATTED DISK PACK. THE PACK MAY BE FORMATTED IN EITHER 16-BIT OR 18-BIT MODE, DEPENDING ON THE TESTING REQUIREMENTS. NOTE THAT THE PROGRAM WILL NOT TEST A MIXTURE OF DRIVES WITH BOTH 16 AND 18 BIT MODE PACKS

3. LOADING PROCEDURE

THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER. THE PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN. IF THE PROGRAM IS BEING RUN ON A PROCESSOR WITH 16K, THE 'XXDP' LOADER WILL NOT BE PRESERVED. THE PROGRAM MUST BE RUN ON A SYSTEM WITH 20K OR MORE TO PRESERVE THE 'XXDP' LOADER. THE 'ABSOLUTE' LOADER WILL BE PRESERVED IN A 16K SYSTEM, HOWEVER.

4. STARTING PROCEDURE

4.1 STARTING ADDRESSES

200 NORMAL STARTING ADDRESS
 204 SELECT OPERATING PARAMETERS
 210 SELECT RW70 ADDRESSES
 214 COMBINATION OF 204 AND 210

NOTE: STARTING ADDRESSES 210 AND 214 ARE AVAILABLE WHEN THE PROGRAM IS INITIALLY STARTED; THESE STARTING ADDRESSES ARE TREATED AS ADDRESSES 200 OR 204 RESPECTIVELY ON RESTARTS.

4.2 OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 3.)
2. LOAD A FORMATTED PACK INTO DRIVE(S) TO BE TESTED
3. BRING DRIVE(S) TO ONLINE STATE, WRITE ENABLED, AND LOCKED ON PORT.
4. LOAD ADDRESS 200
5. SET SWITCHES (SEE SECTION 5.)
6. PRESS START.
7. THE PROGRAM WILL TYPEOUT THE STATUS OF THE DRIVES ATTACHED TO THE SELECTED MASSBUS SUBSYSTEM. TO INHIBIT THIS TYPEOUT, DO NOT RESTART THE PROGRAM FROM ANY OF THE STARTING ADDRESSES; INSTEAD TYPE A 'CONTROL C' ON THE KEYBOARD TO RETURN THE PROGRAM TO COMMAND ENTRY MODE.

4.3 PROGRAM ACTION

IN AN EFFORT TO ALLOW CONVERSATION WITH A PROGRAM FOR THE PURPOSE OF CONTROLLING ITS OPERATION AND PARAMETERS THE FOLLOWING CONSTRUCTIONS HAVE BEEN ADOPTED.

NOTE1: IN ALL EXAMPLES BRACKETS ARE USED FOR CLARITY AND ARE NOT TYPED BY THE USER.

NOTE2: THE CARRIAGE RETURN TYPED BY THE USER IS INDICATED BY '<CR>' AND WILL BE ECHOED AS A 'CARRIAGE RETURN-LINE FEED'.

'<CR>' PERIOD

A STATEMENT TERMINATOR: WHEN TYPED AT THE END OF A LINE (LEGAL ON ALL LINES) IT TELLS THE PARAMETER STRING INTERPRETER (PSI) THIS IS THE END OF CHANGES TO THE CURRENT PARAMETER STRING.

'<CR>' PERIOD PERIOD

THE 'PERIOD PERIOD' TERMINATOR IS TYPED TO INDICATE THE END OF TEST PARAMETER MODIFICATION AND TO SIGNAL THE START OF TEST EXECUTION.

'<CR>' COMMA

THE COMMA IS USED AS A SEPARATOR BETWEEN DRIVE NUMBERS AND TEST NUMBERS.

'/' SLASH

A MODIFICATION INDICATOR: IF A SLASH FOLLOWS A TEST

F01

NUMBER, THE PROGRAM WILL OPEN THAT TEST FOR PARAMETER MODIFICATION.

SEG 0005

CONTROL-U

DELETE THE PRESENT INPUT STRING AND START A NEW LINE. TYPED BY DEPRESSING THE "CONTROL KEY" (CTRL) AND THEN STRIKING THE "U".

RUBOUT

DELETE THE LAST CHARACTER FROM THE INPUT STRING. TYPED BY STRIKING THE "RUBOUT" KEY, WHICH WILL BE ECHOED BY A BACKSLASH (\) FOLLOWED BY THE CHARACTER DELETED.

4.3.1 CONTROL SWITCH SELECTION

STARTING THE PROGRAM AT ANY OF THE POSSIBLE STARTING ADDRESSES WITH SW<07>=1 WILL RESULT IN ENTERING THE "CONTROL SWITCH SETTING" MODE. THUS, ALLOWING THE OPERATOR TO SPECIFY THE DESIRED STATE OF "C.SWR".

CONTROL SWITCH SELECTION EXAMPLES:

EXAMPLE #1

```
SET SW<07>=0
C.SWR=000000 / 400..
```

EXAMPLE #2

```
SET SW<07>=0
C.SWR=000000 / 220.
C.SWR=000000 / 220..
```

4.3.2 RH70 ADDRESS SELECTION

STARTING THE PROGRAM AT 200 WILL RESULT IN AUTOMATIC SELECT OF THE DEFAULT VALUES OF BUS ADDRESS (RMCS1), VECTOR ADDRESS, AND PRIORITY LEVEL OF THE RH70. IF THE DEFAULT VAULE OF THE BUS ADDRESS DOES NOT RESPOND (TIMES OUT) WHEN ADDRESSED, AN ERROR IS REPORTED. AFTER THE ERROR IS REPORTED ONE OF TWO COURSES OF ACTION WILL BE TAKEN:

1. IF THERE IS A MONITOR -- RETURN TO THE MONITOR
2. IF THERE ISN'T A MONITOR -- ASK FOR NEW ADDRESSES

STARTING THE PROGRAM AT 210 OR 214 ALLOWS THE OPERATOR TO CHANGE THE ADDRESS OF THE RH70 AND THE VECTOR ADDRESS. STARTING ADDRESSES 210(8) AND 214(8) ARE TREATED AS ADDRESSES 200(8) OR 204(8) RESPECTIVELY.

ADDRESS SELECTION EXAMPLES

EXAMPLE #1

RMCSI=176700 / 177200.

EXAMPLE #2

RMCSI=176700 / 176300<CR>
RHVEC=254 / 260<CR>
RHPRIO=5 / 6.

EXAMPLE #3

RMCSI=176700<CR>
RHVEC=254 / 260.

EXAMPLE #4

RH70/RM03 FAILED TO RESPOND TO ADDRESSING
RMCSI ERR PC
176300 XXXXXX
RMCSI=176300 / 176700.

EXAMPLE #5

RMCSI=176700 / 1776\67\6300<CR>
RHVEC=254<CR>
RHPRIO=5<CR>
RMCSI=176300.

4.3.3 DRIVE AND PARAMETER SELECTION

STARTING THE PROGRAM AT 200 OR 210 WILL RESULT IN AUTOMATIC SELECTION OF THE DRIVES TO TEST AND THE TESTS TO RUN.

STARTING THE PROGRAM AT 204 OR 214 ALLOWS THE OPERATOR TO SELECT THE DRIVE(S) TO BE TESTED, THE TESTS TO BE EXECUTED, AND THE PARAMETERS TO USE.

4.3.3.1 DRIVE AND PARAMETER SELECTION DESCRIPTION

THE FOLLOWING IS A TABLE OF TERMS USED BY THE PSI.

"R"	REPEATS (ITERATIONS)
"FC"	FIRST CYLINDER ADDRESS
"LC"	LAST CYLINDER ADDRESS
"IC"	INCREMENT CYLINDER
"FT"	FIRST TRACK ADDRESS
"LT"	LAST TRACK ADDRESS
"IT"	INCREMENT TRACK
"FS"	FIRST SECTOR ADDRESS
"LS"	LAST SECTOR ADDRESS
"PAT"	PATTERN (USED FOR DATA TEST)
"WDX"	WORD OF PATTERN 0 WHERE X IS 1 TO 16
*"S"	ALL SEEK TESTS (TESTS 0 - 10)
*"T"	ALL TIMING TESTS (TESTS 12 - 15)
*"A"	ALL ADDRESS TESTS (TESTS 16 - 17)
*"D"	THE DATA TEST (TEST 20)
*"E"	THE EXERCISER (TEST 21)

H01

SEQ 0007

NOTE: * USED BY THE OPERATOR TO SELECT TEST GROUPS
ALL NUMBERS WILL BE IN DECIMAL EXCEPT FOR THE PATTERN
(PAT) AND WORDS (WDX) SELECTION. "PAT" WILL BE SELECTED
BY A BIT (I.E. 001000(8)=PATTERN 9) AND "WDX" WILL BE IN OCTAL.

SPECIAL CASES OF CONTROL CHARACTERS

IF (<..>) IS TYPED WHILE A TEST IS OPEN FOR MODIFICATION
(<..>) AND OTHER TESTS IN THE "TEST COMMAND" STRING
ARE TO BE MODIFIED, THE REMAINING TESTS WILL BE UNCHANGED.

WHEN THE PROGRAM IS STARTED FROM LOCATION 200 OR 210, TESTS 0-10,
12-20 WILL BE RUN USING ALL AVAILABLE ONLINE DRIVES. IF THE OPERATOR
WISHES TO SELECT THE DRIVES TO BE TESTED, THE TESTS TO BE PERFORMED,
OR THE PARAMETERS TO BE USED, THE CONVERSATION MODE MAY BE ENTERED
BY TYPING A 'CONTROL C' OR BY STARTING THE PROGRAM FROM EITHER
LOCATION 204 OR 214.

THE PROGRAM WILL THEN RESPOND WITH:

DRIVE(S)=

THE FOLLOWING EXAMPLES ASSUME THAT THE OPERATOR IS TO TEST
DRIVE #3 USING TESTS 2 THRU 7 AND TEST 11 AND DOES NOT DESIRE TO CHANGE
THE PARAMETERS (INITIAL CYLINDER ADDRESS, FINAL CYLINDER ADDRESS, ETC.).
THE USER WOULD TYPE '3<CR>' WHICH SAYS 'THIS IS THE END OF DRIVE ENTRY'.
THE PROGRAM WILL THEN REQUEST TEST NUMBERS.

THE TRANSACTION APPEARS AS FOLLOWS:

DRIVE(S)=3<CR>
TEST=

THE OPERATOR MAY NOW ENTER DESIRED TEST NUMBERS. IN THE EXAMPLE,
HE WANTS TESTS 2 THRU 7 AND TEST 11 SO HE TYPES 2-7<,> (THE 'COMMA'
SEPARATES ENTRIES) 11<.><CR> ('PERIOD' 'CARRIAGE RETURN' -
END OF CHANGES, START TEST EXECUTION.)

IT NOW LOOKS LIKE THIS

DRIVE(S)=3<CR>
TEST=2-7,11.<CR>

IN THE NEXT EXAMPLE, IT IS ASSUMED THAT THE OPERATOR WISHES TO TEST
DRIVE 4 AND TO RUN TESTS 1 AND 3 THRU 11, MODIFYING THE PARAMETERS
FOR TESTS 3 AND 10.

THE TRANSACTION WOULD BE AS FOLLOWS:

DRIVE(S)=4<CR>
TEST=

THE OPERATOR NOW ENTERS THE TEST NUMBERS. THE TRANSACTION IS
GIVEN BELOW:

DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>

NOTICE THIS SAYS SELECT TEST 1, CONTINUE<.>; SELECT TEST 3, OPEN</>;
SELECT TESTS 4-7, CONTINUE<.>; SELECT TEST 10, OPEN</>; SELECT TEST
11, END OF INPUT <.>.

THE PROGRAM SCANS THE TEST NUMBER INPUT AND DETERMINES THAT THE
PARAMETERS FOR TEST 3 AND TEST 10 ARE TO BE CHANGED. THE OTHER
TESTS WILL NOT BE ALTERED.

(THE ENTIRE TRANSACTION IS REPEATED FOR CLARITY)

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=X / ;WHERE X IS ITERATION
```

THE NEW VALUE FOR 'R' MAY BE ENTERED. TERMINATING THE ENTRY WITH
A <.> (PERIOD) WILL TERMINATE THE CHANGES FOR THIS TEST; TYPING A
<CR> OR TERMINATING THE ENTRY WITH A <CR> WILL CAUSE THE PROGRAM
TO MOVE TO THE NEXT PARAMETER.

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=1 / <CR> ;DO NOT ALTER-BUT CONTINUE
FC=N / ;WHERE 'N' IS FIRST CYLINDER ADDRESS
```

IF THE OPERATOR DOES NOT WISH TO CHANGE 'FC', THE FOLLOWING OCCURS:

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11.<CR>
TEST 3
R=1 / <CR> ;DO NOT ALTER THIS LINE BUT CONTINUE
FC=0 / <CR> ;DO NOT ALTER THIS LINE BUT CONTINUE
LC=822 /
```

THE PROGRAM RESPONDS WITH THE PREVIOUSLY ASSIGNED PARAMETER FOR LAST
CYLINDER ADDRESS IN THIS CASE USING 822 AS THE EXAMPLE. THIS IS
WHAT THE OPERATOR INTENDED TO MODIFY AND IS WHY TEST 3 WAS
OPENED. TO CHANGE THE VALUE TO '20', THE NEW VALUE IS TYPED
FOLLOWED BY A 'PERIOD' TERMINATOR (<.><CR>).

THE TOTAL TRANSACTION AND RESPONSE:

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=1 / <CR>
FC=0 / <CR>
LC= 822 / 20.<CR>
TEST 10
R=1 /
```

THE PROGRAM HAS LOADED TEST 3 WITH ITS NEW PARAMETERS AND THE
PROGRAM IS WAITING FOR CHANGES TO TEST 10'S PARAMETERS.

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=1 / <CR>
```



```

FC=0 / <CR>
LC= 822 / 20.<CR>
TEST 10
R=1 / 10.<CR>

```

THE OPERATOR TYPES THE NEW VALUE (10) AND TERMINATES THE ENTRY WITH A 'PERIOD' 'CARRIAGE RETURN'.

THE PROGRAM NOW LOADS TEST 10 WITH THE NEW PARAMETERS (TEST 11 RETAINS THE PREVIOUSLY ASSIGNED PARAMETERS) AND RESPONDS WITH:

DRIVE(S)=

SINCE THE USER DID NOT END THE CONVERSATION MODE WITH A 'PERIOD PERIOD', THE PROGRAM HAS LOOPED BACK TO THE BEGINNING LOOKING FOR MORE CHANGES. THAT IS TO SAY, AFTER THE ENTRY FOR DRIVE SELECTION, A '<,><CR>' WILL CAUSE THE TEST MESSAGE TO BE REPEATED AND FURTHER CHANGES CAN BE MADE. HOWEVER, AT SOME POINT IN ORDER TO EXECUTE THE PROGRAM, A 'PERIOD PERIOD' MUST BE TYPED.

IF A SINGLE 'PERIOD' IS TYPED WHILE DRIVE OR TEST NUMBERS ARE BEING ENTERED, THE PROGRAM WILL START EXECUTION IMMEDIATELY. A 'PERIOD PERIOD' MUST BE TYPED BEFORE THE PROGRAM WILL EXIT TEST PARAMETER CHANGE MODE TO GO TO EXECUTION.

4.3.3.2 DRIVE AND PARAMETER SELECTION EXAMPLES

EXAMPLE #1

```

DRIVE=4.<CR>          ;SELECT DRIVE #4, TERMINATE AND
                     ;BEGIN EXECUTION USING PREVIOUSLY ASSIGNED
                     ;PARAMETERS

```

EXAMPLE #2

```

DRIVE=0<CR>          ;SELECT DRIVE #0 AND MAKE CHANGES " "
TEST=1-5.<CR>        ;RUN TEST 1 THRU 5 ONLY, USE DEFAULT
                     ;PARAMETERS AND TERMINATE AND EXECUTE."

```

EXAMPLE #3

```

DRIVE=2<CR>          ;SFLECT DRIVE #2 AND MAKE CHANGES " "
TEST=1-5,6,7,10/<CR> ;RUN TEST 1-5 WITH DEFAULT PARAMETERS, OPEN
TEST 6              ;TEST 6,7 AND 10 FOR CHANGES
  R=1 / <CR>         ;LEAVE 'R' AS IS AND MOVE TO NEXT PARAMETER
  FC=0 / 10.<CR>     ;SET 'FC' CYLINDER ADDRESS TO 10, END CHANGES
                     ;TO TEST 6.

TEST 7              ;50 ITERATIONS, MOVE TO NEXT PARAMETER
  R=1 / 50.<CR>      ;DO NOT CHANGE 'FC' CYLINDER ADDRESS BUT CONTINUE
  FC=0 / <CR>       ;TEST 10 IS STILL PENDING AND WILL BE
  LC=822 / 50..<CR> ;RETAIN ITS PRESENT PARAMETERS.

```

EXAMPLE #4

K01

SEQ 0010

```

-----
DRIVE=0<CR>           ;SELECT DRIVE #0 AND MAKE CHANGES
TEST=S,E.<CR>         ;RUN ALL SEEK TESTS AND THE EXERCISER

```

EXAMPLE #5

```

-----
DRIVE=1<CR>
TEST=S/D<CR>         ;RUN ALL SEEK TESTS (OPEN FOR CHANGES) AND
TEST 0               ;THE DATA TEST (WITH DEFAULT PARAMETERS).
  R=10 / <CR>        ;RUN WITH 10 ITERATIONS
  FC=0 / 10.<CR>     ;CHANGE FIRST CYLINDER ADDRESS
                   ;AND START EXECUTION
                   ;TESTS 1 - 10 WILL RETAIN THEIR PREVIOUSLY
                   ;ASSIGNED PARAMETERS.

```

EXAMPLE #6

```

-----
DRIVE=1<CR>
TEST=S/<CR>          ;OPEN THE SEEK TESTS (TESTS 0-10)
TEST 0              ;CHANGE TO 100 ITERATIONS, TO TO THE NEXT TEST
  R=10 / 100.<CR>
TEST 1              ;CHANGE 'R' TO 1000 ITERATIONS, MOVE TO NEXT TEST
  R=100 / 1000.<CR>
TEST 2              ;CHANGE 'R' TO 10 ITERATIONS, GO TO NEXT PARAMETER
  R=1 / 10<CR>      ;CHANGE 'FC' TO 50, GO TO NEXT PARAMETER
  FC=0 / 50<CR>     ;CHANGE 'LC' TO 51, GO TO THE NEXT TEST
  LC=822 / 51.<CR>
TEST 3              ;MOVE TO NEXT TEST
  R=1.<CR>
TEST 4              ;USE TEST 4'S PARAMETERS AND START PROGRAM EXECUTION
  R=1.<CR>

```

EXAMPLE #7

```

-----
DRIVE=1<CR>
TEST=D.<CR>          ;SELECT AND OPEN THE DATA TEST
TEST 20             ;DO 1000 ITERATION OF TEST PATTERN
  R=1 / 1000<CR>    ;#8 ON CYLINDER 10, TRACK 2, SECTOR 4
  FC=0 / 10<CR>
  LC=822 / 10<CR>
  IC=64 / 0<CR>
  FT=0 / 2<CR>
  LT=4 / 2<CR>
  IT=1 / <CR>
  FS=0 / 4<CR>
  LS=32 / 4<CR>
  PAT=177777 / 400.<CR> ;RUN WITH PATTERN #8

```

EXAMPLE #8

```

-----
DRIVE=1<CR>
TEST=D/<CR>         ;USE THE SAME PARAMETERS AS IN EXAMPLE
TEST 20             ;#7, BUT ALSO SPECIFY A DATA PATTERN (PAT #0).
  R=1000 / <CR>
  FC=10 / <CR>

```

```

LC=10 / <CR>
YC=0 / <CR>
FY=2 / <CR>
LI=2 / <CR>
IT=1 / <CR>
FS=4 / <CR>
LS=4 / <CR>
PAT=000400 / 401<CR> ;RUN WITH PATTERNS #8 & #0 (0=OPERATOR INPUT)
WD1=165555 / 125252<CR> ;FIRST WORD OF PATTERN 0
WD2=133333 / 52525.<CR> ;SECOND WORD OF PATTERN 0
;...> START EXECUTION

```

EXAMPLE #9

```

-----
DRIVE=0,1,4<CR> ;TEST DRIVES 0,1, AND 4 IN SEQUENCE
TEST=0-5<CR> ;CHANGE TEST 5
TEST 0
R=10 / <CR>
FC=0 / <CR>
LC=822 / 1.<CR> ;CHANGE LAST CYLINDER FROM 822 TO 1
;START PROGRAM EXECUTION.

```

5. SWITCH SETTINGS

5.1 OPERATIONAL SWITCH SETTINGS

WITH SW<15:0>=0 THE PROGRAM WILL PRINT OUT ON ERRORS AND CONTINUE IN TEST. THE SWITCH SETTINGS ARE:

```

SW<15>=1...HALT ON ERROR
SW<14>=1...LOOP ON TEST
SW<13>=1...INHIBIT ERROR TYPEOUTS
SW<12>=1...TYPE OUT TEST NUMBER FOR EACH TEST
SW<11>=1...INHIBIT ITERATIONS
SW<10>=1...RING BELL ON ERROR
SW<09>=1...LOOP ON ERROR
SW<08>=1...PRINT ERROR MESSAGE ON LINE PRINTER
SW<07>=1...READ CONTROL SWITCH SETTINGS FROM TTY
SW<06>=1...INHIBIT TIME REPORTS (TESTS 12-15)
SW<05>=1...REPORT ONE ERROR PER SECTOR (TESTS 16 & 17)
SW<04>=1...INHIBIT WRITES (TEST 20)
SW<03>=1...INHIBIT WRITE CHECKS (TEST 20)
SW<02>=1...INHIBIT READ AND SOFTWARE COMPARES (TEST 20)
SW<01>=1...INHIBIT SOFTWARE COMPARES (TEST 20)
SW<00>=1...PERFORM READ AFTER WRITE CHECK ERROR (TEST 20)

```

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS AT A HIGHER PRIORITY PROCESSING AN RMO3 INTERRUPT. THE

MO1

'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

SEG 0012

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

5.2 CONTROL SWITCH SETTINGS

THE CONTROL SWITCH SETTINGS ARE ENTERED THROUGH THE KEYBOARD.

TO ENTER THE CONTROL SWITCH SETTING MODE PLACE SW<07>=1 BEFORE PRESSING START. THEN UPON STARTING THE PROGRAM IT WILL TYPE THE PRESENT CONTENTS OF THE CONTROL SWITCH REGISTER (C.SWR) AND WAIT FOR THE NEW SETTING TO BE INPUT. THE INPUT STRING MUST CONSIST OF 1 TO 6 OCTAL DIGITS, TWO PERIODS (...), AND A CARRIAGE RETURN.

THE C.SWR SETTINGS ARE:

C.SWR<15>=0...WRITE PACK BEFORE TESTING (TEST16)
 =1...INHIBIT WRITE PACK BEFORE TESTING (TEST16)
C.SWR<14>=0...NO STALL BETWEEN DRIVE FUNCTIONS
 =1...STALL AFTER EVERY DRIVE FUNCTION
C.SWR<13>=0...USE SPECIFIC STALL TIMES
 =1...USE RANDOM STALL TIMES
C.SWR<12>=0...NO INCREMENTING STALLS IN TEST4
 =1...PERFORM INCREMENTING STALLS IN TEST4
C.SWR<08>=0...DO IMPLIED SEEKS WITH DATA TRANSFERS
 =1...DO EXPLICIT SEEKS BEFORE DATA TRANSFERS
C.SWR<07>=0...DO READ HEADER AND DATA COMMANDS IN TESTS 0-6
 =1...DO EXPLICIT SEEK COMMANDS IN TESTS 0-6
C.SWR<06>=0...60 HZ POWER SOURCE
 =1...50 HZ POWER SOURCE
C.SWR<05>=0...ALLOW SOFTWARE TIMEOUTS(ENABLE WATCHDOG TIMER)
 =1...INHIBIT SOFTWARE TIMEOUTS(DISABLE WATCHDOG TIMER)
C.SWR<00>=0...OPERATE IN 22 SECTOR (16 BIT) MODE
 =1...OPERATE IN 20 SECTOR (13 BIT) MODE

THE DEFAULT CONDITION OF C.SWR<15:00>=0.

REFER TO 4.3.1 FOR C.SWR SELECTION

E. ERRORS

THERE ARE ANUMBER OF ERRORS THAT CAN OCCUR IN THIS PROGRAM. WHEN AN ERROR IS ENCOUNTERED, THE CALL TO THE ERROR ROUTINE

IS MADE AND IF SW(13) IS NOT SET, AN ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPEOUT WILL CONTAIN THE FOLLOWING:

SEG 0013

1. AN ERROR MESSAGE
2. A DATA HEADER
3. A DATA STRING

REFER TO THE FOLLOWING SECTION FOR THE DIFFERENT ERRORS THAT CAN OCCUR.

E.1 ERROR TYPES

THE ERRORS THAT OCCUR IN THIS PROGRAM FALL INTO THREE (3) CATEGORIES DEFINED AND EXPLAINED AS FOLLOWS:

E.1.1 DRIVER ERROR

THESE ERRORS WILL BE DETECTED BY THE RH70/RM03 DRIVER. THERE ARE TWO CLASSES OF DRIVER ERRORS; THOSE THAT CAN NOT BE IDENTIFIED IN A MANNER THAT ALLOWS THE INFORMATION TO BE RETURNED TO A "DATA PARAMETER BLOCK" (DPB) AND THOSE THAT CAN. THE FIRST CLASS WILL BE REPORTED BY ERROR CALLS (EMT'S) 1-5 WITHIN THE DRIVER. THE SECOND CLASS WILL PASS THE ERROR CODES TO THE STATUS/ERROR WORD (DPB+16) OF THE PROPER DPB.

E.1.2 NON-FATAL ERRORS

THESE ERRORS WILL BE DUE TO "DISK" OR "DATA" FAILURES WHICH WILL BE REPORTED AS THEY OCCUR. AFTER REPORTING THE ERROR THE PROGRAM WILL CONTINUE TESTING.

E.1.3 FATAL ERRORS

THIS TYPE OF ERROR WILL BE THE RESULT OF ANY KIND OF ERROR THAT INHIBITS THE PROGRAM FROM TESTING THE DISK.

THIS ERROR WILL BE REPORTED WHEN IT OCCURS, THEN THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

E.2 ERROR RECOVERY

E.2.1 PRETEST ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED. THEN DEPENDING ON HOW THE PROGRAM WAS STARTED IT WILL ASK FOR THE DRIVES AND ADDRESSES FOR TESTING OR RETURN TO MONITOR.

E.2.2 NON-FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED AND THE PROGRAM WILL CONTINUE IN TEST.

E.2.3 FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED. THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

7. RESTRICTIONS

THE PROGRAM WILL TEST THE DRIVES IN EITHER 16 BIT MODE OR IN 18 BIT MODE DEPENDING ON THE SETTING OF 'S.SWR<00>'. IF 'C.SWR<00>' IS 0, ALL OF THE DRIVES WILL BE TESTED IN 16 BIT MODE; IF 'C.SWR<00>' IS 1, ALL OF THE DRIVES WILL BE TESTED IN 18 BIT MODE. THE PROGRAM HAS NO PROVISIONS FOR TESTING DRIVES WITH INTERMIXED PACKS OR TESTING BOTH 16 BIT MODE AND 18 BIT MODE DRIVES ON THE SAME SYSTEM.

BEFORE THE PROGRAM IS STARTED, PROPERLY FORMATTED PACKS MUST BE MOUNTED ON THE DRIVES WHICH WILL BE TESTED. THE PROGRAM ASSUMES A PROPERLY FORMATTED PACK. THE FORMAT OF THE PACK IS NOT ALTERED BY THE PROGRAM.

8. MISCELLANEOUS

8.1 EXECUTION TIME

THE PROGRAM REQUIRES APPROXIMATELY 22 MINUTES TO MAKE ONE PASS PER DRIVE USING AN 11/70 CPU. THIS ASSUMES THE DEFAULT TEST SEQUENCE (TESTS 0-10, 12-21) AND DEFAULT TEST PARAMETERS.

8.2 STACK POINTER

THE STACK POINTER IS INITIALLY SET TO 1100.

8.3 TIMING TESTS (TESTS 12-15) PRINTOUTS

AT THE COMPLETION OF EACH OF THE TIMING TESTS THE TIME OF THE MINIMUM SEEK, MAXIMUM SEEK, AND THE AVERAGE OF ALL OF THE SEEKS PERFORMED ARE TYPED ON THE TTY. THE NUMBER OF SEEKS THAT HAD TIMES BELOW THE MINIMUM TIME ALLOWED WILL BE TYPED ON THE SAME LINE AS THE MINIMUM TIME. THE NUMBER ABOVE THE MAXIMUM WILL BE TYPED ON THE SAME LINE AS THE MAXIMUM TIME, AND THE TOTAL NUMBER OF SEEKS PERFORMED WILL BE ON THE SAME LINE AS THE AVERAGE.

8.3 : TIMING TOLERANCES

1. TEST 12 -- ROTATIONAL SPEED TIMES

60 HZ
MINIMUM=16260 US
MAXIMUM=17300 US
NOMINAL=16670 US

50 HZ
MINIMUM=16250 US
MAXIMUM=17090 US
NOMINAL=16670 US

2. TEST 13 -- ONE CYLINDER SEEK TIMES

MAXIMUM=8000 US
 NOMINAL=6000 US

3. TEST 14 -- ACCESS TIME MEASUREMENT

MAXIMUM=32000 US
 NOMINAL=30000 US

4. TEST 15 -- MAXIMUM SEEK TIMES

MAXIMUM=57000 US
 NOMINAL=55000 US

8.3.2. TIMING TESTS PRINTOUT EXAMPLES

EXAMPLE #1

ROTATIONAL SPEED TIMES

MIN=16670 US
 MAX=16690 US
 AVG=16680 US 10 SEEKS TIMED

ONE CYLINDER SEEK TIMES

* FORWARD

MIN=5350 US
 MAX=6920 US
 AVG=5550 US 822 SEEKS TIMED

* REVERSE

MIN=5140 US
 MAX=5960 US
 AVG=5430 US 822 SEEKS TIMED

ACCESS TIME MEASUREMENTS

* FORWARD

MIN=27770 US
 MAX=28640 US
 AVG=28230 US 128 SEEKS TIMED

* REVERSE

MIN=27990 US
 MAX=28550 US
 AVG=28220 US 128 SEEKS TIMED

MAXIMUM SEEK TIMES

* FORWARD

MIN=56990 US
 MAX=57980 US
 AVG=57010 US 128 SEEKS TIMED

* REVERSE

MIN=55120 US
 MAX=57650 US
 AVG=56340 US 128 SEEKS TIMED

EXAMPLE #2

ROTATIONAL SPEED TIMES
 MIN=16670 US
 MAX=16690 US
 AVG=16680 US 10 SEEKS TIMED

ONE CYLINDER SEEK TIMES

* FORWARD
 MIN=5470 US
 MAX=8940 US 3 ABOVE THE MAXIMUM OF 8000 US
 AVG=5830 US 822 SEEKS TIMED
 * REVERSE
 MIN=5040 US
 MAX=5970 US
 AVG=5330 US 822 SEEKS TIMED

ACCESS TIME MEASUREMENTS

* FORWARD
 MIN=29730 US
 MAX=32620 US 73 ABOVE THE MAXIMUM OF 32000 US
 AVG=30320 US 128 SEEKS TIMED
 * REVERSE
 MIN=28620
 MAX=32230 US 128 ABOVE THE MAXIMUM OF 32000 US
 AVG=32800 US 128 SEEKS TIMED

MAXIMUM SEEK TIMES

* FORWARD
 MIN=57510 US
 MAX=57240 US 128 ABOVE THE MAXIMUM OF 57000 US
 AVG=57020 US 128 SEEKS TIMED
 * REVERSE
 MIN=57050 US
 MAX=57550 US 128 ABOVE THE MAXIMUM OF 57000 US
 AVG=57210 US 128 SEEKS TIMED

8.4 END OF TEST

WITH ALL SWITCHES ON A "0" AN "END OF PASS" MESSAGE WILL BE
 TYPED AT THE COMPLETION OF TESTING A DRIVE AND THE "END OF TEST"
 TIMEOUT WILL OCCUR WHEN ALL DRIVES HAVE BEEN TESTED.

9. PROGRAM DESCRIPTION

 THIS PROGRAM CONTAINS NINETEEN TESTS NUMBERED 0-22 IN OCTAL.
 TESTS 0-7 & 11 WILL READ THE CYLINDER, TRACK, AND SECTOR INFORMATION
 FROM THE HEADER, USING A "READ HEADER AND DATA" COMMAND, AND
 THEN CHECK THE INFORMATION FOR VALIDITY, THUS, INSURING
 THE SEEK OPERATION FUNCTIONS PROPERLY. TESTS 12-15 WILL MEASURE
 THE ROTATIONAL SPEED, THE ONE CYLINDER SEEK, THE ACCESS TIME,
 AND THE MAXIMUM SEEK TIMES TO ENSURE THEY ARE ALL WITHIN THE
 TOLERANCES ALLOWED. TEST 16 AND 17 ENSURES THE SECTOR AND
 TRACK ADDRESSING CIRCUITRY WORKS PROPERLY. TEST 20 VERIFIES
 THE DATA STORAGE AND RETRIEVAL CAPABILITIES ARE FUNCTIONAL.
 AND TEST 21 WILL STRESS AND CHECK THE READ/WRITE AND SERVO
 SYSTEMS.

THE PROGRAM WILL START BY IDENTIFYING ITSELF AND DETERMINING ALL DRIVES THAT ARE AVAILABLE FOR TESTING. THEN BEGINNING WITH THE LOWEST NUMERICAL DRIVE AND PROCEEDING IN SEQUENTIAL ORDER. ALL OF THE DRIVES WILL BE TESTED. ONE PASS THROUGH THE TEST SEQUENCE (TESTS 0-10, 12-20) WILL BE PERFORMED ON EACH DRIVE BEFORE MOVING TO THE NEXT DRIVE IN SEQUENCE. THE ADDRESS OF EACH DRIVE TO BE TESTED WILL BE TYPED AT THE BEGINNING OF EACH PASS, AN "END OF PASS" MESSAGE WILL BE TYPED AT THE COMPLETION OF EACH PASS, AND AN "END OF TEST" MESSAGE WILL BE TYPED AFTER TESTING ALL DRIVES.

REFER TO THE FOLLOWING SECTIONS FOR DETAILED DESCRIPTIONS OF EACH TEST.

9.1 TEST 0 - RECAL/SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE COMMAND CYCLE AND THEN SEEK FORWARD TO CYLINDER "LC". AT THE COMPLETION OF BOTH COMMANDS, STATUS INDICATORS ARE CHECKED TO ENSURE NO ERRORS OCCURRED.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	200
LC	-	822
FT	-	0
FS	-	0

9.2 TEST 1 - SEEK/SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK CYCLE TO "LC" "LT" "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO "FC" "FT" "FS". AT THE COMPLETION OF EACH SEEK, THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	100
FC	-	0
LC	-	256
IC	-	0
FT	-	0
LT	-	0
FS	-	0
LS	-	0

9.3 TEST 2 - INCREMENTAL SEEK TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC". WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS "LC" REVERSE SEEK CYCLES ARE INITIATED; STARTING AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC" UNTIL "NC" IS LESS THAN "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	1
FC	-	00
LC	-	822
IC	-	1
FT	-	00
FS	-	0

9.4 TEST 3 - STEPPING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0, 1, 2, 4, 8, 16, 32, 64, 128, AND 256. AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	8
FC	-	00
LC	-	256
IC	-	1
FT	-	00
FS	-	0

9.5 TEST 4 - OSCILLATING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK TO "FC". "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC". AT THE COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	00
LC	-	822
IC	-	1
FT	-	00
FS	-	0

9.6 TEST 5 - CONVERGING/DIVERGING SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE SEEKS FROM "NC1" AND "NC2" RESPECTIVELY. "NC1" WILL BE INCREMENTED BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS LESS THAN THE INITIAL VALUE OF "NC1". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION. "NC1" AND "NC2" DEFAULT TO "FC" AND "LC" RESPECTIVELY.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	00
LC	-	822
IC	-	1
FT	-	00
FS	-	0

9.7 TEST 6 - SERVO ADDRESSING LOGIC NOISE GENERATOR TEST

IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5. NOW "NC" IS UPDATED BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS EXCEEDED BY ANY OF THE ABOVE VALUES. THE INITIAL VALUE OF "NC" IS "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	1
FT	-	0
FS	-	0

9.8 TEST 7 - RANDOM SEEK TEST

THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC' 'LC'. AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK. THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION OF POSITIONING OCCURS USING EACH HEAD. TRACK ADDRESSES ARE INCREMENTED BETWEEN PARAMETERS 'FT' AND 'LT'.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	5000
FC	-	0
LC	-	822
FT	-	0
LT	-	18

9.9 TEST 10 - SERVO SETTLE DOWN TEST

THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE. RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC'. 'NC1' STARTS AT VALUE 'FC'. AT THE COMPLETION OF 1000 (10) SEEKS, 'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED. THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.

WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD REGISTER (RLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO POSITION. THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND FOR THAT SECTOR. ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PACK WITH MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.

THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS. THE NECESSARY TIME DEPENDENT PARAMETERS OCCUR WITHIN THE REQUIRED TIME RANGE FREQUENTLY ENOUGH TO PERMIT THIS TEST TO BE EFFECTIVE.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	100
FT	-	0

9.10 TEST 11 - ALL SEEKS TEST

THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER TO ALL OTHER CYLINDERS.

BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC'. THE BEGINNING CYLINDER ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC'. THE SEQUENCE CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED.

THE FOLLOWING PARAMETERS ARE USED BY THIS TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	100
FT	-	0
FS	-	0

9.11 TEST 12 - ROTATIONAL SPEED TIMING TEST

THIS TEST WILL START A SEARCH TO CYLINDER 0, TRACK 0, SECTOR 0. AS SOON AS THE INTERRUPT OCCURS, THE GO BIT IS SET AGAIN AND THE OPERATION IS TIMED. THIS PROCEDURE IS REPEATED 10 TIMES THEN THE AVERAGE TIME IS CALCULATED AND CHECKED TO ENSURE IT IS WITHIN TOLERANCE:

16.67 MS/REV + 2% OR - 3.5% IF 60HZ
 16.67 MS/REV + 2% OR - 3.5% IF 50HZ.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
FT	-	0
FS	-	0

9.12 TEST 13 - ONE CYLINDER SEEK TIMING TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC'. THE TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK. THE TIME MUST BE LESS THAN 10MS.

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	822

9.13 TEST 14 - ACCESS TIME MEASUREMENT

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE ACCESS TIME MEASUREMENT. THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256 SEEKS). THE AVERAGE ACCESS TIME MUST BE LESS THAN 32 MS. CYLINDER 'LC' DEFAULTS TO 255 (10).

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	255

9.14 TEST 15 - MAXIMUM SEEK TIMING TEST

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE MAXIMUM SEEK TIME. THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256 SEEKS). THE MAXIMUM SEEK TIME MUST BE LESS THAN 54 MS. 'LC' DEFAULTS TO 822 (10).

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	822

9.15 TEST 16 - SECTOR ADDRESSING TEST

THIS TEST WRITES DATA INTO ALL SECTORS OF TRACK "FT". THE DATA WILL BE 256 WORDS OF THE SECTOR ADDRESS OF THE SECTOR BEING WRITTEN. A WRITE CHECK IS PERFORMED, THE BUFFER IS CLEARED (TO 177400) AND THE DATA IS READ AND COMPARED. THEN SECTOR 0 IS REWRITTEN AND SECTORS 0 - 31 ARE WRITE CHECKED. THEN SECTOR 1 IS REWRITTEN AND SECTORS 0 - 31 ARE WRITE CHECKED. THIS REWRITE AND WRITE CHECK PROCEDURE IS CONTINUED UP THROUGH REWRITE SECTOR 31 AND WRITE CHECK SECTORS 0-31.

THE TEST USES THE FOLLOWING PARAMETERS:

R - 1
 FC - 0
 FT - 0

9.16 TEST 17 - TRACK ADDRESSING TEST

THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES IN CYLINDER "FC" SECTOR "FS" OF EVERY TRACK WITH EACH TRACK GETTING ITS OWN TRACK ADDRESS. A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO INSURE THE DATA IS VALID. THEN TRACK 0 IS REWRITTEN AND TRACK 1 THROUGH TRACK 4 IS WRITE CHECKED. THEN TRACK 1 IS REWRITTEN AND TRACK 2 THROUGH TRACK 4 IS WRITE CHECKED. THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING TRACK 3 AND WRITE CHECKING TRACK 4.

THE TEST USES THE FOLLOWING PARAMETERS:

R - 1
 FC - 0
 FS - 0

9.17 TEST 20 - DATA TEST

THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS "FC" THROUGH "LC" BY THE INCREMENT "IC" USING THE DATA PATTERNS SPECIFIED. THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER:

1. SET "NT" TO "FT" THEN REPEAT 2-4 UNTIL "NT" > "LT"
2. WRITE THEN WRITE CHECK "FS" THROUGH "LS" OF TRACK "NT"
3. READ THEN SOFTWARE COMPARE "FS" THROUGH "LS" OF TRACK "NT"
4. INCREMENT "NT" BY "IT"
5. REPEAT STEPS 1-4 FOR EACH DATA PATTERN
6. REPEAT STEPS 1-5 FOR "FC" THROUGH "LC" ADVANCING BY "IC"

IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS FATAL AND NO READ OCCURS.

FS DEFAULTS TO 1 AND LS DEFAULTS TO 0
 PAT DEFAULTS TO 177777 (ALL POSSIBLE PATTERNS)
 THE POSSIBLE PATTERNS ARE:

PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
165555	000001	177776	000000	000000	052525	007417	026455
133333	000003	177774	000000	010421	052525	007417	026455
165555	000007	177770	000000	021042	052525	007417	026455
133333	000017	177760	177777	031463	125252	170360	151322
165555	000037	177740	177777	042104	125252	170360	151322
133333	000077	177700	177777	052525	125252	170360	151322
165555	000177	177600	000000	063146	052525	007417	026455
133333	000377	177400	000000	073567	052525	007417	026455
165555	000777	177000	177777	104210	125252	170360	151322
133333	001777	176000	177777	114631	125252	170360	151322
165555	003777	174000	000000	125252	052525	007417	026455
133333	007777	170000	177777	135673	125252	170360	151322
165555	017777	160000	000000	146314	052525	007417	026455
133333	037777	140000	177777	156735	125252	170360	151322
165555	077777	100000	000000	167356	052525	007417	026455

133333	177777	000000	177777	177777	125252	170360	151322
PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
165555	000001	177776	172666	077777	153333	000000	177777
133333	000002	177775	155555	137777	066667	177777	000000
165555	000004	177773	172666	157777	153333	177777	000000
133333	000010	177767	155555	167777	066667	177777	000000
165555	000020	177757	172666	173777	153333	177777	000000
133333	000040	177737	155555	175777	066667	177777	000000
165555	000100	177677	172666	176777	153333	177777	000000
133333	000200	177577	155555	177377	066667	177777	000000
165555	000400	177377	172666	177577	153333	177777	000000
133333	001000	176777	155555	177677	066667	177777	000000
165555	002000	175777	172666	177737	153333	177777	000000
133333	004000	173777	155555	177757	066667	177777	000000
165555	010000	167777	172666	177767	153333	177777	000000
133333	020000	157777	155555	177773	066667	177777	000000
165555	040000	137777	172666	177775	153333	177777	000000
133333	100000	077777	155555	177776	066667	177777	000000

SEQ 0023

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	821
IC	-	64
FT	-	0
LT	-	4
IT	-	1
FS	-	1
LS	-	0
PAT	-	177777

9.18 TEST 21 - RANDOM ADDRESS AND RANDOM PATTERN TEST

STARTING AT "FC" AND GOING THROUGH "LC" THE DISK PACK IS WRITTEN WITH A RANDOM PATTERN. THE FIRST TWO WORDS OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR FOR THAT SECTOR. THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE "R" TIMES "R" DEFAULTS TO 20,000.

1. GENERATE A RANDOM ADDRESS
2. WRITE A RANDOM PATTERN AT THE ADDRESS GENERATED IN 1.
3. GENERATE A RANDOM ADDRESS
4. READ THE SECTOR AT THE ADDRESS GENERATED IN 3.
5. DO A SOFTWARE CHECK OF THE DATA READ IN 4.
6. DO A WRITE CHECK OF THE DATA WRITTEN IN 2.
7. GENERATE A RANDOM ADDRESS
8. READ THE SECTOR AT THE ADDRESS GENERATED IN 7.
9. DO A SOFTWARE CHECK OF THE DATA READ IN 8.
10. DO A WRITE CHECK OF THE DATA WRITTEN IN 2.

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	20000
---	---	-------

FC - 0
LC - B21

SEG 0024

9.19 TEST 22 - RMO3 ACCESS TIME TEST

THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 255 TO ALLOW THE OPERATOR TO ADJUST THE ACCESS TIME ON AN RMO3 USING THE DDU. THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS SO THAT THE ACCESS TIME INDICATORS ON THE DDU MAY BE OBSERVED.

THE TEST USES THE FOLLOWING PARAMETERS:

R - 5000
FC - 0
LC - 255

I D E N T I F I C A T I O N

PRODUCT NAME: RMO3 SOFTWARE DRIVER MODULE

DATE CREATED: AUGUST 1977

MAINTAINER: DIAGNOSTIC ENGINEERING

AUTHOR: J. LACEY/C. HESS/C. CHEN

COPYRIGHT (C) 1977 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE
WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A
COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS
DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO
BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT
CORPORATION.DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR
RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS
NOT SUPPLIED BY DEC.THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE
TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH
INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH
SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING
BY DEC.

10.1 RH70/RM03 DRIVER MODULE

THIS DOCUMENT IS THE USER'S GUIDE FOR THE RH70/RM03 DRIVER.

10.2 TO INITIALIZE THE DRIVER:

```
JSR   PC,RMINIT
RETURN
```

UPON RETURN YOU MUST EXAMINE THE "DRVSTA" TABLE TO DETERMINE THE DRIVES THAT ARE ONLINE FOR TESTING. THE 'DRVSTA' TABLE IS EIGHT BYTES; ONE BYTE PER DRIVE. THE STATE OF EACH DRIVE WILL BE INDICATED AS FOLLOWS:

DRVSTA	DRIVE STATE
0	ONLINE RM03
=0	OFFLINE RM03 DRIVE IS NOT AN RM03, OR NONEXISTENT DRIVE
<0	UNSAFE RM03

THE DRIVE TYPE IS DEFINED IN AN 8 BYTE LONG TABLE TAGGED 'DRVTYP'. THE TABLE CONTAINS ONE BYTE FOR EACH DRIVE AND IS INDEXED BY THE DRIVE NUMBER. ENTRIES ARE ENCODED AS FOLLOWS.

DRVTYP	CONDITION
0	NONEXISTENT DRIVE
4	RM03
-1	NOT AN RM03

THE 'RMINIT' ROUTINE WILL DO A READIN PRESET AND WILL SET FMT22.

10.3 AFTER THE DRIVER HAS BEEN INITIALIZED, IT IS CALLED USING THE FOLLOWING SEQUENCE.

```
CALL: JSR   RO,RM03      ;MAKE THE CALL
       PNTDPB          ;ADDRESS OF DPB*
       RETURN1         ;RETURN IF QUEUE IS FULL
       RETURN2         ;RETURN IF REQUEST IS IN
                       ;QUEUE OR THERE IS AN
                       ;ERROR CONDITION
```

*DPB (DATA PARAMETER BLOCK)

PNTDPB: .BYTE	0	;(0) DRIVE NUMBER
.BYTE	0	;(1) OFFSET VALUE 0? FMT22, ECT, AND HCI
.BYTE	0	;(2) COMMAND
.BYTE	0	;(3) PSEL AND A17 AND A16
.WORD	0	;(4) WORD COUNT (MUST BE NEG.)
.WORD	0	;(6) BUFFER ADDRESS OR REGISTER TABLE POINTER
.BYTE	0	;(10) SECTOR ADDRESS OR FIRST REG. INDEX

```

.BYTE 0      ;(11) TRACK ADDRESS OR
              ;LAST REG. INDEX
.WORD 0      ;(12) CYLINDER ADDRESS
WORD 0      ;(14) ERROR TABLE POINTER
              ;POINTS TO THE FIRST OF TWENTY
              ;LOCATIONS OF WHERE THE DRIVER
              ;IS TO STORE THE R70/RM03
              ;REGISTERS ON AN ERROR. IF LEFT
              ;ZERO REGISTERS ARE NOT SAVED.
.WORD 0      ;(16) STATUS/ERROR INDICATOR
              ;BIT15=1=>ERROR OCCURRED
              ;BIT07=1=>DONE
              ;BIT14-BIT09 AND BIT06-BIT03
              ;INDICATE TYPE OF ERROR

```

10.4 THE DRIVER PROVIDES A SOFTWARE TIMEOUT CAPABILITY. TO UTILIZE THIS CAPABILITY YOU MUST SUPPLY THE "RM TIMER" ROUTINE WITH THE ELAPSED TIME IN THE FOLLOWING MANNER:

```

MOV    #15.,-(SP) ;16 MILLISECONDS BETWEEN
              ;CLOCK TICKS
JSR    PC,RMTMR  ;CALL THE TIMER ROUTINE

```

IT SHOULD BE NOTED THAT YOU MUST PROVIDE THE CODE TO DRIVE THE CLOCK. AND THE ELAPSED TIME MUST BE IN MILLISECONDS. THE DRIVER WILL SET THE TIMEOUT TO 1 SECOND FOR ALL POSITIONING AND DATA TRANSFER OPERATIONS AND WILL SET THE TIMEOUT TO 30 SECONDS FOR ERROR RECOVERY OPERATIONS.

10.4.1 EXAMPLE - WRITE 1000. WORDS

```

1S:    JSR    R0,RM03      ;CALL THE DRIVER
        WRTDPB      ;DPB ADDRESS
        BR     1S         ;WAIT FOR QUEUE IF FULL
2S:    TST    WRTDPB+16   ;WAIT FOR COMMAND TO COMPLETE
        BEQ    2S
        BMI    ERROR1    ;ERROR OCCURRED
        .
        .
        .

```

```

WRTDPB: .BYTE 5          ;DRIVE #5
        .BYTE 0
        .BYTE 161      ;WRITE COMMAND
        .BYTE 0
        .WORD -1000.   ;WORD COUNT
        .WORD WRTBUF   ;BUFFER ADDRESS
        .BYTE 3        ;SECTOR
        .BYTE 5        ;TRACK
        .WORD 400      ;CYLINDER
        .WORD ERRTB5   ;ERROR TABLE
        .WORD 0        ;STATUS/ERROR INDICATOR

```

ALTERNATE DPB SETUP

```

WRTDPB: .WORD 5          ;THIS SETUP ACHIEVED
        .WORD WRITE     ;EVERYTHING THE
        .WORD -1000.    ;ABOVE TABLE DID, BUT
        .WORD WRTBUF    ;IN A CLEANER FORMAT

```


.BYTE 3,5
.WORD 400,ERRTBS,0

10.5 RM70 RMD3 REGISTERS

MNEMONIC	INDEX
RMCS1	0
RMWC	1
RMBA	2
RMDA	3
RMCS2	4
RMD5	5
RMER1	6
RMA5	7
RMLA	8
RMDB	9
RMMR1	10
RMDT	11
RMSN	12
RMOF	13
RMDC	14
RMHR	15
RMMR2	16
RMER2	17
RMEC1	18
RMEC2	19

10.6 COMMANDS PERFORMED BY THE DRIVER

COMMAND	CODE	COMMAND TYPE
NO OPERATION	101	N
UNLOAD	103	N
SEEK	105	P
RECALIRATE	107	P
DRIVE CLEAR	111	N
RELEASE	113	N
OFFSET	115	P
RETURN TO CENTER	117	P
READIN PRESET	121	N
PACK ACKNOWLEDGE	123	N
SEARCH	131	P
GET REGISTER(S)	141	S
SET FORMAT	143	S

SELECT DRIVE	145	S
WRITE CHECK DATA	151	D
WRITE CHECK HEADER AND DATA	153	D
WRITE DATA	161	D
WRITE HEADER & DATA	163	D
READ DATA	171	D
READ HEADER & DATA	173	D

N = HOUSEKEEPING
P = POSITIONING
D = DATA TRANSFER
S = SPECIAL PROVIDED BY THE DRIVER

10.7 DPB STATUS/ERROR INDICATOR WORD

THIS INDICATOR WILL INFORM THE USER OF THE RESULTS OF THE REQUEST.
THIS IS ACCOMPLISHED BY SETTING VARIOUS BITS OF THE INDICATOR TO
A ONE.

BIT NO.	MEANING IF ON A "1"
-----	-----
15	ERROR OCCURRED DONE (BIT07=0); BITS 14-10 SPECIFIES TYPE DONE (BIT07=1); BITS 06-03 SPECIFIES TYPE
14(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON AN OFFLINE OR UNSAFE DRIVE
13	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON A DRIVE THAT HAS AN UNLOAD REQUEST IN QUEUE.
12(2)	PERSISTENT UNSAFE CONDITION EXIST.
11(2)	UNCORRECTABLE PARITY ERROR OCCURRED
10(2)(4)	FATAL PARITY ERROR. A MASSBUS CLEAR WAS PERFORMED. ALL QUEUES WERE EMPTIED, AND ALL DRVACT'S SET TO THE IDLE STATE
9(3)(4)	SOFTWARE TIMEOUT OCCURRED ON THIS DRIVE
8(4)	SOFTWARE TIMEOUT OCCURRED ON ANOTHER DRIVE
7	DONE
6(2)	ERROR OCCURRED DURING AN I/O OPERATION
5(2)	ERROR OCCURRED DURING AN OPERATION OTHER THAN I/O.

- 4(2) CORRECTABLE UNSAFE CONDITION OCCURRED
- 3(2) DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC "RECALIBRATE" SEQUENCE
- 2 PORT REQUEST TIMEOUT. THE DRIVER REQUESTED THE DRIVE BUT THE OPPOSITE PORT DID NOT RELEASE THE DRIVE WITHIN 20 SECONDS.
- 1 NON-EXISTENT DRIVE REQUESTED. USER MADE A REQUEST FOR A NON-EXISTENT DRIVE.
- (1) => REQUEST WASN'T PUT IN QUEUE. (rh70/RM03 REGISTERS WERE NOT SAVED)
- (2) => REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A "DRIVE CLEAR" TO THE DRIVE. NOTE: ALL rh70/RM03 REGISTERS ARE SAVED AS PER DPB+14 BEFORE THE "DRIVE CLEAR".
- (3) => REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A MASSBUS INIT. ALL rh70/RM03 REGISTERS FOR THE DRIVE WERE SAVED AS PER DPB+14 BEFORE THE INIT.
- (4) => A "RECALIBRATE" SHOULD BE ISSUED BEFORE ANY OTHER COMMAND.

10.8 ERROR CALLS MADE BY THE DRIVER.

THERE ARE A FEW ERRORS THAT CAN OCCUR THAT CAN NOT BE INDICATED IN A DPB.

WHEN THIS TYPE OF ERROR IS DETECTED BY THE DRIVER IT WILL MAKE AN ERROR CALL OF THE FORM "ERROR N", WHERE "N" IS THE ERROR NUMBER AND THE ERROR WILL BE AN EMT INSTRUCTION.

N	TYPE	DATA AVAILABLE
---	----	-----
1	RM70 INTERRUPT OCCURRED (RHAS=0)	*R4= RMCS1'S ADDRESS
2	UNEXPECTED ATTENTION OCCURRED	R1= DRIVE NUMBER R3= ATA BIT *R4= RMCS1'S ADDRESS R5= (RMAS) RMERRS =RMDS RMERRS+2=RMER1 RMERRS+4=RMER2 RMERRS+6=RMMR2
3	MASSBUS PARITY ERROR (MCPF=1)	RD.ADR= ADDRESS OF REG. READ RD.WRD= WORD READ
4	MASSBUS PARITY ERROR (PAR=1)	WRT.AD= ADDRESS OF REG. WRITTEN WRT.WD= WORD WRITTEN RD.WRD= WORD READ BACK
5	ADDRESS PLUG CHANGE	R1= DRIVE NUMBER

F03

BIT SET ('OPE' ERROR)

R3= ATA BIT
*R4= RMCSI'S ADDRESS
R5= (RMAS)
RMERRS =RMDS
RMERRS+2=RMER1
RMERRS+4=RMER2
RMERRS+6=RMMR2

SEG 0031

* THIS IS THE ACTUAL UNIBUS ADDRESS (176700)

!! PROGRAM LISTING

G03

MD-11-DZRMF-B RM03 RM02 EXTENDED DRIVE TEST
CZRMFB.F11 21-NOV-77 14:10

MACY11 30(1046) 22-NOV-77 08:04 PAGE 2

SEG 0032

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

.TITLE MD-11-DZRMF-B RM03/RM02 EXTENDED DRIVE TEST
.*COPYRIGHT (C) 1977
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*PROGRAM BY H. BLACKSTONE
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-'1-DZQAC-C3), JAN 19, 1977.
.*


```

000046 000200 000046 ;HOOKS REQUIRED BY ACT11
000052 000052 000000 ;SSVPC=. ;SAVE PC
000200 000200 000200 ;=46 ;:1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
000200 000137 004740 ;SENDAD ;:2)SET LOC.52 TO ZERO
000204 000137 004762 ;=52 ;: PESTORE PC
000210 000137 004730 ;WORD 0
000214 000137 004752 ;=SSVPC

.SBTTL STARTING ADDRESSES
;=200
;*200 = NORMAL START
JMP @START1
;*204 = SELECT OPERATING PARAMETERS
JMP @START2
;*210 = SELECT RH70/RM03 ADDRESSES
JMP @START3
;*214 = COMBINATION OF 204 AND 210
JMP @START4

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR ;:BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
HT= 11 ;:CODE FOR HORIZONTAL TAB
LF= 12 ;:CODE FOR LINE FEED
CR= 15 ;:CODE FOR CARRIAGE RETURN
CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;:PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774 ;:STACK LIMIT REGISTER
PIRQ= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 ;:HARDWARE SWITCH REGISTER
DDISP= 177570 ;:HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0 ;:GENERAL REGISTER
R1= %1 ;:GENERAL REGISTER
R2= %2 ;:GENERAL REGISTER
R3= %3 ;:GENERAL REGISTER
R4= %4 ;:GENERAL REGISTER
R5= %5 ;:GENERAL REGISTER
R6= %6 ;:GENERAL REGISTER
R7= %7 ;:GENERAL REGISTER
SP= %6 ;:STACK POINTER
PC= %7 ;:PROGRAM COUNTER

;*PRIORITY LEVEL DEFINITIONS
PR0= 0 ;:PRIORITY LEVEL 0
PR1= 40 ;:PRIORITY LEVEL 1
PR2= 100 ;:PRIORITY LEVEL 2
PR3= 140 ;:PRIORITY LEVEL 3
PR4= 200 ;:PRIORITY LEVEL 4

```

124 000240
125 000300
126 000340

PR5= 240 ;: PRIORITY LEVEL 5
PR6= 300 ;: PRIORITY LEVEL 6
PR7= 340 ;: PRIORITY LEVEL 7

128 100000
129 040000
130 020000
131 010000
132 004000
133 002000
134 001000
135 000400
136 000200
137 000100
138 000040
139 000020
140 000010
141 000004
142 000002
143 000001

:*"SWITCH REGISTER" SWITCH DEFINITIONS

SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2
.EQUIV SW01,SW1
.EQUIV SW00,SW0

145 100000
146 040000
147 020000
148 010000
149 004000
150 002000
151 001000
152 000400
153 000200
154 000100
155 000040
156 000020
157 000010
158 000004
159 000002
160 000001

:*DATA BIT DEFINITIONS (BIT00 TO BIT15)

BIT15= 100000
BIT14= 40000
BIT13= 20000
BIT12= 10000
BIT11= 4000
BIT10= 2000
BIT09= 1000
BIT08= 400
BIT07= 200
BIT06= 100
BIT05= 40
BIT04= 20
BIT03= 10
BIT02= 4
BIT01= 2
BIT00= 1
.EQUIV BIT09,BIT9
.EQUIV BIT08,BIT8
.EQUIV BIT07,BIT7
.EQUIV BIT06,BIT6
.EQUIV BIT05,BIT5
.EQUIV BIT04,BIT4
.EQUIV BIT03,BIT3

174
175
176
177
178
179

180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235

```

.EQUIV BIT02,BIT2
.EQUIV BIT01,BIT1
.EQUIV BIT00,BIT0

;*BASIC "CPU" TRAP VECTOR ADDRESSES
ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS
TBITVEC=14 ;: "T" BIT
TRTVEC= 14 ;: TRACE TRAP
BPTVEC= 14 ;: BREAKPOINT TRAP (BPT)
IOTVEC= 20 ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
PWRVEC= 24 ;: POWER FAIL
EMTVEC= 30 ;: EMULATOR TRAP (EMT) **ERROR**
TRAPVEC=34 ;: "TRAP" TRAP
TKVEC= 60 ;: TTY KEYBOARD VECTOR
TPVEC= 64 ;: TTY PRINTER VECTOR
PIRQVEC=240 ;: PROGRAM INTERRUPT REQUEST VECTOR
; ;*****

.SBTTL RH70 REGISTERS
; ;*****

:CONTROL AND STATUS REGISTER 1 (RMCS1)
IE= 100 ;: INTERRUPT ENABLE (BIT #6)
RDY= 200 ;: READY (BIT #7)
A16= 400 ;: HIGH ORDER BUS ADDRESS BIT (BIT #8)
A17= 1000 ;: HIGH ORDER BUS ADDRESS BIT (BIT #9)
PSEL= 2000 ;: PORT SELECT (BIT #10)
MCPE= 20000 ;: MASSBUS PARITY ERROR (BIT #13)
TRE= 40000 ;: TRANSFER ERROR (BIT #14)
;SC= 100000 ;: SPECIAL CONDITION (BIT #15)

:WORD COUNT REGISTER (RMWC)
;(EACH BIT IS CALLED BY BIT NUMBER)

:BUS ADDRESS REGISTER (RMBA)
;(EACH BIT IS CALLED BY BIT NUMBER)

:CONTROL AND STATUS REGISTER 2 (RMCS2)
US1= 1 ;: UNIT SELECT (BIT #0)
US2= 2 ;: UNIT SELECT (BIT #1)
US4= 4 ;: UNIT SELECT (BIT #2)
BAI= 10 ;: BUS ADDRESS INCREMENT INHIBIT (BIT #3)
;PAT= 20 ;: MASSBUS PARITY TEST (BIT #4)
CLR= 40 ;: CLEAR (BIT #5)
IR= 100 ;: INPUT READY (BIT #6)
OR= 200 ;: OUTPUT READY (BIT #7)
MPE= 400 ;: MASS BUS PARITY ERROR (BIT #8)
MXF= 1000 ;: MISSED TRANSFER ERROR (BIT #9)
PGE= 2000 ;: PROGRAM ERROR (BIT #10)
NEM= 4000 ;: NON EXISTENT MEMORY (BIT #11)
NED= 10000 ;: NON EXISTENT DRIVE (BIT #12)
UPE= 20000 ;: UNIBUS PARITY ERROR (BIT #13)

000004
000010
000014
000014
000014
000020
000024
000030
000034
000060
000064
000240

000100
000200
000400
001000
002000
020000
040000

000001
000002
000004
000010
000040
000100
000200
000400
001000
002000
004000
010000
020000

```


M03

;MAINTAINABILITY REGISTER #01 (RMMR1)(#03) - READ ONLY BITS

292		
293		
294	000001	DMD= 1
295	000002	LSIT= 2
296		;LS=4
297		WD= 10
298	000010	EECC= 20
299	000020	WC= 40
300	000040	CONT= 100
301	000100	PHA= 200
302	000200	PDA= 400
303	000400	ECRC= 1000
304	001000	PLFS= 2000
305	002000	ESRC= 4000
306	004000	REX= 10000
307	010000	EBL= 20000
308	020000	:R/G= 40000
309		OCC= 100000
310	100000	

;DIAGNOSTIC MODE

;MAINTAINABILITY REGISTER #01 (RMMR1) (#03) - WRITE ONLY BITS

311		
312		
313	000001	DMD= 1
314	000002	MSC= 2
315	000004	MI= 4
316	000010	MWP= 10
317	000020	DTG= 20
318	000040	MS= 40
319	000100	MDF= 100
320	000200	MSER= 200
321	000400	MOC= 400
322	001000	MUR= 1000
323	002000	MAD= 2000
324	004000	MCLK= 4000
325	010000	MSEN= 10000
326	020000	DTG= 20000
327	040000	OBEN=40000
328	100000	OBCK= 100000

;DIAGNOSTIC MODE BIT

;ATTENTION SUMMARY PSEUDO-REGISTER (RMAS) (#04)

329	000001	AT0= 1	;DEVICE 0 (BIT #0)
330	000002	AT1= 2	;DEVICE 1 (BIT #1)
331	000004	AT2= 4	;DEVICE 2 (BIT #2)
332	000010	AT3= 10	;DEVICE 3 (BIT #3)
333	000020	AT4= 20	;DEVICE 4 (BIT #4)
334	000040	AT5= 40	;DEVICE 5 (BIT #5)
335	000100	AT6= 100	;DEVICE 6 (BIT #6)
336	000200	AT7= 200	;DEVICE 7 (BIT #7)

;DESIRED SECTOR/TRACK ADDRESS REGISTER (RMDA) (#05)
;(EACH BIT IS CALLED BY BIT NUMBER)

;DRIVE TYPE REGISTER (RMDT) (#06)

337	000001	DT00= 1	;DRIVE TYPE NUMBER BIT 1
338	000002	DT01= 2	;DRIVE TYPE NUMBER BIT 2

```

348      000004      DT02= 4      ;DRIVE TYPE NUMBER BIT 3
349      000010      DT03= 10     ;DRIVE TYPE NUMBER BIT 4
350      000020      DT04= 20     ;DRIVE TYPE NUMBER BIT 5
351      000040      DT05= 40     ;DRIVE TYPE NUMBER BIT 6
352      000100      DT06= 100    ;DRIVE TYPE NUMBER BIT 7
353      000200      DT07= 200    ;DRIVE TYPE NUMBER BIT 8
354      000400      DT08= 400    ;DRIVE TYPE NUMBER BIT 9
355      004000      DRQ= 4000   ;DRIVE REQUEST REQUIRED (BIT #11)
356      020000      MOH= 20000  ;MOVING HEAD (BIT #13)
357      040000      TAP= 40000  ;TAPE DRIVE (BIT #14)
358      100000      NBA= 100000 ;NOT BLOCK ADDRESSED (BIT #15)
359
360      ;LOOK-AHEAD REGISTER (RMLA) (#07)
361
362
363      000100      SC0= 100    ;SECTOR COUNT FIELD 0 (BIT #6)
364      000200      SC1= 200    ;SECTOR COUNT FIELD 1 (BIT #7)
365      000400      SC2= 400    ;SECTOR COUNT FIELD 2 (BIT #8)
366
367      ;SC3= 1000   ;SECTOR COUNT FIELD 3 (BIT #9)
368      ;SC4= 2000   ;SECTOR COUNT FIELD 4 (BIT #10)
369
370      ;RM03 MAINTAINABILITY REGISTER #2 (RMMR2) (#10)
371
372
373
374
375
376
377
378
379
380
381
382      ;RM03 ERROR REGISTER #02 (RMMR2) (#10)
383
384
385
386
387
388
389
390
391
392
393
394      ;OFFSET REGISTER (RMOF) (#11)
395
396      000001      OFFDIR= 1      ;RM03 OFFSET DIRECTION
397      002000      HCI= 2000   ;HEADER COMPARE INHIBIT (BIT #10)
398      004000      ECI= 4000   ;ERROR CORRECTION CODE INHIBIT (BIT #11)
399      010000      FMT22= 10000  ;FORMAT BIT (BIT #12)
400
401      ;DESIRED CYLINDER ADDRESS (RMDC) (#12)
402      ;(EACH BIT IS CALLED BY BIT NUMBER)
403

```


104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200

; CURRENT CYLINDER ADDRESS (RMHR) (#13)
; (EACH BIT IS CALLED BY BIT NUMBER)

; SERIAL NUMBER REGISTER (RMSN) (#14)
; (EACH IS CALLED BY BIT NUMBER)

; RM03 ERROR REGISTER #02 (RMER2) (#15)

020000
040000

OPE= 20000 ; OPERATOR PLUG ERROR (BIT #13)
SKI= 40000 ; SEEK INCOMPLETE (BIT #15)

; ECC POSITION REGISTER (RMEC1) (#16)
; (EACH BIT IS CALLED BY BIT NUMBER)

; ECC PATTERN REGISTER (RMEC2) (#17)
; (EACH BIT IS CALLED BY BIT NUMBER)

; *****

; OP CODE DEFINITIONS

000101
000103
000105
000107
000111
000113
000115
000117
000121
000123
000131
000151
000153
000161
000163
000171
000173
000141
000143
000145

NOOP=101
UNLOAD=103
SEEK=105
RECAL=107
DRVCLR=111
RELEASE=113
OFFSET=115
RTC=117
READIN=121
PACK=123
SEARCH=131
WRCKD=151
WRCKHD=153
WRITE=161
WRTHD=163
READ=171
READHD=173
GETREG=141
SETFORM=143
SELDRV=145

; OTHER EQUATES

177400
010000

SCTRWC = -256.
FMT22=10000

; WORD COUNT FOR SECTOR
; FORMAT 22 BIT

```

453
454
455
456
457
458      000220
459      000024
460 000024 00020C
461      000044
462 000044 000220
463      000220
464
465
466
467
468 000220
469 000220 000000
470 000222 001220
471 000224 001604
472 000226 001604
473 000230 001604
474 000232 000030

```

```

.SBTTL APT PARAMETER BLOCK
*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
*****
.$x=      :SAVE CURRENT LOCATION
.=24     :SET POWER FAIL TO POINT TO START OF PROGRAM
200      :FOR APT START UP
.=44     :POINT TO APT INDIRECT ADDRESS PNTR.
$APTHDR  :POINT TO APT HEADER BLOCK
.=.$x    :RESET LOCATION COUNTER
*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.

```

```

$APTHD:
$HIBTS: .WORD 0 ;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL ;ADDRESS OF APT MAILBOX (BITS 0-15)
$TSTM: .WORD 900. ;RUN TIM OF LONGEST TEST
$PASTM: .WORD 900. ;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 900. ;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
        .WORD $ETEND-$MAIL/2 ;LENGTH MAILBOX-ETABLE(WORDS)

```

475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530

001100 001100
001100 000000
001102 000
001103 000
001104 000000
001106 000000
001110 000000
001112 000000
001114 000
001115 001
001116 000000
001120 000000
001122 000000
001124 000000
001126 000000
001130 000000
001132 000000
001134 000
001135 000
001136 000000
001140 177570
001142 177570
001144 177560
001146 177562
001150 177564
001152 177566
001154 000
001155 002
001156 012
001157 000
001160 000000
001162 000000
001164 000000
001166 000000
001170 000000
001172 000000
001174 000000
001176 000000
001200 000000
001202 000000
001204 000000
001206 000000
001210 177607 000377
001214 077
001215 015
001216 000012

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

.=1100

SCMTAG: .WORD 0
STSTNM: .BYTE 00
SERFLG: .BYTE 00
SICNT: .WORD 00
SLPADR: .WORD 00
SLPERR: .WORD 00
SERTTL: .WORD 00
SITEMB: .BYTE 00
SERMAX: .BYTE 1
SERRPC: .WORD 00
SGDADR: .WORD 00
SBDADR: .WORD 00
SGDAT: .WORD 00
SBDAT: .WORD 00
SAUTOB: .BYTE 00
SINTAG: .BYTE 00
SWR: .WORD DSWR
DISPLAY: .WORD DDISP
STKS: 177560
STKB: 177562
STPS: 177564
STPB: 177566
SNUL: .BYTE 0
SFILLS: .BYTE 2
SFILLC: .BYTE 12
STPFLG: .BYTE 0
SREGAD: .WORD 0
SREG0: .WORD 0
SREG1: .WORD 00
SREG2: .WORD 00
SREG3: .WORD 00
SREG4: .WORD 00
SREG5: .WORD 00
STMP0: .WORD 00
STMP1: .WORD 00
STMP2: .WORD 00
STIMES: 0
\$ESCAPE: 0
\$BELL: .ASCIZ <207><377><377>
\$QUES: .ASCII /?/
\$CRLF: .ASCII <15>
\$LF: .ASCIZ <12>

:: START OF COMMON TAGS

:: CONTAINS THE TEST NUMBER
:: CONTAINS ERROR FLAG
:: CONTAINS SUBTEST ITERATION COUNT
:: CONTAINS SCOPE LOOP ADDRESS
:: CONTAINS SCOPE RETURN FOR ERRORS
:: CONTAINS TOTAL ERRORS DETECTED
:: CONTAINS ITEM CONTROL BYTE
:: CONTAINS MAX. ERRORS PER TEST
:: CONTAINS PC OF LAST ERROR INSTRUCTION
:: CONTAINS ADDRESS OF 'GOOD' DATA
:: CONTAINS ADDRESS OF 'BAD' DATA
:: CONTAINS 'GOOD' DATA
:: CONTAINS 'BAD' DATA
:: RESERVED--NOT TO BE USED
:: AUTOMATIC MODE INDICATOR
:: INTERRUPT MODE INDICATOR
:: ADDRESS OF SWITCH REGISTER
:: ADDRESS OF DISPLAY REGISTER
:: TTY KBD STATUS
:: TTY KBD BUFFER
:: TTY PRINTER STATUS REG. ADDRESS
:: TTY PRINTER BUFFER REG. ADDRESS
:: CONTAINS NULL CHARACTER FOR FILLS
:: CONTAINS # OF FILLER CHARACTERS REQUIRED
:: INSERT FILL CHARS. AFTER A "LINE FEED"
:: "TERMINAL AVAILABLE" FLAG (BIT 07)=0=YES,
:: CONTAINS THE ADDRESS FROM
:: WHICH (\$REG0) WAS OBTAINED
:: CONTAINS ((\$REGAD)+0)
:: CONTAINS ((\$REGAD)+2)
:: CONTAINS ((\$REGAD)+4)
:: CONTAINS ((\$REGAD)+6)
:: CONTAINS ((\$REGAD)+10)
:: CONTAINS ((\$REGAD)+12)
:: USER DEFINED
:: USER DEFINED
:: USER DEFINED
:: MAX NUMBER OF ITERATIONS
:: ESCAPE ON ERROR ADDRESS
:: CODE FOR BELL
:: QUESTION MARK
:: CARRIAGE RETURN
:: LINE FEED

.SBTTL AP MAILBOX-ETABLE

```

531
532
533 ;*****
534 .EVEN
535 001220 000000 $MAIL: .WORD AMSGTY ;; APT MAILBOX
536 001222 000000 $FATAL: .WORD AFATAL ;; MESSAGE TYPE CODE
537 001224 000000 $TESTN: .WORD ATESTN ;; FATAL ERROR NUMBER
538 001226 000000 $PASS: .WORD APASS ;; TEST NUMBER
539 001230 000000 $DEVCT: .WORD ADEVCT ;; PASS COUNT
540 001232 000000 $UNIT: .WORD AUNIT ;; DEVICE COUNT
541 001234 000000 $MSGAD: .WORD AMSGAD ;; I/O UNIT NUMBER
542 001236 000000 $MSGLG: .WORD AMSGLG ;; MESSAGE ADDRESS
543 001240 000000 $ETABLE: .WORD ;; MESSAGE LENGTH
544 001240 000 $ENV: .BYTE AENV ;; APT ENVIRONMENT TABLE
545 001241 000 $ENVM: .BYTE AENVM ;; ENVIRONMENT BYTE
546 001242 000000 $SWREG: .WORD ASWREG ;; ENVIRONMENT MODE BITS
547 001244 000000 $USWR: .WORD AUSWR ;; APT SWITCH REGISTER
548 001246 000000 $CPUOP: .WORD ACPUOP ;; USER SWITCHES
549
550 ;; CPU TYPE, OPTIONS
551 ;; BITS 15-11=CPU TYPE
552 ;; 11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
553 ;; 11/70=06, PDQ=07, Q=10
554 ;; BIT 10=REAL TIME CLOCK
555 ;; BIT 9=FLOATING POINT PROCESSOR
556 ;; BIT 8=MEMORY MANAGEMENT
557 001250 000 $MAMS1: .BYTE AMAMS1 ;; HIGH ADDRESS, M.S. BYTE
558 001251 000 $MTYP1: .BYTE AMTYP1 ;; MEM. TYPE, BLK#1
559 ;; MEM. TYPE BYTE -- (HIGH BYTE)
560 ;; 900 NSEC CORE=001
561 ;; 300 NSEC BIPOAR=002
562 ;; 500 NSEC MOS=003
563 001252 000000 $MADR1: .WORD AMADR1 ;; HIGH ADDRESS, BLK#1
564 ;; MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
565 001254 000 $MAMS2: .BYTE AMAMS2 ;; HIGH ADDRESS, M.S. BYTE
566 001255 000 $MTYP2: .BYTE AMTYP2 ;; MEM. TYPE, BLK#2
567 001256 000000 $MADR2: .WORD AMADR2 ;; MEM. LAST ADDRESS, BLK#2
568 001260 000 $MAMS3: .BYTE AMAMS3 ;; HIGH ADDRESS, M.S. BYTE
569 001261 000 $MTYP3: .BYTE AMTYP3 ;; MEM. TYPE, BLK#3
570 001262 000000 $MADR3: .WORD AMADR3 ;; MEM. LAST ADDRESS, BLK#3
571 001264 000 $MAMS4: .BYTE AMAMS4 ;; HIGH ADDRESS, M.S. BYTE
572 001265 000 $MTYP4: .BYTE AMTYP4 ;; MEM. TYPE, BLK#4
573 001266 000000 $MADR4: .WORD AMADR4 ;; MEM. LAST ADDRESS, BLK#4
574 001270 000000 $VECT1: .WORD AVECT1 ;; INTERRUPT VECTOR#1, BUS PRIORITY#1
575 001272 000000 $VECT2: .WORD AVECT2 ;; INTERRUPT VECTOR#2, BUS PRIORITY#2
576 001274 000000 $BASE: .WORD ABASE ;; BASE ADDRESS OF EQUIPMENT UNDER TEST
577 001276 000000 $DEVN: .WORD ADEVN ;; DEVICE MAP
578 001300 000000 $ETEND:
579 .MEXIT
580 CR = 15
581 LF = 12
582 001300 000000 C.SWR: .WORD 0 ;; CONTROL SWITCHES
583 001302 000000 SAVCSW: .WORD 0 ;; PREVIOUS CONTENTS OF 'C.SWR'
584 001304 000000 CNTRLC: .WORD 0 ;; CONTROL "C" FLAG
585 001306 000000 BUSADR: .WORD 0 ;; GET ADDRESSES FROM THE TTY FLAG (0=NO, -1=YES)
586 001310 000000 LPTAVL: .WORD 0 ;; LPT AVAILABLE STATUS (0=NO, 1=YES)
587 001312 000000 DRVSEL: .WORD 0 ;; DRIVES SELECTED FOR TESTING
588 001314 176777 000003 TSTNMS: .WORD 176777.3 ;; DEFAULT IS RUN TESTS 0-10 & 12-21

```

587	001320	000000	000000	OPNFLG: .WORD	0,0	: MODIFY TEST PARAMETER FLAGS
588	001324	000000		CLKSTA: .WORD	0	: CLOCK STATUS (0=NO CLOCK,+1=KW11-P,
589						: AND -1=KW11-L)
590	001326	000000		TICKMS: .WORD	16.	: 16 MILLISECOND PER CLOCK TICK
591	001330	040432		TICKUS: .WORD	16666.	: 16666 MIRCOCSECONDS PER CLOCK TICK
592	001332	000000		BYPASS: .WORD	0	
593	001334	000000		CHKDRV: .WORD	0	: DRIVE UNDER TEST
594	001336	000000		DRVMSK: .WORD	0	: DRIVE MASK BIT
595	001340	000000		SVSTAT: .WORD	0	: STATUS/ERROR INDICATOR IS
596						: SAVED HERE ON AN ERROR
597	001342	000000		CYL.RD: .WORD	0	: CYLINDER READ
598	001344	000000		TRK.RD: .WORD	0	: TRACK READ
599	001346	000000		SEC.RD: .WORD	0	: SECTOR READ
600	001350	000000		CYL.DS: .WORD	0	: CYLINDER DESIRED
601	001352	000000		SEC.DS: .WORD	0	: SECTOR DESIRED
602	001354	000000		TRK.DS: .WORD	0	: TRACK DESIRED
603	001358	000000		TIM.UP: .WORD	0	: MINIMUM TIME
604	001360	000000			0	: NUMBER OF COUNTS BELOW MIN. LIMIT
605	001362	000000			7	: MAXIMUM TIME
606	001364	000000			0	: NUMBER OF COUNTS ABOVE MAX. LIMIT
607	001366	000000	000000		0,0	: TOTAL TIME OF ALL SEEKS
608	001372	000000			0	: NUMBER OF SEEKS PERFORMED
609	001374	000000		TIM.DN: .WORD	0	: MINIMUM TIME
610	001376	000000			0	: NUMBER OF COUNTS BELOW MIN. LIMIT
611	001400	000000			0	: MAXIMUM TIME
612	001402	000000			0	: NUMBER OF COUNTS ABOVE MAX. LIMIT
613	001404	000000	000000		0,0	: TOTAL TIME OF ALL SEEKS
614	001410	000000			0	: NUMBER OF SEEKS PERFORMED
615	001412	000000		TIM.PT: .WORD	0	: POINTS TO TABLE OF TIMES
616	001414	000000		WCEFLG: .WORD	0	: FATAL WRITE CHECK ERROR FLAG (TEST 20)
617	001416	000000		STALLO: .WORD	0	: VARIABLE STALL (TEST 4)
618	001420	000000	000000	SVADR: .WORD	0,0	: SAVE DISK ADDRESS (TEST 22)
619	001424	000000		SEKTR: .WORD	0	: SEEK TIMER (TEST 10)
620	001426	000000		SEKCN: .WORD	0	: SEEK COUNTER
621	001430	000000		DELTA: .WORD	0	: TESTING RANGE FOR SERVO SETTLE DOWN TEST
622	001432	160000		TRCKWC: .WORD	-<256.*32.>	: WORD COUNT FOR A FULL TRACK IN 16 BIT MODE
623	001434	000012		STALL1: .WORD	10.	: 10 MILLISECOND STALL (TEST 0-11)
624	001436	000012		STALL2: .WORD	10.	: 10 MILLISECOND STALL (TEST 16-21)
625	001440	011610		STALL3: .WORD	5000.	: 5 SEC STALL (TEST 22)
626	001442	000031		MXSTAL: .WORD	25.	: MAX. INCREMENTING STALL ALLOWED IN TEST 4
627	001444	144		ERR.CT: .BYTE	100.	: NUMBER OF ERRORS ALLOWED IN TESTS 16 - 21
628						: BEFORE GOING TO THE NEXT TEST
629	001446	000		BASFLG: .BYTE	0	: RESERVED
630	001446	000000			0	: FLAG FOR DETECTING BAD SECTOR
631						
632				: ADDRESSES AND VECTORS		
633	001450	176700		RH.ADR: .WORD	176700	: RH70 UNIBUS ADDRESS
634	001452	000254	000240	RHVEC: .WORD	254,5*32.	: RH70 VECTOR ADDRESS AND PRIORITY
635	001456	000104	000106	PKV: .WORD	104,106	: KW11-P VECTOR ADDRESS
636	001462	172540		PKCS: .WORD	172540	: KW11-P CONTROL AND STATUS REG.
637	001464	172542		PKB: .WORD	172542	: KW11-P COUNT SET BUFFER
638	001466	172544		PKC: .WORD	172544	: KW11-P COUNTER
639	001470	000100	000102	LKV: .WORD	100,102	: KW11-L VECTOR ADDRESS
640	001474	177546		LKS: .WORD	177546	: KW11-L STATUS REGISTER
641	001476	177564		TPS: .WORD	177564	: TTY PRINTER STATUS
642	001500	177566		TPB: .WORD	177566	: TTY PRINTER BUFFER

643 001502 177514 LPS: .WORD 177514 ;LINE PRINTER STATUS
644 001504 177516 LPB: .WORD 177516 ;LINE PRINTER BUFFER

645
646
647 001506 000001 ;BIT TABLE
648 001510 000002 BITS: .WORD BIT00
649 001512 000004 .WORD BIT01
650 001514 000010 .WORD BIT02
651 001516 000020 .WORD BIT03
652 001520 000040 .WORD BIT04
653 001522 000100 .WORD BIT05
654 001524 000200 .WORD BIT06
655 001526 000400 .WORD BIT07
656 001530 001000 .WORD BIT08
657 001532 002000 .WORD BIT09
658 001534 004000 .WORD BIT10
659 001536 010000 .WORD BIT11
660 001540 020000 .WORD BIT12
661 001542 040000 .WORD BIT13
662 001544 100000 .WORD BIT14
663 001546 000001 .WORD BIT15
664 001550 000002 .WORD BIT00
665 001552 000004 .WORD BIT01
666 001554 000010 .WORD BIT02
667 001556 000020 .WORD BIT03
668 001560 000040 .WORD BIT04
669 001562 000100 .WORD BIT05
670 001564 000200 .WORD BIT06
671
672
673

674 001566 000000 ;COMMON STORAGE FOR TEST PARAMETER
675 PRM: .WORD 0 ;THIS WORD TELLS WHICH OF THE
676 001570 000000 RPT: .WORD 0 ;FOLLOWING PARAMETERS ARE TO BE USED
677 001572 000000 FC: .WORD 0 ;REPEAT COUNTS FOR ALL TESTS
678 001574 000000 LC: .WORD 0 ;FIRST CYLINDER
679 001576 000000 IC: .WORD 0 ;LAST CYLINDER
680 001600 000000 FT: .WORD 0 ;INCREMENT CYLINDER
681 001602 000000 LT: .WORD 0 ;FIRST TRACK
682 001604 000000 IT: .WORD 0 ;LAST TRACK
683 001606 000000 FS: .WORD 0 ;INCREMENT TRACK
684 001610 000000 LS: .WORD 0 ;FIRST SECTOR
685 001612 000000 PAT: .WORD 0 ;LAST SECTOR
686 001614 000000 NC1: .WORD 0 ;PATTERN CODE
687 001616 000000 NC2: .WORD 0 ;NEW CYLINDER ADDRESS
688 ;NEW CYLINDER ADDRESS
689

690 001620 002412 ;TABLE OF PARAMETER POINTERS
691 001622 002426 PRMPT: .WORD PRM0
692 001624 002454 .WORD PRM1
693 001626 002476 .WORD PRM2
694 001630 002520 .WORD PRM3
695 001632 002542 .WORD PRM4
696 001634 002564 .WORD PRM5
697 001636 002606 .WORD PRM6
698 001640 002626 .WORD PRM7
699 .WORD PRM10

699	001642	002646	.WORD	PRM11
700	001644	002670	.WORD	PRM12
701	001646	002704	.WORD	PRM13
702	001650	002720	.WORD	PRM14
703	001652	002734	.WORD	PRM15
704	001654	002750	.WORD	PRM16
705	001656	002762	.WORD	PRM17
706	001660	002774	.WORD	PRM20
707	001662	003026	.WORD	PRM21
708	001664	003042	.WORD	PRM22
709	001666	000000	.WORD	0

; TERMINATOR

: TABLE OF PARAMETER UPPER LIMITS

712	001670	032767	PRMLMT: .WORD	32767	:"R"
713	001672	001466	.WORD	822.	:"FC"
714	001674	001466	.WORD	822.	:"LC"
715	001676	001466	.WORD	822.	:"FC"
716	001700	001466	.WORD	822.	:"LC"
717	001702	001466	.WORD	822.	:"IC"
718	001704	000004	.WORD	4	:"FT"
719	001706	000004	.WORD	4	:"LT"
720	001710	000004	.WORD	4	:"IT"
721	001712	000037	.WORD	31.	:"FS"
722	001714	000037	.WORD	31.	:"LS"
723	001716	177777	.WORD	177777	:"PAT"

: TABLE OF MESSAGE POINTERS

726	001720	045104	PRMMSG: .WORD	MSG.R
727	001722	045106	.WORD	MSG.FC
728	001724	045111	.WORD	MSG.LC
729	001726	045114	.WORD	MSGFCP
730	001730	045120	.WORD	MSGLCP
731	001732	045124	.WORD	MSG.IC
732	001734	045127	.WORD	MSG.FT
733	001736	045132	.WORD	MSG.LT
734	001740	045135	.WORD	MSG.IT
735	001742	045140	.WORD	MSG.FS
736	001744	045143	.WORD	MSG.LS

: STATUS/ERROR INDICATOR MESSAGES POINTER TABLE
: DEFAULT VALUES OF TEST PARAMETERS

743	001746	001125	000310	000632	DFLT: .WORD	1125,200.,410.,822.,0,0	; RECAL/SEEK (T0)
744	001754	001466	000000	000000	.WORD	3377,100.,0,128.,0,256.,0,0,0,0,0	; SEEK/SEEK (T1)
745	001762	003377	000144	000000			
746	001770	000200	000000	000400			
747	001776	000000	000000	000000			
748	002004	000000	000000				
749	002010	001177	000001	000000	.WORD	1177,1,0,410.,0,822.,1,0,0	; INCREMENT SEEK (T2)
750	002016	000632	000000	001466			
751	002024	000001	000000	000000			
752	002032	001177	000010	000000	.WORD	1177,10,0,256.,0,512.,1,0,0	; STEPPING SEEK (T3)
753	002040	000400	000000	001000			
754	002046	000001	000000	000000			


```

755 002054 001177 000001 000000 .WORD 1177,1,0,410.,0,822.,1,0,0 ;OSCILLATING SEEK (T4)
756 002062 000632 000000 001466
757 002070 000001 000000 000000
758 002076 001177 000001 000000 .WORD 1177,1,0,410.,0,822.,1,0,0 ;CONVERGING/DIVERGING SEEK (T5)
759 002104 000632 000000 001466
760 002112 000001 000000 000000
761 002120 001177 000001 000000 .WORD 1177,1,0,410.,0,822.,1,0,0 ;SERVO ADDRESSING LOGIC NOISE (T6)
762 002126 000632 000000 001466
763 002134 000001 000000 000000
764 002142 000337 011610 000000 .WORD 337,5000.,0,410.,0,822.,0,4 ;RANDOM SEEK TEST (T7)
765 002150 000632 000000 001466
766 002156 000000 000004
767 002162 000177 000001 000000 .WORD 177,1,0,410.,0,822.,100.,0 ;SERVO SETTLE DOWN TEST (T10)
768 002170 000632 000000 001466
769 002176 000144 000000
770 002202 001177 000001 000000 .WORD 1177,1,0,410.,0,822.,1,0,0 ;ALL SEEKS TEST (T11)
771 002210 000632 000000 001466
772 002216 000001 000000 000000
773 002224 001113 000001 000000 .WORD 1113,1,0,0,0,0 ;ROTATIONAL SPEED TIMING TEST (T12)
774 002232 000000 000000 000000
775 002240 000037 000001 000000 .WORD 37,1,0,410.,0,822. ;ONE CYLINDER SEEK TIMING TEST (T13)
776 002246 000632 000000 001466
777 002254 000037 000001 000000 .WORD 37,1,0,136.,0,255. ;ACCESS TIME MEASUREMENT TEST (T14)
778 002262 000210 000000 000377
779 002270 000037 000001 000000 .WORD 37,1,0,410.,0,822. ;MAXIMUM SEEK TIMING TEST (T15)
780 002276 000632 000000 001466
781 002304 000113 000001 000000 .WORD 113,1,0,0,0 ;SECTOR ADDRESSING TEST (T16)
782 002312 000000 000000
783 002316 001013 000001 000000 .WORD 1013,1,0,0,0 ;TRACK ADDRESSING TEST (T17)
784 002324 000000 000000
785 002330 007777 000001 000000 .WORD 7777,1,0,410.,0,821.,64.,0,4,1,1,0,177777 ;DATA TEST (T20)
786 002336 000632 000000 001466
787 002344 000100 000000 000004
788 002352 000001 000001 000000
789 002360 177777
790 002362 000037 001750 000000 .WORD 37,1000.,0,410.,0,821. ;EXERCISER (T21)
791 002370 000632 000000 001466
792 002376 000037 011610 000000 .WORD 37,5000.,0,136.,0,255. ;RM03 ACCESS TIME ADJUSTMENT TEST (T22)
793 002404 000210 000000 000377
794
795
796
797
798
799

```

;PARAMETER TABLES

;RECAL/SEEK (T0)

```

PRM0: .WORD 1125
       .WORD 200.
       .WORD 410.
       .WORD 822.
       .WORD 0
       .WORD 0

```

;SEEK/SEEK (T1)

```

PRM1: .WORD 3377
       .WORD 100.
       .WORD 0

```

```

800 002412 001125
801 002414 000310
802 002416 000632
803 002420 001466
804 002422 000000
805 002424 000000
806
807
808 002426 003377
809 002430 000144
810 002432 000000

```

811	002434	000200	.WORD	128.
812	002436	000000	.WORD	0
813	002440	000400	.WORD	256.
814	002442	000000	.WORD	0
815	002444	000000	.WORD	0
816	002446	000000	.WORD	0
817	002450	000000	.WORD	0
818	002452	000000	.WORD	0

: INCREMENT SEEK (T2)

820			PRM2:	.WORD	1177
821	002454	001177		.WORD	1
822	002456	000001		.WORD	0
823	002460	000000		.WORD	410.
824	002462	000632		.WORD	0
825	002464	000000		.WORD	822.
826	002466	001466		.WORD	1
827	002470	000001		.WORD	0
828	002472	000000		.WORD	0
829	002474	000000		.WORD	0

: STEPPING SEEK (T3)

830			PRM3:	.WORD	1177
831				.WORD	1
832	002476	001177		.WORD	0
833	002500	000001		.WORD	256.
834	002502	000000		.WORD	0
835	002504	000400		.WORD	512.
836	002506	000000		.WORD	1
837	002510	001000		.WORD	0
838	002512	000001		.WORD	0
839	002514	000000		.WORD	0
840	002516	000000		.WORD	0

: OSCILLATING SEEK (T4)

841			PRM4:	.WORD	1177
842				.WORD	1
843	002520	001177		.WORD	0
844	002522	000001		.WORD	410.
845	002524	000000		.WORD	0
846	002526	000632		.WORD	822.
847	002530	000000		.WORD	1
848	002532	001466		.WORD	0
849	002534	000001		.WORD	0
850	002536	000000		.WORD	0
851	002540	000000		.WORD	0

: CONVERGING/DIVERGING SEEK (T5)

852			PRM5:	.WORD	1177
853				.WORD	1
854	002542	001177		.WORD	0
855	002544	000001		.WORD	410.
856	002546	000000		.WORD	0
857	002550	000632		.WORD	822.
858	002552	000000		.WORD	1
859	002554	001466		.WORD	0
860	002556	000001		.WORD	0
861	002560	000000		.WORD	0
862	002562	000000		.WORD	0

: SERVO ADDRESSING LOGIC NOISE GENERATOR (T6)

863			PRM6:	.WORD	1177
864				.WORD	1
865	002564	001177			
866	002566	000001			

867	002570	000000	.WORD	0
868	002572	000632	.WORD	410.
869	002574	000000	.WORD	0
870	002576	001466	.WORD	822.
871	002600	000001	.WORD	1
872	002602	000000	.WORD	0
873	002604	000000	.WORD	0

:RANDOM SEEK TEST (T7)

875			PRM7:	.WORD	337
876	002606	000337		.WORD	5000.
877	002610	011610		.WORD	0
878	002612	000000		.WORD	410.
879	002614	000632		.WORD	0
880	002616	000000		.WORD	822.
881	002620	001466		.WORD	0
882	002622	000000		.WORD	4
883	002624	000004			

:SERVO SETTLE DOWN TEST (T10)

885			PRM10:	.WORD	177
886	002626	000177		.WORD	1
887	002630	000001		.WORD	0
888	002632	000000		.WORD	410.
889	002634	000632		.WORD	0
890	002636	000000		.WORD	822.
891	002640	001466		.WORD	100.
892	002642	000144		.WORD	0
893	002644	000000			

:ALL SEEKS TEST (T11)

894			PRM11:	.WORD	1177
895				.WORD	1
896	002646	001177		.WORD	0
897	002650	000001		.WORD	410.
898	002652	000000		.WORD	0
899	002654	000632		.WORD	822.
900	002656	000000		.WORD	1
901	002660	001466		.WORD	0
902	002662	000001		.WORD	0
903	002664	000000			
904	002666	000000			

:ROTATIONAL SPEED TIMING TEST (T12)

905			PRM12:	.WORD	1113
906				.WORD	1
907	002670	001113		.WORD	0
908	002672	000001		.WORD	0
909	002674	000000		.WORD	0
910	002676	000000		.WORD	0
911	002700	000000			
912	002702	000000			

:ONE CYLINDER SEEK TIMING TEST (T13)

913			PRM13:	.WORD	37
914				.WORD	1
915	002704	000037		.WORD	0
916	002706	000001		.WORD	410.
917	002710	000000		.WORD	0
918	002712	000632		.WORD	822.
919	002714	000000			
920	002716	001466			

:ACCESS TIME MEASUREMENT TEST (T14)

921
922

923 002720 000037
 924 002722 000001
 925 002724 000000
 926 002726 000210
 927 002730 000000
 928 002732 000377
 929
 930
 931 002734 000037
 932 002736 000001
 933 002740 000000
 934 002742 000632
 935 002744 000000
 936 002746 001466
 937
 938
 939 002750 000113
 940 002752 000001
 941 002754 000000
 942 002756 000000
 943 002760 000000
 944
 945
 946 002762 001013
 947 002764 000001
 948 002766 000000
 949 002770 000000
 950 002772 000000
 951
 952
 953 002774 007777
 954 002776 000001
 955 003000 000000
 956 003002 000632
 957 003004 000000
 958 003006 001465
 959 003010 000100
 960 003012 000000
 961 003014 000004
 962 003016 000001
 963 003020 000001
 964 003022 000000
 965 003024 177777
 966
 967
 968 003026 000037
 969 003030 001750
 970 003032 000000
 971 003034 000632
 972 003036 000000
 973 003040 001465
 974
 975
 976 003042 000037
 977 003044 011610
 978 003046 000000

PRM14: .WORD 37
 .WORD 1
 .WORD 0
 .WORD 136.
 .WORD 0
 .WORD 255.

 :MAXIMUM SEEK TIMING TEST (T15)
 PRM15: .WORD 37
 .WORD 1
 .WORD 0
 .WORD 410.
 .WORD 0
 .WORD 822.

 :SECTOR ADDRESSING TEST (T16)
 PRM16: .WORD 113
 .WORD 1
 .WORD 0
 .WORD 0
 .WORD 0

 :TRACK ADDRESSING TEST (T17)
 PRM17: .WORD 1013
 .WORD 1
 .WORD 0
 .WORD 0
 .WORD 0

 :DATA TEST (T20)
 PRM20: .WORD 7777
 .WORD 1
 .WORD 0
 .WORD 410.
 .WORD 0
 .WORD 821.
 .WORD 64.
 .WORD 0
 .WORD 4
 .WORD 1
 .WORD 1
 .WORD 0
 PTRN15: .WORD 177777

 :EXERCISER (T21)
 PRM21: .WORD 37
 .WORD 1000.
 .WORD 0
 .WORD 410.
 .WORD 0
 .WORD 821.

 :RM03 ACCESS TIME ADJUSTMENT TEST (T22)
 PRM22: .WORD 37
 .WORD 5000.
 .WORD 0

979	003050	000210	.WORD	136.	
980	003052	000000	.WORD	0	
981	003054	000377	.WORD	255.	
982					
983					
984					
985					
986					
987	003056	045520	T7A:	.WORD	MSG7
988	003060	000000		.WORD	0
989	003062	003142		.WORD	1634.
990	003064	003244		.WORD	1700.
991					;(16.67-2%)*2
992	003066	045520	T7B:	.WORD	MSG7
993	003070	000000		.WORD	0
994	003072	003131		.WORD	1625.
995	003074	003255		.WORD	1709.
996					;(16.67+2%)*2
997					
998	003076	045520	T7A1:	.WORD	MSG7
999	003100	000000		.WORD	0
1000	003102	004622		.WORD	2450.
1001	003104	004766		.WORD	2550.
1002					;(25.00-2% MS X 100.
1003	003106	045520	T7B1:	.WORD	MSG7
1004	003110	000000		.WORD	0
1005	003112	004605		.WORD	2437.
1006	003114	005003		.WORD	2563.
1007					;(25.00+2% MS X 100.
1008	003116	045552	T10:	.WORD	MSG10A
1009	003120	045621		.WORD	MSG10B
1010	003122	000000		.WORD	0
1011	003124	001274		.WORD	700.
1012					;(7)*2
1013	003126	045636	T11:	.WORD	MSG11A
1014	003130	045705		.WORD	MSG11B
1015	003132	000000		.WORD	0
1016	003134	006200		.WORD	3200.
1017					;(32)*2
1018	003136	045722	T12:	.WORD	MSG12A
1019	003140	045764		.WORD	MSG12B
1020	003142	000000		.WORD	0
1021	003144	012574		.WORD	5500.
1022					;(55)*2
1023	003146	003206	PAT.PT:	.WORD	PAT0
1024	003150	003246		.WORD	PAT1
1025	003152	003306		.WORD	PAT2
1026	003154	003346		.WORD	PAT3
1027	003156	003406		.WORD	PAT4
1028	003160	003446		.WORD	PAT5
1029	003162	003506		.WORD	PAT6
1030	003164	003546		.WORD	PAT7
1031	003166	003606		.WORD	PAT8
1032	003170	003646		.WORD	PAT9
1033	003172	003706		.WORD	PAT10
1034	003174	003746		.WORD	PAT11

; ROTATION TEST TABLES FOR RM02 DRIVE

;(7)*2

;(32)*2

;(55)*2

;(16.67-2%)*2
;(16.67+2%)*2
;(25.00-2% MS X 100.
;(25.00+2% MS X 100.
;(25.00-2.5%
;(25.00+2.5%
;(7)*2
;(32)*2
;(55)*2
; TABLE OF POINTERS WHICH POINT TO THE
; PATTERNS USED BY THE DATA TEST

1035	003176	001006	.WORD	PAT12
1036	003200	004046	.WORD	PAT13
1037	003202	004106	.WORD	PAT14
1038	003204	004146	.WORD	PAT15

1039
1040 ; PATTERNS 0 THRU 15

1041				
1042	003206	066666	PAT0: .WORD	066666 ; PATTERN 0
1043	003210	066666	.WORD	066666
1044	003212	066666	.WORD	066666
1045	003214	066666	.WORD	066666
1046	003216	066666	.WORD	066666
1047	003220	066666	.WORD	066666
1048	003222	066666	.WORD	066666
1049	003224	066666	.WORD	066666
1050	003226	066666	.WORD	066666
1051	003230	066666	.WORD	066666
1052	003232	066666	.WORD	066666
1053	003234	066666	.WORD	066666
1054	003236	066666	.WORD	066666
1055	003240	066666	.WORD	066666
1056	003242	066666	.WORD	066666
1057	003244	066666	.WORD	066666

1058				
1059	003246	000001	PAT1: .WORD	000001 ; PATTERN 1
1060	003250	000003	.WORD	000003
1061	003252	000007	.WORD	000007
1062	003254	000017	.WORD	000017
1063	003256	000037	.WORD	000037
1064	003260	000077	.WORD	000077
1065	003262	000177	.WORD	000177
1066	003264	000377	.WORD	000377
1067	003266	000777	.WORD	000777
1068	003270	001777	.WORD	001777
1069	003272	003777	.WORD	003777
1070	003274	007777	.WORD	007777
1071	003276	017777	.WORD	017777
1072	003300	037777	.WORD	037777
1073	003302	077777	.WORD	077777
1074	003304	177777	.WORD	177777

1075				
1076	003306	177776	PAT2: .WORD	177776 ; PATTERN 2
1077	003310	177774	.WORD	177774
1078	003312	177770	.WORD	177770
1079	003314	177760	.WORD	177760
1080	003316	177740	.WORD	177740
1081	003320	177700	.WORD	177700
1082	003322	177600	.WORD	177600
1083	003324	177400	.WORD	177400
1084	003326	177000	.WORD	177000
1085	003330	176000	.WORD	176000
1086	003332	174000	.WORD	174000
1087	003334	170000	.WORD	170000
1088	003336	160000	.WORD	160000
1089	003340	140000	.WORD	140000
1090	003342	100000	.WORD	100000

1091	003344	000000	.WORD	000000	
1092					
1093	003346	000000	PAT3: .WORD	000000	;PATTERN 3
1094	003350	000000	.WORD	000000	
1095	003352	000000	.WORD	000000	
1096	003354	177777	.WORD	177777	
1097	003356	177777	.WORD	177777	
1098	003360	177777	.WORD	177777	
1099	003362	000000	.WORD	000000	
1100	003364	000000	.WORD	000000	
1101	003366	177777	.WORD	177777	
1102	003370	177777	.WORD	177777	
1103	003372	000000	.WORD	000000	
1104	003374	177777	.WORD	177777	
1105	003376	000000	.WORD	000000	
1106	003400	177777	.WORD	177777	
1107	003402	000000	.WORD	000000	
1108	003404	177777	.WORD	177777	
1109					
1110	003406	000000	PAT4: .WORD	000000	;PATTERN 4
1111	003410	010421	.WORD	010421	
1112	003412	021042	.WORD	021042	
1113	003414	031463	.WORD	031463	
1114	003416	042104	.WORD	042104	
1115	003420	052525	.WORD	052525	
1116	003422	063146	.WORD	063146	
1117	003424	073567	.WORD	073567	
1118	003426	104210	.WORD	104210	
1119	003430	114631	.WORD	114631	
1120	003432	125252	.WORD	125252	
1121	003434	135673	.WORD	135673	
1122	003436	146314	.WORD	146314	
1123	003440	156735	.WORD	156735	
1124	003442	167356	.WORD	167356	
1125	003444	177777	.WORD	177777	
1126					
1127	003446	052525	PAT5: .WORD	052525	;PATTERN 5
1128	003450	052525	.WORD	052525	
1129	003452	052525	.WORD	052525	
1130	003454	125252	.WORD	125252	
1131	003456	125252	.WORD	125252	
1132	003460	125252	.WORD	125252	
1133	003462	052525	.WORD	052525	
1134	003464	052525	.WORD	052525	
1135	003466	125252	.WORD	125252	
1136	003470	125252	.WORD	125252	
1137	003472	052525	.WORD	052525	
1138	003474	125252	.WORD	125252	
1139	003476	052525	.WORD	052525	
1140	003500	125252	.WORD	125252	
1141	003502	052525	.WORD	052525	
1142	003504	125252	.WORD	125252	
1143					
1144	003506	007417	PAT6: .WORD	007417	;PATTERN 6
1145	003510	007417	.WORD	007417	
1146	003512	007417	.WORD	007417	

1147	003514	170360	.WORD	170360	
1148	003516	170360	.WORD	170360	
1149	003520	170360	.WORD	170360	
1150	003522	007417	.WORD	007417	
1151	003524	007417	.WORD	007417	
1152	003526	170360	.WORD	170360	
1153	003530	170360	.WORD	170360	
1154	003532	007417	.WORD	007417	
1155	003534	170360	.WORD	170360	
1156	003536	007417	.WORD	007417	
1157	003540	170360	.WORD	170360	
1158	003542	007417	.WORD	007417	
1159	003544	170360	.WORD	170360	
1160					
1161	003546	026455	PAT7: .WORD	026455	;PATTERN 7
1162	003550	026455	.WORD	026455	
1163	003552	026455	.WORD	026455	
1164	003554	151322	.WORD	151322	
1165	003556	151322	.WORD	151322	
1166	003560	151322	.WORD	151322	
1167	003562	026455	.WORD	026455	
1168	003564	026455	.WORD	026455	
1169	003566	151322	.WORD	151322	
1170	003570	151322	.WORD	151322	
1171	003572	026455	.WORD	026455	
1172	003574	151322	.WORD	151322	
1173	003576	026455	.WORD	026455	
1174	003600	151322	.WORD	151322	
1175	003602	026455	.WORD	026455	
1176	003604	151322	.WORD	151322	
1177					
1178	003606	165555	PAT8: .WORD	165555	;PATTERN 8
1179	003610	133333	.WORD	133333	
1180	003612	165555	.WORD	165555	
1181	003614	133333	.WORD	133333	
1182	003616	165555	.WORD	165555	
1183	003620	133333	.WORD	133333	
1184	003622	165555	.WORD	165555	
1185	003624	133333	.WORD	133333	
1186	003626	165555	.WORD	165555	
1187	003630	133333	.WORD	133333	
1188	003632	165555	.WORD	165555	
1189	003634	133333	.WORD	133333	
1190	003636	165555	.WORD	165555	
1191	003640	133333	.WORD	133333	
1192	003642	165555	.WORD	165555	
1193	003644	133333	.WORD	133333	
1194					
1195	003646	000001	PAT9: .WORD	000001	;PATTERN 9
1196	003650	000002	.WORD	000002	
1197	003652	000004	.WORD	000004	
1198	003654	000010	.WORD	000010	
1199	003656	000020	.WORD	000020	
1200	003660	000040	.WORD	000040	
1201	003662	000100	.WORD	000100	
1202	003664	000200	.WORD	000200	

1203	003666	000400	.WORD	000400	
1204	003670	001000	.WORD	001000	
1205	003672	002000	.WORD	002000	
1206	003674	004000	.WORD	004000	
1207	003676	010000	.WORD	010000	
1208	003700	020000	.WORD	020000	
1209	003702	040000	.WORD	040000	
1210	003704	100000	.WORD	100000	
1211					
1212	003706	177776	PAT10: .WORD	177776	;PATTERN 10
1213	003710	177775	.WORD	177775	
1214	003712	177773	.WORD	177773	
1215	003714	177767	.WORD	177767	
1216	003716	177757	.WORD	177757	
1217	003720	177737	.WORD	177737	
1218	003722	177677	.WORD	177677	
1219	003724	177577	.WORD	177577	
1220	003726	177377	.WORD	177377	
1221	003730	176777	.WORD	176777	
1222	003732	175777	.WORD	175777	
1223	003734	173777	.WORD	173777	
1224	003736	167777	.WORD	167777	
1225	003740	157777	.WORD	157777	
1226	003742	137777	.WORD	137777	
1227	003744	077777	.WORD	077777	
1228					
1229	003746	172666	PAT11: .WORD	172666	;PATTERN 11
1230	003750	155555	.WORD	155555	
1231	003752	172666	.WORD	172666	
1232	003754	155555	.WORD	155555	
1233	003756	172666	.WORD	172666	
1234	003760	155555	.WORD	155555	
1235	003762	172666	.WORD	172666	
1236	003764	155555	.WORD	155555	
1237	003766	172666	.WORD	172666	
1238	003770	155555	.WORD	155555	
1239	003772	172666	.WORD	172666	
1240	003774	155555	.WORD	155555	
1241	003776	172666	.WORD	172666	
1242	004000	155555	.WORD	155555	
1243	004002	172666	.WORD	172666	
1244	004004	155555	.WORD	155555	
1245					
1246	004006	077777	PAT12: .WORD	077777	;PATTERN 12
1247	004010	137777	.WORD	137777	
1248	004012	157777	.WORD	157777	
1249	004014	167777	.WORD	167777	
1250	004016	173777	.WORD	173777	
1251	004020	175777	.WORD	175777	
1252	004022	176777	.WORD	176777	
1253	004024	177377	.WORD	177377	
1254	004026	177577	.WORD	177577	
1255	004030	177677	.WORD	177677	
1256	004032	177737	.WORD	177737	
1257	004034	177757	.WORD	177757	
1258	004036	177767	.WORD	177767	

1259	004040	177773	.WORD	177773	
1260	004042	177775	.WORD	177775	
1261	004044	177776	.WORD	177776	
1262					
1263	004046	153333	PAT13: .WORD	153333	;PATTERN 13
1264	004050	066667	.WORD	066667	
1265	004052	153333	.WORD	153333	
1266	004054	066667	.WORD	066667	
1267	004056	153333	.WORD	153333	
1268	004060	066667	.WORD	066667	
1269	004062	153333	.WORD	153333	
1270	004064	066667	.WORD	066667	
1271	004066	153333	.WORD	153333	
1272	004070	066667	.WORD	066667	
1273	004072	153333	.WORD	153333	
1274	004074	066667	.WORD	066667	
1275	004076	153333	.WORD	153333	
1276	004100	066667	.WORD	066667	
1277	004102	153333	.WORD	153333	
1278	004104	066667	.WORD	066667	
1279					
1280	004106	000000	PAT14: .WORD	000000	;PATTERN 14
1281	004110	177777	.WORD	177777	
1282	004112	177777	.WORD	177777	
1283	004114	177777	.WORD	177777	
1284	004116	177777	.WORD	177777	
1285	004120	177777	.WORD	177777	
1286	004122	177777	.WORD	177777	
1287	004124	177777	.WORD	177777	
1288	004126	177777	.WORD	177777	
1289	004130	177777	.WORD	177777	
1290	004132	177777	.WORD	177777	
1291	004134	177777	.WORD	177777	
1292	004136	177777	.WORD	177777	
1293	004140	177777	.WORD	177777	
1294	004142	177777	.WORD	177777	
1295	004144	177777	.WORD	177777	
1296					
1297	004146	177777	PAT15: .WORD	177777	;PATTERN 15
1298	004150	000000	.WORD	000000	
1299	004152	000000	.WORD	000000	
1300	004154	000000	.WORD	000000	
1301	004156	000000	.WORD	000000	
1302	004160	000000	.WORD	000000	
1303	004162	000000	.WORD	000000	
1304	004164	000000	.WORD	000000	
1305	004166	000000	.WORD	000000	
1306	004170	000000	.WORD	000000	
1307	004172	000000	.WORD	000000	
1308	004174	000000	.WORD	000000	
1309	004176	000000	.WORD	000000	
1310	004200	000000	.WORD	000000	
1311	004202	000000	.WORD	000000	
1312	004204	000000	.WORD	000000	
1313					
1314					

:DPB DATA PARAMETER BLOCK)

F05

1315						
1316	004206	000	DPB.A:	.BYTE	0	;(0) DRIVE NUMBER
1317	004207	000		.BYTE	0	;(1) OFFSET VALUE OR FMT22, ECI, AND HCI
1318	004210	000		.BYTE	0	;(2) COMMAND
1319	004211	000		.BYTE	0	;(3) PSEL AND A17 AND A16
1320	004212	000000		.WORD	0	;(4) WORD COUNT (MUST BE NEG.)
1321	004214	051776		.WORD	BUFFER	;(6) BUFFER ADDRESS OR
1322						REGISTER TABLE POINTER
1323	004216	000		.BYTE	0	;(10) SECTOR ADDRESS OR
1324						FIRST REG. INDEX
1325	004217	000		.BYTE	0	;(11) TRACK ADDRESS OR
1326						LAST REG. INDEX
1327	004220	000000		.WORD	0	;(12) CYLINDER ADDRESS
1328	004222	004306		.WORD	RM.REG	;(14) ERROR TABLE POINTER
1329						POINTS TO THE FIRST OF TWENTY
1330						LOCATIONS OF WHERE THE DRIVER
1331						IS TO STORE THE RM70/RM03
1332						REGISTERS ON AN ERROR. IF LEFT
1333						ZERO REGISTERS ARE NOT SAVED.
1334	004224	000000		.WORD	0	;(16) STATUS/ERROR INDICATOR
1335						:BIT15=1=>ERROR OCCURRED
1336						:BIT07=1=>DONE
1337						:BIT14-BIT09 AND BIT06-BIT03
1338						:INDICATE TYPE OF ERROR
1339						
1340	004226	000	DPB.B:	.BYTE	0	;(0) DRIVE NUMBER
1341	004227	000		.BYTE	0	;(1) OFFSET VALUE OR FMT22, ECI, AND HCI
1342	004230	000		.BYTE	0	;(2) COMMAND
1343	004231	000		.BYTE	0	;(3) PSEL AND A17 AND A16
1344	004232	177776		.WORD	-2	;(4) WORD COUNT (MUST BE NEG.)
1345	004234	051776		.WORD	BUFFER	;(6) BUFFER ADDRESS OR
1346						REGISTER TABLE POINTER
1347	004236	000		.BYTE	0	;(10) SECTOR ADDRESS OR
1348						FIRST REG. INDEX
1349	004237	000		.BYTE	0	;(11) TRACK ADDRESS OR
1350						LAST REG. INDEX
1351	004240	000000		.WORD	0	;(12) CYLINDER ADDRESS
1352	004242	004306		.WORD	RM.REG	;(14) ERROR TABLE POINTER
1353						POINTS TO THE FIRST OF TWENTY
1354						LOCATIONS OF WHERE THE DRIVER
1355						IS TO STORE THE RM70/RM03
1356						REGISTERS ON AN ERROR. IF LEFT
1357						ZERO REGISTERS ARE NOT SAVED.
1358	004244	000000		.WORD	0	;(16) STATUS/ERROR INDICATOR
1359						:BIT15=1=>ERROR OCCURRED
1360						:BIT07=1=>DONE
1361						:BIT14-BIT09 AND BIT06-BIT03
1362						:INDICATE TYPE OF ERROR
1363						
1364	004246	000	DPB.C:	.BYTE	0	;(0) DRIVE NUMBER
1365	004247	000		.BYTE	0	;(1) OFFSET VALUE OR FMT22, ECI, AND HCI
1366	004250	000		.BYTE	0	;(2) COMMAND
1367	004251	000		.BYTE	0	;(3) PSEL AND A17 AND A16
1368	004252	177776		.WORD	-2	;(4) WORD COUNT (MUST BE NEG.)
1369	004254	051776		.WORD	BUFFER	;(6) BUFFER ADDRESS OR
1370						REGISTER TABLE POINTER

1371	004256	000	.BYTE	0	;(10) SECTOR ADDRESS OR
1372					;(11) TRACK ADDRESS OR
1373	004257	000	.BYTE	0	;(12) CYLINDER ADDRESS
1374					;(14) ERROR TABLE POINTER
1375	004260	000000	.WORD	0	POINTS TO THE FIRST OF TWENTY
1376	004262	004306	.WORD	RM.REG	LOCATIONS OF WHERE THE DRIVER
1377					IS TO STORE THE RM70/RM03
1378					REGISTERS ON AN ERROR. IF LEFT
1379					ZERO REGISTERS ARE NOT SAVED.
1380					;(16) STATUS/ERROR INDICATOR
1381					:BIT15=1=>ERROR OCCURRED
1382	004264	000000	.WORD	0	:BIT07=1=>DONE
1383					:BIT14-BIT09 AND BIT06-BIT03
1384					:INDICATE TYPE OF ERROR
1385					
1386					
1387					
1388	004266	000	DTADPB: .BYTE	0	;(0) DRIVE NUMBER
1389	004267	000	.BYTE	0	;(1) OFFSET VALUE OR FMT22, ECT. AND HCI
1390	004270	000	.BYTE	0	;(2) COMMAND
1391	004271	000	.BYTE	0	;(3) PSEL AND A17 AND A16
1392	004272	000000	.WORD	0	;(4) WORD COUNT (MUST BE NEG.)
1393	004274	051776	.WORD	BUFFER	;(6) BUFFER ADDRESS OR
1394					REGISTER TABLE POINTER
1395	004276	000	.BYTE	0	;(10) SECTOR ADDRESS OR
1396					;(11) TRACK ADDRESS OR
1397	004277	000	.BYTE	0	;(12) CYLINDER ADDRESS
1398					;(14) ERROR TABLE POINTER
1399	004300	000000	.WORD	0	POINTS TO THE FIRST OF TWENTY
1400	004302	004306	.WORD	RM.REG	LOCATIONS OF WHERE THE DRIVER
1401					IS TO STORE THE RM70/RM03
1402					REGISTERS ON AN ERROR. IF LEFT
1403					ZERO REGISTERS ARE NOT SAVED.
1404					;(16) STATUS/ERROR INDICATOR
1405	004304	000000	.WORD	0	:BIT15=1=>ERROR OCCURRED
1406					:BIT07=1=>DONE
1407					:BIT14-BIT09 AND BIT06-BIT03
1408					:INDICATE TYPE OF ERROR
1409					
1410					
1411					
1412					
1413					
1414					
1415					
1416	004306	000000	RM.REG: .WORD	0	:RMCS1 (776700) CONTROL & STATUS #1
1417	004310	000000	.WORD	0	:RMWC (776702) WORD COUNT
1418	004312	000000	.WORD	0	:RMB (776704) BUS ADDRESS
1419	004314	000000	.WORD	0	:RMDA (776706) DESIRED SECTOR TRACK
1420	004316	000000	.WORD	0	:RMCS2 (776710) CONTROL & STATUS #2
1421	004320	000000	.WORD	0	:RMD5 (776712) DISK STATUS
1422	004322	000000	.WORD	0	:RMER1 (776714) ERROR REG. #1
1423	004324	000000	.WORD	0	:RMA5 (776716) ATTENTION SUMMARY
1424	004326	000000	.WORD	0	:RMLA (776720) LOOK AHEAD
1425	004330	000000	.WORD	0	:RMD8 (776722) DATA BUFFER
1426	004332	000000	.WORD	0	:RMMR1 (776724) MAINTAINABILITY

H05

1427	004334	000000	.WORD	0	:RMDT (776726) DRIVE TYPE
1428	004336	000000	.WORD	00	:RMSN (776730) SERIAL NUMBER
1429	004340	000000	.WORD	00	:RMOF (776732) OFFSET
1430	004342	000000	.WORD	00	:RMDC (776734) DESIRED CYLINDER
1431	004344	000000	.WORD	00	:RMHR (776736) CURRENT CYLINDER
1432	004346	000000	.WORD	00	:RMMR2 (776740) ERROR REG #2
1433	004350	000000	.WORD	00	:RMR2 (776742) ERROR REG #3
1434	004352	000000	.WORD	00	:RMEC1 (776744) ECC POSITION
1435	004354	000000	.WORD	0	:RMEC2 (776746) ECC PATTERN

1436					
1437					
1438	004356	047013	:STATUS/ERROR	MESSAGE POINTER TABLE	
1439	004360	047055	STATBL: .WORD	MSGB14	:OFFLINE OR UNSAFE DRIVE REQUESTED
1440	004362	047106	.WORD	MSGB13	:UNLOAD DRIVE REQUESTED
1441	004364	047130	.WORD	MSGB12	:PERSISTENT UNSAFE
1442	004366	047156	.WORD	MSGB11	:PARITY ERROR OCCURRED
1443	004370	047201	.WORD	MSGB10	:FATAL PARITY ERROR
1444	004372	047240	.WORD	MSGB09	:SOFTWARE TIMEOUT ON THIS DRIVE
1445	004374	047302	.WORD	MSGB08	:SOFTWARE TIMEOUT ON ANOTHER DRIVE
1446	004376	047346	.WORD	MSGB06	:ERROR OCCURRED DURING I/O OPERATION
1447	004400	047416	.WORD	MSGB05	:ERROR OCCURRED DURING NON-I/O OPERATION
1448	004402	047436	.WORD	MSGB04	:UNSAFE OCCURRED
1449	004404	047506	.WORD	MSGB03	:AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
1500	004406	047556	.WORD	MSGB02	:DRIVE HAS NOT RESPONDED TO PORT REQUEST
			.WORD	MSGB01	:DRIVE HAS BECOME NONEXISTENT

.SBTTL ERROR POINTER TABLE

.*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
.*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
.*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
.*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
.*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

.* EM ::POINTS TO THE ERROR MESSAGE
.* DH ::POINTS TO THE DATA HEADER
.* DT ::POINTS TO THE DATA
.* DF ::POINTS TO THE DATA FORMAT

\$ERRTB:

.*EM AND DH ARE ASCIZ MESSAGES, DT IS A STRING OF WORDS THAT POINT TO THE
.*DATA TO BE TYPED AND DF IS A STRING OF DATA THAT TELL HOW THE DT WORDS
.*ARE TO BE TYPED. IF ANY OF THE POINTERS ARE NOT NEEDED FOR A PARTICULAR
.*ERROR IT IS REPLACED WITH A ZERO.
.*EACH OF THE ITEMS BELOW REFER TO THE ERROR NUMBER AND INDICATE
.*THE INFORMATION THAT WILL BE TYPED WHEN THE ERROR OCCURS.
.*UNLESS STATED OTHER ALL NUMBERS ARE OCTAL

.* ERROR ITEM 1
.* RH70 INTERRUPT OCCURED (RMAS = 0)
.* ERR PC RMAS
.* \$ERRPC \$REG3

EM1
DH1
DT1
DF1

.* ERROR ITEM 2
.* UNEXPECTED ATTENTION OCCURRED
.* ERR PC DRIVE RMAS RMD5 RMER1 RMMR2 RMER2
.* \$ERRPC \$REG1 \$REG3 RMERRS RMERRS+2 RMERRS+4 RMERRS+6

EM2
DH2
DT2
DF2

.* ERROR ITEM 3
.* MASSBUS PARITY ERROR (MCPE=1)
.* TEST ERR PC ADDRESS DATA
.* \$TMPD \$ERRPC RD.ADR RD.WRD

EM3
DH3
DT3
DF3

.* ERROR ITEM 4
.* MASSBUS PARITY ERROR (PAR=1)
.* TEST ERR PC ADDRESS GDDATA BDDATA

1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465 004410
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479 004410 046144
1480 004412 047614
1481 004414 051170
1482 004416 051622
1483
1484
1485
1486
1487
1488
1489 004420 046207
1490 004422 047631
1491 004424 051174
1492 004426 051626
1493
1494
1495
1496
1497
1498
1499 004430 046245
1500 004432 047716
1501 004434 051212
1502 004436 051632
1503
1504
1505
1506

1507			;	*	STMPD	SERRPC	WRT.ADR	WRT.WD	RD.WPD	
1508										
1509	004440	046302				EM4				
1510	004442	047753				DH4				
1511	004444	051222				DT4				
1512	004446	051636				DF4				
1513										
1514			;	*	ERROR ITEM 5					
1515			;	*	ADDRESS	PLUG	CHANGE	BIT	SET	
1516			;	*	ERR PC	DRIVE	RMS	RMS	RMR1	RMR2
1517			;	*	SERRPC	\$REG1	\$REG3	RMERRS	RMRRS+2	RMRRS+4 RMERRS+6
1518										
1519	004450	046336				EM5				
1520	004452	047631				DH2				
1521	004454	051174				DT2				
1522	004456	051626				DF2				
1523										
1524			;	*	ERROR ITEM 6 -- NOT USED					
1525										
1526	004460	000000				0				
1527	004462	000000				0				
1528	004464	000000				0				
1529	004466	000000				0				
1530										
1531			;	*	ERROR ITEM 7 - NOT USED					
1532										
1533	004470	000000				0				
1534	004472	000000				0				
1535	004474	000000				0				
1536	004476	000000				0				
1537										
1538			;	*	ERROR ITEM 10					
1539			;	*	RH70/RM03	FAILED	TO	RESPOND	TO	ADDRESSING
1540			;	*	RMCS1	ERR PC				
1541			;	*	RH.ADR	SERRPC				
1542										
1543	004500	046372				EM10				
1544	004502	050022				DH10				
1545	004504	051254				DT10				
1546	004506	051642				DF10				
1547										
1548			;	*	ERROR ITEM 11					
1549			;	*	DRIVE	SELECTED	IS	NOT	ONLINE	
1550			;	*	DRIVE	ERR PC				
1551			;	*	\$REG2	SERRPC				
1552										
1553	004510	046444				EM11				
1554	004512	050041				DH11				
1555	004514	051260				DT11				
1556	004516	051646				DF11				
1557										
1558			;	*	ERROR ITEM 12					
1559			;	*	IMPROPER	HEADER	DATA			
1560			;	*	TEST	ERR PC	TST PC	DRIVE	CYLNR	TRACK
1561			;	*	STMPD	SERRPC	\$REG0	CHKDRV	CYL.DS	TRK.DS
1562			;	*				BDCYL	BDTRK	BDSCTR

K05

```

1563          ;*      CYL.DS TRK.DS SEC.DS CYL.RD TRK.RD SEC.RD
1564          ;*      CYLNDR, TRACK, AND SECTOR ARE DECIMAL
1565
1566 004520 046501      EM12
1567 004522 050060      DH12
1568 004524 051264      DT12
1569 004526 051652      DF12
1570
1571          ;*      ERROR ITEM 13
1572          ;*      DATA COMPARE FAILURE
1573          ;*      TEST      ERR PC TST PC DRIVE  CYLNDR TRACK  SECTOR
1574          ;*      $TMPO  $ERRPC $REGO  CHKDRV  CYL.DS TRK.DS SEC.DS
1575          ;*      GDDAT  BDDAT  WRDCNT  GDADR  BDADR
1576          ;*      $GDDAT $BDDAT $REG4  $GDADR $BDADR
1577          ;*      CYLNDR, TRACK, SECTOR, AND WRDCNT ARE DECIMAL
1578
1579 004530 046526      EM13
1580 004532 050060      DH12
1581 004534 051316      DT13
1582 004536 051662      DF13
1583
1584          ;*      ERROR ITEM 14 -- FOLLOWS #13
1585          ;*      $GDDAT $BDDAT $REG4  $GDADR $BDADR
1586
1587 004540 000000      0
1588 004542 000000      0
1589 004544 051334      DT13A
1590 004546 051672      DF14
1591
1592          ;*      ERROR ITEM 15
1593          ;*      DATA COMPARE FAILURE
1594          ;*      TEST      ERR PC TST PC DRIVE  CYLNDR TRACK  SECTOR
1595          ;*      $TMPO  $ERRPC $REGO  CHKDRV  CYL.DS TRK.DS SEC.DS
1596          ;*      GDDAT  BDDAT  WRDCNT  GDADR  BDADR
1597          ;*      $GDDAT $BDDAT $REG4  $GDADR $BDADR
1598          ;*      CYLNDR, TRACK, SECTOR, AND WRDCNT ARE DECIMAL
1599
1600 004550 046526      EM13
1601 004552 050060      DH12
1602 004554 051316      DT13
1603 004556 051662      DF13
1604
1605          ;*      ERROR ITEM 16 -- FOLLOWS #15
1606          ;*      $GDDAT $BDDAT $REG4  $GDADR $BDADR
1607
1608 004560 000000      0
1609 004562 000000      0
1610 004564 051334      DT13A
1611 004566 051672      DF14
1612
1613          ;*      ERROR ITEM 17
1614          ;*      DISK ERROR IN TIMING TEST
1615          ;*      TEST      ERR PC DRIVE  RMCS1  RMS  RMER1  RMMR2  RMER2
1616          ;*      $TMPO  $ERRPC  CHKDRV  RM.REG  RM.REG+12 RM.REG+14 RM.REG+40 RM.REG+42
1617
1618 004570 046553      EM17
  
```


1619	004572	050274	DH17
1620	004574	051346	DT17
1621	004576	051676	DF17
1622			
1623			:* ERROR ITEM 20
1624			:* CLOCK (KW11-P) OVERFLOW IN TIMING TEST
1625			:* TEST ERR PC DRIVE RMCS1 RMDS RMER1 RMMR2 RMER2
1626			:* STMPO \$ERRPC CHKDRV RM.REG RM.REG+12 RM.REG+14 RM.REG+40 RM.REG+42
1627			
1628	004600	046605	EM20
1629	004602	050274	DH17
1630	004604	051346	DT17
1631	004606	051676	DF17
1632			
1633			:* ERROR ITEM 21
1634			:* DATA COMPARE FAILURE
1635			:* TEST ERR PC TST PC DRIVE CYLNR TRACK
1636			:* STMPO \$ERRPC \$REGD CHKDRV CYL.DS TRK.DS
1637			:* GDDAT BDDAT WRDCNT SECTOR
1638			:* \$REG1 \$BDDAT \$REG4 \$REG1
1639			:* CYLINDR, TRACK, WRDCNT, AND SECTOR ARE DECIMAL
1640			
1641	004610	046526	EM13
1642	004612	050371	DH21
1643	004614	051366	DT21
1644	004616	051702	DF21
1645			
1646			:* ERROR ITEM 22--FOLLOWS #21
1647			:* \$REG1 \$BDDAT \$REG4 \$REG1
1648			
1649	004620	000000	0
1650	004622	000000	0
1651	004624	051402	DT21A
1652	004626	051712	DF22
1653			
1654			:* ERROR ITEM 23
1655			:* DISK ERROR DURING SEEK
1656			:* TEST ERR PC DRIVE CYLNR RMCS1 RMCS2 RMDS
1657			:* STMPO \$ERRPC CHKDRV CYL.DS RM.REG RM.REG+10 RM.REG+12
1658			:* RMER1 RMMR2 RMER2 RMDC RMHR
1659			:* RM.REG+14 RM.REG+40 RM.REG+42 RM.REG+34 RM.REG+36
1660			
1661	004630	046654	EM23
1662	004632	050506	DH23
1663	004634	051412	DT23
1664	004636	051716	DF23
1665			
1666			:* ERROR ITEM 24
1667			:* SEEK NOT COMPLETE WITHIN 120 MS
1668			:* TEST ERR PC DRIVE CYLNR RMCS1 RMCS2 RMDS
1669			:* STMPO \$ERRPC CHKDRV CYL.DS RM.REG RM.REG+10 RM.REG+12
1670			:* RMER1 RMMR2 RMER2 RMDC RMHR
1671			:* RM.REG+14 RM.REG+40 RM.REG+42 RM.REG+34 RM.REG+36
1672			
1673	004640	046703	EM24
1674	004642	050506	DH23

1675 004644 051412
1676 004646 051716

DT23
DF23

1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730

004650

004650 046743
004652 050640
004654 051442
004656 051726

004660 046743
004662 050675
004664 051452
004666 051732

004670 046743
004672 050676
004674 051470

* ERROR ITEMS 23-40 NOT USED
* ERROR ITEMS 41-46 WILL HAVE AN EM THAT
* VARIES DEPENDING ON THE ERROR, IT WILL BE IN THE FORM:
* RH70/RM03 ERROR (MESSAGE)
* WHERE MESSAGE WILL BE ONE OR MORE OF THE FOLLOWING:
* 1) OFFLINE OR UNSAFE DRIVE REQUESTED
* 2) UNLOADED DRIVE REQUESTED
* 3) PERSISTENT UNSAFE
* 4) PARITY ERROR OCCURRED
* 5) FATAL PARITY ERROR
* 6) SOFTWARE TIMEOUT ON THIS DRIVE
* 7) SOFTWARE TIMEOUT ON ANOTHER DRIVE
* 8) ERROR OCCURRED DURING I/O OPERATION
* 9) ERROR OCCURRED DURING NON-I/O OPERATION
* 10) UNSAFE OCCURRED
* 11) AUTOMATIC RECALIBRATE SEQUENCE OCCURRED

ITEM41:

* ERROR ITEM 41
* RH70/RM03 ERROR (MESSAGE)
* TEST ERR PC TST PC DRIVE
* \$TMPO \$ERRPC \$REGO CHKDRV

EM41
DH41
DT41
DF41

* ERROR ITEM 42
* RH70/RM03 ERROR (MESSAGE)
* TEST ERR PC TST PC DRIVE RMCS1 RMCS2 RMDS
* \$TMPO \$ERRPC \$REGO CHKDRV RM.REG RM.REG+10 RM.REG+12

EM41
DH42
DT42
DF42

* ERROR ITEM 43
* RH70/RM03 ERROR (MESSAGE)
* TEST ERR PC TST PC DRIVE RMCS1 RMCS2 RMDS
* \$TMPO \$ERRPC \$REGO CHKDRV RM.REG RM.REG+10 RM.REG+12
* RMER1 RMMR2 RMER2
* RM.REG+14 RM.REG+40 RM.REG+42

EM41
DH42
DT43

1731 004676 051736

DF43

```

:* ERROR ITEM 44
:* RH70/RM03 ERROR (MESSAGE)
:* TEST ERR PC TST PC DRIVE CYLNDR TRACK SECTOR
:* $TMPO $ERRPC $REGO CHKDRV CYL.DS TRK.DS SEC.DS
:* RMCS1 RMCS2 RMDS RMHR RMDC RMDA
:* RM.REG RM.REG+10 RM.REG+12 RM.REG+36 RM.REG+34 RM.REG+06
:* RMER1 RMMR2 RMER2
:* RM.REG+14 RM.REG+40 RM.REG+42
:* CYLNDR, TRACK, AND SECTOR ARE DECIMAL

```

1743 004700 046743

EM41

1744 004702 050060

DH12

1745 004704 051514

DT44

1746 004706 051746

DF44

1748

```

:* ERROR ITEM 45
:* RH70/RM03 ERROR (MESSAGE)
:* TEST ERR PC TST PC DRIVE CYLNDR TRACK SECTOR
:* $TMPO $ERRPC $REGO CHKDRV CYL.DS TRK.DS SEC.DS
:* RMCS1 RMCS2 RMDS RMHR RMDC RMDA
:* RM.REG RM.REG+10 RM.REG+12 RM.REG+36 RM.REG+34 RM.REG+06
:* RMER1 RMMR2 RMER2 RMWC RMBA RMOB
:* RM.REG+14 RM.REG+40 RM.REG+42 RM.REG+2 RM.REG+4 RM.REG+22
:* CYLNDR, TRACK, AND SECTOR ARE DECIMAL

```

1758 004710 046743

EM41

1759 004712 050060

DH12

1760 004714 051554

DT45

1761 004716 051762

DF45

1762

```

:* ERROR ITEM 46
:* FATAL WRITE CHECK ERROR (MESSAGE)
:* TEST ERR PC TST PC DRIVE CYLNDR TRACK SECTOR
:* $TMPO $ERRPC $REGO CHKDRV CYL.DS TRK.DS SEC.DS
:* RMCS1 RMCS2 RMDS RMHR RMDC RMDA
:* RM.REG RM.REG+10 RM.REG+12 RM.REG+36 RM.REG+34 RM.REG+06
:* RMER1 RMMR2 RMER2 RMWC RMBA RMOB
:* RM.REG+14 RM.REG+40 RM.REG+42 RM.REG+2 RM.REG+4 RM.REG+22
:* CYLNDR, TRACK, AND SECTOR ARE DECIMAL

```

1773 004720 046763

EM46

1774 004722 050060

DH12

1775 004724 051554

DT45

1776 004726 051762

DF45

1777

```

1778
1779
1780
1781
1782 004730 012737 177777 001306 START3: MOV # -1, @BUSADR ; GET BUSADR FLAG
1783 004736 000402 BR STAT1A
1784 004740 005037 001306 START1: CLR @BUSADR ; CLR BUSADR FLAG
1785 004744 005037 001304 STAT1A: CLR @CNTRLC ; NO CONTROL "C"
1786 004750 000411 BR START
1787 004752 012737 177777 001306 START4: MOV # -1, @BUSADR ; SET BUSADR FLAG
1788 004760 000402 BR STAT2A
1789 004762 005037 001306 START2: CLR @BUSADR ; CLR BUSADR FLAG
1790 004766 012737 177777 001304 START2A: MOV # -1, @CNTRLC ; SET CONTROL "C" FLAG
1791 004774 000005 START: RESET
1792
1793 .SBTTL INITIALIZE THE COMMON TAGS
1794 ;; CLEAR THE COMMON TAGS ($CMTAG) AREA
1795 MOV # $CMTAG, R6 ;; FIRST LOCATION TO BE CLEARED
1796 CLR (R6)+ ;; CLEAR MEMORY LOCATION
1797 CMP # SWR, R6 ;; DONE?
1798 BNE -6 ;; LOOP BACK IF NO
1799 MOV # STACK, SP ;; SETUP THE STACK POINTER
1800 ;; INITIALIZE A FEW VECTORS
1801 MOV # $SCOPE, @ IOTVEC ;; IOT VECTOR FOR SCOPE ROUTINE
1802 MOV # 340, @ IOTVEC+2 ;; LEVEL 7
1803 MOV # $ERROR, @ EMTVEC ;; EMT VECTOR FOR ERROR ROUTINE
1804 MOV # 340, @ EMTVEC+2 ;; LEVEL 7
1805 MOV # $TRAP, @ TRAPVEC ;; TRAP VECTOR FOR TRAP CALLS
1806 MOV # 340, @ TRAPVEC+2 ;; LEVEL 7
1807 MOV $ENDCT, $EOPCT ;; SETUP END-OF-PROGRAM COUNTER
1808 MOV # 176543, $MINUM ;; PRIME THE RANDOM NUMBER GENERATOR
1809 MOV # 123456, $LONUM ;; BOTH HIGH AND LOW WORDS
1810 CLR $TIMES ;; INITIALIZE NUMBER OF ITERATIONS
1811 CLR $ESCAPE ;; CLEAR THE ESCAPE ON ERROR ADDRESS
1812 MOV # 1, $ERMAX ;; ALLOW ONE ERROR PER TEST
1813 MOV # , $LPADR ;; INITIALIZE THE LOOP ADDRESS FOR SCOPE
1814 MOV # , $LPERR ;; SETUP THE ERROR LOOP ADDRESS
1815 ;; SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1816 ;; EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
1817 MOV @ $ERRVEC, -(SP) ;; SAVE ERROR VECTOR
1818 MOV # 64$, @ $ERRVEC ;; SET UP ERROR VECTOR
1819 MOV # $SWR, SWR ;; SETUP FOR A HARDWARE SWITCH REGISTER
1820 MOV # $DISP, DISPLAY ;; AND A HARDWARE DISPLAY REGISTER
1821 CMP # -1, @ SWR ;; TRY TO REFERENCE HARDWARE SWR
1822 BNE 66$ ;; BRANCH IF NO TIMEOUT TRAP OCCURRED
1823 BR 65$ ;; AND THE HARDWARE SWR IS NOT = -1
1824 MOV # 65$, (SP) ;; BRANCH IF NO TIMEOUT
1825 RTI ;; SET UP FOR TRAP RETURN
1826 MOV # SWREG, SWR ;; POINT TO SOFTWARE SWR
1827 MOV # $DISPREG, DISPLAY
1828 MOV (SP)+, @ $ERRVEC ;; RESTORE ERROR VECTOR
1829
1830 CLR $PASS ;; CLEAR PASS COUNT
1831 BITB # APTSIZE, $ENVM ;; TEST USER SIZE UNDER APT
1832 BEQ 67$ ;; YES, USE NON-APT SWITCH
1833 MOV # $SWREG, SWR ;; NO, USE APT SWITCH REGISTER
    
```

1834	005246			67\$:							
1835	005246	012700	001160		MOV	#REGAD,RO				:FIRST ADDRESS	
1836	005252	005020		1\$:	CLR	(R0)+				:CLEAR VARIABLE STORAGE	
1837	005254	022700	001210		CMP	#\$BELL,RO				:DONE?	
1838	005260	001374			BNE	1\$:NO--BRANCH	
1839	005262	013737	001476	001150	MOV	#IPS,#\$IPS				:SETUP THE STATUS AND BUFFER REG'S	
1840	005270	013737	001500	001152	MOV	#TPB,#\$TPB				:FOR THE TYPE ROUTINE	
1841	005276	005227	177777		INC	#-1				:FIRST START ?	
1842	005302	001027			BNE	3\$:BR IF NOT	
1843	005304	104401	051776		TYPE	TITLE				:TYPE THE PROGRAM'S TITLE	
1844	005310	005737	000042		TST	42				:AUTO ACCEPT OR CHAIN MODE ?	
1845	005314	001007			BNE	2\$:BR IF EITHER	
1846	005316	122737	000077	000041	CMPB	#77,41				:LOADED FROM AN RMO3 ?	
1847	005324	001003			BNE	2\$:BR IF NOT	
1848	005326	104401	052052		TYPE	,LOADRV				:INSTRUCT THE OPERATOR TO REMOVE THE PACK	
1849										:ON DRIVE 0 IF DRIVE 0 IS TO BE TESTED	
1850	005332	000000			HALT					:HALT IF LOAD FROM RMO3.RMO2	
1851	005334	105737	000041	2\$:	TSTB	#41				:LOADED FROM PAPER TAPE ?	
1852	005340	001410			BEQ	3\$:BR IF NOT	
1853	005342	004737	052346		JSR	PC,\$SIZE				:SIZE THE MEMORY	
1854	005346	023727	052442	100000	CMP	\$LSTAD,#100000				:16K OR MORE ON THE SYSTEM ?	
1855	005354	103002			BHIS	3\$:BR IF YES	
1856	005356	104401	052250		TYPE	,NOLOAD				:INFORM THE OPERATOR THAT THE 'XXDP' LOADER	
1857										:WILL BE OVERWRITTEN	
1858	005362	004737	023366	3\$:	JSR	PC,\$TKINT				:TURN ON THE TTY KEYBOARD INTERRUPT	
1859					.SBTTL	GET VALUE FOR SOFTWARE SWITCH REGISTER				:SWITCH REGISTER	
1860	005366	005737	000042		TST	#42				:ARE WE RUNNING UNDER XXDP/ACT?	
1861	005372	001012			BNE	68\$:BRANCH IF YES	
1862	005374	123727	001240	000001	CMPB	\$ENV,#1				:ARE WE RUNNING UNDER APT?	
1863	005402	001406			BEQ	68\$:BRANCH IF YES	
1864	005404	023727	001140	000176	CMP	\$WR,#\$WREG				:SOFTWARE SWITCH REG SELECTED?	
1865	005412	001005			BNE	69\$:BRANCH IF NO	
1866	005414	104406			GTSWR					:GET SOFT-SWR SETTINGS	
1867	005416	000403			BR	69\$					
1868	005420	112737	000001	001134	68\$:	MOV#B	#1,\$AUTOB			::SET AUTO-MODE INDICATOR	
1869	005426				69\$:						
1870	005426	005227	177777		INC	#-1				:SEE IF FIRST START	
1871	005432	001002			BNE	SRTINT				:BR IF NOT	
1872	005434	004737	052444		JSR	PC,GETADR				:GET OR CHECK THE RH70 ADDRESS	
1873	005440	104401	001215		SRTINT:	TYPE	,\$CRLF			:CR-LF	
1874	005444	004737	026054		JSR	PC,\$PLP.AVL				:CHECK FOR A LINE PRINTER	
1875	005450	005037	177776		CLR	#PS				:ENSURE THE PRIORITY = 0	
1876	005454	012737	000001	001104	MOV	#1,\$ICNT				:SET ITERATION COUNT TO 1	
1877	005462	004737	033646		JSR	PC,\$GETSWR				:GO CHECK FOR CONTROL SWITCHES	
1878	005466	004737	026116		JSR	PC,\$ST.CLK				:INITIALIZE THE CLOCK	
1879	005472	004737	036754		SETVEC:	JSR	PC,\$RMINIT			:CHECK THE DRIVE STATUS	
1880	005476	012737	177777	036676	MOV	#-1,\$SAVEFG				:SET THE SAVE REGISTERS FLAG	
1881	005504	062727	177777	000000	ADD	#-1,#0				:FIRST START ?	
1882	005512	103003			BCC	11\$:BR IF YES	
1883	005514	005737	001304		TST	CNTRLC				:CONTROL 'C' SWITCH SET ?	
1884	005520	001101			BNE	SRTDRV				:CONTINUE IF YES	
1885	005522	012737	000340	177776	11\$:	MOV	#PR7,\$PS			:SET PRIORITY TO 7	
1886	005530	005004			CLR	R4				:DRIVE TABLE POINTER	
1887	005532	104401	001215		TYPE	,\$CRLF				:CR-LF	
1888	005536	104401	045204		TYPE	,\$SYSTAT				:TYPE STATUS HEADING	
1889	005542				1\$:						

1890	005542	010446		MOV	R4, -(SP)	:: SAVE R4 FOR TYPEOUT
1891						:: TYPE DRIVE NUMBER
1892	005544	104403		TYPOS		:: GO TYPE--OCTAL ASCII
1893	005546	002		.BYTE	2	:: TYPE 2 DIGIT(S)
1894	005547	000		.BYTE	0	:: SUPPRESS LEADING ZEROS
1895	005550	104401	046141	TYPE	, MSG.SP	:: SPACES
1896	005554	104401	046141	TYPE	, MSG.SP	:: SPACES
1897	005560	105764	036610	TSTB	DRVSTA(R4)	:: CHECK DRIVE'S STATUS
1898	005564	100416		BMI	4\$:: BR IF UNSAFE
1899	005566	001020		BNE	5\$:: BR IF ONLINE
1900	005570	105764	036620	TSTB	DRVTYP(R4)	:: SEE IF OFFLINE OR NONEXISTENT
1901	005574	001404		BEQ	2\$:: BR IF NONEXISTENT
1902	005576	100006		BPL	3\$:: BR IF OFFLINE
1903	005600	104401	045300	TYPE	, NOTRM	:: DRIVE NOT AN RM03
1904	005604	000437		BR	9\$:: CHECK NEXT DRIVE
1905	005606	104401	045253	TYPE	, NOTPRS	:: DRIVE NOT PRESENT
1906	005612	000434		BR	9\$:: CHECK NEXT DRIVE
1907	005614	104401	045232	TYPE	, UNTOFF	:: DRIVE OFFLINE
1908	005620	000405		BR	6\$:: PRINT DRIVE TYPE
1909	005622	104401	045270	TYPE	, NOTSAF	:: DRIVE UNSAFE
1910	005626	000402		BR	6\$:: PRINT DRIVE TYPE
1911	005630	104401	045243	TYPE	, UNTON	:: DRIVE ONLINE
1912	005634	104401	046141	TYPE	, MSG.SP	:: SPACES
1913	005640	012737	045324 005702	MOV	#1, RM03, B\$:: ADDRESS OF RM03 MESSAGE
1914	005646	122764	000004 036620	CMPB	#4, DRVTYP(R4)	:: RM03 ?
1915	005654	001411		BEQ	7\$:: TYPE IT IF YES
1916	005656	012737	045317 005702	MOV	#1, RM02, B\$:: MESSAGE OF RM02
1917	005664	122764	000005 036620	CMPB	#5, DRVTYP(R4)	:: RM02 ?
1918	005672	001402		BEQ	7\$:: BRANCH IF SO
1919	005674	104401	045300	TYPE	, NOTRM	:: TYPE DRIVE NOT AN RM03 IF NOT
1920	005700	104401		TYPE		:: TYPE THE DRIVE TYPE MESSAGE
1921	005702	000000		.WORD	0	:: MESSAGE ADDRESS HERE
1922	005704	104401	001215	TYPE	, \$CRLF	:: CR-LF
1923	005710	005204		INC	R4	:: INCREMENT DRIVE NUMBER/TABLE POINTER
1924	005712	020427	000010	CMP	R4, #8.	:: FINISHED ?
1925	005716	001311		BNE	1\$:: BR IF NOT
1926	005720	005037	177776	CLR	PS	:: SET PRIORITY BACK TO '0'
1927	005724	005737	001304	TST	#C, CNTRLC	:: CONTROL "C" START/RESTART?
1928	005730	001417		BEQ	1\$:: NO--BRANCH
1929	005732	013746	001302	MOV	SAVCSW, -(SP)	:: GET THE PREVIOUS 'C.SWR' CONTENTS
1930	005736	063716	001300	ADD	C.SWR, (SP)	:: SET UP TO SEE IF 'BIT00' IS DIFFERENT
1931	005742	032726	000001	BIT	#BIT00, (SP)+	:: IS 'BIT00' DIFFERENT ?
1932	005746	001405		BEQ	9\$:: BR IF NOT
1933	005750	013737	001300 001302	MOV	C.SWR, SAVCSW	:: STORE PRESENT 'C.SWR' VALUE
1934	005756	004737	026374	JSR	PC, LODFLT	:: RESET PARAMETERS TO THEIR DEFAULT VALUES
1935	005762	004737	034076	JSR	PC, #GT.PRM	:: GET PARAMETERS
1936	005766	000420		BR	4\$	
1937	005770	004737	026374	JSR	PC, LODFLT	:: SETUP DEFAULT PARAMETERS
1938	005774	005037	001312	CLR	DRVSEL	:: NO DRIVES SELECTED
1939	006000	005000		CLR	RO	:: DETERMINE THE DRIVES THAT
1940	006002	012701	000001	MOV	#1, R1	:: ARE AVAILABLE FOR TESTING
1941	006006	105760	036610	TSTB	DRVSTA(RO)	
1942	006012	003403		BLE	3\$	
1943	006014	156037	036724 001312	BISB	ATABIT(RO), #DRVSEL	
1944	006022	005200		INC	RO	
1945	006024	106301		ASLB	R1	

E06

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST MACY11 30(1046) 22-NOV-77 08:04 PAGE 39
 CZRMFB.P11 21-NOV-77 14:10 GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0069

```

1946 006026 001367          BNE      2$
1947 006030 005037 036700 4$: CLR      @#SEEKFG ; CLEAR SEEK FLAG
1948 006034 032737 000400 001300 BIT      @#SW08,@#C.SWR ; DO SEEK BEFORE DATA TRANSFER?
1949 006042 001002          BNE      5$ ; YES--BRANCH
1950 006044 005137 036700 COM      @#SEEKFG ; NO
1951 006050 122737 000011 000041 5$: CMPB   @11,41 ; LOADED FROM AN RMO3 ?
1952 006056 001003          BNE      10$ ; BR IF NOT
1953 006060 042737 000001 001312 BIC     @BIT00,DRVSEL ; CLEAR THE DRIVE 0 SELECTION BIT
1954 006066 104401 045331 10$: TYPE  @DRIVES ; 'DRIVES(S) TO BE TESTED'
1955 006072 005037 021234 CLR     @#SENDCT ; DETERMINE PASSES TO MAKE AND
1956 006076 005000          CLR     @#SENDCT ; THE DRIVES TO BE TESTED
1957 006100 013701 001312 MOV     @#DRVSEL,R1 ; ANY DRIVES SELECTED?
1958 006104 001004          BNE     6$ ; YES--BRANCH
1959 006106 104401 045362 TYPE    ,NONE ; 'NONE'
1960
1961 006112 000137 021052          JMP     @#SEOP ; GO TO END OF PROGRAM
1962 006116 006201 6$: ASR     R1 ; REPORT THE DRIVES TO BE TESTED
1963 006120 103011          BCC     7$
1964 006122 005237 021234 INC     @#SENDCT ; GIVE THIS DRIVE A PASS
1965 006126 010046          MOV     @#RO,-(SP) ; SAVE RO FOR TYPEOUT
1966 006130 104403          TYPOS   ; GO TYPE--OCTAL ASCII
1967 006132 001          .BYTE  1 ; TYPE 1 DIGIT(S)
1968 006133 000          .BYTE  0 ; SUPPRESS LEADING ZEROS
1969 006134 005701          TST     R1 ; MORE DRIVES?
1970 006136 001404          BEQ     6$ ; NO--BRANCH
1971 006140 104401 045367          TYPE   @COMMA ; ','
1972 006144 005200 7$: INC     @#RO ; FORM DRIVE NUMBER
1973 006146 000763          BR      6$
1974 006150 013737 021234 021226 8$: MOV     @#SENDCT,@#SEOPCT
1975 006156 005737 001324 TST     @#CLKSTA ; KW11-P AVAILABLE
1976 006162 003006          BGT     RSTART1 ; YES--BRANCH
1977 006164 032737 036000 001314 BIT     @#36000,@#TSTNMS ; NO--ANY TIMING TESTS TO BE PERFORMED?
1978 006172 001402          BEQ     RSTART1 ; NO--BRANCH
1979 006174 104401 045371          TYPE   @NOCLOCK ; 'NO KW11-P CLOCK, TIMING TESTS WILL NOT BE PERFORMED'
1980 006200 005737 001312 RSTART1: TST   @DRVSEL ; ANY DRIVES SELECTED ?
1981 006204 001002          BNE     1$ ; BR IF YES
1982 006206 000137 004762          JMP     START2 ; GET DRIVE SELECTION ENTRY
1983 ; & RESTART AT BEGINNING -----
1984
1985 006212 005037 001334 1$: CLR     CHKDRV ; INIT. THE CHECK DRIVE KEY
1986 006216 012737 000001 001336 MOV     @1,DRVMSK ; START TO CHECK DESIRED DRIVES
1987 006224 033737 001336 001312 RSTART2: BIT   @DRVMSK,DRVSEL ; IS THIS DRIVE SELECTED?
1988 006232 001010          BNE     DRVOK ; YES--GO CHECK IF DRIVE IS READY FOR TESTING
1989 006234 012706 001100 RESTART: MOV  @#STACK,SP ; SETUP THE STACK POINTER
1990 006240 005237 001334 INC     CHKDRV ; MOVE TO NEXT DRIVE NUMBER
1991 006244 106337 001336 ASLB   @DRVMSK ; POSITION THE MASK
1992 006250 103753          BCS     RSTART1 ; BRANCH IF THE DRIVE NUMBER NEEDS INITIALIZED
1993 006252 000764          BR      RSTART2
1994
1995 006254 013702 001334 DRVOK: MOV   @CHKDRV,R2 ; PICKUP THE DRIVE NUMBER
1996 006260 105762 036610 TSTB   @DRVSTA(R2) ; IS DESIRED DRIVE ON-LINE?
1997 006264 003005          BGT     1$ ; YES, BRANCH
1998 006266 104011          ERROR  11 ; DRIVE SELECTED IS NOT ONLINE
1999 006270 043737 001336 001312 BIC     @DRVMSK,DRVSEL ; CLEAR DRIVE'S SELECTION BIT
2000 006276 000756          BR      RESTART ; RETURN
2001 006300 010237 004206 1$: MOV     R2,@#DPB.A ; SET THE DRIVE NUMBER INTO THE DPB'S

```


2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152

;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE
;* COMMAND CYCLE AND THEN SEEK FORWARD TO CYLINDER "LC" AT
;* THE COMPLETION OF BOTH COMMANDS STATUS INDICATIONS ARE
;* CHECKED TO ENSURE NO ERRORS OCCURRED.

TSTO:

```

006506      NOP
006506 000240      BIT      2#BITS+(0*2),TSTNMS ;DO THIS TEST?
006510 033737 001506 001314      BNE      64$ ;YES--BRANCH
006516 001002      JMP      TST1 ;NO--GO TO THE NEXT TEST
006520 000137 006714      MOV      #0,2#TSTNM ;SET UP TEST NUMBER AND
006524 012737 000000 001102 64$: ;CLEAR THE ERROR FLAG ($ERFLG)
;LOAD THE PARAMETERS FOR THE TEST
006532 004737 026632      JSR      PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
006536 012737 006676 001110      MOV      #TSTO,2#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
006544 013777 001102 172370      MOV      $TSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
006552 013737 001570 001204      MOV      2#RPT,$TIMES ;GET THE ITERATION COUNT
006560 112737 000031 001115      MOV      #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
006566 012737 000000 001224      MOV      #0,$TSTN ;SET TEST NUMBER IN APT MAIL BOX

```

: THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET

```

006574 032777 010000 172336      BIT      #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
006602 001413      BEQ      20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
006604 013700 001102      MOV      $TSTNM,RO ;ELSE, TYPE THE NUMBER
006610 042700 177000      BIC      #177000,RO ;MASK' OUT THE HIGH ORDER BYTE
006614 104401 001215      TYPE      $,CRLF
006620 010046      MOV      RO,-(SP) ;SAVE RO FOR TYPEOUT
;TEST NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 2 DIGIT(S)
;SUPPRESS LEADING ZEROS
006622 104403      TYPOS
006624 002      .BYTE 2
006625 000      .BYTE 0
006626 104401 001215      TYPE      $,CRLF
20$:

```

20\$:

```

006632 112737 000107 004210      MOV      #RECAL,2#DPB.A+2 ;RECAL=COMMAND
006640 113737 001606 004236      MOV      2#FS,2#DPB.B+10 ;FS
006646 113737 001600 004237      MOV      2#FT,2#DPB.B+11 ;FT
006654 013737 001574 004240      MOV      2#LC,2#DPB.B+12 ;LC
006662 012737 006712 001332      MOV      #EXITO,2#BYPASS ;GO TO EXITO ON ERROR
006670 012737 006676 001106      MOV      #TSTO,$LPADR ;SETUP LOOP ADDRESS
TESTO: 006676 012706 001100      MOV      #STACK,SP ;SET UP STACK POINTER
006702 004037 027054      JSR      RO,2#CALL.A ;GO EXECUTE THE COMMAND
006706 004037 027206      JSR      RO,2#CALL.B ;GO EXECUTE THE COMMAND
EXITO: SCOPE ;LOOP

```

*TEST 1 SEEK/SEEK TEST

;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK
;* CYCLE TO "LC" "LT" "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO
;* "FC" "FT" "FS". AT THE COMPLETION OF EACH SEEK, THE PROPER
;* INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
;* "LC" WILL DEFAULT TO 128 AND "FC", "FT", "LT", "FS", AND "LS"
;* WILL DEFAULT TO 0

```

2153
2154 006714
2155 006714 000240
2156 006716 033737 001510 001314
2157 006724 001002
2158 006726 000137 007142
2159 006732 012737 000001 001102 64$:
2160
2161 006740 004737 026632
2162 006744 012737 007124 001110
2163 006752 013777 001102 172162
2164 006760 013737 001570 001204
2165 006766 112737 000031 001115
2166 006774 012737 000001 001224
2167
2168
2169 007002 032777 010000 172130
2170 007010 001413
2171 007012 013700 001102
2172 007016 042700 177000
2173 007022 104401 001215
2174 007026 010046
2175
2176 007030 104403
2177 007032 002
2178 007033 000
2179 007034 104401 001215 20$:
2180 007040
2181
2182 007040 005037 001446
2183 007044 113737 001606 004236
2184 007052 113737 001610 004256
2185 007060 113737 001600 004237
2186 007066 113737 001602 004257
2187 007074 013737 001572 004240
2188 007102 013737 001574 004260
2189 007110 012737 007140 001332
2190 007116 012737 007124 001106
2191 007124 012706 001100
2192 007130 004037 027410
2193 007134 004037 027206
2194 007140 000004
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208

:*****
↑ST1:
NOP
BIT @#BITS+(<1*2>),TSTNMS ;DO THIS TEST?
BNE 64$ ;YES--BRANCH
JMP TST2 ;NO--GO TO THE NEXT TEST
MOV #1,@#STSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG (SERFLG)
JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
MOV #TEST1,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
MOV $STSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV @#RPT,$TIMES ;GET THE ITERATION COUNT
MOVB #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
MOV #1,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
BIT #SW12,@SWR ;CHECK FOR SWITCH 12 SET
BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
MOV $STSTNM,R0 ;ELSE, ↑PE THE NUMBER
BIC #177000,R0 ;MASK OUT THE HIGH ORDER BYTE
TYPE $CRLF
MOV R0,-(SP) ;;SAVE R0 FOR TYPEOUT
;;TEST NUMBER
;;GO TYPE--OCTAL ASCII
;;TYPE 2 DIGIT(S)
;;SUPPRESS LEADING ZEROS
20$:
TYPE ,CRLF

CLR BASFLG ;CLEAR BAD SECTOR ENCOUNTER FOR THE DRIVE
MOVB @#FS,@#DPB.B+10 ;FS
MOVB @#LS,@#DPB.C+10 ;LS
MOVB @#FT,@#DPB.B+11 ;FT
MOVB @#LT,@#DPB.C+11 ;LT
MOV @#FC,@#DPB.B+12 ;FC
MOV @#LC,@#DPB.C+12 ;LC
MOV #EXIT1,@#BYPASS ;GO TO EXIT1 ON ERROR
MOV #TEST1,$LPADR ;SETUP LOOP ADDRESS
TEST1: MOV #STACK,SP ;SET THE STACK POINTER
JSR R0,@#CALL.C ;GO EXECUTE THE COMMAND
JSR R0,@#CALL.B ;GO EXECUTE THE COMMAND
EXIT1: SCOPE ;LOOP

:*****
;TEST 2 INCREMENT/SEEK TEST

;*
;* THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
;* CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC".
;* WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS
;* "LC" REVERSE SEEK CYCLES ARE INITIATED; STARTING
;* AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC"
;* UNTIL "NC" IS LESS THAN "FC". AT THE COMPLETION OF EACH
;* SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
;* ENSURE PROPER OPERATION.
;*****

```

J06

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T2

MACY11 30(1046) 22-NOV-77 08:04 PAGE 44
INCREMENT/SEEK TEST

SEQ 0074

```

2209 007142          TS 2:
2210 007142 000240  NOP
2211 007144 033737 001512 001314  BIT      @#BITS+(2*2),TSTNMS,DO THIS TEST?
2212 007152 001002  BNE      64$ ;YES--BRANCH
2213 007154 000137 007424  JMP      TST3 ;NO--GO TO THE NEXT TEST
2214 007160 012737 000002 001102 64$: MOV      #2,@#TSTNM ;SET UP TEST NUMBER AND
2215          ;CLEAR THE ERROR FLAG ($ERFLG)
2216 007166 004737 026632  JSR      PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
2217 007172 012737 007316 001110  MOV      @#TEST2,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
2218 007200 013777 001102 171734  MOV      $TSTNM,@#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2219 007206 013737 001570 001204  MOV      @#RPT,$TIMES ;GET THE ITERATION COUNT
2220 007214 112737 000031 001115  MOVVB   #25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
2221 007222 012737 000002 001224  MOV      #2,$TSTN ;SET TEST NUMBER IN APT MAIL BOX
2222
2223          ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
2224 007230 032777 010000 171702  BIT      #SW12,@SWR ;CHECK FOR SWITCH 12 SET
2225 007236 001413  BEQ      20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
2226 007240 013700 001102  MOV      $TSTNM,RO ;ELSE, TYPE THE NUMBER
2227 007244 042700 177000  BIC      #177000,RO ;MASK OUT THE HIGH ORDER BYTE
2228 007250 104401 001215  TYPE    $CRLF
2229 007254 010046  MOV      RO,-(SP) ;SAVE RO FOR TYPEOUT
2230          ;TEST NUMBER
2231 007256 104403  TYPOS   ;GO TYPE--OCTAL ASCII
2232 007260 002      .BYTE 2 ;TYPE 2 DIGIT(S)
2233 007261 000      .BYTE 0 ;SUPPRESS LEADING ZEROS
2234 007262 104401 001215  TYPE    ,CRLF
2235 007266          20$:
2236
2237 007266 012737 007274 001106  MOV      #1$,SLPADR ;SETUP LOOP ADDRESS
2238 007274 113737 001606 004236 1$: MOVVB  @#FS,@#DPB.B+10 ;FS
2239 007302 113737 001600 004237  MOVVB  @#FT,@#DPB.B+11 ;FT
2240 007310 012737 007422 001332  MOV      @#EXIT2,@#BYPASS ;GO TO EXIT2 ON ERROR
2241 007316 013737 001572 004240  TEST2: MOV      @#FC,@#DPB.B+12 ;FC
2242 007324 012737 007324 001110  MOV      #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
2243 007332 012706 001100  MOV      @#STACK,SP ;LOAD THE STACK POINTER
2244 007336          INCSK:
2245 007336 004037 027206  JSR      RO,@#CALL.B ;GO EXECUTE THE COMMAND
2246 007342 063737 001576 004240  ADD      @#IC,@#DPB.B+12 ;MOVE TO NEXT CYLINDER
2247 007350 023737 001574 004240  CMP      @#LC,@#DPB.B+12 ;OUT OF CYLINDERS?
2248 007356 002367  BGE      INCSK ;NO--BRANCH
2249 007360 013737 001574 004 40  MOV      @#LC,@#DPB.B+12
2250 007366 012737 007366 001110  MOV      #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
2251 007374 012706 001100  MOV      @#STACK,SP ;LOAD THE STACK POINTER
2252          DECSK:
2253 007400 004037 027206  JSR      RO,@#CALL.B ;GO EXECUTE THE COMMAND
2254 007404 163737 001576 004240  SUB      @#IC,@#DPB.B+12
2255 007412 023737 001572 004240  CMP      @#FC,@#DPB.B+12
2256 007420 003767  BLE      DECSK
2257 007422 000004  EXIT2: SCOPE ;LOOP
2258
2259          ;*****
2260          ;*TEST 3 STEPPING SEEK TEST
2261
2262          ;* THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0,1,2,4,
2263          ;* 8,16,32,64,128, AND 256. AT THE COMPLETION OF EACH SEEK
2264          ;* COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER

```

```

2265 ;* OPERATION.
2266
2267 ;*****
2268 †ST3:
2269 007424 000240 NOP
2270 007426 033737 001514 001314 BIT 2#BITS+(3*2),TSTNMS ;DO THIS TEST?
2271 007434 001002 BNE 64$ ;YES--BRANCH
2272 007436 000137 007664 JMP TST4 ;NO--GO TO THE NEXT TEST
2273 007442 012737 000003 001102 64$: MOV #3,2#STSTNM ;SET UP TEST NUMBER AND
2274 ;CLEAR THE ERROR FLAG (SERFLG)
2275 007450 004737 026632 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
2276 007454 012737 007600 001110 MOV #TST3,2#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
2277 007462 013777 001102 171452 MOV STSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2278 007470 013737 001570 001204 MOV 2#RPT,$TIMES ;GET THE ITERATION COUNT
2279 007476 112737 000031 001115 MOVB #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
2280 007504 012737 000003 001224 MOV #3,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
2281
2282 ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
2283 007512 032777 010000 171420 BIT #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
2284 007520 001413 BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
2285 007522 013700 001102 MOV $STSTNM,R0 ;ELSE, TYPE THE NUMBER
2286 007526 042700 177000 BIC #177000,R0 ;MASK OUT THE HIGH ORDER BYTE
2287 007532 104401 001215 TYPE $CRLF
2288 007536 010046 MOV R0,-(SP) ;SAVE R0 FOR TYPEOUT
2289 ;TEST NUMBER
2290 007540 104403 TYPOS ;GO TYPE--OCTAL ASCII
2291 007542 002 .BYTE 2 ;TYPE 2 DIGIT(S)
2292 007543 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
2293 007544 104401 001215 TYPE , $CRLF
2294 007550 20$:
2295
2296 007550 012737 007556 001106 MOV #1$,$LPADR ;SETUP TEST LOOP ADDRESS
2297 007556 113737 001606 004236 1$: MOVB 2#FS,2#DPB.B+10 ;FS
2298 007564 113737 001600 004237 MOVB 2#FT,2#DPB.B+11 ;FT
2299 007572 012737 007662 001332 MOV #EXIT3,2#BYPASS ;GO TO BYPASS ON ERROR
2300 007600 013737 001572 004240 TEST3: MOV 2#FC,2#DPB.B+12 ;FC
2301 007606 012737 007606 001110 MOV #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
2302 007614 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
2303 007620 004037 027206 JSR R0,2#CALL.B ;GO EXECUTE THE COMMAND
2304 007624 013701 001576 MOV IC,R1 ;CYLINDER 1
2305 007630 012737 007630 001110 MOV #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
2306 007636 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
2307 007642 010137 004240 1$: MOV R1,2#DPB.B+12 ;DESIRED CYLINDER
2308 007646 004037 027206 JSR R0,2#CALL.B ;GO EXECUTE THE COMMAND
2309 007652 006301 ASL R1 ;MOVE TO NEXT CYLINDER
2310 007654 020137 001574 CMP R1,2#LC ;DONE?
2311 007660 003770 BLE 1$ ;NO--LOOP
2312 007662 000004 EXIT3: SCOPE
2313
2314 ;*****
2315 ;*TEST 4 OSCILLATING SEEK TEST
2316
2317 ;* THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK
2318 ;* TO "FC". "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER
2319 ;* "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC". AT THE
2320 ;* COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE

```

```

2321 ;* EXAMINED TO ENSURE PROPER OPERATION.
2322
2323
2324 ;*****
2325 †ST4:
2326 NOP
2327 BIT 2#BITS+(4*2),TSTNMS ;DO THIS TEST?
2328 BNE 64$ ;YES--BRANCH
2329 JMP TST5 ;NO--GO TO THE NEXT TEST
2330 MOV #4,2#STSTNM ;SET UP TEST NUMBER AND
2331 JSR PC,LODPRM ;CLEAR THE ERROR FLAG (SERFLG)
2332 MOV #TEST4,2#SLPERR ;LOAD THE PARAMETERS FOR THE TEST
2333 MOV STSTNM,2#DISPLAY ;SETUP THE LOOP ON ERROR ADDRESS
2334 MOV 2#RPT,$TIMES ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2335 MOVB #25,$ERMAX ;GET THE ITERATION COUNT
2336 MOV #4,$TESTN ;MAX ERRORS ALLOWED FOR TEST
2337 ;SET TEST NUMBER IN APT MAIL BOX
2338
2339 .THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
2340 BIT #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
2341 BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
2342 MOV STSTNM,RO ;ELSE, TYPE THE NUMBER
2343 BIC #177000,RO ;MASK OUT THE HIGH ORDER BYTE
2344 TYPE $CRLF
2345 MOV RO,-(SP) ;SAVE RO FOR TYPEOUT
2346 ;TEST NUMBER
2347 ;GO TYPE--OCTAL ASCII
2348 .BYTE 2 ;TYPE 2 DIGIT(S)
2349 .BYTE 0 ;SUPPRESS LEADING ZEROS
2350 TYPE , $CRLF
2351
2352 20$:
2353 MOV #15,$LPADR ;SETUP LOOP ADDRESS
2354 MOVB 2#FS,2#DPB.B+10 ;FS
2355 MOVB 2#FT,2#DPB.B+11 ;FT
2356 MOV #EXIT4,2#BYPASS ;GO TO EXIT4 ON ERROR
2357 CLR R2 ;CLEAR STALL SWITCH (NO STALL)
2358 BIT #SW12,2#C.SWR ;STALL REQUIRED?
2359 BEQ TEST4 ;NO--BRANCH
2360 COM R2 ;YES--SET SWITCH
2361 MOV 2#FC,R1 ;SET NC TO FC
2362 CLR 2#STALLO ;START AT ZERO IF STALLS REQUIRED
2363 MOV #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
2364 MOV #,$STACK,SP ;LOAD THE STACK POINTER
2365 MOV R1,2#DPB.B+12 ;NC
2366 JSR RO,2#CALL.B ;GO EXECUTE THE COMMAND
2367 TST R2 ;STALL?
2368 BEQ 2$ ;NO--BRANCH
2369 JSR RO,2#STALL ;YES--GO TO STALL ROUTINE
2370 .WORD STALLO ;TIME POINTER
2371 MOV FC,2#DPB.B+12 ;FC
2372 JSR RO,2#CALL.B ;GO EXECUTE THE COMMAND
2373 TST R2 ;STALL?
2374 BEQ 3$ ;NO--BRANCH
2375 JSR RO,2#STALL ;YES--GO TO STALL ROUTINE
2376 .WORD STALLO ;TIME POINTER
2377 INC 2#STALLO ;UPDATE THE TIME

```

M06

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T4

MACY11 30(1046) 22-NOV-77 08:04 PAGE 47
OSCILLATING SEEK TEST

SEQ 0077

2377	010150	023737	001442	001416		CMP	2#MXSTAL,2#STALLO	:TIME TO BIG?
2378	010156	003347				BGT	1\$:NO--BRANCH
2379	010160	005037	001416			CLR	2#STALLO	:YES--START OVER AT ZERO
2380	010164	063701	001576		3\$:	ADD	2#IC,R1	:MOVE TO NEXT CYLINDER
2381	010170	020137	001574			R1,2#LC		:LAST CYLINDER COMPLETED?
2382	010174	003740				BLE	1\$:NO--BRANCH
2383	010176	013701	001574			MOV	2#LC,R1	:SET NC TO LC
2384	010202	012737	010202	001110		MOV	2#SLPERR	:SETUP THE ERROR LOOP ADDRESS
2385	010210	012706	001100			MOV	2#STACK,SP	:LOAD THE STACK POINTER
2386	010214	010137	004240		4\$:	MOV	R1,2#DPB.B+12	:NC
2387	010220	004037	027206			JSR	R0,2#CALL.B	:GO EXECUTE THE COMMAND
2388	010224	005702				TST	R2	:STALL?
2389	010226	001403				BEQ	5\$:NO--BRANCH
2390	010230	004037	030606			JSR	R0,2#STALL	:YES--GO TO STALL ROUTINE
2391	010234	001416				.WORD	STALLO	:TIME POINTER
2392	010236	013737	001574	004240	5\$:	MOV	2#LC,2#DPB.B+12	:LC
2393	010244	004037	027206			JSR	R0,2#CALL.B	:GO EXECUTE THE COMMAND
2394	010250	005702				TST	R2	:STALL?
2395	010252	001413				BEQ	6\$:NO--BRANCH
2396	010254	004037	030606			JSR	R0,2#STALL	:YES--GO TO STALL ROUTINE
2397	010260	001416				.WORD	STALLO	:TIME POINTER
2398	010262	005237	001416			INC	2#STALLO	:UPDATE STALL TIME
2399	010266	023737	001442	001416		CMP	2#MXSTAL,2#STALLO	:TIME TOO BIG?
2400	010274	003347				BGT	4\$:NO--BRANCH
2401	010276	005037	001416			CLR	2#STALLO	:YES--SET STALL TIME BACK TO ZERO
2402	010302	163701	001576		6\$:	SUB	2#IC,R1	:NEXT CYLINDER
2403	010306	020137	001572			CMP	R1,2#FC	:DONE?
2404	010312	002340				BGE	4\$:NO--BRANCH
2405	010314	000004			EXIT4:	SCOPE		:LOOP

;*TEST 5 CONVERGING/DIVERGING SEEK TEST

;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE
;* SEEKS FROM "NC1" AND "NC2" RESPECTIVELY, "NC1" WILL BE INCREMENTED
;* BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS
;* GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS
;* LESS THAN THE INITIAL VALUE OF "NC1". AT THE COMPLETION OF
;* EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
;* ENSURE PROPER OPERATION. "NC1" AND "NC2" DEFAULT TO
;* "FC" AND "LC" RESPECTIVELY.

;*TESTS:

2420	010316					NOP		
2421	010316	000240				BIT	2#BITS+(5*2),TS^NMS	:DO THIS TEST?
2422	010320	033737	001520	001314		BNE	64\$:YES--BRANCH
2423	010326	001002				JMP	TST6	:NO--GO TO THE NEXT TEST
2424	010330	000137	010562			MOV	#5,2#STSTNM	:SET UP TEST NUMBER AND
2425	010334	012737	000005	001102	64\$:			:CLEAR THE ERROR FLAG (SERFLG)
2426						JSR	PC,LODPRM	:LOAD THE PARAMETERS FOR THE TEST
2427	010342	004737	026632			MOV	2#TESTS,2#SLPERR	:SETUP THE LOOP ON ERROR ADDRESS
2428	010346	012737	010472	001110		MOV	2#STSTNM,2#DISPLAY	:LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2429	010354	013777	001102	170560		MOV	2#RPT,\$TIMES	:GET THE ITERATION COUNT
2430	010362	013737	001570	001204		MOV	#25,\$ERMAX	:MAX ERRORS ALLOWED FOR TEST
2431	010370	112737	000031	001115		MOV	#5,\$TESTN	:SET TEST NUMBER IN APT MAIL BOX
2432	010376	012737	000005	001224				

N06

MD-11-DZRMF-B RM03/RM02 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T5

MACY11 30(1046) 22-NOV-77 08:04 PAGE 48
CONVERGING/DIVERGING SEEK TEST

SEQ 0078

```

2433
2434
2435 010404 032777 010000 170526
2436 010412 001413
2437 010414 013700 001102
2438 010420 042700 177000
2439 010424 104401 001215
2440 010430 010046
2441
2442 010432 104403
2443 010434 002
2444 010435 000
2445 010436 104401 001215
2446 010442
2447
2448 010442 012737 010450 001106
2449 010450 113737 001606 004236 1$:
2450 010456 113737 001600 004237
2451 010464 012737 010560 001332
2452 010472 013701 001572 TESTS:
2453 010476 013702 001574
2454 010502 012737 010502 001110
2455 010510 012706 001100
2456 010514 010137 004240 1$:
2457 010520 004037 027206
2458 010524 010237 004240
2459 010530 004037 027206
2460 010534 063701 001576
2461 010540 163702 001576
2462 010544 020137 001574
2463 010550 003003
2464 010552 020237 001572
2465 010556 002356
2466 010560 000004
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479 010562
2480 010562 000240
2481 010564 033737 001522 001314
2482 010572 001002
2483 010574 000137 011072
2484 010600 012737 000006 001102 64$:
2485
2486 010606 004737 026632
2487 010612 012737 010736 001110
2488 010620 013777 001102 170314

; THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
BIT #SW12, @SWR ; CHECK FOR SWITCH 12 SET
BEQ 20$ ; IF = 0, THEN DON'T TYPE TEST NUMBER
MOV $TSTNM, R0 ; ELSE, TYPE THE NUMBER
BIC #177000, R0 ; MASK OUT THE HIGH ORDER BYTE
TYPE $CRLF
MOV R0, -(SP) ; SAVE R0 FOR TYPEOUT
; TEST NUMBER
; GO TYPE--OCTAL ASCII
; TYPE 2 DIGIT(S)
; SUPPRESS LEADING ZEROS
TYPE , $CRLF

20$:
MOV #1$ $LPADR ; SETUP LOOP ADDRESS
1$: MOVB @#FS, @#DPB.B+10 ; FS
MOVB @#FT, @#DPB.B+11 ; FT
MOV @#EXITS, @#BYPASS ; GO TO EXITS ON ERROR
TESTS: MOV @#FC, R1 ; START NC1 AT FC
MOV @#LC, R2 ; START NC2 AT LC
MOV #. $LPERR ; SETUP THE ERROR LOOP ADDRESS
1$: MOV #STACK SP ; LOAD THE STACK POINTER
NC1: MOV R1, @#DPB.B+12 ; NC1
JSR R0, @#CALL.B ; GO EXECUTE THE COMMAND
NC2: MOV R2, @#DPB.B+12 ; NC2
JSR R0, @#CALL.B ; GO EXECUTE THE COMMAND
ADD @#IC, R1 ; NEXT NC1
SUB @#IC, R2 ; NEXT NC2
CMP R1, @#LC ; DONE?
BGT EXITS ; YES--BRANCH
CMP R2, @#FC ; ?
1$ ; NO--BRANCH
EXITS: SCOPE ; LOOP

; *****
; *TEST 6 SERVO ADDRESSING LOGIC NOISE GENERATOR
; *****
; * IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO
; * NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5. NOW "NC" IS UPDATED
; * BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS
; * EXCEEDED BY ANY OF THE ABOVE VALUES. THE INITIAL VALUE OF "NC"
; * IS "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE
; * PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
; *****
†$T6:
NOP
BIT @#BITS+(6*2), $TSTNMS ; DO THIS TEST?
BNE 64$ ; YES--BRANCH
JMP TST7 ; NO--GO TO THE NEXT TEST
64$: MOV #6, @#$TSTNM ; SET UP TEST NUMBER AND
; CLEAR THE ERROR FLAG ($ERFLG)
JSR PC, LODPRM ; LOAD THE PARAMETERS FOR THE TEST
MOV #TST6, @#$LPERR ; SETUP THE LOOP ON ERROR ADDRESS
MOV $TSTNM, @DISPLAY ; LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER

```



```

2489 010626 013737 001570 001204
2490 010634 112737 000031 001115
2491 010642 012737 000006 001224
2492
2493
2494
2495 010650 032777 010000 170262
2496 010656 001413
2497 010660 013700 001102
2498 010664 042700 177000
2499 010670 104401 001215
2500 010674 010046
2501 010676 104403
2502 010700 002
2503 010701 000
2504 010702 104401 001215
2505 010706
2506
2507 010706 012737 010714 001106
2508 010714 113737 001606 004236
2509 010722 113737 001600 004237
2510 010730 012737 011070 001332
2511 010736 013701 001572
2512 010742 013702 001574
2513 010746 162702 000005
2514 010752 012737 010752 001110
2515 010760 012706 001100
2516 010764 020102
2517 010766 003040
2518 010770 010137 004240
2519 010774 004037 027206
2520 011000 062737 000004 004240
2521 011006 004037 027206
2522 011012 162737 000003 004240
2523 011020 004037 027206
2524 011024 062737 000002 004240
2525 011032 004037 027206
2526 011036 162737 000001 004240
2527 011044 004037 027206
2528 011050 062737 000003 004240
2529 011056 004037 027206
2530 011062 063701 001576
2531 011066 000736
2532 011070 000004
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544

```

```

MOV      @RPT, $TIMES      ; GET THE ITERATION COUNT
MOVVB   #25, $ERMAX       ; MAX ERRORS ALLOWED FOR TEST
MOV      #6, $TESTN       ; SET TEST NUMBER IN APT MAIL BOX

; THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
BIT      #SW12, @SWR      ; CHECK FOR SWITCH 12 SET
BEQ     20$, $            ; IF = 0, THEN DON'T TYPE TEST NUMBER
MOV      $STNM, R0        ; ELSE, TYPE THE NUMBER
BIC     #177000, R0       ; MASK OUT THE HIGH ORDER BYTE
TYPE    $RCLF
MOV      R0, -(SP)        ; GIVE R0 FOR TYPEOUT
; TEST NUMBER
; GO TYPE--OCTAL ASCII
; TYPE 2 DIGIT(S)
; SUPPRESS LEADING ZEROS
TYPE    , $RCLF

20$:
MOV      #1$, $LPADR      ; SETUP LOOP ADDRESS
1$:
MOVVB   @#FS, @#DPB.B+10 ; FS
MOVVB   @#FT, @#DPB.B+11 ; FT
MOV      @EXIT6, @#BYPASS ; GO TO EXIT6 ON ERROR
TEST6:
MOV      @#FC, R1        ; PICKUP "FC"
MOV      @#LC, R2        ; FORM LAST CYLINDER THAT
SUB      #5, R2          ; IS AVAILABLE FOR TESTING
MOV      @#SLPERR, R1     ; SETUP THE ERROR LOOP ADDRESS
MOV      @#STACK, SP     ; LOAD THE STACK POINTER
1$:
CMP     R1, R2          ; LAST CYLINDER
BGT     EXIT6           ; YES--BRANCH
MOV      R1, @#DPB.B+12  ; NC
JSR     R0, @#CALL.B     ; GO EXECUTE THE COMMAND
ADD     #4, @#DPB.B+12  ; NC+4
JSR     R0, @#CALL.B     ; GO EXECUTE THE COMMAND
SUB     #3, @#DPB.B+12  ; NC+1
JSR     R0, @#CALL.B     ; GO EXECUTE THE COMMAND
ADD     #2, @#DPB.B+12  ; NC+3
JSR     R0, @#CALL.B     ; GO EXECUTE THE COMMAND
SUB     #1, @#DPB.B+12  ; NC+2
JSR     R0, @#CALL.B     ; GO EXECUTE THE COMMAND
ADD     #3, @#DPB.B+12  ; NC+5
JSR     R0, @#CALL.B     ; GO EXECUTE THE COMMAND
ADD     @#IC, R1
BR      1$
EXIT6:
SCOPE
; LOOP

```

```

; *****
; *TEST 7 RANDOM SEEK TEST
; *
; * THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC'
; * 'LC'. AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY
; * READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK.
; * THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION
; * OF POSITIONING OCCURS USING EACH HEAD. TRACK ADDRESSES ARE INCREMENTED
; * BETWEEN PARAMTERS 'FT' AND 'LT'.
; *****

```

```

2545 011072          TST7:
2546 011072 000240      NOP
2547 011074 033737 001524 001314  BIT      2#BITS+<7*2>,TSTNMS ;DO THIS TEST?
2548 C11102 001002      BNE      64$                ;YES--BRANCH
2549 011104 000137 011516  JMP      TST10             ;NO--GO TO THE NEXT TEST
2550 011110 012737 000007 001102 64$:  MOV      #7,2#TSTNM        ;SET UP TEST NUMBER AND
2551                                     ;CLEAR THE ERROR FLAG (SERFLG)
2552 011116 004737 026632      JSR      PC,LODPRM         ;LOAD THE PARAMETERS FOR THE TEST
2553 011122 012737 011260 001110  MOV      #TST7,2#SLPERR    ;SETUP THE LOOP ON ERROR ADDRESS
2554 011130 013777 001102 170004  MOV      $TSTNM,2#DISPLAY  ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2555 011136 013737 001570 001204  MOV      2#RPT,$TIMES      ;GET THE ITERATION COUNT
2556 011144 112737 000031 001115  MOV      #25,$SERMAX      ;MAX ERRORS ALLOWED FOR TEST
2557 011152 012737 000007 001224  MOV      #7,$TSTN         ;SET TEST NUMBER IN APT MAIL BOX
2558
2559                                     ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
2560 011160 032777 010000 167752  BIT      #SW12,2#SWR      ;CHECK FOR SWITCH 12 SET
2561 011166 001413      BEQ      20$                ;IF = 0, THEN DON'T TYPE TEST NUMBER
2562 011170 013700 001102      MOV      $TSTNM,R0        ;ELSE, TYPE THE NUMBER
2563 011174 042700 177000      BIC      #177000,R0      ;MASK OUT THE HIGH ORDER BYTE
2564 011200 104401 001215      TYPE    $RCLF
2565 011204 010046      MOV      R0,-(SP)         ;SAVE R0 FOR TYPEOUT
2566                                     ;TEST NUMBER
2567 011206 104403      TYPOS   ;GO TYPE--OCTAL ASCII
2568 011210          002      .BYTE  2                ;TYPE 2 DIGIT(S)
2569 011211          000      .BYTE  0                ;SUPPRESS LEADING ZEROS
2570 011212 104401 001215      TYPE    $RCLF
2571 011216          20$:
2572
2573 011216 113737 001600 004237  MOV      FT,DPB.B+11      ;LOAD STARTING TRACK ADDRESS
2574 011224 112737 000105 004210  MOV      #SEEK,2#DPB.A+2  ;SEEK=COMMAND
2575 011232 112737 000173 004230  MOV      #READHD,DPB.B+2 ;READ HEADER & DATA COMMAN.
2576 011240 013704 036736      MOV      RMAADR,R4        ;UNIBUS ADDRESS OF THE RH70
2577 011244 012737 011514 001332  MOV      #EXIT7,BYPASS    ;ERROR TERMINATION ADDRESS
2578 011252 012737 011260 001106  MOV      #TST7,$LPAOR     ;SETUP THE LOOP ON TEST ADDRESS
2579 011260 012706 001100      MOV      #STACK,SP        ;SETUP THE STACK POINTER
2580 011264 013737 001572 004240  MOV      FC,DPB.B+12      ;INITIAL CYLINDER ADDRESS
2581 011272 023737 001572 001574  CMP      FC,LC            ;CYLINDER LIMITS THE SAME ?
2582 011300 001422      BEQ      1$                ;BR IF THEY ARE
2583 011302 004737 025532      JSR      PC,$RAND         ;CYCLE THE RANDOM NUMBER GENERATOR
2584 011306 013746 025630      MOV      $HNUM,-(SP)      ;USE THE HIGH RANDOM NUMBER
2585 011312 005046      CLR      -(SP)           ;UPPER DIVIDEND
2586 011314 013746 001574      MOV      LC,-(SP)         ;FORM THE DIVISOR
2587 011320 005216      INC      (SP)            ;INCREMENT
2588 011322 163716 001572      SUB      FC,(SP)         ;SUBTRACT THE LOWER LIMIT
2589 011326 004737 025634      JSR      PC,$DIV         ;DIVIDE
2590 011332 062637 004240      ADD      (SP)+,DPB.B+12   ;ADD THE REMAINDER TO THE INITIAL CYLINDER
2591 011336 005726      TST     (SP)+            ;DISCARD THE QUOTIENT
2592 011340 013737 004240 004220  MOV      DPB.B+12,DPB.A+12 ;COPY NEW CYLINDER ADDRESS
2593 011346          1$:
2594 011346 012737 011346 001110  MOV      #,$SLPERR        ;SETUP THE ERROR LOOP ADDRESS
2595 011354 012706 001100      MOV      #STACK,SP       ;LOAD THE STACK POINTER
2596 011360 004037 027054      JSR      RD,2#CALL.A      ;GO EXECUTE THE COMMAND
2597 011364 012737 011364 001110  MOV      #,$SLPER?        ;SETUP THE ERROR LOOP ADDRESS
2598 011372 012706 001100      MOV      #STACK,SP       ;LOAD THE STACK POINTER
2599 011376 113764 004206 000010  MOV      DPB.A,RMCS2(R4)  ;SELECT THE DRIVE
2600 011404 016446 000020      MOV      RMLA(R4),-(SP)  ;GET THE LOOK AHEAD REGISTER

```

```

2601 011410 006316 ASL (SP) ;ALIGN THE SECTOR ADDRESS
2602 011412 006316 ASL (SP) ;ALIGN THE SECTOR ADDRESS
2603 011414 000316 SWAB (SP) ;PUT ADDRESS IN LOWER BYTE
2604 011416 105766 000001 TSTB 1(SP) ;IN THE 1ST 20% OF SECTOR ?
2605 011422 001401 BEQ 2$ ;BR IF YES
2606 011424 105216 INCB (SP) ;INCREMENT THE SECTOR ADDRESS
2607 011426 105216 2$: INCB (SP) ;INCREMENT THE SECTOR ADDRESS
2608 011430 112637 004276 MOVB (SP)+,DTADPB+10 ;LOAD THE DPB
2609 011434 013746 001712 MOV PRMLM+22,-(SP) ;PUT LAST SECTOR ADDRESS ON THE STACK
2610 011440 005216 INC (SP) ;INCREMENT IT
2611 011442 122637 004276 CMPB (SP)+,DTADPB+10 ;NEW SECTOR ADDRESS TOO LARGE ?
2612 011446 103007 BHS 4$ ;BR IF NOT
2613 011450 103403 BLO 3$ ;BR IF ADDRESS IS 2 GREATER
2614 011452 105037 004276 CLRB DTADPB+10 ;RESET TO SECTOR ADDRESS 0
2615 011456 000403 BR 4$ ;CONTINUE
2616 011460 112737 000001 004276 3$: MOVB #1,DTADPB+10 ;RESET ADDRESS TO SECTOR 1
2617 011466 4$:
2618 011466 004037 027206 JSR RD, @CALL.B ;GO EXECUTE THE COMMAND
2619 011472 105237 004237 INCB DPB.B+11 ;INCREMENT THE TRACK ADDRESS
2620 011476 123737 004237 001602 CMPB DPB.B+11,LT ;MAXIMUM ?
2621 011504 101403 BLOS EXIT7 ;BR IF NOT
2622 011506 113737 001600 004237 MOVB FT,DPB.B+11 ;RELOAD STARTING TRACK ADDRESS
2623 011514 000004 EXIT7: SCOPE ;LOOP ?

```

```

;*****
;TEST 10 SERVO SETTLE DOWN TEST

```

```

; * THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT
; * THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE.
; * RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC'
; * ('NC1' STARTS AT VALUE 'FC'). AT THE COMPLETION OF 1000 (10) SEEKS,
; * 'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED.
; * THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.
; *
; * WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD
; * REGISTER (RMLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO
; * POSITION. THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND
; * FOR THAT SECTOR.
; * ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED
; * CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PACK WITH
; * MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.
; *
; * THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW
; * HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS. THE NECESSARY
; * TIME DEPENDENT PARAMETERS OCCUR FREQUENTLY ENOUGH WITHIN THE REQUIRED
; * RANGE TO PERMIT THIS TEST TO BE EFFECTIVE.

```

```

;*****
;ST10:

```

```

2650 011516 000240 NOP
2651 011516 033737 001526 001314 BIT @#BITS+<10*2>,TSTNMS ;DO THIS TEST?
2652 011520 001002 BNE 64$ ;YES--BRANCH
2653 011526 000137 JMP TST11 ;NO--GO TO THE NEXT TEST
2654 011530 000137 012666 001102 64$: JMP #10,@#STSTNM ;SET UP TEST NUMBER AND
2655 011534 012737 000010 MOV #10,@#STSTNM ;CLEAR THE ERROR FLAG (SERFLG)
2656

```

E07

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T10

MACY1: 30(1046) 22-NOV-77 08:04 PAGE 52
SERVO SETTLE DOWN TEST

SEQ 0082

```

2657 011542 004737 026632 JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
2658 011546 012737 011770 001110 MOV #TEST10,#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
2659 011554 013777 001102 167360 MOV $TSTNM,#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2660 011562 013737 001570 001204 MOV #RPT,#TIMES ;GET THE ITERATION COUNT
2661 011570 112737 000031 001115 MOV #25,#ERMAX ;MAX ERRORS ALLOWED FOR TEST
2662 011576 012737 000010 001224 MOV #10,#TESTN ;SET TEST NUMBER IN APT MAIL BOX
2663
2664 ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
2665 011604 032777 010000 167326 BIT #SW12,#SWR ;CHECK FOR SWITCH 12 SET
2666 011612 001413 BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
2667 011614 013700 001102 MOV $TSTNM,R0 ;ELSE, TYPE THE NUMBER
2668 011620 042700 177000 BIC #177000,R0 ;MASK OUT THE HIGH ORDER BYTE
2669 011624 104401 001215 TYPE $SCRLF
2670 011630 010046 MOV R0,-(SP) ;;SAVE R0 FOR TYPEOUT
2671 ;;TEST NUMBER
2672 011632 104403 TYPOS ;;GO TYPE--OCTAL ASCII
2673 011634 002 .BYTE 2 ;;TYPE 2 DIGIT(S)
2674 011635 000 .BYTE 0 ;;SUPPRESS LEADING ZEROS
2675 011636 104401 001215 TYPE ,SCRLF
2676 011642
2677
2678 011642 012737 011650 001106 MOV #1$,SLPADR ;SETUP THE LOOP ADDRESS
2679 011650
2680 011650 112737 000105 004210 1$: MOV #1$,SLPADR ;SEEK=COMMAND
2681 011656 112737 000161 004270 MOV #WRITE,#DTADPB+2 ;COMMAND
2682 011664 113737 001600 004277 MOV #FT,#DTADPB+11 ;TRACK ADDRESS FOR THE WRITE
2683 011672 013737 001572 004220 MOV #FC,#DPB.A+12 ;CYLINDER ADDRESS FOR THE SEEK
2684 011700 013737 001572 004300 MOV #FC,#DTADPB+12 ;CYLINDER ADDRESS FOR THE WRITE
2685 011706 013737 001572 001614 MOV #FC,#NC1 ;STARTING CYLINDER
2686 011714 013737 001576 001430 MOV #IC,#DELTA ;CYLINDER INCREMENT VALUE
2687 011722 012737 176000 004272 MOV #-(256*4),#DTADPB+4 ;WORD COUNT
2688 011730 012737 051776 004274 MOV #BUFFER,#DTADPB+6 ;BUFFER ADDRESS
2689 011736 005000 R0 ;PATTERN POINTER (WC PATTERN)
2690 011740 004737 032602 JSR PC,SETBUF ;LOAD THE WRITE BUFFER
2691 011744 005001 CLR R1 ;CLEAR REGISTER
2692 011746 113701 004206 MOV #DPB.A,R1 ;LOAD DRIVE ADDRESS
2693 011752 013704 036736 MOV #RMAUR,R4 ;UNIBUS ADDRESS OF THE RH70
2694 011756 004737 044616 JSR PC,CLAUQE ;CLEAR THE OPERATION QUEUES
2695 011762 012737 012664 001332 MOV #EXIT10,BYPASS ;ERROR EXIT FROM TEST
2696 011770
2697 011770 012737 011770 001110 TEST10: MOV #SLPERR ;SETUP THE ERROR LOOP ADDRESS
2698 011776 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
2699 012002 012737 000340 177776 MOV #PR7,#PS ;SET PRIORITY TO 7
2700 012010 005737 001324 TST CLKSTA ;SEE WHICH CLOCK ON SYSTEM
2701 012014 001415 BEQ 3$ ;BR IF NO CLOCK
2702 012016 100405 BMI 1$ ;BR IF KW11-L CLOCK
2703 012020 017746 167432 MOV #PKV,-(SP) ;SAVE THE VECTOR
2704 012024 013746 001456 MOV #PKV,-(SP) ;SAVE THE VECTOR ADDRESS
2705 012030 000404 BR 2$ ;CONTINUE
2706 012032 017746 167432 1$: MOV #LKV,-(SP) ;SAVE THE 'L' CLOCK VECTOR
2707 012036 013746 001470 MOV #LKV,-(SP) ;SAVE THE VECTOR ADDRESS
2708 012042 012776 012620 000000 2$: MOV #TST10B,#(SP) ;CHANGE THE VECTOR
2709 012050 012777 031274 024662 3$: MOV #DORTI,#RMVEC ;CHANGE THE RMO3 VECTOR
2710 012056 012737 000010 001424 MOV #B,#SEKTR ;LOAD THE SEEK TIMER
2711 012064 012764 000040 000010 MOV #BIT05,RMCS2(R4) ;INIT THE MASSBUS
2712 012072 110164 000010 MOV #R1,RMCS2(R4) ;RESELECT THE DRIVE

```

F07

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST
 CZRMFB.P11 21-NOV-77 14:10 T10

MACY11 30(1046) 22-NOV-77 08:04 PAGE 53
 SERVO SETTLE DOWN TEST

SEQ 0083

2713	012076	013764	004220	000034		MOV	DPB.A+12,RMDC(R4)	;LOAD THE CYLINDER ADDRESS
2714	012104	013737	004220	001350		MOV	DPB.A+12,CYL.D5	;CYLINDER ADDRESS FOR ERROR MESSAGE
2715	012112	112764	000105	000000		MOVB	#SEEK,RMCS1(R4)	;START THE SEEK
2716	012120	005037	177776			CLR	#PS	;CLEAR THE PRIORITY
2717	012124	105764	000012		4\$:	TSTB	RMDS(R4)	;HAS THE DRIVE FINISHED ?
2718	012130	100402				BMI	5\$;BR IF IT HAS
2719	012132	000001				WAIT		;WAIT FOR THE OPERATION TO COMPLETE
2720	012134	000773				BR	4\$;CONTINUE
2721	012136	012737	000340	177776	5\$:	MOV	#PR7,#PS	;CHANGE PRIORITY TO MAX
2722	012144	032764	040000	000012		BIT	#BIT14,RMDS(R4)	;ERROR ?
2723	012152	001412				BEQ	6\$;BR IF NOT
2724	012154	012702	004206			MOV	#DPB.A,R2	;DPB POINTER
2725	012160	004737	044134			JSR	PC,SVRA70	;SAVE THE REGISTERS
2726	012164	104023				ERROR	23	;ERROR DURING SEEK
2727	012166	012764	000040	000010		MOV	#BIT05,RMCS2(R4)	;INIT THE MASSBUS
2728	012174	110164	000010			MOVB	R1,RMCS2(R4)	;RESELECT THE DRIVE
2729	012200	012777	041566	024532	6\$:	MOV	#ISR,#RMVEC	;SETUP THE RMO3 VECTOR
2730	012206	005737	001324			TST	CLKSTA	;WHICH CLOCK
2731	012212	001405				BEQ	TST10A	;BR IF NONE
2732	012214	016676	000002	000000		MOV	2(SP),2(SP)	;RELOAD THE CLOCK VECTOR
2733	012222	062706	000004			ADD	#4,SP	;CORRECT THE STACK POINTER
2734	012226							
2735	012226	012737	012226	001110		MOV	#SLPERR	;SETUP THE ERROR LOOP ADDRESS
2736	012234	012706	001100			MOV	#STACK,SP	;LOAD THE STACK POINTER
2737	012240	110164	000010			MOVB	R1,RMCS2(R4)	;SELECT THE DRIVE
2738	012244	016446	000020			MOV	RMLA(R4),-(SP)	;GET THE LOOK AHEAD REGISTER
2739	012250	006316				ASL	(SP)	;ALIGN THE SECTOR ADDRESS
2740	012252	006316				ASL	(SP)	;ALIGN THE SECTOR ADDRESS
2741	012254	000316				SWAB	(SP)	;PUT ADDRESS IN LOWER BYTE
2742	012256	122766	000300	000001		CMPB	#300,1(SP)	;IN THE LAST 20% OF SECTOR ?
2743	012264	001001				BNE	2\$;BR IF NOT
2744	012266	105216				INCB	(SP)	;INCREMENT THE SECTOR ADDRESS
2745	012270	105216			2\$:	INCB	(SP)	;INCREMENT THE SECTOR ADDRESS
2746	012272	112637	004276			MOVB	(SP)+,DTADPB+10	;LOAD THE DPB
2747	012276	013746	001712			MOV	PRMLM↑+22,-(SP)	;PUT MAXIMUM SECTOR ADDRESS ON THE STACK
2748	012302	005216				INC	(SP)	;INCREMENT PAST THE MAXIMUM ADDRESS
2749	012304	122637	004276			CMPB	(SP)+,DTADPB+10	;NEW SECTOR ADDRESS TOO LARGE ?
2750	012310	101007				BHI	4\$;BR IF NOT
2751	012312	103403				BLO	3\$;BR IF ADDRESS IS 2 GREATER THAN MAXIMUM
2752	012314	105037	004276			CLRB	DTADPB+10	;RESET TO SECTOR ADDRESS 0
2753	012320	000403				BR	4\$;CONTINUE
2754	012322	112737	000001	004276	3\$:	MOVB	#1,DTADPB+10	;RESET ADDRESS TO SECTOR 1
2755	012330	012703	004272		4\$:	MOV	#DTADPB+4,R3	;POINTER
2756	012334	012764	000111	000000		MOV	#DRVCLR,RMCS1(R4)	;CLEAR THE DRIVE
2757	012342	012364	000002			MOV	(R3)+,RMWC(R4)	;LOAD THE WORD COUNT
2758	012346	012364	000004			MOV	(R3)+,RMBA(R4)	;LOAD THE BUFFER ADDRESS
2759	012352	012364	000006			MOV	(R3)+,RMDA(R4)	;LOAD THE TRACK/SECTOR ADDR
2760	012356	005037	004304			CLR	DTADPB+16	;RESET 'DONE' INDICATOR
2761	012362	012737	004266	036650		MOV	#DTADPB,TRNSWT	;LOAD 'TRANSFER' DPB ADDRESS
2762	012370	010137	036722			MOV	R1,DTUW	;ADDRESS OF DRIVE TRANSFERRING
2763	012374	112761	000001	036600		MOVB	#1,DRVACT(R1)	;SET DRIVE ACTIVE INDICATOR
2764	012402	006301				ASL	R1	;SHIFT DRIVE ADDRESS
2765	012404	012761	001750	036702		MOV	#1000.,TIMER(R1)	;SETUP THE OPERATION TIMER
2766	012412	006201				ASR	R1	;RESTORE R1
2767	012414	013764	004270	000000		MOV	DTADPB+2,RMCS1(R4)	;START THE OPERATION
2768	012422	005037	177776			CLR	#PS	;CLEAR THE PRIORITY

2769	012426	004037	027632			JSR	RO,DRVCL1	:WAIT FOR OPERATION TO COMPLETE
2770	012432	023727	001426	001750	5\$:	CMP	SEKCNT,#1000.	:FINISHED SEEKS ?
2771	012440	001026				BNE	6\$:BR IF NOT
2772	012442	005037	001426			CLR	SEKCNT	:CLEAR THE SEEK COUNT
2773	012446	063737	001576	001614		ADD	IC,NC1	:ADD THE INCREMENT
2774	012454	023737	001614	001574		CMP	NC1,LC	:EXCEEDED THE CYLINDER LIMIT ?
2775	012462	103100				BHIS	EXIT10	:BR IF IT HAS
2776	012464	013737	001574	001430		MOV	LC,DELTA	:GET THE NEXT 'ZONE' ADDRESS
2777	012472	163737	001614	001430		SUB	NC1,DELTA	:CHECK THE DIFFERENCE
2778	012500	023737	001576	001430		CMP	IC,DELTA	:DIFFERENCE GREATER THAN THE INCREMENT ?
2779	012506	101003				BHI	6\$:BR IF IT IS
2780	012510	013737	001576	001430		MOV	IC,DELTA	:USE THE ICREMENT PARAMETER
2781	012516	005237	001426		6\$:	INC	SEKCNT	:COUNT THE NEXT SEEK
2782	012522	023737	001572	001574		CMP	FC,LC	:BEGINNING AND ENDING CYLINDERS THE SAME ?
2783	012530	001002				BNE	7\$:BR IF NOT
2784	012532	000137	011770			JMP	TEST10	:BR IF THEY ARE
2785	012536	013737	001614	004220	7\$:	MOV	NC1,DPB.A+12	:RESET THE CYLINDER ADDRESS
2786	012544	004737	025532			JSR	PC,\$RAND	:CYCLE THE RANDOM NUMBER GENERATOR
2787	012550	013746	025630			MOV	\$HINUM,-(SP)	:USE THE HIGH RANDOM NUMBER
2788	012554	005046				CLR	-(SP)	:CLEAR THE UPPER DIVIDEND
2789	012556	013746	001430			MOV	DELTA,-(SP)	:FORM THE DIVISOR
2790	012562	005216				INC	(SP)	:INCREMENT
2791	012564	004737	025634			JSR	PC,\$DIV	:DIVIDE
2792	012570	062637	004220			ADD	(SP)+,DPB.A+12	:ADD THE REMAINDER TO THE INITIAL CYLINDER
2793	012574	005726				TST	(SP)+	:DISCARD THE QUOTIENT
2794	012576	023737	004220	004300		CMP	DPB.A+12,DTADPB+12	:SAME CYLINDER SELECTED AS LAST TIME ?
2795	012604	001754				BEQ	7\$:BR IF IT WAS
2796	012606	013737	004220	004300		MOV	DPB.A+12,DTADPB+12	:COPY NEW CYLINDER ADDRESS
2797	012614	000137	011770			JMP	TEST10	:CONTINUE
2798	012620	005337	001424		TST10B:	DEC	SEKTMR	:DECREMENT THE SEEK TIMER
2799	012624	001016				BNE	1\$:CONTINUE IF NOT DONE
2800	012626	012702	004206			MOV	#DPB.A,R2	:DPB ADDRESS
2801	012632	004737	044134			JSR	PC,SVRA70	:SAVE THE REGISTERS
2802	012636	104024				ERROR	24	:TIMEOUT DURING SEEK
2803	012640	012764	000040	000010		MOV	#BIT05,RMC52(R4)	:INIT THE MASSBUS
2804	012646	110164	000010			MOVB	R1,RMC52(R4)	:RESELECT THE DRIVE
2805	012652	016676	000002	000000		MOV	2(SP),2(SP)	:RESTORE THE CLOCK VECTOR ADDRESS
2806	012660	000401				BR	EXIT10	:ABORT THE TEST
2807	012662	000002			1\$:	RTI		:RETURN
2808	012664	000004			EXIT10:	SCOPE		:LOOP ?
2809								
2810								
2811								
2812								
2813								
2814								
2815								
2816								
2817								
2818								
2819								
2820								
2821								
2822								
2823	012666							
2824	012666	000240						

:TEST 11 ALL SEEKS TEST

: THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER
: TO ALL OTHER CYLINDERS.
: *****
: BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER
: BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC'. THE BEGINNING CYLINDER
: ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER
: ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC'. THE SEQUENCE
: CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED.
: *****
:ST11:
NOP

```

2825 012670 033737 001530 001314 BIT 2#BITS+(11*2),TSTNMS ;DO THIS TEST?
2826 012676 001002 BNE 64$ ;YES--BRANCH
2827 012700 000137 013152 JMP TST12 ;NO--GO TO THE NEXT TEST
2828 012704 012737 000011 001102 64$: MOV #11,2#STSTNM ;SET UP TEST NUMBER AND
2829 ;CLEAR THE ERROR FLAG ($ERFLG)
2830 012712 004737 026632 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
2831 012716 012737 013072 001110 MOV #TST11,2#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
2832 012724 013777 001102 166210 MOV $TSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
2833 012732 013737 001570 001204 MOV 2#APT,$TIMES ;GET THE ITERATION COUNT
2834 012740 112737 000031 001115 MOVG #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
2835 012746 012737 000011 001224 MOV #11,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
2836
2837 ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
2838 012754 032777 010000 166156 BIT #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
2839 012762 001413 BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
2840 012764 013700 001102 MOV $TSTNM,RO ;ELSE, TYPE THE NUMBER
2841 012770 042700 177000 BIC #177000,RO ;MASK OUT THE HIGH ORDER BYTE
2842 012774 104401 001215 TYPE $CRLF
2843 013000 010046 MOV RO,-(SP) ;SAVE RO FOR TYPEOUT
2844 ;TEST NUMBER
2845 013002 104403 TYPOS ;GO TYPE--OCTAL ASCII
2846 013004 002 .BYTE 2 ;TYPE 2 DIGIT(S)
2847 013005 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
2848 013006 104401 001215 TYPE , $CRLF
2849 013012 20$:
2850
2851 013012 012737 013020 001106 MOV #15,$LPADR ;SETUP THE LOOP ADDRESS
2852 013020 113737 001606 004236 1$: MOVB FS,DPB.B+10 ;SECTOR ADDRESS
2853 013026 113737 001606 004256 MOVB FS,DPB.C+10 ;SECTOR ADDRESS
2854 013034 113737 001600 004237 MOVB FT,DPB.B+11 ;TRACK ADDRESS
2855 013042 113737 001600 004257 MOVB FT,DPB.C+11 ;TRACK ADDRESS
2856 013050 013737 001572 004240 MOV FC,DPB.B+12 ;STARTING CYLINDER ADDRESS
2857 013056 013737 001572 004260 MOV FC,DPB.C+12 ;STARTING CYLINDER ADDRESS
2858 013064 012737 013150 001332 MOV #EXIT11,BYPASS ;TEST ABORT EXIT
2859 013072 012706 001100 TEST11: MOV #STACK,$P ;SETUP THE STACK POINTER
2860 013076 1$:
2861 013076 004037 027410 JSR RO,2#CALL.C ;GO EXECUTE THE COMMAND
2862 013102 004037 027206 JSR RO,2#CALL.B ;GO EXECUTE THE COMMAND
2863 013106 063737 001576 004260 ADD IC,DPB.C+12 ;INCREMENT THE ENDING CYLINDER ADDRESS
2864 013114 023737 001574 004260 CMP LC,DPB.C+12 ;CHECK IF EXCEEDING MAXIMUM
2865 013122 002365 BGE 1$ ;BR IF NOT
2866 013124 013737 001572 004260 MOV FC,DPB.C+12 ;RESET ENDING CYLINDER ADDRESS
2867 013132 063737 001576 004240 ADD IC,DPB.B+12 ;INCREMENT THE STARTING ADDRESS
2868 013140 023737 001574 004240 CMP LC,DPB.B+12 ;EXCEEDING MAXIMUM
2869 013146 002353 BGE 1$ ;BR IF NOT
2870 013150 000004 EXIT11: SCOPE ;LOOP ?
2871

```


J07

MD-11-DZRMF-B RMO3 RMO2 EXTENDED DRIVE TEST
 ZRMFB.P11 21-NOV-77 14:10 T12

MACY11 30(1046) 22-NOV-77 08:04 PAGE 57
 ROTATIONAL SPEED TIMING TEST

SEQ 0087

2928	013263	000					.BYTE 0	;;SUPPRESS LEADING ZEROS
2929	013264	104401	001215				TYPE ,SCLF	
2930	013270			20\$:				
2931								
2932	013270	005737	001324				TST @CLKSTA	:KW11-P CLOCK?
2933	013274	003002					BGT 1\$:YES--START TEST
2934	013276	000137	014042				JMP TST13	:NO--GO TO NEXT TEST
2935	013302	012737	013302	001106	1\$:		MOV #1\$, \$LPADR	:SETUP LOOP ADDRESS
2936	013310	004037	031112				JSR R0, @SRCH00	:DO A MASSBUS INIT & RECAL
2937	013314	000402					BR 2\$:RETURN HERE IF NO ERROR
2938	013316	000137	014040				JMP EXIT12	:RETURN HERE IF ERROR
2939	013322	013764	001572	000034	2\$:		MOV @FC, RMOA(R4)	:FC
2940	013330	013746	001606				MOV @FS, -(SP)	:FS
2941	013334	113766	001600	000001			MOVB @FT, 1(SP)	:FT
2942	013342	012664	000006				MOV (SP)+, RMOA(R4)	:LOAD FT/FS
2943	013346	012737	014040	001206			MOV @EXIT12, \$ESCAPE	:ESCAPE TO EXIT12 ON ERROR
2944	013354	005005					CLR R5	:COUNT UP
2945							MOV #T7A, R3	:60HZ PARAMETERS
2946							BIT #SW06, @C.SWR	:60 HZ?
2947							BEQ TEST12	:YES--BRANCH
2948							MOV #T7B, R3	:NO--50 HZ PARAMETERS
2949								:SETUP PRAMETER TABLE FOR RMO2/RMO3
2950	013356	010046					MOV R0, -(SP)	:SAVE R0
2951	013360	113700	004266				MOVB DTADPB, R0	:DRIVE ADDRESS
2952	013364	032737	000100	001300			BIT #SW06, @C.SWR	:60 HZ ?
2953	013372	001417					BEQ 3\$:BRANCH IF 50
2954	013374	012703	003066				MOV #T7B, R3	:50 HZ TABLE FOR RMO3
2955	013400	012737	003066	014036			MOV #T7B, TP50	:50 HZ TABLE FOR RMO3
2956	013406	122760	000004	036620			CMPB #4, DRVTYP(R0)	:A RMO3 DRIVE ?
2957	013414	001424					BEQ 4\$:BRANCH IF 50
2958	013416	012703	003106				MOV #T7B1, R3	:OTHERWISE LOAD THE TABLE FOR RMO2
2959	013422	012737	003106	014036			MOV #T7B1, TP50	
2960	013430	000416					BR 4\$:EXIT
2961	013432	012737	003056	014026	3\$:		MOV #T7A, TP60	:60 HZ TABLE FOR RMO3
2962	013440	012703	003056				MOV #T7A, R3	:60 HZ TABLE FOR RMO3
2963	013444	122760	000004	036620			CMPB #4, DRVTYP(R0)	:A RMO3 DRIVE ?
2964	013452	001405					BEQ 4\$:BRANCH IF 50
2965	013454	012737	003076	014026			MOV #T7A1, TP60	:OTHERWISE LOAD THE TABLE FOR RMO2
2966	013462	012703	003076				MOV #T7A1, R3	
2967	013466	012600			4\$:		MOV (SP)+, R0	:RESTORE R0
2968	013470	000240					NOP	:EXIT
2969	013472	012706	001100				TEST12: MOV #STACK, SP	:SETUP STACK
2970	013476	012701	000012				MOV #10, R1	:TIME 10 SEARCHES
2971	013502	004737	031276				JSR PC, @STRMTR	:INITIALIZE THE TIMERS
2972	013506	012777	013714	165742			MOV #7\$, @PKV	:SETUP VECTOR IN CASE OF OVERFLOW
2973	013514	012777	031274	023216			MOV #DOATI, @RMVEC	:SETUP RMO3 VECTOR
2974	013522	005077	165736		1\$:		CLR @PKB	:START COUNTING AT ZERO
2975	013526	012777	000131	165726			MOV #131, @PKCS	:INT.EN., COUNT UP AT 100KHZ
2976	013534	012714	000131				MOV #SEARCH, (R4)	:START A SEARCH
2977	013540	000001					WAIT	:WAIT ON INTERRUPT
2978	013542	042777	000101	165712			BIT #101, @PKCS	:STOP THE CLOCK
2979	013550	032764	040000	000012			BIT #BIT14, RMOA(R4)	:ERROR?
2980	013556	001415					BEQ 2\$:NO--BRANCH
2981	013560	104412					SAVREG	:SAVE R0-R5
2982	013562	012702	004266				MOV #DTADPB, R2	:DPB POINTER
2983	013566	004737	044134				JSR PC, @SVRH70	:SAVE ALL THE RH70/RMO3 REGISTERS

K07

MD-11-DZRMF-B RMO3.RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T12

MACY11 30(1046) 22-NOV-77 08:04 PAGE 58
ROTATIONAL SPEED TIMING TEST

SEG 0088

2984	013572	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	: MASSBUS CLEAR
2985	013600	013764	004266	000010	MOV	@DTADPB, RMCS2(R4)	: SELECT DRIVE
2986	013606	104413			RESREG		: RESTORE RO-R5
2987	013610	104017			ERROR	17	
2988	013612	005077	165646		CLR	@PKB	: START THE COUNT AT ZERO
2989	013616	012714	000131		MOV	#SEARCH, (R4)	: START A SEARCH
2990	013622	012777	000131	165632	MOV	#131, @PKCS	: START THE CLOCK
2991	013630	000001			WAIT		: WAIT ON INTERRUPT
2992	013632	042777	000101	165622	BIC	#101, @PKCS	: STOP THE CLOCK
2993	013640	032764	040000	000012	BIT	#BIT14, RMCS2(R4)	: IS "ERR=1"?
2994	013646	001415			BEQ	3\$: NO--BRANCH
2995	013650	104412			SAVREG		: SAVE RO-R5
2996	013652	012702	004266		MOV	@DTADPB, R2	: DPB POINTER
2997	013656	004737	044134		JSR	PC, @SVRH70	: SAVE ALL THE RH70/RMO3 REGISTERS
2998	013662	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	: MASSBUS CLEAR
2999	013670	013764	004266	000010	MOV	@DTADPB, RMCS2(R4)	: SELECT DRIVE
3000	013676	104413			RESREG		: RESTORE RO-R5
3001	013700	104017			ERROR	17	: DISK ERROR OCCURRED
3002	013702	004737	031342		JSR	PC, @COUNT	: UPDATE THE COUNT
3003	013706	005301			DEC	R1	: DONE?
3004	013710	003304			BGT	1\$: NO--BRANCH
3005	013712	000424			BR	8\$: YES--GO TO THE EXIT
3006	013714	042777	000101	165540	BIC	#101, @PKCS	: STOP THE CLOCK
3007	013722	005037	177776		CLR	@#PS	: DROP THE PRIORITY
3008	013726	012600			MOV	(SP)+, RO	: PC OF WAIT+2
3009	013730	005726			TST	(SP)+	: POP THE PS FROM THE STACK
3010	013732	104412			SAVREG		: SAVE RO-R5
3011	013734	012702	004266		MOV	@DTADPB, R2	: DPB POINTER
3012	013740	004737	044134		JSR	PC, @SVRH70	: SAVE ALL THE RH70/RMO3 REGISTERS
3013	013744	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	: MASSBUS CLEAR
3014	013752	013764	004266	000010	MOV	@DTADPB, RMCS2(R4)	: SELECT DRIVE
3015	013760	104413			RESREG		: RESTORE RO-R5
3016	013762	104020			ERROR	20	: CLOCK OVERFLOWED
3017	013764						
3018	013764	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	: MASSBUS INIT.
3019	013772	013764	004266	000010	MOV	@DTADPB, RMCS2(R4)	: SELECT DRIVE
3020	014000	004737	026116		JSR	PC, @ST.CLK	: INITIALIZE THE CLOCK
3021	014004	012777	041566	022726	MOV	#ISR, @RMVEC	: RESTORE RH70/RMO3 INT. VECTOR
3022	014012	032737	000100	001300	BIT	#SW06, @#C.SWR	: 60 HZ?
3023					BNE	9\$: NO -- BRANCH
3024					REPORT	T7A	: REPORT THE TIMES
3025					BR	EXIT12	: GO TO EXIT
3026							
3027	014020	001004			REPORT	T7B	
3028	014022	004037	031474		BNE	EXIT.A	: NO-BRANCH
3029	014026	003056			JSR	RO, @#TYPTIM	: TYPE THE TIMING
3030	014030	000403			T7A		: TABLE ADDRESS
3031	014032	004037	031474		BR	EXIT12	: EXIT
3032	014036	003066			EXIT.A: JSR	RO, @#TYPTIM	: TYPE THE TIMING
3033	014040	000004			TP50: T7B		: TABLE ADDRESS
3034					EXIT12: SCOPE		: LOOP ?
3035							
3036							
3037							
3038							
3039							

: *TEST 13 ONE CYLINDER SEEK TIMING TEST
: * THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE

```

3040      ;*      CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE
3041      ;*      CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC'. THE
3042      ;*      TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT
3043      ;*      EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK.
3044      ;*      THE TIME MUST BE LESS THAN 10MS.
3045
3046      ;*****
3047      †TST13:
3048      014042      000240      NOP
3049      014044      033737      001534      001314      BIT      @#BITS+(13*2),TSTNMS ;DO THIS TEST?
3050      014052      001002      BNE      64$              ;YES--BRANCH
3051      014054      000137      014552      JMP      TST14          ;NO--GO TO THE NEXT TEST
3052      014060      012737      000013      001102      64$:      MOV      #13,@#TSTNM    ;SET UP TEST NUMBER AND
3053      ;CLEAR THE ERROR FLAG ($ERFLG)
3054      014066      004737      026632      JSR      PC,LODPRM     ;LOAD THE PARAMETERS FOR THE TEST
3055      014072      012737      014042      001110      MOV      #TST13,@#SLPERR ;SETUP THE ERROR LOOP ADDRESS
3056      014100      013777      001102      165034      MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3057      014106      013737      001570      001204      MOV      @RPT,$TIMES    ;GET THE ITERATION COUNT
3058      014114      1.2737      000031      001115      MOVB    #25,$ERMAX     ;MAX ERRORS ALLOWED FOR TEST
3059      014122      012737      000013      001224      MOV      #13,$TESTN    ;SET TEST NUMBER IN APT MAIL BOX
3060
3061      ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
3062      014130      032777      010000      165002      BIT      #SW12,@SWR    ;CHECK FOR SWITCH 12 SET
3063      014136      001413      BEQ      20$              ;IF = 0, THEN DON'T TYPE TEST NUMBER
3064      014140      013700      001102      MOV      $TSTNM,R0     ;ELSE, TYPE THE NUMBER
3065      014144      042700      177000      BIC      #177000,R0    ;MASK OUT THE HIGH ORDER BYTE
3066      014150      104401      001215      TYPE    $CRLF
3067      014154      010046      MOV      R0,-(SP)      ;SAVE R0 FOR TYPEOUT
3068      ;TEST NUMBER
3069      014156      104403      TYPOS    ;GO TYPE--OCTAL ASCII
3070      014160      .002      .BYTE    2            ;TYPE 2 DIGIT(S)
3071      014161      .000      .BYTE    0            ;SUPPRESS LEADING ZEROS
3072      014162      104401      001215      TYPE    , $CRLF
3073      014166      20$:
3074
3075      014166      005737      001324      TST      @#CLKSTA      ;KW11-P CLOCK?
3076      014172      003002      BGT      1$              ;YES--START TEST
3077      014174      000137      014552      JMP      TST14          ;NO--GO TO NEXT TEST
3078      014200      012737      014200      001106      1$:      MOV      #1$, $LPADR    ;SETUP THE LOOP ADDRESS
3079      014206      004037      031112      JSR      R0,@#SRCH00   ;DO A MASSBUS INIT. AND RECAL
3080      014212      000402      BR       2$              ;NO ERROR RETURN
3081      014214      000137      014550      JMP      EXIT13        ;ERROR RETURN--SCOPE LOOP CALL
3082      014220      012703      003116      2$:      MOV      #T10,R3       ;PARAMETER POINTER
3083      014224      012737      014550      001206      MOV      #EXIT13,$ESCAPE ;ESCAPE TO EXIT13 ON ERROR
3084      014232      012706      001100      TEST13: MOV      #STACK,$P     ;SETUP STACK
3085      014236      013737      001572      004300      MOV      FC,@#DTADPB+12 ;START WITH BEGINNING CYLINDER
3086      014244      005237      004300      INC      DTADPB+12     ;INCREMENT THE BEGINNING CYLINDER
3087      014250      005005      CLR      RS            ;SET THE UP/DOWN SWITCH TO UP
3088      014252      004737      031276      JSR      PC,@#STRMTR   ;INITIALIZE THE TIMERS
3089      014256      012777      014444      165172      MOV      #7$,@PKV     ;SETUP INCASE OF OVERFLOW
3090      014264      012777      031274      022446      MOV      #DORTI,@RMVEC ;SET RM03 VECTOR
3091      014272      005077      165166      1$:      CLR      @PKB         ;START THE COUNTER AT ZERO
3092      014276      013764      004300      000034      MOV      @#DTADPB+12,RMDC(R4) ;LOAD DESIRED CYLINDER
3093      014304      012714      000105      MOV      #SEEK,(R4)    ;START A SEEK
3094      014310      012777      000131      165144      MOV      #131,@PKCS   ;START THE CLOCK
3095      014316      000001      WAIT

```

M07

MD-11-DZRMF-B RM03/RM02 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T13

MACY11 30(1046) 22-NOV-77 08:04 PAGE 60
ONE CYLINDER SEEK TIMING TEST

SEG 0090

3096	014320	042777	000101	165134		BIC	#101,APKCS	:STOP THE CLOCK
3097	014326	032764	040000	000012		BIT	#BIT14,RMDS(R4)	:ANY DISK ERRORS?
3098	014334	001415				BEG	25	:NO--BRANCH
3099	014336	104412				SAVREG		:SAVE R0-R5
3100	014340	012702	004266			MOV	#DTADPB,R2	:DPB POINTER
3101	014344	004737	044134			JSR	PC,#SVRH70	:SAVE ALL THE RH70/RM03 REGISTERS
3102	014350	012764	000040	000010		MOV	#BIT05,RMCS2(R4)	:MASSBUS CLEAR
3103	014356	013764	004266	000010		MOV	#DTADPB,RMCS2(R4)	:SELECT DRIVE
3104	014364	104413				RESREG		:RESTORE R0-R5
3105	014366	104017				ERROR	17	:REPORT THE ERROR
3106	014370	004737	031342		25:	JSR	PC,#COUNT	:COUNT THIS SEEKS TIME
3107	014374	004737	030570			JSR	PC,#TWOMS	:STALL FOR 2 MILLISECONDS
3108	014400	005705				TST	R5	:UP OR DOWN?
3109	014402	001011				BNE	45	:DOWN--BRANCH
3110	014404	005237	004300		35:	INC	#DTADPB+12	:MOVE TO NEXT CYLINDER
3111	014410	023737	004300	001574		CMP	#DTADPB+12,LC	:OUT OF CYLINDERS?
3112	014416	002725				BLT	15	:NO--GO DO THE NEXT SEEK
3113	014420	012705	177777			MOV	#-1,R5	:SET UP/DOWN SWITCH TO DOWN
3114	014424	000722				BR	15	:GO DO THE NEXT SEEK
3115	014426	005337	004300		45:	DEC	#DTADPB+12	:MOVE TO NEXT CYLINDER
3116	014432	023727	004300	000000		CMP	#DTADPB+12,#0	:OUT OF CYLINDERS?
3117	014440	003314				BGT	15	:NO--GO DO THE NEXT SEEK
3118	014442	000424				BR	85	:GO TO THE EXIT
3119	014444	042777	000101	165010	75:	BIC	#101,APKCS	:STOP THE CLOCK
3120	014452	005037	177776			CLR	#PS	:DROP THE PRIORITY
3121	014456	012600				MOV	(SP)+,R0	:PC OF WAIT+2
3122	014460	005726				TST	(SP)+	:POP THE PS FROM THE STACK
3123	014462	104412				SAVREG		:SAVE R0-R5
3124	014464	012702	004266			MOV	#DTADPB,R2	:DPB POINTER
3125	014470	004737	044134			JSR	PC,#SVRH70	:SAVE ALL THE RH70/RM03 REGISTERS
3126	014474	012764	000040	000010		MOV	#BIT05,RMCS2(R4)	:MASSBUS CLEAR
3127	014502	013764	004266	000010		MOV	#DTADPB,RMCS2(R4)	:SELECT DRIVE
3128	014510	104413				RESREG		:RESTORE R0-R5
3129	014512	104020				ERROR	20	:REPORT CLOCK OVERFLOW
3130	014514				85:			
3131	014514	012764	000040	000010		MOV	#BIT05,RMCS2(R4)	:MASSBUS INIT.
3132	014522	013764	004266	000010		MOV	#DTADPB,RMCS2(R4)	:SELECT DRIVE
3133	014530	004737	026116			JSR	PC,#ST.CLK	:INITIALIZE THE CLOCK
3134	014534	012777	041566	022176		MOV	#ISR,ARMVEC	:RESTORE RH70/RM03 INT. VECTOR
3135	014542	004037	031474			JSR	R0,#TYPTIM	:GO TYPE THE TIMES
3136	014546	003116				TIO		:POINTER
3137	014550	000004				EXIT13:	SCOPE	:LOOP ?

:TEST 14 ACCESS TIME MEASUREMENT TEST

:* THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO
:* CYLINDER 'LC', THEN A REVERSEK FROM CYLINDER 'LC' TO
:* CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY
:* ARE WITHIN THE TOLERANCE ALLOWED FOR THE ACCESS TIME MEASUREMENT.
:* THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL
:* OF 256 SEEKS). THE AVERAGE ACCESS TIME MUST BE LESS THAN 30 MS.
:* CYLINDER 'LC' DEFAULTS TO 136 (10) FOR AN RM03/5 OR TO 255 (10)
:* FOR AN RM03.

3138
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149
3150
3151

NO7

MO-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T14

MACY11 30(1046) 22-NOV-77 08:04 PAGE 61
ACCESS TIME MEASUREMENT TEST

SEQ 0091

```

3152
3153 014552
3154 014552 000240
3155 014554 033737 001536 001314
3156 014562 001002
3157 014564 000137 015334
3158 014570 012737 000014 001102 64$:
3159
3160 014576 004737 026632
3161 014602 012737 014552 001110
3162 014610 013777 001102 164324
3163 014616 013737 001570 001204
3164 014624 112737 000031 001115
3165 014632 012737 000014 001224
3166
3167
3168 014640 032777 010000 164272
3169 014646 001413
3170 014650 013700 001102
3171 014654 042700 177000
3172 014660 104401 001215
3173 014664 010046
3174
3175 014666 104403
3176 014670 002
3177 014671 000
3178 014672 104401 001215
3179 014676
3180
3181 014676 005737 001324
3182 014702 003002
3183 014704 000137 015334
3184 014710 012737 014710 001106 1$:
3185 014716 004037 031112
3186 014722 000402
3187 014724 000137 015332
3188 014730 012703 003126 2$:
3189 014734 012737 015332 001206
3190 014742 012706 001100 TEST14:
3191 014746 012701 000200
3192 014752 004737 031276
3193 014756 012777 015226 164472
3194 014764 012777 031274 021746
3195 014772 005077 164466 1$:
3196 014776 013764 001574 000034
3197 015004 012764 000105 000000
3198 015012 012777 000131 164442
3199 015020 000001
3200 015022 042777 000101 164432
3201 015030 032764 040000 000012
3202 015036 001415
3203 015040 104412
3204 015042 012702 004266
3205 015046 004737 044134
3206 015052 012764 000040 000010
3207 015060 013764 004266 000010

```

```

*****
TST14:
NOP
BIT 2#BITS+(14*2),TSTNMS ;DO THIS TEST?
BNE 64$ ;YES--BRANCH
JMP TST15 ;NO--GO TO THE NEXT TEST
MOV #14,2#STSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG ($ERFLG)
JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
MOV #TST14,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
MOV $STSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV 2#RPT,$TIMES ;GET THE ITERATION COUNT
MOVB #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
MOV #14,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
BIT #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
MOV $STSTNM,R0 ;ELSE, TYPE THE NUMBER
BIC #177000,R0 ;MASK OUT THE HIGH ORDER BYTE
TYPE $CRLF
MOV R0,-(SP) ;;SAVE R0 FOR TYPEOUT
; ;TEST NUMBER
; ;GO TYPE--OCTAL ASCII
; ;TYPE 2 DIGIT(S)
; ;SUPPRESS LEADING ZEROS
20$:
TYPE ,CRLF

TST 2#CLKSTA ;KW11-P CLOCK?
BGT 1$ ;YES--START TEST
JMP TST15 ;NO--GO TO NEXT TEST
MOV #1$,2#SLPADR ;SET THE LOOP ADDRESS
JSR R0,2#SRCH00 ;DO A MASSBUS INIT & RECAL
BR 2$ ;RETURN HERE IF NO ERROR
JMP EXIT14 ;RETURN HERE ON ERROR
MOV #T11,R3 ;PARAMETER POINTER
MOV #EXIT14,$ESCAPE ;ESCAPE TO EXIT14 ON ERROR
TEST14: MOV #STACK,$P ;SETUP STACK
MOV #128,R1 ;REPEAT "0-136-0" 128 TIMES
JSR PC,2#STATMR ;INIT. THE COUNTERS
MOV #7$,2#PKV ;SET UP VECTOR IN CASE OF OVERFLOW
MOV #DORTI,2#RMVEC ;SETUP RMO3 VECTOR
CLR 2#PKB ;START COUNT AT ZERO
MOV LC,RMDC(R4) ;'MIDDLE' CYLINDER
MOV #SEEK,RMCS1(R4) ;START A SEEK
MOV #131,2#PKCS ;START THE CLOCK
WAIT ;WAIT ON INTERRUPT
BIC #101,2#PKCS ;STOP CLOCK
BIT #BIT14,RMDS(R4) ;ERR=1?
BEQ 2$ ;NO--BRANCH
SAVREG ;SAVE R0-R5
MOV #DTADPB,R2 ;DPB POINTER
JSR PC,2#SVRH70 ;SAVE ALL THE RH70/RMO3 REGISTERS
MOV #BIT05,RMCS2(R4) ;MASSBUS CLEAR
MOV #DTADPB,RMCS2(R4) ;SELECT DRIVE

```

```

3208 015066 104413 RESREG :RESTORE R0-R5
3209 015070 104017 ERROR 17
3210 015072 005005 25: CLR R5 ;SET UP/DOWN SWITCH TO UP
3211 015074 004737 031342 JSR PC,@#COUNT ;UPDATE THE COUNT
3212 015100 004737 030670 JSR PC,@#TWOMS ;STALL FOR 2 MILLISECONDS
3213 015104 005077 164354 CLR @PKB ;START THE COUNT AT ZERO
3214 015110 013764 001572 000034 MOV FC,RMOC(R4) ;BEGINNING CYLINDER
3215 015116 012764 000105 000000 MOV #SEEK,RMCS1(R4) ;START A SEEK
3216 015124 012777 000131 164330 MOV #131,@PKCS ;START THE CLOCK
3217 015132 000001 WAIT ;WAIT ON INTERRUPT
3218 015134 042777 000101 164320 BIC #101,@PKCS ;STOP THE CLOCK
3219 015142 032764 040000 000012 BIT #BIT14,RMDS(R4) ;ERR=1?
3220 015150 001415 BEQ 35 ;NO--BRANCH
3221 015152 104412 SAVREG ;SAVE R0-R5
3222 015154 012702 004266 MOV #DTADPB,R2 ;DPB POINTER
3223 015160 004737 044134 JSR PC,@#SVRH70 ;SAVE ALL THE RH70/PM03 REGISTERS
3224 015164 012764 000040 000010 MOV #BIT05,RMCS2(R4) ;MASSBUS CLEAR
3225 015172 013764 004266 000010 MOV @DTADPB,RMCS2(R4) ;SELECT DRIVE
3226 015200 104413 RESREG :RESTORE R0-R5
3227 015202 104017 ERROR 17
3228 015204 012705 177777 35: MOV #-1,R5 ;SET UP/DOWN SWITCH TO DOWN
3229 015210 004737 031342 JSR PC,@#COUNT ;UPDATE THE COUNT
3230 015214 004737 030670 JSR PC,@#TWOMS ;STALL FOR 2 MILLISECONDS
3231 015220 005301 DEC R1 ;DONE?
3232 015222 003263 BGT 15 ;NO--BRANCH
3233 015224 000424 BR 85 ;YES--EXIT
3234 015226 042777 000101 164226 75: BIC #101,@PKCS ;STOP THE CLOCK
3235 015234 005037 177776 CLR @PS ;DROP THE PRIORITY
3236 015240 012600 MOV (SP)+,R0 ;PC OF WAIT+2
3237 015242 005726 TST (SP)+ ;POP THE PS FROM THE STACK
3238 015244 104412 SAVREG ;SAVE R0-R5
3239 015246 012702 004266 MOV #DTADPB,R2 ;DPB POINTER
3240 015252 004737 044134 JSR PC,@#SVRH70 ;SAVE ALL THE RH70/RM03 REGISTERS
3241 015256 012764 000040 000010 MOV #BIT05,RMCS2(R4) ;MASSBUS CLEAR
3242 015264 013764 004266 000010 MOV @DTADPB,RMCS2(R4) ;SELECT DRIVE
3243 015272 104413 RESREG :RESTORE R0-R5
3244 015274 104020 ERROR 20 ;CLOCK OVERFLOWED
3245 015276 85:
3246 015276 012764 000040 000010 MOV #BIT05,RMCS2(R4) ;MASSBUS INIT.
3247 015304 013764 004266 000010 MOV @DTADPB,RMCS2(R4) ;SELECT DRIVE
3248 015312 004737 026116 JSR PC,@#ST.CLK ;INITIALIZE THE CLOCK
3249 015316 012777 041566 021414 MOV #ISR,@RMVEC ;RESTORE RH70/RM03 INT. VECTOR
3250 015324 004037 031474 JSR R0,@#TYPTIM ;GO TYPE THE TIMES
3251 015330 003126 T11 ;POINTER
3252 015332 000004 EXIT14: SCOPE ;LOOP ?
3253
3254 ;*****
3255 ;*TEST 15 MAXIMUM SEEK TIMING TEST
3256
3257 ;*
3258 ;* THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO
3259 ;* CYLINDER 'LC' THEN A REVERSE SEEK FROM CYLINDER 'LC' TO
3260 ;* CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE
3261 ;* THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE MAXIMUM SEEK
3262 ;* TIME. THIS SEQUENCE IS REPEATED 128 TIMES (FOR
3263 ;* A TOTAL OF 256 SEEKS). THE MAXIMUM SEEK TIME MUST BE LESS THAN
;* 54 MS. 'LC' DEFAULTS TO 410 (10) FOR RM03'S'S AND TO 814 (10)

```

C08

MO-11-DZRMF-B RMO3 RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10 T15

MACY11 30(1046) 22-NOV-77 08:04 PAGE 63
MAXIMUM SEEK TIMING TEST

SEG 0093

```

3264 ;* FOR RMO3'S.
3265
3266 ;*****
3267 TST15:
3268 015334 000240 NOP
3269 015334 033737 001540 001314 BIT 2#BITS+<15*2>,TSTNM3 ;DO THIS TEST?
3270 015344 001002 BNE 64$ ;YES--BRANCH
3271 015346 000137 016116 JMP TST16 ;NO--GO TO THE NEXT TEST
3272 015352 012737 000015 001102 64$: MOV #15,2#STSTNM ;SET UP TEST NUMBER AND
3273 ;CLEAR THE ERROR FLAG ($ERFLG)
3274 015360 004737 026632 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
3275 015364 012737 015334 001110 MOV #TST15,2#SLPERR ;SETUP THE ERROR LOOP ADDRESS
3276 015372 013777 001102 163542 MOV STSTNM,2#DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3277 015400 013737 001570 001204 MOV #2#APT,$TIMES ;GET THE ITERATION COUNT
3278 015406 112737 000031 001115 MOVB #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
3279 015414 012737 000015 001224 MOV #15,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
3280
3281 ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
3282 015422 032777 010000 163510 BIT #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
3283 015430 001413 BEQ 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
3284 015432 013700 001102 MOV $STSTNM,R0 ;ELSE, TYPE THE NUMBER
3285 015436 042700 177000 BIC #177000,R0 ;MASK OUT THE HIGH ORDER BYTE
3286 015442 104401 001215 TYPE $RCLF
3287 015446 010046 MOV R0,-(SP) ;;SAVE R0 FOR TYPEOUT
3288 ;TEST NUMBER
3289 015450 104403 TYPOS ;GO TYPE--OCTAL ASCII
3290 015452 002 .BYTE 2 ;TYPE 2 DIGIT(S)
3291 015453 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
3292 015454 104401 001215 TYPE ,RCLF
3293
3294 20$:
3295 015460 005737 001324 TST 2#CLKSTA ;KW11-P CLOCK
3296 015464 033002 BGT 1$ ;YES--START TEST
3297 015466 000137 016116 JMP TST16 ;NO--GO TO NEXT TEST
3298 015472 012737 015472 001106 1$: MOV #15,$LPADR ;SETUP THE LOOP ADDRESS
3299 015500 004037 031112 R0,2#SRCH00 ;DO A MASSBUS INIT & RECAL
3300 015504 000402 BR 2$ ;RETURN HERE IF NO ERROR
3301 015506 000137 016114 JMP EXIT15 ;RETURN HERE ON ERROR
3302 015512 012703 003136 2$: MOV #T12,R3 ;PARAMETER POINTER
3303 015516 012737 016114 001206 MOV #EXIT15,$ESCAPE ;ESCAPE TO EXIT15 ON ERROR
3304 015524 012706 001100 TEST15: MOV #STACK,$P ;SETUP STACK
3305 015530 012701 000200 MOV #128,R1 ;REPEAT "0-'LC'-0" 128 TIMES
3306 015534 004737 031276 JSR PC,2#STATMR ;INIT. THE TIMERS
3307 015540 012777 016010 163710 MOV #7,$2PKV ;SETUP VECTOR IN CASE OF OVERFLOW
3308 015546 012777 031274 021164 MOV #DORTI,2#RMVEC ;SETUP RMO3 VECTOR
3309 015554 005077 163704 1$: CLR 2#PKB ;START COUNTING FROM ZERO
3310 015560 013764 001574 000034 MOV LC,RMDC(R4) ;MAXIMUM CYLINDER
3311 015566 012764 000105 000000 MOV #SEEK,RMCS1(R4) ;START A SEEK
3312 015574 012777 000131 163660 MOV #131,2#PKCS ;START THE CLOCK
3313 015602 000001 WAIT ;WAIT ON INTERRUPT
3314 015604 042777 000101 163650 BIC #101,2#PKCS ;STOP THE CLOCK
3315 015612 032764 040000 000012 BIT #BIT14,RMDS(R4) ;ERR=1?
3316 015620 001415 BEQ 2$ ;NO--BRANCH
3317 015622 104415 SAVREG ;SAVE R0-R5
3318 015624 012702 004266 MOV #DTADPB,R2 ;DPB POINTER
3319 015630 004737 044134 JSR PC,2#SVRH70 ;SAVE ALL THE RH70/RMO3 REGISTERS

```

3320	015634	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	; MASSBUS CLEAR
3321	015642	013764	004266	000010	MOV	#DTADPB, RMCS2(R4)	; SELECT DRIVE
3322	015650	104413			RESREG		; RESTORE RO-R5
3323	015652	104017			ERROR	17	
3324	015654	005005			2S: CLR	R5	; SET THE UP/DOWN SWITCH TO UP
3325	015656	004737	031342		JSR	PC, #COUNT	; UP THE COUNT
3326	015662	004737	030670		JSR	PC, #TWOMS	; STALL FOR 2 MILLISECONDS
3327	015666	005077	163572		CLR	#PKB	; START COUNT AT ZERO
3328	015672	013764	001572	000034	MOV	FC, RMDC(R4)	; BEGINNING CYLINDER
3329	015700	012764	000105	000000	MOV	#SEEK, RMCS1(R4)	; START A SEEK
3330	015706	012777	000131	163546	MOV	#131, #PKCS	; START THE CLOCK
3331	015714	000001			WAIT		; WAIT ON INTERRUPT
3332	015716	042777	000101	163536	BIC	#101, #PKCS	; STOP THE CLOCK
3333	015724	032764	040000	000012	BIT	#BIT14, RMDS(R4)	; "ERR"=1?
3334	015732	001415			BEQ	3S	; NO--BRANCH
3335	015734	104412			SAVREG		; SAVE RO-F5
3336	015736	012702	004266		MOV	#DTADPB, R2	; DPB POINTER
3337	015742	004737	044134		JSR	PC, #SVRH70	; SAVE ALL THE RH70/RM03 REGISTERS
3338	015746	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	; MASSBUS CLEAR
3339	015754	013764	004266	000010	MOV	#DTADPB, RMCS2(R4)	; SELECT DRIVE
3340	015762	104413			RESREG		; RESTORE RO-R5
3341	015764	104017			ERROR	17	; REPORT THE ERROR
3342	015766	012705	177777		3S: MOV	#-1, R5	; SET THE UP/DOWN SWITCH TO DOWN
3343	015772	004737	031342		JSR	PC, #COUNT	; UPDATE THE COUNT
3344	015776	004737	030670		JSR	PC, #TWOMS	; STALL FOR 2 MILLISECONDS
3345	016002	005301			DEC	R1	; DONE?
3346	016004	003263			BGT	1S	; NO--BRANCH
3347	016006	000424			BR	8S	; YES--EXIT
3348	016010	042777	000101	163444	7S: BIC	#101, #PKCS	; STOP THE CLOCK
3349	016016	005037	177776		CLR	#PS	; DROP THE PRIORITY
3350	016022	012600			MOV	(SP)+, RO	; PC OF WAIT+2
3351	016024	005726			TST	(SP)+	; POP THE PS FROM THE STACK
3352	016026	104412			SAVREG		; SAVE RO-R5
3353	016030	012702	004266		MOV	#DTADPB, R2	; DPB POINTER
3354	016034	004737	044134		JSR	PC, #SVRH70	; SAVE ALL THE RH70/RM03 REGISTERS
3355	016040	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	; MASSBUS CLEAR
3356	016046	013764	004266	000010	MOV	#DTADPB, RMCS2(R4)	; SELECT DRIVE
3357	016054	104413			RESREG		; RESTORE RO-R5
3358	016056	104020			ERROR	20	; CLOCK OVERFLOWED
3359	016060				8S:		
3360	016060	012764	000040	000010	MOV	#BIT05, RMCS2(R4)	; MASSBUS INIT.
3361	016066	013764	004266	000010	MOV	#DTADPB, RMCS2(R4)	; SELECT DRIVE
3362	016074	004737	026116		JSR	PC, #ST.CLK	; INITIALIZE THE CLOCK
3363	016100	012777	041566	020632	MOV	#ISR, #RMVEC	; RESTORE RH70/RM03 INT. VECTOR
3364	016106	004037	031474		JSR	RO, #TYPTIM	; GO TYPE THE TIMES
3365	016112	003136			T12		; POINTER
3366	016114	000004			EXIT15: SCOPE		; LOOP ?

F08

```

3423 016242 205:
3424
3425 016242 012737 016556 001332
3426 016250 012737 016256 001106
3427 016256 012706 001100
3428 016262 004737 032126
3429 016266 013737 001572 004300
3430 016274 113737 001600 004277
3431 016302 105037 004276
3432 016306 013737 001432 004272
3433 016314 012737 051776 004274
3434 016322 012737 016322 001110
3435 016330 012706 001100
3436 016334 012737 000161 004270
3437 016342 004037 027612
3438 016346 012737 000151 004270
3439 016354 012737 016354 001110
3440 016362 012706 001100
3441 016366 004037 027612
3442 016372 012737 016372 001110
3443 016400 012706 001100
3444 016404 004037 032164
3445 016410 012737 000171 004270
3446 016416 004037 027612
3447 016422 004037 032232
3448 016426 012700 051776
3449 016432 005001
3450 016434 012737 016434 001110
3451 016442 012706 001100
3452 016446 012737 000161 004270
3453 016454 012737 177400 004272
3454 016462 010037 004274
3455 016466 110137 004276
3456 016472 004037 027612
3457 016476 012737 016476 001110
3458 016504 012706 001100
3459 016510 012737 000151 004270
3460 016516 013737 001432 004272
3461 016524 012737 051776 004274
3462 016532 105037 004276
3463 016536 004037 027612
3464 016542 062700 001000
3465 016546 005201
3466 016550 023701 001712
3467 016554 103334
3468 016556 000004

```

```

TEST16: MOV #EXIT16, @#BYPASS
MOV #TEST16, $LPADR ; SETUP THE LOOP ADDRESS
MOV #STACK, SP ; SET THE STACK POINTER
JSR PC, @#FILBUF ; FILL THE BUFFER WITH SECTOR ADDRESSES
MOV @#FC, @#DTADPB+12 ; CYLINDER
MOV @#FT, @#DTADPB+11 ; TRACK
CLRB @#DTADPB+10 ; SECTOR
MOV TRCKWC, @#DTADPB+4 ; WORD COUNT
MOV #BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
MOV #STACK, SP ; LOAD THE STACK POINTER
MOV #WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
JSR RO, @#DRVCAL ; START A DATA TRANSFER
MOV #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
MOV #STACK, SP ; LOAD THE STACK POINTER
JSR RO, @#DRVCAL ; START A DATA TRANSFER
MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
MOV #STACK, SP ; LOAD THE STACK POINTER
JSR RO, @#CLRBUF ; CLEAR BUFFER
MOV #READ, @#DTADPB+2 ; COMMAND = READ
JSR RO, @#DRVCAL ; START A DATA TRANSFER
JSR RO, @#CKSCTR ; CHECK THE SECTOR DATA READ
MOV #BUFFER, RO ; BUFFER ADDRESS
CLR R1 ; FIRST SECTOR
MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
MOV #STACK, SP ; LOAD THE STACK POINTER
TEST17: MOV #WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
MOV #SCTRWC, @#DTADPB+4 ; WORD COUNT
MOV RO, @#DTADPB+6 ; BUFFER ADDRESS
MOV @#DTADPB+10 ; SECTOR
JSR RO, @#DRVCAL ; START A DATA TRANSFER
MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
MOV #STACK, SP ; LOAD THE STACK POINTER
MOV #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
MOV TRCKWC, @#DTADPB+4 ; WORD COUNT
MOV #BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
CLRB @#DTADPB+10 ; SECTOR
JSR RO, @#DRVCAL ; START A DATA TRANSFER
ADD #512., RO ; MOVE TO NEXT SECTOR
INC R1
CMP PRMLMT+22, R1 ; DONE?
BHS 15 ; NO--BRANCH
EXIT16: SCOPE ; LOOP ?

```

```

*****
; *TEST 17 TRACK ADDRESSING TEST
; *
; * THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES
; * IN CYLINDER "FC" SECTOR "FS" OF EVERY TRACK WITH EACH TRACK
; * GETTING ITS OWN TRACK ADDRESS.
; * A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO ENSURE
; * THE DATA IS VALID. THEN TRACK 0 IS REWRITTEN AND TRACK 1
; * THROUGH TRACK 18 IS WRITE CHECKED. THEN TRACK 1 IS

```

G08

```

3479      ;* REWRITTEN AND TRACK 2 THROUGH TRACK 18 IS WRITE CHECKED.
3480      ;* THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING TRACK 17
3481      ;* AND WRITE CHECKING TRACK 18.
3482
3483      ;*****
3484      †ST17:
3485      016560      000240      NOP
3486      016562      033737      001544      001314      BIT      2#BITS+<17*2>,TSTNMS ;DO THIS TEST?
3487      016570      001002      BNE      64$      ;YES--BRANCH
3488      016572      000137      017244      JMP      TST20      ;NO--GO TO THE NEXT TEST
3489      016576      012737      000017      001102      64$:      MOV      #17,2#STSTNM ;SET UP TEST NUMBER AND
3490      ;CLEAR THE ERROR FLAG ($ERFLG)
3491      016604      004737      026632      JSR      PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
3492      016610      012737      016720      001110      MOV      #TST17,2#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3493      016616      013777      001102      162316      MOV      $STSTNM,$DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3494      016624      013737      001570      001204      MOV      2#RPT,$TIMES ;GET THE ITERATION COUNT
3495      016632      113737      001444      001115      MOV      ERR.CT,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
3496      016640      012737      000017      001224      MOV      #17,$TSTN ;SET TEST NUMBER IN APT MAIL BOX
3497
3498      ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
3499      016646      032777      010000      162264      BIT      #SW12,2#SWR ;CHECK FOR SWITCH 12 SET
3500      016654      001413      BEQ      20$      ;IF = 0, THEN DON'T TYPE TEST NUMBER
3501      016656      013700      001102      MOV      $STSTNM,RO ;ELSE, TYPE THE NUMBER
3502      016662      042700      177000      BIC      #177000,RO ;MASK OUT THE HIGH ORDER BYTE
3503      016666      104401      001215      TYPE      $CRLF
3504      016672      010046      MOV      RO,-(SP) ;SAVE RO FOR TYPEOUT
3505
3506      016674      104403      TYPOS
3507      016676      002      .BYTE      2 ;TEST NUMBER
3508      016677      000      .BYTE      0 ;GO TYPE--OCTAL ASCII
3509      016700      104401      001215      TYPE      , $CRLF ;TYPE 2 DIGIT(S)
3510      016704      20$:
3511
3512      016704      012737      017242      001332      MOV      #EXIT17,2#BYPASS
3513      016712      012737      016720      001106      MOV      #TST17,$SLPADR ;SETUP THE LOOP ADDRESS
3514      016720      012706      001100      TEST17: MOV      #STACK,SP ;SET THE STACK POINTER
3515      016724      004737      032126      JSR      PC,2#FILBUF ;FILL THE BUFFER WITH TRACK ADDRESS
3516      016730      012737      000161      004270      MOV      #WRITE,2#DTADPB+2 ;COMMAND=WRITE DATA
3517      016736      013737      001572      004300      MOV      2#FC,2#DTADPB+12 ;CYLINDER
3518      016744      113737      001606      004276      MOV      2#FS,2#DTADPB+10 ;SECTOR
3519      016752      012737      177400      004272      MOV      #SCTRWC,2#DTADPB+4 ;WORD COUNT
3520      016760      012737      051776      004274      MOV      #BUFFER,2#DTADPB+6 ;BUFFER ADDRESS
3521      016766      005000      CLR      RO ;TRACK=0
3522      016770      012737      016770      001110      MOV      #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
3523      016776      012706      001100      MOV      #STACK,SP ;LOAD THE STACK POINTER
3524      017002      110037      004277      1$:      MOV      RO,2#DTADPB+11 ;TRACK ADDRESS
3525      017006      004037      027612      JSR      RO,2#DRVCAL ;START A DATA TRANSFER
3526      017012      062737      001000      004274      ADD      #256.*2.,2#DTADPB+6 ;UPDATE BUFFER ADDRESS
3527      017020      005200      INC      RO ;UPDATE TRACK NUMBER
3528      017022      022700      000005      CMP      #5,RO ;OUT OF TRACKS?
3529      017026      003365      BGT      1$ ;NO--BRANCH
3530      017030      012737      051776      004274      MOV      #BUFFER,2#DTADPB+6 ;BUFFER ADDRESS
3531      017036      005000      CLR      RO
3532      017040      012737      017040      001110      MOV      #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
3533      017046      012706      001100      MOV      #STACK,SP ;LOAD THE STACK POINTER
3534      017052      012737      000151      004270      MOV      #WRCKD,2#DTADPB+2 ;COMMAND=WRITE CHECK

```

3535	017060	110037	004277	25:
3536	017064	004037	027612	
3537	017070	062737	001000	004274
3538	017076	005200		
3539	017100	022700	000005	
3540	017104	003365		
3541	017106	005000		
3542	017110	110037	004277	35:
3543	017114	010001		
3544	017116	012737	051776	004274
3545	017124	005301		45:
3546	017126	002411		
3547	017130	062737	001000	004274
3548	017136	000772		
3549	017140	012737	017140	001110
3550	017146	012706	001100	
3551	017152	012737	000161	004270 55:
3552	017160	004037	027612	
3553	017164	062737	001000	004274 65:
3554	017172	105237	004277	
3555	017176	012737	017176	001110
3556	017204	012706	001100	
3557	017210	012737	000151	004270
3558	017216	004037	027612	
3559	017222	122737	000004	004277
3560	017230	003355		
3561	017232	005200		
3562	017234	022700	000004	
3563	017240	003323		
3564	017242	000004		

```

MOV B   RO, @#DTADPB+11 ; TRACK ADDRESS
JSR     RO, @#DRVCAL    ; START A DATA TRANSFER
ADD     #256.*2., @#DTADPB+6 ; UPDATE BUFFER ADDRESS
INC     RO              ; UPDATE TRACK NUMBER
CMP     #5, RO         ; OUT OF TRACKS?
BGT     25             ; NO--BRANCH
CLR     RO              ; FIRST TRACK ADDRESS
MOV B   RO, @#DTADPB+11 ; TRACK
MOV     RO, R1         ; FORM BUFFER ADDRESS
MOV     #BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
DEC     R1
BLT     55
ADD     #256.*2., @#DTADPB+6
BR      45
MOV     #. $LPERR      ; SETUP THE ERROR LOOP ADDRESS
MOV     #STACK, SP    ; LOAD THE STACK POINTER
MOV     #WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
JSR     RO, @#DRVCAL  ; START A DATA TRANSFER
ADD     #256.*2., @#DTADPB+6 ; UPDATE BUFFER ADDRESS
INCB   @#DTADPB+11    ; MOVE TO NEXT TRACK
MOV     #. $LPERR      ; SETUP THE ERROR LOOP ADDRESS
MOV     #STACK, SP    ; LOAD THE STACK POINTER
MOV     #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
JSR     RO, @#DRVCAL  ; START A DATA TRANSFER
CMP B   #4, @#DTADPB+11 ; OUT OF TRACKS?
BGT     65            ; NO--BRANCH
INC     RO              ; NEXT TRACK TO WRITE
CMP     #4, RO         ; OUT OF TRACKS?
BGT     35            ; NO--BRANCH
EXIT17: SCOPE

```

.SBTTL *** DATA TEST ***

: *TEST 20 DATA TEST

: * THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS
: * "FC" THROUGH "LC" BY THE INCREMENT "IC" USING THE DATA PATTEPNS
: * SPECIFIED. THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER:
: * 1. SET "NT" TO "FT" THEN REPEAT 2-4 UNTIL "NT" > "LT"
: * 2. WRITE THEN WRITE CHECK "FS" THROUGH "LS" OF TRACK "NT"
: * 3. READ THEN SOFTWARE COMPARE "FS" THROUGH "LS" OF TRACK "NT"
: * 4. INCREMENT "NT" BY "IT"
: * 5. REPEAT STEPS 1-4 FOR EACH DATA PATTERN
: * 6. REPEAT STEPS 1-5 FOR "FC" THROUGH "LC" ADVANCING BY "IC"

: * IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND
: * THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS
: * ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE
: * WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS
: * FATAL AND NO READ OCCURS.
: * FS DEFAULTS TO 1 AND LS DEFAULTS TO 0
: * PAT DEFAULTS TO 177777 (ALL POSSIBLE PATTERNS)
: * THE POSSIBLE PATTERNS ARE:

PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
165555	000001	177776	000000	000000	052525	007417	026455
133333	000003	177774	000000	010421	052525	007417	026455
165555	000007	177770	000000	021042	052525	007417	026455
133333	000017	177760	177777	031463	125252	170360	151322
165555	000037	177740	177777	042104	125252	170360	151322
133333	000077	177700	177777	052525	125252	170360	151322
165555	000177	177600	000000	063146	052525	007417	026455
133333	000377	177400	000000	073567	052525	007417	026455
165555	000777	177000	177777	104210	125252	170360	151322
133333	001777	176000	177777	114631	125252	170360	151322
165555	003777	174000	000000	125252	052525	007417	026455
133333	007777	170000	177777	135673	125252	170360	151322
165555	017777	160000	000000	146314	052525	007417	026455
133333	037777	140000	177777	156735	125252	170360	151322
165555	077777	100000	000000	167356	052525	007417	026455
133333	177777	000000	177777	177777	125252	170360	151322
PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
165555	000001	177776	172666	077777	153333	000000	177777
133333	000002	177775	155555	137777	066667	177777	000000
165555	000004	177773	172666	157777	153333	177777	000000
133333	000010	177767	155555	167777	066667	177777	000000
165555	000020	177757	172666	173777	153333	177777	000000
133333	000040	177737	155555	175777	066667	177777	000000
165555	000100	177677	172666	176777	153333	177777	000000
133333	000200	177577	155555	177377	066667	177777	000000
165555	000400	177377	172666	177577	153333	177777	000000
133333	001000	176777	155555	177677	066667	177777	000000
165555	002000	175777	172666	177737	153333	177777	000000

3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579
3580
3581
3582
3583
3584
3585
3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620

JOB

MD-11-DZRMF-B RMO3 RMO2 EXTENDED DRIVE TEST
 CZRMFB.F11 21-NOV-77 14.10 T20

MACY11 30(1046) 22-NOV-77 08:04 PAGE 70
 DATA TEST

SEQ 0100

```

3621      :*      133333  004000  173777  155555  177757  066667  177777  000000
3622      :*      165555  010000  167777  172666  177767  153333  177777  000000
3623      :*      133333  020000  157777  155555  177773  066667  177777  000000
3624      :*      165555  040000  137777  172666  177775  153333  177777  000000
3625      :*      133333  100000  077777  155555  177776  066667  177777  000000
3626      :*
3627      :*
3628      :*
3629      :*
  
```

```

3629      017244      :*      *****
3630      017244 000240      †ST20:
3631      017246 033737 001506 001316      NOP
3632      017254 001002      BIT      BITS+<20*2-40>,TSTNMS+2 ;DO THIS TEST ?
3633      017256 000137 020044      BNE      64$ ;YES--BRANCH
3634      017262 012737 000020 001102 64$:      JMP      TST21 ;NO--GO TO THE NEXT TEST
3635      017270 004737 026632      MOV      #20,#STSTNM ;SET UP TEST NUMBER AND
3636      017274 012737 017512 001110      JSR      PC,LODPRM ;CLEAR THE ERROR FLAG ($ERFLG)
3637      017302 013777 001102 161632      MOV      #TST20,#SLPERR ;LOAD THE PARAMETERS FOR THE TEST
3638      017310 013737 001570 001204      MOV      $STSTNM,#DISPLAY ;SETUP THE LOOP ON ERROR ADDRESS
3639      017316 113737 001444 001115      MOV      #RPT,$TIMES ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3640      017324 012737 000020 001224      MOV      ERR.CT,$ERMAX ;GET THE ITERATION COUNT
3641      017324 012737 000020 001224      MOV      #20,$TSTN ;MAX ERRORS ALLOWED FOR TEST
3642      017324 012737 000020 001224      MOV      #20,$TSTN ;;SET TEST NUMBER IN APT MAIL BOX
3643      017332 032777 010000 161600      ;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
3644      017340 001413      BIT      #SW12,#SWR ;CHECK FOR SWITCH 12 SET
3645      017342 013700 001102      BEQ      20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
3646      017346 042700 177000      MOV      $STSTNM,R0 ;ELSE, TYPE THE NUMBER
3647      017352 104401 001215      BIC      #177000,R0 ;MASK'OUT THE HIGH ORDER BYTE
3648      017356 010046      TYPE    $,R0 ;SAVE R0 FOR TYPEOUT
3649      017360 104403      MOV      R0,-(SP) ;TEST NUMBER
3650      017362 002 ;GO TYPE--OCTAL ASCII
3651      017363 000 ;TYPE 2 DIGIT(S)
3652      017364 104401 001215      TYPE    $,R0 ;SUPPRESS LEADING ZEROS
3653      017370 20$:
3654      017370 ;SET UP THE TRACK WORD COUNT FOR DATA TRANSFER
3655      017370 012737 017370 001106      MOV      #,$LPADR ;SETUP THE LOOP ADDRESS
3656      017376 005000      CLR      R0 ;CLEAR SWITCH
3657      017400 005004      CLR      R4 ;FORM WORD COUNT IN R4
3658      017402 013701 001610      MOV      #LS,R1 ;LOAD LAST SECTOR
3659      017406 163701 001606      SUB      #FS,R1 ;COMPARE WITH FIRST SECTOR
3660      017412 002004      BGE     1$ ;SKIP NEXT IF FS < OR = LS
3661      017414 063701 001712      ADD      PRMLT+22,R1 ;ADD MAXIMUM SECTOR ADDRESS TO
3662      017420 005201      INC      R1 ;MAKE THE DIFFERENCE POSITIVE
3663      017422 005100      COM     R0 ;SET SWITCH FOR FS > LS
3664      017424 062704 000400 1$:      ADD      #256.,R4 ;WORDS/SECTOR
3665      017430 005301      DEC     R1 ;LS - FS SECTORS MINUS ONE
3666      017432 002374      BGE     1$ ;INCR. WORD COUNT IF NO. SECTORS STILL +
3667      017434 005404      NEG     R4 ;FORM NEGATIVE WORD COUNT
3668      017436 010405      MOV     R4,R5 ;COPY NORMAL WORD COUNT INTO SMALL WC
3669      017440 005700      TST     R0 ;FS > LS SWITCH SET?
  
```

K08

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST
 CZRMFB.P11 21-NOV-77 14:10 T20

MACY11 30(1046) 22-NOV-77 08:04 PAGE 71
 DATA TEST

SEG 0101

```

3677 017442 001412          BEQ      3$          ;NO, SKIP NEXT
3678
3679 017444 005005          CLR      R5          ;FORM WORD COUNT FOR FS > LS
3680 017446 013701 001712    MOV      PRMLMT+22,R1 ;MAX SECTOR ADDRESS
3681 017452 163701 001606    SUB      @#FS,R1     ;SUBTRACT THE FIRST SECTOR
3682 017456 062705 000400    2$:     ADD      #256.,R5 ;WORDS/SECTOR
3683 017462 005301          DEC      R1          ;NO SECTORS MINUS ONE
3684 017464 002374          BGE     2$          ;INCR. WORD COUNT IF NO. SECTORS STILL +
3685 017466 005405          NEG     R5          ;FORM NEGATIVE WORD COUNT FOR THIS CASE
3686
3687                          ;SET UP FOR DATA TRANSFERS AND PATTERN VARIATIONS
3688
3689 017470 113737 001606 004276 3$:     MOV     @#FS,@#DTADPB+10 ;SECTOR
3690 017475 012737 051776 004274    MOV     #BUFFER,@#DTADPB+6 ;DATA BUFFER
3691 017504 012737 020042 001332    MOV     #EXIT20,@#BYPASS
3692 017512 012706 001100    TEST20: MOV     #STACK,SP ;LOAD THE STACK POINTER
3693 017516 005037 001414    CLR     @#WCEFLG    ;CLEAR THE WRITE CHECK ERROR FLAG
3694 017522 013701 001572    MOV     @#FC,R1     ;PICKUP FIRST CYLINDER
3695 017526 000407          BR      2$          ;SKIP PATTERN SET-UP FIRST TIME THRU
3696
3697 017530 005720          1$:     TST     (R0)+       ;MOVE TO NEXT DATA PATTERN
3698 017532 022700 000040    CMP     #16.*2.,R0 ;OUT OF PATTERNS?
3699 017536 003004          BGT     3$          ;NO, STAY ON THIS CYLINDER UNTIL DONE
3700 017540 004037 032052    JSR     R0,@#INCCYL ;MOVE TO NEXT CYLINDER
3701 017544 000536          BR      EXIT20     ;OUT OF CYLINDERS -----
3702
3703                          ;DO NEXT CYLINDER
3704
3705 017546 005000          2$:     CLR     R0          ;START WITH PATTERN 0
3706 017550 036037 001506 001612 3$:     BIT     BITS(R0),@#PAT ;THIS PATTERN SELECTED?
3707 017556 001764          BEQ     1$          ;NO, GO BACK AND GET ONE THAT WAS
3708 017560 013702 001600    MOV     @#FT,R2     ;FIRST TRACK
3709 017564 010137 004300    MOV     R1,@#DTADPB+12 ;LOAD THE CYLINDER
3710 017570 110237 004277    4$:     MOV     R2,@#DTADPB+11 ;LOAD THE TRACK
3711
3712 017574 020127 001466    CMP     R1,#822.    ;CHECK FOR LAST DISK CYLINDER
3713 017600 001003          BNE     10$        ;SKIP LAST TRACK CHECK IF NOT
3714 017602 020227 000004    CMP     R2,#4      ;LAST DISK TRACK ?
3715 017606 001515          BEQ     EXIT20     ;DON'T TEST LAST TRACK AS IT HAS BAD
3716 017610          10$:    ;BLOCK INFORMATION STORED ON IT -----
3717
3718 017610 010437 004272    MOV     R4,@#DTADPB+4 ;LOAD THE WORD COUNT
3719 017614 023701 001574    CMP     LC,R1       ;LAST DISK CYLINDER TO TEST ?
3720 017620 003005          BGT     5$          ;NO, SKIP TRACK CHECK
3721 017622 022702 000004    CMP     #4,R2       ;LAST DISK TRACK TO TEST ?
3722 017626 003002          BGT     5$          ;NO, SKIP NEXT
3723 017630 010537 004272    MOV     R5,@#DTADPB+4 ;SHORT WORD COUNT
3724 017634 017703 161300    5$:     MOV     @SWR,R3     ;INHIBIT WRITE AND
3725 017640 005103          COM     R3          ;WRITE CHECK?
3726 017642 032703 000030    BIT     #SW04!SW03,R3
3727 017646 001436          BEQ     7$          ;YES--BRANCH
3728 017650 004737 032602    JSR     PC,@#SETBUF ;MOVE DATA PATTERN INTO THE BUFFER
3729 017654 032777 000020 161256 BIT     #SW04,@SWR ;INHIBIT WRITE?
3730 017662 001012          BNE     6$          ;YES, DO NEXT PORTION OF TESTING
3731 017664 012737 017664 001110 MOV     #,$LPERR    ;SETUP THE ERROR LOOP ADDRESS
3732 017672 012706 001100    MOV     #STACK,SP  ;LOAD THE STACK POINTER

```

L08

MD-11-DZRM-B RM03/RM02 EXTENDED DRIVE TEST
 CZRMFB.F11 21-NOV-77 14:10 T20

MACY11 30(1046) 22-NOV-77 08:04 PAGE 72
 DATA TEST

SEG 0102

3733	017676	012737	000161	004270		MOV	#WRITE, @#DTADPB+2 ;COMMAND=WRITE DATA	
3734								
3735								
3736								
3737	017704	004037	027612			JSR	RO, @#DRVCAL ;START A DATA TRANSFER	
3738	017710	032777	000010	161222	6\$:	BIT	#SW03, @SWR ;INHIBIT WRITE CHECK?	
3739	017716	001012				BNE	7\$;YES--BRANCH	
3740	017720	012737	017720	001110		MOV	#, \$LPERR ;SETUP THE ERROR LOOP ADDRESS	
3741	017726	012706	001100			MOV	#STACK, SP ;LOAD THE STACK POINTER	
3742	017732	012737	000151	004270		MOV	#WRCKD, @#DTADPB+2 ;COMMAND=WRITE CHECK DATA	
3743	017740	004037	027612			JSR	RO, @#DRVCAL ;START A DATA TRANSFER	
3744	017744	005737	001414		7\$:	TST	@#WCEFLG ;WRITE CHECK ERROR FLAG SET?	
3745	017750	001404				BEQ	8\$;NO--BRANCH	
3746	017752	032777	000001	161160		BIT	#SW00, @SWR ;PERFORM READ AFTER FATAL "WCE"?	
3747	017760	001424				BEQ	9\$;NO--BRANCH	
3748	017762	032777	000004	161150	8\$:	BIT	#SW02, @SWR ;INHIBIT READ DATA AND SOFTWARE COMPARE?	
3749	017770	001020				BNE	9\$;YES--BRANCH	
3750	017772	012737	017772	001110		MOV	#, \$LPERR ;SETUP THE ERROR LOOP ADDRESS	
3751	020000	012706	001100			MOV	#STACK, SP ;LOAD THE STACK POINTER	
3752	020004	012737	000171	004270		MOV	#READ, @#DTADPB+2 ;COMMAND=READ	
3753	020012	004037	027612			JSR	RO, @#DRVCAL ;START A DATA TRANSFER	
3754	020016	032777	000002	161114		BIT	#SW01, @SWR ;COMPARE THE DATA?	
3755	020024	001002				BNE	9\$;NO--BRANCH	
3756	020026	004737	032672			JSR	PC, @#DATCMP ;YES--DO IT	
3757	020032	004037	032022		9\$:	JSR	RO, @#INCTRK ;MOVE TO NEXT TRACK	
3758	020036	000634				BR	1\$;OUT OF TRACKS GO TO NEXT PATTERN	
3759	020040	000653				BR	4\$;LOOP	
3760	020042	000004			EXIT20:	SCOPE	;SCOPE LOOP	

.SBTTL *** EXERCISE TEST ***

: TEST 21 RANDOM ADDRESS AND RANDOM PATTERN TEST

: * STARTING AT "FC" AND GOING SEQUENTIALLY TO "LC" THE DISK
: * PACK IS WRITTEN WITH A RANDOM PATTERN. THE FIRST TWO WORDS
: * OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR
: * FOR THAT SECTOR.

: * THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE "R" TIMES
: * "R" DEFAULTS TO 1000.

- : * 1) GENERATE A RANDOM SECTOR ADDRESS
- : * 2) WRITE A RANDOM PATTERN AT THE ADDRESS
GENERATED IN 1.
- : * 3) GENERATE A NEW RANDOM SECTOR ADDRESS
- : * 4) READ THE SECTOR AT THE ADDRESS
GENERATED IN 3.
- : * 5) DO A SOFTWARE CHECK OF THE DATA READ IN 4 AGAINST
THE ORIGINAL RANDOM PACK DATA.
- : * 6) DO A WRITE CHECK OF THE DATA WRITTEN IN 2
- : * 7) GENERATE A NEW RANDOM SECTOR ADDRESS
- : * 8) READ THE SECTOR AT THE ADDRESS
GENERATED IN 7.
- : * 9) DO A SOFTWARE CHECK OF THE DATA READ IN 8
- : * 10) DO A WRITE CHECK OF THE DATA WRITTEN IN 2

: TST21:

3761
3762
3763
3764
3765
3766
3767
3768
3769
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779
3780
3781
3782
3783
3784
3785
3786
3787
3788
3789
3790 020044
3791 020044 000240
3792 020046 033737 001510 001316
3793 020054 001002
3794 020056 000137 020702
3795 020062 012737 000021 001102 64\$:
3796
3797 020070 004737 026632
3798 020074 012737 020360 001110
3799 020102 013777 001102 161032
3800 020110 013737 001570 001204
3801 020116 113737 001444 001115
3802 020124 012737 000021 001224
3803
3804
3805 020132 032777 010000 161000
3806 020140 001413
3807 020142 013700 001102
3808 020146 042700 177000
3809 020152 104401 001215
3810 020156 010046
3811
3812 020160 104403
3813 020162 002
3814 020163 000
3815 020164 104401 001215
3816 020170

```

NOP
BIT BITS+(21*2-40),TSTNMS+2 ;DO THIS TEST ?
64$ :YES--BRANCH
BNE 64$ ;NO--GO TO THE NEXT TEST
JMP TST22 ;SET UP TEST NUMBER AND
64$ :MOV #21,#TSTNM ;CLEAR THE ERROR FLAG (SERFLG)
;LOAD THE PARAMETERS FOR THE TEST
JSR PC,LOPRM ;SETUP THE LOOP ON ERROR ADDRESS
MOV #TST21,#SLPERR ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV $TSTNM,#DISPLAY ;GET THE ITERATION COUNT
MOV #RPT,$TIMES ;MAX ERRORS ALLOWED FOR TEST
MOVB ERR.CT,$ERMAX ;SET TEST NUMBER IN APT MAIL BOX
MOV #21,$TSTN

;THIS IS A MACRO TO TYPE OUT THE TEST BEING EXECUTED IF SW12 IS SET
BIT #SW12,$SWR ;CHECK FOR SWITCH 12 SET
BEG 20$ ;IF = 0, THEN DON'T TYPE TEST NUMBER
MOV $TSTNM,R0 ;ELSE, TYPE THE NUMBER
BIC #177000,R0 ;MASK OUT THE HIGH ORDER BYTE
TYPE $CRLF
MOV R0,-(SP) ;SAVE R0 FOR TYPEOUT
;TEST NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 2 DIGIT(S)
;SUPPRESS LEADING ZEROS
20$:
TYPE ,CRLF

```

N08

MD-11-DZRMF-B RM03/RM02 EXTENDED DRIVE TEST
 CZRMFB.P11 21-NOV-77 14:10 T21

MACY11 30(1046) 22-NOV-77 08:04 PAGE 74
 RANDOM ADDRESS AND RANDOM PATTERN TEST

SEQ 0104

3817										
3818	020170	012737	020170	001106		MOV	#, \$LPADR	; SETUP THE LOOP ADDRESS		
3819	020176	012737	020700	001332		MOV	#EXIT21, #BYPASS			
3820	020204	012737	176543	025630		MOV	#176543, #SHINUM	; PRIME THE RANDOM NUMBER GENERATOR		
3821	020212	012737	123456	025632		MOV	#123456, #LONUM			
3822	020220	013737	001572	004300		MOV	#FC, #DTADPB+12	; CYLINDER		
3823	020226	013737	001432	004272		MOV	TRCKWC, #DTADPB+4	; WORD COUNT FOR 32/30 SECTORS (FULL TRACK)		
3824	020234	012737	051776	004274		MOV	#BUFFER, #DTADPB+6	; BUFFER ADDRESS		
3825	020242	012737	000161	004270		MOV	#WRITE, #DTADPB+2	; COMMAND		
3826	020250	032737	100000	001300		BIT	#SW15, #C.SWR	; WRITE THE DISK PACK BEFORE TESTING?		
3827	020256	001027				BNE	3\$; NO--BEGIN TESTING		
3828	020260	004037	033210			JSR	RO, #FILRAN	; FILL DATA BUFFER WITH RANDOM DATA		
3829	020264	005037	004276		1\$:	CLR	#DTADPB+10	; SECTOR AND TRACK		
3830	020270	012737	020270	001110		MOV	#, \$LPERR	; SETUP THE ERROR LOOP ADDRESS		
3831	020276	012706	001100			MOV	#STACK, SP	; LOAD THE STACK POINTER		
3832	020302				2\$:					
3833	020302	004037	027612			JSR	RO, #DRVCAL	; START A DATA TRANSFER		
3834	020306	105237	004277			INCB	#DTADPB+11	; NEXT TRACK		
3835	020312	122737	000005	004277		CMPB	#5, #DTADPB+11	; TIME FOR NEXT CYLINDER ?		
3836	020320	003370				BGT	2\$; NO--DO NEXT TRACK ON THIS CYL.		
3837	020322	005237	004300			INC	#DTADPB+12	; INCR CYLINDER ADDRESS		
3838	020326	023737	001574	004300		CMP	#LC, #DTADPB+12	; OUT OF CYLINDERS?		
3839	020334	002353				BGE	1\$; NO--CONTINUE SEQUENTIAL RANDOM WRITE		
3840										
3841										
3842	020336	012737	177400	004272	3\$:	MOV	#SCRWC, #DTADPB+4	; WORD COUNT		
3843	020344	012737	020360	001106		MOV	#TEST21, #SLPADR			
3844	020352	012737	020360	001110		MOV	#TEST21, #SLPERR			
3845	020360	012706	001100		TEST21:	MOV	#STACK, SP	; SET STACK POINTER		
3846										
3847	020364	004037	033464			JSR	RO, #RANADR	; GENERATE A RANDOM ADDRESS		
3848	020370	013737	004276	001420		MOV	#DTADPB+10, #SVADR	; SAVE THE TRACK/SECTOR		
3849	020376	013737	004300	001422		MOV	#DTADPB+12, #SVADR+2	; SAVE THE CYLINDER		
3850	020404	012737	000161	004270		MOV	#WRITE, #DTADPB+2	; COMMAND=WRITE DATA		
3851	020412	012701	051776			MOV	#BUFFER, R1	; WRITE BUFFER ADDRESS FOR "RANPAT"		
3852	020416	010137	004274			MOV	R1, #DTADPB+6	; INTO THE DATA PARAMETER BLOCK		
3853	020422	004037	033430			JSR	RO, #RANPAT	; GENERATE RANDOM 256 WORD PATTERN		
3854								; AND PUT INTO THE WRITE BUFFER		
3855	020426	012737	020426	001110		MOV	#, \$LPERR	; SETUP THE ERROR LOOP ADDRESS		
3856	020434	012706	001100			MOV	#STACK, SP	; LOAD THE STACK POINTER		
3857	020440	004037	027612			JSR	RO, #DRVCAL	; START A DATA TRANSFER		
3858										
3859	020444	004037	033464			JSR	RO, #RANADR	; GENERATE A NEW RANDOM ADDRESS		
3860	020450	012737	000171	004270		MOV	#READ, #DTADPB+2	; COMMAND=READ DATA		
3861	020456	012737	052776	004274		MOV	#BUFFER+512, #DTADPB+6	; READ BUFFER ADDRESS		
3862	020464	012737	020464	001110		MOV	#, \$LPERR	; SETUP THE ERROR LOOP ADDRESS		
3863	020472	012706	001100			MOV	#STACK, SP	; LOAD THE STACK POINTER		
3864	020476	004037	027612			JSR	RO, #DRVCAL	; START A DATA TRANSFER		
3865	020502	005737	001446			TST	BASFLG	; IF BAD SECTOR ENCOUNTERED, SKIP NEXT CALL		
3866	020506	100402				BMI	+6	; DON'T COMPARE DATA		
3867	020510	004037	033232			JSR	RO, #RANCK	; SOFTWARE CHECK THE DATA		
3868										
3869	020514	013737	001420	004276		MOV	#SVADR, #DTADPB+10	; GET ADDRESS OF WHERE THE LAST		
3870	020522	013737	001422	004300		MOV	#SVADR+2, #DTADPB+12	; WRITE WAS PERFORMED		
3871	020530	012737	000151	004270		MOV	#WRCKD, #DTADPB+2	; COMMAND=WRITE CHECK DATA		
3872	020536	012737	051776	004274		MOV	#BUFFER, #DTADPB+6	; DATA BUFFER ADDRESS FOR HARDWARE		

```

3873
3874 020544 012737 020544 001110 MOV #,$LPERR ;CHECK OF THE DATA
3875 020552 012706 001100 MOV #STACK,SP ;SETUP THE ERROR LOOP ADDRESS
3876 020556 004037 027612 JSR RO,$DAVCAL ;LOAD THE STACK POINTER
3877 ;START A DATA TRANSFER
3878 020562 004037 033464 JSR RO,$RANADR ;GENERATE A NEW RANDOM ADDRESS
3879 020566 012737 000171 004270 MOV #READ,$DTADPB+2 ;COMMAND=READ
3880 020574 012737 052776 004274 MOV #BUFFER+512,$DTADPB+6 ;DATA BUFFER ADDRESS
3881 020602 012737 020602 001110 MOV #,$LPERR ;SETUP THE ERROR LOOP ADDRESS
3882 020610 012706 001100 MCV #STACK,SP ;LOAD THE STACK POINTER
3883 020614 004037 027612 JSR RO,$DAVCAL ;START A DATA TRANSFER
3884 020620 005737 001446 TST BASFLG ;ENCOUNTER BAD SECTOR ?
3885 020624 100402 BML +6 ;DON'T COMPARE DATA IF SO
3886 020626 004037 033232 JSR RO,$RANCK ;SOFTWARE CHECK THE DATA
3887
3888 020632 013737 001420 004276 MOV $SVADR,$DTADPB+10 ;GET DISK ADDRESS OF THE
3889 020640 013737 001422 004300 MOV $SVADR+2,$DTADPB+12 ;LAST WRITE
3890 020646 012737 000151 004270 MOV #WRCKD,$DTADPB+2 ;COMMAND=WRITE CHECK DATA
3891 020654 012737 051776 004274 MOV #BUFFER,$DTADPB+6 ;DATA BUFFER ADDRESS
3892 020662 012737 020662 001110 MOV #,$LPERR ;SETUP THE ERROR LOOP ADDRESS
3893 020670 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
3894 020674 004037 027612 JSR RO,$DAVCAL ;START A DATA TRANSFER
3895 020700 000004 EXIT21: SCOPE ;LOOP ?
3896
3897 .SBTTL *** RMO3 ACCESS TIME ADJUSTMENT TEST ***
3898
3899 ;*****
3900 ;*TEST 22 RMO3 ACCESS TIME ADJUSTMENT TEST
3901 ;*****
3902 ;* THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 136 TO ALLOW THE
3903 ;* OPERATOR TO ADJUST THE ACCESS TIME ON AN RMO3 USING THE
3904 ;* DDU. THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS
3905 ;* SO THAT THE ACCESS TIME INDICATORS ON THE DDU MAY BE OBSERVED.
3906 ;*****
3907
3908 †ST22:
3909 020702 000240 NOP
3910 020704 033737 001512 001316 BIT BITS+(22*2-40),TSTNMS+2 ;DO THIS TEST ?
3911 020712 001002 BNE 64$ ;YES--BRANCH
3912 020714 000137 021052 JMP SEOP ;NO--GO TO THE END OF THE PROGRAM
3913 020720 012737 000022 001102 64$: MOV #22,$STSTNM ;SET UP TEST NUMBER AND
3914 ;CLEAR THE ERROR FLAG ($ERFLG)
3915 020726 004737 026632 JSR PC,LOPRM ;LOAD THE PARAMETERS FOR THE TEST
3916 020732 012737 020770 001110 MOV #TEST22,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
3917 020740 013777 001102 160174 MOV $STSTNM,$DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3918 020746 013737 001570 001204 MOV $RPT,$TIMES ;GET THE ITERATION COUNT
3919 020754 112737 000144 001115 MOVB #100,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
3920 020762 012737 020770 001106 MOV #TEST22,$LPADR ;SETUP THE LOOP ADDRESS
3921 020770 012706 001100 TEST22: MOV #STACK,SP ;SETUP THE STACK POINTER
3922 020774 013737 001574 004220 MOV LC,DPB.A+12 ;ENDING CYLINDER
3923 021002 112737 000105 004210 MOVB #SEEK,$DPB.A+2 ;SEEK=COMMAND
3924 021010 004037 027054 JSR RO,$CALL.A ;GO EXECUTE THE COMMAND
3925 021014 004037 030606 JSR RO,STALL ;STALL
3926 021020 001440 .WORD STALL3 ;ADDRESS OF STALL VALUE
3927 021022 013737 001572 004220 MOV FC,DPB.A+12 ;STARTING CYLINDER
3928 021030 112737 000105 004210 MOVB #SEEK,$DPB.A+2 ;SEEK=COMMAND

```

3929 021036 004037 027054
 3930 021042 004037 030606
 3931 02104E 001440
 3932 021050 000004
 3933
 3934
 3935
 3936
 3937
 3938
 3939
 3940
 3941
 3942
 3943
 3944 021052
 3945 021052 104401 021060
 3946 021056 000410
 3947
 3948 021100
 3949 021100 005737 001312
 3950 021104 001434
 3951 021106 104401 021114
 3952 021112 000405
 3953
 3954 021126
 3955 021126 013746 001334
 3956 021132 104403
 3957 021134 002
 3958 021135 000
 3959 021136 104401 021144
 3960 021142 000412
 3961
 3962 021170
 3963 021170 013746 001112
 3964 021174 104402
 3965 021176 005037 001112
 3966 021202 005037 001102
 3967 021206 005037 001204
 3968 021212 005237 001226
 3969 021216 042737 100000 001226
 3970 021224 005327
 3971 021226 000010
 3972 021230 003027
 3973 021232 012737
 3974 021234 000010
 3975 021236 021226
 3976 021240 104401 021246
 3977 021244 000407
 3978
 3979 021264
 3980 021264 104401 021314
 3981 021270 013700 000042
 3982 021274 001405
 3983 021276 000005
 3984 021300 004710

```

JSR RO, @CALL.A ;GO EXECUTE THE COMMAND
JSR RO, STALL ;STALL
;WORD STALL3 ;ADDRESS OF STALL VALUE
EXIT22: SCOPE ;LOOP ?

.SBTTL END OF PASS ROUTINE

;*****
;INCREMENT THE PASS NUMBER ($PASS)
;INDICATE END-OF-PROGRAM AFTER 8. PASSES THRU THE PROGRAM
;IF THERE'S A MONITOR GO TO IT
;IF THERE ISN'T JUMP TO RESTART

SEOP:
  TYPE 65$ ;TYPE ASCIZ STRING
  BR 64$ ;GET OVER THE ASCIZ
64$: .ASCIZ <CR><LF><LF>/END OF PASS/

  TST @DRVSEL ;ANY DRIVES SELECTED?
  BEQ 1$ ;NO--BRANCH
  TYPE 67$ ;TYPE ASCIZ STRING
  BR 66$ ;GET OVER THE ASCIZ
67$: .ASCIZ / ON DRIVE/

66$: MOV @CHKDRV, -(SP) ;SAVE @CHKDRV FOR TYPEOUT
  TYPOS ;GO TYPE--OCTAL ASCII
  .BYTE 2 ;TYPE 2 DIGIT(S)
  .BYTE 0 ;SUPPRESS LEADING ZEROS
  TYPE 69$ ;TYPE ASCIZ STRING
  BR 68$ ;GET OVER THE ASCIZ
69$: .ASCIZ / ERRORS DETECTED=/

68$: MOV @SERTTL, -(SP) ;SAVE @SERTTL FOR TYPEOUT
  TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
  CLR @SERTTL ;ZERO ERROR TOTAL
  CLR $STNM ;ZERO THE TEST NUMBER
  CLR $TIMES ;ZERO THE NUMBER OF ITERATIONS
  INC $PASS ;INCREMENT THE PASS NUMBER
  BIC #10000, $PASS ;DON'T ALLOW A NEG. NUMBER
  DEC (PC)+ ;LOOP?

SEOPCT: .WORD 8.
  BGT $DOAGN ;YES
  MOV (PC)+, @ (PC)+ ;RESTORE COUNTER

SENDCT: .WORD 8.
  SEOPCT
  TYPE 65$ ;TYPE ASCIZ STRING
  BR 64$ ;GET OVER THE ASCIZ
64$: .ASCIZ <CR><LF>/END OF TEST/

$GET42: MOV @42, RO ;TYPE NULL CHARACTER
  BEQ $DOAGN ;GET MONITOR ADDRESS
  RESET ;BRANCH IF NO MONITOR
  JSR PC, (RO) ;CLEAR THE WORLD
  ;GO TO MONITOR

```



```

3993
3994 .SBTTL *** SYSMAC SUBROUTINES ***
3995
3996 .SBTTL APT COMMUNICATIONS ROUTINE
3997
3998 ..*****
3999 021320 112737 000001 021564 $ATY1: MOVB #1,$FFLG ;; TO REPORT FATAL ERROR
4000 021326 112737 000001 021562 $ATY3: MOVB #1,$MFLG ;; TO TYPE A MESSAGE
4001 021334 000403 BR $ATYC
4002 021336 112737 000001 021564 $ATY4: MOVB #1,$FFLG ;; TO ONLY REPORT FATAL ERROR
4003 021344 $ATYC:
4004 021344 010046 MOV RO,-(SP) ;; PUSH RO ON STACK
4005 021346 010146 MOV R1,-(SP) ;; PUSH R1 ON STACK
4006 021350 105737 021562 TSTB $MFLG ;; SHOULD TYPE A MESSAGE?
4007 021354 001450 BEQ $S IF NOT: BR
4008 021356 122737 000001 001240 CMPB $APTENV,$ENV ;; OPERATING UNDER APT?
4009 021364 001031 BNE $S IF NOT: BR
4010 021366 132737 000100 001241 BITB $APTPOOL,$ENVM ;; SHOULD SPOOL MESSAGES?
4011 021374 001425 BEQ $S IF NOT: BR
4012 021376 017600 MOV #4(SP),RO ;; GET MESSAGE ADDR.
4013 021402 062766 000002 000004 ADD #2,4(SP) ;; BUMP RETURN ADDR.
4014 021410 005737 001220 1$: TST $MSGTYPE ;; SEE IF DONE W/ LAST XMISSION?
4015 021414 001375 BNE 1$ IF NOT: WAIT
4016 021416 010037 001234 MOV RO,$MSGAD ;; PUT ADDR IN MAILBOX
4017 021422 105720 2$: TSTB (RO)+ ;; FIND END OF MESSAGE
4018 021424 001376 BNE 2$
4019 021426 163700 001234 SUB $MSGAD,RO ;; SUB START OF MESSAGE
4020 021432 006200 ASR RO ;; GET MESSAGE LNTH IN WORDS
4021 021434 010037 001236 MOV RO,$MSGGLT ;; PUT LENGTH IN MAILBOX
4022 021440 012737 000004 001220 MOV #4,$MSGTYPE ;; TELL APT TO TAKE MSG.
4023 021446 000413 BR $S
4024 021450 017637 000004 021474 3$: MOV #4(SP),4$ ;; PUT MSG ADDR IN JSR LINKAGE
4025 021456 062766 000002 000004 ADD #2,4(SP) ;; BUMP RETURN ADDRESS
4026 021464 013746 177776 MOV 177776,-(SP) ;; PUSH 177776 ON STACK
4027 021470 004737 022422 JSR PC,$TYPE ;; CALL TYPE MACRO
4028 021474 000000 4$: .WORD 0
4029 021476 5$:
4030 021476 105737 021564 10$: TSTB $FFLG ;; SHOULD REPORT FATAL ERROR?
4031 021502 001416 BEQ 12$ IF NOT: BR
4032 021504 005737 001240 TST $ENV ;; RUNNING UNDER APT?
4033 021510 001413 BEQ 12$ IF NOT: BR
4034 021512 005737 001220 11$: TST $MSGTYPE ;; FINISHED LAST MESSAGE?
4035 021516 001375 BNE 11$ IF NOT: WAIT
4036 021520 017637 000004 001222 MOV #4(SP),$FATAL ;; GET ERROR #
4037 021526 062766 000002 000004 ADD #2,4(SP) ;; BUMP RETURN ADDR.
4038 021534 005237 001220 INC $MSGTYPE ;; TELL APT TO TAKE ERROR
4039 021540 105037 021564 12$: CLRB $FFLG ;; CLEAR FATAL FLAG
4040 021544 105037 021563 CLRB $LFLG ;; CLEAR LOG FLAG
4041 021550 105037 021562 CLRB $MFLG ;; CLEAR MESSAGE FLAG
4042 021554 012601 MOV (SP)+,R1 ;; POP STACK INTO R1
4043 021556 012600 MOV (SP)+,RO ;; POP STACK INTO RO
4044 021560 000207 RTS PC ;; RETURN
4045 021562 000 $MFLG: .BYTE 0 ;; MESSG. FLAG
4046 021563 000 $LFLG: .BYTE 0 ;; LOG FLAG
4047 021564 000 $FFLG: .BYTE 0 ;; FATAL FLAG
4048 021566 .EVEN

```

```

4049          000200          APTSIZE=200
4050          000001          APTENV=001
4051          000100          APTSPOOL=100
4052          000040          APTCSUP=040
4053          .SBTTL  ERROR HANDLER ROUTINE
4054
4055          ;*****
4056          ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
4057          ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
4058          ;*AND GO TO TYPERR ON ERROR
4059          ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4060          ;*SW15=1          HALT ON ERROR
4061          ;*SW13=1          INHIBIT ERROR TYPEOUTS
4062          ;*SW10=1          BELL ON ERROR
4063          ;*SW09=1          LOOP ON ERROR
4064          ;*CALL
4065          ;*          ERROR      N          ;;ERROR=EMT AND N=ERROR ITEM NUMBER
4066
4067          021566          $ERROR:
4068          021566          104407          CKSWR
4069          021570          032777          000400          157342          BIT          #SW08,@SWR          ;;TEST FOR CHANGE IN SOFT-SWR
4070          021576          001411          BEQ          7$          SEND ERROR MESSAGE TO TTY?
4071          021600          005737          001310          TST          @LPTAVL          YES--BRANCH
4072          021604          001406          BEQ          7$          IS THERE A LINE PRINTER AVAILABLE?
4073          021606          013737          001502          001150          MOV          @LPS,@STPS          NO--BRANCH
4074          021614          013737          001504          001152          MOV          @LPB,@STPB          YES--SETUP STATUS
4075          021622          105237          001103          7$:          INCB          $ERFLG          AND BUFFER REG.'S FOR LINE PRINTER
4076          021626          001775          BEQ          7$          SET THE ERROR FLAG
4077          021630          013777          001102          157304          MOV          $STNM,@DISPLAY          DON'T LET THE FLAG GO TO ZERO
4078          021636          032777          002000          157274          BIT          #BIT10,@SWR          DISPLAY TEST NUMBER AND ERROR FLAG
4079          021644          001402          BEQ          1$          BELL ON ERROR?
4080          021646          104401          001210          TYPE          $BELL          NO - SKIP
4081          021652          005237          001112          1$:          INC          $ERTTL          RING BELL
4082          021656          011637          001116          MOV          (SP),$ERRPC          COUNT THE NUMBER OF ERRORS
4083          021662          162737          000002          001116          SUB          #2,$ERRPC          GET ADDRESS OF ERROR INSTRUCTION
4084          021670          117737          157222          001114          MOV          @ERRPC,$ITEMB          STRIP AND SAVE THE ERROR ITEM CODE
4085          021676          032777          020000          157234          BIT          #BIT13,@SWR          SKIP TYPEOUT IF SET
4086          021704          001004          BNE          20$          SKIP TYPEOUTS
4087          021706          004737          022034          JSR          PC,TYPERR          GO TO USER ERROR ROUTINE
4088          021712          104401          001215          TYPE          ,SCLF
4089          021716          122737          000001          001240          20$:          CMPB          #APTENV,$ENV          RUNNING IN APT MODE
4090          021724          001007          2$:          BNE          $ITEMB,21$          NO SKIP APT ERROR REPORT
4091          021726          113737          001114          021740          MOV          $ITEMB,21$          SET ITEM NUMBER AS ERROR NUMBER
4092          021734          004737          021336          JSR          PC,$ATY4          REPORT FATAL ERROR TO APT
4093          021740          000          21$:          .BYTE          0
4094          021741          000          .BYTE          0
4095          021742          000777          22$:          BR          22$
4096          021744          005777          157170          2$:          TST          @SWR          APT ERROR LOOP
4097          021750          100002          BPL          3$          HALT ON ERROR
4098          021752          000000          HALT          SKIP IF CONTINUE
4099          021754          104407          CKSWR          HALT ON ERROR!
4100          021756          032777          001000          157154          3$:          BIT          #BIT09,@SWR          TEST FOR CHANGE IN SOFT-SWR
4101          021764          001402          BEQ          4$          LOOP ON ERROR SWITCH SET?
4102          021766          013716          001110          MOV          $LPERR,(SP)          BR IF NO
4103          021772          005737          001206          4$:          TST          $ESCAPE          FUDGE RETURN FOR LOOPING
4104          ;*          ERROR      N          ;;ERROR=EMT AND N=ERROR ITEM NUMBER

```

```

4105 021776 001402          BEQ      5$          ;;BR IF NONE
4106 022000 013716 001206    MOV      $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
4107 022004          5$:          CMP      #SENDAD,#42  ;;ACT-11 AUTO-ACCEPT?
4108 022004 022737 021300 000042 BNE      6$          ;;BRANCH IF NO
4109 022012 001001          HALT     6$          ;;YES
4110 022014 000000          6$:          MOV      @#TPS,@#STPS  ;;SET STATUS AND BUFFER REG.'S
4111 022016          MOV      @#TPB,@#STPB ;;FOR TTY
4112 022016 013737 001476 001150 RTI      6$          ;;RETURN FROM ERROR CALL
4113 022024 013737 001500 001152
4114 022032 000002
4115
4116 ;:*****
4117 ;SBTTL  TYPERR - TYPE ERROR ROUTINE
4118 ;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE
4119 ;WHICH ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR
4120 ;TABLE" ($ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
4121 ;CONCERNING THE ERROR.
4122 ;CALL
4123 ;
4124 ;      JSR      PC,@#TYPERR
4125 ;
4126 022034 113737 001102 001176 TYPERR: MOVB    @#STSTNM,@#STMPO ;SAVE THE TEST NUMBER
4127 022042 104412          SAVREG  ;SAVE R0 - R5
4128 022044 162700 000004          SUB     #4,R0        ;FORM TEST PC
4129 022050 010037 001162          MOV    R0,@#$REG0  ;COPY R0-R5 IN $REG0-$REG5
4130 022054 010137 001164          MOV    R1,@#$REG1
4131 022060 010237 001166          MOV    R2,@#$REG2
4132 022064 010337 001170          MOV    R3,@#$REG3
4133 022070 010437 001172          MOV    R4,@#$REG4
4134 022074 010537 001174          MOV    R5,@#$REG5
4135 022100 113700 001114          MOVB   @#$ITEMB,R0  ;PICKUP ERROR ITEM NUMBER
4136 022104 010001          MOV    R0,R1        ;AND COPY IT INTO R1
4137 022106 005300          DEC    R0           ;FORM INDEX FOR ERROR TABLE
4138 022110 106300          ASLB  R0
4139 022112 106300          ASLB  R0
4140 022114 106300          ASLB  R0
4141 022116 103002          BCC   1$           ;IS ERROR > 37?
4142 022120 062700 000240          ADD   #ITEM41-$ERRTB,R0 ;YES--FORM OFFSET
4143 022124 062700 004410          ADD   $ERRTB,R0      ;FORM ADDRESS
4144 022130 012037 022144          MOV   (R0)+,2$      ;GET ERROR MESSAGE (EM) POINTER
4145 022134 001447          BEQ   7$           ;BRANCH IF THERE ISN'T ONE
4146 022136 104401 001215          TYPE ,SCLF        ;"CARRIAGE RETURN - LINE FEED"
4147 022142 104401          TYPE
4148 022144 000000          2$:          .WORD 0           ;"EM" POINTER GOES HERE
4149 022146 162701 000041          SUB   #41,R1        ;SPECIAL ERROR ITEM NUMBER?
4150 022152 100440          BMI  7$           ;NO--BRANCH
4151 022154 013701 001340          MOV   @#SVSTAT,R1   ;GET STATUS/ERROR INDICATOR
4152 022160 106301          ASLB R1           ;STRIP "DONE" BIT (BIT07)
4153 022162 006301          ASL  R1           ;STRIP "ERROR" BIT (BIT15)
4154 022164 012702 004356          MOV   #STATBL,R2    ;1ST ADDRESS ON STATUS MESSAGE POINTERS
4155 022170 0J5003          CLR  R3           ;CARRIAGE RETURN-LINE FEED SWITCH
4156 022172 104401 022200          TYPE ,65$        ;;TYPE ASCIZ STRING
4157 022176 000402          BR   64$         ;;GET OVER THE ASCIZ
4158
4159 022204          64$:          .ASCIZ /
4160 022204 012237 022226          3$:          MOV   (R2)+,5$      ;MESSAGE POINTER

```


4161	022210	006301		ASL	R1		:TYPE THIS MESSAGE?
4162	022212	103013		BCC	65		:NO--BRANCH
4163	022214	005103		COM	R3		:YES--TYPE A "CR" & "LF"?
4164	022216	001002		BNE	45		:NO--BRANCH
4165	022220	104401	001215	TYPE	,SCLF		:YES
4166	022224	104401		45:	TYPE		
4167	022226	000000		55:	.WORD	0	:MESSAGE POINTER GOES HERE
4168	022230	005701		TST	R1		:MORE TO TYPE?
4169	022232	001403		SEQ	65		:NO--BRANCH
4170	022234	104401	046141	TYPE	,MSG.SP		:YES--SPACES
4171	022240	000761		BR	35		:LOOP
4172	022242	001360		65:	BNE	35	:BRANCH IF NOT FINISHED
4173	022244	104401	022252	TYPE	,675		:TYPE ASCIZ STRING
4174	022250	000401		BR	665		:GET OVER THE ASCIZ
4175				675:	.ASCIZ	/	
4176	022254			665:			
4177	022254	012037	022270	75:	MOV	(R0)+,85	:PICK UP DATA HEADER (DH) POINTER
4178	022260	001404		BEG	95		:BRANCH IF NONE
4179	022262	104401	001215	TYPE	,SCLF		:CARRIAGE RETURN-LINE FEED
4180	022266	104401		TYPE			
4181	022270	000000		85:	.WORD	0	: "DH" POINTER GOES HERE
4182	022272	012001		95:	MOV	(R0)+,R1	:PICKUP DATA TABLE (DT) POINTER
4183	022274	001450		BEG	205		:BRANCH IF NONE
4184	022276	005005		CLR	R5		:SET INDENT SWITCH
4185	022300	012000		MOV	(R0)+,R0		:DATA FORMAT (DF) POINTER
4186	022302	012002		MOV	(R0)+,R2		:NUMBER OF DH'S TO TYPE
4187	022304	001441		BEG	175		:BRANCH IF DH NUMBER IS 0
4188	022306	005105		COM	R5		:NO INDENT
4189	022310	104401	001215	TYPE	,SCLF		:CARRIAGE RETURN-LINE FEED
4190	022314	112003		105:	MOVB	(R0)+,R3	:NUMBER OF DATA WORDS TO TYPE
4191	022316	112004		MOVB	(R0)+,R4		:AND HOW TO TYPE THEM
4192	022320	006004		115:	ROR	R4	:OCTAL OR DECIMAL?
4193	022322	103403		BCS	125		:DECIMAL--BRANCH
4194	022324	013146		MOV	2(R1)+,-(SP)		:SAVE 2(R1)+ FOR TYPEOUT
4195	022326	104402		TYPOC			:GO TYPE--OCTAL ASCII(ALL DIGITS,
4196	022330	000402		BR	135		
4197	022332			125:			
4198	022332	013146		MOV	2(R1)+,-(SP)		:SAVE 2(R1)+ FOR TYPEOUT
4199	022334	104405		TYPDS			:GO TYPE--DECIMAL ASCII WITH SIGN
4200	022336	005303		135:	DEC	R3	:MORE NUMBERS TO TYPE?
4201	022340	001403		BEG	145		:NO--BRANCH
4202	022342	104401	046141	TYPE	,MSG.SP		:YES--TYPE SEPERATORS
4203	022346	000764		BR	115		:LOOP
4204	022350	005302		145:	DEC	R2	:MORE DH'S?
4205	022352	003421		BLE	205		:NO--BRANCH
4206	022354	104401	001215	TYPE	,SCLF		:YES--START A NEW LINE
4207	022360	005105		COM	R5		:INDENT?
4208	022362	001002		BNE	155		:NO--BRANCH
4209	022364	104401	046141	TYPE	,MSG.SP		:YES--TYPE SPACES
4210	022370	012037	022376	155:	MOV	(R0)+,165	:GET NEXT DH
4211	022374	104401		TYPE			:AND TYPE IT
4212	022376	000000		165:	.WORD	0	:DH POINTER GOES HERE
4213	022400	104401	001215	TYPE	,SCLF		:CARRIAGE RETURN-LINE FEED
4214	022404	005705		TST	R5		:INDENT?
4215	022406	001342		BNE	105		:NO--BRANCH
4216	022410	104401	046141	175:	TYPE	,MSG.SP	:YES--TYPE SPACES

```

022414 000737
022416 104413
022420 000207
BR 10$ ;LOOP
RESREG ;RESTORE R0 - R5
RTS PC ;RETURN

.SBTTL TYPE ROUTINE
*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
*
*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;; MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR
*
$TYPE: TSTB $TPFLG ;; IS THERE A TERMINAL?
BPL 1$ ; BR IF YES
HALT ; HALT HERE IF NO TERMINAL
BR 3$ ; LEAVE
1$: MOV RO, -(SP) ; SAVE RO
MOV @2(SP), RO ; GET ADDRESS OF ASCIZ STRING
CMPB #APTENV, $ENV ; RUNNING IN APT MODE
BNE 62$ ; NO, GO CHECK FOR APT CONSOLE
BITB #APTSPOOL, $ENV ; SPOOL MESSAGE TO APT
BEQ 62$ ; NO, GO CHECK FOR CONSOLE
MOV RO, 61$ ; SETUP MESSAGE ADDRESS FOR APT
JSR PC, $ATY3 ; SPOOL MESSAGE TO APT
0 ; MESSAGE ADDRESS
61$: BITB #APTCSUP, $ENV ; APT CONSOLE SUPPRESSED
BNE 60$ ; YES, SKIP TYPE OUT
2$: MOVB (RO)+, -(SP) ; PUSH CHARACTER TO BE TYPED ONTO STACK
BNE 4$ ; BR IF IT ISN'T THE TERMINATOR
TST (SP)+ ; IF TERMINATOR POP IT OFF THE STACK
60$: MOV (SP)+, RO ; RESTORE RO
3$: ADD #2, (SP) ; ADJUST RETURN PC
RTI ; RETURN
4$: CMPB #HT, (SP) ; BRANCH IF <HT>
BEQ 8$
CMPB #CRLF, (SP) ; BRANCH IF NOT <CRLF>
BNE 5$
TST (SP)+ ; POP <CR><LF> EQUIV
TYPE ; TYPE A CR AND LF
5$: CLRB $CRLF ; CLEAR CHARACTER COUNT
BR 2$ ; GET NEXT CHARACTER
6$: JSR PC, $TYPEC ; GO TYPE THIS CHARACTER
CMPB $FILLC, (SP)+ ; IS IT TIME FOR FILLER CHARS.?
BNE 2$ ; IF NO GO GET NEXT CHAR.
MOV $NULL, -(SP) ; GET # OF FILLER CHARS. NEEDED
; AND THE NULL CHAR.

```

```

4273 022570 105366 000001 7$: DEC B 1(SP) ;: DOES A NULL NEED TO BE TYPED?
4274 022574 002770 ;: BLT 6$ ;: BR IF NO--GO POP THE NULL OFF OF STACK
4275 022576 004737 022634 ;: JSR PC,$TYPEC ;: GO TYPE A NULL
4276 022602 105337 022700 ;: DEC B $CHARCNT ;: DO NOT COUNT AS A COUNT
4277 022606 000770 ;: BR 7$ ;: LOOP

```

;HORIZONTAL TAB PROCESSOR

```

4281 022610 112716 000040 8$: MOV B #' (SP) ;: REPLACE TAB WITH SPACE
4282 022614 004737 022634 9$: JSR PC,$TYPEC ;: TYPE A SPACE
4283 022620 132737 000007 022700 ;: BIT B #7,$CHARCNT ;: BRANCH IF NOT AT
4284 022626 001372 ;: BNE 9$ ;: TAB STOP
4285 022630 005726 ;: TST (SP)+ ;: POP SPACE OFF STACK
4286 022632 000724 ;: BR 2$ ;: GET NEXT CHARACTER
4287 022634 105777 156310 $TYPEC: TST B 2$TPS ;: WAIT UNTIL PRINTER IS READY
4288 022640 100375 ;: BPL $TYPEC
4289 022642 116677 000002 156302 ;: MOV B 2(SP),2$TPB ;: LOAD CHAR TO BE TYPED INTO DATA REG.
4290 022650 122766 000015 000002 ;: CMP B #CR,2(SP) ;: IS CHARACTER A CARRIAGE RETURN?
4291 022656 001003 ;: BNE 1$ ;: BRANCH IF NO
4292 022660 105037 022700 ;: CLRB $CHARCNT ;: YES--CLEAR CHARACTER COUNT
4293 022664 000406 ;: BR $TYPEX ;: EXIT
4294 022666 122766 000012 000002 1$: CMP B #LF,2(SP) ;: IS CHARACTER A LINE FEED?
4295 022674 001402 ;: BEQ $TYPEX ;: BRANCH IF YES
4296 022676 105227 ;: INCB (PC)+ ;: COUNT THE CHARACTER
4297 022700 000000 ;: $CHARCNT: .WORD 0 ;: CHARACTER COUNT STORAGE
4298 022702 000207 ;: $TYPEX: RTS PC

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

4300 ;: *****
4301 ;: *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
4302 ;: *OCTAL (ASCII) NUMBER AND TYPE IT.
4303 ;: *$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
4304 ;: *CALL:
4305 ;: * MOV NUM,-(SP) ;: NUMBER TO BE TYPED
4306 ;: * TYPOS ;: CALL FOR TYPEOUT
4307 ;: * .BYTE N ;: N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
4308 ;: * .BYTE M ;: M=1 OR 0
4309 ;: * ;: ;: 1=TYPE LEADING ZEROS
4310 ;: * ;: ;: 0=SUPPRESS LEADING ZEROS
4311 ;: *
4312 ;: *$STYPO---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
4313 ;: *$TYPOS OR $TYPOC
4314 ;: *CALL:
4315 ;: * MOV NUM,-(SP) ;: NUMBER TO BE TYPED
4316 ;: * TYPON ;: CALL FOR TYPEOUT
4317 ;: *
4318 ;: *$STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
4319 ;: *CALL:
4320 ;: * MOV NUM,-(SP) ;: NUMBER TO BE TYPED
4321 ;: * TYPOC ;: CALL FOR TYPEOUT
4322 ;: *
4323 ;: *
4324 ;: *
4325 ;: *
4326 022704 017646 000000 $TYPOS: MOV 2(SP),-(SP) ;: PICKUP THE MODE
4327 022710 116637 000001 023127 ;: MOV B 1(SP),$OFILL ;: LOAD ZERO FILL SWITCH
4328 022716 112637 023131 ;: MOV B (SP)+,$SOMODE+1 ;: NUMBER OF DIGITS TO TYPE

```

```

4329 022722 062716 000002          ADD      #2,(SP)          ;;ADJUST RETURN ADDRESS
4330 022726 000406          BR       $TYPON
4331 022730 112737 000001 023127 $TYPON: MOVB   #1,$OFILL          ;;SET THE ZERO FILL SWITCH
4332 022736 112737 000006 023131 MOVB   #6,$SOMODE+1      ;;SET FOR SIX(6) DIGITS
4333 022744 112737 000005 023126 $TYPON: MOVB   #5,$SOCNT          ;;SET THE ITERATION COUNT
4334 022752 010346          MOV     R3,-(SP)        ;;SAVE R3
4335 022754 010446          MOV     R4,-(SP)        ;;SAVE R4
4336 022756 010546          MOV     R5,-(SP)        ;;SAVE R5
4337 022760 113704 023131 MOVB   $SOMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
4338 022764 005404          NEG     R4
4339 022766 062704 000006          ADD     #6,R4           ;;SUBTRACT IT FOR MAX. ALLOWED
4340 022772 110437 023130 MOVB   R4,$SOMODE        ;;SAVE IT FOR USE
4341 022776 113704 023127 MOVB   $OFILL,R4         ;;GET THE ZERO FILL SWITCH
4342 023002 016605 000012 MOV     12(SP),R5        ;;PICKUP THE INPUT NUMBER
4343 023006 005003          CLR     R3             ;;CLEAR THE OUTPUT WORD
4344 023010 006105          1$:    ROL     R5         ;;ROTATE MSB INTO "C"
4345 023012 000404          BR      3$
4346 023014 006105          2$:    ROL     R5         ;;FORM THIS DIGIT
4347 023016 006105          ROL     R5
4348 023020 006105          ROL     R5
4349 023022 010503          MOV     R5,R3
4350 023024 006103          3$:    ROL     R3         ;;GET LSB OF THIS DIGIT
4351 023026 105337 023130 DECB   $SOMODE          ;;TYPE THIS DIGIT?
4352 023032 100016          BPL     #7$            ;;BR IF NO
4353 023034 042703 177770 BIC     #177770,R3      ;;GET RID OF JUNK
4354 023040 001002          BNE     #4$            ;;TEST FOR 0
4355 023042 005704          TST     R4             ;;SUPPRESS THIS 0?
4356 023044 001403          BEQ     #5$            ;;BR IF YES
4357 023046 005204          4$:    INC     R4         ;;DON'T SUPPRESS ANYMORE 0'S
4358 023050 052703 000060          BIS     #'0,R3        ;;MAKE THIS DIGIT ASCII
4359 023054 052703 000040          5$:    BIS     #' ,R3        ;;MAKE ASCII IF NOT ALREADY
4360 023060 110337 023124 MOVB   R3,#8$          ;;SAVE FOR TYPING
4361 023064 104401 023124 TYPE   #8$            ;;GO TYPE THIS DIGIT
4362 023070 105337 023126          7$:    DECB   $SOCNT          ;;COUNT BY 1
4363 023074 003347          BGT     #2$            ;;BR IF MORE TO DO
4364 023076 002402          BLT     #6$            ;;BR IF DONE
4365 023100 005204          INC     R4             ;;INSURE LAST DIGIT ISN'T A BLANK
4366 023102 000744          BR      2$            ;;GO DO THE LAST DIGIT
4367 023104 012605          6$:    MOV     (SP)+,R5      ;;RESTORE R5
4368 023106 012604          MOV     (SP)+,R4        ;;RESTORE R4
4369 023110 012603          MOV     (SP)+,R3        ;;RESTORE R3
4370 023112 016666 000002 000004 MOV     2(SP),4(SP)     ;;SET THE STACK FOR RETURNING
4371 023120 012616          MOV     (SP)+,(SP)
4372 023122 000002          RTI
4373 023124          8$:    .BYTE 0           ;;RETURN
4374 023125          .BYTE 0           ;;STORAGE FOR ASCII DIGIT
4375 023126          .BYTE 0           ;;TERMINATOR FOR TYPE ROUTINE
4376 023127          .BYTE 0           ;;OCTAL DIGIT COUNTER
4377 023130 000000          .WORD 0           ;;ZERO FILL SWITCH
4378          .WORD 0           ;;NUMBER OF DIGITS TO TYPE
4379          .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
4380
4381 *****
4382 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
4383 ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
4384 ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED

```

```

4385 ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
4386 ;*REPLACED WITH SPACES.
4387 ;*CALL:
4388 ;*      MOV      NUM,-(SP)      ;:PUT THE BINARY NUMBER ON THE STACK
4389 ;*      TYPDS                    ;:GO TO THE ROUTINE
4390
4391 $TYPDS:
4392      MOV      R0,-(SP)      ;:PUSH R0 ON STACK
4393      MOV      R1,-(SP)      ;:PUSH R1 ON STACK
4394      MOV      R2,-(SP)      ;:PUSH R2 ON STACK
4395      MOV      R3,-(SP)      ;:PUSH R3 ON STACK
4396      MOV      R5,-(SP)      ;:PUSH R5 ON STACK
4397      MOV      #20200,-(SP) ;:SET BLANK SWITCH AND SIGN
4398      MOV      20(SP),R5    ;:GET THE INPUT NUMBER
4399      BPL      1$          ;:BR IF INPUT IS POS.
4400      NEG      R5          ;:MAKE THE BINARY NUMBER POS.
4401      MOVB    #'-',1(SP)   ;:MAKE THE ASCII NUMBER NEG.
4402      CLR      R0          ;:ZERO THE CONSTANTS INDEX
4403      MOV      #SDBLK,R3    ;:SETUP THE OUTPUT POINTER
4404      MOVB    #'',(R3)+    ;:SET THE FIRST CHARACTER TO A BLANK
4405      CLR      R2          ;:CLEAR THE BCD NUMBER
4406      MOV      $DTBL(R0),R1 ;:GET THE CONSTANT
4407      SUB      R1,R5       ;:FORM THIS BCD DIGIT
4408      BLT     4$          ;:BR IF DONE
4409      INC     R2          ;:INCREASE THE BCD DIGIT BY 1
4410      BR     3$
4411      ADD     R1,R5       ;:ADD BACK THE CONSTANT
4412      TST     R2          ;:CHECK IF BCD DIGIT=0
4413      BNE     5$          ;:FALL THROUGH IF 0
4414      TSTB   (SP)         ;:STILL DOING LEADING 0'S?
4415      BMI     7$          ;:BR IF YES
4416      ASLB   (SP)         ;:MSD?
4417      BCC     6$          ;:BR IF NO
4418      MOVB   1(SP),-1(R3) ;:YES--SET THE SIGN
4419      BIS    #'0,R2        ;:MAKE THE BCD DIGIT ASCII
4420      BIS    #' ,R2        ;:MAKE IT A SPACE IF NOT ALREADY A DIGIT
4421      MOVB   R2,(R3)+     ;:PUT THIS CHARACTER IN THE OUTPUT BUFFER
4422      TST    (R0)+        ;:JUST INCREMENTING
4423      CMP    R0,#10       ;:CHECK THE TABLE INDEX
4424      BLT    2$          ;:GO DO THE NEXT DIGIT
4425      BGT    8$          ;:GO TO EXIT
4426      MOV    R5,R2        ;:GET THE LSD
4427      BR     6$          ;:GO CHANGE TO ASCII
4428      TSTB   (SP)+        ;:WAS THE LSD THE FIRST NON-ZERO?
4429      BPL    9$          ;:BR IF NO
4430      MOVB   -1(SP),-2(R3) ;:YES--SET THE SIGN FOR TYPING
4431      CLRB   (R3)         ;:SET THE TERMINATOR
4432      MOV    (SP)+,R5     ;:POP STACK INTO R5
4433      MOV    (SP)+,R3     ;:POP STACK INTO R3
4434      MOV    (SP)+,R2     ;:POP STACK INTO R2
4435      MOV    (SP)+,R1     ;:POP STACK INTO R1
4436      MOV    (SP)+,R0     ;:POP STACK INTO R0
4437      TYPE   $SDBLK      ;:NOW TYPE THE NUMBER
4438      MOV    2(SP),4(SP)  ;:ADJUST THE STACK
4439      MOV    (SP)+,(SP)
4440      RTI
;:RETURN TO USER

```

```

4441 023336 023420
4442 023340 001750
4443 023342 000144
4444 023344 000012
4445 023346 000004
4446
4447
4448
4449
4450
4451 023356 000000
4452 023360 000000
4453 023362 000000
4454 023364 000002
4455 023366
4456
4457
4458
4459
4460
4461
4462
4463
4464
4465 023366 005037 023356
4466 023372 012737 023364 023360
4467 023400 013737 023360 023362
4468 023406 012737 023436 000060
4469 023414 012737 000200 000062
4470 023422 005777 155520
4471 023426 012777 000100 155510
4472 023434 000207
4473
4474
4475
4476
4477
4478
4479
4480
4481 023436 117746 155504
4482 023442 042716 177600
4483 023446 021627 000003
4484 023452 001007
4485 023454 104401 024566
4486 023460 004737 023366
4487 023464 005726
4488 023466 000137 004762
4489 023472 021627 000007
4490 023476 001004
4491 023500 022737 000176 001140
4492 023506 001500
4493
4494 023510
4495 023510 022737 000002 023356
4496 023516 001004

```

```

SDTB: 10000.
      1000.
      100.
      10.
      1.
SDBLK: .BLKW 4
.SBTTL TTY INPUT ROUTINE
*****
. ENABL LSB
$TKCNT: .WORD 0 ;; NUMBER OF ITEMS IN QUEUE
$TKQIN: .WORD 0 ;; INPUT POINTER
$TKQOUT: .WORD 0 ;; OUTPUT POINTER
$TKQSRT: .BLKB 2 ;; TTY KEYBOARD QUEUE
$TKQEND=.

;*TK INITIALIZE ROUTINE
;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
:
*CALL:
* JSR PC,$TKINT
* RETURN
$TKINT: CLR $TKCNT ;; CLEAR COUNT OF ITEMS IN QUEUE
      MOV $TKQSRT,$TKQIN ;; MOVE THE STARTING ADDRESS OF THE
      MOV $TKQIN,$TKQOUT ;; QUEUE INTO THE INPUT & OUTPUT POINTERS.
      MOV $TKSRV,$TKVEC ;; INITIALIZE THE KEYBOARD VECTOR
      MOV #200,$TKVEC+2 ;; "BR" LEVEL 4
      TST $TKB ;; CLEAR DONE FLAG
      MOV #100,$TKS ;; ENABLE TTY KEYBOARD INTERRUPT
      RTS PC ;; RETURN TO CALLER

;*TK SERVICE ROUTINE
;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;*IT IN THE QUEUE.
;*IF THE CHARACTER IS A "CONTROL-C" (1C) $TKINT IS CALLED AND
;*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (START2)
$TKSRV: MOVB $TKB,-(SP) ;; PICKUP THE CHARACTER
      BIC #1C177,(SP) ;; STRIP THE JUNK
      CMP (SP),#3 ;; IS IT A CONTROL C?
      BNE 1$ ;; BRANCH IF NO
      TYPE $CNTLC ;; TYPE A CONTROL-C (1C)
      JSR PC,$TKINT ;; INIT THE KEYBOARD
      TST (SP)+ ;; CLEAN UP STACK
      JMP START2 ;; CONTROL C RESTART
1$: CMP (SP),#7 ;; IS IT A CONTROL G?
      BNE 2$ ;; BRANCH IF NO
      CMP #SWREG,SWR ;; IS SOFT-SWR SELECTED?
      BEQ 6$ ;; GO TO SWR CHANGE
2$:
      CMP #2,$TKCNT ;; IS THE QUEUE FULL?
      BNE 3$ ;; BRANCH IF NO

```

```

4497 023520 104401 001210          TYPE      $BELL          ;; RING THE TTY BELL
4498 023524 005726          TST        (SP)+        ;; CLEAN CHARACTER OFF OF STACK
4499 023526 000451          BR         $$           ;; EXIT
4500 023530 021627 000023      3$: CMP      (SP),#23     ;; IS IT A CONTROL-S?
4501 023534 001021          BNE       32$          ;; BRANCH IF NO
4502 023536 005077 155402          CLR      @STKS        ;; DISABLE TTY KEYBOARD INTERRUPTS
4503 023542 005726          TST      (SP)+        ;; CLEAN CHAR OFF STACK
4504 023544 105777 155374      31$: TSTB     @STKS        ;; WAIT FOR A CHAR
4505 023550 100375          BPL      31$          ;; LOOP UNTIL ITS THERE
4506 023552 117746 155370          MOVB    @STKB, -(SP)   ;; GET THE CHARACTER
4507 023556 042716 177600          BIC     #1C177, (SP)  ;; MAKE IT 7-BIT ASCII
4508 023562 022627 000021          CMP     (SP)+, #21    ;; IS IT A CONTROL-Q?
4509 023566 001366          BNE     31$          ;; BRANCH IF NO
4510 023570 012777 000100 155346          MOV     #100, @STKS   ;; REENABLE TTY KEYBOARD INTERRUPTS
4511 023576 000002          RTI                          ;; RETURN
4512 023600 005237 023356      32$: INC     $TKCNT       ;; COUNT THIS CHARACTER
4513 023604 021627 000140          CMP     (SP), #140    ;; IS IT UPPER CASE?
4514 023610 002405          BLT     4$           ;; BRANCH IF YES
4515 023612 021627 000175          CMP     (SP), #175    ;; IS IT A SPECIAL CHAR?
4516 023616 003002          BGT     4$           ;; BRANCH IF YES
4517 023620 042716 000040          BIC     #40, (SP)     ;; MAKE IT UPPER CASE
4518 023624 112677 177530      4$: MOVB    (SP)+, @STKQIN ;; AND PUT IT IN QUE JE
4519 023630 005237 023360          INC     $TKQIN       ;; UPDATE THE POINTER
4520 023634 023727 023360 023366          CMP     $TKQIN, $STKQEND ;; GO OFF THE END?
4521 023642 001003          BNE     $$           ;; BRANCH IF NO
4522 023644 012737 023364 023360          MOV     @STKQSR, $TKQIN ;; RESET THE POINTER
4523 023652 000002      5$: RTI                          ;; RETURN

```

```

4524
4525 *****
4526 *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
4527 *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
4528 *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
4529 *CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

```

4530 023654 022737 000176 001140 $CKSWR: CMP     $SWREG, SWR      ;; IS THE SOFT-SWR SELECTED
4531 023662 001124          BNE     15$          ;; EXIT IF NOT
4532 023664 105777 155254          TSTB   @STKS        ;; IS A CHAR WAITING?
4533 023670 100121          BPL     15$          ;; IF NOT, EXIT
4534 023672 117746 155250          MOVB   @STKB, -(SP)  ;; YES
4535 023676 042716 177600          BIC     #1C177, (SP) ;; MAKE IT 7-BIT ASCII
4536 023702 021627 000007          CMP     (SP), #7     ;; IS IT A CONTROL-G?
4537 023706 001300          BNE     2$           ;; IF NOT, PUT IT IN THE TTY QUEUE
4538                                     ;; AND EXIT

```

```

4539 *****
4540 *CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
4541 *ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
4542 *CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

```

4543
4544 023710 123727 001134 000001 6$: CMPB   $AUTOB, #1    ;; ARE WE RUNNING IN AUTO-MODE?
4545 023716 001674          BEQ     2$           ;; BRANCH IF YES
4546 023720 005726          TST    (SP)+        ;; CLEAR CONTROL-G OFF STACK
4547 023722 004737 023366          JSR    PC, $TKINT   ;; FLUSH THE TTY INPUT QUEUE
4548 023726 005077 155212          CLR    @STKS        ;; DISABLE TTY KEYBOARD INTERRUPTS
4549 023732 112737 000001 001135          MOVB   #1, $INTAG   ;; SET INTERRUPT MODE INDICATOR
4550
4551 023740 104401 024600          TYPE   , $CNTLG     ;; ECHO THE CONTROL-G (↑G)
4552 023744 104401 024605 $GTSWR: TYPE   , $MSWR  ;; TYPE CURRENT CONTENTS

```

4553	023750	013746	000176		MOV	SWREG, -(SP)	:: SAVE SWREG FOR TYPEOU
4554	023754	104402			TYPOC		:: GO TYPE--OCTAL ASCII: ALL DIGITS
4555	023756	104401	024616		TYPE	, SMNEW	:: PROMPT FOR NEW SWR
4556	023762	005046		19\$	CLR	-(SP)	:: CLEAR COUNTER
4557	023764	005046			CLR	-(SP)	:: THE NEW SWR
4558	023766	105777	155152		TSTB	2\$TKS	:: CHAR THERE?
4559	023772	100375			BPL	7\$:: IF NOT TRY AGAIN
4560							
4561	023774	117746	155146		MOVB	2\$TKB, -(SP)	:: PICK UP CHAR
4562	024000	042716	177600		BIC	#177, (SP)	:: MAKE IT 7-BIT ASCII
4563							
4564	024004	021627	000003		CMP	(SP), #3	:: IS IT A CONTROL-C?
4565	024010	001015			BNE	9\$:: BRANCH IF NOT
4566	024012	104401	024566		TYPE	, \$CNTLC	:: YES, ECHO CONTROL-C (↑C)
4567	024016	062706	000006		ADD	#6, SP	:: CLEAN UP STACK
4568	024022	123727	001135	000001	CMPB	\$INTAG, #1	:: REENABLE TTY KEYBOARD INTERRUPTS?
4569	024030	001003			BNE	6\$:: BRANCH IF NO
4570	024032	012777	000100	155104	MOV	#100, 2\$TKS	:: ALLOW TTY KEYBOARD INTERRUPTS
4571	024040	000137	004762		JMF	START2	:: CONTROL-C RESTART
4572				8\$:			
4573							
4574	024044	021627	000025		CMP	(SP), #25	:: IS IT A CONTROL-U?
4575	024050	001005		9\$:	BNE	10\$:: BRANCH IF NOT
4576	024052	104401	024573		TYPE	, \$CNTLU	:: YES, ECHO CONTROL-U (↑U)
4577	024056	062706	000006		ADD	#6, SP	:: IGNORE PREVIOUS INPUT
4578	024062	000737		20\$:	BR	19\$:: LET'S TRY IT AGAIN
4579							
4580							
4581	024064	021627	000015		CMP	(SP), #15	:: IS IT A <CR>?
4582	024070	001022		10\$:	BNE	16\$:: BRANCH IF NO
4583	024072	065766	000004		TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
4584	024076	001403			BEQ	11\$:: BRANCH IF YES
4585	024100	016677	000002	155032	MOV	2(SP), 2\$SWR	:: SAVE NEW SWR
4586	024106	062706	000006		ADD	#6, SP	:: CLEAN UP STACK
4587	024112	104401	001215		TYPE	, \$CR LF	:: ECHO <CR> AND <LF>
4588	024116	123727	001135	000001	CMPB	\$INTAG, #1	:: RE-ENABLE TTY KBD INTERRUPTS?
4589	024124	001003			BNE	15\$:: BRANCH IF NOT
4590	024126	012777	000100	155010	MOV	#100, 2\$TKS	:: RE-ENABLE TTY KBD INTERRUPTS
4591	024134	000002			RTI		:: RETURN
4592	024136	004737	022634		JSR	PC, \$TYPEC	:: ECHO CHAR
4593	024142	021627	000060	16\$:	CMP	(SP), #60	:: CHAR < 0?
4594	024146	002420			BLT	18\$:: BRANCH IF YES
4595	024150	021627	000067		CMP	(SP), #67	:: CHAR > 7?
4596	024154	003015			BGT	18\$:: BRANCH IF YES
4597	024156	042726	000060		BIC	#60, (SP)+	:: STRIP-OFF ASCII
4598	024162	005766	000002		TST	2(SP)	:: IS THIS THE FIRST CHAR
4599	024166	001403			BEQ	17\$:: BRANCH IF YES
4600	024170	006316			ASL	(SP)	:: NO, SHIFT PRESENT
4601	024172	006316			ASL	(SP)	:: CHAR OVER TO MAKE
4602	024174	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
4603	024176	005266	000002	17\$:	INC	2(SP)	:: KEEP COUNT OF CHAR
4604	024202	056616	177776		BIS	-2(SP), (SP)	:: SET IN NEW CHAR
4605	024206	000667			BR	7\$:: GET THE NEXT ONE
4606	024210	104401	001214	18\$:	TYPE	, \$QUES	:: TYPE ?<CR><LF>
4607	024214	000720			BR	20\$:: SIMULATE CONTROL-U
4608					.DSABL	LSB	


```

4609
4610
4611 *****
4612 *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
4613 *CALL:
4614 *      RDCHR          ;; GET A CHARACTER FROM THE QUEUE
4615 *      RETURN HERE   ;; CHARACTER IS ON THE STACK
4616 *                  ;; WITH PARITY BIT STRIPPED OFF
4617
4618
4619 024216 011646          $RDCHR: MOV      (SP), -(SP)      ;; PUSH DOWN THE PC AND
4620 024220 016666 000004 000002      MOV      4(SP), 2(SP)      ;; THE PS
4621 024226 005066 000004          CLR      4(SP)          ;; GET READY FOR A CHARACTER
4622 024232 005046          CLR      -(SP)         ;; PUT NEW PS ON STACK
4623 024234 012746 024242          MOV      #64$, -(SP)      ;; PUT NEW PC ON STACK
4624 024240 000072          RTI          ;; POP NEW PC AND PS
4625 024242
4626 024242 005737 023356          64$:   TST      $STKCNT      ;; WAIT ON A CHARACTER
4627 024246 001775          1$:   BEQ      1$
4628 024250 005337 023356          DEC      $STKCNT      ;; DECREMENT THE COUNTER
4629 024254 117766 177102 000004      MOVB     2$STKQOUT, 4(SP) ;; GET ONE CHARACTER
4630 024262 005237 023362          INC      $STKQOUT     ;; UPDATE THE POINTER
4631 024266 023727 023362 023366      CMP      $STKQOUT, #2$STKQEND ;; DID IT GO OFF OF THE END?
4632 024274 001003          BNE      2$          ;; BRANCH IF NO
4633 024276 012737 023364 023362      MOV      #2$STKQRT, $STKQOUT ;; RESET THE POINTER
4634 024304 000002          RTI          ;; RETURN
4635 *****
4636 *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
4637 *CALL:
4638 *      RDLIN         ;; INPUT A STRING FROM THE TTY
4639 *      RETURN HERE  ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
4640 *                  ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
4641
4642 024306 010346          $RDLIN: MOV      R3, -(SP)      ;; SAVE R3
4643 024310 005046          CLR      -(SP)         ;; CLEAR THE RUBOUT KEY
4644 024312 012703 024542          1$:   MOV      #2$TTYIN, R3    ;; GET ADDRESS
4645 024316 022703 024566          2$:   CMP      #2$TTYIN+20., R3 ;; BUFFER FULL?
4646 024322 101456          BLOS     4$          ;; BR IF YES
4647 024324 104410          RDCHR     ;; GO READ ONE CHARACTER FROM THE TTY
4648 024326 112613          MOVB     (SP)+, (R3)    ;; GET CHARACTER
4649 024330 122713 000177          10$:  CMPB     #177, (R3)    ;; IS IT A RUBOUT
4650 024334 001022          BNE      5$          ;; BR IF NO
4651 024336 005716          TST      (SP)         ;; IS THIS THE FIRST RUBOUT?
4652 024340 001007          BNE      6$          ;; BR IF NO
4653 024342 112737 000134 024540      MOVB     #' \, 9$      ;; TYPE A BACK SLASH
4654 024350 104401 024540          TYPE     9$
4655 024354 012716 177777          MOV      #-1, (SP)    ;; SET THE RUBOUT KEY
4656 024360 005303          6$:   DEC      R3          ;; BACKUP BY ONE
4657 024362 020327 024542          CMP      R3, #2$TTYIN ;; STACK EMPTY?
4658 024366 103434          BLO      4$          ;; BR IF YES
4659 024370 111337 024540          MOVB     (R3), 9$     ;; SETUP TO TYPEOUT THE DELETED CHAR.
4660 024374 104401 024540          TYPE     9$          ;; GO TYPE
4661 024400 000746          BR      2$          ;; GO READ ANOTHER CHAR.
4662 024402 005716          5$:   TST      (SP)         ;; RUBOUT KEY SET?
4663 024404 001406          BEQ      7$          ;; BR IF NO
4664 024406 112737 000134 024540      MOVB     #' \, 9$      ;; TYPE A BACK SLASH

```

```

4665 024414 104401 024540          TYPE          9$
4666 024420 005016          CLR            (SP)
4667 024422 122713 000025 7$: CMPB        #25,(R3)
4668 024426 001003          BNE           8$
4669 024430 104401 024573          TYPE          $CNTLU
4670 024434 000726          BR            1$
4671 024436 122713 000022 8$: CMPB        #22,(R3)
4672 024442 001011          BNE           3$
4673 024444 105013          CLRB         (R3)
4674 024446 104401 001215          TYPE          $CRLF
4675 024452 104401 024542          TYPE          $TTYIN
4676 024456 000717          BR            2$
4677 024460 104401 001214 4$: TYPE          $QUES
4678 024464 000712          BR            1$
4679 024466 111337 024540 3$: MOVB        (R3),9$
4680 024472 104401 024540          TYPE          9$
4681 024476 122723 000015          CMPB        #15,(R3)+
4682 024502 001305          BNE           2$
4683 024504 105063 177777          CLRB        -1(R3)
4684 024510 104401 001216          TYPE          $LF
4685 024514 005726          TST         (SP)+
4686 024516 012603          MOV         (SP)+,R3
4687 024520 011646          MOV         (SP),-(SP)
4688 024522 016666 000004 000002          MOV         4(SP),2(SP)
4689 024530 012766 024542 000004          MOV         #TTYIN,4(SP)
4690 024536 000002          RTI
4691 024540 000          9$: .BYTE      0
4692 024541 000          .BYTE      0
4693 024542 000024          $TTYIN: .BLKB 20.
4694 024566 041536 005015 000          $CNTLC: .ASCIZ /C/<15><12>
4695 024573 136 006525 000012          $CNTLU: .ASCIZ /U/<15><12>
4696 024600 043536 005015 000          $CNTLG: .ASCIZ /G/<15><12>
4697 024605 015 051412 051127          $MSWR: .ASCIZ /15><12>/SWR = /
4698 024612 036440 000040          $MNEW: .ASCIZ / NEW = /
4699 024616 020040 042516 020127
4700 024624 020075 000
4701 024630
4702
4703
4704
4705
4706
4707
4708
4709
4710
4711
4712
4713
4714
4715
4716 024630          $SCOPE:
4717 024630 104407          CKSWR
4718 024632 032777 04000C 154300 1$: BIT        #BIT14,$SWR
4719 024640 001101          BNE          $OVER
4720

```

```

: CLEAR THE RUBOUT KEY
: IS CHARACTER A CTRL U?
: BR IF NO
: TYPE A CONTROL "U"
: GO START OVER
: IS CHARACTER A "r"?
: BRANCH IF NO
: CLEAR THE CHARACTER
: TYPE A "CR" & "LF"
: TYPE THE INPUT STRING
: GO PICKUP ANOTHER CHACTER
: TYPE A '?'
: CLEAR THE BUFFER AND LOOP
: ECHO THE CHARACTER

: CHECK FOR RETURN
: LOOP IF NOT RETURN
: CLEAR RETURN (THE 15)
: TYPE A LINE FEED
: CLEAN RUBOUT KEY FROM THE STACK
: RESTORE R3
: ADJUST THE STACK AND PUT ADDRESS OF THE
: FIRST ASCII CHARACTER ON IT

: RETURN
: STORAGE FOR ASCII CHAR. TO TYPE
: TERMINATOR
: RESERVE 20. BYTES FOR TTY INPUT
: CONTROL "C"
: CONTROL "U"
: CONTROL "G"

```

```

.EVEN
.SBTTL SCOPE HANDLER ROUTINE
: *****
: *THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
: *AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
: *AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
: *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
: *SW14=1 LOOP ON TEST
: *SW11=1 INHIBIT ITERATIONS
: *SW09=1 LOOP ON ERROR
: *CALL SCOPE ;:SCOPE=IGT
$SCOPE:
: *TEST FOR CHANGE IN SOFT-SWR
: *LOOP ON PRESENT TEST?
: *YES IF SW14=1
: *****START OF CODE FOR THE XOR TESTER*****

```

```

4721 024642 000416 $XTSTR: BR 6$ ; IF RUNNING ON THE ">OR" TESTER CHANGE
4722 ; THIS INSTRUCTION TO A "NOP" (NOP=240)
4723 024644 013746 000004 MOV @#ERRVEC, -(SP) ; SAVE THE CONTENTS OF THE ERROR VECTOR
4724 024650 012737 024670 000004 MOV #SS, @#ERRVEC ; SET FOR TIMEOUT
4725 024656 005737 177060 TST @#177060 ; TIME OUT ON XOR?
4726 024662 012637 000004 MOV (SP)+, @#ERRVEC ; RESTORE THE ERROR VECTOR
4727 024666 000450 BR $SVLAD ; GO TO THE NEXT TEST
4728 024670 022626 5$: CMP (SP)+, (SP)+ ; CLEAR THE STACK AFTER A TIME OUT
4729 024672 012637 000004 MOV (SP)+, @#ERRVEC ; RESTORE THE ERROR VECTOR
4730 024676 000413 BR 7$ ; LOOP ON THE PRESENT TEST
4731 024700 6$: ; *****END OF CODE FOR THE XOR TESTER*****
4732 024700 105737 001103 2$: TSTB $ERFLG ; HAS AN ERROR OCCURRED?
4733 024704 001421 BEQ 3$ ; BR IF NO
4734 024706 123737 001115 001103 CMPB $ERMAX, $ERFLG ; MAX. ERRORS FOR THIS TEST OCCURRED?
4735 024714 101015 BHI 3$ ; BR IF NO
4736 024716 032777 001000 154214 BIT #BIT09, @SWR ; LOOP ON ERROR?
4737 024724 001404 BEQ 4$ ; BR IF NO
4738 024726 013737 001110 001106 7$: MOV $LPERR, $LPADR ; SET LOOP ADDRESS TO LAST SCOPE
4739 024734 000443 BR $OVER
4740 024736 105037 001103 4$: CLRB $ERFLG ; ZERO THE ERROR FLAG
4741 024742 005037 001204 CLR $TIMES ; CLEAR THE NUMBER OF ITERATIONS TO MAKE
4742 024746 000412 BR 1$ ; ESCAPE TO THE NEXT TEST
4743 024750 032777 004000 154162 3$: BIT #BIT11, @SWR ; INHIBIT ITERATIONS?
4744 024756 001006 BNE 1$ ; BR IF YES
4745 024760 005237 001104 INC $ICNT ; INCREMENT ITERATION COUNT
4746 024764 023737 001204 001104 CMP $TIMES, $ICNT ; CHECK THE NUMBER OF ITERATIONS MADE
4747 024772 002024 BGE $OVER ; BR IF MORE ITERATION REQUIRED
4748 024774 012737 000001 001104 1$: MOV #1, $ICNT ; REINITIALIZE THE ITERATION COUNTER
4749 025002 013737 025060 001204 MOV $MXCNT, $TIMES ; SET NUMBER OF ITERATIONS TO DO
4750 025010 105237 001102 $SVLAD: INCB $TSTNM ; COUNT TEST NUMBERS
4751 025014 113737 001102 001224 MOVB $TSTNM, $TSTNM ; SET TEST NUMBER IN APT MAILBOX
4752 025022 011637 001106 MOV (SP), $LPADR ; SAVE SCOPE LOOP ADDRESS
4753 025026 011637 001110 MOV (SP), $LPERR ; SAVE ERROR LOOP ADDRESS
4754 025032 005037 001206 CLR $ESCAPE ; CLEAR THE ESCAPE FROM ERROR ADDRESS
4755 025036 112737 000001 001115 MOVB #1, $ERMAX ; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
4756 025044 013777 001102 154070 $OVER: MOV $TSTNM, @DISPLAY ; DISPLAY TEST NUMBER
4757 025052 013716 001106 MOV $LPADR, (SP) ; FUDGE RETURN ADDRESS
4758 025056 000002 RTI ; FIXES PS
4759 025060 000001 $MXCNT: 1 ; MAX. NUMBER OF ITERATIONS

```

```

4760
4761 .SBTTL SAVE AND RESTORE R0-R5 ROUTINES
4762
4763 ; *****
4764 ; *SAVE R0-R5
4765 ; *CALL:
4766 ; * SAVREG
4767 ; *UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
4768 ; *
4769 ; *TOP---(+16)
4770 ; * +2---(+18)
4771 ; * +4---R5
4772 ; * +6---R4
4773 ; * +8---R3
4774 ; * +10---R2
4775 ; * +12---R1
4776 ; * +14---R0

```

```

4777 025062
4778 025062 010046
4779 025064 010146
4780 025066 010246
4781 025070 010346
4782 025072 010446
4783 025074 010546
4784 025076 016646 000022
4785 025102 016646 000022
4786 025106 016646 000022
4787 025112 016646 000022
4788 025116 000002
4789
4790
4791
4792
4793
4794 025120
4795 025120 012666 000022
4796 025124 012666 000022
4797 025130 012666 000022
4798 025134 012666 000022
4799 025140 012605
4800 025142 012604
4801 025144 012603
4802 025146 012602
4803 025150 012601
4804 025152 012600
4805 025154 000002
4806
4807
4808
4809
4810
4811
4812
4813
4814
4815 025156 010046
4816 025160 016600 000002
4817 025164 005740
4818 025166 111000
4819 025170 006300
4820 025172 016000 025212
4821 025176 000200
4822
4823
4824
4825
4826 025200 011646
4827 025202 016666 000004 000002
4828 025210 000002
4829
4830
4831
4832

```

```

$SAVREG:
MOV R0,-(SP) ;; PUSH R0 ON STACK
MOV R1,-(SP) ;; PUSH R1 ON STACK
MOV R2,-(SP) ;; PUSH R2 ON STACK
MOV R3,-(SP) ;; PUSH R3 ON STACK
MOV R4,-(SP) ;; PUSH R4 ON STACK
MOV R5,-(SP) ;; PUSH R5 ON STACK
MOV 22(SP),-(SP) ;; SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;; SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;; SAVE PS OF CALL
MOV 22(SP),-(SP) ;; SAVE PC OF CALL
RTI

```

```

;*RESTORE R0-R5
;*CALL:
;*RESREG

```

```

$RESREG:
MOV (SP)+,22(SP) ;; RESTORE PC OF CALL
MOV (SP)+,22(SP) ;; RESTORE PS OF CALL
MOV (SP)+,22(SP) ;; RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;; RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;; POP STACK INTO R5
MOV (SP)+,R4 ;; POP STACK INTO R4
MOV (SP)+,R3 ;; POP STACK INTO R3
MOV (SP)+,R2 ;; POP STACK INTO R2
MOV (SP)+,R1 ;; POP STACK INTO R1
MOV (SP)+,R0 ;; POP STACK INTO R0
RTI

```

```
.SBTTL TRAP DECODER
```

```

;*****
;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;GO TO THAT ROUTINE.

```

```

$TRAP: MOV R0,-(SP) ;; SAVE R0
MOV 2(SP),R0 ;; GET TRAP ADDRESS
TST -(R0) ;; BACKUP BY 2
MOVB (R0),R0 ;; GET RIGHT BYTE OF TRAP
ASL R0 ;; POSITION FOR INDEXING
MOV $TRAP(R0),R0 ;; INDEX TO TABLE
RTS R0 ;; GO TO ROUTINE

```

```
;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
```

```

$TRAP2: MOV (SP),-(SP) ;; MOVE THE PC DOWN
MOV 4(SP),2(SP) ;; MOVE THE PSW DOWN
RTI ;; RESTORE THE PSW

```

```
.SBTTL TRAP TABLE
```

```
;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
```

4833
4834
4835
4836
4837
4838
4839
4840
4841
4842
4843
4844
4845
4846
4847
4848
4849
4850
4851
4852
4853
4854
4855
4856
4857
4858
4859
4860
4861
4862
4863
4864
4865
4866
4867
4868
4869
4870
4871
4872
4873
4874
4875
4876
4877
4878
4879
4880
4881
4882
4883
4884
4885
4886
4887
4888

;*BY THE "TRAP" INSTRUCTION.

ROUTINE

```

$TRPAD: .WORD $TRAP2
$TYPE    ;;CALL=TYPE    TRAP+1(104401)  TTY TYPEOUT ROUTINE
$TYPOC   ;;CALL=TYPOC   TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS   ;;CALL=TYPOS   TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPON   ;;CALL=TYPON   TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPOS   ;;CALL=TYPOS   TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)

$GTSWR   ;;CALL=GTSWR   TRAP+6(104406)  GET SOFT-SWR SETTING

$CKSWR   ;;CALL=CKSWR   TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
$RDCHR   ;;CALL=RDCHR   TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
$RDLIN   ;;CALL=RDLIN   TRAP+11(104411) TTY TYPEIN STRING ROUTINE
$SAVREG  ;;CALL=SAVREG  TRAP+12(104412) SAVE R0-R5 ROUTINE
$RESREG  ;;CALL=RESREG  TRAP+13(104413) RESTORE R0-R5 ROUTINE

```

.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCIZ ROUTINE

```

;*****
;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
;UNSIGNED DECIMAL ASCIZ NUMBER.
;CALL
;*
*   MOV    NUMBER, -(SP)    ;;PUT BINARY NUMBER ON THE STACK
*   JSR    PC, @#$5B2D     ;;CALL
*   RETURN                               ;;ADDRESS OF THE 1ST ASCIZ CHAR. IS ON THE STACK

```

```

$5B2D:  MOV    2(SP), 1$    ;;SAVE BINARY NUMBER
        MOV    #1$, -(SP)  ;;SET POINTER
        JSR    PC, @#$DB2D ;;CALL DOUBLE LENGTH CONVERT
        ADD    #5, (SP)    ;;ONLY ALLOW FIVE CHARACTERS
        MOV    (SP)+, 2(SP) ;;PICKUP POINTER
        RTS    PC         ;;RETURN
1$:     .WORD  0,0

```

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

```

;*****
;THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
;DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
;POSITIVE.
;CALL
;*
*   MOV    #PNTR, -(SP)    ;;POINTER TO LOW WORD OF BINARY NUMBER
*   JSR    PC, @#$DB2D     ;;CALL
*   RETURN                               ;;THE FIRST ADDRESS OF ASCII
;                               ;;IS ON THE STACK

```

```

$DB2D:  SAVREG                               ;;SAVE REGISTERS
        MOV    2(SP), R2    ;;PICKUP THE DATA POINTER
        MOV    #$DECVL, R0  ;;GET ADDRESS OF "$DECVL" STRING
        MOV    R0, 2(SP)    ;;PUT ADDRESS OF ASCII STRING ON STACK
        MOV    (R2)+, R1    ;;PICKUP THE BINARY NUMBER

```

```

025212 025200
025214 022422
025216 022730
025220 022704
025222 022744
025224 023132

025226 023744

025230 023654
025232 024216
025234 024306
025236 025062
025240 025120

016637 000002 025272
012746 025272
004737 025276
062716 000005
012666 000002
000207 000000
000000 000000

104412
016602 000002
012700 02545E
010066 000002
012201

```

H10

MC-11-DZRMF-B RMO3 RMO2 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10

MACY11 30(1046) 22-NOV-77 08:04 PAGE 94
DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

SEG 0124

```
4889 025316 012202      MOV      (R2)+,R2
4890 025320 012737 000012 025374      MOV      #10.,4$      ;; SET UP TO DO 10 CONVERSIONS
4891 025326 012704 025406      MOV      #STNPNW,R4    ;; ADDRESS OF TEN POWER
4892 025332 012705 025410      MOV      #STNPNW+2,R5
4893 025336 005003      1$:     CLR      R3      ;; CLEAR PARTIAL
4894 025340 161401      2$:     SUB      (R4),R1    ;; SUBTRACT TEN POWER
4895 025342 005602      SBC      R2
4896 025344 161502      SUB      (R5),R2
4897 025346 002402      BLT      3$
4898 025350 005203      INC      R3      ;; BR IF TEN POWER TO LARGE
4899 025352 000772      BR      2$      ;; ADD 1 TO PARTIAL
4900 025354 062401      3$:     ADD      (R4)+,R1    ;; LOOP
4901 025356 005502      ADC      R2      ;; RESTORE SUBTRACTED VALUE
4902 025360 062402      ADD      (R4)+,R2
4903 025362 022525      CMP      (R5)+,(R5)+
4904 025364 052703 000060      BIS      #0,R3      ;; MOVE TO NEXT TEN POWER
4905 025370 110320      MOVB     R3,(R0)+    ;; CHANGE PARTIAL TO ASCII
4906 025372 005327      DEC      (PC)+      ;; SAVE IT
4907 025374 000000      4$:     .WORD    0      ;; DONE?
4908 025376 001357      BNE     1$
4909 025400 105020      CLRB     (R0)+      ;; BR IF NO
4910 025402 104413      RESREG   ;; TERMINATOR
4911 025404 000207      RTS      PC      ;; RESTORE REGISTERS
4912 025406 145000      $STNPNW: 145000    ;; RETURN
4913 025410 035632      35632
4914 025412 160400      160400    ;; 1.0E08
4915 025414 002765      2765
4916 025416 113200      113200    ;; 1.0E07
4917 025420 000230      230
4918 025422 041100      041100    ;; 1.0E06
4919 025424 000017      17
4920 025426 103240      103240    ;; 1.0E05
4921 025430 000001
4922 025432 023420      23420    ;; 1.0E04
4923 025434 000000
4924 025436 001750      1750    ;; 1.0E03
4925 025440 000000
4926 025442 000144      144    ;; 1.0E02
4927 025444 000000
4928 025446 000012      12    ;; 1.0E01
4929 025450 000000
4930 025452 000001      1    ;; 1.0E00
4931 025454 000000
4932 025456 000014      $DECVL: .BLKB 12.    ;; RESERVE STORAGE FOR ASCII STRING
4933
4934      .SBTTL TYPE NUMERICAL ASCII STRING SUPPRESS LEADING ZEROS
4935
4936      ;*****
4937      ;THIS ROUTINE IS USED TO TYPE AN ASCII NUMBER SUPPRESSING THE
4938      ;LEADING NUMBERS.
4939      ;CALL
4940      ;*      MOV      #NUMADR,-(SP)    ;; FIRST ADDRESS OF ASCII STRING
4941      ;*      JSR      PC,@#$SUPRS
4942
4943
4944 025472 010046      $SUPRS: MOV      R0,-(SP)    ;; SAVE R0
```

4945 025474 016600 000004
4946 025500 105710
4947 025502 001403
4948 025504 122720 000060
4949 025510 001773
4950 025512 005300
4951 025514 010037 025522
4952 025520 104401
4953 025522 000000
4954 025524 012600
4955 025526 012616
4956 025530 000207

MOV 4(SP),RO ;: PICKUP THE POINTER
1\$: TSTB (RO) ;: TERMINATE OR?
BEQ 2\$;: BR IF YES
CMPB #'D,(RO)+ ;: IS THIS AN ASCII "D" ?
BEQ 1\$;: BR IF YES
2\$: DEC RO ;: BACKUP BY "1"
MOV RO,3\$;: SAVE FOR TYPING
TYPE ;: GO TYPE
3\$: .WORD 0 ;: ASCIZ POINTER GOES HERE
MOV (SP)+,RO ;: RESTORE RO
MOV (SP)+,(SP) ;: RESTORE THE STACK
RTS PC ;: RETURN

.SBTTL RANDOM NUMBER GENERATOR ROUTINE

: THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
: WITH A RANGE OF 0 TO 2(+33)-1.

: CALL:
* JSR PC,\$RAND ;: CALL THE ROUTINE
* RETURN ;: RETURN HERE THE RANDOM
* ;: NUMBER WILL BE IN
* ;: \$HINUM,\$LONUM

\$RAND:
MOV RO,-(SP) ;: PUSH RO ON STACK
MOV R1,-(SP) ;: PUSH R1 ON STACK
MOV R2,-(SP) ;: PUSH R2 ON STACK
MOV \$LONUM,RO ;: SET RO WITH LOW
MOV \$HINUM,R1 ;: SET R1 WITH HIGH
MOV #-7,R2 ;: SET SHIFT COUNT
1\$: ASL RO ;: SHIFT RO LEFT AND
ROL R1 ;: ROTATE CARRY INTO R1 AND
INC R2 ;: CHECK FOR DONE
BNE 1\$;: CONTINUE SHIFT LOOP
ADD \$LONUM,RO ;: ADD NUMBER TO MAKE X 129
ADC R1 ;: PROPOGATE CARRY
ADD \$HINUM,R1 ;: ADD NUMBER TO MAKE X 129
ADD #1057,RO ;: ADD LOW CONSTANT
ADC R1 ;: PROPOGATE CARRY
ADD #47401,R1 ;: ADD HIGH CONSTANT
MOV RO,\$LONUM ;: SAVE RO
MOV R1,\$HINUM ;: SAVE R1
MOV (SP)+,R2 ;: POP STACK INTO R2
MOV (SP)+,R1 ;: POP STACK INTO R1
MOV (SP)+,RO ;: POP STACK INTO RO
RTS PC ;: RETURN

\$HINUM: .WORD 176543
\$LONUM: .WORD 123456

.SBTTL INTEGER DIVIDE ROUTINE

: THIS ROUTINE WILL DIVIDE A 32-BIT TWO'S COMPLEMENT INTEGER
: DIVIDEND BY A 16-BIT TWO'S COMPLEMENT INTEGER DIVISOR GIVING
: A 16-BIT TWO'S COMPLEMENT INTEGER QUOTIENT AND A 16-BIT REMAINDER.

4957
4958
4959
4960
4961
4962
4963
4964
4965
4966
4967
4968
4969 025532
4970 025532 010046
4971 025534 010146
4972 025536 010246
4973 025540 013700 025632
4974 025544 013701 025630
4975 025550 012702 177771
4976 025554 006300
4977 025556 006101
4978 025560 005202
4979 025562 001374
4980 025564 063700 025632
4981 025570 005501
4982 025572 063701 025630
4983 025576 062700 001057
4984 025602 005501
4985 025604 062701 047401
4986 025610 010037 025632
4987 025614 010137 025630
4988 025620 012602
4989 025622 012601
4990 025624 012600
4991 025626 000207
4992 025630 176543
4993 025632 123456
4994
4995
4996
4997
4998
4999
SCCC

```

5001 ;*DIVISION WILL BE PERFORMED SO THAT THE REMAINDER IS OF THE
5002 ;*SAVE SIGN AS THE DIVIDEND.
5003 ;*CALL:
5004 ;*      MOV      LOW DIVIDEND,-(SP) ;;THE HIGH DIVIDEND MUST BE 1/2
5005 ;*      MOV      HIGH DIVIDEND,-(SP); AS LARGE AS THE DIVISOR
5006 ;*      MOV      DIVISOR,-(SP)
5007 ;*      JSR      PC,$DIV
5008 ;*      RETURN   ;;QUOTIENT & REMAINDER ARE ON THE STACK
5009 ;*      "V"=0   IMPLIES NO ERROR
5010 ;*      "V"=1   IMPLIES ERROR OCCURRED
5011 ;*      "C"=0   DIVIDE OVERFLOW OCCURRED
5012 ;*      "C"=1   ATTEMPTED TO DIVIDE BY ZERO
5013
5014
5015 ;*      STACK      NO ERROR      OVERFLOW      DIVIDE BY ZERO
5016 ;*      -----
5017 ;*      TOP        REMAINDER     ALL ZEROS     ALL ONES
5018 ;*      +2         QUOTIENT      ALL ZEROS     ALL ONES
5019
5020 $DIV:
5021 025634 104400 TRAP      ;; PUSH OLD PSW AND PC ON STACK
5022 025636 042716 000017 BIC      #17,(SP) ;; STRIP AWAY CONDITION CODES
5023 025642 010046 MOV      R0,-(SP) ;; PUSH R0 ON STACK
5024 025644 010146 MOV      R1,-(SP) ;; PUSH R1 ON STACK
5025 025646 010246 MOV      R2,-(SP) ;; PUSH R2 ON STACK
5026 025650 010346 MOV      R3,-(SP) ;; PUSH R3 ON STACK
5027 025652 005046 CLR      -(SP)   ;; SAVE A PLACE FOR SIGNS
5028 025654 012746 000021 MOV      #17,-(SP) ;; SETUP THE ITERATION COUNTER
5029 025660 016601 000024 MOV      24(SP),R1 ;; PICKUP THE DIVIDEND
5030 025664 016600 000022 MOV      22(SP),R0
5031 025670 100005 BPL      1$
5032 025672 105366 000003 DECB     3(SP)   ;; CHECK THE SIGN
5033 025676 005400 NEG      R0     ;; KEEP TRACK OF THE SIGN
5034 025700 005401 NEG      R1     ;; AND NEGATE THE ORIGINAL
5035 025702 005600 SBC      R0     ;; NUMBER
5036 025704 016602 000020 1$: MOV     20(SP),R2 ;; PICKUP THE DIVISOR
5037 025710 002407 BLT      2$
5038 025712 003011 BGT      3$
5039 025714 052766 000003 000014 BIS      #3,14(SP) ;; CHECK THE SIGN
5040 025722 012700 177777 MOV      #-1,R0 ;; DIVISOR OF 0 IS A NO-NO
5041 025726 00424 BR       7$     ;; SET "V" & "C"
5042 025730 005266 000002 2$: INC     2(SP)  ;; SET REMAINDER TO ALL ONES
5043 025734 000401 BR       4$     ;; EXIT
5044 025736 005402 3$: NEG     R2   ;; KEEP TRACK OF DIVISORS SIGN
5045 025740 000241 4$: CLC    ;; NEGATE THE ORIGINAL NUMBER
5046 025742 000405 BR       6$     ;; CLEAR "C"
5047 025744 006100 5$: ROL     R0   ;; START FORMING QUOTIENT
5048 025746 010003 MOV      R0,R3  ;; POSITION MSB'S
5049 025750 060203 ADD      R2,R3  ;; COPY
5050 025752 103001 BCC      6$     ;; COMPARE DIVIDEND & DIVISOR
5051 025754 010300 MOV      R3,R0  ;; BR IF DIVIDEND > DIVISOR
5052 025756 006101 6$: ROL     R1   ;; REMAINDER AFTER THIS LOOP
5053 025760 005316 DEC      (SP)  ;; QUOTIENT BIT ENTERS HERE
5054 025762 001370 BNE      5$     ;; DONE?
5055 025764 005701 TST      R1    ;; BR IF NO
5056 025766 100005 BPL      8$     ;; OVERFLOW?
                    BPL      8$     ;; BR IF NO

```



```

5057 025770 052766 000002 000014 BIS #2,14(SP) ; SET "V" IN RETURN STATUS WORD
5058 025776 005000 CLR R0 ; SET REMAINDER TO ALL ZEROS
5059 026000 010001 7$: MOV R0,R1 ; COPY REMAINDER INTO QUOTIENT
5060 026002 005726 8$: TST (SP)+ ; CLEAR COUNTER FROM STACK
5061 026004 005716 TST (SP) ; REMAINDER SIGN CORRECTION NEEDED?
5062 026006 002004 BGE 9$ ; BR IF NO
5063 026010 005400 NEG R0 ; NEGATE REMAINDER
5064 026012 105066 000001 CLR B 1(SP) ; CLEAR SIGN
5065 026016 005316 DEC (SP) ; BUT DON'T FORGET QUOTIENT
5066 026020 005726 9$: TST (SP)+ ; QUOTIENT SIGN CORRECTION NEEDED?
5067 026022 001401 BEQ 10$ ; BR IF NO
5068 026024 005401 NEG R1 ; NEGATE QUOTIENT
5069 026026 010166 000020 10$: MOV R1,20(SP) ; RETURN QUOTIENT AND
5070 026032 010066 000016 MOV R0,16(SP) ; REMAINDER TO USER
5071 026036 012603 MOV (SP)+,R3 ; POP STACK INTO R3
5072 026040 012602 MOV (SP)+,R2 ; POP STACK INTO R2
5073 026042 012601 MOV (SP)+,R1 ; POP STACK INTO R1
5074 026044 012600 MOV (SP)+,R0 ; POP STACK INTO R0
5075 026046 012666 000002 MOV (SP)+,2(SP) ; SETUP TO RETURN CONDITION CODES
5076 026052 000002 RTI ; RETURN
    
```

.SBTTL *** PROGRAM SUBROUTINES ***

```

5078 ; SET "LPTAVL" TO THE PROPER STATE.
5079 ; LPTAVL = 0 IF NO LINE PRINTER AVAILABLE
5080 ; LPTAVL = 1 IF LINE PRINTER IS AVAILABLE
5081 ; CALL
5082 ; JSR PC, @LPT.AVL
5083 ; RETURN
5084
5085 LP.AVL: CLR @LPTAVL ; START WITH NO PRINTER AVAIABLE
5086 MOV #15,@ERRVEC ; SETUP THE TIMEOUT VECTOR
5087 CLR @ERRVEC+2
5088 TST @LPS ; IS THERE A LINE PRINTER?
5089 INC @LPTAVL ; YES--SET AVAILABLE SWITCH
5090 BR 2$
5091 1$: CMP (SP)+,(SP)+ ; NO--POP STACK
5092 2$: MOV @ERRVEC+2,@ERRVEC ; RESTORE TIMEOUT VECTOR
5093 RTS PC ; RETURN
    
```

```

5094 ; THIS ROUTINE WILL DETERMINE IF THERE IS A CLOCK ON THE SYSTEM
5095 ; AND IF THERE IS IT WILL SETUP THE VECTOR AND START THE CLOCK
5096 ; "CLKSTA" WILL INDICATE THE CLOCK TYPE
5097 ; 0= NO CLOCK
5098 ; +1= KW11-P
5099 ; -1= KW11-L
5100 ; THIS ROUTINE WILL ALSO SETUP "TICKMS" (TIME
5101 ; PER CLOCK TICK IN MILLISECONDS) AND "TICKUS"
5102 ; (TIME PER CLOCK TICK IN MICROSECONDS) AS
5103 ; PER SW00.
5104 ; SW00=0 -- 60HZ
5105 ; SW00=1 -- 50HZ
5106 ; CALL
5107 ; JSR PC,@ST.CLK
5108 ; RETURN
5109
5110
5111
5112
    
```


M10

```

5169 ; RETURN
5170
5171 LODFLT:
5172 026374 010046 MOV R0, -(SP) ;: PUSH R0 ON STACK
5173 026376 010146 MOV R1, -(SP) ;: PUSH R1 ON STACK
5174 026400 010246 MOV R2, -(SP) ;: PUSH R2 ON STACK
5175 026402 010346 MOV R3, -(SP) ;: PUSH R3 ON STACK
5176 026404 012737 176777 001314 MOV #176777, TSTNMS ;: SELECT TESTS 0-10, 12-17
5177 026412 012737 000003 001316 MOV #3, TSTNMS+2 ;: SELECT TESTS 20 & 21
5178 026420 012700 001746 MOV #DFLT, R0 ;: DEFAULT PARAMETERS POINTER
5179 026424 012701 002412 MOV #PRMO, R1 ;: TABLE POINTER
5180 026430 010102 MOV R1, R2 ;: STOP ADDRESS
5181 026432 012021 1$: MOV (R0)+, (R1)+ ;: MOVE DEFAULT PARAMETERS INTO
5182 026434 020002 CMP R0, R2 ;: RUN TIME TABLES ** DONE?
5183 026436 103775 BLO 1$ ;: NO--BRANCH
5184 026440 012700 003606 MOV #PAT8, R0 ;: PAT0 DEFAULTS TO PATTERN 8
5185 026444 012701 003206 MOV #PATO, R1
5186 026450 012021 2$: MOV (R0)+, (R1)+
5187 026452 020027 003646 CMP R0, #PAT9
5188 026456 103774 BLO 2$
5189 026460 032737 000001 001300 BIT #BIT00, C.SWR ;: 16 BIT MODE ?
5190 026466 001012 BNE 3$ ;: BR IF 18 BIT MODE
5191 026470 012737 000037 001712 MOV #31, PRMLMT+22 ;: SET 'FS' LIMIT TO 31.
5192 026476 012737 000037 001714 MOV #31, PRMLMT+24 ;: SET 'LS' LIMIT TO 31.
5193 026504 012737 160000 001432 MOV #-(<256.*32.>, TRCKWC ;: WORD COUNT FOR A 16 BIT TRACK
5194 026512 000411 BR 4$ ;: CONTINUE
5195 026514 012737 000035 001712 3$: MOV #29, PRMLMT+22 ;: SET 'FS' LIMIT TO 29.
5196 026522 012737 000035 001714 MOV #29, PRMLMT+24 ;: SET 'LS' LIMIT TO 29.
5197 026530 012737 161000 001432 MOV #-(<256.*30.>, TRCKWC ;: WORD COUNT FOR AN 18 BIT TRACK
5198 026536 012701 001620 4$: MOV #PRMPT, R1 ;: ADDRESS OF PARAMETER POINTER TABLE
5199 026542 005711 5$: TST (R1) ;: END OF THE TABLE ?
5200 026544 001425 BEQ 3$ ;: BR IF END
5201 026546 032731 002000 BIT #BIT10, @ (R1)+ ;: 'LS' SELECTED ?
5202 026552 001773 BEQ 5$ ;: BR IF NOT
5203 026554 016102 177776 MOV -(R1), R2 ;: PARAMETER TABLE ADDRESS
5204 026560 011246 MOV (R2), -(SP) ;: PARAMETER ALLOCATION BITS
5205 026562 012703 000013 MOV #11, R3 ;: NUMBER OF PARAMETERS (MAXIMUM) BEFORE 'LS'
5206 026566 006216 6$: ASR (SP), R3 ;: COUNT THE PARAMETER
5207 026570 103002 BCC 7$ ;: BR IF NOT USED
5208 026572 062702 000002 ADD #2, R2 ;: INCREMENT THE PARAMETER TABLE ADDRESS
5209 026576 005303 7$: DEC R3 ;: COUNT THE PARAMETER
5210 026600 001372 BNE 6$ ;: BR IF NOT THERE YET
5211 026602 005726 TST (SP)+ ;: CORRECT THE STACK POINTER
5212 026604 021237 001712 CMP (R2), PRMLMT+22 ;: IS 'LS' TOO LARGE FOR THE MODE SELECTED ?
5213 026610 101754 BLOS 5$ ;: BR IF NOT
5214 026612 013712 001712 MOV PRMLMT+22, (R2) ;: RESET VALUE FOR MODE USED
5215 026616 000751 BR 5$ ;: CONTINUE
5216
5217 8$: MOV (SP)+, R3 ;: POP STACK INTO R3
5218 MOV (SP)+, R2 ;: POP STACK INTO R2
5219 MOV (SP)+, R1 ;: POP STACK INTO R1
5220 MOV (SP)+, R0 ;: POP STACK INTO R0
5221 026630 000207 RTS PC ;: RETURN

```

: THIS ROUTINE FILLS THE PARAMETER TABLE THE CURRENT TEST.
 : CALL

```

5225      ;      MOV      #TESTNUM,$STNM  ;LOAD THE TEST NUMBER
5226      ;      JSR      PC.LODPRM
5227      ;      RETURN
5228
5229      LODPRM:
5230      026632      010146      MOV      R1,-(SP)      ;: PUSH R1 ON STACK
5231      026634      010246      MOV      R2,-(SP)      ;: PUSH R2 ON STACK
5232      026636      010346      MOV      R3,-(SP)      ;: PUSH R3 ON STACK
5233      026640      010446      MOV      R4,-(SP)      ;: PUSH R4 ON STACK
5234      026642      005004      CLR      R4           ;: CLEAR R4
5235      026644      113704      001102      MOVB     $STNM,R4      ;: GET THE TEST NUMBER
5236      026650      006304      ASL      R4           ;: SETUP TO ADDRESS WORDS
5237      026652      016401      001620      MOV      PRMPT(R4),R1  ;: GET THE TEST'S PARAMETER TABLE ADDRESS
5238      026656      012702      001566      MOV      #PRM,R2      ;: PARAMETER EXECUTION TABLE
5239      026662      005003      CLR      R3           ;: R3 IS USED AS A COUNTER
5240      026664      013704      001334      MOV      CHKDRV,R4     ;: DRIVE'S ADDRESS
5241      026670      012122      MOV      (R1)+,(R2)+   ;: PARAMETER SPECIFIER
5242      026672      006237      001566      1$:    ASR      PRM        ;: THIS PARAMETER USED IN THE TEST ?
5243      026676      103002      BCC      2$           ;: BR IF NOT
5244      026700      012122      MOV      (R1)+,(R2)+   ;: LOAD THE VALUE
5245      026702      000401      BR       3$           ;: CONTINUE
5246      026704      005022      CLR      (R2)+        ;: CLEAR THE UNUSED PARAMETER LOCATION
5247      026706      005203      2$:    INC      R3        ;: COUNT THE POSITION IN THE OUTPUT TABLE
5248      026710      020327      000014      3$:    CMP      R3,#12.     ;: FINISHED ?
5249      026714      001430      BEQ      6$           ;: BR IF YES
5250      026716      020327      000003      CMP      R3,#3       ;: DOING THE CYLINDER ADDRESSES ?
5251      026722      001363      BNE      1$           ;: BR IF NOT
5252      026724      132764      000004      036620  BITB     #BIT02,DRVTF(R4) ;: RM03 ?
5253      026732      001016      BNE      5$           ;: IF IT IS OVERLAY FC & LC WITH FC' & LC'
5254      026734      062703      000002      ADD      #2,R3        ;: COUNT THE BYPASSED PARAMETERS (FC' & LC')
5255      026740      006237      001566      ASR      PRM        ;: SHIFT THE COUNTER
5256      026744      103002      BCC      4$           ;: BR IF FC' IS NOT USED
5257      026746      062701      000002      ADD      #2,R1        ;: MOVE THE INPUT POINTER
5258      026752      006237      001566      4$:    ASR      PRM        ;: COUNT THE PARAMETER
5259      026756      103345      BCC      1$           ;: BR IF LC' NOT USED
5260      026760      052701      000002      ADD      #2,R1        ;: MOVE THE INPUT PINTER
5261      026764      000742      BR       1$           ;: KEEP GOING
5262      026766      000741      BR       1$           ;: KEEP GOING
5263      026770      162702      000004      5$:    SUB      #4,R2        ;: BACKUP THE OUTPUT POINTER
5264      026774      000736      BR       1$           ;: KEEP GOING
5265      026776      6$:
5266      026776      012604      MOV      (SP)+,R4     ;: POP STACK INTO R4
5267      027000      012603      MOV      (SP)+,R3     ;: POP STACK INTO R3
5268      027002      012602      MOV      (SP)+,R2     ;: POP STACK INTO R2
5269      027004      012601      MOV      (SP)+,R1     ;: POP STACK INTO R1
5270      027006      000207      RTS      PC           ;: RETURN
5271
5272      ; THIS ROUTINE LOADS A READ HEADER AND DATA COMMAND OR A SEEK COMMAND.
5273      ; INTO DPB.B+2 AND DPB.C+2. DEPENDING ON THE STATE OF "CONTROL SWITCH"
5274      ; BIT07.
5275      ; CALL
5276      ;
5277      ;      JSR      PC,@#LDCMD
5278      ;      RETURN
5279      027010      032737      000200      001300  LDCMD:  BIT      #SW07,@#C.SWR  ;: DO EXPLICIT SEEKS?
5280      027016      001007      BNE      1$           ;: YES--BRANCH
  
```

```

5281 027020 012737 000173 004230      MOV      #READHD,2#DPB.B+2 ;NO--SET UP FOR READ HEADER AND
5282 027026 012737 000173 004250      MOV      #READHD,2#DPB.C+2 ;DATA COMMAND
5283 027034 000406                BR        2$
5284 027036 012737 000105 004230 1$:  MOV      #SEEK,2#DPB.B+2 ;SETUP FOR SEEK COMMAND
5285 027044 012737 000105 004250      MOV      #SEEK,2#DPB.C+2
5286 027052 000207                2$:  RTS      PC
5287
5288 ; THIS ROUTINE WILL CALL THE RMO3 DRIVER AND THEN WAIT ON THE FUNCTION
5289 ; TO COMPLETE. IF AN ERROR OCCURS IT IS REPORTED.
5290 ; CALL
5291 ;     FILL "DPB" WITH COMMAND INFORMATION
5292 ;     JSR      RO,2#CALL.A
5293 ;     RETURN
5294
5295 027054 005037 001206      CALL.A: CLR      2#SEESCAPE      ;NO ESCAPE ADDRESS
5296 027060 004037 037502      JSR      RO,2#RMO3          ;CALL RMO3 DRIVER
5297 027064 004206      DPB.A
5298 027066 000772      BR        CALL.A
5299 027070 005737 004224 1$:  TST      2#DPB.A+16        ;DONE?
5300 027074 001775      BEQ      4$                ;NO--LOOP
5301 027076 100042      BPL      4$                ;BRANCH IF NO ERROR
5302 027100 012737 027174 001206      MOV      #3$,SEESCAPE      ;ESCAPE TO 3$ ON ERROR
5303 027106 013737 004220 001350      MOV      2#DPB.W+12,2#CYL.DS ;CYLINDER
5304 027114 113737 004217 001354      MOV      2#DPB.A+11,2#TRK.DS ;TRACK
5305 027122 113737 004216 001352      MOV      2#DPB.A+10,2#SEC.DS ;SECTOR
5306 027130 012746 004224      MOV      #DPB.A+16, -(SP)   ;STATUS/ERROR INDICATOR ADDRESS
5307 027134 004737 030450      JSR      PC,2#ERINDEX      ;FORM DISPATCH INDEX
5308 027140 062607      ADD      (SP)+,PC          ;REPORT PROPER ERROR
5309 027142 104041      ERROR   41
5310 027144 104042      ERROR   42                ;PARITY ERROR
5311 027146 104043      ERROR   43                ;UNSAFE ERROR
5312 027150 104044      ERROR   44                ;NON-I/O ERROR
5313 027152 000240      NOP
5314 027154 005737 004322      TST      RM.REG+RMER1      ;ANY DRIVE ERROR
5315 027160 001004      BNE      2$                ;BRANCH IF 50
5316 027162 032737 100000 004350      BIT      #BIT15,RM.REG+RMER2 ;BAD SPOT ERROR
5317 027170 001005      BNE      4$                ;BRANCH IF 50
5318 027172 104045      ERROR   45                ;I/O ERROR
5319 027174 013746 004224 3$:  MOV      DPB.A+16, -(SP)   ;STATUS WORD
5320 027200 034737 030410      JSR      PC,LOP.CK        ;SEE IF LOOP, ABORT, OR CONTINUE
5321 027204 000200      4$:  RTS      RO              ;RETURN
5322
5323 ; THIS ROUTINE IS THE SAME AS "CALL.A" EXCEPT FOR THE DPB USED AND IF
5324 ; THE COMMAND IS A READ HEADER AND DATA THE HEADER (CYLINDER, TRACK,
5325 ; AND SECTOR) READ IS CHECKED FOR VALIDITY.
5326 ; CALL
5327 ;     FILL DPB
5328 ;     JSR      RG,2#CALL.B
5329 ;     RETURN
5330
5331 027206 005037 001206      CALL.B: CLR      2#SEESCAPE      ;NO ESCAPE ADDRESS
5332 027212 004037 037502      JSR      RO,2#RMO3          ;CALL RMO3 DRIVER
5333 027216 004226      DPB.B
5334 027220 000772      BR        CALL.B
5335 027222 005737 004244 1$:  TST      DPB.B+16        ;DONE?
5336 027226 001775      BEQ      1$                ;NO--BRANCH

```

```

5337 027230 100047          BPL      4$          ;BRANCH IF NO ERROR
5338 027232 012737 027336 001206  MOV      #3$, $ESCAPE ; ESCAPE TO 3$ ON ERROR
5339 027240 013737 004240 001350  MOV      @DPB.B+12,@#CYL.DS ;CYLINDER
5340 027246 113737 004237 001354  MOVB     @DPB.B+11,@#TRK.DS ;TRACK
5341 027254 113737 004236 001352  MOVB     @DPB.B+10,@#SEC.DS ;SECTOR
5342 027262 012746 004244          MOV      @DPB.B+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
5343 027266 004737 030450          JSR      PC,@#ERINDX    ;FORM DISPATCH INDEX
5344 027272 062607          ADD      (SP)+,PC      ;REPORT PROPER ERROR
5345 027274 104041          ERROR   41
5346 027276 104042          ERROR   42          ;PARITY ERROR
5347 027300 104043          ERROR   43          ;UNSAFE ERROR
5348 027302 104044          ERROR   44          ;NON-I/O ERROR
5349 027304 000240          NOP
5350 027306 005737 004322          TST     RM.REG+RMER1   ;DRIVE ERROR ?
5351 027312 001404          BEQ     2$           ;BR IF NOT
5352 027314 032737 177677 004322          BIT     #1C100,RM.REG+RMER1 ;SEE IF ONLY 'HCE' SET
5353 027322 001412          BEQ     4$           ;BR IF IT IS
5354 027324          2$:
5355 027324 032737 100000 004350          BIT     #BIT15,RM.REG+RMER2 ;BSE ERROR
5356 027332 001025          BNE     6$           ;BRANCH IF 50
5357 027334 104045          ERROR   45          ;I/O ERROR
5358 027336 013746 004244          MOV     DPB.B+16,-(SP) ;STATUS WORD
5359 027342 004737 030410          JSR     PC,LOP.CK     ;SEE IF LOOP, ABORT, OR CONTINUE
5360 027346 000410          BR
5361 027350 123727 004230 000173 4$: CMPB     @DPB.B+2,@#READHD ;DOING IMPLIED SEEKS?
5362 027356 001004          BNE     5$           ;NO--BRANCH
5363 027360 004037 030750          JSR     RD,@#VERIFY   ;YES--GO CHECK THE DATA
5364 027364 004236          DPB.B+10
5365 027366 000407          BR      6$           ;ERROR DURING VERIFY
5366 027370 032737 040000 001300 5$: BIT     #SW14,@#C.SWR   ;STALL?
5367 027376 001403          BEQ     6$           ;NO--BRANCH
5368 027400 004037 030606          JSR     RD,@#STALL    ;YES--CALL STALL ROUTINE
5369 027404 001434          .WORD  STALL1       ;STALL TIME POINTER
5370 027406 000200          6$: RTS      RD      ;RETURN
5371
5372          ;THIS ROUTINE IS THE SAME AS "CALL.B" EXCEPT FOR THE DPB USED.
5373          ;CALL
5374          ;
5375          ; FILL DPB
5376          ; JSR      RD,@#CALL.C
5377          ; RETURN
5378 027410 005037 001206  CALL.C: CLR      @#ESCAPE   ;NO ESCAPE ADDRESS
5379 027414 004037 037502          JSR     RD,@#RMO3     ;CALL RMO3 DRIVER
5380 027420 004246          DPB.C
5381 027422 000772          BR      CALL.C
5382 027424 005737 004264          1$: TST     @DPB.C+16     ;DONE?
5383 027430 001775          BEQ     1$           ;NO--LOOP
5384 027432 100047          BPL     4$           ;YES--BRANCH IF NO ERROR
5385 027434 012737 027540 001206  MOV      #3$, $ESCAPE ; ESCAPE TO 3$ ON ERROR
5386 027442 013737 004260 001350  MOV      @DPB.C+12,@#CYL.DS ;CYLINDER
5387 027450 113737 004257 001354  MOVB     @DPB.C+11,@#TRK.DS ;TRACK
5388 027456 113737 004256 001352  MOVB     @DPB.C+10,@#SEC.DS ;SECTOR
5389 027464 012746 004264          MOV      @DPB.C+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
5390 027470 004737 030450          JSR     PC,@#ERINDX    ;FORM DISPATCH INDEX
5391 027474 062607          ADD      (SP)+,PC      ;REPORT PROPER ERROR
5392 027476 104041          ERROR   41

```

```

5393 027500 104042 ERROR 42 ; PARITY ERROR
5394 027502 104043 ERROR 43 ; UNSAFE ERROR
5395 027504 104044 ERROR 44 ; NON-I/O ERROR
5396 027506 000240 NOP ; TO SYNC THE CALLING SEQ OF ERINDX: RT.
5397 027510 005737 004322 TST RM.REG+RMER1 ; DRIVE ERROR ?
5398 027514 001404 BEQ 2$ ; BR IF NOT
5399 027516 032737 177677 004322 BIT #C100, RM.REG+RMER1 ; SEE IF ONLY 'HCE' SET
5400 027524 001412 BEQ 4$ ; BR IF IT IS
5401 027526 2$:
5402 027526 032737 100000 004350 BIT #BIT15, RM.REG+RMER2 ; BSE ERROR ONLY ?
5403 027534 001025 BNE 6$ ; BRANCH IF SO
5404 027536 104045 ERROR 45 ; I/O ERROR
5405 027540 013746 004264 3$: MOV DPB.C+16, -(SP) ; STATUS WORD
5406 027544 004737 030410 JSR PC, LOP.CK ; SEE IF LOOP, ABORT, OR CONTINUE
5407 027550 000410 BR 5$
5408 027552 123727 004250 000173 4$: CMPB @DPB.C+2, @READHD ; DOING IMPLIED SEEK?
5409 027560 001004 BNE 5$ ; NO--EXIT
5410 027562 004037 030750 JSR RO, @VERIFY ; YES--CHECK THE DATA
5411 027566 004256 DPB.C+10
5412 027570 000407 BR 6$ ; ERROR DURING VERIFY
5413 027572 032737 040000 001300 5$: BIT #SW14, @C.SWR ; STALL?
5414 027600 001403 BEQ 6$ ; NO--BRANCH
5415 027602 004037 030606 JSR RO, @STALL ; YES--CALL STALL ROUTINE
5416 027606 001434 .WORD STALL1 ; STALL TIME POINTER
5417 027610 000200 6$: RTS RO

```

: THIS ROUTINE IS THE SAME AS "CALL.A" EXCEPT FOR THE DPB USED AND
: ON AN ERROR LOCATION "ERR.CT" IS EXAMINED. IF ERR.CT IS EQUAL TO
: \$ERFLG EXIT IS TO THE NEXT TEST.

```

: CALL
: FILL DPB
: JSR RO, @DRVCAL
: RETURN

```

```

428 027612 005037 001206 DRVCAL: CLR @SEESCAPE ; NO ESCAPE ADDRESS
429 027616 005037 001414 CLR @WCEFLG ; CLEAR WRITE CHECK ERROR FLAG
430 027622 004037 037502 JSR RO, @RMO3 ; CALL RMO3 DRIVER
431 027626 004266 DTADPB
432 027630 000770 BR DRVCAL
433 027632 005737 004304 DRVCL1: TST @DTADPB+16 ; DONE
434 027636 001775 BEQ DRVCL1 ; NO--LOOP
435 027640 100402 BMI 1$ ; BR IF ERRORS
436 027642 000137 030370 JMP 10$ ; NO ERRORS
437 027646 1$:
438 027646 012737 027754 001206 MOV #2$, SEESCAPE ; ESCAPE TO 2$ ON ERROR
439 027654 013737 004300 001350 MOV @DTADPB+12, @CYL.DS ; CYLINDER
440 027662 113737 004277 001354 MOV @DTADPB+11, @TRK.DS ; TRACK
441 027670 113737 004276 001352 MOV @DTADPB+10, @SEC.DS ; SECTOR
442 027676 012746 004304 MOV @DTADPB+16, -(SP) ; STATUS/ERROR INDICATOR ADDRESS
443 027702 004737 030450 JSR PC, @ERINDX ; FORM DISPATCH INDEX
444 027706 062607 ADD (SP)+, PC ; REPORT PROPER ERROR
445 027710 104041 ERROR 41
446 027712 104042 ERROR 42 ; PARITY ERROR
447 027714 104043 ERROR 43 ; UNSAFE ERROR
448 027716 104044 ERROR 44 ; NON-I/O ERROR

```



```

5505 030226 001775      BEQ      6$          ;NO--LOOP
5506 030230 100057      BPL      10$        ;YES--BRANCH IF NO ERROR
5507 030232 012737 000001 001414 7$:  MOV     #1, @WCEFLG ;SET THE WRITE CHECK ERROR FLAG
5508 030240 012737 030344 001206      MOV     @8$, $ESCAPE ;ESCAPE TO 8$ ON ERROR
5509 030246 013737 004300 001350      MOV     @DTADPB+12, @CYL.DS ;CYLINDER
5510 030254 113737 004277 001354      MOV     @DTADPB+11, @TRK.DS ;TRACK
5511 030262 113737 004276 001352      MOV     @DTADPB+10, @SEC.DS ;SECTOR
5512 030270 012746 004304      MOV     @DTADPB+16, -(SP) ;STATUS/ERROR INDICATOR ADDRESS
5513 030274 004737 030450      JSR     PC, @ERINDX ;FORM DISPATCH INDEX
5514 030300 062607      ADD     (SP)+, PC   ;REPORT PROPER ERROR
5515 030302 104041      ERROR   41
5516 030304 104042      ERROR   42          ;PARITY ERROR
5517 030306 104043      ERROR   43          ;UNSAFE ERROR
5518 030310 104044      ERROR   44          ;NON-I/O ERROR
5519 030312 000240      NOP
5520 030314 005737 004322      TST     RM.REG+RMER1 ;ANY DRIVE ERROR
5521 030320 001010      BNE     88$        ;BRANCH IF 50
5522 030322 032737 100000 004350      BIT     #BIT15, RM.REG+RMER2 ;BAD SOPT ERROR ?
5523 030330 001404      BEQ     88$        ;BRANCH IF NOT
5524 030332 012737 177777 001446      MOV     #-1, BASFLG ;SET BAD SECTOR ENCOUNTER FLAG
5525 030340 000413      BR      10$        ;OTHERWISE EXIT
5526 030342 104046      ERROR   46          ;REPORT THE FATAL WRITE CHECK ERROR
5527 030344 013746 004304 8$:  MOV     DTADPB+16, -(SP) ;STATUS WORD
5528 030350 004737 030410      JSR     PC, LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
5529 030354 123737 001444 001103 12$: CMP     @ERR.CT, @SERFLG ;GO TO NEXT TEST?
5530 030362 101002      BHI     10$        ;NO--BRANCH
5531 030364 013700 001332 9$:  MOV     @BYPASS, R0  ;YES--GET EXIT ADDRESS
5532 030370 032737 040000 001300 10$: BIT     #SW14, @C.SWR ;STALL?
5533 030376 001403      BEQ     11$        ;NO--BRANCH
5534 030400 004037 030606      JSR     R0, @STALL ;YES--CALL STALL ROUTINE
5535 030404 001436      .WORD  STALL2     ;STALL TIME POINTER
5536 030406 00020C 11$:  RTS      R0
5537
5538 ;THIS SUBROUTINE CHECK FOR LOOP, ABORT, OR CONTINUE SWITCHES AFTER
5539 ;ERRORS 41, 42, 43, 44, 45, AND 46.
5540 ;CALL
5541 ;
5542 ;
5543 ;
5544 ;
5545 030410 032777 001000 150522 LOP.CK: BIT     #SW9, @SWR ;LOOP ON ERROR
5546 030416 001402      BEQ     1$         ;BR IF NOT
5547 030420 000177 150464      JMP     @SLPERR ;START AT THE LOOP ADDRESS
5548 030424 005037 001206 1$:  CLR     $ESCAPE ;CLEAR ERROR ESCAPE FLAG
5549 030430 032766 072006 000002      BIT     #BIT14!BIT13!BIT12!BIT10!BIT02!BIT01, 2(SP) ;CHECK ERROR TYPE
5550 030436 001402      BEQ     2$         ;BR IF DRIVE NOT OFFLINE, UNLOADED, OR
5551 ;PERSISTENT UNSAFE OR FATAL MASSBUS PARITY
5552 030440 000137 021052 2$:  JMP     $EOP ;TERMINATE DRIVE
5553 030444 012616      MOV     (SP)+, (SP) ;ADJUST RETURN ADDRESS
5554 030446 000207      RTS      PC
5555
5556 ;THIS ROUTINE FORMS AN INDEX THAT WILL BE USED TO DISPATCH
5557 ;TO THE PROPER ERROR CALL. THE INDEX IS FORMED BY EXAMINING
5558 ;THE STATUS/ERROR INDICATOR OF THE APPLICABLE DPB.
5559 ;INDEX
5560 ;-----
5561 ;-----

```

G11

```

5561      0 BIT14!BIT13!BIT08!BIT01
5562      2 BIT11!BIT10!BIT02
5563      4 BIT12!BIT04
5564      6 BIT05!BIT03!<BIT09 & COMMAND=NON-I/O>
5565     10 BIT06!<BIT09 & COMMAND=I/O>
5566      :CALL
5567      JSR      #DPB+16,-(SP)      ;ADDRESS OF STATUS/ERROR INDICATOR
5568      JSR      PC,#ERINDX      ;FORM INDEX
5569      RETURN      ;INDEX IS ON THE STACK
5570
5571 030450 010046 ERINDX: MOV      RO,-(SP)      ;SAVE RO
5572 030452 010146      MOV      R1,-(SP)      ;SAVE R1
5573 030454 016600 000006      MOV      6(SP),RO      ;GET STATUS/ERROR INDICATOR POINTER
5574 030460 011037 001340      MOV      (RO),#SVSTAT      ;SAVE THE STATUS/ERROR INDICATOR
5575 030464 005001      CLR      R1      ;START INDEX AT ZERO
5576 030466 032710      BIT      (PC)+,(RO)      ;FORM INDEX OF 0?
5577 030470 020402      .WORD   BIT13!BIT08!BIT01
5578 030472 001037      BNE     5$      ;YES--BRANCH
5579 030474 032710      BIT      (PC)+,(RO)      ;FORM PARITY ERROR OR PORT REQUEST INDEX (2)
5580 030476 006004      .WORD   BIT11!BIT10!BIT02
5581 030500 001033      BNE     4$      ;YES--BRANCH
5582 030502 032710      BIT      (PC)+,(RO)      ;FORM UNSAFE INDEX (4)?
5583 030504 050020      .WORD   BIT14!BIT12!BIT04
5584 030506 001027      BNE     3$      ;YES--BRANCH
5585 030510 032710      BIT      (PC)+,(RO)      ;FORM NON-I/O ERROR INDEX (6)?
5586 030512 000050      .WORD   BIT05!BIT03
5587 030514 001023      BNE     2$      ;YES--BRANCH
5588 030516 032710      BIT      (PC)+,(RO)      ;FORM I/O ERROR INDEX (10)?
5589 030520 000100      .WORD   BIT06
5590 030522 001017      BNE     1$      ;YES--BRANCH
5591 030524 032710      BIT      (PC)+,(RO)      ;SOFTWARE TIMEOUT?
5592 030526 001000      .WORD   BIT09
5593 030530 001420      BEQ     5$      ;NO--FORM INDEX OF 0
5594 030532 122760 000150 177762      CMPB   #150,-16(RO)      ;YES--I/O?
5595 030540 003011      BGT     2$      ;NO--BRANCH
5596 030542 005737 004322      TST    RM.REG+RMEP1      ;ANY DRIVE ERROR?
5597 030546 001005      BNE     1$      ;BRANCH IF SO
5598 030550 032737 100000 004350      BIT    #BIT15,RM.REG+RMEP2 ;BSE ERROR
5599 030556 001401      BEQ     1$      ;BRANCH IF NOT
5600 030560 005201      INC    R1      ;SKIP, NOT REPORT BSE ERROR
5601 030562 005201      INC    R1      ;INDEX=10---ERROR=45 OR 46
5602 030564 005201      INC    R1      ;INDEX=6---ERROR=44
5603 030566 005201      INC    R1      ;INDEX=4---ERROR=43
5604 030570 005201      INC    R1      ;INDEX=2---ERROR=42
5605 030572 006301      ASL   R1      ;INDEX=0---ERROR=41
5606 030574 010166 000006      MOV    R1,6(SP)      ;RETURN INDEX TO USER
5607 030600 012601      MOV    (SP)+,R1      ;RESTORE R1
5608 030602 012600      MOV    (SP)+,RO      ;RESTORE RO
5609 030604 000207      RTS    PC      ;RETURN FROM CALL

```

```

: THIS ROUTINE WILL PROVIDE A STALL IN MILLISECONDS FOR A SPECIFIC
: AMOUNT OF TIME IF BIT13 OF C.SWR = 0 OR A RANDOM AMOUNT OF TIME
: IF BIT 13 OF C.SWR = 1.
: STALL1 CONTAINS SPECIFIED TIME FOR TESTS 0 - 7, AND STALL2
: CONTAINS THE TIME FOR TESTS 16-21.
: CALL

```

```

5610
5611
5612
5613
5614
5615
5616

```

```

5617      :      JSR      RO,@#STALL
5618      :      TIME POINTER      ;WHERE TO FIND THE STALL TIME
5619      :
5620      030606 013046          STALL:  MOV      @#(RO)+, -(SP)      ; PICKUP STALL TIME
5621      030610 032737 020000 001300 BIT      @#SW13,@#C.SWR      ; USE A RANDOM TIME?
5622      030616 001406          BEQ      1$              ; NO--BRANCH
5623      030620 004737 025532          JSR      PC,@#SRAND          ; YES--FORM RANDOM NUMBER
5624      030624 013716 025632          MOV      @#LONUM,(SP)      ; AND USE IT FOR THE STALL TIME
5625      030630 042716 177700          BIC      @#C77,(SP)      ; BUT NEVER > 64 MILLISECONDS
5626      030634 005046          1$:  CLR      -(SP)          ; CLEAR TEMP. LOCATION
5627      030636 162766 000001 000002 2$:  SUB      @#1,2(SP)      ; MORE STALL REQUIRED?
5628      030644 103407          BLO      4$              ; NO--BRANCH
5629      030646 012716 000144          MOV      @#100.,(SP)      ; STALL FOR ABOUT 1 MILLISECOND
5630      030652 005700          3$:  TST      RO              ; NOP TO KILL TIME
5631      030654 005366 000000          DEC      0(SP)          ; COUNT
5632      030660 001374          BNE      3$              ; LOOP IF MORE COUNTS NEEDED
5633      030662 000765          BR       2$              ;
5634      030664 022626          4$:  CMP      (SP)+,(SP)+      ; CLEAN OFF THE STACK
5635      030666 000200          RTS      RO              ; EXIT
5636
5637
5638      :ROUTINE TO PROVIDE A 2 MS STALL AFTER A SEEK OPERATION IN THE SEEK TIMING
5639      :TESTS. THIS STALL IS REQUIRED TO COMPENSATE FOR THE 'ACCESS READY' DELAY
5640      :IN THE RM03. THIS STALL TIME IS NOT INCLUDED IN THE CALCULATED SEEK TIMES.
5641      :CALL
5642      :
5643      :      JSR      PC,@#TWOMS
5644      :      RETURN
5645      030670 013746 177776          TWOMS: MOV      @#PS, -(SP)      ; SAVE THE PRESENT PROCESSOR STATUS
5646      030674 012737 000240 177776 MOV      @#(5#32.),@#PS      ; SET THE PROCESSOR PRIORITY TO 5
5647      030702 017746 150550          MOV      @#PKV, -(SP)      ; SAVE THE OLD CLOCK VECTOR ADDRESS
5648      030706 012777 030732 150542 MOV      @#1,@#PKV          ; SETUP NEW VECTOR ADDRESS
5649      030714 012777 000310 150542 MOV      @#200.,@#PKB      ; LOAD THE CLOCK BUFFER
5650      030722 012777 000101 150532 MOV      @#101,@#PKCS      ; START THE CLOCK
5651      030730 000001          WAIT          ; WAIT FOR 2 MS
5652      030732 062706 000004          1$:  ADD      @#4,SP          ; INCREMENT STACK FOR RETURN
5653      030736 012677 150514          MOV      (SP)+,@#PKV      ; RESTORE OLD CLOCK VECTOR
5654      030742 012637 177776          MOV      (SP)+,@#PS      ; RESTORE THE OLD PROCESSOR STATUS
5655      030746 000207          RTS      PC              ; RETURN
5656
5657      :ROUTINE TO SOFTWARE COMPARE HEADER ON IMPLIED SEEKS
5658      :CALL
5659      :
5660      :      JSR      RO,@#VERIFY
5661      :      ADDR POINTER      ; ADDRESS OF DPB+10 (SECTOR NUMBER)
5662      :      RETURN
5663
5664      030750 010146          VERIFY: MOV      R1, -(SP)      ; SAVE R1
5665      030752 012001          MOV      (RO)+,R1          ; GET ADDRESS OF DPB+10
5666      030754 042737 150000 051776 BIC      @#150000,@#BUFFER ; STRIP FORMAT AND BAD SECTOR BITS FROM CYLINDER NUMBER
5667      030762 023761 05177E 000002 CMP      @#BUFFER,2(R1)    ; CYLINDER NUMBER OK?
5668      030770 001003          BNE      1$              ; NO--BRANCH
5669      030772 023711 052000          CMP      @#BUFFER+2,(R1) ; YES--HOW ABOUT TRACK SECTOR?
5670      030776 001441          BEQ      3$              ; BRANCH IF GOOD
5671      031000 013737 051776 001342 1$:  MOV      @#BUFFER,@#CYL.RD ; SAVE THE EXPECTED AND THE
5672      031006 113737 052001 001344 MOV      @#BUFFER+3,@#TRK.RD ; RECIEVED CYLINDER, TRACK.
5673      031014 113737 052000 001346 MOV      @#BUFFER+2,@#SEC.RD ; AND SECTOR

```

```

5673 031022 112137 001352      MOVB      (R1)+,2#SEC.DS
5674 031026 112137 001354      MOVB      (R1)+,2#TRK.DS
5675 031032 011137 001350      MOV       (R1),2#CYL.DS
5676 031036 012737 031050 001206  MOV       #2$, $ESCAPE      ; ESCAPE TO 2$ ON ERROR
5677 031044 005740          TST      -(R0)             ; MAKE IT TEST PC+4
5678 031046 104012          ERROR    12              ; REPORT THE ERROR
5679 031050 012737 000107 004210 2$:  MOV       #RECAL DPB.A+2   ; LOAD RECALIBRATE ORDER CODE
5680 031056 004037 027054          JSR      RO,2#CALL.A     ; GO EXECUTE THE COMMAND
5681 031062 005037 001206          CLR      $ESCAPE        ; CLEAR ERROR ESCAPE FLAG
5682 031066 032777 001000 150044  BIT      #SW9,2$SWR      ; LOOP ON ERROR ?
5683 031074 001404          BEQ      4$             ; BR IF NOT
5684 031076 000177 150006          JMP      2$SLPERR       ; RETURN TO ERROR LOOP ADDRESS
5685 031102 062700 000002          3$:  ADD      #2,RO          ; INCREMENT RETURN ADDRESS
5686 031106 012601          4$:  MOV      (SP)+,R1      ; RESTORE R1
5687 031110 000200          RTS      RO             ; EXIT
5688
5689 ; THIS ROUTINE WILL PERFORM A "MASSBUS" INIT. FOLLOWED BY
5690 ; A "RECALIBRATE" ON THE DRIVE UNDER TEST.
5691 ; NOTE: THIS ROUTINE DESTROYS R1 AND R4
5692 ; CALL
5693 ;
5694 ; JSR      RO,SRCH00      ; DO A MASSBUS INIT. AND RECAL
5695 ; RETURN1 ; RETURN HERE IF NO ERROR
5696 ; RETURN2 ; RETURN HERE ON ERROR
5697
5697 031112 005001          SRCH00: CLR      R1          ; INCASE OF ERROR (TYPTIM)
5698 031114 005037 177776          CLR      2#PS
5699 031120 012777 041566 005612  MOV      #ISR,2#RVEC     ; SETUP INTERRUPT VECTOR
5700 031126 013704 036736          MOV      2#RMDR,R4     ; PICKUP ADDRESS OF RMCS1
5701 031132 012764 000040 000010  MOV      #BIT05,2#RMC2(R4) ; MASSBUS INIT.
5702 031140 005037 004276          CLR      2#DTADPB+10   ; TRACK=0; SECTOR=0
5703 031144 005037 004300          CLR      2#DTADPB+12   ; CYLINDER = 0
5704 031150 012737 000107 004270  MOV      #RECAL,2#DTADPB+2 ; COMMAND = RECALIBRATE
5705 031156 005037 001206          CLR      2#$ESCAPE     ; NO ESCAPE ADDRESS
5706 031162 004037 037502          JSR      RO,2#RMO3     ; CALL THE DRIVER
5707 031166 004266          DTADPB ; DPB POINTER
5708 031170 000440          BR      4$             ; QUEUE IS FULL
5709 031172 005737 004304          1$:  TST      DTADPB+16     ; WAIT ON DONE
5710 031176 001775          BEQ      1$
5711 031200 100030          BPL      3$
5712 031202 012737 031256 001206  MOV      #2$, $ESCAPE     ; TAKE NORMAL EXIT IF NO ERROR
5713 031210 013737 004300 001350  MOV      2#DTADPB+12,2#CYL.DS ; ESCAPE TO 2$ ON ERROR
5714 031216 113737 004277 001354  MOVB     2#DTADPB+11,2#TRK.DS ; CYLINDER
5715 031224 113737 004276 001352  MOVB     2#DTADPB+10,2#TRK.DS ; TRACK
5716 031232 012746 004304          MOVB     2#DTADPB+10,2#SEC.DS ; SECTOR
5717 031236 004737 030450          MOV      #DTADPB+16,-(SP) ; STATUS/ERROR INDICATOR ADDRESS
5718 031242 062607          JSR      PC,2#ERINDX   ; FORM DISPATCH INDEX
5719 031244 104041          ADD     (SP)+,PC      ; REPORT PROPER ERROR
5720 031246 104042          ERROR   41
5721 031250 104043          ERROR   42            ; PARITY ERROR
5722 031252 104044          ERROR   43            ; UNSAFE ERROR
5723 031254 104045          ERROR   44            ; NON-I/O ERROR
5724 031256 005720          2$:  ERROR   45            ; I/O ERROR
5725 031260 000404          TST     (R0)+         ; ADJUST FOR ERROR EXIT
5726 031262 005064 000006          BR      4$            ; GO TO THE EXIT
5727 031266 005064 000034          3$:  CLR     RMDA(R4)     ; TRACK AND SECTOR = 0
5728 031272 000200          CLR     RMDC(R4)     ; CYLINDER = 0
5728          4$:  RTS     RO             ; RETURN

```

```

5729
5730 ;THIS IS AN RTI WHICH IS USED BY THE TIMING TESTS & THE SERVO SETTLE DOWN TEST
5731
5732 031274 000002 DORTI: RTI ;RETURN FROM INTERRUPT
5733
5734 ;THIS ROUTINE WILL INITIALIZE THE TIMERS USED BY THE "TIMING ROUTINES"
5735 ;CALL
5736 ; JSR PC,@#STRTMR
5737 ; RETURN
5738
5739 031276 104412 STRTMR: SAVREG ;SAVE R0-R5
5740 031300 012700 001356 MOV #TIM.UP,R0 ;START AT TIM.UP (MINIMUM)
5741 031304 012701 001412 MOV #TIM.PT,R1 ;STOP AT TIM.PT
5742 031310 005020 1$: CLR (R0)+ ;CLEAR
5743 031312 020001 CMP R0,R1 ;DONE?
5744 031314 103775 BLO 1$ ;NO--BRANCH
5745 031316 012710 051776 MOV #BUFFER,(R0) ;SETUP POINTER
5746 031322 012737 077777 001356 MOV #1CBIT15,@#TIM.UP ;SET MINIMUM TIME TO MAXIMUM
5747 031330 012737 077777 001374 MOV #1CBIT15,@#TIM.DN ;POSITIVE NUMBER
5748 031336 104413 RESREG ;RESTORE R0-R5
5749 031340 000207 RTS PC ;RETURN
5750
5751 ;THIS ROUTINE WILL ADD THE ELAPSED TIME TO THE AVERAGE COUNTER AND
5752 ;MAINTAIN THE MINIMUM AND MAXIMUM TIMES.
5753 ;NOTE: THIS ROUTINE DESTROYS R2
5754 ;CALL
5755 ; MOV #TP,R3 ;PARAMETER POINTER
5756 ; MOV FLAG,R5 ;FLAG=0=COUNT UP
5757 ; ;FLAG=-1=COUNT DOWN
5758 ; JSR PC,@#COUNT
5759 ; RETURN
5760
5761 031342 012702 001356 COUNT: MOV #TIM.UP,R2 ;PICKUP THE "UP" POINTER
5762 031346 005705 TST R5 ;USE IT?
5763 031350 001402 BEQ 1$ ;YES--BRANCH
5764 031352 012702 001374 MOV #TIM.DN,R2 ;NO--PICKUP "DOWN" POINTER
5765 031356 027722 150104 1$: CMP @PKC,(R2)+ ;LESS THAN PREVIOUS LOW?
5766 031362 002003 BGE 2$ ;NO--BRANCH
5767 031364 017762 150076 177776 MOV @PKC,-2(R2) ;YES--SAVE IT
5768 031372 027763 150070 000004 2$: CMP @PKC,4(R3) ;LESS THAN THE LOW LIMIT?
5769 031400 002001 BGE 3$ ;NO--BRANCH
5770 031402 005212 INC (R2) ;YES--COUNT IT
5771 031404 005722 3$: TST (R2)+ ;ADVANCE THE POINTER
5772 031406 027722 150054 CMP @PKC,(R2)+ ;GREATER THAN PREVIOUS HIGH?
5773 031412 003403 BLE 4$ ;NO--BRANCH
5774 031414 017762 150046 177776 MOV @PKC,-2(R2) ;YES--SAVE IT
5775 031422 027763 150040 000006 4$: CMP @PKC,6(R3) ;GREATER THAN THE HIGH LIMIT?
5776 031430 003401 BLE 5$ ;NO--BRANCH
5777 031432 005212 INC (R2) ;YES--COUNT IT
5778 031434 005722 5$: TST (R2)+ ;ADVANCE THE POINTER
5779 031436 067722 150024 ADD @PKC,(R2)+ ;ADD THIS COUNT TO THE TOTAL
5780 031442 005522 ADC (R2)+
5781 031444 005212 INC (R2) ;COUNT THIS READING
5782 031446 022737 060266 001412 CMP #BUFFER+(4*814),@#TIM.PT ;SAVE THIS COUNT?
5783 031454 101406 BLOS 6$ ;NO--BRANCH
5784 031456 017777 150004 147726 MOV @PKC,@TIM.PT ;YES--WELL SAVE IT THEN

```

```

5785 031464 062737 000002 001412 ADD #2,2#TIM.PT ;ADVANCE THE POINTER
5786 031472 000207 6S: RTS RC ;RETURN
5787
5788 ; THIS ROUTINE IS USED TO TYPE THE MINIMUM,
5789 ; MAXIMUM, AND AVERAGE TIMES FOR THE TIMING TESTS
5790 ; IT WILL ALSO CHECK THE TIMES TO ENSURE
5791 ; THEY ARE WITHIN TOLERANCE AND IF NOT FLAG THE BAD TIMES.
5792 ; NOTE: THIS ROUTINE DESTROYS R2-R5
5793 CALL
5794 JSR RO,2#TYPTIM ;GO REPORT THE TIMES
5795 TABLE ;POINT TO THE PROPER TABLE
5796 RETURN
5797
5798 ;TABLE:MSGADR1 ;ADDRESS OF ASCIZ MESSAGE NUMBER 1
5799 MSGADR2 ;ADDRESS OF ASCIZ MESSAGE NUMBER 2
5800 MIN.ALLOWED ;MINIMUM TIME ALLOWED
5801 MAX.ALLOWED ;MAXIMUM TIME ALLOWED
5802
5803 031474 012002 TYPTIM: MOV (R0)+,R2 ;PICKUP THE TABLE POINTER
5804 031476 032777 000100 147434 BIT #SW06,2SWR ;INHIBIT TIME REPORTS?
5805 031504 001145 BNE 7$ ;YES--BRANCH
5806 031506 012237 031526 MOV (R2)+,2$ ;ADDRESS OF MESSAGE NUMBER 1
5807 031512 012205 MOV (R2)+,R5 ;ADDRESS OF MESSAGE NUMBER 2
5808 031514 012203 MOV (R2)+,R3 ;PICKUP THE LOW LIMIT
5809 031516 011202 MOV (R2),R2 ;AND THE HIGH LIMIT
5810 031520 012704 001356 MOV #TIM.UP,R4 ;PARAMETER POINTER
5811 031524 104401 1$: TYPE ;TYPE THE MESSAGE
5812 031526 000000 2$: .WORD 0 ;ASCIZ MESSAGE POINTER GOES HERE
5813 031530 005764 000014 TST 14(R4) ;DID ANY COUNTS OCCUR?
5814 031534 001527 BEQ 6$ ;NO--BRANCH
5815 031536 104401 046001 TYPE MSGMIN ;"MIN="
5816 031542 012446 MOV (R4)+,-(SP) ;PUT (R4)+ ON THE STACK
5817 031544 004737 025242 JSR PC,2#$$SB2D ;CHANGE (R4)+ TO DECIMAL ASCIZ
5818 031550 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5819 031554 104401 046026 TYPE MSGOUS ;"0 US"
5820 031560 005724 TST (R4)+ ;ANY SEEKS BELOW THE LOW LIMIT
5821 031562 001421 BEQ 3$ ;NO--BRANCH
5822 031564 104401 046141 TYPE MSG.SP ;" "
5823 031570 016446 MOV -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
5824 031574 004737 025242 JSR PC,2#$$SB2D ;CHANGE -2(R4) TO DECIMAL ASCIZ
5825 031600 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5826 031604 104401 046033 TYPE MBELOW ;"BELOW THE MINIMUM OF"
5827 031610 010346 MOV R3,-(SP) ;PUT R3 ON THE STACK
5828 031612 004737 025242 JSR PC,2#$$SB2D ;CHANGE R3 TO DECIMAL ASCIZ
5829 031616 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5830 031622 104401 046026 TYPE MSGOUS ;"0 US"
5831 031626 104401 046010 3$: TYPE MSGMAX ;"MAX="
5832 031632 012446 MOV (R4)+,-(SP) ;PUT (R4)+ ON THE STACK
5833 031634 004737 025242 JSR PC,2#$$SB2D ;CHANGE (R4)+ TO DECIMAL ASCIZ
5834 031640 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5835 031644 104401 046026 TYPE MSGOUS ;"0 US"
5836 031650 005724 TST (R4)+ ;ANY SEEKS ABOVE THE HIGH LIMIT
5837 031652 000421 BR 4$ ;NO--BRANCH
5838 031654 104401 046141 TYPE MSG.SP ;YES--REPORT HOW MANY
5839 031660 016446 177776 MOV -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
5840 031664 004737 025242 JSR PC,2#$$SB2D ;CHANGE -2(R4) TO DECIMAL ASCIZ

```

```

5841 031670 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5842 031674 104401 046062 TYPE MABOVE ;"ABOVE THE MAXIMUM OF"
5843 031700 010246 MOV R2,-(SP) ;PUT R2 ON THE STACK
5844 031702 004737 025242 JSR PC,2#$$SB2D ;CHANGE R2 TO DECIMAL ASCIZ
5845 031706 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5846 031712 104401 046026 TYPE ,MSGOUS
5847 031716 104401 046017 4$: TYPE ,MSGAVG ;"AVG="
5848 031722 012446 MOV (R4)+,-(SP) ;FORM THE AVERAGE
5849 031724 012446 MOV (R4)+,-(SP)
5850 031726 012446 MOV (R4)+,-(SP)
5851 031730 004737 025634 JSR PC,2#$$DIV
5852 031734 006126 ROL (SP)+ ;IS THE REMAINDER OVER HALF?
5853 031736 100001 BPL 5$ ;NO--BRANCH
5854 031740 005216 INC (SP) ;YES--ROUND UP
5855 031742 5$:
5856 031742 004737 025242 JSR PC,2#$$SB2D ;CHANGE TO DECIMAL ASCIZ
5857 031746 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5858 031752 104401 046026 TYPE ,MSGOUS
5859 031756 104401 046141 TYPE ,MSG.SP
5860 031762 016446 177776 MOV -2(R4),-(SP) ;PUT -2(R4) ON THE STACK
5861 031766 004737 025242 JSR PC,2#$$SB2D ;CHANGE -2(R4) TO DECIMAL ASCIZ
5862 031772 004737 025472 JSR PC,2#$$SUPRS ;TYPE WITHOUT LEADING ZEROS
5863 031776 104401 046111 TYPE ,MSGNUM ;"SEEKS TIMED"
5864 032002 010537 031526 MOV R5,2$ ;NEXT MESSAGE POINTER
5865 032006 001404 BEQ 7$ ;IF NONE EXIT
5866 032010 005005 CLR R5 ;NO MORE THAN 2
5867 032012 000644 BR 1$
5868 032014 104401 046126 6$: TYPE ,MSGNON
5869 032020 000200 7$: RTS R0 ;EXIT
5870
5871 ;THIS SUBROUTINE WILL INCREMENT THE TRACK
5872 ;NUMBER (R2) BY THE AMOUNT SPECIFIED BY 'IT'.
5873 ;CALL
5874 ; JSR R0,2#INCTRK
5875 ; RETURN1 ;TRACK NUMBER GREATER THAN LT15
5876 ; RETURN2 ;TRACK NUMBER INCREMENTED
5877
5878 032022 020237 001602 INCTRK: CMP R2,2#LT ;LAST TRACK COMPLETED?
5879 032026 001410 BEQ 2$ ;YES--EXIT
5880 032030 063702 001604 ADD 2#IT,R2 ;NO--UPDATE TRACK
5881 032034 020237 001602 CMP R2,2#LT ;TRACK TO BIG?
5882 032040 003402 BLE 1$ ;NO--EXIT
5883 032042 013702 001602 MOV 2#LT,R2 ;YES--SET TRACK TO LAST TRACK
5884 032046 005720 1$: TST (R0)+ ;ADJUST FOR RETURN 2
5885 032050 000200 2$: RTS R0 ;RETURN
5886
5887
5888 ;THIS SUBROUTINE WILL INCREMENT THE CYLINDER
5889 ;NUMBER (R1) BY THE AMOUNT SPECIFIED BY 'IC'.
5890 ;CALL
5891 ; JSR R0,2#INCCYL
5892 ; RETURN1 ;CYLINDER NUMBER GREATER THAN LC15
5893 ; RETURN2 ;CYLINDER NUMBER INCREMENTED
5894
5895 032052 020137 001574 INCCYL: CMP R1,2#LC ;LAST CYLINDER COMPLETED?
5896 032056 001410 BEQ 2$ ;YES--EXIT

```

```

5897 032060 063701 001576      ADD    2#IC,R1      ;NO--UPDATE CYLINDER
5898 032064 020137 001574      CMP    R1,2#LC     ;CYLINDER TO BIG?
5899 032070 003402              BLE    1$          ;NO--EXIT
5900 032072 013701 001574      MOV    2#LC,R1     ;YES--SET CYLINDER TO LAST CYLINDER
5901 032076 005720              1$:   TST    (R0)+   ;ADJUST FOR RETURN 2
5902 032100 000200              2$:   RTS     R0    ;RETURN
5903
5904      ;THIS ROUTINE DECREASES THE SECTOR ADDRESS.
5905      ;CALL
5906      ;
5907      ;   CLR    -(SP)      ;CLEAR THE STACK
5908      ;   JSR    PC,DECSEC ;SUBROUTINE ENTRY
5909      ;   RETURN
5910 032102 113766 004314 000002  DECSEC: MOV    RM.REG+RMDA,2(SP) ;PUT THE SECTOR ADDRESS ON THE STACK
5911 032110 005366 000002              DEC    2(SP)      ;DECREMENT THE ADDRESS
5912 032114 100003              BPL    1$          ;BR IF NOT CORRECTION NEEDED
5913 032116 013766 001716 000002  1$:   MOV    PRMLT+22.,2(SP) ;OVERFLOW OCCURED. FORC TO MAXIMUM ADDRESS
5914 032124 000207              RTS     PC        ;RETURN
5915
5916      ;THIS SUBROUTINE IS USED TO FILL THE DATA BUFFER
5917      ;WITH ADDRESSES FROM 0 TO 21 WITH EACH ADDRESS
5918      ;BEING STORED IN 256 CONSECUTIVE LOCATIONS
5919      ;CALL
5920      ;
5921      ;   JSR    PC,2#FILBUF
5922      ;   RETURN
5923 032126 104412              FILBUF: SAVREG
5924 032130 005000              CLR    R0         ;SAVE R0 - R5
5925 032132 012701 051776      MOV    #BUFFER,R1 ;FIRST DISK ADDRESS
5926 032136 012702 000400      1$:   MOV    #256,R2  ;START FILLING HERE
5927 032142 010021              2$:   MOV    R0,(R1)+ ;DO 256 WORDS
5928 032144 005302              DEC    R2         ;STORE
5929 032146 003375              BGT    2$         ;MORE?
5930 032150 005200              INC    R0         ;YES--BRANCH
5931 032152 023700 001712      CMP    PRMLT+22,R0 ;NO--UPDATE DISK ADDRESS
5932 032156 103367              BHS    1$         ;DONE?
5933 032160 104413              RESREG
5934 032162 000207              RTS     PC        ;RESTORE R0 - R5
5935
5936      ;THIS ROUTINE WILL CLEAR THE BUFFER BY
5937      ;SETTING EACH WORD TO "177400".
5938      ;CALL
5939      ;
5940      ;   JSR    R0,2#CLRBUF
5941      ;   RETURN
5942 032164 104412              CLRBUF: SAVREG
5943 032166 012701 177400      MOV    #177400,R1 ;SAVE R0 - R5
5944 032172 012702 051776      MOV    #BUFFER,R2 ;WORD TO FILL BUFFER WITH
5945 032176 012703 077776      MOV    #BUFFER+512.*22,R3 ;FIRST ADDRESS OF BUFFER
5946 032202 010122              1$:   MOV    R1,(R2)+  ;LAST ADDRESS+2 OF BUFFER
5947 032204 010122              MOV    R1,(R2)+  ;FILL WORDS 1, 9,...249,...5625
5948 032206 010122              MOV    R1,(R2)+  ;FILL WORDS 2,10,...250,...5626
5949 032210 010122              MOV    R1,(R2)+  ;FILL WORDS 3,11,...251,...5627
5950 032212 010122              MOV    R1,(R2)+  ;FILL WORDS 4,12,...252,...5628
5951 032214 010122              MOV    R1,(R2)+  ;FILL WORDS 5,13,...253,...5629
5952 032216 010122              MOV    R1,(R2)+  ;FILL WORDS 6,14,...254,...5630
                    MOV    R1,(R2)+  ;FILL WORDS 7,15,...255,...5631

```



```

5953 032220 010122      MOV      R1,(R2)+      ;FILL WORDS 8,16,...256,...5632
5954 032222 020203      CMP      R2,R3        ;DONE?
5955 032224 103766      BLO      1$           ;NO--BRANCH
5956 032226 104413      RESREG   RO           ;RESTORE RO - R5
5957 032230 000200      RTS      RO           ;RETURN FROM CALL
5958
5959
5960      ; THIS ROUTINE IS USED TO CHECK THE DATA BUFFER
5961      ; FOR ADDRESSES 0 THROUGH 21 WITH EACH ADDRESS
5962      ; BEING STORED IN 256 CONSECUTIVE LOCATIONS
5963      ; CALL
5964      ; JSR      RO,#CKSCTR
5965      ; RETURN
5966 032232 104412      CKSCTR: SAVREG        ;SAVE RO - R5
5967 032234 162706 000004    SUB      #4,SP        ;RESERVE TEMP. STORAGE AREA
5968 032240 005001      CLR      R1           ;FIRST SECTOR
5969 032242 012716 051776    MOV      #BUFFER,(SP) ;FIRST ADDRESS OF DATA BUFFER
5970 032246 005066 000002    CLR      2(SP)        ;NO ERRORS
5971 032252 012702 000020    1$:     MOV      #16.,R2 ;LOOP COUNT (16*16=256)
5972 032256 011603      MOV      (SP),R3     ;GET 1ST ADDRESS OF THIS SECTORS DATA
5973 032260
5974 032260 020123      2$:     CMP      R1,(R3)+    ;WORD 1
5975 032262 001063      BNE      7$          ;BRANCH IF BAD
5976 032264 020123      CMP      R1,(R3)+    ;WORD 2
5977 032266 001061      BNE      7$          ;BRANCH IF BAD
5978 032270 020123      CMP      R1,(R3)+    ;WORD 3
5979 032272 001057      BNE      7$          ;BRANCH IF BAD
5980 032274 020123      CMP      R1,(R3)+    ;WORD 4
5981 032276 001055      BNE      7$          ;BRANCH IF BAD
5982 032300 020123      CMP      R1,(R3)+    ;WORD 5
5983 032302 001053      BNE      7$          ;BRANCH IF BAD
5984 032304 020123      CMP      R1,(R3)+    ;WORD 6
5985 032306 001051      BNE      7$          ;BRANCH IF BAD
5986 032310 020123      CMP      R1,(R3)+    ;WORD 7
5987 032312 001047      BNE      7$          ;BRANCH IF BAD
5988 032314 020123      CMP      R1,(R3)+    ;WORD 8
5989 032316 001045      BNE      7$          ;BRANCH IF BAD
5990 032320 020123      CMP      R1,(R3)+    ;WORD 9
5991 032322 001043      BNE      7$          ;BRANCH IF BAD
5992 032324 020123      CMP      R1,(R3)+    ;WORD 10
5993 032326 001041      BNE      7$          ;BRANCH IF BAD
5994 032330 020123      CMP      R1,(R3)+    ;WORD 11
5995 032332 001037      BNE      7$          ;BRANCH IF BAD
5996 032334 020123      CMP      R1,(R3)+    ;WORD 12
5997 032336 001035      BNE      7$          ;BRANCH IF BAD
5998 032340 020123      CMP      R1,(R3)+    ;WORD 13
5999 032342 001033      BNE      7$          ;BRANCH IF BAD
6000 032344 020123      CMP      R1,(R3)+    ;WORD 14
6001 032346 001031      BNE      7$          ;BRANCH IF BAD
6002 032350 020123      CMP      R1,(R3)+    ;WORD 15
6003 032352 001027      BNE      7$          ;BRANCH IF BAD
6004 032354 020123      CMP      R1,(R3)+    ;WORD 16
6005 032356 001025      BNE      7$          ;BRANCH IF BAD
6006 032360 005302      DEC      R2           ;FINISHED WITH THIS SECTORS DATA?
6007 032362 001336      BNE      2$         ;NO--BRANCH
6008 032364 062716 001000    3$:     ADD      #512.,(SP)  ;YES--FIRST ADDRESS OF NEXT SECTOR

```

```

6009 032370 005201          INC      R1          ; MOVE TO NEXT SECTOR
6010 032372 023701 001712  CMP      PRMLM+22,R1 ; DONE?
6011 032376 103325          BHS      1$          ; NO--BRANCH
6012 032400 005766 000002 4$:      TST      2(SP)      ; ERROR OCCUR?
6013 032404 001406          BFO      5$          ; NO--BRANCH
6014 032406 123737 001444 001103  C1PB    2#ERR.CT,2#SERFLG ; MAX. ERROR OCCUPED?
6015 032414 101002          PHI      6$          ; NO--BRANCH
6016 032416 013700 001332 5$:      MOV      2#BYPASS,R0 ; TAKE ERROR EXIT
6017 032422 062706 000004 6$:      ADD      #4,SP      ; FREE TEMP. AREA
6018 032426 104413          RESREG          ; RESTORE R0 - R5
6019 032430 000200          RTS      R0          ; RETURN FROM CALL
6020 032432 010304 7$:      MOV      R3,R4      ; FORM WORD NUMBER AND
6021 032434 161604          SUB      (SP),R4    ; ADDRESS TO CONTINUE FROM
6022 032436 010405          MOV      R4,R5
6023 032440 006204          ASR      R4          ; WORD NUMBER
6024 032442 042705 177740  BIC      #1C37,R5
6025 032446 001002          BNE      8$          ; BRANCH IF NOT A MULTIPLE OF 16
6026 032450 012705 000040 8$:      MOV      #40,R5    ; SFT TO WORD 16
6027 032454 006305          ASL      R5
6028 032456 062705 032260 9$:      ADD      #25,R5    ; ADDRESS
6029 032462 016337 177775 001126  MOV      -2(R3),2#SBDDAT ; SAVE BAD DATA
6030 032470 005766 000002  TST      2(SP)      ; FIRST ERROR?
6031 032474 001015          BNE      10$         ; NO--BRANCH
6032 032476 013737 004300 001350  MOV      2#DTADPB+12,2#CYL.DS ; CYLINDER NUMBER
6033 032504 113737 004277 001354  MOV      2#DTADPB+11,2#TRK.DS ; TRACK NUMBER
6034 032512 012737 032522 001206  MOV      9$,SESCAPE ; ESCAPE TO 9$ ON ERROR
6035 032520 104021          EPROR    21          ; REPORT THE ERROR
6036 032522 105166 000002 9$:      COMB    2(SP)      ; SET ERROR SWITCH
6037 032526 000404          BR      11$
6038 032530          BR      10$
6039 032530 012737 032540 001206 10$:     MOV      #11$,SESCAPE ; ESCAPE TO 11$ ON ERROR
6040 032536 104022          ERROR    22          ; REPORT THE ERROR
6041 032540 032777 001000 146372 11$:     BIT      #SW09,2$SWR ; LOOP ON ERROR?
6042 032546 001323          BNE      5$          ; YES
6043 032550 032777 000002 146362  BIT      #SW01,2$SWR ; STOP DATA COMPARE?
6044 032556 001310          BNE      4$          ; YES--BRANCH
6045 032560 123737 001444 001103  CMPB    2#ERR.CT,2#SERFLG ; MAX. ERRORS?
6046 032566 101713          BLOS    5$          ; YES--BRANCH
6047 032570 032777 000040 146342  BIT      #SW05,2$SWR ; REPORT ONLY 1ST ERROR PER SECTOR?
6048 032576 001272          BNE      3$          ; YES--BRANCH
6049 032600 000115          JMP      (R5)
6050
6051          ; THIS ROUTINE WILL MOVE THE 16 WORDS OF THE
6052          ; DESIRED PATTERN INTO THE DATA BUFFER.
6053          ; CALL
6054          ;
6055          ;      MOV      #NX,R0          ; PATTERN NUMBER INDEX TO R0
6056          ;      JSR      PC,2#SETBUF
6057 032602 104412  SETBUF: SAVREG          ; SAVE R0 - R5
6058 032604 012701 051776  MOV      #BUFFER,R1 ; FIRST ADDRESS
6059 032610 013702 004272  MOV      2#DTADPB+4,R2 ; WORD COUNT
6060 032614 016003 003146 1$:      MOV      PAT,PT(R0),R3 ; PICKUP PATTERN POINTER
6061 032620 012321          MOV      (R3)+,(R1)+ ; MOVE WORD 1 INTO DATA BUFFER
6062 032622 012321          MOV      (R3)+,(R1)+ ; MOVE WORD 2 INTO DATA BUFFER
6063 032624 012321          MOV      (R3)+,(R1)+ ; MOVE WORD 3 INTO DATA BUFFER
6064 032626 012321          MOV      (R3)+,(R1)+ ; MOVE WORD 4 INTO DATA BUFFER
    
```

6065	032630	012321		MOV	(R3)+,(R1)+	: MOVE WORD 5 INTO DATA BUFFER
6066	032632	012321		MOV	(R3)+,(R1)+	: MOVE WORD 6 INTO DATA BUFFER
6067	032634	012321		MOV	(R3)+,(R1)+	: MOVE WORD 7 INTO DATA BUFFER
6068	032636	012321		MOV	(R3)+,(R1)+	: MOVE WORD 8 INTO DATA BUFFER
6069	032640	012321		MOV	(R3)+,(R1)+	: MOVE WORD 9 INTO DATA BUFFER
6070	032642	012321		MOV	(R3)+,(R1)+	: MOVE WORD 10 INTO DATA BUFFER
6071	032644	012321		MOV	(R3)+,(R1)+	: MOVE WORD 11 INTO DATA BUFFER
6072	032646	012321		MOV	(R3)+,(R1)+	: MOVE WORD 12 INTO DATA BUFFER
6073	032650	012321		MOV	(R3)+,(R1)+	: MOVE WORD 13 INTO DATA BUFFER
6074	032652	012321		MOV	(R3)+,(R1)+	: MOVE WORD 14 INTO DATA BUFFER
6075	032654	012321		MOV	(R3)+,(R1)+	: MOVE WORD 15 INTO DATA BUFFER
6076	032656	012321		MOV	(R3)+,(R1)+	: MOVE WORD 16 INTO DATA BUFFER
6077	032660	062702	000020	ADD	#16.,R2 ; DONE?	
6078	032664	001353		BNE	1\$: NO--BRANCH
6079	032666	104413		RESREG		: RESTORE R0 - R5
6080	032670	000207		RTS	PC	: RETURN
6081						
6082						: THIS ROUTINE COMPARES A 16 WORD DATA PATTERN
6083						: AGAINST THE DATA BUFFER
6084				CALL		
6085						
6086				MOV	#NX,R0	: PATTERN NUMBER INDEX TO R0
6087				JSR	PC,#DATCMP	
6088				RETURN		
6089	032672	104412		DATCMP:	SAVREG	: SAVE R0 - R5
6090	032674	012701	051776	MOV	#BUFFER,R1	: FIRST ADDRESS OF BUFFER
6091	032700	013702	004272	MOV	#OTADPB+4,R2	: WORD COUNT
6092	032704	005046		CLR	-(SP)	: NO ERROR
6093	032706	016003	003146	1\$:	MOV	PAT.PT(R0),R3
6094	032712			2\$:		
6095	032712	162321		SUB	(R3)+,(R1)+	: CHECK WORD 1
6096	032714	001044		BNE	4\$: BRANCH IF DIFFERENT
6097	032716	162321		SUB	(R3)+,(R1)+	: CHECK WORD 2
6098	032720	001042		BNE	4\$: BRANCH IF DIFFERENT
6099	032722	162321		SUB	(R3)+,(R1)+	: CHECK WORD 3
6100	032724	001040		BNE	4\$: BRANCH IF DIFFERENT
6101	032726	162321		SUB	(R3)+,(R1)+	: CHECK WORD 4
6102	032730	001036		BNE	4\$: BRANCH IF DIFFERENT
6103	032732	162321		SUB	(R3)+,(R1)+	: CHECK WORD 5
6104	032734	001034		BNE	4\$: BRANCH IF DIFFERENT
6105	032736	162321		SUB	(R3)+,(R1)+	: CHECK WORD 6
6106	032740	001032		BNE	4\$: BRANCH IF DIFFERENT
6107	032742	162321		SUB	(R3)+,(R1)+	: CHECK WORD 7
6108	032744	001030		BNE	4\$: BRANCH IF DIFFERENT
6109	032746	162321		SUB	(R3)+,(R1)+	: CHECK WORD 8
6110	032750	001026		BNE	4\$: BRANCH IF DIFFERENT
6111	032752	162321		SUB	(R3)+,(R1)+	: CHECK WORD 9
6112	032754	001024		BNE	4\$: BRANCH IF DIFFERENT
6113	032756	162321		SUB	(R3)+,(R1)+	: CHECK WORD 10
6114	032760	001022		BNE	4\$: BRANCH IF DIFFERENT
6115	032762	162321		SUB	(R3)+,(R1)+	: CHECK WORD 11
6116	032764	001020		BNE	4\$: BRANCH IF DIFFERENT
6117	032766	162321		SUB	(R3)+,(R1)+	: CHECK WORD 12
6118	032770	001016		BNE	4\$: BRANCH IF DIFFERENT
6119	032772	162321		SUB	(R3)+,(R1)+	: CHECK WORD 13
6120	032774	001014		BNE	4\$: BRANCH IF DIFFERENT

```

6121 032776 162321 SUB (R3)+,(R1)+ ;CHECK WORD 14
6122 033060 001012 BNE 4$ ;BRANCH IF DIFFERENT
6123 033002 162321 SUB (R3)+,(R1)+ ;CHECK WORD 15
6124 033004 001010 BNE 4$ ;BRANCH IF DIFFERENT
6125 033006 162321 SUB (R3)+,(R1)+ ;CHECK WORD 16
6126 033010 001006 BNE 4$ ;BRANCH IF DIFFERENT
6127 033012 062702 000020 ADD #16.,R2 ;DONE ?
6128 033016 001333 BNE 1$ ;NO--BRANCH
6129 033020 005726 3$: TST (SP)+ ;YES -- CLEAN UP STACK
6130 033022 104413 RESREG ;RESTORE R0 - R5
6131 033024 000207 RTS PC
6132 033026 010104 4$: MOV R1,R4 ;FORM THE WORD NUMBER
6133 033030 162704 051776 SUB #BUFFER,R4
6134 033034 006204 ASR R4 ;WORD NUMBER
6135 033036 010305 MOV R3,R5 ;FORM ADDRESS TO CONTINUE FROM
6136 033040 166005 003146 SUB PAT.PT(R0),R5
6137 033044 006305 ASL R5
6138 033046 062705 032712 ADD #2$,R5 ;ADDRESS
6139 033052 064341 ADD -(R3)-,(R1) ;RECONSTRUCT THE BAD WORD
6140 033054 010137 001122 MOV R1,#$BDAC ;SAVE THE ERROR INFORMATION
6141 033060 010337 001120 MOV R3,#$GDAOR
6142 033064 012137 001126 MOV (R1)+,#$BDDAT
6143 033070 012337 001124 MOV (R3)+,#$GDDAT
6144 033074 005716 TST (SP) ;1ST DATA COMPARE ERROR?
6145 033076 001023 BNE 6$ ;NO--BRANCH
6146 033100 013737 004300 001350 MOV #DTADPB+12,#CYL.DS ;CYLINDER
6147 033106 113737 004277 001354 MOVB #DTADPB+11,#TRK.DS ;TRACK
6148 033114 113737 004276 001352 MOVB #DTADPB+10,#SEC.DS ;SECTOR
6149 033122 016600 000016 MOV 16(SP),R0 ;GET TEST PC+4
6150 033126 012737 033136 001206 MOV #5$,SE$CAPE ;ESCAPE TO 5$ ON ERROR
6151 033134 104013 ERROR 13 ;REPORT THE ERROR
6152 033136 016600 000014 5$: MOV 14(SP),R0 ;PATTERN NUMBER INDEX
6153 033142 105116 COMB (SP) ;SET THE ERROR SWITCH
6154 033144 000404 BR 7$
6155 033146 6$:
6156 033146 012737 033156 001206 MOV #7$,SE$CAPE ;ESCAPE TO 7$ ON ERROR
6157 033154 104014 ERROR 14 ;REPORT THE ERROR
6158 033156 032777 000002 145754 7$: BIT #SW01,#SWR ;STOP DATA COMPARE?
6159 033164 001315 BNE 3$ ;YES--EXIT
6160 033166 123737 001444 001103 CMPB #ERR.CT,#SERFLG ;MAX. ERRORS?
6161 033174 101004 BHI 8$ ;NO--BRANCH
6162 033176 013766 001332 000016 MOV #BYPASS,16(SP) ;YES--ERROR EXIT
6163 033204 000705 BR 3$
6164 033206 8$: JMP (R5) ;NO--CONTINUE AT NEXT WORD
6165
6166 ;THIS ROUTINE WILL FILL THE DATA BUFFER (256*22 WORDS) WITH
6167 ;A RANDOM PATTERN. THE FIRST TWO WORDS OF EVERY 256 WILL
6168 ;BE THE BASE OF THE RANDOM NUMBER GENERATOR FOR THE
6169 ;NEXT 254 WORDS.
6170 ;NOTE: THIS ROUTINE DESTROYS R1 AND R2
6171 ;CALL
6172 ; JSR R0,#FILRAN
6173 ; RETURN
6174
6175 033210 012701 051776 FILRAN: MOV #BUFFER,R1
6176 033214 013702 001712 MOV PRMLMT+22,R2 ;MAXIMUM NUMBER OF SECTORS

```

6177 033220 004037 033430
6178 033224 005302
6179 033226 100374
6180 033230 000200
6181
6182
6183
6184
6185
6186
6187
6188
6189
6190 033232 013746 025630
6191 033236 013746 025632
6192 033242 012702 052776
6193 033246 012701 053776
6194 033252 010103
6195 033254 011237 025632
6196 033260 016237 000002 025630
6197 033266 004037 033430
6198 033272 012637 025632
6199 033276 012637 025630
6200 033302 005046
6201 033304 162322
6202 033306 001441
6203 033310 012737 033362 001206
6204 033316 064342
6205 033320 010237 001122
6206 033324 010337 001120
6207 033330 012237 001126
6208 033334 012337 001124
6209 033340 010204
6210 033342 162704 052776
6211 033346 006204
6212 033350 005716
6213 033352 001002
6214 033354 105116
6215 033356 104015
6216 033360 104016
6217 033362 032777 001000 145550
6218 033370 001012
6219 033372 123737 001444 001103
6220 033400 101406
6221 033402 032777 000002 145530
6222 033410 001002
6223 033412 020103
6224 033414 101333
6225 033416 005726
6226 033420 001402
6227 033422 013700 001332
6228 033426 000200
6229
6230
6231
6232

```
1$: JSR RO, @#RANPAT  
DEC R2  
BPL 1$  
RTS RO  
  
: THIS ROUTINE USES THE FIRST TWO WORDS OF THE  
: READ BUFFER TO GENERATED A RANDOM PATTERN. THEN  
: THE READ BUFFER IS COMPARED TO THE PATTERN GENERATED.  
: NOTE: THIS ROUTINE DESTROYS R1-R4  
: CALL  
: JSR RO, @#RANCK  
: RETURN  
  
RANCK: MOV @#$HINUM, -(SP) ;SAVE THE PRESENT RANDOM NUMBER  
MOV @#$LONUM, -(SP)  
MOV #BUFFER+512., R2 ;READ BUFFER ADDRESS  
MOV #BUFFER+1024., R1 ;RANDOM PATTERN ADDRESS  
MOV R1, R3 ;COPY IT INTO R3 FOR LATER USE  
MOV (R2), @#$LONUM ;PRIME THE RANDOM NUMBER GENERATOR  
MOV 2(R2), @#$HINUM  
JSR RO, @#RANPAT ;GENERATE A RANDOM PATTERN  
MOV (SP)+, @#$LONUM ;RESTORE PRESENT RANDOM NUMBER  
MOV (SP)+, @#$HINUM  
CLR -(SP)  
1$: SUB (R3)+, (R2)+ ;NO ERRORS  
BEQ 4$ ;ARE THESE TWO WORDS DIFFERENT?  
MOV #3$ $ESCAPE ;NO--BRANCH  
ADD -(R3), -(R2) ;ESCAPE TO 3$ ON ERROR  
MOV R2, @#$BDADR ;RECREATE THE BAD WORD  
MOV R3, @#$GDADR ;ADDRESS OF BAD DATA  
MOV (R2)+, @#$BDAT ;ADDRESS OF GOOD DATA  
MOV (R3)+, @#$GDAT ;BAD DATA  
MOV R2, R4 ;GOOD DATA  
SUB #BUFFER+512., R4 ;FORM WORD NUMBER (1 TO 256)  
ASR R4  
TST (SP) ;FIRST ERROR  
BNE 2$ ;NO--BRANCH  
COMB (SP) ;YES--SET ERROR SWITCH  
ERROR 15 ;REPORT THE ERROR  
ERROR 16 ;REPORT THE ERROR  
3$: BIT #SW09, @SWR ;LOOP ON ERROR?  
BNE 5$ ;YES--BRANCH  
CMPB @#ERR.CT, @#SERFLG ;MAX. ERRORS OCCURRED?  
BLOS 5$ ;YES--BRANCH  
BIT #SW01, @SWR ;STOP COMPARING?  
BNE 5$ ;YES--BRANCH  
4$: CMP R1, R3 ;ALL DATA BEEN COMPARED?  
BHI 1$ ;NO--BRANCH  
5$: TST (SP)+ ;ERROR OCCUR?  
BEQ 6$ ;NO--BRANCH  
6$: MOV @#BYPASS, RO ;TAKE ERROR EXIT  
RTS RO ;EXIT
```

: THIS ROUTINE FILLS A 256 WORD BUFFER WITH A RANDCM
: PATTERN OF WHICH THE FIRST TWO WORDS ARE THE BASE
: OF THE PATTERN.

```

6233 ;CALL
6234 ;
6235 ;   MOV   #ADR,R1      ;ADDRESS OF THE BUFFER
6236 ;   JSR   RO,@RANPAT
6237 ;   RETURN
6238 033430 010246          RANPAT: MOV   R2,-(SP)      ;SAVE R2
6239 033432 012702 000200  MOV   #256./2.,R2    ;GENERATE 256 WORDS
6240 033436 000402          BR    2$
6241 033440 004737 025532 1$:   JSR   PC,@$RAND    ;GENERATE A RANDOM NUMBER
6242 033444 013721 025632 2$:   MOV   @#$LONUM,(R1)+ ;PUT LOW WORD IN BUFFER
6243 033450 013721 025630  MOV   @#$SHINUM,(R1)+ ;PUT HIGH WORD IN BUFFER
6244 033454 005302          DEC   R2              ;DONE?
6245 033456 003370          BGT   1$              ;NO--BRANCH
6246 033460 012602          MOV   (SP)+,R2        ;RESTORE R2
6247 033462 000200          RTS    RO             ;EXIT
6248
6249 ;THIS ROUTINE GENERATES RANDOM CYLINDER, TRACK, AND SECTOR
6250 ;ADDRESSES AND SAVES THEM IN THE DPB (DTADPB+10, 11 & DTADPB+12).
6251 ;NOTE: THIS ROUTINE DESTROYS R1-R3
6252 ;CALL
6253 ;   JSR   RO,@RANADR
6254 ;   RETURN
6255
6256 033464 004737 025532  RANADR: JSR   PC,@$RAND    ;GENERATE A RANDOM NUMBER
6257 033470 113701 025632  MOVB  @#$LONUM,R1    ;FORM SECTOR IN R1
6258 033474 113702 025633  MOVB  @#$LONUM+1,R2 ;FORM TRACK IN R2
6259 033500 013703 025630  MOV   @#$SHINUM,R3 ;FORM CYLINDER IN R3
6260 033504 105701          TSTB  R1              ;ENSURE THE SECTOR IS BETWEEN 0 AND 31
6261 033506 002403          BLT   2$
6262 033510 123701 001712 1$:   CMPB  PRMLMT+22,R1  ;CHECK MAXIMUM SECTOR ADDRESS
6263 033514 103003          BHIS  3$
6264 033516 000241          CLC
6265 033520 106001          RORB  R1
6266 033522 000772          BR    1$
6267 033524 105702          TSTB  R2              ;ENSURE THE TRACK IS BETWEEN 0 AND 4
6268 033526 002403          BLT   5$
6269 033530 122702 000005 4$:   CMPB  #5,R2
6270 033534 003003          BGT   6$
6271 033536 000241          CLC
6272 033540 106002          RORB  R2
6273 033542 000772          BR    4$
6274 033544 023703 001572 6$:   CMP   @#FC,R3        ;ENSURE THE CYLINDER IS BETWEEN FC AND LC
6275 033550 003413          BLE  7$
6276 033552 000241          CLC
6277 033554 006003          ROR   R3
6278 033556 005503          ADC   R3
6279 033560 001371          BNE  6$
6280 033562 010103          MOV   R1,R3
6281 033564 000303          SWAB R3
6282 033566 060203          ADD  R2,R3
6283 033570 005203          INC  R3
6284 033572 003364          BGT  6$
6285 033574 005403          NEG  R3
6286 033576 000762          BR   6$
6287 033600 023703 001574 7$:   CMP   @#LC,R3
6288 033604 002003          BGE  8$
    
```

```

6289 033606 000241          CLC
6290 033610 006003          ROR      R3
6291 033612 000772          BR       7$
6292 033614 023703 001572    8$:      CMP     2#FC,R3
6293 033620 003403          BLE     9$
6294 033622 005203          INC     R3
6295 033624 000303          SWAB   R3
6296 033626 000764          BR     7$
6297 033630 110137 004276    9$:      MOVB   R1,2#DTADPB+10 ;SAVE SECTOR ADDRESS
6298 033634 110237 004277    MOVB   R2,2#DTADPB+11 ;SAVE TRACK ADDRESS
6299 033640 010337 004300    MOV     R3,2#DTADPB+12 ;SAVE CYLINDER ADDRESS
6300 033644 000200          RTS     R0 ;RETURN
6301
6302 ; THIS ROUTINE IS USED TO INPUT THE "CONTROL SWITCHES".
6303 ; IF SWR<07>=1 THE PRESENT SETTING WILL BE TYPED AND THE NEW
6304 ; SETTING IS READ AND STORED.
6305 ; NOTE: THIS ROUTINE DESTROYS R3 AND R4
6306 ; CALL
6307 ;
6308 ; JSR     PC,2#GETSWR
6309 ; RETURN ; (C.SWR)=DESIRED CONTROL SWITCHES
6310 033646 032777 000200 145264 GETSWR: BIT     #SW07,2SWR ;READ CONTROL SWITCHES?
6311 033654 001430          BEQ     2$ ;NO--BRANCH
6312 033656 104401 033664          TYPE   65$ ;TYPE ASCIZ STRING
6313 033662 000410          BR     64$ ;GET OVER THE ASCIZ
6314 ; 65$: .ASCIZ <CR><LF>/SET SWR<07>=0/
6315 033704          64$:
6316 033704 012703 045154    1$:      MOV     #MSG.CS,R3 ;"CONTROL SWITCHES="
6317 033710 013704 001300    MOV     2#C.SWR,R4 ;PRESENT CONTROL SWITCH SETTINGS
6318 033714 004037 033740    JSR     R0,2#GETNUM ;GET THE NEW SWITCH SETTINGS
6319 033720 000771          BR     1$ ;COMMA
6320 033722 000240          NOP    ;PERIOD
6321 033724 013737 001300 001302    MOV     C.SWR,SAVCSW ;SAVE PREVIOUS VALUE
6322 033732 010437 001300    MOV     R4,2#C.SWR ;DOUBLE PERIOD--SAVE NEW SWITCH SETTING
6323 033736 000207    2$:      RTS     PC ;RETURN FROM CALL
6324
6325 ; THIS ROUTINE WILL TYPE AN ASCIZ MESSAGE AND THEN
6326 ; INPUT AN ASCIZ STRING AND CHANGE THE STRING TO OCTAL
6327 ; IF REQUIRED.
6328 ; NOTE: THIS ROUTINE DESTROYS R1
6329 ; CALL
6330 ;
6331 ; MOV     #ADR,R3 ;ADDRESS OF ASCIZ MESSAGE
6332 ; MOV     #NUM,R4 ;OCTAL NUMBER
6333 ; JSR     R0,2#GETNUM
6334 ; RETURN1 ;INPUT TERMINATED WITH A COMMA
6335 ; RETURN2 ;WITH A PERIOD
6336 ; RETURN3 ;WITH A DOUBLE PERIOD
6337 ; ;R4=INPUT NUMBER AND
6338 ; ;R2=R4*32 FOR ALL
6339 ; ;THREE RETURNS
6340 033740 010337 033746    GETNUM: MOV     R3,2$ ;SAVE MESSAGE POINTER
6341 033744 104401          1$:      TYPE   ;TYPE THE MESSAGE
6342 033746 000000          2$:      .WORD 0 ;MESSAGE POINTER GOES HERE
6343 033750 010446          MOV     R4,-.SP) ;SAVE R4 FOR TYPEOUT
6344 033752 104402          *YPOC ;GO TYPE--OCTAL ASCII:ALL DIGITS

```

```

6345 033754 104401 045200      TYPE      ,SLASH      ;' / '
6346 033760 104411      RDLIN      ;READ AN ASCIZ STRING
6347 033762 012601      MOV        (SP)+,R1    ;ADDRESS OF FIRST CHARACTER
6348 033764 004037 036210      JSR        RO, @#CK.CHR ;CHECK ONE CHARACTER
6349 033770 033744      1$        ;ILLEGAL CHARACTER
6350 033772 033744      1$        ;CARRIAGE RETURN
6351 033774 034006      3$        ;' '
6352 033776 034032      7$        ;' '
6353 034000 034040      8$        ;DIGIT 0-9
6354 034002 034004      11$       ;DECREMENT THE INPUT POINTER
6355 034004 005301      11$:      DEC        R1
6356 034006      3$:
6357 034006 004037 036450      JSR        RO, @#CK.NUM ;CHECK THE NUMBER
6358 034012 033744      1$        ;ILLEGAL INPUT
6359 034014 034026      6$        ;TERMINATED WITH A " ." OR "CR"
6360 034016 034024      5$        ;TERMINATED WITH A " ."
6361 034020 034022      4$        ;TERMINATED WITH A " ."
6362 034022 005720      4$:      TST        (RO)+    ;DOUBLE PERIOD
6363 034024 005720      5$:      TST        (RO)+    ;SINGLE PERIOD
6364 034026 010204      6$:      MOV        R2, R4    ;COMMA--SAVE INPUT NUMBER
6365 034030 000414      10$       BR         10$       ;GO TO EXIT
6366 034032 105711      7$:      TSTB       (R1)      ;TERMINATOR AFTER A COMMA?
6367 034034 001343      1$        BNE        1$        ;NO--LOOP
6368 034036 000411      10$       BR         10$       ;YES--EXIT
6369 034040 105711      8$:      TSTB       (R1)      ;TERMINATOR AFTER A PERIOD?
6370 034042 001406      9$        BEQ        9$        ;YES--EXIT
6371 034044 122721 000056      CMPB       #'.,(R1)+  ;NO--DOUBLE PERIOD?
6372 034050 001335      1$        BNE        1$        ;NO--LOOP
6373 034052 105711      TSTB       (R1)      ;YES--TERMINATOR?
6374 034054 001333      1$        BNE        1$        ;NO--LOOP
6375 034056 005720      TST        (RO)+    ;DCUBLE PERIOD
6376 034060 005720      9$:      TST        (RO)+    ;PERIOD
6377 034062 010402      10$:     MOV        R4, R2    ;COMMA--POSITION THE
6378 034064 000302      SWAB       R2        ;NUMBER IN CASE IT
6379 034066 006202      ASR        R2        ;IS THE PRIORITY LEVEL
6380 034070 006202      ASR        R2
6381 034072 006202      ASR        R2
6382 034074 000200      RTS         RO        ;EXIT
6383
6384      ;THIS ROUTINE IS USED TO CHANGE OR MODIFY
6385      ;THE TEST PARAMETERS. IT GIVES THE OPERATOR
6386      ;THE CAPABILITY OF SPECIFYING WHICH DRIVES TO TEST, WHICH
6387      ;TESTS TO RUN AND HOW MANY TIMES TO
6388      ;REPEAT EACH TEST
6389
6390 034076 104412      GT.PRM:   SAVREG      ;SAVE R0 - R5
6391 034100 005037 001312      GT.PRI:   CLR         DRVSEL  ;NO DRIVE SELECTED
6392 034104 104401 034112      TYPE      65$       ;TYPE ASCIZ STRING
6393 034110 000406      BR         64$       ;GET OVER THE ASCIZ
6394
6395      ;65$: .ASCIZ 'CR', 'LF', 'DRIVE(S)='
6396      64$:
6397 034126 104411      RDLIN      ;READ TTY
6398 034130 012601      MOV        (SP)+,R1    ;ADDRESS OF ASCIZ STRING
6399 034132 004037 036210      JSR        RO, @#CK.CHR ;CHECK ONE CHARACTER
6400 034136 034100      GT.PRI     ;ILLEGAL CHARACTER
6401 034140 034100      GT.PRI     ;CARRIAGE RETURN

```



```

6401 034142 034100 GT.PRI ;"/
6402 034144 034100 GT.PRI ;:
6403 034146 034100 GT.PRI ;:
6404 034150 034152 1$ ;DIGIT 0-9
6405 034152 005301 1$: DEC R1
6406 034154 2$:
6407 034154 012702 000007 MOV #7,R2 ;UPPER LIMIT OF INPUT
6408 034150 004037 036264 JSR RO,#CHK.DIG ;CHECK THE DIGIT(S)
6409 034164 034100 GT.PRI ;ILLEGAL INPUT
6410 034166 034100 GT.PRI ;INPUT TOO LARGE
6411 034170 034176 3$ ;TERMINATED WITH A "." OR "CR"
6412 034172 034222 4$ ;TERMINATED WITH A ":"
6413 034174 034222 4$ ;TERMINATED WITH A ";"
6414 034176 156237 036724 001312 3$: BISB ATABIT(R2),DRVSEL ;SET THE DRIVE SELECTED BIT
6415 034204 105741 TSTB -(R1) ;WAS THE LINE TERMINATED?
6416 034206 001362 BNE 2$ ;NO-GET THE NEXT DRIVE
6417 034210 005037 001314 CLR #TSTNMS ;DESELECT ALL TESTS
6418 034214 005037 001316 CLR TSTNMS+2
6419 034220 000405 BR GTTST1 ;YES--SELECT TEST
6420 034222 156237 036724 001312 4$: BISB ATABIT(R2),DRVSEL ;SET THE SELECTED DRIVE BITS
6421 034230 104413 GT.PR2: RESREG ;RESTORE RO - RS
6422 034232 000207 RTS PC ;EXIT
6423
6424 034234 GTTST1:
6425 034234 104401 034242 TYPE 65$ ;:TYPE ASCIZ STRING
6426 034240 070403 BR 64$ ;:GET OVER THE ASCIZ
6427 ;:65$: .ASCIZ /TEST=/
6428 64$:
6429 034250 104411 RDLIN ;:READ AN ASCIZ STRING
6430 034252 012601 MOV (SP)+,R1 ;:POINTER TO R1
6431 034254 122711 000056 CMPB #'.,(R1) ;:DOUBLE PERIOD?
6432 034260 001007 BNE 1$ ;:NO--BRANCH
6433 034262 122761 000056 000001 CMPB #'.,1(R1)
6434 034270 001003 BNE 1$
6435 034272 105761 000002 TSTB 2(R1) ;:"CR"?
6436 034276 001754 BEQ GT.PR2 ;:YES--EXIT
6437 034300 005037 001314 1$: CLR TSTNMS ;:NO TEST SELECTED
6438 034304 005037 001316 CLR TSTNMS+2
6439 034310 005037 001320 CLR OPNFLG ;:NO TESTS TO BE OPENED
6440 034314 005037 001322 CLR OPNFLG+2
6441 034320 121127 000123 GTTST2: CMPB (R1),#'S ;:ALL SEEK TESTS?
6442 034324 001004 BNE 1$ ;:NO--BRANCH
6443 034326 052737 000777 001314 BIS #777,TSTNMS ;:YES--SELECT TESTS 0-10
6444 034334 000552 BR GTTST3
6445 034336 121127 000124 1$: CMPB (R1),#'T ;:ALL TIMING TESTS?
6446 034342 001004 BNE 2$ ;:NO--BRANCH
6447 034344 052737 036000 001314 BIS #36000,TSTNMS ;:YES--SELECT TESTS 12-15
6448 034352 000543 BR GTTST3
6449 034354 121127 000101 2$: CMPB (R1),#'A ;:ALL ADDRESSING TESTS?
6450 034360 001004 BNE 3$ ;:NO--BRANCH
6451 034362 052737 140000 001314 BIS #140000,TSTNMS ;:YES--SELECT TESTS 16 & 17
6452 034370 000534 BR GTTST3
6453 034372 121127 000104 3$: CMPB (R1),#'D ;:DATA TEST?
6454 034376 001004 BNE 4$ ;:NO--BRANCH
6455 034400 052737 000001 001316 BIS #1,TSTNMS+2 ;:YES--SELECT TEST 20
6456 034406 000525 BR GTTST3

```

```

6457 034410 121127 000105 4$: CMPB (R1), #'E ;EXERCISER TEST?
6458 034414 001004 BNE 5$ ;NO--BRANCH
6459 034416 052737 000002 001316 BIS #2,TSTNMS+2 ;YES--SELECT TEST 21
6460 034424 000516 BR GTTST3
6461 034426 004037 036134 5$: JSR R0,@#CK.OCT ;OCTAL DIGIT?
6462 034432 000514 BR GTTST4 ;NO--BRANCH
6463 034434 010205 MOV R2,R5 ;YES--SAVE IT
6464 034436 005201 INC R1 ;MOVE TO NEXT CHARACTER
6465 034440 004037 036134 JSR R0,@#CK.OCT ;OCTAL DIGIT
6466 034444 000405 BR 6$ ;NO--BRANCH
6467 034446 005201 INC R1 ;MOVE TO NEXT CHARACTER
6468 034450 006305 ASL R5 ;SCALE HIGH DIGIT
6469 034452 006305 ASL R5
6470 034454 006305 ASL R5
6471 034456 060502 ADD R5,R2 ;COMBINE HIGH & LOW DIGITS
6472 034460 020227 000022 6$: CMP R2,#$TN-1 ;VALID TEST NUMBER?
6473 034464 0032E3 BGT GTTST1 ;NO--BRANCH
6474 034466 010237 034660 MOV R2,R5 ;SAVE THE TEST NUMBER
6475 034472 010204 MOV R2,R4 ;CONVERT TEST NUMBER INTO AN INDEX
6476 034474 042704 000017 BIC #17,R4 ;CLEAR UNTESTED BITS
6477 034500 006204 ASR R4 ;SHIFT THE BITS
6478 034502 006204 ASR R4 ;SHIFT THE BITS
6479 034504 006204 ASR R4 ;SHIFT THE BITS
6480 034506 006302 ASL R2
6481 034510 056264 001506 001314 BIS BITS(R2),TSTNMS(R4) ;SELECT TEST
6482 034516 121127 000055 CMPB (R1), #'- ;TEST STRING?
6483 034522 001060 BNE GTTST4 ;NO--BRANCH
6484 034524 005201 INC R1 ;YES--MOVE TO NEXT CHARACTER
6485 034526 004037 036134 JSR R0,@#CK.OCT ;OCTAL DIGIT?
6486 034532 000640 BR GTTST1 ;NO--BRANCH
6487 034534 010205 MOV R2,R5 ;YES--SAVE IT
6488 034536 005201 INC R1 ;MOVE TO NEXT CHARACTER
6489 034540 004037 036134 JSR R0,@#CK.OCT ;OCTAL DIGIT?
6490 034544 000405 BR 7$ ;NO--BRANCH
6491 034546 005201 INC R1 ;YES--MOVE TO NEXT CHARACTER
6492 034550 006305 ASL R5 ;SCALE HIGH DIGIT
6493 034552 006305 ASL R5
6494 034554 006305 ASL R5
6495 034556 060502 ADD R5,R2 ;COMBINE HIGH & LOW DIGIT
6496 034560 020227 000022 7$: CMP R2,#$TN-1 ;VALID TEST NUMBER?
6497 034564 003223 BGT GTTST1 ;NO--BRANCH
6498 034566 023702 034660 CMP 9$,R2 ;IS THE FIRST NUMBER OF THE
;STRING SMALLER THAN THE LAST?
6499 BGE GTTST1 ;NO--BRANCH
6500 MOV R2,-(SP) ;SAVE ENDING TEST NUMBER
6501 034574 010246 034660 MOV 9$,R2 ;GET STARTING TEST NUMBER
6502 034576 013702 034660 MOV (SP)+,9$ ;STORE ENDING TEST NUMBER
6503 034602 012637 034660 ASL 9$ ;SHIFT ENDING TEST NUMBER
6504 034606 006337 034660 ASL R2 ;SHIFT TEST NUMBER
6505 034612 006302 ASL R2
6506 034614 010204 8$: MOV R2,R4 ;COPY TEST NUMBER INTO R4
6507 034616 042704 000037 BIC #37,R4 ;CLEAR LOWER BITS
6508 034622 006204 ASR R4 ;SHIFT THE TEST NUMBER
6509 034624 006204 ASR R4 ;SHIFT THE TEST NUMBER
6510 034626 006204 ASR R4 ;SHIFT THE TEST NUMBER
6511 034630 006204 ASR R4 ;SHIFT THE TEST NUMBER
6512 034632 056264 001506 001314 BIS BITS(R2),TSTNMS(R4) ;SELECT THE TEST

```

```

6513 034640 062702 000002          ADD    #2,R2          ; INCREMENT THE TEST NUMBER
6514 034644 020237 034660          CMP    R2,R9$        ; SEE IF FINISHED
6515 034650 101761          BLOS  8$             ; BR IF NOT
6516 034652 162702 000002          SUB    #2,R2          ; CORRECT TEST NUMBER
6517 034656 000402          BR    GTTST4         ; CONTINUE
6518 034660 000000          9$: .WORD 0          ; STORE TEST NUMBER HERE
6519 034662 005201          GTTST3: INC R1        ; MOVE TO NEXT CHARACTER
6520 034664 121127 000056          GTTST4: CMPB (R1),#'.' ; "PERIOD"?
6521 034670 001441          BEQ   GTTST5         ; YES--BRANCH
6522 034672 005737 001314          TST   TSTNMS         ; ANY TEST SELECTED THIS CYCLE?
6523 034676 001005          BNE  1$             ; BR IF YES
6524 034700 005737 001316          TST   TSTNMS+2       ; ANY TEST SELECTED THIS CYCLE ?
6525 034704 001002          BNE  1$             ; BR IF YES
6526 034706 000137 034234          JMP   GTTST1         ; NO
6527 034712 121127 000057          1$:  CMPB (R1),#'/'  ; "OPEN"?
6528 034716 001004          BNE  2$             ; NO--BRANCH
6529 034720 056264 001506 001320          BIS  BITS(R2), OPNFLG(R4) ; YES--SET BITS FOR TEST TO OPEN
6530 034726 000405          BR    3$
6531 034730 121127 000054          2$:  CMPB (R1),#'.'  ; "COMMA"?
6532 034734 001402          BEQ   3$            ; BR IF YES
6533 034736 000137 034234          JMP   GTTST1         ; NO
6534 034742 005201          3$:  INC  R1          ; MOVE TO NEXT CHARACTER
6535 034744 105711          TSTB (R1)           ; "CR"?
6536 034746 001402          BEQ   4$            ; BR IF 'CR'
6537 034750 000137 034320          JMP   GTTST2         ; NO--GO GET NEXT CHARACTER
6538 034754 005737 001320          4$:  TST   OPNFLG      ; ANY TESTS TO OPEN ?
6539 034760 001042          BNE  OPNTST         ; BR IF YES
6540 034762 005737 001322          TST   OPNFLG+2     ; ANY TESTS TO OPEN ?
6541 034766 001037          BNE  OPNTST         ; BR IF YES
6542 034770 000137 034234          JMP   GTTST1         ; NO--START AGAIN
6543 034774 005201          GTTST5: INC R1       ; MOVE TO NEXT CHARACTER
6544 034776 121127 000056          CMPB (R1),#'.'     ; "PERIOD"?
6545 035002 001414          BEQ   GTTST6         ; YES--BRANCH
6546 035004 105711          TSTB (R1)           ; "CR"?
6547 035006 001402          BEQ   1$            ; YES--BRANCH
6548 035010 000137 034234          JMP   GTTST1         ; NO
6549 035014 005737 001320          1$:  TST   OPNFLG      ; ANY TESTS TO OPEN ?
6550 035020 001022          BNE  OPNTST         ; BR IF YES
6551 035022 005737 001322          TST   OPNFLG+2     ; ANY TESTS TO OPEN ?
6552 035026 001017          BNE  OPNTST         ; BR IF YES
6553 035030 000137 034230          JMP   GT.PR2        ; NO--GO START TESTING
6554 035034 005201          GTTST6: INC R1       ; MOVE TO NEXT CHARACTER
6555 035036 105711          TSTB (R1)           ; "CR"?
6556 035040 001402          BEQ   1$            ; YES--BRANCH
6557 035042 000137 034234          JMP   GTTST1         ; NO--GO ASK FOR TEST
6558 035046 005737 001320          1$:  TST   OPNFLG      ; ANY TESTS TO OPEN ?
6559 035052 001005          BNE  OPNTST         ; BR IF YES
6560 035054 005737 001322          TST   OPNFLG+2     ; ANY TESTS TO OPEN ?
6561 035060 001002          BNE  OPNTST         ; BR IF YES
6562 035062 000137 034230          JMP   GT.PR2        ; NO--GO START TESTING
6563
6564          ; OPEN THE SELECTED TEST FOR CHANGES
6565
6566 035066 104412          OPNTST: SAVREG      ; SAVE R0 - R5
6567 035070 005027          CLR   (PC)+         ; START WITH TEST 0
6568 035072 000000          OPN.CT: .WORD 0     ; COUNT STORED HERE

```

```

6569 035074 000411 BR OPN.2 ;SKIP THE INCREMENT
6570 035076 005237 035072 OPN.1: INC OPN.CT ;MOVE TO THE NEXT TEST
6571 035102 022737 000022 035072 CMP #STN-1,OPN.CT ;TEST NUMBER TOO BIG?
6572 035110 002003 BGE OPN.2 ;NO--OPEN THE NEXT TEST
6573 035112 104413 RESREG ;RESTORE R0 - R5
6574 035114 000137 034234 JMP GTTST1 ;YES--GO ASK FOR MORE TESTS
6575 035120 013705 035072 OPN.2: MOV OPN.CT,R5 ;SETUP TO USE THE
6576 035124 006305 ASL R5 ;TEST NUMBER AS AN INDEX
6577 035126 013703 035072 MOV OPN.CT,R3 ;GET INDEX
6578 035132 042703 000017 BIC #17,R3 ;CLEAR LOWER TEST BITS
6579 035136 006203 ASR R3 ;SHIFT TEST NUMBER
6580 035140 006203 ASR R3 ;SHIFT TEST NUMBER
6581 035142 006203 ASR R3 ;SHIFT TEST NUMBER
6582 035144 036563 001506 001320 BIT BITS(R5),OPNFLG(R3) ;OPEN THIS TEST?
6583 035152 001751 BEQ OPN.1 ;NO--MOVE TO NEXT TEST
6584 035154 104401 035162 TYPE ,65$ ;TYPE ASCIZ STRING
6585 035160 000404 BR ,64$ ;GET OVER THE ASCIZ
6586 ;:65$:
6587 ;64$: .ASCIZ / TEST /
6588 035172 013746 035072 MOV OPN.CT,-(SP) ;SAVE OPN.CT FOR TYPEOUT
6589 ;TEST NUMBER
6590 035176 104403 TYPOS ;GO TYPE--OCTAL ASCII
6591 035200 002 .BYTE 2 ;TYPE 2 DIGIT(S)
6592 035201 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
6593 035202 104401 001215 TYPE ,SCRFL ;TYPE "CR" & "LF"
6594 035206 016500 001620 MOV PRMPT(R5),R0 ;PICKUP PARAMETER POINTER
6595 035212 011046 MOV (R0),-(SP) ;SAVE THE VARIABLE INDICATOR
6596 035214 012702 001566 MOV #PRM,R2 ;FIRST ADDRESS OF TABLE
6597 035220 000405 BR 2$
6598 035222 006216 1$: ASR (SP) ;CHECK FOR A VARIABLE
6599 035224 103403 BCS 2$ ;GO MOVE THIS ONE
6600 035226 001404 BEQ OPNPRM ;DONE
6601 035230 005722 TST (R2)+ ;BUMP THE POINTER
6602 035232 000773 BR 1$
6603 035234 012022 2$: MOV (R0)+,(R2)+ ;MOVE THIS VARIABLE INTO THE
6604 035236 000771 BR 1$ ;COMMON AREA
6605 035240 013716 001566 OPNPRM: MOV #PRM,(SP) ;GET THE VARIABLE INDICATOR
6606 035244 005004 CLR R4 ;ZERO THE INDEX
6607 035246 006216 1$: ASR (SP) ;CHECK FOR A VARIABLE
6608 035250 103403 BCS 3$ ;GO GET IT
6609 035252 001772 BEQ OPNPRM ;OUT OF VARIABLES
6610 035254 005724 2$: TST (R4)+ ;UPDATE THE INDEX
6611 035256 000773 BR 1$
6612 035260 005764 001670 3$: TST PRMLMT(R4) ;IS THE MAX. MAGNITUDE NEG?
6613 035264 100466 BMI OPNPAT ;YES--THEN IT IS THE PATTERN
6614 035266 104401 046141 TYPE ,MSG.SP ;TYPE SPACES
6615 035272 016437 001720 035302 MOV PRMMSG(R4),4$ ;TYPE THE NAME OF THIS VARIABLE
6616 035300 104401 TYPE
6617 035302 000000 4$: .WORD 0
6618 035304 104401 045152 TYPE ,MSG.EQ ;TYPE "="
6619 035310 016446 001570 MOV RPT(R4),-(SP) ;PUT RPT(R4) ON THE STACK
6620 035314 004737 025242 JSR PC,#SSB20 ;CHANGE RPT(R4) TO DECIMAL ASCII
6621 035320 004737 025472 JSR PC,#SSUPRS ;TYPE WITHOUT LEADING ZEROS
6622 035324 104401 045200 TYPE ,SLASH ;
6623 035330 104411 RDL IN
6624 035332 012601 MOV (SP)+,R1 ;READ AN ASCII STRING

```

6625	035334	004037	036210	JSR	RO, @#CK.CHR	; CHECK ONE CHARACTER
6626	035340	035260		3\$; ILLEGAL CHARACTER
6627	035342	035254		2\$; CARRIAGE RETURN
6628	035344	035412		8\$		"/"
6629	035346	035354		5\$		":"
6630	035350	035362		6\$		":"
6631	035352	035410		7\$; DIGIT 0-9
6632	035354	105711		5\$:	TSTB (R1)	"CR"?
6633	035356	001340		BNE	3\$; NO--STAY ON THIS VARIABLE
6634	035360	000735		BR	2\$; YES--MOVE TO NEXT VARIABLE
6635	035362	105711		6\$:	TSTB (R1)	; IS THERE A "CR" AFTER THE PERIOD?
6636	035364	001002		BNE	64\$; NO
6637	035366	000137	036002	JMP	OPN.N2	; YES--GO CLOSE THIS TEST
6638	035372	122721	000056	64\$:	CMPB #'.,(R1)+	; DOUBLE PERIOD?
6639	035376	001330		BNE	3\$; NO--GO ASK FOR THIS VARIABLE
6640	035400	105711		TSTB	(R1)	; YES--IS A "CR" AFTER THE DOUBLE PERIOD?
6641	035402	001326		BNE	3\$; NO--ASK FOR THIS VARIABLE AGAIN
6642	035404	000137	036020	JMP	OPN.X2	; YES--CLOSE ALL TEST
6643	035410	005301		7\$:	DEC R1	; BACK THE POINTER UP BY ONE
6644	035412			8\$:		
6645	035412	016402	001670	MOV	PRMLT(R4), R2	; UPPER LIMIT OF INPUT
6646	035416	004037	036264	JSR	RO, @#CK.DIG	; CHECK THE DIGIT(S)
6647	035422	035260		3\$; ILLEGAL INPUT
6648	035424	035260		3\$; INPUT TOO LARGE
6649	035426	035434		9\$; TERMINATED WITH A "," OR "CR"
6650	035430	035776		OPN.N1		; TERMINATED WITH A ","
6651	035432	036014		OPN.X1		; TERMINATED WITH A "..."
6652	035434	010264	001570	9\$:	MOV R2, RPT(R4)	; SAVE THIS VARIABLE
6653	035440	000705		BR	2\$; MOVE TO NEXT VARIABLE
6654	035442	104401	046141	OPNPAT:	TYPE ,MSG.SP	; TYPE SPACES
6655	035446	104401	045146	TYPE	,MSG.PAT	; TYPE "PAT"
6656	035452	104401	045152	TYPE	,MSG.EQ	; TYPE "="
6657	035456	016446	001570	MOV	RPT(R4), -(SP)	; SAVE RPT(R4) FOR TYPEOUT
6658	035462	104402		TYPOC		; GO TYPE--OCTAL ASCII(ALL DIGITS)
6659	035464	104401	046142	TYPE	,MSG.SP+1	; TYPE ONE SPACE
6660	035470	104411		ROLIN		; READ ASCII STRING
6661	035472	012601		MOV	(SP)+, R1	; PICKUP POINTER
6662	035474	004037	036210	JSR	RO, @#CK.CHR	; CHECK ONE CHARACTER
6663	035500	035442		OPNPAT		; ILLEGAL CHARACTER
6664	035502	035240		OPNPRM		; CARRIAGE RETURN
6665	035504	035536		3\$		"/"
6666	035506	035240		OPNPRM		":"
6667	035510	035514		1\$		":"
6668	035512	035534		2\$; DIGIT 0-9
6669	035514	105711		1\$:	TSTB (R1)	"CR" AFTER THE PERIOD?
6670	035516	001531		BEQ	OPN.N2	; YES--GO CLOSE THIS TEST
6671	035520	122721	000056	CMPB	#'.,(R1)+	; NO--PERIOD?
6672	035524	001346		BNE	OPNPAT	; NO--LOOP
6673	035526	105711		TSTB	(R1)	"CR" AFTER A DOUBLE PERIOD?
6674	035530	001533		BEQ	OPN.X2	; YES--GO START TESTING
6675	035532	000743		BR	OPNPAT	; NO--LOOP
6676	035534	005301		2\$:	DEC R1	; BACKUP THE ASCII POINTER
6677	035536			3\$:		
6678	035536	004037	036450	JSR	RO, @#CK.NUM	; CHECK THE NUMBER
6679	035542	035442		OPNPAT		; ILLEGAL INPUT
6680	035544	035552		4\$; TERMINATED WITH A "," OR "CR"

6737	035754	012701	003206	CLSWDS: MOV	#PATO,R1	: FIRST ADDRESS OF DATA PATTERN
6738	035760	005200		IS: INC	RO	: COUNT THE LAST WORD THAT WAS STORED
6739	035762	022700	000017		#15,R0	: END OF TABLE
6740	035766	002402			2\$: YES--EXIT
6741	035770	012124			(R1)+,R4+	: COPY
6742	035772	000772			IS	: LOOP
6743	035774	000207		2\$: RTS	PC	: RETURN
6744	035776	010264	001570	OPN.N1: MOV	R2,RPT(R4)	: SAVE THIS VARIABLE
6745	036002	005726		OPN.N2: TST	(SP)+	: CLEAN OFF THE STACK
6746	036004	004737	036054		PC,CLOSE	: CLOSE THIS TEST
6747	036010	000137	035076		OPN.1	: GO OPEN THE NEXT TEST
6748	036014	010264	001570	OPN.X1: MOV	R2,RPT(R4)	: SAVE THIS VARIABLE
6749	036020	005726		OPN.X2: TST	(SP)+	: CLEAN OFF THE STACK
6750	036022	004737	036054	IS: JSR	PC,CLOSE	: CLOSE THIS TEST
6751	036026	005726		2\$: TST	(R5)+	: UPDATE THE INDEX
6752	036030	020527	000034		CMP	: INDEX TO BIG?
6753	036034	002403			BLT	: NO--BRANCH
6754	036036	104413			RESREG	: RESTORE RO - R5
6755	036040	000137	034230		JMP	: GO TO EXIT
6756	036044	036503	001506	3\$: BIT	GT.PR2	: IS THIS TEST OPEN FOR CHANGE?
6757	036050	001364			IS	: YES--GO CLOSE IT
6758	036052	000765			BR	: NO--MOVE TO NEXT TEST
6759	036054	104412		CLOSE: SAVREG		: SAVE RO - R5
6760	036056	012700	001566		MOV	: "FROM" ADDRESS
6761	036062	016501	001620		MOV	: "TO" ADDRESS
6762	036066	012002			MOV	: "FROM" INDICATOR
6763	036070	012103			MOV	: "TO" INDICATOR
6764	036072	012704	000001		MOV	: TEST BIT START A "RPT"
6765	036076	030402		IS: BIT	#1,R4	: PARAMETER TO BE MOVED?
6766	036100	001403			BEQ	: NO--BRANCH
6767	036102	030403			BIT	: A PLACE TO PUT IT?
6768	036104	001404			BEQ	: NO--BRANCH
6769	036106	011011			MOV	: YES--MOVE "FROM" TO "TO"
6770	036110	030403		2\$: BIT	(R0),(R1)	: "TO" PARAMETER?
6771	036112	001401			BEQ	: NO--BRANCH
6772	036114	005721			TST	: YES--UPDATE THE POINTER
6773	036116	005720		3\$: TST	(R0)+	: UPDATE FROM POINTER
6774	036120	006304			ASL	: POSITION THE TEST BIT
6775	036122	032704	002000		BIT	: DONE?
6776	036126	001763			BEQ	: NO--BRANCH
6777	036130	104413			RESREG	: RESTORE RO - R5
6778	036132	000207			RTS	: RETURN
6779					PC	
6780						: THIS ROUTINE IS USED TO CHECK IF AN
6781						: ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
6782					CALL	
6783					MOV	: ADDRESS OF ASCII CHARACTER
6784					JSR	: CHECK THE CHARACTER
6785					RETURN1	: CHARACTER IS NOT BETWEEN 0-7
6786					RETURN2	: CHARACTER IS IN R2 AS A
6787						: OCTAL DIGIT
6788	036134	121127	000060	CK.OCT: CMPB	(R1),#0	: LESS THAN ZERO?
6789	036140	103407			BLG	: YES -- BRANCH
6790	036142	121127	000067		CMPB	: GREATER THAN SEVEN?
6791	036146	101004			BHI	: YES -- BRANCH
6792	036150	111102			MOVE	: GET THE CHARACTER

```

6793 036152 042702 177770          BIC    #C7,R2          ;STRIP AWAY THE ASCII
6794 036156 005720                TST    (R0)+          ;ADJUST FOR RETURN
6795 036160 000200          1$:    RTS    RO          ;RETURN
6796
6797
6798
6799
6800
6801
6802
6803
6804
6805
6806 036162 121127 000060          ;THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
6807 036166 103407                ;AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
6808 036170 121127 000071          :CALL
6809 036174 101004                MOV    #ADR,R1          ;ADDRESS OF ASCII CHARACTER
6810 036176 111102                JSR    RO,@CK.DEC      ;CHECK THE CHARACTER
6811 036200 042702 000060          ;NOT BETWEEN 0 AND 9
6812 036204 005720                ;BETWEEN 0 AND 9
6813 036206 000200                ;R2 = DIGIT
6814
6815
6816
6817
6818
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828 036210 105711                CK.DEC: CMPB   (R1),#'0    ;LESS THAN ZERO?
6829 036212 001420                BLO    1$             ;YES -- BRANCH
6830 036214 121127 000057          CMPB   (R1),#'9      ;GREATER THAN NINE?
6831 036220 001414                BHI    1$             ;YES -- BRANCH
6832 036222 121127 000054          MOVB   (R1),R2        ;GET THE CHARACTER
6833 036226 001410                BIC    #'0,R2         ;STRIP AWAY THE ASCII
6834 036230 121127 000056          TST    (R0)+          ;ADJUST FOR RETURN
6835 036234 001404                1$:    RTS    RO          ;RETURN
6836 036236 004037 036162          ;THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
6837 036242 000406                ;DETERMINE WHAT IT IS.
6838 036244 005720                :CALL
6839 036246 005720                MOV    #ADR,R1        ;ADDRESS OF ASCII CHARACTER
6840 036250 005720                JSR    RO,@CK.CHR     ;CHECK CHARACTER
6841 036252 005720                RETURN ADR1           ;UNKNOWN CHARACTER
6842 036254 005720                RETURN ADR2           ;CARRIAGE RETURN * (R1)=ADR+1
6843 036256 005201                RETURN ADR3           ;SLASH * (R1)=ADR+1
6844 036260 011000                RETURN ADR4           ;COMMA * (R1)=ADR+1
6845 036262 000200                RETURN ADR5           ;PERIOD * (R1)=ADR+1
6846
6847
6848
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865
6866
6867
6868
6869
6870
6871
6872
6873
6874
6875
6876
6877
6878
6879
6880
6881
6882
6883
6884
6885
6886
6887
6888
6889
6890
6891
6892
6893
6894
6895
6896
6897
6898
6899
6900
6901
6902
6903
6904
6905
6906
6907
6908
6909
6910
6911
6912
6913
6914
6915
6916
6917
6918
6919
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
7000
    
```

;THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
 ;CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.


```

6849          :CALL
6850          :      MOV      #ADR,R1      ;ADDRESS OF ASCIZ STRING
6851          :      MOV      #NUM,R2      ;MAX. MAGNITUDE OF INPUT NUMBER
6852          :      JSR      RO, @#CK.DIG ;CHECK DIGITS
6853          :      RETURN   ADR1         ;ILLEGAL CHARACTER -- R2=?
6854          :      RETURN   ADR2         ;INPUT NUMBER TO LARGE -- R2=?
6855          :      RETURN   ADR3         ;"COMMA" -- R2 = NUMBER
6856          :      RETURN   ADR4         ;"PERIOD" -- R2 = NUMBER
6857          :      RETURN   ADR5         ;"PERIOD-PERIOD" -- R2 = NUMBER
6858
6859 036264 010446 CK.DIG: MOV      R4, -(SP)      ;SAVE R4
6860 036266 010346          :      MOV      R3, -(SP)      ;SAVE R3
6861 036270 010246          :      MOV      R2, -(SP)      ;SAVE THE MAX. SIZE ON THE STACK
6862 036272 005002          :      CLR      R2            ;START WITH 0
6863 036274 005003          :
6864 036276 005004          :
6865 036300 004037 036210 JSR      RO, @#CK.CHR      ;CHECK ONE CHARACTER
6866 036304 036434          :      BS      ;ILLEGAL CHARACTER
6867 036306 036434          :      BS      ;CARRIAGE RETURN
6868 036310 036434          :      BS      ;"/"
6869 036312 036434          :      BS      ;"."
6870 036314 036434          :      BS      ;"."
6871 036316 036320          :      IS      ;DIGIT 0-9
6872 036320 006303 1S:   ASL      R3            ;2
6873 036322 010346          :      MOV      R3, -(SP)      ;SAVE *2
6874 036324 006303          :      ASL      R3            ;4
6875 036326 006303          :      ASL      R3            ;8
6876 036330 062603          :      ADD     (SP)+, R3        ;(*8)+(*2)=*10.
6877 036332 060203 036210 ADD     R2, R3            ;UPDATE THE INPUT NUMBER
6878 036334 004037          :      JSR      RO, @#CK.CHR      ;CHECK ONE CHARACTER
6879 036340 036434          :      BS      ;ILLEGAL CHARACTER
6880 036342 036354          :      BS      ;CARRIAGE RETURN
6881 036344 036434          :      BS      ;"/"
6882 036346 036362          :      BS      ;"."
6883 036350 036360          :      BS      ;"."
6884 036352 036320          :      IS      ;DIGIT 0-9
6885 036354 005301 9S:   DEC      R1            ;BACKUP THE CHARACTER POINTER
6886 036356 000401          :      BR      ;CONTINUE
6887 036360 005724 2S:   TST     (R4)+        ;"PERIOD"
6888 036362 005724 3S:   TST     (R4)+        ;"COMMA" OR "CR"
6889 036364 004037 036210 JSR      RO, @#CK.CHR      ;CHECK ONE CHARACTER
6890 036370 036434          :      BS      ;ILLEGAL CHARACTER
6891 036372 036424          :      BS      ;CARRIAGE RETURN
6892 036374 036434          :      BS      ;"/"
6893 036376 036434          :      BS      ;"."
6894 036400 036404          :      BS      ;"."
6895 036402 036414          :      IS      ;DIGIT 0-9
6896 036404 005724 4S:   TST     (R4)+        ;"PERIOD-PERIOD"
6897 036406 105711          :      TSTB   (R1)           ;"CR"?
6898 036410 001405          :      BEQ    ;YES--BRANCH
6899 036412 000410          :      BR      ;
6900 036414 126127 177776 000054 5S:  CMPB   -2(R1), #'.'      ;WAS CHARACTER BEFORE THE DIGIT A COMMA?
6901 036422 001004          :      BNE    ;NO--EXIT
6902 036424 020316 6S:   CMP     R3, (SP)        ;INPUT TO LARGE?
6903 036426 101001          :      BHI    ;YES -- BRANCH
6904 036430 060400          :      ADD     R4, RO        ;ADJUST RETURN ADDRESS

```

6905	036432	005720	7\$:	TST	(R0)+	
6906	036434	010302	8\$:	MOV	R3,R2	:NUMBER TO R2
6907	036436	005726		TST	(SP)+	:CLEAN MAX. SIZE OFF OF STACK
6908	036440	012603		MOV	(SP)+,R3	:RESTORE R3
6909	036442	012604		MOV	(SP)+,R4	:RESTORE R4
6910	036444	011000		MOV	(R0),R0	:GET RETURN ADDRESS
6911	036446	000200		RTS	R0	:RETURN
6912						
6913						
6914						
6915						
6916						
6917						
6918						
6919						
6920						
6921						
6922						
6923	036450	010346				
6924	036452	005003				
6925	036454	004037	036134			
6926	036460	000440				
6927	036462	005201				
6928	036464	006303	1\$:	INC	R1	:MOVE TO NEXT CHARACTER
6929	036466	103435		ASL	R3	:FOR THE OCTAL NUMBER IN R3
6930	036470	006303		BCS	6\$:DON'T LET IT GET TO BIG
6931	036472	103433		ASL	R3	
6932	036474	006303		BCS	6\$	
6933	036476	103431		ASL	R3	
6934	036500	060203		BCS	6\$	
6935	036502	004037	036134	ADD	R2,R3	
6936	036506	000401		JSR	R0,R3	
6937	036510	000764		BR	2\$:IS THIS AN OCTAL DIGIT?
6938	036512	010302		BR	1\$:NO--FIND OUT WHAT IT IS
6939	036514	005003		BR	1\$:YES--MAKE IT PART OF THE NUMBER
6940	036516	004037	036210	2\$:	MOV	R3,R2
6941	036522	036562		CLR	R3	:SAVE THE OCTAL NUMBER
6942	036524	036552		JSR	R0,R3	:START WITH ZERO INDEX
6943	036526	036562		BR	6\$:CHECK ONE CHARACTER
6944	036530	036552		BR	5\$:ILLEGAL CHARACTER
6945	036532	036536		BR	5\$:CARRIAGE RETURN
6946	036534	036562		BR	5\$: " / "
6947	036536	005723		BR	5\$: " ' "
6948	036540	121127	000056	3\$:	TST	(R3)+
6949	036544	001002		CMPB	(R1),#'	:DIGIT 0-9
6950	036546	005201		BNE	5\$: "PERIOD"
6951	036550	005723		INC	R1	: "PERIOD-PERIOD"?
6952	036552	005723		4\$:	TST	(R3)+
6953	036554	105711		5\$:	TST	(R3)+
6954	036556	001001		TSTB	(R1)	:NO--BRANCH
6955	036560	060300		BNE	6\$:YES--ADVANCE THE POINTER
6956	036562	012603		ADD	R3,R0	: "PERIOD-PERIOD"
6957	036564	011000		MOV	(SP)+,R3	: "COMMA"
6958	036566	000200		MOV	(R0),R0	: "CR"?
				RTS	R0	:NO--BRANCH
						:YES--SAVE THE OCTAL NUMBER
						:RESTORE R3
						:PICKUP EXIT ADDRESS
						:RETURN

: THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
 : AND FORMS AN OCTAL NUMBER IN R2

: CALL:

...	MOV	#ADR,R1	: ADDRESS OF ASCIZ STRING
...	JSR	R0,#CK.NUM	: GO FORM THE NUMBER
...	RETURN	ADR1	: ILLEGAL CHARACTER IN THE INPUT STRING
...	RETURN	ADR2	: "COMMA" OR "CR"--R2=NUMBER
...	RETURN	ADR3	: "PERIOD"--R2=NUMBER
...	RETURN	ADR4	: "PERIOD-PERIOD"--R2=NUMBER

CK.NUM:	MOV	R3,-(SP)	: SAVE R3
	CLR	R3	: START NUMBER AT ZERO
	JSR	R0,#CK.OCT	: OCTAL DIGIT?
	BR	6\$: NO--BRANCH
1\$:	INC	R1	: MOVE TO NEXT CHARACTER
	ASL	R3	: FOR THE OCTAL NUMBER IN R3
	BCS	6\$: DON'T LET IT GET TO BIG

2\$:	MOV	R3,R2	: IS THIS AN OCTAL DIGIT?
	CLR	R3	: NO--FIND OUT WHAT IT IS
	JSR	R0,#CK.CHP	: YES--MAKE IT PART OF THE NUMBER
	BR	2\$: SAVE THE OCTAL NUMBER
	BR	1\$: START WITH ZERO INDEX
	BR	6\$: CHECK ONE CHARACTER
	BR	5\$: ILLEGAL CHARACTER
	BR	5\$: CARRIAGE RETURN
	BR	5\$: " / "
	BR	5\$: " ' "

3\$:	TST	(R3)+	: DIGIT 0-9
	CMPB	(R1),#'	: "PERIOD"
	BNE	5\$: "PERIOD-PERIOD"?
	INC	R1	: NO--BRANCH
4\$:	TST	(R3)+	: YES--ADVANCE THE POINTER
5\$:	TST	(R3)+	: "PERIOD-PERIOD"
	TSTB	(R1)	: "COMMA"
	BNE	6\$: "CR"?
	ADD	R3,R0	: NO--BRANCH
6\$:	MOV	(SP)+,R3	: YES--SAVE THE OCTAL NUMBER
	MOV	(R0),R0	: RESTORE R3
	RTS	R0	: PICKUP EXIT ADDRESS
			: RETURN

6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
7000
7001
7002
7003
7004
7005
7006
7007
7008
7009
7010
7011
7012
7013
7014

036570 000000 000000 000000
036576 000000

036600 000
036601 000
036602 000
036603 000
036604 000
036605 000
036606 000
036607 000

036610 000
036611 000
036612 000
036613 000
036614 000
036615 000
036616 000
036617 000

```
;;*****  
:SBTTL SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 5.1)-24-AUG-77  
:NEW DRIVE TYPE ID FOR RMO2 *****  
: 10-AUG-77 *****  
  
:COPYRIGHT (C) 1977  
:DIGITAL EQUIPMENT CORP.  
:MAYNARD, MA 01754  
:AUTHOR(S): JIM LACEY/CHUCK HESS/C. CHEN  
  
;;*****  
:STORAGE FOR RMOs, RMER1, RMER2, AND RMMR2 ON AN ERROR "2"  
:RMERRS = RMOs  
:RMERRS+2 = RMER1  
:RMERRS+4 = RMER2  
:RMERRS+6 = RMMR2  
  
RMERRS: .WORD 0,0,0,0  
  
:TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)  
:DRVACT=0 IF DRIVE IS IDLE  
:DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND  
:DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION  
  
DRVACT: .BYTE 0 ;DRIVE 0  
:BYTE 0 ;DRIVE 1  
:BYTE 0 ;DRIVE 2  
:BYTE 0 ;DRIVE 3  
:BYTE 0 ;DRIVE 4  
:BYTE 0 ;DRIVE 5  
:BYTE 0 ;DRIVE 6  
:BYTE 0 ;DRIVE 7  
  
:TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)  
:DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT  
:DRVSTA>0 IF DRIVE IS ONLINE  
:DRVSTA<0 IF DRIVE IS UNSAFE  
  
DRVSTA: .BYTE 0 ;DRIVE 0  
:BYTE 0 ;DRIVE 1  
:BYTE 0 ;DRIVE 2  
:BYTE 0 ;DRIVE 3  
:BYTE 0 ;DRIVE 4  
:BYTE 0 ;DRIVE 5  
:BYTE 0 ;DRIVE 6  
:BYTE 0 ;DRIVE 7  
  
:TABLE OF DRIVE TYPES (DRV TYP=8 BYTES)  
:DRV TYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, HLS  
:DRV TYP=5 IF DRIVE IS RMO2 *****  
:DRV TYP=4 IF DRIVE IS RMO3  
:DRV TYP=-1 IF NOT RMO3
```

```

7015
7016 036620 000
7017 036621 000
7018 036622 000
7019 036623 000
7020 036624 000
7021 036625 000
7022 036626 000
7023 036627 000
7024
7025
7026
7027
7028
7029 036630 000
7030 036631 000
7031 036632 000
7032 036633 000
7033 036634 000
7034 036635 000
7035 036636 000
7036 036637 000
7037
7038
7039
7040
7041
7042 036640 000
7043 036641 000
7044 036642 000
7045 036643 000
7046 036644 000
7047 036645 000
7048 036646 000
7049 036647 000
7050
7051
7052
7053
7054
7055 036650 000000
7056
7057
7058
7059
7060
7061
7062
7063 036652 000000
7064
7065
7066
7067
7068
7069 036654 000
7070

```

```

DRV TYP: .BYTE 0          ; DRIVE 0
          .BYTE 0          ; DRIVE 1
          .BYTE 0          ; DRIVE 2
          .BYTE 0          ; DRIVE 3
          .BYTE 0          ; DRIVE 4
          .BYTE 0          ; DRIVE 5
          .BYTE 0          ; DRIVE 6
          .BYTE 0          ; DRIVE 7

; TABLE OF DUAL PORT INITIALIZATION INDICATORS
; DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
; DPINT<0 IF INITIALIZATION IS IN PROGRESS

DPINT: .BYTE 0          ; DRIVE 0
        .BYTE 0          ; DRIVE 1
        .BYTE 0          ; DRIVE 2
        .BYTE 0          ; DRIVE 3
        .BYTE 0          ; DRIVE 4
        .BYTE 0          ; DRIVE 5
        .BYTE 0          ; DRIVE 6
        .BYTE 0          ; DRIVE 7

; TABLE OF PENDING DUAL PORT REQUESTS
; DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
; DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE

DPRQS: .BYTE 0          ; DRIVE 0
        .BYTE 0          ; DRIVE 1
        .BYTE 0          ; DRIVE 2
        .BYTE 0          ; DRIVE 3
        .BYTE 0          ; DRIVE 4
        .BYTE 0          ; DRIVE 5
        .BYTE 0          ; DRIVE 6
        .BYTE 0          ; DRIVE 7

; TRANSFER WAIT FLAG (TRNSWT=1 WORD)
; THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
; "DPB" OF THE I/O OPERATION.

TRNSWT: .WORD 0

; SEARCH WAIT KEYS (SRCHWT=1 WORD)
; THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
; THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
; REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
; EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.

SRCHWT: .WORD 0

; RM03 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
; ACTDRV=0 IF DRIVER IS INACTIVE
; ACTDRV>0 IF DRIVER IS ACTIVE

ACTDRV: .BYTE 0

```

H13

MD-11-DZRMF-B RM03 RM02 EXTENDED DRIVE TEST MACY11 30(1046) 22-NOV-77 08:04 PAGE 133
CZRMFB.P11 21-NOV-77 14:10 SINGLE/DUAL PORT RH70/RM03 DRIVER (REV 5.1)-24-AUG-77

SEQ 0163

```
7071 ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
7072 ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
7073 ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
7074
7075 036655 000 ACTSTR: .BYTE 0
7076
7077 ;UNLOAD FLAG (ULDFLG=8 BYTES)
7078 ;ULDFLG=0 IF NO UNLOAD COMMAND
7079 ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
7080 ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
7081
7082 036656 000 ULDFLG: .BYTE 0 ;DRIVE 0
7083 036657 000 .BYTE 00 ;DRIVE 1
7084 036658 001 .BYTE 00 ;DRIVE 2
7085 036661 000 .BYTE 00 ;DRIVE 3
7086 036662 000 .BYTE 00 ;DRIVE 4
7087 036663 000 .BYTE 00 ;DRIVE 5
7088 036664 000 .BYTE 00 ;DRIVE 6
7089 036665 000 .BYTE 0 ;DRIVE 7
7090
7091 ;LOOK AHEAD COUNT (LACNT=8 BYTES)
7092 ;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
7093
7094 036666 000 LACNT: .BYTE 0 ;DRIVE 0
7095 036667 000 .BYTE 00 ;DRIVE 1
7096 036670 000 .BYTE 00 ;DRIVE 2
7097 036671 000 .BYTE 00 ;DRIVE 3
7098 036672 000 .BYTE 00 ;DRIVE 4
7099 036673 000 .BYTE 00 ;DRIVE 5
7100 036674 000 .BYTE 00 ;DRIVE 6
7101 036675 000 .BYTE 0 ;DRIVE 7
7102
7103 ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
7104 ;SAVEFG <0 IF SAVE THE RH70/RM03 REGISTERS WHEN THE
7105 ;OPERATION IS COMPLETED AS PER (DPB+14).
7106 ;SAVEFG=0 IF SAVE THE RH70/RM03 REGISTERS, AS PER
7107 ;(DPB+14), AFTER AN ERROR.
7108
7109 036676 000000 SAVEFG: .WORD 0
7110
7111 ;SEEK FLAG (SEEKFG=1 WORD)
7112 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
7113 ;FOR A DATA TRANSFER START A SEARCH COMMAND
7114 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS.
7115 ;DISREGARD THE WINDOW
7116
7117 036700 177777 SEEKFG: .WORD -1
7118
7119 ;TIMEOUT TABLE (TIMER=8 WORDS)
7120 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
7121
7122 036702 177777 TIMER: .WORD -1 ;DRIVE 0
7123 036704 177777 .WORD -1 ;DRIVE 1
7124 036706 177777 .WORD -1 ;DRIVE 2
7125 036710 177777 .WORD -1 ;DRIVE 3
7126 036712 177777 .WORD -1 ;DRIVE 4
```

```

7127 036714 177777 .WORD -1 ;DRIVE 5
7128 036716 177777 .WORD -1 ;DRIVE 6
7129 036720 177777 .WORD -1 ;DRIVE 7
7130
7131 ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
7132 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
7133 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
7134
7135 036722 177777 DTUW: .WORD -1
7136
7137 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
7138 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
7139 ;ATTENTION BIT
7140
7141 036724 001 ATABIT: .BYTE 1 ;DRIVE 0
7142 036725 002 .BYTE 2 ;DRIVE 1
7143 036726 004 .BYTE 4 ;DRIVE 2
7144 036727 010 .BYTE 10 ;DRIVE 3
7145 036730 020 .BYTE 20 ;DRIVE 4
7146 036731 040 .BYTE 40 ;DRIVE 5
7147 036732 100 .BYTE 100 ;DRIVE 6
7148 036733 200 .BYTE 200 ;DRIVE 7
7149
7150 ;FSRM03 TO RH70 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
7151 ;CALLING IT FATAL (MCPEM=1 WORD)
7152
7153 036734 000003 MCPEM: .WORD 3
7154
7155 ;STORAGE FOR RMADR (THE FIRST ADDRESS (776700) OF THE RH70/RM03),
7156 ;RMVEC (THE VECTOR ADDRESS (254)). AND RMVEC+2 (THE BP LEVEL (5)).
7157
7158 036736 17670C RMADR: .WORD 176700
7159 036740 000254 000240 RMVEC: .WORD 254,5*32.
7160
7161 ;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)
7162
7163 036744 000004 MXLACT: .WORD 4
7164 ;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)
7165
7166 036746 001000 MXDLTA: .WORD 8*64.
7167 ;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)
7168
7169 036750 000200 MNDLTA: .WORD 2*64.
7170 ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW=1 WORD)
7171
7172 036752 000005 MXWNDW: .WORD 5
7173
7174 ;DEFINITIONS OF THE RH70/RM03 ADDRESS INDEXES
7175
7176 000000 RMCS1=0 ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
7177 000002 RMWC=2 ;WORD COUNT REGISTER (NOT A DRIVE REG)
7178 000004 RMBA=4 ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
7179 000006 RMDA=6 ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
7180 000010 RMCS2=10 ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
7181 000012 RMDS=12 ;DRIVE STATUS REGISTER (DRIVE REG 01)
7182 000014 RMEP1=14 ;ERROR REGISTER #1 (DRIVE REG. 02)

```

```

7183      000016      RMA5=16      ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
7184      000020      RMLA=20      ;LOOK AHEAD REGISTER (DRIVE REG. 07)
7185      000022      RMOB=22      ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
7186      000024      RMMR1=24     ;MAINTAINABILITY REGISTER (DRIVE REG. 03)
7187      000026      RMDT=26     ;DRIVE TYPE REGISTER (DRIVE REG. 06)
7189      000030      RMSN=30     ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
7189      000032      RMOF=32     ;OFFSET REGISTER (DRIVE REG. 11)
7190      000034      RMOC=34     ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
7191      000036      RMHR=36     ;DUMMY ADDRESS REGISTER (DRIVE REG. 13)
7192      000040      RMMR2=40     ;MAINTENANCE REGISTER #2
7193      000042      RMER2=42     ;ERROR REGISTER #2 (DRIVE REG. 15)
7194      000044      RMEC1=44     ;ECC POSITION REGISTER (DRIVE REG. 16)
7195      000046      RMEC2=46     ;ECC PATTERN REGISTER (DRIVE REG. 17)
7196
7197      ;RH70/RM03 DRIVER INITIALIZATION CODE
7198      ;THIS ROUTINE WILL DETERMINE WHICH RM03 DRIVES ARE
7199      ;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
7200      ;TO THE PROPER STATE FOR EACH DRIVE.
7201      ;NOTE: THIS ROUTINE CALLS DRVINT
7202
7203      ;CALL
7204
7205      ;       JSR      PC,RMINIT
7206      ;       RETURN
7207
7208      ;NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
7209
7210      RMINIT: SAVREG      ;SAVE R0 - R5
7211      MOV      @#PS, -(SP) ;SAVE THE PRESENT PROCESSOR STATUS
7212      MOV      @(<5*32.> @#PS ;CHANGE THE PRIORITY TO 5
7213      JSR      PC,CLIQUE  ;CLEAR ALL REQUEST QUEUES
7214      MOV      @RMERRS,R1  ;FIRST ADDRESS TO BE CLEARED
7215      MOV      @SEEKFG,R2  ;LAST ADDRESS TO BE CLEARED
7216      1$: CLR      (R1)+    ;CLEAR
7217      CMP      R1,R2      ;ARE WE DONE?
7218      BLO     1$         ;BRANCH IF NO
7219      MOV      @DTUW,R2   ;LAST ADDRESS
7220      2$: MOV      @-1,(R1)+ ;INITIALIZE
7221      CMP      R1,R2      ;DONE?
7222      BLOS   2$         ;LOOP IF NO
7223      CLR      DRVSTA     ;SET ALL DRIVES TO OFFLINE
7224      CLR      DRVSTA+2
7225      CLR      DRVSTA+4
7226      CLR      DRVSTA+6
7227      MOV      @RVEC,R3   ;SETUP THE RH70/RM03 VECTOR
7228      MOV      @ISR,(R3)+
7229      MOV      @RVEC+2,(R3)
7230      MOV      @RADR,R4   ;FIRST ADDRESS OF RH70/RM03
7231      MOV      @BIT05,RMCS2(R4) ;MASSBUS INIT
7232      CLR      R1         ;START WITH DRIVE 0
7233      JSR      @R0,DRVINT  ;INIT THE DRIVE
7234      BR      4$         ;'DVA' NOT SET OR PARITY ERROR
7235      BR      5$         ;NORMAL RETURN
7236      4$: CLRB   DRVSTA(R1) ;SET DRIVE STATUS TO OFFLINE
7237      5$: INC     R1       ;GO TO NEXT DRIVE
7238      BIC     @IC7,R1     ;MASK OUT UNUSED BITS
  
```

K13

```

7239 037120 001366      BNE      3$          ;BR IF MORE DRIVES TO GO
7240 037122 012701 000007  MOV      #7,R1      ;START WITH DRIVE 7
7241 037126 005037 177776  CLR      @#PS       ;CLEAR THE PROCESSOR STATUS
7242 037132 105761 036630 6$: TSTB   DPINT(R1)  ;WAITING FOR DRIVE TO SWITCH PORTS ?
7243 037136 001405      BEQ      8$          ;BR NOT WAITING
7244 037140 004737 044252  JSR      PC,SET.IE  ;SET INTERRUPT
7245 037144 105761 036630 7$: TSTB   DPINT(R1)  ;DRIVE SWITCHED PORTS ?
7246 037150 001375      BNE      7$          ;BR IF NOT
7247 037152 005301 8$: DEC   R1          ;GO TO THE NEXT DRIVE
7248 037154 100366      BPL      6$          ;CHECK NEXT DRIVE
7249 037156 012637 177776  MOV      (SP)+,@#PS ;RESTORE THE PROCESSOR STATUS
7250 037162 104413      RESREG   ;RESTORE RD - R5
7251 037164 000207      RTS      PC          ;BYE-BYE
7252
7253
7254
7255
7256
7257
7258
7259
7260
7261
7262
7263
7264
7265
7266
7267 037166 010546      :DRIVE INITIALIZATION ROUTINE
7268 037170 105061 036610  ;THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
7269 037174 105061 036620  ;AN RMO3. IF IT IS A "READ-IN PRESET" IS ISSUED AND FMT22
7270 037200 105061 036656  ;IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
7271 037204 010164 000010  ;INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
7272 037210 112764 000111 000000  ;DRVSTA IS SET TO THE PROPER CONDITION.
7273 037216 032764 010000 000010  :CALL
7274 037224 001403      :
7275 037226 004737 044252  MOV      #DRVNUM,R1 ;DRIVE NUMBER TO R1
7276 037232 000507      MOV      RMAADR,R4  ;UNIBUS ADDRESS OF RH70/RMO3 (RMCS1)
7277 037234 105061 036610  JSR      RD,DRVINT  ;CALLED BY A JSR
7278 037240 032764 004000 000000  RETURN1 ;ERROR OCCURRED (PARITY)
7279 037246 001750      RETURN2 ;NORMAL RETURN
7280 037250 004037 043562  :
7281 037254 000026      DRVINT: MOV      R5,-(SP)  ;SAVE R5
7282 037256 037476      DULP:  CLRB   DRVSTA(R1) ;START DRIVE STATUS AS OFFLINE
7283 037260 012605      CLRB   DRVSTYP(R1)  ;CLEAR THE DRIVE TYPE INDICATOR
7284 037262 112761 000004 036620  CLRB   ULDFLG(R1)   ;CLEAR THE UNLOAD FLAG
7285 037270 022705 020024  MOV      R1,RMCS2(R4) ;SELECT A DRIVE
7286 037274 001420      MOVB   #11,RMCS1(R4) ;DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
7287 037276 022705 024024  BIT     #BIT12,RMCS2(R4) ;NONEXISTENT DRIVE?
7288 037302 001415      BEQ    1$          ;NO---BRANCH
7289 037304 112761 000005 036620  JSR    PC,SET.IE  ;GO SET "IE" WITHOUT A "TRE"
7290 037312 022705 020025  BR     6$          ;LEAVE THIS ROUTINE
7291 037316 001407      1$: CLRB   DRVSTA(R1) ;SET DRIVE STATUS TO OFFLINE
7292 037320 022705 024025  BIT     #BIT11,RMCS1(R4) ;SEE IF DRIVE AVAILABLE
7293 037324 001404      BEQ    DULP       ;BR IF DRIVE NOT AVAILABLE
7294 037326 112761 177777 036620  JSR    RD,RD.RM   ;READ THE DRIVE TYPE REG.
7295
7296
7297
7298
7299
7300
7301
7302
7303
7304
7305
7306
7307
7308
7309
7310
7311
7312
7313
7314
7315
7316
7317
7318
7319
7320
7321
7322
7323
7324
7325
7326
7327
7328
7329
7330
7331
7332
7333
7334
7335
7336
7337
7338
7339
7340
7341
7342
7343
7344
7345
7346
7347
7348
7349
7350
7351
7352
7353
7354
7355
7356
7357
7358
7359
7360
7361
7362
7363
7364
7365
7366
7367
7368
7369
7370
7371
7372
7373
7374
7375
7376
7377
7378
7379
7380
7381
7382
7383
7384
7385
7386
7387
7388
7389
7390
7391
7392
7393
7394
7395
7396
7397
7398
7399
7400
7401
7402
7403
7404
7405
7406
7407
7408
7409
7410
7411
7412
7413
7414
7415
7416
7417
7418
7419
7420
7421
7422
7423
7424
7425
7426
7427
7428
7429
7430
7431
7432
7433
7434
7435
7436
7437
7438
7439
7440
7441
7442
7443
7444
7445
7446
7447
7448
7449
7450
7451
7452
7453
7454
7455
7456
7457
7458
7459
7460
7461
7462
7463
7464
7465
7466
7467
7468
7469
7470
7471
7472
7473
7474
7475
7476
7477
7478
7479
7480
7481
7482
7483
7484
7485
7486
7487
7488
7489
7490
7491
7492
7493
7494
7495
7496
7497
7498
7499
7500
  
```



```

7295 037334 000446          BR      6$          ;EXIT
7296 037336 012746 000121     2$:  MOV      #121, -(SP) ;DO A "READ-IN PRESET"
7297 037342 004037 043742     JSR      RO, WRT.RM
7298 037346 000000          RMCS1
7299 037350 037476          B$
7300 037352 012746 010000     MOV      #BIT12, -(SP) ;SET FMT22=1
7301 037356 004037 043742     JSR      RO, WRT.RM
7302 037362 000032          RMOF
7303 037364 037476          B$
7304 037366 004037 043562     JSR      RO, RD.RM ;READ RMD5
7305 037372 000012          RMD5
7306 037374 037476          B$
7307 037376 012605          MOV      (SP)+, R5 ;AND SAVE IT IN R5
7308 037400 100015          BPL      4$          ;BRANCH IF ATA=0
7309 037402 116164 036724 000016     MOVB     ATABIT(R1), RMA5(R4) ;CLEAR ATTENTION BIT
7310 037410 004037 043562     JSR      RO, RD.RM ;FIND OUT WHY ATA=1
7311 037414 000014          RMER1
7312 037416 037476          B$
7313 037420 006126          ROL      (SP)+ ;IS IT UNSAFE?
7314 037422 100004          BPL      4$          ;BR IF NOT
7315 037424 112761 177777 036610     MOVB     #-1, DRVSTA(R1) ;SET UNSAFE INDICATOR
7316 037432 000407          BR      6$          ;EXIT
7317 037434 005105          COM      R5 ;CHECK MOL, DPR, DRY, AND VV
7318 037436 042705 167077     BIC      #1<BIT12!BIT08!BIT07!BIT06>, R5
7319 037442 001003          BNE     6$          ;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
7320 037444 112761 000001 036610     MOVB     #1, DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
7321 037452 005720          TST      (R0)+ ;STEP OVER THE ERROR RETURN
7322 037454 000410          BR      8$          ;EXIT
7323 037456 006301          ASL      R1 ;CHANGE INDEX TO ADDRESS WORDS
7324 037460 012761 060000 036702     MOV      #60000, TIMER(R1) ;START 2 SEC TIMER
7325 037466 006201          ASR      R1 ;RESTORE R1
7326 037470 112761 177777 036630     MOVB     #-1, DPINT(R1) ;SET PORT INITIALIZE INIDICATOR
7327 037476 012605          MOV      (SP)+, R5 ;RESTORE R5
7328 037500 000200          RTS      RO ;EXIT
7329
7330 ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
7331 ;CALL
7332 ;
7333 ;
7334 ; JSR      RO, @#RMO3 ;CALL THE RMO3 DRIVER
7335 ; PNTADR ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
7336 ; RETURN1 ;RETURN HERE IF QUEUE IS FULL
7337 ; RETURN2 ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
7338 ; ;IS AN ERROR CONDITION
7339
7340 037502 013746 177776          RMO3: MOV      @#PS, -(SP) ;SAVE THE CALLING STATUS
7341 037506 013737 036742 177776     MOV      RMVEC+2, @#PS ;DON'T ALLOW ANY RMO3 INTERRUPTS
7342 037514 112737 000001 036654     MOVB     #1, ACTDRV ;SET "ACTIVE DRIVER" FLAG
7343 037522 104412          SAVREG ;SAVE R0 - R5
7344 037524 011002          MOV      (R0), R2 ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
7345 037526 005062 000016     CLR      16(R2) ;CLEAR THE STATUS/ERROR INDICATOR
7346 037532 111201          MOVB     (R2), R1 ;PICKUP THE DRIVE NUMBER
7347 037534 013704 036736     MOV      RMDR, R4 ;UNIBUS ADDRESS OF RMCS1
7348 037540 105761 036610     TSTB     DRVSTA(R1) ;CHECK DRIVES STATUS
7349 037544 003014          BGT      1$          ;BRANCH IF ONLINE
7350 037546 105761 036656     TSTB     ULDFLG(R1) ;UNLOAD COMMAND IN QUEUE?
    
```

M13

```

7351 037552 001036 BNE 3$ ;BRANCH IF YES
7352 037554 105761 036630 TSTB DPINT(R1) ;TRYING TO INIT THE DRIVE
7353 037560 001042 BNE 5$ ;BR IF YES
7354 037562 004037 037166 JSR RO,DRVINT ;GO INIT. THE DRIVE
7355 037566 000434 BR 4$ ;ERROR RETURN
7356 037570 105761 036610 TSTB DRVSTA(R1) ;IS DRIVE STATUS ONLINE?
7357 037574 003445 BLE 6$ ;BR IF NOT
7358 037576 105761 036640 1$: TSTB DPRQS(R1) ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
7359 037602 001031 BNE 5$ ;BR IF YES
7360 037604 010164 000010 MOV R1,RMCS2(R4) ;SELECT THE DRIVE
7361 037610 004037 044714 JSR RO,DRVQUE ;PUT THIS REQUEST IN QUEUE
7362 037614 000460 BR 9$ ;QUEUE IS FULL
7363 037616 122762 000103 000002 CMPB #103,2(R2) ;IS THIS REQ. FOR AN UNLOAD?
7364 037624 001003 BNE 2$ ;BR IF NO
7365 037626 112761 177777 036656 MOVB #-1,ULDFLG(R1) ;SET THE "UNLOAD IN QUEUE" FLAG
7366 037634 105761 036600 2$: TSTB DRVACT(R1) ;IS THIS DRIVE ACTIVE?
7367 037640 001043 BNE 8$ ;BR IF YES
7368 037642 004737 037774 JSR PC,OPT ;CALL THE OPTIMIZER
7369 037646 000440 BR 8$
7370 037650 012762 120000 000016 3$: MOV #BIT15!BIT13,16(R2) ;SET THE "UNLOAD IN QUEUE" ERROR FLAG
7371 037656 000434 BR 8$ ;EXIT
7372 037660 004737 041054 4$: JSR PC,C17 ;GO HANDLE THE PARITY ERROR
7373 037664 000431 BR 8$
7374 037666 004037 044714 5$: JSR RO,DRVQUE ;PUT REQUEST IN QUEUE
7375 037672 000431 BR 9$ ;QUEUE IS FULL
7376 037674 032714 000100 BIT #BIT06,(R4) ;IE BIT SET ?
7377 037700 001023 BNE 8$ ;YES
7378 037702 004737 044252 JSR PC,SET.IE ;SET THE INTERRUPT
7379 037706 000420 BR 8$ ;RETURN
7380 037710 105761 036610 6$: TSTB DRVSTA(R1) ;SEE IF DRIVE OFFLINE OR UNSAFE
7381 037714 002412 BLT 7$ ;BR IF UNSAFE
7382 037716 012762 140000 000016 MOV #BIT15!BIT14,16(R2) ;SET OFFLINE ERROR INDICATOR
7383 037724 105761 036620 TSTB DRVSTYP(R1) ;SEE IF OFFLINE OR NONEXISTENT
7384 037730 001007 BNE 8$ ;BR IF OFFLINE
7385 037732 012762 100002 000016 MOV #BIT15!BIT01,16(R2) ;REPORT DRIVE NONEXISTENT
7386 037740 000403 BR 8$ ;GO TO EXIT
7387 037742 012762 110000 000016 7$: MOV #BIT15!BIT12,16(R2) ;DRIVE IS UNSAFE
7388 037750 104413 8$: RESREG ;RESTORE R0 - R5
7389 037752 005720 TST (R0)+ ;SETUP FOR NORMAL RETURN
7390 037754 000401 BR 10$ ;FINISH UP, THEN EXIT
7391 037756 104413 9$: RESREG ;RESTORE R0 - R5
7392 037760 005720 10$: TST (R0)+ ;CORRECT THE RETURN ADDRESS
7393 037762 105037 036654 CLRB ACTDRV ;CLEAR "ACTIVE DRIVER" FLAG
7394 037766 012637 177776 MOV (SP)+,2#PS ;RETURN "PS" TO USER LEVEL
7395 037772 000200 RTS RO ;RETURN TO CALLER
7396
7397 ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
7398
7399 ;CALL
7400
7401 MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
7402 JSR PC,OPT ;SETUP A COMMAND
7403
7404 OPT: SAVREG ;SAVE R0 - R5
7405 MOV 2#PS,-(SP) ;SAVE PROC. STATUS
7406 BICB ATABIT(R1),SRCHWT ;CLEAR LA SEACH FLAG
7406 CLRB DPRQS(R1) ;RESET THE PORT REQ FLAG ****

```

```

7407 040014 004737 044770 JSR PC,GETREQ ;GET "DPB" POINTER OF REQUEST
7408 040020 005702 TST R2 ;IS THERE A REQUEST IN QUEUE?
7409 040022 001472 BEQ 7$ ;NO--BRANCH TO EXIT
7410 040024 010164 000010 MOV R1, RMCS2(R4) ;LOAD THE DRIVE ADDRESS *****
7411 040030 012764 000111 000000 MOV #111, RMCS1(R4) ;CLEAR THE DRIVE
7412 040036 032764 004000 000000 BIT #BIT11, RMCS1(R4) ;DVA SET ?
7413 040044 001446 BEQ 5$ ;TO PROT REQUEST, IF NOT
7414 040046 105761 036610 10$: TSTB DRVSTA(R1) ;IS DRIVE ONLINE?
7415 040052 003014 BGT 1$ ;YES--BRANCH
7416 040054 004737 045012 JSR PC,POPQUE ;NO--REMOVE REQUEST FROM QUEUE
7417 040060 012762 140000 000016 MOV #BIT15!BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
7418 040066 105761 036610 TSTB DRVSTA(R1) ;IS DRIVE UNSAFE ?
7419 040072 100053 BPL 8$ ;BR TO EXIT IF NOT
7420 040074 012762 110000 000016 MOV #BIT15!BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
7421 040102 000447 BR 8$ ;BRANCH TO EXIT
7422 040104 1$:
7423 : MOV #111, -(SP) ;LOAD COMMAND ONTO THE STACK
7424 : JSR RO, WAT.RM ;LOAD THE REGISTER
7425 : RMCS1 ;REGISTER INCREMENT
7426 : 6$ ;ERROR RETURN ADDRESS
7427 : BIT #BIT11, (R4) ;DRIVE AVAILABLE ?
7428 : BEQ 9$ ;BR IF NOT
7429 040104 122762 000150 000002 CMPB #150,2(R2) ;IS THE REQUEST FOR I/O?
7430 040112 002403 BLT 2$ ;YES--BRANCH
7431 040114 004737 040440 JSR PC,C14 ;CALL THE COMMAND INITIATOR
7432 040120 000440 BR 8$ ;BRANCH TO EXIT
7433 040122 005737 036722 2$: TST DTUW ;DATA TRANSFER UNDERWAY?
7434 040126 002012 BGE 4$ ;YES--GO START A SEARCH
7435 040130 005737 036700 TST SEEKFG ;DO IMPLIED SEEKS?
7436 040134 100404 BMT 3$ ;YES---BRANCH
7437 040136 004037 041412 JSR RO,LA ;NO--DO LOOK AHEAD
7438 040142 000427 BR 8$ ;RETURN HERE ON A PARITY ERROR
7439 040144 000403 BR 4$ ;GO START A SEARCH
7440 040146 004737 040232 3$: JSR PC,C11 ;START A DATA TRANSFER
7441 040152 000423 BR 8$
7442 040154 004737 040340 4$: JSR PC,C13 ;START A SEARCH
7443 040160 000420 BR 8$ ;GO TO THE EXIT
7444 040162 112761 177777 036640 5$: MOV #1, DPRQS(R1) ;SET PORT REQUEST INDICATOR
7445 040170 010103 MOV R1,R3 ;SET UP TO ADDRESS WORDS
7446 040172 006303 ASL R3 ;CONVERT TO WORD INDEX
7447 040174 012763 060000 036702 MOV #60000, TIMER(R3) ;START 10 SEC TIMER
7448 040202 000402 BR 7$ ;EXIT
7449 040204 004737 041054 6$: JSR PC,C17 ;PROCESS THE PARITY ERROR
7450 040210 032714 000100 7$: BIT #BIT06, (R4) ;SEE IF 'IE' ALREADY SET
7451 040214 001002 BNE 8$ ;BR IF SET
7452 040216 004737 044252 JSR PC,SET.IE ;SET "IE" WITHOUT A "TRE"
7453 040222 012637 177776 8$: MOV (SP)+, @#PS ;RESTORE PROC. STATUS
7454 040226 104413 RESREG ;RESTORE R0 - R5
7455 040230 000207 RTS PC
7456 :
7457 :COMMAND INITIATOR
7458 :
7459 :CALL
7460 : MOV #DRVNUM,R1 ;DRIVE NUMBER
7461 : MOV #DPB,R2 ;ADDRESS OF DPB
7462 : JSR PC,C1? ;C1? = C11,C13, OR C14

```

```

7463 :
7464 :
7465 :
7466 :
7467 :
7468 040232 004737 045012 CI1: JSR 00.POPQUE ;REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
7469 040236 010237 036650 MOV R2,TRANSW ;PUT REQ. IN TRANSFER WAIT QUEUE
7470 040242 010203 MOV R2,R3 ;UPB ADDRESS TO R3
7471 040244 013704 036736 MOV RMAADR,R4 ;RMCS1 ADDRESS
7472 040250 010164 000010 MOV R1,RMCS2,R4 ;SELECT DRIVE
7473 040254 062703 000004 ADD #4,R3 ;DESIRED WORD COUNT
7474 040260 062704 000002 ADD #2,R4 ;RMHC ADDRESS
7475 040264 012324 MOV (R3)+,(R4)+ ;LOAD WORD COUNT
7476 040266 012324 MOV (R3)+,(R4)+ ;LOAD BUFFER ADDRESS
7477 040270 012346 MOV (R3)+,(SP) ;LOAD SECTOR AND TRACK
7478 040272 004037 043742 JSR RO,WRT.RM ;CALL THE LOAD(WRITE) ROUTINE
7479 040276 000006 RMDR ;INDEX OF REGISTER TO LOAD
7480 040300 041054 CI7 ;ERROR RETURN ADDRESS
7481 040302 012346 MOV (R3)+,(SP) ;LOAD CYLINDER ADDRESS
7482 040304 004037 043742 JSR RO,WRT.RM
7483 040310 000034 RMDC
7484 040312 041054 CI7
7485 040314 016246 000002 MOV 2(R2),-(SP) ;LOAD "COMMAND+GO", "R17&R16", AND "PSEL"
7486 040320 004037 043742 JSR RO,WRT.RM
7487 040324 000000 RMCS1
7488 040326 041054 CI7
7489 040330 010137 036722 MOV R1,DTUM ;SET "DATA TRANSFER UNDERWAY"
7490 040334 000137 041016 JMP C15
7491 040340 013704 036736 CI3: MOV RMAADR,R4 ;RMCS1 ADDRESS
7492 040344 010164 000010 MOV R1,RMCS2,R4 ;SELECT DRIVE
7493 040350 016246 000012 MOV 12(R2),-(SP) ;DESIRED CYLINDER ADDRESS
7494 040354 004037 043742 JSR RO,WRT.RM
7495 040360 000034 RMDC
7496 040362 041054 CI7
7497 040364 116203 000010 MOVVB 10(R2),R3 ;PICKUP SECTOR ADDRESS
7498 : SUB MXWINDW,R3 ;BACKUP BY MAX. SEARCH FOR I/O WINDOW
7499 : BGE 1$
7500 : ADD #32,R3
7501 040370 010346 1$ : MOV R3,-(SP) ;COMBINE THE ADJUSTED SECTOR WITH
7502 040372 042716 177740 BIC #177740,(SP) ;CHOP OF ALL EXENTED BITS ,IF ANY
7503 040376 116266 000011 000001 MOVVB 11(R2),1(SP) ;THE DESIRED TRACK
7504 040404 004037 043742 JSR RO,WRT.RM ;LOAD DESIRED TRACK & SECTOR
7505 040410 000006 RMDR
7506 040412 041054 CI7
7507 040414 012746 000131 MOV #131,-(SP) ;START A SEARCH
7508 040420 004037 043742 JSR RO,WRT.RM
7509 040424 000000 RMCS1
7510 040426 041054 CI7
7511 040430 156137 036724 036652 BISB ATABIT(R1),SRCHWT ;SET "SEARCH WAIT" KEY
7512 040436 000567 BR C15
7513 040440 013704 036736 CI4: MOV RMAADR,R4 ;RMCS1 ADDRESS
7514 040444 010164 000010 MOV R1,RMCS2,R4 ;SELECT DRIVE
7515 040450 116203 000002 MOVVB 2(R2),R3 ;PICKUP THE REQUESTED COMMAND
7516 040454 122703 000131 CMPB #131,R3 ;IS IT A SEARCH COMMAND?
7517 040460 001007 BNE 1$ ;BRANCH IF NO
7518 040462 C16246 000010 MOV 10(R2),-(SP) ;LOAD DESIRED TRACK & SECTOR

```

C14

7519	040466	004037	043742		JSR	RO,WRT.RM	
7520	040472	000006			RMDA		
7521	040474	041054			CI7		
7522	040476	000403			BR	2\$:GO LOAD CYLINDER
7523	040500	122703	000105	1\$:	CMPB	#105,R3	:IS IT A SEEK COMMAND
7524	040504	001007			BNE	3\$:BRANCH IF NO
7525	040506	016246	000012	2\$:	MOV	12(R2),-(SP)	:LOAD DESIRED CYLINDER
7526	040512	004037	043742		JSR	RO,WRT.RM	
7527	040516	000034			RMDC		
7528	040520	041054			CI7		
7529	040522	000546			BR	CI6	
7530	040524	122703	000115	3\$:	CMPB	#115,R3	:IS IT AN "OFFSET" COMMAND?
7531	040530	001013			BNE	4\$:BR IF NO
7532	040532	004037	043562		JSR	RO,RO.RM	:MERGE THE OFFSET VALUE INTO RMOF
7533	040536	000032			RMOF		:BUT DON'T CHANGE THE UPPER
7534	040540	041054			CI7		
7535	040542	116216	000001		MOVB	1(R2), (SP)	:BYTE WHEN LOADING THE
7536	040546	004037	043742		JSR	RO,WRT.RM	:REGISTER (RMOF)
7537	040552	000032			RMOF		
7538	040554	041054			CI7		
7539	040556	000530			BR	CI6	:GO START THE COMMAND
7540	040560	122703	000107	4\$:	CMPB	#107,R3	:IS IT A "RECALIBRATE" COMMAND?
7541	040564	001525			BEQ	CI6	:BRANCH IF YES
7542	040566	122703	000117		CMPB	#117,R3	:IS IT A RETURN TO CENTER?
7543	040572	001522			BEQ	CI6	:BRANCH IF YES
7544	040574	122703	000103		CMPB	#103,R3	:IS IT AN "UNLOAD" COMMAND?
7545	040600	001016			BNE	5\$:BRANCH IF NO
7546	040602	112761	000001	036600	MOVB	#1,DRVACT(R1)	:SET THE DRIVE ACTIVE INDICATOR
7547	040610	105061	036E10		CLRB	DRVSTA(R1)	:PUT DRIVE STATUS TO OFFLINE
7548	040614	112761	000001	036656	MOVB	#1,ULDFLG(R1)	:SET "UNLOAD IN PROGRESS" FLAG
7549	040622	010346			MOV	R3,-(SP)	:START THE "UNLOAD" COMMAND
7550	040624	004037	043742		JSR	RO,WRT.RM	
7551	040630	000000			RMCS1		
7552	040632	041054			CI7		
7553	040634	000207			RTS	PC	:RETURN TO USER
7554	040636	122703	000143	5\$:	CMPB	#143,R3	:IS IT A "SET FORMAT" COMMAND?
7555	040642	001014			BNE	6\$:BRANCH IF NO
7556	040644	004037	043562		JSR	RO,RO.RM	:READ THE OFFSET REGISTER
7557	040650	000032			RMOF		
7558	040652	041054			CI7		
7559	040654	116266	000001	000001	MOVB	1(R2), 1(SP)	:COMBINE "FMT22" "ECI" AND "HCI"
7560	040662	004037	043742		JSR	RO,WRT.RM	:LOAD "FMT22", "ECI", AND/OR "HCI".
7561	040666	000032			RMOF		
7562	040670	041054			CI7		
7563	040672	000436			BR	12\$	
7564	040674	122703	000141	6\$:	CMPB	#141,R3	:IS IT A "GET REGISTER" COMMAND?
7565	040700	001023			BNE	10\$:BRANCH IF NO
7566	040702	016203	000006	7\$:	MOV	6(R2),R3	:POINTS TO 1ST ADDRESS OF WHERE
7567							:TO PUT THE REGISTER(S)
7568	040706	116237	000010	040724	MOVB	10(R2),9\$:INIT. THE INDEX FOR THE FIRST REG.
7569	040714	116205	000011		MOVB	11(R2),R5	:INDEX OF LAST REG. TO MOVE
7570	040720	004037	043562	8\$:	JSR	RO,RO.RM	:READ RH70/RMO3 REGISTER
7571	040724	000000		9\$:	RMCS1		:INDEX OF REG. TO READ
7572	040726	041054			CI7		
7573	040730	012623			MOV	(SP)+,(R3)+	:GET THE CONTENTS OF RH70 RMO3 REG.
7574	040732	023705	040724		CMP	9\$,R5	:LAST REG. BEEN READ

7575	040736	001414				BEQ	12\$:GET OUT IF YES
7576	040740	062737	000002	040724		ADD	#2,9\$:INCREASE THE INDEX BY 2
7577	040746	000764				BR	8\$:LOOP--MORE TO READ
7578	040750	132703	000145		10\$:	CMPB	#145,R3		:IS IT A "SELECT DRIVE" COMMAND?
7579	040754	001405				BEQ	12\$:BRANCH IF YES
7580	040756	010346			11\$:	MOV	R3,-(SP)		:LOAD THE COMMAND
7581	040760	004037	043742			JSR	RD,WRT.RM		
7582	040764	000000				RMCS1			
7583	040766	041054				CI7			
7584	040770	004737	045012		12\$:	JSR	PC,POPQUE		:REMOVE REQ. FROM QUEUE
7585	040774	052762	000200	000016		BIS	#BIT07,16(R2)		:SET THE "DONE" BIT
7586	041002	005737	036676			TST	SAVEFG		:SAVE THE RH70/RM03 REGISTERS?
7587	041006	100002				BPL	13\$:BRANCH IF NO
7588	041010	004737	044134			JSR	PC,SVRH70		:YES--GO SAVE THE REGISTERS
7589	041014	000207			13\$:	RTS	PC		:RETURN TO USER
7590	041016	006301			CI5:	ASL	R1		
7591	041020	012761	060000	036702		MOV	#60000,TIMER(R1)		:SET A ONE SECOND TIMER
7592	041026	006201				ASR	R1		
7593	041030	112761	000001	036600		MOVB	#1,DRVACT(R1)		:SET THE DRIVE ACTIVE
7594	041036	000207				RTS	PC		:RETURN TO THE USER
7595	041040	010346			CI6:	MOV	R3,-(SP)		:LOAD THE COMMAND
7596	041042	004037	043742			JSR	RD,WRT.RM		
7597	041046	000000				RMCS1			
7598	041050	041054				CI7			
7599	041052	000761				BR	CI5		
7600	041054	032764	010000	000010	CI7:	BIT	#BIT12,RMCS2(R4)		:DRIVE NON-EXISTENT ?
7601					1\$:	BNE	CI8		:BR IF YES
7602	041062	005702				TST	R2		:ANYTHING IN QUEUE ?
7603						BEQ	CI7B		:BR IF NOT
7604	041064	001001				BNE	2\$:BRANCH IF QUEUE IS THERE
7605	041066	000207				RTS	PC		:OTHERWISE EXIT
7606	041070	012762	104000	000016	2\$:	MOV	#BIT15!BIT11,16(R2)		:SET "PARITY" ERROR INDICATOR
7607					CI7B:	JSR	PC,SVRH70		:GO SAVE THE RH70/RM03 REGISTERS
7608	041076	012746	000111			MOV	#11,-(SP)		:DO A "DRIVE CLEAR"
7609	041102	004037	043742			JSR	RD,WRT.RM		
7610	041106	000000				RMCS1			
7611	041110	041154				CI8			
7612	041112	004737	044674		2\$:	JSR	PC,EMPTYQ		:EMPTY THE QUEUE
7613	041116	105061	036640			CLRB	DPRQS(R1)		:CLEAR THE PORT REQUEST FLAG
7614	041122	105061	036656			CLRB	ULDFLG(R1)		:CLEAR THE UNLOAD IN QUEUE FLAG
7615	041126	105061	036600			CLRB	DRVACT(R1)		:DRIVE IS IDLE
7616	041132	020237	036650			CMP	R2,TRNSWT		:IF THIS DRIVE HAD AN I/O REQUEST
7617						CMP	R1,DTUW		:IF THIS DRIVE HAD AN I/O REQUEST
7618	041136	001005				BNE	1\$:IN PROGRESS CLEAR ALL OF THE FLAGS
7619	041140	005037	736650			CLR	TRNSWT		
7620	041144	012737	177777	036722		MOV	#-1,DTUW		
7621	041152	000207			1\$:	RTS	PC		
7622	041154	104412			CI8:	SAVREG			:SAVE R0 - R5
7623	041156	032764	010000	000010		BIT	#BIT12,RMCS2(R4)		:IS "NEO" SET ?
7624						BNE	1\$:BR IF YES
7625	041164	005001				CLP	R1		
7626	041166	005003				CLP	R3		
7627	041170	105761	036600		1\$:	TSTB	DRVACT(R1)		:DRIVE ACTIVE?
7628						BEQ	5\$:BRANCH IF NO
7629	041174	001003				BNE	22\$:BRANCH IF IN ACTIVE
7630	041176	105761	036640			TSTB	DPRQS(R1)		:PORT REQUEST

E14

```

7631 041202 001443          BEQ      5$          ;BRANCH IF NOT
7632 041204 013702 036650 22$:  MOV      TRANSW,R2    ;GET THE "TRANSFER WAIT" QUEUE
7633 041210 020137 036722    CMP      R1,DTUW    ;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
7634 041214 001402          BEQ      2$          ;BRANCH IF YES
7635 041216 004737 044770    JSR      PC,GETREQ  ;GET THE DPB POINTER
7636 041222 005702          TST      R2         ;QUEUE ENTRY FOR DRIVE ?
7637 041224 001413          BEQ      4$          ;BR IF NOT
7638 041226 032764 010000 000010 BIT      #BIT12,RMCS2(R4) ;'NED' SET ?
7639 041234 001404          BEQ      3$          ;BR IF NOT
7640 041236 012762 100002 000016 MOV      #BIT15!BIT01,16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
7641 041244 000403          BR       4$          ;CONTINUE
7642 041246 012762 102000 000016 3$:  MOV      #BIT15!BIT10,16(R2) ;SET "NON-CLEARABLE PARITY" ERROR INDICATOR
7643          JSR      PC,SVRH70 ;SAVE RH70/RM03 REGISTERS
7644 041254 012763 177777 036702 4$:  MOV      #-1,TIMER(R3) ;STOP THE TIMER
7645 041262 105061 036600    CLRB    DRVACT(R1) ;SET "DRIVE ACTIVE" TO IDLE
7646 041266 105061 036640    CLRB    DPRQS(R1) ;CLEAR PORT REQUEST FLAG
7647 041272 020137 036722    CMP      R1,DTUW    ;IS THIS DRIVE SETUP FOR A TRANSFER
7648 041276 001005          BNE     5$          ;BR IF NOT
7649 041300 012737 177777 036722 MOV      #-1,DTUW    ;RESET THE INDICATOR
7650 041306 005037 036650    CLR     TRANSW      ;CLEAR THE TRANSFER QUEUE
7651 041312 105061 036656          CLRB    ULDFLG(R1) ;CLEAR UNLOAD FLAG
7652 041316 032764 010000 000010 5$:  BIT      #BIT12,RMCS2(R4) ;'NED' SET ?
7653          BNE     6$          ;BR IF YES
7654 041324 005201          INC     R1         ;MOVE TO THE NEXT DRIVE
7655 041326 062703 000002          ADD     #2,R3
7656 041332 042701 177770          BIC     #1<7,R1
7657 041336 001314          BNE     1$          ;BRANCH IF MORE DRIVES
7658 041340 012737 177777 036722 MOV      #-1,DTUW    ;NO DATA TRANSFERS UNDERWAY
7659 041346 005037 036650    CLR     TRANSW      ;CLEAR THE 'TRANSFER WAIT' QUEUE
7660 041352 004737 044616          JSR      PC,CLRQUE  ;CLEAR ALL OF THE REQUEST QUEUES
7661 041356 012764 000040 000010 MOV      #BIT05,RMCS2(R4) ;DO A MASSBUS INIT.
7662 041364 000406          BR       7$          ;CONTINUE
7663 041366 004737 044674          JSR      PC,EMPTYQ  ;CLEAR THE DRIVE'S QUEUE
7664 041372 105061 036610          CLRB    DRVSTA(R1) ;SET DRIVE TO OFFLINE
7665 041376 105061 036620          CLRB    DRVSTYP(R1) ;CLEAR THE DRIVE TYPE INDICATOR
7666 041402 004737 044252          JSR      PC,SET.IE  ;SET "IE" WITHOUT "TPE"
7667 041406 104413          RESREG ;RESTORE R0 - R5
7668 041410 000207          RTS     PC         ;RETURN
7669
7670          ;LOOK AHEAD ROUTINE
7671          ;CALL
7672          ;
7673          ;
7674          ;
7675          ;
7676          ;
7677          ;
7678          ;
7679          ;
7680 LA:  MOV      RMADR,R4 ;GET RMCS1'S ADDRESS
7681  MOV      R1,RMCS2(R4) ;SELECT DRIVE
7682  JSR      RO,RO.AM ;READ DRIVE STATUS
7683  RMDS
7684  4$
7685  BIC     #1<020200,(SP) ;ON CYLINDER ?
7686  CMP     #200,(SP)+ ;PIP=0,DRY=1?
  
```

F14

MD-11-DZRMF-B RM03/RM02 EXTENDED DRIVE TEST MACY11 30(1046) 22-NOV-77 08:04 PAGE 144
 C2RMFB.P11 21-NOV-77 14:10 SINGLE/DUAL PORT RH70/RM03 DRIVER (REV 5.1)-24-AUG-77

SEQ 0174

```

7687 041442 001044          BNE      3$          ;NO
7688 041444 105261 036666     INCB     LACNT(R1)    ;INCREMENT THE LOOK AHEAD COUNT
7689 041450 126137 036666 036744  CMPB     LACNT(R1),MXLACT ;EXCEED MAX?
7690 041456 003033          BGT      2$          ;BRANCH IF YES
7691 041460 116203 000010     MOVB     10(R2),R3   ;GET DESIRED SECTOR ADDRESS AND
7692 041464 000303          SWAB     R3          ;MULT. BY 64--ALIGN WITH
7693 041466 006203          ASR      R3          ;LOOK AHEAD REGISTER
7694 041470 006203          ASR      R3
7695 041472 012737 000340 177776  MOV      #340,R#PS   ;PRIORITY LEVEL "7"
7696 041500 004037 043562 6$:     JSR      R0,RD.RM   ;READ LOOK AHEAD REGISTER
7697 041504 000020          RMLA
7698 041506 041560          4$
7699 041510 021664 000020     CMP      (SP),RMLA(R4) ;CORRECT LA NUMBER ?
7700 041514 001402          BEQ      7$          ;YES
7701 041516 005726          TST      (SP)+       ;NO,CLEAR STACK
7702 041520 000415          BR       3$
7703 041522 162603          7$:     SUB      (SP)+,R3   ;CALCULATE THE DELTA
7704 041524 002002          BGE      1$
7705 041526 062703 004000     ADD      #(-32.*64.),R3 ;MAKE THE DELTA POSITIVE
7706 041532 023703 036746 1$:     CMP      MXDLTA,R3   ;CHECK THE DELTA TO SEE
7707 041536 002406          BLT      3$          ;IF IT IS WITHIN THE
7708 041540 023703 036750     CMP      MNDLTA,R3  ;WINDOW---IF YES, ZERO
7709 041544 002003          BGE      3$          ;THE LOOK AHEAD COUNT
7710 041546 105061 036666 2$:     CLRB     LACNT(R1)  ;AND TAKE THE I/O EXIT
7711 041552 005720          TST      (R0)+
7712 041554 005720 3$:     TST      (R0)+       ;ADJUST THE RETURN ADDRESS
7713 041556 000402          BR       5$
7714 041560 004737 041054 4$:     JSR      PC,C17     ;PROCESS THE ERROR
7715 041564 000200 5$:     RTS      R0        ;RETURN
7716
7717 ;INTERRUPT SERVICE ROUTINE
7718
7719 041566 112737 000001 036654 ISR:   MOVB     #1,ACTDRV   ;SET "ACTIVE DRIVER" FLAG
7720 041574 104412          SAVREG   ;SAVE R0 - R5
7721 041576 013704 036736     MOV      RMADR,R4   ;ADDRESS OF RHSCSI
7722 041602 013701 036722     MOV      DTUW,R1    ;GET "DATA TRANSFER UNDERWAY" INDICATOR
7723 041606 002403          BLT      1$
7724 041610 004737 041632     JSR      PC,TD      ;BRANCH IF NO DATA TRANSFER UNDERWAY
7725 041614 000402          BR       2$
7726 041616 004737 042002 1$:     JSR      PC,SC      ;CALL TRANSFER DONE
7727 041622 104413 2$:     RESREG   ;EXIT
7728 041624 105037 036654     CLRB     ACTDRV    ;CALL SPECIAL CONDITIONS
7729 041630 000002          RTI      ;RESTORE R0 - R5
7730 ;CLEAR "ACTIVE DRIVER" FLAG
7731 ;RETURN
7732 ;TRANSFER DONE ROUTINE
7733 041632 105061 036600 7D:   CLRB     DRVACT(R1) ;SET DRIVE ACTIVE INDICATOR TO IDLE
7734 041636 012737 177777 036722  MOV      #-1,DTUW   ;NO DATA TRANSFERS UNDERWAY
7735 041644 006301          ASL      R1
7736 041646 012761 177777 036702  MOV      #-1,TIMER(R1) ;CANCEL TIMEOUT
7737 041654 006201          ASR      R1
7738 041656 013702 036650     MOV      TRNSWT,R2 ;GET "DPB" ADDRESS FROM THE
7739 041662 005037 036650     CLR      TRNSWT    ;TRANSFER WAIT QUEUE--CLEAR QUEUE
7740 041666 052762 000200 000016  BIS      #BIT07,16(R2) ;SET DONE
7741 041674 010164 000010     MOV      R1,RMC$2(R4) ;SELECT THE DRIVE
7742 041700 004037 043562     JSR      R0,RD.RM   ;TRANSFER ERROR,TR=1

```



```

7743 041704 000000 RMCS1
7744 041706 041054 CI7
7745 041710 006126 ROL (SP)+
7746 041712 100417 BMI 3$ ;BR IF YES
7747 041714 005737 036676 TST SAVEFG ;SAVE THE RH70/RM03 REGISTERS?
7748 041720 100002 BPL 1$ ;BRANCH IF NO
7749 041722 004737 044134 JSR PC,SVRH70 ;YES--SAVE THE REGISTERS
7750 041726
7751 041726 004737 044770 1$: JSR PC,GETREG ;GET DPB POINTER
7752 041732 005702 TST R2 ;ENTRY FOR DRIVE ?
7753 041734 001403 BEQ 2$ ;BR IF NOT
7754 041736 004737 037774 JSR PC,OPT ;CALL OPTIMIZER
7755 041742 000417 BR SC ;CHECK OTHER DRIVES
7756 ;THE RELEASE DRIVE COMMAND IS FORCED TO ENTER FOR DUAL PORT OPERATION
7757 041744 012714 000113 2$: MOV #113,(R4) ;RELEASE THE DRIVE
7758 041750 000414 BR SC ;CHECK FOR OTHER DRIVES
7759 041752 052762 100100 000016 3$: BIS #BIT15:BIT06,16(R2) ;SET DATA ERROR FLAG
7760 041760 004737 044674 JSR PC,EMPTYQ ;EMPTY THE "DRIVE'S WAIT" QUEUE
7761 041764 004737 044134 JSR PC,SVRH70 ;SAVE THE RH70/RM03 REGISTERS
7762 041770 012714 040111 MOV #40111,(R4) ;ISSUE A "DRIVE CLEAR"
7763 041774 012714 000113 MOV #113,(R4) ;ISSUE A RELEASE TO THE DRIVE
7764 042000 000400 BR SC ;CHECK FOR OTHER DRIVES
7765
7766
7767
7768 ;SPECIAL CONDITION ROUTINE
7769
7770 042002 116403 000016 SC- MOVB RMAS(R4),R3 ;READ "RMAS"
7771 042006 001014 BNE 2$ ;BRANCH IF ANY 'ATA' BITS SET
7772 042010 004037 043562 JSR R0,RD.RM ;READ CONTROL AND STATUS REGISTER
7773 042014 000000 RMCS1
7774 ;
7775 042016 042036 ;EXIT IF FAIL TO READ
7776 042020 106126 ROLB (SP)+ ;IS "IE"=1?
7777 042022 100405 BMI 1$ ;YES, NO DRIVES TO CHECK
7778 042024 004037 045060 JSR R0,ES.SAV ;SAVE THE ADDRESS IN 'SESCAPE'
7779 042030 104001 ERROR 1 ;REPORT AN ILLEGAL INTERRUPT
7780 042032 004737 044252 JSR PC,SET.IE ;SET INTERRUPT ENABLE
7781 042036 000207 1$: RTS PC ;RETURN
7782 042040 005046 2$: CLR -(SP) ;PROCESS ALL DRIVES THAT HAVE
7783 042042 110316 MOVB R3,(SP) ;AN "ATA"=1
7784 042044 012703 000001 MOV #1,R3
7785 042050 005001 CLR R1
7786 042052 030316 SC3: BIT R3,(SP) ;ATA=1?
7787 042054 001005 BNE SC5 ;YES--BRANCH
7788 042056 005201 SC4: INC R1 ;MOVE TO THE NEXT DRIVE
7789 042060 106303 ASLB R3
7790 042062 001373 BNE SC3 ;BRANCH IF MORE TO CHECK?
7791 042064 005726 TST (SP)+ ;CLEAN OFF THE STACK
7792 042066 000207 RTS PC ;RETURN TO USER
7793 042070 105761 036630 SC5: TSTB DPINT(R1) ;INITIALIZING THE DRIVE ?
7794 042074 001402 BEQ 1$ ;BR IF NOT
7795 042076 000137 043012 JMP SC13 ;PROCESS THE DRIVE
7796 042102 105761 036640 1$: TSTB DPRQS(R1) ;PORT REQUEST OUTSTANDING ?
7797 042106 001402 BEQ 2$ ;BR IF NOT
7798 042110 000137 043012 JMP SC13 ;START THE OUTSTANDING COMMAND

```

H14

MD-11-DZRMF-B RM03 RM02 EXTENDED DRIVE TEST
CZRMFB.P11 21-NOV-77 14:10

MACY11 30(1046) 22-NOV-77 08:04 PAGE 146
SINGLE DUAL PORT RH70/RM03 DRIVER (REV 5.1)-24-AUG-77

SEQ 0176

7799	042114	105761	036610	2\$:	TSTB	DRVSTA(R1)	;CHECK THE DRIVE STATUS
7800	042120	003025			BGT	5\$;BRANCH IF ONLINE
7801	042122	105761	036656		TSTB	ULDFLG(R1)	;UNLOAD IN PROGRESS?
7802	042126	003422			BLE	5\$;BRANCH IF NOT
7803	042130	004737	044770		JSR	PC,GETREQ	;GET DPB POINTER
7804	042134	004737	044134		JSR	PC,SVRH70	;SAVE THE RH70/RM03 REGISTERS
7805	042140	004737	042750		JSR	PC,SC12	;SAVE RMD5, RMER1, RMER2, AND RMMR2
7806							;ALSO DO A DRIVE INIT (DRVINT)
7807	042144	105761	036610		TSTB	DRVSTA(R1)	;DID DRIVE COME ONLINE?
7808	042150	003416			BLE	6\$;NO---BRANCH
7809	042152	032737	040000	036570	BIT	#BIT14,RMERRS	;WAS THERE AN ERROR?
7810	042160	001002			BNE	3\$;BR IF ERROR
7811	042162	000137	042640		JMP	SC11	;NO ERROR
7812	042166	013705	036572	3\$:	MOV	RMERRS+2.R5	;YES -- PICKUP RMER1 AND
7813	042172	000504			BR	SC6A	;GO PROCESS THE ERROR
7814	042174	105761	036600	5\$:	TSTB	DRVACT(R1)	;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY
7815	042200	001033			BNE	SC6	;BR IF EITHER
7816	042202	004737	042750		JSR	PC,SC12	;SAVE RMD5, RMER1, RMER2, AND RMMR2
7817							;ALSO DO A DRVINT
7818	042206	105761	036630	6\$:	TSTB	DPINT(R1)	;TRYING TO INIT THE DRIVE ?
7819	042212	001321			BNE	SC4	;BR IF YES CHECK ON MORE DRIVES
7820	042214	105761	036610		TSTB	DRVSTA(R1)	;CHECK ON DRIVE'S STATUS
7821	042220	100412			BMI	7\$;BR IF UNSAFE
7822	042222	032737	020000	036574	BIT	#BIT13,RMERRS+4	;ADDRESS PLUG CHANGED ?
7823	042230	001013			BNE	8\$;BR IF YES
7824					MOV	#113,-(SP)	;RELEASE COMMAND
7825	042232	012746	000111		MOV	#111,-(SP)	;DRIVE CLEAR
7826	042236	004037	043742		JSR	RD,WRT.RM	;WRITE THE COMMAND INTO RMCS1
7827	042242	000000			RMCS1		;REGISTER INDEX
7828	042244	042610			SCB		;PARITY EXIT ADDRESS
7829	042246	011605		7\$:	MOV	(SP),R5	;PICKUP (RMAS) BEFORE THE ERROR CALL
7830	042250	004037	045060		JSR	RD,ES.SAV	;SAVE THE ADDRESS IN 'SESCAPE'
7831	042254	104002			ERROR	2	;REPORT THE UNEXPECTED ATTENTION
7832	042256	000677			BR	SC4	;GO CHECK FOR MORE ATA'S
7833	042260			8\$:			
7834	042260	004037	045060		JSR	RD,ES.SAV	;SAVE THE ADDRESS IN 'SESCAPE'
7835	042264	104005			ERROR	5	;REPORT THE ADDRESS PLUG CHANGE
7836	042266	000673			BR	SC4	;CHECK FOR MORE DRIVES
7837	042270	006301		SC6:	ASL	R1	;SETUP TO ADDRESS WORDS
7838	042272	012761	177777	036702	MOV	#-1,TIMER R1)	;STOP THE TIMER
7839	042300	006201			ASR	R1	;RESTORE THE DRIVE ADDRESS
7840	042302	004737	044770		JSR	PC,GETREQ	;GET THE DPB POINTER FROM THE QUEUE
7841	042306	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
7842	042312	000137	042640		JMP	SC11	;PROCESS THE SEARCH
7843	042316	004037	043562		JSR	RD,RD.RM	;READ THE RM03'S STATUS REG.
7844	042322	000012			RMD5		
7845	042324	042610			SCB		
7846	042326	011605			MOV	(SP),R5	;AND PUT IT IN R5
7847	042330	006126			ROL	(SP)+	;WAS THERE AN ERROR?
7848	042332	100407			BMI	1\$;BR IF ERROR
7849	042334	105761	036600		TSTB	DRVACT(R1)	;CHECK DRIVE'S STATE
7850	042340	003137			BGT	SC11	;BR IF DRIVE ACTIVE WITH ORDER
7851	042342	052762	100210	000C1E	BIS	#BIT15!BIT07!BIT03,16(R2)	;INFORM USER OF ERROR RECOVER COMPLETION
7852	042350	000470			BR	SC7	
7853	042352	004037	043562	1\$:	JSR	RD,RD.RM	;READ ERROR REGISTER #1
7854	042356	000C14			RMER1		

```

7855 042360 042610 SCB
7856 042362 012605 MOV (SP)+,R5 ;AND SAVE IT IN R5
7857 042364 004737 044134 JSR PC,SVRH70 ;SAVE RH70/RMO3 REGISTERS
7858 042370 012746 000111 MOV #111,-(SP) ;ISSUE A DRIVE CLEAR
7859 042374 004037 043742 JSR RO,WRT.RM
7860 042400 000000 RMCS1
7861 042402 042610 SCB
7862 042404 006105 SC6A: R5 ;WAS "UNSAFE" CONDITION =1?
7863 042406 100406 BMI 1$ ;BRANCH IF YES
7864 042410 005702 TST R2 ;ANYTHING IN QUEUE ?
7865 042412 001447 BEQ SC7 ;BR IF NOT
7866 042414 052762 100240 000016 BIS #BIT15:BIT07:BIT05,16(R2) ;INFORM USER OF ERROR
7867 042422 000443 BR SC7
7868 042424 004037 043562 1$: JSR RO,RO.RM ;READ DRIVE STATUS REG. #1
7869 042430 000012 RMDS
7870 042432 042610 SCB
7871 042434 011605 MOV (SP),R5 ;SAVE RMD5 IN R5
7872 042436 006126 ROL (SP)+ ;"ERR"=1?
7873 042440 100011 BPL 2$ ;BR IF NO--UNSAFE CLEARED
7874 042442 112761 177777 036610 MOVB #-1,DRVSTA(R1) ;DRIVE IS UNSAFE
7875 042450 004737 044134 JSR PC,SVRH70 ;SAVE RH70/RMO3 REGISTERS
7876 042454 052762 110000 000016 BIS #BIT15:BIT12,16(R2) ;INFORM USER OF UNSAFE ERROR
7877 042462 000423 BR SC7
7878 042464 032705 010000 2$: BIT #BIT12,R5 ;"MOL" = 1 ?
7879 042470 001015 BNE 3$ ;BR IF YES
7880 042472 112761 177777 036600 MOVB #-1,DRVACT(R1) ;ACTIVE ERROR RECOVER
7881 042500 112761 000001 036610 MOVB #1,DRVSTA(R1) ;ONLINE
7882 042506 006301 ASL R1
7883 042510 012761 072460 036702 MOV #30000.,TIMER(R1) ;START 30 SECOND TIMER
7884 042516 006201 R1
7885 042520 000137 042056 JMP SC4
7886 042524 052762 100220 000016 3$: BIS #BIT15:BIT07:BIT04,16(R2) ;INFORM USER OF ERROR
7887 042532 105061 036600 SC7: CLRB DRVACT(R1) ;DRIVE IS IDLE
7888 : JSR PC,EMPTYQ ;DUMP THE QUEUE
7889 042536 004737 045012 JSR PC,POPQUE ;REMOVE THE QUEUE
7890 042542 105761 036656 TSTB ULDFLG(R1) ;UNLOAD IN PROGRESS OR QUEUE?
7891 042546 003002 BGT 1$ ;BR IF NOT
7892 042550 105061 036656 CLRB ULDFLG(R1) ;CLEAR UNLOAD FLAG
7893 042554 116164 036724 000016 1$: MOVB ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
7894 042562 105761 036610 TSTB DRVSTA(R1) ;IS THE DRIVE UNSAFE ?
7895 042566 100406 BMI 2$ ;BR IF IT IS
7896 : MOV #113,-(SP) ;RELEASE COMMAND
7897 042570 012746 000111 MOV #111,-(SP) ;DRIVE CLEAR COMMAND
7898 042574 004037 043742 JSR RO,WRT.RM ;WRITE THE COMMAND INTO RPCS1
7899 042600 000000 RMCS1 ;REGISTER INDEX
7900 042602 042610 SCB ;PARITY EXIT ADDRESS
7901 042604 000137 042056 2$: JMP SC4 ;CHECK FOR MORE DRIVES
7902 042610 105761 036600 SCB: TSTB DRVACT(R1) ;IS DRIVE IDLE?
7903 042614 001405 BEQ 1$ ;YES--BRANCH
7904 042616 004737 044770 JSR PC,GETREG ;GET DPB POINTER
7905 042622 004737 041054 JSR PC,CI7 ;PROCESS THE PARITY ERROR
7906 042626 000402 BR 2$ ;CONTINUE
7907 042630 1$:
7908 : JSR PC,CI7 ;PROCESS THE PARITY ERROR
7909 042630 004737 041076 JSR PC,CI7B ;PROCESS THE UNCORRECTABLE PARITY ERROR
7910 042634 000137 042056 2$: JMP SC4 ;CHECK MORE DRIVES

```

J14

MD-11-DZRMF-B RMO3.RMO2 EXTENDED DRIVE TEST MACY11 30(1046) 22-NOV-77 08:04 PAGE 148
 DZRMFB.P11 21-NOV-77 14:10 SINGLE/DUAL PORT RH70/RMO3 DRIVER (REV 5.1)-24-AUG-77

SEQ 0178

7911	042640	105761	036656		SC11:	TSTB	ULDFLG(R1)	:"UNLOAD IN PROGRESS"?
7912	042644	003402				BLE	1\$:BRANCH IF NO
7913	042646	105061	036656			CLRB	ULDFLG(R1)	:CLEAR UNLOAD FLAG
7914	042652	105061	036600		1\$:	CLRB	DRVACT(R1)	:SET DRIVE IDLE
7915	042656	136137	036724	036652		BITB	ATABIT(R1),SRCHWT	:DOING A SEARCH OPERATION FOR
7916								:AN I/O COMMAND?
7917	042664	001012				BNE	2\$:BRANCH IF YES
7918	042666	004737	045012			JSR	PC,POPQUE	:REMOVE REQUEST FROM QUEUE
7919	042672	052762	000200	000016		BIS	#BIT07,16(R2)	:SET "DONE" BIT
7920	042700	005737	036676			TST	SAVEFG	:SAVE THE REGISTERS?
7921	042704	100002				BPL	2\$:BRANCH IF NO
7922	042706	004737	044134			JSR	PC,SVRH70	:YES--SAVE ALL OF THE RH70/RMO3 REG'S
7923	042712	116164	036724	000016	2\$:	MOVW	ATABIT(R1),RMAS(R4)	:CLEAR ATTENTION BIT
7924	042720	146137	036724	036652		BICB	ATABIT(R1),SRCHWT	:CLEAR IMPLIED SEEK SET
7925	042726	006301				ASL	R1	:WORD INDEX
7926	042730	012761	177777	036702		MOV	#-1,TIMER(R1)	:STOP CLOCK
7927	042736	006201				ASR	R1	:RESTORE R1
7928	042740	004737	037774			JSR	PC,OPT	:START A REQUEST
7929	042744	000137	042056			JMP	SC4	:CHECK FOR MORE DRIVES
7930	042750	010164	000010		SC12:	MOV	R1,RMCS2(R4)	:SELECT DRIVE
7931	042754	016437	000012	036570		MOV	RMDS(R4),RMERRS	:SAVE THE FOUR REGISTERS THAT
7932	042762	016437	000014	036572		MOV	RMER1(R4),RMERRS+2	:WILL TELL US SOMETHING
7933	042770	016437	000042	036574		MOV	RMER2(R4),RMERRS+4	
7934	042776	016437	000040	036576		MOV	RMMR2(R4),RMERRS+6	
7935						JSR	RO,DRVINT	:INIT. THE STATE OF THE DRIVE
7936						BR	1\$:TAKE ERROR EXIT
7937	043004	000207				RTS	PC	:RETURN
7938	043006	005726			1\$:	TST	(SP)+	:POP PC OFF OF THE STACK
7939	043010	000677				BR	SC8	:PROCESS THE PARITY ERROR
7940	043012	006301			SC13:	ASL	R1	:SETUP TO ADDRESS WORDS
7941	043014	012761	177777	036702		MOV	#-1,TIMER(R1)	:STOP THE TIMER
7942	043022	006201				ASR	R1	
7943	043024	010164	000010			MOV	R1,RMCS2(R4)	:SELECT THE DRIVE
7944	043030	116164	036724	000016		MOVW	ATABIT(R1),RMAS(R4)	:CLEAR THE ATTENTION BIT
7945	043036	105761	036630		1\$:	TSTB	DPINT(R1)	:INITIALIZING THE DRIVE ?
7946	043042	001424				BEQ	2\$:BR IF NOT
7947	043044	105061	036630			CLRB	DPINT(R1)	:CLEAR THE INIT INDICATOR
7948	043050	004037	037166			JSR	RO,DRVINT	:GO INIT THE DRIVE
7949	043054	000240				NOP		:DUMMY PARITY ERROR RETURN
7950	043056	105761	036610			TSTB	DRVSTA(R1)	:DRIVE ONLINE ?
7951	043062	003014				BGT	2\$:BR IF YES -- START ORDER
7952	043064	005702				TST	R2	:QUEUE ENTRY FOR THE DRIVE
7953	043066	001426				BEQ	3\$:BR IF NOT
7954	043070	004737	044770			JSR	PC,GETREQ	:GET DPB ADDRESS
7955	043074	052762	140000	000016		BIS	#BIT15:BIT14,16(R2)	:INFORM USER THAT DRIVE OFFLINE
7956	043102	004737	044134			JSR	PC,SVRH70	:SAVE THE REGISTERS
7957						JSR	PC,EMPTYQ	:EMPTY THE REQUEST QUEUE
7958	043106	004737	045012			JSR	PC,POPQUE	:REMOVE THE QUEUE
7959	043112	000414				BR	3\$	
7960	043114	032764	004000	000000	2\$:	BIT	#BIT11,RMCS1(R4)	:DVA SET ?
7961	043122	001006				BNE	4\$:SET THEN CALL OPT
7962	043124	006301				ASL	R1	
7963	043126	012761	060000	036702		MOV	#60000,TIMER(R1)	
7964	043134	006201				ASR	R1	
7965	043136	000402				BR	3\$	
7966	043140	004737	037774		4\$:	JSR	PC,OPT	:START THE PENDING REQUEST

```

7967 043144 000137 042056 3$: JMP SC4 ;PROCESS OTHER DRIVES
7968
7969 ;/RMO3 TIMER ROUTINE
7970 ;CALL
7971 ; MOV #TIME, -(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
7972 ; JSR PC, RPTMR ;CALL RMO3 TIME ROUTINE
7973
7974 043150 005737 036654 RPTMR: TST ACTDRV ;CHECK "ACTDRV & ACTSTR"
7975 043154 001027 4$ BNE ;IF NON ZERO EXIT
7976 043156 112737 000001 036655 MOVB #1, ACTSTR ;SET "ACTSTR"
7977 043164 104412 SAVREG ;SAVE R0 - R5
7978 043166 005001 CLR R1 ;START WITH DRIVE 0
7979 043170 005003 CLR R3
7980 043172 005763 036702 1$: TST TIMER(R3) ;IS THE TIMER RUNNING?
7981 043176 002406 2$ BLT ;BRANCH IF NO
7982 043200 166663 000002 036702 SUB 2(SP), TIMER(R3) ;COUNT THE INTERVAL
7983 043206 003002 BGT 2$ ;BR IF NO SOFTWARE TIMEOUT
7984 043210 004737 043240 JSR PC, STO ;CALL SOFTWARE TIMEOUT ROUTINE
7985 043214 005201 2$: INC R1 ;MOVE TO NEXT DRIVE
7986 043216 005723 TST (R3)+
7987 043220 022701 000010 CMP #8, R1 ;OUT OF DRIVES?
7988 043224 003362 BGT 1$ ;BRANCH IF NO
7989 043226 104413 3$: RESREG ;RESTORE R0 - R5
7990 043230 105037 036655 CLRB ACTSTR ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
7991 043234 012616 4$: MOV (SP)+, (SP) ;ADJUST THE STACK
7992 043236 000207 RTS PC ;RETURN
7993
7994 ;SOFTWARE TIMEOUT ROUTINE
7995
7996 ;NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
7997 ; OR GREATER
7998
7999 ;CALL:
8000 ; STO #DRVNUM, R1 ;DRIVE NUMBER
8001 ; JSR PC, STO ;CALL
8002 ; RETURN
8003
8004 043240 010146 STO: MOV R1, -(SP) ;SAVE R1
8005 043242 010246 MOV R2, -(SP) ;SAVE R2
8006 043244 010346 MOV R3, -(SP) ;SAVE R3
8007 043246 010446 MOV R4, -(SP) ;SAVE R4
8008 043250 013704 036736 MOV RADDR, R4 ;GET ADDRESS OF "RMCS1"
8009 043254 010164 000010 MOV R1, RMCS2(R4) ;SELECT THE DRIVE
8010 043260 004037 043562 JSR R0, RD RM ;READ "DRIVE STATUS REG"
8011 043264 000012 RMDS
8012 ; STOS
8013 ; STOS
8014 043266 043550 ;
8015 043270 105726 ;
8016 043272 100436 ;
8017 043274 105761 036630 ST01: TSTB (SP)+ ;IS "DRY"=1?
8018 043300 001033 BMI ST02 ;BR IF YES
8019 043302 105761 036640 TSTB DPINT(R1) ;TRYING TO INTIALIZE THE DRIVE ?
8020 043310 013702 036650 BNE ST02 ;BR IF YES
8021 043314 020137 036722 TSTB DPRQS(R1) ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8022 043320 001404 BNE ST02 ;BR IF YES
; MOV TRNSWT, R2 ;PICKUP TRANSFER WAIT QUEUE
; CMP R1, DTUW ;TRANSFER UNDERWAY ON THIS DRIVE?
; BEQ 1$ ;BRANCH IF YES
    
```

```

8023 043322 000137 043550      JMP      ST09      ; IF NOT DON'T BOTHER DRIVES
8024 043326 004737 044770      JSR      PC,GETREQ ; GET DPB ADDRESS
8025 043332 052762 101000 000016 1$:  BIS      #BIT15!BIT09,16(R2) ; SET THE ERROR FLAGS
8026 043340 004737 044134      JSR      PC,SVRH70 ; SAVE RH70/RM03 REGISTERS
8027      :      MOV      #BIT05,RMCS2(R4) ; "INIT" THE MASS BUS
8028 043344 105061 036600      CLR      DRVACT(R1) ; DRIVE IS IDLE
8029 043350 105061 036656      CLR      ULDFLG(R1) ; CLEAR THE UNLOAD FLAG
8030 043354 005037 036650      CLR      TRNSWT      ; CLEAR DPB ADDRESS
8031 043360 012737 177777 036722  MOV      #-1,DTUW      ; CLEAR THE TRANSFER DRIVE #
8032 043366 000470      BR       ST09      ; DON'T BOTHER OTHER DRIVES
8033 043370 116405 000016  ST02:  MOV      RMAS(R4),R5      ; READ ATTENTION REG
8034 043374 136105 036724      BIT      ATABIT(R1),R5 ; IS ATTENTION FOR THIS DRIVE UP ?
8035 043400 001007      BNE      ST03      ; YES--BRANCH
8036 043402 105761 036630      TST      DPINT(R1)      ; TRYING TO INITIALIZE THE DRIVE ?
8037 043406 001021      BNE      ST06      ; BR IF YES - DRIVE NOT ONLINE
8038 043410 105761 036640      TST      DPRQS(R1)      ; OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8039 043414 001035      BNE      ST07      ; BR IF YES - NO RESPONSE TO REQUEST
8040 043416 000454      BR       ST09      ; OTHER WISE EXIT
8041 043420 105761 036630  ST03:  TST      DPINT(R1)      ; INITIALIZING THE DRIVE ?
8042 043424 001003      BNE      1$      ; BR IF INIT PENDING
8043 043426 105761 036640      TST      DPRQS(R1)      ; PORT REQUEST PENDING ?
8044 043432 001446      BEQ      ST09      ; BR IF NOT
8045 043434 012763 177777 036702 1$:  MOV      #-1,TIMER(R3) ; STOP THE TIMER
8046 043442 000442      BR       ST09      ; EXIT
8047 043444 004737 041154  ST05:  JSR      PC,CIB      ; GO HANDLE THE PARITY ERROR
8048 043450 000437      BR       ST09
8049 043452 105061 036630  ST06:  CLR      DPINT(R1)      ; CLEAR THE INITIALIZE INDICATOR
8050 043456 105061 036610      CLR      DRVSTA(R1)      ; SET UNIT OFFLINE
8051 043462 012763 177777 036702  MOV      #-1,TIMER(R3) ; STOP THE TIMER
8052 043470 004737 044770      JSR      PC,GETREQ      ; GET THE DPB ADDRESS
8053 043474 005702      TST      R2      ; REQUEST IN QUEUE ?
8054 043476 001424      BEQ      ST09      ; BR IF NOT
8055 043500 052762 140000 000016  BIS      #BIT15!BIT14,16(R2) ; INFORM THE USER DRIVE NOT AVAILABLE
8056 043506 000414      BR       ST08
8057 043510 012763 177777 036702  ST07:  MOV      #-1,TIMER(R3) ; STOP THE TIMER
8058 043516 105061 036640      CLR      DPRQS(R1)      ; CLEAR PORT REQUEST INDICATOR
8059 043522 004737 044770      JSR      PC,GETREQ      ; GET DPB ADDRESS
8060 043526 005702      TST      R2      ; QUEUE ENTRY FOR DRIVE ?
8061 043530 001407      BEQ      ST09      ; BR IF NONE
8062 043532 012762 100004 000016  MOV      #BIT15!BIT2,16(R2) ; INFORM USER OF PORT REQUEST ERRGR
8063 043540 004737 044674  ST08:  JSR      PC,EMPTYQ      ; CLEAR THE QUEUE FOR THE DRIVE
8064 043544 004737 044134      JSR      PC,SVRH70      ; SAVE THE REGISTERS
8065 043550 012604  ST09:  MOV      (SP)+,R4      ; RESTORE R4
8066 043552 012603      MOV      (SP)+,R3      ; RESTORE R3
8067 043554 012602      MOV      (SP)+,R2      ; RESTORE R2
8068 043556 012601      MOV      (SP)+,R1      ; RESTORE R1
8069 043560 000207      RTS      PC      ; RETURN
8070
8071      ; ROUTINE TO READ A RH70/RM03 REGISTER
8072
8073      ; CALL
8074      JSR      RO,RD,RM      ; GO READ A REGISTER
8075      INDEX      ; REG. INDEX FROM BASE
8076      ERRADR      ; ERROR ADDRESS--PROCESS ERROR STARTING
8077      ; AT THIS ADDRESS
8078      ; CONTENTS OF REG. IS ON THE STACK
      RETURN
    
```

M14

8079											
8080	043562	013737	036734	043730	RD.RM:	MOV	MCPEMX, RD.RM2				: MAX. RETRYS ALLOWED
8081	043570	011646				MOV	(SP) -(SP)				: SAVE RD FOR RETURN
8082	043572	013737	036736	043606		MOV	RMADR, RD.ADR				: FORM THE DESIRED ADDRESS
8083	043600	062037	043606			ADD	(RD)+, RD.ADR				: USING THE BASE AND THE INDEX
8084	043604	013727			RD.RM1:	MOV	2(PC)+, (PC)+				: READ THE DESIRED REGISTER OF THE RM03
8085	043606	000000			RD.ADR:	.WORD	0				: ADDRESS IS FORMED HERE
8086	043610	000000			RD.WRD:	.WORD	0				: REG. CONTENTS PUT HERE
8087	043612	013766	043610	000002		MOV	RD.WRD, 2(SP)				: RETURN IT TO THE USER
8088	043620	013746	036736			MOV	RMADR, -(SP)				: PUT THE ADDRESS ON THE STACK
8089	043624	062716	000010			ADD	RMCS2, (SP)				: FORM THE ADDRESS OF RMCS2
8090	043630	032736	010000			BIT	#BIT12, 2(SP)+				: CHECK THE 'NED' BIT
8091	043634	001037				BNE	RD.RM3				: BR IF DRIVE NON-EXISTENT
8092	043636	017746	:73074			MOV	RMADR, -(SP)				: READ RMCS1
8093	043642	032716	020000			BIT	#BIT13, (SP)				: DID MCPE SET?
8094	043646	001002				BNE	1\$: BRANCH IF YES
8095	043650	022620				CMP	(SP)+, (RD)+				: ADJUST FOR RETURN
8096	043652	000432				BR	RD.RM4				: EXIT
8097	043654				1\$:						
8098	043654	004037	045060			JSR	RD, ES.SAV				: SAVE THE ADDRESS IN '\$ESCAPE'
8099	043660	104003				ERROR	3				: REPORT "MCPE" ERROR
8100	043662	005737	036722			TST	DTUW				: DATA TRANSFER UNDERWAY?
8101	043666	100405				BMI	2\$: NO--BRANCH
8102	043670	032716	040000			BIT	#BIT14, (SP)				: NO--"TRE"=1?
8103	043674	001402				BEQ	2\$: NO--BRANCH
8104	043676	005726				TST	(SP)+				: YES--CLEAN OFF THE STACK AND
8105	043700	000415				BR	RD.RM3				: TAKE THE FATAL ERROR EXIT
8106	043702	052716	040000		2\$:	BIS	#BIT14, (SP)				: CLEAR "MCPE" BY SENDING A "1" TO "TRE"
8107	043706	000316				SWAB	(SP)				: POSITION BEFORE WRITING
8108	043710	017737	036736	043724		MOV	RMADR, 3\$: FORM ADDRESS OF HIGH BYTE
8109	043716	005237	043724			INC	3\$				
8110	043722	112637				MOVW	(SP)+, 2(PC)+				: WRITE THE HIGH BYTE OF RMCS1
8111	043724	000000			3\$:	.WORD	0				: ADDRESS STORAGE
8112	043726	005327				DEC	(PC)+				: EXCEEDED MAX. RETRYS
8113	043730	000003			RD.RM2:	.WORD	3				
8114	043732	002324				BGE	RD.RM1				: BRANCH IF NO
8115	043734	011000			RD.RM3:	MOV	(RD), RD				: FATAL ERROR EXIT
8116	043736	012616				MOV	(SP)+, (SP)				
8117	043740	000200			RD.RM4:	RTS	RD				
8118											
8119											
8120											
8121											
8122											
8123											
8124											
8125											
8126											
8127											
8128	043742	013737	036734	044120	WRT.RM:	MOV	MCPEMX, WRT.R2				: MAX RETRYS ALLOWED
8129	043750	016637	000002	044030		MOV	2(SP), WRT.WD				: SAVE THE WORD TO WRITE
8130	043756	012616				MOV	(SP)+, (SP)				: ADJUST THE STACK
8131	043760	012037	044032			MOV	(RD)+, WRT.AD				: GET INDEX OF REGISTER TO BE WRITTEN
8132	043764	001015				BNE	1\$: BRANCH IF NOT RMCS1
8133	043766	122737	000150	044030		CMPB	#150, WRT.WD				: IS THE COMMAND FOR DATA TRANSFERS?
8134	043774	002411				BLT	1\$: YES--DON'T GET THE OLD A16 & A17, & PSEL

: ROUTINE TO WRITE A REGISTER

```

: CALL
:     MOV     DATA -(SP)
:     JSR     RD, WRT.RM
:     INDEX
:     ERRADR
:     RETURN
  
```

```

8135 043776 004037 043562 JSR RO,RO.RM ;NO---COMBINE A16&A17, & PSEL WITH
8136 044002 000000 RMCS1 ;THE COMMAND BEFORE SENDING IT TO
8137 044004 044124 WRT.R3 ;THE RH70/RM03
8138 044006 000316 SWAB (SP)
8139 044010 042716 177770 BIC #1C7,(SP)
8140 044014 112637 044031 MOVB (SP)+,WRT.WD+1
8141 044020 063737 036736 044032 1$: ADD RMADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.
8142 044026 012737 WRT.R1: MOV (PC)+,@(PC)+ ;LOAD THE DESIRED REG.
8143 044030 000000 WRT.WD: .WORD 0 ;WORD TO WRITE GOES HERE
8144 044032 000000 WRT.AD: .WORD 0 ;ADDRESS IS FORMED HERE
8145 044034 013746 036736 MOV RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
8146 044040 062716 000010 ADD #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
8147 044044 032736 010000 BIT #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
8148 044050 001025 BNE WRT.R3 ;BR IF DRIVE NON-EXISTENT
8149 044052 004037 043562 JSR RO,RO.RM ;CHECK FOR PARITY ERROR ON WRITE
8150 044056 000014 RMER1
8151 044060 044124 WRT.R3
8152 044062 032726 000010 BIT #BIT03,(SP)+
8153 044066 001420 BEQ WRT.R4 ;BRANCH IF "PAR=0"
8154 044070 016037 177776 044102 MOV -2(RO),1$ ;PICKUP THE INDEX
8155 044076 004037 043562 JSR RO,RO.RM ;READ THE REG.
8156 044102 000000 1$: .WORD 0 ;REG. INDEX
8157 044104 044124 WRT.R3 ;RETURN TO THIS ADDRESS ON ERROR
8158 044106 004037 045060 JSR RO,ES.SAV ;SAVE THE ADDRESS IN 'SESCAPE'
8159 044112 104004 ERROR 4 ;REPORT THE PARITY ON WRITE ERROR
8160 044114 005726 TST (SP)+ ;CLEAR OFF THE STACK
8161 044116 005327 DEC (PC)+ ;DECREMENT THE ERROR COUNT
8162 044120 000003 WRT.R2: .WORD 3 ;RETRY COUNTER
8163 044122 002341 BGE WRT.R1 ;TRY AGAIN IF NOT FINISHED
8164 044124 011000 WRT.R3: MOV (RO),RO ;TAKE THE "PARITY ON WRITE" ERROR EXIT
8165 044126 000401 BR WRT.R5 ;EXIT
8166 044130 005720 WRT.R4: TST (RO)+ ;ADJUST FOR ERROR FREE EXIT
8167 044132 000200 WRT.R5: RTS RO
8168
8169 ;ROUTINE TO SAVE THE RH70/RP04/5/RM03 REGISTERS AS PER DPB+14
8170
8171 ;CALL
8172 ;
8173 ; MOV #DPBNUM,R2 ;DPB POINTER TO R2
8174 ; JSR PC,SVRH70 ;SAVE THE DRIVES REG'S
8175 044134 104412 SVRH70: SAVREG ;SAVE RO - R5
8176 044136 005702 TST R2 ;QUEUE ENTRY FOR THE DRIVE ?
8177 044140 001442 BEQ 6$ ;BR IF NONE
8178 044142 013704 036736 MOV RMADR,R4
8179 044146 111264 000010 MOVB (R2),RMCS2(R4) ;SELECT DRIVE
8180 044152 016203 000014 MOV 14(R2),R3 ;GET THE ERROR TABLE POINTER
8181 044156 001433 BEQ 6$ ;EXIT IF NO ADDRESS
8182 044160 005037 044214 CLR 3$ ;COUNTER & POINTER
8183 044164 023727 044214 000022 1$: CMP 3$,#RMOB ;REACHED THE BUFFER REGISTER
8184 044172 001006 BNE 2$ ;BR IF NOT
8185 044174 032764 000200 000010 BIT #BIT07,RMCS2(R4) ;'OR' SET ?
8186 044202 001002 BNE 2$ ;BR IF SET
8187 044204 005023 CLR (R3)+ ;STORE RMOB AS ZEROES
8188 044206 000405 BR 4$ ;CONTINUE
8189 044210 004037 043562 2$: JSR RO,RO.RM ;READ THE SELECTED REGISTER
8190 044214 000000 3$: .WORD 0 ;REGISTER INDEX
    
```


B15

```

00191 044216 044212          SS          : ERROR RETURN ADDRESS
00192 044220 012623          MOV          SP, (R3) * : STORE THE REGISTER CONTENTS
00193 044220 023727 044214 000046 4S: CMP          3S, #RMEC2 : REACHED THE END ?
00194 044220 001406          BEQ          6S          : BR IF YES
00195 044230 062737 000002 044214 ADD          #2, 3S      : INCREMENT THE REGISTER INDEX
00196 044230 000751          BR          1S          : CONTINUE READING THE REGISTERS
00197 044240 004737 041054          JSR          PC, C17    : PROCESS THE UNCORRECTABLE PARITY ERROR
00198 044240 104413 6S: RESREG          : RESTORE R0 - R5
00199 044250 000207          RTS          PC        : RETURN

: ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
: CALL
: MOV          #DRVNUM, R1 : DRIVE NUMBER TO R1
: JSR          PC, SET.IE : SET "IE"
: RETURN

SET.IE: MOV          R4, -(SP) : SAVE R4
: MOV          RMADR, R4 : PICKUP ADDRESS OF RMCS1
: MOV          R1, RMCS2(R4) : SELECT DRIVE
: MOV          (R4), -(SP) : -10 RMCS1
: BIS          #BIT14, (SP) : SET THE "TRE" BIT OF THE WORD READ
: SWAB        (SP) : ADJUST FOR DATO
: MOVB        #BIT06, (R4) : SET "IE"
: BIT         #BIT12, RMCS2(R4) : IS "NEC"=1?
: BNE         1S          : YES--CLEAR "TRE"
: TST        (SP)+ : CLEAN OFF THE STACK
: BR          2S
1S: MOVB        (SP)+, 1(R4) : CLEAR "TRE"
2S: MOVB        (SP)+, R4 : RESTORE R4
: RTS          PC        : RETURN TO CALLER

: QUEUE COUNT
QCNT: .BYTE 0 : DRIVE 0
: .BYTE 0 : DRIVE 1
: .BYTE 0 : DRIVE 2
: .BYTE 0 : DRIVE 3
: .BYTE 0 : DRIVE 4
: .BYTE 0 : DRIVE 5
: .BYTE 0 : DRIVE 6
: .BYTE 0 : DRIVE 7

: QUEUE INPUT POINTERS
QINPT: .WORD QDRV0 : DRIVE 0
: .WORD QDRV1 : DRIVE 1
: .WORD QDRV2 : DRIVE 2
: .WORD QDRV3 : DRIVE 3
: .WORD QDRV4 : DRIVE 4
: .WORD QDRV5 : DRIVE 5
: .WORD QDRV6 : DRIVE 6
: .WORD QDRV7 : DRIVE 7

: QUEUE OUTPUT POINTERS
QOUTPT: .WORD QDRV0 : DRIVE 0
: .WORD QDRV1 : DRIVE 1

```

8247	044360	044456	.WORD	QDRV2	.DRIVE 2
8248	044362	044476	.WORD	QDRV3	.DRIVE 3
8249	044364	044496	.WORD	QDRV4	.DRIVE 4
8250	044366	044516	.WORD	QDRV5	.DRIVE 5
8251	044370	044556	.WORD	QDRV6	.DRIVE 6
8252	044372	044576	.WORD	QDRV7	.DRIVE 7
8253					
8254	044374	044416	QSTART:	.WORD QDRV0	.DRIVE 0 START ADDRESS
8255	044376	044436	QSTOP:	.WORD QDRV1	.DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
8256	044400	044456		.WORD QDRV2	.STOP DRIVE 1--START DRIVE 2
8257	044402	044476		.WORD QDRV3	.STOP DRIVE 2--START DRIVE 3
8258	044404	044496		.WORD QDRV4	.STOP DRIVE 3--START DRIVE 4
8259	044406	044516		.WORD QDRV5	.STOP DRIVE 4--START DRIVE 5
8260	044410	044556		.WORD QDRV6	.STOP DRIVE 5--START DRIVE 6
8261	044412	044576		.WORD QDRV7	.STOP DRIVE 6--START DRIVE 7
8262	044414	044616		.WORD QTERM	.STOP DRIVE 7

;DRIVE REQUEST QUEUES

8264			QDRV0:	.BLKW	10
8265			QDRV1:	.BLKW	10
8266	044416	000010	QDRV2:	.BLKW	10
8267	044436	000010	QDRV3:	.BLKW	10
8268	044456	000010	QDRV4:	.BLKW	10
8269	044476	000010	QDRV5:	.BLKW	10
8270	044516	000010	QDRV6:	.BLKW	10
8271	044536	000010	QDRV7:	.BLKW	10
8272	044556	000010	QTERM=.		
8273	044576	000010			
8274		044616			

;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES

```

;CALL
;
; JSR PC,CLPQUE
;
CLRQUE: SAVREG
MOV #QCNT,R2
CLR (R2)+
CLR (R2)+
CLR (R2)+
CLR (R2)+
MOV #8,R3
MOV #QSTART,R1
1$: MOV (R1)+,(R2)+
DEC R3
BNE 1$
MOV #8,R3
MOV #QSTART,R1
2$: MOV (R1)+,(R2)+
DEC R3
BNE 2$
RESREG
RTS PC
;RESTORE R0 - R5
;SAVE R0 - R5
;ZERO THE QUEUE COUNTS
;DRIVES 0 & 1
;DRIVES 2 & 3
;DRIVES 4 & 5
;DRIVES 6 & 7
;MOVE THE STARTING
;ADDRESS OF THE QUEUE INTO
;THE QUEUE INPUT POINTER
;MOVE THE STARTING ADDRESS
;OF THE QUEUE INTO THE
;QUEUE OUTPUT POINTER

```

;EMPTY THE QUEUE SPECIFIED BY R1

;CALL

```

8303      :      MOV      DRVNUM,R1      ;DRIVE NUMBER TO R1
8304      :      JSR      PC,EMPTYQ
8305
8306      044674  105061  044324      EMPTYQ: CLR      QCNT(R1)      ;CLEAR NUMBER OF ITEMS IN QUEUE
8307      044700  006301
8308      044702  016161  044334  044354      ASL      R1
8309      044710  006201      MOV      QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
8310      044712  000207      ASR      R1
8311      :      RTS      PC
8312
8313      :ROUTINE TO PUT A REQUEST IN QUEUE
8314      :CALL
8315      :      MOV      #DRVNUM,R1      ;DRIVE NUMBER
8316      :      MOV      #DPB,R2      ;ADDRESS OF PARAMETER BLOCK
8317      :      JSR      RO,DRVQUE      ;GO PUT REQUEST IN QUEUE
8318      :      RETURN1      ;RETURN HERE IF QUEUE IS FULL
8319      :      RETURN2      ;RETURN HERE IF REQUEST IS IN QUEUE
8320
8321      044714  122761  000010  044324      DRVQUE: CMPB     #10,QCNT(R1)      ;IS QUEUE FULL?
8322      044722  001421      BEQ      2$      ;BR IF YES-TAKE RETURN1
8323      044724  105261  044324      INCB     QCNT(R1)      ;INCREMENT QUEUE COUNT
8324      044730  006301      ASL      R1
8325      044732  010271  044334      MOV      R2,QINPT(R1)      ;PUT THIS REQUEST IN QUEUE
8326      044736  062761  000002  044334      ADD      #2,QINPT(R1)      ;UPDATE THE QUEUE POINTER
8327      044744  026161  044334  044376      CMP      QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
8328      044752  001003      BNE     1$      ;BRANCH IF NO
8329      044754  016161  044374  044334      MOV      QSTART(R1),QINPT(R1) ;YES--RESET POINTER
8330      1$:      ASR      R1
8331      044764  005720      TST      (R0)+      ;TAKE RETURN 2
8332      044766  000200      2$:      RTS      RO      ;RETURN TO USER
8333
8334      :ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
8335      :CALL
8336      :      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
8337      :      JSR      PC,GETREQ      ;GO GET THE REQUEST
8338      :      RETURN      ;R2="DPB" ADDRESS OF THE REQUEST
8339      :      ;R2=0 IF NO REQUEST IN QUEUE
8340
8341      044770  005002
8342      044772  105761  044324      GETREQ: CLR      R2
8343      044776  001404      TSTB    QCNT(R1)      ;IS THERE ANY REQUEST IN QUEUE?
8344      045000  006301      BEQ      2$      ;NO---BRANCH
8345      045002  017102  044354      1$:      ASL      R1
8346      045006  006201      MOV      QOUTPT(R1),R2      ;PICKUP "DPB" POINTER FOR THIS DRIVE
8347      045010  000207      ASR      R1
8348      :      RTS      PC      ;RETURN TO USER
8349
8350      :ROUTINE TO "POP" THE REQUEST FROM QUEUE
8351      :CALL
8352      :      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
8353      :      JSR      PC,POPQUE      ;CALL TO REMOVE REQUEST
8354      :      RETURN      ;R2=ADDRESS OF DPB REMOVED
8355
8356      045012  105361  044324      POPQUE: DECB    QCNT(R1)      ;DECREMENT QUEUE COUNT
8357      045016  006301      ASL      R1
  
```

```

8359 045020 017102 044354      MOV      QOUTPT(R1),R2      ;GET THE "DPB" POINTER
8360 045024 005071 044354      CLR      QOUTPT(R1)       ;REMOVE OPB ADDRESS FROM THE QUEUE
8361 045030 062761 000002 044354      ADD      #2,QOUTPT(R1)    ;UPDATE THE QUEUE POINTER
8362 045036 026161 044354 044376      CMP      QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
8363 045044 001003          BNE      1$              ;NO--BRANCH TO EXIT
8364 045046 016161 044374 044354      MOV      QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
8365 045054 006201          1$:      ASR      R1
8366 045056 000207          RTS      PC              ;RETURN TO USER

;ROUTINE TO SAVE THE CONTENTS OF '$ESCAPE' WHEN THE DRIVER
;REPORTS AN ERROR DIRECTLY.
;CALL
;JSR      RO,ES.SAV
;ERROR   N
;RETURN  ;THE ERROR CALL
;THE RETURN IS PAST THE ERROR CALL

ES.SAV: MOV      (RO)+,1$      ;GET THE ERROR CALL
        MOV      $ESCAPE,-(SP) ;SAVE THE ADDRESS IN '$ESCAPE'
        CLR      $ESCAPE      ;CLEAR THE ESCAPE RETURN
        .WORD   0              ;THE ERROR CALL IS MOVED HERE
1$:     MOV      (SP)+,$ESCAPE ;RESTORE THE ESCAPE ADDRESS
        RTS      RO          ;RETURN

.SBTTL  ASCIZ  MESSAGES

MSG.R:  .ASCIZ  /R/
MSG.FC: .ASCIZ  /FC/
MSG.LC: .ASCIZ  /LC/
MSG.FCP: .ASCIZ /FC'/
MSG.LCP: .ASCIZ /LC'/
MSG.IC: .ASCIZ  /IC/
MSG.FT: .ASCIZ  /FT/
MSG.LT: .ASCIZ  /LT/
MSG.IT: .ASCIZ  /IT/
MSG.FS: .ASCIZ  /FS/
MSG.LS: .ASCIZ  /LS/
MSG.PAT: .ASCIZ  /PAT
MSG.EQ: .ASCIZ  /=/
MSG.CS: .ASCIZ  /CR><LF>>CONTROL SWITCHES=

SLASH:  .ASCIZ  @ / @
SYSTAT: .ASCIZ  /UNIT STATUS: /<CR><LF><LF>

UNTMSG: .ASCIZ  /DRIVE/
UNTOFF: .ASCIZ  / OFFLINE/

UNTON:  .ASCIZ  / ONLINE/

NOTPPS: .ASCIZ  / NOT PRESENT

```

0415	045266	000124			
0416	045270	052440	051516	043101	NOTSAF: .ASCIZ / UNSAFE/
0417	045276	000105			
0418	045300	047040	052117	051040	NOTRM: .ASCIZ a NOT RMO3/RMO2a
0419	045306	030115	027463	046522	
0420	045314	031060	000		
0421	045317	122	030115	000062	ISRMO2: .ASCIZ /RMO2/
0422	045324	046522	031460	000	ISRMO3: .ASCIZ /RMO3/
0423	045331	015	042012	044522	DRIVES: .ASCIZ <CR><LF>/DRIVE(S) TO BE TESTED /
0424	045336	042526	051450	020051	
0425	045344	047524	041040	020105	
0426	045352	042524	052123	042105	
0427	045360	000040			
0428	045362	047516	042516	000	NONE: .ASCIZ /NONE/
0429	045367	054	000		COMMA: .ASCIZ / /
0430	045371	015	047012	020117	NOCLOK: .ASCIZ <CR><LF>/NO KW11-P CLOCK. TIMING TESTS WILL NOT BE PERFORMED/
0431	045376	053513	030461	050055	
0432	045404	041440	047514	045503	
0433	045412	020054	044524	044515	
0434	045420	043516	052040	051505	
0435	045426	051524	053440	046111	
0436	045434	020114	047516	020124	
0437	045442	042502	050040	051105	
0438	045450	047506	046522	042105	
0439	045456	000			
0440	045457	015	005012	042524	TESTNG: .ASCIZ <CR><LF><LF>/TESTING DRIVE /
0441	045464	052123	047111	020107	
0442	045472	051104	053111	020105	
0443	045500	000			
0444	045501	123	051105	040511	SERIAL: .ASCIZ /SERIAL NUMBER /
0445	045506	020114	052516	041115	
0446	045514	051105	000040		
0447					
0448	045520	005015	051012	052117	MSG7: .ASCIZ <CR><LF><LF>/ROTATIONAL SPEED TIMES/
0449	045526	052101	047511	040516	
0450	045534	020114	050123	042505	
0451	045542	020104	044524	042515	
0452	045550	000123			
0453	045552	005015	047412	042516	MSG10A: .ASCIZ <CR><LF><LF>/ONE CYLINDER SEEK TIMES/<CR><LF>/ * FORWARD/
0454	045560	041440	046131	047111	
0455	045566	042504	020122	042523	
0456	045574	045505	052040	046511	
0457	045602	051505	005015	025040	
0458	045610	043040	051117	040527	
0459	045616	042122	000		
0460	045621	015	020012	020052	MSG10B: .ASCIZ <CR><LF>/ * REVERSE/
0461	045626	042522	042526	051522	
0462	045634	000105			
0463	045636	005015	040412	041503	MSG11A: .ASCIZ <CR><LF><LF>/ACCESS TIME MEASUREMENT/<CR><LF>/ * FORWARD.
0464	045644	051505	020123	044524	
0465	045652	042515	046440	040505	
0466	045660	052523	042522	042515	
0467	045666	052116	005015	025040	
0468	045674	043040	051117	040527	
0469	045702	042122	000		
0470	045705	015	020012	020052	MSG11B: .ASCIZ <CR><LF>/ * REVERSE/

8471	045712	042522	042526	051522	
8472	045720	000105			
8473	045722	005015	046412	054101	MSG12A: .ASCIZ <CR><LF><LF>/MAXIMUM SEEK TIMES/'CR><LF>/ * FORWARD/
8474	045730	046511	046525	051440	
8475	045736	042505	020113	044524	
8476	045744	042515	006523	020012	
8477	045752	020052	047506	053522	
8478	045760	051101	000104		
8479	045764	005015	025040	051040	MSG12B: .ASCIZ <CR><LF>/ * REVERSE/
8480	045772	053105	051105	042523	
8481	046000	000			
8482					
8483	046001	015	046412	047111	MSGMIN: .ASCIZ <CR><LF>/MIN=/'
8484	046006	000075			
8485	046010	005015	040515	036530	MSGMAX: .ASCIZ <CR><LF>/MAX=/'
8486	046016	000			
8487	046017	015	040412	043526	MSGAVG: .ASCIZ <CR><LF>/AVG=/'
8488	046024	000075			
8489	046026	020060	051525	000	MSGDUS: .ASCIZ /D US/
8490	046033	040	042502	047514	MBELOW: .ASCIZ / BELOW THE MINIMUM OF /
8491	046040	020127	044124	020105	
8492	046046	044515	044516	052515	
8493	046054	020115	043117	000040	
8494	046062	040440	047502	042526	MABOVE: .ASCIZ / ABOVE THE MAXIMUM OF /
8495	046070	052040	042510	046440	
8496	046076	054101	046511	046525	
8497	046104	047440	020106	000	
8498	046111	040	042523	045505	MSGNUM: .ASCIZ / SEEKS TIMED/
8499	046116	020123	044524	042515	
8500	046124	000104			
8501	046126	047040	052117	052040	MSGNON: .ASCIZ / NOT TIMED/
8502	046134	046511	042105	000	
8503	046141	040	000040		MSG.SP: .ASCIZ / / ; TWO (2) SPACES
8504					
8505					.SBTTL ERROR HEADER (EM) MESSAGES
8506					
8507	046144	044122	030067	044440	EM1: .ASCIZ .RH70 INTERRUPT OCCURRED (RMAS = 0) /
8508	046152	052116	051105	052522	
8509	046160	052120	047440	041503	
8510	046166	051125	042522	020104	
8511	046174	051050	040515	020123	
8512	046202	020075	024460	000	
8513	046207	125	042516	050130	EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
8514	046214	041505	042524	020104	
8515	046222	052101	042524	052116	
8516	046230	047511	020116	041517	
8517	046236	052503	051122	042105	
8518	046244	000			
8519	046245	115	051501	041123	EM3: .ASCIZ .MASSBUS PARITY ERROR(MCPE=1) /
8520	046252	051525	050040	051101	
8521	046260	052111	020131	051105	
8522	046266	047522	024122	041515	
8523	046274	042520	030475	000051	
8524	046302	040515	051523	052502	EM4: .ASCIZ .MASSBUS PARITY ERROR(PAR=1) /
8525	046310	020123	040520	044522	
8526	046316	054524	047440	051122	

051117	050050	051101	
030475	000051		
042101	051104	051505	EMS: .ASCIZ /ADDRESS PLUG CHANGE BIT SET/
020123	046120	043525	
041440	040510	043516	
020109	044522	020124	
042523	000124		
044122	030067	051057	EM10: .ASCIZ "RH70/RMO3 FAILED TO RESPOND TO ADDRESSING"
046400	030115	020063	040506
046406	046111	042105	052040
046414	020117	042522	050123
046422	047117	020104	047524
046430	040440	042104	042522
046436	051523	047111	000107
046444	051104	053111	020105
046452	042523	042514	052103
046460	042105	044440	020123
046466	047516	020124	047117
046474	044514	042516	000
046501	111	050115	047522
046506	042520	020122	042510
046514	042101	051105	042040
046522	052101	000101	
046526	040504	040524	041440
046534	046517	040520	042522
046542	043040	044501	052514
046550	042522	000	
046553	104	051511	020113
046560	051105	047522	020122
046566	047111	052040	046511
046574	047111	020107	042524
046602	052123	000	
046605	103	047514	045503
046612	024040	053513	030461
046620	050055	020051	053117
046626	051105	046106	053517
046634	044440	020116	044524
046642	044515	043516	052040
046650	051505	000124	
046654	044504	045523	042440
046662	051122	051117	042040
046670	051125	047111	020107
046676	042523	045505	000
046703	123	042505	020113
046710	047516	020124	047503
046716	050115	042514	042524
046724	053440	052111	044510
046732	020116	031061	020060
046740	051515	000	
046743	122	033510	027460
046750	046522	031460	042440
046756	051122	051117	000
046763	106	052101	046101
046772	053440	044522	042524
046776	041440	042510	045503
042440	051122	051117	051117

8583	047012	000			
8584					
8585					.SBTTL STATUS/ERROR INDICATOR MESSAGES
8586					
8587	047013	117	043106	044514	MSG814: .ASCIZ /OFFLINE OR UNSAFE DRIVE REQUESTED/
8588	047020	042516	047440	020122	
8589	047026	047125	040523	042506	
8590	047034	042040	044522	042526	
8591	047042	051040	050505	042525	
8592	047050	052123	042105	000	
8593	047055	125	046116	040517	MSG813: .ASCIZ /UNLOADED DRIVE REQUESTED.
8594	047062	042504	020104	051104	
8595	047070	053111	020105	042522	
8596	047076	052521	051505	042524	
8597	047104	000104			
8598	047106	042520	051522	051511	MSG812: .ASCIZ /PERSISTENT UNSAFE/
8599	047114	042524	052116	052440	
8600	047122	051516	043101	000105	
8601	047130	040520	044522	054524	MSG811: .ASCIZ /PARITY ERROR OCCURRED/
8602	047136	042440	051122	051117	
8603	047144	047440	041503	051125	
8604	047152	042522	000104		
8605	047156	040506	040524	020114	MSG810: .ASCIZ /FATAL PARITY ERROR/
8606	047164	040520	044522	054524	
8607	047172	042440	051122	051117	
8608	047200	000			
8609	047201	123	043117	053524	MSG809: .ASCIZ /SOFTWARE TIMEOUT ON THIS DRIVE/
8610	047206	051101	020105	044524	
8611	047214	042515	052517	020124	
8612	047222	047117	052040	044510	
8613	047230	020123	051104	053111	
8614	047236	000105			
8615	047240	047523	052106	040527	MSG808: .ASCIZ /SOFTWARE TIMEOUT ON ANOTHER DRIVE/
8616	047246	042522	052040	046511	
8617	047254	047505	052125	047440	
8618	047262	020116	047101	052117	
8619	047270	042510	020122	051104	
8620	047276	053111	000105		
8621	047302	051105	047522	020122	MSG806: .ASCIZ "ERROR OCCURRED DURING I/O OPERATION"
8622	047310	041517	052503	051122	
8623	047316	042105	042040	051125	
8624	047324	047111	020107	027511	
8625	047332	020117	050117	051105	
8626	047340	052101	047511	000116	
8627	047346	051105	047522	020122	MSG805: .ASCIZ "ERROR OCCURRED DURING NON-I/O OPERATION"
8628	047354	041517	052503	051122	
8629	047362	042105	042040	051125	
8630	047370	047111	020107	047516	
8631	047376	026516	027511	020117	
8632	047404	050117	051105	052101	
8633	047412	047511	000116		
8634	047416	047125	040523	042506	MSG804: .ASCIZ /UNSAFE OCCURRED/
8635	047424	047440	041503	051125	
8636	047432	042522	000104		
8637	047436	052501	047524	040515	MSG803: .ASCIZ AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
8638	047444	044524	020103	042522	

8639	047452	040503	044514	051102	
8640	047460	052101	020105	042523	
8641	047466	052521	047105	042503	
8642	047474	047440	041503	051125	
8643	047502	042522	000104		
8644	047506	051104	053111	020105	MSG802: .ASCIZ /DRIVE HAS NOT RESPONDED TO PORT REQUEST/
8645	047514	040510	020123	047516	
8646	047522	020124	042522	050123	
8647	047530	047117	042504	020104	
8648	047536	047524	050040	051117	
8649	047544	020124	042522	052521	
8650	047552	051505	000124		
8651	047556	051104	053111	020105	MSG801: .ASCIZ /DRIVE HAS BECOME NON-EXISTENT/
8652	047564	040510	020123	042502	
8653	047572	047503	042515	047040	
8654	047600	047117	042455	044530	
8655	047606	052123	047105	000124	
8656					
8657					.SBTTL DATA HEADER (DT) MESSAGES
8658					
8659	047614	051105	020122	041520	DH1: .ASCIZ /ERR PC RMAS/
8660	047622	020040	046522	051501	
8661	047630	000			
8662	047631	105	051122	050040	DH2: .ASCIZ /ERR PC DRIVE RMAS RMO5 RMER1 RMMR2 RMER2/
8663	047636	020103	042040	044522	
8664	047644	042526	020040	051040	
8665	047652	040515	020123	020040	
8666	047660	051040	042115	020123	
8667	047666	020040	046522	051105	
8668	047674	020061	020040	046522	
8669	047702	051115	020062	020040	
8670	047710	046522	051105	000062	
8671	047716	042574	052123	020040	DH3: .ASCIZ /TEST ERR PC ADDRESS DATA/
8672	047724	020040	051105	020122	
8673	047732	041520	020040	042101	
8674	047740	051104	051505	020123	
8675	047746	040504	040524	000	
8676	047753	124	051505	020124	DH4: .ASCIZ /TEST ERR PC ADDRESS GDDATA BDDATA/
8677	047760	020040	042440	051122	
8678	047766	050040	020103	040440	
8679	047774	042104	042522	051523	
8680	050002	043440	042104	052101	
8681	050010	020101	041040	042104	
8682	050016	052101	000101		
8683	050022	046522	051503	020061	DH10: .ASCIZ /RMCS1 ERR PC/
8684	050030	020040	051105	020122	
8685	050036	041520	000		
8686	050041	104	044522	042526	DH11: .ASCIZ /DRIVE ERR PC/
8687	050046	020040	042440	051122	
8688	050054	050040	000103		
8689	050060	042524	052123	020040	DH12: .ASCIZ /TEST ERR PC TST PC DRIVE CYLNRD TRACK SECTOR
8690	050066	020040	051105	020122	
8691	050074	041520	020040	051524	
8692	050102	020124	041520	020040	
8693	050110	051104	053111	020105	
8694	050116	020040	054503	047114	

M15

8807	051234	001176	001116	001164	DT5:	.WORD	\$TMP0,\$ERRPC,\$REG1,\$REG5, RMERRS, RMERRS+2, RMERRS+4, RMERRS+6
8808	051242	001174	036570	036572			
8809	051250	036574	036576				
8810	051254	001450	001116		DT10:	.WORD	RH.ADR,\$ERRPC
8811	051260	001166	001116		DT11:	.WORD	\$REG2,\$ERRPC
8812	051264	001176	001116	001162	DT12:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
8813	051272	001334	001350	001354			
8814	051300	001352					
8815	051302	001350	001354	001352	DT12A:	.WORD	CYL.DS,TRK.DS,SEC.DS,CYL.RD,TRK.RD,SEC.RD
8816	051310	001342	001344	001346			
8817	051316	001176	001116	001162	DT13:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
8818	051324	001334	001350	001354			
8819	051332	001352					
8820	051334	001124	001126	001172	DT13A:	.WORD	\$GDDAT,\$BDDAT,\$REG4,\$GDADR,\$BDADR
8821	051342	001120	001122				
8822	051346	001176	001116	001334	DT17:	.WORD	\$TMP0,\$ERRPC,CHKDRV, RM.REG, RM.REG+12, RM.REG+14, RM.REG+40, RM.REG+42
8823	051354	004306	004320	004322			
8824	051362	004346	004350				
8825	051366	001176	001116	001162	DT21:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS
8826	051374	001334	001350	001354			
8827	051402	001164	001126	001172	DT21A:	.WORD	\$REG1,\$BDDAT,\$REG4,\$REG1
8828	051410	001164					
8829	051412	001176	001116	001334	DT23:	.WORD	\$TMP0,\$ERRPC,CHKDRV,CYL.DS, RM.REG, RM.REG+10, RM.REG+12
8830	051420	001350	004306	004316			
8831	051426	004320					
8832	051430	004322	004346	004350	DT23A:	.WORD	RM.REG+14, RM.REG+40, RM.REG+42, RM.REG+34, RM.REG+36
8833	051436	004342	004344				
8834	051442	001176	001116	001162	DT41:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV
8835	051450	001334					
8836	051452	001176	001116	001162	DT42:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV, RM.REG, RM.REG+10, RM.REG+12
8837	051460	001334	004306	004316			
8838	051466	004320					
8839	051470	001176	001116	001162	DT43:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV, RM.REG, RM.REG+10, RM.REG+12
8840	051476	001334	004306	004316			
8841	051504	004320					
8842	051506	004322	004346	004350	DT43A:	.WORD	RM.REG+14, RM.REG+40, RM.REG+42
8843	051514	001176	001116	001162	DT44:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
8844	051522	001334	001350	001354			
8845	051530	001352					
8846	051532	004306	004316	004320	DT44A:	.WORD	RM.REG, RM.REG+10, RM.REG+12, RM.REG+36, RM.REG+34, RM.REG+06
8847	051540	004344	004342	004314			
8848	051546	004322	004346	004350	DT44B:	.WORD	RM.REG+14, RM.REG+40, RM.REG+42
8849	051554	001176	001116	001162	DT45:	.WORD	\$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
8850	051562	001334	001350	001354			
8851	051570	001352					
8852	051572	004306	004316	004320	DT45A:	.WORD	RM.REG, RM.REG+10, RM.REG+12, RM.REG+36, RM.REG+34, RM.REG+06
8853	051600	004344	004342	004314			
8854	051606	004322	004346	004350	DT45B:	.WORD	RM.REG+14, RM.REG+40, RM.REG+42, RM.REG+2, RM.REG+4, RM.REG+22
8855	051614	004310	004312	004330			

.SBTTL DATA FORMAT (DF) TABLE

8859	051622	000001	DF1:	.WORD	1	: NUMBER OF DATA HEADERS
8860	051624	002		.BYTE	2	: NUMBER OF WORDS IN DATA TABLE
8861	051626	000		.BYTE	0	: ALL 3 NUMBERS ARE OCTAL
8862						

8863	051626	000001	DF2:	.WORD	1
8864	051630	007		.BYTE	7
8865	051631	000		.BYTE	0
8866					
8867	051632	000001	DF3:	.WORD	1
8868	051634	004		.BYTE	4
8869	051635	000		.BYTE	0
8870					
8871	051636	000001	DF4:	.WORD	1
8872	051640	005		.BYTE	5
8873	051641	000		.BYTE	0
8874					
8875	051642	000001	DF10:	.WORD	1
8876	051644	002		.BYTE	2
8877	051645	000		.BYTE	0
8878					
8879	051646	000001	DF11:	.WORD	1
8880	051650	002		.BYTE	2
8881	051651	000		.BYTE	0
8882					
8883	051652	000002	DF12:	.WORD	2
8884	051654	007		.BYTE	7
8885	051655	160		.BYTE	160
8886	051656	050147		.WORD	DH12A
8887	051660	006		.BYTE	6
8888	051661	000		.BYTE	0
8889					
8890	051662	000002	DF13:	.WORD	2
8891	051664	007		.BYTE	7
8892	051665	160		.BYTE	160
8893	051666	050226		.WORD	DH13A
8894	051670	005		.BYTE	5
8895	051671	004		.BYTE	4
8896					
8897	051672	000000	DF14:	.WORD	0
8898	051674	005		.BYTE	5
8899	051675	004		.BYTE	4
8900					
8901	051676	000001	DF17:	.WORD	1
8902	051700	010		.BYTE	108
8903	051701	000		.BYTE	0
8904					
8905	051702	000002	DF21:	.WORD	2
8906	051704	006		.BYTE	6
8907	051705	060		.BYTE	60
8908	051706	050447		.WORD	DH21A
8909	051710	004		.BYTE	4
8910	051711	014		.BYTE	14
8911					
8912	051712	000000	DF22:	.WORD	0
8913	051714	004		.BYTE	4
8914	051715	014		.BYTE	14
8915					
8916	051716	000002	DF23:	.WORD	2
8917	051720	007		.BYTE	7
8918	051721	010		.BYTE	10

: 2 DH'S TO BE TYPED
 : 7 DATA WORDS FOLLOW THE 1ST DH
 : WORDS 1-4 ARE OCTAL 5-7 ARE DECIMAL
 : ADDRESS OF 2ND DH
 : 6 DATA WORDS FOLLOW THE 2ND DH
 : ALL WORDS ARE OCTAL

;WORD 3 IS DECIMAL

;WORD 3 IS DECIMAL

;WORD 4 IS DECIMAL

8919	051722	050573				.WORD	0H23A
8920	051724	005				.BYTE	5
8921	051725	000				.BYTE	0
8922							
8923							
8924	051726	000001			DF41:	.WORD	1
8925	051730	004				.BYTE	4
8926	051731	000				.BYTE	0
8927							
8928	051732	000001			DF42:	.WORD	1
8929	051734	007				.BYTE	7
8930	051735	000				.BYTE	0
8931							
8932	051736	000002			DF43:	.WORD	2
8933	051740	007				.BYTE	7
8934	051741	000				.BYTE	0
8935	051742	050763				.WORD	0H43A
8936	051744	003				.BYTE	3
8937	051745	000				.BYTE	0
8938							
8939	051746	000003			DF44:	.WORD	3
8940	051750	007				.BYTE	7
8941	051751	160				.BYTE	160
8942	051752	051011				.WORD	0H44A
8943	051754	006				.BYTE	6
8944	051755	000				.BYTE	0
8945	051756	051065				.WORD	0H44B
8946	051760	003				.BYTE	3
8947	051761	000				.BYTE	0
8948							
8949	051762	000003			DF45:	.WORD	3
8950	051764	007				.BYTE	7
8951	051765	160				.BYTE	160
8952	051766	051011				.WORD	0H44A
8953	051770	006				.BYTE	6
8954	051771	000				.BYTE	0
8955	051772	051113				.WORD	0H45A
8956	051774	006				.BYTE	6
8957	051775	000				.BYTE	0
8958							
8959							
8960		051776			.EVEN		
8961					BUFFER=.		
8962	051776	005015	041412	051132	TITLE:	.ASCII	<CR><LF>/CZRMFB/<CR><LF>
8963	052004	043115	030102	005015			
8964	052012	046522	031450	051057		.ASCIIZ	ARM03/ARM02 EXTENDED DRIVE TEST<CR><LF>
8965	052020	030115	020062	054105			
8966	052026	042524	042116	042105			
8967	052034	042040	044522	042526			
8968	052042	052040	051505	006524			
8969	052050	000012					
8970	052052	055015	047524	052040	LOADRV:	.ASCII	<CR><LF>/TO TEST DRIVE 0 REPLACE THE 'XXDP' PACK ON DRIVE 0<CR><LF>
8971	052060	051505	020124	051104			
8972	052066	053111	020105	020060			
8973	052074	042522	046120	041501			
8974	052102	020105	044124	020105			

8975	052110	054047	042130	023520
8976	052116	050040	041501	020113
8977	052124	047117	042040	044522
8978	052132	042526	030040	005015
8979	052140	044527	044124	040440
8980	052146	047516	044124	051105
8981	052154	050040	041501	026113
8982	052162	041440	042514	051101
8983	052170	046440	046505	051117
8984	052176	020131	047514	040503
8985	052204	044524	047117	032040
8986	052212	026050	040440	042116
8987	052220	051040	051505	040524
8988	052226	052122	005015	
8989	052232	044124	020105	051120
8990	052240	043517	040522	006515
8991	052246	000012		
8992	052250	005015	054523	052123
8993	052256	046505	044040	051501
8994	052264	030440	045466	046440
8995	052272	046505	051117	026131
8996	052300	023440	054130	050104
8997	052306	020047	047514	042101
8998	052314	051105	053440	046111
8999	052322	020114	042502	047440
9000	052330	042526	053522	044522
9001	052336	052124	047105	005015
9002	052344	000012		
9003				
9004				
9005				
9006				
9007				
9008				
9009				
9010				
9011				
9012				
9013				
9014	052346	010046		
9015	052350	010146		
9016	052352	013746	000004	
9017	052356	013746	000006	
9018	052362	010600		
9019				
9020	052364	104400		
9021	052366	012637	000006	
9022	052372	012737	052412	000004
9023	052400	012701	020000	
9024	052404	005711		
9025	052406	005721		
9026	052410	000775		
9027	052412	105701	000002	
9028	052416	010006		
9029	052420	012637	000006	
9030	052424	012637	000004	

.ASCII /WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40, AND RESTART<<CR>><LF>

.ASCIIZ /THE PROGRAM<<CR>><LF>

NOLOAD: .ASCIIZ <CR><LF>/SYSTEM HAS 16K MEMORY, 'XXDP' LOADER WILL BE OVERWRITTEN<<CR>>

.EVEN

.SBTTL ROUTINE TO SIZE MEMORY

*CALL:

* JSR PC,\$SIZE

* RETURN

*\$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION

```

$SIZE:  MOV    R0,-(SP)      ;;SAVE R0 ON THE STACK
        MOV    R1,-(SP)      ;;SAVE R1 ON THE STACK
        MOV    @#ERRVEC-(SP) ;;SAVE PRESENT ERROR VECTOR PS & PC
        MOV    @#ERRVEC+2,-(SP)
        MOV    SP,R0        ;;SAVE THE STACK POINTER
;;SET THE ERRVEC PS TO THE PRESENT PS
        TRAP
        MOV    (SP)+,@#ERRVEC+2 ;;PUSH OLD PSW AND PC ON STACK
        MOV    @#ERRVEC+2, @#ERRVEC ;;SAVE THE PSW IN @#ERRVEC+2
        MOV    @#20000,R1    ;;SET FOR TIMEOUT
        MOV    @#20000,R1    ;;FIRST ADDRESS
1$:     TST    (R1)          ;;TEST THIS ADDRESS
        TST    (R1)+        ;;STEP TO NEXT ADDRESS
        BR    1$           ;;TRY ANOTHER
2$:     SUB    @#2,R1        ;;DROP BACK
        MOV    R0,SP        ;;RESTORE THE STACK
        MOV    (SP)+,@#ERRVEC+2 ;;RESTORE ERROR VECTOR
        MOV    (SP)+,@#ERRVEC

```

```

9031 052430 010137 052442      MOV      R1,$LSTAD      ;;LAST ADDRESS
9032 052434 012601      MOV      (SP)+,R1      ;;RESTORE R1
9033 052436 012600      MOV      (SP)+,R0      ;;RESTORE R0
9034 052440 000207      RTS      PC
9035 052442 000000      $LSTAD: .WORD 0        ;;CONTAINS THE LAST ADDRESS
9036
9037
9038
9039
9040
9041
9042
9043
9044
9045
9046
9047
9048
9049 052444 005737 001306      GETADR: TST      @#BUSADR      ; INPUT FROM TTY REQUESTED?
9050 052450 001427      BEQ      7$              ; NO--BRANCH
9051 052452 005037 001306      CLR      @#BUSADR      ; YES--CLEAR THE REQUEST FLAG
9052 052456 012700 001450      1$:  MOV      @#RH.ADR,R0      ; FIRST ADDRESS
9053 052462 012703 052622      MOV      @#RMCS1,R3      ; "RMCS1="
9054 052466 011004      MOV      (R0),R4        ; PRESENT RMCS1 ADDRESS
9055 052470 004037 033740      JSR      R0,@#GETNUM     ; GET NEW RMCS1
9056 052474 000402      BR       2$              ; COMMA
9057 052476 000767      BR       1$              ; PERIOD
9058 052500 000412      BR       5$              ; DOUBLE PERIOD
9059 052502 010420      2$:  MOV      R4,(R0)+      ; SAVE NEW RMCS1
9060 052504 012703 052712      MOV      @#RHVEC,R3     ; "RHVEC="
9061 052510 011004      MOV      (R0),R4        ; PRESENT RH70 VECTOR ADDRESS
9062 052512 004037 033740      JSR      R0,@#GETNUM     ; GET NEW RHVEC
9063 052516 000402      BR       3$              ; COMMA
9064 052520 000756      BR       1$              ; PERIOD
9065 052522 000401      BR       5$              ; DOUBLE PERIOD
9066 052524 010420      3$:  MOV      R4,(R0)+      ; SAVE NEW RHVEC
9067 052526 010410      5$:  MOV      R4,(R0)        ; SAVE INPUT
9068 052530 013701 000004      7$:  MOV      @#ERRVEC,R1     ; SAVE THE ERROR VECTOR
9069 052534 012737 052570 000004      MOV      @#S,@#ERRVEC   ; SETUP FOR TRAP
9070 052542 005777 126702      TST      @#RH.ADR      ; CHECK FOR RH70/RM03
9071 052546 010137 000004      MOV      R1,@#ERRVEC    ; RESTORE ERROR VECTOR
9072 052552 012700 001450      MOV      @#RH.ADR,R0    ; FIRST ADDRESS OF NEW PARAMETERS
9073 052556 012701 036736      MOV      @#RMADR,R1     ; FIRST ADDRESS OF WHERE TO PUT THEM
9074 052562 012021      MOV      (R0)+,(R1)+    ; BUS ADDRESS
9075 052564 012021      MOV      (R0)+,(R1)+    ; VECTOR ADDRESS
9076 052566 000207      RTS      PC              ; RETURN
9077 052570 010137 000004      8$:  MOV      R1,@#ERRVEC    ; RESTORE ERROR VECTOR
9078 052574 022626      CMP      (SP)+,(SP)+    ; CLEAN OFF THE STACK
9079 052576 104010      ERROR 10                ; REPORT THE ERROR
9080 052600 005737 000042      TST      @#42           ; IS THERE A MONITOR?
9081 052604 001724      BEQ      1$              ; NO--GO ASK FOR ADDRESS
9082 052606 005037 001312      CLR      @#DRVSEL      ; YES--NO DRIVES SELECTED
9083 052612 005037 021226      CLR      @#SEOPCT      ; NO PASSES
9084 052616 000137 021052      JMP      @#SEOP         ; GO TO END OF PROGRAM
9085
9086 052622 005015 047105 042524 MFMCS1: .ASCII <CR><LF><ENTER SIX OCTAL DIGITS,FOLLOWED BY . AND CR

```


E16

MO-11-DZRMF-B RM03/RM02 EXTENDED DRIVE TEST MACY11 30(1046) 22-NOV-77 08:04 PAGE 169
CZRMFB.P11 21-NOV-77 14:10 GETADR - GET BUS ADDRESS AND VECTOR ADDRESS

SEQ 0199

9087	052630	020122	044523	020130	
9088	052636	041517	040524	020114	
9089	052644	044504	044507	051524	
9090	052652	043054	046117	047514	
9091	052660	042527	020104	054502	
9092	052666	026040	040440	042116	
9093	052674	036040	051103	076	
9094	052701	015	051012	041515	.ASCIZ <CR><LF>/RMCS1=/ MRHVEC: .ASCIZ <CR><LF>/RHVEC=/ .END
9095	052706	030523	000075		
9096	052712	005015	044122	042526	
9097	052720	036503	000		
9098		000001			

\$MNEW	024616	4555	4699#											
\$MSGAD	001234	541#	4016#	4019										
\$MSGLG	001236	542#	4021#											
\$MSGTY	001220	535#	4014	4022*	4034	4038*								
\$MSWR	024605	4552	4697#											
\$MTYP1	001251	556#												
\$MTYP2	001255	564#												
\$MTYP3	001261	567#												
\$MTYP4	001265	570#												
\$MXCNT	025060	4749	4759#											
\$NULL	001154	508#	4271	4300										
\$NWTST=	000001	2095#	2097	2143#	2145	2196#	2198	2259#	2261	2314#	2316	2407#	2409	2468#
		2470	2534#	2536	2626#	2628	2810#	2812	2893#	2895	3036#	3038	3140#	3142
		3254#	3256	3384#	3386	3470#	3472	3567#	3569	3763#	3765	3899#	3901	
\$OCNT	023126	4333#	4362#	4375#										
\$OMODE	023130	4328#	4332#	4337	4340#	4351#	4377#							
\$OVER	025044	4719	4739	4747	4756#									
\$PASS	001226	538#	1830*	3968*	3969*	3991								
\$PASTM	000226	472#												
\$QUES	001214	526#	4115	4300	4606	4677	4694							
\$RAND	025532	2583	2786	4969#	5623	6241	6256							
\$ROCHR	024216	4619#	4847											
\$RDOEC=	***** U	4849												
\$RDLIN	024306 U	4642#	4848											
\$RDOCT=	***** U	4849												
\$RDSZ =	000024	4635#												
\$REGAD	001160	512#	1835											
\$REGO	001162	514#	4129#	8812	8817	8825	8834	8836	8839	8843	8849			
\$REG1	001164	515#	4130#	8800	8807	8827								
\$REG2	001166	516#	4131#	8811										
\$R_3	001170	517#	4132#	8799	8800									
\$R_4	001172	518#	4133#	8820	8827									
\$REG5	001174	519#	4134#	8807										
\$RESRE	025120	4794#	4850											
\$RTNAD	021312	3990#												
\$R2A =	***** U	4851												
\$SAVRE	025062	4778#	4849											
\$SB20	025242	4863#	5817	5824	5828	5833	5840	5844	5856	5861	6620	6695		
\$SCOPE	024630	1800	4716#											
\$SETUP=	000167	1782#	1799	1800	1802	1804	1806	1807	1809	1810	1812	1859	3966	4068
		4100	4108	4489	4494	4495	4525	4701	4717					
\$SIZE	052346	1853	9014#											
\$STUP =	177777	1782#												
\$SUPRS	025472	4944#	5818	5825	5829	5834	5841	5845	5857	5862	6621	6696		
\$SVLAD	025010	4727	4750#											
\$SVPC =	000200	69#	74											
\$SWR =	167000	1#	11	40	41	42	43	44	45	453#	523	524	525	1809
		1810	1812	1813	2116	2166	2221	2280	2336	2432	2491	2557	2662	2835
		2917	3059	3165	3279	3409	3496	3641	3802	3920	3941	3967	3983	3989
		3991	4059	4060	4061	4062	4063	4078	4085	4097	4101	4115	4709	4710
		4711	4712	4713	4718	4730	4732	4733	4734	4741	4742	4743	4753	4756
		4759												
\$SWREG	001242	546#	1833											
\$SWPMK=	000000	4713												
\$TESTN	001224	537#	2116*	2166*	2221*	2280*	2336*	2432*	2491*	2557*	2662*	2835*	3059*	3165*
		3279#	3409*	3496*	3641*	3802*	4751*							

CKCHR	1778#	6348	6398	6625	6662	6702	6865	6878	6889	6940					
CKDIG	1778#	6406	6644												
CKNUM	1778#	6356	6677	6710											
COMMEN	197#	2044	2079	2875	3370										
COMND	1778#	2013	2132	2574	2679	3923	3928								
DO	1778#	2012	2014	2139	2140	2192	2193	2245	2253	2303	2308	2365	2371	2387	2393
	2457	2459	2519	2521	2523	2525	2527	2529	2596	2617	2860	2862	3924	3929	5680
DODTA	1778#	3437	3441	3446	3456	3463	3525	3536	3552	3558	3737	3743	3753	3832	3857
	3864	3876	3883	3894											
DRV. IN	1778#	3017	3130	3245	3359										
ENDCOM	197#	2072	2090	2888	3379										
ENDPAS	1778#	3976													
ERRCAL	6960#	7778	7830	7833	8097	8158									
ERREND	1778#	4112													
ERROR	91#	1998	2726	2802	2987	3001	3016	3105	3129	3209	3227	3244	3323	3341	3358
	5309	5310	5311	5312	5318	5345	5346	5347	5348	5357	5392	5393	5394	5395	5404
	5445	5446	5447	5448	5456	5482	5483	5484	5485	5493	5515	5516	5517	5518	5526
	5678	5719	5720	5721	5722	5723	6035	6040	6151	6157	6215	6216	7779	7831	7835
	8099	8159	9079												
ERRTYP	1778#	4069													
ER. NDX	1778#	5303	5339	5386	5439	5476	5509	5713							
ESCAPE	197#	2943	3083	3189	3303	5302	5338	5385	5437	5475	5508	5676	5712	6034	6038
	6150	6155	6203												
GETPRI	197#	5020	9020												
GETSWR	1#	197#	1859												
LOOP	1778#	2242	2250	2301	2305	2362	2384	2454	2514	2593	2597	2696	2734	3434	3439
	3442	3450	3457	3522	3532	3549	3555	3731	3740	3750	3830	3855	3862	3874	3881
	3892														
MORETA	453#	578													
MORE. S	1778#	2104	2154	2209	2268	2324	2420	2479	2545	2650	2823	2905	3047	3153	3267
	3397	3484	3629	3790	3908										
MSG	2095#	2097	2143#	2145	2196#	2198	2259#	2261	2314#	2316	2407#	2409	2468#	2470	2534#
	2536	2625#	2628	2810#	2812	2892#	2895	3036#	3038	3140#	3142	3254#	3256	3384#	3386
	3470#	3472	3567#	3569	3763#	3765	3899#	3901							
MULT	197#														
NEWTST	197#	2095	2143	2196	2259	2314	2407	2468	2534	2626	2810	2893	3036	3140	3254
	3384	3470	3567	3763	3899										
POP	197#	4042	4043	4432	4799	4988	5071	5216	5265						
PUSH	197#	4003	4005	4026	4391	4779	4969	5023	5171	5229					
REPORT	197#	1778#	3135	3250	3364										
RMO3.0	1#	6960													
SAV. RH	1778#	2981	2995	3010	3099	3123	3203	3221	3238	3317	3335	3352			
SCOPE	92#	2141	2194	2257	2312	2405	2466	2532	2623	2808	2870	3033	3137	3252	3366
	3468	3564	3760	3895	3932										
SETPRI	197#	4622													
SETTRA	4830#	4839	4840	4841	4842	4844	4846	4847	4848	4849	4850				
SETUP	197#	1792													
SET. TN	1778#	2105	2155	2210	2269	2325	2421	2480	2546	2651	2824	2906	3048	3154	3268
	3398	3485	3630	3791	3909										
SKIP	197#														
SLASH	197#														
SPACE	197#														
STARS	67	197#	201	243	247	424	455	457	464	477	529	532	1680	2095	2103
	2143	2153	2196	2208	2259	2267	2314	2323	2407	2419	2468	2478	2534	2544	2626
	2649	2810	2822	2893	2904	3036	3046	3140	3152	3254	3266	3384	3396	3470	3483
	3567	3628	3763	3789	3899	3907	3938	3998	4055	4116	4223	4303	4381	4449	4525

	4547	4611	4635	4705	4763	4809	4854	4873	4936	4960	4997	6959	6971	9008	9037
SWRSU	197#	1814#													
TRMTRP	4837#														
TSTTYP	12#	2117	2167	2222	2281	2337	2433	2492	2558	2663	2836	2917	3060	3166	3280
	34.0	3497	3642	3803											
TYPBIN	167#														
TYPB2D	1778#	5816	5823	5827	5832	5839	5843	5855	5860	6619	6694				
TYPDEC	197#	4197													
TYPEND	1778#	3945													
TYPNAM	197#														
TYPNUM	197#														
TYPOCS	197#	1889	1965	2016	2124	2174	2229	2288	2344	2440	2499	2565	2670	2843	2924
	3067	3173	3287	3417	3504	3649	3810	3955	6588						
TYPOCT	197#	3963	4194	4553	6343	6657	6698								
TYPTXT	197#	3945	3951	3959	3976	4156	4173	6312	6392	6424	6584	6689			
\$\$CMRE	475#	514	515	516	517	518	519								
\$\$CMTM	475#	520	521	522											
\$\$ESCA	197#														
\$\$NEWT	197#	2095	2143	2196	2259	2314	2407	2468	2534	2626	2810	2893	3036	3140	3254
	3384	3470	3567	3763	3899										
\$\$SET	4830#	4839	4840	4841	4842	4844	4846	4847	4848	4849	4850				
\$\$SETH	1830#														
\$\$SKIP	197#														
.EQUAT	1#	87													
.HEADE	1#														
.SETUP	1#	1782													
.SWRHI	1#	36													
.SWRLO	46#	47	48	49	50	51	52	53							
.\$ACTI	1#	65													
.\$APT8	1#	530#													
.\$ZPTH	1#	453													
.\$AITY	1#	3996													
.\$CAIC	1#	55													
.\$CMTA	1#	475													
.\$DB2D	1#	4871													
.\$DIV	1#	4995													
.\$EOP	1#	3936													
.\$ERRO	1#	4053													
.\$RAND	1#	4958													
.\$RDDE	1#														
.\$ROOC	1#														
.\$READ	1#	4447													
.\$SAVE	1#	4761													
.\$SB2D	1#	4852													
.\$SCOP	1#	4703													
.\$SIZE	1#	9006													
.\$SUPR	1#	4934													
.\$STRAP	1#	4807													
.\$STYPD	1#	4379													
.\$STYPE	1#	4221													
.\$STYPO	1#	4301													

. ABS. 052723 000

002

MD-11-DZRMF-B RMO3/RMO2 EXTENDED DRIVE TEST MACY11 30(1046) 22-NOV-77 08:04 PAGE 195
CZRMFB.P11 21-NOV-77 14:10 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0223

ERRORS DETECTED: 0

RMO3:CZRMFB,RMO3:CZRMFB.LST/NL:MD:MC:CND:TOC/SOL/CRF=RMO3:RMDRV5.P11,RMO3:CZRMFB.P11
RUN-TIME: 33 27 2 SECONDS
RUN-TIME RATIO: 558/64=8.6
CORE USED: 47K (93 PAGES)