

# RP04/5/6

MECHANICAL & READ/WRITE  
MD-11-DZRJA-B  
TESTS

EP-DZRJA-B-DL  
COPYRIGHT © 74-77  
FICHE 1 OF 1

DEC 1977  
**digital**  
MADE IN USA

This microfiche card contains 144 individual frames arranged in a 12x12 grid. Each frame displays a unique test pattern, likely used for mechanical and read/write testing of the MD-11-DZRJA-B system. The patterns vary significantly, including:

- Vertical and horizontal bar codes of varying lengths and spacings.
- Complex geometric shapes and grids.
- Text-based patterns, possibly representing data or instructions.
- Diagonal and irregular line patterns.

The frames are densely packed and cover the majority of the card's surface, with some blank or less distinct frames visible in the bottom right corner.

.REM 2

I D E N T I F I C A T I O N  
-----

PRODUCT CODE: MAINDEC-11-DZRJA-B-D  
PRODUCT NAME RPO4/5/6 MECHANICAL AND READ-WRITE TEST  
DATE SEPTEMBER 1977  
MAINTAINER DIAGNOSTIC ENGINEERING  
AUTHOR C HESS

COPYRIGHT (C) 1974, 1977 DIGITAL EQUIPMENT CORP , MAYNARD, MASS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE  
WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A  
COMMITMENT BY DIGITAL EQUIPMENT CORPORATION DIGITAL  
EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY  
ERRORS THAT MAY APPEAR IN THIS DOCUMENT

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED  
UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE  
WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY  
FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT  
THAT IS NOT SUPPLIED BY DIGITAL

CONTENTS

1	ABSTRACT
2	REQUIREMENTS
2 1	EQUIPMENT
2 2	PRELIMINARY PROGRAMS
2 3	MEDIA
3	LOADING PROCEDURE
4.	STARTING PROCEDURE
4. 1	STARTING ADDRESSES
4. 2	OPERATOR ACTION
4. 3	PROGRAM ACTION
4. 3 1	CONTROL SWITCH SELECTION
4. 3 2	RH11 - RH70 ADDRESS SELECTION
4. 3 3	DRIVE AND PARAMETER SELECTION
5	OPERATING PROCEDURE
5 1	OPERATIONAL SWITCH SETTINGS
5 2	CONTROL SWITCH SETTINGS
6	ERRORS
6 1	ERROR TYPES
6 2	ERROR RECOVERY
7	RESTRICTIONS
8	MISCELLANEOUS
8 1	EXECUTION TIME
8 2	STACK POINTER
8 3	TIMING TEST (TESTS 12 - 15) PRINTOUTS
8 4	END OF TEST
9	PROGRAM DESCRIPTION
10	PROGRAM LISTING

1 ABSTRACT  
-----

THIS PROGRAM CONTAINS A SERIES OF TESTS THAT WILL VERIFY THAT THE DISK IS CAPABLE OF PERFORMING SEEKS, THAT THE ACCESS TIMES ARE WITHIN TOLERANCE, THAT THE TRACK AND SECTOR ADDRESSING CIRCUITRY OPERATES PROPERLY, AND THAT THE DATA STORAGE AND RETRIEVAL CAPABILITIES ARE FUNCTIONING.

2 REQUIREMENTS  
-----

2 1 EQUIPMENT

PDP-11 PROCESSOR  
16K MEMORY  
TELETYPE  
PROGRAM LOADING DEVICE  
KW11-L OR KW11-P (THE KW11-P IS REQUIRED FOR THE TIMING TESTS)  
RH11 OR RH70 WITH 1 - 8 RPO4/5/6 DISK DRIVES

2 2 PRELIMINARY PROGRAMS

RPO4/5/6 DISKLESS CONTROLLER TEST  
PART 1 (MAINDEC-11-DZRJG)  
PART 2 (MAINDEC-11-DZRJH)  
  
RPO4/5/6 FUNCTIONAL CONTROLLER TEST  
PART 1 (MAINDEC-11-DZRJI)  
PART 2 (MAINDEC-11-DZRJJ)

2 3 MEDIA

THE PROGRAM REQUIRES THAT EACH DRIVE TO BE TESTED HAS A FORMATTED DISK PACK. THE PACK MAY BE FORMATTED IN EITHER 16-BIT OR 18-BIT MODE, DEPENDING ON THE TESTING REQUIREMENTS. NOTE THAT THE PROGRAM WILL NOT TEST A MIXTURE OF DRIVES WITH BOTH 16 AND 18 BIT MODE PACKS

3 LOADING PROCEDURE  
-----

THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER. THE PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN IF THE PROGRAM IS BEING RUN ON A PROCESSOR WITH 16K. THE 'XXDP' LOADER WILL NOT BE PRESERVED. THE PROGRAM MUST BE RUN ON A SYSTEM WITH 20K OR MORE TO PRESERVE THE 'XXDP' LOADER. THE 'ABSOLUTE' LOADER WILL BE PRESERVED IN A 16K SYSTEM, HOWEVER

4 STARTING PROCEDURE  
-----

4 1 STARTING ADDRESSES

200 NORMAL STARTING ADDRESS  
204 SELECT OPERATING PARAMETERS  
210 SELECT RH11-RH70 ADDRESSES  
214 COMBINATION OF 204 AND 210

NOTE STARTING ADDRESSES 210 AND 214 ARE AVAILABLE WHEN THE PROGRAM IS INITIALLY STARTED; THESE STARTING ADDRESSES ARE TREATED AS ADDRESSES 200 OR 204 RESPECTIVELY ON RESTARTS

4 2 OPERATOR ACTION

1 LOAD PROGRAM INTO MEMORY (SEE SECTION 3 )  
2 LOAD A FORMATTED PACK INTO DRIVE(S) TO BE TESTED  
3 BRING DRIVE(S) TO ONLINE STATE, WRITE ENABLED,  
AND LOCKED ON PORT  
4. LOAD ADDRESS 200  
5 SET SWITCHES (SEE SECTION 5 )  
6 PRESS START.  
7 THE PROGRAM WILL TYPEOUT THE STATUS OF THE DRIVES ATTACHED TO THE SELECTED MASSBUS SUBSYSTEM TO INHIBIT THIS TYPEOUT, DO NOT RESTART THE PROGRAM FROM ANY OF THE STARTING ADDRESSES, INSTEAD TYPE A 'CONTROL C' ON THE KEYBOARD TO RETURN THE PROGRAM TO COMMAND ENTRY MODE

4.3 PROGRAM ACTION

IN AN EFFORT TO ALLOW CONVERSATION WITH A PROGRAM FOR THE PURPOSE OF CONTROLLING ITS OPERATION AND PARAMETERS THE FOLLOWING CONSTRUCTIONS HAVE BEEN ADOPTED

NOTE1 IN ALL EXAMPLES BRACKETS ARE USED FOR CLARITY AND ARE NOT TYPED BY THE USER

NOTE2 THE CARRIAGE RETURN TYPED BY THE USER IS INDICATED BY <CR> AND WILL BE ECHOED AS A 'CARRIAGE RETURN-LINE FEED'

< ><CR> PERIOD

A STATEMENT TERMINATOR WHEN TYPED AT THE END OF A LINE (LEGAL ON ALL LINES) IT TELLS THE PARAMETER STRING INTERPRETER (PSI) THIS IS THE END OF CHANGES TO THE CURRENT PARAMETER STRING.

< ><CR> PERIOD PERIOD

THE 'PERIOD PERIOD' TERMINATOR IS TYPED TO INDICATE THE END OF TEST PARAMETER MODIFICATION AND TO SIGNAL

THE START OF TEST EXECUTION

<,><CR>

COMMA

THE COMMA IS USED AS A SEPARATOR BETWEEN DRIVE NUMBERS AND TEST NUMBERS

</>

SLASH

A MODIFICATION INDICATOR IF A SLASH FOLLOWS A TEST NUMBER, THE PROGRAM WILL OPEN THAT TEST FOR PARAMETER MODIFICATION

< U>

CONTROL-U

DELETE THE PRESENT INPUT STRING AND START A NEW LINE TYPED BY DEPRESSING THE "CONTROL KEY" (CTRL) AND THEN STRIKING THE "U"

< >

RUBOUT

DELETE THE LAST CHARACTER FROM THE INPUT STRING TYPED BY STRIKING THE "RUBOUT" KEY WHICH WILL BE ECHOED BY A BACKSLASH ( ) FOLLOWED BY THE CHARACTER DELETED

4 3 1 CONTROL SWITCH SELECTION

STARTING THE PROGRAM AT ANY OF THE POSSIBLE STARTING ADDRESSES WITH SW<07>=1 WILL RESULT IN ENTERING THE "CONTROL SWITCH SETTING" MODE THUS, ALLOWING THE OPERATOR TO SPECIFY THE DESIRED STATE OF "C SWR"

CONTROL SWITCH SELECTION EXAMPLES

EXAMPLE #1

SET SW<07>=0  
C SWR=000000 / 400

EXAMPLE #2

SET SW<07>=0  
C SWR=000000 / 220  
C SWR=000000 / 220

4 3 2 RH11 - RH70 ADDRESS SELECTION

STARTING THE PROGRAM AT 200 WILL RESULT IN AUTOMATIC SELECT OF THE DEFAULT VALUES OF BUS ADDRESS (RPCS1), VECTOR ADDRESS, AND PRIORITY LEVEL OF THE RH11-RH70 IF THE DEFAULT VAULE OF THE BUS ADDRESS DOES NOT RESPOND (TIMES OUT) WHEN ADDRESSED, AN ERROR IS REPORTED AFTER THE ERROR IS REPORTED ONE OF TWO COURSES OF ACTION

WILL BE TAKEN

- 1 IF THERE IS A MONITOR -- RETURN TO THE MONITOR
- 2 IF THERE ISN'T A MONITOR -- ASK FOR NEW ADDRESSES

STARTING THE PROGRAM AT 210 OR 214 ALLOWS THE OPERATOR TO CHANGE THE ADDRESS OF THE RH11 OR RH70 AND THE VECTOR ADDRESS.

THE PROGRAM ALLOWS THE ADDRESSES TO BE CHANGED ON WHEN THE PROGRAM IS FIRST STARTED STARTING ADDRESSES 210(8) AND 214(8) ARE TREATED AS ADDRESSES 200(8) OR 204(8) RESPECTIVELY

ADDRESS SELECTION EXAMPLES

EXAMPLE #1

RPCS1=176700 / 177200

EXAMPLE #2

RPCS1=176700 / 176300<CR>  
RHVEC=254 / 260<CR>  
RHPRIO=5 / 6

EXAMPLE #3

RPCS1=176700<CR>  
RHVEC=254 / 260

EXAMPLE #4

RH11/RPO4 FAILED TO RESPOND TO ADDRESSING  
RPCS1 ERR PC  
176300 XXXXXX  
RPCS1=176300 / 176700

EXAMPLE #5

RPCS1=176700 / 1776 67 6300<CR>  
RHVEC=254<CR>  
RHPRIO=5<CR>  
RPCS1=176300.

4 3 3 DRIVE AND PARAMETER SELECTION

STARTING THE PROGRAM AT 200 OR 210 WILL RESULT IN AUTOMATIC SELECTION OF THE DRIVES TO TEST AND THE TESTS TO RUN

STARTING THE PROGRAM AT 204 OR 214 ALLOWS THE OPERATOR TO SELECT THE DRIVE(S) TO BE TESTED, THE TESTS TO BE EXECUTED, AND THE PARAMETERS TO USE.

EACH TEST CONTAINS TWO SETS OF CYLINDER LIMIT PARAMETERS PARAMETERS 'LC' AND 'FC' ARE USED BY RPO4/5 DRIVES AND PARAMETERS 'LC' AND

'FC' ARE USED BY RPO6 DRIVES. THE PROGRAM DETERMINES WHICH DRIVE IS BEING TESTED AND SELECTS THE CORRECT SET OF CYLINDER LIMIT VALUES. IF THE PROGRAM IS BEING USED TO TEST A SUBSYSTEM WHICH CONTAINS BOTH RPO4/5 AND RPO6 DRIVES, THE OPERATOR MUST CHANGE BOTH SETS OF CYLINDER LIMITS IF THE TESTS ARE TO BE MODIFIED FOR ALL DRIVES TESTED.

#### 4 3 3 1 DRIVE AND PARAMETER SELECTION DESCRIPTION

THE FOLLOWING IS A TABLE OF TERMS USED BY THE PSI.

"R"	REPEATS (ITERATIONS)
"FC"	FIRST CYLINDER ADDRESS FOR RPO4/5'S
"LC"	LAST CYLINDER ADDRESS FOR RPO4/5'S
"FC'"	FIRST CYLINDER ADDRESS FOR RPO6'S
"LC'"	LAST CYLINDER ADDRESS FOR RPO6'S
"IC"	INCREMENT CYLINDER
"FT"	FIRST TRACK ADDRESS
"LT"	LAST TRACK ADDRESS
"IT"	INCREMENT TRACK
"FS"	FIRST SECTOR ADDRESS
"LS"	LAST SECTOR ADDRESS
"PAT"	PATTERN (USED FOR DATA TEST)
"WDX"	WORD OF PATTERN 0 WHERE X IS 1 TO 16
*"S"	ALL SEEK TESTS (TESTS 0 - 10)
*"T"	ALL TIMING TESTS (TESTS 12 - 15)
*"A"	ALL ADDRESS TESTS (TESTS 16 - 17)
*"D"	THE DATA TEST (TEST 20)
*"E"	THE EXERCISER (TEST 21)

\* USED BY THE OPERATOR TO SELECT TEST GROUPS  
NOTE ALL NUMBERS WILL BE IN DECIMAL EXCEPT FOR THE PATTERN (PAT) AND WORDS (WDX) SELECTION "PAT" WILL BE SELECTED BY A BIT (I E 001000(8)=PATTERN 9) AND "WDX" WILL BE IN OCTAL

#### SPECIAL CASES OF CONTROL CHARACTERS

IF < > IS TYPED WHILE A TEST IS OPEN FOR MODIFICATION (</>) AND OTHER TESTS IN THE "TEST COMMAND" STRING ARE TO BE MODIFIED, THE REMAINING TESTS WILL BE UNCHANGED

WHEN THE PROGRAM IS STARTED FROM LOCATION 200 OR 210, TESTS 0-10, 12-20 WILL BE RUN USING ALL AVAILABLE, ONLINE DRIVES IF THE OPERATOR WISHES TO SELECT THE DRIVES TO BE TESTED, THE TESTS TO BE PERFORMED, OR THE PARAMETERS TO BE USED, THE CONVERSATION MODE MAY BE ENTERED BY TYPING A 'CONTROL C' OR BY STARTING THE PROGRAM FROM EITHER LOCATION 204 OR 214

THE PROGRAM WILL THEN RESPOND WITH

DRIVE(S)=

THE FOLLOWING EXAMPLES ASSUME THAT THE OPERATOR IS TO TEST

DRIVE #3 USING TESTS 2 THRU 7 AND TEST 11 AND DOES NOT DESIRE TO CHANGE THE PARAMETERS (INITIAL CYLINDER ADDRESS, FINAL CYLINDER ADDRESS, ETC.) THE USER WOULD TYPE '3<CR>' WHICH SAYS 'THIS IS THE END OF DRIVE ENTRY'. THE PROGRAM WILL THEN REQUEST TEST NUMBERS.

THE TRANSACTION APPEARS AS FOLLOWS:

```
DRIVE(S)=3<CR>
TEST=
```

THE OPERATOR MAY NOW ENTER DESIRED TEST NUMBERS. IN THE EXAMPLE, HE WANTS TESTS 2 THRU 7 AND TEST 11 SO HE TYPES 2-7<,> (THE 'COMMA' SEPARATES ENTRIES), 11< ><CR> ('PERIOD' 'CARRIAGE RETURN' - END OF CHANGES, START TEST EXECUTION )

IT NOW LOOKS LIKE THIS

```
DRIVE(S)=3<CR>
TEST=2-7,11.<CR>
```

IN THE NEXT EXAMPLE, IT IS ASSUMED THAT THE OPERATOR WISHES TO TEST DRIVE 4 AND TO RUN TESTS 1 AND 3 THRU 11, MODIFYING THE PARAMETERS FOR TESTS 3 AND 10

THE TRANSACTION WOULD BE AS FOLLOWS

```
DRIVE(S)=4<CR>
TEST=
```

THE OPERATOR NOW ENTERS THE TEST NUMBERS THE TRANSACTION IS GIVEN BELOW

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
```

NOTICE THIS SAYS SELECT TEST 1, CONTINUE<,>, SELECT TEST 3, OPEN</>, SELECT TESTS 4-7, CONTINUE<,>, SELECT TEST 10, OPEN</>, SELECT TEST 11, END OF INPUT < >.

THE PROGRAM SCANS THE TEST NUMBER INPUT AND DETERMINES THAT THE PARAMETERS FOR TEST 3 AND TEST 10 ARE TO BE CHANGED THE OTHER TESTS WILL NOT BE ALTERED

(THE ENTIRE TRANSACTION IS REPEATED FOR CLARITY)

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
P=X /
```

,WHERE X IS ITERATION

THE NEW VALUE FOR 'R' MAY BE ENTERED TERMINATING THE ENTRY WITH A < > (PERIOD) WILL TERMINATE THE CHANGES FOR THIS TEST, TYPING A <CR> OR TERMINATING THE ENTRY WITH A <CR> WILL CAUSE THE PROGRAM TO MOVE TO THE NEXT PARAMETER

```
DRIVE(S)=4<CR>
```

TEST=1,3/4-7,10/11<CR>  
TEST 3  
R=1 / <CR> ,DO NOT ALTER-BUT CONTINUE  
FC=N / ,WHERE 'N' IS FIRST CYLINDER ADDRESS

IF THE OPERATOR DOES NOT WISH TO CHANGE 'FC', THE FOLLOWING OCCURS.

DRIVE(S)=4<CR>  
TEST=1,3/4-7,10/11 <CR>  
TEST 3  
R=1 / <CR> ,DO NOT ALTER THIS LINE BUT CONTINUE  
FC=0 / <CR> ,DO NOT ALTER THIS LINE BUT CONTINUE  
LC=410 /

THE PROGRAM RESPONDS WITH THE PREVIOUSLY ASSIGNED PARAMETER FOR LAST CYLINDER ADDRESS IN THIS CASE USING 410 AS THE EXAMPLE. THIS IS WHAT THE OPERATOR INTENDED TO MODIFY AND IS WHY TEST 3 WAS OPENED TO CHANGE THE VALUE TO '20', THE NEW VALUE IS TYPED FOLLOWED BY A 'PERIOD' TERMINATOR (< ><CR>)

THE TOTAL TRANSACTION AND RESPONSE

DRIVE(S)=4<CR>  
TEST=1,3/4-7,10/11<CR>  
TEST 3  
R=1 / <CR>  
FC=0 / <CR>  
LC= 410 / 20 <CR>  
TEST 10  
R=1 /

THE PROGRAM HAS LOADED TEST 3 WITH ITS NEW PARAMETERS AND THE PROGRAM IS WAITING FOR CHANGES TO TEST 10'S PARAMETERS

DRIVE(S)=4<CR>  
TEST=1,3/4-7,10/11<CR>  
TEST 3  
R=1 / <CR>  
FC=0 / <CR>  
LC= 410 / 20 <CR>  
TEST 10  
R=1 / 10 <CR>

THE OPERATOR TYPES THE NEW VALUE (10) AND TERMINATES THE ENTRY WITH A 'PERIOD' 'CARRIAGE RETURN'

THE PROGRAM NOW LOADS TEST 10 WITH THE NEW PARAMETERS (TEST 11 RETAINS THE PREVIOUSLY ASSIGNED PARAMETERS) AND RESPONDS WITH

DRIVE(S)=

SINCE THE USER DID NOT END THE CONVERSATION MODE WITH A 'PERIOD PERIOD', THE PROGRAM HAS LOOPED BACK TO THE BEGINNING LOOKING FOR MORE CHANGES THAT IS TO SAY, AFTER THE ENTRY FOR DRIVE SELECTION, A (<,><CR>) WILL CAUSE THE TEST MESSAGE TO BE REPEATED AND FURTHER CHANGES CAN BE MADE HOWEVER, AT SOME POINT IN ORDER TO EXECUTE

THE PROGRAM, A 'PERIOD PERIOD' MUST BE TYPED

IF A SINGLE 'PERIOD' IS TYPED WHILE DRIVE OR TEST NUMBERS ARE BEING ENTERED, THE PROGRAM WILL START EXECUTION IMMEDIATELY. A 'PERIOD PERIOD' MUST BE TYPED BEFORE THE PROGRAM WILL EXIT TEST PARAMETER CHANGE MODE TO GO TO EXECUTION.

4 3 3 2 DRIVE AND PARAMETER SELECTION EXAMPLES

EXAMPLE #1

-----  
DRIVE=4 <CR> ;SELECT DRIVE #4, TERMINATE AND  
;BEGIN EXECUTION USING PREVIOUSLY ASSIGNED  
;PARAMETERS

EXAMPLE #2

-----  
DRIVE=0<CR> ;SELECT DRIVE #0 AND MAKE CHANGES "", "  
TEST=1-5. <CR> ;RUN TEST 1 THRU 5 ONLY, USE DEFAULT  
;PARAMETERS AND TERMINATE AND EXECUTE. "

EXAMPLE #3

-----  
DRIVE=2<CR> ;SELECT DRIVE #2 AND MAKE CHANGES "", "  
TEST=1-5,6/7/10/<CR> ;RUN TEST 1-5 WITH DEFAULT PARAMETERS, OPEN  
TEST 6 ;TEST 6,7 AND 10 FOR CHANGES  
R=1 / <CR> ;LEAVE 'R' AS IS AND MOVE TO NEXT PARAMETER  
FC=0 / 10. <CR> ;SET 'FC' CYLINDER ADDRESS TO 10, END CHANGES  
;TO TEST 6

TEST 7  
R=1 / 50<CR> ;50 ITERATIONS, MOVE TO NEXT PARAMETER  
FC=0 / <CR> ;DO NOT CHANGE 'FC' CYLINDER ADDRESS BUT CONTINUE  
LC=410 / 50. <CR> ;TEST 10 IS STILL PENDING AND WILL BE  
;RETAIN ITS PRESENT PARAMETERS

EXAMPLE #4

-----  
DRIVE=0<CR> ;SELECT DRIVE #0 AND MAKE CHANGES  
TEST=S,E <CR> ;RUN ALL SEEK TESTS AND THE EXERCISER

EXAMPLE #5

-----  
DRIVE=1<CR>  
TEST=S/D<CR> ;RUN ALL SEEK TESTS (OPEN FOR CHANGES) AND  
TEST 0 ;THE DATA TEST (WITH DEFAULT PARAMETERS)  
R=10 / <CR> ;RUN WITH 10 ITERATIONS  
FC=0 / 10 <CR> ;CHANGE FIRST CYLINDER ADDRESS  
;AND START EXECUTION

; TESTS 1 - 10 WILL RETAIN THEIR PREVIOUSLY  
; ASSIGNED PARAMETERS.

EXAMPLE #6  
-----

```
DRIVE=1<CR>
TEST=S/<CR>           ; OPEN THE SEEK TESTS (TESTS 0-10)
TEST 0
  R=10 / 100 <CR>    ; CHANGE TO 100 ITERATIONS, TO TO THE NEXT TEST
TEST 1
  R=100 / 1000. <CR> ; CHANGE 'R' TO 1000 ITERATIONS, MOVE TO NEXT TEST
TEST 2
  R=1 / 10<CR>       ; CHANGE 'R' TO 10 ITERATIONS, GO TO NEXT PARAMETER
  FC=0 / 50<CR>      ; CHANGE 'FC' TO 50, GO TO NEXT PARAMETER
  LC=410 / 51. <CR>   ; CHANGE 'LC' TO 51, GO TO THE NEXT TEST
TEST 3
  R=1. <CR>          ; MOVE TO NEXT TEST
TEST 4
  R=1 . <CR>         ; USE TEST 4'S PARAMETERS AND START PROGRAM EXECUTION
```

EXAMPLE #7  
-----

```
DRIVE=1<CR>
TEST=D/<CR>           ; SELECT AND OPEN THE DATA TEST
TEST 20
  R=1 / 1000<CR>     ; DO 1000 ITERATION OF TEST PATTERN
  FC=0 / 10<CR>      ; #8 ON CYLINDER 10, TRACK 2, SECTOR 4
  LC=410 / 10<CR>
  FC'=0 / <CR>       ; RPO6 PARAMETER
  LC'=814 / <CR>     ; RPO6 PARAMETER
  IC=64 / 0<CR>
  FT=0 / 2<CR>
  LT=18 / 2<CR>
  IT=1 / <CR>
  FS=0 / 4<CR>
  LS=22 / 4<CR>
  PAT=177777 / 400 <CR> ; RUN WITH PATTERN #8
```

EXAMPLE #8  
-----

```
DRIVE=1<CR>           ; USE THE SAME PARAMETERS AS IN EXAMPLE
TEST=D/<CR>           ; #7, BUT ALSO SPECIFY A DATA PATTERN (PAT #0)
TEST 20
  R=1000 / <CR>
  FC=10 / <CR>
  LC=10 / <CR>
  FC'=0 / <CR>
  LC'=814 / <CR>
  IC=0 / <CR>
  FT=2 / <CR>
  LT=2 / <CR>
  IT=1 / <CR>
  FS=4 / <CR>
```

LS=4 / <CR>  
PAT=000400 / 401<CR> , RUN WITH PATTERNS #8 & #0 (O=OPERATOR INPUT)  
WD1=165555 / 125252<CR> ; FIRST WORD OF PATTERN 0  
WD2=133333 / 52525. <CR> , SECOND WORD OF PATTERN 0  
 , < . . > START EXECUTION

EXAMPLE #9  
-----

DRIVE=0,1,4<CR> , TEST DRIVES 0,1, AND 4 IN SEQUENCE  
TEST=0-5/<CR> , CHANGE TEST 5  
TEST 0  
R=10 / <CR>  
FC=0 / <CR>  
LC=410 / 1<CR> , CHANGE LAST CYLINDER FROM 410 TO 1  
FC'=0 / <CR>  
LC'=814 / 2 . <CR> , CHANGE THE LAST CYLINDER FOR ALL RPO6'S TO  
 , 2 START PROGRAM EXECUTION

5. SWITCH SETTINGS  
-----

5.1 OPERATIONAL SWITCH SETTINGS

WITH SW<15 0>=0 THE PROGRAM WILL PRINT OUT ON  
ERRORS AND CONTINUE IN TEST  
THE SWITCH SETTINGS ARE.

SW<15>=1. HALT ON ERROR  
SW<14>=1. LOOP ON TEST  
SW<13>=1. . INHIBIT ERROR TYPEOUTS  
SW<11>=1. . INHIBIT ITERATIONS  
SW<10>=1. . RING BELL ON ERROR  
SW<09>=1. LOOP ON ERROR  
SW<08>=1. PRINT ERROR MESSAGE ON LINE PRINTER  
SW<07>=1. READ CONTROL SWITCH SETTINGS FROM TTY  
SW<06>=1. . INHIBIT TIME REPORTS (TESTS 12-15)  
SW<05>=1. . REPORT ONE ERROR PER SECTOR (TESTS 16 & 17)  
SW<04>=1. . INHIBIT WRITES (TEST 20)  
SW<03>=1. . INHIBIT WRITE CHECKS (TEST 20)  
SW<02>=1. . INHIBIT READ AND SOFTWARE COMPARES (TEST 20)  
SW<01>=1. . INHIBIT SOFTWARE COMPARES (TEST 20)  
SW<00>=1. . PERFORM READ AFTER WRITE CHECK ERROR (TEST 20)

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I E AN 11/34)  
THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS  
NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER THE  
'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8) THE  
SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD  
ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G' THE PROGRAM WILL  
RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM  
IS AT A HIGHER PRIORITY PROCESSING AN RPO4/5/6 INTERRUPT THE  
'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE

TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED, 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

## 5 2 CONTROL SWITCH SETTINGS

THE CONTROL SWITCH SETTINGS ARE ENTERED THROUGH THE KEYBOARD

TO ENTER THE CONTROL SWITCH SETTING MODE PLACE SW<07>=1 BEFORE PRESSING START THEN UPON STARTING THE PROGRAM IT WILL TYPE THE PRESENT CONTENTS OF THE CONTROL SWITCH REGISTER (C SWR) AND WAIT FOR THE NEW SETTING TO BE INPUT THE INPUT STRING MUST CONSIST OF 1 TO 6 OCTAL DIGITS, TWO PERIODS ( ), AND A CARRIAGE RETURN.

THE C SWR SETTINGS ARE:

C SWR<15>=0 WRITE PACK BEFORE TESTING (TEST16)  
=1 INHIBIT WRITE PACK BEFORE TESTING (TEST16)  
C SWR<14>=0 .. NO STALL BETWEEN DRIVE FUNCTIONS  
=1 .. STALL AFTER EVERY DRIVE FUNCTION  
C SWR<13>=0 .. USE SPECIFIC STALL TIMES  
=1 .. USE RANDOM STALL TIMES  
C SWR<12>=0 .. NO INCREMENTING STALLS IN TEST4  
=1 .. PERFORM INCREMENTING STALLS IN TEST4  
C SWR<08>=0 .. DO IMPLIED SEEKS WITH DATA TRANSFERS  
=1 .. DO EXPLICIT SEEKS BEFORE DATA TRANSFERS  
C SWR<07>=0 .. DO READ HEADER AND DATA COMMANDS IN TESTS 0-6  
=1 .. DO EXPLICIT SEEK COMMANDS IN TESTS 0-6  
C SWR<06>=0 .. 60 HZ POWER SOURCE  
=1 .. 50 HZ POWER SOURCE  
C SWR<05>=0 .. ALLOW SOFTWARE TIMEOUTS(ENABLE WATCHDOG TIMER)  
=1 .. INHIBIT SOFTWARE TIMEOUTS(DISABLE WATCHDOG TIMER)  
C SWR<00>=0 .. OPERATE IN 22 SECTOR (16 BIT) MODE  
=1 .. OPERATE IN 20 SECTOR (18 BIT) MODE

THE DEFAULT CONDITION OF C SWR<15 00>=0

REFER TO 4 3 1 FOR C SWR SELECTION

## 6 ERRORS

-----

THERE ARE ANUMBER OF ERRORS THAT CAN OCCUR IN THIS PROGRAM.  
WHEN AN ERROR IS ENCOUNTERED, THE CALL TO THE ERROR ROUTINE  
IS MADE AND IF SW<13> IS NOT SET, AN ERROR MESSAGE PERTAINING  
TO THE ERROR WILL BE TYPED EACH ERROR TYPEOUT WILL CONTAIN  
THE FOLLOWING:

1. AN ERROR MESSAGE
2. A DATA HEADER
3. A DATA STRING

REFER TO THE FOLLOWING SECTION FOR THE DIFFERENT ERRORS  
THAT CAN OCCUR

## 6.1 ERROR TYPES

THE ERRORS THAT OCCUR IN THIS PROGRAM FALL INTO THREE  
(3) CATEGORIES DEFINED AND EXPLAINED AS FOLLOWS

### 6.1.1 DRIVER ERROR

THESE ERRORS WILL BE DETECTED BY THE RH11/RPO4/5/6 DRIVER  
THERE ARE TWO CLASSES OF DRIVER ERRORS; THOSE THAT  
CAN NOT BE IDENTIFIED IN A MANNER THAT ALLOWS THE  
INFORMATION TO BE RETURNED TO A "DATA PARAMETER BLOCK"  
(DPB) AND THOSE THAT CAN. THE FIRST CLASS WILL BE  
REPORTED BY ERROR CALLS (EMT'S) 1-5 WITHIN THE DRIVER  
THE SECOND CLASS WILL PASS THE ERROR CODES TO THE  
STATUS/ERROR WORD (DPB+16) OF THE PROPER DPB

### 6.1.2 NON-FATAL ERRORS

THESE ERRORS WILL BE DUE TO "DISK" OR "DATA" FAILURES  
WHICH WILL BE REPORTED AS THEY OCCUR AFTER REPORTING  
THE ERROR THE PROGRAM WILL CONTINUE TESTING

### 6.1.3 FATAL ERRORS

THIS TYPE OF ERROR WILL BE THE RESULT OF ANY KIND  
OF ERROR THAT INHIBITS THE PROGRAM FROM TESTING THE DISK

THIS ERROR WILL BE REPORTED WHEN IT OCCURS, THEN THE PROGRAM  
WILL ABORT THE TEST AND GO TO THE END OF PROGRAM

## 6.2 ERROR RECOVERY

### 6.2.1 PRETEST ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED THEN DEPENDING  
ON HOW THE PROGRAM WAS STARTED IT WILL ASK FOR THE DRIVES AND  
ADDRESSES FOR TESTING OR RETURN TO MONITOR

### 6.2.2 NON-FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED AND  
THE PROGRAM WILL CONTINUE IN TEST

6 2 3 FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED. THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

7 RESTRICTIONS  
-----

THE PROGRAM WILL TEST THE DRIVES IN EITHER 16 BIT MODE OR IN 18 BIT MODE DEPENDING ON THE SETTING OF 'S.SWR<00>'. IF 'C.SWR<00>' IS 0, ALL OF THE DRIVES WILL BE TESTED IN 16 BIT MODE, IF 'C.SWR<00>' IS 1, ALL OF THE DRIVES WILL BE TESTED IN 18 BIT MODE. THE PROGRAM HAS NO PROVISIONS FOR TESTING DRIVES WITH INTERMIXED PACKS OR TESTING BOTH 16 BIT MODE AND 18 BIT MODE DRIVES ON THE SAME SYSTEM. ACT11 AUTOMATIC MODE ASSUMES 16 BIT MODE.

BEFORE THE PROGRAM IS STARTED, PROPERLY FORMATTED PACKS MUST BE MOUNTED ON THE DRIVES WHICH WILL BE TESTED. THE PROGRAM ASSUMES A PROPERLY FORMATTED PACK. THE FORMAT OF THE PACK IS NOT ALTERED BY THE PROGRAM.

8 MISCELLANEOUS  
-----

8 1 EXECUTION TIME

THE PROGRAM REQUIRES APPROXIMATELY 15 MINUTES TO MAKE ONE PASS WITH RPO4/5 DRIVES AND APPROXIMATELY 16 5 MINUTES TO A PASS WITH RPO6 DRIVES. THIS ASSUMES THE DEFAULT TEST SEQUENCE (TESTS 0-10, 12-20) AND DEFAULT TEST PARAMETERS.

8 2 STACK POINTER

THE STACK POINTER IS INITIALLY SET TO 1100

8 3 TIMING TESTS (TESTS 12-15) PRINTOUTS

AT THE COMPLETION OF EACH OF THE TIMING TESTS THE TIME OF THE MINIMUM SEEK, MAXIMUM SEEK, AND THE AVERAGE OF ALL OF THE SEEKS PERFORMED ARE TYPED ON THE TTY. THE NUMBER OF SEEKS THAT HAD TIMES BELOW THE MINIMUM TIME ALLOWED WILL BE TYPED ON THE SAME LINE AS THE MINIMUM TIME. THE NUMBER ABOVE THE MAXIMUM WILL BE TYPED ON THE SAME LINE AS THE MAXIMUM TIME, AND THE TOTAL NUMBER OF SEEKS PERFORMED WILL BE ON THE SAME LINE AS THE AVERAGE.

NOTE THE PROGRAM STALLS FOR 2 MILLISECONDS BETWEEN SEEK ORDERS. THIS STALL TIME IS NOT INCLUDED IN THE CALCULATED SEEK TIMES. THE 2 MILLISECOND STALL BETWEEN SEEK ORDERS IS SPECIFIED BY

THE RPO4 VENDOR. THE SEEK TIMES SPECIFIED FOR THE RPO4  
ARE POSITIONER MOVEMENT TIMES ONLY AND ARE NOT A MEASUREMENT  
OF EFFECTIVE SEEK TIME.

8 3 1 TIMING TOLERANCES

1 TEST 12 -- ROTATIONAL SPEED TIMES

60 HZ  
MINIMUM=16340 US  
MAXIMUM=17000 US  
NOMINAL=16670 US

50 HZ  
MINIMUM=16250 US  
MAXIMUM=17090 US  
NOMINAL=16670 US

2 TEST 13 -- ONE CYLINDER SEEK TIMES

MAXIMUM=10000 US  
NOMINAL=7000 US

3 TEST 14 -- ACCESS TIME MEASUREMENT

MAXIMUM=30000 US  
NOMINAL=28000 US

4 TEST 15 -- MAXIMUM SEEK TIMES

MAXIMUM=52000 US  
NOMINAL=50000 US

8 3 2 TIMING TESTS PRINTOUT EXAMPLES

EXAMPLE #1

-----

ROTATIONAL SPEED TIMES

MIN=16670 US  
MAX=16690 US  
AVG=16680 US 10 SEEKS TIMED

ONE CYLINDER SEEK TIMES

\* FORWARD  
MIN=5350 US  
MAX=6920 US  
AVG=5550 US 409 SEEKS TIMED  
\* REVERSE  
MIN=5140 US  
MAX=5960 US  
AVG=5430 US 410 SEEKS TIMED

ACCESS TIME MEASUREMENTS

\* FORWARD

MIN=27770 US  
MAX=28640 US  
AVG=28230 US 128 SEEKS TIMED  
\* REVERSE  
MIN=27990 US  
MAX=28550 US  
AVG=28220 US 128 SEEKS TIMED

MAXIMUM SEEK TIMES  
\* FORWARD  
MIN=49990 US  
MAX=51980 US  
AVG=51010 US 128 SEEKS TIMED  
\* REVERSE  
MIN=48120 US  
MAX=50650 US  
AVG=49340 US 128 SEEKS TIMED

EXAMPLE #2  
-----

ROTATIONAL SPEED TIMES  
MIN=16670 US  
MAX=16690 US  
AVG=16680 US 10 SEEKS TIMED

ONE CYLINDER SEEK TIMES  
\* FORWARD  
MIN=5470 US  
MAX=10940 US 3 ABOVE THE MAXIMUM OF 10000 US  
AVG=5830 US 409 SEEKS TIMED  
\* REVERSE  
MIN=5040 US  
MAX=5970 US  
AVG=5330 US 410 SEEKS TIMED

ACCESS TIME MEASUREMENTS  
\* FORWARD  
MIN=29730 US  
MAX=31620 US 73 ABOVE THE MAXIMUM OF 30000 US  
AVG=30320 US 128 SEEKS TIMED  
\* REVERSE  
MIN=28620  
MAX=31230 US 128 ABOVE THE MAXIMUM OF 30000 US  
AVG=30800 US 128 SEEKS TIMED

MAXIMUM SEEK TIMES  
\* FORWARD  
MIN=53510 US  
MAX=54240 US 128 ABOVE THE MAXIMUM OF 52000 US  
AVG=54020 US 128 SEEKS TIMED  
\* REVERSE  
MIN=52050 US  
MAX=54550 US 128 ABOVE THE MAXIMUM OF 52000 US  
AVG=52210 US 128 SEEKS TIMED

8 4 END OF TEST

WITH ALL SWITCHES ON A "0" AN "END OF PASS" MESSAGE WILL BE TYPED AT THE COMPLETION OF TESTING A DRIVE AND THE "END OF TEST" TYPEOUT WILL OCCUR WHEN ALL DRIVES HAVE BEEN TESTED

9 PROGRAM DESCRIPTION  
-----

THIS PROGRAM CONTAINS NINETEEN TESTS NUMBERED 0-22 IN OCTAL TESTS 0-7 & 11 WILL READ THE CYLINDER, TRACK, AND SECTOR INFORMATION FROM THE HEADER, USING A "READ HEADER AND DATA" COMMAND, AND THEN CHECK THE INFORMATION FOR VALIDITY. THUS, INSURING THE SEEK OPERATION FUNCTIONS PROPERLY. TESTS 12-15 WILL MEASURE THE ROTATIONAL SPEED, THE ONE CYLINDER SEEK, THE ACCESS TIME, AND THE MAXIMUM SEEK TIMES TO ENSURE THEY ARE ALL WITHIN THE TOLERANCES ALLOWED. TEST 16 AND 17 ENSURES THE SECTOR AND TRACK ADDRESSING CIRCUITRY WORKS PROPERLY. TEST 20 VERIFIES THE DATA STORAGE AND RETRIEVAL CAPABILITIES ARE FUNCTIONAL AND TEST 21 WILL STRESS AND CHECK THE READ/WRITE AND SERVO SYSTEMS.

THE PROGRAM WILL START BY IDENTIFYING ITSELF AND DETERMINING ALL DRIVES THAT ARE AVAILABLE FOR TESTING. THEN BEGINNING WITH THE LOWEST NUMERICAL DRIVE AND PROCEEDING IN SEQUENTIAL ORDER ALL OF THE DRIVES WILL BE TESTED. ONE PASS THROUGH THE TEST SEQUENCE (TESTS 0-10, 12-20) WILL BE PERFORMED ON EACH DRIVE BEFORE MOVING TO THE NEXT DRIVE IN SEQUENCE. DRIVE TO BE TESTED WILL BE TYPED AT THE BEGINNING OF EACH PASS, AN "END OF PASS" MESSAGE WILL BE TYPED AT THE COMPLETION OF EACH PASS, AND AN "END OF TEST" MESSAGE WILL BE TYPED AFTER TESTING ALL DRIVES

REFER TO THE FOLLOWING SECTIONS FOR DETAILED DESCRIPTIONS OF EACH TEST

9.1 TEST 0 - RECAL/SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE COMMAND CYCLE AND THEN SEEK FORWARD TO CYLINDER "LC" AT THE COMPLETION OF BOTH COMMANDS, STATUS INDICATIONS ARE CHECKED TO ENSURE NO ERRORS OCCURRED

THE PARAMETEPS USED BY THE TEST ARE GIVEN BELOW

R	-	200
LC	-	410
LC'	-	814
FT	-	0
FS	-	0

9 2 TEST 1 - SEEK/SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK CYCLE TO "LC", "LT", "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO "FC", "FT", "FS" AT THE COMPLETION OF EACH SEEK, THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW

R	-	100
FC	-	0
LC	-	128
FC'	-	0
LC'	-	256
IC	-	0
FT	-	0
LT	-	0
FS	-	0
LS	-	0

9 3 TEST 2 - INCREMENTAL SEEK TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC" WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS "LC" REVERSE SEEK CYCLES ARE INITIATED, STARTING AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC" UNTIL "NC" IS LESS THAN "FC" AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	1
FT	-	0
FS	-	0

9 4 TEST 3 - STEPPING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0, 1, 2, 4, 8, 16, 32, 64, 128, AND 256 AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW

R	-	8
FC	-	0
LC	-	256
FC'	-	0

LC'	-	256
IC	-	1
FT	-	0
FS	-	0

9 5 TEST 4 - OSCILLATING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK TO "FC" "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC" AT THE COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST.

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	1
FT	-	0
FS	-	0

9 6 TEST 5 - CONVERGING/DIVERGING SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE SEEKS FROM "NC1" AND "NC2" RESPECTIVELY, "NC1" WILL BE INCREMENTED BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS LESS THAN THE INITIAL VALUE OF "NC1" AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION "NC1" AND "NC2" DEFAULT TO "FC" AND "LC" RESPECTIVELY

THE FOLLOWING PARAMETERS ARE USED BY THE TEST

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	1
FT	-	0
FS	-	0

9 7 TEST 6 - SERVO ADDRESSING LOGIC NOISE GENERATOR TEST

IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5 NOW "NC" IS UPDATED BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS EXCEEDED BY ANY OF THE ABOVE VALUES THE INITIAL VALUE OF "NC" IS "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION

THE FOLLOWING PARAMETERS ARE USED BY THE TEST

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	1
FT	-	0
FS	-	0

9 8 TEST 7 - RANDOM SEEK TEST

THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC' 'LC' AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK. THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION OF POSITIONING OCCURS USING EACH HEAD TRACK ADDRESSES ARE INCREMENTED BETWEEN PARAMTERS 'FT' AND 'LT'.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST

R	-	5000
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
FT	-	0
LT	-	18

9 9 TEST 10 - SERVO SETTLE DOWN TEST

THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE. RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC' ('NC1' STARTS AT VALUE 'FC'). AT THE COMPLETION OF 1000 (10) SEEKS, 'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED. THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.

WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD REGISTER (RPLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO POSITION. THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND FOR THAT SECTOR. IF THE DRIVE'S POSITIONER HAS NOT SETTLED DOWN OR IF THE POSITIONER IS NOT ON CYLINDER (IF THE DRIVE IS AN RPO4, THE OFF CYLINDER CONDITION MUST LAST FOR AT LEAST 800 US), THE DRIVE WILL REPORT A 'WRU' ERROR (RPO5/6'S MAY ALSO REPORT 'NHS' ERROR UNDER ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PCAK WITH MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.

THIS TEST USES THE EXTENTION BITS IN THE LOOK-AHEAD REGISTER TO DETERMINE WHETHER OR NOT IT CAN PICK UP THE SECTOR ROTATING INTO POSITION. THE TEST IS OPTIMIZED SUCH THAT IF THE DRIVE SIGNALS SEEK DONE WITHIN THE FIRST 80% OF THE SECTOR CURRENTLY UNDER THE HEAD, THE TEST WILL TRY TO ADDRESS THE NEXT SECTOR. BASED ON OBSERVATION, THE PROGRAM IS ABLE TO START THE OPERATION WITHOUT LOSING A REVOLUTION MOST OF THE TIME.

J 2  
THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS THE NECESSARY TIME DEPENDENT PARAMETERS OCCUR WITHIN THE REQUIRED TIME RANGE FREQUENTLY ENOUGH TO PERMIT THIS TEST TO BE EFFECTIVE

THE FOLLOWING PARAMETERS ARE USED BY THE TEST

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	100
FT	-	0

9 10 TEST 11 - ALL SEEKS TEST

THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER TO ALL OTHER CYLINDERS.

BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC'. THE BEGINNING CYLINDER ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC' THE SEQUENCE CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED

THE FOLLOWING PARAMETERS ARE USED BY THIS TEST

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	1
FT	-	0
FS	-	0

9 11 TEST 12 - ROTATIONAL SPEED TIMING TEST

THIS TEST WILL START A SEARCH TO CYLINDER 0, TRACK 0, SECTOR 0 AS SOON AS THE INTERRUPT OCCURS, THE GO BIT IS SET AGAIN AND THE OPERATION IS TIMED THIS PROCEDURE IS REPEATED 10 TIMES THEN THE AVERAGE TIME IS CALCULATED AND CHECKED TO ENSURE IT IS WITHIN TOLERANCE

16 67 MS/REV + OR - 2% IF 60HZ  
16 67 MS/REV + OR - 2 5% IF 50HZ

THE FOLLOWING PARAMETERS ARE USED BY THE TEST

R	-	1
FC	-	0
FC'	-	0
FT	-	0
FS	-	0

9 12 TEST 13 - ONE CYLINDER SEEK TIMING TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC'. THE TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK THE TIME MUST BE LESS THAN 10MS.

THE TEST USES THE FOLLOWING PARAMETERS.

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814

9 13 TEST 14 - ACCESS TIME MEASUREMENT

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE ACCESS TIME MEASUREMENT. THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256 SEEKS). THE AVERAGE ACCESS TIME MUST BE LESS THAN 30 MS CYLINDER 'LC' DEFAULTS TO 136 (10) FOR AN RPO4/5 OR TO 255 (10) FOR AN RPO6.

THE TEST USES THE FOLLOWING PARAMETERS

R	-	1
FC	-	0
LC	-	136
FC'	-	0
LC'	-	255

9 14 TEST 15 - MAXIMUM SEEK TIMING TEST

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE MAXIMUM SEEK TIME THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256 SEEKS). THE MAXIMUM SEEK TIME MUST BE LESS THAN 54 MS 'LC' DEFAULTS TO 410 (10) FOR RPO4/5'S AND TO 814 (10) FOR RPO6'S

THE TEST USES THE FOLLOWING PARAMETERS

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814

9 15 TEST 16 - SECTOR ADDRESSING TEST

THIS TEST WRITES DATA INTO ALL SECTORS OF TRACK "FT". THE DATA WILL BE 256 WORDS OF THE SECTOR ADDRESS OF THE SECTOR BEING WRITTEN. A WRITE CHECK IS PERFORMED, THE BUFFER IS CLEARED (TO 177400) AND THE DATA IS READ AND COMPARED. THEN SECTOR 0 IS REWRITTEN AND SECTORS 0 - 21 ARE WRITE CHECKED. THEN SECTOR 1 IS REWRITTEN AND SECTORS 0 - 21 ARE WRITE CHECKED. THIS REWRITE AND WRITE CHECK PROCEDURE IS CONTINUED UP THROUGH REWRITE SECTOR 21 AND WRITE CHECK SECTORS 0-21.

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
FC'	-	0
FT	-	0

9 16 TEST 17 - TRACK ADDRESSING TEST

THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES IN CYLINDER "FC" SECTOR "FS" OF EVERY TRACK WITH EACH TRACK GETTING ITS OWN TRACK ADDRESS. A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO INSURE THE DATA IS VALID. THEN TRACK 0 IS REWRITTEN AND TRACK 1 THROUGH TRACK 18 IS WRITE CHECKED. THEN TRACK 1 IS REWRITTEN AND TRACK 2 THROUGH TRACK 18 IS WRITE CHECKED THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING TRACK 17 AND WRITE CHECKING TRACK 18

THE TEST USES THE FOLLOWING PARAMETERS

R	-	1
FC	-	0
FC'	-	0
FS	-	0

9 17 TEST 20 - DATA TEST

THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS "FC" THROUGH "LC" BY THE INCREMENT "IC" USING THE DATA PATTERNS SPECIFIED THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER

- 1 SET "NT" TO "FT" THEN REPEAT 2-4 UNTIL "NT" > "LT"
- 2 WRITE THEN WRITE CHECK "FS" THROUGH "LS" OF TRACK "NT"
- 3 READ THEN SOFTWARE COMPARE "FS" THROUGH "LS" OF TRACK "NT"
- 4 INCREMENT "NT" BY "IT"
- 5 REPEAT STEPS 1-4 FOR EACH DATA PATTERN
- 6 REPEAT STEPS 1-5 FOR "FC" THROUGH "LC" ADVANCING BY "IC"

IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS FATAL AND NO READ OCCURS.

FS DEFAULTS TO 1 AND LS DEFAULTS TO 0  
PAT DEFAULTS TO 177777 (ALL POSSIBLE PATTERNS)  
THE POSSIBLE PATTERNS ARE

PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
165555	000001	177776	000000	000000	052525	007417	026455
133333	000003	177774	000000	010421	052525	007417	026455
165555	000007	177770	000000	021042	052525	007417	026455
133333	000017	177760	177777	031463	125252	170360	151322
165555	000037	177740	177777	042104	125252	170360	151322
133333	000077	177700	177777	052525	125252	170360	151322
165555	000177	177600	000000	063146	052525	007417	026455
133333	000377	177400	000000	073567	052525	007417	026455
165555	000777	177000	177777	104210	125252	170360	151322
133333	001777	176000	177777	114631	125252	170360	151322
165555	003777	174000	000000	125252	052525	007417	026455
133333	007777	170000	177777	135673	125252	170360	151322
165555	017777	160000	000000	146314	052525	007417	026455
133333	037777	140000	177777	156735	125252	170360	151322
165555	077777	100000	000000	167356	052525	007417	026455
133333	177777	000000	177777	177777	125252	170360	151322

PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
165555	000001	177776	172666	077777	153333	000000	177777
133333	000002	177775	155555	137777	066667	177777	000000
165555	000004	177773	172666	157777	153333	177777	000000
133333	000010	177767	155555	167777	066667	177777	000000
165555	000020	177757	172666	173777	153333	177777	000000
133333	000040	177737	155555	175777	066667	177777	000000
165555	000100	177677	172666	176777	153333	177777	000000
133333	000200	177577	155555	177377	066667	177777	000000
165555	000400	177377	172666	177577	153333	177777	000000
133333	001000	176777	155555	177677	066667	177777	000000
165555	002000	175777	172666	177737	153333	177777	000000
133333	004000	173777	155555	177757	066667	177777	000000
165555	010000	167777	172666	177767	153333	177777	000000
133333	020000	157777	155555	177773	066667	177777	000000
165555	040000	137777	172666	177775	153333	177777	000000
133333	100000	077777	155555	177776	066667	177777	000000

THE TEST USES THE FOLLOWING PARAMETERS

R	-	1
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814
IC	-	64
FT	-	0
LT	-	18
IT	-	1
FS	-	1
LS	-	0
PAT	-	177777

N 2  
STARTING AT "FC" AND GOING THROUGH "LC" THE DISK PACK IS WRITTEN WITH A RANDOM PATTERN THE FIRST TWO WORDS OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR FOR THAT SECTOR THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE "R" TIMES "R" DEFAULTS TO 20,000.

- 1) GENERATE A RANDOM ADDRESS
- 2) WRITE A RANDOM PATTERN AT THE ADDRESS GENERATED IN 1.
- 3) GENERATE A RANDOM ADDRESS
- 4) READ THE SECTOR AT THE ADDRESS GENERATED IN 3.
- 5) DO A SOFTWARE CHECK OF THE DATA READ IN 4
- 6) DO A WRITE CHECK OF THE DATA WRITTEN IN 2
- 7) GENERATE A RANDOM ADDRESS
- 8) READ THE SECTOR AT THE ADDRESS GENERATED IN 7.
- 9) DO A SOFTWARE CHECK OF THE DATA READ IN 8
- 10) DO A WRITE CHECK OF THE DATA WRITTEN IN 2

THE TEST USES THE FOLLOWING PARAMETERS

R	-	20000
FC	-	0
LC	-	410
FC'	-	0
LC'	-	814

9 19 TEST 22 - RPO4 ACCESS TIME ADJUSTMENT TEST

THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 136 TO ALLOW THE OPERATOR TO ADJUST THE ACCESS TIME ON AN RPO4 USING THE DDU THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS SO THAT THE ACCESS TIME INDICATORS ON THE DDU MAY BE OBSERVED

THE TEST USES THE FOLLOWING PARAMETERS

R	-	5000
FC	-	0
LC	-	136
FC'	-	0
LC'	-	255

10 PROGRAM LISTING  
-----

1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448  
1449  
1450  
1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459  
1460  
1461  
1462  
1463  
1464  
1465  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475  
1476  
1477  
1478  
1479

```

TITLE MD-11-DZRJA-B RPO4/5/6 MECHANICAL AND READ/WRITE TEST
; *COPYRIGHT (C) 1976, 1977
; *DIGITAL EQUIPMENT CORP.
; *MAYNARD, MASS. 01754
; *
; *PROGRAM BY C. HESS
; *
; *THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
; *PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977
; *

```

SBTTL CONTROL SWITCH SETTINGS

```

; *
; * SWITCH STATE USE
; * -----
; * 15 0 WRITE PACK BEFORE TESTING (TEST 21)
; * 1 1 INHIBIT WRITING PACK BEFORE TESTING (TEST 21)
; * 14 0 NO STALL BETWEEN DRIVE FUNCTIONS
; * 1 1 STALL AFTER EVERY DRIVE FUNCTION
; * 13 0 USE SPECIFIC STALL TIME
; * 1 1 USE RANDOM STALL
; * 12 0 NO INCREMENTING STALL IN TEST 4
; * 1 1 DO INCREMENTING STALL IN TEST 4
; * 8 0 DO IMPLIED SEEKS WITH DATA TRANSFERS
; * 1 1 DO EXPLICIT SEEKS BEFORE DATA TRANSFERS
; * 7 0 DO "READ HEADER AND DATA" IN TESTS 0-11
; * 1 1 DO EXPLICIT SEEKS IN TESTS 0-11
; * 6 0 60 HZ
; * 1 1 50 HZ
; * 5 0 RUN WATCHDOG TIMER
; * 1 1 INHIBIT WATCHDOG TIMER
; * 0 0 TEST DRIVE(S) IN 22 SECTOR (16 BIT) MODE
; * 1 1 TEST DRIVE(S) IN 20 SECTOR (18 BIT) MODE

```

SBTTL OPERATIONAL SWITCH SETTINGS

```

; *
; * SWITCH USE
; * -----
; * 15 HALT ON ERROR
; * 14 LOOP ON TEST
; * 13 INHIBIT ERROR TYPEOUTS
; * 10 BELL ON ERROR
; * 9 LOOP ON ERROR
; * 8 PRINT ERROR MESSAGE ON LINE PRINTER
; * 7 READ CONTROL SWITCH SETTINGS FROM TTY
; * 6 INHIBIT TIME REPORTS (TESTS 12-15)
; * 5 REPORT ONE ERROR PER SECTOR (TESTS 16 & 17)
; * 4 INHIBIT WRITES (TEST 15)
; * 3 INHIBIT WRITE CHECKS (TEST 20)
; * 2 INHIBIT READ AND SOFTWARE COMPARES (TEST 20)
; * 1 INHIBIT SOFTWARE COMPARES (TEST 20)
; * 0 PERFORM READ AFTER WRITE CHECK ERROR (TEST 20)

```

SBTTL TRAP CATCHER

```

1480
1481      000000      =0
1482      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1483      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1484      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1485      000174      =174
1486 000174 000000  DISPREG: .WORD 0      ;; SOFTWARE DISPLAY REGISTER
1487 000176 000000  SWREG:   .WORD 0      ;; SOFTWARE SWITCH REGISTER
1488
1489      .SBTTL  ACT11 HOOKS
1490
1491      ;*****
1492      ;HOOKS REQUIRED BY ACT11
1493      000200      $SVPC=      ;SAVE PC
1494      000046      =46
1495 000046 017614  SENDAD      ;; 1)SET LOC.46 TO ADDRESS OF SENDAD IN $EOP
1496      000052      =52
1497 000052 000000  .WORD 0      ;; 2)SET LOC 52 TO ZERO
1498      000200      = $SVPC      ;; RESTORE PC
1499
1500      SBTTL  STARTING ADDRESSES
1501      000200      =200
1502      ;*200 = NORMAL START
1503 000200 000137 004636  JMP      @#START1
1504      ;*204 = SELECT OPERATING PARAMETERS
1505 000204 000137 004660  JMP      @#START2
1506      ;*210 = SELECT RH11/RPO4/5/6 ADDRESSES
1507 000210 000137 004626  JMP      @#START3
1508      ;*214 = COMBINATION OF 204 AND 210
1509 000214 000137 004650  JMP      @#START4
1510
1511      SBTTL  BASIC DEFINITIONS
1512
1513      ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
1514      001100      STACK= 1100
1515      .EQUIV  EMT,ERROR      ;; BASIC DEFINITION OF ERROR CALL
1516      .EQUIV  IOT,SCOPE      ;; BASIC DEFINITION OF SCOPE CALL
1517
1518      ;*MISCELLANEOUS DEFINITIONS
1519      000011      HT= 11      ;; CODE FOR HORIZONTAL TAB
1520      000012      LF= 12      ;; CODE FOR LINE FEED
1521      000015      CR= 15      ;; CODE FOR CARRIAGE RETURN
1522      000200      CRLF= 200    ;; CODE FOR CARRIAGE RETURN-LINE FEED
1523      177776      PS= 177776  ;; PROCESSOR STATUS WORD
1524      .EQUIV  PS,PSW
1525      177774      STKLMT= 177774  ;; STACK LIMIT REGISTER
1526      177772      PIRQ= 177772  ;; PROGRAM INTERRUPT REQUEST REGISTER
1527      177570      DSWR= 177570  ;; HARDWARE SWITCH REGISTER
1528      177570      DDISP= 177570  ;; HARDWARE DISPLAY REGISTER
1529
1530      ;*GENERAL PURPOSE REGISTER DEFINITIONS
1531      000000      R0= %0      ;; GENERAL REGISTER
1532      000001      R1= %1      ;; GENERAL REGISTER
1533      000002      R2= %2      ;; GENERAL REGISTER
1534      000003      R3= %3      ;; GENERAL REGISTER
1535      000004      R4= %4      ;; GENERAL REGISTER
    
```

1536	000.05	R5=	%5	:: GENERAL REGISTER
1537	000006	R6=	%6	:: GENERAL REGISTER
1538	000007	R7=	%7	:: GENERAL REGISTER
1539	000006	SP=	%6	:: STACK POINTER
1540	000007	PC=	%7	:: PROGRAM COUNTER

1541

1542 ; \*PRIORITY LEVEL DEFINITIONS

1543	000000	PRO=	0	:: PRIORITY LEVEL 0
1544	000040	PR1=	40	:: PRIORITY LEVEL 1
1545	000100	PR2=	100	:: PRIORITY LEVEL 2
1546	000140	PR3=	140	:: PRIORITY LEVEL 3
1547	000200	PR4=	200	:: PRIORITY LEVEL 4
1548	000240	PR5=	240	:: PRIORITY LEVEL 5
1549	000300	PR6=	300	:: PRIORITY LEVEL 6
1550	000340	PR7=	340	:: PRIORITY LEVEL 7

1551

1552 ; \*"SWITCH REGISTER" SWITCH DEFINITIONS

1553	100000	SW15=	100000
1554	040000	SW14=	40000
1555	020000	SW13=	20000
1556	010000	SW12=	10000
1557	004000	SW11=	4000
1558	002000	SW10=	2000
1559	001000	SW09=	1000
1560	000400	SW08=	400
1561	000200	SW07=	200
1562	000100	SW06=	100
1563	000040	SW05=	40
1564	000020	SW04=	20
1565	000010	SW03=	10
1566	000004	SW02=	4
1567	000002	SW01=	2
1568	000001	SW00=	1
1569		EQUIV	SW09, SW9
1570		EQUIV	SW08, SW8
1571		EQUIV	SW07, SW7
1572		EQUIV	SW06, SW6
1573		EQUIV	SW05, SW5
1574		EQUIV	SW04, SW4
1575		EQUIV	SW03, SW3
1576		EQUIV	SW02, SW2
1577		EQUIV	SW01, SW1
1578		EQUIV	SW00, SW0

1579

1580 ; \*DATA BIT DEFINITIONS (BIT00 TO BIT15)

1581	100000	BIT15=	100000
1582	040000	BIT14=	40000
1583	020000	BIT13=	20000
1584	010000	BIT12=	10000
1585	004000	BIT11=	4000
1586	002000	BIT10=	2000
1587	001000	BIT09=	1000
1588	000400	BIT08=	400
1589	000200	BIT07=	200
1590	000100	BIT06=	100
1591	000040	BIT05=	40

```

1592      000020      BIT04= 20
1593      000010      BIT03= 10
1594      000004      BIT02= 4
1595      000002      BIT01= 2
1596      000001      BIT00= 1
1597      .EQUIV BIT09,BIT9
1598      .EQUIV BIT08,BIT8
1599      .EQUIV BIT07,BIT7
1600      .EQUIV BIT06,BIT6
1601      .EQUIV BIT05,BIT5
1602      .EQUIV BIT04,BIT4
1603      .EQUIV BIT03,BIT3
1604      .EQUIV BIT02,BIT2
1605      .EQUIV BIT01,BIT1
1606      .EQUIV BIT00,BIT0
1607
1608      . *BASIC "CPU" TRAP VECTOR ADDRESSES
1609      000004      ERRVEC= 4      ., TIME OUT AND OTHER ERRORS
1610      000010      RESVEC= 10     ., RESERVED AND ILLEGAL INSTRUCTIONS
1611      000014      TBITVEC=14     ., "T" BIT
1612      000014      TRTVEC= 14     ., TRACE TRAP
1613      000014      BPTVEC= 14     ., BREAKPOINT TRAP (BPT)
1614      000020      IOTVEC= 20     ., INPUT/OUTPUT TRAP (IOT) **SCOPE**
1615      000024      PWRVEC= 24     ., POWER FAIL
1616      000030      EMTVEC= 30     ., EMULATOR TRAP (EMT) **ERROR**
1617      000034      TRAPVEC=34     ., "TRAP" TRAP
1618      000060      TKVEC= 60      ., TTY KEYBOARD VECTOR
1619      000064      TPVEC= 64      ., TTY PRINTER VECTOR
1620      000240      PIRQVEC=240    ., PROGRAM INTERRUPT REQUEST VECTOR
1621      ., *****
1622
1623      SBTTL RH11 REGISTERS
1624
1625      ., *****
1626
1627      . CONTROL AND STATUS REGISTER 1 (RPCS1)
1628
1629      000100      IE= 100      ., INTERRUPT ENABLE (BIT #6)
1630      000200      RDY= 200     ., READY (BIT #7)
1631      000400      A16= 400      ., HIGH ORDER BUS ADDRESS BIT (BIT #8)
1632      001000      A17= 1000     ., HIGH ORDER BUS ADDRESS BIT (BIT #9)
1633      002000      PSEL= 2000    ., PORT SELECT (BIT #10)
1634      020000      MCPE= 20000   ., MASSBUSS PARITY ERROR (BIT #13)
1635      040000      TRE= 40000    ., TRANSFER ERROR (BIT #14)
1636      .SC= 100000 ., SPECIAL CONDITION (BIT #15)
1637
1638      . WORD COUNT REGISTER (RPWC)
1639      . (EACH BIT IS CALLED BY BIT NUMBER)
1640
1641      . BUS ADDRESS REGISTER (RPBA)
1642      . (EACH BIT IS CALLED BY BIT NUMBER)
1643
1644      . CONTROL AND STATUS REGISTER 2 (RPCS2)
1645
1646      000001      US1= 1      ., UNIT SELECT (BIT #0)
1647      000002      US2= 2      ., UNIT SELECT (BIT #1)
    
```

1648	000004	US4=	4	; UNIT SELECT (BIT #2)
1649	000010	BAI=	10	; BUS ADDRESS INCREMENT INHIBIT (BIT #3)
1650		,PAT=	20	; MASSBUS PARITY TEST (BIT #4)
1651	000040	CLR=	40	; CLEAR (BIT #5)
1652	000100	IR=	100	; INPUT READY (BIT #6)
1653	000200	OR=	200	; OUTPUT READY (BIT #7)
1654	000400	MPE=	400	; MASS BUS PARITY ERROR (BIT #8)
1655	001000	MXF=	1000	; MISSED TRANSFER ERROR (BIT #9)
1656	002000	PGE=	2000	; PROGRAM ERROR (BIT #10)
1657	004000	NEM=	4000	; NON EXISTENT MEMORY (BIT #11)
1658	010000	NED=	10000	; NON EXISTENT DRIVE (BIT #12)
1659	020000	UPE=	20000	; UNIBUS PARITY ERROR (BIT #13)
1660	040000	WCE=	40000	; WRITE CHECK ERROR (BIT #14)
1661	100000	DLT=	100000	; DATA LATE (BIT #15)

, DATA BUFFER REGISTER (RPDB)  
 ,(EACH BIT IS CALLED BY BIT NUMBER)

., \*\*\*\*\*

SBTTL RPO4/5/6 REGISTERS

., \*\*\*\*\*

, CONTROL AND STATUS 1 REGISTER (#00)

1675	000001	GO=	1	, GO BIT (BIT #0)
1676	000002	F1=	2	, FUNCTION CODE BIT #1
1677	000004	F2=	4	, FUNCTION CODE BIT #2
1678	000010	F3=	10	, FUNCTION CODE BIT #3
1679	000020	F4=	20	, FUNCTION CODE BIT #4
1680	000040	F5=	40	, FUNCTION CODE BIT #5
1681	004000	DVA=	4000	, DEVICE AVAILABLE (BIT #11)

, DRIVE STATUS REGISTER (RPDS1) (#01)

1685		,DF5=	1	DRIVE FORWARD 5"/SEC (BIT #0)
1686	000002	OFF20=	2	, DRIVE FORWARD 20"/SEC (BIT #1)
1687	000004	DIGB=	4	, DRIVE TO INNER GUARD BAND (BIT #2)
1688	000010	GRV=	10	, GO REVERSE (BIT #3)
1689	000020	DL64=	20	, DIFFERENCE LESS THAN 64 (BIT #4)
1690	000040	DE1=	40	, DIFFERENCE EQUALS 1 (BIT #5)
1691	000100	VV=	100	, VOLUME VALID (BIT #6)
1692	000200	DRY=	200	, DRIVE READY (BIT #7)
1693	000400	DPR=	400	, DRIVE PRESENT (BIT #8)
1694	001000	PGM=	1000	, PROGRAMABLE (BIT #9)
1695	002000	LST=	2000	, LAST SECTOR TRANSFERRED (BIT #10)
1696	004000	WRL=	4000	, WRITE LOCK (BIT #11)
1697	010000	MOL=	10000	, MEDIUM ON-LINE (BIT #12)
1698	020000	PIP=	20000	, POSITIONING OPERATION IN PROGRESS (BIT #13)
1699	040000	ERR=	40000	, COMPOSITE ERROR (BIT #14)
1700	100000	ATA=	100000	, ATTENTION ACTIVE (BIT #15)

, ERROR REGISTER #01 (RPER1) (#02)

1701  
 1702  
 1703

1704	000001	ILF=	1	, ILLEGAL FUNCTION (BIT #0)
1705	000002	ILR=	2	, ILLEGAL REGISTER (BIT #1)
1706	000004	RMR=	4	, REGISTER MODIFICATION REFUSED (BIT #2)
1707	000010	PAR=	10	, PARITY ERROR (BIT #3)
1708	000020	FER=	20	, FORMAT ERROR (BIT #4)
1709	000040	WCF=	40	, WRITE CLOCK FAIL (BIT #5)
1710	000100	ECH=	100	, ECC HARD ERROR (BIT #6)
1711	000200	HCE=	200	, HEADER COMPARE ERROR (BIT #7)
1712	000400	HCRC=	400	, HEADER CRC ERROR (BIT #8)
1713	001000	AOE=	1000	, ADDRESS OVERFLOW ERROR (BIT #9)
1714	002000	IAE=	2000	, INVALID ADDRESS ERROR (BIT #10)
1715	004000	WLE=	4000	, WRITE LOCK ERROR (BIT #11)
1716	010000	DTE=	10000	, DRIVE TIMING ERROR (BIT #12)
1717	020000	OPI=	20000	, OPERATION INCOMPLETE (BIT #13)
1718	040000	UNS=	40000	, DRIVE UNSAFE (BIT #14)
1719	100000	DCK=	100000	, DATA CHECK ERROR (BIT 15)
1720				
1721				, MAINTAINABILITY REGISTER (RPMR) (#03)
1722				
1723	000001	DMD=	1	, DIAGINOSTIC MODE (BIT #0)
1724	000002	MCLK=	2	, MAINTAINABILITY CLOCK (BIT #1)
1725	000004	MINX=	4	, MAINTAINABILITY INDEX (BIT #2)
1726	000010	MSTCK=	10	, MAINTAINABILITY SECTOR CLOCK (BIT #3)
1727	000020	MRD=	20	, MAINTAINABILITY READ (BIT #4)
1728	000040	MWR=	40	, MAINTAINABILITY WRITE (BIT #5)
1729	000200	DTSY=	200	, MAINTAINABILITY SYNC DETECTED (BIT #7)
1730				
1731				, ATTENTION SUMMARY PSEUDO-REGISTER (RPAS) (#04)
1732				
1733	000001	AT0=	1	, DEVICE 0 (BIT #0)
1734	000002	AT1=	2	, DEVICE 1 (BIT #1)
1735	000004	AT2=	4	, DEVICE 2 (BIT #2)
1736	000010	AT3=	10	, DEVICE 3 (BIT #3)
1737	000020	AT4=	20	, DEVICE 4 (BIT #4)
1738	000040	AT5=	40	, DEVICE 5 (BIT #5)
1739	000100	AT6=	100	, DEVICE 6 (BIT #6)
1740	000200	AT7=	200	, DEVICE 7 (BIT #7)
1741				
1742				, DESIRED SECTOR/TRACK ADDRESS REGISTER (RPDA) (#05)
1743				, (EACH BIT IS CALLED BY BIT NUMBER)
1744				
1745				, DRIVE TYPE REGISTER (RPDT) (#06)
1746				
1747	000001	DT00=	1	, DRIVE TYPE NUMBER BIT 1
1748	000002	DT01=	2	, DRIVE TYPE NUMBER BIT 2
1749	000004	DT02=	4	, DRIVE TYPE NUMBER BIT 3
1750	000010	DT03=	10	, DRIVE TYPE NUMBER BIT 4
1751	000020	DT04=	20	, DRIVE TYPE NUMBER BIT 5
1752	000040	DT05=	40	, DRIVE TYPE NUMBER BIT 6
1753	000100	DT06=	100	, DRIVE TYPE NUMBER BIT 7
1754	000200	DT07=	200	, DRIVE TYPE NUMBER BIT 8
1755	000400	DT08=	400	, DRIVE TYPE NUMBER BIT 9
1756	004000	DRQ=	4000	, DRIVE REQUEST REQUIRED (BIT #11)
1757	020000	MOH=	20000	, MOVING HEAD (BIT #13)
1758	040000	TAP=	40000	, TAPE DRIVE (BIT #14)
1759	100000	NBA=	100000	, NOT BLOCK ADDRESSED (B T #15)

```

1760
1761      ,LOOK-AHEAD REGISTER (RPLA) (#07)
1762
1763      000001      EXT1= 1      ;EXTENSION 1 (BIT #0)
1764      000002      EXT2= 2      ;EXTENSION 2 (BIT #1)
1765      000004      EXT4= 4      ;EXTENSION 3 (BIT #2)
1766      000010      EXT10= 10     ;EXTENSION 4 (BIT #3)
1767      000020      EXT20= 20     ;EXTENSION 5 (BIT #4)
1768      000040      EXT40= 40     ;EXTENSION 6 (BIT #5)
1769      000100      SC1= 100      ;SECTOR COUNT FIELD 0 (BIT #6)
1770      000200      SC2= 200      ;SECTOR COUNT FIELD 1 (BIT #7)
1771      ,SC4= 400      ;SECTOR COUNT FIELD 2 (BIT #8)
1772      001000      SC10= 1000     ;SECTOR COUNT FIELD 3 (BIT #9)
1773      002000      SC20= 2000     ;SECTOR COUNT FIELD 4 (BIT #10)
1774      004000      TRK1= 4000     ;TRACK FIELD 1 (BIT #11)
1775      010000      TRK2= 10000    ;TRACK FIELD 2 (BIT #12)
1776      020000      TRK4= 20000    ;TRACK FIELD 3 (BIT #13)
1777      040000      TRK10= 40000   ;TRACK FIELD 4 (BIT #14)
1778      100000      TRK20= 100000  ;TRACK FIELD 5 (BIT #15)
1779
1780      ,RPO4 ERROR REGISTER #2 (RPER2) (#10)
1781
1782      000001      WCU= 1      ;WRITE CURRENT UNSAFE (BIT #0)
1783      000002      CSF= 2      ;CURRENT SINK FAILURE (BIT #1)
1784      000004      WSU= 4      ;WRITE SELECT UNSAFE (BIT #2)
1785      000010      CSU= 10     ;CURRENT SWITCH UNSAFE (BIT #3)
1786      000020      MSE= 20     ;MOTOR SEQUENCE ERROR (BIT #4)
1787      000040      TDF= 40     ;TRANSITIONS DETECTOR FAILURE (BIT #5)
1788      000100      TUF= 100     ;TRANSITIONS UNSAFE (BIT #6)
1789      000200      FEN= 200     ;FAILSAFE ENABLED (BIT #7)
1790      000400      WRU= 400     ;WRITE READY UNSAFE (BIT #8)
1791      001000      MHS= 1000    ;MULTIPLE HEAD SELECT (BIT #9)
1792      002000      NHS= 2000    ;NO HEAD SELECTION (BIT #10)
1793      004000      IXE= 4000    ;INDEX ERROR (BIT #11)
1794      010000      VU30= 10000   ;30VOLT UNSAFE (BIT #12)
1795      020000      PLU= 20000   ;PLO UNSAFE (BIT #13)
1796      100000      ACU= 100000  ;AC UNSAFE (BIT #15)
1797
1798      ,RPO5/6 ERROR REGISTER #02 (RPER2) (#10)
1799
1800      000001      WCU= 1      ;WRITE CURRENT UNSAFE (BIT #0)
1801      000002      CSF= 2      ;CURRENT SINK FAILURE (BIT #1)
1802      000004      WSU= 4      ;WRITE SELECT UNSAFE (BIT #2)
1803      000010      CSU= 10     ;CURRENT SWITCH UNSAFE (BIT #3)
1804      000020      RAW= 20     ;READ AND WRITE (BIT #4)
1805      000040      TDF= 40     ;TRANSITIONS DETECTOR FAILURE (BIT #5)
1806      000100      TUF= 100     ;TRANSITIONS UNSAFE (BIT #6)
1807      000200      ABS= 200     ;ABNORMAL STOP (BIT #7)
1808      000400      WRU= 400     ;WRITE PEADY UNSAFE (BIT #8)
1809      001000      MHS= 1000    ;MUTLTIPLE HEAD SELECT (BIT #9)
1810      002000      NHS= 2000    ;NO HEAD SELECTION (BIT #10)
1811      004000      IXE= 4000    ;INDEX ERROR (BIT #11)
1812      020000      PLU= 20000   ;PLO UNSAFE (BIT #12)
1813
1814      ,OFFSET REGISTER (RPOF) (#11)
1815
    
```

```

1816      000001      OF25= 1      ;OFFSET 25 MICRO INCHES (BIT #0)
1817      000002      OF50= 2      ;OFFSET 50 MICRO INCHES (BIT #1)
1818      000004      OF100= 4     ;OFFSET 100 MICRO INCHES (BIT #2)
1819      000010      OF200= 10    ;OFFSET 200 MICRO INCHES (BIT #3)
1820      000020      OF400= 20    ;OFFSET 400 MICRO INCHES (BIT #4)
1821      000040      OF800= 40    ;OFFSET 800 MICRO INCHES (BIT #5)
1822      000200      OFREV= 200   ;OFFSET NEGATIVE (REVERSE) (BIT #5)
1823      002000      HCI= 2000   ;HEADER COMPARE INHIBIT (BIT #10)
1824      004000      ECI= 4000   ;ERROR CORRECTION CODE INHIBIT (BIT #11)
1825      010000      FMT22= 10000 ;FORMAT BIT (BIT #12)
1826
1827      , DESIRED CYLINDER ADDRESS (RPCA) (#12)
1828      , (EACH BIT IS CALLED BY BIT NUMBER)
1829
1830      , CURRENT CYLINDER ADDRESS (RPCC) (#13)
1831      , (EACH BIT IS CALLED BY BIT NUMBER)
1832
1833      , SERIAL NUMBER REGISTER (RPSN) (#14)
1834      , (EACH IS CALLED BY BIT NUMBER)
1835
1836      , RPO4 ERROR REGISTER #03 (RPER3) (#15)
1837
1838      000001      PSU= 1      , PACK SPEED UNSAFE (BIT #0)
1839      000002      VUF= 2      , VELOCITY UNSAFE (BIT #1)
1840      000010      UWR= 10     , ANY UNSAFE EXCEPT READ/WRITE (BIT #3)
1841      000040      ACL= 40     , AC LOW (BIT #5)
1842      000100      DCL= 100    , DC LOW (BIT #6)
1843      040000      SKI= 40000   , SEEK INCOMPLETE (BIT #14)
1844      100000      OCYL= 100000  , OFF CYLINDER (BIT #15)
1845
1846      , RPO5/6 ERROR REGISTER #03 (RPER3) (#15)
1847
1848      000001      DCU= 1      , DC UNSAFE (BIT #0)
1849      000002      WAO= 2      , WRITE AND OFFSET (BIT #1)
1850      000040      ACL= 40     , AC LOW (BIT #5)
1851      000100      DCL= 100    , DC LOW (BIT #6)
1852      020000      OPE= 20000   , OPERATOR PLUG ERROR (BIT #13)
1853      040000      SKI= 40000   , SEEK INCOMPLETE (BIT #14)
1854      100000      OCYL= 100000  , OFF CYLINDER ERROR (BIT #15)
1855
1856      , ECC POSITION REGISTER (RPEC1) (#16)
1857      , (EACH BIT IS CALLED BY BIT NUMBER)
1858
1859      , ECC PATTERN REGISTER (RPEC2) (#17)
1860      , (EACH BIT IS CALLED BY BIT NUMBER)
1861
1862      , , *****
1863
1864      , OP CODE DEFINITIONS
1865      000101      NOOP=101
1866      000103      UNLOAD=103
1867      000105      SEEK=105
1868      000107      RECAL=107
1869      000111      DRVCLR=111
1870      000113      RELEASE=113
1871      000115      OFFSET=115
    
```

1872 000117 RTC=117  
.873 000121 READIN=121  
1874 000123 PACK=123  
1875 000131 SEARCH=131  
1876 000151 WRCKD=151  
1877 000153 WRCKHD=153  
1878 000161 WRITE=161  
1879 000163 WRTHD=163  
1880 000171 READ=171  
1881 000173 READHD=173  
1882 000141 GETREG=141  
1883 000143 SETFORM=143  
1884 000145 SELDRV=145  
1885  
1886 . OTHER EQUATES  
1887  
1888 177400 SCTRWC = -256  
1889 010000 FMT22=10000  
1890

.WORD COUNT FOR SECTOR  
.FORMAT 22 BIT

```

1891 .SBTTL COMMON TAGS
1892
1893 ;*****
1894 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
1895 ;*USED IN THE PROGRAM.
1896
1897 001100 =1100
1898 001100 $CMTAG: .WORD 0 ; START OF COMMON TAGS
1899 001100 000000 $PASS: .WORD 0 ; CONTAINS PASS COUNT
1900 001102 000 $STNM: .BYTE 0 ; CONTAINS THE TEST NUMBER
1901 001103 000 $ERFLG: .BYTE 0 ; CONTAINS ERROR FLAG
1902 001104 000000 $ICNT: .WORD 0 ; CONTAINS SUBTEST ITERATION COUNT
1903 001106 000000 $LPADR: .WORD 0 ; CONTAINS SCOPE LOOP ADDRESS
1904 001110 000000 $LPERR: .WORD 0 ; CONTAINS SCOPE RETURN FOR ERRORS
1905 001112 000000 $ERTTL: .WORD 0 ; CONTAINS TOTAL ERRORS DETECTED
1906 001114 000 $ITEMB: .BYTE 0 ; CONTAINS ITEM CONTROL BYTE
1907 001115 001 $ERMAX: .BYTE 1 ; CONTAINS MAX. ERRORS PER TEST
1908 001116 000000 $ERRPC: .WORD 0 ; CONTAINS PC OF LAST ERROR INSTRUCTION
1909 001120 000000 $GDADR: .WORD 0 ; CONTAINS ADDRESS OF 'GOOD' DATA
1910 001122 000000 $BDADR: .WORD 0 ; CONTAINS ADDRESS OF 'BAD' DATA
1911 001124 000000 $GDDAT: .WORD 0 ; CONTAINS 'GOOD' DATA
1912 001126 000000 $BDDAT: .WORD 0 ; CONTAINS 'BAD' DATA
1913 001130 000000 .WORD 0 ; RESERVED--NOT TO BE USED
1914 001132 000000 .WORD 0
1915 001134 000 $AUTOB: .BYTE 0 ; AUTOMATIC MODE INDICATOR
1916 001135 000 $INTAG: .BYTE 0 ; INTERRUPT MODE INDICATOR
1917 001136 000000 .WORD 0
1918 001140 177570 $SWR: .WORD DSWR ; ADDRESS OF SWITCH REGISTER
1919 001142 177570 $DISPLAY: .WORD DDISP ; ADDRESS OF DISPLAY REGISTER
1920 001144 177560 $TKS: 177560 ; TTY KBD STATUS
1921 001146 177562 $TKB: 177562 ; TTY KBD BUFFER
1922 001150 177564 $TPS: 177564 ; TTY PRINTER STATUS REG. ADDRESS
1923 001152 177566 $TPB: 177566 ; TTY PRINTER BUFFER REG. ADDRESS
1924 001154 000 $NULL: .BYTE 0 ; CONTAINS NULL CHARACTER FOR FILLS
1925 001155 002 $FILLS: .BYTE 2 ; CONTAINS # OF FILLER CHARACTERS REQUIRED
1926 001156 012 $FILLC: .BYTE 12 ; INSERT FILL CHARS. AFTER A "LINE FEED"
1927 001157 000 $TPFLG: .BYTE 0 ; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
1928 001160 000000 $REGAD: .WORD 0 ; CONTAINS THE ADDRESS FROM
1929 ; WHICH ($REGO) WAS OBTAINED
1930 001162 000000 $REG0: .WORD 0 ; CONTAINS (($REGAD)+0)
1931 001164 000000 $REG1: .WORD 0 ; CONTAINS (($REGAD)+2)
1932 001166 000000 $REG2: .WORD 0 ; CONTAINS (($REGAD)+4)
1933 001170 000000 $REG3: .WORD 0 ; CONTAINS (($REGAD)+6)
1934 001172 000000 $REG4: .WORD 0 ; CONTAINS (($REGAD)+10)
1935 001174 000000 $REG5: .WORD 0 ; CONTAINS (($REGAD)+12)
1936 001176 000000 $TMP0: .WORD 0 ; USER DEFINED
1937 001200 000000 $TMP1: .WORD 0 ; USER DEFINED
1938 001202 000000 $TMP2: .WORD 0 ; USER DEFINED
1939 001204 000000 $TIMES: 0 ; MAX. NUMBER OF ITERATIONS
1940 001206 000000 $ESCAPE: 0 ; ESCAPE ON ERROR ADDRESS
1941 001210 177607 000377 $BELL: .ASCIZ <207><377><377> ; CODE FOR BELL
1942 001214 077 $QUES: .ASCII /?/ ; QUESTION MARK
1943 001215 015 $CRLF: .ASCII <15> ; CARRIAGE RETURN
1944 001216 000012 $LF: .ASCIZ <12> ; LINE FEED
1945 ;*****
1946 000015 CR = 15
    
```

1947		000012		LF	=	12		
1948	001220	000000		C. SWR:	. WORD	0		; CONTROL SWITCHES
1949	001222	000000		SAVCSW:	. WORD	0		; PREVIOUS CONTENTS OF 'C. SWR'
1950	001224	000000		CNTRLC:	. WORD	0		; CONTROL "C" FLAG
1951	001226	000000		BUSADR:	. WORD	0		; GET ADDRESSES FROM THE TTY FLAG (0=NO, -1=YES)
1952	001230	000000		LPTAVL:	. WORD	0		; LPT AVAILABLE STATUS (0=NO, 1=YES)
1953	001232	000000		DRVSEL:	. WORD	0		; DRIVES SELECTED FOR TESTING
1954	001234	037777	000000	TSTNMS:	. WORD	37777,0		; RUN TESTS 0-15
1955	001240	000000	000000	OPNFLG:	. WORD	0,0		; MODIFY TEST PARAMETER FLAGS
1956	001244	000000		CLKSTA:	. WORD	0		; CLOCK STATUS (0=NO CLOCK, +1=KW11-P, AND -1=KW11-L)
1957								; 16 MILLISECONDS PER CLOCK TICK
1958	001246	000020		TICKMS:	. WORD	16		; 16666 MICROSECONDS PER CLOCK TICK
1959	001250	040432		TICKUS:	. WORD	16666		
1960	001252	000000		BYPASS:	. WORD	0		
1961	001254	000000		CHKDRV:	. WORD	0		; DRIVE UNDER TEST
1962	001256	000000		DRVMSK:	. WORD	0		; DRIVE MASK BIT
1963	001260	000000		SVSTAT:	. WORD	0		; STATUS/ERROR INDICATOR IS SAVED HERE ON AN ERROR
1964								; CYLINDER READ
1965	001262	000000		CYL. RD:	. WORD	0		; TRACK READ
1966	001264	000000		TRK RD	. WORD	0		; SECTOR READ
1967	001266	000000		SEC. RD	. WORD	0		; CYLINDER DESIRED
1968	001270	000000		CYL DS	. WORD	0		; SECTOR DESIRED
1969	001272	000000		SEC DS:	. WORD	0		; TRACK DESIRED
1970	001274	000000		TRK. DS:	. WORD	0		; MINIMUM TIME
1971	001276	000000		TIM. UP:	. WORD	0		; NUMBER OF COUNTS BELOW MIN LIMIT
1972	001300	000000			. WORD	0		; MAXIMUM TIME
1973	001302	000000			. WORD	0		; NUMBER OF COUNTS ABOVE MAX. LIMIT
1974	001304	000000			. WORD	0		; TOTAL TIME OF ALL SEEKS
1975	001306	000000	000000		. WORD	0,0		; NUMBER OF SEEKS PERFORMED
1976	001312	000000			. WORD	0		; MINIMUM TIME
1977	001314	000000		TIM DN	. WORD	0		; NUMBER OF COUNTS BELOW MIN LIMIT
1978	001316	000000			. WORD	0		; MAXIMUM TIME
1979	001320	000000			. WORD	0		; NUMBER OF COUNTS ABOVE MAX. LIMIT
1980	001322	000000			. WORD	0		; TOTAL TIME OF ALL SEEKS
1981	001324	000000	000000		. WORD	0,0		; NUMBER OF SEEKS PERFORMED
1982	001330	000000			. WORD	0		; POINTS TO TABLE OF TIMES
1983	001332	000000		TIM. PT.	. WORD	0		; FATAL WRITE CHECK ERROR FLAG (TEST 20)
1984	001334	000000		WCEFLG:	. WORD	0		; VARIABLE STALL (TEST 4)
1985	001336	000000		STALLO:	. WORD	0		; SAVE DISK ADDRESS (TEST 22)
1986	001340	000000	000000	SVADR:	. WORD	0,0		; SEEK TIMER (TEST 10)
1987	001344	000000		SEKTR:	. WORD	0		; SEEK COUNTER
1988	001346	000000		SEKCN:	. WORD	0		; TESTING RANGE FOR SERVO SETTLE DOWN TEST
1989	001350	000000		DELTA:	. WORD	0		; WORD COUNT FOR A FULL TRACK IN 16 BIT MODE
1990	001352	165000		TRCKWC:	. WORD	-<256 *22 >		; 10 MILLISECONDS STALL (TEST 0-11)
1991	001354	000012		STALL1:	. WORD	10.		; 10 MILLISECONDS STALL (TEST 16-21)
1992	001356	000012		STALL2:	. WORD	10		; 5 SEC STALL (TEST 22)
1993	001360	011610		STALL3:	. WORD	5000.		; MAX. INCREMENTING STALL ALLOWED IN TEST 4
1994	001362	000031		MXSTAL:	. WORD	25		; NUMBER OF ERRORS ALLOWED IN TESTS 16 - 21
1995	001364	144		ERR CT.	. BYTE	100		; BEFORE GOING TO THE NEXT TEST
1996								; RESERVED
1997	001365	000			. BYTE	0		
1998								
1999				; ADDRESSES AND VECTORS				
2000	001366	176700		RH. ADR.	. WORD	176700		; RH11-RH70 UNIBUS ADDRESS
2001	001370	000254	000240	RHVEC:	. WORD	254,5*32		; RH11-RH70 VECTOR ADDRESS AND PRIORITY
2002	001374	000104	000106	PKV	. WORD	104,106		; KW11-P VECTOR ADDRESS

2003	001400	172540	PKCS:	. WORD	172540	;KW11-P CONTROL AND STATUS REG.
2004	001402	172542	PKB:	. WORD	172542	;KW11-P COUNT SET BUFFER
2005	001404	172544	PKC:	. WORD	172544	;KW11-P COUNTER
2006	001406	000100	LKV:	. WORD	100,102	;KW11-L VECTOR ADDRESS
2007	001412	177546	LKS:	. WORD	177546	;KW11-L STATUS REGISTER
2008	001414	177564	TPS	. WORD	177564	;TTY PRINTER STATUS
2009	001416	177566	TPB	. WORD	177566	;TTY PRINTER BUFFER
2010	001420	177514	LPS	. WORD	177514	;LINE PRINTER STATUS
2011	001422	177516	LPB:	. WORD	177516	;LINE PRINTER BUFFER

000102

,BIT TABLE

2014	001424	000001	BITS:	. WORD	BIT00
2015	001426	000002		. WORD	BIT01
2016	001430	000004		. WORD	BIT02
2017	001432	000010		. WORD	BIT03
2018	001434	000020		. WORD	BIT04
2019	001436	000040		. WORD	BIT05
2020	001440	000100		. WORD	BIT06
2021	001442	000200		. WORD	BIT07
2022	001444	000400		. WORD	BIT08
2023	001446	001000		. WORD	BIT09
2024	001450	002000		. WORD	BIT10
2025	001452	004000		. WORD	BIT11
2026	001454	010000		. WORD	BIT12
2027	001456	020000		. WORD	BIT13
2028	001460	040000		. WORD	BIT14
2029	001462	100000		. WORD	BIT15
2030	001464	000001		. WORD	BIT00
2031	001466	000002		. WORD	BIT01
2032	001470	000004		. WORD	BIT02
2033	001472	000010		. WORD	BIT03
2034	001474	000020		. WORD	BIT04
2035	001476	000040		. WORD	BIT05
2036	001500	000100		. WORD	BIT06
2037	001502	000200		. WORD	BIT07

;COMMON STORAGE FOR TEST PARAMETER

2041	001504	000000	PRM:	. WORD	0	
2042	001506	000000	RPT	. WORD	0	;REPEAT COUNTS FOR ALL TESTS
2043	001510	000000	FC	. WORD	0	;FIRST CYLINDER
2044	001512	000000	LC	. WORD	0	;LAST CYLINDER
2045	001514	000000	IC	. WORD	0	;INCREMENT CYLINDER
2046	001516	000000	FT	. WORD	0	;FIRST TRACK
2047	001520	000000	LT	. WORD	0	;LAST TRACK
2048	001522	000000	IT	. WORD	0	;INCREMENT TRACK
2049	001524	000000	FS	. WORD	0	;FIRST SECTOR
2050	001526	000000	LS	. WORD	0	;LAST SECTOR
2051	001530	000000	PAT	. WORD	0	;PATTERN CODE
2052	001532	000000	NC1	. WORD	0	;NEW CYLINDER ADDRESS
2053	001534	000000	NC2	. WORD	0	;NEW CYLINDER ADDRESS

,TABLE OF PARAMETER POINTERS

2056	001536	002330	PRMPT	. WORD	PRM0
2057	001540	002344		. WORD	PRM1
2058	001542	002372		. WORD	PRM2

2059	001544	002414	. WORD	PRM3	
2060	001546	002436	. WORD	PRM4	
2061	001550	002460	. WORD	PRM5	
2062	001552	002502	. WORD	PRM6	
2063	001554	002524	. WORD	PRM7	
2064	001556	002544	. WORD	PRM10	
2065	001560	002564	. WORD	PRM11	
2066	001562	002606	. WORD	PRM12	
2067	001564	002622	. WORD	PRM13	
2068	001566	002636	. WORD	PRM14	
2069	001570	002652	. WORD	PRM15	
2070	001572	002666	. WORD	PRM16	
2071	001574	002700	. WORD	PRM17	
2072	001576	002712	. WORD	PRM20	
2073	001600	002744	. WORD	PRM21	
2074	001602	002760	. WORD	PRM22	
2075	001604	000000	. WORD	0	, TERMINATOR

2076					
2077			. PARAMETER UPPER LIMIT		
2078	001606	032767	PRMLMT. . WORD	32767	, "R"
2079	001610	000632	. WORD	410	, "FC"
2080	001612	000632	. WORD	410.	, "LC"
2081	001614	001456	. WORD	814	, "FC'"
2082	001616	001456	. WORD	814	, "LC'"
2083	001620	001456	. WORD	814.	, "IC"
2084	001622	000022	. WORD	18.	, "FT"
2085	001624	000022	. WORD	18	, "LT"
2086	001626	000022	. WORD	18.	, "IT"
2087	001630	000025	. WORD	21	, "FS"
2088	001632	000025	. WORD	21.	, "LS"
2089	001634	177777	. WORD	177777	, "PAT"

2090					
2091			. TABLE OF MESSAGE POINTERS		
2092	001636	043000	PRMMSG: . WORD	MSG. R	
2093	001640	043002	. WORD	MSG FC	
2094	001642	043005	. WORD	MSG LC	
2095	001644	043010	. WORD	MSGFCP	
2096	001646	043014	. WORD	MSG LCP	
2097	001650	043020	. WORD	MSG. IC	
2098	001652	043023	. WORD	MSG FT	
2099	001654	043026	. WORD	MSG. LT	
2100	001656	043031	. WORD	MSG. IT	
2101	001660	043034	. WORD	MSG FS	
2102	001662	043037	. WORD	MSG. LS	

2103					
2104			. STATUS/ERROR INDICATOR MESSAGES POINTER TABLE		
2105			. DEFAULT VALUES OF TEST PARAMETERS		
2106	001664	001125	000310	000632	DFLT. . WORD 1125, 200, 410, 814, 0, 0 ; RECAL/SEEK (T0)
2107	001672	001456	000000	000000	
2108	001700	003377	000144	000000	. WORD 3377, 100, 0, 128, 0, 256, 0, 0, 0, 0, 0 ; SEEK/SEEK (T1)
2109	001706	000200	000000	000400	
2110	001714	000000	000000	000000	
2111	001722	000000	000000		
2112	001726	001177	000001	000000	. WORD 1177, 1, 0, 410, 0, 814, 1, 0, 0 ; INCREMENT SEEK (T2)
2113	001734	000632	000000	001456	
2114	001742	000001	000000	000000	

2115	001750	001177	000010	000000	. WORD	1177,10,0,256.,0,256.,1,0,0 ; STEPPING SEEK (T3)
2116	001756	000400	000000	000400		
2117	001764	000001	000000	000000		
2118	001772	001177	000001	000000	. WORD	1177,1,0,410.,0,814.,1,0,0 ; OSCILLATING SEEK (T4)
2119	002000	000632	000000	001456		
2120	002006	000001	000000	000000		
2121	002014	001177	000001	000000	. WORD	1177,1,0,410.,0,814.,1,0,0 ; CONVERGING/DIVERGING SEEK (T5)
2122	002022	000632	000000	001456		
2123	002030	000001	000000	000000		
2124	002036	001177	000001	000000	. WORD	1177,1,0,410.,0,814.,1,0,0 ; SERVO ADDRESSING LOGIC NOISE (T6)
2125	002044	000632	000000	001456		
2126	002052	000001	000000	000000		
2127	002060	000337	011610	000000	. WORD	337,5000.,0,410.,0,814.,0,18. ; RANDOM SEEK TEST (T7)
2128	002066	000632	000000	001456		
2129	002074	000000	000022			
2130	002100	000177	000001	000000	. WORD	177,1,0,410.,0,814.,100.,0 ; SERVO SETTLE DOWN TEST (T10)
2131	002106	000632	000000	001456		
2132	002114	000144	000000			
2133	002120	001177	000001	000000	. WORD	1177,1,0,410.,0,814.,1,0,0 , ALL SEEKS TEST (T11)
2134	002126	000632	000000	001456		
2135	002134	000001	000000	000000		
2136	002142	001113	000001	000000	. WORD	1113,1,0,0,0,0 ; ROTATIONAL SPEED TIMING TEST (T12)
2137	002150	000000	000000	000000		
2138	002156	000037	000001	000000	. WORD	37,1,0,410.,0,814. ; ONE CYLINDER SEEK TIMING TEST (T13)
2139	002164	000632	000000	001456		
2140	002172	000037	000001	000000	. WORD	37,1,0,136.,0,255. ; ACCESS TIME MEASUREMENT TEST (T14)
2141	002200	000210	000000	000377		
2142	002206	000037	000001	000000	. WORD	37,1,0,410.,0,814. ; MAXIMUM SEEK TIMING TEST (T15)
2143	002214	000632	000000	001456		
2144	002222	000113	000001	000000	. WORD	113,1,0,0,0 , SECTOR ADDRESSING TEST (T16)
2145	002230	000000	000000			
2146	002234	001013	000001	000000	. WORD	1013,1,0,0,0 ; TRACK ADDRESSING TEST (T17)
2147	002242	000000	000000			
2148	002246	007777	000001	000000	. WORD	7777,1,0,410.,0,814.,64,0,18,1,1,0,17777 , DATA TEST (T20)
2149	002254	000632	000000	001456		
2150	002262	000100	000000	000022		
2151	002270	000001	000001	000000		
2152	002276	177777				
2153	002300	000037	047040	000000	. WORD	37,20000.,0,410.,0,814. , EXERCISER (T21)
2154	002306	000632	000000	001456		
2155	002314	000037	011610	000000	. WORD	37,5000.,0,136.,0,255 , RPO4 ACCESS TIME ADJUSTMENT TEST (T22)
2156	002322	000210	000000	000377		

. PARAMETER TABLES

. RECAL/SEEK (T0)

PRM0	. WORD	1125
	. WORD	200
	. WORD	410
	. WORD	814
	. WORD	0
	. WORD	0

. SEEK/SEEK (T1)

PRM1	. WORD	3377
	. WORD	100

2160						
2161	002330	001125				
2162	002332	000310				
2163	002334	000632				
2164	002336	001456				
2165	002340	000000				
2166	002342	000000				
2167						
2168						
2169	002344	003377				
2170	002346	000144				

2171	002350	000000	. WORD	0
2172	002352	000200	. WORD	128.
2173	002354	000000	. WORD	0
2174	002356	000400	. WORD	256.
2175	002360	000000	. WORD	0
2176	002362	000000	. WORD	0
2177	002364	000000	. WORD	0
2178	002366	000000	. WORD	0
2179	002370	000000	. WORD	0
2180				
2181			. INCREMENT SEEK (T2)	
2182	002372	001177	PRM2. . WORD	1177
2183	002374	000001	. WORD	1
2184	002376	000000	. WORD	0
2185	002400	000632	. WORD	410
2186	002402	000000	. WORD	0
2187	002404	001456	. WORD	814
2188	002406	000001	. WORD	1
2189	002410	000000	. WORD	0
2190	002412	000000	. WORD	0
2191				
2192			. STEPPING SEEK (T3)	
2193	002414	001177	PRM3 . WORD	1177
2194	002416	000001	. WORD	1
2195	002420	000000	. WORD	0
2196	002422	000400	. WORD	256.
2197	002424	000000	. WORD	0
2198	002426	001000	. WORD	512
2199	002430	000001	. WORD	1
2200	002432	000000	. WORD	0
2201	002434	000000	. WORD	0
2202				
2203			. OSCILLATING SEEK (T4)	
2204	002436	001177	PRM4 . WORD	1177
2205	002440	000001	. WORD	1
2206	002442	000000	. WORD	0
2207	002444	000632	. WORD	410
2208	002446	000000	. WORD	0
2209	002450	001456	. WORD	814
2210	002452	000001	. WORD	1
2211	002454	000000	. WORD	0
2212	002456	000000	. WORD	0
2213				
2214			. CONVERGING/DIVERGING SEEK (T5)	
2215	002460	001177	PRM5 . WORD	1177
2216	002462	000001	. WORD	1
2217	002464	000000	. WORD	0
2218	002466	000632	. WORD	410
2219	002470	000000	. WORD	0
2220	002472	001456	. WORD	814
2221	002474	000001	. WORD	1
2222	002476	000000	. WORD	0
2223	002500	000000	. WORD	0
2224				
2225			. SERVO ADDRESSING LOGIC NOISE GENERATOR (T6)	
2226	002502	001177	PRM6 . WORD	1177

2227	002504	000001	. WORD	1
2228	002506	000000	. WORD	0
2229	002510	000632	. WORD	410.
2230	002512	000000	. WORD	0
2231	002514	001456	. WORD	814.
2232	002516	000001	. WORD	1
2233	002520	000000	. WORD	0
2234	002522	000000	. WORD	0
2235				
2236			. RANDOM SEEK TEST (T7)	
2237	002524	000337	PRM7 . WORD	337
2238	002526	011610	. WORD	5000.
2239	002530	000000	. WORD	0
2240	002532	000632	. WORD	410.
2241	002534	000000	. WORD	0
2242	002536	001456	. WORD	814
2243	002540	000000	. WORD	0
2244	002542	000022	. WORD	18
2245				
2246			. SERVO SETTLE DOWN TEST (T10)	
2247	002544	000177	PRM10 . WORD	177
2248	002546	000001	. WORD	1
2249	002550	000000	. WORD	0
2250	002552	000632	. WORD	410
2251	002554	000000	. WORD	0
2252	002556	001456	. WORD	814.
2253	002560	000144	. WORD	100.
2254	002562	000000	. WORD	0
2255				
2256			. ALL SEEKS TEST (T11)	
2257	002564	001177	PRM11 . WORD	1177
2258	002566	000001	. WORD	1
2259	002570	000000	. WORD	0
2260	002572	000632	. WORD	410.
2261	002574	000000	. WORD	0
2262	002576	001456	. WORD	814
2263	002600	000001	. WORD	1
2264	002602	000000	. WORD	0
2265	002604	000000	. WORD	0
2266				
2267			. ROTATIONAL SPEED TIMING TEST (T12)	
2268	002606	001113	PRM12 . WORD	1113
2269	002610	000001	. WORD	1
2270	002612	000000	. WORD	0
2271	002614	000000	. WORD	0
2272	002616	000000	. WORD	0
2273	002620	000000	. WORD	0
2274				
2275			. ONE CYLINDER SEEK TIMING TEST (T13)	
2276	002622	000037	PRM13 . WORD	37
2277	002624	000001	. WORD	1
2278	002626	000000	. WORD	0
2279	002630	000632	. WORD	410
2280	002632	000000	. WORD	0
2281	002634	001456	. WORD	814
2282				

```

2283 ;ACCESS TIME MEASUREMENT TEST (T14)
2284 002636 000037 PRM14: WORD 37
2285 002640 000001 WORD 1
2286 002642 000000 WORD 0
2287 002644 000210 WORD 136.
2288 002646 000000 WORD 0
2289 002650 000377 WORD 255.
2290
2291 ;MAXIMUM SEEK TIMING TEST (T15)
2292 002652 000037 PRM15 WORD 37
2293 002654 000001 WORD 1
2294 002656 000000 WORD 0
2295 002660 000632 WORD 410
2296 002662 000000 WORD 0
2297 002664 001456 WORD 814
2298
2299 ;SECTOR ADDRESSING TEST (T16)
2300 002666 000113 PRM16 WORD 113
2301 002670 000001 WORD 1
2302 002672 000000 WORD 0
2303 002674 000000 WORD 0
2304 002676 000000 WORD 0
2305
2306 ;TRACK ADDRESSING TEST (T17)
2307 002700 001013 PRM17 WORD 1013
2308 002702 000001 WORD 1
2309 002704 000000 WORD 0
2310 002706 000000 WORD 0
2311 002710 000000 WORD 0
2312
2313 ;DATA TEST (T20)
2314 002712 007777 PRM20 WORD 7777
2315 002714 000001 WORD 1
2316 002716 000000 WORD 0
2317 002720 000632 WORD 410
2318 002722 000000 WORD 0
2319 002724 001456 WORD 814.
2320 002726 000100 WORD 64
2321 002730 000000 WORD 0
2322 002732 000022 WORD 18
2323 002734 000001 WORD 1
2324 002736 000001 WORD 1
2325 002740 000000 WORD 0
2326 002742 177777 PTRN15 WORD 177777
2327
2328 ;EXERCISER (T21)
2329 002744 000037 PRM21 WORD 37
2330 002746 047040 WORD 20000
2331 002750 000000 WORD 0
2332 002752 000632 WORD 410
2333 002754 000000 WORD 0
2334 002756 001456 WORD 814
2335
2336 ;RPO4 ACCESS TIME ADJUSTMENT TEST (T22)
2337 002760 000037 PRM22 WORD 37
2338 002762 011610 WORD 5000
    
```

2339	002764	000000	WORD	0	
2340	002766	000210	WORD	136.	
2341	002770	000000	WORD	0	
2342	002772	000377	WORD	255.	
2343					
2344					
2345					
2346					
2347					. SEEK TIMING LIMITS
2348	002774	043420	T7A WORD	MSG7	
2349	002776	000000	WORD	0	
2350	003000	003142	WORD	1634	. (16 67-2%)*2
2351	003002	003244	WORD	1700	. (16 67+2%)*2
2352					
2353	003004	043420	T7B WORD	MSG7	
2354	003006	000000	WORD	0	
2355	003010	003131	WORD	1625	. (16 67-2 5%)*2
2356	003012	003255	WORD	1709	. (16 67+2 5%)*2
2357					
2358	003014	043452	T10 WORD	MSG10A	
2359	003016	043521	WORD	MSG10B	
2360	003020	000000	WORD	0	. NO LOWER LIMIT
2361	003022	001750	WORD	1000	. (7+3)*2
2362					
2363	003024	043536	T11 WORD	MSG11A	
2364	003026	043604	WORD	MSG11B	
2365	003030	000000	WORD	0	. NO LOWER LIMIT
2366	003032	005670	WORD	3000	. (28+2)*2
2367					
2368	003034	043621	T12 WORD	MSG12A	
2369	003036	043663	WORD	MSG12B	
2370	003040	000000	WORD	0	. NO LOWER LIMIT
2371	003042	012574	WORD	5500	. (50+2)*2
2372					
2373	003044	003104	PAT PT WORD	PAT0	. TABLE OF POINTERS WHICH POINT TO THE
2374	003046	003144	WORD	PAT1	. PATTERNS USED BY THE DATA TEST
2375	003050	003204	WORD	PAT2	
2376	003052	003244	WORD	PAT3	
2377	003054	003304	WORD	PAT4	
2378	003056	003344	WORD	PAT5	
2379	003060	003404	WORD	PAT6	
2380	003062	003444	WORD	PAT7	
2381	003064	003504	WORD	PAT8	
2382	003066	003544	WORD	PAT9	
2383	003070	003604	WORD	PAT10	
2384	003072	003644	WORD	PAT11	
2385	003074	003704	WORD	PAT12	
2386	003076	003744	WORD	PAT13	
2387	003100	004004	WORD	PAT14	
2388	003102	004044	WORD	PAT15	
2389					
2390					. PATTERNS 0 THRU 15
2391					
2392	003104	165555	PAT0 WORD	165555	. PATTERN 0
2393	003106	133333	WORD	133333	
2394	003110	165555	WORD	165555	

2395	003112	133333	.WORD	133333	
2396	003114	165555	.WORD	165555	
2397	003116	133333	.WORD	133333	
2398	003120	165555	.WORD	165555	
2399	003122	133333	.WORD	133333	
2400	003124	165555	.WORD	165555	
2401	003126	133333	.WORD	133333	
2402	003130	165555	.WORD	165555	
2403	003132	133333	.WORD	133333	
2404	003134	165555	.WORD	165555	
2405	003136	133333	.WORD	133333	
2406	003140	165555	.WORD	165555	
2407	003142	133333	.WORD	133333	
2408					
2409	003144	000001	PAT1 .WORD	000001	.PATTERN 1
2410	003146	000003	.WORD	000003	
2411	003150	000007	.WORD	000007	
2412	003152	000017	.WORD	000017	
2413	003154	000037	.WORD	000037	
2414	003156	000077	.WORD	000077	
2415	003160	000177	.WORD	000177	
2416	003162	000377	.WORD	000377	
2417	003164	000777	.WORD	000777	
2418	003166	001777	.WORD	001777	
2419	003170	003777	.WORD	003777	
2420	003172	007777	.WORD	007777	
2421	003174	017777	.WORD	017777	
2422	003176	037777	.WORD	037777	
2423	003200	077777	.WORD	077777	
2424	003202	177777	.WORD	177777	
2425					
2426	003204	177776	PAT2 .WORD	177776	.PATTERN 2
2427	003206	177774	.WORD	177774	
2428	003210	177770	.WORD	177770	
2429	003212	177760	.WORD	177760	
2430	003214	177740	.WORD	177740	
2431	003216	177700	.WORD	177700	
2432	003220	177600	.WORD	177600	
2433	003222	177400	.WORD	177400	
2434	003224	177000	.WORD	177000	
2435	003226	176000	.WORD	176000	
2436	003230	174000	.WORD	174000	
2437	003232	170000	.WORD	170000	
2438	003234	160000	.WORD	160000	
2439	003236	140000	.WORD	140000	
2440	003240	100000	.WORD	100000	
2441	003242	000000	.WORD	000000	
2442					
2443	003244	000000	PAT3 .WORD	000000	.PATTERN 3
2444	003246	000000	.WORD	000000	
2445	003250	000000	.WORD	000000	
2446	003252	177777	.WORD	177777	
2447	003254	177777	.WORD	177777	
2448	003256	177777	.WORD	177777	
2449	003260	000000	.WORD	000000	
2450	003262	000000	.WORD	000000	

2451	003264	177777	WORD	177777	
2452	003266	177777	WORD	177777	
2453	003270	000000	WORD	000000	
2454	003272	177777	WORD	177777	
2455	003274	000000	WORD	000000	
2456	003276	177777	WORD	177777	
2457	003300	000000	WORD	000000	
2458	003302	177777	WORD	177777	
2459					
2460	003304	000000	PAT4 WORD	000000	, PATTERN 4
2461	003306	010421	WORD	010421	
2462	003310	021042	WORD	021042	
2463	003312	031463	WORD	031463	
2464	003314	042104	WORD	042104	
2465	003316	052525	WORD	052525	
2466	003320	063146	WORD	063146	
2467	003322	073567	WORD	073567	
2468	003324	104210	WORD	104210	
2469	003326	114631	WORD	114631	
2470	003330	125252	WORD	125252	
2471	003332	135673	WORD	135673	
2472	003334	146314	WORD	146314	
2473	003336	156735	WORD	156735	
2474	003340	167356	WORD	167356	
2475	003342	177777	WORD	177777	
2476					
2477	003344	052525	PAT5 WORD	052525	, PATTERN 5
2478	003346	052525	WORD	052525	
2479	003350	052525	WORD	052525	
2480	003352	125252	WORD	125252	
2481	003354	125252	WORD	125252	
2482	003356	125252	WORD	125252	
2483	003360	052525	WORD	052525	
2484	003362	052525	WORD	052525	
2485	003364	125252	WORD	125252	
2486	003366	125252	WORD	125252	
2487	003370	052525	WORD	052525	
2488	003372	125252	WORD	125252	
2489	003374	052525	WORD	052525	
2490	003376	125252	WORD	125252	
2491	003400	052525	WORD	052525	
2492	003402	125252	WORD	125252	
2493					
2494	003404	007417	PAT6 WORD	007417	, PATTERN 6
2495	003406	007417	WORD	007417	
2496	003410	007417	WORD	007417	
2497	003412	170360	WORD	170360	
2498	003414	170360	WORD	170360	
2499	003416	170360	WORD	170360	
2500	003420	007417	WORD	007417	
2501	003422	007417	WORD	007417	
2502	003424	170360	WORD	170360	
2503	003426	170360	WORD	170360	
2504	003430	007417	WORD	007417	
2505	003432	170360	WORD	170360	
2506	003434	007417	WORD	007417	

2507	003436	170360	WORD	170360	
2508	003440	007417	WORD	007417	
2509	003442	170360	WORD	170360	
2510					
2511	003444	026455	PAT7 WORD	026455	. PATTERN 7
2512	003446	026455	WORD	026455	
2513	003450	026455	WORD	026455	
2514	003452	151322	WORD	151322	
2515	003454	151322	WORD	151322	
2516	003456	151322	WORD	151322	
2517	003460	026455	WORD	026455	
2518	003462	026455	WORD	026455	
2519	003464	151322	WORD	151322	
2520	003466	151322	WORD	151322	
2521	003470	026455	WORD	026455	
2522	003472	151322	WORD	151322	
2523	003474	026455	WORD	026455	
2524	003476	151322	WORD	151322	
2525	003500	026455	WORD	026455	
2526	003502	151322	WORD	151322	
2527					
2528	003504	165555	PAT8 WORD	165555	. PATTERN 8
2529	003506	133333	WORD	133333	
2530	003510	165555	WORD	165555	
2531	003512	133333	WORD	133333	
2532	003514	165555	WORD	165555	
2533	003516	133333	WORD	133333	
2534	003520	165555	WORD	165555	
2535	003522	133333	WORD	133333	
2536	003524	165555	WORD	165555	
2537	003526	133333	WORD	133333	
2538	003530	165555	WORD	165555	
2539	003532	133333	WORD	133333	
2540	003534	165555	WORD	165555	
2541	003536	133333	WORD	133333	
2542	003540	165555	WORD	165555	
2543	003542	133333	WORD	133333	
2544					
2545	003544	000001	PAT9 WORD	000001	. PATTERN 9
2546	003546	000002	WORD	000002	
2547	003550	000004	WORD	000004	
2548	003552	000010	WORD	000010	
2549	003554	000020	WORD	000020	
2550	003556	000040	WORD	000040	
2551	003560	000100	WORD	000100	
2552	003562	000200	WORD	000200	
2553	003564	000400	WORD	000400	
2554	003566	001000	WORD	001000	
2555	003570	002000	WORD	002000	
2556	003572	004000	WORD	004000	
2557	003574	010000	WORD	010000	
2558	003576	020000	WORD	020000	
2559	003600	040000	WORD	040000	
2560	003602	100000	WORD	100000	
2561					
2562	003604	177776	PAT10 WORD	177776	. PATTERN 10

2563	003606	177775	WORD	177775	
2564	003610	177773	WORD	177773	
2565	003612	177767	WORD	177767	
2566	003614	177757	WORD	177757	
2567	003616	177737	WORD	177737	
2568	003620	177677	WORD	177677	
2569	003622	177577	WORD	177577	
2570	003624	177377	WORD	177377	
2571	003626	176777	WORD	176777	
2572	003630	175777	WORD	175777	
2573	003632	173777	WORD	173777	
2574	003634	167777	WORD	167777	
2575	003636	157777	WORD	157777	
2576	003640	137777	WORD	137777	
2577	003642	077777	WORD	077777	
2578					
2579	003644	172666	PAT11 WORD	172666	, PATTERN 11
2580	003646	155555	WORD	155555	
2581	003650	172666	WORD	172666	
2582	003652	155555	WORD	155555	
2583	003654	172666	WORD	172666	
2584	003656	155555	WORD	155555	
2585	003660	172666	WORD	172666	
2586	003662	155555	WORD	155555	
2587	003664	172666	WORD	172666	
2588	003666	155555	WORD	155555	
2589	003670	172666	WORD	172666	
2590	003672	155555	WORD	155555	
2591	003674	172666	WORD	172666	
2592	003676	155555	WORD	155555	
2593	003700	172666	WORD	172666	
2594	003702	155555	WORD	155555	
2595					
2596	003704	077777	PAT12 WORD	077777	, PATTERN 12
2597	003706	137777	WORD	137777	
2598	003710	157777	WORD	157777	
2599	003712	167777	WORD	167777	
2600	003714	173777	WORD	173777	
2601	003716	175777	WORD	175777	
2602	003720	176777	WORD	176777	
2603	003722	177377	WORD	177377	
2604	003724	177577	WORD	177577	
2605	003726	177677	WORD	177677	
2606	003730	177737	WORD	177737	
2607	003732	177757	WORD	177757	
2608	003734	177767	WORD	177767	
2609	003736	177773	WORD	177773	
2610	003740	177775	WORD	177775	
2611	003742	177776	WORD	177776	
2612					
2613	003744	153333	PAT13 WORD	153333	, PATTERN 13
2614	003746	066667	WORD	066667	
2615	003750	153333	WORD	153333	
2616	003752	066667	WORD	066667	
2617	003754	153333	WORD	153333	
2618	003756	066667	WORD	066667	

K 4

2619 003760 153333 . WORD 153333  
 2620 003762 066667 . WORD 066667  
 2621 003764 153333 . WORD 153333  
 2622 003766 066667 . WORD 066667  
 2623 003770 153333 . WORD 153333  
 2624 003772 066667 . WORD 066667  
 2625 003774 153333 . WORD 153333  
 2626 003776 066667 . WORD 066667  
 2627 004000 153333 . WORD 153333  
 2628 004002 066667 . WORD 066667

2630 004004 000000 PAT14 . WORD 000000 ; PATTERN 14  
 2631 004006 177777 . WORD 177777  
 2632 004010 177777 . WORD 177777  
 2633 004012 177777 . WORD 177777  
 2634 004014 177777 . WORD 177777  
 2635 004016 177777 . WORD 177777  
 2636 004020 177777 . WORD 177777  
 2637 004022 177777 . WORD 177777  
 2638 004024 177777 . WORD 177777  
 2639 004026 177777 . WORD 177777  
 2640 004030 177777 . WORD 177777  
 2641 004032 177777 . WORD 177777  
 2642 004034 177777 . WORD 177777  
 2643 004036 177777 . WORD 177777  
 2644 004040 177777 . WORD 177777  
 2645 004042 177777 . WORD 177777

2646  
 2647 004044 177777 PAT15 . WORD 177777 ; PATTERN 15  
 2648 004046 000000 . WORD 000000  
 2649 004050 000000 . WORD 000000  
 2650 004052 000000 . WORD 000000  
 2651 004054 000000 . WORD 000000  
 2652 004056 000000 . WORD 000000  
 2653 004060 000000 . WORD 000000  
 2654 004062 000000 . WORD 000000  
 2655 004064 000000 . WORD 000000  
 2656 004066 000000 . WORD 000000  
 2657 004070 000000 . WORD 000000  
 2658 004072 000000 . WORD 000000  
 2659 004074 000000 . WORD 000000  
 2660 004076 000000 . WORD 000000  
 2661 004100 000000 . WORD 000000  
 2662 004102 000000 . WORD 000000

.DPB (DATA PARAMETER BLOCK)

2663  
 2664  
 2665  
 2666 004104 000 DPB A . BYTE 0 ; (0) DRIVE NUMBER  
 2667 004105 000 . BYTE 0 ; (1) OFFSET VALUE OR FMT22, ECI, AND HCI  
 2668 004106 000 . BYTE 0 ; (2) COMMAND  
 2669 004107 000 . BYTE 0 ; (3) PSEL AND A17 AND A16  
 2670 004110 000000 . WORD 0 ; (4) WORD COUNT (MUST BE NEG )  
 2671 004112 047712 . WORD BUFFER ; (6) BUFFER ADDRESS OR  
 2672 . REGISTER TABLE POINTER  
 2673 004114 000 . BYTE 0 ; (10) SECTOR ADDRESS OR  
 2674 . FIRST REG INDEX

2675	004115	000	BYTE	0	; (11) TRACK ADDRESS OR	
2676					; LAST REG. INDEX	
2677	004116	000000	WORD	0	; (12) CYLINDER ADDRESS	
2678	004120	004204	WORD	RP. REG	; (14) ERROR TABLE POINTER	
2679					; POINTS TO THE FIRST OF TWENTY	
2680					; LOCATIONS OF WHERE THE DRIVER	
2681					; IS TO STORE THE RH11/RPO4	
2682					; REGISTERS ON AN ERROR. IF LEFT	
2683					; ZERO REGISTERS ARE NOT SAVED.	
2684	004122	000000	WORD	0	; (16) STATUS/ERROR INDICATOR	
2685					; BIT15=1=>ERROR OCCURRED	
2686					; BIT07=1=>DONE	
2687					; BIT14-BIT09 AND BIT06-BIT03	
2688					; INDICATE TYPE OF ERROR	
2689						
2690	004124	000	DPB B	BYTE	0	; (0) DRIVE NUMBER
2691	004125	000		BYTE	0	; (1) OFFSET VALUE OR FMT22, ECI, AND HCI
2692	004126	000		BYTE	0	; (2) COMMAND
2693	004127	000		BYTE	0	; (3) PSEL AND A17 AND A16
2694	004130	177776		WORD	-2	; (4) WORD COUNT (MUST BE NEG )
2695	004132	047712		WORD	BUFFER	; (6) BUFFER ADDRESS OR
2696						; REGISTER TABLE POINTER
2697	004134	000		BYTE	0	; (10) SECTOR ADDRESS OR
2698						; FIRST REG. INDEX
2699	004135	000		BYTE	0	; (11) TRACK ADDRESS OR
2700						; LAST REG. INDEX
2701	004136	000000		WORD	0	; (12) CYLINDER ADDRESS
2702	004140	004204		WORD	RP REG	; (14) ERROR TABLE POINTER
2703						; POINTS TO THE FIRST OF TWENTY
2704						; LOCATIONS OF WHERE THE DRIVER
2705						; IS TO STORE THE RH11/RPO4
2706						; REGISTERS ON AN ERROR. IF LEFT
2707						; ZERO REGISTERS ARE NOT SAVED
2708	004142	000000		WORD	0	; (16) STATUS/ERROR INDICATOR
2709						; BIT15=1=>ERROR OCCURRED
2710						; BIT07=1=>DONE
2711						; BIT14-BIT09 AND BIT06-BIT03
2712						; INDICATE TYPE OF ERROR
2713						
2714	004144	000	DPB C	BYTE	0	; (0) DRIVE NUMBER
2715	004145	000		BYTE	0	; (1) OFFSET VALUE OR FMT22, ECI, AND HCI
2716	004146	000		BYTE	0	; (2) COMMAND
2717	004147	000		BYTE	0	; (3) PSEL AND A17 AND A16
2718	004150	177776		WORD	-2	; (4) WORD COUNT (MUST BE NEG )
2719	004152	047712		WORD	BUFFER	; (6) BUFFER ADDRESS OR
2720						; REGISTER TABLE POINTER
2721	004154	000		BYTE	0	; (10) SECTOR ADDRESS OR
2722						; FIRST REG. INDEX
2723	004155	000		BYTE	0	; (11) TRACK ADDRESS OR
2724						; LAST REG. INDEX
2725	004156	000000		WORD	0	; (12) CYLINDER ADDRESS
2726	004160	004204		WORD	RP REG	; (14) ERROR TABLE POINTER
2727						; POINTS TO THE FIRST OF TWENTY
2728						; LOCATIONS OF WHERE THE DRIVER
2729						; IS TO STORE THE RH11/RPO4
2730						; REGISTERS ON AN ERROR IF LEFT

2731					; ZERO REGISTERS ARE NOT SAVED.
2732	004162	000000	WORD	0	; (16) STATUS/ERROR INDICATOR
2733					; BIT15=1=>ERROR OCCURRED
2734					; BIT07=1=>DONE
2735					; BIT14-BIT09 AND BIT06-BIT03
2736					; INDICATE TYPE OF ERROR
2737					
2738	004164	000	DTADPB	BYTE	; (0) DRIVE NUMBER
2739	004165	000		BYTE	; (1) OFFSET VALUE OR FMT22, ECT, AND HCI
2740	004166	000		BYTE	; (2) COMMAND
2741	004167	000		BYTE	; (3) PSEL AND A17 AND A16
2742	004170	000000		WORD	; (4) WORD COUNT (MUST BE NEG )
2743	004172	047712		WORD	; (6) BUFFER ADDRESS OR
2744					; REGISTER TABLE POINTER
2745	004174	000		BYTE	; (10) SECTOR ADDRESS OR
2746					; FIRST REG. INDEX
2747	004175	000		BYTE	; (11) TRACK ADDRESS OR
2748					; LAST REG. INDEX
2749	004176	000000		WORD	; (12) CYLINDER ADDRESS
2750	004200	004204		WORD	; (14) ERROR TABLE POINTER
2751					; POINTS TO THE FIRST OF TWENTY
2752					; LOCATIONS OF WHERE THE DRIVER
2753					; IS TO STORE THE RH11/RPO4
2754					; REGISTERS ON AN ERROR. IF LEFT
2755					; ZERO REGISTERS ARE NOT SAVED.
2756	004202	000000		WORD	; (16) STATUS/ERROR INDICATOR
2757					; BIT15=1=>ERROR OCCURRED
2758					; BIT07=1=>DONE
2759					; BIT14-BIT09 AND BIT06-BIT03
2760					; INDICATE TYPE OF ERROR
2761					
2762					
2763					
2764					; SAVE RH11/RPO4 REGISTERS HERE ON ERROR
2765					
2766	004204	000000	RP. REG.	WORD	; RPCS1 (776700) CONTROL & STATUS #1
2767	004206	000000		WORD	; RPWC (776702) WORD COUNT
2768	004210	000000		WORD	; RPBA (776704) BUS ADDRESS
2769	004212	000000		WORD	; RPOA (776706) DESIRED SECTOR/TRACK
2770	004214	000000		WORD	; RPCS2 (776710) CONTROL & STATUS #2
2771	004216	000000		WORD	; RPOD1 (776712) DISK STATUS
2772	004220	000000		WORD	; RPER1 (776714) ERROR REG. #1
2773	004222	000000		WORD	; RPAS (776716) ATTENTION SUMMARY
2774	004224	000000		WORD	; RPLA (776720) LOOK AHEAD
2775	004226	000000		WORD	; RPDB (776722) DATA BUFFER
2776	004230	000000		WORD	; RPMR (776724) MAINTAINABILITY
2777	004232	000000		WORD	; RPDT (776726) DRIVE TYPE
2778	004234	000000		WORD	; RPSN (776730) SERIAL NUMBER
2779	004236	000000		WORD	; RPOF (776732) OFFSET
2780	004240	000000		WORD	; RPCA (776734) DESIRED CYLINDER
2781	004242	000000		WORD	; RPCC (776736) CURRENT CYLINDER
2782	004244	000000		WORD	; RPER2 (776740) ERROR REG #2
2783	004246	000000		WORD	; RPER3 (776742) ERROR REG #3
2784	004250	000000		WORD	; RPEC1 (776744) ECC POSITION
2785	004252	000000		WORD	; RPEC2 (776746) ECC PATTERN
2786					

			STATUS/ERROR	MESSAGE POINTER	TABLE
2787					
2788	004254	044722	STATBL: . WORD	MSG814	; OFFLINE OR UNSAFE DRIVE REQUESTED
2789	004256	044764	. WORD	MSG813	; UNLOAD DRIVE REQUESTED
2790	004260	045015	. WORD	MSG812	; PERSISTENT UNSAFE
2791	004262	045037	. WORD	MSG811	; PARITY ERROR OCCURRED
2792	004264	045065	. WORD	MSG810	; FATAL PARITY ERROR
2793	004266	045110	. WORD	MSG809	; SOFTWARE TIMEOUT ON THIS DRIVE
2794	004270	045147	. WORD	MSG808	; SOFTWARE TIMEOUT ON ANOTHER DRIVE
2795	004272	045211	. WORD	MSG806	; ERROR OCCURRED DURING I/O OPERATION
2796	004274	045255	. WORD	MSG805	; ERROR OCCURRED DURING NON-I/O OPERATION
2797	004276	045325	. WORD	MSG804	; UNSAFE OCCURRED
2798	004300	045345	. WORD	MSG803	; AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
2799	004302	045415	. WORD	MSG802	; DRIVE HAS NOT RESPONDED TO PORT REQUEST
2800	004304	045465	. WORD	MSG801	; DRIVE HAS BECOME NONEXISTENT

.SBTTL ERROR POINTER TABLE

.\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
.\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
.\*LOCATION \$ITEMB THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT  
.\*NOTE1. IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
.\*NOTE2. EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS

.\* EM ;;POINTS TO THE ERROR MESSAGE  
.\* DH ;;POINTS TO THE DATA HEADER  
.\* DT ;;POINTS TO THE DATA  
.\* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB

.\*EM AND DH ARE ASCIZ MESSAGES, DT IS A STRING OF WORDS THAT POINT TO THE  
.\*DATA TO BE TYPED AND DF IS A STRING OF DATA THAT TELL HOW THE DT WORDS  
.\*ARE TO BE TYPED. IF ANY OF THE POINTERS ARE NOT NEEDED FOR A PARTICULAR  
.\*ERROR IT IS REPLACED WITH A ZERO.  
.\*EACH OF THE ITEMS BELOW REFER TO THE ERROR NUMBER AND INDICATE  
.\*THE INFORMATION THAT WILL BE TYPED WHEN THE ERROR OCCURS.  
.\*UNLESS STATED OTHER ALL NUMBERS ARE OCTAL

.\* ERROR ITEM 1  
.\* RH11 INTERRUPT OCCURED (RPAS = 0)  
.\* ERR PC RPAS  
.\* \$ERRPC \$REG3

EM1  
DH1  
DT1  
DF1

.\* ERROR ITEM 2  
.\* UNEXPECTED ATTENTION OCCURRED  
.\* ERR PC DRIVE RPAS RPDS1 RPER1 RPER2 RPER3  
.\* \$ERRPC \$REG1 \$REG3 RPERRS RPERRS+2 RPERRS+4 RPERRS+6

EM2  
DH2  
DT2  
DF2

.\* ERROR ITEM 3  
.\* MASSBUS PARITY ERROR (MCPE=1)  
.\* TEST ERR PC ADDRESS DATA  
.\* \$TMPO \$ERRPC RD ADR RD WRD

EM3  
DH3  
DT3  
DF3

.\* ERROR ITEM 4  
.\* MASSBUS PARITY ERROR (PAR=1)  
.\* TEST ERR PC ADDRESS GDATA BDDATA

2801  
2802  
2803  
2804  
2805  
2806  
2807  
2808  
2809  
2810  
2811  
2812  
2813  
2814  
2815 004306  
2816  
2817  
2818  
2819  
2820  
2821  
2822  
2823  
2824  
2825  
2826  
2827  
2828  
2829 004306 044043  
2830 004310 045523  
2831 004312 047104  
2832 004314 047536  
2833  
2834  
2835  
2836  
2837  
2838  
2839 004316 044106  
2840 004320 045540  
2841 004322 047110  
2842 004324 047542  
2843  
2844  
2845  
2846  
2847  
2848  
2849 004326 044144  
2850 004330 045626  
2851 004332 047126  
2852 004334 047546  
2853  
2854  
2855  
2856

```

2857          , *   $TMPO   $ERRPC  WRT ADR WRT. WD  RD. WRD
2858
2859 004336    044201          EM4
2860 004340    045663          DH4
2861 004342    047136          DT4
2862 004344    047552          DF4
2863
2864          , *   ERROR ITEM 5
2865          , *   ADDRESS PLUG CHANGE BIT SET
2866          , *   ERR PC  DRIVE  RPAS  RPDS1  RPER1  RPER2  RPER3
2867          , *   $ERRPC  $REG1  $REG3  RPERRS  RPERRS+2  RPERRS+4  RPERRS+6
2868
2869 004346    044235          EM5
2870 004350    045540          DH2
2871 004352    047110          DT2
2872 004354    047542          DF2
2873
2874          , *   ERROR ITEM 6 -- NOT USED
2875
2876 004356    000000          0
2877 004360    000000          0
2878 004362    000000          0
2879 004364    000000          0
2880
2881          , *   ERROR ITEM 7 -- NOT USED
2882
2883 004366    000000          0
2884 004370    000000          0
2885 004372    000000          0
2886 004374    000000          0
2887
2888          , *   ERROR ITEM 10
2889          , *   RH11/RPO4/5/6 FAILED TO RESPOND TO ADDRESSING
2890          , *   RPCS1  ERR PC
2891          , *   RH. ADR  $ERRPC
2892
2893 004376    044271          EM10
2894 004400    045732          DH10
2895 004402    047170          DT10
2896 004404    047556          DF10
2897
2898          , *   ERROR ITEM 11
2899          , *   DRIVE SELECTED IS NOT ONLINE
2900          , *   DRIVE  ERR PC
2901          , *   $REG2  $ERRPC
2902
2903 004406    044347          EM11
2904 004410    045751          DH11
2905 004412    047174          DT11
2906 004414    047562          DF11
2907
2908          , *   ERROR ITEM 12
2909          , *   IMPROPER HEADER DATA
2910          , *   TEST  ERR PC  TST PC  DRIVE  CYLNDR  TRACK  SECTOR
2911          , *   $TMPO  $ERRPC  $REGO  CHKDRV  CYL DS  TRK DS  SEC DS
2912          , *   GOCYL  GOTRK  GOSCTR  BDCYL  BOTRK  BOSCTR

```

```

2913          ,*      CYL DS TRK DS SEC DS CYL RD TRK RD SEC RD
2914          ,*      CYLNDR, TRACK, AND SECTOR ARE DECIMAL
2915
2916 004416    044404          EM12
2917 004420    045770          DH12
2918 004422    047200          DT12
2919 004424    047566          DF12
2920
2921          ,*      ERROR ITEM 13
2922          ,*      DATA COMPARE FAILURE
2923          ,*      TEST   ERR PC TST PC DRIVE  CYLNDR TRACK  SECTOR
2924          ,*      $TMPO  $ERRPC $REG0  CHKDRV  CYL DS TRK DS SEC DS
2925          ,*      $GDDAT  $BDDAT  $WRCNT  $GADR  $BADR
2926          ,*      $SGDAT  $SBDDAT  $REG4  $GDADR  $BDADR
2927          ,*      CYLNDR, TRACK, SECTOR, AND WRCNT ARE DECIMAL
2928
2929 004426    044431          EM13
2930 004430    045770          DH12
2931 004432    047232          DT13
2932 004434    047576          DF13
2933
2934          ,*      ERROR ITEM 14 -- FOLLOWS #13
2935          ,*      $GDDAT  $BDDAT  $REG4  $GDADR  $BDADR
2936
2937 004436    000000          0
2938 004440    000000          0
2939 004442    047250          DT13A
2940 004444    047606          DF14
2941
2942          ,*      ERROR ITEM 15
2943          ,*      DATA COMPARE FAILURE
2944          ,*      TEST   ERR PC TST PC DRIVE  CYLNDR TRACK  SECTOR
2945          ,*      $TMPO  $ERRPC $REG0  CHKDRV  CYL DS TRK DS SEC DS
2946          ,*      $GDDAT  $BDDAT  $WRCNT  $GADR  $BADR
2947          ,*      $SGDAT  $SBDDAT  $REG4  $GDADR  $BDADR
2948          ,*      CYLNDR, TRACK, SECTOR, AND WRCNT ARE DECIMAL
2949
2950 004446    044431          EM13
2951 004450    045770          DH12
2952 004452    047232          DT13
2953 004454    047576          DF13
2954
2955          ,*      ERROR ITEM 16 -- FOLLOWS #15
2956          ,*      $GDDAT  $BDDAT  $REG4  $GDADR  $BDADR
2957
2958 004456    000000          0
2959 004460    000000          0
2960 004462    047250          DT13A
2961 004464    047606          DF14
2962
2963          ,*      ERROR ITEM 17
2964          ,*      DISK ERROR IN TIMING TEST
2965          ,*      TEST   ERR PC DRIVE  RPCS1  RPS1    RPER1    RPER2    RPER3
2966          ,*      $TMPO  $ERRPC  CHKDRV  RP REG  RP REG+12 RP REG+14 RP REG+40 RP REG+42
2967
2968 004466    044456          EM17
    
```

2969	004470	046204	DH17
2970	004472	047262	DT17
2971	004474	047612	DF17
2972			
2973			* ERROR ITEM 20
2974			* CLOCK (KH11-P) OVERFLOW IN TIMING TEST
2975			* TEST ERR PC DRIVE RPCS1 RPDS1 RPER1 RPER2 RPER3
2976			* STMPO \$ERRPC CHKDRV RP. REG RP. REG+12 RP REG+14 RP REG+40 RP REG+42
2977			
2978	004476	044510	EM20
2979	004500	046204	DH17
2980	004502	047262	DT17
2981	004504	047612	DF17
2982			
2983			* ERROR ITEM 21
2984			* DATA COMPARE FAILURE
2985			* TEST ERR PC TST PC DRIVE CYLNDR TRACK
2986			* STMPO \$ERRPC \$REGO CHKDRV CYL DS TRK DS
2987			* GDDAT BDDAT WRDCNT SECTOR
2988			* \$REG1 \$BDDAT \$REG4 \$REG1
2989			* CYLINDR, TRACK, WRDCNT, AND SECTOR ARE DECIMAL
2990			
2991	004506	044431	EM13
2992	004510	046302	DH21
2993	004512	047302	DT21
2994	004514	047616	DF21
2995			
2996			* ERROR ITEM 22--FOLLOWS #21
2997			* \$REG1 \$BDDAT \$REG4 \$PEG1
2998			
2999	004516	000000	0
3000	004520	000000	0
3001	004522	047316	DT21A
3002	004524	047626	DF22
3003			
3004			* ERROR ITEM 23
3005			* DISK ERROR DURING SEEK
3006			* TEST ERR PC DRIVE CYLNDR RPCS1 RPCS2 RPDS1
3007			* STMPO \$ERRPC CHKDRV CYL DS RP REG RP REG+10 RP REG+12
3008			* RPER1 RPER2 RPER3 RPCA RPCC
3009			* RP REG+14 RP REG+40 RP REG+42 RP REG+34 RP REG+36
3010			
3011	004526	044557	EM23
3012	004530	046417	DH23
3013	004532	047326	DT23
3014	004534	047632	DF23
3015			
3016			* ERROR ITEM 24
3017			* SEEK NOT COMPLETE WITHIN 120 MS
3018			* TEST ERR PC DRIVE CYLNDR RPCS1 RPCS2 RPDS1
3019			* STMPO \$ERRPC CHKDRV CYL DS RP REG RP REG+10 RP REG+12
3020			* RPER1 RPER2 RPER3 RPCA RPCC
3021			* RP REG+14 RP REG+40 RP REG+42 RP REG+34 RP REG+36
3022			
3023	004536	044606	EM24
3024	004540	046417	DH23

```

3025 004542 047326 DT23
3026 004544 047632 DF23
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039
3040
3041
3042
3043
3044
3045
3046
3047
3048
3049 004546
3050
3051
3052
3053
3054
3055
3056 004546 044646 EM41
3057 004550 046552 DH41
3058 004552 047356 DT41
3059 004554 047642 DF41
3060
3061
3062
3063
3064
3065
3066 004556 044646 EM41
3067 004560 046610 DH42
3068 004562 047366 DT42
3069 004564 047646 DF42
3070
3071
3072
3073
3074
3075
3076
3077
3078 004566 044646 EM41
3079 004570 046610 DH42
3080 004572 047404 DT43

```

\*\*\*\*\*  
 \*\*\*\*\*  
 \* ERROR ITEMS 23-40 NOT USED  
 \* ERROR ITEMS 41-46 WILL HAVE AN EM THAT  
 \* VARIES DEPENDING ON THE ERROR, IT WILL BE IN THE FORM  
 \* RH11/RPO4/5/6 ERROR (MESSAGE)  
 \* WHERE MESSAGE WILL BE ONE OR MORE OF THE FOLLOWING:  
 \* 1) OFFLINE OR UNSAFE DRIVE REQUESTED  
 \* 2) UNLOADED DRIVE REQUESTED  
 \* 3) PERSISTENT UNSAFE  
 \* 4) PARITY ERROR OCCURRED  
 \* 5) FATAL PARITY ERROR  
 \* 6) SOFTWARE TIMEOUT ON THIS DRIVE  
 \* 7) SOFTWARE TIMEOUT ON ANOTHER DRIVE  
 \* 8) ERROR OCCURRED DURING I/O OPERATION  
 \* 9) ERROR OCCURRED DURING NON-I/O OPERATION  
 \* 10) UNSAFE OCCURRED  
 \* 11) AUTOMATIC RECALIBRATE SEQUENCE OCCURRED

ITEM41  
 \* ERROR ITEM 41  
 \* RH11/RPO4/5/6 ERROR (MESSAGE)  
 \* TEST ERR PC TST PC DRIVE  
 \* \$TMPO \$ERRPC \$REGO CHKDRV

\* ERROR ITEM 42  
 \* RH11/RPO4/5/6 ERROR (MESSAGE)  
 \* TEST ERR PC TST PC DRIVE RPCS1 RPCS2 RPDS1  
 \* \$TMPO \$ERRPC \$REGO CHKDRV RP REG RP REG+10 RP REG+12

\* ERROR ITEM 43  
 \* RH11/RPO4/5/6 ERROR (MESSAGE)  
 \* TEST ERR PC TST PC DRIVE RPCS1 RPCS2 RPDS1  
 \* \$TMPO \$ERRPC \$REGO CHKDRV RP REG RP REG+10 RP REG+12  
 \* RPER1 RPER2 RPER3  
 \* RP REG+14 RP REG+40 RP REG+42

```

3081 004574 047652          DF43
3082
3083 ,* ERROR ITEM 44
3084 ,* RH11/RPO4/5/6 ERROR (MESSAGE)
3085 ,* TEST   ERR PC  TST PC  DRIVE  CYLNR  TRACK  SECTOR
3086 ,* $TMPO  $ERRPC  $REGO  CHKDRV  CYL DS  TRK DS  SEC DS
3087 ,*      RPCS1   RPCS2   RPDS1   RPCC   RPCA   RPDA
3088 ,*      RP REG  RP REG+10 RP REG+12 RP REG+36 RP REG+34 RP REG+06
3089 ,*      RPER1   RPER2   RPER3
3090 ,*      RP REG+14  RP REG+40  RP REG+42
3091 ,*      CYLNR, TRACK, AND SECTOR ARE DECIMAL
3092
3093 004576 044646          EM41
3094 004600 045770          DH12
3095 004602 047430          DT44
3096 004604 047662          DF44
3097
3098 ,* ERROR ITEM 45
3099 ,* RH11/RPO4/5/6 ERROR (MESSAGE)
3100 ,* TEST   ERR PC  TST PC  DRIVE  CYLNR  TRACK  SECTOR
3101 ,* $TMPO  $ERRPC  $REGO  CHKDRV  CYL DS  TRK DS  SEC DS
3102 ,*      RPCS1   RPCS2   RPDS1   RPCC   RPCA   RPDA
3103 ,*      RP REG  RP REG+10 RP REG+12 RP REG+36 RP REG+34 RP REG+06
3104 ,*      RPER1   RPER2   RPER3   RPWC   RPBA   RPDB
3105 ,*      RP REG+14  RP REG+40  RP REG+42  RP REG+2  RP REG+4  RP REG+22
3106 ,*      CYLNR, TRACK, AND SECTOR ARE DECIMAL
3107
3108 004606 044646          EM41
3109 004610 045770          DH12
3110 004612 047470          DT45
3111 004614 047676          DF45
3112
3113 ,* ERROR ITEM 46
3114 ,* FATAL WRITE CHECK ERROR (MESSAGE)
3115 ,* TEST   ERR PC  TST PC  DRIVE  CYLNR  TRACK  SECTOR
3116 ,* $TMPO  $ERRPC  $REGO  CHKDRV  CYL DS  TRK DS  SEC DS
3117 ,*      RPCS1   RPCS2   RPDS1   RPCC   RPCA   RPDA
3118 ,*      RP REG  RP REG+10 RP REG+12 RP REG+36 RP REG+34 RP REG+06
3119 ,*      RPER1   RPER2   RPER3   RPWC   RPBA   RPDB
3120 ,*      RP REG+14  RP REG+40  RP REG+42  RP REG+2  RP REG+4  RP REG+22
3121 ,*      CYLNR, TRACK, AND SECTOR ARE DECIMAL
3122
3123 004616 044672          EM46
3124 004620 045770          DH12
3125 004622 047470          DT45
3126 004624 047676          DF45
3127
    
```

```

3128
3129          SBTTL  START OF PROGRAM
3130
3131
3132 004626 012737 177777 001226 START3 MOV    #-1,@#BUSADR ,GET BUSADR FLAG
3133 004634 000402          BR      STRT1A
3134 004636 005037 001226 START1: CLR    @#BUSADR ,CLR BUSADR FLAG
3135 004642 005037 001224 STRT1A: CLR   @#CNTRLC ,NO CONTROL "C"
3136 004646 000411          BR      START
3137 004650 012737 177777 001226 START4 MOV    #-1,@#BUSADR ,SET BUSADR FLAG
3138 004656 000402          BR      STRT2A
3139 004660 005037 001226 START2 CLR    @#BUSADR ,CLR BUSADR FLAG
3140 004664 012737 177777 001224 STRT2A MOV    #-1,@#CNTRLC ,SET CONTROL "C" FLAG
3141 004672 000005          START: RESET
3142          SBTTL  INITIALIZE THE COMMON TAGS
3143          ;; CLEAR THE COMMON TAGS ($CMTAG) AREA
3144 004674 012706 001100          MOV    # $CMTAG,R6 ,; FIRST LOCATION TO BE CLEARED
3145 004700 005026          CLR    (R6)+ ,; CLEAR MEMORY LOCATION
3146 004702 022706 001140          CMP    #SWR,R6 ,; DONE?
3147 004706 001374          BNE   -6 ,; LOOP BACK IF NO
3148 004710 012706 001100          MOV    #STACK,SP ,; SETUP THE STACK POINTER
3149          ;; INITIALIZE A FEW VECTORS
3150 004714 012737 022606 000020          MOV    # $SCOPE,@#IOTVEC ,; IOT VECTOR FOR SCOPE ROUTINE
3151 004722 012737 000340 000022          MOV    #340,@#IOTVEC+2 ,; LEVEL 7
3152 004730 012737 017634 000030          MOV    # $ERROR,@#EMTVEC ,; EMT VECTOR FOR ERROR ROUTINE
3153 004736 012737 000340 000032          MOV    #340,@#EMTVEC+2 ,; LEVEL 7
3154 004744 012737 023134 000034          MOV    #STRAP,@#TRAPVEC ,; TRAP VECTOR FOR TRAP CALLS
3155 004752 012737 000340 000036          MOV    #340,@#TRAPVEC+2; LEVEL 7
3156 004760 012737 176543 023606          MOV    #176543,$HINUM ,; PRIME THE RANDOM NUMBER GENERATOR
3157 004766 012737 123456 023610          MOV    #123456,$LONUM ,; BOTH HIGH AND LOW WORDS
3158 004774 005037 001204          CLR    $TIMES ,; INITIALIZE NUMBER OF ITERATIONS
3159 005000 005037 001206          CLR    $ESCAPE ,; CLEAR THE ESCAPE ON ERROR ADDRESS
3160 005004 112737 000001 001115          MOVB  #1,$ERMAX ,; ALLOW ONE ERROR PER TEST
3161 005012 012737 005012 001106          MOV    #,$SLPADR ,; INITIALIZE THE LOOP ADDRESS FOR SCOPE
3162 005020 012737 005020 001110          MOV    #,$SLPERR ,; SETUP THE ERROR LOOP ADDRESS
3163          ;; SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
3164          ;; EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER
3165 005026 013746 000004          MOV    @#ERRVEC,-(SP) ,; SAVE ERROR VECTOR
3166 005032 012737 005066 000004          MOV    #64,$@#ERRVEC ,; SET UP ERROR VECTOR
3167 005040 012737 177570 001140          MOV    #DSWR,SWR ,; SETUP FOR A HARDWARE SWICH REGISTER
3168 005046 012737 177570 001142          MOV    #DDISP,DISPLAY ,; AND A HARDWARE DISPLAY REGISTER
3169 005054 022777 177777 174056          CMP    #-1,@SWR ,; TRY TO REFERENCE HARDWARE SWR
3170 005062 001012          BNE   66$ ,; BRANCH IF NO TIMEOUT TRAP OCCURRED
3171          ,; AND THE HARDWARE SWR IS NOT = -1
3172 005064 000403          BR    65$ ,; BRANCH IF NO TIMEOUT
3173 005066 012716 005074          64$ MOV    #65$,(SP) ,; SET UP FOR TRAP RETURN
3174 005072 000002          RTI
3175 005074 012737 000176 001140          65$ MOV    #SWREG,SWR ,; POINT TO SOFTWARE SWR
3176 005102 012737 000174 001142          MOV    #DISPREG,DISPLAY
3177 005110 012637 000004          66$ MOV    (SP)+,@#ERRVEC ,; RESTORE ERROR VECTOR
3178
3179 005114 012700 001160          MOV    # $REGAD,RO ,; FIRST ADDRESS
3180 005120 005020          1$ CLR    (RO)+ ,; CLEAR VARIABLE STORAGE
3181 005122 022700 001210          CMP    # $BELL,RO ,; DONE?
3182 005126 001374          BNE   1$ ,; NO--BRANCH
3183 005130 013737 001414 001150          MOV    @#TPS,@#STPS ,; SETUP THE STATUS AND BUFFER REG'S
    
```

3184	005136	013737	001416	001152		MOV	@#TPB,@#STPB	;FOR THE TYPE ROUTINE
3185	005144	005227	177777			INC	#-1	;FIRST START ?
3186	005150	001032				BNE	3\$	;BR IF NOT
3187	005152	023737	000042	000046		CMP	@#42,@#46	;ACT11 AUTOMATIC MODE?
3188	005160	001002				BNE	4\$	;YES, SKIP TITLE PRINTOUT
3189	005162	104401	047712			TYPE	,TITLE	;TYPE THE PROGRAM'S TITLE
3190	005166	005737	000042		4\$	TST	42	;AUTO ACCEPT OR CHAIN MODE ?
3191	005172	001006				BNE	2\$	;BR IF EITHER
3192	005174	122737	000011	000041		CMPB	#11,41	;LOADED FROM AN RPO4/5/6 ?
3193	005202	001002				BNE	2\$	;BR IF NOT
3194	005204	104401	050012			TYPE	,LOADRV	;INSTRUCT THE OPERATOR TO REMOVE THE PACK
3195								;ON DRIVE 0 IF DRIVE 0 IS TO BE TESTED
3196	005210	105737	000041		2\$	TSTB	@#41	;LOADED FROM PAPER TAPE ?
3197	005214	001410				BEQ	3\$	;BR IF NOT
3198	005216	004737	050306			JSR	PC,\$SIZE	;SIZE THE MEMORY
3199	005222	023727	050402	100000		CMP	\$LSTAD,#100000	;16K OR MORE ON THE SYSTEM ?
3200	005230	103002				BHIS	3\$	;BR IF YES
3201	005232	104401	050210			TYPE	,NOLOAD	;INFORM THE OPEATOR THAT THE 'XXDP' LOADER
3202								;WILL BE OVERWRITTEN
3203	005236	004737	021344		3\$	JSR	PC,\$TKINT	;TURN ON THE TTY KEYBOARD INTERRUPT
3204						SBTTL	GET VALUE FOR SOFTWARE	SWITCH REGISTER
3205	005242	005737	000042			TST	@#42	;ARE WE RUNNING UNDER XXDP/ACT?
3206	005246	001006				BNE	67\$	;BRANCH IF YES
3207	005250	023727	001140	000176		CMP	SWR,\$SWREG	;SOFTWARE SWITCH REG SELECTED?
3208	005256	001005				BNE	68\$	;BRANCH IF NO
3209	005260	104406				GTSWR		;GET SOFT-SWR SETTINGS
3210	005262	000403				BR	68\$	
3211	005264	112737	000001	001134	67\$	MOVB	#1,\$AUTOB	;SET AUTO-MODE INDICATOR
3212	005272				68\$			
3213	005272	005227	177777			INC	#-1	;SEE IF FIRST START
3214	005276	001002				BNE	SRTINT	;BR IF NOT
3215	005300	004737	050404			JSR	PC,GETADR	;GET OR CHECK THE RH11 ADDRESS
3216	005304	104401	001215		SRTINT	TYPE	,\$CRLF	;CR-LF
3217	005310	004737	024032			JSR	PC,@#LP AVL	;CHECK FOR A LINE PRINTER
3218	005314	005037	177776			CLR	@#PS	;ENSURE THE PRIORITY = 0
3219	005320	012737	000001	001104		MOV	#1,\$ICNT	;SET ITERATION COUNT TO 1
3220	005326	004737	031424			JSR	PC,@#GETSWR	;GO CHECK FOR CONTROL SWITCHES
3221	005332	004737	024074			JSR	PC,@#ST CLK	;INITIALIZE THE CLOCK
3222	005336	004737	034532		SETVEC	JSR	PC,RPINIT	;CHECK THE DRIVE STATUS
3223	005342	012737	177777	034454		MOV	#-1,\$SAVEFG	;SET THE SAVE REGISTERS FLAG
3224	005350	062727	177777	000000		ADD	#-1,#0	;FIRST START ?
3225	005356	103003				BCC	11\$	;BR IF YES
3226	005360	005737	001224			TST	CNTRLC	;CONTROL 'C' SWITCH SET ?
3227	005364	001102				BNE	SRTDRV	;CONTINUE IF YES
3228	005366	012737	000340	177776	11\$	MOV	#PR7,\$PS	;SET PRIORITY TO 7
3229	005374	005004				CLR	R4	;DRIVE TABLE POINTER
3230	005376	104401	001215			TYPE	, \$CRLF	;CR-LF
3231	005402	104401	043100			TYPE	,SYSTAT	;TYPE STATUS HEADING
3232	005406				1\$			
3233	005406	010446				MOV	R4,-(SP)	;SAVE R4 FOR TYPEOUT
3234								;TYPE DRIVE NUMBER
3235	005410	104403				TYPOS		;GO TYPE--OCTAL ASCII
3236	005412	002				BYTE	2	;TYPE 2 DIGIT(S)
3237	005413	000				BYTE	0	;SUPPRESS LEADING ZEROS
3238	005414	104401	044040			TYPE	,MSG SP	;SPACES
3239	005420	104401	044040			TYPE	,MSG SP	;SPACES

3240	005424	105764	034366		TSTB	DRVSTA(R4)		;CHECK DRIVE'S STATUS
3241	005430	100416			BMI	4%		;BR IF UNSAFE
3242	005432	001020			BNE	5%		;BR IF ONLINE
3243	005434	105764	034376		TSTB	DRVSTYP(R4)		;SEE IF OFFLINE OR NONEXISTENT
3244	005440	001404			BEQ	2%		;BR IF NONEXISTENT
3245	005442	100006			BPL	3%		;BR IF OFFLINE
3246	005444	104401	043174		TYPE	,NOTRP		;DRIVE NOT AN RPO4/5/6
3247	005450	000440			BR	9%		;CHECK NEXT DRIVE
3248	005452	104401	043147	2%	TYPE	,NOTPRS		;DRIVE NOT PRESENT
3249	005456	000435			BR	9%		;CHECK NEXT DRIVE
3250	005460	104401	043126	3%	TYPE	,UNTOFF		;DRIVE OFFLINE
3251	005464	000405			BR	6%		;PRINT DRIVE TYPE
3252	005466	104401	043164	4%	TYPE	,NOTSAF		;DRIVE UNSAFE
3253	005472	000402			BR	6%		;PRINT DRIVE TYPE
3254	005474	104401	043137	5%	TYPE	,UNTON		;DRIVE ONLINE
3255	005500	104401	044040	6%	TYPE	,MSG.SP		;SPACES
3256	005504	012737	043212	005550	MOV	#RPO4,8%		;ADDRESS OF RPO4 MESSAGE
3257	005512	132764	000001	034376	BITB	#BIT00,DRVSTYP(R4)		;RPO4 ?
3258	005520	001012			BNE	7%		;BR IF YES
3259	005522	012737	043217	005550	MOV	#RPO5,8%		;ADDRESS OF RPO5 MESSAGE
3260	005530	132764	000002	034376	BITB	#BIT01,DRVSTYP(R4)		;RPO5 ?
3261	005536	001003			BNE	7%		;BR IF YES
3262	005540	012737	043224	005550	MOV	#RPO6,8%		;ADDRESS OF RPO6 MESSAGE
3263	005546	104401		7%	TYPE			;TYPE THE DRIVE TYPE MESSAGE
3264	005550	000000		8%	WORD	0		;MESSAGE ADDRESS HERE
3265	005552	104401	001215	9%	TYPE	,%CRLF		;CR-LF
3266	005556	005204			INC	R4		;INCREMENT DRIVE NUMBER/TABLE POINTER
3267	005560	020427	000010		CMP	R4,#8		;FINISHED ?
3268	005564	001310			BNE	1%		;BR IF NOT
3269	005566	005037	177776		CLR	PS		;SET PRIORITY BACK TO '0'
3270	005572	005737	001224	SRTDRV	TST	@#CNTRLC		;CONTROL "C" START/RESTART?
3271	005576	001417			BEQ	1%		;NO--BRANCH
3272	005600	013746	001222		MOV	SAVCSW,-(SP)		;GET THE PREVIOUS 'C SWR' CONTENTS
3273	005604	063716	001220		ADD	C SWR,(SP)		;SET UP TO SEE IF 'BIT00' IS DIFFERENT
3274	005610	032726	000001		BIT	#BIT00,(SP)+		;IS 'BIT00' DIFFERENT ?
3275	005614	001405			BEQ	9%		;BR IF NOT
3276	005616	013737	001220	001222	MOV	C SWR,SAVCSW		;STORE PRESENT 'C SWR' VALUE
3277	005624	004737	024352		JSR	PC,LODFLT		;RESET PARAMETERS TO THEIR DEFAULT VALUES
3278	005630	004737	031654	9%	JSR	PC,@#GT PRM		;GET PARAMETERS
3279	005634	000420			BR	4%		
3280	005636	004737	024352	1%	JSR	PC,LODFLT		;SETUP DEFAULT PARAMETERS
3281	005642	005037	001232		CLR	DRVSEL		;NO DRIVES SELECTED
3282	005646	005000			CLR	R0		;DETERMINE THE DRIVES THAT
3283	005650	012701	000001		MOV	#1,R1		;ARE AVAILABLE FOR TESTING
3284	005654	105760	034366	2%	TSTB	DRVSTA(R0)		
3285	005660	003403			BLE	3%		
3286	005662	156037	034502	001232	BISB	ATABIT(R0),@#DRVSEL		
3287	005670	005200		3%	INC	R0		
3288	005672	106301			ASLB	R1		
3289	005674	001367			BNE	2%		
3290	005676	005037	034456	4%	CLR	@#SEEKFG		;CLEAR SEEK FLAG
3291	005702	032737	000400	001220	BIT	#SW08,@#C SWR		;DO SEEK BEFORE DATA TRANSFER?
3292	005710	001002			BNE	5%		;YES--BRANCH
3293	005712	005137	034456		COM	@#SEEKFG		;NO
3294	005716	122737	000011	000041	CMPB	#11,41		;LOADED FROM AN RPO4/5/6 ?
3295	005724	001003			BNE	10%		;BR IF NOT

```

3296 005726 042737 000001 001232      BIC      #BIT00,DRVSEL ;CLEAR THE DRIVE 0 SELECTION BIT
3297 005734 104401 043231      TYPE    ,DRIVES    ;'DRIVES(S) TO BE TESTED'
3298 005740 005037 017550      CLR     @#SENDCT   ;DETERMINE PASSES TO MAKE AND
3299 005744 005000                CLR     R0         ;THE DRIVES TO BE TESTED
3300 005746 013701 001232      MOV     @#DRVSEL,R1 ;ANY DRIVES SELECTED?
3301 005752 001004                BNE     6$        ;YES--BRANCH
3302 005754 104401 043262      TYPE    ,NONE     ;'NONE'
3303
3304 005760 000137 017366                JMP     @#SEOP    ;GO TO END OF PROGRAM
3305 005764 006201                ASR     R1        ;REPORT THE DRIVES TO BE TESTED
3306 005766 103011                BCC     7$
3307 005770 005237 017550      INC     @#SENDCT   ;GIVE THIS DRIVE A PASS
3308 005774 010046                MOV     R0,-(SP)  ;;SAVE R0 FOR TYPEOUT
3309 005776 104403                TYPOS   ;GO TYPE--OCTAL ASCII
3310 006000 001                .BYTE  1         ;;TYPE 1 DIGIT(S)
3311 006001 000                .BYTE  0         ;;SUPPRESS LEADING ZEROS
3312 006002 005701                TST     R1        ;MORE DRIVES?
3313 006004 001404                BEQ     8$        ;NO--BRANCH
3314 006006 104401 043267      TYPE    ,COMMA    ;
3315 006012 005200                INC     R0        ;FORM DRIVE NUMBER
3316 006014 000763                BR      6$
3317 006016 013737 017550 017542 8$      MOV     @#SENDCT,@#SEOPCT
3318 006024 005737 001244                TST     @#CLKSTA  ;KW11-P AVAILABLE
3319 006030 003006                BGT     RSTRT1   ;YES--BRANCH
3320 006032 032737 036000 001234      BIT     #36000,@#TSTNMS ;NO--ANY TIMING TESTS TO BE PERFORMED?
3321 006040 001402                BEQ     RSTRT1   ;NO--BRANCH
3322 006042 104401 043271                TYPE    ,NOCLOK  ;'NO KW11-P CLOCK, TIMING TESTS WILL NOT BE PERFORMED'
3323 006046 005737 001232      RSTRT1 TST     DRVSEL ;ANY DRIVES SELECTED ?
3324 006052 001002                BNE     1$       ;BR IF YES
3325 006054 000137 004660                JMP     START2   ;GET DRIVE SELECTION ENTRY
3326 006060 005037 001254                CLR     CHKDRV   ;INIT. THE CHECK DRIVE KEY
3327 006064 012737 000001 001256      MOV     #1,DRVMSK ;START TO CHECK DESIRED DRIVES
3328 006072 033737 001256 001232  RSTRT2 BIT     DRVMSK,DRVSEL ;IS THIS DRIVE SELECTED?
3329 006100 001010                BNE     DRVOK    ;YES--GO CHECK IF DRIVE IS READY FOR TESTING
3330 006102 012706 001100      RESTART MOV    #STACK,SP ;SETUP THE STACK POINTER
3331 006106 005237 001254                INC     CHKDRV   ;MOVE TO NEXT DRIVE NUMBER
3332 006112 106337 001256                ASLB   DRVMSK   ;POSITION THE MASK
3333 006116 103753                BCS     RSTRT1  ;BRANCH IF THE DRIVE NUMBER NEEDS INITIALIZED
3334 006120 000764                BR      RSTRT2
3335
3336 006122 013702 001254                DRVOK  MOV     CHKDRV,R2 ;PICKUP THE DRIVE NUMBER
3337 006126 105762 034366                TSTB   DRVSTA(R2) ;IS DESIRED DRIVE ON-LINE?
3338 006132 003005                BGT     1$       ;YES, BRANCH
3339 006134 104011                ERROR  11         ;DRIVE SELECTED IS NOT ONLINE
3340 006136 043737 001256 001232      BIC     DRVMSK,DRVSEL ;CLEAR DRIVE'S SELECTION BIT
3341 006144 000756                BR      RESTART  ;RETURN
3342 006146 010237 004104                1$    MOV     R2,@#DPB A ;SET THE DRIVE NUMBER INTO THE DPB'S
3343 006152 010237 004124                MOV     R2,@#DPB B
3344 006156 010237 004144                MOV     R2,@#DPB C
3345 006162 010237 004164                MOV     R2,@#DTADPB
3346 006166 004737 024766                JSR     PC,@#LDCMD ;LOAD COMMAND INTO DPB B AND DPB C
3347 006172 012737 017366 001252      MOV     #SEOP,@#BYPASS ;IF ERROR GO TO END OF PROGRAM
3348 006200 112737 000020 004105      MOVB   #FMT22/256,DPB A+1 ;ASSUME 16 BIT FORMAT
3349 006206 032737 000001 001220      BIT     #BIT00,C.SWR ;16 BIT FORMAT REQUESTED ?
3350 006214 001402                BEQ     2$       ;BR IF YES
3351 006216 105037 004105                CLRB   DPB A+1  ;CLEAR THE 'FMT22' BIT
    
```

```

3352 006222 112737 000143 004106 25:  MOVB  #SETFORM,DPB.A+2 ;SET THE FORMAT BIT PER DPB.A+1
3353 006230 004037 025032      JSR   RO,@#CALL.A ;GO EXECUTE THE COMMAND
3354 006234 112737 000107 004106      MOVB  #RECAL,@#DPB.A+2 ;RECAL=COMMAND
3355 006242 004037 025032      JSR   RO,@#CALL.A ;GO EXECUTE THE COMMAND
3356 006246 104401 043357      TYPE  ,TESTNG ;'TESTING DRIVE'
3357 006252 010246      MOV   R2,-(SP) ;SAVE R2 FOR TYPEOUT
3358 006254 104403      TYPOS ;GO TYPE--OCTAL ASCII
3359 006256 001      .BYTE 1 ;TYPE 1 DIGIT(S)
3360 006257 000      .BYTE 0 ;SUPPRESS LEADING ZEROS
3361 006260 104401 044040      TYPE  ,MSG SP ;TYPE SPACES
3362 006264 104401 043401      TYPE  ,SERIAL ;'SERIAL NUMBER'
3363 006270 012700 000004      MOV   #4,R0 ;FOUR DIGITS TO TYPE
3364 006274 013701 004234      MOV   RP,REG+30,R1 ;SERIAL NUMBER
3365 006300 005002      CLR   R2 ;ZERO
3366 006302 006101      ROL   R1 ;PUT THE NEXT DIGIT
3367 006304 006102      ROL   R2 ;INTO R2
3368 006306 006101      ROL   R1
3369 006310 006102      ROL   R2
3370 006312 006101      ROL   R1
3371 006314 006102      ROL   R2
3372 006316 006101      ROL   R1
3373 006320 006102      ROL   R2
3374 006322 062702 000060      ADD   #'0',R2 ;MAKE IT ASCII
3375 006326 010227      MOV   R2,(PC)+ ;SAVE IT
3376 006330 000000      WORD 0
3377 006332 104401 006330      TYPE  ,4$ ;TYPE
3378 006336 005300      DEC   R0 ;ALL DIGITS TYPED?
3379 006340 003357      BGT   3$ ;NO -- BRANCH
3380 006342 104401 001215      TYPE  ,%CRLF
3381 006346 113737 001364 001115      MOVB  ERR CT,%SERMAX ;SETUP MAX ERROR COUNT
    
```



```

3438
3439 ;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE
3440 ;* COMMAND CYCLE AND THEN SEEK FORWARD TO CYLINDER "LC" AT
3441 ;* THE COMPLETION OF BOTH COMMANDS STATUS INDICATIONS ARE
3442 ;* CHECKED TO ENSURE NO ERRORS OCCURRED.
3443
3444 ;*****
3445 TST0:
3446 006354 000240 NOP
3447 006356 033737 001424 001234 BIT @#BITS+(0*2),TSTNMS ;DO THIS TEST?
3448 006364 001002 BNE 64$ ;YES--BRANCH
3449 006366 000137 006516 JMP TST1 ;NO--GO TO THE NEXT TEST
3450 006372 012737 000000 001102 64$: MOV #0,@#STSTNM ;SET UP TEST NUMBER AND
3451 ;CLEAR THE ERROR FLAG (SERFLG)
3452 006400 004737 024610 JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
3453 006404 012737 006500 001110 MOV #TEST0,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3454 006412 013777 001102 172522 MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3455 006420 013737 001506 001204 MOV @RPT,$TIMES ;GET THE ITERATION COUNT
3456 006426 112737 000031 001115 MOVB #25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
3457 006434 112737 000107 004106 MOVB #RECAL,@DPB.A+2 ;RECAL=COMMAND
3458 006442 113737 001524 004134 MOVB @#FS,@DPB.B+10 ;FS
3459 006450 113737 001516 004135 MOVB @#FT,@DPB.B+11 ;FT
3460 006456 013737 001512 004136 MOV @#LC,@DPB.B+12 ;LC
3461 006464 012737 006514 001252 MOV #EXIT0,@#BYPASS ;GO TO EXIT0 ON ERROR
3462 006472 012737 006500 001106 MOV #TEST0,$LPADR ;SETUP LOOP ADDRESS
3463 006500 012706 001100 TEST0 MOV #STACK,$P ;SET UP STACK POINTER
3464 006504 004037 025J32 JSR RD,@CALL.A ;GO EXECUTE THE COMMAND
3465 006510 004037 025144 JSR RD,@CALL.B ;GO EXECUTE THE COMMAND
3466 006514 000004 EXIT0. SCOPE ;LOOP
3467
3468 ;*****
3469 ;*TEST 1 SEEK/SEEK TEST
3470
3471 ;* THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK
3472 ;* CYCLE TO "LC", "LT", "LS" FOLLOWED BY A REVERSE SEEK CYCLE TO
3473 ;* "FC", "FT", "FS". AT THE COMPLETION OF EACH SEEK, THE PROPER
3474 ;* INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION
3475 ;* "LC" WILL DEFAULT TO 128 AND "FC", "FT", "LT", "FS", AND "LS"
3476 ;* WILL DEFAULT TO 0
3477
3478 ;*****
3479 TST1:
3480 006516 000240 NOP
3481 006520 033737 001426 001234 BIT @#BITS+(1*2),TSTNMS ;DO THIS TEST?
3482 006526 001002 BNE 64$ ;YES--BRANCH
3483 006530 000137 006674 JMP TST2 ;NO--GO TO THE NEXT TEST
3484 006534 012737 000001 001102 64$: MOV #1,@#STSTNM ;SET UP TEST NUMBER AND
3485 ;CLEAR THE ERROR FLAG (SERFLG)
3486 006542 004737 024610 JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
3487 006546 012737 006656 001110 MOV #TEST1,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3488 006554 013777 001102 172360 MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3489 006562 013737 001506 001204 MOV @RPT,$TIMES ;GET THE ITERATION COUNT
3490 006570 112737 000031 001115 MOVB #25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
3491 006576 113737 001524 004134 MOVB @#FS,@DPB.B+10 ;FS
3492 006604 113737 001526 004154 MOVB @#LS,@DPB.C+10 ;LS
3493 006612 113737 001516 004135 MOVB @#FT,@DPB.B+11 ;FT

```

```

3494 006620 113737 001520 004155      MOV      @#LT,@#DPB.C+11 ;LT
3495 006626 013737 001510 004136      MOV      @#FC,@#DPB.B+12 ;FC
3496 006634 013737 001512 004156      MOV      @#LC,@#DPB.C+12 ;LC
3497 006642 012737 006672 001252      MOV      #EXIT1,@#BYPASS ;GO TO EXIT1 ON ERROR
3498 006650 012737 006656 001106      MOV      #TEST1,$LPADR ;SETUP LOOP ADDRESS
3499 006656 012706 001100      TEST1:  MOV      #STACK,SP ;SET THE STACK POINTER
3500 006662 004037 025334      JSR      RO,@#CALL.C ;GO EXECUTE THE COMMAND
3501 006666 004037 025144      JSR      RO,@#CALL.B ;GO EXECUTE THE COMMAND
3502 006672 000004      EXIT1:  SCOPE ;LOOP
3503
3504      , ,*****
3505      ;*TEST 2      INCREMENT/SEEK TEST
3506
3507      ,*      THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
3508      ,*      CYLINDER ADDRESS FROM "FC" TO "LC" BY THE INCREMENT "IC"
3509      ,*      WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS
3510      ,*      "LC" REVERSE SEEK CYCLES ARE INITIATED; STARTING
3511      ,*      AT THE LAST LEGAL "NC" AND DECREMENTING BY "IC"
3512      ,*      UNTIL "NC" IS LESS THAN "FC". AT THE COMPLETION OF EACH
3513      ,*      SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
3514      ,*      ENSURE PROPER OPERATION.
3515
3516      , ,*****
3517      TST2
3518 006674 000240      NOP
3519 006676 033737 001430 001234      BIT      @#BITS+(2*2),TSTNMS ,DO THIS TEST?
3520 006704 001002      BNE      645 ;YES--BRANCH
3521 006706 000137 007112      JMP      TST3 ;NO--GO TO THE NEXT TEST
3522 006712 012737 000002 001102 645      MOV      #2,@#STSTNM ;SET UP TEST NUMBER AND
3523      ;CLEAR THE ERROR FLAG ($ERFLG)
3524 006720 004737 024610      JSR      PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
3525 006724 012737 007004 001110      MOV      #TEST2,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3526 006732 013777 001102 172202      MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3527 006740 013737 001506 001204      MOV      @#RPT,$TIMES ;GET THE ITERATION COUNT
3528 006746 112737 000031 001115      MOV      #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
3529 006754 012737 006762 001106      MOV      #15,$LPADR ;SETUP LOOP ADDRESS
3530 006762 113737 001524 004134 15      MOV      @#FS,@#DPB.B+10 ;FS
3531 006770 113737 001516 004135      MOV      @#FT,@#DPB.B+11 ;FT
3532 006776 012737 007110 001252      MOV      #EXIT2,@#BYPASS ;GO TO EXIT2 ON ERROR
3533 007004 013737 001510 004136      TEST2:  MOV      @#FC,@#DPB.B+12 ;FC
3534 007012 012737 007012 001110      MOV      #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
3535 007020 012706 001100      MOV      #STACK,SP ;LOAD THE STACK POINTER
3536 007024
3537 007024 004037 025144      INCSK   JSR      RO,@#CALL.B ;GO EXECUTE THE COMMAND
3538 007030 063737 001514 004136      ADD      @#IC,@#DPB.B+12 ;MOVE TO NEXT CYLINDER
3539 007036 023737 001512 004136      CMP      @#LC,@#DPB.B+12 ;OUT OF CYLINDERS?
3540 007044 002367      BGE      INCSK ;NO--BRANCH
3541 007046 013737 001512 004136      MOV      @#LC,@#DPB.B+12
3542 007054 012737 007054 001110      MOV      #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
3543 007062 012706 001100      MOV      #STACK,SP ;LOAD THE STACK POINTER
3544 007066
3545 007066 004037 025144      DECSK   JSR      RO,@#CALL.B ;GO EXECUTE THE COMMAND
3546 007072 163737 001514 004136      SUB      @#IC,@#DPB.B+12
3547 007100 023737 001510 004136      CMP      @#FC,@#DPB.B+12
3548 007106 003767      BLE      DECSK
3549 007110 000004      EXIT2:  SCOPE ;LOOP
    
```

```

3550
3551      ;*****
3552      *TEST 3      STEPPING SEEK TEST
3553
3554      *      THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0,1,2,4,
3555      *      8,16,32,64,128, AND 256. AT THE COMPLETION OF EACH SEEK
3556      *      COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER
3557      *      OPERATION.
3558
3559      ;*****
3560      TST3
3561      007112      000240      NOP
3562      007114      033737      001432      001234      BIT      @#BITS+<3*2>,TSTNMS ;DO THIS TEST?
3563      007122      001002      BNE      645          ;YES--BRANCH
3564      007124      000137      007306      JMP      TST4          ;NO--GO TO THE NEXT TEST
3565      007130      012737      000003      001102      645      MOV      #3,@#STSTNM      ;SET UP TEST NUMBER AND
3566      ;CLEAR THE ERROR FLAG (SERFLG)
3567      007136      004737      024610      JSR      PC,LODPRM      ;LOAD THE PARMETERS FOR THE TEST
3568      007142      012737      007222      001110      MOV      #TEST3,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3569      007150      013777      001102      171764      MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3570      007156      013737      001506      001204      MOV      @#RPT,$TIMES    ;GET THE ITERATION COUNT
3571      007164      112737      000031      001115      MOVB     #25,$SERMAX     ;MAX ERRORS ALLOWED FOR TEST
3572      007172      012737      007200      001106      MOV      #15,$LPADR     ;SETUP TEST LOOP ADDRESS
3573      007200      113737      001524      004134      15      MOVB     @#FS,@#DPB.B+10 ;FS
3574      007206      113737      001516      004135      MOVB     @#FT,@#DPB.B+11 ;FT
3575      007214      012737      007304      001252      MOV      #EXIT3,@#BYPASS ;GO TO BYPASS ON ERROR
3576      007222      013737      001510      004136      TEST3   MOV      @#FC,@#DPB.B+12 ;FC
3577      007230      012737      007230      001110      MOV      #,$SLPERR      ;SETUP THE ERROR LOOP ADDRESS
3578      007236      012706      001100      MOV      #STACK,SP      ;LOAD THE STACK POINTER
3579      007242      004037      025144      JSR      RO,@#CALL B    ;GO EXECUTE THE COMMAND
3580      007246      013701      001514      MOV      IC,R1          ;CYLINDER 1
3581      007252      012737      007252      001110      MOV      #,$SLPERR      ;SETUP THE ERROR LOOP ADDRESS
3582      007260      012706      001100      MOV      #STACK,SP      ;LOAD THE STACK POINTER
3583      007264      010137      004136      15      MOV      R1,@#DPB.B+12  ;DESIRED CYLINDER
3584      007270      004037      025144      JSR      RO,@#CALL B    ;GO EXECUTE THE COMMAND
3585      007274      006301      ASL      R1            ;MOVE TO NEXT CYLINDER
3586      007276      020137      001512      CMP      R1,@#LC       ;DONE?
3587      007302      003770      BLE      15           ;NO--LOOP
3588      007304      000004      EXIT3.   SCOPE
3589
3590      ;*****
3591      *TEST 4      OSCILLATING SEEK TEST
3592
3593      *      THIS TEST WILL COMMAND SEEK CYCLES FROM "FC" TO "NC" AND BACK
3594      *      TO "FC". "NC" STARTS AT "FC" AND INCREMENTS BY "IC" UP TO CYLINDER
3595      *      "LC", THEN IS DECREMENTED BY "IC" BACK TO CYLINDER "FC" AT THE
3596      *      COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE
3597      *      EXAMINED TO ENSURE PROPER OPERATION
3598
3599      ;*****
3600      TST4
3601      007306      000240      NOP
3602      007310      033737      001434      001234      BIT      @#BITS+<4*2>,TSTNMS ;DO THIS TEST?
3603      007316      001002      BNE      645          ;YES--BRANCH
3604      007320      000137      007674      JMP      TST5          ;NO--GO TO THE NEXT TEST
3605      007324      012737      000004      001102      645      MOV      #4,@#STSTNM      ;SET UP TEST NUMBER AND
    
```

```

3606                                     ;CLEAR THE ERROR FLAG ($ERFLG)
3607 007332 004737 024610                JSR  PC,LOOPRM                    ;LOAD THE PARMETERS FOR THE TEST
3608 007336 012737 007432 001110        MOV  #TEST4,@$SLPERR             ;SETUP THE LOOP ON ERROR ADDRESS
3609 007344 013777 001102 171570        MOV  $STNM,@DISPLAY             ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3610 007352 013737 001506 001204        MOV  @#RPT,$TIMES              ;GET THE ITERATION COUNT
3611 007360 112737 000031 001115        MOV  #25,$SERMAX              ;MAX ERRORS ALLOWED FOR TEST
3612 007366 012737 007374 001106        MOV  #1$, $LPADR              ;SETUP LOOP ADDRESS
3613 007374 113737 001524 004134 15     MOV  @#FS,@#DPB.B+10          ;FS
3614 007402 113737 001516 004135        MOV  @#FT,@#DPB.B+11          ;FT
3615 007410 012737 007672 001252        MOV  #EXIT4,@#BYPASS          ;GO TO EXIT4 ON ERROR
3616 007416 005002                        CLR  R2                        ;CLEAR STALL SWITCH (NO STALL)
3617 007420 032737 010000 001220        BIT  #SW12,@#C.SWR            ;STALL REQUIRED?
3618 007426 001401                        BEQ  TEST4                     ;NO--BRANCH
3619 007430 005102                        COM  R2                        ;YES--SET SWITCH
3620 007432 013701 001510                TEST4 MOV @#FC,R1                 ;SET NC TO FC
3621 007436 005037 001336                CLR  @#STALLO                 ;START AT ZERO IF STALLS REQUIRED
3622 007442 012737 007442 001110        MOV  #,$SLPERR                ;SETUP THE ERROR LOOP ADDRESS
3623 007450 012706 001100                MOV  #STACK,SP               ;LOAD THE STACK POINTER
3624 007454 010137 004136 15           MOV  R1,@#DPB.B+12            ;NC
3625 007460 004037 025144                JSR  RD,@#CALL B              ;GO EXECUTE THE COMMAND
3626 007464 005702                        TST  R2                        ;STALL?
3627 007466 001403                        BEQ  25                        ;NO--BRANCH
3628 007470 004037 026364                JSR  RD,@#STALL              ;YES-GO TO STALL ROUTINE
3629 007474 001336                WORD STALLO                    ;TIME POINTER
3630 007476 013737 001510 004136 25     MOV  FC,@#DPB.B+12           ;FC
3631 007504 004037 025144                JSR  RD,@#CALL B              ;GO EXECUTE THE COMMAND
3632 007510 005702                        TST  R2                        ;STALL?
3633 007512 001413                        BEQ  35                        ;NO--BRANCH
3634 007514 004037 026364                JSR  RD,@#STALL              ;YES--GO TO STALL ROUTINE
3635 007520 001336                WORD STALLO                    ;TIME POINTER
3636 007522 005237 001336                INC  @#STALLO                 ;UPDATE THE TIME
3637 007526 023737 001362 001336        CMP  @#MXSTAL,@#STALLO       ;TIME TOO BIG?
3638 007534 003347                        BGT  15                        ;NO--BRANCH
3639 007536 005037 001336                CLR  @#STALLO                 ;YES--START OVER AT ZERO
3640 007542 063701 001514 35           ADD  @#IC,R1                  ;MOVE TO NEXT CYLINDER
3641 007546 020137 001512                CMP  R1,@#LC                  ;LAST CYLINDER COMPLETED?
3642 007552 003740                        BLE  15                        ;NO--BRANCH
3643 007554 013701 001512                MOV  @#LC,R1                  ;SET NC TO LC
3644 007560 012737 007560 001110        MOV  #,$SLPERR                ;SETUP THE ERROR LOOP ADDRESS
3645 007566 012706 001100                MOV  #STACK,SP               ;LOAD THE STACK POINTER
3646 007572 010137 004136 45           MOV  R1,@#DPB B+12           ;NC
3647 007576 004037 025144                JSR  RD,@#CALL B              ;GO EXECUTE THE COMMAND
3648 007602 005702                        TST  R2                        ;STALL?
3649 007604 001403                        BEQ  55                        ;NO--BRANCH
3650 007606 004037 026364                JSR  RD,@#STALL              ;YES--GO TO STALL ROUTINE
3651 007612 001336                WORD STALLO                    ;TIME POINTER
3652 007614 013737 001512 004136 55     MOV  @#LC,@#DPB B+12         ;LC
3653 007622 004037 025144                JSR  RD,@#CALL B              ;GO EXECUTE THE COMMAND
3654 007626 005702                        TST  R2                        ;STALL?
3655 007630 001413                        BEQ  65                        ;NO--BRANCH
3656 007632 004037 026364                JSR  RD,@#STALL              ;YES--GO TO STALL ROUTINE
3657 007636 001336                WORD STALLO                    ;TIME POINTER
3658 007640 005237 001336                INC  @#STALLO                 ;UPDATE STALL TIME
3659 007644 023737 001362 001336        CMP  @#MXSTAL,@#STALLO       ;TIME TOO BIG?
3660 007652 003347                        BGT  45                        ;NO--BRANCH
3661 007654 005037 001336                CLR  @#STALLO                 ;YES--SET STALL TIME BACK TO ZERO
    
```

```

3662 007660 163701 001514      65      SUB      @#IC,R1      ;NEXT CYLINDER
3663 007664 020137 001510      CMP      R1,@#FC      ;DONE?
3664 007670 002340      BGE      45           ;NO--BRANCH
3665 007672 000004      EXIT4·   SCOPE       ;LOOP
3666
3667      ;,*****
3668      ;*TEST 5      CONVERGING/DIVERGING SEEK TEST
3669
3670      ;*      THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE
3671      ;*      SEEKS FROM "NC1" AND "NC2" RESPECTIVELY, "NC1" WILL BE INCREMENTED
3672      ;*      BY "IC" AND "NC2" WILL BE DECREMENTED BY "IC" UNTIL "NC1" IS
3673      ;*      GREATER THAN THE INITIAL VALUE OF "NC2" AND "NC2" IS
3674      ;*      LESS THAN THE INITIAL VALUE OF "NC1". AT THE COMPLETION OF
3675      ;*      EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
3676      ;*      ENSURE PROPER OPERATION. "NC1" AND "NC2" DEFAULT TO
3677      ;*      "FC" AND "LC" RESPECTIVELY
3678
3679      ;,*****
3680      TST5
3681      NOP
3682 007674 000240      BIT      @#BITS+<5*2>,TSTNMS ;DO THIS TEST?
3683 007676 033737 001436 001234      BNE      645         ;YES--BRANCH
3684 007704 001002      JMP
3685 007706 000137 010074      JMP      TST6        ;NO--GO TO THE NEXT TEST
3686 007712 012737 000005 001102 645      MOV      #5,@#STSTNM ;SET UP TEST NUMBER AND
3687      ;CLEAR THE ERROR FLAG (SERFLG)
3688 007720 004737 024610      JSR      PC,LODPRM   ;LOAD THE PARMETERS FOR THE TEST
3689 007724 012737 010004 001110      MOV      #TEST5,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3690 007732 013777 001102 171202      MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3691 007740 013737 001506 001204      MOV      @#RPT,$TIMES ;GET THE ITERATION COUNT
3692 007746 112737 000031 001115      MOV      #25,$SERMAX  ;MAX ERRORS ALLOWED FOR TEST
3693 007754 012737 007762 001106      MOV      #15,$LPADR   ;SETUP LOOP ADDRESS
3694 007762 113737 001524 004134 15      MOV      @#FS,@#DPB.B+10 ;FS
3695 007770 113737 001516 004135      MOV      @#FT,@#DPB.B+11 ;FT
3696 007776 012737 010072 001252      MOV      #EXITS,@#BYPASS ;GO TO EXITS ON ERROR
3697 010004 013701 001510      TEST5   MOV      @#FC,R1   ;START NC1 AT FC
3698 010010 013702 001512      MOV      @#LC,R2     ;START NC2 AT LC
3699 010014 012737 010014 001110      MOV      #,$SLPERR   ;SETUP THE ERROR LOOP ADDRESS
3700 010022 012706 001100      MOV      #STACK,SP   ;LOAD THE STACK POINTER
3701 010026 010137 004136 15      MOV      R1,@#DPB.B+12 ;NC1
3702 010032 004037 025144      JSR      RD,@#CALL.B ;GO EXECUTE THE COMMAND
3703 010036 010237 004136      MOV      R2,@#DPB.B+12 ;NC2
3704 010042 004037 025144      JSR      RD,@#CALL.B ;GO EXECUTE THE COMMAND
3705 010046 063701 001514      ADD      @#IC,R1     ;NEXT NC1
3706 010052 163702 001514      SUB      @#IC,R2     ;NEXT NC2
3707 010056 020137 001512      CMP      R1,@#LC     ;DONE?
3708 010062 003003      BGT      EXITS       ;YES--BRANCH
3709 010064 020237 001510      CMP      R2,@#FC,?   ;
3710 010070 002356      BGE      15          ;NO--BRANCH
3711 010072 000004      EXIT5·   SCOPE       ;LOOP
3712
3713      ;,*****
3714      ;*TEST 6      SERVO ADDRESSING LOGIC NOISE GENERATOR
3715
3716      ;*      IN THIS TEST A SEEK IS DONE TO CYL "NC" THEN A SEEK TO
3717      ;*      NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5 NOW "NC" IS UPDATED
3718      ;*      BY "IC" AND THE ABOVE SEQUENCE IS REPEATED UNTIL "LC" IS
    
```

```

3718 ,* EXCEEDED BY ANY OF THE ABOVE VALUES THE INITIAL VALUE -- "NC"
3719 ,* IS "FC". AT THE COMPLETION OF EACH SEEK COMMAND THE
3720 ,* PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
3721
3722 ,;*****
3723 TST6
3724 010074 000240 NOP
3725 010076 033737 001440 001234 BIT @#BITS+<6*2>,TSTNMS ;DO THIS TEST?
3726 010104 001002 BNE 645 ;YES--BRANCH
3727 010106 000137 010340 JMP TST7 ;NO--GO TO THE NEXT TEST
3728 010112 012737 000006 001102 645: MOV #6,@#STSTNM ;SET UP TEST NUMBER AND
3729 ;CLEAR THE ERROR FLAG (SERFLG)
3730 010120 004737 024610 JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
3731 010124 012737 010204 001110 MOV #TEST6,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
3732 010132 013777 001102 171002 MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3733 010140 013737 001506 001204 MOV @#RPT,$TIMES ;GET THE ITERATION COUNT
3734 010146 112737 000031 001115 MOVB #25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
3735 010154 012737 010162 001106 MOV #15,$LPADR ;SETUP LOOP ADDRESS
3736 010162 113737 001524 004134 15: MOVB @#FS,@#DPB.B+10 ;FS
3737 010170 113737 001516 004135 MOVB @#FT,@#DPB.B+11 ;FT
3738 010176 012737 010336 001252 MOV #EXIT6,@#BYPASS ;GO TO EXIT6 ON ERROR
3739 010204 013701 001510 TEST6 MOV @#FC,R1 ;PICKUP "FC"
3740 010210 013702 001512 MOV @#LC,R2 ;FORM LAST CYLINDER THAT
3741 010214 162702 000005 SUB #5,R2 ;IS AVAILABLE FOR TESTING
3742 010220 012737 010220 001110 MOV #,$SLPERR ;SETUP THE ERROR LOOP ADDRESS
3743 010226 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
3744 010232 020102 15 CMP R1,R2 ;LAST CYLINDER
3745 010234 003040 BGT EXIT6 ;YES--BRANCH
3746 010236 010137 004136 MOV R1,@#DPB.B+12 ;NC
3747 010242 004037 025144 JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
3748 010246 062737 000004 004136 ADD #4,@#DPB.B+12 ;NC+4
3749 010254 004037 025144 JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
3750 010260 162737 000003 004136 SUB #3,@#DPB.B+12 ;NC+1
3751 010266 004037 025144 JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
3752 010272 062737 000002 004136 ADD #2,@#DPB.B+12 ;NC+3
3753 010300 004037 025144 JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
3754 010304 162737 000001 004136 SUB #1,@#DPB.B+12 ;NC+2
3755 010312 004037 025144 JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
3756 010316 062737 000003 004136 ADD #3,@#DPB.B+12 ;NC+5
3757 010324 004037 025144 JSR RD,@#CALL.B ;GO EXECUTE THE COMMAND
3758 010330 063701 001514 ADD @#IC,R1
3759 010334 000736 BR 15
3760 010336 000004 EXIT6: SCOPE ;LOOP
3761
3762 ,;*****
3763 ,*TEST 7 RANDOM SEEK TEST
3764
3765 ,* THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC'
3766 ,* 'LC'. AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY
3767 ,* READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK.
3768 ,* THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION
3769 ,* OF POSITIONING OCCURS USING EACH HEAD TRACK ADDRESSES ARE INCREMENTED
3770 ,* BETWEEN PARAMTERS 'FT' AND 'LT'
3771
3772 ,;*****
3773 010340 TST?
    
```

3774	010340	000240				NOP		
3775	010342	033737	001442	001234		BIT	2#BITS+<7*2>,TSTNMS	; DO THIS TEST?
3776	010350	001002				BNE	64\$	; YES--BRANCH
3777	010352	000137	010720			JMP	TST10	; NO--GO TO THE NEXT TEST
3778	010356	012737	000007	001102	64\$	MOV	#7,2#STSTNM	; SET UP TEST NUMBER AND
3779								; CLEAR THE ERROR FLAG (\$ERFLG)
3780	010364	004737	024610			JSR	PC,LODPRM	; LOAD THE PARAMETERS FOR THE TEST
3781	010370	012737	010462	001110		MOV	#TEST7,2#SLPERR	; SETUP THE LOOP ON ERROR ADDRESS
3782	010376	013777	001102	170536		MOV	\$STSTNM,2DISPLAY	; LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
3783	010404	013737	001506	001204		MOV	2#RPT,\$TIMES	; GET THE ITERATION COUNT
3784	010412	112737	000031	001115		MOVB	#25,\$ERMAX	; MAX ERRORS ALLOWED FOR TEST
3785	010420	113737	001516	004135		MOVB	FT,DPB.B+11	; LOAD STARTING TRACK ADDRESS
3786	010426	112737	000105	004106		MOVB	#SEEK,2#DPB.A+2	; SEEK=COMMAND
3787	010434	112737	000173	004126		MOVB	#READHD,DPB.B+2	; READ HEADER & DATA COMMAND
3788	010442	013704	034514			MOV	RPADR,R4	; UNIBUS ADDRESS OF THE RH11
3789	010446	012737	010716	001252		MOV	#EXIT7,BYPASS	; ERROR TERMINATION ADDRESS
3790	010454	012737	010462	001106		MOV	#TEST7,\$LPADR	; SETUP THE LOOP ON TEST ADDRESS
3791	010462	012706	001100		TEST7	MOV	#STACK,SP	; SETUP THE STACK POINTER
3792	010466	013737	001510	004136		MOV	FC,DPB.B+12	; INITIAL CYLINDER ADDRESS
3793	010474	023737	001510	001512		CMP	FC,LC	; CYLINDER LIMITS THE SAME ?
3794	010502	001422				BEQ	1\$	; BR IF THEY ARE
3795	010504	004737	023510			JSR	PC,\$RAND	; CYCLE THE RANDOM NUMBER GENERATOR
3796	010510	013746	023606			MOV	\$HINUM,-(SP)	; USE THE HIGH RANDOM NUMBER
3797	010514	005046				CLR	-(SP)	; UPPER DIVIDEND
3798	010516	013746	001512			MOV	LC,-(SP)	; FORM THE DIVISOR
3799	010522	005216				INC	(SP)	; INCREMENT
3800	010524	163716	001510			SUB	FC,(SP)	; SUBTRACT THE LOWER LIMIT
3801	010530	004737	023612			JSR	PC,\$DIV	; DIVIDE
3802	010534	062637	004136			ADD	(SP)+,DPB.B+12	; ADD THE REMAINDER TO THE INITIAL CYLINDER
3803	010540	005726				TST	(SP)+	; DISCARD THE QUOTIENT
3804	010542	013737	004136	004116		MOV	DPB.B+12,DPB.A+12	; COPY NEW CYLINDER ADDRESS
3805	010550				15			
3806	010550	012737	010550	001110		MOV	,\$SLPERR	; SETUP THE ERROR LOOP ADDRESS
3807	010556	012706	001100			MOV	#STACK,SP	; LOAD THE STACK POINTER
3808	010562	004037	025032			JSR	RD,2#CALL.A	; GO EXECUTE THE COMMAND
3809	010566	012737	010566	001110		MOV	,\$SLPERR	; SETUP THE ERROR LOOP ADDRESS
3810	010574	012706	001100			MOV	#STACK,SP	; LOAD THE STACK POINTER
3811	010600	113764	004104	000010		MOVB	DPB.A,RPCS2(R4)	; SELECT THE DRIVE
3812	010606	016446	000020			MOV	RPLA(R4),-(SP)	; GET THE LOOK AHEAD REGISTER
3813	010612	006316				ASL	(SP)	; ALIGN THE SECTOR ADDRESS
3814	010614	006316				ASL	(SP)	; ALIGN THE SECTOR ADDRESS
3815	010616	000316				SWAB	(SP)	; PUT ADDRESS IN LOWER BYTE
3816	010620	105766	000001			TSTB	1(SP)	; IN THE 1ST 20% OF SECTOR ?
3817	010624	001401				BEQ	2\$	; BR IF YES
3818	010626	105216				INCB	(SP)	; INCREMENT THE SECTOR ADDRESS
3819	010630	105216			25	INCB	(SP)	; INCREMENT THE SECTOR ADDRESS
3820	010632	112637	004174			MOVB	(SP)+,DTADPB+10	; LOAD THE DPB
3821	010636	013746	001630			MOV	PRMLT+22,-(SP)	; PUT LAST SECTOR ADDRESS ON THE STACK
3822	010642	005216				INC	(SP)	; INCREMENT IT
3823	010644	122637	004174			CMPB	(SP)+,DTADPB+10	; NEW SECTOR ADDRESS TOO LARGE ?
3824	010650	103007				BHIS	4\$	; BR IF NOT
3825	010652	103403				BLO	3\$	; BR IF ADDRESS IS 2 GREATER
3826	010654	105037	004174			CLRB	DTADPB+10	; RESET TO SECTOR ADDRESS 0
3827	010660	000403				BR	4\$	; CONTINUE
3828	010662	112737	000001	004174	3\$	MOVB	#1,DTADPB+10	; RESET ADDRESS TO SECTOR 1
3829	010670				4\$			

```

3830 010670 004037 025144 JSR RO, @CALL. B ; GO EXECUTE THE COMMAND
3831 010674 105237 004135 INCB DPB. B+11 ; INCREMENT THE TRACK ADDRESS
3832 010700 123737 004135 001520 CMPB DPB. B+11, LT ; MAXIMUM ?
3833 010706 101403 BLOS EXIT7 ; BR IF NOT
3834 010710 113737 001516 004135 MOVB FT, DPB. B+11 ; RELOAD STARTING TRACK ADDRESS
3835 010716 000004 EXIT7 SCOPE ; LOOP ?
    
```

3836  
3837

\*\*\*\*\*  
 \*TEST 10 SERVO SETTLE DOWN TEST

3838  
3839  
3840  
3841  
3842  
3843  
3844  
3845  
3846  
3847  
3848  
3849  
3850  
3851  
3852  
3853  
3854  
3855  
3856  
3857  
3858  
3859  
3860  
3861  
3862  
3863  
3864  
3865  
3866  
3867  
3868  
3869  
3870

\* THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT  
 \* THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE.  
 \* RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC'  
 \* ('NC1' STARTS AT VALUE 'FC'). AT THE COMPLETION OF 1000 (10) SEEKS,  
 \* 'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED  
 \* THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.  
 \*  
 \* WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD  
 \* REGISTER (RPLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO  
 \* POSITION THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND  
 \* FOR THAT SECTOR. IF THE DRIVE'S POSITIONER HAS NOT SETTLED DOWN OR  
 \* IF THE POSITIONER IS NOT ON CYLINDER (IF THE DRIVE IS AN RPO4, THE  
 \* OFF CYLINDER CONDITION MUST LAST FOR AT LEAST 800 US), THE DRIVE  
 \* WILL REPORT A 'WRU' ERROR. (RPO5/6'S MAY ALSO REPORT 'NHS' ERROR UNDER  
 \* ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED  
 \* CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PACK WITH  
 \* MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.  
 \*  
 \* THIS TEST USES THE EXTENTION BITS IN THE LOOK-AHEAD REGISTER TO DETERMINE  
 \* WHETHER OR NOT IT CAN PICK UP THE SECTOR ROTATING INTO POSITION. THE  
 \* TEST IS OPTIMIZED SUCH THAT IF THE DRIVE SIGNALS SEEK DONE WITHIN  
 \* THE FIRST 80% OF THE SECTOR CURRENTLY UNDER THE HEAD, THE TEST WILL  
 \* TRY TO ADDRESS THE NEXT SECTOR BASED ON OBSERVATION, THE PROGRAM  
 \* IS ABLE TO START THE OPERATION WITHOUT LOSING A REVOLUTION MOST OF  
 \* THE TIME  
 \*  
 \* THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW  
 \* HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS THE NECESSARY TIME  
 \* TIME DEPENDENT PARAMETERS OCCUR FREQUENTLY ENOUGH WITHIN THE REQUIRED  
 \* RANGE TO PERMIT THIS TEST TO BE EFFECTIVE

3871  
3872

\*\*\*\*\*  
 TST10

```

3873 010720 000240  

3874 010720 000240  

3875 010722 033737 001444 001234  

3876 010730 001002  

3877 010732 000137 012024  

3878 010736 012737 000010 001102 645  

3879  

3880 010744 004737 024610  

3881 010750 012737 011126 001110  

3882 010756 013777 001102 170156  

3883 010764 013737 001506 001204  

3884 010772 112737 000031 001115  

3885 011000 012737 011006 001106
    
```

```

NOP  

BIT @#BITS+(10*2), TSTNMS , DO THIS TEST?  

BNE 645 , YES--BRANCH  

JMP TST11 , NO--GO TO THE NEXT TEST  

MOV #10, @#STSTNM , SET UP TEST NUMBER AND  

; CLEAR THE ERROR FLAG ($ERFLG)  

JSR PC, LODPRM ; LOAD THE PARMETERS FOR THE TEST  

MOV #TEST10, @#SLPERR ; SETUP THE LOOP ON ERROR ADDRESS  

MOV $TSTNM, @DISPLAY , LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER  

MOV @RPT, $TIMES , GET THE ITERATION COUNT  

MOVB #25, $ERMAX , MAX ERRORS ALLOWED FOR TEST  

MOV #15, $LPADR , SETUP THE LOOP ADDRESS
    
```

```

3886 011006          15
3887 011006 112737 000105 004106   MOVB   #SEEK, @DPB, A+2 ; SEEK=COMMAND
3888 011014 112737 000161 004166   MOVB   #WRITE, DTADPB+2 ; COMMAND
3889 011022 113737 001516 004175   MOVB   FT, DTADPB+11 ; TRACK ADDRESS FOR THE WRITE
3890 011030 013737 001510 004116   MOV    FC, DPB, A+12 ; CYLINDER ADDRESS FOR THE SEEK
3891 011036 013737 001510 004176   MOV    FC, DTADPB+12 ; CYLINDER ADDRESS FOR THE WRITE
3892 011044 013737 001510 001532   MOV    FC, NC1 ; STARTING CYLINDER
3893 011052 013737 001514 001350   MOV    IC, DELTA ; CYLINDER INCREMENT VALUE
3894 011060 012737 176000 004170   MOV    #-<256 *4 >, DTADPB+4 ; WORD COUNT
3895 011066 012737 047712 004172   MOV    #BUFFER, DTADPB+6 ; BUFFER ADDRESS
3896 011074 005000          CLR    R0 ; PATTERN POINTER (WC PATTERN)
3897 011076 004737 030360          JSR    PC, SETBUF ; LOAD THE WRITE BUFFER
3898 011102 005001          CLR    R1 ; CLEAR REGISTER
3899 011104 113701 004104          MOVB   DPB, A, R1 ; LOAD DRIVE ADDRESS
3900 011110 013704 034514          MOV    RPADR, R4 ; UNIBUS ADDRESS OF THE RH11
3901 011114 004737 042516          JSR    PC, CLRQUE ; CLEAR THE OPERATION QUEUES
3902 011120 012737 012022 001252   MOV    #EXIT10, BYPASS ; ERROR EXIT FROM TEST
3903 011126          TEST10
3904 011126 012737 011126 001110   MOV    #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
3905 011134 012706 001100          MOV    #STACK, SP ; LOAD THE STACK POINTER
3906 011140 012737 000340 177776   MOV    #PR7, @#PS ; SET PRIORITY TO 7
3907 011146 005737 001244          TST    CLKSTA ; SEE WHICH CLOCK ON SYSTEM
3908 011152 001415          BEQ    3$ ; BR IF NO CLOCK
3909 011154 100405          BMI    1$ ; BR IF KW11-L CLOCK
3910 011156 017746 170212          MOV    @PKV, -(SP) ; SAVE THE VECTOR
3911 011162 013746 001374          MOV    PKV, -(SP) ; SAVE THE VECTOR ADDRESS
3912 011166 000404          BR     2$ ; CONTINUE
3913 011170 017746 170212 15      MOV    @LKV, -(SP) ; SAVE THE 'L' CLOCK VECTOR
3914 011174 013746 001406          MOV    LKV, -(SP) ; SAVE THE VECTOR ADDRESS
3915 011200 012776 011756 000000 25     MOV    #TST10B, @ (SP) ; CHANGE THE VECTOR
3916 011206 012777 027052 023302 35     MOV    #DORT1, @RPVEC ; CHANGE THE RPO4/RPO5 VECTOR
3917 011214 012737 000010 001344          MOV    #8, SEKTR ; LOAD THE SEEK TIMER
3918 011222 012764 000040 000010          MOV    #BIT05, RPCS2(R4) ; INIT THE MASSBUS
3919 011230 110164 000010          MOVB   R1, RPCS2(R4) ; RESELECT THE DRIVE
3920 011234 013764 004116 000034          MOV    DPB, A+12, RPCA(R4) ; LOAD THE CYLINDER ADDRESS
3921 011242 013737 004116 001270          MOV    DPB, A+12, CYL DS ; CYLINDER ADDRESS FOR ERROR MESSAGE
3922 011250 112764 000105 000000          MOVB   #SEEK, RPCS1(R4) ; START THE SEEK
3923 011256 005037 177776          CLR    @#PS ; CLEAR THE PRIORITY
3924 011262 105764 000012          45     TSTB   RPDS1(R4) ; HAS THE DRIVE FINISHED ?
3925 011266 100402          BMI    5$ ; BR IF IT HAS
3926 011270 000001          WAIT ; WAIT FOR THE OPERATION TO COMPLETE
3927 011272 000773          BR     4$ ; CONTINUE
3928 011274 012737 000340 177776 55     MOV    #PR7, @#PS ; CHANGE PRIORITY TO MAX
3929 011302 032764 040000 000012          BIT    #BIT14, RPDS1(R4) ; ERROR ?
3930 011310 001412          BEQ    6$ ; BR IF NOT
3931 011312 012702 004104          MOV    #DPB, A, R2 ; DPB POINTER
3932 011316 004737 042034          JSR    PC, SVRH11 ; SAVE THE REGISTERS
3933 011322 104023          ERROR 23 ; ERROR DURING SEEK
3934 011324 012764 000040 0000!0          MOV    #BIT05, RPCS2(R4) ; INIT THE MASSBUS
3935 011332 110164 000010          MOVB   R1, RPCS2(R4) ; RESELECT THE DRIVE
3936 011336 012777 037376 023152 65     MOV    #ISR, @RPVEC ; SETUP THE RPO4/RPO5 VECTOR
3937 011344 005737 001244          TST    CLKSTA ; WHICH CLOCK
3938 011350 001405          BEQ    TST10A ; BR IF NONE
3939 011352 016676 000002 000000          MOV    2(SP), @ (SP) ; RELOAD THE CLOCK VECTOR
3940 011360 062706 000004          ADD    #4, SP ; CORRECT THE STACK POINTER
3941 011364          TST10A
    
```

3942	011364	012737	011364	001110		MOV	#, \$LPERR	; SETUP THE ERROR LOOP ADDRESS
3943	011372	012706	001100			MOV	#STACK, SP	; LOAD THE STACK POINTER
3944	011376	110164	000010			MOVB	R1, RPCS2(R4)	; SELECT THE DRIVE
3945	011402	016446	000020			MOV	RPLA(R4), -(SP)	; GET THE LOOK AHEAD REGISTER
3946	011406	006316				ASL	(SP)	; ALIGN THE SECTOR ADDRESS
3947	011410	006316				ASL	(SP)	; ALIGN THE SECTOR ADDRESS
3948	011412	000316				SWAB	(SP)	; PUT ADDRESS IN LOWER BYTE
3949	011414	122766	000300	000001		CMPB	#300, 1(SP)	; IN THE LAST 20% OR SECTOR ?
3950	011422	001001				BNE	2\$	; BR IF NOT
3951	011424	105216				INCB	(SP)	; INCREMENT THE SECTOR ADDRESS
3952	011426	105216			2\$	INCB	(SP)	; INCREMENT THE SECTOR ADDRESS
3953	011430	112637	004174			MOVB	(SP)+, DTADPB+10	; LOAD THE DPB
3954	011434	013746	001630			MOV	PRMLMT+22, -(SP)	; PUT MAXIMUM SECTOR ADDRESS ON THE STACK
3955	011440	005216				INC	(SP)	; INCREMENT PAST THE MAXIMUM ADDRESS
3956	011442	122637	004174			CMPB	(SP)+, DTADPB+10	; NEW SECTOR ADDRESS TOO LARGE ?
3957	011446	101007				BHI	4\$	; BR IF NOT
3958	011450	103403				BLO	3\$	; BR IF ADDRESS IS 2 GREATER THAN MAXIMUM
3959	011452	105037	004174			CLRB	DTADPB+10	; RESET TO SECTOR ADDRESS 0
3960	011456	000403				BR	4\$	; CONTINUE
3961	011460	112737	000001	004174	3\$	MOVB	#1, DTADPB+10	; RESET ADDRESS TO SECTOR 1
3962	011466	012703	004170		4\$	MOV	#DTADPB+4, R3	; POINTER
3963	011472	012764	000111	000000		MOV	#DRVCLR, RPCS1(R4)	; CLEAR THE DRIVE
3964	011500	012364	000002			MOV	(R3)+, RPWC(R4)	; LOAD THE WORD COUNT
3965	011504	012364	000004			MOV	(R3)+, RPBA(R4)	; LOAD THE BUFFER ADDRESS
3966	011510	012364	000006			MOV	(R3)+, RPDA(R4)	; LOAD THE TRACK/SECTOR ADDR
3967	011514	005037	004202			CLR	DTADPB+16	; RESET 'DONE' INDICATOR
3968	011520	012737	004164	034426		MOV	#DTADPB, TRNSWT	; LOAD 'TRANSFER' DPB ADDRESS
3969	011526	010137	034500			MOV	R1, DTUW	; ADDRESS OF DRIVE TRANSFERRING
3970	011532	112761	000001	034356		MOVB	#1, DRVACT(R1)	; SET DRIVE ACTIVE INDICATOR
3971	011540	006301				ASL	R1	; SHIFT DRIVE ADDRESS
3972	011542	012761	001750	034460		MOV	#1000, TIMER(R1)	; SETUP THE OPERATION TIMER
3973	011550	006201				ASR	R1	; RESTORE R1
3974	011552	013764	004166	000000		MOV	DTADPB+2, RPCS1(R4)	; START THE OPERATION
3975	011560	005037	177776			CLR	@#PS	; CLEAR THE PRIORITY
3976	011564	004037	025544			JSR	RD, DRVCL1	; WAIT FOR OPERATION TO COMPLETE
3977	011570	023727	001346	001750	5\$	CMP	SEKCNT, #1000	; FINISHED SEEKS ?
3978	011576	001026				BNE	6\$	; BR IF NOT
3979	011600	005037	001346			CLR	SEKCNT	; CLEAR THE SEEK COUNT
3980	011604	063737	001514	001532		ADD	IC, NC1	; ADD THE INCREMENT
3981	011612	023737	001532	001512		CMP	NC1, LC	; EXCEEDED THE CYLINDER LIMIT ?
3982	011620	103100				BHIS	EXIT10	; BR IF IT HAS
3983	011622	013737	001512	001350		MOV	LC, DELTA	; GET THE NEXT 'ZONE' ADDRESS
3984	011630	163737	001532	001350		SUB	NC1, DELTA	; CHECK THE DIFFERENCE
3985	011636	023737	001514	001350		CMP	IC, DELTA	; DIFFERENCE GREATER THAN THE INCREMENT ?
3986	011644	101003				BHI	6\$	; BR IF IT IS
3987	011646	013737	001514	001350		MOV	IC, DELTA	; USE THE INCREMENT PARAMETER
3988	011654	005237	001346		6\$	INC	SEKCNT	; COUNT THE NEXT SEEK
3989	011660	023737	001510	001512		CMP	FC, LC	; BEGINNING AND ENDING CYLINDERS THE SAME ?
3990	011666	001002				BNE	7\$	; BR IF NOT
3991	011670	000137	011126			JMP	TEST10	; BR IF THEY ARE
3992	011674	013737	001532	004116	7\$	MOV	NC1, DPB A+12	; RESET THE CYLINDER ADDRESS
3993	011702	004737	023510			JSR	PC, \$RAND	; CYCLE THE RANDOM NUMBER GENERATOR
3994	011706	013746	023606			MOV	\$HINUM, -(SP)	; USE THE HIGH RANDOM NUMBER
3995	011712	005046				CLR	-(SP)	; CLEAR THE UPPER DIVIDEND
3996	011714	013746	001350			MOV	DELTA, -(SP)	; FORM THE DIVISOR
3997	011720	005216				INC	(SP)	; INCREMENT

```

3998 011722 004737 023612 JSR PC,$DIV ;DIVIDE
3999 011726 062637 004116 ADD (SP)+,DPB A+12 ;ADD THE REMAINDER TO THE INITIAL CYLINDER
4000 011732 005726 TST (SP)+ ;DISCARD THE QUOTIENT
4001 011734 023737 004116 004176 CMP DPB A+12,DTADPB+12 ;SAME CYLINDER SELECTED AS LAST TIME ?
4002 011742 001754 BEQ 7$ ;BR IF IT WAS
4003 011744 013737 004116 004176 MOV DPB A+12,DTADPB+12 ;COPY NEW CYLINDER ADDRESS
4004 011752 000137 011126 JMP TEST10 ;CONTINUE
4005 011756 005337 001344 TST10B DEC SEKTR ;DECREMENT THE SEEK TIMER
4006 011762 001016 BNE 1$ ;CONTINUE IF NOT DONE
4007 011764 012702 004104 MOV #DPB A,R2 ;DPB ADDRESS
4008 011770 004737 042034 JSR PC,SVRH1 ;SAVE THE REGISTERS
4009 011774 104024 ERROR 24 ;TIMEOUT DURING SEEK
4010 011776 012764 000040 000010 MOV #BIT05,RPCS2(R4) ;INIT THE MASSBUS
4011 012004 110164 000010 MOV R1,RPCS2(R4) ;RESELECT THE DRIVE
4012 012010 016676 000002 000000 MOV 2(SP),2(SP) ;RESTORE THE CLOCK VECTOR ADDRESS
4013 012016 000401 BR EXIT10 ;ABORT THE TEST
4014 012020 000002 1$ RTI ;RETURN
4015 012022 000004 EXIT10: SCOPE ;LOOP ?
4016
4017 ,,*****
4018 ;*TEST 11 ALL SEEKS TEST
4019
4020 ;* THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER
4021 ;* TO ALL OTHER CYLINDERS
4022
4023 ;* BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER
4024 ;* BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC' THE BEGINNING CYLINDER
4025 ;* ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER
4026 ;* ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC'. THE SEQUENCE
4027 ;* CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED
4028
4029 ,,*****
4030 TST11
4031 012024 000240 NOP
4032 012026 033737 001446 001234 BIT @#BITS+(11*2),TSTNMS ;DO THIS TEST?
4033 012034 001002 BNE 64$ ;YES--BRANCH
4034 012036 000137 012244 JMP TST12 ;NO--GO TO THE NEXT TEST
4035 012042 012737 000011 001102 64$ MOV #11,@$TSTNM ;SET UP TEST NUMBER AND
4036 ;CLEAR THE ERROR FLAG ($ERFLG)
4037 012050 004737 024610 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
4038 012054 012737 012164 001110 MOV #TEST11,@$SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
4039 012062 013777 001102 167052 MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4040 012070 013737 001506 001204 MOV @RPT,$TIMES ;GET THE ITERATION COUNT
4041 012076 112737 000031 001115 MOV B #25,$$ERMAX ;MAX ERRORS ALLOWED FOR TEST
4042 012104 012737 012112 001106 MOV #1$, $LPADR ;SETUP THE LOOP ADDRESS
4043 012112 113737 001524 004134 :$ MOV B FS,DPB B+10 ;SECTOR ADDRESS
4044 012120 113737 001524 004154 MOV B FS,DPB C+10 ;SECTOR ADDRESS
4045 012126 113737 001516 004135 MOV B FT,DPB B+11 ;TRACK ADDRESS
4046 012134 113737 001516 004155 MOV B FT,DPB C+11 ;TRACK ADDRESS
4047 012142 013737 001510 004136 MOV FC,DPB B+12 ;STARTING CYLINDER ADDRESS
4048 012150 013737 001510 004156 MOV FC,DPB C+12 ;STARTING CYLINDER ADDRESS
4049 012156 012737 012242 001252 MOV #EXIT11,BYPASS ;TEST ABORT EXIT
4050 012164 012706 001100 TEST11: MOV #STACK,SP ;SETUP THE STACK POINTER
4051 012170 1$:
4052 012170 004037 025334 JSR RO,@$CALL C ;GO EXECUTE THE COMMAND
4053 012174 004037 025144 JSR RO,@$CALL B ;GO EXECUTE THE COMMAND

```

```
4054 012200 063737 001514 004156      ADD      IC,DPB C+12      ; INCREMENT THE ENDING CYLINDER ADDRESS
4055 012206 023737 001512 004156      CMP      LC,DPB C+12      ; CHECK IF EXCEEDING MAXIMUM
4056 012214 002365                BGE      1$                ; BR IF NOT
4057 012216 013737 001510 004156      MOV      FC,DPB C+12      ; RESET ENDING CYLINDER ADDRESS
4058 012224 063737 001514 004136      ADD      IC,DPB B+12      ; INCREMENT THE STARTING ADDRESS
4059 012232 023737 001512 004136      CMP      LC,DPB B+12      ; EXCEEDING MAXIMUM ?
4060 012240 002353                BGE      1$                ; BR IF NOT
4061 012242 000004                EXIT11   SCOPE            ; LOOP ?
4062
```

4063  
4064  
4065

SBTTL \*\*\* TIMING TESTS \*\*\*

```

/* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /*
/* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /*
/* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /*

```

\*THE TIMING TESTS WILL ENSURE THAT THOSE FUNCTIONS BEING  
\*TIMED ARE WITHIN THE TOLERANCES SPECIFIED IN THE "RPO4  
\*ENGINEERING SPECIFICATIONS".  
\*THE SEEK TIMING WILL BE PERFORMED USING EXPLICIT SEEK  
\*OPERATIONS AT THE COMPLETION OF EACH OF THE TIMING  
\*TESTS THE MINIMUM, MAXIMUM AND AVERAGE TIMES WILL BE  
\* TYPED

```

/* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /*
/* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /*
/* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /* /*

```

4083  
4084  
4085  
4086  
4087  
4088  
4089  
4090  
4091  
4092  
4093  
4094  
4095  
4096  
4097  
4098  
4099  
4100  
4101  
4102  
4103  
4104  
4105  
4106  
4107  
4108  
4109  
4110  
4111  
4112  
4113  
4114  
4115  
4116  
4117  
4118

```

*****
;TEST 12 ROTATIONAL SPEED TIMING TEST

```

```

; * THIS TEST WILL START A SEARCH TO CYLINDER 0, TRACK 0, SECTOR
; * 0 AS SOON AS THE INTERRUPT OCCURS, THE GO BIT IS SET AGAIN
; * AND THE OPERATION IS TIMED. THIS PROCEDURE IS REPEATED 10
; * TIMES THEN THE AVERAGE TIME IS CALCULATED AND CHECKED TO
; * ENSURE IT IS WITHIN TOLERANCE:
; * 16.67 MS/REV + OR - 2% IF 60HZ
; * 16.67 MS/REV + OR - 2.5% IF 50HZ

```

```

*****
TST12:

```

```

NOP
BIT @#BITS+(12*2), TSTNMS ;DO THIS TEST?
BNE 645 ;YES--BRANCH
JMP TST13 ;NO--GO TO THE NEXT TEST
MOV #12, @#STSTNM ;SET UP TEST NUMBER AND
;CLEAR THE ERROR FLAG ($ERFLG)
JSR PC, LODPRM ;LOAD THE PARMETERS FOR THE TEST
MOV #TST12, @#$LPERR ;SETUP THE ERROR LOOP ADDRESS
MOV $TSTNM, @DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
MOV @#RPT, $TIMES ;GET THE ITERATION COUNT
MOVB #25, $ERMAX ;MAX ERRORS ALLOWED FOR TEST
TST @#CLKSTA ;KW11-P CLOCK?
BGT 15 ;YES--START TEST
JMP TST13 ;NO--GO TO NEXT TEST
MOV #15, $LPADR ;SETUP LOOP ADDRESS
JSR RO, @#SRCHOO ;DO A MASSBUS INIT & RECAL
BR 25 ;RETURN HERE IF NO ERROR
JMP EXIT12 ;RETURN HERE IF ERROR
MOV @#FC, RPA(R4) ;FC
MOV @#FS, -(SP) ;FS
MOVB @#FT, 1(SP) ;FT
MOV (SP)+, RPA(R4) ;LOAD FT/FS

```

```

4119 012402 012737 013000 001206      MOV      #EXIT12,$ESCAPE ;,ESCAPE TO EXIT12 ON ERROR
4120 012410 005005                    CLR      R5              ;COUNT UP
4121 012412 012703 002774            MOV      #T7A,R3        ;60HZ PARAMETERS
4122 012416 032737 000100 001220      BIT      #SW06,@#C.SWR ;60 HZ?
4123 012424 001402                    BEQ      TEST12         ;YES--BRANCH
4124 012426 012703 003004            MOV      #T7B,R3        ;NO--50 HZ PARAMETERS
4125 012432 012706 001100      TEST12. MOV      #STACK,SP   ;SETUP STACK
4126 012436 012701 000012            MOV      #10,R1         ;TIME 10 SEARCHES
4127 012442 004737 027054            JSR      PC,@#STRMR     ;INITIALIZE THE TIMERS
4128 012446 012777 012654 166720      MOV      #7$,@PKV       ;SETUP VECTOR IN CASE OF OVERFLOW
4129 012454 012777 027052 022034      MOV      #DORT1,@RPVEC ;SETUP RPO4/5/6 VECTOR
4130 012462 005077 166714      15:     CLR      @PKB         ;START COUNTING AT ZERO
4131 012466 012777 000131 166704      MOV      #131,@PKCS     ;INT.EN., COUNT UP AT 100KHZ
4132 012474 012714 000131            MOV      #SEARCH,(R4)   ;START A SEARCH
4133 012500 000001                    WAIT     ;WAIT ON INTERRUPT
4134 012502 042777 000101 166670      BIC      #101,@PKCS     ;STOP THE CLOCK
4135 012510 032764 040000 000012      BIT      #BIT14,RPDS1(R4);ERROR?
4136 012516 001415                    BEQ      2$             ;NO--BRANCH
4137 012520 104412                    SAVREG   ;SAVE R0-R5
4138 012522 012702 004164            MOV      #DTADPB,R2     ;DPB POINTER
4139 012526 004737 042034            JSR      PC,@#SVRH11    ;SAVE ALL THE RH11/RPO4 REGISTERS
4140 012532 012764 000040 000010      MOV      #BIT05,RPCS2(R4);MASSBUS CLEAR
4141 012540 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4);SELECT DRIVE
4142 012546 104413                    RESREG   ;RESTORE R0-R5
4143 012550 104017                    ERROR    17
4144 012552 005077 166624      2$     CLR      @PKB         ;START THE COUNT AT ZERO
4145 012556 012714 000131            MOV      #SEARCH,(R4)   ;START A SEARCH
4146 012562 012777 000131 166610      MOV      #131,@PKCS     ;START THE CLOCK
4147 012570 000001                    WAIT     ;WAIT ON INTERRUPT
4148 012572 042777 000101 166600      BIC      #101,@PKCS     ;STOP THE CLOCK
4149 012600 032764 040000 000012      BIT      #BIT14,RPDS1(R4);IS "ERR=1"?
4150 012606 001415                    BEQ      3$             ;NO--BRANCH
4151 012610 104412                    SAVREG   ;SAVE R0-R5
4152 012612 012702 004164            MOV      #DTADPB,R2     ;DPB POINTER
4153 012616 004737 042034            JSR      PC,@#SVRH11    ;SAVE ALL THE RH11/RPO4 REGISTERS
4154 012622 012764 000040 000010      MOV      #BIT05,RPCS2(R4);MASSBUS CLEAR
4155 012630 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4);SELECT DRIVE
4156 012636 104413                    RESREG   ;RESTORE R0-R5
4157 012640 104017                    ERROR    17            ;DISK ERROR OCCURRED
4158 012642 004737 027120      3$     JSR      PC,@#COUNT    ;UPDATE THE COUNT
4159 012646 005301                    DEC      R1              ;DONE?
4160 012650 003304                    BGT      1$             ;NO--BRANCH
4161 012652 000424                    BR       8$             ;YES--GO TO THE EXIT
4162 012654 042777 000101 166516      7$     BIC      #101,@PKCS     ;STOP THE CLOCK
4163 012662 005037 177776            CLR      @#PS           ;DROP THE PRIORITY
4164 012666 012600                    MOV      (SP)+,R0        ;PC OF WAIT+2
4165 012670 005726                    TST     (SP)+           ;POP THE PS FROM THE STACK
4166 012672 104412                    SAVREG   ;SAVE R0-R5
4167 012674 012702 004164            MOV      #DTADPB,R2     ;DPB POINTER
4168 012700 004737 042034            JSR      PC,@#SVRH11    ;SAVE ALL THE RH11/RPO4 REGISTERS
4169 012704 012764 000040 000010      MOV      #BIT05,RPCS2(R4);MASSBUS CLEAR
4170 012712 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4);SELECT DRIVE
4171 012720 104413                    RESREG   ;RESTORE R0-R5
4172 012722 104020                    ERROR    20            ;CLOCK OVERFLOWED
4173 012724                                8$
4174 012724 012764 000040 000010      MOV      #BIT05,RPCS2(R4);MASSBUS INIT

```

```

4175 012732 013764 004164 000010      MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
4176 012740 004737 024074              JSR      PC,@#ST.CLK      ;INITIALIZE THE CLOCK
4177 012744 012777 037376 021544      MOV      #ISR,@RPVEC      ;RESTORE RH11/RPO4/5/6 INT VECTOR
4178 012752 032737 000100 001220      BIT      #SW06,@#C.SWR    ;60 HZ?
4179 012760 001004              BNE      9$              ;NO -- BRANCH
4180 012762 004037 027252              JSR      RO,@#TYPTIM      ;GO TYPE THE TIMES
4181 012766 002774              T7A                      ;POINTER
4182 012770 000403              BR       EXIT12          ;GO TO EXIT
4183 012772              9$:
4184 012772 004037 027252              JSR      RO,@#TYPTIM      ;GO TYPE THE TIMES
4185 012776 003004              T7B                      ;POINTER
4186 013000 000004      EXIT12: SCOPE           ;LOOP ?
4187
4188
4189                                     ,,*XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4190                                     ,*TEST 13          ONE CYLINDER SEEK TIMING TEST
4191
4192                                     ;*      THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
4193                                     ;*      CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE
4194                                     ;*      CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC' THE
4195                                     ;*      TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT
4196                                     ;*      EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK
4197                                     ;*      THE TIME MUST BE LESS THAN 10MS.
4198
4199                                     ,,*XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
4200      013002      TST13:
4201      013002 000240      NOP
4202      013004 033737 001452 001234      BIT      @#BITS+<13*2>,TSTNMS ;DO THIS TEST?
4203      013012 001002      BNE      64$              ;YES--BRANCH
4204      013014 000137 013446              JMP      TST14            ;NO--GO TO THE NEXT TEST
4205      013020 012737 000013 001102 64$:      MOV      #13,@#STSTNM     ;SET UP TEST NUMBER AND
4206                                     ;CLEAR THE ERROR FLAG (SERFLG)
4207      013026 004737 024610              JSR      PC,LODPRM        ;LOAD THE PARMETERS FOR THE TEST
4208      013032 012737 013002 001110      MOV      #TST13,@#SLPERR ;SETUP THE ERROR LOOP ADDRESS
4209      013040 013777 001102 166074      MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4210      013046 013737 001506 001204      MOV      @#RPT,$TIMES    ;GET THE ITERATION COUNT
4211      013054 112737 000031 001115      MOV      #25,$SERMAX     ;MAX ERRORS ALLOWED FOR TEST
4212      013062 005737 001244              TST      @#CLKSTA        ;KW11-P CLOCK?
4213      013066 003002      BGT      1$              ;YES--START TEST
4214      013070 000137 013446              JMP      TST14            ;NO--GO TO NEXT TEST
4215      013074 012737 013074 001106 1$:      MOV      #15,$LPADR      ;SETUP THE LOOP ADDRESS
4216      013102 004037 026670              JSR      RO,@#SRCHOO     ;DO A MASSBUS INIT. AND RECAL
4217      013106 000402      BR       2$              ;NO ERROR RETURN
4218      013110 000137 013444              JMP      EXIT13          ;ERROR RETURN--SCOPE LOOP CALL
4219      013114 012703 003014              2$:      MOV      #T10,R3         ;PARAMETER POINTER
4220      013120 012737 013444 001206      MOV      #EXIT13,$ESCAPE ;ESCAPE TO EXIT13 ON ERROR
4221      013126 012706 001100      TEST13: MOV      #STACK,SP      ;SETUP STACK
4222      013132 013737 001510 004176      MOV      FC,@#DTADPB+12 ;START WITH BEGINNING CYLINDER
4223      013140 005237 004176              INC      DTADPB+12       ;INCREMENT THE BEGINNING CYLINDER
4224      013144 005005      CLR      R5              ;SET THE UP/DOWN SWITCH TO UP
4225      013146 004737 027054              JSR      PC,@#STRTHR     ;INITIALIZE THE TIMERS
4226      013152 012777 013340 166214      MOV      #75,@PKV        ;SETUP INCASE OF OVERFLOW
4227      013160 012777 027052 021330      MOV      #DORTI,@RPVEC   ;SET RPO4/5/6 VECTOR
4228      013166 005077 166210      1$:      CLR      @PKB           ;START THE COUNTER AT ZERO
4229      013172 013764 004176 000034      MOV      @#DTADPB+12,RPCA(R4) ;LOAD DESIRED CYLINDER
4230      013200 012714 000105      MOV      #SEEK,(R4)      ;START A SEEK
    
```

```

4231 013204 012777 000131 166166 MOV #131,@PKCS ;START THE CLOCK
4232 013212 000001 WAIT ;WAIT ON INTERRUPT
4233 013214 2777 000101 166156 BIC #101,@PKCS ;STOP THE CLOCK
4234 013222 032764 040000 000012 BIT #BIT14,RPDS1(R4) ;ANY DISK ERRORS?
4235 013230 001415 BEQ 25 ;NO--BRANCH
4236 013232 104412 SAVREG ;SAVE RO-R5
4237 013234 012702 004164 MOV #DTADPB,R2 ;DPB POINTER
4238 013240 004737 042034 JSR PC,@SVRH11 ;SAVE ALL THE RH11/RPO4 REGISTERS
4239 013244 012764 000040 000010 MOV #BIT05,RPCS2(R4) ;MASSBUS CLEAR
4240 013252 013764 004164 000010 MOV @DTADPB,RPCS2(R4) ;SELECT DRIVE
4241 013260 104413 RESREG ;RESTORE RO-R5
4242 013262 104017 ERROR 17 ;REPORT THE ERROR
4243 013264 004737 027120 25 JSR PC,@COUNT ;COUNT THIS SEEKS TIME
4244 013270 004737 026446 JSR PC,@THOMS ;STALL FOR 2 MILLISECONDS
4245 013274 005705 TST R5 ;UP OR DOWN?
4246 013276 001011 BNE 45 ;DOWN--BRANCH
4247 013300 005237 004176 35 INC @DTADPB+12 ;MOVE TO NEXT CYLINDER
4248 013304 023737 004176 001512 CMP @DTADPB+12,LC ;OUT OF CYLINDERS?
4249 013312 002725 BLT 15 ;NO--GO DO THE NEXT SEEK
4250 013314 012705 177777 MOV #-1,R5 ;SET UP/DOWN SWITCH TO DOWN
4251 013320 000722 BR 15 ;GO DO THE NEXT SEEK
4252 013322 005337 004176 45 DEC @DTADPB+12 ;MOVE TO NEXT CYLINDER
4253 013326 023727 004176 000000 CMP @DTADPB+12,#0 ;OUT OF CYLINDERS?
4254 013334 003314 BGT 15 ;NO--GO DO THE NEXT SEEK
4255 013336 000424 BR 85 ;GO TO THE EXIT
4256 013340 042777 000101 166032 75 BIC #101,@PKCS ;STOP THE CLOCK
4257 013346 005037 177776 CLR @PS ;DROP THE PRIORITY
4258 013352 012600 MOV (SP)+,RO ;PC OF WAIT+2
4259 013354 005726 TST (SP)+ ;POP THE PS FROM THE STACK
4260 013356 104412 SAVREG ;SAVE RO-R5
4261 013360 012702 004164 MOV #DTADPB,R2 ;DPB POINTER
4262 013364 004737 042034 JSR PC,@SVRH11 ;SAVE ALL THE RH11/RPO4 REGISTERS
4263 013370 012764 000040 000010 MOV #BIT05,RPCS2(R4) ;MASSBUS CLEAR
4264 013376 013764 004164 000010 MOV @DTADPB,RPCS2(R4) ;SELECT DRIVE
4265 013404 104413 RESREG ;RESTORE RO-R5
4266 013406 104020 ERROR 20 ;REPORT CLOCK OVERFLOW
4267 013410 85
4268 013410 012764 000040 000010 MOV #BIT05,RPCS2(R4) ;MASSBUS INIT
4269 013416 013764 004164 000010 MOV @DTADPB,RPCS2(R4) ;SELECT DRIVE
4270 013424 004737 024074 JSR PC,@ST CLK ;INITIALIZE THE CLOCK
4271 013430 012777 037376 021060 MOV #ISR,@RPVEC ;RESTORE RH11/RPO4/5/6 INT VECTOR
4272 013436 004037 027252 JSR RO,@TYPTIM ;GO TYPE THE TIMES
4273 013442 003014 T10 ;POINTER
4274 013444 000004 EXIT13 SCOPE ;LOOP ?

```

\*\*\*\*\*  
 ,\*TEST 14 ACCESS TIME MEASUREMENT TEST

,\* THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO  
 ,\* CYLINDER 'LC', THEN A REVERSEK FROM CYLINDER 'LC' TO  
 ,\* CYLINDER 0. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY  
 ,\* ARE WITHIN THE TOLERANCE ALLOWED FOR THE ACCESS TIME MEASUREMENT  
 ,\* THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL  
 ,\* OF 256 SEEKS). THE AVERAGE ACCESS TIME MUST BE LESS THAN 30 MS  
 ,\* CYLINDER 'LC' DEFAULTS TO 136 (10) FOR AN RPO4/5 OR TO 255 (10)

4275  
 4276  
 4277  
 4278  
 4279  
 4280  
 4281  
 4282  
 4283  
 4284  
 4285  
 4286

```

4287      , *      FOR AN RPO6.
4288
4289      ; , *****
4290      013446      TST14
4291      013446      000240      NOP
4292      013450      033737      001454      001234      BIT      @#BITS+<14*2>,TSTNMS ; DO THIS TEST?
4293      013456      001002      BNE      64$      ; YES--BRANCH
4294      013460      000137      014164      JMP      TST15      ; NO--GO TO THE NEXT TEST
4295      013464      012737      000014      001102      64$      MOV      #14,@#STSTNM ; SET UP TEST NUMBER AND
4296      ; CLEAR THE ERROR FLAG ($ERFLG)
4297      013472      004737      024610      JSR      PC,LODPRM ; LOAD THE PARAMETERS FOR THE TEST
4298      013476      012737      013446      001110      MOV      #TST14,@#SLPERR ; SETUP THE ERROR LOOP ADDRESS
4299      013504      013777      001102      165430      MOV      $TSTNM,@DISPLAY ; LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4300      013512      013737      001506      001204      MOV      @#RPT,$TIMES ; GET THE ITERATION COUNT
4301      013520      112737      000031      001115      MOVB     #25,$ERMAX ; MAX ERRORS ALLOWED FOR TEST
4302      013526      005737      001244      TST      @#CLKSTA ; KW11-P CLOCK?
4303      013532      003002      BGT      1$      ; YES--START TEST
4304      013534      000137      014164      JMP      TST15      ; NO--GO TO NEXT TEST
4305      013540      012737      013540      001106      1$      MOV      #1$,$LPADR ; SET THE LOOP ADDRESS
4306      013546      004037      026670      JSR      RO,@#SRCHOO ; DO A MASSBUS INIT & RECAL
4307      013552      000402      BR       2$      ; RETURN HERE IF NO ERROR
4308      013554      000137      014162      JMP      EXIT14 ; RETURN HERE ON ERROR
4309      013560      012703      003024      2$      MOV      #T11,R3 ; PARAMETER POINTER
4310      013564      012737      014162      001206      MOV      #EXIT14,$ESCAPE ; ESCAPE TO EXIT14 ON ERROR
4311      013572      012706      001100      TEST14  MOV      #STACK,SP ; SETUP STACK
4312      013576      012701      000200      MOV      #128,R1 ; REPEAT "0-136-0" 128 TIMES
4313      013602      004737      027054      JSR      PC,@#STRTHR ; INIT. THE COUNTERS
4314      013606      012777      014056      165560      MOV      #7$,@PKV ; SET UP VECTOR IN CASE OF OVERFLOW
4315      013614      012777      027052      020674      MOV      #DORTI,@RPVEC ; SETUP RPO4/5/6 VECTOR
4316      013622      005077      165554      1$      CLR      @PKB ; START COUNT AT ZERO
4317      013626      013764      001512      000034      MOV      LC,RPC(R4) ; 'MIDDLE' CYLINDER
4318      013634      012764      000105      000000      MOV      #SEEK,RPCS1(R4) ; START A SEEK
4319      013642      012777      000131      165530      MOV      #131,@PKCS ; START THE CLOCK
4320      013650      000001      WAIT ; WAIT ON INTERRUPT
4321      013652      042777      000101      165520      BIC      #101,@PKCS ; STOP CLOCK
4322      013660      032764      040000      000012      BIT      #BIT14,RPDS1(R4) ; ERR=1?
4323      013666      001415      BEQ      2$      ; NO--BRANCH
4324      013670      104412      SAVREG ; SAVE RO-R5
4325      013672      012702      004164      MOV      #DTADPB,R2 ; DPB POINTER
4326      013676      004737      042034      JSR      PC,@#SVRH11 ; SAVE ALL THE RH11/RPO4 REGISTERS
4327      013702      012764      000040      000010      MOV      #BIT05,RPCS2(R4) ; MASSBUS CLEAR
4328      013710      013764      004164      000010      MOV      @#DTADPB,RPCS2(R4) ; SELECT DRIVE
4329      013716      104413      RESREG ; RESTORE RO-R5
4330      013720      104017      ERROR 17
4331      013722      005005      2$      CLR      R5 ; SET UP/DOWN SWITCH TO UP
4332      013724      004737      027120      JSR      PC,@#COUNT ; UPDATE THE COUNT
4333      013730      004737      026446      JSR      PC,@#TWOMS ; STALL FOR 2 MILLISECONDS
4334      013734      005077      165442      CLR      @PKB ; START THE COUNT AT ZERO
4335      013740      013764      001510      000034      MOV      FC,RPC(R4) ; BEGINNING CYLINDER
4336      013746      012764      000105      000000      MOV      #SEEK,RPCS1(R4) ; START A SEEK
4337      013754      012777      000131      165416      MOV      #131,@PKCS ; START THE CLOCK
4338      013762      000001      WAIT ; WAIT ON INTERRUPT
4339      013764      042777      000101      165406      BIC      #101,@PKCS ; STOP THE CLOCK
4340      013772      032764      040000      000012      BIT      #BIT14,RPDS1(R4) ; ERR=1?
4341      014000      001415      BEQ      3$      ; NO--BRANCH
4342      014002      104412      SAVREG ; SAVE RO-R5
    
```

```

4343 014004 012702 004164      MOV      #DTADPB,R2      ;DPB POINTER
4344 014010 004737 042034      JSR      PC,@#SVRH11    ;SAVE ALL THE RH11/RPO4 REGISTERS
4345 014014 012764 000040 000010  MOV      #BIT05,RPCS2(R4) ;MASSBUS CLEAR
4346 014022 013764 004164 000010  MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
4347 014030 104413      RESREG                      ;RESTORE RO-R5
4348 014032 104017      ERROR      17
4349 014034 012705 177777      3$      MOV      #-1,R5          ;SET UP/DOWN SWITCH TO DOWN
4350 014040 004737 027120      JSR      PC,@#COUNT    ;UPDATE THE COUNT
4351 014044 004737 026446      JSR      PC,@#TWOMS     ;STALL FOR 2 MILLISECONDS
4352 014050 005301      DEC      R1              ;DONE?
4353 014052 003263      BGT      1$              ;NO--BRANCH
4354 014054 000424      BR       8$              ;YES--EXIT
4355 014056 042777 000101 165314 7$      BIC      #101,@PKCS     ;STOP THE CLOCK
4356 014064 005037 177776      CLR      @#PS            ;DROP THE PRIORITY
4357 014070 012600      MOV      (SP)+,RO        ;PC OF WAIT+2
4358 014072 005726      TST      (SP)+          ;POP THE PS FROM THE STACK
4359 014074 104412      SAVREG                      ;SAVE RO-R5
4360 014076 012702 004164      MOV      #DTADPB,R2      ;DPB POINTER
4361 014102 004737 042034      JSR      PC,@#SVRH11    ;SAVE ALL THE RH11/RPO4 REGISTERS
4362 014106 012764 000040 000010  MOV      #BIT05,RPCS2(R4) ;MASSBUS CLEAR
4363 014114 013764 004164 000010  MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
4364 014122 104413      RESREG                      ;RESTORE RO-R5
4365 014124 104020      ERROR      20            ;CLOCK OVERFLOWED
4366 014126      8$
4367 014126 012764 000040 000010  MOV      #BIT05,RPCS2(R4) ;MASSBUS INIT.
4368 014134 013764 004164 000010  MOV      @#DTADPB,RPCS2(R4) ;SELECT DRIVE
4369 014142 004737 024074      JSR      PC,@#ST CLK     ;INITIALIZE THE CLOCK
4370 014146 012777 037376 020342  MOV      #ISR,@RPVEC     ;RESTORE RH11/RPO4/5/6 INT VECTOR
4371 014154 004037 027252      JSR      RO,@#TYPTIM     ;GO TYPE THE TIMES
4372 014160 003024      T11                          ;POINTER
4373 014162 000004      EXIT14 SCOPE              ;LOOP ?
4374
4375      ;*****
4376      ;*TEST 15          MAXIMUM SEEK TIMING TEST
4377
4378      ;*      THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 0 TO
4379      ;*      CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO
4380      ;*      CYLINDER 0.  BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE
4381      ;*      THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE MAXIMUM SEEK
4382      ;*      TIME.  THIS SEQUENCE IS REPEATED 128 TIMES (FOR
4383      ;*      A TOTAL OF 256 SEEKS).  THE MAXIMUM SEEK TIME MUST BE LESS THAN
4384      ;*      54 MS 'LC' DEFAULTS TO 410 (10) FOR RPO4/5'S AND TO 814 (10)
4385      ;*      FOR RPO6'S
4386
4387      ;*****
4388      TST15
4389      NOP
4390 014166 033737 001456 001234  BIT      @#BITS+(15*2),TSTNMS ;DO THIS TEST?
4391 014174 001002      BNE      64$            ;YES--BRANCH
4392 014176 000137 014702      JMP      TST16          ;NO--GO TO THE NEXT TEST
4393 014202 012737 000015 001102 64$      MOV      #15,@#STSTNM   ;SET UP TEST NUMBER AND
4394      ;CLEAR THE ERROR FLAG (SERFLG)
4395 014210 004737 024610      JSR      PC,LODPRM      ;LOAD THE PARMETERS FOR THE TEST
4396 014214 012737 014164 001110  MOV      #TST15,@#SLPERR ;SETUP THE ERROR LOOP ADDRESS
4397 014222 013777 001102 164712  MOV      $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4398 014230 013737 001506 001204  MOV      @#RPT,$TIMES    ;GET THE ITERATION COUNT
    
```

4399	014236	112737	000031	001115		MOVB	#25, \$ERMAX	; MAX ERRORS ALLOWED FOR TEST
4400	014244	005737	001244			TST	@CLKSTA	; KW11-P CLOCK
4401	014250	003002				BGT	1\$	; YES--START TEST
4402	014252	000137	014702			JMP	TST16	; NO--GO TO NEXT TEST
4403	014256	012737	014256	001106	1\$	MOV	#1\$, \$LPADR	; SETUP THE LOOP ADDRESS
4404	014264	004037	026670			JSR	RD, @SRCH00	; DO A MASSBUS INIT & RECAL
4405	014270	000402				BR	2\$	; RETURN HERE IF NO ERROR
4406	014272	000137	014700			JMP	EXIT15	; RETURN HERE ON ERROR
4407	014276	012703	003034		2\$	MOV	#T12, R3	; PARAMETER POINTER
4408	014302	012737	014700	001206		MOV	#EXIT15, \$ESCAPE	; ESCAPE TO EXIT15 ON ERROR
4409	014310	012706	001100		TEST15	MOV	#STACK, SP	; SETUP STACK
4410	014314	012701	000200			MOV	#128, R1	; REPEAT "O-'LC'-O" 128 TIMES
4411	014320	004737	027054			JSR	PC, @STRTRM	; INIT. THE TIMERS
4412	014324	012777	014574	165042		MOV	#7\$, @PKV	; SETUP VECTOR IN CASE OF OVERFLOW
4413	014332	012777	027052	020156		MOV	#DORT1, @RPVEC	; SETUP RPO4/5/6 VECTOR
4414	014340	005077	165036		1\$	CLR	@PKB	; START COUNTING FROM ZERO
4415	014344	013764	001512	000034		MOV	LC, RPCA(R4)	; MAXIMUM CYLINDER
4416	014352	012764	000105	000000		MOV	#SEEK, RPCS1(R4)	; START A SEEK
4417	014360	012777	000131	165012		MOV	#131, @PKCS	; START THE CLOCK
4418	014366	000001				WAIT		; WAIT ON INTERRUPT
4419	014370	042777	000101	165002		BIC	#101, @PKCS	; STOP THE CLOCK
4420	014376	032764	040000	000012		BIT	#BIT14, RPDS1(R4)	; ERR=1?
4421	014404	001415				BEQ	2\$	; NO--BRANCH
4422	014406	104412				SAVREG		; SAVE R0-R5
4423	014410	012702	004164			MOV	#DTADPB, R2	; DPB POINTER
4424	014414	004737	042034			JSR	PC, @SVRH11	; SAVE ALL THE RH11/RPO4 REGISTERS
4425	014420	012764	000040	000010		MOV	#BIT05, RPCS2(R4)	; MASSBUS CLEAR
4426	014426	013764	004164	000010		MOV	@DTADPB, RPCS2(R4)	; SELECT DRIVE
4427	014434	104413				RESREG		; RESTORE R0-R5
4428	014436	104017				ERROR	17	
4429	014440	005005			2\$	CLR	R5	; SET THE UP/DOWN SWITCH TO UP
4430	014442	004737	027120			JSR	PC, @COUNT	; UP THE COUNT
4431	014446	004737	026446			JSR	PC, @THOMS	; STALL FOR 2 MILLISECONDS
4432	014452	005077	164724			CLR	@PKB	; START COUNT AT ZERO
4433	014456	013764	001510	000034		MOV	FC, RPCA(R4)	; BEGINNING CYLINDER
4434	014464	012764	000105	000000		MOV	#SEEK, RPCS1(R4)	; START A SEEK
4435	014472	012777	000131	164700		MOV	#131, @PKCS	; START THE CLOCK
4436	014500	000001				WAIT		; WAIT ON INTERRUPT
4437	014502	042777	000101	164670		BIC	#101, @PKCS	; STOP THE CLOCK
4438	014510	032764	040000	000012		BIT	#BIT14, RPDS1(R4)	; "ERR"=1?
4439	014516	001415				BEQ	3\$	; NO--BRANCH
4440	014520	104412				SAVREG		; SAVE R0-R5
4441	014522	012702	004164			MOV	#DTADPB, R2	; DPB POINTER
4442	014526	004737	042034			JSR	PC, @SVRH11	; SAVE ALL THE RH11/RPO4 REGISTERS
4443	014532	012764	000040	000010		MOV	#BIT05, RPCS2(R4)	; MASSBUS CLEAR
4444	014540	013764	004164	000010		MOV	@DTADPB, RPCS2(R4)	; SELECT DRIVE
4445	014546	104413				RESREG		; RESTORE R0-R5
4446	014550	104017				ERROR	17	; REPORT THE ERROR
4447	014552	012705	177777		3\$	MOV	#-1, R5	; SET THE UP/DOWN SWITCH TO DOWN
4448	014556	004737	027120			JSR	PC, @COUNT	; UPDATE THE COUNT
4449	014562	004737	026446			JSR	PC, @THOMS	; STALL FOR 2 MILLISECONDS
4450	014566	005301				DEC	R1	; DONE?
4451	014570	003263				BGT	1\$	; NO--BRANCH
4452	014572	000424				BR	8\$	; YES--EXIT
4453	014574	042777	000101	164576	7\$	BIC	#101, @PKCS	; STOP THE CLOCK
4454	014602	005037	177776			CLR	@PS	; DROP THE PRIORITY

4455	014606	012600			MOV	(SP)+,R0	,PC OF WAIT+2
4456	014610	005726			TST	(SP)+	;POP THE PS FROM THE STACK
4457	014612	104412			SAVREG		,SAVE R0-R5
4458	014614	012702	004164		MOV	#DTADPB,R2	;DPB POINTER
4459	014620	004737	042034		JSR	PC,@#SVRH11	;SAVE ALL THE RH11/RPO4 REGISTERS
4460	014624	012764	000040	000010	MOV	#BIT05,RPCS2(R4)	;MASSBUS CLEAR
4461	014632	013764	004164	000010	MOV	@#DTADPB,RPCS2(R4)	;SELECT DRIVE
4462	014640	104413			RESREG		;RESTORE R0-R5
4463	014642	104020			ERROR	20	;CLOCK OVERFLOWED
4464	014644						
4465	014644	012764	000040	000010	MOV	#BIT05,RPCS2(R4)	;MASSBUS INIT.
4466	014652	013764	004164	000010	MOV	@#DTADPB,RPCS2(R4)	,SELECT DRIVE
4467	014660	004737	024074		JSR	PC,@#ST CLK	,INITIALIZE THE CLOCK
4468	014664	012777	037376	017624	MOV	#ISK,@RPVEC	,RESTORE RH11/RPO4/5'6 INT VECTOR
4469	014672	004037	027252		JSR	R0,@#TYPTIM	,GO TYPE THE TIMES
4470	014676	003034			T12		,POINTER
4471	014700	000004			EXIT15	SCOPE	,LOOP ?



```

4528 015074 012737 015074 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4529 015102 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4530 015106 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4531 015112 012737 015112 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4532 015120 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4533 015124 004037 027742 JSR RO, @#CLRBUF ; CLEAR BUFFER
4534 015130 012737 000171 004166 MOV #READ, @#DTADPB+2 ; COMMAND = READ
4535 015136 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4536 015142 004037 030010 JSR RO, @#CKSCTR ; CHECK THE SECTOR DATA READ
4537 015146 012700 047712 MOV #BUFFER, RO ; BUFFER ADDRESS
4538 015152 005001 CLR R1 ; FIRST SECTOR
4539 015154 012737 015154 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4540 015162 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4541 015166 012737 000161 004166 15 MOV #WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
4542 015174 012737 177400 004170 MOV #SCTRWC, @#DTADPB+4 ; WORD COUNT
4543 015202 010037 004172 MOV RO, @#DTADPB+6 ; BUFFER ADDRESS
4544 015206 110137 004174 MOV#B R1, @#DTADPB+10 ; SECTOR
4545 015212 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4546 015216 012737 015216 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4547 015224 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4548 015230 012737 000151 004166 MOV #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
4549 015236 013737 001352 004170 MOV TRCKWC, @#DTADPB+4 ; WORD COUNT
4550 015244 012737 047712 004172 MOV #BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
4551 015252 105037 004174 CLRB @#DTADPB+10 ; SECTOR
4552 015256 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4553 015262 062700 001000 ADD #512, RO ; MOVE TO NEXT SECTOR
4554 015266 005201 INC R1
4555 015270 023701 001630 CMP PRMLMT+22, R1 ; DONE?
4556 015274 103334 BHIS 15 ; NO--BRANCH
4557 015276 000004 EXIT16 SCOPE ; LOOP ?
4558
4559 ;, *****
4560 ;*TEST 17 TRACK ADDRESSING TEST
4561
4562 ;* THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES
4563 ;* IN CYLINDER "FC" SECTOR "FS" OF EVERY TRACK WITH EACH TRACK
4564 ;* GETTING ITS OWN TRACK ADDRESS
4565 ;* A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO ENSURE
4566 ;* THE DATA IS VALID THEN TRACK 0 IS REWRITTEN AND TRACK 1
4567 ;* THROUGH TRACK 18 IS WRITE CHECKED THEN TRACK 1 IS
4568 ;* REWRITTEN AND TRACK 2 THROUGH TRACK 18 IS WRITE CHECKED
4569 ;* THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING TRACK 17
4570 ;* AND WRITE CHECKING TRACK 18.
4571
4572 ;, *****
4573 TST17
4574 015300 000240 NOP
4575 015302 033737 001462 001234 BIT @#BITS+(17*2), TSTNMS ; DO THIS TEST?
4576 015310 001002 BNE 645 ; YES--BPNCH
4577 015312 000137 015720 JMP TST20 ; NO--GO TO THE NEXT TEST
4578 015316 012737 000017 001102 645 MOV #17, @#STSTNM ; SET UP TEST NUMBER AND
4579 ; CLEAR THE ERROR FLAG ($ERFLG)
4580 015324 004737 024610 JSR PC, LODPRM ; LOAD THE PARMETERS FOR THE TEST
4581 015330 012737 015374 001110 MOV #TEST17, @#$LPERR ; SETUP THE LOOP ON ERROR ADDRESS
4582 015336 013777 001102 163576 MOV $TSTNM, @DISPLAY ; LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4583 015344 013737 001506 001204 MOV @RPT, $TIMES ; GET THE ITERATION COUNT
    
```

4584	015352	113737	001364	001115		MOVB	ERR. CT, \$ERMAX ; MAX ERRORS ALLOWED FOR TEST
4585	015360	012737	015716	001252		MOV	#EXIT17, @#BYPASS
4586	015366	012737	015374	001106		MOV	#TEST17, \$LPADR ; SETUP THE LOOP ADDRESS
4587	015374	012706	001100		TEST17.	MOV	#STACK, SP ; SET THE STACK POINTER
4588	015400	004737	027704			JSR	PC, @#FILBUF ; FILL THE BUFFER WITH TRACK ADDRESS
4589	015404	012737	000161	004166		MOV	#WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
4590	015412	013737	001510	004176		MOV	@#FC, @#DTADPB+12 ; CYLINDER
4591	015420	113737	001524	004174		MOVB	@#FS, @#DTADPB+10 ; SECTOR
4592	015426	012737	177400	004170		MOV	#SCTRC, @#DTADPB+4 ; WORD COUNT
4593	015434	012737	047712	004172		MOV	#BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
4594	015442	005000				CLR	RO ; TRACK=0
4595	015444	012737	015444	001110		MOV	#, \$LPERR ; SETUP THE ERROR LOOP ADDRESS
4596	015452	012706	001100			MOV	#STACK, SP ; LOAD THE STACK POINTER
4597	015456	110037	004175		1\$	MOVB	RO, @#DTADPB+11 ; TRACK ADDRESS
4598	015462	004037	025524			JSR	RO, @#DRVCAL ; START A DATA TRANSFER
4599	015466	062737	001000	004172		ADD	#256. *2, @#DTADPB+6 ; UPDATE BUFFER ADDRESS
4600	015474	005200				INC	RO ; UPDATE TRACK NUMBER
4601	015476	022700	J00023			CMP	#19, RO ; OUT OF TRACKS?
4602	015502	003365				BGT	1\$ ; NO--BRANCH
4603	015504	012737	047712	004172		MOV	#BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
4604	015512	005000				CLR	RO
4605	015514	012737	015514	001110		MOV	#, \$LPERR ; SETUP THE ERROR LOOP ADDRESS
4606	015522	012706	001100			MOV	#STACK, SP ; LOAD THE STACK POINTER
4607	015526	012737	000151	004166		MOV	#WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK
4608	015534	110037	004175		2\$	MOVB	RO, @#DTADPB+11 ; TRACK ADDRESS
4609	015540	004037	025524			JSR	RO, @#DRVCAL ; START A DATA TRANSFER
4610	015544	062737	001000	004172		ADD	#256. *2, @#DTADPB+6 ; UPDATE BUFFER ADDRESS
4611	015552	005200				INC	RO ; UPDATE TRACK NUMBER
4612	015554	022700	000023			CMP	#19, RO ; OUT OF TRACKS?
4613	015560	003365				BGT	2\$ ; NO--BRANCH
4614	015562	005000				CLR	RO ; FIRST TRACK ADDRESS
4615	015564	110037	004175		3\$	MOVB	RO, @#DTADPB+11 ; TRACK
4616	015570	010001				MOV	RO, R1 ; FORM BUFFER ADDRESS
4617	015572	012737	047712	004172		MOV	#BUFFER, @#DTADPB+6 ; BUFFER ADDRESS
4618	015600	005301			4\$	DEC	R1
4619	015602	002411				BLT	5\$
4620	015604	062737	001000	004172		ADD	#256 *2, @#DTADPB+6
4621	015612	000772				BR	4\$
4622	015614	012737	015614	001110		MOV	#, \$LPERR ; SETUP THE ERROR LOOP ADDRESS
4623	015622	012706	001100			MOV	#STACK, SP ; LOAD THE STACK POINTER
4624	015626	012737	000161	004166	5\$	MOV	#WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
4625	015634	004037	025524			JSR	RO, @#DRVCAL ; START A DATA TRANSFER
4626	015640	062737	001000	004172	6\$	ADD	#256. *2, @#DTADPB+6 ; UPDATE BUFFER ADDRESS
4627	015646	105237	004175			INCB	@#DTADPB+11 ; MOVE TO NEXT TRACK
4628	015652	012737	015652	001110		MOV	#, \$LPERR ; SETUP THE ERROR LOOP ADDRESS
4629	015660	012706	001100			MOV	#STACK, SP ; LOAD THE STACK POINTER
4630	015664	012737	000151	004166		MOV	#WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
4631	015672	004037	025524			JSR	RO, @#DRVCAL ; START A DATA TRANSFER
4632	015676	122737	000022	004175		CMPB	#18, @#DTADPB+11 ; OUT OF TRACKS?
4633	015704	003355				BGT	6\$ ; NO--BRANCH
4634	015706	005200				INC	RO ; NEXT TRACK TO WRITE
4635	015710	022700	000022			CMP	#18, RO ; OUT OF TRACKS?
4636	015714	003323				BGT	3\$ ; NO--BRANCH
4637	015716	000004			EXIT17	SCOPE	

4638  
4639  
4640  
4641  
4642  
4643  
4644  
4645  
4646  
4647  
4648  
4649  
4650  
4651  
4652  
4653  
4654  
4655  
4656  
4657  
4658  
4659  
4660  
4661  
4662  
4663  
4664  
4665  
4666  
4667  
4668  
4669  
4670  
4671  
4672  
4673  
4674  
4675  
4676  
4677  
4678  
4679  
4680  
4681  
4682  
4683  
4684  
4685  
4686  
4687  
4688  
4689  
4690  
4691  
4692  
4693

.SBTTL \*\*\* DATA TEST \*\*\*

\*\*\*\*\*

\*TEST 20 DATA TEST

\* THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS  
 \* "FC" THROUGH "LC" BY THE INCREMENT "IC" USING THE DATA PATTERNS  
 \* SPECIFIED. THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER:  
 \* 1 SET "NT" TO "FT" THEN REPEAT 2-4 UNTIL "NT" > "LT"  
 \* 2 WRITE THEN WRITE CHECK "FS" THROUGH "LS" OF TRACK "NT"  
 \* 3 READ THEN SOFTWARE COMPARE "FS" THROUGH "LS" OF TRACK "NT"  
 \* 4 INCREMENT "NT" BY "IT"  
 \* 5 REPEAT STEPS 1-4 FOR EACH DATA PATTERN  
 \* 6. REPEAT STEPS 1-5 FOR "FC" THROUGH "LC" ADVANCING BY "IC"

\* IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND  
 \* THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS  
 \* ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE  
 \* WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS  
 \* FATAL AND NO READ OCCURS.  
 \* FS DEFAULTS TO 1 AND LS DEFAULTS TO 0  
 \* PAT DEFAULTS TO 17777 (ALL POSSIBLE PATTERNS)  
 \* THE POSSIBLE PATTERNS ARE:

PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
165555	000001	177776	000000	000000	052525	007417	026455
133333	000003	177774	000000	010421	052525	007417	026455
165555	000007	177770	000000	021042	052525	007417	026455
133333	000017	177760	177777	031463	125252	170360	151322
165555	000037	177740	177777	042104	125252	170360	151322
133333	000077	177700	177777	052525	125252	170360	151322
165555	000177	177600	000000	063146	052525	007417	026455
133333	000377	177400	000000	073567	052525	007417	026455
165555	000777	177000	177777	104210	125252	170360	151322
133333	001777	176000	177777	114631	125252	170360	151322
165555	003777	174000	000000	125252	052525	007417	026455
133333	007777	170000	177777	135673	125252	170360	151322
165555	017777	160000	000000	146314	052525	007417	026455
133333	037777	140000	177777	156735	125252	170360	151322
165555	077777	100000	000000	167356	052525	007417	026455
133333	177777	000000	177777	177777	125252	170360	151322
PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
165555	000001	177776	172666	077777	153333	000000	177777
133333	000002	177775	155555	137777	066667	177777	000000
165555	000004	177773	172666	157777	153333	177777	000000
133333	000010	177767	155555	167777	066667	177777	000000
165555	000020	177757	172666	173777	153333	177777	000000
133333	000040	177737	155555	175777	066667	177777	000000
165555	000100	177677	172666	176777	153333	177777	000000
133333	000200	177577	155555	177377	066667	177777	000000
165555	000400	177377	172666	177577	153333	177777	000000
133333	001000	176777	155555	177677	066667	177777	000000
165555	002000	175777	172666	177737	153333	177777	000000

```

4694 ;* 133333 004000 173777 155555 177757 066667 177777 000000
4695 ;* 165555 010000 167777 172666 177767 153333 177777 000000
4696 ;* 133333 020000 157777 155555 177773 066667 177777 000000
4697 ;* 165555 040000 137777 172666 177775 153333 177777 000000
4698 ;* 133333 100000 077777 155555 177776 066667 177777 000000
4699 ;*
4700
4701 ;, *****
4702 015720 TST20
4703 015720 000240 NOP
4704 015722 033737 001424 001236 BIT BITS+(20*2-40),TSTNMS+2 ;DO THIS TEST ?
4705 015730 001002 BNE 64$ ;YES--BRANCH
4706 015732 000137 016440 JMP TST21 ;NO--GO TO THE NEXT TEST
4707 015736 012737 000020 001102 64$ MOV #20,@#STSTNM ;SET UP TEST NUMBER AND
4708 ;CLEAR THE ERROR FLAG ($ERFLG)
4709 015744 004737 024610 JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
4710 015750 012737 016122 001110 MOV #TEST20,@#$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
4711 015756 013777 001102 163156 MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4712 015764 013737 001506 001204 MOV @#RPT,$TIMES ;GET THE ITERATION COUNT
4713 015772 113737 001364 001115 MOV#B ERR,CT,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
4714 016000 012737 016000 001106 MOV #,$LPADR ;SETUP THE LOOP ADDRESS
4715 016006 005000 CLR R0 ;CLEAR SWITCH
4716 016010 005004 CLR R4 ;FORM WORD COUNT IN R4
4717 016012 013701 001526 MOV @#LS,R1
4718 016016 163701 001524 SUB @#FS,R1
4719 016022 002004 BGE 1$ ;BRANCH IF FS < OR = LS
4720 016024 063701 001630 ADD PRMLMT+22,R1 ;ADD MAXIMUM SECTOR ADDRESS TO
4721 016030 005201 INC R1 ;MAKE THE DIFFERENCE POSITIVE
4722 016032 005100 COM R0 ;SET SWITCH
4723 016034 062704 000400 1$ ADD #256,R4
4724 016040 005301 DEC R1
4725 016042 002374 BGE 1$
4726 016044 005404 NEG R4
4727 016046 010405 MOV R4,R5 ;COPY NORMAL WORD COUNT INTO SMALL WC
4728 016050 005700 TST R0 ;SWITCH SET?
4729 016052 001412 BEQ 3$ ;NO--BRANCH
4730 016054 005005 CLR R5 ;FORM WORD COUNT FOR LS < FS
4731 016056 013701 001630 MOV PRMLMT+22,R1
4732 016062 163701 001524 SUB @#FS,R1
4733 016066 062705 000400 2$ ADD #256,R5
4734 016072 005301 DEC R1
4735 016074 002374 BGE 2$
4736 016076 005405 NEG R5
4737 016100 113737 001524 004174 3$ MOV#B @#FS,@#DTADPB+10,SECTOR
4738 016106 012737 047712 004172 MOV #BUFFER,@#DTADPB+6 ;DATA BUFFER
4739 016114 012737 016436 001252 MOV #EXIT20,@#BYPASS
4740 016122 012706 001100 TEST20 MOV #STACK,SP ;LOAD THE STACK POINTER
4741 016126 005037 001334 CLR @#WCEFLG ;CLEAR THE WRITE CHECK ERROR FLAG
4742 016132 013701 001510 MOV @#FC,R1 ;PICKUP FIRST CYLINDER
4743 016136 000407 BR 2$
4744 016140 005720 1$ TST (R0)+ ;MOVE TO NEXT DATA PATTERN
4745 016142 022700 000040 CMP #16*2,R0 ;OUT OF PATTERNS?
4746 016146 003004 BGT 3$ ;NO--BRANCH
4747 016150 004037 027630 JSR R0,@#INCCYL ;MOVE TO NEXT CYLINDER
4748 016154 000530 BR EXIT20 ;OUT OF CYLINDERS
4749 016156 005000 2$ CLR R0 ;START WITH PATTERN 0
    
```

```

4750 016160 036037 001424 001530 35: BIT BITS(RO), @#PAT ; THIS PATTERN SELECTED?
4751 016166 001764 BEQ 15 ; NO--BRANCH
4752 016170 013702 MOV @#FT, R2 ; FIRST TRACK
4753 016174 010137 004176 MOV R1, @#DTADPB+12 ; CYLINDER
4754 016200 110237 004175 45: MOV R2, @#DTADPB+11 ; TRACK
4755 016204 010437 004170 MOV R4, @#DTADPB+4 ; WORD COUNT
4756 016210 023701 001512 CMP LC, R1 ; LAST DISK CYLINDER?
4757 016214 003005 BGT 55 ; NO--BRANCH
4758 016216 022702 000022 CMP #18, R2 ; LAST DISK TRACK?
4759 016222 003002 BGT 55 ; NO--BRANCH
4760 016224 010537 004170 MOV R5, @#DTADPB+4 ; SHORT WORD COUNT
4761 016230 017703 162704 55: MOV @SWR, R3 ; INHIBIT WRITE AND
4762 016234 005103 COM R3 ; WRITE CHECK?
4763 016236 032703 000030 BIT #SW04!SW03, R3
4764 016242 001436 BEQ 75 ; YES--BRANCH
4765 016244 004737 030360 JSR PC, @#SETBUF ; MOVE DATA PATTERN INTO THE BUFFER
4766 016250 032777 000020 162662 BIT #SW04, @SWR ; INHIBIT WRITE?
4767 016256 001012 BNE 65 ; YES--BRANCH
4768 016260 012737 016260 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4769 016266 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4770 016272 012737 000161 004166 MOV #WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
4771 016300 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4772 016304 032777 000010 162626 65: BIT #SW03, @SWR ; INHIBIT WRITE CHECK?
4773 016312 001012 BNE 75 ; YES--BRANCH
4774 016314 012737 016314 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4775 016322 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4776 016326 012737 000151 004166 MOV #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
4777 016334 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4778 016340 005737 001334 75: TST @#WCEFLG ; WRITE CHECK ERROR FLAG SET?
4779 016344 001404 BEQ 85 ; NO--BRANCH
4780 016346 032777 000001 162564 BIT #SW00, @SWR ; PERFORM READ AFTER FATAL "WCE"?
4781 016354 001424 BEQ 95 ; NO--BRANCH
4782 016356 032777 000004 162554 85: BIT #SW02, @SWR ; INHIBIT READ DATA AND SOFTWARE COMPARE?
4783 016364 001020 BNE 95 ; YES--BRANCH
4784 016366 012737 016366 001110 MOV #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4785 016374 012706 001100 MOV #STACK, SP ; LOAD THE STACK POINTER
4786 016400 012737 000171 004166 MOV #READ, @#DTADPB+2 ; COMMAND=READ
4787 016406 004037 025524 JSR RO, @#DRVCAL ; START A DATA TRANSFER
4788 016412 032777 000002 162520 BIT #SW01, @SWR ; COMPARE THE DATA?
4789 016420 001002 BNE 95 ; NO--BRANCH
4790 016422 004737 030450 JSR PC, @#DATCMP ; YES--DO IT
4791 016426 004037 027600 95: JSR RO, @#INCTRK ; MOVE TO NEXT TRACK
4792 016432 000642 BR 15 ; OUT OF TRACKS GO TO NEXT PATTERN
4793 016434 000661 BR 45 ; LOOP
4794 016436 000004 EXIT20 SCOPE ; SCOPE LOOP
  
```

```

4795 .SBTTL *** EXERCISE TEST ***
4796
4797 ;*****
4798 ;*TEST 21          RANDOM ADDRESS AND RANDOM PATTERN TEST
4799
4800 ;*          STARTING AT "FC" AND GOING THROUGH "LC" THE DISK PACK
4801 ;*          IS WRITTEN WITH A RANDOM PATTERN THE FIRST TWO WORDS
4802 ;*          OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR
4803 ;*          FOR THAT SECTOR
4804 ;*          THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE "R" TIMES
4805 ;*          "R" DEFAULTS TO 20,000.
4806 ;*
4807 ;*          1)      GENERATE A RANDOM ADDRESS
4808 ;*          2)      WRITE A RANDOM PATTERN AT THE ADDRESS
4809 ;*                   GENERATED IN 1.
4810 ;*          3)      GENERATE A RANDOM ADDRESS
4811 ;*          4)      READ THE SECTOR AT THE ADDRESS
4812 ;*                   GENERATED IN 3.
4813 ;*          5)      DO A SOFTWARE CHECK OF THE DATA READ IN 4
4814 ;*          6)      DO A WRITE CHECK OF THE DATA WRITTEN IN 2
4815 ;*          7)      GENERATE A RANDOM ADDRESS
4816 ;*          8)      READ THE SECTOR AT THE ADDRESS
4817 ;*                   GENERATED IN 7.
4818 ;*          9)      DO A SOFTWARE CHECK OF THE DATA READ IN 8
4819 ;*          10)     DO A WRITE CHECK OF THE DATA WRITTEN IN 2
4820
4821 ;*****
4822 TST21
4823 016440 000240      NOP
4824 016442 033737 001426 001236      BIT      BITS+(21*2-40),TSTNMS+2 ;DO THIS TEST ?
4825 016450 001002      BNE      64$          ,YES--BRANCH
4826 016452 000137 017216      JMP      TST22          ,NO--GO TO THE NEXT TEST
4827 016456 012737 000021 001102 64$: MOV     #21,@#STSTNM    ,SET UP TEST NUMBER AND
4828                                     ,CLEAR THE ERROR FLAG (SERFLG)
4829 016464 004737 024610      JSR     PC,LODPRM      ;LOAD THE PARMETERS FOR THE TEST
4830 016470 012737 016710 001110      MOV     #TST21,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
4831 016476 013777 001102 162436      MOV     $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4832 016504 013737 001506 001204      MOV     @#RPT,$TIMES  ;GET THE ITERATION COUNT
4833 016512 113737 001364 001115      MOV     ERR,CT,SERMAX ;MAX ERRORS ALLOWED FOR TEST
4834 016520 012737 016520 001106      MOV     #.,$LPADR     ;SETUP THE LOOP ADDRESS
4835 016526 012737 017214 001252      MOV     #EXIT21,@#BYPASS
4836 016534 012737 176543 023606      MOV     #176543,@#SHINUM ;PRIME THE RANDOM NUMBER GENERATOR
4837 016542 012737 123456 023610      MOV     #123456,@#SLONUM
4838 016550 013737 001510 004176      MOV     @#FC,@#DTADPB+12 ;CYLINDER
4839 016556 013737 001352 004170      MOV     TRCKWC,@#DTADPB+4 ;WORD COUNT
4840 016564 012737 047712 004172      MOV     #BUFFER,@#DTADPB+6 ;BUFFER ADDRESS
4841 016572 012737 000161 004166      MOV     #WRITE,@#DTADPB+2 ;COMMAND
4842 016600 032737 100000 001220      BIT     #SW15,@#C.SWR  ;WRITE THE DISK PACK BEFORE TESTING?
4843 016606 001027      BNE     3$          ;NO--BRANCH
4844 016610 004037 030766      JSR     RO,@#FILRAN   ;FILL DATA BUFFER WITH RANDOM DATA
4845 016614 005037 004174      CLR     @#DTADPB+10  ;SECTOR AND TRACK
4846 016620 012737 016620 001110      MOV     #,$SLPERR    ;SETUP THE ERROR LOOP ADDRESS
4847 016626 012706 001100      MOV     #STACK,SP    ;LOAD THE STACK POINTER
4848 016632
4849 016632 004037 025524      JSR     RO,@#DRVCL    ;START A DATA TRANSFER
4850 016636 105237 004175      INCB   @#DTADPB+11  ;NEXT TRACK
  
```

```

4851 016642 122737 000023 004175      CMPB   #19, @#DTADPB+11 ; TIME FOR NEXT CYLINDER
4852 016650 003370                    BGT    2$ ; NO--BRANCH
4853 016652 005237 004176              INC    @#DTADPB+12
4854 016656 023737 001512 004176      CMP    @#LC, @#DTADPB+12 ; OUT OF CYLINDERS?
4855 016664 002353                    BGE    1$ ; NO--BRANCH
4856 016666 012737 177400 004170 3$:   MOV    #SCTW, @#DTADPB+4 ; WORD COUNT
4857 016674 012737 016710 001106      MOV    #TEST21, @#SLPADR
4858 016702 012737 016710 001110      MOV    #TEST21, @#SLPERR
4859 016710 012706 001100      TEST21: MOV  #STACK, SP ; SET STACK POINTER
4860 016714 004037 031242              JSR    RO, @#RANADR ; GENERATE A RANDOM ADDRESS
4861 016720 013737 004174 001340      MOV    @#DTADPB+10, @#SVADR ; SAVE THE TRACK/SECTOR
4862 016726 013737 004176 001342      MOV    @#DTADPB+12, @#SVADR+2 ; SAVE THE CYLINDER
4863 016734 012737 000161 004166      MOV    #WRITE, @#DTADPB+2 ; COMMAND=WRITE DATA
4864 016742 012701 047712              MOV    #BUFFER, R1 ; BUFFER ADDRESS
4865 016746 010137 004172              MOV    R1, @#DTADPB+6
4866 016752 004037 031206              JSR    RO, @#RANPAT ; GENERATE RANDOM PATTERN
4867 016756 012737 016756 001110      MOV    #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4868 016764 012706 001100              MOV    #STACK, SP ; LOAD THE STACK POINTER
4869 016770 004037 025524              JSR    RO, @#DRVCAL ; START A DATA TRANSFER
4870 016774 004037 031242              JSR    RO, @#RANADR
4871 017000 012737 000171 004166      MOV    #READ, @#DTADPB+2 ; COMMAND=READ DATA
4872 017006 012737 050712 004172      MOV    #BUFFER+512, @#DTADPB+6 ; BUFFER ADDRESS
4873 017014 012737 017014 001110      MOV    #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4874 017022 012706 001100              MOV    #STACK, SP ; LOAD THE STACK POINTER
4875 017026 004037 025524              JSR    RO, @#DRVCAL ; START A DATA TRANSFER
4876 017032 004037 031010              JSR    RO, @#RANCK ; CHECK THE DATA
4877 017036 013737 001340 004174      MOV    @#SVADR, @#DTADPB+10 ; GET ADDRESS OF WHERE THE LAST
4878 017044 013737 001342 004176      MOV    @#SVADR+2, @#DTADPB+12 ; WRITE WAS PERFORMED
4879 017052 012737 000151 004166      MOV    #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
4880 017060 012737 047712 004172      MOV    #BUFFER, @#DTADPB+6 ; DATA BUFFER ADDRESS
4881 017066 012737 017066 001110      MOV    #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4882 017074 012706 001100              MOV    #STACK, SP ; LOAD THE STACK POINTER
4883 017100 004037 025524              JSR    RO, @#DRVCAL ; START A DATA TRANSFER
4884 017104 004037 031242              JSR    RO, @#RANADR ; GENERATE A RANDOM ADDRESS
4885 017110 012737 000171 004166      MOV    #READ, @#DTADPB+2 ; COMMAND=READ
4886 017116 012737 050712 004172      MOV    #BUFFER+512, @#DTADPB+6 ; DATA BUFFER ADDRESS
4887 017124 012737 017124 001110      MOV    #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4888 017132 012706 001100              MOV    #STACK, SP ; LOAD THE STACK POINTER
4889 017136 004037 025524              JSR    RO, @#DRVCAL ; START A DATA TRANSFER
4890 017142 004037 031010              JSR    RO, @#RANCK ; CHECK THE DATA
4891 017146 013737 001340 004174      MOV    @#SVADR, @#DTADPB+10 ; GET DISK ADDRESS OF THE
4892 017154 013737 001342 004176      MOV    @#SVADR+2, @#DTADPB+12 ; LAST WRITE
4893 017162 012737 000151 004166      MOV    #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
4894 017170 012737 047712 004172      MOV    #BUFFER, @#DTADPB+6 ; DATA BUFFER ADDRESS
4895 017176 012737 017176 001110      MOV    #, $LPERR ; SETUP THE ERROR LOOP ADDRESS
4896 017204 012706 001100              MOV    #STACK, SP ; LOAD THE STACK POINTER
4897 017210 004037 025524              JSR    RO, @#DRVCAL ; START A DATA TRANSFER
4898 017214 000004      EXIT21. SCOPE ; LOOP ?
4899
4900      SBTTL *** RPO4 ACCESS TIME ADJUSTMENT TEST ***
4901
4902      ;, *****
4903      ;*TEST 22 RPO4 ACCESS TIME ADJUSTMENT TEST
4904
4905      ;* THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 136 TO ALLOW THE
4906      ;* OPERATOR TO ADJUST THE ACCESS TIME ON AN RPO4 USING THE
    
```

```

4907 ,* DDU. THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS
4908 ;* SO THAT THE ACCESS TIME INDICATORS ON THE DDU MAY BE OBSERVED.
4909
4910 ,,*****
4911 TST22
4912 017216 000240 NOP
4913 017220 033737 001430 001236 BIT BITS+<22*2-40>,TSTNMS+2 ;DO THIS TEST ?
4914 017226 001002 BNE 645 ;YES--BRANCH
4915 017230 000137 017366 JMP SEOP ;NO--GO TO THE END OF THE PROGRAM
4916 017234 012737 000022 001102 645 MOV #22,@#STSTNM ;SET UP TEST NUMBER AND
4917 ;CLEAR THE ERROR FLAG ($ERFLG)
4918 017242 004737 024610 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
4919 017246 012737 017304 001110 MOV #TEST22,@#$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
4920 017254 013777 001102 161660 MOV $TSTNM,@DISPLAY ;LOAD THE TEST NUMBER INTO THE DISPLAY REGISTER
4921 017262 013737 001506 001204 MOV @#RPT,$TIMES ;GET THE ITERATION COUNT
4922 017270 112737 000144 001115 MOVB #100,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
4923 017276 012737 017304 001106 MOV #TEST22,$LPADR ;SETUP THE LOOP ADDRESS
4924 017304 012706 001100 TEST22: MOV #STACK,SP ;SETUP THE STACK POINTER
4925 017310 013737 001512 004116 MOV LC,DPB A+12 ;ENDING CYLINDER
4926 017316 112737 000105 004106 MOVB #SEEK,@#DPB A+2 ;SEEK=COMMAND
4927 017324 004037 025032 JSR RD,@#CALL.A ;GO EXECUTE THE COMMAND
4928 017330 004037 026364 JSR RD,STALL ;STALL
4929 017334 001360 .WORD STALL3 ;ADDRESS OF STALL VALUE
4930 017336 013737 001510 004116 MOV FC,DPB A+12 ;STARTING CYLINDER
4931 017344 112737 000105 004106 MOVB #SEEK,@#DPB A+2 ;SEEK=COMMAND
4932 017352 004037 025032 JSR RD,@#CALL.A ;GO EXECUTE THE COMMAND
4933 017356 004037 026364 JSR RD,STALL ;STALL
4934 017362 001360 .WORD STALL3 ;ADDRESS OF STALL VALUE
4935 017364 000004 EXIT22: SCOPE ;LOOP ?
4936
4937
4938
4939 SBTTL END OF PASS ROUTINE
4940
4941 ,,*****
4942 ,*INCREMENT THE PASS NUMBER ($PASS)
4943 ,*INDICATE END-OF-PROGRAM AFTER 8 PASSES THRU THE PROGRAM
4944 ,*IF THERES A MONITOR GO TO IT
4945 ,*IF THERE ISN'T JUMP TO RESTART
4946
4947 SEOP
4948 017366 104401 017374 TYPE ,655 ;,TYPE ASCIZ STRING
4949 017372 000410 BR 645 ;,GET OVER THE ASCIZ
4950 ,,655 ASCIZ <CR><LF><LF>/END OF PASS/
4951 645
4952 017414 005737 001232 TST @#DRVSEL ;ANY DRIVES SELECTED?
4953 017420 001434 BEQ 15 ;NO--BRANCH
4954 017422 104401 017430 TYPE ,675 ;,TYPE ASCIZ STRING
4955 017426 000405 BR 665 ;,GET OVER THE ASCIZ
4956 ,,675 .ASCIZ / ON DRIVE/
4957 665
4958 017442 013746 001254 MOV @#CHKDRV,-(SP) ;,SAVE @#CHKDRV FOR TYPEOUT
4959 017446 104403 TYPOS ;,GO TYPE--OCTAL ASCII
4960 017450 002 BYTE 2 ;,TYPE 2 DIGIT(S)
4961 017451 000 BYTE 0 ;,SUPPRESS LEADING ZEROS
4962 017452 104401 017460 TYPE ,695 ;,TYPE ASCIZ STRING
    
```

```

4963 017456 000412          BR      68$          ;;GET OVER THE ASCIZ
4964          ;;69$ .ASCIZ / ERRORS DETECTED=/
4965 017504          68$
4966 017504 013746 001112    MOV     @#$ERTTL, -(SP) ;;SAVE @#$ERTTL FOR TYPEOUT
4967 017510 104402          TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
4968 017512 005037 001112    1$      CLR     @#$ERTTL    ;;ZERO ERROR TOTAL
4969 017516 005037 001102    CLR     $TSTNM      ;;ZERO THE TEST NUMBER
4970 017522 005037 001204    CLR     $TIMES      ;;ZERO THE NUMBER OF ITERATIONS
4971 017526 005237 001100    INC     $PASS       ;;INCREMENT THE PASS NUMBER
4972 017532 042737 100000 001100    BIC     #100000, $PASS ;;DON'T ALLOW A NEG NUMBER
4973 017540 005327          DEC     (PC)+       ;;LOOP?
4974 017542 000010          $EOPCT .WORD      8
4975 017544 003027          BGT     $DOAGN      ;;YES
4976 017546 012737          MOV     (PC)+, @ (PC)+ ;;RESTORE COUNTER
4977 017550 000010          $ENDCT .WORD      8
4978 017552 017542          $EOPCT
4979 017554 104401 017562    TYPE    , 65$      ;;TYPE ASCIZ STRING
4980 017560 000407          BR      64$      ;;GET OVER THE ASCIZ
4981          ;;65$ .ASCIZ <CR><LF>/END OF TEST/
4982 017600          64$
4983 017600 104401 017630    TYPE    , $ENULL   ;;TYPE NULL CHARACTER
4984 017604 013700 000042    $GET42 MOV     @#42, R0  ;;GET MONITOR ADDRESS
4985 017610 001405          BEQ     $DOAGN      ;;BRANCH IF NO MONITOR
4986 017612 000005          RESET          ;;CLEAR THE WORLD
4987 017614 004710          $ENDAD JSR     PC, (R0) ;;GO TO MONITOR
4988 017616 000240          NOP           ;;SAVE ROOM
4989 017620 000240          NOP           ;;FOR
4990 017622 000240          NOP           ;;ACT11
4991 017624          $DOAGN
4992 017624 000137          JMP     @ (PC)+     ;;RETURN
4993 017626 006102          $RTNAD .WORD      RESTART
4994 017630 377 377 000 $ENULL .BYTE    -1, -1, 0 ;;NULL CHARACTER STRING
4995 017634          EVEN
    
```

```

4996
4997          SBTTL *** SYSMAC SUBROUTINES ***
4998
4999          SBTTL ERROR HANDLER ROUTINE
5000
5001          ;*****
5002          ;THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
5003          ;SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
5004          ;AND GO TO TYPERR ON ERROR
5005          ;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE
5006          ;*SW15=1      HALT ON ERROR
5007          ;*SW13=1      INHIBIT ERROR TYPEOUTS
5008          ;*SW10=1      BELL ON ERROR
5009          ;*SW09=1      LOOP ON ERROR
5010          ;*CALL
5011          ;*      ERROR      N      ;, ERROR=EMT AND N=ERROR ITEM NUMBER
5012
5013          SERROR:
5014          017634      104407      CKSWR      ;, TEST FOR CHANGE IN SOFT-SWR
5015          017636      032777      000400      161274      BIT      #SW08, @SWR      ;SEND ERROR MESSAGE TO TTY?
5016          017644      001411      BEQ      7$      ;YES--BRANCH
5017          017646      005737      001230      TST      @#LPTAVL      ;IS THERE A LINE PRINTER AVAILABLE?
5018          017652      001406      BEQ      7$      ;NO--BRANCH
5019          017654      013737      001420      001150      MOV      @#LPS, @#STPS      ;YES--SETUP STATUS
5020          017662      013737      001422      001152      MOV      @#LPB, @#STPB      ;AND BUFFER REG 'S FOR LINE PRINTER
5021          017670      105237      001103      7$      INCB      $ERFLG      ;, SET THE ERROR FLAG
5022          017674      001775      BEQ      7$      ;, DON'T LET THE FLAG GO TO ZERO
5023          017676      013777      001102      161236      MOV      $STNM, @DISPLAY      ;, DISPLAY TEST NUMBER AND ERROR FLAG
5024          017704      032777      002000      161226      BIT      #BIT10, @SWR      ;, BELL ON ERROR?
5025          017712      001402      BEQ      1$      ;, NO - SKIP
5026          017714      104401      001210      TYPE      , $BELL      ;, RING BELL
5027          017720      005237      001112      1$      INC      $ERTTL      ;, COUNT THE NUMBER OF ERRORS
5028          017724      011637      001116      MOV      (SP), $ERRPC      ;, GET ADDRESS OF ERROR INSTRUCTION
5029          017730      162737      000002      001116      SUB      #2, $ERRPC
5030          017736      117737      161154      001114      MOV      @ $ERRPC, $ITEMB      ;, STRIP AND SAVE THE ERROR ITEM CODE
5031          017744      032777      020000      161166      BIT      #BIT13, @SWR      ;, SKIP TYPEOUT IF SET
5032          017752      001004      BNE      20$      ;, SKIP TYPEOUTS
5033          017754      004737      020054      JSR      PC, TYPERR      ;, GO TO USER ERROR ROUTINE
5034          017760      104401      001215      TYPE      , $CRLF
5035          017764      20$
5036          017764      005777      161150      2$      TST      @SWR      ;, HALT ON ERROR
5037          017770      100002      BPL      3$      ;, SKIP IF CONTINUE
5038          017772      000000      HALT      ;, HALT ON ERROR!
5039          017774      104407      CKSWR      ;, TEST FOR CHANGE IN SOFT-SWR
5040          017776      032777      001000      161134      3$      BIT      #BIT09, @SWR      ;, LOOP ON ERROR SWITCH SET?
5041          020004      001402      BEQ      4$      ;, BR IF NO
5042          020006      013716      001110      MOV      $LPERR, (SP)      ;, FUDGE RETURN FOR LOOPING
5043          020012      005737      001206      4$      TST      $ESCAPE      ;, CHECK FOR AN ESCAPE ADDRESS
5044          020016      001402      BEQ      5$      ;, BR IF NONE
5045          020020      013716      001206      MOV      $ESCAPE, (SP)      ;, FUDGE RETURN ADDRESS FOR ESCAPE
5046          020024      5$
5047          020024      023737      000042      000046      CMP      @#42, @#46      ;, ACT11 AUTOMATIC MODE?
5048          020032      001001      BNE      6$      ;, NO, CONTINUE
5049          020034      000000      HALT      ;, HALT ON ERROR
5050          020036      013737      001414      001150      6$      MOV      @#TPS, @#STPS      ;, SET STATUS AND BUFFER REG 'S
5051          020044      013737      001416      001152      MOV      @#TPB, @#STPB      ;, FOR TTY
    
```

```

5052 020052 000002          RTI          ;RETURN FROM ERROR CALL
5053
5054                      ;*****
5055                      ;SBTTL TYPERR - TYPE ERROR ROUTINE
5056                      ;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE
5057                      ;WHICH ERROR IS TO BE REPORTED, IT THEN OBTAINS, FROM THE "ERROR
5058                      ;TABLE" ($ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
5059                      ;CONCERNING THE ERROR.
5060                      ;CALL
5061                      ;      JSR      PC, @#TYPERR
5062                      ;      RETURN
5063
5064 020054 113737 001102 001176 TYPERR. MOVB   @#STSTNM, @#STMPO ;SAVE THE TEST NUMBER
5065 020062 104412          SAVREG          ;SAVE R0 - R5
5066 020064 162700 000004  SUB      #4, R0          ;FORM TEST PC
5067 020070 010037 001162  MOV      R0, @#$REG0      ;COPY R0-R5 IN $REG0-$REG5
5068 020074 010137 001164  MOV      R1, @#$REG1
5069 020100 010237 001166  MOV      R2, @#$REG2
5070 020104 010337 001170  MOV      R3, @#$REG3
5071 020110 010437 001172  MOV      R4, @#$REG4
5072 020114 010537 001174  MOV      R5, @#$REG5
5073 020120 113700 001114  MOVB   @#$ITEMB, R0      ;PICKUP ERROR ITEM NUMBER
5074 020124 010001          MOV      R0, R1          ;AND COPY IT INTO R1
5075 020126 005300          DEC      R0          ;FORM INDEX FOR ERROR TABLE
5076 020130 106300          ASLB   R0
5077 020132 106300          ASLB   R0
5078 020134 106300          ASLB   R0
5079 020136 103002          BCC    1$          ;IS ERROR > 37?
5080 020140 062700 000240  ADD     #ITEM41-$ERRTB, R0 ;YES--FORM OFFSET
5081 020144 062700 004306 1$     ADD     #$ERRTB, R0      ;FORM ADDRESS
5082 020150 012037 020164  MOV     (R0)+, 2$        ;GET ERROR MESSAGE (EM) POINTER
5083 020154 001447          BEQ    7$          ;BRANCH IF THERE ISN'T ONE
5084 020156 104401 001215  TYPE   , $CRLF        ;"CARRIAGE RETURN - LINE FEED"
5085 020162 104401          TYPE
5086 020164 000000 2$     WORD   0          ;"EM" POINTER GOES HERE
5087 020166 162701 000041  SUB     #41, R1         ;SPECIAL ERROR ITEM NUMBER?
5088 020172 100440          BMI    7$          ;NO--BRANCH
5089 020174 013701 001260  MOV     @#SVSTAT, R1    ;GET STATUS/ERROR INDICATOR
5090 020200 106301          ASLB   R1          ;STRIP "DONE" BIT (BIT07)
5091 020202 006301          ASL   R1          ;STRIP "ERROR" BIT (BIT15)
5092 020204 012702 004254  MOV     #STATBL, R2     ;1ST ADDRESS ON STATUS MESSAGE POINTERS
5093 020210 005003          CLR   R3          ;CARRIAGE RETURN-LINE FEED SWITCH
5094 020212 104401 020220  TYPE   , 65$         ;, TYPE ASCIZ STRING
5095 020216 000402          BR    64$         ;, GET OVER THE ASCIZ
5096                      ;, 65$
5097                      64$
5098 020224 012237 020246 3$     MOV     (R2)+, 5$        ;MESSAGE POINTER
5099 020230 006301          ASL   R1          ;TYPE THIS MESSAGE?
5100 020232 103013          BCC   6$          ;NO--BRANCH
5101 020234 005103          COM   R3          ;YES--TYPE A "CR" & "LF"?
5102 020236 001002          BNE   4$          ;NO--BRANCH
5103 020240 104401 001215  TYPE   , $CRLF        ;YES
5104 020244 104401          TYPE
5105 020246 000000 4$     WORD   0          ;MESSAGE POINTER GOES HERE
5106 020250 005701          TST   R1          ;MORE TO TYPE?
5107 020252 001403          BEQ   6$          ;NO--BRANCH
    
```

```

5108 020254 104401 044040          TYPE      ,MSG SP      ;YES--SPACES
5109 020260 000761                    BR          3$          ;LOOP
5110 020262 001360                    BNE          3$          ;BRANCH IF NOT FINISHED
5111 020264 104401 020272          TYPE      ,67$          ;,TYPE ASCIZ STRING
5112 020270 000401                    BR          66$          ;,GET OVER THE ASCIZ
5113                    ;,67$          ;ASCIZ  /)/
5114 020274                    66$
5115 020274 012037 020310          7$          MOV      (R0)+,8$      ;PICK UP DATA HEADER (DH) POINTER
5116 020300 001404                    BEQ          9$          ;BRANCH IF NONE
5117 020302 104401 001215          TYPE      , $CRLF      ;CARRIAGE RETURN-LINE FEED
5118 020306 104401                    TYPE
5119 020310 000000                    8$          .WORD      0          ;"DH" POINTER GOES HERE
5120 020312 012001                    9$          MOV      (R0)+,R1      ;PICKUP DATA TABLE (DT) POINTER
5121 020314 001450                    BEQ         20$          ;BRANCH IF NONE
5122 020316 005005                    CLR          R5          ;SET INDENT SWITCH
5123 020320 012000                    MOV      (R0)+,R0      ;DATA FORMAT (DF) POINTER
5124 020322 012002                    MOV      (R0)+,R2      ;NUMBER OF DH'S TO TYPE
5125 020324 001441                    BEQ         17$          ;BRANCH IF DH NUMBER IS 0
5126 020326 005105                    COM          R5          ;NO INDENT
5127 020330 104401 001215          TYPE      , $CRLF      ;CARRIAGE RETURN-LINE FEED
5128 020334 112003                    10$         MOV      (R0)+,R3      ;NUMBER OF DATA WORDS TO TYPE
5129 020336 112004                    MOV      (R0)+,R4      ;AND HOW TO TYPE THEM
5130 020340 006004                    11$         ROR          R4          ;OCTAL OR DECIMAL?
5131 020342 103403                    BCS         12$          ;DECIMAL--BRANCH
5132 020344 013146                    MOV      @ (R1)+, -(SP) ;,SAVE @ (R1)+ FOR TYPEOUT
5133 020346 104402                    TYPOC
5134 020350 000402                    BR          13$          ;,GO TYPE--OCTAL ASCII (ALL DIGITS)
5135 020352                    12$
5136 020352 013146                    MOV      @ (R1)+, -(SP) ;,SAVE @ (R1)+ FOR TYPEOUT
5137 020354 104405                    TYPDS
5138 020356 005303                    13$         DEC          R3          ;,GO TYPE--DECIMAL ASCII WITH SIGN
5139 020360 001403                    BEQ         14$          ;MORE NUMBERS TO TYPE?
5140 020362 104401 044040          TYPE      ,MSG SP      ;NO--BRANCH
5141 020366 000764                    BR          11$          ;YES--TYPE SEPERATORS
5142 020370 005302                    14$         DEC          R2          ;LOOP
5143 020372 003421                    BLE         20$          ;MORE DH'S?
5144 020374 104401 001215          TYPE      , $CRLF      ;NO--BRANCH
5145 020400 005105                    COM          R5          ;YES--START A NEW LINE
5146 020402 001002                    BNE         15$          ;INDENT?
5147 020404 104401 044040          TYPE      ,MSG SP      ;NO--BRANCH
5148 020410 012037 020416          15$         MOV      (R0)+,16$      ;YES--TYPE SPACES
5149 020414 104401                    TYPE
5150 020416 000000                    16$         .WORD      0          ;GET NEXT DH
5151 020420 104401 001215          TYPE      , $CRLF      ;AND TYPE IT
5152 020424 005705                    TST          R5          ;DH POINTER GOES HERE
5153 020426 001342                    BNE         10$          ;CARRIAGE RETURN-LINE FEED
5154 020430 104401 044040          17$         TYPE      ,MSG SP      ;INDENT?
5155 020434 000737                    BR          10$          ;NO--BRANCH
5156 020436 104413                    20$         RESREG
5157 020440 000207                    RTS          PC          ;YES--TYPE SPACES
5158                    ;LOOP
5159                    ;RESTORE R0 - R5
5160                    ;RETURN
5161                    SBTTL  TYPE ROUTINE
5162                    ;,*****
5163                    ;*ROUTINE TO TYPE ASCIZ MESSAGE MESSAGE MUST TERMINATE WITH A 0 BYTE
                    ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED
    
```

TYPE ROUTINE

```

5164 ,*NOTE1          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER
5165 ,*NOTE2          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
5166 ;*NOTE3          $FILLC CONTAINS THE CHARACTER TO FILL AFTER
5167 ,*
5168 ,*CALL
5169 ,*1) USING A TRAP INSTRUCTION
5170 ,*      TYPE      ,MESADR          ..MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
5171 ,*OR
5172 ,*      TYPE
5173 ,*      MESADR
5174 ,*
5175
5176 020442 105737 001157 $TYPE  TSTB  $TFPLG          .. IS THERE A TERMINAL?
5177 020446 100002          BPL      1$          .. BR IF YES
5178 020450 000000          HALT          .. HALT HERE IF NO TERMINAL
5179 020452 000407          BR        3$          .. LEAVE
5180 020454 010046          1$  MOV      RO, -(SP)          .. SAVE RO
5181 020456 017600 000002  MOV      @2(SP), RO          .. GET ADDRESS OF ASCIZ STRING
5182 020462 112046          2$  MOVVB   (RO)+, -(SP)          .. PUSH CHARACTER TO BE TYPED ONTO STACK
5183 020464 001005          BNE      4$          .. BR IF IT ISN'T THE TERMINATOR
5184 020466 005726          TST      (SP)+          .. IF TERMINATOR POP IT OFF THE STACK
5185 020470 012600          60$  MOV      (SP)+, RO          .. RESTORE RO
5186 020472 062716 000002  3$  ADD      #2, (SP)          .. ADJUST RETURN PC
5187 020476 000002          RTI          .. RETURN
5188 020500 122716 000011  4$  CMPB    #HT, (SP)          .. BRANCH IF <HT>
5189 020504 001430          BEQ      8$
5190 020506 122716 000200  CMPB    #CRLF, (SP)          .. BRANCH IF NOT <CRLF>
5191 020512 001006          BNE      5$
5192 020514 005726          TST      (SP)+          .. POP <CR><LF> EQUIV
5193 020516 104401          TYPE          .. TYPE A CR AND LF
5194 020520 001215          $CRLF
5195 020522 105037 020656  CLRB    $CHARCNT          .. CLEAR CHARACTER COUNT
5196 020526 000755          BR      2$          .. GET NEXT CHARACTER
5197 020530 004737 020612  5$  JSR      PC, $TYPEPC          .. GO TYPE THIS CHARACTER
5198 020534 123726 001156  6$  CMPB    $FILLC, (SP)+          .. IS IT TIME FOR FILLER CHARS ?
5199 020540 001350          BNE      2$          .. IF NO GO GET NEXT CHAR
5200 020542 013746 001154  MOV      $NULL, -(SP)          .. GET # OF FILLER CHARS NEEDED
5201          AND THE NULL CHAR
5202 020546 105366 000001  7$  DECB    1(SP)          .. DOES A NULL NEED TO BE TYPED?
5203 020552 002770          BLT      6$          .. BR IF NO--GO POP THE NULL OFF OF STACK
5204 020554 004737 020612  JSR      PC, $TYPEPC          .. GO TYPE A NULL
5205 020560 105337 020656  DECB    $CHARCNT          .. DO NOT COUNT AS A COUNT
5206 020564 000770          BR      7$          .. LOOP
5207
5208 ,HORIZONTAL TAB PROCESSOR
5209
5210 020566 112716 000040  8$  MOVVB   #' , (SP)          .. REPLACE TAB WITH SPACE
5211 020572 004737 020612  9$  JSR      PC, $TYPEPC          .. TYPE A SPACE
5212 020576 132737 000007 020656  BITB    #7, $CHARCNT          .. BRANCH IF NOT AT
5213 020604 001372          BNE      9$          .. TAB STOP
5214 020606 005726          TST      (SP)+          .. POP SPACE OFF STACK
5215 020610 000724          BR      2$          .. GET NEXT CHARACTER
5216 020612 105777 160332  $TYPEPC TSTB    @5TPS          .. WAIT UNTIL PRINTER IS READY
5217 020616 100375          BPL      $TYPEPC
5218 020620 116677 000002 160324  MOVVB   2(SP), @5TPB          .. LOAD CHAR TO BE TYPED INTO DATA REG
5219 020626 122766 000015 000002  CMPB    #CR, 2(SP)          .. IS CHARACTER A CARRIAGE RETURN?

```

```

5220 020634 001003          BNE      1$          ;; BRANCH IF NO
5221 020636 105037 020656  CLR$     $CHARCNT  ;; YES--CLEAR CHARACTER COUNT
5222 020642 000406          BR       $TYPEX    ;; EXIT
5223 020644 122766 000012 000002 1$     CMPB     #LF,2(SP)  ;; IS CHARACTER A LINE FEED?
5224 020652 001402          BEQ      $TYPEX    ;; BRANCH IF YES
5225 020654 105227          INCB     (PC)+    ;; COUNT THE CHARACTER
5226 020656 000000          $CHARCNT WORD 0    ;; CHARACTER COUNT STORAGE
5227 020660 000207          $TYPEX  RTS     PC
5228
5229
5230          .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
5231
5232          ;; *****
5233          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
5234          ;*OCTAL (ASCII) NUMBER AND TYPE IT
5235          ;*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
5236          ;*CALL.
5237          ;*      MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
5238          ;*      TYPOS   ;; CALL FOR TYPEOUT
5239          ;*      BYTE   N              ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
5240          ;*      .BYTE  M              ;; M=1 OR 0
5241          ;*                                  ;; 1=TYPE LEADING ZEROS
5242          ;*                                  ;; 0=SUPPRESS LEADING ZEROS
5243          ;*
5244          ;*STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
5245          ;*STYPOS OR STYPOC
5246          ;*CALL.
5247          ;*      MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
5248          ;*      TYPON  ;; CALL FOR TYPEOUT
5249          ;*
5250          ;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
5251          ;*CALL
5252          ;*      MOV      NUM,-(SP)      ;; NUMBER TO BE TYPED
5253          ;*      TYPOC  ;; CALL FOR TYPEOUT
5254
5255 020662 017646 000000          $TYPOS  MOV      @($P),-(SP)  ;; PICKUP THE MODE
5256 020666 116637 000001 021105  MOV$B   1($P),$OFILL  ;; LOAD ZERO FILL SWITCH
5257 020674 112637 021107          MOV$B   ($P)+,$OMODE+1  ;; NUMBER OF DIGITS TO TYPE
5258 020700 062716 000002          ADD     #2,$P        ;; ADJUST RETURN ADDRESS
5259 020704 000406          BR       $TYPON
5260 020706 112737 000001 021105  $TYPOC  MOV$B   #1,$OFILL  ;; SET THE ZERO FILL SWITCH
5261 020714 112737 000006 021107  MOV$B   #6,$OMODE+1  ;; SET FOR SIX(6) DIGITS
5262 020722 112737 000005 021104  $TYPON  MOV$B   #5,$OCNT    ;; SET THE ITERATION COUNT
5263 020730 010346          MOV     R3,-(SP)    ;; SAVE R3
5264 020732 010446          MOV     R4,-(SP)    ;; SAVE R4
5265 020734 010546          MOV     R5,-(SP)    ;; SAVE R5
5266 020736 113704 021107          MOV$B   $OMODE+1,R4  ;; GET THE NUMBER OF DIGITS TO TYPE
5267 020742 005404          NEG     R4
5268 020744 062704 000006          ADD     #6,R4      ;; SUBTRACT IT FOR MAX ALLOWED
5269 020750 110437 021106          MOV$B   R4,$OMODE  ;; SAVE IT FOR USE
5270 020754 113704 021105          MOV$B   $OFILL,R4  ;; GET THE ZERO FILL SWITCH
5271 020760 016605 000012          MOV     12($P),R5  ;; PICKUP THE INPUT NUMBER
5272 020764 005003          CLR     R3        ;; CLEAR THE OUTPUT WORD
5273 020766 006105          1$     ROL     R5  ;; ROTATE MSB INTO "C"
5274 020770 000404          BR      3$        ;; GO DO MSB
5275 020772 006105          2$     ROL     R5  ;; FORM THIS DIGIT

```

```

5276 020774 006105          ROL    R5
5277 020776 006105          ROL    R5
5278 021000 010503          MOV    R5,R3
5279 021002 006103          3$    ROL    R3          ;; GET LSB OF THIS DIGIT
5280 021004 105337 021106    DECB   $OMODE          ;; TYPE THIS DIGIT?
5281 021010 100016          BPL    7$              ;; BR IF NO
5282 021012 042703 177770    BIC    #177770,R3      ;; GET RID OF JUNK
5283 021016 001002          BNE    4$              ;; TEST FOR 0
5284 021020 005704          TST    R4              ;; SUPPRESS THIS 0?
5285 021022 001403          BEQ    5$              ;; BR IF YES
5286 021024 005204          4$    INC    R4          ;; DON'T SUPPRESS ANYMORE 0'S
5287 021026 052703 000060    BIS    #'0,R3          ;; MAKE THIS DIGIT ASCII
5288 021032 052703 000040    5$    BIS    #' ,R3      ;; MAKE ASCII IF NOT ALREADY
5289 021036 110337 021102    MOVB   R3,8$          ;; SAVE FOR TYPING
5290 021042 104401 021102    TYPE   ,8$            ;; GO TYPE THIS DIGIT
5291 021046 105337 021104    7$    DECB   $OCNT          ;; COUNT BY 1
5292 021052 003347          BGT    2$              ;; BR IF MORE TO DO
5293 021054 002402          BLT    6$              ;; BR IF DONE
5294 021056 005204          INC    R4              ;; INSURE LAST DIGIT ISN'T A BLANK
5295 021060 000744          BR     2$              ;; GO DO THE LAST DIGIT
5296 021062 012605          6$    MOV    (SP)+,R5      ;; RESTORE R5
5297 021064 012604          MOV    (SP)+,R4      ;; RESTORE R4
5298 021066 012603          MOV    (SP)+,R3      ;; RESTORE R3
5299 021070 016666 000002 000004  MOV    2(SP),4(SP)    ;; SET THE STACK FOR RETURNING
5300 021076 012616          MOV    (SP)+,(SP)
5301 021100 000002          RTI                    ;; RETURN
5302 021102 000          8$    BYTE   0          ;; STORAGE FOR ASCII DIGIT
5303 021103 000          BYTE   0          ;; TERMINATOR FOR TYPE ROUTINE
5304 021104 000          $OCNT  .BYTE  0      ;; OCTAL DIGIT COUNTER
5305 021105 000          $OFILL .BYTE  0      ;; ZERO FILL SWITCH
5306 021106 000000          $OMODE .WORD   0      ;; NUMBER OF DIGITS TO TYPE
5307
5308          SBTTL  CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
5309
5310          ;; *****
5311          ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
5312          ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT  DEPENDING ON WHETHER THE
5313          ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
5314          ;*BEFORE THE FIRST DIGIT OF THE NUMBER  LEADING ZEROS WILL ALWAYS BE
5315          ;*REPLACED WITH SPACES.
5316          ;*CALL:
5317          ;*      MOV    NUM,-(SP)          ;; PUT THE BINARY NUMBER ON THE STACK
5318          ;*      TYPDS          ;; GO TO THE ROUTINE
5319
5320          $TYPDS
5321          MOV    R0,-(SP)          ;; PUSH R0 ON STACK
5322          MOV    R1,-(SP)          ;; PUSH R1 ON STACK
5323          MOV    R2,-(SP)          ;; PUSH R2 ON STACK
5324          MOV    R3,-(SP)          ;; PUSH R3 ON STACK
5325          MOV    R5,-(SP)          ;; PUSH R5 ON STACK
5326          MOV    #20200,-(SP)      ;; SET BLANK SWITCH AND SIGN
5327          MOV    20(SP),R5        ;; GET THE INPUT NUMBER
5328          BPL    1$              ;; BR IF INPUT IS POS
5329          NEG    R5              ;; MAKE THE BINARY NUMBER POS
5330          MOVB   #'-,1(SP)        ;; MAKE THE ASCII NUMBER NEG
5331          1$    CLR    R0          ;; ZERO THE CONSTANTS INDEX
    
```

```

5332 021146 012703 021324      MOV      #SDBLK,R3      ;; SETUP THE OUTPUT POINTER
5333 021152 112723 000040      MOVVB   #' ,(R3)+     ;; SET THE FIRST CHARACTER TO A BLANK
5334 021156 005002           2$     CLR      R2           ;; CLEAR THE BCD NUMBER
5335 021160 016001 021314      MOV      $DTBL(RO),R1  ;; GET THE CONSTANT
5336 021164 160105           3$     SUB      R1,R5        ;; FORM THIS BCD DIGIT
5337 021166 002402           4$     BLT     4$           ;; BR IF DONE
5338 021170 005202           5$     INC     R2           ;; INCREASE THE BCD DIGIT BY 1
5339 021172 000774           6$     BR      3$
5340 021174 060105           7$     ADD     R1,R5        ;; ADD BACK THE CONSTANT
5341 021176 005702           8$     TST     R2           ;; CHECK IF BCD DIGIT=0
5342 021200 001002           9$     BNE     5$           ;; FALL THROUGH IF 0
5343 021202 105716           0$     TSTB   (SP)          ;; STILL DOING LEADING 0'S?
5344 021204 100407           1$     BMI     7$           ;; BR IF YES
5345 021206 106316           2$     ASLB   (SP)          ;; MSD?
5346 021210 103003           3$     BCC     6$           ;; BR IF NO
5347 021212 116663 000001 177777  MOVVB   1(SP),-1(R3)   ;; YES--SET THE SIGN
5348 021220 052702 000060 6$     BIS     #'0,R2        ;; MAKE THE BCD DIGIT ASCII
5349 021224 052702 000040 7$     BIS     #' ,R2        ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
5350 021230 110223           8$     MOVVB  R2,(R3)+     ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
5351 021232 005720           9$     TST     (RO)+        ;; JUST INCREMENTING
5352 021234 020027 000010      CMP     RO,#10        ;; CHECK THE TABLE INDEX
5353 021240 002746           0$     BLT     2$           ;; GO DO THE NEXT DIGIT
5354 021242 003002           1$     BGT     8$           ;; GO TO EXIT
5355 021244 010502           2$     MOV     R5,R2        ;; GET THE LSD
5356 021246 000764           3$     BR      6$           ;; GO CHANGE TO ASCII
5357 021250 105726           4$     TSTB   (SP)+        ;; WAS THE LSD THE FIRST NON-ZERO?
5358 021252 100003           5$     BPL     9$           ;; BR IF NO
5359 021254 116663 177777 177776  MOVVB  -1(SP),-2(R3)   ;; YES--SET THE SIGN FOR TYPING
5360 021262 105013           6$     CLRB   (R3)          ;; SET THE TERMINATOR
5361 021264 012605           7$     MOV     (SP)+,R5     ;; POP STACK INTO R5
5362 021266 012603           8$     MOV     (SP)+,R3     ;; POP STACK INTO R3
5363 021270 012602           9$     MOV     (SP)+,R2     ;; POP STACK INTO R2
5364 021272 012601           0$     MOV     (SP)+,R1     ;; POP STACK INTO R1
5365 021274 012600           1$     MOV     (SP)+,R0     ;; POP STACK INTO R0
5366 021276 104401 021324      TYPE    ,SDBLK        ;; NOW TYPE THE NUMBER
5367 021302 016666 000002 000004  MOV     2(SP),4(SP)   ;; ADJUST THE STACK
5368 021310 012616           2$     MOV     (SP)+,(SP)   ;; RETURN TO USER
5369 021312 000002           3$     RTI
5370 021314 023420           4$     $DTBL: 10000
5371 021316 001750           5$           1000
5372 021320 000144           6$           100.
5373 021322 000012           7$           10.
5374 021324 000004           8$     $SDBLK: .BLKW 4
5375
5376           SBTTL  TTY INPUT ROUTINE
5377
5378           ; *****
5379           ENABL  LSB
5380 021334 000000      $TKCNT: .WORD 0      ;; NUMBER OF ITEMS IN QUEUE
5381 021336 000000      $TKQIN: .WORD 0     ;; INPUT POINTER
5382 021340 000000      $TKQOUT: .WORD 0    ;; OUTPUT POINTER
5383 021342 000002      $TKQSRT: .BLKB 2    ;; TTY KEYBOARD QUEUE
5384           $TKQEND=
5385
5386           ;*TK INITIALIZE ROUTINE
5387           ;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE

```

```

5388      ,*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
5389      ;
5390      ,*CALL
5391      ,*      JSR      PC, $TKINT
5392      ,*      RETURN
5393      ;
5394      021344 005037 021334 $TKINT. CLR      $TKCNT      ;; CLEAR COUNT OF ITEMS IN QUEUE
5395      021350 012737 021342 021336 MOV      $TKQSR, $TKQIN ;; MOVE THE STARTING ADDRESS OF THE
5396      021356 013737 021336 021340 MOV      $TKQIN, $TKQOUT ;; QUEUE INTO THE INPUT & OUTPUT POINTERS
5397      021364 012737 021414 000060 MOV      $TKSRV, @TKVEC ;; INITIALIZE THE KEYBOARD VECTOR
5398      021372 012737 000200 000062 MOV      #200, @TKVEC+2 ;; "BR" LEVEL 4
5399      021400 005777 157542 TST      @TKB      ;; CLEAR DONE FLAG
5400      021404 012777 000100 157532 MOV      #100, @TKS      ;; ENABLE TTY KEYBOARD INTERRUPT
5401      021412 000207 RTS      PC      ;; RETURN TO CALLER
5402
5403      ,*TK SERVICE ROUTINE
5404      ,*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
5405      ,*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
5406      ,*IT IN THE QUEUE
5407      ,*IF THE CHARACTER IS A "CONTROL-C" ( C ) $TKINT IS CALLED AND
5408      ,*UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (START2)
5409      ;
5410      021414 117746 157526 $TKSRV MOVB     @TKB, -(SP)      ;; PICKUP THE CHARACTER
5411      021420 042716 177600 BIC      # C177, (SP)      ;; STRIP THE JUNK
5412      021424 021627 000003 CMP      (SP), #3      ;; IS IT A CONTROL C?
5413      021430 001007 BNE      1$      ;; BRANCH IF NO
5414      021432 104401 022544 TYPE     , $CNTLC      ;; TYPE A CONTROL-C ( C )
5415      021436 004737 021344 JSR      PC, $TKINT      ;; INIT THE KEYBOARD
5416      021442 005726 TST      (SP)+      ;; CLEAN UP STACK
5417      021444 000137 004660 JMP      START2      ;; CONTROL C RESTART
5418      021450 021627 000007 1$ CMP      (SP), #7      ;; IS IT A CONTROL G?
5419      021454 001004 BNE      2$      ;; BRANCH IF NO
5420      021456 022737 000176 001140 CMP      $SWREG, SWR      ;; IS SOFT-SWR SELECTED?
5421      021464 001500 BEQ      6$      ;; GO TO SWR CHANGE
5422
5423      021466 022737 000002 021334 2$ CMP      #2, $TKCNT      ;; IS THE QUEUE FULL?
5424      021474 001004 BNE      3$      ;; BRANCH IF NO
5425      021476 104401 001210 TYPE     , $BELL      ;; RING THE TTY BELL
5426      021502 005726 TST      (SP)+      ;; CLEAN CHARACTER OFF OF STACK
5427      021504 000451 BR      5$      ;; EXIT
5428      021506 021627 000023 3$ CMP      (SP), #23      ;; IS IT A CONTROL-S?
5429      021512 001021 BNE      32$      ;; BRANCH IF NO
5430      021514 005077 157424 CLR      @TKS      ;; DISABLE TTY KEYBOARD INTERRUPTS
5431      021520 005726 TST      (SP)+      ;; CLEAN CHAR OFF STACK
5432      021522 105777 157416 31$ TSTB     @TKS      ;; WAIT FOR A CHAR
5433      021526 100375 BPL      31$      ;; LOOP UNTIL ITS THERE
5434      021530 117746 157412 MOVB     @TKB, -(SP)      ;; GET THE CHARACTER
5435      021534 042716 177600 BIC      # C177, (SP)      ;; MAKE IT 7-BIT ASCII
5436      021540 022627 000021 CMP      (SP)+, #21      ;; IS IT A CONTROL-Q?
5437      021544 001366 BNE      31$      ;; BRANCH IF NO
5438      021546 012777 000100 157370 MOV      #100, @TKS      ;; REENABLE TTY KEYBOARD INTERRUPTS
5439      021554 000002 RTI      ;; RETURN
5440      021556 005237 021334 32$ INC      $TKCNT      ;; COUNT THIS CHARACTER
5441      021562 021627 000140 CMP      (SP), #140      ;; IS IT UPPER CASE?
5442      021566 002405 BLT      4$      ;; BRANCH IF YES
5443

```

```

5444 021570 021627 000175          CMP      (SP),#175      ;; IS IT A SPECIAL CHAR?
5445 021574 003002                   BGT      4$            ;; BRANCH IF YES
5446 021576 042716 000040          BIC      #40,(SP)      ;; MAKE IT UPPER CASE
5447 021602 112677 177530          4$:     MOVB     (SP)+,@$TKQIN ;; AND PUT IT IN QUEUE
5448 021606 005237 021336          INC      $TKQIN        ;; UPDATE THE POINTER
5449 021612 023727 021336 021344   CMP      $TKQIN,$$TKQEND ;; GO OFF THE END?
5450 021620 001003                   BNE      5$            ;; BRANCH IF NO
5451 021622 012737 021342 021336   MOV      $$TKQRT,$TKQIN ;; RESET THE POINTER
5452 021630 000002                   5$:     RTI             ;; RETURN
5453
5454                               ;; *****
5455                               ;; *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
5456                               ;; *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
5457                               ;; *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
5458                               ;; *CALL WHEN OPERATING IN TTY INTERRUPT MODE.
5459 021632 022737 000176 001140   $CKSWR: CMP      $$SWREG,$SWR ;; IS THE SOFT-SWR SELECTED
5460 021640 001124                   BNE      15$           ;; EXIT IF NOT
5461 021642 105777 157276          TSTB     @$TKS         ;; IS A CHAR WAITING?
5462 021646 100121                   BPL      15$           ;; IF NOT, EXIT
5463 021650 117746 157272          MOVB     @$TKB,-(SP)   ;; YES
5464 021654 042716 177600          BIC      #C177,(SP)   ;; MAKE IT 7-BIT ASCII
5465 021660 021627 000007          CMP      (SP),#7      ;; IS IT A CONTROL-G?
5466 021664 001300                   BNE      2$            ;; IF NOT, PUT IT IN THE TTY QUEUE
5467                               ;; AND EXIT
5468
5469                               ;; *****
5470                               ;; *CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
5471                               ;; *ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
5472                               ;; *CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
5473 021666 123727 001134 000001   6$:     CMPB     $AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
5474 021674 001674                   BEQ      2$            ;; BRANCH IF YES
5475 021676 005726                   TST      (SP)+         ;; CLEAR CONTROL-G OFF STACK
5476 021700 004737 021344          JSR      PC,$TKINT    ;; FLUSH THE TTY INPUT QUEUE
5477 021704 005077 157234          CLR      @$TKS         ;; DISABLE TTY KEYBOARD INTERRUPTS
5478 021710 112737 000001 001135   MOVB     #1,$INTAG    ;; SET INTERRUPT MODE INDICATOR
5479
5480 021716 104401 022556          $GTSWR: TYPE     , $CNTLG ;; ECHO THE CONTROL-G ( G)
5481 021722 104401 022563          TYPE     , $MSWR      ;; TYPE CURRENT CONTENTS
5482 021726 013746 000176          MOV      SWREG,-(SP)  ;; SAVE SWREG FOR TYPEOUT
5483 021732 104402                   TYPOC    ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
5484 021734 104401 022574          TYPE     , $MNEW      ;; PROMPT FOR NEW SWR
5485 021740 005046          19$:    CLR      -(SP)    ;; CLEAR COUNTER
5486 021742 005046          CLR      -(SP)        ;; THE NEW SWR
5487 021744 105777 157174          7$:     TSTB     @$TKS   ;; CHAR THERE?
5488 021750 100375                   BPL      7$           ;; IF NOT TRY AGAIN
5489
5490 021752 117746 157170          MOVB     @$TKB,-(SP)  ;; PICK UP CHAR
5491 021756 042716 177600          BIC      #C177,(SP)  ;; MAKE IT 7-BIT ASCII
5492
5493 021762 021627 000003          CMP      (SP),#3     ;; IS IT A CONTROL-C?
5494 021766 001015                   BNE      9$            ;; BRANCH IF NOT
5495 021770 104401 022544          TYPE     , $CNTLC    ;; YES, ECHO CONTROL-C ( C)
5496 021774 062706 000006          ADD      #6,SP        ;; CLEAN UP STACK
5497 022000 123727 001135 000001   CMPB     $INTAG,#1   ;; REENABLE TTY KEYBOARD INTERRUPTS?
5498 022006 001003                   BNE      8$            ;; BRANCH IF NO
5499 022010 012777 000100 157126   MOV      #100,@$TKS  ;; ALLOW TTY KEYBOARD INTERRUPTS

```

```

5500 022016 000137 004660      85    JMP    START2      ;;CONTROL-C RESTART
5501
5502
5503 022022 021627 000025      95    CMP    (SP),#25    ;; IS IT A CONTROL-U?
5504 022026 001005                BNE    105          ;; BRANCH IF NOT
5505 022030 104401 022551                TYPE  ,%CNTLU      ;; YES, ECHO CONTROL-U ( U)
5506 022034 062706 000006      205   ADD    #6,SP        ;; IGNORE PREVIOUS INPUT
5507 022040 000737                BR     195          ;; LET'S TRY IT AGAIN
5508
5509
5510 022042 021627 000015      105   CMP    (SP),#15     ;; IS IT A <CR>?
5511 022046 001022                BNE    165          ;; BRANCH IF NO
5512 022050 005766 000004                TST    4(SP)        ;; YES, IS IT THE FIRST CHAR?
5513 022054 001403                BEQ    115          ;; BRANCH IF YES
5514 022056 016677 000002 157054    MOV    2(SP),@SWR   ;; SAVE NEW SWR
5515 022064 062706 000006      115   ADD    #6,SP        ;; CLEAR UP STACK
5516 022070 104401 001215      145   TYPE  ,%CRLF        ;; ECHO <CR> AND <LF>
5517 022074 123727 001135 000001    CMPB  $INTAG,#1    ;; RE-ENABLE TTY KBD INTERRUPTS?
5518 022102 001003                BNE    155          ;; BRANCH IF NOT
5519 022104 012777 000100 157032    MOV    #100,@STKS  ;; RE-ENABLE TTY KBD INTERRUPTS
5520 022112 000002      155   RTI                    ;; RETURN
5521 022114 004737 020612      165   JSR    PC,$TYPEC    ;; ECHO CHAR
5522 022120 021627 000060                CMP    (SP),#60     ;; CHAR < 0?
5523 022124 002420                BLT    185          ;; BRANCH IF YES
5524 022126 021627 000067                CMP    (SP),#67     ;; CHAR > 7?
5525 022132 003015                BGT    185          ;; BRANCH IF YES
5526 022134 042726 000060                BIC    #60,(SP)+    ;; STRIP-OFF ASCII
5527 022140 005766 000002                TST    2(SP)        ;; IS THIS THE FIRST CHAR
5528 022144 001403                BEQ    175          ;; BRANCH IF YES
5529 022146 006316                ASL    (SP)         ;; NO, SHIFT PRESENT
5530 022150 006316                ASL    (SP)         ;; CHAR OVER TO MAKE
5531 022152 006316                ASL    (SP)         ;; ROOM FOR NEW ONE
5532 022154 005266 000002      175   INC    2(SP)        ;; KEEP COUNT OF CHAR
5533 022160 056616 177776                BIS    -2(SP),(SP)  ;; SET IN NEW CHAR
5534 022164 000667                BR     75           ;; GET THE NEXT ONE
5535 022166 104401 001214      185   TYPE  ,%QUES       ;; TYPE ?<CR><LF>
5536 022172 000720                BR     205          ;; SIMULATE CONTROL-U
5537                DSABL  LSB
5538
5539
5540                ;; *****
5541                ;; *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
5542                ;; *CALL
5543                ;; *      ROCHR      ;; GET A CHARACTER FROM THE QUEUE
5544                ;; *      RETURN HERE  ;; CHARACTER IS ON THE STACK
5545                ;; *                ;; WITH PARITY BIT STRIPPED OFF
5546                ;; *
5547
5548 022174 011646 000004 000002    $POCHR MOV    (SP),-(SP)  ;; PUSH DOWN THE PC AND
5549 022176 016666 000004                MOV    4(SP),2(SP)  ;; THE PS
5550 022204 005066 000004                CLR    4(SP)        ;; GET READY FOR A CHARACTER
5551 022210 005046                CLR    -(SP)        ;; PUT NEW PS ON STACK
5552 022212 012746 022220                MOV    #64$,-(SP)  ;; PUT NEW PC ON STACK
5553 022216 000002                RTI                    ;; POP NEW PC AND PS
5554 022220      64$
5555 022220 005737 021334      15    TST    $TKCNT      ;; WAIT ON A CHARACTER

```

```

5556 022224 001775          BEQ      1$
5557 022226 005337 021334    DEC      $TKCNT          ;; DECREMENT THE COUNTER
5558 022232 117766 177102 000004    MOVB    $TKQOUT,4(SP)  ;; GET ONE CHARACTER
5559 022240 005237 021340          INC      $TKQOUT        ;; UPDATE THE POINTER
5560 022244 023727 021340 021344    CMP     $TKQOUT,$TKQEND ;; DID IT GO OFF OF THE END?
5561 022252 001003          BNE     2$              ;; BRANCH IF NO
5562 022254 012737 021342 021340    MOV     $TKQSRRT,$TKQOUT ;; RESET THE POINTER
5563 022262 000002          2$      RTI              ;; RETURN
5564                                     ;; *****
5565                                     ;; *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
5566                                     ;; *CALL:
5567                                     ;; *      RDLIN              ;; INPUT A STRING FROM THE TTY
5568                                     ;; *      RETURN HERE      ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
5569                                     ;; *                          ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
5570
5571 022264 010346          $RDLIN MOV     R3,-(SP)      ;; SAVE R3
5572 022266 005046          CLR     -(SP)          ;; CLEAR THE RUBOUT KEY
5573 022270 012703 022520    1$     MOV     $TTYIN,R3  ;; GET ADDRESS
5574 022274 022703 022544    2$     CMP     $TTYIN+20,R3 ;; BUFFER FULL?
5575 022300 101456          BLOS   4$              ;; BR IF YES
5576 022302 104410          RDCHR          ;; GO READ ONE CHARACTER FROM THE TTY
5577 022304 112613          MOVB   (SP)+,(R3)     ;; GET CHARACTER
5578 022306 122713 000177    10$    CMPB   #177,(R3)      ;; IS IT A RUBOUT
5579 022312 001022          BNE   5$              ;; BR IF NO
5580 022314 005716          TST   (SP)           ;; IS THIS THE FIRST RUBOUT?
5581 022316 001007          BNE   6$              ;; BR IF NO
5582 022320 112737 000134 022516    MOVB   #' ,9$         ;; TYPE A BACK SLASH
5583 022326 104401 022516          TYPE   ,9$
5584 022332 012716 177777          MOV   #-1,(SP)       ;; SET THE RUBOUT KEY
5585 022336 005303          6$     DEC     R3          ;; BACKUP BY ONE
5586 022340 020327 022520    CMP   R3,$TTYIN      ;; STACK EMPTY?
5587 022344 103434          BLO   4$              ;; BR IF YES
5588 022346 111337 022516    MOVB   (R3),9$       ;; SETUP TO TYPEOUT THE DELETED CHAR
5589 022352 104401 022516          TYPE   ,9$          ;; GO TYPE
5590 022356 000746          BR    2$              ;; GO READ ANOTHER CHAR
5591 022360 005716          5$     TST   (SP)           ;; RUBOUT KEY SET?
5592 022362 001406          BEQ   7$              ;; BR IF NO
5593 022364 112737 000134 022516    MOVB   #' ,9$         ;; TYPE A BACK SLASH
5594 022372 104401 022516          TYPE   ,9$
5595 022376 005016          CLR   (SP)           ;; CLEAR THE RUBOUT KEY
5596 022400 122713 000025    7$     CMPB   #25,(R3)      ;; IS CHARACTER A CTRL U?
5597 022404 001003          BNE   8$              ;; BR IF NO
5598 022406 104401 022551          TYPE   ,%CNTLU      ;; TYPE A CONTROL "U"
5599 022412 000726          BR    1$              ;; GO START OVER
5600 022414 122713 000022    8$     CMPB   #22,(R3)      ;; IS CHARACTER A " R"?
5601 022420 001011          BNE   3$              ;; BRANCH IF NO
5602 022422 105013          CLRB  (R3)           ;; CLEAR THE CHARACTER
5603 022424 104401 001215          TYPE   ,%SCRLF      ;; TYPE A "CR" & "LF"
5604 022430 104401 022520          TYPE   , $TTYIN     ;; TYPE THE INPUT STRING
5605 022434 000717          BR    2$              ;; GO PICKUP ANOTHER CHACTER
5606 022436 104401 001214    4$     TYPE   , $QUES      ;; TYPE A '?'
5607 022442 000712          BR    1$              ;; CLEAR THE BUFFER AND LOOP
5608 022444 111337 022516    3$     MOVB   (R3),9$       ;; ECHO THE CHARACTER
5609 022450 104401 022516          TYPE   ,9$
5610 022454 122723 000015          CMPB   #15,(R3)+     ;; CHECK FOR RETURN
5611 022460 001305          BNE   2$              ;; LOOP IF NOT RETURN
    
```

```

5612 022462 105063 177777          CLR B    -1(R3)          ;; CLEAR RETURN (THE 15)
5613 022466 104401 001216          TYPE    ,SLF           ;; TYPE A LINE FEED
5614 022472 005726                   TST     (SP)+          ;; CLEAN RUBOUT KEY FROM THE STACK
5615 022474 012603                   MOV     (SP)+,R3       ;; RESTORE R3
5616 022476 011646                   MOV     (SP),-(SP)     ;; ADJUST THE STACK AND PUT ADDRESS OF THE
5617 022500 016666 000004 000002    MOV     4(SP),2(SP)    ;; FIRST ASCII CHARACTER ON IT
5618 022506 012766 022520 000004    MOV     #STTYIN,4(SP)
5619 022514 000002                   RTI                    ;; RETURN
5620 022516 000          9$          .BYTE   0              ;; STORAGE FOR ASCII CHAR TO TYPE
5621 022517 000          .BYTE   0              ;; TERMINATOR
5622 022520 000024                   STTYIN: .BLKB 20.     ;; RESERVE 20. BYTES FOR TTY INPUT
5623 022544 041536 005015 000        SCNTLC: .ASCIZ / C/<15><12> ;; CONTROL "C"
5624 022551 136 006525 000012        SCNTLU: .ASCIZ / U/<15><12> ;; CONTROL "U"
5625 022556 043536 005015 000        SCNTLG: .ASCIZ / G/<15><12> ;; CONTROL "G"
5626 022563 015 051412 051127        SMSWR:  .ASCIZ <15><12>/SWR = /
5627 022570 036440 000040
5628 022574 020040 042516 020127        SMNEW:  .ASCIZ / NEW = /
5629 022602 020075 000
5630 022606                   EVEN
5631
5632                   SBTTL  SCOPE HANDLER ROUTINE
5633
5634                   ; *****
5635                   ; *THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
5636                   ; *AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG (DISPLAY<7 0>)
5637                   ; *AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15.08>
5638                   ; *THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE
5639                   ; *SW14=1      LOOP ON TEST
5640                   ; *SW11=1      INHIBIT ITERATIONS
5641                   ; *SW09=1      LOOP ON ERROR
5642                   ; *CALL
5643                   ; *      SCOPE          ; ; SCOPE=10T
5644
5645                   $SCOPE:
5646 022606 104407                   CKSWR          ;; TEST FOR CHANGE IN SOFT-SWR
5647 022610 032777 040000 156322 1$:  BIT     #BIT14,$SWR  ;; LOOP ON PRESENT TEST?
5648 022616 001101                   BNE     $OVER      ;; YES IF SW14=1
5649                   ; *****START OF CODE FOR THE XOR TESTER*****
5650 022620 000416                   $XTSTR  BR     6$    ;; IF RUNNING ON THE "XOR" TESTER CHANGE
5651                   ;; THIS INSTRUCTION TO A "NOP" (NOP=240)
5652 022622 013746 000004                   MOV     @#ERRVEC,-(SP) ;; SAVE THE CONTENTS OF THE ERROR VECTOR
5653 022626 012737 022646 000004    MOV     #5$,@#ERRVEC  ;; SET FOR TIMEOUT
5654 022634 005737 177060                   TST     @#177060     ;; TIME OUT ON XOR?
5655 022640 012637 000004    MOV     (SP)+,@#ERRVEC ;; RESTORE THE ERROR VECTOR
5656 022644 000453                   BR     $$VLAD        ;; GO TO THE NEXT TEST
5657 022646 022626 5$:  CMP     (SP)+,(SP)+   ;; CLEAR THE STACK AFTER A TIME OUT
5658 022650 012637 000004    MOV     (SP)+,@#ERRVEC ;; RESTORE THE ERROR VECTOR
5659 022654 000413                   BR     7$           ;; LOOP ON THE PRESENT TEST
5660 022656 6$:  ; *****END OF CODE FOR THE XOR TESTER*****
5661 022656 105737 001103 2$:  TSTB   $ERFLG      ;; HAS AN ERROR OCCURRED?
5662 022662 001421                   BEQ     3$           ;; BR IF NO
5663 022664 123737 001115 001103    CMPB   $ERMAX,$ERFLG ;; MAX. ERRORS FOR THIS TEST OCCURRED?
5664 022672 101015                   BHI    3$           ;; BR IF NO
5665 022674 032777 001000 156236    BIT    #BIT09,$SWR   ;; LOOP ON ERROR?
5666 022702 001404                   BEQ    4$           ;; BR IF NO
5667 022704 013737 001110 001106 7$:  MOV     $LPERR,$LPADR ;; SET LOOP ADDRESS TO LAST SCOPE
    
```

```

5668 022712 000443          BR      $OVER
5669 022714 105037 001103    4$     CLRB   $ERFLG      ;; ZERO THE ERROR FLAG
5670 022720 005037 001204          CLR    $TIMES      ;; CLEAR THE NUMBER OF ITERATIONS TO MAKE
5671 022724 000415          BR      $          ;; ESCAPE TO THE NEXT TEST
5672 022726 032777 004000 156204 3$     BIT    #BIT11,$SWR  ;; INHIBIT ITERATIONS?
5673 022734 001011          BNE    $          ;; BR IF YES
5674 022736 005737 001100          TST   $PASS       ;; IF FIRST PASS OF PROGRAM
5675 022742 001406          BEQ    $          ;; INHIBIT ITERATIONS
5676 022744 005237 001104          INC   $ICNT       ;; INCREMENT ITERATION COUNT
5677 022750 023737 001204 001104          CMP   $TIMES,$ICNT ;; CHECK THE NUMBER OF ITERATIONS MADE
5678 022756 002021          BGE    $OVER      ;; BR IF MORE ITERATION REQUIRED
5679 022760 012737 000001 001104 1$     MOV   #1,$ICNT     ;; REINITIALIZE THE ITERATION COUNTER
5680 022766 013737 023036 001204          MOV   $SMXCNT,$TIMES ;; SET NUMBER OF ITERATIONS TO DO
5681 022774 105237 001102    $SVLAD INCB  $TSTNM   ;; COUNT TEST NUMBERS
5682 023000 011637 001106          MOV   (SP),$LPADR  ;; SAVE SCOPE LOOP ADDRESS
5683 023004 011637 001110          MOV   (SP),$LPERR  ;; SAVE ERROR LOOP ADDRESS
5684 023010 005037 001206          CLR   $ESCAPE     ;; CLEAR THE ESCAPE FROM ERROR ADDRESS
5685 023014 112737 000001 001115          MOVB #1,$ERMAX    ;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
5686 023022 013777 001102 156112 $OVER  MOV   $TSTNM,$DISPLAY ;; DISPLAY TEST NUMBER
5687 023030 013716 001106          MOV   $LPADR,(SP)  ;; FUDGE RETURN ADDRESS
5688 023034 000002          RTI              ;; FIXES PS
5689 023036 000001    $SMXCNT 1          ;; MAX. NUMBER OF ITERATIONS
5690
5691          SBTTL  SAVE AND RESTORE R0-R5 ROUTINES
5692
5693          , , *****
5694          , *SAVE R0-R5
5695          , *CALL
5696          , * SAVREG
5697          , *UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
5698          , *
5699          , *TOP---(+16)
5700          , * +2---(+18)
5701          , * +4---R5
5702          , * +6---R4
5703          , * +8---R3
5704          , * +10---R2
5705          , * +12---R1
5706          , * +14---R0
5707
5708          $SAVREG:
5709 023040 010046          MOV   R0,-(SP)     ;; PUSH R0 ON STACK
5710 023042 010146          MOV   R1,-(SP)     ;; PUSH R1 ON STACK
5711 023044 010246          MOV   R2,-(SP)     ;; PUSH R2 ON STACK
5712 023046 010346          MOV   R3,-(SP)     ;; PUSH R3 ON STACK
5713 023050 010446          MOV   R4,-(SP)     ;; PUSH R4 ON STACK
5714 023052 010546          MOV   R5,-(SP)     ;; PUSH R5 ON STACK
5715 023054 016646 000022          MOV   22(SP),-(SP) ;; SAVE PS OF MAIN FLOW
5716 023060 016646 000022          MOV   22(SP),-(SP) ;; SAVE PC OF MAIN FLOW
5717 023064 016646 000022          MOV   22(SP),-(SP) ;; SAVE PS OF CALL
5718 023070 016646 000022          MOV   22(SP),-(SP) ;; SAVE PC OF CALL
5719 023074 000002          RTI
5720
5721          , *RESTORE R0-R5
5722          , *CALL
5723          , * RESREG

```

```

5724 023076          $RESREG
5725 023076 012666 000022      MOV      (SP)+, 22(SP)      ;; RESTORE PC OF CALL
5726 023102 012666 000022      MOV      (SP)+, 22(SP)      ;; RESTORE PS OF CALL
5727 023106 012666 000022      MOV      (SP)+, 22(SP)      ;; RESTORE PC OF MAIN FLOW
5728 023112 012666 000022      MOV      (SP)+, 22(SP)      ;; RESTORE PS OF MAIN FLOW
5729 023116 012605          MOV      (SP)+, R5         ;; POP STACK INTO R5
5730 023120 012604          MOV      (SP)+, R4         ;; POP STACK INTO R4
5731 023122 012603          MOV      (SP)+, R3         ;; POP STACK INTO R3
5732 023124 012602          MOV      (SP)+, R2         ;; POP STACK INTO R2
5733 023126 012601          MOV      (SP)+, R1         ;; POP STACK INTO R1
5734 023130 012600          MOV      (SP)+, R0         ;; POP STACK INTO R0
5735 023132 000002          RTI
    
```

SBTTL TRAP DECODER

```

, , *****
, *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
, *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
, *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
, *GO TO THAT ROUTINE.
    
```

```

5745 023134 010046          STRAP  MOV      RO, -(SP)      ;; SAVE RO
5746 023136 016600 000002      MOV      2(SP), RO         ;; GET TRAP ADDRESS
5747 023142 005740          TST      -(RO)            ;; BACKUP BY 2
5748 023144 111000          MOV      (RO), RO         ;; GET RIGHT BYTE OF TRAP
5749 023146 006300          ASL      RO              ;; POSITION FOR INDEXING
5750 023150 016000 023170      MOV      $TRPAD(RO), RO    ;; INDEX TO TABLE
5751 023154 000200          RTS      RO              ;; GO TO ROUTINE
    
```

;; THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

5756 023156 011646          STRAP2 MOV      (SP), -(SP)    ;; MOVE THE PC DOWN
5757 023160 016666 000004 000002  MOV      4(SP), 2(SP)      ;; MOVE THE PSW DOWN
5758 023166 000002          RTI                      ;; RESTORE THE PSW
    
```

SBTTL TRAP TABLE

```

, *THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
, *BY THE "TRAP" INSTRUCTION
    
```

```

,          ROUTINE
,          -----
5767 023170 023156          $TRPAD  . WORD  $TRAP2
5768 023172 020442          $TYPE   ;; CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
5769 023174 020706          $TYPOC  ;; CALL=TYPOC     TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
5770 023176 020662          $TYPOS  ;; CALL=TYPOS     TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
5771 023200 020722          $TYPON  ;; CALL=TYPON     TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
5772 023202 021110          $TYPDS  ;; CALL=TYPDS     TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
5773
5774 023204 021722          $GTSWR  ;; CALL=GTSWR      TRAP+6(104406)  GET SOFT-SWR SETTING
5775
5776 023206 021632          $CKSWR  ;; CALL=CKSWR      TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
5777 023210 022174          $RDCHR  ;; CALL=RDCHR     TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
5778 023212 022264          $RDLIN  ;; CALL=RDLIN     TRAP+11(104411) TTY TYPEIN STRING ROUTINE
5779 023214 023040          $SAVREG ;; CALL=SAVREG          TRAP+12(104412) SAVE RO-R5 ROUTINE
    
```

```

5780 023216 023076          $RESREG ,,CALL=RESREG TRAP+13(104413) RESTORE R0-R5 ROUTINE
5781
5782          SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCIZ ROUTINE
5783
5784          ;,*****
5785          ;*THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
5786          ;*UNSIGNED DECIMAL ASCIZ NUMBER.
5787          ;*CALL
5788          ;*      MOV      NUMBER, -(SP)      ;;PUT BINARY NUMBER ON THE STACK
5789          ;*      JSR      PC,@#$SB2D        ;;CALL
5790          ;*      RETURN                      ;;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
5791
5792
5793 023220 016637 000002 023250 $SB2D MOV      2(SP), 1$      ;;SAVE BINARY NUMBER
5794 023226 012746 023250          MOV      #1$, -(SP)      ;;SET POINTER
5795 023232 004737 023254          JSR      PC,@#$DB2D        ;;CALL DOUBLE LENGTH CONVERT
5796 023236 062716 000005          ADD      #5, (SP)        ;;ONLY ALLOW FIVE CHARACTERS
5797 023242 012666 000002          MOV      (SP)+, 2(SP)    ;;PICKUP POINTER
5798 023246 000207          RTS      PC            ;;RETURN
5799 023250 000000 000000          1$      WORD      0, 0
5800
5801          SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
5802
5803          ;,*****
5804          ;*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
5805          ;*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
5806          ;*POSITIVE.
5807          ;*CALL
5808          ;*      MOV      #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
5809          ;*      JSR      PC,@#$DB2D        ;;
5810          ;*      RETURN                      ;; THE FIRST ADDRESS OF ASCIZ
5811          ;*                                  ;; IS ON THE STACK
5812
5813
5814 023254 104412          $DB2D SAVREG          ;;SAVE REGISTERS
5815 023256 016602 000002          MOV      2(SP), R2      ;;PICKUP THE DATA POINTER
5816 023262 012700 023434          MOV      #$DECVL, R0   ;;GET ADDRESS OF "$DECVL" STRING
5817 023266 010066 000002          MOV      R0, 2(SP)     ;;PUT ADDRESS OF ASCIZ STRING ON STACK
5818 023272 012201          MOV      (R2)+, R1     ;;PICKUP THE BINARY NUMBER
5819 023274 012202          MOV      (R2)+, R2
5820 023276 012737 000012 023352          MOV      #10, 4$      ;;SET UP TO DO 10 CONVERSIONS
5821 023304 012704 023364          MOV      #$TNPWR, R4   ;;ADDRESS OF TEN POWER
5822 023310 012705 023366          MOV      #$TNPWR+2, R5
5823 023314 005003          1$      CLR      R3            ;;CLEAR PARTIAL
5824 023316 161401          2$      SUB      (R4), R1      ;;SUBTRACT TEN POWER
5825 023320 005602          SBC      R2
5826 023322 161502          SUB      (R5), R2
5827 023324 002402          BLT      3$            ;;BR IF TEN POWER TO LARGE
5828 023326 005203          INC      R3            ;;ADD 1 TO PARTIAL
5829 023330 000772          BR      2$            ;;LOOP
5830 023332 062401          3$      ADD      (R4)+, R1     ;;RESTORE SUBTRACTED VALUE
5831 023334 005502          ADC      R2
5832 023336 062402          ADD      (R4)+, R2
5833 023340 022525          CMP      (R5)+, (R5)+  ;;MOVE TO NEXT TEN POWER
5834 023342 052703 000060          BIS      #'0, R3      ;;CHANGE PARTIAL TO ASCII
5835 023346 110320          MOVB     R3, (R0)+     ;;SAVE IT
    
```

```

5836 023350 005327          DEC      (PC)+      ;; DONE?
5837 023352 000000          4$      WORD      0
5838 023354 001357          BNE      1$              ;; BR IF NO
5839 023356 105020          CLRB     (RO)+          ;; TERMINATOR
5840 023360 104413          RESREG
5841 023362 000207          RTS      PC              ;; RESTORE REGISTERS
5842 023364 145000          STNPRW 145000          ;; RETURN
5843 023366 035632          35632
5844 023370 160400          160400          ;; 1 OE08
5845 023372 002765          2765
5846 023374 113200          113200          ;; 1 OE07
5847 023376 000230          230
5848 023400 041100          041100          ;; 1 OE06
5849 023402 000017          17
5850 023404 103240          103240          ;; 1 OE05
5851 023406 000001          1
5852 023410 023420          23420          ;; 1 OE04
5853 023412 000000          0
5854 023414 001750          1750           ;; 1 OE03
5855 023416 000000          0
5856 023420 000144          144           ;; 1 OE02
5857 023422 000000          0
5858 023424 000012          12           ;; 1 OE01
5859 023426 000000          0
5860 023430 000001          1           ;; 1 OE00
5861 023432 000000          0
5862 023434 000014          $DECVL  BLKB  12      ;; RESERVE STORAGE FOR ASCIZ STRING
5863
5864          SBTTL  TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS
5865
5866          ;; *****
5867          ;*THIS ROUTINE IS USED TO TYPE AN ASCIZ NUMBER SUPPRESSING THE
5868          ;*LEADING NUMBERS
5869          ;*CALL
5870          ;*      MOV      #NUMADR, -(SP)  ;; FIRST ADDRESS OF ASCIZ STRING
5871          ;*      JSR      PC, @#$SUPRS
5872
5873          $$SUPRS  MOV      RO, -(SP)      ;; SAVE RO
5874 023450 010046          MOV      4(SP), RO      ;; PICKUP THE POINTER
5875 023452 016600 000004          TSTB     (RO)          ;; TERMINATOR?
5876 023456 105710          BEQ      2$              ;; BR IF YES
5877 023460 001403          CMPB     #'0, (RO)+     ;; IS THIS AN ASCII "0" ?
5878 023462 122720 000060          BEQ      1$              ;; BR IF YES
5879 023466 001773          DEC      RO              ;; BACKUP BY "1"
5880 023470 005300          MOV      RO, 3$         ;; SAVE FOR TYPING
5881 023472 010037 023500          TYPE
5882 023476 104401          WORD     0              ;; GO TYPE
5883 023500 000000          MOV      (SP)+, RO      ;; ASCIZ POINTER GOES HERE
5884 023502 012600          MOV      (SP)+, (SP)    ;; RESTORE RO
5885 023504 012616          RTS      PC              ;; RESTORE THE STACK
5886 023506 000207          ;; RETURN
5887
5888          SBTTL  RANDOM NUMBER GENERATOR ROUTINE
5889
5890          ;; *****
5891          ;*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
    
```

```

5892 , *WITH A RANGE OF 0 TO 2(+33)-1
5893 , *CALL
5894 , * JSR PC, $RAND , *CALL THE ROUTINE
5895 , * RETURN , *RETURN HERE THE RPNDOM
5896 , * , *NUMBER WILL BE IN
5897 , * , * $HINUM, $LONUM
5898
5899 $RAND
5900 023510 010046 MOV RO, -(SP) , *PUSH RO ON STACK
5901 023512 010146 MOV R1, -(SP) , *PUSH R1 ON STACK
5902 023514 010246 MOV R2, -(SP) , *PUSH R2 ON STACK
5903 023516 013700 023610 MOV $LONUM, RO , *SET RO WITH LOW
5904 023522 013701 023606 MOV $HINUM, R1 , *SET R1 WITH HIGH
5905 023526 012702 177771 MOV #-7, R2 , *SET SHIFT COUNT
5906 023532 006300 1$ ASL RO , *SHIFT RO LEFT AND
5907 023534 006101 ROL R1 , *ROTATE CARRY INTO R1 AND
5908 023536 005202 INC R2 , *CHECK FOR DONE
5909 023540 001374 BNE 1$ , *CONTINUE SHIFT LOOP
5910 023542 063700 023610 ADD $LONUM, RO , *ADD NUMBER TO MAKE X 129
5911 023546 005501 ADC R1 , *PROPOGATE CARRY
5912 023550 063701 023606 ADD $HINUM, R1 , *ADD NUMBER TO MAKE X 129
5913 023554 062700 001057 ADD #1057, RO , *ADD LOW CONSTANT
5914 023560 005501 ADC R1 , *PROPOGATE CARRY
5915 023562 062701 047401 ADD #47401, R1 , *ADD HIGH CONSTANT
5916 023566 010037 023610 MOV RO, $LONUM , *SAVE RO
5917 023572 010137 023606 MOV R1, $HINUM , *SAVE R1
5918 023576 012602 MOV (SP)+, R2 , *POP STACK INTO R2
5919 023600 012601 MOV (SP)+, R1 , *POP STACK INTO R1
5920 023602 012600 MOV (SP)+, RO , *POP STACK INTO RO
5921 023604 000207 RTS PC , *RETURN
5922 023606 176543 $HINUM . WORD 176543
5923 023610 123456 $LONUM . WORD 123456
    
```

SBTTL INTEGER DIVIDE ROUTINE

```

5924
5925
5926
5927 , *****
5928 , *THIS ROUTINE WILL DIVIDE A 32-BIT TWO'S COMPLEMENT INTEGER
5929 , *DIVIDEND BY A 16-BIT TWO'S COMPLEMENT INTEGER DIVISOR GIVING
5930 , *A 16-BIT TWO'S COMPLEMENT INTEGER QUOTIENT AND A 16-BIT REMAINDER
5931 , *DIVISION WILL BE PERFORMED SO THAT THE REMAINDER IS OF THE
5932 , *SAVE SIGN AS THE DIVIDEND.
5933 , *CALL:
5934 , * MOV LOW DIVIDEND, -(SP) , *THE HIGH DIVIDEND MUST BE < 1/2
5935 , * MOV HIGH DIVIDEND, -(SP). AS LARGE AS THE DIVISOR
5936 , * MOV DIVISOR, -(SP)
5937 , * JSR PC, $DIV
5938 , * RETURN , *QUOTIENT & REMAINDER ARE ON THE STACK
5939 , * "V"=0 IMPLIES NO ERROR
5940 , * "V"=1 IMPLIES ERROR OCCURRED
5941 , * "C"=0 DIVIDE OVERFLOW OCCURRED
5942 , * "C"=1 ATTEMPTED TO DIVIDE BY ZERO
5943
5944
5945 , * STACK NO ERROR OVERFLOW DIVIDE BY ZERO
5946 , * ---- - - - - -
5947 , * TOP REMAINDER ALL ZEROS ALL ONES
    
```

5948									
5949									
5950	023612								
5951	023612	104400							
5952	023614	042716	000017						
5953	023620	010046							
5954	023622	010146							
5955	023624	010246							
5956	023626	010346							
5957	023630	005046							
5958	023632	012746	000021						
5959	023636	016601	000024						
5960	023642	016600	000022						
5961	023646	100005							
5962	023650	105366	000003						
5963	023654	005400							
5964	023656	005401							
5965	023660	005600							
5966	023662	016602	000020	1%					
5967	023666	002407							
5968	023670	003011							
5969	023672	052766	000003	000014					
5970	023700	012700	177777						
5971	023704	000424							
5972	023706	005266	000002	2%					
5973	023712	000401							
5974	023714	005402		3%					
5975	023716	000241		4%					
5976	023720	000405							
5977	023722	006100		5%					
5978	023724	010003							
5979	023726	060203							
5980	023730	103001							
5981	023732	010300							
5982	023734	006101		6%					
5983	023736	005316							
5984	023740	001370							
5985	023742	005701							
5986	023744	100005							
5987	023746	052766	000002	000014					
5988	023754	005000							
5989	023756	010001		7%					
5990	023760	005726		8%					
5991	023762	005716							
5992	023764	002004							
5993	023766	005400							
5994	023770	105066	000001						
5995	023774	005316							
5996	023776	005726		9%					
5997	024000	001401							
5998	024002	005401							
5999	024004	010166	000020	10%					
6000	024010	010066	000016						
6001	024014	012603							
6002	024016	012602							
6003	024020	012601							

```

6004 024022 012600          MOV      (SP)+,RO      ;,POP STACK INTO RO
6005 024024 012666 000002  MOV      (SP)+,2(SP)   ;,SETUP TO RETURN CONDITION CODES
6006 024030 000002          RTI                          ;,RETURN
6007
6008          SBTTL    *** PROGRAM SUBROUTINES ***
6009
6010          ;SET "LPTAVL" TO THE PROPER STATE.
6011          ; LPTAVL = 0 IF NO LINE PRINTER AVAILABLE
6012          ; LPTAVL = 1 IF LINE PRINTER IS AVAILABLE
6013          ;CALL
6014          ;      JSR      PC,@#LP.AVL
6015          ;      RETURN
6016
6017 024032 005037 001230  LP AVL  CLR      @#LPTAVL      ;,START WITH NO PRINTER AVAIABLE
6018 024036 012737 024062 000004  MOV      #1$,@#ERRVEC  ;,SETUP THE TIMEOUT VECTOR
6019 024044 005037 000006          CLR      @#ERRVEC+2
6020 024050 005777 155344          TST      @LPS          ;,IS THERE A LINE PRINTER?
6021 024054 005237 001230          INC      @#LPTAVL     ;,YES--SET AVAILABLE SWITCH
6022 024060 000401          BR      2$
6023 024062 022626          1$  CMP      (SP)+,(SP)+  ;,NO--POP STACK
6024 024064 012737 000006 000004  2$  MOV      #ERRVEC+2,@#ERRVEC ;,RESTORE TIMEOUT VECTOR
6025 024072 000207          RTS      PC          ;,RETURN
6026
6027          ;,THIS ROUTINE WILL DETERMINE IF THERE IS A CLOCK ON THE SYSTEM
6028          ;,AND IF THERE IS IT WILL SETUP THE VECTOR AND START THE CLOCK
6029          ;,"CLKSTA" WILL INDICATE THE CLOCK TYPE
6030          ;, 0= NO CLOCK
6031          ;,+1= KW11-P
6032          ;,-1= KW11-L
6033          ;,THIS ROUTINE WILL ALSO SETUP "TICKMS" (TIME
6034          ;,PER CLOCK TICK IN MILLISECONDS) AND "TICKUS"
6035          ;,(TIME PER CLOCK TICK IN MICROSECONDS) AS
6036          ;,PER SWOO.
6037          ;,SWOO=0 -- 60HZ
6038          ;,SWOO=1 -- 50HZ
6039          ;CALL
6040          ;      JSR      PC,@#ST CLK
6041          ;      RETURN
6042
6043 024074 010146          ST CLK  MOV      R1,-(SP)      ;,SAVE R1
6044 024076 012701 000006  MOV      #ERRVEC+2,R1  ;,SAVE AND SETUP TIMEOUT VECTOR
6045 024102 011146          MOV      (R1),-(SP)
6046 024104 005011          CLR      (R1)          ;,LEVEL 0
6047 024106 014146          MOV      -(R1),-(SP)
6048 024110 012711 024140  MOV      #1$,(R1)      ;,GO TO 1$ ON TIMEOUT
6049 024114 005037 001244  CLR      CLKSTA        ;,SET CLOCK STATUS TO NO CLOCK
6050 024120 005777 155254  TST      @PKCS         ;,IS THERE A KW11-P?
6051 024124 012737 000001 001244  MOV      #1,CLKSTA     ;,YES--SET STATUS TO KW11-P
6052 024132 004737 024242  JSR      PC,ST.PCLK    ;,START THE KW11-P
6053 024136 000414          BR      3$            ;,GO TO EXIT
6054 024140 022626          1$  CMP      (SP)+,(SP)+  ;,CLEAN UP THE STACK
6055 024142 012711 024166  MOV      #2$,(R1)      ;,IF TIMEOUT GO TO 2$
6056 024146 005777 155240  TST      @LKS          ;,IS THERE A KW11-L?
6057 024152 012737 177777 001244  MOV      #-1,CLKSTA    ;,YES-- SET STATUS TO KW11-L
6058 024160 004737 024304  JSR      PC,ST.LCLK    ;,START THE KW11-L
6059 024164 000401          BR      3$            ;,EXIT
    
```

```

6060 024166 022626      2$    CMP    (SP)+, (SP)+    ; CLEAN UP THE STACK
6061 024170 012621      3$    MOV    (SP)+, (R1)+    ; RESTORE THE TIMEOUT VECTOR
6062 024172 012621      MOV    (SP)+, (R1)+
6063 024174 012601      MOV    (SP)+, R1      ; RESTORE R1
6064 024176 032737 000100 001220  BIT    #SW06, @#C SWR  ; 50HZ OR 60HZ?
6065 024204 001407      BEQ    4$              ; BRANCH IF 60
6066 024206 012737 000020 001246  MOV    #20, @#TICKMS  ; SETUP TIME PER
6067 024214 012737 047040 001250  MOV    #20000, @#TICKUS ; TICK FOR 50HZ
6068 024222 000406      BR     5$
6069 024224 012737 000016 001246  4$    MOV    #16, @#TICKMS  ; SETUP TIME PER
6070 024232 012737 040432 001250  MOV    #16666, @#TICKUS ; TICK FOR 60HZ
6071 024240 000207      5$    RTS    PC            ; RETURN
6072
6073 024242      ST PCLK
6074 024242 032737 000040 001220  BIT    #SW05, @#C SWR  ; ALLOW SOFTWARE TIMEOUTS?
6075 024250 001014      BNE    1$              ; NO--BRANCH
6076 024252 012777 024340 155114  MOV    #SRVCLK, @PKV   ; SETUP THE KW11-P VECTOR
6077 024260 012777 000300 155110  MOV    #300, @PKV+2
6078 024266 012777 000001 155106  MOV    #1, @PKB        ; COUNT ONE TICK
6079 024274 012777 000115 155076  MOV    #115, @PKCS     ; "INT EN.", "COUNT DOWN", "MODE 1 (REPEAT)",
6080                                     ; "LINE FREQ", AND "RUN"
6081 024302 000207      1$    RTS    PC            ; RETURN
6082
6083 024304      ST LCLK
6084 024304 032737 000040 001220  BIT    #SW05, @#C SWR  ; ALLOW SOFTWARE TIMEOUTS?
6085 024312 001011      BNE    1$              ; NO--BRANCH
6086 024314 012777 024340 155064  MOV    #SRVCLK, @LKV   ; SETUP THE KW11-L VECTOR
6087 024322 012777 000300 155060  MOV    #300, @LKV+2
6088 024330 012777 000100 155054  MOV    #100, @LKS      ; START THE KW11-L
6089 024336 000207      1$    RTS    PC            ; RETURN
6090
6091 024340 013746 001246  SRVCLK. MOV    @#TICKMS, -(SP) ; TIME PER TICK IN MILLISECONDS
6092 024344 004737 040734  JSR    PC, @#RPTMR    ; COUNT THE ELAPSED TIME
6093 024350 000002      RTI                   ; RETURN AFTER INTERRUPT
6094
6095                                     ; THIS ROUTINE SETS UP DEFAULT PARAMETER VALUES WHEN THE PROGRAM IS
6096                                     ; STARTED OR WHEN THE VALUE OF BIT00 IN 'C SWR' IS CHANGED
6097                                     ; CALL
6098                                     ; JSR PC, LODFLT
6099                                     ; RETURN
6100
6101 LODFLT:
6102 024352 010046      MOV    R0, -(SP)      ; ; PUSH R0 ON STACK
6103 024354 010146      MOV    R1, -(SP)      ; ; PUSH R1 ON STACK
6104 024356 010246      MOV    R2, -(SP)      ; ; PUSH R2 ON STACK
6105 024360 010346      MOV    R3, -(SP)      ; ; PUSH R3 ON STACK
6106 024362 012737 176777 001234  MOV    #176777, TSTNMS ; SELECT TESTS 0-10, 12-17
6107 024370 012737 000001 001236  MOV    #1, TSTNMS+2    ; SET SELECT BIT FOR TEST 20
6108 024376 012700 001664      MOV    #DFLT, R0      ; DEFAULT PARAMETERS POINTER
6109 024402 012701 002330      MOV    #PRMO, R1      ; TABLE POINTER
6110 024406 010102      MOV    R1, R2          ; STOP ADDRESS
6111 024410 012021      1$    MOV    (R0)+, (R1)+    ; MOVE DEFAULT PARAMETERS INTO
6112 024412 020002      CMP    R0, R2          ; RUN TIME TABLES ** DONE?
6113 024414 103775      BLO    1$              ; NO--BRANCH
6114 024416 012700 003504      MOV    #PAT8, R0      ; PAT0 DEFAULTS TO PATTERN 8
6115 024422 012701 003104      MOV    #PATO, R1

```

```

6116 024426 012021          25    MOV    (R0)+, (R1)+
6117 024430 020027 003544    CMP    RO, #PAT9
6118 024434 103774          BLO   25
6119 024436 032737 000001 001220 BIT    #BIT00, C. SWR ; 16 BIT MODE ?
6120 024444 001012          BNE   35 ; BR IF 18
6121 024446 012737 000025 001630 MOV    #21., PRMLMT+22 ; SET 'FS' LIMIT TO 21.
6122 024454 012737 000025 001632 MOV    #21., PRMLMT+24 ; SET 'LS' LIMIT TO 21
6123 024462 012737 165000 001352 MOV    #-<256. *22. >, TRCKWC ; WORD COUNT FOR A 16 BIT TRACK
6124 024470 000411          BR    45 ; CONTINUE
6125 024472 012737 000023 001630 35    MOV    #19., PRMLMT+22 ; SET 'FS' LIMIT TO 19.
6126 024500 012737 000023 001632 MOV    #19., PRMLMT+24 ; SET 'LS' LIMIT TO 19
6127 024506 012737 166000 001352 MOV    #-<256 *20. >, TRCKWC ; WORD COUNT FOR COUNT FOR AN 18 BIT TRACK
6128 024514 012701 001536          45    MOV    #PRMPT, R1 ; ADDRESS OF PARAMETER POINTER TABLE
6129 024520 005711          55    TST    (R1) ; END OF THE TABLE ?
6130 024522 001425          BEQ   85 ; BR IF END
6131 024524 032731 002000          BIT    #BIT10, @ (R1)+ ; 'LS' SELECTED ?
6132 024530 001773          BEQ   55 ; BR IF NOT
6133 024532 016102 177776          MOV    -2(R1), R2 ; PARAMETER TABLE ADDRESS
6134 024536 011246          MOV    (R2), -(SP) ; PARAMETER ALLOCATION BITS
6135 024540 012703 000013          MOV    #11, R3 ; NUMBER OF PARAMETERS (MAXIMUM) BEFORE 'LS'
6136 024544 006216          65    ASR    (SP) ; COUNT THE PARAMETER
6137 024546 103002          BCC   75 ; BR IF NOT USED
6138 024550 062702 000002          ADD    #2, R2 ; INCREMENT THE PARAMETER TABLE ADDRESS
6139 024554 005303          75    DEC    R3 ; COUNT THE PARAMETER
6140 024556 001372          BNE   65 ; BR IF NOT THERE YET
6141 024560 005726          TST    (SP)+ ; CORRECT THE STACK POINTER
6142 024562 021237 001630          CMP    (R2), PRMLMT+22 ; IS 'LS' TOO LARGE FOR THE MODE SELECTED ?
6143 024566 101754          BLOS  55 ; BR IF NOT
6144 024570 013712 001630          MOV    PRMLMT+22, (R2) ; RESET VALUE FOR MODE USED
6145 024574 000751          BR    55 ; CONTINUE
6146 024576          85
6147 024576 012603          MOV    (SP)+, R3 ; POP STACK INTO R3
6148 024600 012602          MOV    (SP)+, R2 ; POP STACK INTO R2
6149 024602 012601          MOV    (SP)+, R1 ; POP STACK INTO R1
6150 024604 012600          MOV    (SP)+, R0 ; POP STACK INTO R0
6151 024606 000207          RTS   PC ; RETURN
6152
6153          ; THIS ROUTINE FILLS THE PARAMETER TABLE THE CURRENT TEST
6154          ; CALL
6155          ; MOV    #TESTNUM, $STNM ; LOAD THE TEST NUMBER
6156          ; JSR    PC, LODPRM
6157          ; RETURN
6158
6159          LODPRM
6160 024610          MOV    R1, -(SP) ; PUSH R1 ON STACK
6161 024612 010246          MOV    R2, -(SP) ; PUSH R2 ON STACK
6162 024614 010346          MOV    R3, -(SP) ; PUSH R3 ON STACK
6163 024616 010446          MOV    R4, -(SP) ; PUSH R4 ON STACK
6164 024620 005004          CLR    R4 ; CLEAR P4
6165 024622 113704 001102          MOVB  $STNM, R4 ; GET THE TEST NUMBER
6166 024626 006304          ASL   R4 ; SETUP TO ADDRESS WORDS
6167 024630 016401 001536          MOV    PRMPT(R4), R1 ; GET THE TEST'S PARAMETER TABLE ADDRESS
6168 024634 012702 001504          MOV    #PRM, R2 ; PARAMETER EXECUTION TABLE
6169 024640 005003          CLR    R3 ; R3 IS USED AS A COUNTER
6170 024642 013704 001254          MOV    CHKDRV, R4 ; DRIVE'S ADDRESS
6171 024646 012122          MOV    (R1)+, (R2)+ ; PARAMETER SPECIFIER

```

```

6172 024650 006237 001504 1S: ASR PRM ; THIS PARAMETER USED IN THE TEST ?
6173 024654 103002 BCC 2S ; BR IF NOT
6174 024656 012122 MOV (R1)+, (R2)+ ; LOAD THE VALUE
6175 024660 000401 BR 3S ; CONTINUE
6176 024662 005022 2S CLR (R2)+ ; CLEAR THE UNUSED PARAMETER LOCATION
6177 024664 005203 3S INC R3 ; COUNT THE POSITION IN THE OUTPUT TABLE
6178 024666 020327 000014 CMP R3, #12 ; FINISHED ?
6179 024672 001430 BEQ 6S ; BR IF YES
6180 024674 020327 000003 CMP R3, #3 ; DOING THE CYLINDER ADDRESSES ?
6181 024700 001363 BNE 1S ; BR IF NOT
6182 024702 132764 000004 034376 BITB #BIT02, DRV TYP (R4) ; RPO6 ?
6183 024710 001016 BNE 5S ; BR IF IT IS
6184 024712 062703 000002 ADD #2, R3 ; COUNT THE BYPASSED PARAMETERS (FC' & LC')
6185 024716 006237 001504 ASR PRM ; SHIFT THE COUNTER
6186 024722 103002 BCC 4S ; BR IF FC' IS NOT USED
6187 024724 062701 000002 ADD #2, R1 ; MOVE THE INPUT POINTER
6188 024730 006237 001504 4S ASR PRM ; COUNT THE PARAMETER
6189 024734 103345 BCC 1S ; BR IF LC' NOT USED
6190 024736 062701 000002 ADD #2, R1 ; MOVE THE INPUT PINTER
6191 024742 000742 BR 1S ; KEEP GOING
6192 024744 000741 BR 1S ; KEEP GOING
6193 024746 162702 000004 5S SUB #4, R2 ; BACKUP THE OUTPUT POINTER
6194 024752 000736 BR 1S ; KEEP GOING
6195 024754 6S
6196 024754 012604 MOV (SP)+, R4 ; POP STACK INTO R4
6197 024756 012603 MOV (SP)+, R3 ; POP STACK INTO R3
6198 024760 012602 MOV (SP)+, R2 ; POP STACK INTO R2
6199 024762 012601 MOV (SP)+, R1 ; POP STACK INTO R1
6200 024764 000207 RTS PC ; RETURN
6201
6202 ; THIS ROUTINE LOADS A READ HEADER AND DATA COMMAND OR A SEEK COMMAND
6203 ; INTO DPB. B+2 AND DPB C+2, DEPENDING ON THE STATE OF "CONTROL SWITCH"
6204 ; BIT07.
6205 ; CALL
6206 ; JSR PC, @#LDCMD
6207 ; RETURN
6208
6209 024766 032737 000200 001220 LDCMD BIT #SW07, @#C. SWR ; DO EXPLICIT SEEKS?
6210 024774 001007 BNE 1S ; YES--BRANCH
6211 024776 012737 000173 004126 MOV #READHD, @#DPB B+2 ; NO--SET UP FOR READ HEADER AND
6212 025004 012737 000173 004146 MOV #READHD, @#DPB. C+2 ; DATA COMMAND
6213 025012 000406 BR 2S
6214 025014 012737 000105 004126 1S MOV #SEEK, @#DPB. B+2 ; SETUP FOR SEEK COMMAND
6215 025022 012737 000105 004146 MOV #SEEK, @#DPB. C+2
6216 025030 000207 2S RTS PC
6217
6218 ; THIS ROUTINE WILL CALL THE RPO4/5/6 DRIVER AND THEN WAIT ON THE FUNCTION
6219 ; TO COMPLETE IF AN ERROR OCCURS IT IS REPORTED
6220 ; CALL
6221 ; FILL "DPB" WITH COMMAND INFORMATION
6222 ; JSR RO, @#CALL A
6223 ; RETURN
6224
6225 025032 005037 001206 CALL A CLR @#$ESCAPE ; NO ESCAPE ADDRESS
6226 025036 004037 035302 JSR RO, @#RPO4 ; CALL RPO4 DRIVER
6227 025042 004104 OPB A

```

```

6228 025044 000772          BR      CALL A
6229 025046 005737 004122 15      TST     @DPB, A+16      ; DONE?
6230 025052 001775          BEQ     15              ; NO--LOOP
6231 025054 100032          BPL     35              ; BRANCH IF NO ERROR
6232 025056 012737 025132 001206 MOV     #2$, $ESCAPE    ; ESCAPE TO 2$ ON ERROR
6233 025064 013737 004116 001270 MOV     @DPB, A+12, @CYL DS ; CYLINDER
6234 025072 113737 004115 001274 MOV     @DPB, A+11, @TRK DS ; TRACK
6235 025100 113737 004114 001272 MOV     @DPB, A+10, @SEC DS ; SECTOR
6236 025106 012746 004122          MOV     #DPB, A+16, -(SP) ; STATUS/ERROR INDICATOR ADDRESS
6237 025112 004737 026245          JSR     PC, @#ERINDX    ; FORM DISPATCH INDEX
6238 025116 062607          ADD     (SP)+, PC      ; REPORT PROPER ERROR
6239 025120 104041          ERROR  41              ;
6240 025122 104042          ERROR  42              ; PARITY ERROR
6241 025124 104043          ERROR  43              ; UNSAFE ERROR
6242 025126 104044          ERROR  44              ; NON-1/0 ERROR
6243 025130 104045          ERROR  45              ; 1/0 ERROR
6244 025132 013746 004122 25      MOV     DPB, A+16, -(SP) ; STATUS WORD
6245 025136 004737 026206          JSR     PC, LOP CK      ; SEE IF LOOP, ABORT, OR CONTINUE
6246 025142 000200          35      RTS     RO      ; RETURN
    
```

, THIS ROUTINE IS THE SAME AS "CALL A" EXCEPT FOR THE DPB USED AND IF  
 , THE COMMAND IS A READ HEADER AND DATA THE HEADER (CYLINDER, TRACK,  
 , AND SECTOR) READ IS CHECKED FOR VALIDITY

; CALL

;/ FILL DPB

;/ JSR RO, @#CALL. B

;/ RETURN

```

6251
6252
6253
6254
6255
6256 025144 005037 001206 CALL B CLR     @#$ESCAPE    ; NO ESCAPE ADDRESS
6257 025150 004037 035302          JSR     RO, @#RPO4      ; CALL RPO4 DRIVER
6258 025154 004124          DPB B
6259 025156 000772          BR      CALL B
6260 025160 005737 004142 15      TST     DPB, B+16      ; DONE?
6261 025164 001775          BEQ     15              ; NO--BRANCH
6262 025166 100042          BPL     45              ; BRANCH IF NO ERROR
6263 025170 012737 025262 001206 MOV     #3$, $ESCAPE    ; ESCAPE TO 3$ ON ERROR
6264 025176 013737 004136 001270 MOV     @DPB, B+12, @CYL DS ; CYLINDER
6265 025204 113737 004135 001274 MOV     @DPB, B+11, @TRK DS ; TRACK
6266 025212 113737 004134 001272 MOV     @DPB, B+10, @SEC DS ; SECTOR
6267 025220 012746 004142          MOV     #DPB, B+16, -(SP) ; STATUS/ERROR INDICATOR ADDRESS
6268 025224 004737 026246          JSR     PC, @#ERINDX    ; FORM DISPATCH INDEX
6269 025230 062607          ADD     (SP)+, PC      ; REPORT PROPER ERROR
6270 025232 104041          ERROR  41              ;
6271 025234 104042          ERROR  42              ; PARITY ERROR
6272 025236 104043          ERROR  43              ; UNSAFE ERROR
6273 025240 104044          ERROR  44              ; NON-1/0 ERROR
6274 025242 005737 004220          TST     R? REG+RPER1    ; DRIVE ERROR ?
6275 025246 001404          BEQ     25              ; BR IF NOT
6276 025250 032737 177677 004220 BIT     # C100, R? REG+RPER1 ; SEE IF ONLY 'HCE' SET
6277 025256 001406          BEQ     45              ; BR IF IT IS
6278 025260 104045          25      ERROR  45              ; 1/0 ERROR
6279 025262 013746 004142 35      MOV     DPB, B+16, -(SP) ; STATUS WORD
6280 025266 004737 026206          JSR     PC, LOP CK      ; SEE IF LOOP, ABORT, OR CONTINUE
6281 025272 000410          BR      55              ; CHECK FOR STALL
6282 025274 123727 004126 000173 45      CMP     @#DPB, B+2, #READHD ; DOING IMPLIED SEEKS?
6283 025302 001004          BNE     55              ; NO--BRANCH
    
```



```

6340      ,CALL
6341      ;      FILL DPB
6342      ;      JSR      RO,@#DRVCAL
6343      ;      RETURN
6344
6345      025524 005037 001206      DRVCAL. CLR      @#SEESCAPE      ;NO ESCAPE ADDRESS
6346      025530 005037 001334      CLR      @#WCEFLG      ;CLEAR WRITE CHECK ERROR FLAG
6347      025534 004037 035302      JSR      RO,@#RPO4      ;CALL RPO4 DRIVER
6348      025540 004164      DTADPB
6349      025542 000770      BR      DRVCAL
6350      025544 005737 004202      DRVCL1 TST      @#DTADPB+16      ;DONE
6351      025550 001775      BEQ      DRVCL1      ;NO--LOOP
6352      025552 100402      BMI      1$      ;BR IF ERRORS
6353      025554 000137 026166      JMP      10$      ;NO ERRORS
6354      025560
6355      025560 012737 025634 001206      1$.  MOV      #2$,SEESCAPE      ;;ESCAPE TO 2$ ON ERROR
6356      025566 013737 004176 001270      MOV      @#DTADPB+12,@#CYL.DS ;CYLINDER
6357      025574 113737 004175 001274      MOV      @#DTADPB+11,@#TRK.DS ;TRACK
6358      025602 113737 004174 001272      MOV      @#DTADPB+10,@#SEC.DS ;SECTOR
6359      025610 012746 004202      MOV      #DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
6360      025614 004737 026246      JSR      PC,@#ERINDX      ;FORM DISPATCH INDEX
6361      025620 062607      ADD      (SP)+,PC      ;REPORT PROPER ERROR
6362      025622 104041      ERROR    41      ;
6363      025624 104042      ERROR    42      ;PARITY ERROR
6364      025626 104043      ERROR    43      ;UNSAFE ERROR
6365      025630 104044      ERROR    44      ;NON-1/O ERROR
6366      025632 104045      ERROR    45      ;1/O ERROR
6367      025634 122737 000020 001102 2$.  CMP      #20,@#STSTNM      ;TEST 20?
6368      025642 001137      BNE      8$      ;NO--BRANCH
6369      025644 013746 004202      MOV      DTADPB+16,-(SP) ;STATUS WORD
6370      025650 004737 026206      JSR      PC,LOP CK      ;SEE IF LOOP, ABORT, OR CONTINUE
6371      025654 122737 000151 004166      CMP      #WRCKD,@#DTADPB+2 ;DOING A WRITE CHECK?
6372      025662 001133      BNE      12$      ;NO--BRANCH
6373      025664 032737 040000 004214      BIT      #BIT14,@#RP REG+10 ;IS "WCE"=1?
6374      025672 001527      BEQ      12$      ;NO--BRANCH
6375      025674 032777 000020 153236      BIT      #SHO4,@SWR      ;INHIBIT WRITES?
6376      025702 001123      BNE      12$      ;YES--BRANCH
6377      025704 112737 000161 004166      MOV      #WRITE,@#DTADPB+2 ;SETUP FOR A WRITE
6378      025712 005037 001206      CLR      @#SEESCAPE      ;NO ESCAPE ADDRESS
6379      025716 004037 035302      JSR      RO,@#RPO4      ;DO THE WRITE
6380      025722 004164      DTADPB
6381      025724 000240      NOP
6382      025726 005737 004202      3$.  TST      @#DTADPB+16      ;DONE?
6383      025732 001775      BEQ      3$      ;NO--LOOP
6384      025734 100026      BPL      4$      ;YES--BRANCH IF NO ERROR
6385      025736 012737 026142 001206      MOV      #8$,SEESCAPE      ;;ESCAPE TO 8$ ON ERROR
6386      025744 013737 004176 001270      MOV      @#DTADPB+12,@#CYL.DS ;CYLINDER
6387      025752 113737 004175 001274      MOV      @#DTADPB+11,@#TRK.DS ;TRACK
6388      025760 113737 004174 001272      MOV      @#DTADPB+10,@#SEC.DS ;SECTOR
6389      025766 012746 004202      MOV      #DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
6390      025772 004737 026246      JSR      PC,@#ERINDX      ;FORM DISPATCH INDEX
6391      025776 062607      ADD      (SP)+,PC      ;REPORT PROPER ERROR
6392      026000 104041      ERROR    41      ;
6393      026002 104042      ERROR    42      ;PARITY ERROR
6394      026004 104043      ERROR    43      ;UNSAFE ERROR
6395      026006 104044      ERROR    44      ;NON-1/O ERROR
    
```

```

6396 026010 104045          ERROR 45          ; I/O ERROR
6397 026012 112737 000151 004166 45.  MOVB  #WRCKD, @#DTADPB+2 ; COMMAND=WRITE CHECK DATA
6398 026020 004037 035302      JSR   RO, @#RPO4        ; DO THE WRITE CHECK
6399 026024 004164          DTADPB
6400 026026 000240          NOP
6401 026030 005737 004202      55    TST   @#DTADPB+16      ; DONE?
6402 026034 001775          BEQ   55              ; NO--LOOP
6403 026036 100410          BMI   75              ; YES--BRANCH IF ERROR
6404 026040 004037 035302      JSR   RO, @#RPO4        ; DO A 2ND WRITE CHECK
6405 026044 004164          DTADPB
6406 026046 000240          NOP
6407 026050 005737 004202      65    TST   @#DTADPB+16      ; DONE?
6408 026054 001775          BEQ   65              ; NO--LOOP
6409 026056 100043          BPL   105             ; YES--BRANCH IF NO ERROR
6410 026060 012737 000001 001334 75    MOV   #1, @#WCEFLG     ; SET THE WRITE CHECK ERROR FLAG
6411 026066 012737 026142 001206  MOV   #85, $ESCAPE     ; ESCAPE TO 85 ON ERROR
6412 026074 013737 004176 001270  MOV   @#DTADPB+12, @#CYL.DS ; CYLINDER
6413 026102 113737 004175 001274  MOVB  @#DTADPB+11, @#TRK.DS ; TRACK
6414 026110 113737 004174 001272  MOVB  @#DTADPB+10, @#SEC.DS ; SECTOR
6415 026116 012746 004202      MOV   @#DTADPB+16, -(SP) ; STATUS/ERROR INDICATOR ADDRESS
6416 026122 004737 026246      JSR   PC, @#ERINDX     ; FORM DISPATCH INDEX
6417 026126 062607          ADD   (SP)+, PC        ; REPORT PROPER ERROR
6418 026130 104041          ERROR 41
6419 026132 104042          ERROR 42          ; PARITY ERROR
6420 026134 104043          ERROR 43          ; UNSAFE ERROR
6421 026136 104044          ERROR 44          ; NON-I/O ERROR
6422 026140 104046          ERROR 46          ; FATAL WRITE CHECK
6423 026142 013746 004202      85    MOV   DTADPB+16, -(SP) ; STATUS WORD
6424 026146 004737 026206      JSR   PC, LOP.CK      ; SEE IF LOOP, ABORT, OR CONTINUE
6425 026152 123737 001364 001103 125   CMPB  @#ERR.CT, @#$ERFLG ; GO TO NEXT TEST?
6426 026160 101002          BHI   105             ; NO--BRANCH
6427 026162 013700 001252      95    MOV   @#BYPASS, RO   ; YES--GET EXIT ADDRESS
6428 026166 032737 040000 001220 105   BIT   #SW14, @#C SWR  ; STALL?
6429 026174 001403          BEQ   115             ; NO--BRANCH
6430 026176 004037 026364      JSR   RO, @#STALL     ; YES--CALL STALL ROUTINE
6431 026202 001356          WORD  STALL2        ; STALL TIME POINTER
6432 026204 000200          115   RTS   RO
6433
6434          ; THIS SUBROUTINE CHECK FOR LOOP, ABORT, OR CONTINUE SWITCHES AFTER
6435          ; ERRORS 41, 42, 43, 44, 45, AND 46
6436          ; CALL
6437          ;     MOV   DTA+16, -(SP) ; STATUS WORD FROM DPB IN USE
6438          ;     JSR   PC, LOP.CK
6439          ;     RETURN
6440
6441 026206 032777 001000 152724 LOP CK BIT   #SW9, @SWR ; LOOP ON ERROR
6442 026214 001402          BEQ   15              ; BR IF NOT
6443 026216 000177 152666          JMP   @#LPERR        ; START AT THE LOOP ADDRESS
6444 026222 005037 001206          CLR   $ESCAPE        ; CLEAR ERROR ESCAPE FLAG
6445 026226 032766 072006 000002 15    BIT   #BIT14'BIT13'BIT12'BIT10'BIT02'BIT01, 2(SP) ; CHECK ERROR TYPE
6446 026234 001402          BEQ   25              ; BR IF DRIVE NOT OFFLINE, UNLOADED, OR
6447          ; PERSISTENT UNSAFE OR FATAL MASSBUS PARITY
6448 026236 000137 017366          JMP   $EOP          ; TERMINATE DRIVE
6449 026242 012616          25    MOV   (SP)+, (SP)    ; ADJUST RETURN ADDRESS
6450 026244 000207          RTS   PC
6451
    
```

```

6452 , THIS ROUTINE FORMS AN INDEX THAT WILL BE USED TO DISPATCH
6453 , TO THE PROPER ERROR CALL. THE INDEX IS FORMED BY EXAMINING
6454 , THE STATUS/ERROR INDICATOR OF THE APPLICABLE DPB
6455 , INDEX          STATUS/ERROR
6456 ,-----
6457 ,      0 BIT14!BIT13!BIT08!BIT01
6458 ,      2 BIT11!BIT10!BIT02
6459 ,      4 BIT12!BIT04
6460 ,      6 BIT05!BIT03!<BIT09 & COMMAND=NON-1/0>
6461 ,     10 BIT06!<BIT09 & COMMAND=1/0>
6462 , CALL
6463 ,      JSR      #DPB+16, -(SP) ; ADDRESS OF STATUS/ERROR INDICATOR
6464 ,      JSR      PC, @#ERINDX ; FORM INDEX
6465 ,      RETURN   ; INDEX IS ON THE STACK
6466
6467 026246 010046 ERINDX MOV      RO, -(SP) ; SAVE RO
6468 026250 010146      MOV      R1, -(SP) ; SAVE R1
6469 026252 016600 000006      MOV      6(SP), RO ; GET STATUS/ERROR INDICATOR POINTER
6470 026256 011037 001260      MOV      (RO), @#SVSTAT ; SAVE THE STATUS/ERROR INDICATOR
6471 026262 005001      CLR      R1 ; START INDEX AT ZERO
6472 026264 032710      BIT      (PC)+, (RO) ; FORM INDEX OF 0?
6473 026266 020402      WORD   BIT13!BIT08!BIT01
6474 026270 001027      BNE     5$ ; YES--BRANCH
6475 026272 032710      BIT      (PC)+, (RO) ; FORM PARITY ERROR OR PORT REQUEST INDEX (2)?
6476 026274 006004      WORD   BIT11!BIT10!BIT02
6477 026276 001023      BNE     4$ ; YES--BRANCH
6478 026300 032710      BIT      (PC)+, (RO) ; FORM UNSAFE INDEX (4)?
6479 026302 050020      WORD   BIT14!BIT12!BIT04
6480 026304 001017      BNE     3$ ; YES--BRANCH
6481 026306 032710      BIT      (PC)+, (RO) ; FORM NON-1/0 ERROR INDEX (6)?
6482 026310 000050      WORD   BIT05!BIT03
6483 026312 001013      BNE     2$ ; YES--BRANCH
6484 026314 032710      BIT      (PC)+, (RO) ; FORM 1/0 ERROR INDEX (10)?
6485 026316 000100      WORD   BIT06
6486 026320 001007      BNE     1$ ; YES--BRANCH
6487 026322 032710      BIT      (PC)+, (RO) ; SOFTWARE TIMEOUT?
6488 026324 001000      WORD   BIT09
6489 026326 001410      BEQ     5$ ; NO--FORM INDEX OF 0
6490 026330 122760 000150 177762      CMPB   #150, -16(RO) ; YES--1/0?
6491 026336 003001      BGT     2$ ; NO--BRANCH
6492 026340 005201      1$     INC      R1 ; INDEX=10---ERROR=45 OR 46
6493 026342 005201      2$     INC      R1 ; INDEX=6---ERROR=44
6494 026344 005201      3$     INC      R1 ; INDEX=4---ERROR=43
6495 026346 005201      4$     INC      R1 ; INDEX=2---ERROR=42
6496 026350 006301      5$     ASL     R1 ; INDEX=0---ERROR=41
6497 026352 010166 000006      MOV     R1, 6(SP) ; RETURN INDEX TO USER
6498 026356 012601      MOV     (SP)+, R1 ; RESTORE R1
6499 026360 012600      MOV     (SP)+, RO ; RESTORE RO
6500 026362 000207      RTS    PC ; RETURN FROM CALL
6501
6502 , THIS ROUTINE WILL PROVIDE A STALL IN MILLISECONDS FOR A SPECIFIC
6503 , AMOUNT OF TIME IF BIT13 OF C SWR = 0 OR A RANDOM AMOUNT OF TIME
6504 , IF BIT 13 OF C SWR = 1
6505 , STALL1 CONTAINS SPECIFIED TIME FOR TESTS 0 - 7, AND STALL2
6506 , CONTAINS THE TIME FOR TESTS 16-21
6507 , CALL
    
```

```

6508      ,      JSR      RD,@#STALL
6509      ,      TIME POINTER      ;WHERE TO FIND THE STALL TIME
6510
6511 026364 013046      STALL  MOV      @ (RD)+, -(SP)      ; PICKUP STALL TIME
6512 026366 032737 020000 001220  BIT      #SW13,@#C SWR      ; USE A RANDOM TIME?
6513 026374 001406      BEQ      1$      ; NO--BRANCH
6514 026376 004737 023510  JSR      PC,@#SRAND      ; YES--FORM RANDOM NUMBER
6515 026402 013716 023610  MOV      @#SLONUM,(SP)      ; AND USE IT FOR THE STALL TIME
6516 026406 042716 177700  BIC      # (77,(SP)      ; BUT NEVER > 64 MILLISECONDS
6517 026412 005046      1$  CLR      -(SP)      ; CLEAR TEMP. LOCATION
6518 026414 162766 000001 000002  2$  SUB      #1,2(SP)      ; MORE STALL REQUIRED?
6519 026422 103407      BLO      4$      ; NO--BRANCH
6520 026424 012716 000144      MOV      #100,(SP)      ; STALL FOR ABOUT 1 MILLISECOND
6521 026430 005700      3$  TST      RD      ; NOP TO KILL TIME
6522 026432 005366 000000      DEC      0(SP)      ; COUNT
6523 026436 001374      BNE      3$      ; LOOP IF MORE COUNTS NEEDED
6524 026440 000765      BR      2$
6525 026442 022626      4$  CMP      (SP)+,(SP)+      ; CLEAN OFF THE STACK
6526 026444 000200      RTS      RD      ; EXIT
6527
6528
6529      ,ROUTINE TO PROVIDE A 2 MS STALL AFTER A SEEK OPERATION IN THE SEEK TIMING
6530      ,TESTS THIS STALL IS REQUIRED TO COMPENSATE FOR THE 'ACCESS READY' DELAY
6531      ,IN THE RPO4 THIS STALL TIME IS NOT INCLUDED IN THE CALCULATED SEEK TIMES
6532      ,CALL
6533      ,      JSR      PC,@#TWOMS
6534      ,      RETURN
6535
6536 026446 013746 177776      TWO*MS  MOV      @#PS, -(SP)      ; SAVE THE PRESENT PROCESSOR STATUS
6537 026452 012737 000240 177776  MOV      #(<5*32 >,@#PS      ; SET THE PROCESSOR PRIORITY TO 5
6538 026460 017746 152710  MOV      @PKV, -(SP)      ; SAVE THE OLD CLOCK VECTOR ADDRESS
6539 026464 012777 026510 152702  MOV      #1$,@PKV      ; SETUP NEW VECTOR ADDRESS
6540 026472 012777 000310 152702  MOV      #200,@PKB      ; LOAD THE CLOCK BUFFER
6541 026500 012777 000101 152672  MOV      #101,@PKCS      ; START THE CLOCK
6542 026506 000001      WAIT      ; WAIT FOR 2 MS
6543 026510 062706 000004      1$  ADD      #4,SP      ; INCREMENT STACK FOR RETURN
6544 026514 012677 152654      MOV      (SP)+,@PKV      ; RESTORE OLD CLOCK VECTOR
6545 026520 012637 177776      MOV      (SP)+,@#PS      ; RESTORE THE OLD PROCESSOR STATUS
6546 026524 000207      RTS      PC      ; RETURN
6547
6548      ,ROUTINE TO SOFTWARE COMPARE HEADER ON IMPLIED SEEKS
6549      ,CALL
6550      ,      JSR      RD,@#VERIFY
6551      ,      ADR POINTER      ; ADDRESS OF DPB+10 (SECTOR NUMBER)
6552      ,      RETURN
6553
6554 026526 010146      VERIFY  MOV      R1, -(SP)      ; SAVE R1
6555 026530 012001      MOV      (RD)+,R1      ; GET ADDRESS OF DPB+10
6556 026532 042737 010000 047712  BIC      #FMT22,@#BUFFER      ; STRIP FORMAT BIT FROM CYLINDER NUMBER
6557 026540 023761 047712 000002  CMP      @#BUFFER,2(R1)      ; CYLINDER NUMBER OK?
6558 026546 001003      BNE      1$      ; NO--BRANCH
6559 026550 023711 047714      CMP      @#BUFFER+2,(R1)      ; YES--HOW ABOUT TRACK/SECTOR?
6560 026554 001441      BEQ      3$      ; BRANCH IF GOOD
6561 026556 013737 047712 001262  1$  MOV      @#BUFFER,@#CYL RD ; SAVE THE EXPECTED AND THE
6562 026564 113737 047715 001264  MOVB     @#BUFFER+3,@#TRK RD ; RECIEVED CYLINDER, TRACK.
6563 026572 113737 047714 001266  MOVB     @#BUFFER+2,@#SEC RD ; AND SECTOR
    
```

```

6564 026600 112137 001272      MOV      (R1)+, @#SEC DS
6565 026604 112137 001274      MOV      (R1)+, @#TRK DS
6566 026610 011137 001270      MOV      (R1), @#CYL DS
6567 026614 012737 026626 001206  MOV      #2$, $ESCAPE      ; ESCAPE TO 2$ ON ERROR
6568 026622 005740      TST      -(R0)            ; MAKE IT TEST PC+4
6569 026624 104012      ERROR    12              ; REPORT THE ERROR
6570 026626 012737 000107 004106 2$  MOV      #RECAL, DPB A+2  ; LOAD RECALIBRATE ORDER CODE
6571 026634 004037 025032      JSR      RO, @#CALL A    ; GO EXECUTE THE COMMAND
6572 026640 005037 001206      CLR      $ESCAPE        ; CLEAR ERROR ESCAPE FLAG
6573 026644 032777 001000 152266  BIT      #SW9, @SWR      ; LOOP ON ERROR ?
6574 026652 001404      BEQ      4$             ; BR IF NOT
6575 026654 000177 152230      JMP      @SLPERR        ; RETURN TO ERROR LOOP ADDRESS
6576 026660 062700 000002      3$  ADD      #2, RO        ; INCREMENT RETURN ADDRESS
6577 026664 012601      4$  MOV      (SP)+, R1      ; RESTORE R1
6578 026666 000200      RTS      RO              ; EXIT
6579
6580      ; THIS ROUTINE WILL PERFORM A "MASSBUS" INIT FOLLOWED BY
6581      ; A "RECALIBRATE" ON THE DRIVE UNDER TEST
6582      ; NOTE THIS ROUTINE DESTROYS R1 AND R4
6583      ; CALL
6584      ; JSR      RO, SRCHOO      ; DO A MASSBUS INIT AND RECAL
6585      ; RETURN1      ; RETURN HERE IF NO ERROR
6586      ; RETURN2      ; RETURN HERE ON ERROR
6587
6588 026670 005001      SRCHOO  CLR      R1          ; INCASE OF ERROR (TYPTIM)
6589 026672 005037 177776      CLR      @#PS
6590 026676 012777 037376 005612  MOV      #ISR, @RPVEC    ; SETUP INTERRUPT VECTOR
6591 026704 013704 034514      MOV      @#RPADR, R4    ; PICKUP ADDRESS OF RPCS1
6592 026710 012764 000040 000010  MOV      #BIT05, RPCS2(R4) ; MASSBUS INIT
6593 026716 005037 004174      CLR      @#DTADPB+10    ; TRACK=0, SECTOR=0
6594 026722 005037 004176      CLR      @#DTADPB+12    ; CYLINDER = 0
6595 026726 012737 000107 004166  MOV      #RECAL, @#DTADPB+2 ; COMMAND = RECALIBRATE
6596 026734 005037 001206      CLR      @#$ESCAPE      ; NO ESCAPE ADDRESS
6597 026740 004037 035302      JSR      RO, @#RPO4     ; CALL THE DRIVER
6598 026744 004164      DTADPB
6599 026746 000440      BR       4$             ; QUEUE IS FULL
6600 026750 005737 004202      1$  TST      DTADPB+16      ; WAIT ON DONE
6601 026754 001775      BEQ      1$
6602 026756 100030      BPL      3$             ; TAKE NORMAL EXIT IF NO ERROR
6603 026760 012737 027034 001206  MOV      #2$, $ESCAPE    ; ESCAPE TO 2$ ON ERROR
6604 026766 013737 004176 001270  MOV      @#DTADPB+12, @#CYL DS ; CYLINDER
6605 026774 113737 004175 001274  MOV      @#DTADPB+11, @#TRK DS ; TRACK
6606 027002 113737 004174 001272  MOV      @#DTADPB+10, @#SEC DS ; SECTOR
6607 027010 012746 004202      MOV      #DTADPB+16, -(SP) ; STATUS/ERROR INDICATOR ADDRESS
6608 027014 004737 026246      JSR      PC, @#ERINDX   ; FORM DISPATCH INDEX
6609 027020 062607      ADD      (SP)+, PC      ; REPORT PROPER ERROR
6610 027022 104041      ERROR    41
6611 027024 104042      ERROR    42            ; PARITY ERROR
6612 027026 104043      ERROR    43            ; UNSAFE ERROR
6613 027030 104044      ERROR    44            ; NON-I/O ERROR
6614 027032 104045      ERROR    45            ; I/O ERROR
6615 027034 005720      2$  TST      (R0)+          ; ADJUST FOR ERROR EXIT
6616 027036 000404      BR       4$             ; GO TO THE EXIT
6617 027040 005064 000006 3$  CLR      RPD(R4)        ; TRACK AND SECTOR = 0
6618 027044 005064 000034      CLR      RPC(R4)        ; CYLINDER = 0
6619 027050 000200      4$  RTS      RO              ; RETURN
    
```

```

6620
6621      , THIS IS AN RTI WHICH IS USED BY THE TIMING TESTS & THE SERVO SETTLE DOWN TEST
6622
6623 027052 000002      DORTI   RTI           , RETURN FROM INTERRUPT
6624
6625      , THIS ROUTINE WILL INITIALIZE THE TIMERS USED BY THE "TIMING ROUTINES"
6626      , CALL
6627      ,       JSR       PC, @#STRTMR
6628      ,       RETURN
6629
6630 027054 104412      STRTMR  SAVREG          ; SAVE R0-R5
6631 027056 012700 001276      MOV     #TIM UP, R0      ; START AT TIM UP (MINIMUM)
6632 027062 012701 001332      MOV     #TIM PT, R1     ; STOP AT TIM PT
6633 027066 005020      1$     CLR     (R0)+       ; CLEAR
6634 027070 020001      CMP     R0, R1         ; DONE?
6635 027072 103775      BLO    1$             ; NO--BRANCH
6636 027074 012710 047712      MOV     #BUFFER, (R0)   ; SETUP POINTER
6637 027100 012737 077777 001276      MOV     #CBIT15, @#TIM UP ; SET MINIMUM TIME TO MAXIMUM
6638 027106 012737 077777 001314      MOV     #CBIT15, @#TIM DN ; POSITIVE NUMBER
6639 027114 104413      RESREG
6640 027116 000207      RTS     PC           ; RETURN
6641
6642      , THIS ROUTINE WILL ADD THE ELAPSED TIME TO THE AVERAGE COUNTER AND
6643      , MAINTAIN THE MINIMUM AND MAXIMUM TIMES
6644      , NOTE THIS ROUTINE DESTROYS R2
6645      , CALL
6646      ,       MOV     #TP, R3      ; PARAMETER POINTER
6647      ,       MOV     FLAG, R5     ; FLAG=0=COUNT UP
6648      ,                               ; FLAG=-1=COUNT DOWN
6649      ,       JSR     PC, @#COUNT
6650      ,       RETURN
6651
6652 027120 012702 001276      COUNT  MOV     #TIM UP, R2   ; PICKUP THE "UP" POINTER
6653 027124 005705      TST    R5             ; USE IT?
6654 027126 001402      BEQ    1$             ; YES--BRANCH
6655 027130 012702 001314      MOV     #TIM DN, R2    ; NO--PICKUP "DOWN" POINTER
6656 027134 027722 152244      1$     CMP     @PKC, (R2)+   ; LESS THAN PREVIOUS LOW?
6657 027140 002003      BGE    2$             ; NO--BRANCH
6658 027142 017762 152236 177776      MOV     @PKC, -2(R2)   ; YES--SAVE IT
6659 027150 027763 152230 000004      2$     CMP     @PKC, 4(R3)  ; LESS THAN THE LOW LIMIT?
6660 027156 002001      BGE    3$             ; NO--BRANCH
6661 027160 005212      INC    (R2)          ; YES--COUNT IT
6662 027162 005722      3$     TST    (R2)+       ; ADVANCE THE POINTER
6663 027164 027722 152214      CMP     @PKC, (R2)+   ; GREATER THAN PREVIOUS HIGH?
6664 027170 003403      BLE    4$             ; NO--BRANCH
6665 027172 017762 152206 177776      MOV     @PKC, -2(R2)   ; YES--SAVE IT
6666 027200 027763 152200 000006      4$     CMP     @PKC, 6(R3)  ; GREATER THAN THE HIGH LIMIT?
6667 027206 003401      BLE    5$             ; NO--BRANCH
6668 027210 005212      INC    (R2)          ; YES--COUNT IT
6669 027212 005722      5$     TST    (R2)+       ; ADVANCE THE POINTER
6670 027214 067722 152164      ADD     @PKC, (R2)+   ; ADD THIS COUNT TO THE TOTAL
6671 027220 005522      ADC    (R2)+
6672 027222 005212      INC    (R2)
6673 027224 022737 056202 001332      CMP     #BUFFER+<4*814 >, @#TIM PT ; SAVE THIS COUNT?
6674 027232 101406      BLOS   6$             ; NO--BRANCH
6675 027234 017777 152144 152070      MOV     @PKC, @TIM PT ; YES--WELL SAVE IT THEN
    
```

6676	027242	062737	000002	001332		ADD	#2, @TIM.PT	, ADVANCE THE POINTER
6677	027250	000207			65	RTS	PC	; RETURN
6678								
6679								, THIS ROUTINE IS USED TO TYPE THE MINIMUM,
6680								, MAXIMUM, AND AVERAGE TIMES FOR THE TIMING TESTS
6681								, IT WILL ALSO CHECK THE TIMES TO ENSURE
6682								, THEY ARE WITHIN TOLERANCE AND IF NOT FLAG THE BAD TIMES
6683								, NOTE THIS ROUTINE DESTROYS R2-R5
6684								, CALL
6685							JSR	RO, @TYPTIM
6686							TABLE	; GO REPORT THE TIMES
6687							RETURN	; POINT TO THE PROPER TABLE
6688								
6689							TABLE MSGADR1	; ADDRESS OF ASCIZ MESSAGE NUMBER 1
6690							MSGADR2	; ADDRESS OF ASCIZ MESSAGE NUMBER 2
6691							MIN ALLOWED	; MINIMUM TIME ALLOWED
6692							MAX ALLOWED	; MAXIMUM TIME ALLOWED
6693								
6694	027252	012002				TYPTIM	MOV	(R0)+, R2
6695	027254	032777	000100	151656			BIT	#SW06, @SWR
6696	027262	001145					BNE	75
6697	027264	012237	027304				MOV	(R2)+, 25
6698	027270	012205					MOV	(R2)+, R5
6699	027272	012203					MOV	(R2)+, R3
6700	027274	011202					MOV	(R2), R2
6701	027276	012704	001276				MOV	#TIM UP, R4
6702	027302	104401			15		TYPE	; TYPE THE MESSAGE
6703	027304	000000			25		WORD	0
6704	027306	005764	000014				TST	14(R4)
6705	027312	001527					BEQ	65
6706	027314	104401	043700				TYPE	, MSGMIN
6707	027320	012446					MOV	(R4)+, -(SP)
6708	027322	004737	023220				JSR	PC, @\$\$SB2D
6709	027326	004737	023450				JSR	PC, @\$\$SUPRS
6710	027332	104401	043725				TYPE	, MSGOUS
6711	027336	005724					TST	(R4)+
6712	027340	001421					BEQ	35
6713	027342	104401	044040				TYPE	, MSG SP
6714	027346	016446	177776				MOV	-2(R4), -(SP)
6715	027352	004737	023220				JSR	PC, @\$\$SB2D
6716	027356	004737	023450				JSR	PC, @\$\$SUPRS
6717	027362	104401	043732				TYPE	, MBELOW
6718	027366	010346					MOV	R3, -(SP)
6719	027370	004737	023220				JSR	PC, @\$\$SB2D
6720	027374	004737	023450				JSR	PC, @\$\$SUPRS
6721	027400	104401	043725				TYPE	, MSGOUS
6722	027404	104401	043707		35		TYPE	, MSGMAX
6723	027410	012446					MOV	(R4)+, -(SP)
6724	027412	004737	023220				JSR	PC, @\$\$SB2D
6725	027416	004737	023450				JSR	PC, @\$\$SUPRS
6726	027422	104401	043725				TYPE	, MSGOUS
6727	027426	005724					TST	(R4)+
6728	027430	001421					BEQ	45
6729	027432	104401	044040				TYPE	, MSG. SP
6730	027436	016446	177776				MOV	-2(R4), -(SP)
6731	027442	004737	023220				JSR	PC, @\$\$SB2D

```

6732 027446 004737 023450      JSR    PC,@#SSUPRS    ,TYPE WITHOUT LEADING ZEROS
6733 027452 104401 043761      TYPE    ,MABOVE      , "ABOVE THE MAXIMUM OF"
6734 027456 010246                MOV    R2,-(SP)      ;PUT R2 ON THE STACK
6735 027460 004737 023220      JSR    PC,@#SSB2D    ,CHANGE R2 TO DECIMPL ASCIZ
6736 027464 004737 023450      JSR    PC,@#SSUPRS    ;TYPE WITHOUT LEADING ZEROS
6737 027470 104401 043725      TYPE    ,MSGOUS
6738 027474 104401 043716      4$    TYPE    ,MSGAVG      , "AVG="
6739 027500 012446                MOV    (R4)+,-(SP)   ,FORM THE AVERAGE
6740 027502 012446                MOV    (R4)+,-(SP)
6741 027504 012446                MOV    (R4)+,-(SP)
6742 027506 004737 023612      JSR    PC,@#SDIV
6743 027512 006126                ROL    (SP)+        , IS THE REMAINDER OVER HALF?
6744 027514 100001                BPL    5$           ,NO--BRANCH
6745 027516 005216                INC    (SP)         ,YES--ROUND UP
6746 027520                5$
6747 027520 004737 023220      JSR    PC,@#SSB2D    ,CHANGE TO DECIMAL ASCIZ
6748 027524 004737 023450      JSR    PC,@#SSUPRS    ,TYPE WITHOUT LEADING ZEROS
6749 027530 104401 043725      TYPE    ,MSGOUS
6750 027534 104401 044040      TYPE    ,MSG SP
6751 027540 016446 177776      MOV    -2(R4),-(SP)  ,PUT -2(R4) ON THE STACK
6752 027544 004737 023220      JSR    PC,@#SSB2D    ,CHANGE -2(R4) TO DECIMAL ASCIZ
6753 027550 004737 023450      JSR    PC,@#SSUPRS    ,TYPE WITHOUT LEADING ZEROS
6754 027554 104401 044010      TYPE    ,MSGNUM
6755 027560 010537 027304      MOV    R5,2$        ,NEXT MESSAGE POINTER
6756 027564 001404                BEQ    7$           ,IF NONE EXIT
6757 027566 005005                CLR    R5           ,NO MORE THAN 2
6758 027570 000644                BR     1$
6759 027572 104401 044025      6$    TYPE    ,MSGNON
6760 027576 000200      7$    RTS     R0        ,EXIT
6761
6762      , THIS SUBROUTINE WILL INCREMENT THE TRACK
6763      , NUMBER (R2) BY THE AMOUNT SPECIFIED BY 'IT'
6764      , CALL
6765      ,      JSR    R0,@#INCTRK
6766      ,      RETURN1
6767      ,      RETURN2
6768      ,      TRACK NUMBER GREATER THAN LT15
6769      ,      TRACK NUMBER INCREMENTED
6770      INCTRK CMP    R2,@#LT    ,LAST TRACK COMPLETED?
6771      BEQ    2$        ,YES--EXIT
6772      ADD    @#IT,R2    ,NO--UPDATE TRACK
6773      CMP    R2,@#LT    ,TRACK TO BIG?
6774      BLE    1$        ,NO--EXIT
6775      MOV    @#LT,R2    ,YES--SET TRACK TO LAST TRACK
6776      1$    TST    (R0)+    ,ADJUST FOR RETURN 2
6777      2$    RTS     R0        ,RETURN
6778
6779      , THIS SUBROUTINE WILL INCREMENT THE CYLINDER
6780      , NUMBER (R1) BY THE AMOUNT SPECIFIED BY 'IC'
6781      , CALL
6782      ,      JSR    R0,@#INCCYL
6783      ,      RETURN1
6784      ,      RETURN2
6785      ,      CYLINDER NUMBER GREATER THAN LC15
6786      ,      CYLINDER NUMBER INCREMENTED
6787      INCCYL CMP    R1,@#LC    ,LAST CYLINDER COMPLETED?
6788      BEQ    2$        ,YES--EXIT
  
```

```

6788 027636 063701 001514      ADD    @#IC,R1      ;NO--UPDATE CYLINDER
6789 027642 020137 001512      CMP    R1,@#LC     ;CYLINDER TO BIG?
6790 027646 003402              BLE    1$          ;NO--EXIT
6791 027650 013701 001512      MOV    @#LC,R1     ;YES--SET CYLINDER TO LAST CYLINDER
6792 027654 005720              1$    TST    (R0)+  ;ADJUST FOR RETURN 2
6793 027656 000200              2$    RTS     RO    ;RETURN
6794
6795      ; THIS ROUTINE DECREASES THE SECTOR ADDRESS.
6796      ; CALL
6797      ;
6798      ;     CLR    -(SP)      ;CLEAR THE STACK
6799      ;     JSR    PC,DECSEC  ;SUBROUTINE ENTRY
6800      ;     RETURN
6801 027660 113766 004212 000002  DECSEC  MOV    RP REG+RPDA,2(SP) ; PUT THE SECTOR ADDRESS ON THE STACK
6802 027666 005366 000002              DEC    2(SP)      ; DECREMENT THE ADDRESS
6803 027672 100003              BPL    1$          ; BR IF NOT CORRECTION NEEDED
6804 027674 013766 001634 000002  1$    MOV    PRMLMT+22,2(SP) ; OVERFLOW OCCURED, FORCE TO MAXIMUM ADDRESS
6805 027702 000207              1$    RTS     PC    ; RETURN
6806
6807      ; THIS SUBROUTINE IS USED TO FILL THE DATA BUFFER
6808      ; WITH ADDRESSES FROM 0 TO 21 WITH EACH ADDRESS
6809      ; BEING STORED IN 256 CONSECUTIVE LOCATIONS
6810      ; CALL
6811      ;
6812      ;     JSR    PC,@#FILBUF
6813      ;     RETURN
6814 027704 104412      FILBUF  SAVREG              ; SAVE RO - R5
6815 027706 005000              CLR    RO          ; FIRST DISK ADDRESS
6816 027710 012701 047712      MOV    #BUFFER,R1   ; START FILLING HERE
6817 027714 012702 000400      1$    MOV    #256,R2     ; DO 256 WORDS
6818 027720 010021      2$    MOV    RO,(R1)+   ; STORE
6819 027722 005302              DEC    R2          ; MORE?
6820 027724 003375              BGT    2$          ; YES--BRANCH
6821 027726 005200              INC    RO          ; NO--UPDATE DISK ADDRESS
6822 027730 023700 001630      CMP    PRMLMT+22,RO ; DONE?
6823 027734 103367              BHIS  1$          ; NO--BRANCH
6824 027736 104413      RESREG              ; RESTORE RO - R5
6825 027740 000207      RTS     PC    ; RETURN
6826
6827      ; THIS ROUTINE WILL CLEAR THE BUFFER BY
6828      ; SETTING EACH WORD TO "177400".
6829      ; CALL
6830      ;
6831      ;     JSR    RO,@#CLRBUF
6832      ;     RETURN
6833 027742 104412      CLRBUF  SAVREG              ; SAVE RO - R5
6834 027744 012701 177400      MOV    #177400,R1   ; WORD TO FILL BUFFER WITH
6835 027750 012702 047712      MOV    #BUFFER,R2   ; FIRST ADDRESS OF BUFFER
6836 027754 012703 075712      MOV    #BUFFER+<512 *22 >,R3 ; LAST ADDRESS+2 OF BUFFER
6837 027760 010122      1$    MOV    R1,(R2)+   ; FILL WORDS 1, 9, ... 249, ... 5625
6838 027762 010122              MOV    R1,(R2)+   ; FILL WORDS 2, 10, ... 250, ... 5626
6839 027764 010122              MOV    R1,(R2)+   ; FILL WORDS 3, 11, ... 251, ... 5627
6840 027766 010122              MOV    R1,(R2)+   ; FILL WORDS 4, 12, ... 252, ... 5628
6841 027770 010122              MOV    R1,(R2)+   ; FILL WORDS 5, 13, ... 253, ... 5629
6842 027772 010122              MOV    R1,(R2)+   ; FILL WORDS 6, 14, ... 254, ... 5630
6843 027774 010122              MOV    R1,(R2)+   ; FILL WORDS 7, 15, ... 255, ... 5631
    
```

```

6844 027776 010122          MOV     R1,(R2)+      ;FILL WORDS 8,16, 256, 5632
6845 030000 020203          CMP     R2,R3        ;DONE?
6846 030002 103766          BLO    15           ;NO--BRANCH
6847 030004 104413          RESREG ;RESTORE R0 - R5
6848 030006 000200          RTS     R0          ;RETURN FROM CALL
6849
6850          ; THIS ROUTINE IS USED TO CHECK THE DATA BUFFER
6851          ; FOR ADDRESSES 0 THROUGH 21 WITH EACH ADDRESS
6852          ; BEING STORED IN 256 CONSECUTIVE LOCATIONS
6853          ; CALL
6854          ; JSR     R0,#CKSCTR
6855          ; RETURN
6856
6857 030010 104412          CKSCTR SAVREG      ;SAVE R0 - R5
6858 030012 162706 000004      SUB     #4,SP        ;RESERVE TEMP. STORAGE AREA
6859 030016 005001          CLR    R1          ;FIRST SECTOR
6860 030020 012716 047712      MOV    #BUFFER,(SP) ;FIRST ADDRESS OF DATA BUFFER
6861 030024 005066 000002      CLR    2(SP)       ;NO ERRORS
6862 030030 012702 000020      15    MOV    #16,R2 ;LOOP COUNT (16*16=256)
6863 030034 011603          MOV    (SP),R3     ;GET 1ST ADDRESS OF THIS SECTORS DATA
6864 030036          25
6865 030036 020123          CMP    R1,(R3)+    ;WORD 1
6866 030040 001063          BNE    75         ;BRANCH IF BAD
6867 030042 020123          CMP    R1,(R3)+    ;WORD 2
6868 030044 001061          BNE    75         ;BRANCH IF BAD
6869 030046 020123          CMP    R1,(R3)+    ;WORD 3
6870 030050 001057          BNE    75         ;BRANCH IF BAD
6871 030052 020123          CMP    R1,(R3)+    ;WORD 4
6872 030054 001055          BNE    75         ;BRANCH IF BAD
6873 030056 020123          CMP    R1,(R3)+    ;WORD 5
6874 030060 001053          BNE    75         ;BRANCH IF BAD
6875 030062 020123          CMP    R1,(R3)+    ;WORD 6
6876 030064 001051          BNE    75         ;BRANCH IF BAD
6877 030066 020123          CMP    R1,(R3)+    ;WORD 7
6878 030070 001047          BNE    75         ;BRANCH IF BAD
6879 030072 020123          CMP    R1,(R3)+    ;WORD 8
6880 030074 001045          BNE    75         ;BRANCH IF BAD
6881 030076 020123          CMP    R1,(R3)+    ;WORD 9
6882 030100 001043          BNE    75         ;BRANCH IF BAD
6883 030102 020123          CMP    R1,(R3)+    ;WORD 10
6884 030104 001041          BNE    75         ;BRANCH IF BAD
6885 030106 020123          CMP    R1,(R3)+    ;WORD 11
6886 030110 001037          BNE    75         ;BRANCH IF BAD
6887 030112 020123          CMP    R1,(R3)+    ;WORD 12
6888 030114 001035          BNE    75         ;BRANCH IF BAD
6889 030116 020123          CMP    R1,(R3)+    ;WORD 13
6890 030120 001033          BNE    75         ;BRANCH IF BAD
6891 030122 020123          CMP    R1,(R3)+    ;WORD 14
6892 030124 001031          BNE    75         ;BRANCH IF BAD
6893 030126 020123          CMP    R1,(R3)+    ;WORD 15
6894 030130 001027          BNE    75         ;BRANCH IF BAD
6895 030132 020123          CMP    R1,(R3)+    ;WORD 16
6896 030134 001025          BNE    75         ;BRANCH IF BAD
6897 030136 005302          DEC    R2          ;FINISHED WITH THIS SECTORS DATA?
6898 030140 001336          BNE    25         ;NO--BRANCH
6899 030142 062716 001000      35    ADD    #512,(SP) ;YES--FIRST ADDRESS OF NEXT SECTOR

```

```

6900 030146 005201          INC      R1          ; MOVE TO NEXT SECTOR
6901 030150 023701 001630  CMP      PRMLMT+22,R1 ; DONE?
6902 030154 103325          BHIS     1$          ; NO--BRANCH
6903 030156 005766 000002    4$      TST      2(SP)       ; ERROR OCCUR?
6904 030162 001406          BEQ      6$          ; NO--BRANCH
6905 030164 123737 001364 001103  CMPB    @#ERR.CT,@#SERFLG ; MAX. ERROR OCCUPRED?
6906 030172 101002          BHI      6$          ; NO--BRANCH
6907 030174 013700 001252    5$      MOV      @#BYPASS,R0    ; TAKE ERROR EXIT
6908 030200 062706 000004    6$      ADD      #4,SP         ; FREE TEMP. AREA
6909 030204 104413          RESREG                    ; RESTORE R0 - R5
6910 030206 000200          RTS      R0           ; RETURN FROM CALL
6911 030210 010304          7$      MOV      R3,R4        ; FORM WORD NUMBER AND
6912 030212 161604          SUB      (SP),R4       ; ADDRESS TO CONTINUE FROM
6913 030214 010405          MOV      R4,R5
6914 030216 006204          ASR      R4           ; WORD NUMBER
6915 030220 042705 177740    BIC      # C37,R5
6916 030224 001002          BNE      8$          ; BRANCH IF NOT A MULTIPLE OF 16
6917 030226 012705 000040    MOV      #40,R5       ; SET TO WORD 16
6918 030232 006305          8$      ASL      R5
6919 030234 062705 030036    ADD      #2$,R5       ; ADDRESS
6920 030240 016337 177776 001126  MOV      -2(R3),@#SBDAT ; SAVE BAD DATA
6921 030246 005766 000002    TST      2(SP)       ; FIRST ERROR?
6922 030252 001015          BNE      10$         ; NO--BRANCH
6923 030254 013737 004176 001270  MOV      @#DTADPB+12,@#CYL.DS ; CYLINDER NUMBER
6924 030262 113737 004175 001274  MOV      @#DTADPB+11,@#TRK.DS ; TRACK NUMBER
6925 030270 012737 030300 001206  MOV      #9$, $ESCAPE ; , ESCAPE TO 9$ ON ERROR
6926 030276 104021          ERROR   21           ; REPORT THE ERROR
6927 030300 105166 000002    9$      COMB    2(SP)       ; SET ERROR SWITCH
6928 030304 000404          BR      11$
6929 030306          10$
6930 030306 012737 030316 001206  MOV      #11$, $ESCAPE ; , ESCAPE TO 11$ ON ERROR
6931 030314 104022          ERROR   22           ; REPORT THE ERROR
6932 030316 032777 001000 150614 11$    BIT      #SW09,@SWR   ; LOOP ON ERROR?
6933 030324 001323          BNE      5$          ; YES
6934 030326 032777 000002 150604  BIT      #SW01,@SWR   ; STOP DATA COMPARE?
6935 030334 001310          BNE      4$          ; YES--BRANCH
6936 030336 123737 001364 001103  CMPB    @#ERR.CT,@#SERFLG ; MAX. ERRORS?
6937 030344 101713          BLOS    5$          ; YES--BRANCH
6938 030346 032777 000040 150564  BIT      #SW05,@SWR   ; REPORT ONLY 1ST ERROR PER SECTOR?
6939 030354 001272          BNE      3$          ; YES--BRANCH
6940 030356 000115          JMP      (R5)

```

```

, THIS ROUTINE WILL MOVE THE 16 WORDS OF THE
, DESIRED PATTERN INTO THE DATA BUFFER
, CALL
,      MOV      #NX,R0          ; PATTERN NUMBER INDEX TO R0
,      JSR      PC,@#SETBUF

```

```

6948 030360 104412          SETBUF SAVREG                    ; SAVE R0 - R5
6949 030362 012701 047712    MOV      #BUFFER,R1   ; FIRST ADDRESS
6950 030366 013702 004170    MOV      @#DTADPB+4,R2 ; WORD COUNT
6951 030372 016003 003044    1$      MOV      PAT PT(R0),R3 ; PICKUP PATTERN POINTER
6952 030376 012321          MOV      (R3)+,(R1)+  ; MOVE WORD 1 INTO DATA BUFFER
6953 030400 012321          MOV      (R3)+,(R1)+  ; MOVE WORD 2 INTO DATA BUFFER
6954 030402 012321          MOV      (R3)+,(R1)+  ; MOVE WORD 3 INTO DATA BUFFER
6955 030404 012321          MOV      (R3)+,(R1)+  ; MOVE WORD 4 INTO DATA BUFFER

```

```

6956 030406 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 5 INTO DATA BUFFER
6957 030410 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 6 INTO DATA BUFFER
6958 030412 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 7 INTO DATA BUFFER
6959 030414 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 8 INTO DATA BUFFER
6960 030416 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 9 INTO DATA BUFFER
6961 030420 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 10 INTO DATA BUFFER
6962 030422 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 11 INTO DATA BUFFER
6963 030424 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 12 INTO DATA BUFFER
6964 030426 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 13 INTO DATA BUFFER
6965 030430 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 14 INTO DATA BUFFER
6966 030432 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 15 INTO DATA BUFFER
6967 030434 012321      MOV      (R3)+, (R1)+      ; MOVE WORD 16 INTO DATA BUFFER
6968 030436 062702 000020  ADD      #16, R2, DONE?
6969 030442 001353      BNE      15                ; NO--BRANCH
6970 030444 104413      RESREG
6971 030446 000207      RTS       PC                ; RETURN
6972
6973                      ; THIS ROUTINE COMPARES A 16 WORD DATA PATTERN
6974                      ; AGAINST THE DATA BUFFER
6975                      ; CALL
6976                      ;      MOV      #NX, R0                ; PATTERN NUMBER INDEX TO R0
6977                      ;      JSR      PC, @#DATCMP
6978                      ;      RETURN
6979
6980 030450 104412      DATCMP  SAVREG                ; SAVE R0 - R5
6981 030452 012701 047712  MOV      #BUFFER, R1          ; FIRST ADDRESS OF BUFFER
6982 030456 013702 004170  MOV      @#DTADPB+4, R2       ; WORD COUNT
6983 030462 005046      CLR      -(SP)                ; NO ERROR
6984 030464 016003 003044  15      MOV      PAT PT(R0), R3      ; PATTERN POINTER
6985 030470      25
6986 030470 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 1
6987 030472 001044      BNE      45                  ; BRANCH IF DIFFERENT
6988 030474 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 2
6989 030476 001042      BNE      45                  ; BRANCH IF DIFFERENT
6990 030500 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 3
6991 030502 001040      BNE      45                  ; BRANCH IF DIFFERENT
6992 030504 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 4
6993 030506 001036      BNE      45                  ; BRANCH IF DIFFERENT
6994 030510 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 5
6995 030512 001034      BNE      45                  ; BRANCH IF DIFFERENT
6996 030514 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 6
6997 030516 001032      BNE      45                  ; BRANCH IF DIFFERENT
6998 030520 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 7
6999 030522 001030      BNE      45                  ; BRANCH IF DIFFERENT
7000 030524 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 8
7001 030526 001026      BNE      45                  ; BRANCH IF DIFFERENT
7002 030530 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 9
7003 030532 001024      BNE      45                  ; BRANCH IF DIFFERENT
7004 030534 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 10
7005 030536 001022      BNE      45                  ; BRANCH IF DIFFERENT
7006 030540 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 11
7007 030542 001020      BNE      45                  ; BRANCH IF DIFFERENT
7008 030544 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 12
7009 030546 001016      BNE      45                  ; BRANCH IF DIFFERENT
7010 030550 162321      SUB      (R3)+, (R1)+        ; CHECK WORD 13
7011 030552 001014      BNE      45                  ; BRANCH IF DIFFERENT

```

```

7012 030554 162321          SUB      (R3)+, (R1)+      ;CHECK WORD 14
7013 030556 001012          BNE     4$                ;BRANCH IF DIFFERENT
7014 030560 162321          SUB      (R3)+, (R1)+      ;CHECK WORD 15
7015 030562 001010          BNE     4$                ;BRANCH IF DIFFERENT
7016 030564 162321          SUB      (R3)+, (R1)+      ;CHECK WORD 16
7017 030566 001006          BNE     4$                ;BRANCH IF DIFFERENT
7018 030570 062702 000020   ADD     #16, R2           ;DONE ?
7019 030574 001333          BNE     1$                ;NO--BRANCH
7020 030576 005726          TST     (SP)+             ;YES -- CLEAN UP STACK
7021 030600 104413          RESREG                    ;RESTORE R0 - R5
7022 030602 000207          RTS     PC
7023 030604 010104          MOV     R1, R4            ;FORM THE WORD NUMBER
7024 030606 162704 047712   SUB     #BUFFER, R4
7025 030612 006204          ASR     R4                ;WORD NUMBER
7026 030614 010305          MOV     R3, R5            ;FORM ADDRESS TO CONTINUE FROM
7027 030616 166005 003044   SUB     PAT PT(R0), R5
7028 030622 006305          ASL     R5
7029 030624 062705 030470   ADD     #2$, R5           ;ADDRESS
7030 030630 064341          ADD     -(R3), -(R1)      ;RECONSTRUCT THE BAD WORD
7031 030632 010137 001122   MOV     R1, @#$BDADR      ;SAVE THE ERROR INFORMATION
7032 030636 010337 001120   MOV     R3, @#$GDADR
7033 030642 012137 001126   MOV     (R1)+, @#$BDDAT
7034 030646 012337 001124   MOV     (R3)+, @#$GDDAT
7035 030652 005716          TST     (SP)              ;1ST DATA COMPARE ERROR?
7036 030654 001023          BNE     6$                ;NO--BRANCH
7037 030656 013737 004176 001270  MOV     @#DTADPB+12, @#CYL. DS ;CYLINDER
7038 030664 113737 004175 001274  MOVB   @#DTADPB+11, @#TRK. DS ;TRACK
7039 030672 113737 004174 001272  MOVB   @#DTADPB+10, @#SEC. DS ;SECTOR
7040 030700 016600 000016          MOV     16(SP), R0        ;GET TEST PC+4
7041 030704 012737 030714 001206  MOV     #5$, $ESCAPE      ;ESCAPE TO 5$ ON ERROR
7042 030712 104013          ERROR  13                ;REPORT THE ERROR
7043 030714 016600 000014          MOV     14(SP), R0        ;PATTERN NUMBER INDEX
7044 030720 105116          COMB   (SP)              ;SET THE ERROR SWITCH
7045 030722 000404          BR     7$
7046 030724          BR     6$
7047 030724 012737 030734 001206  MOV     #7$, $ESCAPE      ;ESCAPE TO 7$ ON ERROR
7048 030732 104014          ERROR  14                ;REPORT THE ERROR
7049 030734 032777 000002 150176 7$   BIT     #SW01, @SWR       ;STOP DATA COMPARE?
7050 030742 001315          BNE     3$                ;YES--EXIT
7051 030744 123737 001364 001103  CMPB   @#ERR. CT, @#$ERFLG ;MAX. ERRORS?
7052 030752 101004          BHI     8$                ;NO--BRANCH
7053 030754 013766 001252 000016  MOV     @#BYPASS, 16(SP) ;YES--ERROR EXIT
7054 030762 000705          BR     3$
7055 030764 000115          BR     8$                ;NO--CONTINUE AT NEXT WORD
7056
7057          ; THIS ROUTINE WILL FILL THE DATA BUFFER (256*22 WORDS) WITH
7058          ; A RANDOM PATTERN. THE FIRST TWO WORDS OF EVERY 256 WILL
7059          ; BE THE BASE OF THE RANDOM NUMBER GENERATOR FOR THE
7060          ; NEXT 254 WORDS.
7061          ; NOTE THIS ROUTINE DESTROYS R1 AND R2
7062          ; CALL
7063          ; JSR      RO, @#FILRAN
7064          ; RETURN
7065
7066 030766 012701 047712          FILRAN MOV     #BUFFER, R1
7067 030772 013702 001630          MOV     PRMLNT+22, R2    ; MAXIMUM NUMBER OF SECTORS
    
```

```

7068 030776 004037 031206      15 JSR   RO,@#RANPAT
7069 031002 005302             DEC   R2
7070 031004 100374             BPL  15
7071 031006 000200             RTS   RO
7072
7073 ; THIS ROUTINE USES THE FIRST TWO WORDS OF THE
7074 ; READ BUFFER TO GENERATED A RANDOM PATTERN THEN
7075 ; THE READ BUFFER IS COMPARED TO THE PATTERN GENERATED
7076 ; NOTE THIS ROUTINE DESTROYS R1-R4
7077 ; CALL
7078 ; JSR   RO,@#RANCK
7079 ; RETURN
7080
7081 031010 013746 023606      RANCK MOV  @#$HINUM,-(SP) ;SAVE THE PRESENT RANDOM NUMBER
7082 031014 013746 023610      MOV  @#$LONUM,-(SP)
7083 031020 012702 050712      MOV  #BUFFER+512,R2 ;READ BUFFER ADDRESS
7084 031024 012701 051712      MOV  #BUFFER+1024,R1 ;RANDOM PATTERN ADDRESS
7085 031030 010103             MOV  R1,R3 ;COPY IT INTO R3 FOR LATER USE
7086 031032 011237 023610      MOV  (R2),@#$LONUM ;PRIME THE RANDOM NUMBER GENERATOR
7087 031036 016237 000002 023606 MOV  2(R2),@#$HINUM
7088 031044 004037 031206      JSR  RO,@#RANPAT ;GENERATE A RANDOM PATTERN
7089 031050 012637 023610      MOV  (SP)+,@#$LONUM ;RESTORE PRESENT RANDOM NUMBER
7090 031054 012637 023606      MOV  (SP)+,@#$HINUM
7091 031060 005046             CLR  -(SP) ;NO ERRORS
7092 031062 162322             15 SUB  (R3)+,(R2)+ ;ARE THESE TWO WORDS DIFFERENT?
7093 031064 001441             BEQ  45 ;NO--BRANCH
7094 031066 012737 031140 001206 MOV  #3$, $ESCAPE ;ESCAPE TO 3$ ON ERROR
7095 031074 064342             ADD  -(R3),-(R2) ;RECREATE THE BAD WORD
7096 031076 010237 001122      MOV  R2,@#$BDADR ;ADDRESS OF BAD DATA
7097 031102 010337 001120      MOV  R3,@#$GDADR ;ADDRESS OF GOOD DATA
7098 031106 012237 001126      MOV  (R2)+,@#$BDAT ;BAD DATA
7099 031112 012337 001124      MOV  (R3)+,@#$GDAT ;GOOD DATA
7100 031116 010204             MOV  R2,R4 ;FORM WORD NUMBER (1 TO 256)
7101 031120 162704 050712      SUB  #BUFFER+512,R4
7102 031124 006204             ASR  R4
7103 031126 005716             TST  (SP) ;FIRST ERROR
7104 031130 001002             BNE  25 ;NO--BRANCH
7105 031132 105116             COMB (SP) ;YES--SET ERROR SWITCH
7106 031134 104015             ERROR 15 ;REPORT THE ERROR
7107 031136 104016             25 ERROR 16 ;REPORT THE ERROR
7108 031140 032777 001000 147772 35 BIT  #SW09,@SWR ;LOOP ON ERROR?
7109 031146 001012             BNE  55 ;YES--BRANCH
7110 031150 123737 001364 001103 CMPB @#ERR.CT,@#$ERFLG ;MAX. ERRORS OCCURRED?
7111 031156 101406             BLOS 55 ;YES--BRANCH
7112 031160 032777 000002 147752 BIT  #SW01,@SWR ;STOP COMPARING?
7113 031166 001002             BNE  55 ;YES--BRANCH
7114 031170 020103             45 CMP  R1,R3 ;ALL DATA BEEN COMPARED?
7115 031172 101333             BHI  15 ;NO--BRANCH
7116 031174 005726             55 TST  (SP)+ ;ERROR OCCUR?
7117 031176 001402             BEQ  65 ;NO--BRANCH
7118 031200 013700 001252      MOV  @#BYPASS,RO ;TAKE ERROR EXIT
7119 031204 000200             65 RTS   RO ;EXIT
7120
7121 ; THIS ROUTINE FILLS A 256 WORD BUFFER WITH A RANDOM
7122 ; PATTERN OF WHICH THE FIRST TWO WORDS ARE THE BASE
7123 ; OF THE PATTERN
    
```

```

7124      ,CALL
7125      ,      MOV      #ADR,R1      ;ADDRESS OF THE BUFFER
7126      ,      JSR      RO,@#RANPAT
7127      ,      RETURN
7128
7129      RANPAT  MOV      R2,-(SP)      ;SAVE R2
7130      031206 010246 000200      MOV      #256./2.,R2      ;GENERATE 256 WORDS
7131      031214 000402      BR      2$
7132      031216 004737 023510      1$      JSR      PC,@#SRAND      ;GENERATE A RANDOM NUMBER
7133      031222 013721 023610      2$      MOV      @#SLONUM,(R1)+      ;PUT LOW WORD IN BUFFER
7134      031226 013721 023606      MOV      @#SHINUM,(R1)+      ;PUT HIGH WORD IN BUFFER
7135      031232 005302      DEC      R2      ;DONE?
7136      031234 003370      BGT      1$      ;NO--BRANCH
7137      031236 012602      MOV      (SP)+,R2      ;RESTORE R2
7138      031240 000200      RTS      RO      ;EXIT
7139
7140      ,THIS ROUTINE GENERATES RANDOM CYLINDER, TRACK, AND SECTOR
7141      ,ADDRESSES AND SAVES THEM IN THE DPB (DTADPB+10 AND DTADPB+12)
7142      ,NOTE. THIS ROUTINE DESTROYS R1-R3
7143      ,CALL
7144      ,      JSR      RO,@#RANADR
7145      ,      RETURN
7146
7147      RANADR. JSR      PC,@#SRAND      ;GENERATE A RANDOM NUMBER
7148      031242 004737 023510      MOV      @#SLONUM,R1      ;FORM SECTOR IN R1
7149      031246 113701 023610      MOV      @#SLONUM+1,R2      ;FORM TRACK IN R2
7150      031252 113702 023611      MOV      @#SHINUM,R3      ;FORM CYLINDER IN R3
7151      031256 013703 023606      TST      R1      ;ENSURE THE SECTOR IS BETWEEN 0 AND 21
7152      031262 105701      BLT      2$
7153      031264 002403      BLT      2$
7154      031266 123701 001630      1$      CMP      PRMLMT+22,R1      ;CHECK MAXIMUM SECTOR ADDRESS
7155      031272 103003      BHIS     3$
7156      031274 000241      CLC
7157      031276 106001      RORB     R1
7158      031300 000772      BR      1$
7159      031302 105702      3$      TST      R2      ;ENSURE THE TRACK IS BETWEEN 0 AND 18
7160      031304 002403      BLT      5$
7161      031306 122702 000023      4$      CMP      #19,R2
7162      031312 003003      BGT      6$
7163      031314 000241      CLC
7164      031316 106002      RORB     R2
7165      031320 000772      BR      4$
7166      031322 023703 001510      6$      CMP      @#FC,R3      ;ENSURE THE CYLINDER IS BETWEEN FC AND LC
7167      031326 003413      BLE      7$
7168      031330 000241      CLC
7169      031332 006003      ROR      R3
7170      031334 005503      ADC      R3
7171      031336 001371      BNE      6$
7172      031340 010103      MOV      R1,R3
7173      031342 000303      SWAB     R3
7174      031344 060203      ADD      R2,R3
7175      031346 005203      INC      R3
7176      031350 003364      BGT      6$
7177      031352 005403      NEG      R3
7178      031354 000762      BR      6$
7179      031356 023703 001512      7$      CMP      @#LC,R3
7180      031362 002003      BGE      8$
    
```

```

7180 031364 000241          CLC
7181 031366 006003          ROR      R3
7182 031370 000772          BR       7$
7183 031372 023703 001510    8$      CMP     @#FC,R3
7184 031376 003403          BLE     9$
7185 031400 005203          INC     R3
7186 031402 000303          SWAB   R3
7187 031404 000764          BR       7$
7188 031406 110137 004174    9$      MOVB   R1,@#DTADPB+10 ;SAVE SECTOR ADDRESS
7189 031412 110237 004175    MOVB   R2,@#DTADPB+11 ;SAVE TRACK ADDRESS
7190 031416 010337 004176    MOV     R3,@#DTADPB+12 ;SAVE CYLINDER ADDRESS
7191 031422 000200          RTS     RO ;RETURN
7192
7193          ; THIS ROUTINE IS USED TO INPUT THE "CONTROL SWITCHES".
7194          ; IF SWR<07>=1 THE PRESENT SETTING WILL BE TYPED AND THE NEW
7195          ; SETTING IS READ AND STORED.
7196          ; NOTE THIS ROUTINE DESTROYS R3 AND R4
7197          ; CALL
7198          ; JSR     PC,@#GETSWR
7199          ; RETURN ;(C.SWR)=DESIRED CONTROL SWITCHES
7200
7201 031424 032777 000200 147506 GETSWR BIT     #SW07,@SWR ;READ CONTROL SWITCHES?
7202 031432 001430          BEQ     2$ ;NO--BRANCH
7203 031434 104401 031442          TYPE   .65$ ;TYPE ASCIZ STRING
7204 031440 000410          BR     64$ ;GET OVER THE ASCIZ
7205          ;.65$  ASCIZ <CR><LF>/SET SWR<07>=0/
7206 031462          64$.
7207 031462 012703 043050    1$      MOV     #MSG CS,R3 ;"CONTROL SWITCHES="
7208 031466 013704 001220    MOV     @#C SWR,R4 ;PRESENT CONTROL SWITCH SETTINGS
7209 031472 004037 031516    JSR     RO,@#GETNUM ;GET THE NEW SWITCH SETTINGS
7210 031476 000771          BR     1$ ;COMMA
7211 031500 000240          NOP     ;PERIOD
7212 031502 013737 001220 001222    MOV     C SWR,SAVCSW ;SAVE PREVIOUS VALUE
7213 031510 010437 001220    MOV     R4,@#C SWR ;DOUBLE PERIOD-SAVE NEW SWITCH SETTING
7214 031514 000207          2$      RTS     PC ;RETURN FROM CALL
7215
7216          ; THIS ROUTINE WILL TYPE AN ASCIZ MESSAGE AND THEN
7217          ; INPUT AN ASCIZ STRING AND CHANGE THE STRING TO OCTAL
7218          ; IF REQUIRED
7219          ; NOTE THIS ROUTINE DESTROYS R1
7220          ; CALL
7221          ; MOV     #ADR,R3 ;ADDRESS OF ASCIZ MESSAGE
7222          ; MOV     #NUM,R4 ;OCTAL NUMBER
7223          ; JSR     RO,@#GETNUM
7224          ; RETURN1 ;INPUT TERMINATED WITH A COMMA
7225          ; RETURN2 ;WITH A PERIOD
7226          ; RETURN3 ;WITH A DOUBLE PERIOD
7227          ; ;R4=INPUT NUMBER AND
7228          ; ;R2=R4*32 FOR ALL
7229          ; ;THREE RETURNS
7230
7231 031516 010337 031524    GETNUM MOV     R3,2$ ;SAVE MESSAGE POINTER
7232 031522 104401          1$      TYPE   ;TYPE THE MESSAGE
7233 031524 000000          2$.     WORD  0 ;MESSAGE POINTER GOES HERE
7234 031526 010446          MOV     R4,-(SP) ;SAVE R4 FOR TYPEOUT
7235 031530 104402          TYPOC ;GO TYPE--OCTAL ASCII(ALL DIGITS)
    
```

```

7236 031532 104401 043074          TYPE      , SLASH          , ' / '
7237 031536 104411          RDLIN          ; READ AN ASCIZ STRING
7238 031540 012601          MOV          (SP)+, R1      ; ADDRESS OF FIRST CHARACTER
7239 031542 004037 033766          JSR          RO, @#CK CHR   ; CHECK ONE CHARACTER
7240 031546 031522          1$          ; ILLEGAL CHARACTER
7241 031550 031522          1$          ; CARRIAGE RETURN
7242 031552 031564          3$          ; "/"
7243 031554 031610          7$          ; "."
7244 031556 031616          8$          ; " "
7245 031560 031562          11$         ; DIGIT 0-9
7246 031562 005301          11$         DEC          R1          ; DECREMENT THE INPUT POINTER
7247 031564          3$
7248 031564 004037 034226          JSR          RO, @#CK NUM   ; CHECK THE NUMBER
7249 031570 031522          1$          ; ILLEGAL INPUT
7250 031572 031604          6$          ; TERMINATED WITH A ", " OR "CR"
7251 031574 031602          5$          ; TERMINATED WITH A " "
7252 031576 031600          4$          ; TERMINATED WITH A " ."
7253 031600 005720          4$          TST          (RO)+      ; DOUBLE PERIOD
7254 031602 005720          5$          TST          (RO)+      ; SINGLE PERIOD
7255 031604 010204          6$          MOV          R2, R4        ; COMMA--SAVE INPUT NUMBER
7256 031606 000414          BR          10$         ; GO TO EXIT
7257 031610 105711          7$          TSTB         (R1)        ; TERMINATOR AFTER A COMMA?
7258 031612 001343          BNE         1$          ; NO--LOOP
7259 031614 000411          BR          10$         ; YES--EXIT
7260 031616 105711          8$          TSTB         (R1)        ; TERMINATOR AFTER A PERIOD?
7261 031620 001406          BEQ         9$          ; YES--EXIT
7262 031622 122721 000J56          CMPB        #' , (R1)+    ; NO--DOUBLE PERIOD?
7263 031626 001335          BNE         1$          ; NO--LOOP
7264 031630 105711          TSTB         (R1)        ; YES--TERMINATOR?
7265 031632 001333          BNE         1$          ; NO--LOOP
7266 031634 005720          TST          (RO)+      ; DOUBLE PERIOD
7267 031636 005720          9$          TST          (RO)+      ; PERIOD
7268 031640 010402          10$         MOV          R4, R2        ; COMMA--POSITION THE
7269 031642 000302          SWAB        R2          ; NUMBER IN CASE IT
7270 031644 006202          ASR         R2          ; IS THE PRIORITY LEVEL
7271 031646 006202          ASR         R2
7272 031650 006202          ASR         R2
7273 031652 000200          RTS         RO          ; EXIT
7274
7275          ; THIS ROUTINE IS USED TO CHANGE OR MODIFY
7276          ; THE TEST PARAMETERS IT GIVES THE OPERATOR
7277          ; THE CAPABILITY OF SPECIFYING WHICH DRIVES TO TEST, WHICH
7278          ; TESTS TO RUN AND HOW MANY TIMES TO
7279          ; REPEAT EACH TEST
7280
7281 031654 104412          GT PRM     SAVREG        ; SAVE R0 - R5
7282 031656 005037 001232          GT PR1    CLR           DRVSEL ; NO DRIVE SELECTED
7283 031662 104401 031670          TYPE     , 65$         ; TYPE ASCIZ STRING
7284 031666 000406          BR        64$         ; GET OVER THE ASCIZ
7285          ; 65$ . ASCIZ <CR><LF>/DRIVE(S)=/
7286          64$
7287 031704          RDLIN          ; READ TTY
7288 031706 012601          MOV          (SP)+, R1      ; ADDRESS OF ASCIZ STRING
7289 031710 004037 033766          JSR          RO, @#CK CHR   ; CHECK ONE CHARACTER
7290 031714 031656          GT PR1          ; ILLEGAL CHARACTER
7291 031716 031656          GT PR1          ; CARRIAGE RETURN
    
```

```

7292 031720 031656          GT PR1          ;"/"
7293 031722 031656          GT PR1          ;"/"
7294 031724 031656          GT PR1          ;"/"
7295 031726 031730          1$              ;DIGIT 0-9
7296 031730 005301          1$              DEC          R1
7297 031732          2$
7298 031732 012702 000007    MOV          #7,R2      ;UPPER LIMIT OF INPUT
7299 031736 004037 034042    JSR          RO,@#CK DIG ;CHECK THE DIGIT(S)
7300 031742 031656          GT PR1          ;ILLEGAL INPUT
7301 031744 031656          GT PR1          ;INPUT TO LARGE
7302 031746 031754          3$              ;TERMINATED WITH A "," OR "CR"
7303 031750 032000          4$              ;TERMINATED WITH A " "
7304 031752 032000          4$              ;TERMINATED WITH A " "
7305 031754 156237 034502 001232 3$    BISB        ATABIT(R2),DRVSEL ;SET THE DRIVE SELECTED BIT
7306 031762 105741          TSTB        -(R1)      ;WAS THE LINE TERMINATED?
7307 031764 001362          BNE         2$        ;NO-GET THE NEXT DRIVE
7308 031766 005037 001234    CLR         @#TSTNMS   ;DESELECT ALL TESTS
7309 031772 005037 001236    CLR         TSTNMS+2
7310 031776 000405          BR          GTTST1    ;YES--SELECT TEST
7311 032000 156237 034502 001232 4$    BISB        ATABIT(R2),DRVSEL ;SET THE SELECTED DRIVE BITS
7312 032006 104413          GT PR2        RESREG
7313 032010 000207          RTS         PC        ;EXIT
7314
7315 032012          GTTST1
7316 032012 104401 032020    TYPE        ,65$     ;TYPE ASCIZ STRING
7317 032016 000403          BR          64$     ;GET OVER THE ASCIZ
7318          ;,65$
7319 032026          64$
7320 032026 104411          RDLIN
7321 032030 012601          MOV         (SP)+,R1  ;READ AN ASCIZ STRING
7322 032032 122711 000056    CMPB        #' ,(R1)  ;POINTER TO R1
7323 032036 001007          BNE         1$        ;DOUBLE PERIOD?
7324 032040 122761 000056 000001    CMPB        #' ,1(R1) ;NO--BRANCH
7325 032046 001003          BNE         1$
7326 032050 105761 000002    TSTB        2(R1)    ;"CR"?
7327 032054 001754          BEQ         GT PR2   ;YES--EXIT
7328 032056 005037 001234    CLR         TSTNMS   ;NO TEST SELECTED
7329 032062 005037 001236    CLR         TSTNMS+2
7330 032066 005037 001240    CLR         OPNFLG   ;NO TESTS TO BE OPENED
7331 032072 005037 001242    CLR         OPNFLG+2
7332 032076 121127 000123    GTTST2     CMPB        (R1),#'S  ;ALL SEEK TESTS?
7333 032102 001004          BNE         1$        ;NO--BRANCH
7334 032104 052737 000777 001234    BIS         #777,TSTNMS ;YES--SELECT TESTS 0-10
7335 032112 000552          BR          GTTST3
7336 032114 121127 000124    1$         CMPB        (R1),#'T  ;ALL TIMING TESTS?
7337 032120 001004          BNE         2$        ;NO--BRANCH
7338 032122 052737 036000 001234    BIS         #36000,TSTNMS ;YES--SELECT TESTS 12-15
7339 032130 000543          BR          GTTST3
7340 032132 121127 000101    2$         CMPB        (R1),#'A  ;ALL ADDRESSING TESTS?
7341 032136 001004          BNE         3$        ;NO--BRANCH
7342 032140 052737 140000 001234    BIS         #140000,TSTNMS ;YES--SELECT TESTS 16 & 17
7343 032146 000534          BR          GTTST3
7344 032150 121127 000104    3$         CMPB        (R1),#'D  ;DATA TEST?
7345 032154 001004          BNE         4$        ;NO--BRANCH
7346 032156 052737 000001 001236    BIS         #1,TSTNMS+2 ;YES--SELECT TEST 20
7347 032164 000525          BR          GTTST3
    
```

7348	032166	121127	000105		45	CMPB	(R1), #'E	, EXERCISER TEST?
7349	032172	001004				BNE	55	, NO--BRANCH
7350	032174	052737	000002	001236		BIS	#2, TSTNMS+2	, YES--SELECT TEST 21
7351	032202	000516				BR	GTTST3	
7352	032204	004037	033712		55	JSR	RO, @#CK OCT	, OCTAL DIGIT?
7353	032210	000514				BR	GTTST4	, NO--BRANCH
7354	032212	010205				MOV	R2, R5	, YES--SAVE IT
7355	032214	005201				INC	R1	, MOVE TO NEXT CHARACTER
7356	032216	004037	033712			JSR	RO, @#CK OCT	, OCTAL DIGIT
7357	032222	000405				BR	65	, NO--BRANCH
7358	032224	005201				INC	R1	, MOVE TO NEXT CHARACTER
7359	032226	006305				ASL	R5	, SCALE HIGH DIGIT
7360	032230	006305				ASL	R5	
7361	032232	006305				ASL	R5	
7362	032234	060502				ADD	R5, R2	, COMBINE HIGH & LOW DIGITS
7363	032236	020227	000022		65	CMP	R2, #5TN-1	, VALID TEST NUMBER?
7364	032242	003263				BGT	GTTST1	, NO--BRANCH
7365	032244	010237	032436			MOV	R2, 95	, SAVE THE TEST NUMBER
7366	032250	010204				MOV	R2, R4	, CONVERT TEST NUMBER INTO AN INDEX
7367	032252	042704	000017			BIC	#17, R4	, CLEAR UNWANTED BITS
7368	032256	006204				ASR	R4	, SHIFT THE BITS
7369	032260	006204				ASR	R4	, SHIFT THE BITS
7370	032262	006204				ASR	R4	, SHIFT THE BITS
7371	032264	006302				ASL	R2	
7372	032266	056264	001424	001234		BIS	BITS(R2), TSTNMS(R4)	, SELECT TEST
7373	032274	121127	000055			CMPB	(R1), #'-	, TEST STRING?
7374	032300	001060				BNE	GTTST4	, NO--BRANCH
7375	032302	005201				INC	R1	, YES--MOVE TO NEXT CHARACTER
7376	032304	004037	033712			JSR	RO, @#CK. OCT	, OCTAL DIGIT?
7377	032310	000640				BR	GTTST1	, NO--BRANCH
7378	032312	010205				MOV	R2, R5	, YES--SAVE IT
7379	032314	005201				INC	R1	, MOVE TO NEXT CHARACTER
7380	032316	004037	033712			JSR	RO, @#CK OCT	, OCTAL DIGIT?
7381	032322	000405				BR	75	, NO--BRANCH
7382	032324	005201				INC	R1	, YES--MOVE TO NEXT CHARACTER
7383	032326	006305				ASL	R5	, SCALE HIGH DIGIT
7384	032330	006305				ASL	R5	
7385	032332	006305				ASL	R5	
7386	032334	060502				ADD	R5, R2	, COMBINE HIGH & LOW DIGIT
7387	032336	020227	000022		75	CMP	R2, #5TN-1	, VALID TEST NUMBER?
7388	032342	003223				BGT	GTTST1	, NO--BRANCH
7389	032344	023702	032436			CMP	95, R2	, IS THE FIRST NUMBER OF THE
7390								, STRING SMALLER THAN THE LAST?
7391	032350	002220				BGE	GTTST1	, NO--BRANCH
7392	032352	010246				MOV	R2, -(SP)	, SAVE ENDING TEST NUMBER
7393	032354	013702	032436			MOV	95, R2	, GET STARTING TEST NUMBER
7394	032360	012637	032436			MOV	(SP)+, 95	, STORE ENDING TEST NUMBER
7395	032364	006337	032436			ASL	95	, SHIFT ENDING TEST NUMBER
7396	032370	006302				ASL	R2	, SHIFT TEST NUMBER
7397	032372	010204			85	MOV	R2, R4	, COPY TEST NUMBER INTO R4
7398	032374	042704	000037			BIC	#37, R4	, CLEAR LOWER BITS
7399	032400	006204				ASR	R4	, SHIFT THE TEST NUMBER
7400	032402	006204				ASR	R4	, SHIFT THE TEST NUMBER
7401	032404	006204				ASR	R4	, SHIFT THE TEST NUMBER
7402	032406	006204				ASR	R4	, SHIFT THE TEST NUMBER
7403	032410	056264	001424	001234		BIS	BITS(R2), TSTNMS(R4)	, SELECT THE TEST

7404	032416	062702	000002		ADD	#2,R2	, INCREMENT THE TEST NUMBER
7405	032422	020237	032436		CMP	R2,9\$	, SEE IF FINISHED
7406	032426	101761			BLOS	8\$	, BR IF NOT
7407	032430	162702	000002		SUB	#2,R2	, CORRECT TEST NUMBER
7408	032434	000402			BR	GTTST4	, CONTINUE
7409	032436	000000		9\$	WORD	0	, STORE TEST NUMBER HERE
7410	032440	005201		GTTST3	INC	R1	, MOVE TO NEXT CHARACTER
7411	032442	121127	000056	GTTST4	CMPB	(R1),#'	, "PERIOD"?
7412	032446	001441			BEQ	GTTST5	, YES--BRANCH
7413	032450	005737	001234		TST	TSTNMS	, ANY TEST SELECTED THIS CYCLE?
7414	032454	0C1005			BNE	1\$	, BR IF YES
7415	032456	005737	001236		TST	TSTNMS+2	, ANY TEST SELECTED THIS CYCLE ?
7416	032462	001002			BNE	1\$	, BR IF YES
7417	032464	000137	032012		JMP	GTTST1	, NO
7418	032470	121127	000057	1\$	CMPB	(R1),#'	, "OPEN"?
7419	032474	001004			BNE	2\$	, NO--BRANCH
7420	032476	056264	001424	001240	BIS	BITS(R2), OPNFLG(R4)	, YES--SET BITS FOR TEST TO OPEN
7421	032504	000405			BR	3\$	
7422	032506	121127	000054	2\$	CMPB	(P1),#'	, "COMMA"?
7423	032512	001402			BEQ	3\$	, BR IF YES
7424	032514	000137	032012		JMP	GTTST1	, NO
7425	032520	005201		3\$	INC	R1	, MOVE TO NEXT CHARACTER
7426	032522	105711			TSTB	(R1)	, "CR"?
7427	032524	001402			BEQ	4\$	, BR IF 'CR'
7428	032526	000137	032076		JMP	GTTST2	, NO--GO GET NEXT CHARACTER
7429	032532	005737	001240	4\$	TST	OPNFLG	, ANY TESTS TO OPEN ?
7430	032536	001C42			BNE	OPNTST	, BR IF YES
7431	032540	005737	001242		TST	OPNFLG+2	, ANY TESTS TO OPEN ?
7432	032544	001037			BNE	OPNTST	, BR IF YES
7433	032546	000137	032012		JMP	GTTST1	, NO--START AGAIN
7434	032552	005201		GTTST5	INC	R1	, MOVE TO NEXT CHARACTER
7435	032554	121127	000056		CMPB	(R1),#'	, "PERIOD"?
7436	032560	001414			BEQ	GTTST6	, YES--BRANCH
7437	032562	105711			TSTB	(R1)	, "CR"?
7438	032564	001402			BEQ	1\$	, YES--BRANCH
7439	032566	000137	032012		JMP	GTTST1	
7440	032572	005737	001240	1\$	TST	OPNFLG	, ANY TESTS TO OPEN ?
7441	032576	001022			BNE	OPNTST	, BR IF YES
7442	032600	005737	001242		TST	OPNFLG+2	, ANY TESTS TO OPEN ?
7443	032604	001017			BNE	OPNTST	, BR IF YES
7444	032606	000137	032006		JMP	GT PR2	, NO--GO START TESTING
7445	032612	005201		GTTST6	INC	R1	, MOVE TO NEXT CHARACTER
7446	032614	105711			TSTB	(R1)	, "CR"?
7447	032616	001402			BEQ	1\$	, YES--BRANCH
7448	032620	000137	032012		JMP	GTTST1	, NO--GO ASK FOR TEST
7449	032624	005737	001240	1\$	TST	OPNFLG	, ANY TESTS TO OPEN ?
7450	032630	001005			BNE	OPNTST	, BR IF YES
7451	032632	005737	001242		TST	OPNFLG+2	, ANY TESTS TO OPEN ?
7452	032636	001002			BNE	OPNTST	, BR IF YES
7453	032640	000137	032006		JMP	GT. PR2	, NO--GO START TESTING
7454							
7455							, OPEN THE SELECTED TEST FOR CHANGES
7456							
7457	032644	104412			OPNTST	SAVREG	, SAVE R0 - R5
7458	032646	005027			CLR	(PC)+	, START WITH TEST 0
7459	032650	000000			OPN CT	WORD 0	, COUNT STORED HERE

7460	032652	000411			BR	OPN 2	;SKIP THE INCREMENT
7461	032654	005237	032650		INC	OPN CT	;MOVE TO THE NEXT TEST
7462	032660	022737	000022	032650	CMP	#STN-1,OPN CT	;TEST NUMBER TOO BIG?
7463	032666	002003			BGE	OPN 2	;NO--OPEN THE NEXT TEST
7464	032670	104413			RESREG		;RESTORE R0 - R5
7465	032672	000137	032012		JMP	GTTST1	;YES--GO ASK FOR MORE TESTS
7466	032676	013705	032650		OPN 2	MOV	OPN.CT,R5
7467	032702	006305			ASL	R5	;TEST NUMBER AS AN INDEX
7468	032704	013703	032650		MOV	OPN CT,R3	;GET INDEX
7469	032710	042703	000017		BIC	#17,R3	;CLEAR LOWER TEST BITS
7470	032714	006203			ASR	R3	;SHIFT TEST NUMBER
7471	032716	006203			ASR	R3	;SHIFT TEST NUMBER
7472	032720	006203			ASR	R3	;SHIFT TEST NUMBER
7473	032722	036563	001424	001240	BIT	BITS(R5),OPNFLG(R3)	;OPEN THIS TEST?
7474	032730	001751			BEQ	OPN 1	;NO--MOVE TO NEXT TEST
7475	032732	104401	032740		TYPE	,65\$	..TYPE ASCIZ STRING
7476	032736	000404			BR	64\$	..GET OVER THE ASCIZ
7477						ASCIZ	/ TEST /
7478	032750					64\$	
7479	032750	013746	032650		MOV	OPN CT,-(SP)	..SAVE OPN.CT FOR TYPEOUT
7480							..TEST NUMBER
7481	032754	104403			TYPOS		..GO TYPE--OCTAL ASCII
7482	032756	002			BYTE	2	..TYPE 2 DIGIT(S)
7483	032757	000			BYTE	0	..SUPPRESS LEADING ZEROS
7484	032760	104401	001215		TYPE	,\$CRLF	..TYPE "CR" & "LF"
7485	032764	016500	001536		MOV	PRMPT(R5),R0	..PICKUP PARAMETER POINTER
7486	032770	011046			MOV	(R0),-(SP)	..SAVE THE VARIABLE INDICATOR
7487	032772	012702	001504		MOV	#PRM,R2	..FIRST ADDRESS OF TABLE
7488	032776	000405			BR	2\$	
7489	033000	006216			ASR	(SP)	..CHECK FOR A VARIABLE
7490	033002	103403			BCS	2\$	..GO MOVE THIS ONE
7491	033004	001404			BEQ	OPNPRM	..DONE
7492	033006	005722			TST	(R2)+	..BUMP THE POINTER
7493	033010	000773			BR	1\$	
7494	033012	012022			MOV	(R0)+,(R2)+	..MOVE THIS VARIABLE INTO THE
7495	033014	000771			BR	1\$	..COMMON AREA
7496	033016	013716	001504		OPNPRM	MOV	@#PRM,(SP)
7497	033022	005004			CLR	R4	..ZERO THE INDEX
7498	033024	006216			ASR	(SP)	..CHECK FOR A VARIABLE
7499	033026	103403			BCS	3\$	..GO GET IT
7500	033030	001772			BEQ	OPNPRM	..OUT OF VARIABLES
7501	033032	005724			2\$	TST	(R4)+
7502	033034	000773			BR	1\$	..UPDATE THE INDEX
7503	033036	005764	001606		3\$	TST	PRMLMT(R4)
7504	033042	100466			BMI	OPNPAT	..IS THE MAX MAGNITUDE NEG?
7505	033044	104401	044040		TYPE	,MSG SP	..YES--THEN IT IS THE PATTEON
7506	033050	016437	001636	033060	MOV	PRMMSG(R4),4\$	..TYPE SPACES
7507	033056	104401			TYPE		..TYPE THE NAME OF THIS VARIABLE
7508	033060	000000			4\$	WORD	0
7509	033062	104401	043046		TYPE	,MSG EQ	..TYPE "="
7510	033066	016446	001506		MOV	RPT(R4),-(SP)	..PUT RPT(R4) ON THE STACK
7511	033072	004737	023220		JSR	PC,@#SSB2D	..CHANGE RPT(R4) TO DECIMAL ASCIZ
7512	033076	004737	023450		JSR	PC,@#SSUPRS	..TYPE WITHOUT LEADING ZEROS
7513	033102	104401	043074		TYPE	,SLASH	.. /
7514	033106	104411			RDL IN		
7515	033110	012601			MOV	(SP)+,R1	..READ AN ASCIZ STRING

7516	033112	004037	033766		JSR	RO, @#CK CHR	; CHECK ONE CHARACTER
7517	033116	033036			3\$		; ILLEGAL CHARACTER
7518	033120	033032			2\$		; CARRIAGE RETURN
7519	033122	033170			8\$		; "/"
7520	033124	033132			5\$		; "."
7521	033126	033140			6\$		; " "
7522	033130	033166			7\$		; DIGIT 0-9
7523	033132	105711		5\$	TSTB	(R1)	; "CR"?
7524	033134	001340			BNE	3\$	; NO--STAY ON THIS VARIABLE
7525	033136	000735			BR	2\$	; YES--MOVE TO NEXT VARIABLE
7526	033140	105711		6\$	TSTB	(R1)	; IS THERE A "CR" AFTER THE PERIOD?
7527	033142	001002			BNE	64\$	; NO
7528	033144	000137	033560		JMP	OPN N2	; YES--GO CLOSE THIS TEST
7529	033150	122721	000056	64\$	CMPB	#', (R1)+	; DOUBLE PERIOD?
7530	033154	001330			BNE	3\$	; NO--GO ASK FOR THIS VARIABLE
7531	033156	105711			TSTB	(R1)	; YES--IS A "CR" AFTER THE DOUBLE PERIOD?
7532	033160	001326			BNE	3\$	; NO--ASK FOR THIS VARIABLE AGAIN
7533	033162	000137	033576		JMP	OPN X2	; YES--CLOSE ALL TEST
7534	033166	005301		7\$	DEC	R1	; BACK THE POINTER UP BY ONE
7535	033170			8\$			
7536	033170	016402	001606		MOV	PRMLT(R4), R2	; UPPER LIMIT OF INPUT
7537	033174	004037	034042		JSR	RO, @#CK DIG	; CHECK THE DIGIT(S)
7538	033200	033036			3\$		; ILLEGAL INPUT
7539	033202	033036			3\$		; INPUT TOO LARGE
7540	033204	033212			9\$		; TERMINATED WITH A ", " OR "CR"
7541	033206	033554			OPN N1		; TERMINATED WITH A " "
7542	033210	033572			OPN X1		; TERMINATED WITH A " "
7543	033212	010264	001506	9\$	MOV	R2, RPT(R4)	; SAVE THIS VARIABLE
7544	033216	000705			BR	2\$	; MOVE TO NEXT VARIABLE
7545	033220	104401	044040	OPNPAT	TYPE	, MSG SP	; TYPE SPACES
7546	033224	104401	043042		TYPE	, MSG PAT	; TYPE "PAT"
7547	033230	104401	043046		TYPE	, MSG EQ	; TYPE "="
7548	033234	016446	001506		MOV	RPT(R4), -(SP)	; SAVE RPT(R4) FOR TYPEOUT
7549	033240	104402			TYPOC		; GO TYPE--OCTAL ASCII(ALL DIGITS)
7550	033242	104401	044041		TYPE	, MSG SP+1	; TYPE ONE SPACE
7551	033246	104411			RDLIN		; READ ASCII STRING
7552	033250	012601			MOV	(SP)+, R1	; PICKUP POINTER
7553	033252	004037	033766		JSR	RO, @#CK CHR	; CHECK ONE CHARACTER
7554	033256	033220			OPNPAT		; ILLEGAL CHARACTER
7555	033260	033016			OPNPRM		; CARRIAGE RETURN
7556	033262	033314			3\$		; "/"
7557	033264	033016			OPNPRM		; "."
7558	033266	033272			1\$		; " "
7559	033270	033312			2\$		; DIGIT 0-9
7560	033272	105711		1\$	TSTB	(R1)	; "CR" AFTER THE PERIOD?
7561	033274	001531			BEQ	OPN N2	; YES--GO CLOSE THIS TEST
7562	033276	122721	000056		CMPB	#', (R1)+	; NO--PERIOD?
7563	033302	001346			BNE	OPNPAT	; NO--LOOP
7564	033304	105711			TSTB	(R1)	; "CR" AFTER A DOUBLE PERIOD?
7565	033306	001533			BEQ	OPN X2	; YES--GO START TESTING
7566	033310	000743			BR	OPNPAT	; NO--LOOP
7567	033312	005301		2\$	DEC	R1	; BACKUP THE ASCII POINTER
7568	033314			3\$			
7569	033314	004037	034226		JSR	RO, @#CK NUM	; CHECK THE NUMBER
7570	033320	033220			OPNPAT		; ILLEGAL INPUT
7571	033322	033330			4\$		; TERMINATED WITH A ", " OR "CR"

7572	033324	033554			OPN N1		; TERMINATED WITH A " "
7573	033326	033572			OPN X1		; TERMINATED WITH A " "
7574	033330	010264	001506	45	MOV R2,RPT(R4)		; SAVE THE INPUT NUMBER
7575	033334	006002			ROR R2		; OPEN PATTERN 0?
7576	033336	103227			BCC OPNPRM		; NO--START AT BEGINNING OF PARAMETER TABLE
7577	033340	104412			SAVREG		; SAVE R0 - R5
7578	033342	005000			OPNWDS. CLR RO		; START WITH WORD 0
7579	033344	012704	003104		MOV #PATO,R4		
7580	033350			15			
7581	033350	104401	033356		TYPE ,655		; TYPE ASCIZ STRING
7582	033354	000403			BR 645		; GET OVER THE ASCIZ
7583					,,655 .ASCIZ / WD/		
7584	033364			645			
7585	033364	010046			MOV RO,-(SP)		; PUT RO ON THE STACK
7586	033366	004737	023220		JSR PC,@#5SB2D		; CHANGE RO TO DECIMAL ASCIZ
7587	033372	004737	023450		JSR PC,@#5SUPRS		; TYPE WITHOUT LEADING ZEROS
7588	033376	104401	043046		TYPE ,MSG EQ		; TYPE "="
7589	033402	011446			MOV (R4),-(SP)		; SAVE (R4) FOR TYPEOUT
7590	033404	104402			TYPOC		; GO TYPE--OCTAL ASCII(ALL DIGITS)
7591	033406	104411			RDLIN		; READ ASCIZ STRING
7592	033410	012601			MOV (SP)+,R1		; PICKUP THE POINTER
7593	033412	004037	033766		JSR RO,@#CK CHR		; CHECK ONE CHARACTER
7594	033416	033350			15		; ILLEGAL CHARACTER
7595	033420	033452			45		; CARRIAGE RETURN
7596	033422	033434			25		; "/"
7597	033424	033452			45		; " "
7598	033426	033466			55		; " "
7599	033430	033432			105		; DIGIT 0-9
7600	033432	005301		105	DEC R1		; BACKUP THE ASCII POINTER
7601	033434			25			
7602	033434	004037	034226		JSR RO,@#CK NUM		; CHECK THE NUMBER
7603	033440	033350			15		; ILLEGAL INPUT
7604	033442	033450			35		; TERMINATED WITH A ", " OR "CR"
7605	033444	033506			65		; TERMINATED WITH A " "
7606	033446	033520			85		; TERMINATED WITH A " "
7607	033450	010214		35	MOV R2,(R4)		; SAVE THE INPUT
7608	033452	005724		45	TST (R4)+		; MOVE TO NEXT WORD
7609	033454	005200			INC RO		; INCREMENT THE COUNT
7610	033456	022700	000020		CMP #16,RO		; COUNT TO LARGE?
7611	033462	003332			BGT 15		; NO--BRANCH
7612	033464	000726			BR OPNWDS		; YES--BRANCH
7613	033466	105711		55	TSTB (R1)		; "CR" AFTER THE PERIOD?
7614	033470	001407			BEQ 75		; YES--GO CLOSE THIS TEST
7615	033472	122721	000056		CMPB #' ,(R1)+		; NO--PERIOD?
7616	033476	001324			BNE 15		; NO--BRANCH ILLEGAL INPUT STRING
7617	033500	105711			TSTB (R1)		; "CR" AFTER THE "PERIOD-PERIOD"?
7618	033502	001407			BEQ 95		; YES--GO START TESTING
7619	033504	000721			BR 15		; NO--LOOP
7620	033506	010224		65	MOV R2,(R4)+		; SAVE THE INPUT
7621	033510	004737	033532	75	JSR PC,@#CLSWDS		; CLOSE THE DATA PATTERN
7622	033514	104413			RESREG		; RESTORE R0 - R5
7623	033516	000420			BR OPN N2		; MOVE TO NEXT TEST
7624	033520	010224		85	MOV R2,(R4)+		; SAVE THE INPUT
7625	033522	004737	033532	95	JSR PC,@#CLSWDS		; CLOSE THE DATA PATTERN
7626	033526	104413			RESREG		; RESTORE R0 - R5
7627	033530	000422			BR OPN X2		; START TESTING

```

7628 033532 012701 003104      CLSWDS: MOV      #PATO,R1      ;FIRST ADDRESS OF DATA PATTERN
7629 033536 005200              1$      INC      RO              ;COUNT THE LAST WORD THAT WAS STORED
7630 033540 022700 000017      CMP      #15.,RO          ;END OF TABLE
7631 033544 002402              BLT      2$              ;YES--EXIT
7632 033546 012124              MOV      (R1)+,(R4)+      ;COPY
7633 033550 000772              BR       1$              ;LOOP
7634 033552 000207              2$      RTS      PC              ;RETURN
7635 033554 010264 001506      OPN N1  MOV      R2,RPT(R4)  ;SAVE THIS VARIABLE
7636 033560 005726      OPN N2  TST      (SP)+      ;CLEAN OFF THE STACK
7637 033562 004737 033632      JSR      PC,CLOSE        ;CLOSE THIS TEST
7638 033566 000137 032654      JMP      OPN 1           ;GO OPEN THE NEXT TEST
7639 033572 010264 001506      OPN X1  MOV      R2,RPT(R4)  ;SAVE THIS VARIABLE
7640 033576 005726      OPN X2  TST      (SP)+      ;CLEAN OFF THE STACK
7641 033600 004737 033632      1$      JSR      PC,CLOSE        ;CLOSE THIS TEST
7642 033604 005725              2$      TST      (R5)+          ;UPDATE THE INDEX
7643 033606 020527 000034      CMP      R5,#16*2        ;INDEX TO BIG?
7644 033612 002403              BLT      3$              ;NO--BRANCH
7645 033614 104413              RESREG                      ;RESTORE RO - R5
7646 033616 000137 032006      JMP      GT PR2          ;GO TO EXIT
7647 033622 036503 001424      3$      BIT      BITS(R5),R3     ;IS THIS TEST OPEN FOR CHANGE?
7648 033626 001364              BNE     1$              ;YES--GO CLOSE IT
7649 033630 000765              BR       2$              ;NO--MOVE TO NEXT TEST
7650 033632 104412      CLOSE  SAVREG          ;SAVE RO - R5
7651 033634 012700 001504      MOV      #PRM,RO         ;"FROM" ADDRESS
7652 033640 016501 001536      MOV      PRMPT(R5),R1    ;"TO" ADDRESS
7653 033644 012002      MOV      (RO)+,R2        ;"FROM" INDICATOR
7654 033646 012103      MOV      (R1)+,R3        ;"TO" INDICATOR
7655 033650 012704 000001      MOV      #1,R4          ;TEST BIT START A "RPT"
7656 033654 030402              1$      BIT      R4,R2          ;PARAMETER TO BE MOVED?
7657 033656 001403              BEQ     2$              ;NO--BRANCH
7658 033660 030403              BIT      R4,R3          ;A PLACE TO PUT IT?
7659 033662 001404              BEQ     3$              ;NO--BRANCH
7660 033664 011011      MOV      (RO),(R1)       ;YES--MOVE "FROM" TO "TO"
7661 033666 030403              2$      BIT      R4,R3          ;"TO" PARAMETER?
7662 033670 001401              BEQ     3$              ;NO--BRANCH
7663 033672 005721              TST      (R1)+          ;YES--UPDATE THE POINTER
7664 033674 005720              3$      TST      (RO)+          ;UPDATE FROM POINTER
7665 033676 006304              ASL     R4              ;POSITION THE TEST BIT
7666 033700 032704 002000      BIT      #BIT10,R4       ;DONE?
7667 033704 001763              BEQ     1$              ;NO--BRANCH
7668 033706 104413              RESREG                      ;RESTORE RO - R5
7669 033710 000207      RTS      PC              ;RETURN
7670                          ; THIS ROUTINE IS USED TO CHECK IF AN
7671                          ; ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7
7672                          ; CALL
7673                          ;      MOV      #ADR,R1      ; ADDRESS OF ASCII CHARACTER
7674                          ;      JSR      RD,#CK OCT  ; CHECK THE CHARACTER
7675                          ;      RETURN1   ; CHARACTER IS NOT BETWEEN 0-7
7676                          ;      RETURN2   ; CHARACTER IS IN R2 AS A
7677                          ;      ;      ; OCTAL DIGIT
7678
7679 033712 121127 000060      CK OCT  CMPB     (R1),#'0    ; LESS THAN ZERO?
7680 033716 103407              BLO     1$              ; YES -- BRANCH
7681 033720 121127 000067      CMPB     (R1),#'7        ; GREATER THAN SEVEN?
7682 033724 101004              BHI     1$              ; YES -- BRANCH
7683 033726 111102              MOVB    (R1),R2          ; GET THE CHARACTER
    
```

```

7684 033730 042702 177770          BIC      # (7,R2      ,STRIP AWAY THE ASCII
7685 033734 005720          TST      (R0)+       ;ADJUST FOR RETURN
7686 033736 000200          1$      RTS      RO      ;RETURN
7687
7688          ,THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
7689          ,AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
7690          ,CALL
7691          ,      MOV      #ADR,R1      ,ADDRESS OF ASCII CHARACTER
7692          ,      JSR      RO,@#CK DEC ;CHECK THE CHARACTER
7693          ,      RETURN1 ;NOT BETWEEN 0 AND 9
7694          ,      RETURN2 ;BETWEEN 0 AND 9
7695          ,      ;R2 = DIGIT
7696
7697 033740 121127 000060          CK DEC  CMPB      (R1),#'0      ;LESS THAN ZERO?
7698 033744 103407          BLO      1$          ;YES -- BRANCH
7699 033746 121127 000071          CMPB      (R1),#'9      ;GREATER THAN NINE?
7700 033752 101004          BHI      1$          ;YES -- BRANCH
7701 033754 111102          MOVB      (R1),R2      ,GET THE CHARACTER
7702 033756 042702 000060          BIC      #'0,R2      ,STRIP AWAY THE ASCII
7703 033762 005720          TST      (R0)+       ;ADJUST FOR RETURN
7704 033764 000200          1$      RTS      RO      ;RETURN
7705
7706          ,THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
7707          ,DETERMINE WHAT IT IS
7708          ,CALL
7709          ,      MOV      #ADR,R1      ,ADDRESS OF ASCII CHARACTER
7710          ,      JSR      RO,@#CK CHR ;CHECK CHARACTER
7711          ,      RETURN ADR1 ;UNKNOWN CHARACTER
7712          ,      RETURN ADR2 ;CARRIAGE RETURN * (R1)=ADR+1
7713          ,      RETURN ADR3 ;SLASH * (R1)=ADR+1
7714          ,      RETURN ADR4 ;COMMA * (R1)=ADR+1
7715          ,      RETURN ADR5 ;PERIOD * (R1)=ADR+1
7716          ,      RETURN ADR6 ;DIGIT BETWEEN 0 AND 9
7717          ,      ;R2 = DIGIT * (R1)=ADR+1
7718
7719 033766 105711          CK CHR  TSTB      (R1)      ,"CARRIAGE RETURN"?
7720 033770 001420          BEQ      4$          ;YES -- BRANCH
7721 033772 121127 000057          CMPB      (R1),# '/'    ;"SLASH"?
7722 033776 001414          BEQ      3$          ;YES -- BRANCH
7723 034000 121127 000054          CMPB      (R1),# ','    ;"COMMA"?
7724 034004 001410          BEQ      2$          ;YES -- BRANCH
7725 034006 121127 000056          CMPB      (R1),# '.'    ;"PERIOD"?
7726 034012 001404          BEQ      1$          ;YES -- BRANCH
7727 034014 004037 033740          JSR      RO,@#CK DEC ;"DIGIT"?
7728 034020 000406          BR      5$          ;NO -- BRANCH
7729 034022 005720          TST      (R0)+       ;DIGIT BETWEEN 0-9
7730 034024 005720          1$      TST      (R0)+       ;PERIOD
7731 034026 005720          2$      TST      (R0)+       ;COMMA
7732 034030 005720          3$      TST      (R0)+       ;SLASH
7733 034032 005720          4$      TST      (R0)+       ;CARRIAGE RETURN
7734 034034 005201          INC      R1          ;MOVE POINTER TO NEXT CHARACTER
7735 034036 011000          5$      MOV      (R0),RO      ;UNKNOWN CHARACTER
7736 034040 000200          RTS      RO          ;RETURN
7737
7738          ,THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
7739          CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN P2
    
```

```

7740      ,CALL
7741      ,      MOV      #ADR,R1      ;ADDRESS OF ASCIZ STRING
7742      ,      MOV      #NUM,R2      ;MAX. MAGNITUDE OF INPUT NUMBER
7743      ,      JSR      RO,@#CK.DIG   ;CHECK DIGITS
7744      ,      RETURN   ADR1         ;ILLEGAL CHARACTER -- R2=?
7745      ,      RETURN   ADR2         ;INPUT NUMBER TO LARGE -- R2=?
7746      ,      RETURN   ADR3         ;"COMMA" -- R2 = NUMBER
7747      ,      RETURN   ADR4         ;"PERIOD" -- R2 = NUMBER
7748      ,      RETURN   ADR5         ;"PERIOD-PERIOD" -- R2 = NUMBER
7749
7750 034042 010446      CK DIG  MOV      R4,-(SP)      ;SAVE R4
7751 034044 010346      MOV      R3,-(SP)      ;SAVE R3
7752 034046 010246      MOV      R2,-(SP)      ;SAVE THE MAX. SIZE ON THE STACK
7753 034050 005002      CLR      R2              ;START WITH 0
7754 034052 005003      CLR      R3
7755 034054 005004      CLR      R4
7756 034056 004037 033766 JSR      RO,@#CK CHR   ;CHECK ONE CHARACTER
7757 034062 034212      8$          ;ILLEGAL CHARACTER
7758 034064 034212      8$          ;CARRIAGE RETURN
7759 034066 034212      8$          ;"/"
7760 034070 034212      8$          ;" "
7761 034072 034212      8$          ;" "
7762 034074 034076      1$          ;DIGIT 0-9
7763 034076 006303      1$          ;2
7764 034100 010346      15     MOV      R3,-(SP)      ;SAVE *2
7765 034102 006303      ASL      R3              ;4
7766 034104 006303      ASL      R3              ;8
7767 034106 062603      ADD      (SP)+,R3      ;(*8)+(*2)=*10
7768 034110 060203      ADD      R2,R3        ;UPDATE THE INPUT NUMBER
7769 034112 004037 033766 JSR      RO,@#CK CHR   ;CHECK ONE CHARACTER
7770 034116 034212      8$          ;ILLEGAL CHARACTER
7771 034120 034132      9$          ;CARRIAGE RETURN
7772 034122 034212      8$          ;"/"
7773 034124 034140      3$          ;" "
7774 034126 034136      2$          ;" "
7775 034130 034076      1$          ;DIGIT 0-9
7776 034132 005301      9$          ;BACKUP THE CHARACTER POINTER
7777 034134 000401      BR      3$            ;CONTINUE
7778 034136 005724      2$          TST      (R4)+      ;"PERIOD"
7779 034140 005724      3$          TST      (R4)+      ;"COMMA" OR "CR"
7780 034142 004037 033766 JSR      RO,@#CK CHR   ;CHECK ONE CHARACTER
7781 034146 034212      8$          ;ILLEGAL CHARACTER
7782 034150 034202      6$          ;CARRIAGE RETURN
7783 034152 034212      8$          ;"/"
7784 034154 034212      8$          ;" "
7785 034156 034162      4$          ;" "
7786 034160 034172      5$          ;DIGIT 0-9
7787 034162 005724      4$          TST      (R4)+      ;"PERIOD-PERIOD"
7788 034164 105711      TSTB   (R1)          ;"CR"?
7789 034166 001405      BEQ     6$            ;YES--BRANCH
7790 034170 000410      BR      8$
7791 034172 126127 177776 000054 5$     CMPB   -2(R1),#' ,   ;WAS CHARACTER BEFORE THE DIGIT A COMMA?
7792 034200 001004      BNE     8$            ;NO--EXIT
7793 034202 020316      6$          CMP     R3,(SP)      ;INPUT TO LARGE?
7794 034204 101001      BHI     7$            ;YES -- BRANCH
7795 034206 060400      ADD     R4,RO       ;ADJUST RETURN ADDRESS
    
```

```

7796 034210 005720      7$   TST      (R0)+
7797 034212 010302      8$   MOV      R3,R2      ;NUMBER TO R2
7798 034214 005726      TST      (SP)+      ;CLEAN MAX. SIZE OFF OF STACK
7799 034216 012603      MOV      (SP)+,R3   ;RESTORE R3
7800 034220 012604      MOV      (SP)+,R4   ;RESTORE R4
7801 034222 011000      MOV      (R0),R0    ;GET RETURN ADDRESS
7802 034224 000200      RTS      R0         ;RETURN
7803
7804                      ; THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
7805                      ; AND FORMS AN OCTAL NUMBER IN R2
7806                      ; CALL
7807                      ;     MOV      #ADR,R1      ; ADDRESS OF ASCIZ STRING
7808                      ;     JSR      RO,@#CK.NUM   ; GO FORM THE NUMBER
7809                      ;     RETURN  ADR1        ; ILLEGAL CHARACTER IN THE INPUT STRING
7810                      ;     RETURN  ADR2        ; "COMMA" OR "CR"--R2=NUMBER
7811                      ;     RETURN  ADR3        ; "PERIOD"--R2=NUMBER
7812                      ;     RETURN  ADR4        ; "PERIOD-PERIOD"--R2=NUMBER
7813
7814 034226 010346      CK NUM· MOV      R3,-(SP) ; SAVE R3
7815 034230 005003      CLR      R3         ; START NUMBER AT ZERO
7816 034232 004037 033712 JSR      RO,@#CK OCT ; OCTAL DIGIT?
7817 034236 000440      BR      6$         ; NO--BRANCH
7818 034240 005201      1$   INC      R1         ; MOVE TO NEXT CHARACTER
7819 034242 006303      ASL      R3         ; FOR THE OCTAL NUMBER IN R3
7820 034244 103435      BCS     6$         ; DON'T LET IT GET TO BIG
7821 034246 006303      ASL      R3
7822 034250 103433      BCS     6$
7823 034252 006303      ASL      R3
7824 034254 103431      BCS     6$
7825 034256 060203      ADD     R2,R3
7826 034260 004037 033712 JSR      RO,@#CK OCT ; IS THIS AN OCTAL DIGIT?
7827 034264 000401      BR      2$         ; NO--FIND OUT WHAT IT IS
7828 034266 000764      BR      1$         ; YES--MAKE IT PART OF THE NUMBER
7829 034270 010302      2$   MOV      R3,R2   ; SAVE THE OCTAL NUMBER
7830 034272 005003      CLR      R3         ; START WITH ZERO INDEX
7831 034274 004037 033766 JSR      RO,@#CK CHR ; CHECK ONE CHARACTER
7832 034300 034340      6$   ; ILLEGAL CHARACTER
7833 034302 034330      5$   ; CARRIAGE RETURN
7834 034304 034340      6$   ; "/"
7835 034306 034330      5$   ; " "
7836 034310 034314      3$   ; " "
7837 034312 034340      6$   ; DIGIT 0-9
7838 034314 005723      3$   TST      (R3)+     ; "PERIOD"
7839 034316 121127 000056 CMPB     (R1),#'    ; "PERIOD-PERIOD"?
7840 034322 001002      BNE     5$         ; NO--BRANCH
7841 034324 005201      INC     R1         ; YES--ADVANCE THE POINTER
7842 034326 005723      4$   TST      (R3)+     ; "PERIOD-PERIOD"
7843 034330 005723      5$   TST      (R3)+     ; "COMMA"
7844 034332 105711      TSTB   (R1)        ; "CR"?
7845 034334 001001      BNE     6$         ; NO--BRANCH
7846 034336 060300      ADD     R3,R0      ; YES--SAVE THE OCTAL NUMBER
7847 034340 012603      6$   MOV      (SP)+,R3   ; RESTORE R3
7848 034342 011000      MOV      (R0),R0    ; PICKUP EXIT ADDRESS
7849 034344 000200      RTS      R0         ; RETURN
    
```

```

7850      , , *****
7851
7852
7853      SBTTL  SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)
7854
7855      , COPYRIGHT (C) 1976
7856      , DIGITAL EQUIPMENT CORP.
7857      , MAYNARD, MA 01754
7858      , AUTHOR(S): JIM LACEY/CHUCK HESS
7859
7860      , , *****
7861
7862      , STORAGE FOR RPDS1, RPER1, RPER2, AND RPER3 ON AN ERROR "2"
7863      ; RPERRS = RPDS1
7864      ; RPERRS+2 = RPER1
7865      ; RPERRS+4 = RPER2
7866      ; RPERRS+6 = RPER3
7867
7868      034346 000000 000000 000000 RPERRS  WORD  0,0,0,0
7869      034354 000000
7870
7871      , TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)
7872      ; DRVACT=0 IF DRIVE IS IDLE
7873      ; DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
7874      ; DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION
7875
7876      034356 000      DRVACT  BYTE  0      , DRIVE 0
7877      034357 000      BYTE  0      , DRIVE 1
7878      034360 000      BYTE  0      , DRIVE 2
7879      034361 000      BYTE  0      , DRIVE 3
7880      034362 000      BYTE  0      , DRIVE 4
7881      034363 000      BYTE  0      , DRIVE 5
7882      034364 000      BYTE  0      , DRIVE 6
7883      034365 000      BYTE  0      , DRIVE 7
7884
7885      , TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)
7886      ; DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT
7887      ; DRVSTA>0 IF DRIVE IS ONLINE
7888      ; DRVSTA<0 IF DRIVE IS UNSAFE
7889
7890      034366 000      DRVSTA.  BYTE  0      , DRIVE 0
7891      034367 000      BYTE  0      , DRIVE 1
7892      034370 000      BYTE  0      , DRIVE 2
7893      034371 000      BYTE  0      , DRIVE 3
7894      034372 000      BYTE  0      , DRIVE 4
7895      034373 000      BYTE  0      , DRIVE 5
7896      034374 000      BYTE  0      , DRIVE 6
7897      034375 000      BYTE  0      , DRIVE 7
7898
7899      , TABLE OF DRIVE TYPES (DRVTYP=8 BYTES)
7900      ; DRVTYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
7901      ; DRVTYP=1 IF DRIVE IS RPO4
7902      ; DRVTYP=2 IF DRIVE IS RPO5
7903      ; DRVTYP=4 IF DRIVE IS RPO6
7904      ; DRVTYP=-1 IF NOT RPO4/5/6
7905
    
```

```

7906 034376 000          DRV TYP  . BYTE  0          ; DRIVE 0
7907 034377 000          . BYTE  0          ; DRIVE 1
7908 034400 000          . BYTE  0          ; DRIVE 2
7909 034401 000          . BYTE  0          ; DRIVE 3
7910 034402 000          . BYTE  0          ; DRIVE 4
7911 034403 000          . BYTE  0          ; DRIVE 5
7912 034404 000          . BYTE  0          ; DRIVE 6
7913 034405 000          . BYTE  0          ; DRIVE 7
7914
7915          . TABLE OF DUAL PORT INITIALIZATION INDICATORS
7916          . DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
7917          . DPINT<0 IF INITIALIZATION IS IN PROGRESS
7918
7919 034406 000          DPINT   . BYTE  0          ; DRIVE 0
7920 034407 000          . BYTE  0          ; DRIVE 1
7921 034410 000          . BYTE  0          ; DRIVE 2
7922 034411 000          . BYTE  0          ; DRIVE 3
7923 034412 000          . BYTE  0          ; DRIVE 4
7924 034413 000          . BYTE  0          ; DRIVE 5
7925 034414 000          . BYTE  0          ; DRIVE 6
7926 034415 000          . BYTE  0          ; DRIVE 7
7927
7928          . TABLE OF PENDING DUAL PORT REQUESTS
7929          . DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
7930          . DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
7931
7932 034416 000          DPRQS   . BYTE  0          ; DRIVE 0
7933 034417 000          . BYTE  0          ; DRIVE 1
7934 034420 000          . BYTE  0          ; DRIVE 2
7935 034421 000          . BYTE  0          ; DRIVE 3
7936 034422 000          . BYTE  0          ; DRIVE 4
7937 034423 000          . BYTE  0          ; DRIVE 5
7938 034424 000          . BYTE  0          ; DRIVE 6
7939 034425 000          . BYTE  0          ; DRIVE 7
7940
7941          . TRANSFER WAIT FLAG (TRNSWT=1 WORD)
7942          . THIS IS A ONE WORD QUEUE IT WILL CONTAIN THE ADDRESS OF
7943          . "DPB" OF THE I/O OPERATION
7944
7945 034426 000000      TRNSWT . WORD  0
7946
7947          . SEARCH WAIT KEYS (SRCHWT=1 WORD)
7948          . THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
7949          . THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
7950          . REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE
7951          . EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0
7952
7953 034430 000000      SRCHWT . WORD  0
7954
7955          . RPO4/5/6 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
7956          . ACTDRV=0 IF DRIVER IS INACTIVE
7957          . ACTDRV>0 IF DRIVER IS ACTIVE
7958
7959 034432 000          ACTDRV . BYTE  0
7960
7961          . SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
    
```

```

7962                                     ,ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
7963                                     ,ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
7964
7965 034433      000      ACTSTR . BYTE  0
7966
7967                                     , UNLOAD FLAG (ULDFLG=8 BYTES)
7968                                     , ULDFLG=0 IF NO UNLOAD COMMAND
7969                                     , ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
7970                                     , ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
7971
7972 034434      000      ULDFLG  BYTE  0          ; DRIVE 0
7973 034435      000      BYTE  0          ; DRIVE 1
7974 034436      000      BYTE  0          ; DRIVE 2
7975 034437      000      BYTE  0          ; DRIVE 3
7976 034440      000      BYTE  0          ; DRIVE 4
7977 034441      000      BYTE  0          ; DRIVE 5
7978 034442      000      BYTE  0          ; DRIVE 6
7979 034443      000      BYTE  0          ; DRIVE 7
7980
7981                                     , LOOK AHEAD COUNT (LACNT=8 BYTES)
7982                                     , LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
7983
7984 034444      000      LACNT   BYTE  0          ; DRIVE 0
7985 034445      000      BYTE  0          ; DRIVE 1
7986 034446      000      BYTE  0          ; DRIVE 2
7987 034447      000      BYTE  0          ; DRIVE 3
7988 034450      000      BYTE  0          ; DRIVE 4
7989 034451      000      BYTE  0          ; DRIVE 5
7990 034452      000      BYTE  0          ; DRIVE 6
7991 034453      000      BYTE  0          ; DRIVE 7
7992
7993                                     , SAVE REGISTERS FLAG (SAVEFG =1 WORD)
7994                                     , SAVEFG <0 IF SAVE THE RH11/RPO4/5/6 REGISTERS WHEN THE
7995                                     , OPERATION IS COMPLETED AS PER (DPB+14)
7996                                     , SAVEFG=0 IF SAVE THE RH11/RPO4/5/6 REGISTERS, AS PER
7997                                     , (DPB+14), AFTER AN ERROR
7998
7999 034454      000000    SAVEFG  WORD  0
8000
8001                                     , SEEK FLAG (SEEKFG=1 WORD)
8002                                     , SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
8003                                     , FOR A DATA TRANSFER START A SEARCH COMMAND
8004                                     , SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
8005                                     , DISREGARD THE WINDOW
8006
8007 034456      000000    SEEKFG  WORD  0
8008
8009                                     , TIMEOUT TABLE (TIMER=8 WORDS)
8010                                     , THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
8011
8012 034460      177777    TIMER   WORD  -1      , DRIVE 0
8013 034462      177777    WORD  -1      , DRIVE 1
8014 034464      177777    WORD  -1      , DRIVE 2
8015 034466      177777    WORD  -1      , DRIVE 3
8016 034470      177777    WORD  -1      , DRIVE 4
8017 034472      177777    WORD  -1      , DRIVE 5
    
```

```

8018 034474 177777      WORD -1      ;DRIVE 6
8019 034476 177777      WORD -1      ;DRIVE 7
8020
8021      , DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
8022      , DTUW<0 IF NO DATA TRANSFER UNDERWAY
8023      , DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
8024
8025 034500 177777      DTUW  WORD -1
8026
8027      , ATTENTION BITS TABLE (ATABIT=8 BYTES)
8028      , THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
8029      , ATTENTION BIT
8030
8031 034502 001      ATABIT  BYTE 1      ;DRIVE 0
8032 034503 002      BYTE 2      ;DRIVE 1
8033 034504 004      BYTE 4      ;DRIVE 2
8034 034505 010      BYTE 10     ;DRIVE 3
8035 034506 020      BYTE 20     ;DRIVE 4
8036 034507 040      BYTE 40     ;DRIVE 5
8037 034510 100      BYTE 100    ;DRIVE 6
8038 034511 200      BYTE 200    ;DRIVE 7
8039
8040      , RPO4/5/6 TO RH11 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
8041      , CALLING IT FATAL (MCPEMX=1 WORD)
8042
8043 034512 000003      MCPEMX  WORD 3
8044
8045      , STORAGE FOR RPADR (THE FIRST ADDRESS (776700) OF THE RH11/RPO4/5/6),
8046      , RPVEC (THE VECTOR ADDRESS (254)), AND RPVEC+2 (THE BR LEVEL (5))
8047
8048 034514 176700      RPADR  WORD 176700
8049 034516 000254 000240  RPVEC  WORD 254,5*32
8050
8051      , MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)
8052
8053 034522 000004      MXLACT  WORD 4
8054      , MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)
8055
8056 034524 001000      MXDLTA  WORD 8 *64
8057      , MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)
8058
8059 034526 000200      MNDLTA  WORD 2*64
8060      , MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW=1 WORD)
8061
8062 034530 000005      MXWNDW  WORD 5
8063
8064      , DEFINITIONS OF THE RH11/RPO4/5/6 ADDRESS INDEXES
8065
8066      000000      RPCS1=0      , CONTROL AND STATUS REGISTER #1 (DRIVE REG 00)
8067      000002      RPWC=2      , WORD COUNT REGISTER (NOT A DRIVE REG)
8068      000004      RPBA=4      , UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
8069      000006      RPDA=6      , DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG 05)
8070      000010      RPCS2=10     , CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
8071      000012      RPDS1=12     , DRIVE STATUS REGISTER (DRIVE REG 01)
8072      000014      RPER1=14     , ERROR REGISTER #1 (DRIVE REG 02)
8073      000016      RPAS=16     , ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG 04)
    
```

8074	000020	RPLA=20	, LOOK AHEAD REGISTER (DRIVE REG. 07)
8075	000022	RPDB=22	, DATA BUFFER REGISTER (NOT A DRIVE REG )
8076	000024	RPMR=24	, MAINTAINABILITY REGISTER (DRIVE REG 03)
8077	000026	RPDT=26	, DRIVE TYPE REGISTER (DRIVE REG. 06)
8078	000030	RPSN=30	, SERIAL NUMBER REGISTER (DRIVE REG. 10)
8079	000032	RPOF=32	, OFFSET REGISTER (DRIVE REG. 11)
8080	000034	RPCA=34	, DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG 12)
8081	000036	RPCC=36	, CURRENT CYLINDER ADDRESS REGISTER (DRIVE REG 13)
8082	000040	RPER2=40	, ERROR REGISTER #2 (DRIVE REG. 14)
8083	000042	RPER3=42	, ERROR REGISTER #3 (DRIVE REG. 15)
8084	000044	RPEC1=44	, ECC POSITION REGISTER (DRIVE REG. 16)
8085	000046	RPEC2=46	, ECC PATTERN REGISTER (DRIVE REG. 17)

, RH11/RPO4/5/6 DRIVER INITIALIZATION CODE  
 , THIS ROUTINE WILL DETERMINE WHICH RPO4/5/6 DRIVES ARE  
 , AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR  
 , TO THE PROPER STATE FOR EACH DRIVE.  
 , NOTE THIS ROUTINE CALLS DRVINT

, CALL

JSR PC,RPINIT  
 RETURN

, NOTE THE 'P' OR 'L' CLOCK MUST BE STARTED

8099		RPINIT	SAVREG		, SAVE R0 - R5
8100	034532	104412			, SAVE THE PRESENT PROCESSOR STATUS
8101	034534	013746	177776		, CHANGE THE PRIORITY TO 5
8102	034540	012737	000240	177776	, CLEAR ALL REQUEST QUEUES
8103	034546	004737	042516		, FIRST ADDRESS TO BE CLEARED
8104	034552	012701	034346		, LAST ADDRESS TO BE CLEARED
8105	034556	012702	034456		, CLEAR
8106	034562	005021		15	, ARE WE DONE?
8107	034564	020102			, BRANCH IF NO
8108	034566	101775			, LAST ADDRESS
8109	034570	012702	034500		, INITIALIZE
8110	034574	012721	177777	25	, DONE?
8111	034600	020102			, LOOP IF NO
8112	034602	101774			, SET ALL DRIVES TO OFFLINE
8113	034604	005037	034366		
8114	034610	005037	034370		
8115	034614	005037	034372		
8116	034620	005037	034374		
8117	034624	013703	034516		, SETUP THE RH11/RPO4/5/6 VECTOR
8118	034630	012723	037376		
8119	034634	013713	034520		
8120	034640	013704	034514		, FIRST ADDRESS OF RH11/RPO4
8121	034644	012764	000040	000010	, MASSBUS INIT
8122	034652	005001			, START WITH DRIVE 0
8123	034654	004037	034744	35	, INIT THE DRIVE
8124	034660	000401			, 'DVA' NOT SET OR PARITY ERROR
8125	034662	000402			, NORMAL RETURN
8126	034664	105061	034366	45	, SET DRIVE STATUS TO OFFLINE
8127	034670	005201		55	, GO TO NEXT DRIVE
8128	034672	042701	177770		, MASK OUT UNUSED BITS
8129	034676	001366			, BR IF MORE DRIVES TO GO

```

8130 034700 012701 000007      MOV      #7,R1      ,START WITH DRIVE 7
8131 034704 005037 177776      CLR      @#PS      ;CLEAR THE PROCESSOR STATUS
8132 034710 105761 034406      6$      TSTB     DPINT(R1) ,WAITING FOR DRIVE TO SWITCH PORTS ?
8133 034714 001405                BEQ      8$        ,BR NOT WAITING
8134 034716 004737 042152      JSR      PC,SET IE ,SET INTERRUPT
8135 034722 105761 034406      7$      TSTB     DPINT(R1) ,DRIVE SWITCHED POPTS ?
8136 034726 001375                BNE     7$        ;BR IF NOT
8137 034730 005301      8$      DEC      R1        ,GO TO THE NEXT DRIVE
8138 034732 100366                BPL     6$        ;CHECK NEXT DRIVE
8139 034734 012637 177776      MOV      (SP)+,@#PS ;RESTORE THE PROCESSOR STATUS
8140 034740 104413      RESREG   PC        ,RESTORE RO - R5
8141 034742 000207      RTS      PC        ,BYE-BYE
8142
8143      ,DRIVE INITIALIZATION ROUTINE
8144      ,THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
8145      ,AN RPO4/5/6 IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22
8146      ,IS SET TO A "1" THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
8147      ,INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
8148      ,DRVSTA IS SET TO THE PROPER CONDITION
8149      ,CALL
8150      ,
8151      ,      MOV      #DRVNUM,R1      ,DRIVE NUMBER TO R1
8152      ,      MOV      RPADR,R4      ,UNIBUS ADDRESS OF RH11/RPO4/5/6 (RPCS1)
8153      ,      JSR      RO,DRVINT     ,CALLED BY A JSR
8154      ,      RETURN1    ,ERROR OCCURRED (PARITY)
8155      ,      RETURN2    ,NORMAL RETURN
8156
8157      DRVINT  MOV      R5,-(SP)      ,SAVE R5
8158      034744 010546      CLRB    DRVSTA(R1) ,START DRIVE STATUS AS OFFLINE
8159      034746 105061 034366      CLRB    DRVSTYP(R1) ,CLEAR THE DRIVE TYPE INDICATOR
8160      034752 105061 034376      CLRB    ULDFLG(R1) ,CLEAR THE UNLOAD FLAG
8161      034756 105061 034434      MOV     R1,RPCS2(R4) ;SELECT A DRIVE
8162      034762 010164 000010      MOV     R1,RPCS2(R4) ;SELECT A DRIVE
8163      034766 112764 000111 000000      MOV     #111,RPCS1(R4) ,DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
8164      034774 032764 010000 000010      BIT     #BIT12,RPCS2(R4) ,NONEXISTENT DRIVE?
8165      035002 001403                BEQ     1$        ,NO---BRANCH
8166      035004 004737 042152      JSR     PC,SET IE  ,GO SET "IE" WITHOUT A "TRE"
8167      035010 000520                BR     6$        ,LEAVE THIS ROUTINE
8168      035012 105061 034366      1$      CLRB    DRVSTA(R1) ,SET DRIVE STATUS TO OFFLINE
8169      035016 032764 004000 000000      BIT     #BIT11,RPCS1(R4) ,SEE IF DRIVE AVAILABLE
8170      035024 001514                BEQ     7$        ,BR IF DRIVE NOT AVAILABLE
8171      035026 004037 041462      JSR     RO,RO RP  ,READ THE DRIVE TYPE REG
8172      035032 000026      RPDT    8$        ,ERROR RETURN ADDRESS
8173      035034 035276      MOV     (SP)+,R5   ,PUT DRIVE TYPE IN R5
8174      035036 012605      MOV     #1,DRVSTYP(R1) ,SET RPO4 INDICATOR
8175      035040 112761 000001 034376      CMP     #20020,R5   ,IS IT A SINGLE PORT RPO4?
8176      035046 022705 020020                BEQ     2$        ,BRANCH IF YES
8177      035052 001431                CMP     #24020,R5  ,IS IT A DUAL PORT RPO4?
8178      035054 022705 024020                BEQ     2$        ,BR IF YES
8179      035060 001426                MOV     #2,DRVSTYP(R1) ,SET RPO5 INDICATOR
8180      035062 112761 000002 034376      CMP     #20021,R5   ,SINGLE PORT RPO5 ?
8181      035070 022705 020021                BEQ     2$        ,BR IF YES
8182      035074 001420                CMP     #24021,R5  ,DUAL PORT RPO5 ?
8183      035076 022705 024021                BEQ     2$        ,BR IF YES
8184      035102 001415                MOV     #4,DRVSTYP(R1) ,SET RPO6 INDICATOR
8185      035104 112761 000004 034376      CMP     #20022,R5   ,SINGLE PORT RPO6 ?
8186      035112 022705 020022
    
```

8186	035116	001407			BEQ	2\$		;BR IF YES
8187	035120	022705	024022		CMP	#24022,R5		;DUAL PORT RPO6 ?
8188	035124	001404			BEQ	2\$		;BR IF YES
8189	035126	112761	177777	034376	MOVB	#-1,DRVTP(R1)		;SET INDICATOR TO 'OTHER'
8190	035134	000446			BR	6\$		;EXIT
8191	035136	012746	000121	2\$	MOV	#121,-(SP)		;DO A "READ-IN PRESET"
8192	035142	004037	041642		JSR	RO,WRT RP		
8193	035146	000000			RPCS1			
8194	035150	035276			8\$			
8195	035152	012746	010003		MOV	#BIT12,-(SP)		;SET FMT22=1
8196	035156	004037	041642		JSR	RO,WRT RP		
8197	035162	000032			RPOF			
8198	035164	035276			8\$			
8199	035166	004037	041462		JSR	RO,RO RP		;READ RPO51
8200	035172	000012			RPDS1			
8201	035174	035276			8\$			
8202	035176	012605			MOV	(SP)+,R5		;AND SAVE IT IN R5
8203	035200	100015			BPL	4\$		;BRANCH IF ATA=0
8204	035202	116164	034502	000016	MOVB	ATABIT(R1),RPAS(R4)		;CLEAR ATTENTION BIT
8205	035210	004037	041462		JSR	RO,RO RP		;FIND OUT WHY ATA=1
8206	035214	000014			RPER1			
8207	035216	035276			8\$			
8208	035220	006126			ROL	(SP)+		;IS IT UNSAFE?
8209	035222	100004			BPL	4\$		;BR IF NOT
8210	035224	112761	177777	034366	MOVB	#-1,DRVSTA(R1)		;SET UNSAFE INDICATOR
8211	035232	000407			BR	6\$		;EXIT
8212	035234	005105		4\$	COM	R5		;CHECK MOL, DPR, DRY, AND VV
8213	035236	042705	167077		BIC	#(BIT12'BIT08'BIT07'BIT06),R5		
8214	035242	001003			BNE	6\$		;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
8215	035244	112761	000001	034366	MOVB	#1,DRVSTA(R1)		;SET DRIVE STATUS TO ONLINE
8216	035252	005720		6\$	TST	(RO)+		;STEP OVER THE ERROR RETURN
8217	035254	000410			BR	8\$		;EXIT
8218	035256	006301		7\$	ASL	R1		;CHANGE INDEX TO ADDRESS WORDS
8219	035260	012761	003720	034460	MOV	#2000,TIMER(R1)		;START 2 SEC TIMER
8220	035266	006201			ASR	R1		;RESTORE R1
8221	035270	105161	034406		COMB	DPINT(R1)		
8222	035274	005720			TST	(RO)+		
8223	035276	012605		8\$	MOV	(SP)+,R5		;RESTORE R5
8224	035300	000200			RTS	RO		;EXIT
8225								
8226								;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
8227								;CALL
8228								
8229								
8230					JSR	RO,@#RPO4		;CALL THE RPO4/5/6 DRIVER
8231					PNTADR			;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
8232					RETURN1			;RETURN HERE IF QUEUE IS FULL
8233					RETURN2			;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
8234								;IS AN ERROR CONDITION
8235								
8236	035302	013746	177776		RPO4	MOV	@#PS,-(SP)	;SAVE THE CALLING STATUS
8237	035306	013737	034520	177776		MOV	RPVEC+2,@#PS	;DON'T ALLOW ANY RPO4/5/6 INTERUPTS
8238	035314	112737	000001	034432		MOVB	#1,ACTDRV	;SET "ACTIVE DRIVER" FLAG
8239	035322	104412			SAVREG			;SAVE RO - R5
8240	035324	011002			MOV	(RO),R2		;PICKUP THE DRIVE PARAMETER BLOCK POINTER
8241	035326	005062	000016		CLR	16(R2)		;CLEAR THE STATUS/ERROR INDICATOR

```

8242 035332 111201          MOV      (R2),R1          ;PICKUP THE DRIVE NUMBER
8243 035334 013704 034514    MOV      RPADR,R4        ;UNIBUS ADDRESS OF RPCS1
8244 035340 105761 034366    TSTB    DRVSTA(R1)      ;CHECK DRIVES STATUS
8245 035344 003014          BGT      1$              ;BRANCH IF ONLINE
8246 035346 105761 034434    TSTB    ULDFLG(R1)      ;UNLOAD COMMAND IN QUEUE?
8247 035352 001036          BNE      3$              ;BRANCH IF YES
8248 035354 105761 034406    TSTB    DPINT(R1)       ;TRYING TO INIT THE DRIVE
8249 035360 001042          BNE      5$              ;BR IF YES
8250 035362 004037 034744    JSR     RD,DRVINT        ;GO INIT. THE DRIVE
8251 035366 000434          BR       4$              ;ERROR RETURN
8252 035370 105761 034366    TSTB    DRVSTA(R1)      ;IS DRIVE STATUS ONLINE?
8253 035374 003445          BLE      6$              ;BR IF NOT
8254 035376 105761 034416    TSTB    DPRQS(R1)       ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8255 035402 001031          BNE      5$              ;BR IF YES
8256 035404 010164 000010    MOV      R1,RPCS2(R4)    ;SELECT THE DRIVE
8257 035410 004037 042614    JSR     RD,DRVQUE        ;PUT THIS REQUEST IN QUEUE
8258 035414 000460          BR       9$              ;QUEUE IS FULL
8259 035416 122762 000103 000002 CMPB     #103,2(R2)      ;IS THIS REQ. FOR AN UNLOAD?
8260 035424 001003          BNE      2$              ;BR IF NO
8261 035426 112761 177777 034434 MOVB     #-1,ULDFLG(R1)  ;SET THE "UNLOAD IN QUEUE" FLAG
8262 035434 105761 034356    TSTB    DRVACT(R1)      ;IS THIS DRIVE ACTIVE?
8263 035440 001043          BNE      8$              ;BR IF YES
8264 035442 004737 035574    JSR     PC,OPT           ;CALL THE OPTIMIZER
8265 035446 000440          BR       8$
8266 035450 012762 120000 000016 3$ MOV      #BIT15'BIT13,16(R2) ;SET THE "UNLOAD IN QUEUE" ERROR FLAG
8267 035456 000434          BR       8$              ;EXIT
8268 035460 004737 036704    JSR     PC,C17           ;GO HANDLE THE PARITY ERROR
8269 035464 000431          BR       8$
8270 035466 004037 042614    JSR     RD,DRVQUE        ;PUT REQUEST IN QUEUE
8271 035472 000431          BR       9$              ;QUEUE IS FULL
8272 035474 032714 000100    BIT     #BIT06,(R4)      ;IS 'IE' SET ALREADY ?
8273 035500 001023          BNE      8$              ;BR IF IT IS
8274 035502 004737 042152    JSR     PC,SET IE        ;SET INTERRUPT
8275 035506 000420          BR       8$              ;RETURN, REQUEST IN QUEUE
8276 035510 105761 034366    TSTB    DRVSTA(R1)      ;SEE IF DRIVE OFFLINE OR UNSAFE
8277 035514 002412          BLT     7$              ;BR IF UNSAFE
8278 035516 012762 140000 000016 MOV      #BIT15'BIT14,16(R2) ;SET OFFLINE ERROR INDICATOR
8279 035524 105761 034376    TSTB    DRVTP(R1)       ;SEE IF OFFLINE OR NONEXISTENT
8280 035530 001007          BNE      8$              ;BR IF OFFLINE
8281 035532 012762 100002 000016 MOV      #BIT15'BIT01,16(R2) ;REPORT DRIVE NONEXISTENT
8282 035540 000403          BR       8$              ;GO TO EXIT
8283 035542 012762 110000 000016 7$ MOV      #BIT15'BIT12,16(R2) ;DRIVE IS UNSAFE
8284 035550 104413          8$ RESREG             ;RESTORE R0 - R5
8285 035552 005720          TST     (R0)+            ;SETUP FOR NORMAL RETURN
8286 035554 000401          BR     10$              ;FINISH UP, THEN EXIT
8287 035556 104413          9$ RESREG             ;RESTORE R0 - R5
8288 035560 005720          10$ TST     (R0)+           ;CORRECT THE RETURN ADDRESS
8289 035562 105037 034432    CLRB    ACTDRV          ;CLEAR "ACTIVE DRIVER" FLAG
8290 035566 012637 177776    MOV     (SP)+,0#PS       ;RETURN "PS" TO USER LEVEL
8291 035572 000200          RTS     R0               ;RETURN TO CALLER
8292
8293          ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
8294          ;
8295          ;CALL
8296          ;      MOV     #DRVNUM,R1          ;DRIVE NUMBER TO R1
8297          ;      JSR     PC,OPT           ;SETUP A COMMAND
    
```

```

8298
8299 035574 104412          OPT   SAVREG      ;SAVE R0 - R5
8300 035576 013746 177776   MOV   @#PS, -(SP) ;SAVE PROC. STATUS
8301 035602 146137 034502 034430 BICB  ATABIT(R1), SRCHWT ;CLEAR "SEARCH WAIT" KEY
8302 035610 004737 042670   JSR   PC, GETREQ  ;GET "DPB" POINTER OF REQUEST
8303 035614 005702   TST   R2          ;IS THERE A REQUEST IN QUEUE?
8304 035616 001505   BEQ   7$         ;NO--BRANCH TO EXIT
8305 035620 032764 004000 000000 BIT   #BIT11, RPCS1(R4) ;IS DVA STILL SET ?
8306 035626 001407   BEQ   10$        ;BR IF NOT
8307 035630 032764 000100 000012 BIT   #BIT6, RPDS1(R4) ;IS VV SET ?
8308 035636 001003   BNE   10$        ;BR IF IT IS
8309 035640 004037 034744   JSR   RD, DRVINT ;SEE IF DRIVE STILL ONLINE ?
8310 035644 000470   BR    6$         ;PARITY OR 'DVA' NOT SET
8311 035646 105761 034366   10$  TSTB  DRVSTA(R1) ;IS DRIVE ONLINE?
8312 035652 003014   BGT   1$         ;YES--BRANCH
8313 035654 004737 042712   JSR   PC, POPQUE ;NO--REMOVE REQUEST FROM QUEUE
8314 035660 012762 140000 000016 MOV   #BIT15'BIT14, 16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
8315 035666 105761 034366   TSTB  DRVSTA(R1) ;IS DRIVE UNSAFE ?
8316 035672 100064   BPL   8$         ;BR TO EXIT IF NOT
8317 035674 012762 110000 000016 MOV   #BIT15'BIT12, 16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
8318 035702 000460   BR    8$         ;BRANCH TO EXIT
8319 035704 012746 000111   1$  MOV   #111, -(SP) ;LOAD COMMAND ONTO THE STACK
8320 035710 004037 041642   JSR   RD, WRT RP ;LOAD THE REGISTER
8321 035714 000000   RPCS1 ;REGISTER INCREMENT
8322 035716 036026   6$  ;ERROR RETURN ADDRESS
8323 035720 032714 004000   BIT   #BIT11, (R4) ;DRIVE AVAILABLE ?
8324 035724 001427   BEQ   5$         ;BR IF NOT
8325 035726 122762 000150 000002 CMPB  #150, 2(R2) ;IS THE REQUEST FOR 1/0?
8326 035734 002403   BLT   2$         ;YES--BRANCH
8327 035736 004737 036270   JSR   PC, C14   ;CALL THE COMMAND INITIATOR
8328 035742 000440   BR    8$         ;BRANCH TO EXIT
8329 035744 005737 034500   2$  TST   DTUW      ;DATA TRANSFER UNDERWAY?
8330 035750 002012   BGE   4$         ;YES--GO START A SEARCH
8331 035752 005737 034456   TST   SEEKFG    ;DO IMPLIED SEEKS?
8332 035756 100404   BMI   3$         ;YES---BRANCH
8333 035760 004037 037240   JSR   RD, LA    ;NO--DO LOOK AHEAD
8334 035764 000427   BR    8$         ;RETURN HERE ON A PARITY ERROR
8335 035766 000403   BR    4$         ;GO START A SEARCH
8336 035770 004737 036054   3$  JSR   PC, C11   ;START A DATA TRANSFER
8337 035774 000423   BR    8$         ;
8338 035776 004737 036162   4$  JSR   PC, C13   ;START A SEARCH
8339 036002 000420   BR    8$         ;GO TO THE EXIT
8340 036004 112761 177777 034416 5$  MOVB  #-1, DPRQS(R1) ;SET PORT REQUEST INDICATOR
8341 036012 010103   MOV   R1, R3    ;SET UP TO ADDRESS WORDS
8342 036014 006303   ASL   R3        ;CONVERT TO WORD INDEX
8343 036016 012763 023420 034460 MOV   #10000, TIMER(R3) ;START 10 SEC TIMER
8344 036024 000402   BR    7$         ;EXIT
8345 036026 004737 036704   6$  JSR   PC, C17   ;PROCESS THE PARITY ERROR
8346 036032 032714 000100   7$  BIT   #BIT06, (R4) ;SEE IF 'IE' ALREADY SET
8347 036036 001002   BNE   8$         ;BR IF SET
8348 036040 004737 042152   JSR   PC, SET IE ;SET "IE" WITHOUT A "TRE"
8349 036044 012637 177776   8$  MOV   (SP)+, @#PS ;RESTORE PROC STATUS
8350 036050 104413   RESREG ;RESTORE R0 - R5
8351 036052 000207   RTS   PC
8352
8353          , COMMAND INITIATOR
    
```

```

8354 ;
8355 ;CALL
8356 ; MOV #DRVNUM,R1 ;DRIVE NUMBER
8357 ; MOV #DPB,R2 ;ADDRESS OF DPB
8358 ; JSR PC,C1? ;C1?= C11,C13, OR C14
8359 ; ;WHERE:
8360 ; ;C11=DATA TRANSFER
8361 ; ;C12=SEARCH REQUESTED BY DATA XFER
8362 ; ;C14=NOT DATA TRANSFER
8363 ;
8364 036054 004737 042712 C11 JSR PC,POPQUE ;REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
8365 036060 010237 034426 MOV R2,TRNSWT ;PUT REQ. IN TRANSFER WAIT QUEUE
8366 036064 010203 MOV R2,R3 ;DPB ADDRESS TO R3
8367 036066 013704 034514 MOV RPADR,R4 ;RPCS1 ADDRESS
8368 036072 010164 000010 MOV R1,RPCS2(R4) ;SELECT DRIVE
8369 036076 062703 000004 ADD #4,R3 ;DESIRED WORD COUNT
8370 036102 062704 000002 ADD #2,R4 ;RPWC ADDRESS
8371 036106 012324 MOV (R3)+,(R4)+ ;LOAD WORD COUNT
8372 036110 012324 MOV (R3)+,(R4)+ ;LOAD BUFFER ADDRESS
8373 036112 012346 MOV (R3)+,-(SP) ;LOAD SECTOR AND TRACK
8374 036114 004037 041642 JSR RO,WRT RP ;CALL THE LOAD(WRITE) ROUTINE
8375 036120 000006 RPDA ;INDEX OF REGISTER TO LOAD
8376 036122 036704 C17 ;ERROR RETURN ADDRESS
8377 036124 012346 MOV (R3)+,-(SP) ;LOAD CYLINDER ADDRESS
8378 036126 004037 041642 JSR RO,WRT RP
8379 036132 000034 RPCA
8380 036134 036704 C17
8381 036136 016246 000002 MOV 2(R2),-(SP) ;LOAD "COMMAND+GO", "A17&A16", AND "PSEL"
8382 036142 004037 041642 JSR RO,WRT RP
8383 036146 000000 RPCS1
8384 036150 036704 C17
8385 036152 010137 034500 MOV R1,DTUH ;SET "DATA TRANSFER UNDERWAY"
8386 036156 000137 036646 JMP C15
8387 036162 013704 034514 C13. MOV RPADR,R4 ;RPCS1 ADDRESS
8388 036166 010164 000010 MOV R1,RPCS2(R4) ;SELECT DRIVE
8389 036172 016246 000012 MOV 12(R2),-(SP) ;DESIRED CYLINDER ADDRESS
8390 036176 004037 041642 JSR RO,WRT RP
8391 036202 000034 RPCA
8392 036204 036704 C17
8393 036206 116203 000010 MOV#B 10(R2),R3 ;PICKUP SECTOR ADDRESS
8394 036212 163703 034530 SUB MXWINDW,R3 ;BACKUP BY MAX SEARCH FOR I/O WINDOW
8395 036216 002002 BGE 1$
8396 036220 062703 000026 ADD #22,R3
8397 036224 010346 000011 1$. MOV R3,-(SP) ;COMBINE THE ADJUSTED SECTOR WITH
8398 036226 116266 000011 000001 MOV#B 11(R2),1(SP) ;THE DESIRED TRACK
8399 036234 004037 041642 JSR RO,WRT RP ;LOAD DESIRED TRACK & SECTOR
8400 036240 000006 RPDA
8401 036242 036704 C17
8402 036244 012746 000131 MOV #131,-(SP) ;START A SEARCH
8403 036250 004037 041642 JSR RO,WRT RP
8404 036254 000000 RPCS1
8405 036256 036704 C17
8406 036260 156137 034502 034430 BISB ATABIT(R1),SRCHWT ;SET "SEARCH WAIT" KEY
8407 036266 000567 BR C15
8408 036270 013704 034514 C14 MOV RPADR,R4 ;RPCS1 ADDRESS
8409 036274 010164 000010 MOV R1,RPCS2(R4) ;SELECT DRIVE

```

8410	036300	116203	000002		MOVB	2(R2),R3	, PICKUP THE REQUESTED COMMAND
8411	036304	122703	000131		CMPB	#131,R3	; IS IT A SEARCH COMMAND?
8412	036310	001007			BNE	1\$	, BRANCH IF NO
8413	036312	016246	000010		MOV	10(R2), -(SP)	; LOAD DESIRED TRACK & SECTOR
8414	036316	004037	041642		JSR	RO, WRT RP	
8415	036322	000006			RPDA		
8416	036324	036704			C17		
8417	036326	000403			BR	2\$	, GO LOAD CYLINDER
8418	036330	122703	000105	1\$	CMPB	#105,R3	; IS IT A SEEK COMMAND
8419	036334	001007			BNE	3\$	, BRANCH IF NO
8420	036336	016246	000012	2\$	MOV	12(R2), -(SP)	; LOAD DESIRED CYLINDER
8421	036342	004037	041642		JSR	RO, WRT RP	
8422	036346	000034			RPCA		
8423	036350	036704			C17		
8424	036352	000546			BR	C16	
8425	036354	122703	000115	3\$	CMPB	#115,R3	, IS IT AN "OFFSET" COMMAND?
8426	036360	001013			BNE	4\$	, BR IF NO
8427	036362	004037	041462		JSR	RO, RD RP	, MERGE THE OFFSET VALUE INTO RPOF
8428	036366	000032			RPOF		, BUT DON'T CHANGE THE UPPER
8429	036370	036704			C17		
8430	036372	116216	000001		MOVB	1(R2), (SP)	, BYTE WHEN LOADING THE
8431	036376	004037	041642		JSR	RO, WRT RP	, REGISTER (RPOF)
8432	036402	000032			RPOF		
8433	036404	036704			C17		
8434	036406	000530			BR	C16	, GO START THE COMMAND
8435	036410	122703	000107	4\$	CMPB	#107,R3	, IS IT A "RECALIBRATE" COMMAND?
8436	036414	001525			BEQ	C16	, BRANCH IF YES
8437	036416	122703	000117		CMPB	#117,R3	, IS IT A RETURN TO CENTER?
8438	036422	001522			BEQ	C16	, BRANCH IF YES
8439	036424	122703	000103		CMPB	#103,R3	, IS IT AN "UNLOAD" COMMAND?
8440	036430	001016			BNE	5\$	, BRANCH IF NO
8441	036432	112761	000001	034356	MOVB	#1, DRVACT(P1)	, SET THE DRIVE ACTIVE INDICATOR
8442	036440	105061	034366		CLRB	DRVSTA(R1)	, PUT DRIVE STATUS TO OFFLINE
8443	036444	112761	000001	034434	MOVB	#1, ULDFLG(R1)	, SET "UNLOAD IN PROGRESS" FLAG
8444	036452	010346			MOV	R3, -(SP)	, START THE "UNLOAD" COMMAND
8445	036454	004037	041642		JSR	RO, WRT RP	
8446	036460	000000			RPCS1		
8447	036462	036704			C17		
8448	036464	000207			RTS	PC	, RETURN TO USER
8449	036466	122703	000143	5\$	CMPB	#143,R3	, IS IT A "SET FORMAT" COMMAND?
8450	036472	001014			BNE	6\$	, BRANCH IF NO
8451	036474	004037	041462		JSR	RO, RD RP	, READ THE OFFSET REGISTER
8452	036500	000032			RPOF		
8453	036502	036704			C17		
8454	036504	116266	000001	000001	MOVB	1(R2), 1(SP)	, COMBINE "FMT22", "EC ", AND "HCI"
8455	036512	004037	041642		JSR	RO, WRT RP	, LOAD "FMT22", "ECI", AND/OR "HCI"
8456	036516	000032			RPGF		
8457	036520	036704			C17		
8458	036522	000436			BR	12\$	
8459	036524	122703	000141	6\$	CMPB	#141,R3	, IS IT A "GET REGISTER" COMMAND?
8460	036530	001023			BNE	10\$	, BRANCH IF NO
8461	036532	016203	000006	7\$	MOV	6(R2), R3	, POINTS TO 1ST ADDRESS OF WHERE
8462							, TO PUT THE REGISTER(S)
8463	036536	116237	000010	036554	MOVB	10(R2), 9\$	, INIT THE INDEX FOR THE FIRST REG
8464	036544	116205	000011		MOVB	11(R2), R5	, INDEX OF LAST REG TO MOVE
8465	036550	004037	041462	8\$	JSR	RO, RD RP	, READ RPO4/5/6 REGISTER

8466	036554	000000		95	RPCS1		; INDEX OF REG. TO READ
8467	036556	036704			C17		
8468	036560	012623			MOV	(SP)+, (R3)+	, GET THE CONTENTS OF RH11/RPO4/5/6 REG
8469	036562	023705	036554		CMP	95, R5	, LAST REG. BEEN READ?
8470	036566	001414			BEQ	125	; GET OUT IF YES
8471	036570	062737	000002	036554	ADD	#2, 95	; INCREASE THE INDEX BY 2
8472	036576	000764			BR	85	; LOOP--MORE TO READ
8473	036600	122703	000145		CMPB	#145, R3	; IS IT A "SELECT DRIVE" COMMAND?
8474	036604	001405			BEQ	125	; BRANCH IF YES
8475	036606	010346			MOV	R3, -(SP)	, LOAD THE COMMAND
8476	036610	004037	041642		JSR	RO, WRT RP	
8477	036614	000000			RPCS1		
8478	036616	036704			C17		
8479	036620	004737	042712		JSR	PC, POPQUE	, REMOVE REQ FROM QUEUE
8480	036624	052762	000200	000016	BIS	#BIT07, 16(R2)	, SET THE "DONE" BIT
8481	036632	005737	034454		TST	SAVEFG	, SAVE THE RH11/RPO4/5/6 REGISTERS?
8482	036636	100002			BPL	135	, BRANCH IF NO
8483	036640	004737	042034		JSR	PC, SVRH11	, YES--GO SAVE THE REGISTERS
8484	036644	000207			RTS	PC	, RETURN TO USER
8485	036646	006301			ASL	R1	
8486	036650	012761	001750	034460	MOV	#1000, TIMER(R1)	, SET A ONE SECOND TIMER
8487	036656	006201			ASR	R1	
8488	036660	112761	000001	034356	MOVB	#1, DRVACT(R1)	, SET THE DRIVE ACTIVE
8489	036666	000207			RTS	PC	, RETURN TO THE USER
8490	036670	010346			MOV	R3, -(SP)	, LOAD THE COMMAND
8491	036672	004037	041642		JSR	RO, WRT RP	
8492	036676	000000			RPCS1		
8493	036700	036704			C17		
8494	036702	000761			BR	C15	
8495	036704	032764	010000	000010	C17	BIT #BIT12, RPCS2(R4)	, DRIVE NON-EXISTENT ?
8496	036712	001034			BNE	C18	, BR IF YES
8497	036714	005702			TST	R2	, ANYTHING IN QUEUE ?
8498	036716	001405			BEQ	C17B	, BR IF NOT
8499	036720	012762	104000	000016	MOV	#BIT15'BIT11, 16(R2)	; SET "PARITY" ERROR INDICATOR
8500	036726	004737	042034		JSR	PC, SVRH11	, GO SAVE THE RH11/RPO4/5/6 REGISTERS
8501	036732	012746	000111		C17B	MOV #111, -(SP)	DO A "DRIVE CLEAR"
8502	036736	004037	041642		JSR	RO, WRT. RP	
8503	036742	000000			RPCS1		
8504	036744	037004			C18		
8505	036746	004737	042574		JSR	PC, EMPTYQ	, EMPTY THE QUEUE
8506	036752	105061	034434		CLRB	ULDFLG(R1)	, CLEAR THE UNLOAD IN QUEUE FLAG
8507	036756	105061	034356		CLRB	DRVACT(R1)	, DRIVE IS IDLE
8508	036762	020137	034500		CMP	R1, DTUW	, IF THIS DRIVE HAD AN I/O REQUEST
8509	036766	001005			BNE	15	, IN PROGRESS CLEAR ALL OF THE FLAGS
8510	036770	005037	034426		CLR	TRNSWT	
8511	036774	012737	177777	034500	MOV	#-1, DTUW	
8512	037002	000207			RTS	PC	
8513	037004	104412			C18.	SAVREG	; SAVE RO - R5
8514	037006	032764	010000	000010	C18	BIT #BIT12, RPCS2(R4)	, IS 'NED' SET ?
8515	037014	001002			BNE	15	, BR IF YES
8516	037016	005001			CLR	R1	
8517	037020	005003			CLR	R3	
8518	037022	105761	034356		15	TSTB DRVACT(R1)	; DRIVE ACTIVE?
8519	037026	001443			BEQ	55	, BRANCH IF NO
8520	037030	013702	034426		MOV	TRNSWT, R2	, GET THE "TRANSFER WAIT" QUEUE
8521	037034	020137	034500		CMP	R1, DTUW	, DID THIS DRIVE HAVE AN I/O IN PROGRESS?

```

8522 037040 001402          BEQ      2$          ; BRANCH IF YES
8523 037042 004737 042670   JSR      PC,GETREQ  ; GET THE DPB POINTER
8524 037046 005702          TST      R2          ; QUEUE ENTRY FOR DRIVE ?
8525 037050 001415          BEQ      4$          ; BR IF NOT
8526 037052 032764 010000 000010 BIT      #BIT12,RPCS2(R4) ; 'NED' SET ?
8527 037060 001404          BEQ      3$          ; BR IF NOT
8528 037062 012762 100002 000016 MOV      #BIT15!BIT01,16(R2) ; SET 'DRIVE NON-EXISTENT' INDICATOR
8529 037070 000405          BR       4$          ; CONTINUE
8530 037072 012762 102000 000016 3$ MOV      #BIT15!BIT10,16(R2) ; SET "NON-CLEARABLE PARITY" ERROR INDICATOR
8531 037100 004737 042034   JSR      PC,SVRH11  ; SAVE RH11/RPO4/5/6 REGISTERS
8532 037104 012763 177777 034460 4$ MOV      #-1,TIMER(R3) ; STOP THE TIMER
8533 037112 105061 034356   CLR     DRVACT(R1) ; SET "DRIVE ACTIVE" TO IDLE
8534 037116 020137 034500   CMP     R1,DTUW    ; IS THIS DRIVE SETUP FOR A TRANSFER
8535 037122 001005          BNE     5$          ; BR IF NOT
8536 037124 012737 177777 034500 MOV      #-1,DTUW    ; RESET THE INDICATOR
8537 037132 005037 034426   CLR     TRNSWT     ; CLEAR THE TRANSFER QUEUE
8538 037136 105061 034434          CLR     ULDFLG(R1) ; CLEAR UNLOAD FLAG
8539 037142 032764 010000 000010 5$ BIT      #BIT12,RPCS2(R4) ; 'NED' SET ?
8540 037150 001021          BNE     6$          ; BR IF YES
8541 037152 005201          INC     R1          ; MOVE TO THE NEXT DRIVE
8542 037154 062703 000002   ADD     #2,R3
8543 037160 042701 177770   BIC     #C7,R1
8544 037164 001316          BNE     1$          ; BRANCH IF MORE DRIVES
8545 037166 012737 177777 034500 MOV      #-1,DTUW    ; NO DATA TRANSFERS UNDERWAY
8546 037174 005037 034426   CLR     TRNSWT     ; CLEAR THE 'TRANSFER WAIT' QUEUE
8547 037200 004737 042516   JSR      PC,CLRQUE  ; CLEAR ALL OF THE REQUEST QUEUES
8548 037204 012764 000040 000010 MOV      #BIT05,RPCS2(R4) ; DO A MASSBUS INIT
8549 037212 000406          BR       7$          ; CONTINUE
8550 037214 004737 042574          6$ JSR      PC,EMPTYQ  ; CLEAR THE DRIVE'S QUEUE
8551 037220 105061 034366   CLR     DRVSTA(R1) ; SET DRIVE TO OFFLINE
8552 037224 105061 034376   CLR     DRVTP(R1)  ; CLEAR THE DRIVE TYPE INDICATOR
8553 037230 004737 042152          7$ JSR      PC,SET IE  ; SET "IE" WITHOUT "TRE"
8554 037234 104413          RESREG ; RESTORE R0 - R5
8555 037236 000207          RTS      PC         ; RETURN
8556
8557          ; LOOK AHEAD ROUTINE
8558
8559          ; CALL
8560          ;     MOV      #DRVNUM,R1 ; DRIVE NUMBER
8561          ;     MOV      #DPB,R2    ; POINT TO DPB
8562          ;     JSR      RO,LA     ; GO CHECK THE WINDOW
8563          ;     RETURN1 ; ERROR RETURN
8564          ;     RETURN2 ; START A SEARCH
8565          ;     RETURN3 ; START A DATA TRANSFER
8566
8567 037240 013704 034514          LA     MOV      RPADR,R4 ; GET RPCS1'S ADDRESS
8568 037244 010164 000010          MOV      R1,RPCS2(R4) ; SELECT DRIVE
8569 037250 004037 041462          JSR      RO,RO RP    ; READ CURRENT CYLINDER
8570 037254 000036          RPCC
8571 037256 037370          4$
8572 037260 022662 000012          CMP     (SP)+,12(R2) ; IS CURRENT CYLINDER=DESIRED
8573          ; CYLINDER?
8574 037264 001037          BNE     3$          ; EXIT IF NO
8575 037266 105261 034444          INCB   LACNT(R1)    ; INCREMENT THE LOOK AHEAD COUNT
8576 037272 126137 034444 034522 CMP     LACNT(R1),MXLACT ; EXCEED MAX?
8577 037300 003026          BGT     2$          ; BRANCH IF YES
    
```

```

8578 037302 116203 000010      MOVB    10(R2),R3      ;GET DESIRED SECTOR ADDRESS AND
8579 037306 000303      SWAB    R3            ;MULT. BY 64--ALIGN WITH
8580 037310 006203      ASR     R3            ;LOOK AHEAD REGISTER
8581 037312 006203      ASR     R3
8582 037314 012737 000340 177776      MOV     #340,2#PS     ;PRIORITY LEVEL "7"
8583 037322 004037 041462      JSR     RO,RO RP      ;READ LOOK AHEAD REGISTER
8584 037326 000020      RPLA
8585 037330 037370      4$
8586 037332 162603      SUB     (SP)+,R3      ;CALCULATE THE DELTA
8587 037334 002002      BGE     1$
8588 037336 062703 002600      ADD     #(<22 *64 >),R3 ;MAKE THE DELTA POSITIVE
8589 037342 023703 034524      1$     CMP     MXDLTA,R3  ;CHECK THE DELTA TO SEE
8590 037346 002406      BLT     3$           ;IF IT IS WITHIN THE
8591 037350 023703 034526      CMP     MNDLTA,R3    ;WINDOW---IF YES, ZERO
8592 037354 002003      BGE     3$           ;THE LOOK AHEAD COUNT
8593 037356 105061 034444      2$     CLRB   LACNT(R1) ;AND TAKE THE I/O EXIT
8594 037362 005720      TST     (RO)+
8595 037364 005720      3$     TST     (RO)+    ;ADJUST THE RETURN ADDRESS
8596 037366 000402      BR      5$           ;EXIT
8597 037370 004737 036704      4$     JSR     PC,C17    ;PROCESS THE ERROR
8598 037374 000200      5$     RTS      RO      ;RETURN
8599
8600      ; INTERRUPT SERVICE ROUTINE
8601
8602 037376 112737 000001 034432 1SR    MOVB    #1,ACTDRV    ;SET "ACTIVE DRIVER" FLAG
8603 037404 104412      SAVREG
8604 037406 013704 034514      MOV     RPADR,R4     ;ADDRESS OF RHSCS1
8605 037412 013701 034500      MOV     DTUW,R1      ;GET "DATA TRANSFER UNDERWAY" INDICATOR
8606 037416 002403      BLT     1$           ;BRANCH IF NO DATA TRANSFER UNDERWAY
8607 037420 004737 037442      JSR     PC,TD        ;CALL TRANSFER DONE
8608 037424 000402      BR      2$           ;EXIT
8609 037426 004737 037602      1$     JSR     PC,SC    ;CALL SPECIAL CONDITIONS
8610 037432 104413      2$     RESREG
8611 037434 105037 034432      CLRB   ACTDRV       ;CLEAR "ACTIVE DRIVER" FLAG
8612 037440 000002      RTI
8613
8614      ; TRANSFER DONE ROUTINE
8615
8616 037442 105061 034356      TD     CLRB   DRVACT(R1) ;SET DRIVE ACTIVE INDICATOR TO IDLE
8617 037446 012737 177777 034500      MOV     #-1,DTUW    ;NO DATA TRANSFERS UNDERWAY
8618 037454 006301      ASL     R1
8619 037456 012761 177777 034460      MOV     #-1,TIMER(R1) ;CANCEL TIMEOUT
8620 037464 006201      ASR     R1
8621 037466 013702 034426      MOV     TRNSWT,R2   ;GET "DPB" ADDRESS FROM THE
8622 037472 005037 034426      CLR     TRNSWT      ;TRANSFER WAIT QUEUE--CLEAR QUEUE
8623 037476 052762 000200 000016      BIS     #BIT07,16(R2) ;SET DONE
8624 037504 010164 000010      MOV     R1,RPCS2(R4) ;SELECT THE DRIVE
8625 037510 004037 041462      JSR     RO,RO RP    ;TRANSFER ERROR(TRE=1)?
8626 037514 000000      RPCS1
8627 037516 036704      C17
8628 037520 006126      ROL     (SP)+
8629 037522 100413      BMI     3$           ;BR IF YES
8630 037524 005737 034454      TST     SAVEFG      ;SAVE THE RH11/RPO4/5/6 REGISTERS?
8631 037530 100002      BPL     1$           ;BRANCH IF NO
8632 037532 004737 042034      JSR     PC,SVRH11   ;YES--SAVE THE REGISTERS
8633 037536 004737 035574      1$     JSR     PC,OPT    ;CALL OPTIMIZER

```

8634	037542	000417			BR	SC		, CHECK OTHER DRIVES
8635	037544	012714	000113		MOV	#113, (R4)		, RELEASE THE DRIVE
8636	037550	000414			BR	SC		, CHECK FOR OTHER DRIVES
8637	037552	052762	100100	000016	3\$	BIS	#BIT15, BIT06, 16(R2)	, SET DATA ERROR FLAG
8638	037560	004737	042574		JSR	PC, EMPTYQ		, EMPTY THE "DRIVE'S WAIT" QUEUE
8639	037564	004737	042034		JSR	PC, SVRH11		, SAVE THE RH11/RPO4/5/6 REGISTERS
8640	037570	012714	040111		MOV	#40111, (R4)		, ISSUE A "DRIVE CLEAR"
8641	037574	012714	000113		MOV	#113, (R4)		, ISSUE A RELEASE TO THE DRIVE
8642	037600	000400			BR	SC		, CHECK FOR OTHER DRIVES
8643								
8644								, SPECIAL CONDITION ROUTINE
8645								
8646	037602	116403	000016		SC	MOVB	RPAS(R4), R3	, READ "RPAS"
8647	037606	001014				BNE	2\$	, BRANCH IF ANY 'ATA' BITS SET
8648	037610	004037	041462			JSR	RD, RD RP	, READ CONTROL AND STATUS REGISTER
8649	037614	000000				RPCS1		
8650	037616	037004				CIB		
8651	037620	106126				ROLB	(SP)+	, IS "IE"=1?
8652	037622	100405				BMI	1\$	, YES, NO DRIVES TO CHECK
8653	037624	004037	042754			JSR	RD, ES SAV	, SAVE THE ADDRESS IN 'SESCAPE'
8654	037630	104001				ERROR	1	, REPORT AN ILLEGAL INTERRUPT
8655	037632	004737	042152			JSR	PC, SET 2	, SET INTERRUPT ENABLE
8656	037636	000207			1\$	RTS	PC	, RETURN
8657	037640	005046			2\$	CLR	-(SP)	, PROCESS ALL DRIVES THAT HAVE
8658	037642	110316				MOVB	R3, (SP)	, AN "ATA"=1
8659	037644	012703	000001			MOV	#1, R3	
8660	037650	005001				CLR	R1	
8661	037652	030316			SC3	BIT	R3, (SP)	, ATA=1?
8662	037654	001005				BNE	SC5	, YES--BRANCH
8663	037656	005201			SC4	INC	R1	, MOVE TO THE NEXT DRIVE
8664	037660	106303				ASLB	R3	
8665	037662	001373				BNE	SC3	, BRANCH IF MORE TO CHECK?
8666	037664	005726				TST	(SP)+	, CLEAN OFF THE STACK
8667	037666	000207				RTS	PC	, RETURN TO USER
8668	037670	105761	034406		SC5	TSTB	DPINT(R1)	, INITIALIZING THE DRIVE ?
8669	037674	001402				BEQ	1\$	, BR IF NOT
8670	037676	000137	040574			JMP	SC13	, PROCESS THE DRIVE
8671	037702	105761	034416		1\$	TSTB	DPRQS(R1)	, PORT REQUEST OUTSTANDING ?
8672	037706	001402				BEQ	2\$	, BR IF NOT
8673	037710	000137	040574			JMP	SC13	, START THE OUTSTANDING COMMAND
8674	037714	105761	034366		2\$	TSTB	DRVSTA(R1)	, CHECK THE DRIVE STATUS
8675	037720	003025				BGT	5\$	, BRANCH IF ONLINE
8676	037722	105761	034434			TSTB	ULDFLG(R1)	, UNLOAD IN PROGRESS?
8677	037726	003422				BLE	5\$	, BRANCH IF NOT
8678	037730	004737	042670			JSR	PC, GETREQ	, GET DPB POINTER
8679	037734	004737	042034			JSR	PC, SVRH11	, SAVE THE RH11/RPO4/5/6 REGISTERS
8680	037740	004737	040524			JSR	PC, SC12	, SAVE RPS1, RPER1, RPER2, AND RPER3
8681								, ALSO DO A DRIVE INIT (DRVINT)
8682	037744	105761	034366			TSTB	DRVSTA(R1)	, DID DRIVE COME ONLINE?
8683	037750	003416				BLE	6\$	, NO---BRANCH
8684	037752	032737	040000	034346		BIT	#BIT14, RPERRS	, WAS THERE AN ERROR?
8685	037760	001002				BNE	3\$	, BR IF ERROR
8686	037762	000137	040434			JMP	SC11	, NO ERROR
8687	037766	013705	034350		3\$	MOV	RPERRS+2, R5	, YES -- PICKUP RPER1 AND
8688	037772	000502				BR	SC6A	, GO PROCESS THE ERROR
8689	037774	105761	034356		5\$	TSTB	DRVACT(R1)	, DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?

8690	040000	001033			BNE	SC6		, BR IF EITHER
8691	040002	004737	040524		JSR	PC, SC12		; SAVE RPDS1, RPER1, RPER2, AND RPER3
8692								; ALSO DO A DRVINT
8693	040006	105761	034406	6\$	TSTB	DPINT(R1)		; TRYING TO INIT THE DPIPE ?
8694	040012	001321			BNE	SC4		; BR IF YES, CHECK ON MORE DRIVES
8695	040014	105761	034366		TSTB	DRVSTA(R1)		; CHECK ON DRIVE'S STATUS
8696	040020	100412			BMI	7\$		; BR IF UNSAFE
8697	040022	032737	020000	034354	BIT	#BIT13, RPERRS+6		; ADDRESS PLUG CHANGED ?
8698	040030	001013			BNE	8\$		; BR IF YES
8699	040032	012746	000113		MOV	#113, -(SP)		; RELEASE COMMAND
8700	040036	004037	041642		JSR	RD, WRT RP		; WRITE THE COMMAND INTO RPCS1
8701	040042	000000			RPCS1			; REGISTER INDEX
8702	040044	040404			SC8			; PARITY EXIT ADDRESS
8703	040046	011605		7\$	MOV	(SP), R5		; PICKUP (RPAS) BEFORE THE ERROR CALL
8704	040050	004037	042754		JSR	RD, ES SAV		; SAVE THE ADDRESS IN '\$ESCAPE'
8705	040054	104002			ERROR	2		; REPORT THE UNEXPECTED ATTENTION
8706	040056	000677			BR	SC4		; GO CHECK FOR MORE ATA'S
8707	040060			8\$				
8708	040060	004037	042754		JSR	RD, ES SAV		; SAVE THE ADDRESS IN '\$ESCAPE'
8709	040064	104005			ERROR	5		; REPORT THE ADDRESS PLUG CHANGE
8710	040066	000673			BR	SC4		; CHECK FOR MORE DRIVES
8711	040070	006301		SC6	ASL	R1		; SETUP TO ADDRESS WORDS
8712	040072	012761	177777	034460	MOV	#-1, TIMER(R1)		; STOP THE TIMER
8713	040100	006201			ASR	R1		; RESTORE THE DRIVE ADDRESS
8714	040102	004737	042670		JSR	PC, GETREQ		; GET THE DPB POINTER FROM THE QUEUE
8715	040106	010164	000010		MOV	R1, RPCS2(R4)		; SELECT DRIVE
8716	040112	004037	041462		JSR	RD, RD RP		; READ THE RPO4'S STATUS REG
8717	040116	000012			RPDS1			
8718	040120	040404			SC8			
8719	040122	011605			MOV	(SP), R5		; AND PUT IT IN R5
8720	040124	006126			ROL	(SP)+		; WAS THERE AN ERROR?
8721	040126	100407			BMI	1\$		; BR IF ERROR
8722	040130	105761	034356		TSTB	DRVACT(R1)		; CHECK DRIVE'S STATE
8723	040134	003137			BGT	SC11		; BR IF DRIVE ACTIVE WITH ORDER
8724	040136	052762	100210	000016	BIS	#BIT15'BIT07'BIT03, 16(R2)		; INFORM USER OF ERROR RECOVER COMPLETION
8725	040144	000470			BR	SC7		
8726	040146	004037	041462	1\$	JSR	RD, RD RP		; READ ERROR REGISTER #1
8727	040152	000014			RPER1			
8728	040154	040404			SC8			
8729	040156	012605			MOV	(SP)+, R5		; AND SAVE IT IN R5
8730	040160	004737	042034		JSR	PC, SVRH11		; SAVE RH11/RPO4/5/6 REGISTERS
8731	040164	012746	000111		MOV	#111, -(SP)		; ISSUE A DRIVE CLEAR
8732	040170	004037	041642		JSR	RD, WRT RP		
8733	040174	000000			RPCS1			
8734	040176	040404			SC8			
8735	040200	006105		SC6A	ROL	R5		; WAS 'UNSAFE' CONDITION =1?
8736	040202	100406			BMI	1\$		; BRANCH IF YES
8737	040204	005702			TST	R2		; ANYTHING IN QUEUE ?
8738	040206	001447			BEQ	SC7		; BR IF NOT
8739	040210	052762	100240	000016	BIS	#BIT15'BIT07'BIT05, 16(R2)		; INFORM USER OF ERROR
8740	040216	000443			BR	SC7		
8741	040220	004037	041462	1\$	JSR	RD, RD RP		; READ DRIVE STATUS REG #1
8742	040224	000012			RPDS1			
8743	040226	040404			SC8			
8744	040230	011605			MOV	(SP), R5		; SAVE RPDS1 IN R5
8745	040232	006126			ROL	(SP)+		; "ERR"=1?

8746	040234	100011			BPL	25	,BR IF NO--UNSAFE CLEARED
8747	040236	112761	177777	034366	MOVB	#-1,DRVSTA(R1)	,DRIVE IS UNSAFE
8748	040244	004737	042034		JSR	PC,SVRH11	,SAVE RH11/RPO4/5/6 REGISTERS
8749	040250	052762	110000	000016	BIS	#BIT15!BIT12,16(R2)	,INFORM USER OF UNSAFE ERROR
8750	040256	000423			BR	SC7	
8751	040260	032705	010000		BIT	#BIT12,R5	;"MOL" = 1 ?
8752	040264	001015			BNE	35	,BR IF YES
8753	040266	112761	177777	034356	MOVB	#-1,DRVACT(R1)	,ACTIVE ERROR RECOVER
8754	040274	112761	000001	034366	MOVB	#1,DRVSTA(R1)	,ONLINE
8755	040302	006301			ASL	R1	
8756	040304	012761	072460	034460	MOV	#30000, TIMER(R1)	,START 30 SECOND TIMER
8757	040312	006201			ASR	R1	
8758	040314	000137	037656		JMP	SC4	
8759	040320	052762	100220	000016	BIS	#BIT15!BIT07!BIT04,16(R2)	,INFORM USER OF ERROR
8760	040326	105061	034356		CLRB	DRVACT(R1)	,DRIVE IS IDLE
8761	040332	004737	042574		JSR	PC,EMPTYQ	,DUMP THE QUEUE
8762	040336	105761	034434		TSTB	ULDFLG(R1)	,UNLOAD IN PROGRESS OR QUEUE?
8763	040342	003002			BGT	15	,BR IF NOT
8764	040344	105061	034434		CLRB	ULDFLG(R1)	,CLEAR UNLOAD FLAG
8765	040350	116164	034502	000016	MOVB	ATABIT(R1),RPAS(R4)	,CLEAR ATTENTION BIT
8766	040356	105761	034366		TSTB	DRVSTA(R1)	,IS THE DRIVE UNSAFE ?
8767	040362	100406			BMI	25	,BR IF IT IS
8768	040364	012746	000113		MOV	#113,-(SP)	,RELEASE COMMAND
8769	040370	004037	041642		JSR	RD,WRT RP	,WRITE THE COMMAND INTO RPCS1
8770	040374	000000			RPCS1		,REGISTER INDEX
8771	040376	040404			SC8		,PARITY EXIT ADDRESS
8772	040400	000137	037656		JMP	SC4	,CHECK FOR MORE DRIVES
8773	040404	105761	034356		TSTB	DRVACT(R1)	,IS DRIVE IDLE?
8774	040410	001405			BEQ	15	,YES--BRANCH
8775	040412	004737	042670		JSR	PC,GETREQ	,GET DPB POINTER
8776	040416	004737	036704		JSR	PC,C17	,PROCESS THE PARITY ERROR
8777	040422	000402			BR	25	,CONTINUE
8778	040424	004737	036732		JSR	PC,C17B	,PROCESS THE UNCORRECTABLE PARITY ERROR
8779	040430	000137	037656		JMP	SC4	,CHECK MORE DRIVES
8780	040434	105761	034434		TSTB	ULDFLG(R1)	, "UNLOAD IN PROGRESS"?
8781	040440	003402			BLE	15	,BRANCH IF NO
8782	040442	105061	034434		CLRB	ULDFLG(R1)	,CLEAR UNLOAD FLAG
8783	040446	105061	034356		CLRB	DRVACT(R1)	,SET DRIVE IDLE
8784	040452	136137	034502	034430	BITB	ATABIT(R1),SRCHWT	,DOING A SEARCH OPERATION FOR
8785							;AN I/O COMMAND?
8786	040460	001012			BNE	25	,BRANCH IF YES
8787	040462	004737	042712		JSR	PC,POPQUE	,REMOVE REQUEST FROM QUEUE
8788	040466	052762	000200	000016	BIS	#BIT07,16(R2)	,SET "DONE" BIT
8789	040474	005737	034454		TST	SAVEFG	,SAVE THE REGISTERS?
8790	040500	100002			BPL	25	,BRANCH IF NO
8791	040502	004737	042034		JSR	PC,SVRH11	,YES--SAVE ALL OF THE RH11/RPO4/5/6 REG'S
8792	040506	116164	034502	000016	MOVB	ATABIT(R1),RPAS(R4)	,CLEAR ATTENTION BIT
8793	040514	004737	035574		JSR	PC,OPT	,START A REQUEST
8794	040520	000137	037656		JMP	SC4	,CHECK FOR MORE DRIVES
8795	040524	010164	000010		MOV	R1,RPCS2(R4)	,SELECT DRIVE
8796	040530	016437	000012	034346	MOV	RPDS1(R4),RPERRS	,SAVE THE FOUR REGISTERS THAT
8797	040536	016437	000014	034350	MOV	RPER1(R4),RPERRS+2	,WILL TELL US SOMETHING
8798	040544	016437	000040	034352	MOV	RPER2(R4),RPERRS+4	
8799	040552	016437	000042	034354	MOV	RPER3(R4),RPERRS+6	
8800	040560	004037	034744		JSR	RD,DRVINT	,INIT THE STATE OF THE DRIVE
8801	040564	000401			BR	15	,TAKE ERROR EXIT

8802	040566	000207			RTS	PC	, RETURN	
8803	040570	005726		15	TST	(SP)+	, POP PC OFF OF THE STACK	
8804	040572	000704			BR	SC8	, PROCESS THE PARITY ERROR	
8805	040574	006301			ASL	R1	, SETUP TO ADDRESS WORDS	
8806	040576	012761	177777	034460	MOV	#-1, TIMER(R1)	, STOP THE TIMER	
8807	040604	006201			ASR	R1		
8808	040606	010164	000010		MOV	R1, RPCS2(R4)	, SELECT THE DRIVE	
8809	040612	116164	034502	000016	MOVB	ATABIT(R1), RPAS(R4)	, CLEAR THE ATTENTION BIT	
8810	040620	032714	004000		BIT	#BIT11, (R4)	, DRIVE AVAILABLE ?	
8811	040624	001006			BNE	15	, BR IF AVAILABLE	
8812	040626	006301			ASL	R1		
8813	040630	012761	023420	034460	MOV	#10000, TIMER(R1)	, START 10 SEC TIMER AGAIN	
8814	040636	006201			ASR	R1		
8815	040640	000433			BR	35	, EXIT	
8816	040642	105761	034406		15	TSTB	DPINT(R1)	, INITIALIZING THE DRIVE ?
8817	040646	001424			BEQ	25	, BR IF NOT	
8818	040650	105061	034406		CLRB	DPINT(R1)	, CLEAR THE INIT INDICATOR	
8819	040654	004037	034744		JSR	RD, DRVINT	, GO INIT THE DRIVE	
8820	040660	000240			NOP		, DUMMY PARITY ERROR RETURN	
8821	040662	105761	034366		TSTB	DRVSTA(R1)	, DRIVE ONLINE ?	
8822	040666	003014			BGT	25	, BR IF YES -- START ORDER	
8823	040670	005702			TST	R2	, QUEUE ENTRY FOR THE DRIVE	
8824	040672	001416			BEQ	35	, BR IF NOT	
8825	040674	004737	042670		JSR	PC, GETREQ	, GET DPB ADDRESS	
8826	040700	052762	140000	000016	BIS	#BIT15'BIT14, 16(R2)	, INFORM USER THAT DRIVE OFFLINE	
8827	040706	004737	042034		JSR	PC, SVRH11	, SAVE THE REGISTERS	
8828	040712	004737	042574		JSR	PC, EMPTYQ	, EMPTY THE REQUEST QUEUE	
8829	040716	000404			BP	35		
8830	040720	105061	034416		25	CLRB	DPRQS(R1)	, CLEAR THE PORT REQUEST INDICATOR
8831	040724	004737	035574		JSR	PC, OPT	, START THE PENDING REQUEST	
8832	040730	000137	037656		35	JMP	SC4	, PROCESS OTHER DRIVES
8833								
8834							, RPO4/5/6 TIMER ROUTINE	
8835							, CALL	
8836						MOV	#TIME, -(SP)	, ELAPSED TIME IN MILLISECONDS ON THE STACK
8837						JSR	PC, RPTMR	, CALL RPO4, 5/6 TIME ROUTINE
8838								
8839	040734	005737	034432		RPTMR	TST	ACTDRV	, CHECK "ACTDRV & ACTSTR"
8840	040740	001030				BNE	45	, IF NON ZERO EXIT
8841	040742	112737	000001	034433		MOVB	#1, ACTSTR	, SET "ACTSTR"
8842	040750	104412				SAVREG		, SAVE R0 - R5
8843	040752	005001				CLR	R1	, START WITH DRIVE 0
8844	040754	005003				CLR	R3	
8845	040756	005763	034460		15	TST	TIMER(R3)	, IS THE TIMER RUNNING?
8846	040762	002407				BLT	25	, BRANCH IF NO
8847	040764	166663	000002	034460		SUB	2(SP), TIMER(R3)	, COUNT THE INTERVAL
8848	040772	003003				BGT	25	, BR IF NO SOFTWARE TIMEOUT
8849	040774	004737	041026			JSR	PC, STO	, CALL SOFTWARE TIMEOUT ROUTINE
8850	041000	000405				BR	35	, GO TO THE EXIT
8851	041002	005201			25	INC	R1	, MOVE TO NEXT DRIVE
8852	041004	005723				TST	(R3)+	
8853	041006	022701	000010			CMP	#8, R1	, OUT OF DRIVES?
8854	041012	003361				BGT	15	, BRANCH IF NO
8855	041014	104413			35	RESREG		, RESTORE R0 - R5
8856	041016	105037	034433			CLRB	ACTSTR	, ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
8857	041022	012616			45	MOV	(SP)+, (SP)	, ADJUST THE STACK

```

8858 041024 000207          RTS      PC          ;RETURN
8859
8860          , SOFTWARE TIMEOUT ROUTINE
8861          ,
8862          , NOTE THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
8863          , OR GREATER
8864          ,
8865          , CALL   STO
8866          ,       MOV      #DRVNUM, R1      , DRIVE NUMBER
8867          ,       JSR      PC, STO          , CALL
8868          ,       RETURN
8869
8870 041026 010146          STO      MOV      R1, -(SP)      , SAVE R1
8871 041030 010346          MOV      MOV      R3, -(SP)      , SAVE R3
8872 041032 013704 034514          MOV      MOV      RPADR, R4      , GET ADDRESS OF 'RPCS1"
8873 041036 010164 000010          MOV      MOV      R1, RPCS2(R4)   , SELECT THE DRIVE
8874 041042 004037 041462          JSR      RD, RD RP      , READ "DRIVE STATUS REG"
8875 041046 000012          RPDS1
8876 041050 041350          ST05
8877 041052 105726          TSTB    (SP)+          , IS "DRY"=1?
8878 041054 100477          BMI     ST02          , BR IF YES
8879 041056 105761 034406          ST01  TSTB    DPINT(R1)      , TRYING TO INITIALIZE THE DRIVE ?
8880 041062 001074          BNE     ST02          , BR IF YES
8881 041064 105761 034416          TSTB    DPRQS(R1)      , OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8882 041070 001071          BNE     ST02          , BR IF YES
8883 041072 013702 034426          MOV      TRNSWT, R2    , PICKUP TRANSFER WAIT QUEUE
8884 041076 020137 034500          CMP     R1, DTUW      , TRANSFER UNDERWAY ON THIS DRIVE?
8885 041102 001402          BEQ     1$           , BRANCH IF YES
8886 041104 004737 042670          JSR     PC, GETREQ    , GET DPB ADDRESS
8887 041110 052762 101000 000016 1$          BIS    #BIT15|BIT09, 16(R2) ; SET THE ERROR FLAGS
8888 041116 004737 042034          JSR     PC, SVRH11    , SAVE RH11/RPO4/5/6 REGISTERS
8889 041122 012764 000040 000010          MOV    #BIT05, RPCS2(R4) , "INIT" THE MASS BUS
8890 041130 105061 034356          CLRB   DRVACT(R1)    , DRIVE IS IDLE
8891 041134 105061 034434          CLRB   ULDFLG(R1)    , CLEAR THE UNLOAD FLAG
8892 041140 005001          CLR    R1           , START WITH DRIVE 0
8893 041142 005003          CLR    R3
8894 041144 004037 034744          2$  JSR     RD, DRVINT    , INIT THIS DRIVE
8895 041150 000477          BR     ST05          , PARITY ERROR RETURN
8896 041152 105761 034356          TSTB   DRVACT(R1)    , DRIVE IDLE BEFORE THE INIT ?
8897 041156 001414          BEQ    4$           , YES--BRANCH
8898 041160 013702 034426          MOV    TRNSWT, R2    , GET TRANSFER WAIT QUEUE
8899 041164 023701 034500          CMP    DTUW, R1      , WAS THERE I/O ON THIS DRIVE?
8900 041170 001402          BEQ    3$           , YES--BRANCH
8901 041172 004737 042670          JSR    PC, GETREQ    , GET THE DPB POINTER FROM QUEUE
8902 041176 052762 100400 000016 3$          BIS    #BIT15|BIT08, 16(R2) , INFORM USER OF INIT
8903 041204 105061 034356          CLRB   DRVACT(R1)    , SET DRIVE ACTIVE TO IDLE
8904 041210 105061 034434          4$  CLRB   ULDFLG(R1)    , NO UNLOAD
8905 041214 012763 177777 034460          MOV    #-1, TIMER(R3) , STOP THE TIMER
8906 041222 005723          TST    (R3)+        , UPDATE THE INDEX
8907 041224 005201          INC    R1           , INCREMENT THE DRIVE NUMBER
8908 041226 022701 000010          CMP    #8, R1       , LAST DRIVE BEEN CHECKED?
8909 041232 003344          BGT    2$           , NO--LOOP
8910 041234 012737 177777 034500          MOV    #-1, DTUW     , NO DATA TRANSFERS UNDERWAY
8911 041242 005037 034426          CLR    TRNSWT       , CLEAR TRANSFER WAIT QUEUE
8912 041246 004737 042516          JSR    PC, CLRQUE    , CLEAR ALL REQUEST QUEUES
8913 041252 000500          BR     ST09          , EXIT
    
```

```

8914 041254 116405 000016          ST02  MOV#  RPAS(R4),R5 ;READ ATTENTION REG
8915 041260 136105 034502          BIT#  ATABIT(R1),R5 ; IS ATTENTION FOR THIS DRIVE UP ?
8916 041264 001017                   BNE   ST03          ;YES--BRANCH
8917 041266 105761 034406          TST#  DPINT(R1)    ; TRYING TO INITIALIZE THE DRIVE ?
8918 041272 001031                   BNE   ST06          ; BR IF YES - DRIVE NOT ONLINE
8919 041274 105761 034416          TST#  DPRQS(R1)    ; OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8920 041300 001045                   BNE   ST07          ; BR IF YES - NO RESPONSE TO REQUEST
8921 041302 020137 034500          CMP   R1,DTUW      ; DATA TRANSFER UNDERWAY FOR THIS DRIVE
8922 041306 001263                   BNE   ST01          ; BR IF NO
8923 041310 004037 041462          JSR   RD, RD RP    ; YES--CHECK "RDY"
8924 041314 000000                   RPCS1
8925 041316 041350                   ST05
8926 041320 105726                   TST#  (SP)+
8927 041322 100255                   BPL   ST01          ; BR IF "RDY"=0
8928 041324 105761 034406          ST03  TST#  DPINT(R1) ; INITIALIZING THE DRIVE ?
8929 041330 001003                   BNE   1$           ; BR IF INIT PENDING
8930 041332 105761 034416          TST#  DPRQS(R1)    ; PORT REQUEST PENDING ?
8931 041336 001446                   BEQ   ST09          ; BR IF NOT
8932 041340 012763 177777 034460  1$   MOV   #-1,TIMER(R3) ; STOP THE TIMER
8933 041346 000442                   BR    ST09          ; EXIT
8934 041350 004737 037004          ST05  JSR   PC,C18   ; GO HANDLE THE PARITY ERROR
8935 041354 000437                   BR    ST09
8936 041356 105061 034406          ST06  CLR#  DPINT(R1) ; CLEAR THE INITIALIZE INDICATOR
8937 041362 105061 034366          CLR#  DRVSTA(R1)   ; SET UNIT OFFLINE
8938 041366 012763 177777 034460  MOV   #-1,TIMER(R3) ; STOP THE TIMER
8939 041374 004737 042670          JSR   PC,GETREQ    ; GET THE DPB ADDRESS
8940 041400 005702                   TST   R2           ; REQUEST IN QUEUE ?
8941 041402 001424                   BEQ   ST09          ; BR IF NOT
8942 041404 052762 140000 000016  BIS   #BIT15'BIT14,16(R2) ; INFORM THE USER DRIVE NOT AVAILABLE
8943 041412 000414                   BR    ST08          ; FINISH
8944 041414 012763 177777 034460  ST07  MOV   #-1,TIMER(R3) ; STOP THE TIMER
8945 041422 105061 034416          CLR#  DPRQS(R1)    ; CLEAR PORT REQUEST INDICATOR
8946 041426 004737 042670          JSR   PC,GETREQ    ; GET DPB ADDRESS
8947 041432 005702                   TST   R2           ; QUEUE ENTRY FOR DRIVE ?
8948 041434 001407                   BEQ   ST09          ; BR IF NONE
8949 041436 012762 100004 000016  MOV   #BIT15'BIT2,16(R2) ; INFORM USER OF PORT REQUEST ERROR
8950 041444 004737 042574          ST08  JSR   PC,EMPTYQ ; CLEAR THE QUEUE FOR THE DRIVE
8951 041450 004737 042034          JSR   PC,SURH11    ; SAVE THE REGISTERS
8952 041454 012603          ST09  MOV   (SP)+,R3 ; RESTORE R3
8953 041456 012601          MOV   (SP)+,R1    ; RESTORE R1
8954 041460 000207          RTS   PC           ; RETURN
8955
8956          ; ROUTINE TO READ A RH11/RPO4/5/6 REGISTER
8957          ;
8958          ; CALL
8959          ; JSR   RD, RD RP ; GO READ A REGISTER
8960          ; INDEX ; REG INDEX FROM BASE
8961          ; ERRADR ; ERROR ADDRESS--PROCESS ERROR STARTING
8962          ; ; AT THIS ADDRESS
8963          ; ; CONTENTS OF REG IS ON THE STACK
8964          ;
8965 041462 013737 034512 041630  RD RP  MOV   MCPENX,RD RP2 ; MAX RETRYS ALLOWED
8966 041470 011646          MOV   (SP),-(SP) ; SAVE RD FOR RETURN
8967 041472 013737 034514 041506  MOV   RPADR,RD ADR ; FORM THE DESIRED ADDRESS
8968 041500 062037 041506          ADD   (RD)+,RD ADR ; USING THE BASE AND THE INDEX
8969 041504 013727          RD RP1 MOV   @ (PC)+,(PC)+ ; READ THE DESIRED REGISTER OF THE PPO4

```

8970	041506	000000			RD ADR.	. WORD	0		, ADDRESS IS FORMED HERE
8971	041510	000000			RD WRD	. WORD	0		, REG. CONTENTS PUT HERE
8972	041512	013766	041510	000002		MOV	RD, WRD, 2(SP)		, RETURN IT TO THE USER
8973	041520	013746	034514			MOV	RPADR, -(SP)		, PUT THE ADDRESS ON THE STACK
8974	041524	062716	000010			ADD	#RPCS2, (SP)		, FORM THE ADDRESS OF RPCS2
8975	041530	032736	010000			BIT	#BIT12, @ (SP)+		, CHECK THE 'MED' BIT
8976	041534	001037				BNE	RD RP3		, BR IF DRIVE NON-EXISTENT
8977	041536	017746	172752			MOV	@RPADR, -(SP)		, READ RPCS1
8978	041542	032716	020000			BIT	#BIT13, (SP)		, DID MCPE SET?
8979	041546	001002				BNE	1\$		, BRANCH IF YES
8980	041550	022620				CMP	(SP)+, (RD)+		, ADJUST FOR RETURN
8981	041552	000432				BR	RD RP4		, EXIT
8982	041554				1\$				
8983	041554	004037	042754			JSR	RD, ES SAV		, SAVE THE ADDRESS IN '\$ESCAPE'
8984	041560	104003				ERROR	3		, REPORT "MCPE" ERROR
8985	041562	005737	034500			TST	DTUW		, DATA TRANSFER UNDERWAY?
8986	041566	100405				BMI	2\$		, NO--BRANCH
8987	041570	032716	040000			BIT	#BIT14, (SP)		, NO--"TRE"=1?
8988	041574	001402				BEQ	2\$		, NO--BRANCH
8989	041576	005726				TST	(SP)+		, YES--CLEAN OFF THE STACK AND
8990	041600	000415				BR	RD RP3		, TAKE THE FATAL ERROR EXIT
8991	041602	052716	040000		2\$	BIS	#BIT14, (SP)		, CLEAR "MCPE" BY SENDING A "1" TO "TRE"
8992	041606	000316				SWAB	(SP)		, POSITION BEFORE WRITING
8993	041610	013737	034514	041624		MOV	RPADR, 3\$		, FORM ADDRESS OF HIGH BYTE
8994	041616	005237	041624			INC	3\$		
8995	041622	112637				MOVB	(SP)+, @ (PC)+		, WRITE THE HIGH BYTE OF RPCS1
8996	041624	000000			3\$	WORD	0		, ADDRESS STORAGE.
8997	041626	005327				DEC	(PC)+		, EXCEEDED MAX RETRYS
8998	041630	000003			RD RP2	WORD	3		
8999	041632	002324				BGE	RD RP1		, BRANCH IF NO
9000	041634	011000			RD RP3	MOV	(RD), RD		, FATAL ERROR EXIT
9001	041636	012616				MOV	(SP)+, (SP)		
9002	041640	000200			RD RP4	RTS	RD		
9003									
9004									, ROUTINE TO WRITE A REGISTER
9005									,
9006									, CALL
9007						MOV	DATA, -(SP)		, DATA TO BE LOADED ON THE STACK
9008						JSR	RD, WRT RP		, CALL THE ROUTINE TO LOAD(WRITE) THE REG
9009						INDEX			, INDEX OF THE REGISTER TO BE LOADED
9010						ERRADR			, ADDRESS TO RETURN TO ON AN ERROR
9011						RETURN			, ERROR FREE RETURN
9012									
9013	041642	013737	034512	042016	WRT RP	MOV	MCPEMX, WRT R2		, MAX RETRYS ALLOWED
9014	041650	016637	000002	041730		MOV	2(SP), WRT WD		, SAVE THE WORD TO WRITE
9015	041656	012616				MOV	(SP)+, (SP)		, ADJUST THE STACK
9016	041660	012037	041732			MOV	(RD)+, WRT AD		, GET INDEX OF REGISTER TO BE WRITTEN
9017	041664	001015				BNE	1\$		, BRANCH IF NOT RPCS1
9018	041666	122737	000150	041730		CMPB	#150, WRT WD		, IS THE COMMAND FOR DATA TRANSFERS?
9019	041674	002411				BLT	1\$		, YES--DON'T GET THE OLD A16 & A17, & PSEL
9020	041676	004037	041462			JSR	RD, RD RP		, NO---COMBINE A16&A17, & PSEL WITH
9021	041702	000000				RPCS1			, THE COMMAND BEFORE SENDING IT TO
9022	041704	042024				WRT R3			, THE RH11/RPO4
9023	041706	000316				SWAB	(SP)		
9024	041710	042716	177770			BIC	# (7, (SP)		
9025	041714	112637	041731			MOVB	(SP)+, WRT WD+1		

```

9026 041720 063737 034514 041732 1$: ADD RPADR,WRT AD ;FORM THE ADDRESS OF THE DISK REG
9027 041726 012737 WRT R1: MOV (PC)+,@(PC)+ ;LOAD THE DESIRED REG.
9028 041730 000000 WRT WD: .WORD 0 ;WORD TO WRITE GOES HERE
9029 041732 000000 WRT AD: .WORD 0 ;ADDRESS IS FORMED HEPE
9030 041734 013746 034514 MOV RPADR,-(SP) ;PUT THE ADDRESS ON THE STACK
9031 041740 062716 000010 ADD #RPCS2,(SP) ;FORM THE ADDRESS OF RPCS2
9032 041744 032736 010000 BIT #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
9033 041750 001025 BNE WRT R3 ;BR IF DRIVE NON-EXISTENT
9034 041752 004037 041462 JSR RO,RO RP ;CHECK FOR PARITY ERROR ON WRITE
9035 041756 000014 RPER1
9036 041760 042024 WRT R3
9037 041762 032726 000010 BIT #BIT03,(SP)+
9038 041766 001420 BEQ WRT R4 ;BRANCH IF "PAR=0"
9039 041770 016037 177776 042002 MOV -2(RO),1$ ;PICKUP THE INDEX
9040 041776 004037 041462 JSR RO,RO RP ;READ THE REG.
9041 042002 000000 1$ .WORD 0 ;REG. INDEX
9042 042004 042024 WRT R3 ;RETURN TO THIS ADDRESS ON ERROR
9043 042006 004037 042754 JSR RO,ES SAV ;SAVE THE ADDRESS IN '$ESCAPE'
9044 042012 104004 ERROR 4 ;REPORT THE PARITY ON WRITE ERROR
9045 042014 005327 DEC (PC)+ ;DECREMENT THE ERROR COUNT
9046 042016 000003 WRT R2 .WORD 3 ;RETRY COUNTER
9047 042020 002342 BGE WRT R1 ;TRY AGAIN IF NOT FINISHED
9048 042022 005726 TST (SP)+ ;CLEAN OFF THE STACK
9049 042024 011000 WRT R3 MOV (RO),RO ;TAKE THE "PARITY ON WRITE" ERROR EXIT
9050 042026 000401 BR WRT R5 ;EXIT
9051 042030 005720 WRT R4 TST (RO)+ ;ADJUST FOR ERROR FREE EXIT
9052 042032 000200 WRT R5 RTS RO
9053
9054 ;ROUTINE TO SAVE THE RH11/RPO4/5/6 REGISTERS AS PER DPB+14
9055 ;
9056 ;CALL
9057 ;
9058 ; MOV #DPBNUM,R2 ;DPB POINTER TO R2
9059 ; JSR PC,SVRH11 ;SAVE THE DRIVES REG'S
9060 SVRH11 SAVREG ;SAVE RO - R5
9061 TST R2 ;QUEUE ENTRY FOR THE DRIVE ?
9062 BEQ 4$ ;BR IF NONE
9063 MOV RPADR,R4
9064 MOVB (R2),RPCS2(R4) ;SELECT DRIVE
9065 MOV 14(R2),R3 ;GET THE ERROR TABLE POINTER
9066 BEQ 6$ ;EXIT IF NO ADDRESS
9067 CLR 3$ ;COUNTER & POINTER
9068 CMP 3$,#RPDB ;REACHED THE BUFFER REGISTER ?
9069 BNE 2$ ;BR IF NOT
9070 BIT #BIT07,RPCS2(R4) ;'OR' SET ?
9071 BNE 2$ ;BR IF SET
9072 CLR (R3)+ ;STORE RPDB AS ZEROES
9073 BR 4$ ;CONTINUE
9074 JSR RO,RO RP ;READ THE SELECTED REGISTER
9075 .WORD 0 ;REGISTER INDEX
9076 5$ ;ERROR RETURN ADDRESS
9077 MOV (SP)+,(R3)+ ;STORE THE REGISTER CONTENTS
9078 CMP 3$,#RPEC2 ;REACHED THE END ?
9079 BEQ 6$ ;BR IF YES
9080 ADD #2,3$ ;INCREMENT THE REGISTER INDEX
9081 BR 1$ ;CONTINUE READING THE REGISTERS
    
```

```

9082 042142 004737 036704 5$ JSR PC,C17 ;PROCESS THE UNCORRECTABLE PARITY ERROR
9083 042146 104413 6$ RESREG ;RESTORE R0 - R5
9084 042150 000207 RTS PC ;RETURN
9085
9086 ,ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
9087 ,CALL
9088 , MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
9089 , JSR PC,SET.IE ;SET "IE"
9090 , RETURN
9091
9092 042152 010446 SET IE MOV R4,-(SP) ;SAVE R4
9093 042154 013704 034514 MOV RPADR,R4 ;PICKUP ADDRESS OF RPCS1
9094 042160 010164 000010 MOV R1,RPCS2(R4) ;SELECT DRIVE
9095 042164 011446 MOV (R4),-(SP) ;READ RPCS1
9096 042166 052716 040000 BIS #BIT14,(SP) ;SET THE "TRE" BIT OF THE WORD READ
9097 042172 000316 SWAB (SP) ;ADJUST FOR DATO
9098 042174 112714 000100 MOVB #BIT06,(R4) ;SET "IE"
9099 042200 032764 010000 000010 BIT #BIT12,RPCS2(R4) ;IS "NED"=1?
9100 042206 001002 BNE 1$ ;YES--CLEAR "TRE"
9101 042210 005726 TST (SP)+ ;CLEAN OFF THE STACK
9102 042212 000402 BR 2$
9103 042214 112664 000001 1$ MOVB (SP)+,1(R4) ;CLEAR "TRE"
9104 042220 012604 2$ MOV (SP)+,R4 ;RESTORE R4
9105 042222 000207 RTS PC ;RETURN TO CALLER
9106
9107 ,QUEUE COUNT
9108 042224 000 QCNT BYTE 0 ;DRIVE 0
9109 042225 000 BYTE 0 ;DRIVE 1
9110 042226 000 BYTE 0 ;DRIVE 2
9111 042227 000 BYTE 0 ;DRIVE 3
9112 042230 000 BYTE 0 ;DRIVE 4
9113 042231 000 BYTE 0 ;DRIVE 5
9114 042232 000 BYTE 0 ;DRIVE 6
9115 042233 000 BYTE 0 ;DRIVE 7
9116
9117 ,QUEUE INPUT POINTERS
9118
9119 042234 042316 QINPT WORD QDRV0 ;DRIVE 0
9120 042236 042336 WORD QDRV1 ;DRIVE 1
9121 042240 042356 WORD QDRV2 ;DRIVE 2
9122 042242 042376 WORD QDRV3 ;DRIVE 3
9123 042244 042416 WORD QDRV4 ;DRIVE 4
9124 042246 042436 WORD QDRV5 ;DRIVE 5
9125 042250 042456 WORD QDRV6 ;DRIVE 6
9126 042252 042476 WORD QDRV7 ;DRIVE 7
9127
9128 ,QUEUE OUTPUT POINTERS
9129
9130 042254 042316 QOUTPT WORD QDRV0 ;DRIVE 0
9131 042256 042336 WORD QDRV1 ;DRIVE 1
9132 042260 042356 WORD QDRV2 ;DRIVE 2
9133 042262 042376 WORD QDRV3 ;DRIVE 3
9134 042264 042416 WORD QDRV4 ;DRIVE 4
9135 042266 042436 WORD QDRV5 ;DRIVE 5
9136 042270 042456 WORD QDRV6 ;DRIVE 6
9137 042272 042476 WORD QDRV7 ;DRIVE 7

```

```

9138
9139 042274 042316 QSTART WORD QDRV0 ;DRIVE 0 START ADDRESS
9140 042276 042336 QSTOP. WORD QDRV1 ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
9141 042300 042356 WORD QDRV2 ;STOP DRIVE 1--START DRIVE 2
9142 042302 042376 WORD QDRV3 ;STOP DRIVE 2--START DRIVE 3
9143 042304 042416 WORD QDRV4 ;STOP DRIVE 3--START DRIVE 4
9144 042306 042436 WORD QDRV5 ;STOP DRIVE 4--START DRIVE 5
9145 042310 042456 WORD QDRV6 ;STOP DRIVE 5--START DRIVE 6
9146 042312 042476 WORD QDRV7 ;STOP DRIVE 6--START DRIVE 7
9147 042314 042516 WORD QTERM ;STOP DRIVE 7
9148
9149 .DRIVE REQUEST QUEUES
9150
9151 042316 000010 QDRV0 BLKW 10
9152 042336 000010 QDRV1 BLKW 10
9153 042356 000010 QDRV2 BLKW 10
9154 042376 000010 QDRV3 BLKW 10
9155 042416 000010 QDRV4 BLKW 10
9156 042436 000010 QDRV5 BLKW 10
9157 042456 000010 QDRV6 BLKW 10
9158 042476 000010 QDRV7 BLKW 10
9159 042516 QTERM=
9160
9161 .ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
9162
9163 .CALL
9164 . JSR PC,CLRQUE
9165
9166 042516 104412 CLRQUE SAVREG ;SAVE R0 - R5
9167 042520 012702 042224 MOV #QCNT,R2 ;ZERO THE QUEUE COUNTS
9168 042524 005022 CLR (R2)+ ;DRIVES 0 & 1
9169 042526 005022 CLR (R2)+ ;DRIVES 2 & 3
9170 042530 005022 CLR (R2)+ ;DRIVES 4 & 5
9171 042532 005022 CLR (R2)+ ;DRIVES 6 & 7
9172 042534 012703 000010 MOV #8,R3 ;MOVE THE STARTING
9173 042540 012701 042274 MOV #QSTART,R1 ;ADDRESS OF THE QUEUE INTO
9174 042544 012122 1$ MOV (R1)+,(R2)+ ;THE QUEUE INPUT POINTER
9175 042546 005303 DEC R3
9176 042550 001375 BNE 1$
9177 042552 012703 000010 MOV #8,R3 ;MOVE THE STARTING ADDRESS
9178 042556 012701 042274 MOV #QSTART,R1 ;OF THE QUEUE INTO THE
9179 042562 012122 2$ MOV (R1)+,(R2)+ ;QUEUE OUTPUT POINTER
9180 042564 005303 DEC R3
9181 042566 001375 BNE 2$
9182 042570 104413 RESREG ;RESTORE R0 - R5
9183 042572 000207 RTS PC
9184
9185 .EMPTY THE QUEUE SPECIFIED BY R1
9186
9187 .CALL
9188 . MOV DRVNUM,R1 ;DRIVE NUMBER TO R1
9189 . JSR PC,EMPTYQ
9190
9191 042574 105061 042224 EMPTYQ CLRB QCNT(R1) ;CLEAR NUMBER OF ITEMS IN QUEUE
9192 042600 006301 ASL R1
9193 042602 016161 042234 042254 MOV QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
    
```

```

9194 042610 006201          ASR    R1
9195 042612 000207          RTS    PC
9196
9197          ,ROUTINE TO PUT A REQUEST IN QUEUE
9198
9199          ,CALL
9200          ,      MOV    #DRVNUM,R1      ;DRIVE NUMBER
9201          ,      MOV    #DPB,R2        ;ADDRESS OF PARAMETER BLOCK
9202          ,      JSR    RD,DRVQUE      ;GO PUT REQUEST IN QUEUE
9203          ,      RETURN1                ;RETURN HERE IF QUEUE IS FULL
9204          ,      RETURN2                ;RETURN HERE IF REQUEST IS IN QUEUE
9205
9206 042614 122761 000010 042224 DRVQUE CMPB   #10,QCNT(R1)  ;IS QUEUE FULL?
9207 042622 001421          BEQ    2$          ;BR IF YES-TAKE RETURN1
9208 042624 105261 042224          INCB   QCNT(R1)   ;INCREMENT QUEUE COUNT
9209 042630 006301          ASL    R1
9210 042632 010271 042234          MOV    R2,@QINPT(R1) ;PUT THIS REQUEST IN QUEUE
9211 042636 062761 000002 042234          ADD   #2,QINPT(R1) ;UPDATE THE QUEUE POINTER
9212 042644 026161 042234 042276          CMP   QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
9213 042652 001003          BNE   1$          ;BRANCH IF NO
9214 042654 016161 042274 042234          MOV   QSTART(R1),QINPT(R1) ;YES--RESET POINTER
9215 042662 006201          1$    ASR    R1
9216 042664 005720          TST   (R0)+       ;TAKE RETURN 2
9217 042666 000200          2$    RTS    R0          ;RETURN TO USER
9218
9219          ,ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
9220
9221          ,CALL
9222          ,      MOV    #DRVNUM,R1      ;DRIVE NUMBER TO R1
9223          ,      JSR    PC,GETREQ      ;GO GET THE REQUEST
9224          ,      RETURN                ;R2="DPB" ADDRESS OF THE REQUEST
9225          ,      ;R2=0 IF NO REQUEST IN QUEUE
9226
9227 042670 005002          GETREQ CLR    R2
9228 042672 105761 042224          TSTB  QCNT(R1)   ;IS THERE ANY REQUEST IN QUEUE?
9229 042676 001404          BEQ    2$          ;NO---BRANCH
9230 042700 006301          1$    ASL    R1
9231 042702 017102 042254          MOV   @QOUTPT(R1),R2 ;PICKUP "DPB" POINTER FOR THIS DRIVE
9232 042706 006201          ASR    R1
9233 042710 000207          2$    RTS    PC          ;RETURN TO USER
9234
9235          ,ROUTINE TO "POP" THE REQUEST FROM QUEUE
9236
9237          ,CALL
9238          ,      MOV    #DRVNUM,R1      ;DRIVE NUMBER TO R1
9239          ,      JSR    PC,POPQUE      ;CALL TO REMOVE REQUEST
9240          ,      RETURN                ;R2=ADDRESS OF DPB REMOVED
9241
9242 042712 105361 042224          POPQUE DECB  QCNT(R1)   ;DECREMENT QUEUE COUNT
9243 042716 006301          ASL    R1
9244 042720 017102 042254          MOV   @QOUTPT(R1),R2 ;GET THE "DPB" POINTER
9245 042724 062761 000002 042254          ADD   #2,QOUTPT(R1) ;UPDATE THE QUEUE POINTER
9246 042732 026161 042254 042276          CMP   QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
9247 042740 001003          BNE   1$          ;NO--BRANCH TO EXIT
9248 042742 016161 042274 042254          MOV   QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
9249 042750 006201          1$    ASR    R1
    
```

```

9250 042752 000207          RTS      PC          ,RETURN TO USER
9251
9252          ,ROUTINE TO SAVE THE CONTENTS OF '$ESCAPE' WHEN THE DRIVER
9253          ,REPORTS AN ERROR DIRECTLY
9254
9255          ,CALL
9256          ,      JSR      RO,ES SAV
9257          ,      ERROR   N          ,THE ERROR CALL
9258          ,      RETURN  ,THE RETURN IS PAST THE ERROR CALL
9259
9260 042754 012037 042770    ES SAV  MOV      (RO)+,1$      ;GET THE ERROR CALL
9261 042760 013746 001206    MOV      $ESCAPE,-(SP)   ;SAVE THE ADDRESS IN '$ESCAPE'
9262 042764 005037 001206    CLR      $ESCAPE        ;CLEAR THE ESCAPE RETURN
9263 042770 000000          1$      WORD   0          ;THE ERROR CALL IS MOVED HERE
9264 042772 012637 001206    MOV      (SP)+,$ESCAPE  ;RESTORE THE ESCAPE ADDRESS
9265 042776 000200          RTS      RO          ;RETURN
9266
9267
9268          SBTTL  ASCIZ  MESSAGES
9269
9270 043000 000122          MSG R.  .ASCIZ  /R/
9271 043002 041506          MSG FC. .ASCIZ  /FC/
9272 043005          114 000103    MSG LC. .ASCIZ  /LC/
9273 043010 041506 000047    MSGFCP. .ASCIZ  /FC'/
9274 043014 041514 000047    MSGLCP. .ASCIZ  /LC'/
9275 043020 041511          000    MSG IC. .ASCIZ  /IC/
9276 043023          106 000124    MSG FT. .ASCIZ  /FT/
9277 043026 052114          000    MSG LT. .ASCIZ  /LT/
9278 043031          111 000124    MSG IT. .ASCIZ  /IT/
9279 043034 051506          000    MSG FS. .ASCIZ  /FS/
9280 043037          114 000123    MSG LS. .ASCIZ  /LS/
9281 043042 040520 000124    MSG PAT. .ASCIZ  /PAT/
9282 043046 000075          MSG EQ. .ASCIZ  /=/
9283 043050 005015 047503 052116    MSG CS. .ASCIZ  <CR><LF>/CONTROL SWITCHES=/
9284 043056 047522 020114 053523
9285 043064 052111 044103 051505
9286 043072 000075
9287
9288 043074 027440 000040          SLASH. .ASCIZ  @ / @
9289 043100 047125 052111 051440    SYSTAT .ASCIZ  /UNIT STATUS /<CR><LF><LF>
9290 043106 040524 052524 035123
9291 043114 005015 000012
9292 043120 051104 053111 000105    UNTMSG .ASCIZ  /DRIVE/
9293 043126 047440 043106 044514    UNTOFF .ASCIZ  / OFFLINE/
9294 043134 042516          000
9295 043137          040 047117 044514    UNTON. .ASCIZ  / ONLINE/
9296 043144 042516          000
9297 043147          040 047516 020124    NOTPRS .ASCIZ  / NOT PRESENT/
9298 043154 051120 051505 047105
9299 043162 000124
9300 043164 052440 051516 043101    NOTSAF. .ASCIZ  / UNSAFE/
9301 043172 000105
9302 043174 047040 052117 051040    NOTRP. .ASCIZ  @ NOT RPO4/5/6@
9303 043202 030120 027464 027465
9304 043210 000066
9305 043212 050122 032060          000  RPO4B. .ASCIZ  /RPO4/
    
```

9306	043217	122	030120	000065	RPO5	ASCIZ	/RPO5/
9307	043224	050122	033060	000	RPO6	ASCIZ	/RPO6/
9308	043231	015	042012	044522	DRIVES	ASCIZ	<CR><LF>/DRIVE(S) TO BE TESTED /
9309	043236	042526	051450	020051			
9310	043244	047524	041040	020105			
9311	043252	042524	052123	042105			
9312	043260	000040					
9313	043262	047516	042516	000	NONE	ASCIZ	/NONE/
9314	043267	054	000		COMMA	ASCIZ	/,/
9315	043271	015	047012	020117	NOCLOK	ASCIZ	<CR><LF>/NO KH11-P CLOCK. TIMING TESTS WILL NOT BE PERFORMED/
9316	043276	053513	030461	050055			
9317	043304	041440	047514	045503			
9318	043312	020054	044524	044515			
9319	043320	043516	052040	051505			
9320	043326	051524	053440	046111			
9321	043334	020114	047516	020124			
9322	043342	042502	050040	051105			
9323	043350	047506	046522	042105			
9324	043356	000					
9325	043357	015	005012	042524	TESTNG	ASCIZ	<CR><LF><LF>/TESTING DRIVE /
9326	043364	052123	047111	020107			
9327	043372	051104	053111	020105			
9328	043400	000					
9329	043401	123	051105	040511	SERIAL	ASCIZ	/SERIAL NUMBER /
9330	043406	020114	052516	041115			
9331	043414	051105	000040				
9332							
9333	043420	005015	051012	052117	MSG7	ASCIZ	<CR><LF><LF>/ROTATIONAL SPEED TIMES/
9334	043426	052101	047511	040516			
9335	043434	020114	050123	042505			
9336	043442	020104	044524	042515			
9337	043450	000123					
9338	043452	005015	047412	042516	MSG10A	ASCIZ	<CR><LF><LF>/ONE CYLINDER SEEK TIMES/<CR><LF>/ * FORWARD/
9339	043460	041440	046131	047111			
9340	043466	042504	020122	042523			
9341	043474	045505	052040	046511			
9342	043502	051505	005015	025040			
9343	043510	043040	051117	040527			
9344	043516	042122	000				
9345	043521	015	020012	020052	MSG10B	ASCIZ	<CR><LF>/ * REVERSE/
9346	043526	042522	042526	051522			
9347	043534	000105					
9348	043536	005015	040412	041503	MSG11A	ASCIZ	<CR><LF><LF>/ACCESS TIME MEASUREMENT/<CR><LF>/ * FORWARD/
9349	043544	051505	020123	044524			
9350	043552	042515	046440	040505			
9351	043560	052523	046522	047105			
9352	043566	006524	020012	020052			
9353	043574	047506	053522	051101			
9354	043602	000104					
9355	043604	005015	025040	051040	MSG11B	ASCIZ	<CR><LF>/ * REVERSE/
9356	043612	053105	051105	042523			
9357	043620	000					
9358	043621	015	005012	040515	MSG12A	ASCIZ	<CR><LF><LF>/MAXIMUM SEEK TIMES/<CR><LF>/ * FORWARD/
9359	043626	044530	052515	020115			
9360	043634	042523	045505	052040			
9361	043642	046511	051505	005015			

9362	043650	025040	043040	051117			
9363	043656	040527	042122	000			
9364	043663	015	020012	020052	MSG12B	ASCIZ	<CR><LF>/ * REVERSE/
9365	043670	042522	042526	051522			
9366	043676	000105					
9367							
9368	043700	005015	044515	036516	MSGMIN	ASCIZ	<CR><LF>/MIN=/
9369	043706	000					
9370	043707	015	046412	054101	MSGMAX	ASCIZ	<CR><LF>/MAX=/
9371	043714	000075					
9372	043716	005015	053101	036507	MSGAVG	ASCIZ	<CR><LF>/AVG=/
9373	043724	000					
9374	043725	060	052440	000123	MSGOUS	ASCIZ	/O US/
9375	043732	041040	046105	053517	MBELOW	ASCIZ	/ BELOW THE MINIMUM OF /
9376	043740	052040	042510	046440			
9377	043746	047111	046511	046525			
9378	043754	047440	020106	000			
9379	043761	040	041101	053117	MABOVE	ASCIZ	/ ABOVE THE MAXIMUM OF /
9380	043766	020105	044124	020105			
9381	043774	040515	044530	052515			
9382	044002	020115	043117	000040			
9383	044010	051440	042505	051513	MSGNUM	ASCIZ	/ SEEKS TIMED/
9384	044016	052040	046511	042105			
9385	044024	000					
9386	044025	040	047516	020124	MSGNON	ASCIZ	/ NOT TIMED/
9387	044032	044524	042515	000104			
9388	044040	020040	000		MSG SP	ASCIZ	/ / , TWO (2) SPACES
9389							
9390					SBTTL		ERROR HEADER (EM) MESSAGES
9391							
9392	044043	122	030510	020061	EM1	ASCIZ	/RH11 INTERRUPT OCCURRED (RPAS = 0)/
9393	044050	047111	042524	051122			
9394	044056	050125	020124	041517			
9395	044064	052503	051122	042105			
9396	044072	024040	050122	051501			
9397	044100	036440	030040	000051			
9398	044106	047125	054105	042520	EM2	ASCIZ	/UNEXPECTED ATTENTION OCCURRED/
9399	044114	052103	042105	040440			
9400	044122	052124	047105	044524			
9401	044130	047117	047440	041503			
9402	044136	051125	042522	000104			
9403	044144	040515	051523	052502	EM3	ASCIZ	/MASSBUS PARITY ERROR(MCPE=1)/
9404	044152	020123	040520	044522			
9405	044160	054524	042440	051122			
9406	044166	051117	046450	050103			
9407	044174	036505	024461	000			
9408	044201	115	051501	041123	EM4	ASCIZ	/MASSBUS PARITY ERROR(PAR=1)/
9409	044206	051525	050040	051101			
9410	044214	052111	020131	051105			
9411	044222	047522	024122	040520			
9412	044230	036522	024461	000			
9413	044235	101	042104	042522	EM5	ASCIZ	/ADDRESS PLUG CHANGE BIT SET/
9414	044242	051523	050040	052514			
9415	044250	020107	044103	047101			
9416	044256	042507	041040	052111			
9417	044264	051440	052105	000			

9418	044271	122	030510	027461	EM10	.ASCIZ	"RH11/RPO4/5/6 FAILED TO RESPOND TO ADDRESSING"
9419	044276	050122	032060	032457			
9420	044304	033057	043040	044501			
9421	044312	042514	020104	047524			
9422	044320	051040	051505	047520			
9423	044326	042116	052040	020117			
9424	044334	042101	051104	051505			
9425	044342	044523	043516	000			
9426	044347	104	044522	042526	EM11	ASCIZ	/DRIVE SELECTED IS NOT ONLINE/
9427	044354	051440	046105	041505			
9428	044362	042524	020104	051511			
9429	044370	047040	052117	047440			
9430	044376	046116	047111	000105			
9431	044384	046511	051120	050117	EM12	ASCIZ	/IMPROPER HEADER DATA/
9432	044412	051105	044040	040505			
9433	044420	042504	020122	040504			
9434	044426	040524	000				
9435	044431	104	052101	020101	EM13	ASCIZ	/DATA COMPARE FAILURE/
9436	044436	047503	050115	051101			
9437	044444	020105	040506	046111			
9438	044452	051125	000105				
9439	044456	044504	045523	042440	EM17	ASCIZ	/DISK ERROR IN TIMING TEST/
9440	044464	051122	051117	044440			
9441	044472	020116	044524	044515			
9442	044500	043516	052040	051505			
9443	044506	000124					
9444	044510	046103	041517	020113	EM20	ASCIZ	/CLOCK (KW11-P) OVERFLOW IN TIMING TEST/
9445	044516	045450	030527	026461			
9446	044524	024520	047440	042526			
9447	044532	043122	047514	020127			
9448	044540	047111	052040	046511			
9449	044546	047111	020107	042524			
9450	044554	052123	000				
9451	044557	104	051511	020113	EM23	ASCIZ	/DISK ERROR DURING SEEK/
9452	044564	051105	047522	020122			
9453	044572	052504	044522	043516			
9454	044600	051440	042505	000113			
9455	044606	042523	045505	047040	EM24	ASCIZ	/SEEK NOT COMPLETE WITHIN 120 MS/
9456	044614	052117	041440	046517			
9457	044622	046120	052105	020105			
9458	044630	044527	044124	047111			
9459	044636	030440	030062	046440			
9460	044644	000123					
9461	044646	044122	030461	051057	EM41	ASCIZ	"RH11/RPO4/5/6 ERROR"
9462	044654	030120	027464	027465			
9463	044662	020066	051105	047522			
9464	044670	000122					
9465	044672	040506	040524	020114	EM46	ASCIZ	/FATAL WRITE CHECK ERROR/
9466	044700	051127	052111	020105			
9467	044706	044103	041505	020113			
9468	044714	051105	047522	000122			
9469							
9470					.SBTTL		STATUS/ERROR INDICATOR MESSAGES
9471							
9472	044722	043117	046106	047111	MSG814	ASCIZ	/OFFLINE OR UNSAFE DRIVE REQUESTED/
9473	044730	020105	051117	052440			

9474	044736	051516	043101	020105			
9475	044744	051104	053111	020105			
9476	044752	042522	052521	051505			
9477	044760	042524	000104				
9478	044764	047125	047514	042101	MSG813	ASCIZ	/UNLOADED DRIVE REQUESTED/
9479	044772	042105	042040	044522			
9480	045000	042526	051040	050505			
9481	045006	042525	052123	042105			
9482	045014	000					
9483	045015	120	051105	044523	MSG812	ASCIZ	/PERSISTENT UNSAFE/
9484	045022	052123	047105	020124			
9485	045030	047125	040523	042506			
9486	045036	000					
9487	045037	120	051101	052111	MSG811	ASCIZ	/PARITY ERROR OCCURRED/
9488	045044	020131	051105	047522			
9489	045052	020122	041517	052503			
9490	045060	051122	042105	000			
9491	045065	106	052101	046101	MSG810	ASCIZ	/FATAL PARITY ERROR/
9492	045072	050040	051101	052111			
9493	045100	020131	051105	047522			
9494	045106	000122					
9495	045110	047523	052106	040527	MSG809	ASCIZ	/SOFTWARE TIMEOUT ON THIS DRIVE/
9496	045116	042522	052040	046511			
9497	045124	047505	052125	047440			
9498	045132	020116	044124	051511			
9499	045140	042040	044522	042526			
9500	045146	000					
9501	045147	123	043117	053524	MSG808	ASCIZ	/SOFTWARE TIMEOUT ON ANOTHER DRIVE/
9502	045154	051101	020105	044524			
9503	045162	042515	052517	020124			
9504	045170	047117	040440	047516			
9505	045176	044124	051105	042040			
9506	045204	044522	042526	000			
9507	045211	105	051122	051117	MSG806	ASCIZ	"ERROR OCCURRED DUPING I/O OPERATION"
9508	045216	047440	041503	051125			
9509	045224	042522	020104	052504			
9510	045232	044522	043516	044440			
9511	045240	047457	047440	042520			
9512	045246	040522	044524	047117			
9513	045254	000					
9514	045255	105	051122	051117	MSG805	ASCIZ	"ERROR OCCURRED DURING NON-I/O OPERATION"
9515	045262	047440	041503	051125			
9516	045270	042522	020104	052504			
9517	045276	044522	043516	047040			
9518	045304	047117	044455	047457			
9519	045312	047440	042520	040522			
9520	045320	044524	047117	000			
9521	045325	125	051516	043101	MSG804	ASCIZ	/UNSAFE OCCURRED/
9522	045332	020105	041517	052503			
9523	045340	051122	042105	000			
9524	045345	101	052125	046517	MSG803	ASCIZ	/AUTOMATIC RECALIBRATE SEQUENCE OCCURRED/
9525	045352	052101	041511	051040			
9526	045360	041505	046101	041111			
9527	045366	040522	042524	051440			
9528	045374	050505	042525	041516			
9529	045402	020105	041517	052503			





9642	046542	020040	051040	041520																
9643	046550	000103																		
9644	046552	042524	052123	020040	DH41	ASCIZ	/TEST	ERR PC	TST PC	DRIVE/										
9645	046560	020040	051105	020122																
9646	046566	041520	020040	051524																
9647	046574	020124	041520	020040																
9648	046602	051104	053111	000105																
9649	046610	042524	052123	020040	DH42	ASCIZ	/TEST	ERR PC	TST PC	DRIVE	RPCS1	RPCS2	RPDS1/							
9650	046616	020040	051105	020122																
9651	046624	041520	020040	051524																
9652	046632	020124	041520	020040																
9653	046640	051104	053111	020105																
9654	046646	020040	050122	051503																
9655	046654	020061	020040	050122																
9656	046662	051503	020062	020040																
9657	046670	050122	051504	000061																
9658	046676	050122	051105	020061	DH43A	ASCIZ	/RPER1	RPER2	RPER3/											
9659	046704	020040	050122	051105																
9660	046712	020062	020040	050122																
9661	046720	051105	000063																	
9662	046724	050122	051503	020061	DH44A	ASCIZ	/RPCS1	RPCS2	RPDS1	RPCC	RPCA	RPDA/								
9663	046732	020040	050122	051503																
9664	046740	020062	020040	050122																
9665	046746	051504	020061	020040																
9666	046754	050122	041503	020040																
9667	046762	020040	050122	040503																
9668	046770	020040	020040	050122																
9669	046776	040504	000																	
9670	047001	122	042520	030522	DH44B	ASCIZ	/RPER1	RPER2	RPER3/											
9671	047006	020040	051040	042520																
9672	047014	031122	020040	051040																
9673	047022	042520	031522	000																
9674	047027	122	042520	030522	DH45A	ASCIZ	/RPER1	RPER2	RPER3	RPWC	RPBA	RPDB/								
9675	047034	020040	051040	042520																
9676	047042	031122	020040	051040																
9677	047050	042520	031522	020040																
9678	047056	051040	053520	020103																
9679	047064	020040	051040	041120																
9680	047072	020101	020040	051040																
9681	047100	042120	000102																	
9682																				
9683																				
9684																				
9685																				
9686																				
9687																				
9688	047104	001116	001170		DT1	WORD	SERRPC, SREG3													
9689	047110	001116	001164	001170	DT2	WORD	SERRPC, SREG1, SREG3, RPERRS, RPERRS+2, RPERRS+4, RPERRS+6													
9690	047116	034346	034350	034352																
9691	047124	034354																		
9692	047126	001176	001116	041506	DT3	WORD	STMPD, SERRPC, RD. ADR, RD WRD													
9693	047134	041510																		
9694	047136	001176	001116	041732	DT4	WORD	STMPD, SERRPC, WRT. ADR, WRT WD, RD WRD													
9695	047144	041730	041510																	
9696	047150	001176	001116	001164	DT5	WORD	STMPD, SERRPC, SREG1, SREG5, RPERRS, RPERRS+2, RPERRS+4, RPERRS+6													
9697	047156	001174	034346	034350																

EVEN

SBTTL DATA TABLE (DT)

9698	047164	034352	034354				
9699	047170	001366	001116		DT10	. WORD	RH. ADR, \$ERRPC
9700	047174	001166	001116		DT11	. WORD	\$REG2, \$ERRPC
9701	047200	001176	001116	001162	DT12	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, CYL. DS, TRK. DS, SEC DS
9702	047206	001254	001270	001274			
9703	047214	001272					
9704	047216	001270	001274	001272	DT12A	. WORD	CYL. DS, TRK. DS, SEC. DS, CYL. RD, TRK. RD, SEC RD
9705	047224	001262	001264	001266			
9706	047232	001176	001116	001162	DT13	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, CYL. DS, TRK. DS, SEC DS
9707	047240	001254	001270	001274			
9708	047246	001272					
9709	047250	001124	001126	001172	DT13A	. WORD	\$GDDAT, \$BDDAT, \$REG4, \$GDADR, \$BDADR
9710	047256	001120	001122				
9711	047262	001176	001116	001254	DT17	. WORD	\$TMPO, \$ERRPC, CHKDRV, RP. REG, RP. REG+12, RP. REG+14, RP. REG+40, RP. REG+42
9712	047270	004204	004216	004220			
9713	047276	004244	004246				
9714	047302	001176	001116	001162	DT21	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, CYL. DS, TRK. DS
9715	047310	001254	001270	001274			
9716	047316	001164	001126	001172	DT21A	. WORD	\$REG1, \$BDDAT, \$REG4, \$REG1
9717	047324	001164					
9718	047326	001176	001116	001254	DT23	. WORD	\$TMPO, \$ERRPC, CHKDRV, CYL. DS, RP. REG, RP. REG+10, RP. REG+12
9719	047334	001270	004204	004214			
9720	047342	004216					
9721	047344	004220	004244	004246	DT23A	. WORD	RP. REG+14, RP. REG+40, RP. REG+42, RP. REG+34, RP. REG+36
9722	047352	004240	004242				
9723	047356	001176	001116	001162	DT41	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV
9724	047364	001254					
9725	047366	001176	001116	001162	DT42	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, RP. REG, RP. REG+10, RP. REG+12
9726	047374	001254	004204	004214			
9727	047402	004216					
9728	047404	001176	001116	001162	DT43	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, RP. REG, RP. REG+10, RP. REG+12
9729	047412	001254	004204	004214			
9730	047420	004216					
9731	047422	004220	004244	004246	DT43A	. WORD	RP. REG+14, RP. REG+40, RP. REG+42
9732	047430	001176	001116	001162	DT44	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, CYL. DS, TRK. DS, SEC DS
9733	047436	001254	001270	001274			
9734	047444	001272					
9735	047446	004204	004214	004216	DT44A	. WORD	RP. REG, RP. REG+10, RP. REG+12, RP. REG+36, RP. REG+34, RP. REG+06
9736	047454	004242	004240	004212			
9737	047462	004220	004244	004246	DT44B	. WORD	RP. REG+14, RP. REG+40, RP. REG+42
9738	047470	001176	001116	001162	DT45	. WORD	\$TMPO, \$ERRPC, \$REGO, CHKDRV, CYL. DS, TRK. DS, SEC DS
9739	047476	001254	001270	001274			
9740	047504	001272					
9741	047506	004204	004214	004216	DT45A	. WORD	RP. REG, RP. REG+10, RP. REG+12, RP. REG+36, RP. REG+34, RP. REG+06
9742	047514	004242	004240	004212			
9743	047522	004220	004244	004246	DT45B	. WORD	RP. REG+14, RP. REG+40, RP. REG+42, RP. REG+2, RP. REG+4, RP. REG+22
9744	047530	004206	004210	004226			

SBTTL DATA FORMAT (DF) TABLE

9747								
9748	047536	000001			DF1	. WORD	1	, NUMBER OF DATA HEADERS
9749	047540	002				. BYTE	2	, NUMBER OF WORDS IN DATA TABLE
9750	047541	000				. BYTE	0	, ALL 3 NUMBERS ARE OCTAL
9751								
9752	047542	000001			DF2	. WORD	1	
9753	047544	007				. BYTE	7	

Address	Octal	DF	Format	Value
9754	047545		BYTE	0
9755				
9756	047546	DF3	WORD	1
9757	047550		BYTE	4
9758	047551		BYTE	0
9759				
9760	047552	DF4	WORD	1
9761	047554		BYTE	5
9762	047555		BYTE	0
9763				
9764	047556	DF10	WORD	1
9765	047560		BYTE	2
9766	047561		BYTE	0
9767				
9768	047562	DF11	WORD	1
9769	047564		BYTE	2
9770	047565		BYTE	0
9771				
9772	047566	DF12	WORD	2
9773	047570		BYTE	7
9774	047571		BYTE	160
9775	047572		WORD	DH12A
9776	047574		BYTE	6
9777	047575		BYTE	0
9778				
9779	047576	DF13	WORD	2
9780	047600		BYTE	7
9781	047601		BYTE	160
9782	047602		WORD	DH13A
9783	047604		BYTE	5
9784	047605		BYTE	4
9785				
9786	047606	DF14	WORD	0
9787	047610		BYTE	5
9788	047611		BYTE	4
9789				
9790	047612	DF17	WORD	1
9791	047614		BYTE	08
9792	047615		BYTE	0
9793				
9794	047616	DF21	WORD	2
9795	047620		BYTE	6
9796	047621		BYTE	60
9797	047622		WORD	DH21A
9798	047624		BYTE	4
9799	047625		BYTE	14
9800				
9801	047626	DF22	WORD	0
9802	047630		BYTE	4
9803	047631		BYTE	14
9804				
9805	047632	DF23	WORD	2
9806	047634		BYTE	7
9807	047635		BYTE	10
9808	047636		WORD	DH23A
9809	047640		BYTE	5

; 2 DH'S TO BE TYPED  
 ; 7 DATA WORDS FOLLOW THE 1ST DH  
 ; WORDS 1-4 ARE OCTAL 5-7 ARE DECIMAL  
 ; ADDRESS OF 2ND DH  
 ; 6 DATA WORDS FOLLOW THE 2ND DH  
 ; ALL WORDS ARE OCTAL

; WORD 3 IS DECIMAL

; WORD 3 IS DECIMAL

; WORD 4 IS DECIMAL

9810	047641	000		. BYTE	0
9811					
9812					
9813	047642	000001	DF41	. WORD	1
9814	047644	004		. BYTE	4
9815	047645	000		. BYTE	0
9816					
9817	047646	000001	DF42	. WORD	1
9818	047650	007		. BYTE	7
9819	047651	000		. BYTE	0
9820					
9821	047652	000002	DF43	. WORD	2
9822	047654	007		. BYTE	7
9823	047655	000		. BYTE	0
9824	047656	046676		. WORD	DH43A
9825	047660	003		. BYTE	3
9826	047661	000		. BYTE	0
9827					
9828	047662	000003	DF44	. WORD	3
9829	047664	007		. BYTE	7
9830	047665	160		. BYTE	160
9831	047666	046724		. WORD	DH44A
9832	047670	006		. BYTE	6
9833	047671	000		. BYTE	0
9834	047672	047001		. WORD	DH44B
9835	047674	003		. BYTE	3
9836	047675	000		. BYTE	0
9837					
9838	047676	000003	DF45	. WORD	3
9839	047700	007		. BYTE	7
9840	047701	160		. BYTE	160
9841	047702	046724		. WORD	DH44A
9842	047704	006		. BYTE	6
9843	047705	000		. BYTE	0
9844	047706	047027		. WORD	DH45A
9845	047710	006		. BYTE	6
9846	047711	000		. BYTE	0

EVEN BUFFER=.

9847					
9848					
9849		047712			
9850					
9851	047712	005015	046412	044501	TITLE. . ASCII <CR><LF><LF>/MAINDEC-11-DZRJA-B/<CR><LF>
9852	047720	042116	041505	030455	
9853	047726	026461	055104	045122	
9854	047734	026501	006502	012	
9855	047741	122	030120	027464	ASCII2 @RPO4/5/6 MECHANICAL & READ-WRITE TEST@<CR><LF><LF>
9856	047746	027465	020066	042515	
9857	047754	044103	047101	041511	
9858	047762	046101	023040	051040	
9859	047770	040505	026504	051127	
9860	047776	052111	020105	042524	
9861	050004	052123	005015	000012	
9862	050012	005015	047524	052040	LOADRV: ASCII <CR><LF>/TO TEST DRIVE 0 REPLACE THE 'XXDP' PACK ON DRIVE 0/<CR><LF>
9863	050020	051505	020124	051104	
9864	050026	053111	020105	020060	
9865	050034	042522	046120	041501	

9866	050042	020105	044124	020105	
9867	050050	054047	042130	023520	
9868	050056	050040	041501	020113	
9869	050064	047117	042040	044522	
9870	050072	042526	030040	005015	
9871	050100	044527	044124	040440	ASCII /WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40, AND RESTART/<CR><LF>
9872	050106	047516	044124	051105	
9873	050114	050040	041501	026113	
9874	050122	041440	042514	051101	
9875	050130	046440	046505	051117	
9876	050136	020131	047514	040503	
9877	050144	044524	047117	032040	
9878	050152	026060	040440	042116	
9879	050160	051040	051505	040524	
9880	050166	052122	005015		
9881	050172	044124	020105	051120	ASCIZ /THE PROGRAM/<CR><LF>
9882	050200	043517	040522	006515	
9883	050206	000012			
9884	050210	005015	054523	052123	NOLOAD ASCIZ <CR><LF>/SYSTEM HAS 16K MEMORY, 'XXDP' LOADER WILL BE OVERWRITTEN/<CR><L
9885	050216	046505	044040	051501	
9886	050224	030440	045466	046440	
9887	050232	046505	051117	026131	
9888	050240	023440	054130	050104	
9889	050246	020047	047514	042101	
9890	050254	051105	053440	046111	
9891	050262	020114	042502	047440	
9892	050270	042526	053522	044522	
9893	050276	052124	047105	005015	
9894	050304	000012			
9895					
9896					EVEN
9897					
9898					SBTTL ROUTINE TO SIZE MEMORY
9899					
9900					., *****
9901					., *CALL
9902					., * JSR PC, \$SIZE
9903					., * RETURN
9904					., * \$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION
9905					
9906	050306	010046			\$SIZE MOV R0, -(SP) .. SAVE R0 ON THE STACK
9907	050310	010146			MOV R1, -(SP) .. SAVE R1 ON THE STACK
9908	050312	013746	000004		MOV @ERRVEC, -(SP) .. SAVE PRESENT ERROR VECTOR PS & PC
9909	050316	013746	000006		MOV @ERRVEC+2, -(SP)
9910	050322	010600			MOV SP, R0 .. SAVE THE STACK POINTER
9911					., SET THE ERRVEC PS TO THE PRESENT PS
9912	050324	104400			TRAP .. PUSH OLD PSW AND PC ON STACK
9913	050326	012637	000006		MOV (SP)+, @ERRVEC+2 .. SAVE THE PSW IN @ERRVEC+2
9914	050332	012737	050352	000024	MOV #25, @ERRVEC .. SET FOR TIMEOUT
9915	050340	012701	020000		MOV #20000, R1 .. FIRST ADDRESS
9916	050344	005711			1\$ TST (R1) .. TEST THIS ADDRESS
9917	050346	005721			TST (R1)+ .. STEP TO NEXT ADDRESS
9918	050350	000775			BR 1\$ .. TRY ANOTHER
9919	050352	162701	000002		2\$ SUB #2, R1 .. DROP BACK
9920	050356	010006			MOV R0, SP .. RESTORE THE STACK
9921	050360	012637	000006		MOV (SP)+, @ERRVEC+2 .. RESTORE ERROR VECTOR

```

9922 050364 012637 000004          MOV    (SP)+, @#ERRVEC
9923 050370 010137 050402          MOV    R1, $LSTAD      ;, LAST ADDRESS
9924 050374 012601                MOV    (SP)+, R1      ;, RESTORE R1
9925 050376 012600                MOV    (SP)+, R0      ;, RESTORE R0
9926 050400 000207                RTS    PC
9927 050402 000000          $LSTAD WORD 0          ;, CONTAINS THE LAST ADDRESS
9928
9929          ;, *****
9930          SBTTL GETADR - GET BUS ADDRESS AND VECTOR ADDRESS
9931          ;, THIS ROUTINE IS USED TO ENSURE THE BUS ADDRESS
9932          ;, OF THE RH11/RPO4 IS SETUP TO READ THE PROPER VALUE
9933          ;, IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
9934          ;, REQUIRED
9935          ;, NOTE THIS ROUTINE DESTROYS R0-R4
9936          ;, CALL
9937          ;
9938          ;          JSR    PC, @#GETADR
9939          ;          RETURN
9940
9941 050404 005737 001226          GETADR TST    @#BUSADR      ;, INPUT FROM TTY REQUESTED?
9942 050410 001427                BEQ    7$                ;, NO--BRANCH
9943 050412 005037 001226          CLR    @#BUSADR      ;, YES--CLEAR THE REQUEST FLAG
9944 050416 012700 001366          1$    MOV    #RH ADR, R0 ;, FIRST ADDRESS
9945 050422 012703 050562          MOV    #MRPCS1, R3    ;, "RPCS1="
9946 050426 011004                MOV    (R0), R4        ;, PRESENT RPCS1 ADDRESS
9947 050430 004037 031516          JSR    R0, @#GETNUM    ;, GET NEW RPCS1
9948 050434 000402                BR     2$                ;, COMMA
9949 050436 000767                BP     1$                ;, PERIOD
9950 050440 000412                BR     5$                ;, DOUBLE PERIOD
9951 050442 010420          2$    MOV    R4, (R0)+    ;, SAVE NEW RPCS1
9952 050444 012703 050573          MOV    #MRHVEC, R3    ;, "RHVEC="
9953 050450 011004                MOV    (R0), R4        ;, PRESENT RH11 VECTOR ADDRESS
9954 050452 004037 031516          JSR    R0, @#GETNUM    ;, GET NEW RHVEC
9955 050456 000402                BR     3$                ;, COMMA
9956 050460 000756                BR     1$                ;, PERIOD
9957 050462 000401                BR     5$                ;, DOUBLE PERIOD
9958 050464 010420          3$    MOV    R4, (R0)+    ;, SAVE NEW RHVEC
9959 050466 010410          5$    MOV    R4, (R0)        ;, SAVE INPUT
9960 050470 013701 000004          7$    MOV    @#ERRVEC, R1   ;, SAVE THE ERROR VECTOR
9961 050474 012737 050530 000004    MOV    #8$, @#ERRVEC   ;, SETUP FOR TRAP
9962 050502 005777 130660          TST    @RH ADR        ;, CHECK FOR RH11/RPO4
9963 050506 010137 000004          MOV    R1, @#ERRVEC    ;, RESTORE ERROR VECTOR
9964 050512 012700 001366          MOV    #RH. ADR, R0    ;, FIRST ADDRESS OF NEW PARAMETERS
9965 050516 012701 034514          MOV    #RPAOR, R1      ;, FIRST ADDRESS OF WHERE TO PUT THEM
9966 050522 012021                MOV    (R0)+, (R1)+    ;, BUS ADDRESS
9967 050524 012021                MOV    (R0)+, (R1)+    ;, VECTOR ADDRESS
9968 050526 000207                RTS    PC              ;, RETURN
9969 050530 010137 000004          8$    MOV    R1, @#ERRVEC    ;, RESTORE ERROR VECTOR
9970 050534 022626                CMP    (SP)+, (SP)+    ;, CLEAN OFF THE STACK
9971 050536 104010                ERROR  10              ;, REPORT THE ERROR
9972 050540 005737 000042          TST    @#42            ;, IS THERE A MONITOR?
9973 050544 001724                BEQ    1$                ;, NO--GO ASK FOR ADDRESS
9974 050546 005037 001232          CLR    @#DRUSEL        ;, YES--NO DRIVES SELECTED
9975 050552 005037 01 42          CLR    @#SEOPCT        ;, NO PASSES
9976 050556 000137 017366          JMP    @#SEOP          ;, GO TO END OF PROGRAM
9977
    
```



ABS = 000200	CHKDRV 001254	DF23 047632	DRV TYP 034376	EM2 044106
ACL = 000040	C11 036054	DF3 047546	DRY = 000200	EM20 044510
ACTDRV 034432	C13 036162	DF4 047552	DSWR = 177570	EM23 044557
ACTSTR 034433	C14 036270	DF41 047642	DTADPB 004164	EM24 044606
ACU = 100000	C15 036646	DF42 047646	DTE = 010000	EM3 044144
AOE = 001000	C16 036670	DF43 047652	DTSY = 000200	EM4 044201
ATA = 100000	C17 036704	DF44 047662	DTUW 034500	EM41 044646
ATABIT 034502	C17B 036732	DF45 047676	DT00 = 000001	EM46 044672
ATO = 000001	C18 037004	DH1 045523	DT01 = 000002	EM5 044235
AT1 = 000002	CKSCTR 030010	DH10 045732	DT02 = 000004	ERINDX 026246
AT2 = 000004	CKSWR = 104407	DH11 045751	DT03 = 000010	ERR = 040000
AT3 = 000010	CK CHR 033766	DH12 045770	DT04 = 000020	ERRVEC = 000004
AT4 = 000020	CK DEC 033740	DH12A 046057	DT05 = 000040	ERR CT 001364
AT5 = 000040	CK DIG 034042	DH13A 046136	DT06 = 000100	ES SAV 042754
AT6 = 000100	CK NUM 034226	DH17 046204	DT07 = 000200	EXIT0 006514
AT7 = 000200	CK OCT 033712	DH2 045540	DT08 = 000400	EXIT1 006672
A16 = 000400	CLKSTA 001244	DH21 046302	DT1 047104	EXIT10 012022
A17 = 001000	CLOSE 033632	DH21A 046360	DT10 047170	EXIT11 012242
BA1 = 000010	CLR = 000040	DH23 046417	DT11 047174	EXIT12 013000
BITS 001424	CLRBUF 027742	DH23A 046505	DT12 047200	EXIT13 013444
BIT0 = 000001	CLRQUE 042516	DH3 045626	DT12A 047216	EXIT14 014162
BIT00 = 000001	CLSWDS 033532	DH4 045663	DT13 047232	EXIT15 014700
BIT01 = 000002	CNTRLC 001224	DH41 046552	DT13A 047250	EXIT16 015276
BIT02 = 000004	COMMA 043267	DH42 046610	DT17 047262	EXIT17 015716
BIT03 = 000010	COUNT 027120	DH43A 046676	DT2 047110	EXIT2 007110
BIT04 = 000020	CR = 000015	DH44A 046724	DT21 047302	EXIT20 016436
BIT05 = 000040	CKLF = 000200	DH44B 047001	DT21A 047316	EXIT21 017214
BIT06 = 000100	CSF = 000002	DH45A 047027	DT23 047326	EXIT22 017364
BIT07 = 000200	CSU = 000010	DIGB = 000004	DT23A 047344	EXIT3 007304
BIT08 = 000400	CYL DS 001270	DISPLA 001142	DT3 047126	EXIT4 007672
BIT09 = 001000	CYL RD 001262	DISPRE 000174	DT4 047136	EXIT5 010072
BIT1 = 000002	C SWR 001220	DLT = 100000	DT41 047356	EXIT6 010336
BIT10 = 002000	DATCMP 030450	DL64 = 000020	DT42 047366	EXIT7 010716
BIT11 = 004000	DCK = 100000	DMD = 000001	DT43 047404	EXT1 = 000001
BIT12 = 010000	DCL = 000100	DORT1 027052	DT43A 047422	EXT10 = 000010
BIT13 = 020000	DCU = 000001	DPB A 004104	DT44 047430	EXT2 = 000002
BIT14 = 040000	DDISP = 177570	DPB B 004124	DT44A 047446	EXT20 = 000020
BIT15 = 100000	DECSEC 027660	DPB C 004144	DT44B 047462	EXT4 = 000004
BIT2 = 000004	DECSK 007066	OPINT 034406	DT45 047470	EXT40 = 000040
BIT3 = 000010	DELTA 001350	DPR = 000400	DT45A 047506	FC 001510
BIT4 = 000020	DE1 = 000040	DPRQS 034416	DT45B 047522	FEN = 000200
BIT5 = 000040	OFF20 = 000002	DRIVES 043231	DT5 047150	FER = 000020
BIT6 = 000100	DFLT 001664	DRQ = 004000	DVA = 004000	FILBUF 027704
BIT7 = 000200	DF1 047536	DRVACT 034356	ECH = 000100	FILRAM 030766
BIT8 = 000400	DF10 047556	DRV CAL 025524	ECI = 004000	FMT22 = 010000
BIT9 = 001000	DF11 047562	DRVCLR = 000111	EMPTYQ 042574	FS 001524
BPTVEC = 000014	DF12 047566	DRVCL1 025544	EMTVEC = 000030	FT 001516
BUFFER = 047712	DF13 047576	DRVINT 034744	EM1 044043	F1 = 000002
BUSADR 001226	DF14 047606	DRVMSK 001256	EM10 044271	F2 = 000004
BYPASS 001252	DF17 047612	DRVOK 006122	EM11 044347	F3 = 000010
CALL A 025032	DF2 047542	DRVQUE 042614	EM12 044404	F4 = 000020
CALL B 025144	DF21 047616	DRVSEL 001232	EM13 044431	F5 = 000040
CALL C 025334	DF22 047626	DRVSTA 034366	EM17 044456	GETADR 050404

GETNUM	031516	MBELOW	043732	MSG12B	043663	PAT10	003604	PR5	=	000240						
GETREG=	000141	MCLK	=	000002	MSG7	043420	PAT11	003644	PR6	=	000300					
GETREQ	042670	MCPE	=	020000	MSTCK	=	000010	PAT12	003704	PR7	=	000340				
GETSWR	031424	MCPEMX	034512	MWR	=	000040	PAT13	003744	PS	=	177776					
GO	=	MHS	=	001000	MXDLTA	034524	PAT14	004004	PSEL	=	002000					
GRV	=	MINX	=	000004	MXF	=	001000	PAT15	004044	PSU	=	000001				
GTSWR	=	MNDLTA	034526	MXLACT	034522	PAT2	003204	PSW	=	177776						
GTTST1	032012	MOH	=	020000	MXSTAL	001362	PAT3	003244	PTRN15	002742						
GTTST2	032076	MOL	=	010000	MXWMDW	034530	PAT4	003304	PWRVEC=	000024						
GTTST3	032440	MPE	=	000400	NBA	=	100000	PAT5	003344	QCNT	042224					
GTTST4	032442	MRD	=	000020	NC1	001532	PAT6	003404	QDRV0	042316						
GTTST5	032552	MRHVEC	050573	NC2	001534	PAT7	003444	QDRV1	042336							
GTTST6	032612	MRPCS1	050562	NED	=	010000	PAT8	003504	QDRV2	042356						
GT PRM	031654	MSE	=	000020	NEM	=	004000	PAT9	003544	QDRV3	042376					
GT PR1	031656	MSGAVG	043716	NHS	=	002000	PGE	=	002000	QDRV4	042416					
GT PR2	032006	MSG801	045465	NOCLOK	043271	PGM	=	001000	PIRQ	=	177772					
HCE	=	MSG802	045415	NLOAD	050210	PIP	=	020000	PIRQVE=	000240						
HCI	=	MSG803	045345	NONE	043262	PKB	001402	PKC	001404	QINPT	042234					
HCRC	=	MSG804	045325	NOOP	=	000101	PKCS	001400	PKV	001374	QOUTPT	042254				
HT	=	MSG805	045255	NOTPRS	043147	PLU	=	020000	POPQUE	042712	QSTART	042274				
IAE	=	MSG806	045211	NOTRP	043174	PRM	001504	PRMLMT	001606	QSTOP	042276					
IC	001514	MSG808	045147	NOTSAF	043164	PRMMSG	001636	PRMPT	001536	QTERM	=	042516				
IE	=	MSG809	045110	OCYL	=	100000	PRM1	002344	PRM10	002544	RANADR	031242				
ILF	=	MSG810	045065	OFFSET=	000115	PRM11	002564	PRM12	002606	RANCK	031010					
ILR	=	MSG811	045037	OFREV	=	000200	PRM13	002622	PRM14	002636	RANPAT	031206				
INCCYL	027630	MSG812	045015	OF100	=	000004	PRM15	002652	PRM16	002666	RAW	=	000020			
INCSK	007024	MSG813	044764	OF200	=	000010	PRM17	002700	PRM20	002712	RDCHR	=	104410			
INCRK	027600	MSG814	044722	OF25	=	000001	PRM21	002744	PRM22	002760	RDIN	=	104411			
IOTVEC=	000020	MSGFCP	043010	OF400	=	000020	PRM2	002372	PRM3	002414	RDY	=	000200			
IR	=	MSGGLCP	043014	OF50	=	000002	PRM4	002436	PRM5	002460	RD ADR	041506				
ISR	037376	MSGMAX	043707	OF800	=	000040	PRM6	002502	PRM7	002524	RD RP	041462				
IT	001522	MSGMIN	043700	OPE	=	020000	PRM8	002524	PRM9	=	000000	RD RP1	041504			
ITEM41	004546	MSGNON	044025	OP1	=	020000	PRM10	002544	PRM11	002564	RD RP2	041630				
IXE	=	MSGNUM	044010	OPN FLG	001240	OPN X1	033572	OPN X2	033576	RD RP3	041634					
LA	037240	MSG. CS	043050	OPNPAT	033220	OPN 1	032654	OPN 2	032676	RD RP4	041640					
LACNT	034444	MSG. EQ	043046	OPNPRM	033016	OPT	035574	OR	=	000200	RD WRD	041510				
LC	001512	MSG. FC	043002	OPNTST	032644	PACK	=	000123	PAR	=	000010	READ	=	000171		
LDCMD	024766	MSG. FS	043034	OPNWDS	033342	PAT	001530	PAT PT	003044	PR1	=	000040	READHD=	000173		
LF	=	MSG. FT	043023	OPN CT	032650	PAT0	003104	PAT1	003144	PR2	=	000100	READIN=	000121		
LKS	001412	MSG. IC	043020	OPN N1	033554	PAT2	003044	PAT3	003044	PR3	=	000140	RECAL	=	000107	
LKV	001406	MSG IT	043031	OPN N2	033560	PAT4	003044	PAT5	003044	PR4	=	000200	RELEAS=	000113		
LOADRV	050012	MSG. LC	043005	OPN X1	033572	PAT6	003044	PAT7	003044	PR5	=	000240	RESREG=	104413		
LODFLT	024352	MSG. LS	043037	OPN X2	033576	PAT8	003044	PAT9	003044	PR6	=	000300	RESTAR	006102		
LODPRM	024610	MSG. LT	043026	OPN 1	032654	PAT10	003604	PAT11	003644	PR7	=	000340	RESVEC=	000010		
LOPRM	024610	MSG. LS	043037	OPN X2	033576	PAT12	003704	PAT13	003744	PR8	=	000400	RHVEC	001370		
LOP CK	026206	MSG. LT	043026	OPN 1	032654	PAT14	004004	PAT15	004044	PR9	=	000400	RH ADR	001366		
LPB	001422	MSG. PA	043042	OPN 2	032676	PAT2	003204	PAT3	003244	PR10	=	002544	RMR	=	000004	
LPS	001420	MSG. R	043000	OPT	035574	PAT4	003304	PAT5	003344	PR11	002564	RPADR	034514			
LPTAVL	001230	MSG. R	043000	OR	=	000200	PAT6	003404	PAT7	003444	PR12	002606	RPAS	=	000016	
LP AVL	024032	MSG. SP	044040	PACK	=	000123	PAT8	003504	PAT9	003544	PR13	002622	RPBA	=	000004	
LS	001526	MSGOU S	043725	PAR	=	000010	PAT10	003604	PAT11	003644	PR14	002636	RPCA	=	000034	
LST	=	MSG10A	043452	PAT	001530	PPN	=	000000	PR1	=	000040	PR15	004044	RPCC	=	000036
LT	001520	MSG10B	043521	PAT PT	003044	PR2	=	000100	PR2	=	000100	PR16	002652			
MABOVE	043761	MSG11A	043536	PAT0	003104	PR3	=	000140	PR3	=	000140	PR17	002700			
		MSG11B	043604	PAT1	003144	PR4	=	000200	PR4	=	000200	PR18	002744			
		MSG12A	043621									PR19	002744			

RPCS1 = 000000	SEEK = 000105	SW02 = 000004	TIM UP 001276	T7B 003004
RPCS2 = 000010	SEEKFG 034456	SW03 = 000010	TITLE 047712	ULDFLG 034434
RPDA = 000006	SEKCNT 001346	SW04 = 000020	TKVEC = 000060	UNLOAD= 000103
RPDB = 000022	SEKTR 001344	SW05 = 000040	TPB 001416	UNS = 040000
RPDS1 = 000012	SELDRV= 000145	SW06 = 000100	TPS 001414	UNTMSG 043120
RPDT = 000026	SERIAL 043401	SW07 = 000200	TPVEC = 000064	UNTOFF 043126
RPEC1 = 000044	SETBUF 030360	SW08 = 000400	TRAPVE= 000034	UNTON 043137
RPEC2 = 000046	SETFOR= 000143	SW09 = 001000	TRCKWC 001352	UPE = 020000
RPERRS 034346	SETVEC 005336	SW1 = 000002	TRE = 040000	US1 = 000001
RPER1 = 000014	SET IE 042152	SW10 = 002000	TRK DS 001274	US2 = 000002
RPER2 = 000040	SKI = 040000	SW11 = 004000	TRK RD 001264	US4 = 000004
RPER3 = 000042	SLASH 043074	SW12 = 010000	TRK1 = 004000	UWR = 000010
RPINIT 034532	SRCHWT 034430	SW13 = 020000	TRK10 = 040000	VERIFY 026526
RPLA = 000020	SRCHOO 026670	SW14 = 040000	TRK2 = 010000	VUF = 000002
RPMR = 000024	SRTDRV 005572	SW15 = 100000	TRK20 = 100000	VU30 = 010000
RPOF = 000032	SRTINT 005304	SW2 = 000004	TRK4 = 020000	VV = 000100
RPSN = 000030	SRVCLK 024340	SW3 = 000010	TRNSWT 034426	WAO = 000002
RPT 001506	STACK = 001100	SW4 = 000020	TRTVEC= 000014	WCE = 040000
RPTMR 040734	STALL 026364	SW5 = 000040	TSTNMS 001234	WCEFLG 001334
RPVEC 034516	STALLO 001336	SW6 = 000100	TSTO 006354	WCF = 000040
RPWC = 000002	STALL1 001354	SW7 = 000200	TST1 006516	WCU = 000001
RP REG 004204	STALL2 001356	SW8 = 000400	TST10 010720	WLE = 004000
RPO4 035302	STALL3 001360	SW9 = 001000	TST10A 011364	WRCKD = 000151
RPO4B 043212	START 004672	SYSTAT 043100	TST10B 011756	WRCKHD= 000153
RPO5 043217	START1 004636	TAP = 040000	TST11 012024	WRITE = 000161
RPO6 043224	START2 004660	TBITVE= 000014	TST12 012244	WRL = 004000
RSTRT1 006046	START3 004626	TD 037442	TST13 013002	WRTHD = 000163
RSTRT2 006072	START4 004650	TDF = 000040	TST14 013446	WRT AD 041732
RTC = 000117	STATBL 004254	TESTNG 043357	TST15 014164	WRT RP 041642
R6 = %000006	STKLMT= 177774	TESTO 006500	TST16 014702	WRT R1 041726
R7 = %000007	STO 041026	TEST1 006656	TST17 015300	WRT R2 042016
SAVCSW 001222	STO1 041056	TEST10 011126	TST2 006674	WRT R3 042024
SAVEFG 034454	STO2 041254	TEST11 012164	TST20 015720	WRT R4 042030
SAVREG= 104412	STO3 041324	TEST12 012432	TST21 016440	WRT R5 042032
SC 037602	STO5 041350	TEST13 013126	TST22 017216	WRT WD 041730
SCTRWC= 177400	STO6 041356	TEST14 013572	TST3 007112	WRU = 000400
SC1 = 000100	STO7 041414	TEST15 014310	TST4 007306	WSU = 000004
SC10 = 001000	STO8 041444	TEST16 014776	TST5 007674	\$AUTOB 001134
SC11 040434	STO9 041454	TEST17 015374	TST6 010074	\$BDADR 001122
SC12 040524	STRTMR 027054	TEST2 007004	TST7 010340	\$BODAT 001126
SC13 040574	STRT1A 004642	TEST20 016122	TUF = 000100	\$BELL 001210
SC2 = 000200	STRT2A 004664	TEST21 016710	TWOMS 025446	\$CHARC 020656
SC20 = 002000	ST CLK 024074	TEST22 017304	TYPDS = 104405	\$CKSWR 021632
SC3 037652	ST LCL 024304	TEST3 007222	TYPE = 104401	\$CMTAG 00110C
SC4 037656	ST PCL 024242	TEST4 007432	TYPERR 020054	\$CM1 = 000006
SC5 037670	SVADR 001340	TEST5 010004	TYPOC = 104402	\$CM2 = 000014
SC6 040070	SVRH11 042034	TEST6 010204	TYPON = 104404	\$CM3 = 000006
SC6A 040200	SVSTAT 001260	TEST7 010462	TYPOS = 104403	\$CM4 = 000003
SC7 040326	SWR 001140	TICKMS 001246	TPTIM 027252	\$CNTLC 022544
SC8 040404	SWREG 000176	TICKUS 001250	TIG 003014	\$CNTLG 022556
SEARCH= 000131	SWO = 000001	TIMER 034460	T11 003024	\$CNTLU 022551
SEC DS 001272	SWOO = 000001	TIM DN 001314	T12 003034	\$CRLF 001215
SEC RD 001266	SWO1 = 000002	TIM PT 001332	T7A 002774	\$DBLK 021324

\$DB2D 023254	\$GET42 017604	\$QUES 001214	\$SVLAD 022774	\$TPS 001150
\$DECLV 023434	\$GTSWR 021722	\$RAND 023510	\$SVPC = 000200	\$TRAP 023134
\$DIV 023612	\$HD = 000000	\$RCHR 022174	\$SWR = 167000	\$TRAP2 023156
\$DOAGN 017624	\$HNUM 023606	\$RDLIN 022264	\$SWRMK= 000000	\$TRP = 000014
\$DTBL 021314	\$ICNT 001104	\$RDSZ = 000024	\$TIMES 001204	\$TRPAD 023170
\$ENDAD 017614	\$INTAG 001135	\$REGAD 001160	\$TKB 001146	\$TSTNM 001102
\$ENDCT 017550	\$ITEMB 001114	\$REGO 001162	\$TKCNT 021334	\$TTYIN 022520
\$ENULL 017630	\$LF 001216	\$REG1 001164	\$TKINT 021344	\$TYPOS 021110
\$EOP 017366	\$LONUM 023610	\$REG2 001166	\$TKQEN= 021344	\$TYPE 020442
\$EOPCT 017542	\$LPADR 001106	\$REG3 001170	\$TKQIN 021336	\$TYPEC 020612
\$ERFLG 001103	\$LPERR 001110	\$REG4 001172	\$TKQOU 021340	\$TYPEX 020660
\$ERMAX 001115	\$LSTAD 050402	\$REG5 001174	\$TKQSR 021342	\$TYPOC 020706
\$ERROR 017634	\$MNEW 022574	\$RESRE 023076	\$TKS 001144	\$TYPON 020722
\$ERRPC 001116	\$MSWR 022563	\$RTNAD 017626	\$TKSRV 021414	\$TYPOS 020662
\$ERRTB 004306	\$MXCNT 023036	\$SAVRE 023040	\$TMPD 001176	\$XTSTR 022620
\$ERTTL 001112	\$NULL 001154	\$SB2D 023220	\$TMP1 001200	\$SGET4= 000000
\$ESCAP 001206	\$NWTST= 000001	\$SCOPE 022606	\$TMP2 001202	\$OFILL 021105
\$FILLC 001156	\$OCNT 021104	\$SETUP= 000147	\$TN = 000023	= 050604
\$FILLS 001155	\$OMODE 021106	\$SIZE 050306	\$TNPWR 023364	
\$GDADR 001120	\$OVER 023022	\$STUP = 177777	\$TPB 001152	
\$GDDAT 001124	\$PASS 001100	\$SUPRS 023450	\$TPFLG 001157	

ABS 050604 000

ERRORS DETECTED 0

DSKW DZRJAB, DSKW DZRJAB/SOL=DSKW SYSMAC SML, DSKM DZRJAB 010, DSKM DZRJAB P11  
 RUN-TIME 24 34 9 SECONDS  
 RUN-TIME RATIO 452/59=7 5  
 CORE USED 52K (103 PAGES)

