

```

000002 A 1 VORTEX SET 2 PUT LAST FOR VORTEX 07 00001
2 * 07 00002
3 ***** 07 00003
4 * 07 00004
5 * RE EN TR AN T R U N - T I M E I / O * 07 00005
6 * 07 00006
7 * NAME: SOFTWARE: VSRERS * 07 00007
8 * FIRMWARE: VSRERF * 07 00008
9 * * 07 00009
10 * BITS IN FLAG WORD 'VORTEX' ARE DEFINED THUS: * 07 00010
11 * * 07 00011
12 * BIT 0: SET FOR VORTEX II * 07 00012
13 * BIT 1: SET IF VSRERR IN NUCLEUS * 07 00013
14 * BIT 2: SET IF WCS AVAILABLE * 07 00014
15 * * 07 00015
16 * * 07 00016
17 ***** 07 00017
000000 A 19 WCS SET VORTEX/4 SET WCS=BIT 2 OF VORTEX FG 07 00019
000000 A 20 NUC SET WCS#4 FG 07 00020
000002 A 21 VII SET VORTEX-NUC FG 07 00021
000001 A 22 NUC SET VII/2 SET NUC=BIT 1 OF VORTEX FG 07 00022
000000 A 23 VII SET VII-NUC-NUC SET VII=BIT 0 OF VORTEX FG 07 00023
25 IFF WCS 07 00025
26 TITLE VSRERS SOFTWARE NAME 07 00026
27 IFT WCS 07 00027
28 TITLE VSRERF FIRMWARE NAME 07 00028
30 ***** 07 00030
31 * ENTRIES * 07 00031
32 ***** 07 00032
33 NAME VSRERR ALOC ENTRY 07 00033
34 NAME VSRER1 NON-ALOC ENTRY 07 00034
35 NAME VSRERN VSRERR NUCLEUS FLAG V2 07 00035
37 IFF WCS 07 00037
38 NAME VSRERS SOFTWARE NAME 07 00038
39 IFT WCS 07 00039
40 NAME VSRERF FIRMWARE NAME 07 00040
000000 R 42 VSRERS EQU * SOFTWARE NAME 07 00042
000000 R 43 VSRERF EQU * FIRMWARE NAME 07 00043
45 IFT NUC FG 07 00045
000001 A 46 VSRERN EQU 1 VSRERN = 1 IF VSRERR IN NUCLEUS FG 07 00046
47 IFF NUC FG 07 00047
48 VSRERN EQU 0 VSRERN = 0 IF VSRERR IN DM FG 07 00048
50 ***** 07 00050
51 * EXTERNALS * 07 00051
52 ***** 07 00052
53 EXT SIFCB 07 00053
54 EXT PIFCB 07 00054
55 EXT LOFCB 07 00055
56 EXT BIFCB 07 00056
57 EXT RDFCB 07 00057
58 EXT SSFCB 07 00058
59 EXT GDFCB 07 00059
60 EXT PDFCB 07 00060
61 EXT V4EXEC VORTEX EXEC 07 00061
63 ***** 07 00063
64 * VDM 620/I INSTRUCTION SYMBOLS * 07 00064
65 ***** 07 00065
000040 A 66 ARST SET 040 A-REG BIT RESET 07 00066
000000 A 67 ASET SET 0 A-REG BIT SET 07 00067
000002 A 68 B SET 2 B-REGISTER 07 00068
000000 A 69 B0 SET 0 07 00069
000001 A 70 B1 SET 1 07 00070
000002 A 71 B2 SET 2 07 00071
000003 A 72 B3 SET 3 07 00072
000004 A 73 B4 SET 4 07 00073
000005 A 74 B5 SET 5 07 00074
000006 A 75 B6 SET 6 07 00075
000014 A 76 B12 SET 12 07 00076
000015 A 77 B13 SET 13 07 00077
000016 A 78 B14 SET 14 07 00078
000017 A 79 B15 SET 15 07 00079
000046 A 80 MAP SET 046 MAP DEVICE ADDRESS V2 07 00080
000001 A 81 X SET 1 X-REGISTER 07 00081
83 ***** 07 00083
84 * VORTEX LOW-CORE SYMBOLS * 07 00084
85 ***** 07 00085
000300 A 86 LC SET 0000 07 00086
000420 A 87 MT SET 0420 07 00087
000472 A 88 BR17 SET MT+42 07 00088
000473 A 89 BR37 SET MT+43 07 00089
000474 A 90 BR77 SET MT+44 07 00090
000441 A 91 BR0 SET MT+17 07 00091
000442 A 92 BR1 SET MT+18 07 00092
000443 A 93 BR2 SET MT+19 07 00093
000444 A 94 BR3 SET MT+20 07 00094
000445 A 95 BR4 SET MT+21 07 00095
000446 A 96 BR5 SET MT+22 07 00096
000447 A 97 BR6 SET MT+23 07 00097
000450 A 98 BR7 SET MT+24 07 00098
000451 A 99 BR8 SET MT+25 07 00099
000454 A 100 BR11 SET MT+28 07 00100
000455 A 101 BR12 SET MT+29 07 00101
000457 A 102 BR14 SET MT+31 07 00102

```



000460	A	103	BR15	SET	MT+32			07	00103
000421	A	104	BS0	SET	MT+1		V2	07	00104
000422	A	105	BS1	SET	MT+2			07	00105
000424	A	106	BS3	SET	MT+4			07	00106
000425	A	107	BS4	SET	MT+5			07	00107
000426	A	108	BS5	SET	MT+6			07	00108
000425	A	109	D16	SET	BS4			07	00109
000423	A	110	BS2	SET	MT+3			07	00110
000430	A	111	BS7	SET	MT+8			07	00111
000431	A	112	BS8	SET	MT+9			07	00112
000432	A	113	BS9	SET	MT+10			07	00113
000433	A	114	BS10	SET	MT+11			07	00114
000434	A	115	BS11	SET	MT+12			07	00115
000435	A	116	BS12	SET	MT+13			07	00116
000437	A	117	BS14	SET	MT+15			07	00117
000440	A	118	BS15	SET	MT+16			07	00118
000451	A	119	BFR	SET	BR0+BF	RESET BF FLAG	V2	07	00119
000431	A	120	BFS	SET	BS0+BF	SET BF FLAG	V2	07	00120
000430	A	121	BXBIAS	SET	BS7	BINARY EXPONENT BIAS	V2	07	00121
000472	A	122	D15	SET	BN17			07	00122
000465	A	123	FIVE	SET	MT+37			07	00123
000015	A	124	FLF	SET	SH+LF	FCB LF FLAG	V2	07	00124
000423	A	125	FOUR	SET	MT+3			07	00125
000016	A	126	FPO	SET	SH+FD	FCB PD FLAG	V2	07	00126
000457	A	127	FPOB	SET	BR0+FPO	RESET FCB PD FLAG	V2	07	00127
000437	A	128	FPOS	SET	BS0+FPO	SET FCB PD FLAG	V2	07	00128
000017	A	129	FRB	SET	SH+RB	FCB RB FLAG	V2	07	00129
000440	A	130	FRBS	SET	BS0+FRB	SET FCB RB FLAG	V2	07	00130
000014	A	131	FRM	SET	SH+RM	FCB RM FLAG	V2	07	00131
000430	A	132	GFS	SET	BS0+GF	SET GLOBAL FCB FLAG	V2	07	00132
000424	A	133	EIGHT	EQU	MT+4			07	00133
000447	A	134	INR	SET	BR0+IN	RESET IN BIT	V2	07	00134
000427	A	135	INS	SET	BS0+IN	SET IN FLAG	V2	07	00135
000422	A	136	LFS	SET	BS0+LF	SET LF FLAG	V2	07	00136
000462	A	137	LHW	SET	MT+34			07	00137
000470	A	138	NINE	SET	MT+40			07	00138
000421	A	139	ONE	SET	MT+1			07	00139
000443	A	140	PDR	SET	BR0+PD	RESET PD FLAG	V2	07	00140
000423	A	141	POS	SET	BS0+PD	SET PD FLAG	V2	07	00141
000424	A	142	RBS	SET	BS0+RB	SET RB BIT	V2	07	00142
000463	A	143	RHW	SET	MT+35			07	00143
000446	A	144	SCR	SET	BR0+SC	RESET SC BIT	V2	07	00144
000467	A	145	SEVEN	SET	MT+39			07	00145
000466	A	146	SIX	SET	MT+38			07	00146
000001	A	147	BR	SET	1	STACK B-REGISTER	V2	07	00147
000003	A	148	PR	SET	3	STACK P-REGISTER	V2	07	00148
000421	A	149	RMS	SET	BS0+RM	SET RM BIT	V2	07	00149
000426	A	150	SCS	SET	BS0+SC	SET SC BIT	V2	07	00150
000471	A	151	TEN	SET	MT+41			07	00151
000464	A	152	THREE	SET	MT+36			07	00152
000425	A	153	TRS	SET	BS0+TR	SET TR BIT	V2	07	00153
000422	A	154	TWO	SET	MT+2			07	00154
000414	A	155	V\$BVN	SET	LC+76	BOTTOM OF VORTEX NUCLEUS		07	00155
000301	A	156	V\$CPL	SET	LC+1	CURRENT PRIORITY LEVEL		07	00156
000302	A	157	V\$CRS	SET	LC+2	POINTER TO REENIRANT STACK		07	00157
000355	A	158	V\$DSTB	SET	LC+45			07	00158
000316	A	159	V\$LUP	SET	LC+14	1ST WORD OF BACKGROUND		07	00159
000317	A	160	V\$LLUP	SET	LC+15	LAST WORD OF BACKGROUND		07	00160
000400	A	161	V\$LUT1	SET	LC+64			07	00161
000401	A	162	V\$LUT2	SET	LC+65			07	00162
000402	A	163	V\$LUT3	SET	LC+66			07	00163
000334	A	164	V\$ST0	SET	LC+28	EXEC STATE 0	V2	07	00164
000335	A	165	V\$ST1	SET	LC+29	EXEC STATE 1	V2	07	00165
000336	A	166	V\$ST2	SET	LC+30	EXEC STATE 2	V2	07	00166
000337	A	167	V\$ST3	SET	LC+31	EXEC STATE 3	V2	07	00167
000452	A	168	WR	SET	BR0+WR	RESET WR BIT	V2	07	00168
000432	A	169	WRS	SET	BS0+WR	SET WR BIT	V2	07	00169
000420	A	170	ZERO	EQU	MT			07	00170
172					*****			07	00172
173					* CHARACTER TYPE FLAGS *			07	00173
174					*****			07	00174
000000	A	175	AL	SET	0	ALPHA CHAR BIT(EXCEPT P)		07	00175
000001	A	176	BL	SET	1	BLANK CHAR BIT		07	00176
000002	A	177	CM	SET	2	'.' CHAR BIT		07	00177
000003	A	178	LF	SET	3	'<' CHAR BIT		07	00178
000004	A	179	MN	SET	4	'-' CHAR FLAG		07	00179
000005	A	180	NH	SET	5	NUMERIC CHAR BIT		07	00180
000006	A	181	PL	SET	6	'+' CHAR BIT		07	00181
000007	A	182	PS	SET	7	'P' SCALE FACTOR		07	00182
000010	A	183	PT	SET	8	'.' CHAR BIT		07	00183
000011	A	184	QT	SET	9	' ' CHAR BIT		07	00184
000012	A	185	RP	SET	10	'>' CHAR BIT		07	00185
000013	A	186	SL	SET	11	'/' CHAR BIT		07	00186
187					*****			07	00187
188					* READ/WRITE FLAGS *			07	00188
189					*****			07	00189
000000	A	190	RM	SET	0	RMD FLAG	V2	07	00190
000001	A	191	LF	SET	1	LOGICAL FILE FLAG	V2	07	00191
000002	A	192	PD	SET	2	BUFFER POSTING FLAG	V2	07	00192
000003	A	193	RB	SET	3	READ BEFORE WRITE FLAG	V2	07	00193
000014	A	194	SH	SET	15-RB	FCB CONTROL FLAG SHIFT	V2	07	00194
000004	A	195	TR	SET	4	TERMINATE FLAG	V2	07	00195
000005	A	196	SC	SET	5	SUPPRESS CLEAR	V2	07	00196



```

000006 A 197 IN SET 6 INITIALIZE FLAG V2 07 00197
000007 A 198 GF SET 7 GLOBAL FCB FLAG V2 07 00198
000010 A 199 BF SET 8 BUFFER FILL FLAG V2 07 00199
000400 A 200 BFA SET 0400 BF ABS VALUE 07 00200
000011 A 201 WR SET 9 WRITE FLAG V2 07 00201
000012 A 202 EC SET 10 ENCODE/DECODE FLAG PD 07 00202
000013 A 203 DA SET 11 DIRECT ACCESS FLAG 07 00203
204 07 00204
206 *****
207 * STACK OPS * 07 00206
208 ***** 07 00207
000012 A 209 STKSZ SET 10 STACK SIZE 07 00208
000420 A 210 CXC SET ZERO CALL EXEC FOR IOLINK 07 00209
000421 P 211 CER SET ONE CALL ERROR 07 00210
000422 A 212 CEX SET TWO CALL EXIT 07 00211
000464 A 213 CIO SET THREE CALL I/O 07 00212
000423 A 214 CRB SET FOUR CALL REENTRANT BLOCK 07 00213
000465 A 215 CTR SET FIVE TERMINATE 07 00214
000005 A 216 CTRV SET SIX 07 00215
000466 A 217 CXF SET SEVEN PARAMETER XFER V2 07 00216
000467 A 218 CRK SET EIGHT BACKSPACE V2 07 00217
000424 A 219 CEF SET NINE ENDFILE V2 07 00218
000470 A 220 CRW SET TEN REWIND V2 07 00219
000471 A 221 CRD SET ELEVEN READ V2 07 00220
222 *CWR SET TWELVE WRITE V2 07 00221
223 *COL SET THIRTEEN CLOSE FILE V2 07 00222
224 *CCB SET FOURTEEN CLOSE BLOCKED FILE V2 07 00223
225 *COP SET FIFTEEN OPEN FILE V2 07 00224
000013 A 226 COPV SET OPEN BLOCKED FILE V2 07 00225
227 *COB SET DECODE PD 07 00226
000020 A 228 CDC SET ENCODE PD 07 00227
000021 A 229 CEN SET DIRECT ACCESS READ V2 07 00228
000022 A 230 CRA SET DIRECT ACCESS WRITE V2 07 00229
231 *CWA SET 07 00230
232 07 00231
233 ***** 07 00232
234 * MACROS * 07 00233
235 ***** 07 00234
237 ***** 07 00235
238 * ADD B-REF TO B-REF INTO B-REF * 07 00236
239 ***** 07 00237
240 ADBBB MAC 07 00238
241 LDA P(1),B 07 00239
242 ADD P(2),B 07 00240
243 STA P(3),B 07 00241
244 EMAC 07 00242
246 ***** 07 00243
247 * DECREMENT/IN A/B-REF * 07 00244
248 ***** 07 00245
249 DAB MAC 07 00246
250 LDA P(1),B 07 00247
251 DAR 07 00248
252 STA P(1),B 07 00249
253 EMAC 07 00250
255 ***** 07 00251
256 * DECREMENT B-REF/IN A/TO B-REF * 07 00252
257 ***** 07 00253
258 DABB MAC 07 00254
259 LDA P(1),B 07 00255
260 DAR 07 00256
261 STA P(2),B 07 00257
262 EMAC 07 00258
264 ***** 07 00259
265 * DECREMENT/IN A/X-REF * 07 00260
266 ***** 07 00261
267 DAX MAC 07 00262
268 LDA P(1),X 07 00263
269 DAR 07 00264
270 STA P(1),X 07 00265
271 EMAC 07 00266
273 ***** 07 00267
274 * MOVE 2 REF OP TO B-REF OP THRU A * 07 00268
275 ***** 07 00269
276 MOVBAB MAC 07 00270
277 LDA P(1),B 07 00271
278 STA P(2),B 07 00272
279 EMAC 07 00273
281 ***** 07 00274
282 * MOVE B-REF TO X-REF THRU A * 07 00275
283 ***** 07 00276
284 MOVBAK MAC 07 00277
285 LDA P(1),B 07 00278
286 STA P(2),X 07 00279
287 EMAC 07 00280
289 ***** 07 00281
290 * MOVE P-REF OP TO B-REF OP THRU A * 07 00282
291 ***** 07 00283
292 MOVPAK MAC 07 00284
293 LDA P(1) 07 00285
294 STA P(2),B 07 00286
295 EMAC 07 00287
297 ***** 07 00288
298 * MOVE P-REF/ THRU A/ TO X-REF * 07 00289
299 ***** 07 00290

```



```

300 MOVVAX MAC                                07 00300
301     LDA      P(1)                          07 00301
302     STA      P(2),X                        07 00302
303     EMAC                                     07 00303
305 *****                                  07 00305
306 * MOVE X-REF TO Z-REF THRU A *            07 00306
307 *****                                  07 00307
308 MOVVAB MAC                                07 00308
309     LDA      P(1),X                        07 00309
310     STA      P(2),B                        07 00310
311     EMAC                                     07 00311
313 *****                                  07 00313
314 * MOVE X-REF TO X-REF THRU A *            07 00314
315 *****                                  07 00315
316 MOVVAX MAC                                07 00316
317     LDA      P(1),X                        07 00317
318     STA      P(2),X                        07 00318
319     EMAC                                     07 00319
321 *****                                  07 00321
322 * POP/JUMP *                               FG 07 00322
323 *****                                  FG 07 00323
325 POPJ   MAC                                FG 07 00323
326     IFF      WCS                            FG 07 00326
327     GOTO     WCS1                          FG 07 00327
328     DATA    0105065                       FG 07 00328
329     GOTO     WCS2                          FG 07 00329
330 WCS1   CONT                               FG 07 00330
331     JMP      POJ                            FG 07 00331
332 WCS2   CONT                               FG 07 00332
333     EMAC                                     FG 07 00333
335 *****                                  V2 07 00335
336 * POP OP TO X *                           V2 07 00336
337 *****                                  V2 07 00337
338 POPX   MAC                                07 00338
339     LDX      OPSTKP,B                       07 00339
340     INR      OPSTKP,B                       FG 07 00340
341     LDX      0,X                            FG 07 00341
342     EMAC                                     07 00342
344 *****                                  V2 07 00344
345 * PUSH P(1) *                              V2 07 00345
346 *****                                  V2 07 00346
347 PUSH   MAC                                07 00347
348     INR      OPSTKP,B                       07 00348
349     LDX      OPSTKP,B                       07 00349
350     LDA      P(1)                           07 00350
351     STA      0,X                            07 00351
352     EMAC                                     07 00352
353 *****                                  07 00353
354 * PUSH OP ONTO V$FORTIO STACK *            07 00354
355 *****                                  07 00355
357 PUSMF  MAC                                07 00357
358     LDX      ANRB,B                          07 00358
359     LDX      OPSTKP,X                       07 00359
360     DXR                                     FG 07 00360
361     STA      0,X                            07 00361
362     TXA                                     FG 07 00362
363     LDX      ANRB,B                          FG 07 00363
364     STA      OPSTKP,X                       FG 07 00364
365     EMAC                                     07 00365
367 *****                                  07 00367
368 * PUSH/JUMP TO P(1) *                       V2 07 00368
369 *****                                  07 00369
370 PUSHJ  MAC                                07 00370
371     IFF      WCS                            FG 07 00371
372     GOTO     WCS1                          FG 07 00372
373     DATA    0105025                       FG 07 00373
374     DATA    P(1)                           FG 07 00374
375     GOTO     WCS2                          FG 07 00375
376 WCS1   CONT                               FG 07 00376
377     LDR1     P(1)                            V2 07 00377
378     JSR      PSJ,X                          07 00378
379 WCS2   CONT                               FG 07 00379
380     EMAC                                     07 00380
382 *****                                  07 00382
383 * SUBTRACT B-REF MINUS B-REF *              07 00383
384 *****                                  07 00384
385 SUTBB  MAC                                07 00385
386     LDA      P(1),B                          07 00386
387     SUB      P(2),B                          07 00387
388     EMAC                                     07 00388
390 *****                                  07 00390
391 * SUBTRACT B-REF MINUS B-REF TO B-REF *      07 00391
392 *****                                  07 00392
393 SUTBBB MAC                                07 00393
394     LDA      P(1),B                          07 00394
395     SUB      P(2),B                          07 00395
396     STA      P(3),B                          07 00396
397     EMAC                                     07 00397
399 *****                                  07 00399
400 * SUBTRACT B-REF MINUS P-REF TO B-REF *      07 00400
401 *****                                  07 00401
402 SUTBBB MAC                                07 00402
403     LDA      P(1),B                          07 00403

```







000013	A	507	LOC	SET	LOC+1		V2	07	00507
000110	A	508	AIBUF	SET	ISCB+1	LIST ITEM ADDRESS	V2	07	00508
000013	A	509	AISCB	SET	LOC	ADDRESS OF LIST ITEM SCB	V2	07	00509
000014	A	510	LOC	SET	LOC+1		V2	07	00510
000027	A	511	ALBF	SET	BSCB+1	ADDRESS OF LOGICAL BUFFER	V2	07	00511
000014	A	512	ALOC	SET	LOC	ALOC ENTRY FLAG	V2	07	00512
000015	A	513	LOC	SET	LOC+1		V2	07	00513
000015	A	514	ANPOJ	SET	LOC	ADDRESS OF V\$FORTID PDP/JUMP	V2	07	00514
000016	A	515	LOC	SET	LOC+1		V2	07	00515
000016	A	516	ANRB	SET	LOC	ADDRESS OF V\$FORTID DATA BLOCK	V2	07	00516
000017	A	517	LOC	SET	LOC+1		V2	07	00517
000017	A	518	AOPSTK	SET	LOC	ADDRESS OF OP STACK	V2	07	00518
000020	A	519	LOC	SET	LOC+1		V2	07	00519
000020	A	520	APBF	SET	LOC	ADDRESS OF PHYSICAL BUFFER	V2	07	00520
000021	A	521	LOC	SET	LOC+1		V2	07	00521
000021	A	522	ASCB	SET	LOC	SCAN BLOCK ADDRESS	V2	07	00522
000022	A	523	LOC	SET	LOC+1		V2	07	00523
000022	A	524	ASFL	SET	LOC	** FLAG	V2	07	00524
000023	A	525	LOC	SET	LOC+1		V2	07	00525
000023	A	526	ASYSDC	SET	LOC	ADDRESS OF SYSTEM DCB	V2	07	00526
000024	A	527	LOC	SET	LOC+1		V2	07	00527
000030	A	528	BCHAR	SET	BSCB+2	BUFFER CHARACTER	V2	07	00528
000031	A	529	BCODE	SET	BSCB+3	BUFFER CHARACTER CODE	V2	07	00529
000024	A	530	BEXP	SET	LOC	BINARY EXPONENT	V2	07	00530
000025	A	531	LOC	SET	LOC+1		V2	07	00531
000026	A	532	BFPT	SET	BSCB	BUFFER CHARACTER POINTER	V2	07	00532
000025	A	533	BFHPT	SET	LOC	BUFFER WORD POINTER	V2	07	00533
000026	A	534	LOC	SET	LOC+1		V2	07	00534
000026	A	535	BSCB	SET	LOC	BUFFER SCB	V2	07	00535
000032	A	536	LOC	SET	LOC+4		V2	07	00536
000032	A	537	CHB	SET	LOC	DECIMAL DIGIT ARRAY	V2	07	00537
000050	A	538	LOC	SET	LOC+14		V2	07	00538
000050	A	539	CHBPT	SET	LOC	CHB ARRAY POINTER	V2	07	00539
000051	A	540	LOC	SET	LOC+1		V2	07	00540
000051	A	541	CHNHDR	SET	LOC	FCB CHAIN HEADER	V2	07	00541
000052	A	542	LOC	SET	LOC+1		V2	07	00542
000052	A	543	COUNT	SET	LOC	COUNTER	V2	07	00543
000053	A	544	LOC	SET	LOC+1		V2	07	00544
000053	A	545	CVFL	SET	LOC	CHARACTER VALIDITY FLAGS	V2	07	00545
000054	A	546	LOC	SET	LOC+1		V2	07	00546
000054	A	547	D	SET	LOC	FRACTIONAL FIELD WIDTH	V2	07	00547
000055	A	548	LOC	SET	LOC+1		V2	07	00548
000055	A	549	DEXP	SET	LOC	DECIMAL EXPONENT	V2	07	00549
000056	A	550	LOC	SET	LOC+1		V2	07	00550
000056	A	551	DT	SET	LOC	WORKING FRACTIONAL FIELD WIDTH	V2	07	00551
000057	A	552	LOC	SET	LOC+1		V2	07	00552
000057	A	553	EDEXP	SET	LOC	EXPLICIT DECIMAL EXPONENT	V2	07	00553
000060	A	554	LOC	SET	LOC+1		V2	07	00554
000060	A	555	ERN	SET	LOC	ERROR NUMBER	V2	07	00555
000061	A	556	LOC	SET	LOC+1		V2	07	00556
000064	A	557	FCHAR	SET	FSCB+2	FORMAT CHARACTER	V2	07	00557
000065	A	558	FCDDE	SET	FSCB+3	FORMAT CHARACTER CODE	V2	07	00558
000061	A	559	FDLKEY	SET	LOC	FIELD DESCRIPTOR KEY	V2	07	00559
000062	A	560	LOC	SET	LOC+1		V2	07	00560
000062	A	561	FMPT	SET	FSCB	FORMAT STRING POINTER	V2	07	00561
000063	A	562	FRMT	SET	FSCB+1	ADDRESS OF FORMAT STRING(0 IF NONE)	V2	07	00562
000062	A	563	FRPT	SET	FSCB	FORMAT STRING CURRENT POINTER	V2	07	00563
000062	A	564	FSCB	SET	LOC	FORMAT STRING SCB	V2	07	00564
000066	A	565	LOC	SET	LOC+4		V2	07	00565
000066	A	566	GDRPC	SET	LOC	*(' GROUP DYNAMIC REPEAT COUNT	V2	07	00566
000077	A	567	LOC	SET	LOC+9		V2	07	00567
000071	A	568	GFRPT	SET	GDRPC+3	*(' GROUP FORMAT POINTER	V2	07	00568
000074	A	569	GSRPC	SET	GDRPC+6	*(' GROUP STATIC REPEAT COUNT	V2	07	00569
000111	A	570	ICHAR	SET	ISCB+2	LIST ITEM CHARACTER	V2	07	00570
000077	A	571	IDEXP	SET	LOC	IMPLICIT DECIMAL EXPONENT	V2	07	00571
000100	A	572	LOC	SET	LOC+1		V2	07	00572
000100	A	573	IFW	SET	LOC	INTEGER FIELD WIDTH	V2	07	00573
000101	A	574	LOC	SET	LOC+1		V2	07	00574
000101	A	575	IIBSZ	SET	LOC	INDIVIDUAL ITEM BYTE SIZE	V2	07	00575
000102	A	576	LOC	SET	LOC+1		V2	07	00576
000102	A	577	IISZ	SET	LOC	INDIVIDUAL ITEM WORD SIZE	V2	07	00577
000103	A	578	LOC	SET	LOC+1		V2	07	00578
000102	A	579	INFL	SET	LOC	INITIAL ENTRY FLAG	V2*	07	00579
000104	A	580	LOC	SET	LOC+1		V2	07	00580
000104	A	581	IDCONT	SET	LOC	V\$IDC CONTROL WORD	V2	07	00581
000105	A	582	LOC	SET	LOC+1		V2	07	00582
000105	A	583	IDLNK	SET	LOC	IDLINK CONTROL WORD	V2	07	00583
000106	A	584	LOC	SET	LOC+1		V2	07	00584
000106	A	585	IDSTAT	SET	LOC	I/D STATUS	V2	07	00585
000107	A	586	LOC	SET	LOC+1		V2	07	00586
000107	A	587	ISCB	SET	LOC	ITEM SCB	V2	07	00587
000113	A	588	LOC	SET	LOC+4		V2	07	00588
000113	A	589	ITENAD	SET	LOC	ADDRESS OF LIST ITEM	V2	07	00589
000114	A	590	LOC	SET	LOC+1		V2	07	00590
000114	A	591	ITEMWC	SET	LOC	COUNT OF WORDS REMAINING IN ITEM	V2	07	00591
000115	A	592	LOC	SET	LOC+1		V2	07	00592
000115	A	593	ITMINC	SET	LOC	LIST ITEM WORD INCREMENT	V2	07	00593
000116	A	594	LOC	SET	LOC+1		V2	07	00594
000116	A	595	ITMODE	SET	LOC	LIST ITEM MODE	V2	07	00595
000117	A	596	LOC	SET	LOC+1		V2	07	00596
000123	A	597	LGOV	SET	LRWC	LOGICAL RECORD OVERLAP	V2	07	00597
000117	A	598	LISTFL	SET	LOC	LIST DATA XFER FLAG	V2	07	00598
000120	A	599	LOC	SET	LOC+1		V2	07	00599



000120	A	600	LNKCNT	SET	LDC	LINK COUNT	V2	07	00600
000121	A	601	LDC	SET	LDC+1		V2	07	00601
000121	A	602	LRECND	SET	LDC	LOGICAL RECORD NUMBER	V2	07	00602
000122	A	603	LDC	SET	LDC+1		V2	07	00603
000122	A	604	LRSZ	SET	LDC	LOGICAL RECORD SIZE	V2	07	00604
000123	A	605	LDC	SET	LDC+1		V2	07	00605
000123	A	606	LRWC	SET	LDC	LOGICAL RECORD REMAINING WORD COUNT	V2	07	00606
000124	A	607	LDC	SET	LDC+1		V2	07	00607
000124	A	608	MOV	SET	LDC	MULTIPLY OVERFLOW SWITCH	V2	07	00608
000125	A	609	LDC	SET	LDC+1		V2	07	00609
000125	A	610	N	SET	LDC	H/T/X FIELD WIDTH	V2	07	00610
000126	A	611	LDC	SET	LDC+1		V2	07	00611
000126	A	612	NFF	SET	LDC	NUMERIC FORMAT FIELD VALUE	V2	07	00612
000127	A	613	LDC	SET	LDC+1		V2	07	00613
000127	A	614	DPSTK	SET	LDC	DP STACK	V2	07	00614
000141	A	615	LDC	SET	LDC+STKSZ		V2	07	00615
000000	A	616	DPSTKP	SET	0	DP STACK POINTER	FG	07	00616
000141	A	617	PARLV	SET	LDC	FORMAT 'C' GROUP LEVEL COUNT	V2	07	00617
000142	A	618	LDC	SET	LDC+1		V2	07	00618
000142	A	619	PBRC	SET	LDC	PHYSICAL BUFFER RECORD COUNT	V2	07	00619
000143	A	620	LDC	SET	LDC+1		V2	07	00620
000143	A	621	PBSZ	SET	LDC	PHYSICAL BUFFER SIZE	V2	07	00621
000144	A	622	LDC	SET	LDC+1		V2	07	00622
000144	A	623	PBWC	SET	LDC	PHYSICAL BUFFER REMAINING WORD COUNT	V2	07	00623
000145	A	624	LDC	SET	LDC+1		V2	07	00624
000145	A	625	PRECND	SET	LDC	PHYSICAL RECORD NUMBER	V2	07	00625
000146	A	626	LDC	SET	LDC+1		V2	07	00626
000146	A	627	PRLINK	SET	LDC	PREVIOUS FCB LINK	V2	07	00627
000147	A	628	LDC	SET	LDC+1		V2	07	00628
000147	A	629	PTFL	SET	LDC	'.' FLAG	V2	07	00629
000150	A	630	LDC	SET	LDC+1		V2	07	00630
000150	A	631	QFL	SET	LDC	QUOTE FLAG	V2	07	00631
000151	A	632	LDC	SET	LDC+1		V2	07	00632
000125	A	633	R	SET	N	REPEAT COUNT	V2	07	00633
000012	A	634	ROPSTP	SET	STKSZ	V#RERR DP STACK POINTER	V2	07	00634
000151	A	635	RETURN	SET	LDC	RETURN ADDR/'END' ADDR/'ERR' ADDR	PD	07	00635
000154	A	636	LDC	SET	LDC+3		PD	07	00636
000154	A	637	RWFL	SET	LDC	FLAG WORD	V2	07	00637
000155	A	638	LDC	SET	LDC+1		V2	07	00638
000155	A	639	S	SET	LDC	SCALE FACTOR	V2	07	00639
000156	A	640	LDC	SET	LDC+1		V2	07	00640
000032	A	641	SAVE	SET	CHB	SAVE PARAMETERS	V2	07	00641
000156	A	642	SCF	SET	LDC	SCALE FACTOR FLAG	V2	07	00642
000157	A	643	LDC	SET	LDC+1		V2	07	00643
000157	A	644	SGFL	SET	LDC	SIGN FLAG	V2	07	00644
000160	A	645	LDC	SET	LDC+1		V2	07	00645
000160	A	646	SVRECN	SET	LDC	SAVE RECORD NO		07	00646
000161	A	647	LDC	SET	LDC+1			07	00647
000162	A	648	SYSBF	SET	SYSDCB+1	ADDRESS OF SYSTEM BUFFER \$BUF	V2	07	00648
000161	A	649	SYSDCB	SET	LDC	SYSTEM DCB	V2	07	00649
000164	A	650	LDC	SET	LDC+3		V2	07	00650
000164	A	651	TEMP	SET	LDC	TEMP STORE	V2	07	00651
000165	A	652	LDC	SET	LDC+1		V2	07	00652
000165	A	653	TEMP1	SET	LDC	TEMP STORE		07	00653
000166	A	654	LDC	SET	LDC+1			07	00654
000166	A	655	TERM	SET	LDC	PRODUCT TERM	V2	07	00655
000167	A	656	LDC	SET	LDC+1		V2	07	00656
000167	A	657	UNIT	SET	LDC	I/O UNIT NUMBER	V2	07	00657
000170	A	658	LDC	SET	LDC+1		V2	07	00658
000170	A	659	W	SET	LDC	FIELD WIDTH	V2	07	00659
000171	A	660	LDC	SET	LDC+1		V2	07	00660
000171	A	661	WT	SET	LDC	WORKING VALUE OF W	V2	07	00661
000172	A	662	LDC	SET	LDC+1		V2	07	00662
000172	A	663	XFFL	SET	LDC	PARAMETER XFER ENABLE FLAG	V2	07	00663
000173	A	664	LDC	SET	LDC+1		V2	07	00664
000173	A	665	XFL	SET	LDC	EXPONENT FIELD NON-BLANK FLAG	V2	07	00665
000174	A	666	LDC	SET	LDC+1		V2	07	00666
000174	A	667	XFW	SET	LDC	EXPONENT FIELD WIDTH	V2	07	00667
000175	A	668	LDC	SET	LDC+1		V2	07	00668
000175	A	669	XSG	SET	LDC	EXPONENT SIGN FLAG	V2	07	00669
000176	A	670	LDC	SET	LDC+1		V2	07	00670
000176	A	671	ZFW	SET	LDC	LEADING ZERO FIELD WIDTH	V2	07	00671
000177	A	672	LDC	SET	LDC+1		V2	07	00672
000177	A	673	YYY	SET	LDC	END OF SAVE BLOCK	V2	07	00673
000177	A	674	AZER	SET	LDC	ASCII ZERO	V2	07	00674
000200	A	675	LDC	SET	LDC+1		V2	07	00675
000200	A	676	BD14	SET	LDC	DECIMAL 14	V2	07	00676
000201	A	677	LDC	SET	LDC+1		V2	07	00677
000201	A	678	BD120	SET	LDC	DECIMAL 120	V2	07	00678
000202	A	679	LDC	SET	LDC+1		V2	07	00679
000202	A	680	BLNK1	SET	LDC	ASCII BLANK CHARACTER	V2	07	00680
000203	A	681	LDC	SET	LDC+1		V2	07	00681
000203	A	682	BLNK2	SET	LDC	ASCII BLANK WORD	V2	07	00682
000204	A	683	LDC	SET	LDC+1		V2	07	00683
000204	A	684	ZZZ	SET	LDC	END OF DATA BLOCK	V2	07	00684
685			EJEC					07	00685
686			*****					07	00686
687			*					07	00687
688			* PROCESS A FORMAT DESCRIPTOR (AID)					07	00688
689			*					07	00689
690			* FUNCTION: TO PROCESS THE A FORMAT DESCRIPTOR: RAW					07	00690
691			*					07	00691
692			* ENTRY: DIRECT FROM FRS					07	00692







```

000070 005042 R      741      MOVBAR 1CHAR,BCHAR      MOVE CHAR FROM LIST SCB TO BUFF SCB      07 00741
000071 016111 A
000072 056030 A      742      PUSHJ  UCB      OUTPUT CHARACTER TO BUFFER/EXIT      V2 07 00742
000073 006010 A
000074 002646 R
000075 006505 A
000076 005042 R
000077 001000 A      743      JMP    AIDL2      LOOP TILL DONE      07 00743
000100 000063 R      744      EUEC      07 00744
745 *****
746 *
747 *      C A L L  N O N - R E E N T R A N T  B L O C K ( C A N )
748 *
749 * FUNCTION: TO RETURN TO V$FORTIO      07 00749
750 *
751 * ENTRY: ALOC .NE. 0 IF V$RERR ENTERED BY ALOC      V2* 07 00751
752 *          .EQ. 0 IF V$RERR ENTERED BY DIRECT JUMP      V2* 07 00752
753 *
754 *          V$CRS = CURRENT REENTRANT STACK POINTER      * 07 00754
755 *          V$CRS(PT) = LOCATION WHERE P-REG(RETURN ADDRESS) IS STORED      * 07 00755
756 *
757 * EXIT : TO V$FORTIO POP/JUMP ADDRESS IN ANPOJ      * 07 00757
758 *
759 *          VIA DEALOC IF ENTERED BY ALOC      V2* 07 00759
760 *          VIA DIRECT JUMP IF ENTERED BY DIRECT JUMP      V2* 07 00760
761 *
762 * RETURN ADDRESSES IN V$FORTIO STACK SAVED IN V$RERR IF      * 07 00762
763 * VORTEX II CALL FROM BACKGROUND TO NUCLEUS.      * 07 00763
764 *
765 *****
000101 036015 A      767 CAN  LDX  ANPOJ,B      POINT X AT V$FORTIO POP/JUMP      V2 07 00767
768      IFF  NUC      FG 07 00769
769      GOTO NUC1      FG 07 00770
770      IFT  VII      FG 07 00772
771      GOTO NUC2      FG 07 00773
000102 016014 A      775 LDA  ALOC,B      GET ALOC ENTRY FLAG      FG 07 00775
000103 001016 A      776 JANZ CAN1      TEST VORTEX BACKGROUND CALL TO NUCLEUS      FG 07 00776
000104 000107 R
778 *****
779 * EXIT TO V$FORTIO VIA DIRECT JUMP *      FG 07 00779
780 *****
782 NUC1  CONT      FG 07 00782
000105 006705 A      783      IJMP  0,X      FG 07 00783
000106 000000 A
784 NUC2  CONT      FG 07 00784
786 *****
787 * EXIT TO V$FORTIO VIA DEALOC *      FG 07 00787
788 *****
000107 R      790 CAN1  EQU  *      FG 07 00790
792      IFF  NUC      FG 07 00792
793      GOTO NUC1      FG 07 00793
794      IFT  VII      FG 07 00795
796      DMC  MAP,V$ST2      SET EXEC STATE TO NO      V2 07 00796
000107 005021 A      797      TBA      SAVE B      V2 07 00797
000110 020302 A      798      LDB  V$CRS      POINT B AT ALOC STACK      V2 07 00798
000111 076003 A      799      STX  PR,B      STORE POP/JUMP ADDR IN P-REG FIELD      V2 07 00799
801      IFF  VII      FG 07 00801
802      GOTO VIII      FG 07 00802
803      SPAC      FG 07 00803
804 *****
805 * V$RERR IS IN VORTEX II NUCLEUS *      FG 07 00805
806 *****
807      SPAC      FG 07 00807
808      TAB      RESTORE B      V2 07 00808
809      LDNI BASE      V2 07 00809
810      DECR 1      V2 07 00810
811      STA  POPSTP,X      INITIALIZE COUNT TO -1      V2 07 00811
812      LDX  POPSTK,B      V2 07 00812
813      SPAC      FG 07 00813
814 *****
815 * LOOP TO FIND TOP OF RETURN ADDRESSES IN V$FORTIO STACK *      FG 07 00815
816 *****
817      SPAC      FG 07 00817
818      TXA      FG 07 00818
819 CANL1  SUB  POPSTK,B      FG 07 00819
820      JAP  CAN5      END OF STACK ?      FG 07 00820
821      LDA  J,X      NO. GET DP FROM STACK      FG 07 00821
822      SUB  CEX      V2 07 00822
823      JAP  CAN5      DONT SAVE STACK WITH EXIT OP      V2 07 00823
824      LDA  0,X      LOAD DP      V2 07 00824
825      LARA 0      V2 07 00825
826      JANZ CAN2      EXIT ON ADDRESS OP      V2 07 00826
827      INCR 045      BUMP POINTER      FG 07 00827
828      JMP  CANL1      AND CONTINUE      V2 07 00828
829      SPAC      FG 07 00829
830 *****
831 * TOP OF RETURN ADDRESS STACK FOUND - MOVE FROM V$FORTIO TO V$RERR *      FG 07 00831
832 *****
833      SPAC      FG 07 00833
834 CAN2  TXA      FG 07 00834

```



```

835 SUB AOPSTK,B V2 07 00835
836 CPA FG 07 00836
837 LDXI BASE V2 07 00837
838 STA ROPSTP,X STORE STACK ITEM COUNT-1 FG 07 00838
839 CPA FG 07 00839
840 INCR 014 SET X = -(STACK ITEM COUNT-1) FG 07 00840
841 ADD ANRB,B V2 07 00841
842 ADDI OPSTK+STKSZ FG 07 00842
843 TAB POINT B AT V$FORTIO STACK V2 07 00843
844 CANL2 LDA 0,B MOVE STACK ADDRESSES V2 07 00844
845 STAE BASE+STKSZ-1,X FG 07 00845
846 JXZ CAN5 EXIT AT END V2 07 00846
847 IRR BUMP POINTERS FG 07 00847
848 IXR FG 07 00848
849 JMP CANL2 LOOP TILL DONE V2 07 00849
850 VIII1 CONT FG 07 00850
851 CAN5 DEALOC RETURN TO V$FORTIO VIA DEALOC V2 07 00851

000112 006505 A
000113 000000 E
000114 000700 A

852 NUC1 CONT FG 07 00852
853 EJEC 07 00853
854 ***** 07 00854
855 * * 07 00855
856 * C Y C L E B U F F E R C H A R A C T E R ( C B C ) * 07 00856
857 * * 07 00857
858 * FUNCTION: TO HANDLE CHARACTER I/O FROM/TO BUFFER * 07 00858
859 * * 07 00859
860 * ENTRY: BUFFER SCB(0) = CURRENT CHAR COUNT * 07 00860
861 * RWFL(BIT WR) = 0 READ V2 07 00861
862 * = 1 WRITE * 07 00862
863 * WT = WIDTH REMAINING IN FORMAT FIELD * 07 00863
864 * * 07 00864
865 * EXIT : RWFL(BIT WR) = 0 DIRECT TO ICC(INPUT) V2* 07 00865
866 * = 1 DIRECT TO PCH(OUTPUT) * 07 00866
867 * WT = WT-1 * 07 00867
868 * * 07 00868
869 ***** 07 00869
000115 036002 A 871 CBC LDX ABSCB,B 07 00871
000116 076021 A 872 STX ASOB,B SET SCB TO BUFFER 07 00872
000117 015000 A 873 LDA 0,X GET CURRENT CHAR COUNT 07 00873
000120 006400 A 874 BT ASET+B0,CBC4 ON WORD BOUNDARY ? 07 00874
000121 000126 R
875 PUSHJ GBA YES. GET NEXT BUFFER ADDRESS V2 07 00875
000122 006010 A
000123 001173 R
000124 006505 A
000125 005042 R
876 CBC4 DDB WT DECREMENT REMAINIG FIELD WIDTH 07 00876
000126 016171 A
000127 005311 A
000130 056171 A
877 TRAB RWFL,FC,CBC6 JUMP IF NOT ENCODE/DECODE PD 07 00877
000131 016154 A
000132 006452 A
000133 000140 R
000134 036152 A 878 LDX RETURN+1,B PD 07 00878
000135 001040 A 879 JXZ CBC6 NO COUNT ADDRESS PD 07 00879
000136 000140 R
000137 045000 A 880 INR 0,X BUMP CHARACTER-PROCESSED COUNT PD 07 00880
000140 016154 A 881 CBC6 TRAB RWFL,WR,ICC READ: EXIT TO INPUT CHAR FROM BUFFER PD 07 00881
000141 006451 A
000142 001754 R
000143 001000 A 882 JMP PCH WRITE: EXIT TO PUT CHAR IN BUFFER 07 00882
000144 003557 R
883 EJEC 07 00883
884 ***** 07 00884
885 * * 07 00885
886 * C L E A R B U F F E R ( C L B ) * 07 00886
887 * * 07 00887
888 * FUNCTION: TO CLEAR A BUFFER * 07 00888
889 * * 07 00889
890 * ENTRY: FRMT = 0 IF UNFORMATTED * 07 00890
891 * BWPT = ADDRESS OF PREVIOUS BUFFER WORD V2 07 00891
892 * LRWC = LOGICAL RECORD REMAINING WORD COUNT * 07 00892
893 * PBWC = PHYSICAL BUFFER REMAINING WORD COUNT * 07 00893
894 * * 07 00894
895 * EXIT : BUFFER = BLANKS ON FORMATTED I/O * 07 00895
896 * = 0 ON UNFORMATTED I/O * 07 00896
897 * * 07 00897
898 ***** 07 00898
000145 016123 A 900 CLB MOVBAB LRWC,TEMP1 07 00900
000146 056165 A
000147 146144 A 901 SUB PBWC,B 07 00901
000150 001004 A 902 JAM CLB4 SET COUNT = MINIMUM(LRWC,PBWC) 07 00902
000151 000154 R
903 MOVBAB PBWC,TEMP1 07 00903
000152 016144 A
000153 056165 A 904 CLB4 TZAB TEMP1,CLBX EXIT IF COUNT=0 07 00904
000154 016165 A

```



```

000155 001010 A
000156 000200 R
905 TSAB RWFL, RB, CLBX DONT CLEAR IF READ-BEFORE-WRITE FLAG SET 07 00905

000157 016154 A
000160 006403 A
000161 000200 R
906 TZAB FRMT, CLBS CLEAR TO ZEROS ON UNFORMATTED V2 07 00906

000162 016063 A
000163 001010 A
000164 000166 R
000165 016203 A
000166 056164 A
000167 036025 A
907 LDA BLNK2, B CLEAR TO BLANKS ON FORMATTED V2 07 00907
908 CLBS STA TEMP, B V2 07 00908
909 LDX BFWPT, B V2 07 00909
910 *****
911 * FILL LOOP *
912 *****
000170 000170 R
913 CLBLP EQU * V2 07 00913
000170 005144 A
914 IXR LOAD X AS BUFFER POINTER V2 07 00914
915 MOVBAK TEMP, 0 MOVE FILL WORD TO BUFFER V2 07 00915

000171 016164 A
000172 055000 A
000173 005041 A
000174 146025 A
000175 146165 A
000176 001004 A
000177 000170 R
916 TXA V2 07 00916
917 SUB BFWPT, B V2 07 00917
918 SUB TEMP1, B
919 JAM CLBLP LOOP TILL DONE 07 00919

000200 001000 A
000201 004110 R
920 CLBX POPJ EXIT FG 07 00920

921 EJEC 07 00921
922 ***** 07 00922
923 * 07 00923
924 * CLOSE FILE (CLS) * 07 00924
925 * 07 00925
926 * FUNCTION: TO PROCESS CALLS TO CLOSE AN RMD FILE * 07 00926
927 * 07 00927
928 * ENTRY: DIRECT FROM RBE * 07 00928
929 * TEMP = DP = CCL CLOSE NORMAL RMD FILE V2* 07 00929
930 * CCB CLOSE BLOCKED( LOGICAL ) FILE V2* 07 00930
931 * RETURN = CALL SEQUENCE ADDRESS * 07 00931
932 * RETURN(5) = ADDRESS OF UPDATE/LEAVE CLOSE PARAMETER * 07 00932
933 * 07 00933
934 * EXIT : FCB REMOVED FROM CHAIN * 07 00934
935 * BUFFER FLUSHED IF LOGICAL FILE * 07 00935
936 * 07 00936
937 * ERRORS: ER4 IS U NOT ON CHAIN * 07 00937
938 * 07 00938
939 ***** 07 00939
941 ***** 07 00941
942 * SET UP CONTROL * 07 00942
943 ***** 07 00943
000202 010432 A
000203 056154 A
944 CLS LDA WRS SET WRITE FLAG V2 07 00944
945 STA RWFL, B 07 00945
946 ***** 07 00946
947 * SEARCH FCB CHAIN FOR U * 07 00947
948 ***** 07 00948
949 PUSHJ SCH SEARCH FCB CHAIN V2 07 00949

000204 006010 A
000205 006150 R
000206 006505 A
000207 005042 R
000210 001010 A
000211 005702 R
950 JAZ ER4 ERRDR 4/ FCB(U) NOT ON CHAIN / 07 00950
951 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER U V2 07 00951

000212 006010 A
000213 004216 R
000214 006505 A
000215 005042 R
000216 036016 A
952 LDX ANR2, B V2 07 00952
953 MOVBAK UNIT, IDCONT INITIALIZE IO CONTROL WORD V2 07 00953

000217 016167 A
000220 055104 A
000221 036010 A
000222 015014 A
000223 006455 A
000224 000252 R
000225 006454 P
000226 000252 R
954 LDX ADFCB, B POINT X AT FCB 07 00954
955 LDA 12, X 07 00955
956 BT ARST+FLF, CLS20 TEST FOR LOGICAL FILE V2 07 00956
957 BT ARST+FRM, CLS20 AND RMD V2 07 00957
958 ***** V2 07 00958
959 * U IS RMD LOGICAL FILE * V2 07 00959
960 ***** V2 07 00960
000227 006456 A
000230 000240 R
961 BT ARST+FPD, CLS10 ANY UNPOSTED DATA ? V2 07 00961
962 MOVBAK PBS7, 0 YES. LOAD FCB(0) WITH PHYSICAL BUFF SIZE 07 00962
000231 016143 A
000232 055000 A
963 PUSHJ PSS AND POST BUFFER V2 07 00963

000233 006010 A
000234 005011 R
000235 006505 A
000236 005042 R
000237 036010 A
964 LDX ADFCB, B RESTORE X 07 00964
965 CLS10 MOVBAK PD120, 0 SET FCB(0) = 120 WORDS V2 07 00965

```



```

000240 016201 A
000241 055000 A
966          TZAB      LGDV,CLS15      LOGICAL RECORD OVERLAP ?          07 00966
000242 016123 A
000243 001010 A
000244 000250 R
967          ADBBB      PRECND,PBRC,PRECND      YES. BUMP PHYSICAL RECORD NUMBER 07 00967
000245 016145 A
000246 126142 A
000247 056143 A
968 CLS15  MOVBAK  PRECND,3      SET FCB(3) = PHYSICAL RECORD NUMBER          07 00968
000250 016145 A
000251 055003 A
969 *****
970 * CALL IOC TO CLOSE FILE *
971 *****
000252 036151 A 972 CLS20  LDX      RETURN,B      POINT X AT CALL SEQUENCE          07 00972
000253 035005 A 973          LDX      5,X          POINT X AT UPDATE/LEAVE PARAMETER 07 00973
000254 015000 A 974          LDA      0,X          GET UPDATE/LEAVE PARAMETER        07 00974
000255 001010 A 975          JAZ      *+3
000256 000260 R
000257 010435 A 976          LDA      BS12          SET FLAG FOR UPDATE              07 00976
000260 006110 A 977          DRAI      03400        MERGE IN IOC CLOSE SKELETON WORD  V2 07 00977
000261 003400 A
000262 116167 A 978          DRA      UNIT,B          OR IN LUN                        07 00978
000263 036016 A 979          LDX      ANRB,B          POINT X AT V$FORTID DATA BLOCK  07 00979
000264 055104 A 980          STA      IDCNT,X          STORE IOC CONTROL WORD IN V$FORTID 07 00980
981          DAX      LNKCNT        DECREMENT LINK COUNT            07 00981
000265 015120 A
000266 005311 A
000267 055120 A
000270 010464 A 982          LDA      CTD          V2 07 00982
000271 006505 A 983          JSR      PSJ,X          CALL IOC                          V2 07 00983
000272 005042 R
000273 036010 A 984          LDX      ADFCB,B          POINT X AT FCB                    07 00984
985          TRAB      RWFL,LF,CLS30  LOGICAL FILE ?                  07 00985
000274 016154 A
000275 006441 A
000276 000301 R
986          MOVBAK  LRSZ,0          YES. RESTORE LOGICAL REC SIZE IN FCB(0) 07 00986
000277 016122 A
000300 055000 A
987 *****
988 * TAKE FCB OFF CHAIN *
989 *****
000301 015012 A 990 CLS30  LDA      10,X          GET FORWARD LINK                  07 00990
000302 036146 A 991          LDX      PRLINK,B          HOOK TO PREVIOUS LINK            07 00991
000303 055012 A 992          STA      10,X
993 *****
994 * EXIT *
995 *****
000304 010422 A 996          LDA      CEX          PUSH EXIT OF ONTO V$FORTID STACK  07 00996
997          PUSHF
000305 036016 A
000306 035000 A
000307 005344 A
000310 055000 A
000311 005041 A
000312 036016 A
000313 055000 A
000314 001000 A 998          JMP      CAN          EXIT TO V$FORTID                    07 00998
000315 000101 R
999          EJEC
1000 *****
1001 *
1002 *          4 - W O R D   D I V I D E   B Y   1 0 ( D 1 0 )
1003 *
1004 * FUNCTION: TO DIVIDE A 4-WORD NUMBER BY 10
1005 *
1006 * ENTRY: ACC = DIVIDEND
1007 *
1008 * EXIT : ACC = ACC/10
1009 *
1010 *****
000316 005024 A 1012 D10   TBX          LOAD X AS BASE REGISTER          07 01012
000317 005001 A 1013          TZA          CLEAR HIGH-ORDER WORD OF DIVIDEND      07 01013
000320 025003 A 1014          LDB      ACC,X
000321 170471 A 1015          DIV      TEN          ACC(0)=ACC(0)/10          07 01015
000322 065003 A 1016          STB      ACC,X
000323 025004 A 1017          LDB      ACC+1,X
000324 170471 A 1018          DIV      TEN          ACC(1)=(ACC(1)+REM(0))/10      07 01018
000325 065004 A 1019          STB      ACC+1,X
000326 025005 A 1020          LDB      ACC+2,X
000327 170471 A 1021          DIV      TEN          ACC(2)=(ACC(2)+REM(1))/10      07 01021
000330 065005 A 1022          STB      ACC+2,X
000331 025006 A 1023          LDB      ACC+3,X
000332 170471 A 1024          DIV      TEN          ACC(3)=(ACC(3)+REM(2))/10      07 01024
000333 065006 A 1025          STB      ACC+3,X
000334 005042 A 1026          TXB          RESTORE BASE REGISTER B          07 01026
1027          POPJ          AND EXIT                          FG 07 01027
000335 001000 A
000336 004110 R
1028          EJEC
07 01028

```



```

1029 *****
1030 *
1031 *   P R O C E S S   D / E / F   O U T P U T   D E S C R I P T O R S
1032 *
1033 *           ( D E F )
1034 *
1035 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTORS: SRDW.D
1036 *                                                    SREW.D
1037 *                                                    SRFW.D
1038 *                                                    SRGW.D
1039 *
1040 * ENTRY: A = INTEGER FIELD COUNT
1041 *
1042 * EXIT : DIRECT TO DNF
1043 *       PTFW = 1 = '.*' FLAG
1044 *       IF A.GE.0 IFW = A = INTEGER FIELD WIDTH
1045 *       IF A.LT.0 ZFW = -A = ZERO FILL FIELD WIDTH
1046 *
1047 *****
000337 001004 A 1049 DEF   JAN   DEF4   IS A .GE. ZERO ?
000340 000344 R
000341 056100 A 1050   STA   IFW,B   YES. STORE AS INTEGER FIELD WIDTH
000342 001000 A 1051   JMP   DEF8
000343 000347 R
000344 005211 A 1052 DEF4   CPA           A NEGATIVE
000345 005111 A 1053   IAR
000346 056176 A 1054   STA   ZFW,B   LOAD LEADING ZERO FILL COUNT
000347 046147 A 1055 DEF8   INR   PTFW,B D/E/F HAVE A '.*'
000350 001000 A 1056   JMP   DNF      EXIT TO OUTPUT NUMERIC FIELD
000351 002701 R
1057   EJEC
1058 *****
1059 *
1060 *   P R O C E S S   D / E   O U T P U T   D E S C R I P T O R S
1061 *
1062 *           ( D E D )
1063 *
1064 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTORS: SRDW.D
1065 *                                                    SREW.D
1066 *                                                    SRGW.D
1067 *
1068 * ENTRY: DIRECT FROM FRS
1069 *       TO DOUT FOR 'D' FORMAT DESCRIPTOR
1070 *       TO EOUT FOR 'E' FORMAT DESCRIPTOR
1071 *       TO GOUT FOR 'G' FORMAT DESCRIPTOR
1072 *       S = SCALE FACTOR
1073 *
1074 * EXIT : DIRECT TO DEF
1075 *       A = S
1076 *       DEXP = DEXP - S = DECIMAL EXPONENT
1077 *       XFL = 1 = EXPONENT FIELD FLAG
1078 *       XFW = 0 = EXPONENT FIELD WIDTH
1079 *       IF S .GT. 0, DT = MAX(0,DT-S+1)
1080 *
1081 *****
000352 R 1083 DOUT  EQU   *
000352 R 1084 EOUT  EQU   *
1085   MOVAB  D,COUNT   SET SIGNIFICANT DIGIT COUNT TO D
000352 016054 A
000353 056052 A
1086   TZAB  S,DE010  EXIT IF NO SCALE FACTOR
000354 016155 A
000355 001010 A
000356 000374 R
000357 001004 A 1087   JAN   DE05
000360 000372 R
000361 046052 A 1088   INR  COUNT,B   SCALE FACTOR IS +. BUMP COUNT TO D+1
000362 146054 A 1089   SUB  D,F
000363 005311 A 1090   DAR
000364 001004 A 1091   JAN   DE010   OK IF D.GE.S
000365 000374 R
1092   MOVAB  S,COUNT   OTHERWISE, GET S SIGNIFICANT DIGITS
000366 016155 A
000367 056052 A
000370 001000 A 1093   JMP   DE010
000371 000374 R
000372 126056 A 1094 DE05  ADD   DT,B   SCALE FACTOR IS -. SET COUNT TO DT-S
000373 056052 A 1095   STA  COUNT,B
1096 DE010 PUSHJ  RND      ROUND DECIMAL FIELD
000374 006010 A
000375 006032 R
000376 006505 A
000377 005042 R
000400 046173 A 1098   INR  XFL,B   'D' AND 'E' BOTH HAVE EXPONENT FIELDS
000401 016055 A 1099   OUTBBB DEXP,S,DEXP SET DEXP = DEXP - S
000402 146155 A
000403 056055 A
1100   MOVAB  FOUR,XFW  EXPONENT FIELD IS 4 CHARS WIDE
000404 010423 A
000405 056174 A
000406 016155 A 1101   LDA  S,B
000407 001004 A 1102   JAN  DEF

```



```

000410 000337 R
000411 001010 A 1103 JAZ DEF S .GT. 0 ? 07 01103
000412 000337 R
000413 016056 A 1104 LDA DT,B YES 07 01104
000414 146155 A 1105 SUB S,B 07 01105
000415 005111 A 1106 IAR 07 01106
000416 001002 A 1107 JAP *+3 SET DT = MAX(0,DT-S+1) 07 01107
000417 000421 R
000420 005001 A 1108 TZA 07 01108
000421 056056 A 1109 STA DT,B 07 01109
000422 016155 A 1110 LDA S,B EXIT WITH A = S 07 01110
000423 001000 A 1111 JMP DEF PROCESS S 07 01111
000424 000337 R
1112 EJEJ 07 01112
1113 ***** 07 01113
1114 * 07 01114
1115 * PROCESS F OUTPUT DESCRIPTOR ( F O U ) * 07 01115
1116 * 07 01116
1117 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTOR: SRFW.D * 07 01117
1118 * 07 01118
1119 * ENTRY: DIRECT FROM FRS * 07 01119
1120 * DEXP = DECIMAL EXPONENT * 07 01120
1121 * S = SCALE FACTOR * 07 01121
1122 * 07 01122
1123 * EXIT : DIRECT TO DEF * 07 01123
1124 * A = DEXP = DEXP+S * 07 01124
1125 * 07 01125
1126 ***** 07 01126
000425 000425 R 1128 FOUT EQU * 07 01128
000426 016155 A 1130 LDA S,B GET SCALE FACTOR 07 01130
000427 126055 A 1131 ADD DEXP,B ADD DECIMAL EXPONENT 07 01131
000428 126054 A 1132 ADD D,B ADD FRACTIONAL FIELD COUNT 07 01132
000430 056052 A 1133 STA COUNT,B STORE AS SIGNIFICANT DIGIT COUNT 07 01133
1134 PUSHJ RND ROUND TO SIGNIFICANT DIGIT COUNT V2 07 01134
000431 006010 A
000432 006032 R
000433 006505 A
000434 005042 R
000435 016055 A 1135 LDA DEXP,B 07 01135
000436 126155 A 1136 ADD S,B BUMP EXPONENT BY S 07 01136
000437 056055 A 1137 STA DEXP,B 07 01137
000440 001000 A 1138 JMP DEF EXIT WITH INTEGER FIELD WIDTH IN A 07 01138
000441 000337 R
1139 EJEJ 07 01139
1140 ***** 07 01140
1141 * 07 01141
1142 * FORMAT SCAN ( F R S ) * 07 01142
1143 * 07 01143
1144 * FUNCTION: TO SCAN AND DECODE A FORMAT CHARACTER STRING * 07 01144
1145 * 07 01145
1146 * ENTRY: NO SPECIAL CONDITIONS * 07 01146
1147 * 07 01147
1148 * EXIT : FDLKEY = CONVERSION CODE ID KEY * 07 01148
1149 * TO DESCRIPTOR PROCESSOR FOR H/X/T (NO DATA XFER FROM LIST) * 07 01149
1150 * TO DESCRIPTOR PROCESSOR FOR OTHERS IF LIST NOT EXHAUSTED * 07 01150
1151 * OTHERWISE EXIT TO V$FORTIO THRU GNL V2 * 07 01151
1152 * 07 01152
1153 * ERRORS: ERI ON INVALID FORMAT STRING * 07 01153
1154 * 07 01154
1155 ***** 07 01155
1157 ***** 07 01157
1158 * INITIAL ENTRY * 07 01158
1159 ***** 07 01159
000442 005001 A 1160 FRS ZAB FRPT CLEAR FORMAT STRING POINTER 07 01160
000443 056062 A
000444 056075 A 1161 STA GDRPC+1,B CLEAR LEVEL 2 GROUP REPEAT COUNT 07 01161
000445 056117 A 1162 STA LISTFL,B CLEAR LIST DATA XFER FLAG 07 01162
000446 056141 A 1163 STA PARLV,B CLEAR '*' GROUP LEVEL COUNT 07 01163
000447 056155 A 1164 STA S,B CLEAR SCALE FACTOR 07 01164
000450 005101 A 1165 INCR 1 07 01165
000451 056125 A 1166 STA R,B SET INITIAL '*' REPEAT COUNT TO 1 07 01166
1167 PUSHJ INF INPUT NON-BLANK FORMAT CHARACTER V2 07 01167
000452 006010 A
000453 002113 R
000454 006505 A
000455 005042 R
000456 006443 A 1168 BT ARST+LP,ERI ERROR 1/ 1ST FORMAT CHAR NOT '*' / 07 01168
000457 005705 R
1169 ***** 07 01169
1170 * '*' ENTRY * 07 01170
1171 ***** 07 01171
000460 046141 A 1172 FR32 INR PARLV,B BUMP '*' LEVEL 07 01172
000461 016141 A 1173 LDA PARLV,B 07 01173
000462 140423 A 1174 SUB FUMR 07 01174
000463 001002 A 1175 JAP ERI ERROR 1/ MORE THAN 3 '*' LEVELS / 07 01175
000464 005705 R
000465 016012 A 1176 LDA ACPAR,B 07 01176
000466 126141 A 1177 ADD PARLV,B 07 01177
000467 005014 A 1178 TAX POINT X AT GROUP REPEAT COUNT 07 01178
000470 016125 A 1179 LDA R,B GET REPEAT COUNT 07 01179
000471 055000 A 1180 STA G,X STORE IN DYNAMIC GROUP REPEAT COUNT TABLE 07 01180
000472 055006 A 1181 STA GDRPC-GDRPC,X STORE IN STATIC GROUP REPEAT COUNT TABLE 07 01181

```







000576	126115	A							
000577	056114	A							
			1236	PUSHJ	RCL	RECYCLE LOGICAL BUFFER		V2	07 01236
000600	006010	A							
000601	005464	R							
000602	006505	A							
000603	005042	R							
000604	016117	A	1237	LDA	LISTFL,B				07 01237
000605	001010	A	1238	JAZ	ERI	ERRDR 1/ NO DATA XFER DESCRIPTORS /			07 01238
000606	005705	R							
			1239	ZAB	LISTFL	CLEAR LIST DATA XFER FLAG			07 01239
000607	005001	A							
000610	056117	A							
000611	036012	A	1240	LDX	AGPAR,B				07 01240
000612	005144	A	1241	IXR	IXR	POINT X AT 'C' LEVEL 1			07 01241
000613	046141	A	1242	INR	PARLV,B	ALSO LEVEL COUNTER			07 01242
000614	015006	A	1243	LDA	GSRPC-GDRPC,X				07 01243
000615	055000	A	1244	STA	0,X	RELOAD LEVEL 1 DYNAMIC REPEAT COUNT			07 01244
000616	015007	A	1245	LDA	GSRPC-GDRPC+1,X				07 01245
000617	001010	A	1246	JAZ	FRS19	IS THERE A 2ND LEVEL ?			07 01246
000620	000625	R							
000621	046141	A	1247	INR	PARLV,B	YES			07 01247
000622	005144	A	1248	IXR	IXR	USE 2ND 'C' LEVEL			07 01248
000623	015006	A	1249	LDA	GSRPC-GDRPC,X	GET STATIC REPEAT COUNT			07 01249
000624	055000	A	1250	STA	0,X	RELOAD DYNAMIC REPEAT COUNT			07 01250
000625	015003	A	1251	FRS19	LDA	GFRPT-GDRPC,X			07 01251
000626	056062	A	1252	STA	FRPT,B	BACK UP SCAN TO 'C'			07 01252
000627	001000	A	1253	JMP	FRS5	RESUME SCAN AFTER CORRESPONDING 'C'			07 01253
000630	000475	R							
			1254	*****					07 01254
			1255	* *- INPUT *					07 01255
			1256	*****					07 01256
000631	046157	A	1257	FRS20	INR	SGFL,B	SET SIGN FLAG		07 01257
			1258	PUSHJ	INF	INF	INPUT NON-BLANK FOLLOWING '-'	V2	07 01258
000632	006010	A							
000633	002113	R							
000634	006505	A							
000635	005042	R							
000636	006445	A	1259	BT	ARST+NM,ERI	ERRDR 1/ NOT NUMERIC /			07 01259
000637	005705	R							
			1260	*****					07 01260
			1261	* NUMERIC CHAR INPUT *					07 01261
			1262	*****					07 01262
			1263	FRS25	PUSHJ	IFF	INPUT NUMERIC FORMAT FIELD	V2	07 01263
000640	006010	A							
000641	002054	R							
000642	006505	A							
000643	005042	R							
000644	006150	A	1264	ANAI	0211	ENABLE 'P'/'C'/ALPHA		V2	07 01264
000645	000211	A							
000646	001010	A	1265	JAZ	ERI	ERRDR 1/ ILLEGAL TERMINATOR /			07 01265
000647	005705	R							
000650	016065	A	1266	LDA	FCODE,B				07 01266
000651	006447	A	1267	BT	ARST+PS,FRS90	TEST IF TERMINATOR IS 'P'			07 01267
000652	000670	R							
			1268	*****					07 01268
			1269	* DESCRIPTOR HAS 'P' FIELD *					07 01269
			1270	*****					07 01270
000653	046156	A	1271	INR	SCF,B	SET SCALE FACTOR FLAG			07 01271
000654	016126	A	1272	LDA	NFF,B	GET SCALE FACTOR ABS VALUE IN A			07 01272
000655	036157	A	1273	LDX	SGFL,B	GET SIGN FLAG IN X			07 01273
000656	001040	A	1274	JXZ	**4				07 01274
000657	000662	R							
000660	005211	A	1275	CPA		NEGATE A IF SIGN FLAG SET			07 01275
000661	005111	A	1276	IAR					07 01276
000662	056155	A	1277	STA	S,B	LOAD SCALE FACTOR S			07 01277
000663	006010	A	1278	LDAI	041			V2	07 01278
000664	000041	A							
000665	056053	A	1279	STA	OVFL,B	ENABLE ONLY NUMERIC/ALPHA		V2	07 01279
000666	001000	A	1280	JMP	FRS10				07 01280
000667	000507	R							
			1281	*****					07 01281
			1282	* NUMERIC - NOT SCALE FACTOR *					07 01282
			1283	*****					07 01283
			1284	FRS30	TNZAB	SGFL,ERI	ERRDR 1/ '- ' PRECEDES REPEAT COUNT /		07 01284
000670	016157	A							
000671	001016	A							
000672	005705	R							
			1285	MOVAB	NFF,R	LOAD REPEAT COUNT			07 01285
000673	016126	A							
000674	056125	A							
000675	056171	A	1286	STA	HT,B	ALSO AS FIELD WIDTH FOR H/X			07 01286
000676	016065	A	1287	LDA	FCODE,B				07 01287
000677	006403	A	1288	BT	QSET+LP,FRS2	TEST FOR 'C'			07 01288
000700	000460	R							
000701	005440	A	1289	BT	ARST+AL,ERI	ERRDR 1/ TERMINATOR NOT ALPHA /			07 01289
000702	005705	R							
			1290	*****					07 01290
			1291	* ALPHABETIC CHAR INPUT *					07 01291
			1292	*****					07 01292
			1293	FRS35	EDU	*		V2	07 01293
000703	000703	R	1294	LDA	FCHAR,B	GET FORMAT DESCRIPTOR CHARACTER		V2	07 01294
000703	016064	A	1295	IFF	NUC			FG	07 01295







Address	Code	Label	Operation	Comments	Flags	Page
001000	005042	R				
001001	006445	A	1360	BT ARST+NM,ER1	ERROR 1/ NON-NUMERIC AFTER LETTER /	07 01360
001002	005705	R				
			1361	PUSHJ IFF	INPUT NUMERIC FIELD	V2 07 01361
001003	006010	A				
001004	002054	R				
001005	006505	A				
001006	005042	R				
001007	016126	A	1362	LDA NFF,B		07 01362
001010	056054	A	1363	STA D,B	STORE DECIMAL FIELD WIDTH D	07 01363
			1364	*****		07 01364
			1365	* DESCRIPTOR REQUIRES LIST ITEM *		07 01365
			1366	*****		07 01366
			1367	FRS50 PUSHJ GNL	GET ADDRESS OF NEXT LIST ITEM/EXIT	V2 07 01367
001011	006010	A				
001012	001561	R				
001013	006505	A				
001014	005042	R				
001015	046117	A	1368	INR LISTFL,B	SET LIST FLAG	07 01368
			1369	MOVBAB W,WT	SET WT=W	07 01369
001016	016170	A				
001017	056171	A				
			1370	MOVBAB D,DT	SET DT=D	07 01370
001020	016054	A				
001021	056056	A				
			1371	ZAB ACC	CLEAR ACCUMULATOR ACC	07 01371
001022	005001	A				
001023	056003	A				
001024	056004	A	1372	STA ACC+1,B		07 01372
001025	056005	A	1373	STA ACC+2,B		07 01373
001026	056006	A	1374	STA ACC+3,B		07 01374
001027	056022	A	1375	STA ASFL,B	CLEAR '*' FLAG	07 01375
001030	056055	A	1376	STA DEXP,B	CLEAR DECIMAL EXPONENT	07 01376
001031	056100	A	1377	STA IFW,B	CLEAR INTEGER FIELD WIDTH	07 01377
001032	056147	A	1378	STA PTFB,B	CLEAR '.' FLAG	07 01378
001033	056157	A	1379	STA SGFL,B	CLEAR SIGN FLAG	07 01379
001034	056173	A	1380	STA XFL,B	CLEAR EXPONENT FIELD FLAG	07 01380
001035	056174	A	1381	STA XFW,B	SET EXPONENT FIELD WIDTH TO ZERO	07 01381
001036	056176	A	1382	STA ZFW,B	CLEAR ZERO FILL FIELD WIDTH	07 01382
001037	056166	A	1383	STA TERM,B	CLEAR TERMINATING DIGIT	V2 07 01383
			1384	MOVBAB ABSCB,ASCB	SET SCB TO BUFFER	07 01384
001040	016002	A				
001041	056021	A				
001042	016061	A	1385	LDA FDLKEY,B		07 01385
001043	140465	A	1386	SUB FIVE		07 01386
001044	001002	A	1387	JAP FRS60	EXIT ON NON-NUMERIC DESCRIPTOR	07 01387
001045	001065	R				
			1388	*****		07 01388
			1389	* NUMERIC DESCRIPTOR *		07 01389
			1390	*****		07 01390
001046	005111	A	1391	IAR		07 01391
001047	056156	A	1392	STA SCF,B	DISABLE SCALE FACTOR FOR I INPUT	07 01392
			1393	TSAB RWFL,WR,FRS55	TEST READ OR WRITE	V2 07 01393
001050	016154	A				
001051	006411	A				
001052	001061	R				
			1394	*****		07 01394
			1395	* READ *		07 01395
			1396	*****		07 01396
			1397	PUSHJ IXN	INPUT EXTERNAL NUMERIC FIELD	V2 07 01397
001053	006010	A				
001054	002137	R				
001055	006505	A				
001056	005042	R				
001057	001000	A	1398	JMP FRS60		07 01398
001060	001065	R				
			1399	*****		07 01399
			1400	* WRITE *		07 01400
			1401	*****		07 01401
			1402	FRS55 PUSHJ GNI	GET NUMERIC LIST ITEM	V2 07 01402
001061	006010	A				
001062	001255	R				
001063	006505	A				
001064	005042	R				
			1403	*****		07 01403
			1404	* EXIT TO PROCESSOR *		07 01404
			1405	*****		07 01405
001065	016061	A	1406	FRS60 LDA FDLKEY,B		07 01406
001066	004241	A	1407	LRLA 1		07 01407
001067	003014	A	1408	TAX	SET X = DESCRIPTOR READ KEY	07 01408
001070	016154	A	1409	LDA RWFL,B		07 01409
001071	150432	A	1410	ANA WRS		V2 07 01410
001072	003016	A	1411	XANZ IXR	BUMP KEY FOR WRITE	V2 07 01411
001073	000612	R				
			1412	IFF NUC		FG 07 01412
			1413	GOTO NV2NUC		FG 07 01413
			1414	IFT VII		FG 07 01414
			1415	ONE MAP,VSSTO	SET EXEC STATE TO 00	V2 07 01415
			1416	NV2NUC CONT		FG 07 01416
001074	006035	A	1417	LOXE FRSJT,X	GET PROCESSOR ADDRESS FROM TABLE	07 01417
001075	001145	R				
			1418	IFF NUC		FG 07 01418
			1419	GOTO NV2NUC		FG 07 01419



```

1420          IFT      VII
1421          OME      MAP,V$ST3      SET EXEC STATE TO NM
1422 NV2NUC  CNT      FG 07 01420
1423          IJMP     0,X           V2 07 01421
001076 006705 A      EXIT TO PROCESSOR      FG 07 01422
001077 000000 A      V2 07 01423

1424 *****
1425 * TEST REPEAT COUNT *
1426 *****
1427 FRS65  DAB      R           DECREMENT REPEAT COUNT      07 01424
                                           07 01425
                                           07 01426
                                           07 01427

001100 016125 A
001101 005311 A
001102 056125 A
001103 001016 A      1428          JANZ     FRS50      REPEAT DESCRIPTOR R TIMES      07 01428
001104 001011 R
001105 001000 A      1429          JMP      FRS85      THEN RESUME SCAN      07 01429
001106 001121 R

1430 *****
1431 * PROCESS '/' *
1432 *****
1433 FRS70  PUSHJ    RCL           RECYCLE LOGICAL BUFFER      V2 07 01430
                                           07 01431
                                           07 01432
                                           07 01433

001107 006010 A
001110 005464 R
001111 006505 A
001112 005042 R
001113 001000 A      1434          JMP      FRS5      AND SCAN FORWARD FOR NEXT DESCRIPTOR      07 01434
001114 000475 R

1435 *****
1436 * PROCESS FIELD SEPARATOR *
1437 *****
1438 FRS75  PUSHJ    INF           GET TERMINATING CHARACTER      V2 07 01435
                                           07 01436
                                           07 01437
                                           07 01438

001115 006010 A
001116 002113 R
001117 006505 A
001120 005042 R
001121 016065 A      1439 FRS85  LDA      FLDDE,B      GET CHAR CODE      07 01439
001122 006402 A      1440          BT       ASET+CM,FRS5     TEST FOR ','      07 01440
001123 000475 R
001124 006413 A      1441          BT       ASET+SL,FRS70    TEST FOR '/'      07 01441
001125 001107 R
001126 006412 A      1442          BT       ASET+RP,FRS15    TEST FOR ')'      07 01442
001127 000547 R
001130 001000 A      1443          JMP      ER1      ERROR 1/ ILLEGAL TERMINATOR /      07 01443
001131 005705 R

1444 *****
1445 * TABLE OF VALID FORMAT SPEC CHARS *
1446 *****
001132 001132 R      1447 FRSCHT EQU      *
001133 177777 A      1448          DATA   -1          SRDW.D      V2 07 01447
001134 177777 A      1449          DATA   -1          SRFW.D      V2 07 01448
001135 177776 A      1450          DATA   -1          SRGW.D      V2 07 01449
001136 177757 A      1451          DATA   -2          SRGW.D      V2 07 01450
001137 000016 A      1453          DATA   -021         RIW         07 01451
001140 000013 A      1455          DATA   016          RZW         07 01453
001141 177771 A      1456          DATA   013          RLW         V2 07 01455
001142 177760 A      1457          DATA   -7          RAW         V2 07 01456
001143 000004 A      1459          DATA   -020         NH...      V2 07 01457
001144 000324 A      1460          DATA   4            NX         V2 07 01459
001144 000324 A      1461          DATA   00P4         TN         V2 07 01460
                                           07 01461
                                           07 01462
                                           07 01463
                                           07 01464
                                           07 01465
                                           07 01466
                                           07 01467
                                           07 01468
                                           07 01469
                                           07 01470
                                           07 01471
                                           07 01472
                                           07 01473
                                           07 01474
                                           07 01475
                                           07 01476
                                           07 01477
                                           07 01478
                                           07 01479
                                           07 01480
                                           07 01481
                                           07 01482
                                           07 01483
                                           07 01484
                                           07 01485
                                           07 01486
                                           07 01487
                                           07 01488
                                           07 01489
                                           07 01490
                                           07 01491
                                           07 01492
                                           07 01493
                                           07 01494
                                           07 01495
                                           07 01496
                                           07 01497
                                           07 01498
                                           07 01499

1463 *****
1464 * JUMP TABLE *
1465 *****
001145 001145 R      1466 FRSJT  EQU      *
001145 003607 R      1467          PZE      DIN
001146 000352 R      1468          PZE      DOUT
001147 003607 R      1469          PZE      EIN
001150 000352 R      1470          PZE      EOUT
001151 003607 R      1471          PZE      FIN
001152 000425 R      1472          PZE      FOUT
001153 003607 R      1473          PZE      GIN
001154 001615 R      1474          PZE      GOUT
001155 003607 R      1475          PZE      IIN
001156 002125 R      1476          PZE      IOUT
001157 006550 R      1477          PZE      ZIN
001160 006550 R      1478          PZE      ZOUT
001161 002443 R      1479          PZE      LIN
001162 002501 R      1480          PZE      LOUT
001163 000000 R      1481          PZE      RIN
001164 000000 R      1482          PZE      ROUT
001165 001647 R      1483          PZE      HIN
001166 001647 R      1484          PZE      HOUT
001167 006534 R      1485          PZE      XIN
001170 006534 R      1486          PZE      XOUT
001171 006310 R      1487          PZE      TIN
001172 006310 R      1488          PZE      TOUT
1490          EQU      *
1491 *****
1492 *
1493 *          GET BUFFER ADDRESS (GBA)
1494 *
1495 * FUNCTION: TO GET ADDRESS OF NEXT BUFFER WORD, AND HANDLE CROSSING
1496 * OF LOGICAL AND PHYSICAL RECORD BOUNDARIES
1497 *
1498 * ENTRY: PBWC = COUNT OF WORDS REMAINING IN PHYSICAL BUFFER

```



```

1499 *          LRWC = COUNT OF WORDS REMAINING IN LOGICAL BUFFER          * 07 01499
1500 *          BFWPT = ADDRESS OF PREVIOUS BUFFER WORD                    * 07 01500
1501 *          RWFL(CTR) = 1 ON TERMINATE CALL                            V2* 07 01501
1502 *                                                                 * 07 01502
1503 *          EXIT : IF PBWC .LE. 0                                       V2* 07 01503
1504 *          RCP CALLED TO RECYCLE PHYSICAL BUFFER                       V2* 07 01504
1505 *                                                                 V2* 07 01505
1506 *          BFWPT = BFWPT+1                                             V2* 07 01506
1507 *                                                                 V2* 07 01507
1508 *          IF LRWC .LE. 0                                             V2* 07 01508
1509 *          LRECND = LRECND+1                                           V2* 07 01509
1510 *          ALBF = BFWPT                                               V2* 07 01510
1511 *          LRWC = LRSZ                                               V2* 07 01511
1512 *          BFPT = 0                                                 V2* 07 01512
1513 *          CLB CALLED ON WRITE IF TR=0                                V2* 07 01513
1514 *          PBWC = PBWC-1                                             V2* 07 01514
1515 *          LRWC = LRWC-1                                             V2* 07 01515
1516 *                                                                 * 07 01516
1517 *          *****                                                    07 01517
1519 *          *****                                                    07 01519
1520 *          * TEST FOR END OF PHYSICAL BUFFER *                          07 01520
1521 *          *****                                                    07 01521
001173 016144 A 1522 GBA LDA PBWC,B                                             07 01522
001174 005311 A 1523 DAB                                             07 01523
001175 001002 A 1524 JAP GBA50                                             07 01524
001176 001206 R 1525 TSAB RWFL,EC,GBA80 PD 07 01525

001177 016154 A 1526 *****                                                    07 01526
001200 006412 A 1527 * END OF PHYSICAL BUFFER *                                          07 01527
001201 001247 R 1528 *****                                                    07 01528
1529 PUSHJ RCP RECYCLE PHYSICAL BUFFER V2 07 01529

001202 006010 A 1530 *****                                                    07 01530
001203 005526 R 1531 * TEST FOR END OF LOGICAL RECORD *                          07 01531
001204 006505 A 1532 *****                                                    07 01532
001205 005042 R 1533 GBA50 INR BFWPT,B BUMP BUFFER WORD POINTER 07 01533
001206 046025 A 1534 LDA LRWC,B 07 01534
001207 016123 A 1535 DAB 07 01535
001210 005311 A 1536 JAP GBA70 07 01536
001211 001002 A
001212 001237 R 1537 *****                                                    07 01537
1538 * END OF LOGICAL RECORD *                                          07 01538
1539 *****                                                    07 01539
001213 046121 A 1540 INR LRECND,B BUMP LOGICAL RECORD NUMBER 07 01540
001214 016025 A 1541 MOV8AB BFWPT,ALBF UPDATE LOGICAL BUFFER ADDRESS 07 01541
001215 056027 A 1542 GBA55 MOV8AB LRSZ,LRWC RELOAD REMAINING WORD COUNT PD 07 01542
001216 016122 A
001217 056123 A 1543 ZAB BFPT CLEAR BUFFER CHARACTER POINTER 07 01543
001220 005001 A
001221 056026 A 1544 TRAB RWFL,WR,GBA70 WRITE ? 07 01544
001222 016154 A
001223 006451 A
001224 001237 R 1545 BT ASET+TR,GBA70 YES. TERMINATE ? 07 01545
001225 006404 A
001226 001237 R 1546 GBA60 EQU * V2 07 01546
001227 016025 A 1547 DAB BFWPT NO. SET UP CLB V2 07 01547
001230 005311 A
001231 056025 A 1548 PUSHJ CLB CLEAR LOGICAL BUFFER V2 07 01548
001232 006010 A
001233 000145 R
001234 006505 A
001235 005042 R 1549 INR BFWPT,B RESTORE BFWPT V2 07 01549
001236 046025 A 1550 *****                                                    07 01550
1551 * DECREMENT REMAINING WORD COUNTERS * 07 01551
1552 *****                                                    07 01552
1553 GBA70 DAB PBWC 07 01553

001237 016144 A
001240 005311 A
001241 056144 A 1554 DAB LRWC 07 01554
001242 016123 A
001243 005311 A
001244 056123 A 1555 POPJ EXIT FG 07 01555
001245 001000 A
001246 004110 R 1556 GBA80 MOV8AB PMSZ,PBWC RESET ENCODE/DECODE POINTERS PD 07 01556
001247 016143 A
001250 056144 A

```



```

1557      MOVBAR ALBF,BFAPT                                PD 07 01557
001251 016027 A
001252 056025 A
001253 001000 A 1558      JMP      GBA55                                PD 07 01558
001254 001216 R
1559      EJEC
1560 *****
1561 *
1562 *           G E T   N U M E R I C   I T E M   ( G N I )
1563 *
1564 * FUNCTION: TO GET A LIST ITEM AND CONVERT IT TO A CHAR STRING
1565 *
1566 * ENTRY:  ITEMAD = ADDRESS OF LIST ITEM
1567 *         ITMODE = MODE OF LIST ITEM:
1568 *         = 0 1-WORD INTEGER/LOGICAL
1569 *         = 1 2-WORD INTEGER/LOGICAL
1570 *         = 2 REAL
1571 *         = 3 DOUBLE PRECISION
1572 *         = 4 COMPLEX
1573 *         > 5 DOUBLE PRECISION INTEGER
1574 *
1575 * EXIT :  CHB = FRACTIONAL PART(NORMALIZED STRING OF DECIMAL DIGITS)
1576 *         DEXP = DECIMAL EXPONENT(=1 IF CHB=0)
1577 *         SGFL = 0 POSITIVE ITEM
1578 *         = -1 NEGATIVE ITEM
1579 *
1580 * ERRORS: ER3 IF INTEGER ITEM = 2**15
1581 *
1582 *****
001255 036113 A 1584 GNI   LDY   ITEMAD,B      POINT X AT ITEM
001256 015000 A 1585      LDA   0,X          GET 1ST WORD OF ITEM
001257 004317 A 1586      ASRA  15
001260 056157 A 1587      STA   SGFL,B        SAVE SIGN
001261 016116 A 1588      LDA   ITMODE,B
001262 140422 A 1589      SUB   TWO
001263 001002 A 1590      JAP   GNI4          TEST FOR INTEGER LIST ITEM
001264 001301 R
1591 *****
1592 * INTEGER ITEM *
1593 *****
001265 015000 A 1594      LDA   0,X          GET INTEGER
001266 001002 A 1595      JAP   GNI2
001267 001274 R
001270 005211 A 1596      CPA
001271 005111 A 1597      IAR
001272 001004 A 1598      JAN   ER3          ERROR 3/ INVALID INTEGER /
001273 005703 R
001274 056003 A 1599 GNI2  STA   ACC,B        STORE IN ACC
1600      MOVPAR D15,BEXP    LOAD INTEGER BIAS AS BINARY EXPONENT
001275 010472 A
001276 056024 A
001277 001000 A 1601      JMP   GNI10
001300 001412 R
001301 005311 A 1602 GNI4  DAP
001302 001010 A 1603      JAZ   GNI8          DOUBLE PRECISION #
001303 001335 R
001304 140422 A 1604      SUB   TWO
001305 001010 A 1605      JAZ   GNI9          NO
001306 001360 R
1606 *****
1607 * REAL ITEM *
1608 *****
001307 015000 A 1609      LDA   0,X          GET 1ST WORD OF REAL ITEM
001310 001002 A 1610      JAP   *+3         CONVERT TO ABS
001311 001313 R
001312 005211 A 1611      CPA
001313 056164 A 1612      STA   TEMP,B        SAVE
001314 015001 A 1613      LDA   1,X          GET 2ND WORD OF REAL ITEM
001315 150460 A 1614      ANA   BR15         CLEAR B15
001316 005024 A 1615      TEX
001317 005012 A 1616      TAB
001320 015164 A 1617      LDA   TEMP,X        LOAD X AS BASE REGISTER
001321 065164 A 1618      STB   TEMP,X        2ND WORD TO B-REG
001322 004507 A 1619      LASR  7            1ST WORD TO A-REG
001323 140430 A 1620      SUB   BXBAS        SAVE 2ND WORD
001324 055024 A 1621      STA   BEXP,X       GET BINARY EXPONENT
001325 065003 A 1622      STB   ACC,X        UNSTAS IT
001326 015164 A 1623      LDA   TEMP,X        SAVE
001327 005002 A 1624      TZO
001330 004507 A 1625      LASR  7            STORE 1ST MANTISSA WORD
001331 065004 A 1626      STB   ACC+1,X      RESTORE 2ND WORD
001332 005042 A 1627      TXB
001333 001000 A 1628      JAP   GNI10        CLEAR B
001334 001412 R
1629 *****
1630 * DOUBLE PRECISION ITEM *
1631 *****
001335 015001 A 1632 GNI8  LDA   1,X          GET 1ST MANTISSA WORD
001336 004317 A 1633      ASRA  15
001337 056157 A 1634      STA   SGFL,B        GET SIGN
001340 015001 A 1635      LDA   1,X          RELOAD WORD 1
001341 001002 A 1636      JAP   *+3         IS ITEM NEGATIVE ?
001342 001344 R

```



001343	005211	A	1637	CPA		YES. GET ABS VALUE	07	01637
001344	056003	A	1638	STA	ACC,B	LOAD WORD 0 OF ACCUMULATOR	07	01638
001345	015000	A	1639	LDA	0,X	GET BINARY EXPONENT	07	01639
001346	140430	A	1640	SUB	BXBIAS	UNBIAS IT	V2	07 01640
001347	056024	A	1641	STA	BEXP,B	SAVE	07	01641
001350	015002	A	1642	LDA	2,X	GET WORD 2	D.1	07 01642
001351	150460	A	1643	ANA	BR15	CLEAR B15	D.1	07 01643
001352	056004	A	1644	STA	ACC+1,B		D.1	07 01644
001353	015003	A	1645	LDA	3,X	GET WORD 3	D.1	07 01645
001354	150460	A	1646	ANA	BR15	CLEAR B15	D.1	07 01646
001355	056005	A	1647	STA	ACC+2,B		D.1	07 01647
001356	001000	A	1648	JMP	GNI10		07	01648
001357	001412	R						
			1649	*****			07	01649
			1650	* DP INTEGER *			07	01650
			1651	*****			07	01651
001360	006010	A	1652	GNI9	LDAI 30		07	01652
001361	000036	A						
001362	056024	A	1653	STA	BEXP,B	LOAD BIAS IN BINARY EXPONENT	07	01653
001363	015001	A	1654	LDA	1,X	GET 2ND WORD	07	01654
001364	150460	A	1655	ANA	BR15	CLEAR HIGH BIT	07	01655
001365	050000	A	1656	STA			07	01656
001366	056004	A	1657	STA	ACC+1,B	STORE	07	01657
001367	015000	A	1658	LDA	0,X	GET 1ST WORD	07	01658
001370	056003	A	1659	STA	ACC,B	SAVE	07	01659
001371	001002	A	1660	JAP	GNI10	NEGATIVE #	07	01660
001372	001412	R						
001373	005211	A	1661	CPA		YES. TAKE 1-COMP	07	01661
001374	056003	A	1662	STA	ACC,B		07	01662
001375	016004	A	1663	LDA	ACC+1,B		07	01663
001376	007400	A	1664	ROF			07	01664
001377	001016	A	1665	JANZ	GNI9A	IS WORD 2 ZERO #	07	01665
001400	001406	R						
001401	046003	A	1666	INR	ACC,B	YES. 2-COMP WORD 1	07	01666
001402	001001	A	1667	JOF	BR3	ERRCR 3/INVALID NUMBER/	07	01667
001403	005703	R						
001404	001000	A	1668	JMP	GNI10		07	01668
001405	001412	R						
001406	005211	A	1669	GNI9A	CPA	TAKE 2-COMP OF WORD 2	07	01669
001407	005111	A	1670	IAR			07	01670
001410	150460	A	1671	ANA	BR15		07	01671
001411	056004	A	1672	STA	ACC+1,B		07	01672
			1673	*****			07	01673
			1674	* TEST FOR ZERO *			07	01674
			1675	*****			07	01675
001412	016003	A	1676	GNI10	LDA	ACC,B	07	01676
001413	116004	A	1677	ORA	ACC+1,B		07	01677
001414	116005	A	1678	ORA	ACC+2,B		07	01678
001415	001016	A	1679	JANZ	GNI11	IS ITEM = ZERO ?	07	01679
001416	001423	R						
001417	005101	A	1680	INCR	1	YES	07	01680
001420	056055	A	1681	STA	BEXP,B	YES. SET DECIMAL EXPONENT TO 1	07	01681
001421	001000	A	1682	JMP	GNI50		07	01682
001422	001540	R						
			1683	*****			07	01683
			1684	* CONVERT TO NORMALIZED FRACTION AND DECIMAL EXPONENT *			07	01684
			1685	*****			07	01685
001423	006010	A	1686	GNI11	PUSHJ NRM	NORMALIZE MANTISSA	V2	07 01686
001424	002575	R						
001425	006505	A						
001426	005042	R						
001427	016024	A	1687	LDA	BEXP,B		07	01687
001430	001010	A	1688	JAZ	GNI50	FINISHED IF BINARY EXPONENT = ZERO	07	01688
001431	001540	R						
001432	001004	A	1689	JAN	GNI20		07	01689
001433	001443	R						
			1690	*****			07	01690
			1691	* (ACC,BEXP).GE.1 DIVIDE BY 10 *			07	01691
			1692	*****			07	01692
001434	046055	A	1693	INR	BEXP,B	BUMP DECIMAL EXPONENT	07	01693
			1694	PUSHJ	D10	ACC = ACC/10	V2	07 01694
001435	006010	A						
001436	000316	R						
001437	006505	A						
001440	005042	R						
001441	001000	A	1695	JMP	GNI11	LOOP TILL DONE	07	01695
001442	001423	R						
			1696	*****			07	01696
			1697	* (ACC,BEXP).LT.1 TEST IF .GE. .1 *			07	01697
			1698	*****			07	01698
001443	120464	A	1699	GNI20	ADD THREE		07	01699
001444	001004	A	1700	JAN	GNI30	(ACC,BEXP).LT. .1 IF BEXP .LT. -3	07	01700
001445	001517	R						
001446	001016	A	1701	JANZ	GNI25	(ACC,BEXP).GT. .1 IF BEXP .GT. -3	07	01701
001447	001506	R						
001450	016055	A	1702	LDA	BEXP,B		07	01702
001451	005311	A	1703	JAR			07	01703
001452	001002	A	1704	JAP	GNI25	DONT OSCILLATE	07	01704
001453	001506	R						
001454	016003	A	1705	LDA	ACC,B		07	01705
001455	006140	A	1706	SUBI	063146		V2	07 01706
001456	063146	A						



```

001457 001004 A 1707 JAN GNI30 TEST WORD 0.LT..1 07 01707
001460 001517 R
001461 001016 A 1708 JANZ GNI25 07 01708
001462 001506 R
001463 016004 A 1709 LDA ACC+1,B 07 01709
001464 006140 A 1710 SUBI 031463 V2 07 01710
001465 031463 A
001466 001004 A 1711 JAN GNI30 TEST WORD 1.LT..1 07 01711
001467 001517 R
001470 001016 A 1712 JANZ GNI25 07 01712
001471 001506 R
001472 016005 A 1713 LDA ACC+2,B 07 01713
001473 006140 A 1714 SUBI 014631 V2 07 01714
001474 014631 A
001475 001004 A 1715 JAN GNI30 TEST WORD 2.LT..1 07 01715
001476 001517 R
001477 001016 A 1716 JANZ GNI25 07 01716
001500 001503 R
001501 016006 A 1717 LDA ACC+3,B 07 01717
001502 006140 A 1718 SUBI 046315 V2 07 01718
001503 046315 A
001504 001004 A 1719 JAN GNI30 TEST WORD 3.LT..1 07 01719
001505 001517 R
1720 *****
1721 * .1 .LE. (ACC,BEXP) .LT. 1 SHIFT ACC TO POSITION *
1722 *****
001506 005001 A 1723 GNI25 TZA 07 01723
001507 146024 R 1724 SUB BEXP,B 07 01724
001510 056052 R 1725 STA COUNT,B LOAD SHIFT COUNT 07 01725
1726 PUSHJ SHA SHIFT ACC TO POSITION V2 07 01726
001511 006010 A
001512 006213 R
001513 006505 A
001514 005042 R
001515 001000 A 1727 JMP GNI50 07 01727
001516 001540 R
1728 *****
1729 * (ACC,BEXP) .LT. .1 MULTIPLY BY 10 *
1730 *****
1731 GNI30 MOVPAE FOUR,COUNT SET SHIFT COUNT TO 4 07 01731
001517 010423 A
001520 056052 A 1732 ADD BEXP,B BUMP BINARY EXPONENT BY 4 07 01732
001521 126024 A 1733 STA BEXP,B 07 01733
001522 056024 A 1734 PUSHJ SHA SHIFT ACC RIGHT 4 V2 07 01734
001523 006010 A
001524 006213 R
001525 006503 A
001526 005042 R
1735 PUSHJ M10 ACC = ACC*10 V2 07 01735
001527 006010 A
001530 002530 R
001531 006505 A
001532 005042 R
1736 DAB BEXP DRUP DECIMAL EXPONENT 07 01736
001533 016055 A
001534 005311 A
001535 056055 A
001536 001000 A 1737 JMP GNIL1 LOOP TILL DONE 07 01737
001537 001423 R
1738 *****
1739 * GENERATE DECIMAL DIGITS *
1740 *****
1741 GNI50 MOVBAE ACMB,CHBPT INITIALIZE CHB POINTER 07 01741
001540 016007 A
001541 056053 A
001542 046124 A 1742 INR MOV,B SET MULTIPLY OVERFLOW FLAG 07 01742
1743 GNIL2 PUSHJ M10 ACC = ACC*10 V2 07 01743
001543 006010 A
001544 002530 R
001545 006505 A
001546 005042 R
001547 036050 A 1744 LDX CHEPT,B POINT X AT ARRAY CHB 07 01744
001550 055000 A 1745 STA S,X STORE DECIMAL DIGIT IN ARRAY CHB 07 01745
001551 005145 A 1746 INCR 045 BUMP ARRAY POINTER 07 01746
001552 078050 A 1747 STX CHEPT,B 07 01747
001553 146007 A 1748 SUB ACMB,B 07 01748
001554 146200 A 1749 SUB M14,B V2 07 01749
001555 001004 A 1750 JAN GNIL2 LOOP TILL 14 DECIMAL DIGITS GENERATED 07 01750
001556 001543 R
1751 PUPJ EXIT FG 07 01751
001557 001000 A
001560 004110 R
1752 EJEC 07 01752
1753 ***** 07 01753
1754 * 07 01754
1755 * GET NEXT LIST ADDRESS (GNL) * 07 01755
1756 * 07 01756
1757 * FUNCTION: TO GET ADDRESS OF NEXT ITEM ON I/O LIST * 07 01757
1758 * 07 01758
1759 * ENTRY: ITEMAD = ADDRESS OF PREVIOUS LIST ITEM * 07 01759
1760 * ITMINC = WORD INCREMENT BETWEEN ELEMENTS OF LIST ITEM * 07 01760
1761 * ITEMWC = COUNT OF WORDS REMAINING IN LIST ITEM * 07 01761

```



```

1762 * * * * * 07 01762
1763 * EXIT : ITEMAD = ITEMAD+ITMINC * 07 01763
1764 * IF ITEMWC.LE.0 EXIT TO USER PROGRAM * 07 01764
1765 * ITEMWC = ITEMWC-ITMINC * 07 01765
1766 * * * * * 07 01766
1767 * * * * * 07 01767
1769 GNL ADEBB ITEMAD,ITMINC,ITEMAD BUMP LIST ITEM ADDRESS 07 01769

001561 016113 A
001562 126113 A
001563 056113 A
001564 016114 A 1770 LDA ITEMWC,B 07 01770
001565 005311 A 1771 DAR 07 01771
001566 001002 A 1772 JAP GNL2 LIST ITEM FINISHED ? 07 01772
001567 001610 R
001570 006010 A 1773 LDAI GNL2 YES V2 07 01773
001571 001610 R
001572 036000 A 1774 LDX DPSTKP,B V2 07 01774
001573 005344 A 1775 DXR FG 07 01775
001574 076000 A 1776 STX DPSTKP,B FG 07 01776
001575 055000 A 1777 STA 0,X V2 07 01777
001576 010422 A 1778 LDA CEX 07 01778
1779 PUSHF 07 01779

001577 036016 A
001600 035000 A
001601 005344 A
001602 055000 A
001603 005041 A
001604 036016 A
001605 055000 A
001606 001000 A 1780 JMP CAN EXIT TO V$FURTID 07 01780
001607 000101 R

001610 016114 A 1781 GNL2 SUTBBB ITEMWC,ITMINC,ITEMWC DECREMENT LIST ITEM WORD COUNT 07 01781
001611 146113 A
001612 056114 A
1782 POPJ EXIT FG 07 01782

001613 001000 A
001614 004110 R

1783 EJEC 07 01783
1784 * * * * * 07 01784
1785 * * * * * 07 01785
1786 * P R O C E S S G O U T P U T D E S C R I P T O R ( G O U ) * 07 01786
1787 * * * * * 07 01787
1788 * F U N C T I O N : T O P R O C E S S O U T P U T U N D E R T H E G F O R M A T D E S C R I P T O R : S R G W . D * 07 01788
1789 * * * * * 07 01789
1790 * E N T R Y : D I R E C T F R O M F R S * 07 01790
1791 * O U T P U T N U M B E R I N ( A C C , D E X P ) * 07 01791
1792 * W T = W = T O T A L F I E L D W I D T H * 07 01792
1793 * D T = D = F R A C T I O N A L F I E L D W I D T H * 07 01793
1794 * * * * * 07 01794
1795 * E X I T : D I R E C T T O E D U T I F ( A C C , D E X P ) . L T . . 1 O R . G E . 1 0 * * D T * 07 01795
1796 * O T H E R W I S E D I R E C T T O D N F W I T H * 07 01796
1797 * D T = D T - D E X P * 07 01797
1798 * I F W = D E X P * 07 01798
1799 * X F W = 4 * 07 01799
1800 * X F L = 0 * 07 01800
1801 * * * * * 07 01801
1802 * * * * * 07 01802
001615 016055 A 1804 GOUT LDA DEXP,B GET DECIMAL EXPONENT 07 01804
001616 001004 A 1805 JAN FOUT PROCESS AS 'E' IF DEXP .LT. ZERO 07 01805
001617 000352 R
001620 146054 A 1806 SUB 0,B 07 01806
001621 005311 A 1807 DAR 07 01807
001622 001002 A 1808 JAP EDUT PROCESS AS 'E' IF DEXP .GE. D 07 01808
001623 000352 R
1809 MOVBB DT,COUNT LOAD SIGNIFICANT DIGIT COUNT 07 01809

001624 016056 A
001625 056052 A
1810 PUSHJ RND ROUND DECIMAL DIGIT STRING V2 07 01810

001626 006010 A
001627 006032 R
001630 006505 A
001631 005042 R
001632 016056 A 1811 LDA DT,B 07 01811
001633 146055 A 1812 SUB DEXP,B DECREMENT FRACTIONAL FIELD 07 01812
001634 001004 A 1813 JAN EDUT PROCESS AS 'E' ON ROUNDING OVERFLOW 07 01813
001635 000352 R
001636 056056 A 1814 STA DT,B 07 01814
1815 MOVFAB FOUR,XFW SET EXPONENT FIELD WIDTH TO 4 07 01815

001637 010423 A
001640 056174 A
1816 ZAB XFL SET FLAG TO BLANK OUT EXPONENT FIELD 07 01816

001641 005001 A
001642 056173 A
1817 MOVBB DEXP,IFW LOAD INTEGER FIELD WIDTH 07 01817

001643 016055 A
001644 056100 A
001645 001000 A 1818 JMP DEF PROCESS AS 'F' DESCRIPTOR 07 01818
001646 000337 R

1819 EJEC 07 01819
1820 * * * * * 07 01820
1821 * * * * * 07 01821
1822 * P R O C E S S H D E S C R I P T O R ( H I D ) * 07 01822

```



```

1823 *
1824 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTORS
1825 *
1826 *           NH..
1827 *           '....'
1828 *
1829 * ENTRY: N = FIELD WIDTH( = 2**15-1 FOR '...' DESCRIPTOR)
1830 *       HIN : INPUT ENTRY
1831 *       HOUT : OUTPUT ENTRY
1832 *       QFL = 0 NH.. SPECIFIER
1833 *           = 1 '....' SPECIFIER
1834 *
1835 * EXIT : DIRECT TO FRS
1836 *
1837 *
001647 R 1839 HIN EQU *
001647 R 1840 HOUT EQU *
001647 016150 A 1842 TSAB QFL,HID6 TEST IF H OR '...' DESCRIPTOR
001650 001010 A
001651 001710 R
1843 *****
1844 * '...' SPECIFIER *
1845 *****
001652 005311 A 1846 DAR
001653 001010 A 1847 JAZ HID2 QFL = 2 ?
001654 001660 R
001655 056150 A 1848 STA QFL,B YES. SET QFL = 1
001656 001000 A 1849 JMP HID10 AND INPUT OVER 2ND QUOTE OF PAIR
001657 001720 R
001660 016011 A 1850 HID2 MOVBAE AFSCB,ASCB SET SCB TO FORMAT STRING
001661 056021 A
001662 006010 A 1851 PUSHJ ICC INPUT FORMAT CHARACTER V2 07 01851
001663 001754 R
001664 006505 A
001665 005042 R
001666 006451 A 1852 BT ARST+QT,HID4 IS CHAR A QUOTE ?
001667 001705 R 1853 PUSHJ ICC YES. INPUT NEXT CHARACTER V2 07 01853
001670 006010 A
001671 001754 R
001672 006505 A
001673 005042 R
001674 006451 A 1854 BT ARST+QT,FRS85 EXIT TO FORMAT SCAN ON SINGLE QUOTE
001675 001121 R 1855 DAB FMPT 2 CONSECUTIVE QUOTES - BACK UP FORMAT PTR 07 01855
001676 016062 A
001677 005311 A
001700 056062 A 1856 TSAB RWFL,WR,HID15 READ ? 07 01856
001701 016154 A
001702 006411 A
001703 001736 R
001704 046150 A 1857 HID4 INR QFL,B YES. SET QFL = 2
001705 016062 A 1858 DAB FMPT BACK UP FORMAT POINTER 07 01858
001706 005311 A
001707 056062 A
1859 *****
1860 * NH.. SPECIFIER *
1861 *****
001710 016125 A 1862 HID6 DAB H DECREMENT FIELD WIDTH N
001711 005311 A
001712 056125 A
001713 001004 A 1863 JAN FRSS EXIT WHEN FIELD EXHAUSTED
001714 000475 R 1864 TSAB RWFL,WR,HID15 V2 07 01864
001715 016154 A
001716 006411 A
001717 001736 R
1865 *****
1866 * INPUT *
1867 *****
001720 006010 A 1868 HID10 PUSHJ CRC INPUT BUFFER CHARACTER V2 07 01868
001721 000115 R
001722 006505 A
001723 005042 R
001724 016011 A 1869 MOVBAE AFSCB,ASCB SET SCB TO FORMAT STRING
001725 056021 A
001726 016030 A 1870 MOVBAE BCHAR,FCHAR MOVE CHAR FROM BUFFER SCB TO FORMAT SCB
001727 056064 A
001730 006010 A 1871 PUSHJ PCH PUT CHARACTER IN FORMAT STRING V2 07 01871
001731 003557 R
001732 006505 A
001733 005042 R
001734 001000 A 1872 JMP HIN PROCESS NEXT CHAR 07 01872

```



```

001735 001647 R
1873 *****
1874 * OUTPUT *
1875 *****
1876 HID15 MOVBAB AFSCB,ASCB SET SCB TO FORMAT STRING
001736 016011 A
001737 056021 A
1877 PUSHJ ICC INPUT FORMAT CHARACTER V2 07 01877
001740 006010 A
001741 001734 R
001742 006303 A
001743 005042 R
1878 MOVBAB FCHAR,BCHAR MOVE CHAR FROM FORMAT SCB TO BUFFER SCB 07 01878
001744 016064 A
001745 056030 A
1879 PUSHJ DCB OUTPUT FORMAT CHARACTER TO BUFFER V2 07 01879
001746 006010 A
001747 002646 R
001750 006303 A
001751 005042 R
001752 001000 A
001753 001647 R
1880 JMP HDUT PROCESS NEXT CHAR 07 01880
1881 EJEC 07 01881
1882 ***** 07 01882
1883 * 07 01883
1884 * INPUT / CLASSIFY CHARACTER ( ICC ) * 07 01884
1885 * 07 01885
1886 * FUNCTION: TO INPUT AND CLASSIFY A CHARACTER FROM A STRING. * 07 01886
1887 * 07 01887
1888 * ENTRY: ASCB = ADDRESS OF STRING CONTROL BLOCK SCB * 07 01888
1889 * 07 01889
1890 * SCB(0): CURRENT CHARACTER COUNTER * 07 01890
1891 * SCB(1): STRING START ADDRESS * 07 01891
1892 * 07 01892
1893 * EXIT : A = SCB(3) = CHARACTER CODE * 07 01893
1894 * SCB(2) = CHARACTER * 07 01894
1895 * 07 01895
1896 ***** 07 01896
1898 ***** 07 01898
1899 * GET CHAR FROM STRING * 07 01899
1900 ***** 07 01900
001754 036021 A 1901 ICC LDX ASCB,B POINT X AT SCB 07 01901
001755 013000 A 1902 LDA 0,X GET CURRENT POINTER 07 01902
001756 043000 A 1903 INR 0,X BUMP CURRENT POINTER 07 01903
001757 007401 A 1904 SDF SDF 07 01904
001760 004257 A 1905 LRLA 15 CONVERT BYTE TO WORD COUNT 07 01905
001761 003004 A 1906 XAN RDF DVFL SET IF HIGH BYTE 07 01906
001762 002351 R
001763 150460 A 1907 ANA BR15 CLEAR SIGN BIT 07 01907
001764 125001 A 1908 ADD 1,X ADD STRING START ADDRESS 07 01908
001765 005014 A 1909 TAX POINT X AT WORD 07 01909
001766 015000 A 1910 LDA 0,X GET WORD 07 01910
001767 003001 A 1911 XDF LSRAB RIGHT JUSTIFY BYTE 07 01911
001770 002053 R
001771 150463 A 1912 ANA RHW CLEAR HIGH BYTE 07 01912
001772 036021 A 1913 LDX ASCB,B POINT X AT SCB 07 01913
001773 055002 A 1914 STA 2,X STORE CHAR IN SCB 07 01914
1915 ***** 07 01915
1916 * CLASSIFY CHAR * 07 01916
1917 ***** 07 01917
1918 IFF NUC FG 07 01918
1919 GDID NV2NUC FG 07 01919
1920 IFT VII FG 07 01920
1921 ONE MAP,V$ST0 SET EXEC STATE TO 00 V2 07 01921
1922 NV2NUC CONT FG 07 01922
001774 034011 A 1923 LDX ICCCT 07 01923
001775 005144 A 1924 ICCLP IXR POINT X AT CLASSIFICATION TABLE 07 01924
001776 143000 A 1925 SUB 0,X 07 01925
001777 001002 A 1926 JAF ICCLP 07 01926
002000 001773 R
002001 015022 A 1927 LDA ICCCT1-ICCCT,X GET CHARACTER CLASSIFICATION CODE 07 01927
1928 IFF NUC FG 07 01928
1929 GDID NV2NUC FG 07 01929
1930 IFT VII FG 07 01930
1931 ONE MAP,V$ST3 SET EXEC MODE TO NN V2 07 01931
1932 NV2NUC CONT FG 07 01932
002002 036021 A 1933 LDX ASCB,B POINT X AT SCB 07 01933
002003 053003 A 1934 STA 3,X A = SCB(3) = CODE 07 01934
1935 POPJ EXIT FG 07 01935
002004 001000 A
002005 004110 R
1936 ***** 07 01936
1937 * CLASSIFICATION TABLE - CHARS * 07 01937
1938 ***** 07 01938
002006 002036 R 1939 ICCCT PZE * 07 01939
002007 000240 A 1940 DATA 0240 SPECIAL CHAR 07 01940
002010 000001 A 1941 DATA 0241-0240 BLANK 07 01941
002011 000006 A 1942 DATA 0247-0241 SPECIAL CHAR 07 01942
002012 000001 A 1943 DATA 0250-0247 * QUOTE 07 01943
002013 000001 A 1944 DATA 0251-0250 * < LEFT PAREN 07 01944
002014 000001 A 1945 DATA 0252-0251 * > RIGHT PAREN 07 01945
002015 000001 A 1946 DATA 0253-0252 SPECIAL CHAR 07 01946
002016 000001 A 1947 DATA 0254-0253 *+ PLUS SIGN 07 01947

```



```

002017 000001 A 1948 DATA 0255-0254 * , COMMA 07 01948
002020 000001 A 1949 DATA 0256-0255 * - MINUS SIGN 07 01949
002021 000001 A 1950 DATA 0257-0256 * . PERIOD 07 01950
002022 000001 A 1951 DATA 0260-0257 * / SLASH 07 01951
002023 000012 A 1952 DATA 0272-0260 NUMERIC 07 01952
002024 000007 A 1953 DATA 0301-0272 SPECIAL CHAR 07 01953
002025 000017 A 1954 DATA 0320-0301 ALPHA 07 01954
002026 000001 A 1955 DATA 0321-0320 P 07 01955
002027 000012 A 1956 DATA 0333-0321 ALPHA 07 01956
002030 000045 A 1957 DATA 0400-0333 SPECIAL CHAR 07 01957
1959 *****
1960 * CLASSIFICATION TABLE - CODES * 07 01960
1961 *****
002030 002030 R 1962 ICCCT1 EQU 7-1 07 01962
002031 000000 A 1963 DATA 0 SPECIAL CHAR 07 01963
002032 000002 A 1964 DATA 2 BLANK 07 01964
002033 000000 A 1965 DATA 0 SPECIAL CHAR 07 01965
002034 001000 A 1966 DATA 01000 * QUOTE 07 01966
002035 000010 A 1967 DATA 010 * ( LEFT PAREN 07 01967
002036 002000 A 1968 DATA 02000 * ) RIGHT PAREN 07 01968
002037 000000 A 1969 DATA 0 SPECIAL CHAR 07 01969
002040 000100 A 1970 DATA 0100 * + PLUS SIGN 07 01970
002041 000004 A 1971 DATA 4 * , COMMA 07 01971
002042 000020 A 1972 DATA 020 * - MINUS SIGN 07 01972
002043 000400 A 1973 DATA 0400 * . PERIOD 07 01973
002044 004000 A 1974 DATA 04000 * / SLASH 07 01974
002045 000040 A 1975 DATA 040 NUMERIC 07 01975
002046 000000 A 1976 DATA 0 SPECIAL CHAR 07 01976
002047 000001 A 1977 DATA 1 ALPHA 07 01977
002050 000200 A 1978 DATA 0200 P 07 01978
002051 000001 A 1979 DATA 1 ALPHA 07 01979
002052 000000 A 1980 DATA 0 SPECIAL CHAR 07 01980
002053 004350 A 1981 LSRAS LSRAS 0 07 01981
1982 FSEC *****
1983 *****
1984 * 07 01984
1985 * INPUT NUMERIC FORMAT FIELD (IFF) * 07 01985
1986 * 07 01986
1987 * FUNCTION: TO INPUT AND CONVERT AN ASCII DECIMAL STRING FROM A * 07 01987
1988 * FORMAT FIELD * 07 01988
1989 * 07 01989
1990 * ENTRY: 1ST DIGIT IN FCHAR * 07 01990
1991 * 07 01991
1992 * EXIT : BINARY EQUIVALENT IN NFF * 07 01992
1993 * 07 01993
1994 * ERRORS: ER1 IF NUMBER .GT. 2**16 - 1 * 07 01994
1995 * 07 01995
1996 *****
1998 IFF ZAR NFF CLLAR COUNTER 07 01998
002054 005001 A 1999 ***** 07 01999
002055 056126 A 2000 * INPUT/CONVERT LOOP * 07 02000
2001 ***** 07 02001
2002 IFFL SUB3BB FCHAR, AZER, FCHAR CONVERT ASCII DIGIT TO BINARY V2 07 02002
002056 016064 A 002057 146177 A
002060 056064 A
002061 016126 A 2003 LDA NFF, B GET COUNTER 07 02003
002062 006140 A 2004 SUBT 3277 TEST IF IT CAN BE MULTIPLIED BY 10 V2 07 02004
002063 006315 A
002064 001002 A 2005 JAF ER1 ERROR 1/ NUMBER TOO LARGE / 07 02005
002065 005705 R
002066 016126 A 2006 LDA NFF, B RESTORE COUNTER IN 4 07 02006
002067 005024 A 2007 TBX SAVE BASE REGISTER IN X 07 02007
002070 004560 A 2008 LLSR 16 07 02008
002071 160471 A 2009 MUL TEN 07 02009
002072 005021 A 2010 TBR 07 02010
002073 005042 A 2011 TXB RESTORE BASE REGISTER B 07 02011
002074 007400 A 2012 RFB CLEAR OVFL 07 02012
002075 126064 A 2013 ADD FCHAR, B ADD IN NEW DIGIT 07 02013
002076 001001 A 2014 JAF ER1 ERROR 1/ NUMBER TOO LARGE / 07 02014
002077 005705 R
002100 055126 A 2015 STA NFF, X UPDATE COUNTER 07 02015
2016 IFFL1 PUSHJ TOC INPUT NEXT FORMAT CHARACTER V2 07 02016
002101 006010 A
002102 001754 R
002103 006505 A
002104 005042 R
002105 006405 A 2017 BT ASST+NM, IFFL LOOP ON NUMERIC 07 02017
002106 002056 R
002107 006401 A 2018 BT ASST+BL, IFFL1 IGNORE BLANKS 07 02018
002110 002101 R 2019 POPJ EXIT ON NON-NUMERIC FG 07 02019
002111 001000 A
002112 004110 R
2020 EIEC 07 02020
2021 ***** 07 02021
2022 * 07 02022
2023 * INPUT NON-BLANK FORMAT CHAR (INF) * 07 02023
2024 * 07 02024
2025 * FUNCTION: TO SCAN THRU A FORMAT CHAR STRING TO A NON-BLANK * 07 02025
2026 * 07 02026

```



```

2027 * ENTRY: NO SPECIAL CONDITIONS * 07 02027
2028 * * 07 02028
2029 * EXIT : A = FCODE = NON-BLANK FORMAT CHAR CODE * 07 02029
2030 * FCHAR = FORMAT CHAR * 07 02030
2031 * * 07 02031
2032 * ***** * 07 02032
2034 INF MOVBAB AFSCB,ASCB SET SCB TO FORMAT STRING 07 02034

002113 016011 A
002114 056021 A

2035 INFLP PUSHJ ICC INPUT/CLASSIFY CHARACTER V2 07 02035

002115 006010 A
002116 001754 R
002117 006505 A
002120 005042 R
002121 006401 A
002122 002115 R

2036 BT ASET+BL,INFLP LOOP TILL NON-BLANK INPUT 07 02036

2037 POPJ EXIT FG 07 02037

002123 001000 A
002124 004110 R

2038 EJEC 07 02038
2039 ***** 07 02039
2040 * 07 02040
2041 * P R O C E S S I O U T P U T D E S C R I P T O R ( I O U ) * 07 02041
2042 * * 07 02042
2043 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTOR: RIW * 07 02043
2044 * * 07 02044
2045 * ENTRY: DIRECT TO IOUT * 07 02045
2046 * NUMBER IN (CHB,DEXP,SGFL) WHERE * 07 02046
2047 * * 07 02047
2048 * CHB = 14-WORD ARRAY OF BINARY DECIMAL DIGITS * 07 02048
2049 * DEXP = DECIMAL EXPONENT * 07 02049
2050 * SGFL .EQ. 0 + * 07 02050
2051 * .NE. 0 - * 07 02051
2052 * * 07 02052
2053 * EXIT : DIRECT TO ONF * 07 02053
2054 * IFW = DEXP * 07 02054
2055 * * 07 02055
2056 ***** 07 02056
002125 R 2058 IOUT EQU * 07 02058
2060 MOVBAB DEXP,COUNT 07 02060

002125 016055 A
002126 056052 A

2061 PUSHJ RND ROUND TO DEXP DIGITS V2 07 02061

002127 006010 A
002130 006032 R
002131 006505 A
002132 005042 R

2062 MOVBAB DEXP,IFW SET INTEGER COUNT TO DEXP 07 02062

002133 016055 A
002134 056100 A
002135 001000 A
002136 002701 R

2063 JMP ONF OUTPUT NUMERIC FIELD 07 02063

2064 EJEC 07 02064
2065 ***** 07 02065
2066 * 07 02066
2067 * I N P U T E X T E R N A L N U M E R I C F I E L D ( I X N ) * 07 02067
2068 * * 07 02068
2069 * FUNCTION: TO INPUT/CONVERT AN EXTERNAL NUMERIC FIELD * 07 02069
2070 * * 07 02070
2071 * ENTRY: ACC(0,1,2,3) = 0 * 07 02071
2072 * PTFI = 0 * 07 02072
2073 * S = SCALE FACTOR * 07 02073
2074 * SCF = 0 FOR I FORMAT DESCRIPTOR * 07 02074
2075 * SGFL = 0 * 07 02075
2076 * WT = W = FIELD WIDTH IN CHARACTERS * 07 02076
2077 * * 07 02077
2078 * EXIT : INPUT NUMBER = (SGFL,ACC,DEXP) , WHERE * 07 02078
2079 * SGFL = SIGN FLAG = 0 FOR + * 07 02079
2080 * = 1 FOR - * 07 02080
2081 * ACC = NORMALIZED BINARY FRACTION * 07 02081
2082 * DEXP = BINARY EXPONENT * 07 02082
2083 * * 07 02083
2084 ***** 07 02084
2086 ***** 07 02086
2087 * CLEAR FLAGS AND COUNTERS * 07 02087
2088 ***** 07 02088
2089 IXN ZAB EDEXP CLEAR EXPLICIT DECIMAL EXPONENT 07 02089

002137 005001 A
002140 056057 A
002141 056077 A
002142 056124 A
002143 056175 A
002144 006010 A
002145 000074 A
002146 056024 A

2090 STA IDEXP,B CLEAR IMPLICIT DECIMAL EXPONENT 07 02090
2091 STA MOV,B CLEAR MULTIPLY OVERFLOW FLAG 07 02091
2092 STA XSG,B CLEAR EXPONENT SIGN FLAG 07 02092
2093 LDAI 60 V2 07 02093

2094 STA BEXP,B BIAS ACC AS INTEGER ACCUMULATOR V2 07 02094
2095 ***** 07 02095
2096 * INPUT INTEGER AND FRACTIONAL PART * 07 02096
2097 ***** 07 02097
002147 006010 A
002150 000566 A
002151 056053 A

2098 LDAI 0566 ENABLE BLANK/','/'-'/'-/NUMERIC/'+'/'.' V2 07 02098

002147 006010 A
002150 000566 A
002151 056053 A

2099 STA OVFL,B 07 02099
2100 IXNLI TZAB NT,IXN50 EXIT IF FIELD EXHAUSTED 07 02100

002152 016171 A

```



002153	001010	A							
002154	002342	R							
			2101	PUSHJ	CBC	INPUT BUFFER CHARACTER		V2	07 02101
002155	006010	A							
002156	000115	R							
002157	006505	A							
002160	005042	R							
002161	156053	A	2102	ANA	CVFL,B				07 02102
002162	001010	A	2103	JAZ	CR3	ERRDR 3/ ILLEGAL CHAR /			07 02103
002163	005703	R							
002164	016031	A	2104	LDA	RCODE,B	RELOAD CHARACTER CODE			07 02104
002165	006402	A	2105	RT	RSET+CM,IXN50	STOP SCAN ON ','			07 02105
002166	002342	R							
002167	006400	A	2106	BT	RSET+AL,IXN15	TEST ALPHA			07 02106
002170	002250	R							
			2107	*****					07 02107
			2108	* PROCESS BLANK CHAR *					07 02108
			2109	*****					07 02109
002171	006441	A	2110	BT	RSET+BL,IXN4	TEST FOR BLANK			07 02110
002172	002177	R							
			2111	MOVAB	AZER,BCHAR	REPLACE ASCII BLANK WITH ASCII ZERO		V2	07 02111
002173	016177	A							
002174	056030	A							
002175	001000	A	2112	JMP	IXN10				07 02112
002176	002237	R							
002177	016053	A	2113	IXN4	LDA	CVFL,B	NON-BLANK INPUT		07 02113
002200	150445	A	2114	ANA	BR4	DISABLE '-'			07 02114
002201	150447	A	2115	ANA	BR6	DISABLE '+'			07 02115
002202	056053	A	2116	STA	CVFL,B				07 02116
			2117	*****					07 02117
			2118	* PROCESS '+' AND '-' *					07 02118
			2119	*****					07 02119
002203	016031	A	2120	LDA	RCODE,B	RELOAD CHAR CODE			07 02120
002204	006406	A	2121	BT	RSET+PL,IXN5	TEST '+'			07 02121
002205	002216	R							
002206	006444	A	2122	BT	RSET+MN,IXN6	TEST '-'			07 02122
002207	002223	R							
002210	016053	A	2123	LDA	CVFL,B				07 02123
002211	006414	A	2124	BT	RSET+B12,IXN18	'-' IS EXPONENT IF BIT 12 SET			07 02124
002212	002306	R							
002213	046157	A	2125	INR	SGFL,B	SET '-' FLAG			07 02125
002214	001000	A	2126	JMP	IXNL1	CONTINUE SCAN			07 02126
002215	002152	R							
002216	016053	A	2127	IXN5	LDA	CVFL,B			07 02127
002217	006414	A	2128	BT	RSET+B12,IXN18	'+' IS EXPONENT IF BIT 12 SET			07 02128
002220	002306	R							
002221	001000	A	2129	JMP	IXNL1	CONTINUE SCAN			07 02129
002222	002152	R							
002223	006450	A	2130	IXN6	BT	RSET+PT,IXN9	TEST '+'		07 02130
002224	002203	R							
002225	046147	A	2131	INR	PIFL,B	'.' INPUT. SET FLAG			07 02131
002226	016053	A	2132	LDA	CVFL,B				07 02132
002227	150451	A	2133	ANA	BR2	DISABLE '.'			07 02133
002230	056053	A	2134	STA	CVFL,B				07 02134
002231	001000	R	2135	JMP	IXNL1	CONTINUE SCAN			07 02135
002232	002152	R							
			2136	*****					07 02136
			2137	* PROCESS NUMERIC CHAR *					07 02137
			2138	*****					07 02138
002233	016053	A	2139	IXN8	LDA	CVFL,B			07 02139
002234	006110	A	2140	ORAI	010121	ENABLE ALPHA-EXPONENT SIGN		V2	07 02140
002235	010121	A							
002236	056053	A	2141	STA	CVFL,B				07 02141
002237	016030	A	2142	IXN10	LDA	BCHAR,B	GET INPUT NUMERIC CHAR		07 02142
002240	146177	A	2143	SUB	AZER,B	CONVERT ASCII DIGIT TO BINARY		V2	07 02143
002241	056166	A	2144	STA	TERM,B				07 02144
			2145	PUSHJ	PI0	ACC = ACC*10 + TERM		V2	07 02145
002242	006010	A							
002243	002530	R							
002244	006505	A							
002245	005042	R							
002246	001000	A	2146	JMP	IXNL1	CONTINUE SCAN			07 02146
002247	002152	R							
			2147	*****					07 02147
			2148	* ALPHA CHAR INPUT *					07 02148
			2149	*****					07 02149
002250	016030	A	2150	IXN15	LDA	BCHAR,B	GET INPUT NUMERIC CHAR		07 02150
002251	006140	A	2151	SUPI	0304			V2	07 02151
002252	000304	A							
002253	001004	A	2152	JAN	FR1	ERROR 3/ NOT '0' OR 'E' /			07 02152
002254	005703	R							
002255	140422	A	2153	SUB	RM0				07 02153
002256	001002	A	2154	JAP	CR3	ERROR 3/ NOT '0' OR 'E' /			07 02154
002257	005703	R							
			2155	*****					07 02155
			2156	* PROCESS EXPONENT FIELD *					07 02156
			2157	*****					07 02157
002260	006010	A	2158	ORAI	0106			V2	07 02158
002261	000166	A							
002262	056053	A	2159	STA	CVFL,B	ENABLE BLANK/+/./-/'/'/NUMERIC		V2	07 02159
			2160	IXNL2	FR0B	RT,IXN30	EXIT IF FIELD EXHAUSTED		07 02160
002263	016171	A							
002264	001010	A							







002401	002575	R							
002402	006505	A							
002403	005042	R	2220	TNZAB	DEXP,IXN58			FG 07	02220
002404	016055	A							
002405	001016	A							
002406	002411	R	2221	IXN57	PDPJ	EXIT WHEN DEXP=0		FG 07	02221
002407	001000	A							
002410	004110	R							
002411	001002	A	2222	IXN58	JAP	IXN60	TEST SIGN OF DEXP	FG 07	02222
002412	002422	R							
			2223	*****				07	02223
			2224	* NEGATIVE DECIMAL EXPONENT *				07	02224
			2225	*****				07	02225
			2226	PUSHJ	D10	ACC = ACC/10		V2 07	02226
002413	006010	A							
002414	000316	R							
002415	006505	A							
002416	005042	R							
002417	046055	A	2227	IMP	DEXP,B	BUMP DEXP		07	02227
002420	001000	A	2228	JMP	IXN13	CONTINUE CONVERSION		07	02228
002421	002400	R							
			2229	*****				07	02229
			2230	* POSITIVE DECIMAL EXPONENT *				07	02230
			2231	*****				07	02231
			2232	IXN60	MOVPRB	FOUR,COUNT	SET RIGHT SHIFT COUNT TO 4	07	02232
002422	010423	A							
002423	056052	A							
002424	126024	A	2233	ADD	DEXP,B	BUMP BINARY EXPONENT		07	02233
002425	056024	A	2234	STA	DEXP,B			07	02234
			2235	PUSHJ	SHA	SHIFT ACC RIGHT 4		V2 07	02235
002426	006010	A							
002427	006213	R							
002430	006505	A							
002431	005042	R	2236	PUSHJ	M10	ACC = ACC*10		V2 07	02236
002432	006010	A							
002433	002530	R							
002434	006505	A							
002435	005042	R	2237	DAB	DEXP	DROP DEXP		07	02237
002436	016055	A							
002437	005311	A							
002440	056055	A							
002441	001000	A	2238	JMP	IXN13	CONTINUE CONVERSION		07	02238
002442	002400	R							
			2239	EJEC				07	02239
			2240	*****				07	02240
			2241	*****				07	02241
			2242	* P R O C E S S L I N P U T D E S C R I P T O R S ( L I N ) *				07	02242
			2243	*****				07	02243
			2244	* FUNCTION: TO PROCESS THE INPUT FORMAT DESCRIPTOR: RLW *				07	02244
			2245	*****				07	02245
			2246	* ENTRY: DIRECT FROM FRS *				07	02246
			2247	* WT = W = TOTAL FIELD WIDTH *				07	02247
			2248	* ITEMAD = ADDRESS OF LIST ITEM *				07	02248
			2249	*****				07	02249
			2250	* EXIT : DIRECT TO FRS *				07	02250
			2251	* (ITEMAD) = -1 IF 1ST CHAR 'T' *				07	02251
			2252	* = 0 IF 1ST CHAR 'F' *				07	02252
			2253	*****				07	02253
			2254	* ERRORS: ER3 IF 1ST NON-BLANK CHAR NOT 'T' OR 'F' *				07	02254
			2255	*****				07	02255
			2256	*****				07	02256
			2258	LIN	IZAB	WT,ER3	ERROR 3/ BLANK FIELD /	07	02258
002443	016171	A							
002444	001010	A							
002445	005703	R	2259	PUSHJ	CB0	INPUT BUFFER CHARACTER		V2 07	02259
002446	006010	A							
002447	000115	R							
002450	006505	A							
002451	005042	R							
002452	006401	A	2260	BT	ASET+BL,LIN	SLEW THRU BLANKS		07	02260
002453	002443	R							
002454	036113	A	2261	LIX	ITEMAD,B	POINT X AT LIST ITEM		07	02261
002455	005301	A	2262	DECR	1			07	02262
002456	055000	A	2263	STA	0,X	SET LIST ITEM TO .TRUE. (-1)		07	02263
002457	016030	A	2264	LDA	20MR,B	GET INPUT CHAR		07	02264
002460	006140	A	2265	SUBI	0224			V2 07	02265
002461	000324	A							
002462	001016	A	2266	JAZ	LIX	EXIT TO FORMAT SCAN IF 'T'		07	02266
002463	002471	R							
002464	045000	A	2267	INR	0,5	SET LIST ITEM TO .FALSE. (0)		07	02267
002465	006120	A	2268	ADBI	016	TEST FOR 'F'		V2 07	02268
002466	000016	A							
002467	001016	A	2269	JANZ	CB0	ERROR 3/ 1ST CHAR NOT 'T' OR 'F' /		07	02269
002470	005703	R							
			2270	LIX	MOVPRB	WT,COUNT	LOAD REMAINING FIELD WIDTH AS REPEAT COUNT	07	02270
002471	016171	A							
002472	056052	A	2271	PUSHJ	CB0	GOBBLE REST OF FIELD		V2 07	02271



```

002473 006010 A
002474 005411 R
002475 006503 A
002476 005042 R
002477 001000 A 2272      JMP      FRS65      EXIT TO FORMAT SCAN      07 02272
002500 001100 R
2273      EJEC      07 02273
2274 ***** 07 02274
2275 * 07 02275
2276 * P R O C E S S L O U T P U T D E S C R I P T O R S ( L O U ) * 07 02276
2277 * 07 02277
2278 * F U N C T I O N : T O P R O C E S S T H E O U T P U T F O R M A T D E S C R I P T O R : R L W * 07 02278
2279 * 07 02279
2280 * E N T R Y : D I R E C T F R O M F R S * 07 02280
2281 * W T = W = T O T A L F I E L D W I D T H * 07 02281
2282 * I T E M A D = A D D R E S S O F L I S T I T E M * 07 02282
2283 * 07 02283
2284 * E X I T : T O F R S T H R U O B C * 07 02284
2285 * W T - 1 L E A D I N G B L A N K S O U T P U T * 07 02285
2286 * ' F ' O U T P U T I F ( I T E M A D ) . E Q . Z E R O * 07 02286
2287 * ' T ' O U T P U T O T H E R W I S E * 07 02287
2288 * 07 02288
2289 ***** 07 02289
2291 LOUT  MOVBAB  BLNK1,BCHAR      LOAD BLANK AS FILL CHARACTER      V2 07 02291
002501 016202 A
002502 056030 A
2292      DABB      WT,COUNT      SET COUNT TO WT-1      07 02292
002503 016171 A
002504 005311 A
002505 056052 A
2293      PUSHJ     RCH      OUTPUT WT-1 LEADING BLANKS      V2 07 02293
002506 006010 A
002507 005411 R
002510 006503 A
002511 005042 R
002512 006010 A 2294      LDAI      0306      V2 07 02294
002513 000306 A
002514 056030 A 2295      STA      BCHAR,B      LOAD 'F' AS OUTPUT CHARACTER      V2 07 02295
002515 036113 A 2296      LDX      ITEMAD,B      POINT X AT LIST ITEM      07 02296
2297      TZAX      0,LOU4      TEST LIST ITEM = 0 (FALSE)      07 02297
002516 015000 A
002517 001010 A
002520 002524 R
002521 006010 A 2298      LDAI      0324      SET OUTPUT CHAR TO 'T' IF NOT      V2 07 02298
002522 000324 A
002523 056030 A 2299      STA      BCHAR,B      V2 07 02299
2300 LDU4  PUSHJ     OCB      OUTPUT 'T' OR 'F'/EXIT      V2 07 02300
002524 006010 A
002525 002646 R
002526 006503 A
002527 005042 R
2301      EJEC      07 02301
2302 ***** 07 02302
2303 * 07 02303
2304 * M U L T I P L Y B Y 1 0 ( M 1 0 ) * 07 02304
2305 * 07 02305
2306 * F U N C T I O N : M U L T I P L I E S A 4 - W O R D F I E L D A C C B Y 1 0 A N D A D D S A N I N T E G E R I * 07 02306
2307 * T O T H E P R O D U C T . M O N I T O R S O V E R F L O W A N D D E C I M A L E X P O N E N T * 07 02307
2308 * 07 02308
2309 * E N T R Y : T E R M = I * 07 02309
2310 * P T F L = 1 I F A ' . ' H A S B E E N P A S S E D , 0 I F N O T * 07 02310
2311 * M O V = 1 I F O V E R F L O W A L L O W E D , 0 I F N O T * 07 02311
2312 * 07 02312
2313 * E X I T : A C C = A C C * 1 0 + I * 07 02313
2314 * A = O V E R F L O W D I G I T * 07 02314
2315 * I D E X P I N C R E M E N T E D O N O V E R F L O W I F P T F L = 0 * 07 02315
2316 * I D E X P D E C R E M E N T E D I F N O O V F L A N D P T F L . N E . 0 * 07 02316
2317 * 07 02317
2318 ***** 07 02318
002530 005024 A 2320 M10  IBX      LOAD X AS BASE REGISTER      07 02320
002531 015003 A 2321      LDA      ACC,X      07 02321
002532 006140 A 2322      SUBI     3276      V2 07 02322
002533 006314 A
002534 001004 A 2323      JAN      M104      CAN ACC BE MULTIPLIED BY 10 ?      07 02323
002535 002547 R
002536 015124 A 2324      LDA      MOV,X      NO      07 02324
002537 001016 A 2325      JANZ     M104      MULTIPLY ANYWAY IF MOV SET      07 02325
002540 002547 R
002541 015147 A 2326      LDA      PTFL,X      07 02326
002542 001016 A 2327      JANZ     M10X      EXIT IF '.' PASSED      FG 07 02327
002543 002573 R
002544 045077 A 2328      INR      IDEXP,X      OTHERWISE BUMP IMPLICIT DECIMAL EXPONENT      07 02328
2329      POPJ     AND EXIT      FG 07 02329
002545 001000 A
002546 004110 R
002547 015166 A 2330 M104  LDA      TERM,X      LOAD I      07 02330
002550 025006 A 2331      LDB     ACC+3,X      07 02331
002551 160471 A 2332      MUL     TEN      ACC(3)=ACC(3)*10 + I      07 02332
002552 065006 A 2333      STB     ACC+3,X      07 02333
002553 025003 A 2334      LDB     ACC+2,X      07 02334
002554 160471 A 2335      MUL     TEN      ACC(2)=ACC(2)*10 + OVFL(3)      07 02335
002555 065003 A 2336      STB     ACC+2,X      07 02336
002556 025004 A 2337      LDB     ACC+1,X      07 02337

```



```

002557 160471 A 2338      MUL      TEN      ACC(1)=ACC(1)*10 + DVFL(2)      07 02338
002560 065004 A 2339      STB      ACC+1,X  07 02339
002561 025003 A 2340      LDB      ACC,X    07 02340
002562 160471 A 2341      MUL      TEN      ACC(0)=ACC(0)*10 + DVFL(1)      07 02341
002563 065003 A 2342      STB      ACC,X    07 02342
002564 005042 A 2343      TXB      RESTORE BASE REGISTER B      07 02343
002565 036147 A 2344      LDX      PTFI,B   07 02344
002566 001040 A 2345      JXZ      M10X     HAS A '.' BEEN PASSED ?      FG 07 02345
002567 002573 A          R          07 02345
002570 036077 A 2346      LDY      IDEXP,B  YES      07 02346
002571 005344 A 2347      DXR      DECREMENT IMPLICIT DECIMAL EXPONENT 07 02347
002572 076077 A 2348      STX      IDEXP,B  07 02348
          R          07 02348
          M10X POPJ   EXIT      FG 07 02349

002573 001000 A          R          07 02349
002574 004110 R          R          07 02349

2350      EUEC
2351 *****
2352 *
2353 *      N O R M A L I Z E   A C C U M U L A T O R ( N R M )
2354 *
2355 * FUNCTION: TO NORMALIZE THE 4-WORD ACCUMULATOR ACC WITH BINARY
2356 *          EXPONENT BEXP.
2357 *
2358 * ENTRY: ACC.NE.0
2359 *
2360 * EXIT : (ACC,BEXP) NORMALIZED
2361 *
2362 *****
002575 005024 A 2364 NRM      TBX      LOAD X AS BASE REGISTER      07 02364
002576 015003 A 2365 NRML     LDA      ACC,X    07 02365
002577 004241 A 2366      LRLA     1          07 02366
002600 001004 A 2367      JAB      NRMX     EXIT WHEN NORMALIZED      07 02367
002601 002643 R          R          07 02367
002602 001016 A 2368      JANZ    NRM4     ACC(0) = 0 ?      07 02368
002603 002621 R          R          07 02368
          R          07 02368
002604 015004 A 2369      MOVXAX  ACC+1,ACC YES- SHIFT 1 WORD      07 02369
002605 055003 A          R          07 02369
          R          07 02369
002606 015005 A 2370      MOVXAX  ACC+2,ACC+1      07 02370
002607 055004 A          R          07 02370
          R          07 02370
002610 015006 A 2371      MOVXAX  ACC+3,ACC+2      07 02371
002611 055005 A          R          07 02371
          R          07 02371
002612 005001 A 2372      ZAX      ACC+3          07 02372
002613 055006 A          R          07 02372
002614 016024 A 2373      LDA      BEXP,B    07 02373
002615 140472 A 2374      SUB      B15       07 02374
002616 056024 A 2375      STA      BEXP,B    07 02375
002617 001000 A 2376      JMP      NRML      07 02376
002620 002576 R          R          07 02376
002621 015003 A 2377 NRM4     LDA      ACC,X    07 02377
002622 025004 A 2378      LDB      ACC+1,X  07 02378
002623 004301 A 2379      LASL    1          07 02379
002624 055003 A 2380      STA      ACC,X    SHIFT ACC(0) LEFT 1      07 02380
002625 015004 A 2381      LDA      ACC+1,X  07 02381
002626 025005 A 2382      LDB      ACC+2,X  07 02382
002627 004401 A 2383      LASL    1          07 02383
002630 055004 A 2384      STA      ACC+1,X  SHIFT ACC(1) LEFT 1      07 02384
002631 015005 A 2385      LDA      ACC+2,X  07 02385
002632 025006 A 2386      LDB      ACC+3,X  07 02386
002633 004401 A 2387      LASL    1          07 02387
002634 055005 A 2388      STA      ACC+2,X  SHIFT ACC(2) LEFT 1      07 02388
002635 065006 A 2389      STA      ACC+3,X  SHIFT ACC(3) LEFT 1      07 02389
002636 015024 A 2390      LDA      BEXP,X   07 02390
002637 005311 A 2391      DAP      DECREMENT BINARY EXPONENT BEXP 07 02391
002640 055024 A 2392      STA      BEXP,X   07 02392
002641 001000 A 2393      AND     NRML      CONTINUE NORMALIZE LOOP 07 02393
002642 002576 R          R          07 02393
002643 005042 A 2394 NRMX     TXB      RESTORE BASE REGISTER B      07 02394
          R          07 02394
          POPJ   EXIT      FG 07 02395

002644 001000 A          R          07 02395
002645 004110 R          R          07 02395

2396      EUEC
2397 *****
2398 *
2399 *      O U T P U T   C H A R   T O   B U F F E R ( O C B )
2400 *
2401 * FUNCTION: TO OUTPUT A CHARACTER TO THE BUFFER
2402 *
2403 * ENTRY: BCHAR = CHAR TO BE OUTPUT
2404 *          ASFL.NE.0 IF FIELD IS TO BE TERMINATED BY AN '**'
2405 *          WT = FIELD WIDTH
2406 *
2407 * EXIT : '**' OUTPUT IF ASFL.NE.0 AND WT=1
2408 *          DIRECT TO FRS IF WT=0
2409 *
2410 *****
2412 OCB      TZAB     ASFL,OCB4   IS '**' FLAG SET ?      07 02412

002646 016022 A          R          07 02412
002647 001010 A          R          07 02412
002650 002660 R          R          07 02412
    
```



002651	016171	A	2413	LDA	WT,B	YES		07	02413	
002652	005311	A	2414	DAR				07	02414	
002653	001016	A	2415	JANZ	DCB4	WT = 1 ?		07	02415	
002654	002660	R								
002655	006010	A	2416	LDAI	0052		V2	07	02416	
002656	000252	A								
002657	056030	A	2417	STA	BCHAR,B	YES. LOAD '*' AS OUTPUT CHARACTER	V2	07	02417	
			2418	DCB4	PUSHJ	CBC	V2	07	02418	
002660	006010	A								
002661	000115	R								
002662	006505	A								
002663	005042	R								
			2419	TZAB	WT,DCB6	FIELD EXHAUSTED ?	FG	07	02419	
002664	016171	A								
002665	001010	A								
002666	002671	R								
			2420	POPJ		NO. RETURN	FG	07	02420	
002667	001000	A								
002670	004110	R								
			2421	DCB6	MOVBB	ADPSTK,DPSTKP	YES. CLEAR STACK	FG	07	02421
002671	016017	A								
002672	056000	A								
002673	016061	A	2422	LDA	FOLKEY,B		07	02422		
002674	140424	A	2423	SUB	EIGHT		07	02423		
002675	001002	A	2424	JAP	FRS5	SCAN FOR NEXT FORMAT CHAR ON H/X	07	02424		
002676	000475	R								
002677	001000	A	2425	JMP	FRS65	RETURN TO FORMAT SCAN	07	02425		
002700	001100	R								
			2426	EJEC			07	02426		
			2427	*****			07	02427		
			2428	*			07	02428		
			2429	*	OUTPUT NUMERIC FIELD (DNF)		07	02429		
			2430	*			07	02430		
			2431	*	FUNCTION: TO OUTPUT A STRING OF CHARS REPRESENTING A DECIMAL NUMBER		07	02431		
			2432	*			07	02432		
			2433	*	ENTRY: OUTPUT NUMBER = (SGFL,CHD,DEXP), WHERE:		07	02433		
			2434	*			07	02434		
			2435	*	SGFL = SIGN = 0 FOR '+'		07	02435		
			2436	*	= -1 FOR '--'		07	02436		
			2437	*			07	02437		
			2438	*	CHD = ARRAY OF BINARY DECIMAL DIGITS		07	02438		
			2439	*	= NORMALIZED FRACTIONAL PART OF NUMBER		07	02439		
			2440	*			07	02440		
			2441	*	DEXP = DECIMAL EXPONENT		07	02441		
			2442	*			07	02442		
			2443	*	WT = FIELD WIDTH		07	02443		
			2444	*	IFW = INTEGER FIELD WIDTH		07	02444		
			2445	*	PTFL = 1 IF '.' TO BE OUTPUT, 0 OTHERWISE		07	02445		
			2446	*	DT = FRACTIONAL FIELD WIDTH		07	02446		
			2447	*	ZFW = WIDTH OF LEADING ZERO FIELD		07	02447		
			2448	*	XFL = 1 IF EXPONENT FIELD PRESENT, 0 OTHERWISE		07	02448		
			2449	*	XFW = EXPONENT FIELD WIDTH		07	02449		
			2450	*			07	02450		
			2451	*	EXIT : TO FRS THRU DCB		07	02451		
			2452	*			07	02452		
			2453	*****			07	02453		
			2454	*****			07	02454		
			2455	*	OUTPUT LEADING BLANKS *		07	02455		
			2456	*****			07	02456		
			2457	*****			07	02457		
002701	016171	A	2458	DNF	LDA	WT,B	GET FIELD WIDTH	07	02458	
002702	126157	A	2459		ADD	SGFL,B	SUBTRACT '--'	07	02459	
002703	146100	A	2460		SUB	IFW,B	SUBTRACT WIDTH OF INTEGER FIELD	07	02460	
002704	146147	A	2461		SUB	PTFL,B	SUBTRACT SPACE FOR '.'	07	02461	
002705	146056	A	2462		SUB	DT,B	SUBTRACT WIDTH OF FRACTIONAL FIELD	07	02462	
002706	146174	A	2463		SUB	XFW,B	SUBTRACT WIDTH OF EXPONENT FIELD	07	02463	
002707	056052	A	2464		STA	COUNT,B	STORE LEADING BLANK COUNT	07	02464	
002710	001002	A	2465		JAP	DNF5	TEST FOR FIELD OVERFLOW	07	02465	
002711	002731	R								
			2466	*****			07	02466		
			2467	*	FIELD OVERFLOW *		07	02467		
			2468	*****			07	02468		
002712	005311	A	2469	DAR		ALLOW 1 SPACE FOR '*'	07	02469		
002713	056022	A	2470	STA	ASFL,B	SET '*' FLAG	07	02470		
002714	126056	A	2471	ADD	DT,B		07	02471		
002715	056056	A	2472	STA	DT,B	REDUCE FRACTIONAL FIELD	07	02472		
002716	001002	A	2473	JAP	DNF5	DOES FIELD STILL OVERFLOW ?	07	02473		
002717	002731	R								
002720	005004	A	2474	TZX		YES	07	02474		
002721	076056	A	2475	STX	DT,B	SET FRACTIONAL FIELD WIDTH = 0	07	02475		
002722	126147	A	2476	ADD	PTFL,B	DELETE '.'	07	02476		
002723	076147	A	2477	STX	PTFL,B		07	02477		
002724	126100	A	2478	ADD	IFW,B		07	02478		
002725	056100	A	2479	STA	IFW,B	REDUCE INTEGER FIELD WIDTH	07	02479		
002726	001002	A	2480	JAP	DNF5	DOES FIELD STILL OVERFLOW ?	07	02480		
002727	002731	R								
002730	076100	A	2481	STX	IFW,B	YES. SET INTEGER FIELD WIDTH = 0	07	02481		
			2482	DNF5	MOVBB	BLNK1,BCHAR	V2	07	02482	
002731	016202	A								
002732	056030	A								
			2483	PUSHJ	RCH	OUTPUT COUNT BLANKS	V2	07	02483	
002733	006010	A								
002734	005411	R								
002735	006505	A								







003037	056052	A	2532	STA	COUNT,B			07	02532	
003040	036050	A	2533	LDA	CHBPT,B	POINT X AT DIGIT		07	02533	
003041	046050	A	2534	INR	CHBPT,B	BUMP CHB POINTER		07	02534	
003042	015000	A	2535	LDA	0,X	GET DIGIT		07	02535	
003043	126177	A	2536	ADD	AZER,B	CONVERT TO ASCII	V2	07	02536	
003044	056030	A	2537	STA	BCHAR,B			07	02537	
			2538	PUSHJ	DCB	OUTPUT CHAR TO BUFFER	V2	07	02538	
003045	006010	A								
003046	002646	R								
003047	006505	A								
003050	005042	R								
003051	016050	A	2539	LDA	CHBPT,B			07	02539	
003052	146007	A	2540	SUB	ACHE,B			07	02540	
003053	146200	A	2541	SUB	BD14,B		V2	07	02541	
003054	001004	A	2542	JAN	DNFL2			07	02542	
003055	003033	R								
			2543	MOVBA	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER	V2	07	02543	
003056	016177	A								
003057	056030	A								
			2544	PUSHJ	RCH	OUTPUT '0' FILL	V2	07	02544	
003060	006010	A								
003061	005411	R								
003062	006505	A								
003063	005042	R								
			2545	DNF40	TNZAB	XFL,DNF50	TEST EXPONENT FLAG	V2	07	02545
003064	016173	A								
003065	001016	A								
003066	003077	R								
			2546	*****				07	02546	
			2547	* OUTPUT BLANK EXPONENT FIELD *				07	02547	
			2548	*****				07	02548	
			2549	MOVPA	FOUR,COUNT	SET BLANK COUNT TO 4		07	02549	
003067	010423	A								
003070	056052	A								
			2550	MOVBA	BLNK1,BCHAR		V2	07	02550	
003071	016202	A								
003072	056030	A								
			2551	PUSHJ	RCH	OUTPUT 4 BLANKS AND EXIT	V2	07	02551	
003073	006010	A								
003074	005411	R								
003075	006505	A								
003076	005042	R								
			2552	*****				07	02552	
			2553	* OUTPUT EXPONENT FIELD *				07	02553	
			2554	*****				07	02554	
003077	006010	A								
003100	000305	A								
003101	056030	A								
			2555	DNF50	LDAI	0305	V2	07	02555	
003102	016061	A								
003103	001016	A								
003104	003110	R								
			2556	STA	BCHAR,B	SET EXPONENT CHARACTER TO 'E'	V2	07	02556	
			2557	TNZAB	FOLKEY,DNF52	IS FORMAT DESCRIPTOR 'D' ?	V2	07	02557	
003105	016030	A								
003106	005311	A								
003107	056030	A								
			2558	DAB	BCHAR	YES. LOAD 'D'	V2	07	02558	
003110	006010	A								
003111	002646	R								
003112	006505	A								
003113	005042	R								
			2559	DNF52	PUSHJ	DCB	OUTPUT 'D' OR 'E'	V2	07	02559
003114	016202	A								
003115	056030	A								
			2560	MOVBA	BLNK1,BCHAR	LOAD BLANK FOR PLUS	V2	07	02560	
003116	016055	A								
003117	001002	A								
003120	003127	R								
003121	005211	A	2562	CPA		YES		07	02562	
003122	005111	A	2563	IAR		CONVERT TO ABS		07	02563	
003123	056055	A	2564	STA	DEXP,B			07	02564	
003124	006010	A	2565	LDAI	0255		V2	07	02565	
003125	000255	A								
003126	056030	A								
			2566	DNF55	STA	BCHAR,B	LOAD '--'	V2	07	02566
			2567	PUSHJ	DCB	OUTPUT EXPONENT SIGN	V2	07	02567	
003127	006010	A								
003130	002646	R								
003131	006505	A								
003132	005042	R								
003133	005024	A	2568	TEX		LOAD X AS BASE REGISTER		07	02568	
003134	005001	A	2569	TZA				07	02569	
003135	025055	A	2570	LDB	DEXP,X	GET EXPONENT		07	02570	
003136	170471	A	2571	DIV	TEN	GET DECIMAL DIGITS		07	02571	
003137	053055	A	2572	STA	DEXP,X			07	02572	
003140	005021	A	2573	TBA		GET TENS DIGIT IN A		07	02573	
003141	005042	A	2574	TXB		RESTORE BASE REGISTER B		07	02574	
003142	126177	A	2575	ADD	AZER,B	CONVERT TO ASCII	V2	07	02575	
003143	056030	A	2576	STA	BCHAR,B			07	02576	
			2577	PUSHJ	DCB	OUTPUT TENS DIGIT OF EXPONENT	V2	07	02577	
003144	006010	A								
003145	002646	R								
003146	006505	A								
003147	005042	R								



```

003150 016055 A 2578 LDA DEXP,B RESTORE UNITS DIGIT 07 02578
003151 126177 A 2579 ADD AZER,B CONVERT TO ASCII V2 07 02579
003152 056030 A 2580 STA BCHAR,B 07 02580
2581 DNF60 PUSHJ QCB OUTPUT UNITS DIGIT/ ** / EXIT V2 07 02581

003153 006010 A
003154 002640 R
003155 006505 A
003156 005042 R
003157 001000 A 2582 JMP DNF60 07 02582
003160 003153 R
2583 EJEC 07 02583
2584 ***** 07 02584
2585 * 07 02585
2586 * OPEN FILE ( DPN ) * 07 02586
2587 * 07 02587
2588 * FUNCTION: TO PROCESS CALLS TO OPEN AN RMD FILE * 07 02588
2589 * 07 02589
2590 * ENTRY: DIRECT FROM RBE * 07 02590
2591 * UNIT = FORTRAN UNIT NUMBER U * 07 02591
2592 * RETURN = CALL SEQUENCE ADDRESS * 07 02592
2593 * RETURN(5) = ADDRESS OF LOGICAL UNIT NUMBER L * 07 02593
2594 * RETURN(6) = ADDRESS OF FCB ARRAY * 07 02594
2595 * RETURN(7) = MODE(REWIND OR LEAVE) OF V$IDC OPEN CALL * 07 02595
2596 * 07 02596
2597 * FOR LOGICAL FILES ONLY: * 07 02597
2598 * 07 02598
2599 * RETURN(8) = ADDRESS OF LOGICAL RECORD SIZE * 07 02599
2600 * RETURN(9) = ADDRESS OF I/O BUFFER ARRAY * 07 02600
2601 * RETURN(10) = ADDRESS OF READ BEFORE WRITE FLAG * 07 02601
2602 * 07 02602
2603 * EXIT : FCB LINKED TO CHAIN * 07 02603
2604 * ADFCB = ADDRESS OF FCB * 07 02604
2605 * FCB(0) = LOGICAL RECORD SIZE * 07 02605
2606 * FCB(1) = BUFFER ADDRESS * 07 02606
2607 * FCB OPENED BY V$IDC OPEN CALL * 07 02607
2608 * FCB(11) = U = FORTRAN UNIT NUMBER * 07 02608
2609 * FCB(12)(BITS 0-7) = L = LOGICAL UNIT NUMBER * 07 02609
2610 * 07 02610
2611 * LOGICAL FILES ONLY: * 07 02611
2612 * 07 02612
2613 * FCB(3) = CURRENT LOGICAL RECORD NUMBER * 07 02613
2614 * FCB(12)(BIT RB) = 1 ENABLE READ BEFORE WRITE V2* 07 02614
2615 * = 0 DISABLE READ BEFORE WRITE V2* 07 02615
2616 * (BIT LF) = 1 LOGICAL FILE V2* 07 02616
2617 * 0 NOT LOGICAL FILE V2* 07 02617
2618 * (BIT RM) = 1 RMD DEVICE V2* 07 02618
2619 * 0 NOT RMD DEVICE V2* 07 02619
2620 * (BIT GF) = 1 GLOBAL FCB V2* 07 02620
2621 * 0 NOT GLOBAL FCB V2* 07 02621
2622 * 07 02622
2623 * FCB(13) = 0 * 07 02623
2624 ***** 07 02624
2625 ***** V2 07 02625
2626 ***** V2 07 02626
2627 * INITIALIZE * V2 07 02627
2628 ***** V2 07 02628
2629 DPN LDA TEMP,B GET OP V2 07 02629
2630 SUBI CDPV BIAS IT V2 07 02630
003161 016164 A 2631 JAZ *+3 LOGICAL FILE ? V2 07 02631
003162 006140 A
003163 000016 A
003164 001010 A 2632 LDA LFS YES. SET FLAG V2 07 02632
003165 003167 R 2633 DRB INS SET INITIALIZE FLAG V2 07 02633
003166 010422 A 2634 STA RWFL,B STORE FLAG WORD V2 07 02634
003167 110427 A 2635 LDX ANRB,B POINT X AT V$PORTID DATA BLOCK 07 02635
003170 056154 A 2636 MOVXAB SYSBF,SAVE+3 STORE =#BUF AS BUFFER ADDRESS 07 02636
003171 036016 A
003172 015162 A
003173 056035 A
2637 ***** 07 02637
2638 * MOVE PARAMETERS FROM CALL SEQ TO DATA BLOCK * 07 02638
2639 ***** 07 02639
003174 036151 A 2640 LDX RETURN,B POINT X AT CALL SEQ 07 02640
2641 MOVXAB 5,SAVE MOVE ADDRESS OF LOGICAL UNIT NUMBER L 07 02641
003175 015005 A
003176 056032 A 2642 MOVXAB 6,SAVE+6 MOVE ADDRESS OF FCB ARRAY V2 07 02642
003177 015006 A
003200 056040 A 2643 MOVXAB 7,SAVE+1 MOVE ADDRESS OF OPEN MODE PARAMETER 07 02643
003201 015007 A
003202 056033 A 2644 TRAB RWFL,LF,DPN4 LOGICAL FILE ? V2 07 02644
003203 016154 A
003204 006441 A
003205 003214 R 2645 MOVXAB 9,SAVE+2 YES. MOVE ADDRESS OF LOGICAL RECORD SIZE 07 02645
003206 015010 A
003207 056034 A 2646 MOVXAB 9,SAVE+3 MOVE BUFFER ADDRESS 07 02646
003210 015011 A
003211 056035 A 2647 MOVXAB 10,SAVE+4 SAVE ADDRESS OF READ BEFORE WRITE FLAG 07 02647
003212 015012 A
003213 056036 A

```



```

2648 *****
2649 * PROCESS PARAMETERS *
2650 *****
003214 R 2651 OPN4 EQU *
2652 IFF NUC
2653 GOTO NUC1
2654 IFT VII
2655 GOTO VII1
2656 TZAB ALOC,DPN5 SKIP BOUNDS TEST IF NOT BACKGROUND
003214 016014 A
003215 001010 A
003216 003225 R
003217 016040 A 2657 LDA SAVE+6,B
003220 006505 A 2658 JSR TBK,X TEST FCB IN BACKGROUND
003221 006262 R
003222 126200 A 2659 ADD BD14,B
003223 006505 A 2660 JSR TBK,X
003224 006262 R
003225 R 2661 OPN5 EQU *
2662 VII1 CONT
2663 NUC1 CONT
003225 036032 A 2664 LDX SAVE,B GET ADDRESS OF LOGICAL UNIT NUMBER L
2665 MOVXAB 0,SAVE GET L
003226 015000 A
003227 056032 A
2666 PUSHJ PRU PROCESS UNIT NUMBERS U,L
003230 006010 A
003231 004216 R
003232 006505 A
003233 005042 R
003234 036033 A 2667 LDX SAVE+1,B POINT X AT OPEN MODE M(REWIND,LEAVE)
003235 015000 A 2668 LDA 0,X GET M
003236 001010 A 2669 JAZ *43
003237 003241 R
003240 010435 A 2670 LDA BS12 SET LEAVE BIT
003241 116032 A 2671 ORA SAVE,B MERGE IN L
003242 006110 A 2672 ORAI 0000 MERGE IN SKELETON OF IDC OPEN CONT WD
003243 003000 P
003244 036016 A 2673 LDX ANRB,B POINT X AT V$FORTIO
003245 055104 A 2674 STA IDCNT,X STORE I/O CONTROL WORD IN V$FORTIO
2675 MOVXAB SAVE+6,ADFCB GET FCB ADDRESS
003246 016040 A
003247 056010 A
003250 055010 A 2676 STA ADFCB,X ALSO IN V$FORTIO
003251 005014 A 2677 TAX POINT X AT FCB
2678 MOVXAB BD120,0 SET FCB(0) = 120 WORDS
003252 016201 A
003253 055000 A
2679 MOVXAB SAVE+3,1 LOAD BUFFER ADDRESS INTO FCB(1)
003254 016035 A
003255 055001 A
003256 015002 A 2680 LDA 2,X GET KEY WORD
003257 150463 A 2681 ANA RHW CLEAR UPPER BYTE
003260 006110 A 2682 ORAI 01400 SET MODE TO SEQUENTIAL
003261 001400 A
003262 055002 A 2683 STA 2,X
2684 *****
2685 * MAKE IDC OPEN CALL *
2686 *****
003263 010464 A 2687 LDA 0,X
003264 006505 A 2688 JSR PSJ,X CALL V$FORTIO TO DO IDC OPEN
003265 005042 R
2689 *****
2690 * LINK FCB ON CHAIN *
2691 *****
003266 036146 A 2692 LDX PRLINK,B POINT X AT LAST LINK OF FCB CHAIN
2693 MOVXAB ADICB,10 LINK FCB ON CHAIN
003267 016010 A
003270 055012 A
003271 036016 A 2694 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK
003272 045120 A 2695 INR INKCNT,X BUMP LINK COUNT
2696 *****
2697 * LOAD PARAMETERS INTO FCB ARRAY *
2698 *****
003273 005014 A 2699 TAX POINT X AT FCB(U)
2700 MOVXAB UNIT,11 MOVE FORTRAN UNIT NUMBER U TO FCB(11)
003274 016167 A
003275 055013 A
003276 016154 A 2701 LDA RWFL,B GET FLAG WORD
003277 150447 A 2702 ANA INR CLEAR INITIALIZE FLAG
003300 004254 A 2703 LRLA SH POSITION
003301 116032 A 2704 ORA SAVE,B MERGE IN LOGICAL UNIT NUMBER L
003302 055014 A 2705 STA 12,X STORE IN FCB(12)
003303 006455 A 2706 BT ARST+FLF,DPN30 TEST IF LOGICAL FILE
003304 003344 R
2707 *****
2708 * PROCESS LOGICAL FILE PARAMETERS *
2709 *****
003305 036034 A 2710 LDX SAVE+2,B
2711 MOVXAB 0,SAVE+2 SAVE LOGICAL RECORD SIZE
003306 015000 A
003307 056034 A
003310 036010 A 2712 LDX ADFCB,B POINT X AT FCB

```



E.2 VORTEX LISTING

V\$RERS

PROGRAM PAGE 39

LISTING PAGE ( 751)

```

003311 055000 A 2713 STA 0,X STORE LOGICAL RECORD SIZE IN FCB(0) 07 02713
                2714 TRAB RWFL, RM, DPN30 EXIT IF NOT RMD V2 07 02714
003312 016154 A
003313 006440 A
003314 003344 R
003315 036036 A 2715 LDX SAVE+4, B POINT X AT ADDR OF READ BEFORE WRITE FLAG 07 02715
003316 015000 A 2716 LDA 0,X GET FLAG 07 02716
003317 001010 A 2717 JAZ *+3 07 02717
003320 003322 R
003321 010440 A 2718 LDA FRBS SET READ BEFORE WRITE FLAG V2 07 02718
003322 036010 A 2719 LDX ADFCB, B POINT X AT FCB 07 02719
003323 115014 A 2720 ORA 12,X MERGE WITH L 07 02720
003324 055014 A 2721 STA 12,X STORE IN FCB(12) 07 02721
                2722 ZAX 13 SET FCB(13)=0 TO MARK BUFFER EMPTY 07 02722
003325 005001 A
003326 055015 A
003327 015003 A 2723 LDA 0,X GET CURRENT RECNO 07 02723
003330 005311 A 2724 DAR CHANGE FROM BASE 1 TO BASE 0 07 02724
003331 001010 A 2725 JAZ DPN30 EXIT IF AT START OF FILE 07 02725
003332 003344 R
                2726 *****
                2727 * CONVERT PHYSICAL RECNO TO LOGICAL RECNO IN FCB(3) *
                2728 *****
003333 005024 A 2729 TRX SAVE BASE REGISTER IN X 07 02729
003334 004560 A 2730 LLSR 16 07 02730
003335 165201 A 2731 MUL B0120, X V2 07 02731
003336 175034 A 2732 DIV SAVE+2, X CONVERT PHYSICAL POSITION TO LOGICAL 07 02732
003337 005021 A 2733 TBA 07 02733
003340 005042 A 2734 TRB RESTORE BASE REGISTER B 07 02734
003341 036010 A 2735 LDX ADFCB, B POINT X AT FCB 07 02735
003342 005111 A 2736 IAR CHANGE FROM BASE 0 TO BASE 1 07 02736
003343 055003 A 2737 STA 0,X STORE LOGICAL RECORD POSITION IN FCB(3) 07 02737
003344 010422 A 2738 DPN30 LDA 0,X 07 02738
                2739 PUSHF PUSH EXIT OP ONTO V$FORTIO STACK 07 02739
003345 036016 A
003346 035000 A
003347 005344 A
003350 055000 A
003351 005041 A
003352 036016 A
003353 055000 A
003354 001000 A 2740 JMP CAN EXIT TO V$FORTIO 07 02740
003355 000101 R
                2741 EJC
                2742 *****
                2743 *
                2744 * P R O C E S S A U X I L I A R Y I / O ( P A X )
                2745 *
                2746 * FUNCTION: TO PROCESS THE FORTRAN AUXILIARY I/O STATEMENTS:
                2747 *
                2748 * BACKSPACE U
                2749 * ENDFILE U
                2750 * REWIND U
                2751 *
                2752 * ENTRY: DIRECT FROM RBE
                2753 * UNIT = FORTRAN UNIT NUMBER U
                2754 * TEMP = OP = 6 BACKSPACE
                2755 * = 7 ENDFILE
                2756 * = 8 REWIND
                2757 *
                2758 * EXIT : TO V$FORTIO WITH EXIT OP STACKED
                2759 * I/O AND EXIT OPS STACKED
                2760 *
                2761 *****
                2763 PAX SUTBPB TEMP, CBK, SAVE+1 GET BIASED OP V2 07 02763
003356 016164 A
003357 140467 A
003360 056033 R
                2764 ZAB RWFL CLEAR FLAG WORD 07 02764
003361 005001 A
003362 056154 A
                2765 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER U V2 07 02765
003363 006010 A
003364 004216 R
003365 006505 A
003366 005042 R
                2766 TRAB RWFL, RM, PAX50 TEST IF RMD V2 07 02766
003367 016154 A
003370 006440 A
003371 003517 R
                2767 *****
                2768 * U IS RMD *
                2769 *****
                2770 TZAB SAVE+1, PAX10 BACKSPACE 07 02770
003372 016033 A
003373 001010 A
003374 003402 R
003375 005311 A 2771 DAR NO 07 02771
003376 001010 A 2772 JAZ PAX15 ENDFILE ? 07 02772
003377 003416 R
003400 001000 A 2773 JMP PAX30 NO. REWIND 07 02773
003401 003503 R
                2774 *****

```



```

2775 * BACKSPACE RMD *
2776 *****
2777 PAX10 TRAB RWFL,GF,PAX50 CALL V$IDC BACKSPACE IF GLOBAL FCBV2
003402 016154 A
003403 006407 A
003404 003517 R
2778 *****
2779 * BACKSPACE BY SETTING FCB(3) = FCB(3)-1 *
2780 *****
003405 036010 A
2781 LDX ADFCB,B POINT X AT FCB
2782 DAX 3 DECREMENT CURRENT RECORD NUMBER IN FCB(3)
003406 015003 A
003407 005311 A
003410 055003 A
003411 005311 A
003412 001004 A
003413 003500 R
003414 001000 A
003415 003527 R
2783 DAR
2784 JAN PAX30 DO REWIND IF FCB(3).LT.1
2785 JMP PAX70 EXIT
2786 *****
2787 * ENDFILE RMD *
2788 *****
2789 PAX15 TRAB RWFL,PD,PAX16 POST BIT SET ?
003416 016154 A
003417 006442 A
003420 003425 R
2790 PUSHJ PSB YES. POST BUFFER
003421 006010 A
003422 005011 R
003423 006505 A
003424 005042 R
003425 006010 A
003426 013400 A
003427 116167 A
003430 036016 A
003431 055104 A
003432 016154 A
003433 006441 A
003434 003456 R
003435 036010 A
2791 PAX16 LDAI 013400 GET SKELETON CLOSE/UPDATE CONTROL WD
2792 ORA UNIT,B MERGE IN LOGICAL UNIT NUMBER
2793 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK
2794 STA IDCONT,X STORE IOC CONTROL WORD IN V$FORTIO
2795 LDA RWFL,B
2796 BT ARST+LF,PAX20 LOGICAL FILE ?
003436 016201 A
003437 055000 A
003440 016121 A
003441 005311 A
003442 005024 A
003443 004560 A
003444 165122 A
003445 175201 A
003446 001010 A
003447 003451 R
003450 005122 A
003451 005122 A
003452 005021 A
003453 005042 A
003454 036010 A
003455 055003 A
003456 010464 A
003457 006505 A
003460 005042 R
003461 006010 A
003462 013000 A
003463 116167 A
003464 036016 A
003465 055104 A
003466 010464 A
003467 006505 A
003470 005042 R
2797 LDX ADFCB,B YES. POINT X AT FCB
2798 MOVBAZ BD120,0 SET RECORD SIZE FCB(0) = 120 WORDS
003436 016201 A
003437 055000 A
003440 016121 A
003441 005311 A
003442 005024 A
003443 004560 A
003444 165122 A
003445 175201 A
003446 001010 A
003447 003451 R
003450 005122 A
003451 005122 A
003452 005021 A
003453 005042 A
003454 036010 A
003455 055003 A
003456 010464 A
003457 006505 A
003460 005042 R
003461 006010 A
003462 013000 A
003463 116167 A
003464 036016 A
003465 055104 A
003466 010464 A
003467 006505 A
003470 005042 R
2799 LDA LRECD,B
2800 DAR CONVERT FROM BASE 1 TO BASE 0
2801 TRB SAVE BASE REGISTER IN X
2802 LLNR 16
2803 MUL LRSZ,X GET WORD COUNT
2804 DIV BD120,X CONVERT TO 120-WORD PHYSICAL REC CNT
2805 JAZ *+3
003450 005122 A
003451 005122 A
003452 005021 A
003453 005042 A
003454 036010 A
003455 055003 A
003456 010464 A
003457 006505 A
003460 005042 R
003461 006010 A
003462 013000 A
003463 116167 A
003464 036016 A
003465 055104 A
003466 010464 A
003467 006505 A
003470 005042 R
2806 IBR BUMP 1 FOR PARTIAL RECORD
2807 IBR BUMP 1 TO CONVERT TO BASE 1
2808 TRB
2809 TRB
2810 LDX ADFCB,B RESTORE BASE REGISTER B
2811 STA 3,X POINT X AT FCB
2812 LDA CIO STORE CURRENT PHYSICAL RECD IN FCB(3)
2813 JSR PSJ,X CALL V$IDC FOR CLOSE/UPDATE
003461 006010 A
003462 013000 A
003463 116167 A
003464 036016 A
003465 055104 A
003466 010464 A
003467 006505 A
003470 005042 R
2814 LDAI 013000 GET IOC OPEN/LEAVE SKELETON CONTROL WD
003461 006010 A
003462 013000 A
003463 116167 A
003464 036016 A
003465 055104 A
003466 010464 A
003467 006505 A
003470 005042 R
2815 ORA UNIT,B MERGE IN LOGICAL UNIT NUMBER
2816 LDX ANRB,B POINT X AT V$FORTIO
2817 STA IDCONT,X STORE IOC CONTROL WORD IN V$FORTIO
2818 LDA CIO
2819 JSR PSJ,X CALL V$IDC FOR OPEN/LEAVE
003461 006010 A
003462 013000 A
003463 116167 A
003464 036016 A
003465 055104 A
003466 010464 A
003467 006505 A
003470 005042 R
2820 TRAB RWFL,LF,PAX70 EXIT IF NOT LOGICAL FILE
003471 016154 A
003472 006441 A
003473 003527 R
003474 036010 A
2821 LDX ADFCB,B POINT X AT FCB
2822 MOVBAZ LRSZ,0 RESTORE LOGICAL RECORD SIZE IN FCB(0)
003475 016122 A
003476 055000 A
2823 MOVBAZ LRECD,3 RESTORE CURR LOG RECDRD NUMBER IN FCB(3)
003477 016121 A
003500 055003 A
003501 001000 A
003502 003527 R
2824 JMP PAX70 EXIT
2825 *****
2826 * REWIND RMD *
2827 *****
2828 PAX30 TRAB RWFL,GF,PAX33 GLOBAL FCB ?
003503 016154 A
003504 006447 A
003505 003512 R
003506 006010 A
003507 003000 A
003510 001000 A
003511 003522 R
003512 036010 A
2829 LDAI 03000 YES. CALL V$IDC OPEN/REWIND
2830 JMP PAX55
2831 PAX33 LDX ADFCB,B POINT X AT FCB

```



003513	005101	A	2832	INCR	1			07	02832	
003514	055003	A	2833	STA	3,X	SET CURRENT RECORD NUMBER TO 1		07	02833	
003515	001000	A	2834	JMP	PAX70	EXIT		07	02834	
003516	003527	R	2835	*****					07	02835
			2836	* CALL V\$IOC TO DO OP *				V2	07	02836
			2837	*****					07	02837
003517	036033	A	2838	PAX50	LDX	SAVE+1,B	GET BIASED OP IN X		07	02838
			2839		IFF	NUC		FG	07	02839
			2840		GOTO	NV2NUC		FG	07	02840
			2841		IFT	VII		FG	07	02841
			2842		OME	MAP,V\$ST0	SET EXEC STATE TO 00	V2	07	02842
			2843	NV2NUC	CONT			FG	07	02843
003520	006015	A	2844		LDAE	PAXTAB,X	GET IOC CONTROL WORD MODEL		07	02844
003521	003554	R	2845		IFF	NUC		FG	07	02845
			2846		GOTO	NV2NUC		FG	07	02846
			2847		IFT	VII		FG	07	02847
			2848		OME	MAP,V\$ST3	SET EXEC STATE TO 00	V2	07	02848
			2849	NV2NUC	CONT			FG	07	02849
003522	116167	A	2850	PAX75	ORA	UNIT,B	MERGE IN LOGICAL UNIT NUMBER		07	02850
003523	036016	A	2851		LDX	ANRE,B			07	02851
003524	055104	A	2852		STA	IOCNT,X	STORE AS IOC CONTROL WORD		07	02852
003525	007400	A	2853		RDF				07	02853
003526	001006	A	2854		DATA	01006			07	02854
003527	007401	A	2855	PAX70	SDF				07	02855
003530	010422	A	2856		LDA	CEX			07	02856
			2857		PUSHF		PUSH EXIT OP		07	02857
003531	036016	A								
003532	035000	A								
003533	005344	A								
003534	055000	A								
003535	005041	A								
003536	036016	A								
003537	055000	A								
003540	001001	A	2858	JOF	CAN		EXIT IF DONE		07	02858
003541	000101	R								
003542	010464	A	2859	LDA	CID				07	02859
			2860	PUSHF			PUSH I/O OP		07	02860
003543	036016	A								
003544	035000	A								
003545	005344	A								
003546	055000	A								
003547	005041	A								
003550	036016	A								
003551	055000	A								
003552	001000	A	2861	JMP	CAN		EXIT		07	02861
003553	000101	R								
			2862	*****					07	02862
			2863	* AUXILIARY I/O CONTROL WORD TABLE *					07	02863
			2864	*****					07	02864
003554	012000	A	2865	PAXTAB	DATA	012000	BACKSPACE		07	02865
003555	001000	A	2866		DATA	01000	WRITE EOF		07	02866
003556	001400	A	2867		DATA	01400	REWIND		07	02867
			2868		EJCC				07	02868
			2869	*****					07	02869
			2870	*****					07	02870
			2871	*****					07	02871
			2872	*****					07	02872
			2873	*****					07	02873
			2874	*****					07	02874
			2875	*****					07	02875
			2876	*****					07	02876
			2877	*****					07	02877
			2878	*****					07	02878
			2879	*****					07	02879
			2880	*****					07	02880
			2881	*****					07	02881
			2882	*****					07	02882
			2883	*****					07	02883
003557	036021	A	2885	PCX	LDX	ASCB,B	POINT X AT SCB		07	02885
			2886		MOVXAB	2,TEMP	SAVE CHAR		07	02886
003560	015002	A								
003561	056164	A								
003562	015000	A	2887	LDA	0,X		GET CURRENT POINTER		07	02887
003563	045000	A	2888	INR	0,X		BUMP CURRENT POINTER		07	02888
003564	007401	A	2889	SDF					07	02889
003565	004257	A	2890	LRLA	15		CONVERT BYTE TO WORD COUNT		07	02890
003566	003004	A	2891	XAN	RDF		OVFL SET IF HIGH BYTE		07	02891
003567	002351	R								
003570	150460	A	2892	ANA	BR15		CLEAR SIGN BIT		07	02892
003571	125001	A	2893	ADD	1,X		ADD STRING START ADDRESS		07	02893
003572	005014	A	2894	TAX			POINT X AT WORD		07	02894
003573	015000	A	2895	LDA	0,X		GET WORD		07	02895
003574	001007	A	2896	JUMN	7+4		HIGH BYTE ?		07	02896
003575	003600	R								
003576	007401	A	2897	SDF			YES		07	02897
003577	004250	A	2898	LRLAB	LRLA	8	SWAP BYTES		07	02898
003600	150462	A	2899	ANA	LHM		CLEAR UNWANTED BYTE		07	02899
003601	116164	A	2900	ORA	TEMP,B		MERGE IN NEW CHARACTER		07	02900
003602	003001	A	2901	XDF	LRLAB		SWAP BYTES IF HIGH BYTE		07	02901
003603	003577	R								
003604	055000	A	2902	STA	0,X		STORE IN MEMORY		07	02902



```

2903          POPJ          EXIT          FG 07 02903
003605 001000 A
003606 004110 R
2904          EJEC
2905 *****
2906 *
2907 *   P R O C E S S   N U M E R I C   I N P U T   D E S C R I P T O R
2908 *
2909 *               ( P N I )
2910 *
2911 *   F U N C T I O N :   T O   P R O C E S S   T H E   I N P U T   F O R M A T   D E S C R I P T O R S :
2912 *
2913 *           O R D E . D
2914 *           S R E W . D
2915 *           O R F W . D
2916 *           S R G W . D
2917 *           R I W
2918 *
2919 *   E N T R Y :   ( A C C , B E X P , S G F L ) = I N P U T   N U M B E R ,   W H E R E
2920 *           A C C = N O R M A L I Z E D   B I N A R Y   F R A C T I O N
2921 *           B E X P = B I N A R Y   E X P O N E N T
2922 *           S G F L = S I G N . E Q . 0 +
2923 *                   . N E . 0 -
2924 *           I T E M A D = A D D R E S S   O F   L I S T   I T E M
2925 *           I I W S Z = W O R D   C O U N T   O F   L I S T   I T E M
2926 *           I T M O D E = L I S T   I T E M   M O D E
2927 *                   = 0 1 - W O R D   I N T E G E R / L O G I C A L
2928 *                   = 1 2 - W O R D   I N T E G E R / L O G I C A L
2929 *                   = 2 R E A L
2930 *                   = 3 D O U B L E   P R E C I S I O N
2931 *                   = 4 C O M P L E X
2932 *
2933 *   E X I T   :   D I R E C T   T O   F R S
2934 *
2935 *****
003607 R 2937 DIN EQU *
003607 R 2938 EIN EQU *
003607 R 2939 FIN EQU *
003607 R 2940 GIN EQU *
003607 R 2941 IIN EQU *
2943 *****
2944 * TEST FOR ZERO *
2945 *****
003607 007401 A 2946 SDF
003610 016004 A 2947 LDA ACC+1,B
003611 116005 A 2948 DRA ACC+2,B
003612 116006 A 2949 DRA ACC+3,B
003613 003010 A 2950 XAZ SDF OVFL RESET IF ACC(1)=ACC(2)=ACC(3)=0
003614 002351 R
003615 116003 A 2951 DRA ACC,B
003616 001010 A 2952 JAZ PN150 EXIT IF ACC=0
003617 004012 R
003620 016110 A 2953 LDA ITMODE,B
003621 140422 A 2954 SUB TWO
003622 001002 A 2955 JAP PN14 TEST INTEGER LIST ITEM
003623 003672 R
2956 *****
2957 * INTEGER LIST ITEM *
2958 *****
003624 001001 A 2959 JDF ER3 ERROR 3/ NOT INTEGER /
003625 005703 R
003626 016024 A 2960 LDA BEXP,B GET BINARY EXPONENT
003627 005311 A 2961 DAR
003630 001004 A 2962 JAN ER3 ERROR 3/ NOT INTEGER /
003631 005703 R
003632 140472 A 2963 SUB D10
003633 001002 A 2964 JAP ER3 ERROR 3/ NOT INTEGER /
003634 005703 R
2965 MOVBAB ACC,TEMP SAVE LEFT-JUSTIFIED INTEGER
003635 016003 A
003636 056164 A 2966 ZCB ACC CLEAR ACCUMULATOR ACC
003637 005001 A
003640 056003 A
2967 *****
2968 * INTEGER SHIFT LOOP *
2969 *****
003641 005024 A 2970 TBX USE X AS BASE REGISTER
2971 PNIL1 DAX BEXP DECREMENT BINARY EXPONENT
003642 015024 A
003643 005311 A
003644 055024 A
003645 001004 A 2972 JAN PNIL1X EXIT ON FINISH
003646 003656 R
003647 015003 A 2973 LDA ACC,X
003650 025164 A 2974 LDB TEMP,X
003651 004401 A 2975 LASH SHIFT INTEGER INTO ACC
003652 055003 A 2976 STA ACC,X
003653 065164 A 2977 STB TEMP,X
003654 001000 A 2978 JMP PNIL1 CONTINUE TILL DONE
003655 003642 R
003656 001026 A 2979 PNIL1X JBNZ ER3 ERROR 3/ NOT INTEGER /
003657 005703 R

```



Address	Label	Op	Opnd	Description	Line	Page
003660	005042	A	2980	TXB	RESTORE BASE REGISTER B	V2 07 02980
			2981	TZAB	IS SIGN NEGATIVE ?	07 02981
003661	016157	A				
003662	001010	A				
003663	004012	R				
003664	016003	A	2982	LDA	ACC,B	07 02982
003665	005211	A	2983	CPA	NEGATE INTEGER	07 02983
003666	005111	A	2984	IAR		07 02984
003667	056003	A	2985	STA	ACC,B	07 02985
003670	001000	A	2986	JMP	PN150	07 02986
003671	004012	R				
003672	130464	A	2987	PN14 ERA	THREE	07 02987
003673	001010	A	2988	JAZ	PN160	07 02988
003674	004035	R				
003675	140422	A	2989	SUB	TWO	07 02989
003676	001010	A	2990	JAZ	PN18	07 02990
003677	003734	R				
			2991	*****		07 02991
			2992	* CONSTRUCT REAL *		07 02992
			2993	*****		07 02993
003700	016004	A	2994	LDA	ACC+1,B	07 02994
003701	120430	A	2995	ADD	BS7	07 02995
003702	007400	A	2996	RDF		07 02996
003703	001002	A	2997	JAP	*+4	07 02997
003704	003707	R				
003705	005001	A	2998	TZA	YES, CLEAR WORD	07 02998
003706	046003	A	2999	INR	ACC,B	07 02999
003707	056004	A	3000	STA	ACC+1,B	07 03000
003710	001007	A	3001	JOFN	*+5	07 03001
003711	003715	R				
003712	046024	A	3002	INR	BEXP,B	07 03002
			3003	MOVAB	BS14,ACC	07 03003
003713	010437	A				
003714	056003	A				
003715	005024	A	3004	TXB	LOAD X AS BASE REGISTER	07 03004
003716	015024	A	3005	LDA	BEXP,X	07 03005
003717	120430	A	3006	ADD	BXBIAS	07 03006
003720	025003	A	3007	LDB	ACC,X	V2 07 03007
003721	004407	A	3008	LASL	7	07 03008
003722	055164	A	3009	STA	TEMP,X	07 03009
003723	015003	A	3010	LDA	ACC,X	07 03010
003724	025004	A	3011	LDB	ACC+1,X	07 03011
003725	004407	A	3012	LASL	7	07 03012
003726	055004	A	3013	STA	ACC+1,X	07 03013
003727	005042	A	3014	TXB	RESTORE BASE REGISTER B	07 03014
			3015	MOVAB	TEMP,ACC	07 03015
003730	016164	A				
003731	056003	A				
003732	001000	A	3016	JMP	PN119	07 03016
003733	003775	R				
			3017	*****		07 03017
			3018	* CONSTRUCT DOUBLE PRECISION *		07 03018
			3019	*****		07 03019
003734	016006	A	3020	PN18 LDA	ACC+3,B	07 03020
003735	004241	A	3021	LRLA	1	07 03021
003736	001002	A	3022	JAP	PN118	07 03022
003737	003763	R				
003740	046005	A	3023	INR	ACC+2,B	07 03023
003741	016005	A	3024	LDA	ACC+2,B	07 03024
003742	001002	A	3025	JAP	PN118	07 03025
003743	003763	R				
003744	046004	A	3026	INR	ACC+1,B	07 03026
003745	005001	A	3027	TZA	YES, BUMP WORD 1	07 03027
003746	056005	A	3028	STA	ACC+2,B	07 03028
003747	016004	A	3029	LDA	ACC+1,B	07 03029
003750	001002	A	3030	JAP	PN118	07 03030
003751	003763	R				
003752	046003	A	3031	INR	ACC,B	07 03031
003753	005001	A	3032	TZA	YES, BUMP WORD 0	07 03032
003754	056004	A	3033	STA	ACC+1,B	07 03033
003755	016003	A	3034	LDA	ACC,B	07 03034
003756	001002	A	3035	JAP	PN118	07 03035
003757	003763	R				
003760	046024	A	3036	INR	BEXP,B	07 03036
003761	010437	A	3037	LDA	BS14	07 03037
003762	056003	A	3038	STA	ACC,B	07 03038
			3039	PN118 MOVAB	ACC+2,ACC+3	07 03039
003763	016005	A				
003764	056006	A				
			3040	MOVAB	ACC+1,ACC+2	07 03040
003765	016004	A				
003766	056005	A				
			3041	MOVAB	ACC,ACC+1	07 03041
003767	016003	A				
003770	056004	A				
003771	016024	A	3042	LDA	BEXP,B	07 03042
003772	120430	A	3043	ADD	BXBIAS	V2 07 03043
003773	056003	A	3044	STA	ACC,B	07 03044
003774	005124	A	3045	INCR	BS4	07 03045
003775	016157	A	3046	PN119 LDA	SGFL,B	07 03046
003776	001010	A	3047	JAZ	PN120	07 03047
003777	004003	R				
004000	015003	A	3048	LDA	ACC,X	07 03048



```

004001 005211 A 3049          CPA          NEGATE NUMBER          07 03049
004002 055003 A 3050          STA          ACC,X          07 03050
                                3051 *****
                                3052 * CHECK EXPONENT RANGE * 07 03051
                                3053 *****
004003 016024 A 3054 PNI20  LDA          BEXP,B          GET BINARY EXPONENT      07 03053
004004 120430 A 3055          ADD          3XDIAS         ADD BINARY EXPONENT BIAS  V8 07 03055
004005 001004 A 3056          JAM          ER3           ERROR 3/ UNDERFLOW /    07 03056
004006 005703 R
004007 150462 A 3057          ANA          LHW           07 03057
004008 001016 A 3058          JANZ         ER3           ERROR 3/ OVERFLOW /    07 03058
004011 005703 R
                                3059 *****
                                3060 * LOAD LIST ITEM *      07 03059
                                3061 *****
                                3062 PNI50  ZAB          COUNT          CLEAR COUNTER          07 03061
004012 005001 A
004013 056052 A
                                3063          MOVBAB  ACC,TEMP          INITIALIZE ACC POINTER   07 03063
004014 016001 A
004015 056164 A
                                3064          MOVBAB  ITEMAD,BEXP        INITIALIZE LIST ITEM POINTER 07 03064
004016 016113 A
004017 056024 A
004020 036164 A 3065 PNI12  LDA          TEMP,B          POINT X AT ACC          07 03065
004021 015000 A 3066          LDA          0,X           GET WORD                07 03066
004022 036024 A 3067          LDZ          BEXP,B          POINT X AT LIST ITEM    07 03067
004023 055000 A 3068          STA          0,X           STORE DATA IN LIST ITEM 07 03068
004024 046164 A 3069          INR          TEMP,B          BUMP ACC POINTER        07 03069
004025 046024 A 3070          INR          BEXP,B          BUMP LIST ITEM POINTER  07 03070
004026 046052 A 3071          INR          COUNT,B         BUMP LOOP COUNT        07 03071
004027 016052 A 3072          LDA          COUNT,B         07 03072
004030 146102 A 3073          SUB          IWSZ,B          07 03073
004031 001004 A 3074          JAM          PNI12          LOOP TILL ITEM FILLED   07 03074
004032 004020 R
004033 001000 A 3075          JMP          FRS65          EXIT TO FRS            07 03075
004034 001100 R
                                3077 *
004035 016005 A 3078 PNI60  LDA          ACC+2,B         PROCESS DOUBLE PRECISION INTEGER * 07 03077
004036 116006 A 3079          ORA          ACC+3,B         07 03078
004037 001016 A 3080          JANZ         ER3           NOT INTEGER             07 03079
004040 005703 R
004041 016024 A 3081          LDA          BEXP,B          07 03081
004042 005311 A 3082          DAR          07 03082
004043 001004 A 3083          JAM          ER3           NOT INTEGER             07 03083
004044 005703 R
004045 006140 A 3084          SUBI         30            07 03084
004046 000036 A
004047 001002 A 3085          JAP          ER3           NOT INTEGER             07 03085
004050 005703 R
004051 005024 A 3086          TBX          07 03086
004052 005111 A 3087 PNI62  IAR          POSITION VALUE   07 03087
004053 001002 A 3088          JAP          PNI64          DONE                    07 03088
004054 004066 R
004055 055024 A 3089          STA          BEXP,X         07 03089
004056 015003 A 3090          LDA          ACC,X          07 03090
004057 025004 A 3091          LDB          ACC+1,X        07 03091
004060 004501 A 3092          LASR         1            07 03092
004061 055003 A 3093          STA          ACC,X          07 03093
004062 065004 A 3094          STB          ACC+1,X        07 03094
004063 015024 A 3095          LDA          BEXP,X         07 03095
004064 001000 A 3096          JMP          PNI62          07 03096
004065 004052 R
004066 005042 A 3097 PNI64  TXB          RESTORE BASE REGISTER B 07 03097
                                3098  TXAB          POSITIVE SIGN 07 03098
004067 016157 A
004070 001010 A
004071 004012 R
004072 015004 A 3099          LDA          ACC+1,X        NEGATE VALUE            07 03099
004073 025003 A 3100          LDZ          ACC,X          07 03100
004074 005211 A 3101          CPA          07 03101
004075 005222 A 3102          CPB          07 03102
004076 005111 A 3103          TAP          07 03103
004077 001002 A 3104          JAP          PNI66          07 03104
004100 004103 R
004101 130440 A 3105          ERA          RS15          07 03105
004102 005122 A 3106          IBR          07 03106
004103 055004 A 3107 PNI66  STA          ACC+1,X        07 03107
004104 065003 A 3108          STB          ACC,X          07 03108
004105 005042 A 3109          TXB          07 03109
004106 001000 A 3110          JMP          PNI50          07 03110
004107 004012 R
3111          EJEC          07 03111
3112 *****
3113 *
3114 *
3115 *
3116 * FUNCTION: TO PROVIDE A POP/JUMP CAPABILITY * 07 03116
3117 *
3118 * ENTRY: DPSTKP = DP STACK POINTER * 07 03117
3119 *
3120 * EXIT : DIRECT TO ROUTINE SPECIFIED BY DP * 07 03120
3121 * DPSTKP INCREMENTED * 07 03121

```



		3122	*						* 07	03122
		3123	*****						07	03123
004110	036000	A 3125	PDJ	LDX	OPSTKP,B	POINT X AT OP			07	03125
004111	035000	A 3126		LDX	0,X	GET OP IN X		FG	07	03126
004112	046000	A 3127		INR	OPSTKP,B	BUMP STACK POINTER		FG	07	03127
004113	006705	A 3128		IJMP	0,X	EXIT			07	03128
004114	000000	A								
		3129		EJEC				PD	07	03129
		3130	*****					PD	07	03130
		3131	*					PD	07	03131
		3132	*			PROCESS ENCODE / DECODE		PD	07	03132
		3133	*					PD	07	03133
		3134	*			FUNCTION: TO PROCESS THE FORTRAN STATEMENTS		PD	07	03134
		3135	*			ENCODE(S,F,B,C)		PD	07	03135
		3136	*			DECODE(S,F,B,C)		PD	07	03136
		3137	*					PD	07	03137
		3138	*			ENTRY: DIRECT FROM RBE		PD	07	03138
		3139	*			RETURN = ADDRESS OF PARAMETER LIST		PD	07	03139
		3140	*			UNIT = BUFFER SIZE		PD	07	03140
		3141	*			TEMP = OP = CDC DECODE		PD	07	03141
		3142	*			CEN ENCODE		PD	07	03142
		3143	*					PD	07	03143
		3144	*			EXIT: ENCODE - BUFFER BLANKED		PD	07	03144
		3145	*			FRMT = ADDRESS OF FORMAT STRING		PD	07	03145
		3146	*			XFFL = 1 PARAMETER XFER ENABLED		PD	07	03146
		3147	*			ITEMUC = 0 COUNT OF WORDS REMAINING IN LIST ITEM		PD	07	03147
		3148	*			DIRECT TO FRS TO START FORMAT SCAN		PD	07	03148
		3149	*					PD	07	03149
		3150	*****					PD	07	03150
004115	016164	A 3151	PRD	LDA	TEMP,B			PD	07	03151
004116	006140	A 3152		SUBI	CDC			PD	07	03152
004117	000020	A								
004120	004250	A 3153		LRLA	8	POSITION READ/WRITE FLAG		PD	07	03153
004121	056104	A 3154		STA	IOCONT,B			PD	07	03154
004122	001010	A 3155		JAZ	#+3			PD	07	03155
004123	004123	R								
004124	010432	A 3156		LDA	MRS	SET WRITE BIT		PD	07	03156
004125	110431	A 3157		DRA	MFS	SET FILL FLAG		PD	07	03157
004126	006110	A 3158		ORAT	02000	SET ENCODE/DECODE BIT		PD	07	03158
004127	002000	A								
004130	056154	A 3159		STA	RWFL,B	INITIALIZE READ/WRITE FLAG WORD		PD	07	03159
004131	036151	A 3160		LDX	RETURN,B	POINT X TO PARAMETER LIST		PD	07	03160
		3161		MOVXAB	5,FRMT	SAVE FOR MAT STRING ADDRESS		PD	07	03161
004132	015005	A								
004133	056063	A								
		3162		MOVXAB	6,APBF	BUFFER ADDRESS		PD	07	03162
004134	015006	A								
004135	056020	A								
004136	056027	A 3163		STA	ALBF,B			PD	07	03163
004137	005311	A 3164		DAR				PD	07	03164
004140	056025	A 3165		STA	BFMPT,B			PD	07	03165
004141	015007	A 3166		LDR	7,X	CHARACTER-PROCESSED COUNT ADDRESS		PD	07	03166
004142	056152	A 3167		STA	RETURN+1,B			PD	07	03167
004143	001010	A 3168		JAZ	PRD1	NO COUNT FIELD		PD	07	03168
004144	004151	R								
004145	005014	A 3169		TAX				PD	07	03169
004146	005001	A 3170		TZA				PD	07	03170
004147	055000	A 3171		STA	0,X	INITIALIZE COUNT VARIABLE		PD	07	03171
004150	036151	A 3172		LDX	RETURN,B			PD	07	03172
004151	016167	A 3173	PRD1	LDA	UNIT,B	BUFFER SIZE		PD	07	03173
004152	005111	A 3174		IAR				PD	07	03174
004153	004301	A 3175		ASRA	1	MAKE BUFFER COUNT WORDS		PD	07	03175
004154	056143	A 3176		STA	FRS2,B			PD	07	03176
004155	056144	A 3177		STA	FRWC,B			PD	07	03177
004156	056122	A 3178		STA	LRS2,B			PD	07	03178
004157	056123	A 3179		STA	LRWC,B			PD	07	03179
004160	005001	A 3180		TZA				PD	07	03180
004161	056167	A 3181		STA	UNIT,B	SET NO UNIT		PD	07	03181
004162	035016	A 3182		LDX	ANRB,X	POINT X AT VSFORTIO DATA BLOCK		PD	07	03182
004163	010435	A 3183		LDA	BS12	IOC MODE IS ASCII		PD	07	03183
004164	115104	A 3184		DRA	IOCONT,X			PD	07	03184
004165	055104	A 3185		STA	IOCONT,X			PD	07	03185
		3186		MOVXAB	RWFL,RWFL			PD	07	03186
004166	016154	A								
004167	055154	A								
		3187		IFF	NUC			FG	07	03187
		3188		GOTO	NUC1			FG	07	03188
		3189		IFT	VII			FG	07	03189
		3190		GOTO	VIII			FG	07	03190
		3191		TZAR	ALDC,PRD2	ALDC ENTRY FROM BACKGROUND		PD	07	03191
004170	016014	A								
004171	001010	A								
004172	004202	R								
004173	015020	A 3192		LDA	APDF,X	YES		PD	07	03192
004174	006505	A 3193		JSR	TRK,X	TEST BUFFER START ADDRESS		PD	07	03193
004175	006262	R								
004176	126143	A 3194		ADD	FRS2,B			PD	07	03194
004177	005311	A 3195		DAR				PD	07	03195
004200	006505	A 3196		JSR	TRK,X	TEST BUFFER END ADDRESS		PD	07	03196
004201	006262	R								
		3197	VIII	CONT				FG	07	03197
		3198	NUC1	CONT				FG	07	03198
		3199	PRD2	ZAR	BFPT	CLEAR BUFFER CHARACTER POINTER		PD	07	03199



```

004202 005001 A
004203 056026 A
3200 TRAB RWFL,WR,PRD4 WRITE? PD 07 03200
004204 016154 A
004205 006451 A
004206 004213 R
3201 PUSHJ CLB YES, CLEAR BUFFER PD 07 03201
004207 006010 A
004210 000145 R
004211 006505 A
004212 005042 R
004213 046172 A
004214 001000 A
004215 000442 R
3202 PRD4 INR XFFL,B ENABLE PARAMETER XFER PD 07 03202
3203 JMP FRS TO FORMAT SCAN PD 07 03203
3204 EJEC 07 03204
3205 ***** 07 03205
3206 * 07 03206
3207 * PROCESS UNIT NUMBER (PRU) 07 03207
3208 * 07 03208
3209 * FUNCTION: TO PROCESS A FORTRAN UNIT NUMBER U 07 03209
3210 * 07 03210
3211 * ENTRY: UNIT = FORTRAN UNIT NUMBER U 07 03211
3212 * RWFL(BF) = 1 V2 07 03212
3213 * RWFL(IN) = 1 IF OPEN CALL V2* 07 03213
3214 * FCB CHAIN ITEM XFCB HAS FORMAT: 07 03214
3215 * XFCB(12)(BITS 0-7) = L(XFCB) 07 03215
3216 * XFCB(12)(BIT 12) = 1 RMD FILE V2 07 03216
3217 * 0 NOT RMD FILE V2 07 03217
3218 * XFCB(12)(BIT 13) = 1 LOGICAL FILE V2* 07 03218
3219 * 0 NOT LOGICAL FILE V2* 07 03219
3220 * XFCB(12)(BIT 14) = 1 UNPOSTED DATA IN BUFFER 07 03220
3221 * = 0 NO UNPOSTED DATA IN FILE 07 03221
3222 * XFCB(12)(BIT 15) = 1 ENABLE READ BEFORE WRITE 07 03222
3223 * = 0 DISABLE READ BEFORE WRITE 07 03223
3224 * XFCB(13) = PHYSICAL RECORD NUMBER IN BUFFER(0 IF NONE) 07 03224
3225 * 07 03225
3226 * EXIT : ADFCB = ADDRESS OF DCB/FCB 07 03226
3227 * UNIT = LOGICAL UNIT NUMBER L 07 03227
3228 * LRSZ = FCB(0) = LOGICAL RECORD SIZE IN WORDS 07 03228
3229 * APBF = ADDRESS OF PHYSICAL BUFFER 07 03229
3230 * ALBF = ADDRESS OF LOGICAL BUFFER 07 03230
3231 * PBSZ = PHYSICAL BUFFER SIZE IN WORDS 07 03231
3232 * RWFL(BIT RM) = FCB(12)(BIT 12) RMD FLAG V2 07 03232
3233 * RWFL(BIT LF) = FCB(12)(BIT 13) LOGICAL FILE FLAG V2 07 03233
3234 * RWFL(BIT PD) = FCB(12)(BIT 14) POST FLAG V2 07 03234
3235 * RWFL(BIT RB) = FCB(12)(BIT 15) READ BEFORE WRITE FLAG V2 07 03235
3236 * RWFL(BIT BF) = 0 IF READ IS TO RETURN 1/0 WORD COUNT V2 07 03236
3237 * 1 IF READ IS TO RETURN FULL BUFF(BLANK FILL) V2 07 03237
3238 * RWFL(BIT GF) = 1 IF GLOBAL FCB V2* 07 03238
3239 * 07 03239
3240 * THE FOLLOWING APPLY ONLY TO LOGICAL FILES: 07 03240
3241 * 07 03241
3242 * LGDV = INCREMENT FROM START OF PHYSICAL TO START OF LOGICAL 07 03242
3243 * LRECD = FCB(3) = LOGICAL RECORD NUMBER 07 03243
3244 * PERC = COUNT OF 120-WORD RECORDS IN PHYSICAL BUFFER 07 03244
3245 * 07 03245
3246 * ERRORS: ER4 IF U NOT IN RANGE 1-255 07 03246
3247 * ER4 IF L INVALID 07 03247
3248 * ER4 IF FOREGROUND RMD NOT OPENED 07 03248
3249 * ER4 IF BACKGROUND RMD NOT OPENED NOR W/GLOBAL FCB 07 03249
3250 * ER4 IF U ALREADY ON CHAIN FOR OPEN CALL V2* 07 03250
3251 * 07 03251
3252 ***** 07 03252
3253 ***** 07 03253
3254 ***** 07 03254
3255 * TEST RANGE OF U * 07 03255
3256 ***** 07 03256
004216 016167 A
004217 150462 A
004220 001016 A
004221 005702 R
3257 PRU LDA UNIT,B GET U 07 03257
3258 ANA LHW 07 03258
3259 JANZ TR4 ERROR 4/ U NOT IN (1,255) / 07 03259
3260 ***** 07 03260
3261 * SEARCH FCB CHAIN FOR U ALREADY DEFINED * 07 03261
3262 ***** 07 03262
3263 TRAB RWFL,DA,PRU0 07 03263
004222 016154 A
004223 006453 A
004224 004231 R
004225 036151 A
004226 015011 A
004227 001000 A
004230 004237 R
3264 LDX RETURN,B DIRECT ACCESS 07 03264
3265 LDA P,X FCB ADDRESS 07 03265
3266 JMP PRU05 07 03266
3267 PRU0 PUSHJ SCH SEARCH FCB CHAIN 07 03267
004231 006010 A
004232 006150 R
004233 006505 A
004234 005042 R
004235 001010 A
004236 004345 R
3268 JAZ PRU5 07 03268
3269 ***** 07 03269
3270 * U IS ON FCB CHAIN * 07 03270
3271 ***** 07 03271
004237 056010 A
004240 036010 A
3272 PRU05 STA ANFCB,B STORE FCB ADDRESS 07 03272
3273 LDX ANRB,B E 07 03273

```



Address	Label	Op	Opnd	Description	Flags	Page
004241	055010	A	3274	STA ADFCB,X		07 03274
004242	005014	A	3275	TAX		07 03275
			3276	TSAB RWFL,IN,ER4		07 03276
004243	016154	A				
004244	006406	A				
004245	005702	R				
			3277	MOVXAB 3,SVRECN		07 03277
004246	015003	A				
004247	056160	A				
			3278	MOVXAB 0,LRSZ		07 03278
004250	015000	A				
004251	056122	A				
004252	056143	A	3279	STA PBSZ,B		07 03279
			3280	MOVXAB 1,APBF		07 03280
004253	015001	A				
004254	056020	A				
004255	056027	A	3281	STA ALBF,B		07 03281
004256	015014	A	3282	LDA 12,X		07 03282
004257	150463	A	3283	ANA RMW		07 03283
004260	056167	A	3284	STA UNIT,B		07 03284
004261	015014	A	3285	LDA 12,X		07 03285
004262	004354	A	3286	LSRA SH		07 03286
004263	116154	A	3287	DRA RWFL,B		07 03287
004264	056154	A	3288	STA RWFL,B		07 03288
004265	006441	A	3289	BT BRST+LF,PRU50		07 03289
004266	004615	R				
004267	006400	A	3290	BT ASET+RM,PRU1		07 03290
004270	004275	R				
004271	150451	A	3291	ANA BFR		07 03291
004272	056154	A	3292	STA RWFL,B		07 03292
			3293	POPJ		07 03293
004273	001000	A				
004274	004110	R				
			3294	*****		07 03294
			3295	* U IS AN RMD LOGICAL FILE *		07 03295
			3296	*****		07 03296
			3297	PRU1 EQU *		07 03297
	004275	R	3298	MOVXAB 0,LRECNO		07 03298
004275	015003	A				
004276	056121	A				
004277	016122	A	3299	LDA LRSZ,B		07 03299
004300	005024	A	3300	TBX		07 03300
004301	145201	A	3301	SUB BD120,X		07 03301
004302	001002	A	3302	JAP PRU2		07 03302
004303	004312	R				
004304	015201	A	3303	LDA BD120,X		07 03303
004305	004560	A	3304	LLSR 16		07 03304
004306	175122	A	3305	DIV LRSZ,X		07 03305
004307	005102	A	3306	INCR 8		07 03306
004310	001000	A	3307	JMP PRU3		07 03307
004311	004321	R				
004312	015122	A	3308	PRU2 LDA LRSZ,X		07 03308
004313	004560	A	3309	LLSR 16		07 03309
004314	175201	A	3310	DIV BD120,X		07 03310
004315	001010	A	3311	JAZ PRU4		07 03311
004316	004320	R				
004317	005122	A	3312	IBR		07 03312
004320	005311	A	3313	DAR		07 03313
004321	001010	A	3314	PRU3 JAZ *+3		07 03314
004322	004324	R				
004323	005122	A	3315	PRU4 IBR		07 03315
004324	065142	A	3316	STB PRRC,X		07 03316
004325	005001	A	3317	TZA		07 03317
004326	165201	A	3318	MUL BD120,X		07 03318
004327	065143	A	3319	STB PRSZ,X		07 03319
004330	015121	A	3320	LDA LRECNO,X		07 03320
004331	005311	A	3321	DAR		07 03321
004332	004560	A	3322	LLSR 16		07 03322
004333	165122	A	3323	MUL LRSZ,X		07 03323
004334	175201	A	3324	DIV BD120,X		07 03324
004335	005122	A	3325	IBR		07 03325
004336	065145	A	3326	STB PRRCNO,X		07 03326
004337	055123	A	3327	CTA LBBV,X		07 03327
004340	125020	A	3328	ADD APBF,X		07 03328
004341	055027	A	3329	STA ALBF,X		07 03329
004342	005042	A	3330	TXB		07 03330
			3331	POPJ		07 03331
004343	001000	A				
004344	004110	R				
			3332	*****		07 03332
			3333	* U NOT ON FCB CHAIN - SET L=U *		07 03333
			3334	*****		07 03334
			3335	PRU5 LDW AMRB,B		07 03335
			3336	MOVXAB ASYSDC,ADFCB		07 03336
004345	036016	A				
004346	015023	A				
004347	056010	A				
004350	055010	A	3337	STA ADFCB,X		07 03337
004351	005014	A	3338	TAX		07 03338
			3339	MOVXAB 1,APBF		07 03339
004352	015001	A				
004353	056020	A				
004354	056027	A	3340	STA ALBF,B		07 03340
			3341	MOVXAB BD120,0		07 03341



```

004355 016201 A
004356 055000 A
004357 056143 A 3342 STA PBSZ,B 07 03342
004360 056122 A 3343 STA LRSZ,B 07 03343
3344 ***** 07 03344
3345 * TEST VALIDITY OF L * 07 03345
3346 ***** 07 03346
004361 036032 A 3347 LDX SAVE,B L = SAVE ON OPEN CALL V2 07 03347
3348 TSAB RWFL,IN,PRU6 OPEN CALL ? V2 07 03348
004362 016154 A
004363 006406 A
004364 004366 R
004365 036167 A 3349 PRU6 LDX UNIT,B NO. L=UNIT V2 07 03349
004366 005041 A 3350 TXA GET L IN A V2 07 03350
004367 001010 A 3351 JAZ PRU50 EXIT IF L=0 FG 07 03351
004370 004615 R
004371 006030 A 3352 LDXI V$LUT1 POINT X AT LUN POINTER TABLE V2 07 03352
004372 000400 A
004373 005311 A 3353 DAR 1ST BLOCK BIASED BASE 1 07 03353
004374 056164 A 3354 STA SAVE 07 03354
004375 005111 A 3355 IAR RESTORE L IN A V2 07 03355
004376 006140 A 3356 SUBI 101 V2 07 03356
004377 000145 A
004400 001004 A 3357 JAN PRU10 IS L IN BLOCK 1(1-100) ? 07 03357
004401 004412 R
004402 005144 A 3358 IXR NO. BUMP BLOCK POINTER 07 03358
004403 056164 A 3359 STA TEMP,B SAVE BIASED LUN 07 03359
004404 006140 A 3360 SUBI 79 V2 07 03360
004405 000117 A
004406 001004 A 3361 JAN PRU10 IS L IN BLOCK 2(101-180) ? 07 03361
004407 004412 R
004410 005144 A 3362 IXR NO. BUMP BLOCK POINTER 07 03362
004411 056164 A 3363 STA TEMP,B SAVE BIASED L 07 03363
004412 016164 A 3364 PRU10 LDA TEMP,B GET BIASED L 07 03364
004413 035000 A 3365 LDX 0,X POINT X AT BLOCK POINTER 07 03365
004414 145000 A 3366 SUB 0,X COMPARE BIASED L WITH BLOCK SIZE 07 03366
004415 001002 A 3367 JAP ER4 ERROR 4/ INVALID LUN / 07 03367
004416 005702 R
3368 ***** 07 03368
3369 * GET DST INFO * 07 03369
3370 ***** 07 03370
004417 005141 A 3371 INCR 041 07 03371
004420 126164 A 3372 ADD TEMP,B 07 03372
004421 005014 A 3373 TAX POINT X AT LOGICAL UNIT TABLE ENTRY 07 03373
004422 015000 A 3374 LDA 0,X 07 03374
004423 150463 A 3375 ANA RWFL GET DST INCREMENT FROM LUT 07 03375
004424 056037 A 3376 STA SAVE+5,B SAVE V2 07 03376
004425 001010 A 3377 JAZ PRU50 EXIT IF L=DUMMY FG 07 03377
004426 004615 R
004427 005024 A 3378 TBX SAVE BASE POINTER IN X 07 03378
004430 005312 A 3379 DECR 012 BIASED DST COUNT TO B 07 03379
004431 010355 A 3380 LDA V$DSTB A = BASE OF DST TABLES 07 03380
004432 160464 A 3381 MJL THREE B = DST ADDRESS 07 03381
004433 005041 A 3382 TXA A = BASE REGISTER 07 03382
004434 005024 A 3383 TBX POINT X AT DST 07 03383
004435 005012 A 3384 TAB RESTORE BASE REGISTER B 07 03384
3385 ***** 07 03385
3386 * TEST IF L ASSIGNED TO RMD * 07 03386
3387 ***** 07 03387
004436 015002 A 3388 LDA 2,X 07 03388
004437 004346 A 3389 LSRA 6 07 03389
004440 150473 A 3390 ANA BM37 07 03390
004441 001010 A 3391 JAZ *+3 V2 07 03391
004442 004444 R
004443 010421 A 3392 LDA RMS SET RMD FLAG V2 07 03392
004444 116154 A 3393 DRA RWFL,B V2 07 03393
004445 056154 A 3394 STA RWFL,B V2 07 03394
004446 006406 A 3395 BT ASET+IN,PRU50 EXIT ON OPEN CALL FG 07 03395
004447 004615 R
004450 006400 A 3396 BT ASET+RM,PRU30 V2 07 03396
004451 004525 R
3397 ***** 07 03397
3398 * L NOT RMD * 07 03398
3399 ***** 07 03399
3400 TZAB FRMT,PRU15 FORMATTED I/O ? V2 07 03400
004452 016063 A
004453 001010 A
004454 004456 R
004455 015001 A 3401 PRU15 LDA 1,X YES. GET 1ST TWO CHARS OF NAMR V2 07 03401
3402 EQU * V2 07 03402
004456 076032 A 3403 STX SAVE,B SAVE DST ADDR E.1 07 03403
3404 IFF NUC FG 07 03404
3405 GOTO NV2NUC FG 07 03405
3406 IFT VII FG 07 03406
3407 DMC MAP,V$STO SET EXEC STATE TO 00 V2 07 03407
3408 NV2NUC CONT V2 07 03408
004457 034151 A 3409 LDX PRU15B POINT X AT DEVICE TABLE FG 07 03409
3410 ***** 07 03410
3411 * LOOP TO IDENTIFY DEVICE * 07 03411
3412 ***** 07 03412
004460 005144 A 3413 PRU15 TXR BUMP TABLE POINTER 07 03413
004461 145000 A 3414 SUB 0,X V2 07 03414
004462 001010 A 3415 JAZ PRU20 EXIT ON MATCH V2 07 03415

```







```

004561 005702 R
004562 010422 A 3494 LDA TWO L = SI 07 03494
004563 006110 A 3495 DRAI 01400 MERGE IOLINK SKELETON CONTROL WORD V2 07 03495
004564 001400 A
004565 056105 A 3496 STA IOLNK,B IOLINK CONTROL WORD FOR SIFCB 07 03496
004566 006010 A 3497 LDAI 40 V2 07 03497
004567 000050 A
004570 056143 A 3498 STA PBSZ,B ALSO PHYSICAL BUFFER SIZE 07 03498
004571 056122 A 3499 STA LRSZ,B ALSO LOGICAL BUFFER SIZE 07 03499
004572 036010 A 3500 LDX ADFCB,B POINT X AT V$FORTIO DATA BLOCK 07 03500
004573 055000 A 3501 STA 0,X SET RECORD SIZE DCB(0) = 40 WORDS 07 03501
004574 006030 A 3502 LDXI SIFCB POINT X AS SI GLOBAL FCB V2 07 03502
004575 000000 E
004576 015005 A 3503 LDA 5,X 07 03503
004577 001010 A 3504 JAZ TR4 ERROR 4/ RMD NOT OPEN / 07 03504
004600 005702 R
004601 005041 A 3505 PRU40 TXA GET FCB ADDRESS IN A 07 03505
004602 056010 A 3506 STA ADFCB,B STORE 07 03506
004603 036016 A 3507 LDX ANRB,B POINT X AT V$FORTIO 07 03507
004604 055010 A 3508 STA ADFCB,X STORE IN V$FORTIO 07 03508
004605 016105 A 3509 MOVBA IOLNK,IOLNK MOVE IOLINK CONTROL WORD TO V$FORTIO 07 03509
004606 055105 A
004607 016154 A 3510 LDA RWFL,B V2 07 03510
004610 110430 A 3511 DRA GFS SET GLOBAL FCB FLAG V2 07 03511
004611 056154 A 3512 STA RWFL,B V2 07 03512
004612 010420 A 3513 LDA CXC V2 07 03513
004613 006505 A 3514 JSR PSJ,X V2 07 03514
004614 005042 R
3515 PRU50 POPJ EXIT FG 07 03515
004615 001000 A
004616 004110 R
3516 *****
3517 * GLOBAL FCB POINTERS *
3518 *****
004617 004575 E 3519 PRUASI PZE SIFCB SIC(2) GLOBAL FCB 07 03519
004620 000000 A 3520 DATA 0 SOC(3) NO GLOBAL FCB 07 03520
004621 000000 E 3521 PZE PIFCB PIC(4) GLOBAL FCB 07 03521
004622 000000 E 3522 PZE LDFCB LOC(5) GLOBAL FCB 07 03522
004623 000000 E 3523 PZE BIFCB BIC(6) GLOBAL FCB 07 03523
004624 000000 E 3524 PZE BDFCB BOC(7) GLOBAL FCB 07 03524
004625 000000 E 3525 PZE SSFCB SSC(8) GLOBAL FCB 07 03525
004626 000000 E 3526 PZE GDFCB GOC(9) GLOBAL FCB 07 03526
004627 000000 E 3527 PZE PDFCB POC(10) GLOBAL FCB 07 03527
004630 004630 R 3528 PRUGT PZE * 07 03528
3529 *****
3530 * DEVICE TABLE *
3531 *****
004631 004631 R 3532 PRUDTB PZE * 07 03532
004632 141720 A 3533 DATA 'CP' 1ST 2 CHARS OF DEVICE NAME 07 03533
004633 000002 A 3534 DATA 2 'CR' V2 07 03534
004634 000002 A 3535 DATA 2 'CT' V2 07 03535
004635 004374 A 3536 DATA 04374 'LP' V2 07 03536
004636 003400 A 3537 DATA 03400 :SP: E.1 07 03537
004637 000411 A 3538 DATA 0411 :TY: E.1 07 03538
004640 077777 A 3539 DATA 077777 TABLE END MARKER V2 07 03539
004641 000050 A 3540 PRUDTE EQU *-1 07 03540
004642 000050 A 3541 DATA 40 CONSOLE FLAG/BUFFER SIZE 07 03541
004643 000450 A 3542 DATA 40 07 03542
004644 000102 A 3543 DATA 40+BFA V2 07 03543
004645 177777 A 3544 DATA 66 07 03544
004646 000450 A 3545 DATA -1 SPOOL UNIT INDICATOR E.1 07 03545
004647 000074 A 3546 DATA 40+BFA V2 07 03546
3547 DATA 60 07 03547
3548 FUJEC 07 03548
3549 *****
3550 *
3551 * P R O C E S S R E A D / W R I T E ( P R W ) *
3552 *
3553 * FUNCTION: TO PROCESS THE FORTRAN STATEMENTS:
3554 *
3555 * READ(U)
3556 * READ(U,F)
3557 * WRITE(U)
3558 * WRITE(U,F)
3559 *
3560 *
3561 * ENTRY: DIRECT FROM RBE
3562 * RETURN = ADDRESS OF PARAMETER LIST
3563 * RETURN(5) = 0 IF UNFORMATTED
3564 * UNIT = FORTRAN UNIT NUMBER U
3565 * TEMP = DP = CRD READ V2* 07 03565
3566 * CWR WRITE V2* 07 03566
3567 *
3568 * EXIT : READ : 1ST RECORD READ
3569 * WRITE: BUFFER CLEARED
3570 * FRMT = ADDRESS OF FORMAT STRING
3571 * 0 IF UNFORMATTED
3572 * XFFL = 1 PARAMETER XFER ENABLED
3573 * ITEMWC = 0 = COUNT OF WORDS REMAINING IN LIST ITEM
3574 * UNFORMATTED: DIRECT TO *IO
3575 * FORMATTED : DIRECT TO PRS TO START FORMAT SCAN
3576 * IOCONT = IOC CONTROL WORD * 07 03576

```







```

3634      MOVAB  LRSZ,LRWC      UPDATE LRWC FOR SHORT RECORD      V2  07 03634
004761 016122 A
004762 056123 A
004763 046172 A 3635      INR      XFFL,B      ENABLE PARAMETER XFER      07 03635
3636      TZAB   FRMT,UID      PROCESS UNFORMATTED I/O IF FRMT=0      07 03636
004764 016063 A
004765 001010 A
004766 006505 R
004767 001000 A 3637      JMP      FRS      EXIT TO FORMAT SCAN IF FORMATTED      07 03637
004770 000442 R
3638      EJEC
3639 *****
3640 *
3641 *      P R O C E S S   D I R E C T   A C C E S S   ( P R X )
3642 *
3643 *****
004771 016164 A 3645 PRX   LDA      TEMP,B
001772 006140 A 3646      SUBI   CRA
004773 000022 A
004774 004250 A 3647      LRLA   S      POSITION READ/WRITE FLAG      07 03647
004775 056104 A 3648      STA   IDCONT,B
004776 001010 A 3649      JAZ   *+3
004777 005001 R
005000 010432 A 3650      LDA   WRS
005001 110431 A 3651      GRA   BBS
005002 110434 A 3652      ORA   BS11      SET DIRECT ACCESS FLAG      07 03652
005003 056154 A 3653      STA   RWFL,B
005004 016164 A 3654      LDA   TEMP,B
005005 140424 A 3655      SUB   EIGHT
005006 056164 A 3656      STA   TEMP,B      SET TO READ/WRITE      07 03656
005007 001000 A 3657      JMP   PRW05
005010 004661 R
3658      EJEC
3659 *****
3660 *
3661 *      P O S T   B U F F E R   ( P S B )
3662 *
3663 * FUNCTION: TO WRITE OUT BUFFER TO RMD
3664 *
3665 * ENTRY: ADFCB = FCB ADDRESS
3666 *         FCB(13) = PHYSICAL RECORD NUMBER CORRESPONDING TO BUFFER
3667 *
3668 * EXIT : BUFFER WRITTEN OUT TO RMD
3669 *         RWFL(BIT 1) = FCB(12)(BIT 14) = 0 = POST BITS
3670 *
3671 *****
005011 016154 A 3673 PSB   LDA   RWFL,B
005012 150443 A 3674      ANA   PDR      CLEAR POST BIT IN FLAG WORD      V2  07 03674
005013 056154 A 3675      STA   RWFL,B
005014 036010 A 3676      LDX   ADFCB,B
005015 015014 A 3677      LDA   12,X
005016 150457 A 3678      ANA   FDR      CLEAR POST BIT IN FCB(12)      V2  07 03678
005017 055014 A 3679      STA   12,X
3680      MOVXAX 13,X      LOAD PHYSICAL RECORD NUMBER INTO FCB(3)      07 03680
005020 015015 A
005021 055003 A
005022 036016 A 3681      LDX   ANRB,B      POINT X AT V$FORTIO DATA BLOCK      07 03681
005023 015104 A 3682      LDA   IDCONT,X
005024 110431 A 3683      ORA   BBS      SET WRITE BIT IN V$IOC CONTROL WORD      07 03683
005025 055104 A 3684      STA   IDCONT,X
005026 010464 A 3685      LDA   CID
005027 006505 A 3686      JSR   PSJ,X      PUSH I/O OP      V2  07 03686
005030 005042 R
3687      TSAB   RWFL,WR,PSBX      EXIT ON WRITE      FG  07 03687
005031 016154 A
005032 006411 A
005033 005040 R
005034 036016 A 3688      LDX   ANRB,B      POINT X AT V$FORTIO DATA BLOCK      07 03688
005035 015104 A 3689      LDA   IDCONT,X
005036 150451 A 3690      ANA   BBS      CLEAR WRITE BIT IN V$IOC CONTROL WORD      07 03690
005037 055104 A 3691      STA   IDCONT,X
3692 PSBX  POPJ
3693      EJEC
3694 *****
3695 *
3696 *      P U S H / J U M P   ( P S J )
3697 *
3698 * FUNCTION: TO STACK RETURN ADDRESSES AND OPS, AND EXIT TO CALLED
3699 *         ROUTINE
3700 *
3701 * ENTRY: X = RETURN ADDRESS
3702 *         A = CALL ADDRESS OR OP
3703 *
3704 *         .GE. 0100 ADDRESS(WITHIN REENTRANT RUN-TIME)
3705 *         .LT. 0100 OP
3706 *
3707 * EXIT : RETURN STACKED
3708 *         A = ADDRESS: DIRECT JUMP TO (A)
3709 *         A = OP: STACK ORB OP, THEN CALLED OP, THEN EXIT TO V$FORTIO
3710 *
3711 *****

```







E.2 VORTEX LISTING

V\$RERS

PROGRAM PAGE

54

LISTING PAGE ( 766 )

```

005123 001046 A 3788      JXNZ      *+3      2-WORD INTEGER/LOGICAL ?      V2 07 03788
005124 005126 R          INR      ITMINC,B    YES. SET INCREMENT TO 2      V2 07 03789
005125 046115 A 3789      LDA      FRMT,B    ALL MODES OK FOR UNFORMATTED V2 07 03790
005126 016063 A 3790      JAZ      PXF10
005127 001010 A 3791      LDA      FDLKEY,B  I FORMAT DESCRIPTOR ?      07 03792
005128 005144 R          SUB      FOUR
005129 016061 A 3792      JANZ     PXF10
005130 140423 A 3793
005131 001016 A 3794      LDA      ITMODE,B  YES
005132 005144 R          SUB      TWO
005133 016116 A 3795      JANZ     PXF10      INTEGER ITEM
005134 140422 A 3796
005135 001004 A 3797      SUB      THREE
005136 005144 R          JANZ     ER2      ERR 2/NON-INTEG. ITEM/
005137 140464 A 3798      LDX      RETURN,B  POINT X AT CALL SEQUENCE
005138 001016 A 3799      MOVXAB  4,ITEMWC   SAVE LIST ITEM WORD COUNT
005139 005704 R          3800 PXF10
005140 036151 A 3801      MOVXAB  5,ITEMAD   SAVE LIST ITEM ADDRESS
005141 015004 A          3802
005142 056114 A          3803      IFF      NUC
005143 015005 A          3804      GOTO     NUC1
005144 056113 A          3805      IFT      VII
005145 015005 A          3806      GOTO     VIII1
005146 056113 A          3807      TZAB    ALDC,PXF20  EXIT IF NOT VORTEX BKGND CALLING NUC
005147 015005 A          3808      LDA      ITEMAD,B  TEST START OF ITEM ADDRESS
005148 056113 A          3809      JSR      TBK,X
005149 015005 A          3810      ADD      ITEMWC,B
005150 056113 A          3811      DAR
005151 015005 A          3812      JSR      TBK,X      TEST END OF ITEM ADDRESS
005152 056113 A          3813      VIII1   CONT
005153 015005 A          3814      NUC1    CONT
005154 056113 A          3815      PXF20  POPJ      EXIT
005155 001000 A          3816 *****
005156 004110 R          3817 * TABLE OF ITEM SIZES IN WORDS *
005157 000001 A          3818 *****
005158 000001 A          3819 PXFSZT DATA 1 1-WORD INTEGER/LOGICAL
005159 000002 A          3820 DATA 1 2-WORD INTEGER/LOGICAL
005160 000004 A          3821 DATA 2 REAL
005161 000002 A          3822 DATA 4 DOUBLE PRECISION
005162 000002 A          3823 DATA 2 COMPLEX
005163 000002 A          3824 DATA 2 DOUBLE PRECISION INTEGER
005164 000002 A          3825 EJEC
005165 000001 A          3826 *****
005166 000001 A          3827 *
005167 000002 A          3828 * REENTRANT BLOCK ENTRY (RBE)
005168 000004 A          3829 *
005169 000002 A          3830 * FUNCTION: TO PROVIDE AN ENTRY INTO MODULE V$RERR
005170 000002 A          3831 *
005171 000002 A          3832 * ENTRY: B = V$FORTIO DATA BLOCK ADDRESS
005172 000002 A          3833 * INFL .NE. 0 ON INITIAL ENTRY
005173 000002 A          3834 * .EQ. 0 ON CONTINUATION ENTRY
005174 000002 A          3835 * TO LABEL V$RERR VIA ALOC IF:
005175 000002 A          3836 *
005176 000002 A          3837 * VORTEX: BACKGROUND CALLING NUCLEUS V$RERR
005177 000002 A          3838 * VORTEX II: ANYBODY CALLING NUCLEUS V$RERR
005178 000002 A          3839 *
005179 000002 A          3840 * TO LABEL V$RERR1 VIA DIRECT JUMP OTHERWISE
005180 000002 A          3841 *
005181 000002 A          3842 * EXIT : TO POPJ IF TOP OP IS .GE. 0100(ADDRESS OPERAND)
005182 000002 A          3843 * TO OP PROCESSOR OTHERWISE
005183 000002 A          3844 * ALOC = 1 IF ENTRY THRU V$RERR
005184 000002 A          3845 * 0 IF ENTRY THRU V$RERR1
005185 000002 A          3846 * INFL = 0
005186 000002 A          3847 *
005187 000002 A          3848 * ERRORS: ER4 IF ILLEGAL OP CODE
005188 000002 A          3849 *
005189 000002 A          3850 *****
005190 000002 A          3851 *****
005191 000002 A          3852 * REENTRANT MODULE CALLED BY ALOC *
005192 000002 A          3853 *****
005193 000002 A          3854 *****
005194 000005 A          3855 V$RERR EQU * ALOC ENTRY
005195 000005 A          3856 IFF NUC
005196 000005 A          3857 GOTO NUC1
005197 000005 A          3858 DATA 5
005198 000005 A          3859 IFF VII
005199 000005 A          3860 GOTO VIII1
005200 000005 A          3861 CXCE 0500+MAP
005201 000005 A          3862 BME MAP,V$ST3 SET EXEC STATE TO NH
005202 000005 A          3863 LDA INFL,B
005203 000005 A          3864 JANZ RBE1
005204 000005 A          3865 *****
005205 000005 A          3866 *****

```



		3867	* VORTEX II CONTINUATION *			V2	07	03867
		3868	*****			V2	07	03868
		3869	LDA VSCPL			V2	07	03869
		3870	JANZ RBE4	TEST IF BACKGROUND		V2	07	03870
		3871	*****	*****		V2	07	03871
		3872	* RESTORE STACK ADDRESSES FROM VORERR TO VSFORTID *			V2	07	03872
		3873	*****	*****		V2	07	03873
		3874	LDA ANRB,B			V2	07	03874
		3875	OME MAP,V\$ST1	SET EXEC STATE TO ON		V2	07	03875
		3876	ADDI OPSTK+STKSZ-1			FG	07	03876
		3877	LDXI BASE	POINT X AT VORERR STACK BASE		V2	07	03877
		3878	SUB RUPSTP,X			FG	07	03878
		3879	TAB	POINT B AT VSFORTID STACK		V2	07	03879
		3880	LDA RUPSTP,X	GET COUNT		FG	07	03880
		3881	JAN RBEX	EXIT IF NO MOVE		V2	07	03881
		3882	CPA			FG	07	03882
		3883	INCR 014	SET X = -(COUNT-1)		FG	07	03883
		3884	RBE1 LDAE BASE+STKSZ-1,X			FG	07	03884
		3885	STA 0,B			V2	07	03885
		3886	JXZ RBEX	EXIT WHEN DONE		V2	07	03886
		3887	IBR	BUMP POINTERS		FG	07	03887
		3888	IXR			FG	07	03888
		3889	JMP RBE1			V2	07	03889
		3890	RBEX LDX VSCRS			V2	07	03890
		3891	LDB BR,X	RESTORE B		V2	07	03891
		3892	OME MAP,V\$ST3	SET EXEC STATE TO NN		V2	07	03892
		3893	VIII1 CDNT			FG	07	03893
		3894	*****	*****				
		3895	* INITIALIZE *			V2	07	03895
		3896	*****	*****		V2	07	03896
005174	R	3897	RBE1 EQU *			V2	07	03897
		3898	IFT VII			FG	07	03898
		3899	ZPB IMPL	CLEAR INITIAL ENTRY FLAG		V2*	07	03899
		3900	IFT VII			FG	07	03900
005174	006030	A	3901	GDTD VIII1		FG	07	03901
005175	006727	R	3902	LDXI BASE	POINT X AT VORERR DATA BLOCK	V2	07	03902
005176	065016	A	3903	STB ANRB,X	SAVE ADDRESS OF NON-REENTRANT BLOCK			
			3904	ZAX ERN	CLEAR ERROR COUNTER			
005177	005001	A						
005200	055060	A						
		3905	*****	*****				
		3906	* TEST VSFORTID STACK EMPTY *					
		3907	*****	*****				
005201	016000	A	3908	LDA OPSTK,B				
005202	146017	A	3909	SUB ADPSTK,B				
005203	001016	A	3910	JANZ RBES				
005204	005214	R						
		3911	*****	*****				
		3912	* VSFORTID STACK EMPTY - RESUME EXECUTION FROM VORERR STACK *					
		3913	*****	*****				
005205	015000	A	3914	LDA OPSTK,X				
005206	145017	A	3915	SUB ADPSTK,X				
005207	001010	A	3916	JANZ RBE90	ERROR/ VORERR STACK EMPTY /			
005210	005366	R						
005211	005042	A	3917	TXB	LOAD BASE REGISTER B			
			3918	POPJ	RESUME EXECUTION FROM VORERR STACK	FG	07	03918
005212	001000	A						
005213	004110	R						
		3919	*****	*****				
		3920	* VSFORTID STACK HAS OP - TEST VALIDITY *					
		3921	*****	*****				
005214	036000	A	3922	RBE5 LDX OPSTK,B				
005215	015000	A	3923	LDA 0,X	GET OP			
005216	006140	A	3924	SUBI 10		PD	07	03924
005217	000015	A						
005220	001004	A	3925	JAN RBE90	ERROR/ ILLEGAL OP /			
005221	005366	R						
005222	006140	A	3926	SUBI 11		V2	07	03926
005223	000013	A						
005224	001002	A	3927	JAP RBE90	ERROR/ ILLEGAL OP /			
005225	005366	R						
005226	120425	A	3928	ADD I10	RESTORE OP			
005227	034160	A	3929	LDX RBE8	POINT X AT VORERR DATA BLOCK			
005230	055164	A	3930	STA TEMP,X	SAVE OP			
005231	140466	A	3931	SUB OXF		V2	07	03931
005232	001010	A	3932	JANZ RBE10	PARAMETER XFER ?			
005233	005236	R						
005234	015017	A	3933	LDA ADPSTK,X	NO. INITIALIZE VORERR STACK			
005235	001006	A	3934	DATA 01006	SKIP			
005236	015000	A	3935	RBE10 LDA OPSTK,X				
005237	005311	A	3936	DAR	PUSH VORERR STACK	FG	07	03936
005240	055000	A	3937	STB OPSTK,X				
005241	005014	A	3938	TAX				
005242	024145	A	3939	LDB RDE8	POINT B AT VORERR DATA BLOCK			
005243	016164	A	3940	LDA TEMP,B	RELOAD OP			
005244	055000	A	3941	STA 0,X	PUSH OP ONTO VORERR STACK			
005245	026016	A	3942	LDB ANRB,B	POINT B AT VSFORTID DATA BLOCK			
005246	034141	A	3943	LDX RBE8	POINT X AT VORERR DATA BLOCK			
		3945	*****	*****				
		3946	* MOVE ADDRESSES FROM NON-REENTRANT MODULE TO REENTRANT *					
		3947	*****	*****				
005247	016151	A	3949	LDA RETURN,B				



E.2 VORTEX LISTING

V\$RERS

PROGRAM PAGE

56

LISTING PAGE ( 768)

005250	055151	A	3950	STA	RETURN,X	MOVE CALL SEQ ADDRESS	07	03950
005251	006505	R	3951	JSR	TBK,X	TEST RETURN ADDRESS IN BACKGROUND	07	03951
005252	006262	R						
005253	120471	A	3952	ADD	TEN		07	03952
005254	006505	A	3953	JSR	TBK,X	TEST PARAMETER LIST IN BACKGROUND	07	03953
005255	006262	R						
005256	005021	A	3954	TBA			07	03954
005257	006505	A	3955	JSR	TBK,X	TEST 1ST WORD OF DATA BLOCK IN BACKGRND	07	03955
005260	006262	R						
005261	006120	A	3956	ADDI	YYY-1		V2	07 03956
005262	000176	A						
005263	006505	A	3957	JSR	TBK,X	TEST LAST WORD OF DATA BLOCK IN BACKGRND	07	03957
005264	006262	R						
005265	034122	A	3958	LDX	RREB		07	03958
005266	016015	A	3959	LDA	ANPDJ,B		07	03959
005267	055015	A	3960	STA	ANPDJ,X	MOVE NON-REENTRANT POP/JUMP ADDRESS	07	03960
005270	006505	A	3961	JSR	TBK,X	TEST NON-REENTRANT POP/JUMP IN BACKGROUND	07	03961
005271	006262	R						
005272	034115	A	3962	LDX	RREB	POINT X AT REENTRANT BLOCK	07	03962
005273	016000	A	3963	LDA	DPSTKP,B		07	03963
005274	145016	A	3964	SUB	ANRB,X		07	03964
005275	006140	A	3965	SUBI	VOPSTK-BASE	COMPARE WITH BOTTOM OF STACK	V2	07 03965
005276	000127	A						
005277	001004	A	3966	JAN	RBE90	ERROR/ PROTECTION /	07	03966
005300	005366	R						
005301	006140	A	3967	SUBI	STKSZ		V2	07 03967
005302	000012	A						
005303	001002	A	3968	JAP	RBE90	ERROR/ PROTECTION /	07	03968
005304	005366	R						
005305	046000	A	3969	INR	DPSTKP,B	POP V\$FORTIO STACK	FG	07 03969
005306	024101	A	3970	LDB	RREB	POINT B AT V\$RERR DATA BLOCK	07	03970
005307	016164	A	3971	LDA	TEMP,B	RELOAD OP	07	03971
005310	140466	A	3972	SUB	CMF		V2	07 03972
005311	001016	A	3973	JANZ	RBE4	IS OP PARAMETER XFER ?	V2	07 03973
005312	005316	R						
005313	016172	A	3974	LDA	XFFL,B	YES. GET XFER ENABLE FLAG	07	03974
005314	001010	A	3975	JAZ	RBE90	EXIT IF ILLEGAL OP	07	03975
005315	005366	R						
			3976	VII1	CONT		FG	07 03976
	005316	R	3977	RBE4	EQU	*	V2	07 03977
			3978	IFF	VORTEX-2		V2	07 03978
			3979	OME	MAP,V\$ST3	SET EXEC STATE TO NM	V2	07 03979
005316	103046	A						
005317	000337	A						
005320	005101	A	3980	INCR	1	SET ALDC ENTRY FLAG	V2	07 03980
005321	001006	A	3981	DATA	01006		V2	07 03981
			3982	NUC1	CONT		FG	07 03982
			3983		*****		07	03983
			3984		* REENTRANT MODULE CALLED BY DIRECT JUMP *		07	03984
			3985		*****		07	03985
	005322	R	3986	V\$RER1	EQU	*	07	03986
005322	005001	A	3987	TZA		RESET ALDC ENTRY FLAG	V2	07 03987
005323	056014	A	3988	STA	ALDC,B		V2	07 03988
			3989		*****		07	03989
			3990		* TEST OP *		07	03990
			3991		*****		07	03991
	036000	A	3992	LDX	DPSTKP,B		V2	07 03992
	015000	A	3993	LDX	0,X	GET OP IN A	07	03993
	056104	A	3994	STA	TEMP,B	SAVE	07	03994
	004346	A	3995	LSRA	6		07	03995
	001010	A	3996	JAZ	RBE15	IS OP RETURN ADDRESS ?	FG	07 03996
	005334	R						
			3997	POPJ		YES. RETURN	FG	07 03997
005332	001000	A						
005333	004110	R						
005334	015000	A	3998	RBE15	LDA	0,X	FG	07 03998
005335	005144	A	3999	IXR		RELOAD OP	FG	07 03999
005336	076000	A	4000	STX	DPSTKP,B	POP STACK	07	04000
005337	140465	A	4001	SUB	CTR		V2	07 04001
005340	001004	A	4002	JAN	ER4	ERROR 4/ILLEGAL OP/	07	04002
005341	005702	R						
005342	001010	A	4003	JAZ	RBE25	NO UNIT ASSOCIATED WITH TERMINATE CALL	07	04003
005343	005357	R						
005344	005311	A	4004	DAR			V2	07 04004
005345	001010	A	4005	JAZ	RBE30	NO UNIT ASSOCIATED WITH PARAM XFER CALL	07	04005
005346	005361	R						
005347	006140	A	4006	SUBI	RBEJTE-RBEJT-1		V2	07 04006
005350	000016	A						
005351	001002	A	4007	JAP	ER4	ERROR 4/ILLEGAL OP/	07	04007
005352	005702	R						
005353	036151	A	4008	LDX	RETURN,B		07	04008
005354	035004	A	4009	LDX	0,X	POINT X AT FORTRAN UNIT NUMBER	07	04009
005355	015000	A	4010	LDA	0,X	GET FORTRAN UNIT NUMBER	07	04010
005356	056167	A	4011	STA	UNIT,B	STORE	07	04011
005357	005001	A	4012	RBE25	TZA		07	04012
005360	056172	A	4013	STA	XFFL,B	DISABLE PARAMETER XFER	07	04013
005361	036164	A	4014	RBE30	LDX	TEMP,B	V2	07 04014
			4015	IFF	NUC	LOAD OP AS JUMP TABLE INDEX	FG	07 04015
			4016	GOTO	NV2NUC		FG	07 04016
			4017	IFT	VII		FG	07 04017
			4018	OME	MAP,V\$ST0	SET EXEC STATE TO 00	V2	07 04018
			4019	NV2NUC	CONT		FG	07 04019
005362	006035	A	4020	LDXE	RBEJT-CTRV,X	GET PROCESSOR ADDRESS	V2	07 04020
005363	005364	R						



```

4021      IFF      HUC
4022      GOTO     NV2NUC
4023      IFT      VII
4024      GME      MAP,V$ST3      SET EXEC STATE TO NN
4025 NV2NUC  CONT
4026      IJMP     0,X      EXIT TO PROCESSOR
005364 006705 A 4027 *****
005365 000000 A 4028 * PROTECTION ERROR *
4029 *****
4030      IFF      HUC
4031      GOTO     NUC1
4032      IFT      VII
4033      GOTO     VII1
005366 005001 A 4034 RBE90  TZA
005367 001000 A 4035      JMP      TBK      FORCE TBK ERROR
005370 006262 R
4036 VII1  CONT
4037 NUC1  CONT
4038 *****
4039 * EXIT JUMP TABLE *
4040 *****
005371 006413 R 4041 RBEJT  PZE      TRM      TERMINATE
005372 005101 R 4042      PZE      PNF      PARAMETER XFER
005373 003356 R 4043      PZE      PAX      BACKSPACE
005374 003356 R 4044      PZE      PAY      WRITE EOF
005375 003356 R 4045      PZE      PAX      REWIND
005376 004650 R 4046      PZE      PRW      READ
005377 004650 R 4047      PZE      PRW      WRITE
005400 000202 R 4048      PZE      CLS      CLOSE RMD FILE
005401 000202 R 4049      PZE      CLS      CLOSE RMD FILE
005402 003161 R 4050      PZE      OPN      OPEN RMD FILE
005403 003161 R 4051      PZE      OPN      OPEN RMD FILE
005404 004115 R 4052      PZE      PRD      DECODE
005405 004115 R 4053      PZE      PRD      ENCODE
005406 004771 R 4054      PZE      PRX      READ - DIRECT ACCESS
005407 004771 R 4055      PZE      PRX      WRITE - DIRECT ACCESS
005410 005410 R 4056 RBEJTE EQU      *
4057      IFT      VII
4058      GOTO     VII1
4059      IFF      HUC
4060      GOTO     NUC1
005410 006727 R 4061 RBEB  DATA  BASE
4062 NUC1  CONT
4063 VII1  CONT
4064      EJCC
4065 *****
4066 *
4067 *      R E P E A T   C H A R A C T E R   I / O   ( R C H )
4068 *
4069 * FUNCTION: TO REPEAT A CHARACTER I/O OPERATION N TIMES
4070 *
4071 * ENTRY: COUNT = N
4072 *      RCHAR = CHARACTER TO BE OUTPUT
4073 *
4074 * EXIT : NO SPECIAL CONDITIONS
4075 *
4076 *****
005411 016052 A 4078 RCH  LDA      COUNT,B
005412 005311 A 4079      BAR      DECREMENT COUNT
005413 001002 A 4080      JAP      RCH2
005414 005417 R
4081      POPJ
4082 RCH2  STA      COUNT,B
005415 001000 A 4083      LDA      ASCE,B
005416 004110 R 4084      SUB      ASCE,B
005417 056052 A 4085      ROP
005420 016021 A 4086      XAZ      SET OVFL IF BUFFER SOB
005421 146002 A
005422 007400 A
005423 003010 A
005424 001757 R 4087      TSOB  OVFL,HR,RCH10
005425 016154 A
005426 006411 A
005427 005446 R
4088 *****
4089 * INPUT *
4090 *****
005430 001001 A 4091      JOP      RCH5
005431 005440 R
4092 *****
4093 * INPUTTING FROM NON-BUFFER *
4094 *****
005432 006010 A 4095      PUSHJ  JCC      INPUT CHARACTER
005433 001754 R
005434 006505 A
005435 005042 R
005436 001000 A 4096      JMP      RCH      LOOP TILL DONE
005437 005411 R
4097 *****
4098 * INPUTTING FROM BUFFER *
4099 *****

```



```

4100 RCH5  PUSHJ  CBC          INPUT CHARACTER FROM BUFFER          V2  07 04100
005440 006010 A
005441 000115 R
005442 006505 A
005443 005042 R
005444 001000 A 4101          JMP      RCH          LOOP TILL DONE                      07 04101
005445 005411 R
4102 *****
4103 * OUTPUT *
4104 *****
005446 001001 A 4105 RCH10  JDF      RCH15          V2  07 04105
005447 005456 R
4106 *****
4107 * OUTPUT TO NON-BUFFER *
4108 *****
4109          PUSHJ  PCH          PUT CHARACTER                      V2  07 04109
005450 006010 A
005451 003557 R
005452 006505 A
005453 005042 R
005454 001000 A 4110          JMP      RCH          LOOP TILL DONE                      07 04110
005455 005411 R
4111 *****
4112 * OUTPUT TO BUFFER *
4113 *****
4114 RCH15  PUSHJ  DCP          OUTPUT CHARACTER TO BUFFER          V2  07 04114
005456 006010 A
005457 002646 R
005460 006505 A
005461 005042 R
005462 001000 A 4115          JMP      RCH          LOOP TILL DONE                      07 04115
005463 005411 R
4116          EJEC
4117 *****
4118 *
4119 *          R E C Y C L E   L O G I C A L   B U F F E R ( R C L )
4120 *
4121 * FUNCTION: TO MOVE FORWARD TO NEXT LOGICAL RECORD
4122 *
4123 * ENTRY: LRWC = COUNT OF WORDS REMAINING IN LOGICAL RECORD
4124 *
4125 * EXIT : LRWC = LRSZ
4126 *
4127 *****
4129 RCL    TRAB  RWFL,LF,RCL5          LOGICAL FILE ?          V2  07 04129
005464 016154 A
005465 006441 A
005466 005471 R
005467 006400 A 4130          BT      ASET+RM,RCL10  YES. RMD ?          D.1 07 04130
005470 005476 R
4131 RCL5   ZAB   LRWC          NO. FORCE RECYCLE          V2  07 04131
005471 005001 A
005472 056123 A
005473 056144 A 4132          STA   PBWC,B          CLEAR WORD COUNTS
005474 001000 A 4133          JMP   RCL15          D.1 07 04133
005475 005506 R
005476 006444 A 4134 RCL10  BT      ARST+TR,RCL15  TERMINATE LOGICAL RMD ?          D.1 07 04134
005477 005506 R
4135          TNZAB  LRWC,RCL15  YES. END OF LOGICAL RECORD ?          D.1 07 04135
005500 016123 A
005501 001016 A
005502 005506 R
005503 046121 A 4136          INR   LRECND,B          YES. BUMP LOGICAL RECORD NUMBER          D.1 07 04136
4137          POPJ
4138 RCL15  PUSHJ  GBA          STEP THRU LOGICAL BUFFER          D.1 07 04138
005506 006010 A
005507 001173 R
005510 006505 A
005511 005042 R
005512 016123 A 4139          LDA   LRWC,B          07 04139
005513 005111 A 4140          IAR
005514 146122 A 4141          SUB   LRSZ,B          07 04140
005515 001004 A 4142          JAN   RCL          LOOP TILL LOGICAL BOUNDARY PASSED          D.1 07 04142
005516 005464 R
005517 046123 A 4143          INR   LRWC,B          RESTORE WORD COUNTS          07 04143
005520 046144 A 4144          INR   PBWC,B          07 04144
4145          DAB   BAWPT          AND BUFFER POINTER          07 04145
005521 016025 A
005522 005311 A
005523 056025 A 4146          POPJ          EXIT          FG 07 04146
005524 001000 A
005525 004110 R
4147          EJEC
4148 *****
4149 *
4150 *          R E C Y C L E   P H Y S I C A L   B U F F E R ( R C P )
4151 *
4152 * FUNCTION: TO RECYCLE A PHYSICAL BUFFER
4153 *
4154 * ENTRY: PBSZ = PHYSICAL BUFFER SIZE IN WORDS
07 04147
07 04148
07 04149
07 04150
07 04151
07 04152
07 04153
07 04154

```



```

4155 *          APBF = PHYSICAL BUFFER START ADDRESS          * 07 04155
4156 *          IN = 1 IF INITIALIZING                        V2* 07 04156
4157 *          PD = 1 IF BUFFER MUST BE POSTED              V2* 07 04157
4158 *                                                                 * 07 04158
4159 * EXIT : IN = 1                                          V2* 07 04159
4160 *                                                                 V2* 07 04160
4161 *          BUFFER POSTED IF PD SET                        V2* 07 04161
4162 *          I/O SUPPRESSED                                 V2* 07 04162
4163 *                                                                 V2* 07 04163
4164 *          IN = 0                                          V2* 07 04164
4165 *                                                                 V2* 07 04165
4166 *          PBWC = PBSZ                                     V2* 07 04166
4167 *          BUFFER CLEARED BEFORE NON-RMD READ           V2* 07 04167
4168 *                                                                 * 07 04168
4169 *****
005526 R 4171 RCP EQU *                                     V2 07 04171
4172 TRAB RWFL,IN,RCP5 INITIALIZING ?                       V2 07 04172
005526 016154 A
005527 006446 A
005530 005544 R
005531 006442 A 4173 BT ARST+PD,RCP3 YES. ANY UNPOSTED DATA ? 07 04173
005532 005540 R 4174 PUSHJ PSB YES. POST BUFFER V2 07 04174
005533 006010 A
005534 005011 R
005535 006505 A
005536 005042 R
005537 016154 A 4175 LDA RWFL,B RESTORE FLAG WORD 07 04175
005540 006451 A 4176 RCP3 BT ARST+WR,RCP15 READ ? V2 07 04176
005541 005570 R
005542 001000 A 4177 JMP RCP25 NO. WRITE 07 04177
005543 005617 R 4178 RCP5 MOVAB PBSZ,PBWC RELOAD PHYSICAL WORD COUNT 07 04178
005544 016143 A
005545 056144 A
005546 016027 A 4179 LDA ALBF,B D.1 07 04179
005547 146025 A 4180 SUB ZFWPT,B D.1 07 04180
005550 005311 A 4181 DAB D.1 07 04181
005551 126020 A 4182 ADD APBF,B D.1 07 04182
005552 056027 A 4183 STA ALBF,B UPDATE ADDRESS OF LOGICAL BUFFER D.1 07 04183
4184 DABB APBF,BFWPT INITIALIZE BUFFER POINTER D.1 07 04184
005553 016020 A
005554 005311 A
005555 056025 A 4185 TSAB RWFL,WR,RCP20 READ ? V2 07 04185
005556 016154 A
005557 006411 A
005560 005610 R
005561 006442 A 4186 BT ARST+PD,RCP15 YES. ANY UNPOSTED DATA ? D.1 07 04186
005562 005570 R 4187 PUSHJ PSB YES. POST BUFFER V2 07 04187
005563 006010 A
005564 005011 R
005565 006505 A
005566 005042 R
005567 016154 A 4188 LDA RWFL,B RESTORE FLAG WORD V2 07 04188
4189 ***** V2 07 04189
4190 * CLEAR BUFFER ON NON-RMD READ * V2 07 04190
4191 ***** V2 07 04191
005570 006400 A 4192 RCP15 BT ASET+RM,RCP20 RMD ? V2 07 04192
005571 005610 R 4193 TZAB UNIT,RCP20 NO. DONT CLEAR IF L=0 D.1 07 04193
005572 016167 A
005573 001010 A
005574 005610 R
005575 036010 A 4194 LDX SDFCB,B D.1 07 04194
4195 MOVAB LRWC,SAVE+2 SAVE LRWC 07 04195
005576 016123 A
005577 056034 A 4196 MOVAB 0,LRWC SET LOGICAL WORD COUNT = FCB(0) 07 04196
005600 015000 A
005601 056123 A 4197 PUSHJ CLR CLEAR BUFFER V2 07 04197
005602 006010 A
005603 000145 R
005604 006505 A
005605 005042 R 4198 MOVAB SAVE+2,LRWC RESTORE LRWC 07 04198
005606 016034 A
005607 056123 A
4199 ***** V2 07 04199
4200 * READ/WRITE PHYSICAL RECORD * V2 07 04200
4201 ***** V2 07 04201
4202 RCP20 PUSHJ RPB REFRESH PHYSICAL BUFFER V2 07 04202
005610 006010 A
005611 006105 R
005612 006505 A
005613 005042 R 4203 TRAB RWFL,WR,RCP50 READ ? V2 07 04203
005614 016154 A
005615 006451 A
005616 005674 R
005617 006441 A 4204 RCP25 BT ARST+LF,RCP40 NO. WRITE. LOGICAL FILE ? D.1 07 04204

```



```

005620 005663 R
005621 036010 A 4205 LDX ADFCB,B YES. POINT X AT FCB V2 07 04205
005622 006440 A 4206 BT ARST+RM,RCP40 RMD ? D.1 07 04206
005623 005663 R
005624 110423 A 4207 ORA POS YES. SET POST FLAG D.1 07 04207
005625 056154 A 4208 STA RWFL,B 07 04208
005626 015014 A 4209 LDA 12,X 07 04209
005627 110437 A 4210 ORA FPOS ALSO IN FCB(12) V2 07 04210
005630 055014 A 4211 STA 12,X 07 04211
4212 TRAB RWFL,RB,RCP35 IS READ BEFORE WRITE ENABLED ? 07 04212

005631 016154 A
005632 006443 A
005633 005660 R
005634 036016 A 4213 LDX ANRB,B YES. POINT X AT V$FORTIO DATA BLOCK 07 04213
005635 015104 A 4214 LDA IDCONT,X 07 04214
005636 150451 A 4215 ANA BRB CLEAR WRITE BIT IN V$IDC CONTROL WORD 07 04215
005637 055104 A 4216 STA IDCONT,X 07 04216
4217 PUSHJ RPB READ NEXT PHYSICAL RECORD V2 07 04217

005640 006010 A
005641 006105 R
005642 006505 A
005643 005042 R
4218 SUT33B PRECND,PBRC,PRECND RESTORE PHYSICAL RECORD NUMBER 07 04218

005644 016145 A
005645 146142 A
005646 056145 A
005647 036016 A 4219 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK 07 04219
005650 015106 A 4220 LDA IDSTAT,X GET STATUS OF READ 07 04220
005651 005311 A 4221 JAR 07 04221
005652 001004 A 4222 JAN #+3 TEST FOR EOF 07 04222
005653 005653 R
005654 055106 A 4223 STA IDSTAT,X CLEAR EOF FLAG ON READ BEFORE WRITE 07 04223
005655 015104 A 4224 LDA IDCONT,X 07 04224
005656 110431 A 4225 ORA BRB RESTORE WRITE BIT IN V$IDC CONTROL WORD 07 04225
005657 055104 A 4226 STA IDCONT,X 07 04226
005660 036010 A 4227 RCP35 LDX ADFCB,B 07 04227
4228 MOVBAK PRECND,13 UPDATE FCB(13) 07 04228

005661 016145 A
005662 055015 A
4229 RCP40 TSAB RWFL,IN,RCP50 EXIT ON INITIALIZE D.1 07 04229

005663 016154 A
005664 006406 A
005665 005674 R
005666 006405 A 4230 BT ASET+SC,RCP50 D.1 07 04230
005667 005674 R
4231 PUSHJ CLB CLEAR BUFFER AFTER WRITE D.1 07 04231

005670 006010 A
005671 000145 R
005672 006505 A
005673 005042 R
005674 016154 A 4232 RCP50 LDA RWFL,B D.1 07 04232
005675 150446 A 4233 ANA SCR CLEAR CLEAR SUPPRESS FLAG D.1 07 04233
005676 150447 A 4234 ANA INR CLEAR INITIALIZE FLAG V2 07 04234
005677 056154 A 4235 STA RWFL,B 07 04235
4236 POPJ EXIT FG 07 04236

005700 001000 A
005701 004110 R
4237 EJEC 07 04237
4238 ***** 07 04238
4239 * 07 04239
4240 * REENTRANT ERROR PROCESSOR (RER) * 07 04240
4241 * * 07 04241
4242 * FUNCTION: TO PROCESS ERRORS IN V$RERR V2* 07 04242
4243 * * 07 04243
4244 * ENTRY: ER1 FORMAT * 07 04244
4245 * ER2 MODE * 07 04245
4246 * ER3 DATA * 07 04246
4247 * ER4 I/O ERROR * 07 04247
4248 * * 07 04248
4249 * EXIT : DIRECT TO CAN * 07 04249
4250 * ERN = ERROR NUMBER-1 * 07 04250
4251 * ERROR DP PUSHED V2* 07 04251
4252 * * 07 04252
4253 ***** 07 04253
005702 046060 A 4255 ER4 INR ERN,B I/O 07 04255
005703 046060 A 4256 ER3 INR ERN,B DATA 07 04256
005704 046060 A 4257 ER2 INR ERN,B MODE 07 04257
005705 036016 A 4258 ER1 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK 07 04258
005706 016060 A 4259 LDA ERN,B 07 04259
005707 055060 A 4260 STA ERN,X MOVE ERROR NUMBER 07 04260
005710 010421 A 4261 LDA CER GET ERROR DP 07 04261
4262 PUSHF 07 04262

005711 036016 A
005712 035000 A
005713 005344 A
005714 055000 A
005715 005041 A
005716 036016 A
005717 055000 A
005720 001000 A 4263 JMP CAN EXIT TO V$FORTIO 07 04263
005721 000101 R
4264 EJEC 07 04264
4265 ***** 07 04265

```



```

4266 *
4267 * REPOSITION FILE (RFL)
4268 *
4269 * FUNCTION: TO REPOSITION A FILE AT START OF A READ OR WRITE, OR IF
4270 * A T FORMAT SPECIFIER REQUIRES A PHYSICAL BACKSPACE
4271 *
4272 * ENTRY: ADFCB = ADDRESS OF DCB/FCB
4273 *         APBF = ADDRESS OF PHYSICAL BUFFER
4274 *         ALBF = ADDRESS OF LOGICAL BUFFER
4275 *         PBSZ = PHYSICAL BUFFER SIZE IN WORDS
4276 *         LRSZ = LOGICAL RECORD SIZE IN WORDS
4277 *         PRECND = PHYSICAL RECORD NUMBER
4278 *
4279 * EXIT : READ : 1ST RECORD IN BUFFER
4280 *        WRITE: BUFFER CLEARED
4281 *
4282 *****
4284 RFL  MOVBAB  LRSZ,LRWC  INITIALIZE LOGICAL WORD COUNT          07 04284
005722 016122 A
005723 056123 A
4285          DABB  ALBF,BFWPT  INITIALIZE BUFFER WORD POINTER      V2 07 04285
005724 016027 A
005725 005311 A
005726 056025 A
4286          MOVBAB  PBSZ,PBWC  INITIALIZE PHYSICAL WORD COUNT          07 04286
005727 016143 A
005730 056144 A
4287          TRAB  RWFL,LF,RFL5  LOGICAL FILE ?          V2 07 04287
005731 016154 A
005732 006441 A
005733 005736 R
005734 006400 A
005735 003742 R
4288          BT  ASLT+RM,RFL10  YES. TEST IF RMD          V2 07 04288
4289 *****
4290 * NOT LOGICAL RMD FILE *
4291 *****
005736 006411 A
005737 006023 R
005740 001000 A
005741 005526 R
4292 RFL5  BT  ASLT+WR,RFL40  READ ?          FG 07 04292
4293          JMP  RCP  YES. RECYCLE PHYSICAL BUFFER          07 04293
4294 *****
4295 * LOGICAL RMD FILE *
4296 *****
005742 016020 A
005743 126143 A
005744 146027 A
005745 056144 A
4297 RFL10  LDA  ADFCB,B
4298          ADD  PBSZ,B
4299          SUB  ALBF,B
4300          STA  PBWC,B  INITIALIZE PHYSICAL WORD COUNT          07 04300
4301 *****
4302 * TEST IF LRECND IN BUFFER *
4303 *****
005746 036010 A
005747 015015 A
005750 001010 A
005751 006025 R
005752 146145 A
005753 001010 A
005754 006005 R
005755 001002 R
005756 006025 R
005757 056164 A
005760 126142 A
005761 005311 A
005762 001004 A
005763 006025 R
4304          LDX  ADFCB,B
4305          LDR  IS,X
4306          JAZ  RFL50  TEST IF BUFFER EMPTY          07 04306
4307          SUB  PRECND,B  COMPARE BUFFER ADDRESS WITH PRECND
4308          JAZ  RFL20  LRECND RESIDENT IF EQUAL          07 04308
4309          JAP  RFL50
4310          STA  TEMP,B  SAVE -(RECORD INCREMENT)          07 04310
4311          ADD  PIRC,B
4312          DAB
4313          JAN  RFL50
4314 *****
4315 * LRECND IS RESIDENT *
4316 *****
005764 015015 A
005765 056145 A
005766 005021 A
005767 005001 A
005770 146164 A
005771 004560 A
005772 165201 A
005773 065164 A
005774 005042 A
005775 016027 A
005776 126164 A
005777 056027 A
006000 005311 A
006001 056025 A
006002 016144 A
006003 146164 A
006004 056144 A
4317          MOVXAB  IS,PRECND  UPDATE PHYSICAL RECORD NUMBER          07 04317
4318          TXR  SAVE BASE REGISTER          07 04318
4319          TZR
4320          SUB  TEMP,B  GET RECORD INCREMENT          07 04320
4321          LLR  16
4322          MUL  SD120,X  CONVERT TO WORD INCREMENT          V2 07 04322
4323          STP  TEMP,X
4324          TXR  RESTORE BASE REGISTER B          07 04324
4325          LRA  ALBF,B
4326          ADD  TEMP,B  BUMP LOGICAL BUFFER ADDRESS          07 04326
4327          STA  ALBF,B
4328          DAB
4329          STB  BFWPT,B  ALSO BUFFER WORD POINTER          07 04329
4330          LRA  RWFL,B
4331          SUB  TEMP,B  DECREMENT PHYSICAL WORD COUNT          07 04331
4332          STA  PRECND,B
4333 RFL20  ISR  RWFL,WR,RFL30  READ ?          V2 07 04333
006005 016154 A
006006 006411 A
006007 006015 R
4334          ARBB  PRECND,PIRC,PRECND  YES. BUMP PHYSICAL RECND          V2 07 04334
006010 016145 A
006011 126142 A
006012 056145 A

```



```

006013 001000 A 4335 POPJ AND EXIT FG 07 04335
006014 004110 R
006015 110423 A 4336 RFL30 ORA PDS SET POST FLAG ON WRITE V2 07 04336
006016 056154 A 4337 STA RWFL,B V2 07 04337
006017 036010 A 4338 LDX ADFCB,B POINT X AT FCB V2 07 04338
006020 015014 A 4339 LDA 12,X V2 07 04339
006021 110437 A 4340 ORA FPDS ALSO IN FCB V2 07 04340
006022 055014 A 4341 STA 12,X V2 07 04341
006023 001000 A 4342 RFL40 POPJ AND EXIT FG 07 04342
006024 004110 R
4343 *****
4344 * LRECND NOT IN BUFFER *
4345 *****
006025 016154 A 4346 RFL50 LDA RWFL,B 07 04346
006026 110427 A 4347 ORA INS SET INITIALIZE FLAG V2 07 04347
006027 056154 A 4348 STA RWFL,B 07 04348
006030 001000 A 4349 JMP RCF RECYCLE PHYSICAL BUFFER 07 04349
006031 005526 R
4350 EJEC 07 04350
4351 ***** 07 04351
4352 * 07 04352
4353 * ROUND DECIMAL ARRAY ( RND ) * 07 04353
4354 * 07 04354
4355 * FUNCTION: TO ROUND DECIMAL DIGIT STRING IN ARRAY CHB, PROPAGATING * 07 04355
4356 * CARRIES FORWARD * 07 04356
4357 * 07 04357
4358 * ENTRY: ARRAY CHB CONTAINS BINARY EQUIVALENTS OF DECIMAL DIGITS * 07 04358
4359 * COUNT = ROUND POSITION * 07 04359
4360 * DEXP = DECIMAL EXPONENT * 07 04360
4361 * ACC = BINARY FRACTION REMAINING AFTER 14 DIGITS V2* 07 04361
4362 * 07 04362
4363 * EXIT : DEXP = DEXP+1 ON FIELD OVERFLOW * 07 04363
4364 * 07 04364
4365 ***** 07 04365
006032 006032 R 4367 RNA EQU * 07 04367
006033 016052 A 4368 RND LDA COUNT,B 07 04368
006034 001004 A 4369 JAN RNDX EXIT IF COUNT NEGATIVE FG 07 04369
006035 146200 A 4370 SUB BD14,B V2 07 04370
006036 001004 A 4371 JAN RND5 IS COUNT .GE. 14 ? 07 04371
006037 006051 R
006040 016007 A 4372 LDA ACHB,B YES 07 04372
006041 126200 A 4373 ADD ED14,B V2 07 04373
006042 005314 A 4374 DECR 014 POINT X AT LAST DIGIT 07 04374
006043 016003 A 4375 LDA ACC,B 07 04375
006044 004241 A 4376 LRLA 1 07 04376
006045 001002 A 4377 JAP RNDX EXIT IF NO BUMP FG 07 04377
006046 006103 R
006047 001000 A 4378 JMP RNDL OTHERWISE PROPAGATE CARRY 07 04378
006050 006065 R
006051 016007 A 4379 RND5 LDA ACHB,B 07 04379
006052 126052 A 4380 ADD COUNT,B 07 04380
006053 005314 A 4381 DECR 014 POINT X AT ROUND POSITION-1 07 04381
006054 015001 A 4382 LDA 1,X GET DECIMAL DIGIT 07 04382
006055 140465 A 4383 SUB FIVE 07 04383
006056 001004 A 4384 JAN RNDX EXIT IF NO CARRY FG 07 04384
006057 006103 R
4385 TZAB COUNT,RND10 TEST COUNT=0 07 04385
006060 016052 A
006061 001010 A
006062 006100 R
4386 ZAX 1 CLEAR LAST DIGIT IN CASE OF OVERFLOW 07 04386
006063 005001 A
006064 055001 A
4387 ***** 07 04387
4388 * LOOP TO PROPAGATE CARRIES * 07 04388
4389 ***** 07 04389
006065 045000 A 4390 RNDL INR 0,X BUMP PRECEDING DIGIT 07 04390
006066 015000 A 4391 LDA 0,X 07 04391
006067 140471 A 4392 SUB TEN 07 04392
006070 001004 A 4393 JAN RNDX EXIT IF NO CARRY FG 07 04393
006071 006103 R
006072 005001 A 4394 TZA 07 04394
006073 055000 A 4395 STA 0,X CLEAR DIGIT 07 04395
006074 005345 A 4396 DECR 043 DECREMENT CHB ARRAY POINTER 07 04396
006075 146007 A 4397 SUB ACHB,B 07 04397
006076 001002 A 4398 JAP RNDL IS CARRY PROPAGATED OUT OF CHB ? 07 04398
006077 006065 R
006100 046055 A 4399 RND10 INR DEXP,B YES. BUMP DECIMAL EXPONENT 07 04399
006101 005101 A 4400 INCR 1 07 04400
006102 055001 A 4401 STA 1,X SHIFT CHB RIGHT 1 07 04401
006103 001000 A 4402 RNDX POPJ EXIT FG 07 04402
006104 004110 R
4403 EJEC 07 04403
4404 ***** 07 04404
4405 * 07 04405
4406 * REFRESH PHYSICAL BUFFER ( RFB ) * 07 04406
4407 * 07 04407
4408 * FUNCTION: TO READ OR WRITE A PHYSICAL BUFFER * 07 04408
4409 * 07 04409

```



```

4410 * ENTRY: ADFCB = ADDRESS OF DCB/FCB * 07 04410
4411 * * 07 04411
4412 * LOGICAL FILES ONLY: * 07 04412
4413 * * 07 04413
4414 * PRECND = CURRENT PHYSICAL RECORD NUMBER * 07 04414
4415 * PBRC = COUNT OF 120-WORD RECORDS IN PHYSICAL BUFFER * 07 04415
4416 * * 07 04416
4417 * EXIT : PBWC = PHYSICAL WORD COUNT * 07 04417
4418 * PRECND = PRECND + PBRC * 07 04418
4419 * * 07 04419
4420 ***** * 07 04420
4422 RPB TRAB RWFL,LF,RPB10 TEST IF LOGICAL FILE 07 04422

006105 016154 A
006106 006441 A
006107 006114 R

4423 ***** 07 04423
4424 * LOGICAL FILE - SET UP FCB * 07 04424
4425 ***** 07 04425
006110 036010 A 4426 LDX ADFCB,B POINT X AT FCB 07 04426
4427 MOVBAK PRECND,3 MOVE PHYSICAL RECND TO FCB(3) 07 04427

006111 016145 A
006112 055003 A
006113 055015 A 4428 STA 13,X ALSO FCB(13) 07 04428
4429 ***** 07 04429
4430 * CALL JDC TO DO I/O * 07 04430
4431 ***** 07 04431
006114 010464 A 4432 RPB10 LDA CID CALL V$IDC TO DO I/O V2 07 04432
006115 006505 A 4433 JSR PS1,X V2 07 04433
006116 005042 R 4434 TRAB RWFL,IN,RPB11 INITIALIZING I E.1 07 04434

006117 016154 A
006120 006446 A
006121 006127 R
006122 016020 A 4435 LDA ADFC,B YES E.1 07 04435
006123 126143 A 4436 SUB PBSC,B E.1 07 04436
006124 146027 A 4437 SUB ALDF,B COMPUTE REMAINING PHYSICAL WORD COUNT E.1 07 04437
006125 001000 A 4438 JNP RPB12 E.1 07 04438
006126 006131 R
006127 036016 A 4439 RPB11 LDX ANRP,B NOT INITIALIZING E.1 07 04439
006130 015144 A 4440 LDA PBWC,X XFER I/O WORD COUNT FROM V$PORTIO E.1 07 04440
006131 056144 A 4441 RPB12 STA PBWC,B E.1 07 04441
4442 TRAB RWFL,LF,RPB15 LOGICAL FILE ? V2 07 04442

006132 016154 A
006133 006441 A
006134 006137 R
006135 006400 A 4443 BT ASET+RM,RPB20 YES, RMB ? V2 07 04443
006136 006143 R 4444 RPB15 MOVBAK PBWC,LRSZ NO. UPDATE LOGICAL WORD COUNT V2 07 04444

006137 016144 A
006140 056122 A 4445 POPJ EXIT FG 07 04445

006141 001000 A
006142 004110 R 4446 RPB20 RPB15 PRECND,PBRC,PRECND RMB PHYSICAL RECORD NUMBER 07 04446

006143 016145 A
006144 126142 A
006145 056145 A 4447 POPJ EXIT FG 07 04447

006146 001000 A
006147 004110 R 4448 EJECT 07 04448
4449 ***** 07 04449
4450 * * 07 04450
4451 * SEARCH FOR CHAIN (SCH) * 07 04451
4452 * * 07 04452
4453 * FUNCTION: TO SEARCH AN FCB CHAIN FOR A GIVEN FORTRAN UNIT NUMBER U * 07 04453
4454 * * 07 04454
4455 * ENTRY: UNIT = U * 07 04455
4456 * LNKCNT = COUNT OF FCB'S ON CHAIN V2 07 04456
4457 * EACH CHAIN ITEM XFCB HAS FORMAT: * 07 04457
4458 * XFCB(10) = ADDRESS OF NEXT FCB ON CHAIN * 07 04458
4459 * XFCB(11) = U(XFCB) * 07 04459
4460 * ALOC .MS. 0 IF V$RERR ENTERED BY ALOC V2 07 04460
4461 * * 07 04461
4462 * EXIT : A = ADDRESS OF FCB ARRAY, IF U IN CHAIN * 07 04462
4463 * = 0 IF U NOT ON CHAIN * 07 04463
4464 * PRLINK = ADDRESS OF PREVIOUS CHAIN LINK * 07 04464
4465 * * 07 04465
4466 ***** 07 04466
4467 ***** 07 04467
4468 ***** 07 04468
4469 * INITIALIZE SEARCH LOOP * 07 04469
4470 ***** 07 04470
006150 036016 A 4471 SCH LDX ANRP,B 07 04471
006151 005041 A 4472 TRAB GET DATA BLOCK ADDRESS 07 04472
006152 006120 A 4473 MOVBAK ANRP,10 ADD RIAS V2 07 04473
006153 000037 A
006154 056146 A 4474 STA PRLINK,B POINT PREVIOUS LINK AT CHAIN HEADER 07 04474
006155 015120 A 4475 LDA LNKCNT,X GET LINK COUNT 07 04475
006156 056052 A 4476 STA COUNT,B STORE AS LOOP COUNT 07 04476
006157 035051 A 4477 LDX ANHDR,X POINT X AT HEAD OF CHAIN 07 04477
4478 ***** 07 04478
4479 * SEARCH LOOP * 07 04479
4480 ***** 07 04480

```



```

006160 016052 A 4481 SCHLP LDA COUNT,B
006161 001010 A 4482 JAZ SCHY FLAG NO FIND BY EXIT WITH A=0 FG 07 04481
006162 006211 R 4483 DAB DECREMENT COUNT 07 04482
006163 005311 A 4484 STA COUNT,B
006164 056052 A 4485 IFF NUC 07 04483
4486 GOTO NUC1 FG 07 04484
4487 IFT VII FG 07 04485
4488 GOTO VII1 FG 07 04486
4489 TZAB ALOC,SCH5 VORTEX BKGND CALLING NUCLEUS ? FG 07 04487
006165 016014 A 4490 STX TEMP,B YES. SAVE X 07 04488
006166 001010 A 4491 TXA TEST FCB(0) IN BACKGROUND 07 04489
006167 006200 R 4492 JSR TBK,X TEST FCB(14) IN BACKGROUND 07 04490
006170 076164 A 4493 ADD D15 RESTORE X 07 04491
006171 005041 A 4494 JSR TBK,X TEST FCB(14) IN BACKGROUND 07 04492
006172 006505 A 4495 LDX TEMP,B RESTORE X 07 04493
006173 006262 R 4496 NUC1 CNT FG 07 04494
006174 120472 A 4497 VIII1 CNT FG 07 04495
006175 006505 A 4498 SCH5 LDA 11,X COMPARE WITH U 07 04496
006176 006262 R 4499 SUB UNIT,B EXIT ON FIND WITH X=FCB ADDRESS 07 04497
006177 036164 A 4500 JAZ SCHX 07 04498
006200 015013 A 4501 STX PRLINK,B UPDATE PREVIOUS LINK 07 04499
006201 146167 A 4502 LDX 10,X POINT X AT NEXT LINK 07 04500
006202 001010 A 4503 JMP SCHLP LOOP TILL CHAIN EXHAUSTED 07 04501
006203 006210 R 4504 SCHX TXA FLAG FIND BY A.NE.0 (FCB ADDRESS) 07 04502
006204 076146 A 4505 SCHY POPJ EXIT FG 07 04503
006205 035012 A
006206 001000 A
006207 006160 R
006210 005041 A
006211 001000 A
006212 004110 R
4506 EJEC 07 04506
4507 ***** 07 04507
4508 * 07 04508
4509 * SHIFT ACCUMULATOR ACC(SHA) * 07 04509
4510 * 07 04510
4511 * FUNCTION: TO SHIFT THE 4-WORD ACCUMULATOR ACC 07 04511
4512 * 07 04512
4513 * ENTRY: COUNT = + SHIFT RIGHT COUNT 07 04513
4514 * = - SHIFT LEFT 1 07 04514
4515 * 07 04515
4516 * EXIT : NO SPECIAL CONDITIONS 07 04516
4517 * 07 04517
4518 ***** 07 04518
006213 005024 A 4520 SHA TBX LOAD X AS BASE POINTER 07 04520
4521 SHAL TMAX COUNT,SHA50 TEST DIRECTION OF SHIFT V2 07 04521
006214 015052 A
006215 001004 A
006216 006242 R
006217 001010 A 4522 JAZ SHAX EXIT WHEN FINISHED 07 04522
006220 006257 R
006221 005311 A 4523 DAB DECREMENT SHIFT COUNT 07 04523
006222 055052 A 4524 STA COUNT,X
4525 ***** 07 04524
4526 * RIGHT SHIFT * 07 04525
4527 ***** 07 04526
006223 025006 A 4528 LDB ACC+3,X 07 04527
006224 015003 A 4529 LDA ACC+2,X 07 04528
006225 004501 A 4530 LASR 1 07 04529
006226 065006 A 4531 STB ACC+3,X SHIFT ACC(3) 07 04530
006227 025005 A 4532 LDB ACC+2,X 07 04531
006230 015004 A 4533 LDA ACC+1,X 07 04532
006231 004501 A 4534 LASR 1 07 04533
006232 065005 A 4535 STB ACC+2,X SHIFT ACC(2) 07 04534
006233 025004 A 4536 LDB ACC+1,X 07 04535
006234 015003 A 4537 LDA ACC,X 07 04536
006235 004501 A 4538 LASR 1 07 04537
006236 065004 A 4539 STB ACC+1,X SHIFT ACC(1) 07 04538
006237 055003 A 4540 STA ACC,X SHIFT ACC(0) 07 04539
006240 001000 A 4541 JMP SHAL LOOP TILL DONE 07 04540
006241 006214 R
4542 ***** 07 04541
4543 * LEFT SHIFT * 07 04542
4544 ***** 07 04543
006242 015003 A 4545 SHA50 LDA ACC,X 07 04544
006243 025004 A 4546 LDB ACC+1,X 07 04545
006244 004401 A 4547 LASL 1 07 04546
006245 055003 A 4548 STA ACC,X SHIFT ACC(0) 07 04547
006246 015004 A 4549 LDA ACC+1,X 07 04548
006247 025003 A 4550 LDB ACC+2,X 07 04549
006250 004401 A 4551 LASL 1 07 04550
006251 055004 A 4552 STA ACC+1,X SHIFT ACC(1) 07 04551
006252 015003 A 4553 LDA ACC+2,X 07 04552
006253 025006 A 4554 LDB ACC+3,X 07 04553
006254 004401 A 4555 LASL 1 07 04554
006255 055003 A 4556 STA ACC+2,X SHIFT ACC(2) 07 04555
006256 065006 A 4557 STB ACC+3,X SHIFT ACC(3) 07 04556
006257 005042 A 4558 SHAX TXB RESTORE BASE REGISTER B 07 04557
4559 POPJ EXIT FG 07 04558

```



```

006260 001000 A
006261 004110 R
4560      EJEC
4561      IFF      NUC
4562      GOTO     NUC1
4563      IFT      VII
4564      GOTO     VII1
4565 *****
4566 *
4567 *      T E S T   B A C K G R O U N D   A D D R E S S ( T B K )
4568 *
4569 * FUNCTION: TO TEST IF AN ADDRESS IS IN THE BACKGROUND
4570 *
4571 * ENTRY: A = TEST ADDRESS
4572 *
4573 * CALLING SEQUENCE: JSR TBK,X
4574 *
4575 * EXIT : IF OK, RETURN WITH A UNCHANGED
4576 *      OTHERWISE, SET UP A MEMORY PROTECT ERROR
4577 *
4578 *****
006262 140316 A 4580 TBK      SUB      V$LUP
006263 001004 A 4581      JAN      TBK10      ERROR IF A.LT.V$LUP
006264 006276 R
006265 120316 A 4582      ADD      V$LUP      RESTORE A
006266 140317 A 4583      SUB      V$LLUP
006267 001010 A 4584      JAZ      *+4
006270 006273 R
006271 001002 A 4585      JAP      TBK10      ERROR IF A.GT.V$LLUP
006272 006276 R
006273 120317 A 4586      ADD      V$LLUP      RESTORE A
006274 006705 A 4587      IJMP     0,X        RETURN IF OK
006275 000000 A
4588 *****
4589 * ERROR - CONSTRUCT MEMORY PROTECT VIOLATION *
4590 *****
006276 030316 A 4591 TBK10  LDX      V$LUP      POINT X AT 1ST BACKGROUND WORD
006277 010432 A 4592      LDA      TBKJMP
006300 055000 A 4593      STA      0,X
006301 005001 A 4594      TZA
006302 055001 A 4595      STA      1,X        STORE *JMP 0* IN BACKGROUND
006303 020302 A 4596      LDB      V$CRS      POINT B AT STACK
006304 076003 A 4597      STX      PR1B      SET DEALOC ADDRESS TO 1ST BACKGROUND WORD
4598      DEALOC
006305 006505 A
006306 000113 E
006307 000700 A
006308 000432 A 4599 TBKJMP SET      BS9
4600 VIII1  CONT
4601 NUC1   CONT
4602      EJEC
4603 *****
4604 *
4605 * P R O C E S S   T   F O R M A T   D E S C R I P T O R ( T I D )
4606 *
4607 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTOR: TN
4608 *
4609 * ENTRY: DIRECT FROM FRS
4610 *      BFPT = CURRENT BUFFER CHARACTER POSITION(BASE 0)
4611 *      W = SPECIFIED BUFFER CHARACTER POSITION(BASE 1)
4612 *
4613 * EXIT : DIRECT TO FRS
4614 *      BFPT = W-1
4615 *      BFWPT = ALBF + BFPT/2
4616 *      RWFL(BIT SC) = 1 IF LOGICAL FILE PHYSICALLY POSITIONED BACKV2
4617 *
4618 * ERRORS: ERI IF W OUTSIDE LOGICAL RECORD
4619 *
4620 *****
006310 R 4622 TIN      EQU      *
006310 R 4623 TOUT     EQU      *
4625      MOVEAB BFPT,SAVE      SAVE CURRENT VALUE OF BUFFER CHAR PTR
006310 016026 A
006311 056032 A
006312 016170 A 4626      LDB      W,B        GET W
006313 005311 A 4627      JAR      CONVERT FROM BASE 1 TO BASE 0
006314 056026 A 4628      STA      BFPT,B     STORE AS BUFFER CHARACTER POINTER
006315 146032 A 4629      SUB      SAVE,B
006316 001004 A 4630      JAN      TID10     TEST DIRECTION OF REPOSITION
006317 006327 R
4631 *****
4632 * POSITION FORWARD *
4633 *****
006320 016122 A 4634      LDB      LRSE,B     YES
006321 004241 A 4635      LRLA    1           GET LOGICAL RECORD BYTE COUNT
006322 146170 A 4636      SUB      W,B
006323 001004 A 4637      JAN      ORI        ERROR 1/ W OUTSIDE RECORD /
006324 005705 R
006325 001000 A 4638      JMP      TIDLPL
006326 006374 R
4639 *****
4640 * POSITION BACKWARD *
4641 *****

```



```

006327 016026 A 4642 TID10 LDA BFPT,B 07 04642
006330 004341 A 4643 LSRA 1 07 04643
006331 126027 A 4644 ADD ALBF,B GET WORD POSITION 07 04644
006332 146020 A 4645 SUB APBF,B GET ADDRESS 07 04644
006333 001002 A 4646 JAP TID20 COMPARE WITH BUFFER START ADDRESS 07 04645
006334 006361 R 4647 ***** EXIT IF STILL IN BUFFER 07 04646
4648 * REPOSITION BUFFER *
4649 *****
006335 036010 A 4650 LDX ADFCB,B 07 04649
006336 013015 A 4651 LDA 13,X GET BUFFER RECORD NUMBER 07 04650
006337 146142 A 4652 SUB PBRC,B 07 04651
006340 056145 A 4653 STA PRECND,B BACK UP FILE 07 04653
4654 ADDBB ALBF,PBSZ,ALBF BUMP LOGICAL BUFFER ADDRESS 07 04654
006341 016027 A
006342 126143 A
006343 056027 A
4655 MOVZAB RWFL,SAVE+1 SAVE FLAG WORD 07 04655
006344 016154 A
006345 056033 A
006346 006451 A 4656 BT ARST+WR,TID15 WRITE ? V2 07 04656
006347 006352 R
006350 110424 A 4657 ORA RBS YES. SET READ BEFORE WRITE FLAG V2 07 04657
006351 056154 A 4658 STA RWFL,B 07 04658
4659 TID15 PUSHJ RFL REPOSITION FILE V2 07 04659
006352 006010 A
006353 005722 R
006354 006505 A
006355 005042 R
006356 016033 A 4660 LDA SAVE+1,B RESTORE FLAG WORD 07 04660
006357 110426 A 4661 ORA SCS SET CLEAR SUPPRESS FLAG V2 07 04661
006360 056154 A 4662 STA RWFL,B 07 04662
4663 TID20 DABB ALBF,BFWPT INITIALIZE BUFFER WORD POINTER 07 04663
006361 016027 A
006362 005311 A
006363 056025 A
006364 016020 A 4664 LDA APBF,B 07 04664
006365 126143 A 4665 ADD PBSZ,B 07 04665
006366 146027 A 4666 SUB ALBF,B 07 04666
006367 056144 A 4667 STA PBWC,B REINITIALIZE PHYSICAL WORD COUNT 07 04667
4668 MOVZAB LRSZ,LRWC ALSO LOGICAL WORD COUNT 07 04668
006370 016122 A
006371 056123 A
4669 ZAB SAVE ALSO CHAR COUNTER 07 04669
006372 005001 A
006373 056032 A
4670 *****
4671 * POSITION LOOP *
4672 *****
006374 016026 A 4673 TIDLPL LDA BFPT,B 07 04673
006375 146032 A 4674 SUB SAVE,B 07 04674
006376 001010 A 4675 JAZ FRSS5 EXIT TO FORMAT SCAN WHEN DONE 07 04675
006377 001121 R
006400 016032 A 4676 LDA SAVE,B 07 04676
006401 046032 A 4677 INR SAVC,B BUMP CHAR COUNTER 07 04677
006402 004257 A 4678 LSLA 15 07 04678
006403 001004 A 4679 JAM TIDLPL WORD BOUNDARY ? 07 04679
006404 006374 R
4680 PUSHJ GBA YES. GET NEXT BUFFER ADDRESS V2 07 04680
006405 006010 A
006406 001173 R
006407 006505 A
006410 005042 R
006411 001000 A 4681 JMP TIDLPL LOOP TILL DONE 07 04681
006412 006374 R
4682 EJEC 07 04682
4683 ***** 07 04683
4684 * 07 04684
4685 * TERMINATE (TRM) * 07 04685
4686 * 07 04686
4687 * FUNCTION: TO PROCESS A TERMINATE($ND) CALL 07 04687
4688 * 07 04688
4689 * ENTRY: NO SPECIAL CONDITIONS 07 04689
4690 * 07 04690
4691 * EXIT : LOGICAL BUFFER RECYCLED ON WRITE 07 04691
4692 * EXIT OP PUSHED V2* 07 04692
4693 * I/O OP PUSHED ON TERMINATE WRITE NON-LOGICAL V2* 07 04693
4694 * 07 04694
4695 ***** 07 04695
006413 016154 A 4697 TRM LDA RWFL,B V2 07 04697
006414 110425 A 4698 ORA TRS SET TERMINATE FLAG V2 07 04698
006415 056154 A 4699 STA RWFL,B V2 07 04699
006416 006441 A 4700 BT ARST+LF,TRM20 TEST LOGICAL FILE V2 07 04700
006417 006445 R
4701 ***** 07 04701
4702 * LOGICAL FILE * 07 04702
4703 ***** 07 04703
006420 006440 A 4704 BT ARST+RM,TRM20 RMD ? V2 07 04704
006421 006445 R
006422 006451 A 4705 BT ARST+WR,TRM10 YES. WRITE ? V2 07 04705
006423 006431 R
006424 056154 A 4706 STA RWFL,B 07 04706
4707 PUSHJ RCL YES. RECYCLE LOGICAL BUFFER V2 07 04707

```



```

006425 006010 A
006426 005464 R
006427 006505 A
006430 005042 R
006431 036010 A 4708 TRM10 LDX ADFCB,B POINT X AT FCB 07 04708
                                4709 MOVVAX LRSZ,0 LOAD FCB(0) WITH LOGICAL RECORD SIZE 07 04709
006432 016122 A
006433 055000 A
006434 015002 A 4710 LDA 0,X GET ACCESS MODE FROM FCB 07 04710
006435 007401 A 4711 SDF 07 04711
006436 006410 A 4712 BT ASET+8,*+3 SET OVFL IF SEQUENTIAL 07 04712
006437 006441 R
006440 007400 R 4713 RDF 07 04713
006441 016160 A 4714 LDA SVRECN,B RESTORE RECORD NUMBER IF DIRECT 07 04714
006442 003001 A 4715 XDF TRMI OTHERWISE UPDATE 07 04715
006443 006504 R
006444 055003 A 4716 STA 3,X STORE IN FCB 07 04716
006445 010422 A 4717 TRM20 LDA CEX 07 04717
                                4718 PUSHF PUSH EXIT OP 07 04718
006446 036016 A
006447 035000 A
006450 005344 A
006451 055000 A
006452 005041 A
006453 036016 A
006454 055000 A
                                4719 TRAB RWFL,LF,TRM30 LOGICAL ? V2 07 04719
006455 016154 A
006456 006441 R
006457 006465 R
006460 006400 A 4720 BT ASET+RM,CAN YES, EXIT IF RMD V2 07 04720
006461 000101 R
006462 036010 A 4721 LDX ADFCB,B V2 07 04721
                                4722 MOVVAX PBSZ,0 IF NON-RMD, SET FCB(0) = PBSZ V2 07 04722
006463 016143 A
006464 055000 A
                                4723 TRM30 TRAB RWFL,WR,CAN EXIT ON READ D.1 07 04723
006465 016154 A
006466 006451 A
006467 000101 R
006470 006412 A 4724 BT EC,CAN EXIT FOR ENCODE/DECODE PD 07 04724
006471 000101 R
006472 010464 R 4725 LDA CID 07 04725
                                4726 PUSHF WRITE LAST NON-LOGICAL RECORD 07 04726
006473 036016 A
006474 035000 A
006475 005344 A
006476 055000 A
006477 005041 A
006500 036016 A
006501 055000 A
006502 001000 A 4727 JMP CAN EXIT TO V$FORTID 07 04727
006503 000101 R
006504 016121 A 4728 TRMI LDA LRECNO,B 07 04728
                                4729 EUEC 07 04729
006505 006010 A 4730 ***** 07 04730
                                4731 * 07 04731
                                4732 * UNFORMATTED INPUT/OUTPUT (UID) * 07 04732
                                4733 * 07 04733
                                4734 * FUNCTION: TO PROCESS UNFORMATTED I/O CALLS * 07 04734
                                4735 * 07 04735
                                4736 * ENTRY: ITEMAD = LIST ITEM ADDRESS * 07 04736
                                4737 * BFWPT = ADDRESS OF DATA WORD IN BUFFER * 07 04737
                                4738 * 07 04738
                                4739 * EXIT : TO V$FORTID THRU GNL * 07 04739
                                4740 * 07 04740
                                4741 ***** 07 04741
                                4742 ***** 07 04742
                                4743 ***** 07 04743
                                4744 * TRANSFER EDDP * 07 04744
                                4745 ***** 07 04745
                                4746 UID PUSHJ GNL GET NEXT LIST ITEM ADDRESS/EXIT V2 07 04746
006506 001561 R
006507 006505 A
006510 005042 R
                                4747 PUSHJ GBA GET BUFFER ADDRESS V2 07 04747
006511 006010 A
006512 001173 R
006513 006505 A
006514 005042 R
                                4748 TSAB RWFL,WR,UID4 TEST INPUT OR OUTPUT V2 07 04748
006515 016154 A
006516 006411 A
006517 006520 R
                                4749 ***** 07 04749
                                4750 * INPUT * 07 04750
                                4751 ***** 07 04751
006520 036025 A 4752 LDX BFWPT,B POINT X AT DATA WORD IN BUFFER 07 04752
006521 015000 A 4753 LDA 0,X GET DATA WORD 07 04753
006522 036113 A 4754 LDX ITEMAD,B POINT X AT LIST ITEM 07 04754
006523 055000 A 4755 STA 0,X STORE INPUT DATA WORD IN LIST ITEM 07 04755
006524 001000 A 4756 JMP UID LOOP UNTIL DONE 07 04756
006525 006505 R

```



```

4757 ***** 07 04757
4758 * OUTPUT * 07 04758
4759 ***** 07 04759
006526 036113 A 4760 UID4 LDX ITEMAD,B POINT X AT LIST ITEM 07 04760
006527 015000 A 4761 LDA 0,X GET DATA WORD 07 04761
006530 036025 A 4762 LDX BFWPT,B POINT X AT DATA WORD IN BUFFER 07 04762
006531 055000 A 4763 STA 0,X STORE DATA WORD IN OUTPUT BUFFER 07 04763
006532 001000 A 4764 JMP UID LOOP UNTIL DONE 07 04764
006533 006505 R
4765 EJEC 07 04765
4766 ***** 07 04766
4767 * 07 04767
4768 * PROCESS X FORMAT DESCRIPTOR ( X I D ) * 07 04768
4769 * 07 04769
4770 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTOR: NX 07 04770
4771 * 07 04771
4772 * ENTRY: DIRECT FROM FRS 07 04772
4773 * N = FIELD WIDTH 07 04773
4774 * 07 04774
4775 * EXIT : TO FRS 07 04775
4776 * 07 04776
4777 ***** 07 04777
006534 R 4779 XIN EQU * 07 04779
006534 R 4780 XDUT EQU * 07 04780
4782 MOVBAB BLNK1,BCHAR LOAD BLANK AS REPEAT CHARACTER V2 07 04782
006534 016202 A
006535 056030 A
4783 MOVBAB N,COUNT SET REPEAT COUNT TO N 07 04783
006536 016125 A
006537 056052 A
4784 MOVBAB ABSCB,ASCB SET SCB TO BUFFER 07 04784
006540 016002 A
006541 056021 A
4785 PUSHJ RCH REPEAT CHARACTER I/O N TIMES V2 07 04785
006542 006010 A
006543 005411 R
006544 006505 A
006545 005042 R
006546 001000 A
006547 000475 R
4786 JMP FRSS RESUME FORMAT SCAN 07 04786
4787 EJEC 07 04787
4788 ***** 07 04788
4789 * 07 04789
4790 * PROCESS Z DESCRIPTOR ( Z I N / Z O U T ) * 07 04790
4791 * 07 04791
4792 * FUNCTION: TO PROCESS THE Z FORMAT DESCRIPTOR: RZW 07 04792
4793 * 07 04793
4794 * ENTRY: DIRECT FROM FRS 07 04794
4795 * WT = W TOTAL FIELD WIDTH 07 04795
4796 * IIBSZ = BYTE COUNT OF SINGLE LIST ITEM 07 04796
4797 * ITEMAD = ADDRESS OF LIST ITEM 07 04797
4798 * RWFL(BIT WR) = 0 READ 07 04798
4799 * = 1 WRITE 07 04799
4800 * 07 04800
4801 * EXIT: INPUT : DIRECT TO FRS 07 04801
4802 * OUTPUT: DIRECT TO FRS THRU OBC 07 04802
4803 * 07 04803
4804 ***** 07 04804
006550 R 4806 ZIN EQU * 07 04806
006550 R 4807 ZOUT EQU * 07 04807
4809 ZAB AIBUF-1 SET LIST ITEM SCB(0)=0 (BYTE COUNT) 07 04809
006550 005001 A
006551 056107 A
4810 MOVBAB ITEMAD,AIBUF SET LIST ITEM SCB(1)=ITEM ADDRESS 07 04810
006552 016113 A
006553 056110 A
006554 016171 A
4811 LDA WT,B 07 04811
006555 005111 A
4812 JAR 07 04812
006556 004301 A
4813 ASRA 1 (A)=BYTES TO PROCESS 07 04813
006557 146101 A
4814 SUB IIBSZ,B 07 04814
006560 056052 A
4815 STA COUNT,B EXCESS BYTES 07 04815
4816 MOVBAB BLNK1,BCHAR SLEW THRU W/2-IIBSZ CHAR 07 04816
006561 016202 A
006562 056030 A
4817 PUSHJ RCH 07 04817
006563 006010 A
006564 005411 R
006565 006505 A
006566 005042 R
4818 TSAB RWFL,WR,ZID4 I/O TEST 07 04818
006567 016154 A
006570 006411 A
006571 006636 R
4820 * INPUT 07 04820
4821 ZID1 PUSHJ CBC GET BUFFER CHARACTER 07 04821
006572 004010 A
006573 000115 R
006574 006505 A
006575 005042 R
4822 PUSHJ ZID6 INPUT CHARACTER TEST 07 04822
006576 006010 A
006577 006667 R
006600 006505 A

```



006601	003042	R						
			4823	MOVBAB	BCHAR, ICHAR			07 04823
006602	016030	A						
006603	056111	A	4824	TZAB	WT, ZID2	FIELD WIDTH EXHAUSTED		07 04824
006604	016171	A						
006605	001010	A						
006606	006623	R	4825	PUSHJ	OCB	GET NEXT CHARACTER		07 04825
006607	006010	A						
006610	000115	R						
006611	006505	A						
006612	005042	R	4826	PUSHJ	ZID6	INPUT CHARACTER TEST		07 04826
006613	006010	A						
006614	006667	R						
006615	006505	A						
006616	005042	R						
006617	016111	A	4827	LDA	ICCHAR, B	APPEND RT HALF		07 04827
006620	004204	A	4828	ASLA	4			07 04828
006621	126030	A	4829	ADD	BCHAR, B			07 04829
006622	056111	A	4830	STA	ICCHAR, B			07 04830
			4831	ZID2	MOVBAB	WISCB, ASCB	SET SCB TO LIST ITEM	07 04831
006623	016013	A						
006624	056021	A	4832	PUSHJ	PCH	PUT CHARACTER IN ITEM		07 04832
006625	006010	A						
006626	003557	R						
006627	006505	A						
006630	005042	R	4833	TNZAB	WT, ZID1	LOOP UNTILL FIELD WIDTH EXHAUSTED		07 04833
006631	016171	A						
006632	001016	A						
006633	006572	R						
006634	001000	A	4834	JMP	FRS65	TO FORMAT SCAN		07 04834
006635	001100	R	4836 *	OUTPUT				07 04836
			4837	ZID4	MOVBAB	WISCB, ASCB	SET SCB TO LIST ITEM	07 04837
006636	016013	A						
006637	056021	A	4838	PUSHJ	ICC	INPUT CHARACTER FROM LIST ITEM		07 04838
006640	006010	A						
006641	001754	R						
006642	006505	A						
006643	005042	R	4839	PUSHJ	ZID3	OUTPUT CHARACTER		07 04839
006644	006010	A						
006645	006713	R						
006646	006505	A						
006647	005042	R						
006650	016111	A	4840	LDA	ICCHAR, B			07 04840
006651	004304	A	4841	ASRA	4			07 04841
006652	016111	A	4842	LDA	ICCHAR, B			07 04842
006653	006150	A	4843	ANAI	0177	GET RT HALF		07 04843
006654	000177	A	4844	PUSHJ	ZID8	OUTPUT CHARACTER		07 04844
006655	006010	A						
006656	006713	R						
006657	006505	A						
006660	005042	R	4845	PUSHJ	OCB	OUTPUT CHARACTER TO BUFFER		07 04845
006661	006010	A						
006662	002646	R						
006663	006505	A						
006664	005042	R						
006665	001000	A	4846	JMP	ZID4	LOOP UNTILL DONE		07 04846
006666	006636	R	4848 *	TEST INPUT CHARACTER				07 04848
006667	016030	A	4849	ZID6	LDA	BCHAR, B		07 04849
006670	006140	A	4850	SUBI	'0'			07 04850
006671	000260	A						
006672	001004	A	4851	JAN	ER3			07 04851
006673	005703	R						
006674	056030	A	4852	STA	BCHAR, B			07 04852
006675	140471	A	4853	SUB	TEN			07 04853
006676	001004	A	4854	JAN	ZID7	0-9		07 04854
006677	006711	R						
006700	140467	A	4855	SUB	SEVEN			07 04855
006701	001004	A	4856	JAN	ER3			07 04856
006702	005703	R						
006703	140467	A	4857	SUB	SEVEN			07 04857
006704	001002	A	4858	JAN	ER3			07 04858
006705	005703	R						
006706	006120	A	4859	ADDI	020			07 04859
006707	000020	A						
006710	056030	A	4860	STA	BCHAR, B			07 04860
			4861	ZID7	POPJ	EXIT		07 04861
006711	001000	A						
006712	004110	R	4863 *	GENERATE CHARACTER				07 04863
006713	016111	A	4864	ZID8	LDA	ICCHAR, B		07 04864
006714	006120	A	4865	ADDI	'0'			07 04865
006715	000260	A						



Address	Label	Mode	Value	Symbol	Description	Flags	Page
006716	056111	A	4866	STA	ICHAR,B		07 04866
006717	006140	A	4867	SUBI	0272		07 04867
006720	000272	A					
006721	001004	A	4868	JAN	Z109		07 04868
006722	006725	R					
006723	120467	A	4869	ADD	SEVEN		07 04869
006724	056111	A	4870	STA	ICHAR,B		07 04870
			4871	Z109	POPJ		07 04871
006725	001000	A					
006726	004110	R					
4872				EJEC			07 04872
4873				*****	*****		07 04873
4874				*			07 04874
4875				*			07 04875
4876				*			07 04876
4877				*****	*****		07 04877
006727		R	4879	BASE	EQU	*	07 04879
			4880	IFF	NUC		FG 07 04880
			4881	GOTO	NUC1		FG 07 04881
			4882	IFT	VII		FG 07 04882
			4883	GOTO	VIII		FG 07 04883
006727			4884	VOPSTP	BSS	1	FG 07 04884
006730	006732	R	4885	VAACC	PZE	VACC	07 04885
006731	006735	R	4886	VABSCB	PZE	VBSCB	07 04886
006732			4887	VACC	BSS	4	07 04887
006736	006761	R	4888	VACHB	PZE	VCHB	07 04888
006737			4889	VADFCB	BSS	1	07 04889
006740	007011	R	4890	VAFSCB	PZE	VFSCB	07 04890
006741	007014	R	4891	VAGPAR	PZE	VGDRP-1	07 04891
006742	007036	R	4892	VAISCB	PZE	VISCB	07 04892
006743			4893	VALDC	BSS	1	07 04893
006744	000000	A	4894	VANPOJ	DATA	0	V2 07 04894
006745			4895	VANRB	BSS	1	V2 07 04895
006746	007070	R	4896	VADPST	PZE	VOPSTK+STKSZ	V2 FG 07 04896
006747			4897	VAPBF	BSS	1	07 04897
006750			4898	VASCB	BSS	1	07 04898
006751			4899	VASFL	BSS	1	07 04899
006752	007106	R	4900	VASYSD	PZE	VSYSDC	07 04900
006753			4901	VBEXP	BSS	1	07 04901
006754			4902	VBFWPT	BSS	1	07 04902
006755			4903	VBSCB	BSS	4	07 04903
006761			4904	VCHB	BSS	14	07 04904
006777			4905	VCHBPT	BSS	1	07 04905
007000			4906	VCHNHD	BSS	1	07 04906
007001			4907	VCDUN	BSS	1	07 04907
007002			4908	VCVFL	BSS	1	07 04908
007003			4909	VD	BSS	1	07 04909
007004			4910	VDEXP	BSS	1	07 04910
007005			4911	VDT	BSS	1	07 04911
007006			4912	VEDEXP	BSS	1	07 04912
007007	000000	A	4913	VERN	DATA	0	07 04913
007010			4914	VFDLKY	BSS	1	07 04914
007011			4915	VFSCB	BSS	4	07 04915
007015			4916	VGDRP	BSS	9	07 04916
007026			4917	VIDEXP	BSS	1	07 04917
007027			4918	VIFW	BSS	1	07 04918
007030			4919	VIIBSZ	BSS	1	07 04919
007031	000001	A	4920	VIIWSZ	DATA	1	07 04920
007032			4921	VINFL	BSS	1	V2 07 04921
007033			4922	VIDCON	BSS	1	07 04922
007034			4923	VIDLNK	BSS	1	07 04923
007035	000000	A	4924	VIDSTA	DATA	0	07 04924
007036			4925	VISCB	BSS	4	07 04925
007042			4926	VITEMA	BSS	1	07 04926
007043			4927	VITEMW	BSS	1	07 04927
007044			4928	VITMIN	BSS	1	07 04928
007045			4929	VITMOD	BSS	1	07 04929
007046			4930	VLISTF	BSS	1	07 04930
007047			4931	VLNKC	BSS	1	07 04931
007050			4932	VLRECN	BSS	1	07 04932
007051			4933	VLRSC	BSS	1	07 04933
007052			4934	VLRWC	BSS	1	07 04934
007053			4935	VMDV	BSS	1	07 04935
007054			4936	VN	BSS	1	07 04936
007055			4937	VNFF	BSS	1	07 04937
			4938	VIII	CONT		FG 07 04938
007056			4939	VOPSTK	BSS	STKSZ	07 04939
007070			4940	VPARLV	BSS	1	FG 07 04940
			4941	IFT	VII		FG 07 04941
			4942	GOTO	VIII		FG 07 04942
007071			4943	VPBRC	BSS	1	07 04943
007072			4944	VPBSZ	BSS	1	07 04944
007073			4945	VPBWC	BSS	1	07 04945
007074			4946	VPRECN	BSS	1	07 04946
007075			4947	VPRLIN	BSS	1	07 04947
007076			4948	VPTFL	BSS	1	07 04948
007077			4949	VQFL	BSS	1	07 04949
007100			4950	VRETUR	BSS	1	07 04950
007101			4951	VRHFL	BSS	1	V2 07 04951
007102			4952	VS	BSS	1	07 04952
007103			4953	VSCF	BSS	1	07 04953
007104			4954	VSGFL	BSS	1	07 04954
007105			4955	VSVREC	BSS	1	07 04955

V \$ R E R R D A T A B L O C K

BASE ADDRESS OF DATA BLOCK

OP STACK POINTER

ADDRESS OF ACCUMULATOR ACC

ADDRESS OF BUFFER SCB

4-WORD ACCUMULATOR

ADDRESS OF DECIMAL DIGIT ARRAY

DCB/FCB ADDRESS

ADDRESS OF FORMAT SCB

ADDRESS OF 'C' GROUP BLOCK

ADDRESS OF LIST ITEM SCB

ALOC ENTRY FLAG

ADDRESS OF V\$FORTID POP/JUMP

ADDRESS OF V\$FORTID DATA BLOCK

ADDRESS OF OP STACK

ADDRESS OF PHYSICAL BUFFER

SCAN BLOCK ADDRESS

'\*' FLAG

ADDRESS OF SYSTEM DCB

BINARY EXPONENT

BUFFER WORD POINTER

BUFFER SCB

DECIMAL DIGIT ARRAY

CHB ARRAY POINTER

FCB CHAIN HEADER

COUNTER

CHARACTER VALIDITY FLAGS

FRACTIONAL FIELD WIDTH

DECIMAL EXPONENT

WORKING FRACTIONAL FIELD WIDTH

EXPLICIT DECIMAL EXPONENT

ERROR NUMBER

FIELD DESCRIPTOR LETTER KEY

FORMAT STRING SCB

'C' GROUP DYNAMIC REPEAT COUNT

IMPLICIT DECIMAL EXPONENT

INTEGER FIELD WIDTH

INDIVIDUAL ITEM BYTE SIZE

INDIVIDUAL ITEM WORD SIZE

INITIAL ENTRY FLAG

I/O CONTROL WORD

IDLINK CONTROL WORD

I/O STATUS

LIST ITEM SCB

ADDRESS OF LIST ITEM

COUNT OF WORDS REMAINING IN ITEM

LIST ITEM WORD INCREMENT

LIST ITEM MODE

LIST DATA XFER FLAG

FCB CHAIN LINK COUNT

LOGICAL RECORD NUMBER

LOGICAL RECORD SIZE

LOGICAL RECORD REMAINING WORD COUNT

MULTIPLY OVERFLOW SWITCH

H/T/X FIELD WIDTH

NUMERIC FORMAT FIELD

OP STACK

FORMAT 'C' GROUP LEVEL COUNT

PHYSICAL BUFFER RECORD COUNT

PHYSICAL BUFFER SIZE

PHYSICAL BUFFER REMAINING WORD COUNT

PHYSICAL RECORD NUMBER

PREVIOUS LINK OF FCB CHAIN

'.' POINT FLAG

QUOTE FLAG

RETURN ADDRESS

FLAG WORD

SCALE FACTOR

SCALE FACTOR FLAG

'-' SIGN FLAG

SAVE RECORD NO



007106	000000	A	4956	VSYSDC	DATA	0,1,0	SYSTEM DCB		07	04956
007107	000000	A								
007110	000000	A								
007111			4957	VTEMP	BSS	1	TEMP STORE		07	04957
007112			4958	VTEMP1	BSS	1	TEMP STORE		07	04958
007113			4959	VTERM	BSS	1	PRODUCT TERM		07	04959
007114			4960	VUNIT	BSS	1	I/O UNIT NUMBER		07	04960
007115			4961	VW	BSS	1	FIELD WIDTH		07	04961
007116			4962	VWT	BSS	1	WORKING VALUE OF W		07	04962
007117	000000	A	4963	VXFFL	DATA	0	PARAMTER XFER ENABLE FLAG		07	04963
007120			4964	VXFL	BSS	1	EXPONENT FIELD NON-BLANK FLAG		07	04964
007121			4965	VXFW	BSS	1	EXPONENT FIELD WIDTH		07	04965
007122			4966	VXSG	BSS	1	EXPONENT SIGN FLAG		07	04966
007123			4967	VZFW	BSS	1	LEADING ZERO FIELD WIDTH		07	04967
007124	000260	A	4968		DATA	0260	ASCII ZERO	V2	07	04968
007125	000016	A	4969		DATA	14	DECIMAL 14	V2	07	04969
007126	000170	A	4970		DATA	120	DECIMAL 120	V2	07	04970
007127	000240	A	4971		DATA	0240	ASCII BLANK	V2	07	04971
007130	120240	A	4972		DATA		ASCII BLANK WORD	V2	07	04972
			4973	VIII	CONT			FG	07	04973
			4974	NUC1	CONT			FG	07	04974
			4975	VZZZ	EQU	*	END OF DATA BLOCK		07	04975
			4976		END				07	04976

ENTRY NAMES

005322	R	V\$RER1	000001	A	V\$RERN	005173	R	V\$RERR	000000	R	V\$RERS
004623	E	BIFCB	004624	E	BOFCB	004626	E	GOFCB	004622	E	LOFCB
004621	E	PIFCB	004627	E	POFCB	004617	E	SIFCB	004625	E	SSFCB
006306	E	V\$EXEC									
SYMBOLS											
000001	A	AACC	000002	A	ABSCB	000003	A	ACC	000007	A	ACHE
000010	A	ADFCB	000011	A	AFSCB	000012	A	AGPAR	000110	A	AIBUF
000000	R	AIN	000020	R	AIDL1	000060	R	AIDL2	000013	A	AJSCB
000000	A	AL	000027	A	ALBF	000014	A	ALDC	000015	A	ANPOJ
000016	A	ANRE	000017	A	ANPSTK	000000	R	ADUT	000020	A	APBF
000040	A	ARST	000021	A	ASCB	000000	A	ASET	000022	A	ASFL
000023	A	ASYSDC	000177	A	AZER	000002	A	B	000000	A	B0
000001	A	B1	000014	A	B12	000013	A	B13	000016	A	B14
000017	A	B15	000002	A	B2	000003	A	B3	000004	A	B4
000005	A	B5	000006	A	B6	006727	R	BASE	000030	A	BCHAR
000031	A	BCCDF	000201	A	BD120	000200	A	BD14	000024	A	BEXP
000019	A	BF	000400	A	BFA	000026	A	BFPT	000451	A	BFR
000431	A	BFS	000025	A	BFHPT	004623	E	BIFCB	000001	A	BL
000202	A	BLNK1	000203	A	BLNK2	000472	A	BM17	000473	A	BM37
000474	A	BM77	004624	E	BOFCB	000001	A	BR	000441	A	BR0
000442	A	BR1	000434	A	BR11	000440	A	BR12	000457	A	BR14
000460	A	BR15	000443	A	BR2	000444	A	BR3	000445	A	BR4
000446	A	BR5	000447	A	BR6	000450	A	BR7	000451	A	BR8
000421	A	BS0	000422	A	BS1	000433	A	BS10	000434	A	BS11
000435	A	BS12	000437	A	BS14	000440	A	BS15	000423	A	BS2
000424	A	BS3	000425	A	BS4	000426	A	BS5	000430	A	BS7
000431	A	BS8	000432	A	BS9	000026	A	BSCB	000430	A	BXB1AS
000101	R	CAN	000107	R	CAN1	000112	R	CAN5	000115	R	CBC
000126	R	CBC4	000140	R	CBC6	000467	A	CBK	000020	A	CDC
000424	A	CEF	000021	A	CEN	000421	A	CER	000422	A	CEX
000032	A	CHB	000030	A	CHBPT	000051	A	CHNHDR	000464	A	CID
000145	R	CLB	000154	R	CLB4	000166	R	CLB8	000170	R	CLBLP
000200	R	CLBX	000202	R	CLS	000240	R	CLS10	000250	R	CLS15
000252	R	CLS20	000301	R	CLS30	000002	A	CM	000016	A	CDPV
000052	A	CDUNT	000022	A	CRA	000423	A	CRB	000471	A	CRD
000470	A	CRW	000465	A	CTR	000005	A	CTRV	000053	A	CVFL
000420	A	CXC	000466	A	CXF	000054	A	D	000316	R	D10
000472	A	D15	000425	A	D16	000013	A	DA	000337	R	DEF
000344	A	DEF4	000347	R	DEF8	000374	R	DED10	000372	R	DEDS
000055	A	DEXP	003607	R	DIN	000352	R	DDUT	000056	A	DT
000012	A	EC	000057	A	EDEXP	000404	A	EIGHT	003607	R	EIN
000352	R	EOUT	005705	R	ER1	005704	R	ER2	005703	R	ER3
005702	R	ER4	000060	A	ERN	000064	A	FCHAR	000065	A	FCCDF
000061	A	FDLKEY	003607	R	FIN	000465	A	FIVE	000015	A	FLP
000062	A	FMPT	000423	A	FOUR	000425	R	FOUT	000016	A	FPD
000457	A	FPDR	000437	A	FPDS	000017	A	FRB	000440	A	FRES
000014	A	FRM	000063	A	FRMT	000062	A	FRPT	000442	R	FRS
000507	R	FRS10	000547	R	FRS15	000625	R	FRS19	000468	R	FRS2
000631	R	FRS20	000640	R	FRS25	000670	R	FRS30	000700	R	FRS35
000717	R	FRS40	000730	R	FRS45	000743	R	FRS46	000772	R	FRS47
000475	R	FRS5	001011	R	FRS50	001061	R	FRS55	001060	R	FRS60
001100	R	FRS65	001107	R	FRS70	001115	R	FRS75	001121	R	FRS80
001132	R	FRSCHT	001145	R	FRSJT	000706	R	FRSL1	000062	A	FSCB
001173	R	GBA	001206	R	GBA50	001216	R	GBA55	001227	R	GBA60
001237	R	GBA70	001247	R	GBA80	000006	A	GDRPC	000007	A	GF
000071	A	GFRPT	000430	A	GFS	003607	R	GIN	001250	R	GNI
001412	R	GNI10	001274	R	GNI2	001443	R	GNI20	001500	R	GNI25
001517	R	GNI30	001301	R	GNI4	001540	R	GNI50	001330	R	GNI8
001360	R	GNI9	001406	R	GNI9A	001423	R	GNIL1	001543	R	GNI12
001561	R	GNL	001610	R	GNL2	004626	E	GOFCB	001615	R	GOUT
000074	A	GSRPC	001647	R	HIN	001720	R	HID10	001736	R	HID15
001660	R	HID2	001705	R	HID4	001719	R	HID6	001647	R	HOUT
001754	R	ICC	002006	R	ICCCCT	002030	R	ICCCCT1	001775	R	ICCLP
000111	A	ICCHAR	000077	A	IDEXP	002054	R	IFF	002056	R	IFFL
002101	R	IFFL1	000100	A	IFW	000101	A	IIBSZ	003607	R	IIN
000102	A	IINS2	000006	A	IN	002113	R	INF	000100	A	INFL
002115	R	INFLP	000447	A	INR	000427	A	INS	000104	A	INCONT
000105	A	IDLNK	000106	A	IDSTAT	002125	R	IDUT	000107	A	ISCB



000113	A	ITEMAD	000114	A	ITEMWC	000115	A	ITMINC	000116	A	ITMODE
002137	R	IXN	002237	R	IXN10	002250	R	IXN15	002306	R	IXN18
002311	R	IXN20	002325	R	IXN25	002340	R	IXN30	002177	R	IXN4
002316	R	IXN5	002342	R	IXN50	002360	R	IXN52	002366	R	IXN53
002373	R	IXN55	002407	R	IXN57	002411	R	IXN58	002223	R	IXN6
002422	R	IXN60	002233	R	IXN8	002152	R	IXNLI	002263	R	IXNLI2
002400	R	IXNLI3	000612	R	IXR	000300	A	LC	000001	A	LF
000422	A	LFS	000123	A	LGOV	000462	A	LHW	002443	R	LIN
002471	R	LINX	000117	A	LISTFL	000120	A	LNKCNT	000204	A	LDC
004622	E	LOFCB	002524	R	LOU4	002501	R	LOUT	000003	A	LP
000121	A	LRECND	003577	R	LRLA8	000122	A	LRSZ	000123	A	LRWC
002053	R	LSRAS	002530	R	M10	002547	R	M104	002573	R	M10X
000046	A	MAP	000004	A	MN	000124	A	MOV	000420	A	MT
000125	A	N	000126	A	NFF	000470	A	NINE	000005	A	NM
002575	R	NRM	002621	R	NRM4	002576	R	NRML	002643	R	NRMX
000001	A	NUC	002646	R	OCB	002660	R	OCB4	002671	R	OCB6
000421	A	ONE	002701	R	DNF	002751	R	DNF20	003006	R	DNF30
003064	R	DNF40	002731	R	DNF3	003077	R	DNF50	003110	R	DNF52
003127	R	DNF55	003153	R	DNF60	002755	R	DNFL1	003033	R	DNFL2
003161	R	DPN	003344	R	DPN30	003214	R	DPN4	003225	R	DPN5
000127	A	DPSTK	000000	A	DPSTKP	000141	A	PARLV	003356	R	PAX
003402	P	PAX10	003416	R	PAX15	003425	R	PAX16	003456	R	PAX20
003503	R	PAX30	003512	R	PAX33	003517	R	PAX50	003522	R	PAX55
003527	R	PAX70	003554	R	PAXTAB	000142	A	PBRC	000143	A	PBSZ
000144	A	PBWC	003557	R	PCH	004621	E	PIFCB	000006	A	PL
003763	R	PNI18	003775	R	PNI19	004003	R	PNI20	003672	R	PNI4
004012	R	PNI50	004035	R	PNI60	004032	R	PNI62	004066	R	PNI64
004103	R	PNI66	003734	R	PNI8	003642	R	PNIL1	003656	R	PNIL1X
004020	R	PNIL2	000002	A	PD	004627	E	PDFCB	004110	R	POJ
000443	A	POR	000423	A	POS	000003	A	PR	004115	R	PRD
004151	R	PRD1	004202	R	PRD2	004213	R	PRD4	000145	A	PRECND
000146	A	PRLINK	004216	R	PRU	004231	R	PRU0	004237	R	PRU5
004275	R	PRU1	004412	R	PRU10	004456	R	PRU15	004312	R	PRUC
004470	R	PRU20	004514	R	PRU25	004321	R	PRU3	004525	R	PRU30
004534	R	PRU35	004324	R	PRU4	004601	R	PRU40	004345	R	PRU5
004615	R	PRU50	004366	R	PRU6	004617	R	PRUAS1	004631	R	PRUDTB
004640	R	PRUDTE	004630	R	PRUGT	004460	R	PRUL1	004630	R	PRW
004672	R	PRW0	004661	R	PRW05	004676	R	PRW1	004760	R	PRW10
004710	R	PRW2	004734	R	PRW4	004744	R	PRW6	004771	R	PRX
000007	A	PS	005011	R	PSE	005040	R	PSEBX	005042	R	PSJ
000010	A	PT	000147	A	PTFL	005101	R	PXF	005144	R	PXF10
005163	R	PXF20	005114	R	PXF5	005165	R	PXF5ZT	000150	A	QFL
000011	A	QT	000125	A	R	000003	A	RB	005174	R	RBE1
005236	R	RBE10	005334	R	RBE15	005357	R	RBE25	005361	R	RBE30
005316	R	RBE4	005214	R	RBE5	005366	R	RBE90	005410	R	RBE9
005371	R	RBEJT	005410	R	RBEJTE	000424	A	RBS	005411	R	RCH
005446	R	RCH10	005456	R	RCH15	005417	R	RCH2	005440	R	RCH3
005464	R	RCL	005476	R	RCL10	005506	R	RCL15	005471	P	RCL5
005526	R	RCP	005570	R	RCP15	005610	R	RCP20	005617	R	RCP25
005540	R	RCP3	005660	R	RCP35	005663	R	RCP40	005544	R	RCP5
005674	R	RCP50	000151	A	RETURN	005722	R	RFL	005742	R	RFL10
006005	R	RFL20	006015	R	RFL30	006023	R	RFL40	005736	R	RFL5
006025	R	RFL50	000463	A	RHW	000000	A	RM	000421	A	RMS
006032	R	RNA	006032	R	RND	006100	R	RND10	006051	R	RND5
006065	R	RNDL	006103	R	RNDX	002351	R	RDF	000012	A	ROPSTP
000012	A	RP	006105	R	RPB	006114	R	RPB10	006127	R	RPB11
006131	R	RPB12	006137	R	RPB15	006143	R	RPB20	000154	A	RWFL
000155	A	S	000032	A	SAVE	000005	A	SC	000156	A	SCF
006150	R	SCH	006200	R	SCH5	006160	R	SCHLP	006210	R	SCHX
006211	R	SCHY	000446	A	SCR	000426	A	SCS	000467	A	SEVEN
000157	A	SGFL	000014	A	SH	006213	R	SHA	006242	R	SHA50
006214	R	SHAL	006257	R	SHAX	004617	E	SIFCB	000466	A	SIX
000013	A	SL	001787	R	SDF	004625	E	SSFCB	000012	A	STKSZ
000160	A	SVRECND	000162	A	SYSBF	000161	A	SYSDCB	006262	R	TBK
006276	R	TBK10	000432	A	TBKJMP	000164	A	TEMP	000165	A	TEMP1
000471	A	TEN	000166	A	TERM	000464	A	THREE	006310	R	TIN
006327	R	TID10	006352	R	TID15	006361	R	TID20	006374	R	TIDL
006310	R	TOUT	000004	A	TR	006413	R	TRM	006431	R	TRM10
006445	R	TRM20	006465	R	TRM30	006504	R	TRMI	000425	A	TRS
000422	A	TWD	006505	R	UID	006526	R	UID4	000167	A	UNIT
000414	A	V\$BVN	000301	A	V\$CPL	000302	A	V\$CRS	000350	A	V\$DSTB
006306	E	V\$EXEC	000317	A	V\$LLUP	000316	A	V\$LUP	000400	A	V\$LUT1
000401	A	V\$LUT2	000402	A	V\$LUT3	005322	R	V\$RER1	000000	R	V\$RERF
000001	A	V\$RERN	005173	R	V\$RERR	000000	R	V\$RERS	000334	A	V\$ST0
000335	A	V\$ST1	000336	A	V\$ST2	000337	A	V\$ST3	006730	R	VARCC
006731	R	VABSCB	006732	R	VACC	006736	R	VACHB	006737	R	VADFCB
006740	R	VAFSCB	006741	R	VAGPAR	006712	R	VAISCB	006742	R	VALDC
006744	R	VANPOJ	006745	R	VANRB	006746	R	VADPST	006747	R	VAPBF
006750	R	VASCB	006751	R	VASFL	006752	R	VASYSD	006753	R	VBEXP
006754	R	VBFUPT	006755	R	VBSCB	006761	R	VCHB	006777	R	VCHBPT
007000	R	VCHNHD	007001	R	VCDUN	007002	R	VCVFL	007003	R	VD
007004	R	VDEXP	007005	R	VDT	007006	R	VEDEXP	007007	R	VERN
007010	R	VFDLKY	007011	R	VFSCB	007013	R	VGDRP	007026	R	VIDEXP
007027	R	VIFW	000000	A	VII	007030	R	VIIBSZ	007031	R	VIIWSZ
007032	R	VINFL	007033	R	VIDCON	007034	R	VIDLNK	007035	R	VIDSTA
007036	R	VISCB	007042	R	VITEMA	007043	R	VITEMW	007044	R	VITMIN
007045	R	VITMOD	007046	R	VLISTF	007047	R	VLNKCNT	007050	P	VLRECND
007051	R	VLRSCZ	007052	R	VLRWC	007053	R	VMDV	007054	R	VN
007055	R	VNFF	007056	R	VOPSTK	006727	R	VOPSTP	000002	A	VORTEX
007070	R	VPARLV	007071	R	VPBKC	007072	R	VPBSZ	007073	R	VPBMC
007074	R	VPRECND	007075	R	VPRLIN	007076	R	VPTFL	007077	R	VQFL
007100	R	VRETUR	007101	R	VRWFL	007102	R	VS	007103	R	VSCF
007104	R	VSGFL	007105	R	VSVREC	007106	R	VSYSDC	007111	R	VTEMP



```

007112 R VTEMP1 007113 R VTERM 007114 R VUNIT 007115 R VW
007116 R VMT 007117 R VXFFL 007120 R VXFL 007121 R VXFW
007122 R VXSG 007123 R VZFW 007131 R VZZZ 000170 A W
000000 A WCS 000011 A WR 000452 A WRR 000432 A WRS
000171 A WT 000001 A X 000172 A XFFL 000173 A XFL
000174 A XFW 006534 R XIN 006534 R XOUT 000175 A XSG
000177 A YYY 000420 A ZERO 000176 A ZFW 006550 R ZIN
006572 R Z101 006623 R Z102 006636 R Z104 006667 R Z106
006711 R Z107 006713 R Z108 006725 R Z109 006550 R ZOUT
000204 A ZZZ
0 ERRORS ASSEMBLY COMPLETE
    
```

494	AACC	2199	3063							
496	ABSCB	871	1384	4084	4784					
498	ACC	1014	1016	1017	1019	1020	1022	1023	1025	1371
		1372	1373	1374	1590	1622	1626	1638	1644	1647
		1657	1659	1662	1663	1666	1672	1676	1677	1678
		1705	1709	1713	1717	2321	2331	2333	2334	2336
		2337	2339	2340	2342	2365	2369	2369	2370	2370
		2371	2371	2372	2377	2378	2380	2381	2382	2384
		2385	2386	2388	2389	2947	2948	2949	2951	2965
		2966	2973	2976	2982	2985	2994	2999	3000	3003
		3007	3010	3011	3013	3015	3020	3033	3024	3026
		3028	3029	3031	3033	3034	3038	3039	3039	3040
		3040	3041	3041	3044	3048	3050	3078	3079	3090
		3091	3093	3094	3099	3100	3107	3108	4375	4528
		4529	4531	4532	4533	4535	4536	4537	4539	4540
		4545	4546	4548	4549	4550	4552	4553	4554	4556
		4557								
500	ACHB	1741	1748	2495	2507	2540	4372	4379	4397	
502	ADFCB	954	984	984	2670	2676	2693	2712	2719	2735
		2781	2797	2810	2821	2831	3272	3274	3336	3337
		3430	3500	3506	3508	3627	3676	4104	4205	4227
		4304	4338	4426	4550	4708	4721			
504	AFSCB	1850	1869	1876	2034					
506	AGPAR	1176	1222	1240						
508	AIBUF	707	708	4809	4810					
704	AIN	1481								
719	AIDL1	723								
739	AIDL2	715	743							
509	AISCB	721	739	4831	4837					
175	AL	1213	1289	2106						
511	ALBF	1541	1557	3163	3281	3329	3340	4179	4183	4285
		4299	4325	4327	4437	4644	4654	4654	4663	4666
512	ALOC	775	2656	3191	3617	3807	3988	4489		
514	ANFOJ	767	3959	3860						
516	ANRB	358	363	841	952	979	2635	2673	2694	2793
		2816	2851	3182	3273	3335	3507	3604	3681	3688
		3764	3874	3903	3942	3964	4213	4219	4258	4439
		4471								
518	ADPSTK	819	835	2421	3909	3915	3933			
705	ADUT	1482								
520	APBF	3162	3192	3280	3323	3339	3618	4162	4184	4297
		4435	4645	4671						
66	ARST	445	956	957	961	1168	1259	1267	1289	1346
		1358	1360	1852	1854	2110	2122	2130	2166	2180
		2706	2796	3289	4134	4173	4176	4186	4204	4206
		4656	4700	4704	4705					
522	ASCB	721	739	872	1384	1850	1869	1876	1901	1913
		1933	2034	2885	4083	4784	4831	4837		
67	ASET	453	874	1207	1208	1209	1210	1211	1212	1213
		1288	1440	1441	1442	1545	2017	2018	2036	2105
		2106	2121	2124	2128	2165	2179	2260	3290	3395
		3396	4130	4192	4230	4288	4292	4443	4712	4720
524	ASFL	1197	1375	2412	2470					
526	ASYSDC	3336								
674	AZER	2002	2111	2143	2167	2187	2503	2510	2523	2536
		2543	2575	2579						
68	B	241	242	243	250	252	259	361	277	278
		285	294	310	330	340	348	349	358	363
		386	387	394	395	396	403	405	412	428
		436	444	452	460	477	728	730	732	734
		767	775	799	812	819	835	841	844	971
		872	878	901	907	908	909	917	918	945
		952	954	964	970	978	979	984	991	1053
		1054	1055	1088	1089	1094	1095	1098	1101	1104
		1105	1109	1110	1130	1131	1132	1133	1135	1136
		1137	1161	1162	1163	1164	1166	1172	1173	1176
		1177	1179	1182	1192	1194	1196	1197	1198	1201
		1206	1214	1216	1222	1223	1237	1240	1242	1247
		1252	1257	1266	1271	1272	1273	1277	1279	1286
		1287	1294	1329	1334	1337	1342	1348	1349	1351
		1357	1362	1363	1368	1372	1373	1374	1375	1376
		1377	1378	1379	1380	1381	1382	1383	1385	1392
		1406	1409	1409	1522	1533	1534	1540	1549	1584
		1587	1588	1593	1612	1634	1638	1641	1644	1647
		1653	1657	1659	1660	1663	1666	1672	1676	1677
		1678	1681	1687	1693	1702	1705	1709	1713	1717
		1724	1725	1732	1733	1742	1744	1747	1748	1749
		1770	1774	1776	1804	1806	1811	1812	1814	1848
		1857	1901	1913	1933	2003	2006	2013	2090	2091
		2092	2094	2099	2102	2104	2113	2116	2120	2123



2125	2127	2131	2132	2134	2139	2141	2142	2143
2144	2150	2159	2162	2164	2170	2171	2174	2178
2181	2186	2187	2199	2208	2209	2214	2215	2216
2217	2227	2233	2234	2261	2264	2295	2296	2299
2344	2346	2348	2373	2375	2413	2417	2422	2458
2459	2460	2461	2462	2463	2464	2470	2471	2472
2475	2476	2477	2478	2479	2481	2489	2496	2499
2500	2501	2503	2504	2506	2507	2508	2517	2529
2532	2533	2534	2536	2537	2539	2540	2541	2556
2564	2566	2575	2576	2578	2579	2580	2629	2634
2635	2640	2657	2659	2664	2667	2671	2673	2692
2694	2701	2704	2710	2712	2715	2719	2735	2781
2792	2793	2795	2797	2799	2810	2815	2816	2821
2831	2838	2850	2851	2885	2900	2947	2948	2949
2951	2953	2960	2982	2985	2994	2999	3000	3002
3020	3023	3024	3026	3028	3029	3031	3033	3034
3036	3038	3042	3044	3046	3054	3065	3067	3069
3070	3071	3072	3073	3078	3079	3081	3125	3127
3151	3154	3159	3160	3163	3165	3167	3172	3173
3176	3177	3178	3179	3181	3194	3202	3257	3264
3272	3273	3279	3281	3284	3287	3288	3292	3299
3306	3335	3340	3342	3343	3347	3349	3354	3359
3363	3364	3372	3376	3393	3394	3403	3428	3430
3433	3434	3435	3437	3438	3446	3462	3464	3465
3491	3496	3498	3499	3500	3506	3507	3510	3512
3580	3583	3587	3588	3592	3593	3596	3598	3604
3605	3606	3609	3611	3618	3620	3627	3633	3635
3645	3648	3653	3654	3656	3673	3675	3676	3681
3688	3713	3715	3717	3719	3726	3762	3764	3766
3767	3770	3783	3784	3786	3789	3790	3792	3795
3800	3808	3810	3864	3874	3885	3908	3909	3922
3940	3942	3949	3959	3963	3969	3971	3974	3988
3992	3994	4000	4000	4011	4013	4014	4070	4082
4083	4084	4132	4136	4139	4141	4143	4144	4175
4179	4180	4182	4183	4188	4194	4205	4208	4213
4219	4227	4232	4235	4255	4256	4257	4258	4259
4297	4298	4299	4300	4304	4307	4310	4311	4320
4325	4326	4327	4329	4330	4331	4332	4337	4338
4346	4348	4368	4370	4372	4373	4375	4379	4380
4397	4399	4426	4435	4436	4437	4439	4441	4471
4474	4476	4481	4484	4490	4495	4499	4501	4597
4626	4628	4629	4634	4636	4642	4644	4645	4650
4632	4633	4658	4660	4662	4664	4665	4666	4667
4673	4674	4676	4677	4697	4699	4706	4708	4714
4721	4728	4752	4754	4760	4762	4811	4814	4815
4827	4829	4830	4840	4842	4849	4852	4860	4864
4866	4870							

69	BA	874						
76	B12	2124	2128					
4879	BASE	809	837	845	3877	3884	3902	3965
528	BCHAR	713	720	741	1870	1878	2111	2142
		2186	2264	2291	2295	2299	2417	2482
		2510	2517	2523	2537	2543	2550	2556
		2566	2576	2580	4782	4816	4823	4829
		4860						
529	BCODE	2104	2120	2164	2178			
678	BD120	965	2678	2731	2798	2804	3301	3303
		3324	3341	4322				3310
676	BD14	1749	2508	2541	2659	4370	4373	
530	BEXP	1600	1621	1641	1653	1687	1724	1732
		2233	2234	2373	2375	2390	2392	1733
		3005	3036	3042	3054	3064	3067	2094
		3095					3070	3081
199	BF	119	120					3089
200	BFA	3543	3546					
532	BFPT	1543	3199	3625	4625	4628	4642	4673
119	BFR	3291	3436					
120	BFS	3157	3427	3586	3651			
533	BFWPT	909	917	1533	1541	1547	1549	1557
		4180	4184	4285	4329	4663	4752	3165
		36	3523				4762	4145
0	BIFCB	2018	2036	2110	2166	2260		
176	BL	713	727	2291	2482	2550	2560	4782
680	BLNK1	907						4816
682	BLNK2	122						
88	BM17	3390						
89	BM37	57	3524					
0	BDFCB	3891						
147	BR	119	127	134	140	144	168	
91	BR0	1215	1614	1643	1646	1655	1671	1907
103	BR15	2114	2172					2892
95	BR4	2115	2173					
97	BR6	2133	3690	4215				
99	BR8	120	128	130	132	135	136	141
104	BS0	150	153	169				142
		3652						149
115	BS11	976	2670	3183	3603			
116	BS12	3003	3037					
117	BS14	3105						
118	BS15	109						
107	BS4	121	2995					
111	BS7	3683	4225					
112	BS8	4599						
113	BS9							







130	FRBS	2718								
131	FRM	957								
562	FRMT	906	3161	3400	3600	3602	3636	3767	3790	
863	FRPT	1160	1182	1252						
1160	FRS	3203	3637							
1199	FRS10	1207	1280							
1222	FRS15	1209	1442							
1251	FRS19	1226	1246							
1172	FRS2	1208	1288							
1257	FRS20	1210								
1263	FRS25	1212								
1284	FRS30	1267								
1293	FRS35	1213								
1319	FRS39	1311								
1322	FRS40	1302								
1337	FRS45	1333								
1345	FRS46	1339								
1357	FRS47	1353								
1191	FRS5	1253	1434	1440	1863	2424	4786			
1367	FRS50	1355	1428							
1402	FRS55	1393								
1406	FRS60	1218	1341	1356	1387	1398				
1427	FRS65	726	735	2272	2425	3075	4834			
1433	FRS70	1211	1441							
1438	FRS75	1228								
1439	FRS85	1429	1854	4675						
1447	FRSCHT	1300	1301							
1466	FRSJT	1300	1417							
1301	FRSL1	1314								
564	FSCB	557	558	561	562	563				
1522	GBA	875	4138	4680	4747					
1533	GBA50	1524								
1542	GBA55	1538								
1553	GBA70	1536	1544	1545						
1556	GBA80	1525								
566	GDRPC	568	569	1181	1183	1243	1245	1249	1251	
198	GF	132	2777	2828						
568	GFRPT	1183	1251							
132	GFS	3511								
2940	GIN	1473								
1584	GNI	1402								
1676	GNI10	1601	1628	1648	1660	1668				
1599	GNI2	1595								
1699	GNI20	1689								
1723	GNI25	1701	1704	1708	1712	1716				
1731	GNI30	1700	1707	1711	1715	1719				
1602	GNI4	1590								
1741	GNI50	1682	1688	1727						
1632	GNI8	1603								
1652	GNI9	1605								
1669	GNI9A	1665								
1686	GNI11	1679	1695	1737						
1743	GNI12	1750								
1769	GNI	1233	1367	4746						
1781	GNI2	1772	1773							
0	GDFCB	59	3526							
1804	GOUT	1474								
569	GSRPC	1161	1181	1243	1245	1249				
1839	HIN	1483	1872							
1868	HID10	1849								
1876	HID15	1856	1864							
1850	HID2	1847								
1858	HID4	1852								
1862	HID6	1842								
1840	HOUT	1484	1880							
1901	ICC	740	881	1851	1853	1877	2016	2035	4095	4838
1939	ICCCT	1923	1927							
1962	ICCCT1	1927								
1924	ICCLP	1926								
570	ICHAR	720	727	741	4823	4827	4830	4840	4842	4864
571	IDEXP	4866	4870							
1998	IFF	2090	2211	2211	2215	2328	2346	2348		
2002	IFFL	1263	1347	1361						
2016	IFFL1	2017								
573	IFW	2018								
575	IBSZ	1050	1377	1817	2062	2460	2478	2479	2481	2494
2941	IIN	709	724	3783	4814					
577	IWSZ	1475								
197	IN	3073	3783							
2034	INF	134	135	3276	3348	3395	4172	4229	4434	
579	INFL	1167	1200	1258	1345	1359	1438			
2035	INFLP	3864	3899							
134	INR	2036								
135	INS	2702	4234							
581	IOCONT	2633	4347							
		953	980	2674	2794	2817	2852	3154	3184	3185
		3583	3606	3607	3648	3682	3684	3689	3691	4214
		4216	4224	4226						
583	IDLNK	3464	3496	3509	3509					
585	IDSTAT	4220	4223							
2058	IDUT	1476								
587	ISCB	508	570							
589	ITEMAD	708	1234	1234	1584	1769	1769	2261	2296	3064



		3802	3808	4754	4760	4810	3801	3810				
591	ITEMWC	1235	1235	1770	1781	1781	3801	3810				
593	ITMINC	1234	1235	1769	1781	3784	3789					
595	ITMODE	1588	2953	3765	3766	3770	3795					
2089	IXN	1397										
2142	IXN10	2112										
2150	IXN15	2106										
2169	IXN18	2124	2128									
2171	IXN20	2166										
2186	IXN25	2168	2180									
2195	IXN30	2160	2165									
2113	IXN4	2110										
2127	IXN5	2121										
2199	IXN50	2100	2105									
2210	IXN52	2206										
2212	IXN53	2210										
2215	IXN55	2212										
2221	IXN57	2204										
2222	IXN58	2220										
2130	IXN6	2122										
2232	IXN60	2222										
2139	IXN8	2130										
2100	IXNL1	2126	2129	2135	2146							
2160	IXNL2	2179	2182	2194								
2219	IXNL3	2228	2238									
1241	IXR	1411										
86	LC	155	156	157	159	159	160	161	162	163		
		164	165	166	167							
191	LF	124	136	985	2644	2796	2820	3289	3626	4129		
		4204	4287	4422	4442	4700	4719					
136	LFS	2632										
597	LGDV	966	3327									
137	LHW	2899	3057	3258								
2258	LIN	1479	2260									
2270	LINX	2266										
598	LISTFL	1162	1237	1239	1368							
600	LNKCNT	981	2695	4475								
493	LOC	494	495	496	497	498	499	500	501	502		
		503	504	505	506	507	509	510	512	513		
		514	515	516	517	518	519	520	521	522		
		523	524	525	526	527	530	531	533	534		
		535	536	537	538	539	540	541	542	543		
		544	545	546	547	548	549	550	551	552		
		553	554	555	556	559	560	561	565	566		
		567	571	572	573	574	575	576	577	578		
		579	580	581	582	583	584	585	586	587		
		588	589	590	591	592	593	594	595	596		
		598	599	600	601	602	603	604	605	606		
		607	608	609	610	611	612	613	614	615		
		617	618	619	620	621	622	623	624	625		
		626	627	628	629	630	631	632	633	636		
		637	638	639	640	642	643	644	645	646		
		647	649	650	651	652	653	654	655	656		
		657	658	659	660	661	662	663	664	665		
		660	667	668	669	670	671	672	673	674		
		675	676	677	678	679	680	681	682	683		
		684										
0	LOFCB	55	3522									
2300	LOU4	2297										
2291	LOUT	1480										
178	LP	1168	1208	1288								
602	LRECND	1540	2799	2823	3298	3320	3633	4136	4728			
2898	LRLAS	2901										
604	LRSZ	986	1542	2803	2822	3178	3278	3299	3305	3308		
		3323	3343	3434	3499	3634	4141	4204	4444	4634		
		4668	4709									
606	LRWC	597	900	1534	1542	1554	3179	3634	4131	4135		
		4139	4143	4195	4196	4198	4284	4668				
1981	LSEAB	1911										
2320	M10	1735	1743	2145	2236							
2330	M104	2323	2325									
2349	M10X	2327	2345									
80	MAP	796	1298	1319	1326	1415	1421	1921	1931	2842		
		2848	3467	3425	3444	3473	3481	3773	3781	3862		
		3863	3875	3892	3979	4018	4024					
179	MN	1210	2122	2180								
608	MDV	1742	2091	2324								
87	MT	88	89	90	91	92	93	94	95	96		
		97	98	99	100	101	102	103	104	105		
		106	107	108	110	111	112	113	114	115		
		116	117	118	123	125	133	137	138	139		
		143	145	146	151	152	154	170				
610	N	633	1215	1362	4783							
612	NFF	1272	1285	1348	1362	1998	2003	2006	2015			
138	NINE	220	3468									
180	NM	1212	1259	1346	1360	2017						
2364	NRM	1686	2219									
2377	NRM4	2368										
2365	NRML	2376	2393									
2394	NRMX	2367										
20	NUC	21	23	23	45	47	769	792	1295	1303		
		1315	1323	1412	1418	1918	1928	2652	2839	2845		
		3187	3404	3422	3441	3470	3478	3613	3772	3778		











4439	RPB11	4434								
4441	RPB12	4438								
4444	RPB15	4442								
4446	RPB20	4443								
637	RWFL	715	728	730	732	734	877	881	905	945
		985	1393	1409	1525	1544	1856	1864	2634	2644
		2701	2714	2764	2766	2777	2789	2795	2820	2828
		3159	3186	3186	3200	3263	3276	3287	3288	3292
		3348	3393	3394	3435	3438	3510	3512	3587	3608
		3608	3626	3630	3653	3673	3675	3687	4087	4129
		4172	4175	4185	4188	4203	4208	4212	4229	4232
		4235	4287	4333	4337	4346	4348	4422	4434	4442
		4655	4658	4662	4697	4699	4706	4719	4723	4748
		4818								
639	S	1086	1092	1099	1101	1105	1110	1130	1136	1164
		1277	2214							
641	SAVE	2636	2641	2642	2643	2645	2646	2647	2657	2664
		2665	2667	2671	2673	2679	2704	2710	2711	2715
		2732	2763	2770	2838	3347	3376	3403	3446	3491
		4195	4198	4625	4629	4655	4660	4669	4674	4676
		4677								
196	SC	144	150	4230						
642	SCF	1195	1271	1333	1392	2195	2212			
4471	SCH	949	3267							
4498	SCH5	4489								
4481	SCHLP	4503								
4504	SCHX	4500								
4505	SCHY	4482								
144	SCR	4233								
150	SCS	4661								
145	SEVEN	218	3449	4855	4857	4869				
644	SGFL	1199	1257	1273	1284	1379	1587	1634	2125	2459
		2487	2981	3046	3098					
194	SH	124	126		131	2703	3286			
4520	SHA	1726	1734	2235						
4545	SHA50	4521								
4521	SHAL	4541								
4558	SHAX	4522								
0	SIFCB	53	3502	3519						
146	SIX	217								
186	SL	1211	1441							
1904	SDF	4086								
0	SSFCB	58	3525							
209	STKSZ	615	634	842	845	3876	3884	3967	4896	4939
646	SVRECM	3277	4714							
648	SYSBF	2636								
649	SYSDCB	648								
4580	TBK	2658	2660	3193	3196	3619	3622	3809	3812	3951
		3953	3955	3957	3961	4035	4492	4494		
4591	TBK10	4581	4585							
4599	TBKJMP	4592								
651	TEMP	908	915	1612	1617	1618	1623	2629	2763	2886
		2900	2965	2974	2977	3009	3015	3063	3065	3069
		3151	3354	3359	3363	3364	3372	3428	3437	3580
		3645	3654	3656	3713	3719	3726	3530	3940	3971
		3994	4014	4310	4320	4323	4326	4331	4490	4495
653	TEMP1	900	903	904	913					
151	TEN	221	1015	1018	1021	1024	2009	2190	2332	2335
		2338	2341	2571	3952	4392	4853			
655	TERM	1383	2144	2330						
152	THREE	213	1699	2987	3381	3798				
4622	TIN	1487								
4642	TID10	4630								
4659	TID15	4656								
4663	TID20	4646								
4673	TIDL	4638	4679	4681						
4623	TOUT	1488								
195	TR	153	1545	4134						
4697	TRM	4041								
4708	TRM10	4705								
4717	TRM20	4700	4704							
4723	TRM30	4719								
4728	TRMI	4715								
153	TRS	4698								
154	TWO	212	1340	1343	1589	1604	2153	2954	2989	3457
		3466	3494	3590	3796					
4746	UID	3636	4756	4764						
4760	UID4	4748								
657	UNIT	953	978	2700	2792	2815	2850	3173	3181	3257
		3284	3349	3462	3463	3605	4011	4193	4499	
156	V\$CPL	3456	3869	4596						
157	V\$CRS	798	3890							
158	V\$DSTB	3380								
0	V\$EXEC	61								
160	V\$LLUP	4583	4586							
159	V\$LUP	4530	4532	4591						
161	V\$LUT1	3352	3489							
3986	V\$RER1	34								
43	V\$RERF	28	40							
46	V\$RERN	35								
3856	V\$RERR	33								
42	V\$RERS	26	38							
164	V\$ST0	1298	1415	1921	2842	3407	3473	3775	4018	







```

000004 A 1 VORTEX SET 4 PUT LAST FOR VORTEX 07 00001
2 * 07 00002
3 ***** 07 00003
4 * 07 00004
5 * REENTRANT RUN-TIME I/O 07 00005
6 * 07 00006
7 * NAME: SOFTWARE: VSRERS 07 00007
8 * FIRMWARE: VSRERF 07 00008
9 * 07 00009
10 * BITS IN FLAG WORD 'VORTEX' ARE DEFINED THUS: 07 00010
11 * 07 00011
12 * BIT 0: SET FOR VORTEX II 07 00012
13 * BIT 1: SET IF VSRERR IN NUCLEUS 07 00013
14 * BIT 2: SET IF WCS AVAILABLE 07 00014
15 * 07 00015
16 * 07 00016
17 ***** 07 00017
000001 A 19 WCS SET VORTEX/4 SET WCS=BIT 2 OF VORTEX FG 07 00019
000004 A 20 NUC SET WCS#4 FG 07 00020
000000 A 21 VII SET VORTEX-NUC FG 07 00021
000000 A 22 NUC SET VII/2 SET NUC=BIT 1 OF VORTEX FG 07 00022
000000 A 23 VII SET VII-NUC-NUC SET VII=BIT 0 OF VORTEX FG 07 00023
25 IFF WCS 07 00025
26 TITLE VSRERS SOFTWARE NAME 07 00026
27 IFT WCS 07 00027
28 TITLE VSRERF FIRMWARE NAME 07 00028
30 ***** 07 00030
31 * ENTRIES * 07 00031
32 ***** 07 00032
33 NAME VSRERR ALOC ENTRY 07 00033
34 NAME VSRER1 NON-ALOC ENTRY 07 00034
35 NAME VSRERN VSRERR NUCLEUS FLAG V2 07 00035
37 IFF WCS 07 00037
38 NAME VSRERS SOFTWARE NAME 07 00038
39 IFT WCS 07 00039
40 NAME VSRERF FIRMWARE NAME 07 00040
000000 R 42 VSRERS EQU * SOFTWARE NAME 07 00042
000000 R 43 VSRERF EQU * FIRMWARE NAME 07 00043
45 IFT NUC FG 07 00045
46 VSRERN EQU 1 VSRERN = 1 IF VSRERR IN NUCLEUS FG 07 00046
47 IFF NUC FG 07 00047
000000 A 48 VSRERN EQU 0 VSRERN = 0 IF VSRERR IN DM FG 07 00048
50 ***** 07 00050
51 * EXTERNALS * 07 00051
52 ***** 07 00052
53 EXT SIFCB 07 00053
54 EXT PIFCB 07 00054
55 EXT LDPCB 07 00055
56 EXT BIFCB 07 00056
57 EXT BDFCB 07 00057
58 EXT SSFCB 07 00058
59 EXT GDFCB 07 00059
60 EXT POFCB 07 00060
61 EXT V$EXEC VORTEX EXEC 07 00061
63 ***** 07 00063
64 * VDM 620/I INSTRUCTION SYMBOLS * 07 00064
65 ***** 07 00065
000040 A 66 ARST SET 040 A-REG BIT RESET 07 00066
000000 A 67 ASET SET 0 A-REG BIT SET 07 00067
000002 A 68 B SET 2 B-REGISTER 07 00068
000000 A 69 B0 SET 0 07 00069
000001 A 70 B1 SET 1 07 00070
000002 A 71 B2 SET 2 07 00071
000003 A 72 B3 SET 3 07 00072
000004 A 73 B4 SET 4 07 00073
000005 A 74 B5 SET 5 07 00074
000006 A 75 B6 SET 6 07 00075
000014 A 76 B12 SET 12 07 00076
000015 A 77 B13 SET 13 07 00077
000016 A 78 B14 SET 14 07 00078
000017 A 79 B15 SET 15 07 00079
000046 A 80 MAP SET 046 MAP DEVICE ADDRESS V2 07 00080
000001 A 81 X SET 1 X-REGISTER 07 00081
83 ***** 07 00083
84 * VORTEX LOW-CORE SYMBOLS * 07 00084
85 ***** 07 00085
000300 A 86 LC SET 0000 07 00086
000420 A 87 MT SET 0420 07 00087
000472 A 88 BM17 SET MT+42 07 00088
000473 A 89 BM37 SET MT+43 07 00089
000474 A 90 BM77 SET MT+44 07 00090
000441 A 91 BR0 SET MT+17 07 00091
000442 A 92 BR1 SET MT+18 07 00092
000443 A 93 BR2 SET MT+19 07 00093
000444 A 94 BR3 SET MT+20 07 00094
000445 A 95 BR4 SET MT+21 07 00095
000446 A 96 BR5 SET MT+22 07 00096
000447 A 97 BR6 SET MT+23 07 00097
000450 A 98 BR7 SET MT+24 07 00098
000451 A 99 BR8 SET MT+25 07 00099
000454 A 100 BR11 SET MT+28 07 00100
000455 A 101 BR12 SET MT+29 07 00101
000457 A 102 BR14 SET MT+31 07 00102

```



000460	A	103	BR15	SET	MT+32				07	00103
000421	A	104	BS0	SET	MT+1			V2	07	00104
000422	A	105	BS1	SET	MT+2				07	00105
000424	A	106	BS3	SET	MT+4				07	00106
000425	A	107	BS4	SET	MT+5				07	00107
000426	A	108	BS5	SET	MT+6				07	00108
000425	A	109	D16	SET	BS4				07	00109
000423	A	110	BS2	SET	MT+3				07	00110
000430	A	111	BS7	SET	MT+8				07	00111
000431	A	112	BS8	SET	MT+9				07	00112
000432	A	113	BS9	SET	MT+10				07	00113
000433	A	114	BS10	SET	MT+11				07	00114
000434	A	115	BS11	SET	MT+12				07	00115
000435	A	116	BS12	SET	MT+13				07	00116
000437	A	117	BS14	SET	MT+15				07	00117
000440	A	118	BS15	SET	MT+16				07	00118
000451	A	119	BFR	SET	BR0+BF	RESET BF FLAG		V2	07	00119
000431	A	120	BFS	SET	BR0+BF	SET BF FLAG		V2	07	00120
000430	A	121	BXBIAS	SET	BS7	BINARY EXPONENT BIAS		V2	07	00121
000472	A	122	D15	SET	DM17				07	00122
000465	A	123	FIVE	SET	MT+37				07	00123
000015	A	124	FLF	SET	SH+LF	FCB LF FLAG		V2	07	00124
000423	A	125	FOUR	SET	MT+3				07	00125
000016	A	126	FPD	SET	SH+PD	FCB PD FLAG		V2	07	00126
000457	A	127	FPDR	SET	BR0+FPD	RESET FCB PD FLAG		V2	07	00127
000437	A	128	FPOS	SET	FSC+FPD	SET FCB PD FLAG		V2	07	00128
000017	A	129	FRB	SET	SH+RB	FCB RB FLAG		V2	07	00129
000440	A	130	FRBS	SET	BS0+FRB	SET FCB RB FLAG		V2	07	00130
000014	A	131	FRM	SET	SH+RM	FCB RM FLAG		V2	07	00131
000430	A	132	GFS	SET	BS0+GF	SET GLOBAL FCB FLAG		V2	07	00132
000424	A	133	EIGHT	SET	MT+4				07	00133
000447	A	134	INR	SET	BR0+IN	RESET IN BIT		V2	07	00134
000427	A	135	INS	SET	BS0+IN	SET IN FLAG		V2	07	00135
000422	A	136	LFS	SET	BS0+LF	SET LF FLAG		V2	07	00136
000462	A	137	LHW	SET	MT+34				07	00137
000470	A	138	NINE	SET	MT+40				07	00138
000421	A	139	ONE	SET	MT+1				07	00139
000443	A	140	PDR	SET	BR0+PD	RESET PD FLAG		V2	07	00140
000423	A	141	PDS	SET	BS0+PD	SET PD FLAG		V2	07	00141
000424	A	142	RDS	SET	BS0+RB	SET RB BIT		V2	07	00142
000463	A	143	RHW	SET	MT+35				07	00143
000446	A	144	SCR	SET	BR0+SC	RESET SC BIT		V2	07	00144
000467	A	145	SEVEN	SET	MT+39				07	00145
000466	A	146	SIX	SET	MT+38				07	00146
000001	A	147	BR	SET	1	STACK B-REGISTER		V2	07	00147
000003	A	148	PR	SET	3	STACK P-REGISTER		V2	07	00148
000421	A	149	RMS	SET	BR0+RM	SET RM BIT		V2	07	00149
000426	A	150	SOS	SET	BS0+SC	SET SC BIT		V2	07	00150
000471	A	151	TEN	SET	MT+41				07	00151
000464	A	152	THREE	SET	MT+36				07	00152
000425	A	153	TRS	SET	BS0+TR	SET TR BIT		V2	07	00153
000422	A	154	TWO	SET	MT+2				07	00154
000414	A	155	V\$BVN	SET	LC+76	BOTTOM OF VORTEX NUCLEUS			07	00155
000301	A	156	V\$CPL	SET	LC+1	CURRENT PRIORITY LEVEL			07	00156
000302	A	157	V\$CRS	SET	LC+2	POINTER TO REENRANT STACK			07	00157
000355	A	158	V\$STB	SET	LC+45				07	00158
000316	A	159	V\$LUP	SET	LC+14	1ST WORD OF BACKGROUND			07	00159
000317	A	160	V\$LLUP	SET	LC+15	LAST WORD OF BACKGROUND			07	00160
000400	A	161	V\$LUT1	SET	LC+64				07	00161
000401	A	162	V\$LUT2	SET	LC+65				07	00162
000402	A	163	V\$LUT3	SET	LC+66				07	00163
000334	A	164	V\$ST0	SET	LC+28	EXEC STATE 0		V2	07	00164
000335	A	165	V\$ST1	SET	LC+29	EXEC STATE 1		V2	07	00165
000336	A	166	V\$ST2	SET	LC+30	EXEC STATE 2		V2	07	00166
000337	A	167	V\$ST3	SET	LC+31	EXEC STATE 3		V2	07	00167
000452	A	168	WR	SET	BR0+WR	RESET WR BIT		V2	07	00168
000432	A	169	WRS	SET	BS0+WR	SET WR BIT		V2	07	00169
000420	A	170	ZERO	SET	MT				07	00170
172			*****						07	00171
173			* CHARACTER TYPE FLAGS *						07	00173
174			*****						07	00174
000000	A	175	AL	SET	0	ALPHA CHAR BIT(EXCEPT P)			07	00175
000001	A	176	BL	SET	1	BLANK CHAR BIT			07	00176
000002	A	177	CM	SET	2	'.' CHAR BIT			07	00177
000003	A	178	LP	SET	3	'<' CHAR BIT			07	00178
000004	A	179	MN	SET	4	'-' CHAR FLAG			07	00179
000005	A	180	NM	SET	5	NUMERIC CHAR BIT			07	00180
000006	A	181	PL	SET	6	'+' CHAR BIT			07	00181
000007	A	182	PS	SET	7	'P' SCALE FACTOR			07	00182
000010	A	183	PT	SET	8	'.' CHAR BIT			07	00183
000011	A	184	QT	SET	9	' ' CHAR BIT			07	00184
000012	A	185	RP	SET	10	'>' CHAR BIT			07	00185
000013	A	186	SL	SET	11	'/' CHAR BIT			07	00186
187			*****						07	00187
188			* READ/WRITE FLAGS *						07	00188
189			*****						07	00189
000000	A	190	RM	SET	0	RMD FLAG		V2	07	00190
000001	A	191	LF	SET	1	LOGICAL FILE FLAG		V2	07	00191
000002	A	192	PD	SET	2	BUFFER POSTING FLAG		V2	07	00192
000003	A	193	RB	SET	3	READ BEFORE WRITE FLAG		V2	07	00193
000014	A	194	SA	SET	15-RB	FCB CONTROL FLAG SHIFT		V2	07	00194
000004	A	195	TR	SET	4	TERMINATE FLAG		V2	07	00195
000005	A	196	SC	SET	5	SUPPRESS CLEAR		V2	07	00196



```

000006 A 197 IN SET 6 INITIALIZE FLAG V2 07 00197
000007 A 198 GF SET 7 GLOBAL FCB FLAG V2 07 00198
000010 A 199 BF SET 8 BUFFER FILL FLAG V2 07 00199
000400 A 200 BFA SET 0400 BF ABS VALUE 07 00200
000011 A 201 WR SET 9 WRITE FLAG V2 07 00201
000012 A 202 EC SET 10 ENCODE/DECODE FLAF PD 07 00202
000013 A 203 DA SET 11 DIRECT ACCESS FLAG 07 00203
204 07 00204
206 ***** 07 00206
207 * STACK OPS * 07 00207
208 ***** 07 00208
000012 A 209 STKSZ SET 10 STACK SIZE 07 00209
000420 A 210 CXC SET ZERO CALL EXEC FOR IDLINK 07 00210
000421 A 211 CER SET ONE CALL ERROR 07 00211
000422 A 212 CEX SET TWO CALL EXIT 07 00212
000464 A 213 CJD SET THREE CALL I/O 07 00213
000423 A 214 CRB SET FOUR CALL REENTRANT BLOCK 07 00214
000465 A 215 CTR SET FIVE TERMINATE 07 00215
000005 A 216 CTRV SET 5 07 00216
000466 A 217 CXF SET SIX PARAMETER XFER V2 07 00217
000467 A 218 CBK SET SEVEN BACKSPACE V2 07 00218
000424 A 219 CEF SET EIGHT ENDFILE V2 07 00219
000470 A 220 CRW SET NINE REWIND V2 07 00220
000471 A 221 CRD SET TEN READ V2 07 00221
222 *CHR SET ELEVEN WRITE V2 07 00222
223 *CCL SET TWELVE CLOSE FILE V2 07 00223
224 *CCB SET THIRTEEN CLOSE BLOCKED FILE V2 07 00224
225 *COP SET FOURTEEN OPEN FILE V2 07 00225
000016 A 226 CDPV SET 14 07 00226
227 *CDB SET FIFTEEN OPEN BLOCKED FILE V2 07 00227
000020 A 228 CDC SET 16 DECODE PD 07 00228
000021 A 229 CEN SET 17 ENCODE PD 07 00229
000022 A 230 CRA SET 18 DIRECT ACCESS READ 07 00230
231 *CWA SET 19 DIRECT ACCESS WRITE 07 00231
233 ***** 07 00233
234 * MACROS * 07 00234
235 ***** 07 00235
237 ***** 07 00237
238 * ADD B-REF TO B-REF INTO B-REF * 07 00238
239 ***** 07 00239
240 ADEBB MAC 07 00240
241 LDA P(1),B 07 00241
242 ADD P(2),B 07 00242
243 STA P(3),B 07 00243
244 EMAC 07 00244
246 ***** 07 00246
247 * DECREMENT/IN A/B-REF * 07 00247
248 ***** 07 00248
249 DAB MAC 07 00249
250 LDA P(1),B 07 00250
251 DAR 07 00251
252 STA P(1),B 07 00252
253 EMAC 07 00253
255 ***** 07 00255
256 * DECREMENT B-REF/IN A/TO B-REF * 07 00256
257 ***** 07 00257
258 DABB MAC 07 00258
259 LDA P(1),B 07 00259
260 DAR 07 00260
261 STA P(2),B 07 00261
262 EMAC 07 00262
264 ***** 07 00264
265 * DECREMENT/IN A/X-REF * 07 00265
266 ***** 07 00266
267 DAX MAC 07 00267
268 LDA P(1),X 07 00268
269 DAR 07 00269
270 STA P(1),X 07 00270
271 EMAC 07 00271
273 ***** 07 00273
274 * MOVE B-REF OP TO B-REF OP THRU A * 07 00274
275 ***** 07 00275
276 MOVBAB MAC 07 00276
277 LDA P(1),B 07 00277
278 STA P(2),B 07 00278
279 EMAC 07 00279
281 ***** 07 00281
282 * MOVE B-REF TO X-REF THRU A * 07 00282
283 ***** 07 00283
284 MOVBA X MAC 07 00284
285 LDA P(1),B 07 00285
286 STA P(2),X 07 00286
287 EMAC 07 00287
289 ***** 07 00289
290 * MOVE P-REF OP TO B-REF OP THRU A * 07 00290
291 ***** 07 00291
292 MOVPA B MAC 07 00292
293 LDA P(1) 07 00293
294 STA P(2),B 07 00294
295 EMAC 07 00295
297 ***** 07 00297
298 * MOVE P-REF/ THRU A/ TO X-REF * 07 00298
299 ***** 07 00299

```



```

300 MOVPAZ MAC
301 LDA P(1)
302 STA P(2),X
303 EMAC
305 *****
306 * MOVE X-REF TO B-REF THRU A *
307 *****
308 MOVXAB MAC
309 LDA P(1),X
310 STA P(2),B
311 EMAC
313 *****
314 * MOVE X-REF TO X-REF THRU A *
315 *****
316 MOVXAX MAC
317 LDA P(1),X
318 STA P(2),X
319 EMAC
321 *****
322 * POP/JUMP *
323 *****
325 POPJ MAC
326 IFF WCS
327 GOTO WCS1
328 DATA 0105065
329 GOTO WCS2
330 WCS1 CONT
331 JMP POPJ
332 WCS2 CONT
333 EMAC
335 *****
336 * POP DP TO X *
337 *****
338 POPX MAC
339 LDX DPSTKP,B
340 INR DPSTKP,B
341 LDX 0,X
342 EMAC
344 *****
345 * PUSH P(1) *
346 *****
347 PUSH MAC
348 INR DPSTKP,B
349 LDX DPSTKP,B
350 LDA P(1)
351 STA 0,X
352 EMAC
353 *****
354 * PUSH DP ONTO V$FORTID STACK *
355 *****
357 PUSHF MAC
358 LDX ANRB,B
359 LDX DPSTKP,X
360 DXR
361 STA 0,X
362 TXA
363 LDX ANRB,B
364 STA DPSTKP,X
365 EMAC
367 *****
368 * PUSH/JUMP TO P(1) *
369 *****
370 PUSHJ MAC
371 IFF WCS
372 GOTO WCS1
373 DATA 0105025
374 DATA P(1)
375 GOTO WCS2
376 WCS1 CONT
377 LDAI P(1)
378 JSR PSJ,X
379 WCS2 CONT
380 EMAC
382 *****
383 * SUBTRACT B-REF MINUS B-REF *
384 *****
385 SUTBB MAC
386 LDA P(1),B
387 SUB P(2),B
388 EMAC
390 *****
391 * SUBTRACT B-REF MINUS B-REF TO B-REF *
392 *****
393 SUTBBB MAC
394 LDA P(1),B
395 SUB P(2),B
396 STA P(3),B
397 EMAC
399 *****
400 * SUBTRACT B-REF MINUS P-REF TO B-REF *
401 *****
402 SUTBPP MAC
403 LDA P(1),B

```

```

07 00300
07 00301
07 00302
07 00303
07 00305
07 00306
07 00307
07 00308
07 00309
07 00310
07 00311
07 00313
07 00314
07 00315
07 00316
07 00317
07 00318
07 00319
FG 07 00321
FG 07 00322
FG 07 00323
FG 07 00325
FG 07 00326
FG 07 00327
FG 07 00328
FG 07 00329
FG 07 00330
FG 07 00331
FG 07 00332
FG 07 00333
V2 07 00335
V2 07 00336
V2 07 00337
07 00338
07 00339
FG 07 00340
FG 07 00341
07 00342
V2 07 00344
V2 07 00345
V2 07 00346
07 00347
07 00348
07 00349
07 00350
07 00351
07 00352
07 00353
07 00354
07 00355
07 00357
07 00358
FG 07 00360
07 00361
FG 07 00362
FG 07 00363
FG 07 00364
07 00365
07 00367
V2 07 00368
07 00369
07 00370
FG 07 00371
FG 07 00372
FG 07 00373
FG 07 00374
FG 07 00375
FG 07 00376
V2 07 00377
07 00378
FG 07 00379
07 00380
07 00382
07 00383
07 00384
07 00385
07 00386
07 00387
07 00388
07 00390
07 00391
07 00392
07 00393
07 00394
07 00395
07 00396
07 00397
07 00399
07 00400
07 00401
07 00402
07 00403

```



```

404 SUB P(2)
405 STA P(3),B
406 EMAC
408 *****
409 * TEST NEGATIVE/IN A/B-REF *
410 *****
411 TNAB MAC
412 LDA P(1),B
413 JAN P(2)
414 EMAC
416 *****
417 * TEST NEGATIVE/IN A/X-REF *
418 *****
419 TNAX MAC
420 LDA P(1),X
421 JAN P(2)
422 EMAC
424 *****
425 * TEST NOT ZERO/IN A/B-REF *
426 *****
427 TNZAB MAC
428 LDA P(1),B
429 JANZ P(2)
430 EMAC
432 *****
433 * TEST POSITIVE/IN A/B-REF *
434 *****
435 TPAB MAC
436 LDA P(1),B
437 JAP P(2)
438 EMAC
440 *****
441 * TEST BIT/RESET/IN A/B-REF *
442 *****
443 TRAB MAC
444 LDA P(1),B
445 BT ARST+P(2),P(3)
446 EMAC
448 *****
449 * TEST BIT/SET/IN A/B-REF *
450 *****
451 TSAB MAC
452 LDA P(1),B
453 BT ASET+P(2),P(3)
454 EMAC
456 *****
457 * TEST ZERO/ IN A / B-REF *
458 *****
459 TZAB MAC
460 LDA P(1),B
461 JAZ P(2)
462 EMAC
464 *****
465 * TEST ZERO/IN A/X-REF *
466 *****
467 TZAX MAC
468 LDA P(1),X
469 JAZ P(2)
470 EMAC
472 *****
473 * ZERO THRU A/B-REF *
474 *****
475 ZAB MAC
476 TZA
477 STA P(1),B
478 EMAC
479 *****
480 * ZERO X-REF THRU A *
481 *****
482 ZAX MAC
483 TZA
484 STA P(1),X
485 EMAC
486 EJEC
487 *****

```

V2  
V2  
V2  
V2  
V2  
V2

```

07 00404
07 00405
07 00406
07 00408
07 00409
07 00410
07 00411
07 00412
07 00413
07 00414
07 00416
07 00417
07 00418
07 00419
07 00420
07 00421
07 00422
07 00424
07 00425
07 00426
07 00427
07 00428
07 00429
07 00430
07 00432
07 00433
07 00434
07 00435
07 00436
07 00437
07 00438
07 00440
07 00441
07 00442
07 00443
07 00444
07 00445
07 00446
07 00448
07 00449
07 00450
07 00451
07 00452
07 00453
07 00454
07 00456
07 00457
07 00458
07 00459
07 00460
07 00461
07 00462
07 00464
07 00465
07 00466
07 00467
07 00468
07 00469
07 00470
07 00472
07 00473
07 00474
07 00475
07 00476
07 00477
07 00478
07 00479
07 00480
07 00481
07 00482
07 00483
07 00484
07 00485
07 00486
07 00487
07 00488

```

B A S E - R E L A T I V E S Y M B O L S

000001 A	493 LDC	SET	1				
000001 A	494 AACC	SET	LDC	ADDRESS OF ACCUMULATOR ACC	V2	07	00494
000002 A	495 LDC	SET	LDC+1		V2	07	00495
000002 A	496 ABSCB	SET	LDC	ADDRESS OF BUFFER SCB	V2	07	00496
000003 A	497 LDC	SET	LDC+1		V2	07	00497
000003 A	498 ACC	SET	LDC	4-WORD ACCUMULATOR	V2	07	00498
000007 A	499 LDC	SET	LDC+4		V2	07	00499
000007 A	500 ACHB	SET	LDC	ADDRESS OF DECIMAL DIGIT ARRAY	V2	07	00500
000010 A	501 LDC	SET	LDC+1		V2	07	00501
000010 A	502 ADFCB	SET	LDC	DCB/FCB ADDRESS	V2	07	00502
000011 A	503 LDC	SET	LDC+1		V2	07	00503
000011 A	504 AFSCB	SET	LDC	ADDRESS OF FORMAT SCB	V2	07	00504
000012 A	505 LDC	SET	LDC+1		V2	07	00505
000012 A	506 AGPAR	SET	LDC	ADDRESS OF '*' GROUP BLOCK	V2	07	00506



000013	A	507	LDC	SET	LDC+1		V2	07	00507
000110	A	508	ATBUF	SET	YSCB+1	LIST ITEM ADDRESS	V2	07	00508
000013	A	509	ATSCB	SET	LDC	ADDRESS OF LIST ITEM SCB	V2	07	00509
000014	A	510	LDC	SET	LDC+1		V2	07	00510
000027	A	511	ALBF	SET	BSCB+1	ADDRESS OF LOGICAL BUFFER	V2	07	00511
000014	A	512	ALDC	SET	LDC	ALDC ENTRY FLAG	V2	07	00512
000015	A	513	LDC	SET	LDC+1		V2	07	00513
000015	A	514	ANPOJ	SET	LDC	ADDRESS OF V\$FORTIO POP/JUMP	V2	07	00514
000016	A	515	LDC	SET	LDC+1		V2	07	00515
000016	A	516	ANRB	SET	LDC	ADDRESS OF V\$FORTIO DATA BLOCK	V2	07	00516
000017	A	517	LDC	SET	LDC+1		V2	07	00517
000017	A	518	ADPSTK	SET	LDC	ADDRESS OF DP STACK	V2	07	00518
000020	A	519	LDC	SET	LDC+1		V2	07	00519
000020	A	520	APRF	SET	LDC	ADDRESS OF PHYSICAL BUFFER	V2	07	00520
000021	A	521	LDC	SET	LDC+1		V2	07	00521
000021	A	522	ASCB	SET	LDC	SCAN BLOCK ADDRESS	V2	07	00522
000022	A	523	LDC	SET	LDC+1		V2	07	00523
000022	A	524	ASFL	SET	LDC	'*' FLAG	V2	07	00524
000023	A	525	LDC	SET	LDC+1		V2	07	00525
000023	A	526	ASYSDC	SET	LDC	ADDRESS OF SYSTEM DCB	V2	07	00526
000024	A	527	LDC	SET	LDC+1		V2	07	00527
000030	A	528	BCHAR	SET	BSCB+2	BUFFER CHARACTER	V2	07	00528
000031	A	529	BCDDE	SET	BSCB+3	BUFFER CHARACTER CODE	V2	07	00529
000024	A	530	BEXP	SET	LDC	BINARY EXPONENT	V2	07	00530
000025	A	531	LDC	SET	LDC+1		V2	07	00531
000026	A	532	BFPT	SET	BSCB	BUFFER CHARACTER POINTER	V2	07	00532
000025	A	533	BFWPT	SET	LDC	BUFFER WORD POINTER	V2	07	00533
000026	A	534	LDC	SET	LDC+1		V2	07	00534
000026	A	535	BSCB	SET	LDC	BUFFER SCB	V2	07	00535
000032	A	536	LDC	SET	LDC+4		V2	07	00536
000032	A	537	CHB	SET	LDC	DECIMAL DIGIT ARRAY	V2	07	00537
000050	A	538	LDC	SET	LDC+14		V2	07	00538
000050	A	539	CHBPT	SET	LDC	CHB ARRAY POINTER	V2	07	00539
000051	A	540	LDC	SET	LDC+1		V2	07	00540
000051	A	541	CHNHDR	SET	LDC	FCB CHAIN HEADER	V2	07	00541
000052	A	542	LDC	SET	LDC+1		V2	07	00542
000052	A	543	COUNT	SET	LDC	COUNTER	V2	07	00543
000053	A	544	LDC	SET	LDC+1		V2	07	00544
000053	A	545	CVFL	SET	LDC	CHARACTER VALIDITY FLAGS	V2	07	00545
000054	A	546	LDC	SET	LDC+1		V2	07	00546
000054	A	547	D	SET	LDC	FRACTIONAL FIELD WIDTH	V2	07	00547
000055	A	548	LDC	SET	LDC+1		V2	07	00548
000055	A	549	DEXP	SET	LDC	DECIMAL EXPONENT	V2	07	00549
000056	A	550	LDC	SET	LDC+1		V2	07	00550
000056	A	551	DT	SET	LDC	WORKING FRACTIONAL FIELD WIDTH	V2	07	00551
000057	A	552	LDC	SET	LDC+1		V2	07	00552
000057	A	553	EDEXP	SET	LDC	EXPLICIT DECIMAL EXPONENT	V2	07	00553
000060	A	554	LDC	SET	LDC+1		V2	07	00554
000060	A	555	ERN	SET	LDC	ERROR NUMBER	V2	07	00555
000061	A	556	LDC	SET	LDC+1		V2	07	00556
000064	A	557	FCHAR	SET	FSCB+2	FORMAT CHARACTER	V2	07	00557
000065	A	558	FCDDE	SET	FSCB+3	FORMAT CHARACTER CODE	V2	07	00558
000061	A	559	FDLKEY	SET	LDC	FIELD DESCRIPTOR KEY	V2	07	00559
000062	A	560	LDC	SET	LDC+1		V2	07	00560
000062	A	561	FMPT	SET	FSCB	FORMAT STRING POINTER	V2	07	00561
000063	A	562	FRMT	SET	FSCB+1	ADDRESS OF FORMAT STRING(0 IF NONE)	V2	07	00562
000062	A	563	FRPT	SET	FSCB	FORMAT STRING CURRENT POINTER	V2	07	00563
000062	A	564	FSCB	SET	LDC	FORMAT STRING SCB	V2	07	00564
000066	A	565	LDC	SET	LDC+4		V2	07	00565
000066	A	566	GDRFC	SET	LDC	'*' GROUP DYNAMIC REPEAT COUNT	V2	07	00566
000077	A	567	LDC	SET	LDC+9		V2	07	00567
000071	A	568	GRPT	SET	GDRFC+3	'*' GROUP FORMAT POINTER	V2	07	00568
000074	A	569	GSRFC	SET	GDRFC+6	'*' GROUP STATIC REPEAT COUNT	V2	07	00569
000111	A	570	ICHAR	SET	ISCB+2	LIST ITEM CHARACTER	V2	07	00570
000077	A	571	IDEXP	SET	LDC	IMPLICIT DECIMAL EXPONENT	V2	07	00571
000100	A	572	LDC	SET	LDC+1		V2	07	00572
000100	A	573	IFW	SET	LDC	INTEGER FIELD WIDTH	V2	07	00573
000101	A	574	LDC	SET	LDC+1		V2	07	00574
000101	A	575	IIBSZ	SET	LDC	INDIVIDUAL ITEM BYTE SIZE	V2	07	00575
000102	A	576	LDC	SET	LDC+1		V2	07	00576
000102	A	577	IIBSZ	SET	LDC	INDIVIDUAL ITEM WORD SIZE	V2	07	00577
000103	A	578	LDC	SET	LDC+1		V2	07	00578
000103	A	579	INFL	SET	LDC	INITIAL ENTRY FLAG	V2*	07	00579
000104	A	580	LDC	SET	LDC+1		V2	07	00580
000104	A	581	IOCONT	SET	LDC	V\$DC CONTROL WORD	V2	07	00581
000105	A	582	LDC	SET	LDC+1		V2	07	00582
000105	A	583	IOINK	SET	LDC	IOLINK CONTROL WORD	V2	07	00583
000106	A	584	LDC	SET	LDC+1		V2	07	00584
000106	A	585	IOSTAT	SET	LDC	I/O STATUS	V2	07	00585
000107	A	586	LDC	SET	LDC+1		V2	07	00586
000107	A	587	ISCB	SET	LDC	ITEM SCB	V2	07	00587
000113	A	588	LDC	SET	LDC+4		V2	07	00588
000113	A	589	ITMADR	SET	LDC	ADDRESS OF LIST ITEM	V2	07	00589
000114	A	590	LDC	SET	LDC+1		V2	07	00590
000114	A	591	ITMWC	SET	LDC	COUNT OF WORDS REMAINING IN ITEM	V2	07	00591
000115	A	592	LDC	SET	LDC+1		V2	07	00592
000115	A	593	ITMWC	SET	LDC	LIST ITEM WORD INCREMENT	V2	07	00593
000116	A	594	LDC	SET	LDC+1		V2	07	00594
000116	A	595	ITMODE	SET	LDC	LIST ITEM MODE	V2	07	00595
000117	A	596	LDC	SET	LDC+1		V2	07	00596
000123	A	597	LRDV	SET	LRWC	LOGICAL RECORD OVERLAP	V2	07	00597
000117	A	598	LISTFL	SET	LDC	LIST DATA XFER FLAG	V2	07	00598
000120	A	599	LDC	SET	LDC+1		V2	07	00599



000120	A	600	LNKCNT	SET	LDC	LINK COUNT	V2	07	00600
000121	A	601	LDC	SET	LDC+1		V2	07	00601
000121	A	602	LRECND	SET	LDC	LOGICAL RECORD NUMBER	V2	07	00602
000122	A	603	LDC	SET	LDC+1		V2	07	00603
000122	A	604	LRSZ	SET	LDC	LOGICAL RECORD SIZE	V2	07	00604
000123	A	605	LDC	SET	LDC+1		V2	07	00605
000123	A	606	LRWC	SET	LDC	LOGICAL RECORD REMAINING WORD COUNT	V2	07	00606
000124	A	607	LDC	SET	LDC+1		V2	07	00607
000124	A	608	MDV	SET	LDC	MULTIPLY OVERFLOW SWITCH	V2	07	00608
000125	A	609	LDC	SET	LDC+1		V2	07	00609
000125	A	610	N	SET	LDC	H/T/X FIELD WIDTH	V2	07	00610
000126	A	611	LDC	SET	LDC+1		V2	07	00611
000126	A	612	NFF	SET	LDC	NUMERIC FORMAT FIELD VALUE	V2	07	00612
000127	A	613	LDC	SET	LDC+1		V2	07	00613
000127	A	614	DPSTK	SET	LDC	DP STACK	V2	07	00614
000141	A	615	LDC	SET	LDC+STKSZ		V2	07	00615
000000	A	616	DPSTKP	SET	0	DP STACK POINTER	FG	07	00616
000141	A	617	PARLV	SET	LDC	FORMAT 'C' GROUP LEVEL COUNT	V2	07	00617
000142	A	618	LDC	SET	LDC+1		V2	07	00618
000142	A	619	PBRC	SET	LDC	PHYSICAL BUFFER RECORD COUNT	V2	07	00619
000143	A	620	LDC	SET	LDC+1		V2	07	00620
000143	A	621	PBSZ	SET	LDC	PHYSICAL BUFFER SIZE	V2	07	00621
000144	A	622	LDC	SET	LDC+1		V2	07	00622
000144	A	623	PBWC	SET	LDC	PHYSICAL BUFFER REMAINING WORD COUNT	V2	07	00623
000145	A	624	LDC	SET	LDC+1		V2	07	00624
000145	A	625	PRECND	SET	LDC	PHYSICAL RECORD NUMBER	V2	07	00625
000146	A	626	LDC	SET	LDC+1		V2	07	00626
000146	A	627	PRLINK	SET	LDC	PREVIOUS FCB LINK	V2	07	00627
000147	A	628	LDC	SET	LDC+1		V2	07	00628
000147	A	629	PTFL	SET	LDC	'.' FLAG	V2	07	00629
000150	A	630	LDC	SET	LDC+1		V2	07	00630
000150	A	631	QFL	SET	LDC	QUOTE FLAG	V2	07	00631
000151	A	632	LDC	SET	LDC+1		V2	07	00632
000125	A	633	R	SET	N	REPEAT COUNT	V2	07	00633
000012	A	634	ROPSTP	SET	STKSZ	VSRERR DP STACK POINTER	V2	07	00634
000151	A	635	RETURN	SET	LDC	RETURN ADDR/'END' ADDR/'ERR' ADDR	PD	07	00635
000154	A	636	LDC	SET	LDC+3		PD	07	00636
000154	A	637	RWFL	SET	LDC	FLAG WORD	V2	07	00637
000155	A	638	LDC	SET	LDC+1		V2	07	00638
000155	A	639	S	SET	LDC	SCALE FACTOR	V2	07	00639
000156	A	640	LDC	SET	LDC+1		V2	07	00640
000032	A	641	SAVE	SET	CHB	SAVE PARAMETERS	V2	07	00641
000156	A	642	SCF	SET	LDC	SCALE FACTOR FLAG	V2	07	00642
000157	A	643	LDC	SET	LDC+1		V2	07	00643
000157	A	644	SGFL	SET	LDC	SIGN FLAG	V2	07	00644
000160	A	645	LDC	SET	LDC+1		V2	07	00645
000160	A	646	SVRECN	SET	LDC	SAVE RECORD NO		07	00646
000161	A	647	LDC	SET	LDC+1			07	00647
000162	A	648	SYSBF	SET	SYSDCB+1	ADDRESS OF SYSTEM BUFFER \$BUF	V2	07	00648
000161	A	649	SYSDCB	SET	LDC	SYSTEM DCB	V2	07	00649
000164	A	650	LDC	SET	LDC+3		V2	07	00650
000164	A	651	TEMP	SET	LDC	TEMP STORE	V2	07	00651
000165	A	652	LDC	SET	LDC+1		V2	07	00652
000165	A	653	TEMP1	SET	LDC	TEMP STORE		07	00653
000166	A	654	LDC	SET	LDC+1			07	00654
000166	A	655	TERM	SET	LDC	PRODUCT TERM	V2	07	00655
000167	A	656	LDC	SET	LDC+1		V2	07	00656
000167	A	657	UNIT	SET	LDC	I/O UNIT NUMBER	V2	07	00657
000170	A	658	LDC	SET	LDC+1		V2	07	00658
000170	A	659	W	SET	LDC	FIELD WIDTH	V2	07	00659
000171	A	660	LDC	SET	LDC+1		V2	07	00660
000171	A	661	WT	SET	LDC	WORKING VALUE OF W	V2	07	00661
000172	A	662	LDC	SET	LDC+1		V2	07	00662
000172	A	663	XFFL	SET	LDC	PARAMETER XFER ENABLE FLAG	V2	07	00663
000173	A	664	LDC	SET	LDC+1		V2	07	00664
000173	A	665	XFL	SET	LDC	EXPONENT FIELD NON-BLANK FLAG	V2	07	00665
000174	A	666	LDC	SET	LDC+1		V2	07	00666
000174	A	667	XFW	SET	LDC	EXPONENT FIELD WIDTH	V2	07	00667
000175	A	668	LDC	SET	LDC+1		V2	07	00668
000175	A	669	XSG	SET	LDC	EXPONENT SIGN FLAG	V2	07	00669
000176	A	670	LDC	SET	LDC+1		V2	07	00670
000176	A	671	ZFW	SET	LDC	LEADING ZERO FIELD WIDTH	V2	07	00671
000177	A	672	LDC	SET	LDC+1		V2	07	00672
000177	A	673	YYY	SET	LDC	END OF SAVE BLOCK	V2	07	00673
000177	A	674	AZER	SET	LDC	ASCII ZERO	V2	07	00674
000200	A	675	LDC	SET	LDC+1		V2	07	00675
000200	A	676	BD14	SET	LDC	DECIMAL 14	V2	07	00676
000201	A	677	LDC	SET	LDC+1		V2	07	00677
000201	A	678	BD120	SET	LDC	DECIMAL 120	V2	07	00678
000202	A	679	LDC	SET	LDC+1		V2	07	00679
000202	A	680	BLNK1	SET	LDC	ASCII BLANK CHARACTER	V2	07	00680
000203	A	681	LDC	SET	LDC+1		V2	07	00681
000203	A	682	BLNK2	SET	LDC	ASCII BLANK WORD	V2	07	00682
000204	A	683	LDC	SET	LDC+1		V2	07	00683
000204	A	684	ZZZ	SET	LDC	END OF DATA BLOCK	V2	07	00684
000204	A	685	EJEC					07	00685
686						*****		07	00686
687	*							07	00687
688	*					PROCESS A FORMAT DESCRIPTOR (AID)	*	07	00688
689	*						*	07	00689
690	*					FUNCTION: TO PROCESS THE A FORMAT DESCRIPTOR: RAW	*	07	00690
691	*						*	07	00691
692	*					ENTRY: DIRECT FROM FRS	*	07	00692



```

693 *          WT = W = TOTAL FIELD WIDTH * 07 00693
694 *          IIBSZ = BYTE COUNT OF SINGLE LIST ITEM * 07 00694
695 *          ITEMAD = ADDRESS OF LIST ITEM * 07 00695
696 *          RWFL(BIT WR) = 0 READ * 07 00696
697 *          = 1 WRITE * 07 00697
698 * * 07 00698
699 * EXIT : INPUT : DIRECT TO FRS * 07 00699
700 *          OUTPUT: DIRECT TO FRS THRU OBC * 07 00700
701 * * 07 00701
702 * ***** * 07 00702
000000 R 704 AIN EQU * * 07 00704
000000 R 705 AOUT EQU * * 07 00705
000000 005001 A 707 ZAS AIBUF-1 SET LIST ITEM SCB(0) = 0 (BYTE COUNT) 07 00707
000001 056107 A
000002 016113 A 708 MOVBBB ITEMAD,AIBUF SET LIST ITEM SCB(1) = ITEM ADDRESS 07 00708
000003 056110 A
000004 016171 A 709 SUTBBB WT,IIBSZ,COUNT GET EXCESS CHAR COUNT WT-IIBSZ 07 00709
000005 146101 A
000006 056052 A
710 ***** * 07 00710
711 * SLEW THRU W-IIBSZ CHARS * * 07 00711
712 ***** * 07 00712
000007 016202 A 713 MOVBBB BLNK1,BCHAR LOAD BLANK AS REPEAT CHARACTER V2 07 00713
000010 056030 A
000011 105025 A 714 PUSHJ R0H REPEAT CHARACTER I/O V2 07 00714
000012 004715 R
000013 016154 A 715 TSOB RWFL,WR,AIDL2 TEST IF INPUT OR OUTPUT 07 00715
000014 006411 A
000015 000053 R
716 ***** * 07 00716
717 * INPUT * * 07 00717
718 ***** * 07 00718
000016 105025 A 719 AIDL1 PUSHJ OBC INPUT BUFFER CHARACTER V2 07 00719
000017 000070 R
000020 016030 A 720 MOVBBB BCHAR,ICHAR MOVE CHAR FROM BUFF SCB TO ITEM SCB 07 00720
000021 056111 A
000022 016013 A 721 MOVBBB AISC0,ASC0 SET SCB TO LIST ITEM 07 00721
000023 056021 A
000024 105025 A 722 PUSHJ PC0 PUT CHARACTER IN ITEM V2 07 00722
000025 003276 R
000026 016171 A 723 TNZAB WT,AIDL1 LOOP TILL FIELD WIDTH WT EXHAUSTED 07 00723
000027 001016 A
000030 000016 R
000031 016101 A 724 SUTBBB IIBSZ,W,COUNT GET COUNT OF EXCESS CHARS IN ITEM 07 00724
000032 146170 A
000033 056052 A
000034 005311 A 725 DAB 07 00725
000035 001004 A 726 JAN FRS65 EXIT TO FRS IF LIST ITEM FILLED 07 00726
000036 001003 R
000037 016202 A 727 MOVBBB BLNK1,ICHAR LOAD BLANK AS FILL CHARACTER V2 07 00727
000040 056111 A
000041 016154 A 728 LDA RWFL,B 07 00728
000042 110432 A 729 ORA WRT SET WRITE FLAG V2 07 00729
000043 056154 A 730 STA RWFL,B 07 00730
731 PUSHJ R0H FILL OUT ITEM WITH BLANKS V2 07 00731
000044 105025 A
000045 004715 R
000046 016154 A 732 LDA RWFL,B 07 00732
000047 150452 A 733 ANA WRT RESTORE I/O MODE TO READ V2 07 00733
000050 056154 A 734 STA RWFL,B 07 00734
000051 001000 A 735 JMP FRS65 AND RETURN TO FORMAT SCAN 07 00735
000052 001003 R
736 ***** * 07 00736
737 * OUTPUT * * 07 00737
738 ***** * 07 00738
000053 016013 A 739 AIDL2 MOVBBB AISC0,ASC0 SET SCB TO LIST ITEM 07 00739
000054 056021 A
000055 105025 A 740 PUSHJ I00 INPUT CHARACTER FROM LIST ITEM V2 07 00740
000056 001612 R
000057 016111 A 741 MOVBBB LCHAR,BCHAR MOVE CHAR FROM LIST SCB TO BUFF SCB 07 00741
000060 056030 A
000061 105025 A 742 PUSHJ O00 OUTPUT CHARACTER TO BUFFER/EXIT V2 07 00742
000062 002441 R
000063 001000 R 743 JMP AIDL2 LOOP TILL DONE 07 00743
000064 000053 R 744 EJEC 07 00744

```



```

745 *****
746 *
747 *   C A L L   N O N - R E E N T R A N T   B L O C K ( C A N )
748 *
749 *   FUNCTION: TO RETURN TO V$FORTIO
750 *
751 *   ENTRY: ALOC .NE. 0 IF V$RERR ENTERED BY ALOC
752 *           .EQ. 0 IF V$RERR ENTERED BY DIRECT JUMP
753 *
754 *           V$CRS = CURRENT REENTRANT STACK POINTER
755 *           V$CRS(PR) = LOCATION WHERE P-REG(RETURN ADDRESS) IS STORED
756 *
757 *   EXIT: TO V$FORTIO POP/JUMP ADDRESS IN ANPOJ
758 *
759 *           VIA DEALOC IF ENTERED BY ALOC
760 *           VIA DIRECT JUMP IF ENTERED BY DIRECT JUMP
761 *
762 *   RETURN ADDRESSES IN V$FORTIO STACK SAVED IN V$RERR IF
763 *   VORTEX II CALL FROM BACKGROUND TO NUCLEUS.
764 *
765 *****
000065 036015 A 767 CAN   LDX     ANPOJ,B   POINT X AT V$FORTIO POP/JUMP
768 *           IFF     NUC
769 *           GOTO    NUC1
770 *           SPAC
771 *           IFT     VII
772 *           GOTO    NUC2
773 *           SPAC
774 *           LDA     ALOC,B   GET ALOC ENTRY FLAG
775 *           JANZ    CAN1     TEST VORTEX BACKGROUND CALL TO NUCLEUS
776 *           SPAC
777 *           *****
778 *   EXIT TO V$FORTIO VIA DIRECT JUMP *
779 *           *****
780 *           SPAC
781 *           CONT
782 *           IJMP    0,X
783 *
784 *           NUC2   CONT
785 *           *****
786 *   EXIT TO V$FORTIO VIA DEALOC *
787 *           *****
788 *           EQU     *
789 *           IFF     NUC
790 *           GOTO    NUC1
791 *           SPAC
792 *           IFT     VII
793 *           DME     MAP,V$ST2   SET EXEC STATE TO NO
794 *           TBA     SAVE B
795 *           LDB     V$CRS      POINT B AT ALOC STACK
796 *           STX     PR,B       STORE POP/JUMP ADDR IN P-REG FIELD
797 *           SPAC
798 *           IFF     VII
799 *           GOTO    VII1
800 *           SPAC
801 *           *****
802 *   V$RERR IS IN VORTEX II NUCLEUS *
803 *           *****
804 *           SPAC
805 *           TAB     RESTORE B
806 *           LDXI    BASE
807 *           DECR    1
808 *           STA     ROPSTK,X   INITIALIZE COUNT TO -1
809 *           LDX     OPSTKP,B
810 *           SPAC
811 *           *****
812 *   LOOP TO FIND TOP OF RETURN ADDRESSES IN V$FORTIO STACK *
813 *           *****
814 *           SPAC
815 *           TXA
816 *           CANL1  SUB     ROPSTK,B
817 *           JAP     CAN3       END OF STACK ?
818 *           LDA     0,X        NO. GET OP FROM STACK
819 *           SUB     CEX
820 *           JAZ     CAN5       DONT SAVE STACK WITH EXIT OP
821 *           LDA     0,X        LOAD OP
822 *           LSRA    6
823 *           JANZ   CAN2       EXIT ON ADDRESS OP
824 *           INCR   045        BUMP POINTER
825 *           JMP    CANL1      AND CONTINUE
826 *           SPAC
827 *           *****
828 *   TOP OF RETURN ADDRESS STACK FOUND - MOVE FROM V$FORTIO TO V$RERR *
829 *           *****
830 *           SPAC
831 *           TXA
832 *           CAN2  SUB     ROPSTK,B
833 *           CPA
834 *           LDXI  BASE
835 *           STA  ROPSTK,X   STORE STACK ITEM COUNT-1
836 *           CPA
837 *           INCR  014       SET X = -(STACK ITEM COUNT-1)
838 *           ADD  ANRB,B

```

000065 036015 A

000066 005705 A  
000067 000000 A

000070 R

```

07 00745
* 07 00746
* 07 00747
* 07 00748
* 07 00749
* 07 00750
V2* 07 00751
V2* 07 00752
* 07 00753
* 07 00754
* 07 00755
* 07 00756
* 07 00757
* 07 00758
V2* 07 00759
V2* 07 00760
V2* 07 00761
* 07 00762
* 07 00763
* 07 00764
* 07 00765
V2 07 00767
FG 07 00769
FG 07 00770
FG 07 00771
FG 07 00772
FG 07 00773
FG 07 00774
FG 07 00775
FG 07 00776
FG 07 00777
* 07 00778
FG 07 00779
* 07 00780
FG 07 00781
FG 07 00782
FG 07 00783
FG 07 00784
FG 07 00786
FG 07 00787
FG 07 00788
FG 07 00790
FG 07 00792
FG 07 00793
FG 07 00794
FG 07 00795
V2 07 00796
V2 07 00797
V2 07 00798
V2 07 00799
FG 07 00800
FG 07 00801
FG 07 00802
FG 07 00803
FG 07 00804
FG 07 00805
FG 07 00806
FG 07 00807
V2 07 00808
V2 07 00809
V2 07 00810
V2 07 00811
V2 07 00812
FG 07 00813
FG 07 00814
FG 07 00815
FG 07 00816
FG 07 00817
FG 07 00818
FG 07 00819
FG 07 00820
FG 07 00821
V2 07 00822
V2 07 00823
V2 07 00824
V2 07 00825
V2 07 00826
FG 07 00827
V2 07 00828
FG 07 00829
FG 07 00830
FG 07 00831
FG 07 00832
FG 07 00833
FG 07 00834
V2 07 00835
FG 07 00836
V2 07 00837
FG 07 00838
FG 07 00839
FG 07 00840
V2 07 00841

```



```

842      ADDI      DPSTK+STKSZ
843      TAB
844 CANL2 LDA      0,0      POINT B AT V$FORTIO STACK
845      STAE      BASE+STKSZ-1,X  MOVE STACK ADDRESSES
846      JXZ      CAN5      EXIT AT END
847      IRR      BUMP POINTERS
848      IXR
849      JMP      CANL2      LOOP TILL DONE
850 V111  CONT
851 CAN5  DEALOC      RETURN TO V$FORTIO VIA DEALOC
852 NUC1  CONT
853      EJECT
854 *****
855 *
856 *      C Y C L E   B U F F E R   C H A R A C T E R ( C B C )
857 *
858 * FUNCTION: TO HANDLE CHARACTER I/O FROM/TO BUFFER
859 *
860 * ENTRY: BUFFER SCB(0) = CURRENT CHAR COUNT
861 *        RWFL(BIT WR) = 0 READ
862 *                  = 1 WRITE
863 *        WT = WIDTH REMAINING IN FORMAT FIELD
864 *
865 * EXIT : RWFL(BIT WR) = 0 DIRECT TO ICC(INPUT)
866 *                  = 1 DIRECT TO PCH(OUTPUT)
867 *
868 *
869 *****
000070 036002 A 871 CBC      LDX      ASOQB,B
000071 076021 A 872      STX      ASOQB,B      SET SCB TO BUFFER
000072 015000 A 873      LDA      0,X      GET CURRENT CHAR COUNT
000073 006400 A 874      BT      ASET+B0,CBC4  ON WORD BOUNDARY ?
000074 000077 R
875      PUSHJ   GBA      YES, GET NEXT BUFFER ADDRESS
000075 105025 A
000076 001072 R
876 CBC4  DAB      WT      DECREMENT REMAINING FIELD WIDTH
000077 016171 A
000100 003311 A
000101 056171 A
877      TRAB   RWFL,EC,CBC6  JUMP IF NOT ENCODE/DECODE
000102 016154 A
000103 006452 A
000104 000111 R
000105 036152 A 878      LDX      RETURN+1,B
000106 001040 A 879      JXZ      CBC6      NO COUNT ADDRESS
000107 000111 R
000110 045000 A
880      INR      0,X      BUMP CHARACTER-PROCESSED COUNT
881 CBC6  TRAP   RWFL,WR,ICC  READ: EXIT TO INPUT CHAR FROM BUFFER
000111 016154 A
000112 006451 A
000113 001612 R
000114 001000 A
000115 003276 R
882      JMP      PCH      WRITE: EXIT TO PUT CHAR IN BUFFER
883      EJECT
884 *****
885 *
886 *      C L E A R   B U F F E R ( C L B )
887 *
888 * FUNCTION: TO CLEAR A BUFFER
889 *
890 * ENTRY: FRMT = 0 IF UNFORMATTED
891 *        BFMT = ADDRESS OF PREVIOUS BUFFER WORD
892 *        LRWC = LOGICAL RECORD REMAINING WORD COUNT
893 *        PRWC = PHYSICAL BUFFER REMAINING WORD COUNT
894 *
895 * EXIT : BUFFER = BLANKS ON FORMATTED I/O
896 *        = 0 ON UNFORMATTED I/O
897 *
898 *****
000116 016123 A
000117 056165 A
000120 146144 A
000121 001004 A
000122 000125 R
901      SUB      PRWC,B
902      JAN      CLB4      SET COUNT = MINIMUM(LRWC,PRWC)
903      MOVBA   PRWC,TEMP1
000123 016144 A
000124 056165 A
904 CLB4  TZAB   TEMP1,CLBX  EXIT IF COUNT=0
000125 016165 A
000126 001010 A
000127 000151 R
905      TRAB   RWFL,RB,CLBX  DONT CLEAR IF READ-BEFORE-WRITE FLAG SET
000130 016154 A
000131 006403 A
000132 000151 R
906      TZAB   FRMT,CLB8  CLEAR TO ZEROS ON UNFORMATTED
000133 016063 A
000134 001010 A
000135 000137 R
000136 016203 A
000137 056164 A
907      LDA      BLNK2,B
908 CLB8  STP      TEMP,B      CLEAR TO BLANKS ON FORMATTED

```



```

000140 036025 A 909 LDX BFWPT,B V2 07 00909
910 *****
911 * FILL LOOP * 07 00910
912 ***** 07 00911
000141 000141 R 913 CLBLP EDU * V2 07 00912
000141 005144 A 914 IXR LOAD X AS BUFFER POINTER V2 07 00913
915 MOVBAK TEMP,0 MOVE FILL WORD TO BUFFER V2 07 00914
000142 016164 A 916 TXA V2 07 00916
000143 055000 A 917 SUB BFWPT,B V2 07 00917
000144 005041 A 918 SUB TEMP1,B 07 00918
000145 146025 A 919 JAN CLBLP LOOP TILL DONE 07 00919
000146 146165 A
000147 001004 A
000150 000141 R 920 CLBX POPJ EXIT FG 07 00920
000151 105065 A 921 EJEC 07 00921
922 ***** 07 00922
923 * 07 00923
924 * CLOSE FILE (CLS) * 07 00924
925 * 07 00925
926 * FUNCTION: TO PROCESS CALLS TO CLOSE AN RMD FILE * 07 00926
927 * 07 00927
928 * ENTRY: DIRECT FROM RBE * 07 00928
929 * TEMP = CP = CCL CLOSE NORMAL RMD FILE V2* 07 00929
930 * CCB CLOSE BLOCKED(LOGICAL) FILE V2* 07 00930
931 * RETURN = CALL SEQUENCE ADDRESS * 07 00931
932 * RETURN(5) = ADDRESS OF UPDATE/LEAVE CLOSE PARAMETER * 07 00932
933 * 07 00933
934 * EXIT : FCB REMOVED FROM CHAIN * 07 00934
935 * BUFFER FLUSHED IF LOGICAL FILE * 07 00935
936 * 07 00936
937 * ERRORS: ER4 IF U NOT ON CHAIN * 07 00937
938 * 07 00938
939 ***** 07 00939
941 ***** 07 00941
942 * SET UP CONTROL * 07 00942
943 ***** 07 00943
000152 010432 A 944 CLS LDA MRS SET WRITE FLAG V2 07 00944
000153 056154 A 945 STA RWFL,B 07 00945
946 ***** 07 00946
947 * SEARCH FCB CHAIN FOR U * 07 00947
948 ***** 07 00948
949 PUSHJ SCH SEARCH FCB CHAIN V2 07 00949
000154 105025 A
000155 005415 R
000156 001010 A 950 JAZ ER4 ERROR 4/ FCB(U) NOT ON CHAIN / 07 00950
000157 005154 R 951 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER U V2 07 00951
000160 105025 A
000161 003720 R
000162 036016 A 952 LDX ANRB,B V2 07 00952
953 MOVBAK UNIT,IOCONT INITIALIZE IOC CONTROL WORD V2 07 00953
000163 016167 A
000164 055104 A
000165 036010 A 954 LDX AFPCB,B POINT X AT FCB 07 00954
000166 015014 A 955 LDA 12,X 07 00955
000167 006453 A 956 BT ARST+FLF,CLS20 TEST FOR LOGICAL FILE V2 07 00956
000170 000214 R
000171 006454 A 957 BT ARST+FRM,CLS20 AND RMD V2 07 00957
000172 000214 R 958 ***** V2 07 00958
959 * U IS RMD LOGICAL FILE * V2 07 00959
960 ***** V2 07 00960
000173 006456 A 961 BT ARST+FPD,CLS10 ANY UNPOSTED DATA ? V2 07 00961
000174 000202 R 962 MOVBAK PBSZ,0 YES. LOAD FCB(0) WITH PHYSICAL BUFF SIZE 07 00962
000175 016143 A
000176 055000 A 963 PUSHJ PSB AND POST BUFFER V2 07 00963
000177 105025 A
000200 004465 R
000201 036010 A 964 LDX AFPCB,B RESTORE X 07 00964
965 CLS10 MOVBAK B0120,0 SET FCB(0) = 120 WORDS V2 07 00965
000202 016201 A
000203 055000 A 966 TZAB LGDV,CLS15 LOGICAL RECORD OVERLAP ? 07 00966
000204 016123 A
000205 001010 A
000206 000212 R 967 ADBBB PRECND,PBRC,PRECND YES. BUMP PHYSICAL RECORD NUMBER 07 00967
000207 016145 A
000210 126142 A
000211 056145 A 968 CLS15 MOVBAK PRECND,3 SET FCB(3) = PHYSICAL RECORD NUMBER 07 00968
000212 016145 A
000213 055003 A 969 ***** 07 00969
970 * CALL IOC TO CLOSE FILE * 07 00970
971 ***** 07 00971
000214 036151 A 972 CLS20 LDX RETURN,B POINT X AT CALL SEQUENCE 07 00972
000215 035005 A 973 LDX 5,X POINT X AT UPDATE/LEAVE PARAMETER 07 00973
000216 015000 A 974 LDA 0,X GET UPDATE/LEAVE PARAMETER 07 00974

```



```

000217 001010 A 975 JAZ *+3 07 00975
000220 000222 R
000221 010435 A 976 LDA BS12 SET FLAG FOR UPDATE
000222 006110 A 977 BRAI 03400 MERGE IN IOC CLOSE SKELETON WORD V2 07 00977
000223 003400 A
000224 116167 A 978 BRA UNIT,B OR IN LUN 07 00978
000225 036016 A 979 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK 07 00979
000226 055104 A 980 STA IOCNT,X STORE IOC CONTROL WORD IN V$FORTIO 07 00980
000227 015120 A 981 DAX LINKCNT DECREMENT LINK COUNT 07 00981
000230 005311 A
000231 055120 A
000232 010464 A 982 LDA CID V2 07 00982
000233 006505 A 983 JSR PSJ,X CALL IOC V2 07 00983
000234 004515 R
000235 036018 A 984 LDX RTFCB,B POINT X AT FCB 07 00984
000236 016154 A 985 TRAB RWFL,LF,CLS30 LOGICAL FILE ? 07 00985
000237 006441 A
000240 000243 R
000241 016122 A 986 MOVBAK LRSZ,0 YES. RESTORE LOGICAL REC SIZE IN FCB(0) 07 00986
000242 055000 A
000243 015012 A 987 ***** 07 00987
000244 036146 A 988 * TAKE FCB OFF CHAIN * 07 00988
000245 055012 A 989 ***** 07 00989
000246 010422 A 990 CLS30 LDA 10,X GET FORWARD LINK 07 00990
000247 036016 A 991 LDX PRLINK,B 07 00991
000248 055000 A 992 STA 10,X HOOK TO PREVIOUS LINK 07 00992
000249 010422 A 993 ***** 07 00993
000250 036016 A 994 * EXIT * 07 00994
000251 005344 A 995 ***** 07 00995
000252 055000 A 996 LDA CEX 07 00996
000253 005041 A 997 PUSHF PUSH EXIT OP ONTO V$FORTIO STACK 07 00997
000254 036016 A
000255 055000 A
000256 001000 A 998 JMP CAN EXIT TO V$FORTIO 07 00998
000257 000065 R
000258 055000 A 999 EJECT 07 00999
1000 ***** 07 01000
1001 * 07 01001
1002 * 4 - W O R D D I V I D E B Y 1 0 ( D 1 0 ) * 07 01002
1003 * 07 01003
1004 * FUNCTION: TO DIVIDE A 4-WORD NUMBER BY 10 * 07 01004
1005 * 07 01005
1006 * ENTRY: ACC = DIVIDEND * 07 01006
1007 * 07 01007
1008 * EXIT : ACC = ACC/10 * 07 01008
1009 * 07 01009
1010 ***** 07 01010
000260 005024 A 1011 D10 TBY LOAD X AS BASE REGISTER 07 01011
000261 005001 A 1012 TZA CLEAR HIGH-ORDER WORD OF DIVIDEND 07 01012
000262 025003 A 1013 LDB ACC,X 07 01013
000263 170471 A 1014 DIV TEN ACC(0)=ACC(0)/10 07 01014
000264 065000 A 1015 STB ACC,X 07 01015
000265 025004 A 1016 LDB ACC+1,X 07 01016
000266 170471 A 1017 DIV TEN ACC(1)=(ACC(1)+REM(0))/10 07 01017
000267 065004 A 1018 STB ACC+1,X 07 01018
000270 025005 A 1019 LDB ACC+2,X 07 01019
000271 170471 A 1020 DIV TEN ACC(2)=(ACC(2)+REM(1))/10 07 01020
000272 065005 A 1021 STB ACC+2,X 07 01021
000273 025006 A 1022 LDB ACC+3,X 07 01022
000274 170471 A 1023 DIV TEN ACC(3)=(ACC(3)+REM(2))/10 07 01023
000275 065006 A 1024 STB ACC+3,X 07 01024
000276 005042 A 1025 TBY RESTORE BASE REGISTER B 07 01025
000277 105065 A 1026 POPJ AND EXIT FG 07 01026
1027 ***** 07 01027
1028 EJECT 07 01028
1029 ***** 07 01029
1030 * 07 01030
1031 * P R O C E S S D / E / F O U T P U T D E S C R I P T O R S * 07 01031
1032 * 07 01032
1033 * ( D E F ) * 07 01033
1034 * 07 01034
1035 * FUNCTION: TO PROCESS OUTPUT UNDER THE DOPMAT DESCRIPTORS: SPDU,0 * 07 01035
1036 * SREU,0 * 07 01036
1037 * SREX,0 * 07 01037
1038 * SRG4,0 * 07 01038
1039 * 07 01039
1040 * ENTRY: A = INTEGER FIELD COUNT * 07 01040
1041 * 07 01041
1042 * EXIT : DIRECT TO DNF * 07 01042
1043 * PTFI = 1 = '.' FLAG * 07 01043
1044 * IF A.GE.0 IFW = A = INTEGER FIELD WIDTH * 07 01044
1045 * IF A.LT.0 ZFW = -A = ZERO FILL FIELD WIDTH * 07 01045
1046 * 07 01046
1047 ***** 07 01047
000300 001004 A 1048 DEF JAM DEF4 IS A .GE. ZERO ? 07 01048

```



```

000301 000305 R
000302 056100 A 1050 STA IFW,B YES. STORE AS INTEGER FIELD WIDTH 07 01050
000303 001000 A 1051 JMP DEFB 07 01051
000304 000310 R
000305 005211 A 1052 DEF4 CPA A NEGATIVE 07 01052
000306 005111 A 1053 IAR 07 01053
000307 056176 A 1054 STA ZFW,B LOAD LEADING ZERO FILL COUNT 07 01054
000310 046147 A 1055 DEF8 INR PTFI,B D/E/F HAVE A "." 07 01055
000311 001000 A 1056 JMP ONF EXIT TO OUTPUT NUMERIC FIELD 07 01056
000312 002471 R
1057 EJECT 07 01057
1058 ***** 07 01058
1059 * 07 01059
1060 * PROCESS D/E OUTPUT DESCRIPTORS * 07 01060
1061 * ( D E D ) * 07 01061
1062 * * 07 01062
1063 * * 07 01063
1064 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTORS: SRDW.D * 07 01064
1065 * SREW.D * 07 01065
1066 * SRGW.D * 07 01066
1067 * * 07 01067
1068 * ENTRY: DIRECT FROM FRS * 07 01068
1069 * TO DOUT FOR 'D' FORMAT DESCRIPTOR * 07 01069
1070 * TO EOUT FOR 'E' FORMAT DESCRIPTOR * 07 01070
1071 * TO EOUT FOR 'G' FORMAT DESCRIPTOR * 07 01071
1072 * S = SCALE FACTOR * 07 01072
1073 * * 07 01073
1074 * EXIT : DIRECT TO DEF * 07 01074
1075 * A = S * 07 01075
1076 * DEXP = DEXP - S = DECIMAL EXPONENT * 07 01076
1077 * XFL = 1 = EXPONENT FIELD FLAG * 07 01077
1078 * XFW = 4 = EXPONENT FIELD WIDTH * 07 01078
1079 * IF S .GT. 0, DT = MAX(0,DT-S+1) * 07 01079
1080 * * 07 01080
1081 ***** 07 01081
000313 R 1083 DOUT EQU * 07 01083
000313 R 1084 EOUT EQU * 07 01084
1085 MOVBAB D,COUNT SET SIGNIFICANT DIGIT COUNT TO D 07 01085
000313 016054 A
000314 056052 A
1086 IZAB S,DEQ10 EXIT IF NO SCALE FACTOR 07 01086
000315 016155 A
000316 001010 A
000317 000335 R
000320 001004 A 1087 JAN DEQ5 07 01087
000321 000333 R
000322 046052 A 1088 INR COUNT,B SCALE FACTOR IS +. BUMP COUNT TO D+1 07 01088
000323 146054 A 1089 SUB D,B 07 01089
000324 005311 A 1090 PAR 07 01090
000325 001004 A 1091 JAN DEQ10 OK IF D.GE.S 07 01091
000326 000333 R
1092 MOVBAB S,COUNT OTHERWISE, GET S SIGNIFICANT DIGITS 07 01092
000327 016155 A
000330 056052 A
000331 001000 A 1093 JMP DEQ10 07 01093
000332 000335 R
000333 126056 A 1094 DEQ5 ADD DT,B SCALE FACTOR IS -. SET COUNT TO DT-S 07 01094
000334 056052 A 1095 STA COUNT,B 07 01095
1096 DEQ10 PUSHJ RND ROUND DECIMAL FIELD V2 07 01096
000335 105025 A
000336 005302 R
000337 046173 A 1098 INR XFL,B 'D' AND 'E' BOTH HAVE EXPONENT FIELDS 07 01098
1099 SUTBBB DEXP,S,DEXP SET DEXP = DEXP - S 07 01099
000340 016055 A
000341 146155 A
000342 056055 A
1100 MOVPA8 FOUR,XFW EXPONENT FIELD IS 4 CHARS WIDE 07 01100
000343 010423 A
000344 056174 A
000345 016155 A 1101 LDA S,B 07 01101
000346 001004 A 1102 JAN DEF 07 01102
000347 000300 R
000350 001010 A 1103 JAZ DEF S .GT. 0 ? 07 01103
000351 000300 R
000352 016056 A 1104 LDA DT,B YES 07 01104
000353 146155 A 1105 SUB S,B 07 01105
000354 005111 A 1106 IAR 07 01106
000355 001002 A 1107 JAP DEF SET DT = MAX(0,DT-S+1) 07 01107
000356 000360 R
000357 005001 A 1108 TZA 07 01108
000360 056056 A 1109 STA DT,B 07 01109
000361 016155 A 1110 LDA S,B EXIT WITH A = S 07 01110
000362 001000 A 1111 JMP DEF PROCESS S 07 01111
000363 000300 R
1112 EJECT 07 01112
1113 ***** 07 01113
1114 * 07 01114
1115 * PROCESS F OUTPUT DESCRIPTOR ( F O U ) * 07 01115
1116 * * 07 01116
1117 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTOR: SRFW.D * 07 01117
1118 * * 07 01118
1119 * ENTRY: DIRECT FROM FRS * 07 01119
1120 * DEXP = DECIMAL EXPONENT * 07 01120

```



```

1121 *          S = SCALE FACTOR                                * 07 01121
1122 *                                                    * 07 01122
1123 * EXIT : DIRECT TO DEF                                    * 07 01123
1124 *          A = DEXP = DEXP+S                              * 07 01124
1125 *                                                    * 07 01125
1126 *****                                                    * 07 01126
000364 000364 R 1128 FOUT EQU *                                * 07 01128
000365 016155 A 1130 LDA S,B GET SCALE FACTOR                    * 07 01130
000366 126055 A 1131 ADD DEXP,B ADD DECIMAL EXPONENT              * 07 01131
000367 056052 A 1132 ADD D,B ADD FRACTIONAL FIELD COUNT          * 07 01132
000370 105025 A 1133 STA COUNT,B STORE AS SIGNIFICANT DIGIT COUNT * 07 01133
000371 005302 R 1134 PUSHJ RND ROUND TO SIGNIFICANT DIGIT COUNT      V2 * 07 01134
000372 016055 A 1135 LDA DEXP,B                                * 07 01135
000373 126155 A 1136 ADD S,B BUMP EXPONENT BY S                          * 07 01136
000374 056055 A 1137 STA DEXP,B                                * 07 01137
000375 001000 A 1138 JMP DEF EXIT WITH INTEGER FIELD WIDTH IN A          * 07 01138
000376 000300 R
1139 EJECT                                                    * 07 01139
1140 *****                                                    * 07 01140
1141 *                                                    * 07 01141
1142 *          F O R M A T   S C A N ( F R S )                * 07 01142
1143 *                                                    * 07 01143
1144 * FUNCTION: TO SCAN AND DECODE A FORMAT CHARACTER STRING * 07 01144
1145 *                                                    * 07 01145
1146 * ENTRY: NO SPECIAL CONDITIONS                            * 07 01146
1147 *                                                    * 07 01147
1148 * EXIT : FDLKEY = CONVERSION CODE ID KEY                 * 07 01148
1149 *          TO DESCRIPTOR PROCESSOR FOR H/X/T (NO DATA XFER FROM LIST) * 07 01149
1150 *          TO DESCRIPTOR PROCESSOR FOR OTHERS IF LIST NOT EXHAUSTED * 07 01150
1151 *          OTHERWISE EXIT TO V$FORTIO THRU GNL          V2 * 07 01151
1152 *                                                    * 07 01152
1153 * ERRORS: ER1 ON INVALID FORMAT STRING                    * 07 01153
1154 *                                                    * 07 01154
1155 *****                                                    * 07 01155
1156 *****                                                    * 07 01156
1157 *****                                                    * 07 01157
1158 * INITIAL ENTRY *                                        * 07 01158
1159 *****                                                    * 07 01159
000377 005001 A 1160 FRS ZAB FRPT CLEAR FORMAT STRING POINTER    * 07 01160
000400 056062 A
000401 056075 A 1161 STA GSRPC+1,B CLEAR LEVEL 2 GROUP REPEAT COUNT * 07 01161
000402 056117 A 1162 STA LISTFL,B CLEAR LIST DATA XFER FLAG          * 07 01162
000403 056141 A 1163 STA PARLV,B CLEAR '*' GROUP LEVEL COUNT          * 07 01163
000404 056155 A 1164 STA S,B CLEAR SCALE FACTOR                                * 07 01164
000405 005101 A 1165 INCR 1
000406 056125 A 1166 STA R,B SET INITIAL '*' REPEAT COUNT TO 1          * 07 01166
000407 105025 A 1167 PUSHJ INF INPUT NON-BLANK FORMAT CHARACTER      V2 * 07 01167
000410 001745 R
000411 006443 A 1168 BT ARST+LP,ER1 ERROR 1/ 1ST FORMAT CHAR NOT '*' / * 07 01168
000412 005157 R
1169 *****                                                    * 07 01169
1170 * '*' ENTRY *                                           * 07 01170
1171 *****                                                    * 07 01171
000413 046141 A 1172 FRS2 INR PARLV,B BUMP '*' LEVEL                * 07 01172
000414 016141 A 1173 LDA PARLV,B
000415 140423 A 1174 SUB FOUR
000416 001002 A 1175 JAP ER1 ERROR 1/ MORE THAN 3 '*' LEVELS / * 07 01174
000417 005157 R
000420 016012 A 1176 LDA ASPAR,B
000421 126141 A 1177 ADD PARLV,B
000422 005014 A 1178 TAX POINT X AT GROUP REPEAT COUNT                * 07 01178
000423 016125 A 1179 LDA R,B GET REPEAT COUNT                          * 07 01179
000424 055000 A 1180 STA 0,X STORE IN DYNAMIC GROUP REPEAT COUNT TABLE * 07 01180
000425 055006 A 1181 STA GSRPC-GDRPC,X STORE IN STATIC GROUP REPEAT COUNT TABLE * 07 01181
000426 016062 A 1182 LDA FRPT,B GET FORMAT CHARACTER POINTER          * 07 01182
000427 055003 A 1183 STA GDRPT-GDRPC,X SAVE IN GROUP TABLE          * 07 01183
1184 *****                                                    * 07 01184
1185 * INPUT NEXT FIELD DESCRIPTOR *                          * 07 01185
1186 *****                                                    * 07 01186
1187 *****                                                    * 07 01187
1188 *****                                                    V2 * 07 01188
1189 * ENABLE ALF/BLANK/NUM? , /? (*?/?-/?**/?)?/?/?/? *    V2 * 07 01189
1190 *****                                                    V2 * 07 01190
000430 006010 A 1191 FRS5 LDAI 07077 V2 * 07 01191
000431 007077 A
000432 056053 A 1192 STA CVFL,B V2 * 07 01192
000433 005101 A 1193 INCR 1 * 07 01193
000434 056125 A 1194 STA R,B SET REPEAT COUNT TO 1 * 07 01194
000435 005001 A 1195 ZAB SCF CLEAR SCALE FACTOR FLAG * 07 01195
000436 056156 A
000437 056054 A 1196 STA D,B CLEAR FRACTIONAL FIELD WIDTH * 07 01196
000440 056022 A 1197 STA ASFL,B CLEAR '*' FLAG * 07 01197
000441 056150 A 1198 STA QFL,B CLEAR QUOTE FLAG * 07 01198
000442 005001 A 1199 FRS10 ZAB SGFL CLEAR SIGN FLAG * 07 01199
000443 056157 A
000444 105025 A 1200 PUSHJ INF INPUT NON-BLANK FORMAT CHARACTER      V2 * 07 01200
000445 001745 R
000446 156053 A 1201 ANA CVFL,B CHECK VALIDITY OF CHAR * 07 01201

```



```

000447 001010 A 1202 JAZ ER1 ERROR 1/ ILLEGAL FORMAT CHAR / 07 01202
000450 005157 R
1203 *****
1204 * TEST CHAR *
1205 *****
000451 016065 A 1206 LDA FCODE,B RELOAD FORMAT CHARACTER CODE 07 01203
000452 006402 A 1207 BT ASET+CM,FRS10 TEST FOR ',' 07 01204
000453 000442 R
000454 006403 A 1208 BT ASET+LP,FRS2 TEST FOR '<' 07 01205
000455 000413 R
000456 006412 A 1209 BT ASET+RP,FRS15 TEST FOR '>' 07 01206
000457 000500 R
000460 006404 A 1210 BT ASET+MN,FRS20 TEST FOR '- ' 07 01207
000461 000556 R
000462 006413 A 1211 BT ASET+SL,FRS70 TEST FOR '/' 07 01208
000463 001012 R
000464 006405 A 1212 BT ASET+NM,FRS25 TEST FOR NUMERIC 07 01209
000465 000563 R
000466 006400 A 1213 BT ASET+AL,FRS35 TEST FOR ALPHA 07 01210
000467 000624 R
000470 046150 A 1214 INR QFL,B MUST BE QUOTE. SET FLAG 07 01211
1215 MOV PAB BR15,N SET FIELD WIDTH TO MAX INTEGER 07 01212
000471 010460 A
000472 056125 A
000473 056171 A 1216 STA WT,B LOAD 'H' DESCRIPTOR KEY V2 07 01216
1217 MOV PAB EIGHT,FDLKEY 07 01217
000474 010424 A
000475 056061 A
000476 001000 A 1218 JMP FRS60 EXIT 07 01218
000477 000770 R
1219 *****
1220 * '>' INPUT *
1221 *****
000500 016012 A 1222 FRS15 LDA AGPAR,B 07 01219
000501 126141 A 1223 ADD PARLV,B 07 01220
000502 005014 A 1224 TAX POINT X AT '<' GROUP REPEAT COUNT 07 01221
1225 DAX 0 DECREMENT DYNAMIC '<' REPEAT COUNT 07 01222
000503 015000 A
000504 005311 A
000505 055000 A
000506 001016 A 1226 JANZ FRS19 IS '<' GROUP FINISHED ? 07 01223
000507 000552 R 1227 DAB PARLV YES. DECREMENT '<' LEVEL 07 01224
000510 016141 A
000511 005311 A
000512 056141 A
000513 001016 A 1228 JANZ FRS75 CONTINUE SCAN IF NOT LAST '>' 07 01225
000514 001016 R
1229 *****
1230 * PROCESS RIGHTMOST '>' *
1231 *****
000515 005001 A 1232 ZAB FDLKEY DISABLE PXF MODE TEST 07 01229
000516 056061 A
1233 PUSHJ GNL GET ADDRESS OF NEXT LIST ITEM V2 07 01230
000517 105025 A
000520 001436 R 1234 SUTBBB ITEMAD,ITMINC,ITEMAD REINITIALIZE LIST CONTROL 07 01231
000521 016113 A
000522 146113 A
000523 056113 A 1235 ADBBB ITEMWC,ITMINC,ITEMWC 07 01232
000524 016114 A
000525 126115 A
000526 056114 A 1236 PUSHJ RCL RECYCLE LOGICAL BUFFER V2 07 01233
000527 105025 A
000530 004757 R
000531 016117 A 1237 LDA LISTFL,B 07 01234
000532 001010 A 1238 JAZ ER1 ERROR 1/ NO DATA XFER DESCRIPTORS / 07 01235
000533 005157 R 1239 ZAB LISTFL CLEAR LIST DATA XFER FLAG 07 01236
000534 005001 A
000535 056117 A
000536 036012 A 1240 LDX AGPAR,B 07 01237
000537 005144 A 1241 IXR IXR POINT X AT '<' LEVEL 1 07 01238
000540 046141 A 1242 INR PARLV,B ALSO LEVEL COUNTER 07 01239
000541 015006 A 1243 LDA GSRPC-GDRPC,X 07 01240
000542 055000 A 1244 STA 0,X RELOAD LEVEL 1 DYNAMIC REPEAT COUNT 07 01241
000543 015007 A 1245 LDA GSRPC-GDRPC+1,X 07 01242
000544 001010 A 1246 JAZ FRS19 IS THERE A 2ND LEVEL ? 07 01243
000545 000552 R
000546 046141 A 1247 INR PARLV,B YES 07 01244
000547 005144 A 1248 IXR IXR USE 2ND '<' LEVEL 07 01245
000550 015006 A 1249 LDA GSRPC-GDRPC,X GET STATIC REPEAT COUNT 07 01246
000551 055000 A 1250 STA 0,X RELOAD DYNAMIC REPEAT COUNT 07 01247
000552 015003 A 1251 FRS19 LDA GFRPT-GDRPC,X 07 01248
000553 056062 A 1252 STA FRPT,B BACK UP SCAN TO '<' 07 01249
000554 001000 A 1253 JMP FRS5 RESUME SCAN AFTER CORRESPONDING '<' 07 01250
000555 000430 R
1254 *****
1255 * '- ' INPUT *
1256 *****

```



000556	046157	A	1257	FRS20	INR	SGFL,B	SET SIGN FLAG		07	01257
			1258		PUSHJ	INF	INPUT NON-BLANK FOLLOWING '-'	V2	07	01258
000557	105025	A								
000560	001745	R								
000561	006445	A	1259		BT	ARST+NM,ER1	ERROR 1/ NOT NUMERIC /		07	01259
000562	005157	R								
			1260						07	01260
			1261						07	01261
			1262						07	01262
			1263	FRS25	PUSHJ	IFF	INPUT NUMERIC FORMAT FIELD	V2	07	01263
000563	105025	A								
000564	001711	R								
000565	006150	A	1264		ANAI	0211	ENABLE 'P'/'K'/ALPHA	V2	07	01264
000566	000211	A								
000567	001010	A	1265		JAZ	ER1	ERROR 1/ ILLEGAL TERMINATOR /		07	01265
000570	005157	R								
000571	016065	A	1266		LDA	FOUDE,B			07	01266
000572	006447	A	1267		BT	ARST+PS,FRS30	TEST IF TERMINATOR IS 'P'		07	01267
000573	000611	R								
			1268						07	01268
			1269						07	01269
			1270						07	01270
000574	046156	A	1271		INR	SGFL,B	SET SCALE FACTOR FLAG		07	01271
000575	016126	A	1272		LDA	NFF,B	GET SCALE FACTOR ABS VALUE IN A		07	01272
000576	036157	A	1273		LDA	SGFL,B	GET SIGN FLAG IN X		07	01273
000577	001040	A	1274		JXZ	++4			07	01274
000600	000603	R								
000601	005211	A	1275		CPA		NEGATE A IF SIGN FLAG SET		07	01275
000602	005111	A	1276		IAR				07	01276
000603	056155	A	1277		CTA	S,B	LOAD SCALE FACTOR S		07	01277
000604	006010	A	1278		LDAI	041		V2	07	01278
000605	000041	A								
000606	056053	A	1279		STA	OVFL,B	ENABLE ONLY NUMERIC/ALPHA	V2	07	01279
000607	001000	A	1280		JMP	FRS10			07	01280
000610	000442	R								
			1281						07	01281
			1282						07	01282
			1283						07	01283
			1284	FRS30	INZAB	SGFL,ER1	ERROR 1/ '-' PRECEDES REPEAT COUNT /		07	01284
000611	016157	A								
000612	001016	A								
000613	005157	R								
			1285		MOVAB	NFF,R	LOAD REPEAT COUNT		07	01285
000614	016126	A								
000615	056125	A								
000616	036171	A	1286		STA	MF,B	ALSO AS FIELD WIDTH FOR H/X		07	01286
000617	016065	A	1287		LDA	FOUDE,B			07	01287
000620	006403	A	1288		BT	ARST+LP,FRS2	TEST FOR 'C'		07	01288
000621	000413	R								
000622	006440	A	1289		BT	ARST+AL,ER1	ERROR 1/ TERMINATOR NOT ALPHA /		07	01289
000623	005157	R								
			1290						07	01290
			1291						07	01291
			1292						07	01292
			1293	FRS35	EQU	V		V2	07	01293
000624	000624	R	1294		LDA	FOCHAR,B	GET FORMAT DESCRIPTOR CHARACTER	V2	07	01294
			1295		IFF	NUC		FG	07	01295
			1296		GOTO	NV2NUC		FG	07	01296
			1297		IFT	VII		FG	07	01297
			1298		ORC	MAP,VSST0	SET EXEC STATE TO 00	V2	07	01298
			1299	NV2NUC	CONT			FG	07	01299
000625	006030	A	1300		LDXI	FRSJT-FRSCHT-1	GET TABLE COUNT IN X	V2	07	01300
000626	000012	A								
000627	006145	A	1301	FRSL1	SURE	FRSCHT,X		V2	07	01301
000630	001031	R								
000631	001010	A	1302		JAZ	FRS40	MATCH ?		07	01302
000632	000640	R								
			1303		IFF	NUC		FG	07	01303
			1304		GOTO	NV2NUC		FG	07	01304
			1305		IFT	VII		FG	07	01305
			1306		GOTO	VIIINUC		FG	07	01306
			1307	NV2NUC	CONT			FG	07	01307
000633	001040	A	1308		JXZ	ER1	ERROR 1/ ILLEGAL FORMAT CHAR /	V2	07	01308
000634	005157	R								
			1309		GOTO	NV2NUC		FG	07	01309
			1310	VIIINUC	CONT			FG	07	01310
			1311		JXZ	FRS39		V2	07	01311
			1312	NV2NUC	CONT			FG	07	01312
000635	005344	A	1313		DXR		DROP TABLE COUNT	V2	07	01313
000636	001000	A	1314		JMP	FRSL1	AND CONTINUE COMPARISON		07	01314
000637	000627	R								
			1315		IFF	NUC		FG	07	01315
			1316		GOTO	NV2NUC		FG	07	01316
			1317		IFF	VII		FG	07	01317
			1318		GOTO	NV2NUC		FG	07	01318
			1319	FRS39	ORC	MAP,VSST3	SET EXEC STATE TO NN	V2	07	01319
			1320		JMP	ER1		V2	07	01320
			1321	NV2NUC	CONT			FG	07	01321
	000640	R	1322	FRS40	EQU	*		V2	07	01322
			1323		IFF	NUC		FG	07	01323
			1324		GOTO	NV2NUC		FG	07	01324
			1325		IFT	VII		FG	07	01325
			1326		ORC	MAP,VSST3	SET EXEC STATE TO NN	V2	07	01326



Address	Code	Label	Operation	Comments	Line	FG	Page
000640	005041	A	1327 NV2NUC CONT			07	01327
000641	056061	A	1328 TXA			07	01328
		A	1329 STA FDLKEY,B	SAVE AS DESCRIPTOR KEY		07	01329
		A	1330 *****			07	01330
		A	1331 * SCAN BEYOND DESCRIPTOR LETTER *			07	01331
		A	1332 *****			07	01332
		A	1333 TZAB SCF,FRS45	DOES DESCRIPTOR HAVE A SCALE FACTOR ?		07	01333
000642	016156	A					
000643	001010	A					
000644	000651	R					
000645	016061	A	1334 LDA FDLKEY,B	YES		07	01334
000646	140423	A	1335 SUB FOUR			07	01335
000647	001002	A	1336 JAP ER1	ERROR 1/ ILLEGAL SCALE FACTOR /		07	01336
000650	005157	R					
000651	016061	A	1337 FRS45 LDA FDLKEY,B			07	01337
000652	140424	A	1338 SUB EIGHT			07	01338
000653	001004	A	1339 JAN FRS46			07	01339
000654	000664	R					
000655	140422	A	1340 SUB TWO			07	01340
000656	001016	A	1341 JANZ FRS60	SCAN FINISHED FOR H/X		07	01341
000657	000770	R					
000660	016125	A	1342 LDA R,B			07	01342
000661	140422	A	1343 SUB TWO			07	01343
000662	001002	A	1344 JAP ER1	ERROR 1/ 'T' DESCRIPTOR HAS REPEAT COUNT		07	01344
000663	005157	R					
000664	105025	A	1345 FRS46 PUSHJ INF	INPUT NON-BLANK FORMAT CHARACTER		V2	07 01345
000665	001745	R					
000666	006445	A	1346 BT ARST+NM,ER1	ERROR 1/ NON-NUM AFTER DESCRIPTOR LETTER /		07	01346
000667	005157	R					
		A	1347 PUSHJ IFF	INPUT NUMERIC FIELD		V2	07 01347
000670	105025	A					
000671	001711	R					
000672	016126	A	1348 LDA NFF,B			07	01348
000673	056170	A	1349 STA W,B	LOAD FIELD WIDTH W		07	01349
000674	001010	A	1350 JAZ ER1	ERROR 1/ ZERU FIELD WIDTH /		07	01350
000675	005157	R					
000676	016061	A	1351 LDA FDLKEY,B			07	01351
000677	140423	A	1352 SUB FOUR			07	01352
000700	001004	A	1353 JAN FRS47	CONTINUE SCAN FOR D/E/F/G		07	01353
000701	000707	R					
000702	140423	A	1354 SUB FOUR			07	01354
000703	001004	A	1355 JAN FRS50	NO FRACTIONAL D FIELD FOR I/L/A		V2	07 01355
000704	000722	R					
000705	001000	A	1356 JMP FRS60	SCAN FINISHED FOR T		07	01356
000706	000770	R					
000707	016065	A	1357 FRS47 LDA FCODE,B			07	01357
000710	006450	A	1358 BT ARST+PT,ER1	ERROR 1/ TERMINATOR NOT '.' /		07	01358
000711	005157	R					
		A	1359 PUSHJ INF	INPUT NON-BLANK FORMAT CHARACTER		V2	07 01359
000712	105025	A					
000713	001745	R					
000714	006445	A	1360 BT ARST+NM,ER1	*ERROR 1/ NON-NUMERIC AFTER LETTER /		07	01360
000715	005157	R					
		A	1361 PUSHJ IFF	INPUT NUMERIC FIELD		V2	07 01361
000716	105025	A					
000717	001711	R					
000720	016126	A	1362 LDA NFF,B			07	01362
000721	056054	A	1363 STA D,B	STORE DECIMAL FIELD WIDTH D		07	01363
		A	1364 *****			07	01364
		A	1365 * DESCRIPTOR REQUIRES LIST ITEM *			07	01365
		A	1366 *****			07	01366
		A	1367 FRS50 PUSHJ GNL	GET ADDRESS OF NEXT LIST ITEM/EXIT		V2	07 01367
000722	105025	A					
000723	001436	R					
000724	046117	A	1369 INR LISTFL,B	SET LIST FLAG		07	01368
		A	1369 MOVBAB W,WT	SET WT=W		07	01369
000725	016170	A					
000726	056171	A					
		A	1370 MOVBAB D,DT	SET DT=D		07	01370
000727	016054	A					
000730	056056	A					
		A	1371 ZAB ACC	CLEAR ACCUMULATOR ACC		07	01371
000731	005001	A					
000732	056003	A					
000733	056004	A	1372 STA ACC+1,B			07	01372
000734	056005	A	1373 STA ACC+2,B			07	01373
000735	056006	A	1374 STA ACC+3,B			07	01374
000736	056022	A	1375 STA ASCL,B	CLEAR '*' FLAG		07	01375
000737	056055	A	1376 STA DEXP,B	CLEAR DECIMAL EXPONENT		07	01376
000740	056100	A	1377 STA IFH,B	CLEAR INTEGER FIELD WIDTH		07	01377
000741	056147	A	1378 STA PTFB,B	CLEAR '.' FLAG		07	01378
000742	056157	A	1379 STA SGFL,B	CLEAR SIGN FLAG		07	01379
000743	056173	A	1380 STA XFL,B	CLEAR EXPONENT FIELD FLAG		07	01380
000744	056174	A	1381 STA XFW,B	SET EXPONENT FIELD WIDTH TO ZERO		07	01381
000745	056176	A	1382 STA ZFW,B	CLEAR ZERO FILL FIELD WIDTH		07	01382
000746	056166	A	1383 STA TERM,B	CLEAR TERMINATING DIGIT		07	01383
		A	1384 MOVBAB ASCB,ASCB	SET SCB TO BUFFER		V2	07 01384
000747	016002	A					
000750	056021	A					
000751	016061	A	1385 LDA FDLKEY,B			07	01385
000752	140465	A	1386 SUB FIVE			07	01386
000753	001002	A	1387 JAP FRS60	EXIT ON NON-NUMERIC DESCRIPTOR		07	01387



```

000754 000770 R
1388 *****
1389 * NUMERIC DESCRIPTOR *
1390 *****
000755 005111 A 1391 IAR
000756 056156 A 1392 STA SCF,B DISABLE SCALE FACTOR FOR I INPUT
1393 TSAB RWFL,WR,FRS55 TEST READ OR WRITE V2 07 01392
000757 016154 A
000760 006411 A
000761 000766 R
1394 *****
1395 * READ *
1396 *****
1397 PUSHJ IXN INPUT EXTERNAL NUMERIC FIELD V2 07 01397
000762 105025 A
000763 001764 R
000764 001000 A 1398 JMP FRS60
000765 000770 R
1399 *****
1400 * WRITE *
1401 *****
1402 FRS55 PUSHJ GNI GET NUMERIC LIST ITEM V2 07 01402
000766 105025 A
000767 001147 R
1403 *****
1404 * EXIT TO PROCESSOR *
1405 *****
000770 016061 A 1406 FRS60 LBA FDLKEY,B
000771 004241 A 1407 LRLA I
000772 005014 A 1408 TAX SET W = DESCRIPTOR READ KEY
000773 016154 A 1409 LBA RWFL,B
000774 150432 A 1410 AND WRS V2 07 01410
000775 003017 A 1411 XANZ INR BUMP KEY FOR WRITE V2 07 01411
000776 000537 A
1412 IFF NUC FG 07 01412
1413 GOTO NV2NUC FG 07 01413
1414 IFF VII FG 07 01414
1415 DNE MAP,VSST0 SET EXEC STATE TO 00 V2 07 01415
1416 NV2NUC CNT FG 07 01416
000777 006035 A 1417 LDKE FRSJT,X GET PROCESSOR ADDRESS FROM TABLE
001000 001044 R
1418 IFF NUC FG 07 01418
1419 GOTO NV2NUC FG 07 01419
1420 IFF VII FG 07 01420
1421 DNE MAP,VSST3 SET EXEC STATE TO NN V2 07 01421
1422 NV2NUC CNT FG 07 01422
001001 006705 A 1423 LUMP 0,X EXIT TO PROCESSOR
001002 000000 H
1424 *****
1425 * TEST REPEAT COUNT *
1426 *****
1427 FRS65 DAB R DECREMENT REPEAT COUNT
001003 016175 A
001004 005311 A
001005 056125 A
001006 001016 A 1428 XANZ FRS50 REPEAT DESCRIPTOR R TIMES
001007 000722 R
001010 001000 A 1429 JMP FRS65 THEN RESUME SCAN
001011 001020 R
1430 *****
1431 * PROCESS '/' *
1432 *****
1433 FRS70 PUSHJ RCL RECYCLE LOGICAL BUFFER V2 07 01433
001012 105025 A
001013 004757 R
001014 001000 A 1434 JMP FRS5 AND SCAN FORWARD FOR NEXT DESCRIPTOR
001015 000400 R
1435 *****
1436 * PROCESS FIELD SEPARATOR *
1437 *****
1438 FRS75 PUSHJ INF GET TERMINATING CHARACTER V2 07 01438
001016 105025 A
001017 001745 R
001020 016065 A 1439 FRS65 LBA FCODE,B GET CHAR CODE
001021 006400 A 1440 LI RSET+CM,FRS5 TEST FOR '*'
001022 000430 A
001023 006413 A 1441 BT RSET+SL,FRS70 TEST FOR '/'
001024 001012 R
001025 006412 A 1442 BT RSET+RP,FRS15 TEST FOR ')'
001026 000500 R
001027 001000 A 1443 JMP FRI ERROR 1/ ILLEGAL TERMINATOR /
001030 005157 R
1444 *****
1445 * TABLE OF VALID FORMAT SPEC CHARS *
1446 *****
001031 001031 R 1447 FRSOHT EQU * V2 07 01447
001031 177777 A 1448 DATA -1 SROW,B V2 07 01448
001032 177777 A 1449 DATA -1 SROW,B V2 07 01449
001033 177777 A 1450 DATA -1 SROW,B V2 07 01450
001034 177776 A 1451 DATA -C SROW,B V2 07 01451
001035 177757 A 1453 DATA -001 RIN 07 01453
001036 000016 A 1455 DATA 016 RDN 07 01455
001037 000013 A 1456 DATA 013 RLW V2 07 01456

```



```

001040 177771 A 1457      DATA      -7      RAH
001041 177760 A 1459      DATA     -020    NH...
001042 000004 A 1460      DATA      4      NX
001043 000324 A 1461      DATA     0324    TN
1463 *****
1464 * JUMP TABLE *
1465 *****
001044 001044 R 1466 FRSJT EQU *
001044 003325 R 1467 PZE DIN
001045 000313 R 1468 PZE DOUT
001046 003325 R 1469 PZE EIN
001047 000313 R 1470 PZE EOUT
001050 003325 R 1471 PZE FIN
001051 000364 R 1472 PZE FOUT
001052 003325 R 1473 PZE GIN
001053 001471 R 1474 PZE GOUT
001054 003325 R 1475 PZE IIN
001055 001754 R 1476 PZE IOUT
001056 005736 R 1477 PZE ZIN
001057 005736 R 1478 PZE ZOUT
001060 002251 R 1479 PZE LIN
001061 002303 R 1480 PZE LOUT
001062 000000 R 1481 PZE AIN
001063 000000 R 1482 PZE AOUT
001064 001521 R 1483 PZE HIN
001065 001521 R 1484 PZE HOUT
001066 005724 R 1485 PZE XIN
001067 005724 R 1486 PZE XOUT
001070 005512 R 1487 PZE TIN
001071 005512 R 1488 PZE TOUT
1489
1490 EJEC
1491 *****
1492 *
1493 * GET BUFFER ADDRESS (GBA) *
1494 *
1495 * FUNCTION: TO GET ADDRESS OF NEXT BUFFER WORD, AND HANDLE CROSSING
1496 * OF LOGICAL AND PHYSICAL RECORD BOUNDARIES *
1497 *
1498 * ENTRY: PBWC = COUNT OF WORDS REMAINING IN PHYSICAL BUFFER
1499 * LRWC = COUNT OF WORDS REMAINING IN LOGICAL BUFFER
1500 * BFWPT = ADDRESS OF PREVIOUS BUFFER WORD
1501 * RWFL(TR) = 1 ON TERMINATE CALL
1502 *
1503 * EXIT : IF PBWC .LE. 0
1504 * RCP CALLED TO RECYCLE PHYSICAL BUFFER
1505 *
1506 * BFWPT = BFWPT+1
1507 *
1508 * IF LRWC .LE. 0
1509 * LRECND = LRECND+1
1510 * ALBF = BFWPT
1511 * LRWC = LRSZ
1512 * BFWPT = 0
1513 * CLB CALLED ON WRITE IF TR=0
1514 * PBWC = PBWC-1
1515 * LRWC = LRWC-1
1516 *
1517 *****
1519 *****
1520 * TEST FOR END OF PHYSICAL BUFFER *
1521 *****
001072 016144 A 1522 GBA LDA PBWC,B
001073 005311 A 1523 DAR
001074 001002 A 1524 JAP GBA50
001075 001103 R 1525 TSAB RWFL,EC,GBA80 PD 07 01525
001076 016134 A
001077 006412 A
001100 001141 R
1526 *****
1527 * END OF PHYSICAL BUFFER *
1528 *****
1529 PUSHJ RCP RECYCLE PHYSICAL BUFFER V2 07 01529
001101 105025 A
001102 005015 R
1530 *****
1531 * TEST FOR END OF LOGICAL RECORD *
1532 *****
001103 046025 A 1533 GBA50 INR BFWPT,B BUMP BUFFER WORD POINTER
001104 016123 A 1534 LDA LRWC,B
001105 005311 A 1535 DAR
001106 001002 A 1536 JAP GBA70
001107 001132 R
1537 *****
1538 * END OF LOGICAL RECORD *
1539 *****
001110 046121 A 1540 INR LRECND,B BUMP LOGICAL RECORD NUMBER
001111 016025 A 1541 MOVBAB BFWPT,ALBF UPDATE LOGICAL BUFFER ADDRESS
001112 056027 A
1542 GBA55 MOVBAB LRSZ,LRWC RELOAD REMAINING WORD COUNT PD 07 01542
001113 016122 A
001114 056123 A

```



```

001115 005001 A 1543 ZAB BFPT CLEAR BUFFER CHARACTER POINTER 07 01543
001116 056026 A 1544 IRAB RWFL,WR,GBA70 WRITE ? 07 01544
001117 016154 A
001120 006451 A
001121 001132 R
001122 006404 A 1545 BT ASET+TR,GBA70 YES. TERMINATE ? 07 01545
001123 001132 R 1546 GBA60 EQU * V2 07 01546
001124 016025 A 1547 DAB BFPT NO. SET UP CLB V2 07 01547
001125 005311 A
001126 056025 A 1548 PUSHJ CLB CLEAR LOGICAL BUFFER V2 07 01548
001127 105025 A
001130 000116 R
001131 046025 A 1549 INR BFPT,B RESTORE BFPT V2 07 01549
1550 *****
1551 * DECREMENT REMAINING WORD COUNTERS * 07 01551
1552 ***** 07 01552
1553 GBA70 DAB PBWC 07 01553
001132 015144 A
001133 005311 A
001134 056144 A 1554 DAB LRWC 07 01554
001135 016123 A
001136 005311 A
001137 056123 A 1555 POPJ EXIT FG 07 01555
001140 105065 A 1556 GBA80 MOVAB PLSZ,PBWC RESET ENCODE/DECODE POINTERS PD 07 01556
001141 016143 A
001142 056144 A 1557 MOVAB ALBF,BFPT PD 07 01557
001143 016027 A
001144 056025 A
001145 001000 A 1558 JMP GBA55 PD 07 01558
001146 001113 R 1559 EJEC 07 01559
1560 ***** 07 01560
1561 * 07 01561
1562 * GET NUMERIC ITEM ( G N T ) * 07 01562
1563 * 07 01563
1564 * FUNCTION: TO GET A LIST ITEM AND CONVERT IT TO A CHAR STRING * 07 01564
1565 * 07 01565
1566 * ENTRY: ITEMAD = ADDRESS OF LIST ITEM * 07 01566
1567 * ITMODE = MODE OF LIST ITEM: * 07 01567
1568 * = 0 1-WORD INTEGER/LOGICAL * 07 01568
1569 * = 1 2-WORD INTEGER/LOGICAL * 07 01569
1570 * = 2 REAL * 07 01570
1571 * = 3 DOUBLE PRECISION * 07 01571
1572 * = 4 COMPLEX * 07 01572
1573 * = 5 DOUBLE PRECISION INTEGER * 07 01573
1574 * 07 01574
1575 * EXIT : CHB = FRACTIONAL PART(NORMALIZED STRING OF DECIMAL DIGITS) * 07 01575
1576 * DEXP = DECIMAL EXPONENT(=1 IF CHB=0) * 07 01576
1577 * SGFL = 0 POSITIVE ITEM * 07 01577
1578 * = -1 NEGATIVE ITEM * 07 01578
1579 * 07 01579
1580 * ERRORS: ER3 IF INTEGER ITEM = 2**15 * 07 01580
1581 * 07 01581
1582 ***** 07 01582
001147 036113 A 1584 GNI LDX ITEMAD,B POINT X AT ITEM 07 01584
001150 015000 A 1585 LDA J,X GET 1ST WORD OF ITEM 07 01585
001151 004317 A 1586 CSPA 15 07 01586
001152 056157 A 1587 STA SGFL,B SAVE SIGN 07 01587
001153 016116 A 1588 LDA ITMODE,B 07 01588
001154 140422 A 1589 SUB TWO 07 01589
001155 001002 A 1590 JAP GNI4 TEST FOR INTEGER LIST ITEM 07 01590
001156 001173 R 1591 ***** 07 01591
1592 * INTEGER ITEM * 07 01592
1593 ***** 07 01593
001157 015000 A 1594 LIA J,X GET INTEGER 07 01594
001160 001002 A 1595 JAP GNI2 V2 07 01595
001161 001166 R 1596 CPA 07 01596
001162 005211 A 1597 IAR 07 01597
001163 005111 A 1598 JAR ER3 ERNR 3/ INVALID INTEGER / 07 01598
001164 001004 A
001165 005155 R
001166 056003 A 1599 GNI2 STA ACC,B STORE IN ACC V2 07 01599
1600 MOVAB C10,BEXP LOAD INTEGER BIAS AS BINARY EXPONENT 07 01600
001167 010472 A
001170 056024 A
001171 001000 A 1601 JMP GNI10 07 01601
001172 001304 R
001173 005311 A 1602 GNI4 DAB GNI8 DOUBLE PRECISION # 07 01602
001174 001010 A 1603 JAZ GNI8 07 01603
001175 001227 R
001176 140422 A 1604 SUB TWO NO 07 01604
001177 001010 A 1605 JAZ GNI9 TEST DP INTEGER 07 01605
001200 001252 R

```



```

1606 *****
1607 * REAL ITEM *
1608 *****
001201 015000 A 1609 LDA 0,X GET 1ST WORD OF REAL ITEM
001202 001002 A 1610 JAP *+3 CONVERT TO ABS
001203 001203 R
001204 005211 A 1611 CPA
001205 056164 A 1612 STA TEMP,B SAVE
001206 015001 A 1613 LDA 1,X GET 2ND WORD OF REAL ITEM
001207 150460 A 1614 ANA BR15 CLEAR B15
001210 005024 A 1615 TBX LOAD X AS BASE REGISTER
001211 005012 A 1616 TAB 2ND WORD TO B-REG
001212 015164 A 1617 LDA TEMP,X 1ST WORD TO A-REG
001213 065164 A 1618 STB TEMP,X SAVE 2ND WORD
001214 004507 A 1619 LASR 7 GET BINARY EXPONENT
001215 140430 A 1620 SUB BXBIAS UNBIAS IT
001216 055024 A 1621 STA BEXP,X SAVE
001217 065003 A 1622 STB ACC,X STORE 1ST MANTISSA WORD
001220 015164 A 1623 LDA TEMP,X RESTORE 2ND WORD
001221 005002 A 1624 TZX CLEAR B
001222 004507 A 1625 LASR 7
001223 065004 A 1626 STB ACC+1,X SAVE
001224 005042 A 1627 TXB RESTORE BASE REGISTER B
001225 001000 A 1628 JMP GNI10
001226 001304 R
1629 *****
1630 * DOUBLE PRECISION ITEM *
1631 *****
001227 015001 A 1632 GNI9 LDA 1,X GET 1ST MANTISSA WORD
001230 004317 A 1633 ASRA 15
001231 056157 A 1634 STA SGFL,B GET SIGN
001232 015001 A 1635 LDA 1,X RELOAD WORD 1
001233 001002 A 1636 JAP *+3 IS ITEM NEGATIVE ?
001234 001236 R
001235 005211 A 1637 CPA YES. GET ABS VALUE
001236 056003 A 1638 STA ACC,B LOAD WORD 0 OF ACCUMULATOR
001237 015000 A 1639 LDA 0,X GET BINARY EXPONENT
001240 140430 A 1640 SUB BXBIAS UNBIAS IT
001241 056024 A 1641 STA BEXP,B SAVE
001242 015002 A 1642 LDA 2,X GET WORD 2
001243 150460 A 1643 ANA BR15 CLEAR B15
001244 056004 A 1644 STA ACC+1,B
001245 015003 A 1645 LDA 3,X GET WORD 3
001246 150460 A 1646 ANA BR15 CLEAR B15
001247 056005 A 1647 STA ACC+2,B
001250 001000 A 1648 JMP GNI10
001251 001304 R
1649 *****
1650 * DP INTEGER *
1651 *****
001252 006010 A 1652 GNI9 LDAI 30
001253 000036 A
001254 056024 A 1653 STA BEXP,B LOAD BIAS IN BINARY EXPONENT
001255 015001 A 1654 LDA 1,X GET 2ND WORD
001256 150460 A 1655 ANA BR15 CLEAR HIGH BIT
001257 050000 A 1656 STA
001260 056004 A 1657 STA ACC+1,B STORE
001261 015000 A 1658 LDA 0,X GET 1ST WORD
001262 056003 A 1659 STA ACC,B SAVE
001263 001002 A 1660 JAP GNI10 NEGATIVE #
001264 001304 R
001265 005211 A 1661 CPA YES. TAKE 1-COMP
001266 056003 A 1662 STA ACC,B
001267 016004 A 1663 LDA ACC+1,B
001270 007400 A 1664 RDF
001271 001016 A 1665 JANZ GNI9A IS WORD 2 ZERO #
001272 001300 R
001273 046003 A 1666 INR ACC,B YES. 2-COMP WORD 1
001274 001001 A 1667 JDF ER3 ERROR 3/INVALID NUMBER/
001275 005155 R
001276 001000 A 1668 JMP GNI10
001277 001304 R
001300 005211 A 1669 GNI9A CPA TAKE 2-COMP OF WORD 2
001301 005111 A 1670 IAR
001302 150460 A 1671 ANA BR15
001303 056004 A 1672 STA ACC+1,B
1673 *****
1674 * TEST FOR ZERO *
1675 *****
001304 016003 A 1676 GNI10 LDA ACC,B
001305 116004 A 1677 ORA ACC+1,B
001306 116005 A 1678 ORA ACC+2,B
001307 001016 A 1679 JANZ GNI11 IS ITEM = ZERO ?
001310 001315 R
001311 005101 A 1680 INCR 1 YES
001312 056055 A 1681 STA BEXP,B YES. SET DECIMAL EXPONENT TO 1
001313 001000 A 1682 JMP GNI50
001314 001420 R
1683 *****
1684 * CONVERT TO NORMALIZED FRACTION AND DECIMAL EXPONENT *
1685 *****
001315 105025 A 1686 GNI11 PUSHJ NRM NORMALIZE MANTISSA

```



001316	002371	R							
001317	016024	A	1687	LDA	BEXP,B				07 01687
001320	001010	A	1688	JAZ	GN150	FINISHED IF BINARY EXPONENT = ZERO			07 01688
001321	001420	R							
001322	001004	A	1689	JAN	GN120				07 01689
001323	001331	R							
			1690	*****					07 01690
			1691	* (ACC,BEXP).GE.1 DIVIDE BY 10 *					07 01691
			1692	*****					07 01692
001324	046055	A	1693	INP	BEXP,B	BUMP DECIMAL EXPONENT			07 01693
			1694	PUSHJ	D10	ACC = ACC/10		V2	07 01694
001325	105025	R							
001326	000260	R							
001327	001000	R	1695	JMP	GN111	LOOP TILL DONE			07 01695
001330	001313	R							
			1696	*****					07 01696
			1697	* (ACC,BEXP).LT.1 TEST IF .GE. .1 *					07 01697
			1698	*****					07 01698
001331	020401	A	1699	GN120	ADD	THREE			07 01699
001332	001004	A	1700	JAN	GN130	(ACC,BEXP) .LT. .1 IF BEXP .LT. -3			07 01700
001333	001403	R							
001334	001016	A	1701	JANZ	GN125	(ACC,BEXP) .GT. .1 IF BEXP .GT. -3			07 01701
001335	001371	R							
001336	015055	A	1702	LDA	BEXP,B				07 01702
001337	005311	A	1703	JAZ					07 01703
001340	001002	A	1704	JAP	GN125	DONT OSCILLATE			07 01704
001341	001374	R							
001342	016003	A	1705	LDA	ACC,B				07 01705
001343	006140	A	1706	SUBI	060146			V2	07 01706
001344	063146	A							
001345	001004	A	1707	JAN	GN130	TEST WORD 0.LT..1			07 01707
001346	001403	R							
001347	001016	A	1708	JANZ	GN125				07 01708
001350	001374	R							
001351	016004	A	1709	LDA	ACC+1,B				07 01709
001352	006140	A	1710	SUBI	060146			V2	07 01710
001353	031463	A							
001354	001004	A	1711	JAN	GN130	TEST WORD 1.LT..1			07 01711
001355	001403	R							
001356	001016	A	1712	JANZ	GN125				07 01712
001357	001374	R							
001360	016005	A	1713	LDA	ACC+2,B				07 01713
001361	006140	A	1714	SUBI	060146			V2	07 01714
001362	014031	A							
001363	001004	A	1715	JAN	GN130	TEST WORD 2.LT..1			07 01715
001364	001403	R							
001365	001016	A	1716	JANZ	GN125				07 01716
001366	001374	R							
001367	016006	A	1717	LDA	ACC+3,B				07 01717
001370	006140	A	1718	SUBI	060015			V2	07 01718
001371	046315	A							
001372	001004	A	1719	JAN	GN130	TEST WORD 3.LT..1			07 01719
001373	001403	R							
			1720	*****					07 01720
			1721	* .1 .LE. (ACC,BEXP) .LT. 1 SHIFT ACC TO POSITION *					07 01721
			1722	*****					07 01722
001374	005001	A	1723	GN125	LDA				07 01723
001375	005024	A	1724	SUB	BEXP,B				07 01724
001376	056052	A	1725	LDA	COUNT,B	LOAD SHIFT COUNT			07 01725
			1726	PUSHJ	SRA	SHIFT ACC TO POSITION		V2	07 01726
001377	105025	A							
001400	005444	R							
001401	001000	R	1727	LMP	GN130				07 01727
001402	001420	R							
			1728	*****					07 01728
			1729	* (ACC,BEXP) .LT. .1 MULTIPLY BY 10 *					07 01729
			1730	*****					07 01730
			1731	GN130	MOVAB	FOUR,COUNT	SET SHIFT COUNT TO 4		07 01731
001403	010423	A							
001404	056052	A							
001405	126024	A	1732	ADD	BEXP,B	BUMP BINARY EXPONENT BY 4			07 01732
001406	056024	A	1733	STA	FOUR,B				07 01733
			1734	PUSHJ	SRA	SHIFT ACC RIGHT 4		V2	07 01734
001407	105025	A							
001410	005444	R							
			1735	PUSHJ	D10	ACC = ACC*10		V2	07 01735
001411	105025	A							
001412	002320	R	1736	BAR	BEXP	DRDP DECIMAL EXPONENT			07 01736
001413	016055	A							
001414	005311	A							
001415	056055	A							
001416	001000	R	1737	JMP	GN111	LOOP TILL DONE			07 01737
001417	001313	R							
			1738	*****					07 01738
			1739	* GENERATE DECIMAL DIGITS *					07 01739
			1740	*****					07 01740
			1741	GN150	MOVAB	ACMP,CHRP1	INITIALIZE CHB POINTER		07 01741
001420	016007	A							
001421	056050	A							
001422	046124	A	1742	INR	MOV,B	SET MULTIPLY OVERFLOW FLAG			07 01742
			1743	GN112	PUSHJ	D10	ACC = ACC*10		V2 07 01743
001423	105025	A							



```

001424 002326 R
001425 036050 A 1744 LDX CHBPT,B POINT X AT ARRAY CHB 07 01744
001426 055000 A 1745 STA 0,X STORE DECIMAL DIGIT IN ARRAY CHB 07 01745
001427 005145 A 1746 INCR 045 BUMP ARRAY POINTER 07 01746
001430 076050 A 1747 STX CHBPT,B 07 01747
001431 146007 A 1748 SUB ACHB,B 07 01748
001432 146200 A 1749 SUB BD14,B V2 07 01749
001433 001004 A 1750 JAN GNIL2 LOOP TILL 14 DECIMAL DIGITS GENERATED 07 01750
001434 001423 R
1751 POPJ EXIT FG 07 01751
001435 105065 A
1752 EJEC 07 01752
1753 ***** 07 01753
1754 * 07 01754
1755 * GET NEXT LIST ADDRESS (GNL) * 07 01755
1756 * * 07 01756
1757 * FUNCTION: TO GET ADDRESS OF NEXT ITEM ON I/O LIST * 07 01757
1758 * * 07 01758
1759 * ENTRY: ITEMAD = ADDRESS OF PREVIOUS LIST ITEM * 07 01759
1760 * ITMINC = WORD INCREMENT BETWEEN ELEMENTS OF LIST ITEM * 07 01760
1761 * ITEMWC = COUNT OF WORDS REMAINING IN LIST ITEM * 07 01761
1762 * * 07 01762
1763 * EXIT : ITEMAD = ITEMAD+ITMINC * 07 01763
1764 * IF ITEMWC.LE.0 EXIT TO USER PROGRAM * 07 01764
1765 * ITEMWC = ITEMWC-ITMINC * 07 01765
1766 * * 07 01766
1767 ***** 07 01767
1769 GNL AD8BB ITEMAD,ITMINC,ITEMAD BUMP LIST ITEM ADDRESS 07 01769

001436 016113 A
001437 126115 A
001440 056113 A
001441 016114 A 1770 LDA ITEMWC,B 07 01770
001442 005311 A 1771 DAR 07 01771
001443 001002 A 1772 JAP GNL2 LIST ITEM FINISHED ? 07 01772
001444 001465 R
001445 006010 A 1773 LDAI GNL2 YES V2 07 01773
001446 001465 R
001447 036000 A 1774 LDX DPSTKP,B V2 07 01774
001450 005344 A 1775 DXR FG 07 01775
001451 076000 A 1776 STX DPSTKP,B FG 07 01776
001452 055000 A 1777 STA 0,X V2 07 01777
001453 010422 A 1778 LDA CEX 07 01778
1779 PUSHF PUSH EXIT OP 07 01779

001454 036016 A
001455 035000 A
001456 005344 A
001457 055000 A
001460 005041 A
001461 036016 A
001462 055000 A
001463 001000 A 1780 JMP CAN EXIT TO VSFORTIO 07 01780
001464 000065 R
1781 GNL2 SUTBBB ITEMWC,ITMINC,ITEMWC DECREMENT LIST ITEM WORD COUNT 07 01781

001465 016114 A
001466 146115 A
001467 056114 A
1782 POPJ EXIT FG 07 01782
001470 105065 A
1783 EJEC 07 01783
1784 ***** 07 01784
1785 * 07 01785
1786 * PROCESS G OUTPUT DESCRIPTOR (GOU) * 07 01786
1787 * * 07 01787
1788 * FUNCTION: TO PROCESS OUTPUT UNDER THE G FORMAT DESCRIPTOR: SRGW.D * 07 01788
1789 * * 07 01789
1790 * ENTRY: DIRECT FROM FRS * 07 01790
1791 * OUTPUT NUMBER IN (ACC,DEXP) * 07 01791
1792 * WT = W = TOTAL FIELD WIDTH * 07 01792
1793 * DT = D = FRACTIONAL FIELD WIDTH * 07 01793
1794 * * 07 01794
1795 * EXIT : DIRECT TO EDUT IF (ACC,DEXP) .LT. .1 OR .GE. 10**DT * 07 01795
1796 * OTHERWISE DIRECT TO ONF WITH * 07 01796
1797 * DT = DT-DEXP * 07 01797
1798 * IFW = DEXP * 07 01798
1799 * XFW = 4 * 07 01799
1800 * XFL = 0 * 07 01800
1801 * * 07 01801
1802 ***** 07 01802
001471 016055 A
001472 001004 A 1804 GOUT LDA DEXP,B GET DECIMAL EXPONENT 07 01804
001473 000313 R 1805 JAN EDUT PROCESS AS 'E' IF DEXP .LT. ZERO 07 01805
001474 146054 A 1806 SUB 0,B 07 01806
001475 005311 A 1807 DAR 07 01807
001476 001002 A 1808 JAP EDUT PROCESS AS 'E' IF DEXP .GE. D 07 01808
001477 000313 R
1809 MOVBBB DT,COUNT LOAD SIGNIFICANT DIGIT COUNT 07 01809

001500 016056 A
001501 036052 A
1810 PUSJ RND ROUND DECIMAL DIGIT STRING V2 07 01810

001502 105025 A
001503 005302 R
001504 016056 A 1811 LDA DT,B 07 01811
001505 146055 A 1812 SUB DEXP,B DECREMENT FRACTIONAL FIELD 07 01812
    
```



E.2 VORTEX LISTING

VORCRF

PROGRAM PAGE 24

LISTING PAGE ( 817 )

```

001506 001004 A 1813 JAN EDUT PROCESS AS 'E' ON ROUNDING OVERFLOW 07 01813
001507 000313 R
001510 056056 A 1814 STA WT,B 07 01814
1815 MOVPAE FOUR,XFW SET EXPONENT FIELD WIDTH TO 4 07 01815
001511 010420 A
001512 056170 A 1816 ZAR QFL 07 01816
001513 005001 A
001514 056170 A 1817 MOVPAE DEFP,IFW LOAD INTEGER FIELD WIDTH 07 01817
001515 010050 A
001516 056170 A 1818 JMP DEF PROCESS AS 'V' DESCRIPTOR 07 01818
001517 001000 A
001520 000300 R
1819 EJEC 07 01819
1820 ***** 07 01820
1821 * 07 01821
1822 * P R O C E S S H D E S C R I P T O R ( H I O ) * 07 01822
1823 * 07 01823
1824 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTORS. * 07 01824
1825 * 07 01825
1826 * NH.. * 07 01826
1827 * '...' * 07 01827
1828 * 07 01828
1829 * ENTRY: N = FIELD WIDTH( = 2**10-1 FOR '...' DESCRIPTOR) * 07 01829
1830 * MIN : INPUT ENTRY * 07 01830
1831 * MOUT : OUTPUT ENTRY * 07 01831
1832 * QFL = 0 NH.. SPECIFIER * 07 01832
1833 * = 1 '...' SPECIFIER * 07 01833
1834 * 07 01834
1835 * EXIT : DIRECT TO FRS * 07 01835
1836 * 07 01836
1837 ***** 07 01837
001521 R 1839 MIN EQU % 07 01839
001521 R 1840 MOUT EQU % 07 01840
1841 ZAR QFL,HIO6 TEST IF H OR '...' DESCRIPTOR 07 01841
001521 016150 A
001522 001010 A
001523 001356 R
1842 ***** 07 01842
1843 * '...' SPECIFIER * 07 01843
1844 * 07 01844
1845 ***** 07 01845
001524 005311 A 1846 DAB 07 01846
001525 001010 A 1847 JAL HIO8 QFL = 2 ? 07 01847
001526 001532 F
001527 056150 A 1848 STA QFL,B YES, SET QFL = 1 07 01848
001530 001000 A 1849 JMP HIO10 AND INPUT OVER 2ND QUOTE OF PAIR 07 01849
001531 001566 F
1850 HIO2 MOVPAE AFQCB,ASCB SET SCB TO FORMAT STRING 07 01850
001532 016011 A
001533 056021 A 1851 PUSHJ ICC INPUT FORMAT CHARACTER V2 07 01851
001534 105025 A
001535 001610 F
001536 006401 A 1852 BT (PST+OT,HIO4) IS THAT A QUOTE ? 07 01852
001537 001530 F 1853 PUSHJ ICC YES, INPUT NEXT CHARACTER V2 07 01853
001540 105025 A
001541 001610 F
001542 006401 A 1854 BT (PST+OT,FRSC5) EXIT TO FORMAT SCAN ON SINGLE QUOTE 07 01854
001543 001020 F 1855 DAB FRPT 2 CONSECUTIVE QUOTES - BACK UP FORMAT PTR 07 01855
001544 016060 A
001545 005311 A
001546 056060 A 1856 TARB QFL,WR,HIO15 READ ? 07 01856
001547 016154 A
001550 006411 A
001551 001600 R
001552 046150 A 1857 HIO4 INB QFL,B YES, SET QFL = 2 07 01857
1858 HIO4 DAB FRPT BACK UP FORMAT POINTER 07 01858
001553 016060 A
001554 005311 A
001555 056060 A 1859 ***** 07 01859
1860 * NH.. SPECIFIER * 07 01860
1861 ***** 07 01861
1862 HIO6 DAB N DECREMENT FIELD WIDTH N 07 01862
001556 016125 A
001557 005311 A
001560 056125 A
001561 001004 A 1863 JAN FRSC EXIT WHEN FIELD EXHAUSTED 07 01863
001562 000430 R 1864 TARB QFL,WR,HIO15 V2 07 01864
001563 016154 A
001564 006411 A
001565 001600 R
1865 ***** 07 01865
1866 * INPUT * 07 01866
1867 ***** 07 01867
1868 HIO10 PUSHJ OFC INPUT BUFFER CHARACTER V2 07 01868
001566 105025 A
001567 000070 R

```



E.2 VORTEX LISTING

V#RERF

PROGRAM PAGE 25

LISTING PAGE ( 818 )

Address	Op	Op	Op	Op	Op	Op	Op	Op	Op
001570	016011	A	1869	MOV BAB	AFSCB, ASCB	SET SCB TO FORMAT STRING		07	01869
001571	036021	A							
001572	016030	A	1870	MOV BAB	BCHAR, FCHAR	MOVE CHAR FROM BUFFER SCB TO FORMAT SCB		07	01870
001573	036064	A							
001574	105025	A	1871	PUSHJ	PCH	PUT CHARACTER IN FDMAT STRING	V2	07	01871
001575	003276	R							
001576	001000	A	1872	JMP	HIN	PROCESS NEXT CHAR		07	01872
001577	001521	R							
			1873	*****				07	01873
			1874	* OUTPUT *				07	01874
			1875	*****				07	01875
			1876	HID15	MOV BAB	AFSCB, ASCB	SET SCB TO FORMAT STRING	07	01876
001600	016011	A							
001601	036021	A							
001602	105025	A	1877	PUSHJ	ICC	INPUT FORMAT CHARACTER	V2	07	01877
001603	001612	R							
001604	016064	A	1878	MOV BAB	FCHAR, BCHAR	MOVE CHAR FROM FORMAT SCB TO BUFFER SCB		07	01878
001605	036030	A							
001606	105025	A	1879	PUSHJ	DCB	OUTPUT FORMAT CHARACTER TO BUFFER	V2	07	01879
001607	002441	R							
001610	001000	A	1880	JMP	HOUT	PROCESS NEXT CHAR		07	01880
001611	001521	R							
			1881	EJEC				07	01881
			1882	*****				07	01882
			1883	*				07	01883
			1884	* INPUT / CLASSIFY CHARACTER ( ICC )				07	01884
			1885	*				07	01885
			1886	* FUNCTION: TO INPUT AND CLASSIFY A CHARACTER FROM A STRING.				07	01886
			1887	*				07	01887
			1888	* ENTRY: ASCB = ADDRESS OF STRING CONTROL BLOCK SCB				07	01888
			1889	*				07	01889
			1890	* SCB(0): CURRENT CHARACTER COUNTER				07	01890
			1891	* SCB(1): STRING START ADDRESS				07	01891
			1892	*				07	01892
			1893	* EXIT : A = SCB(3) = CHARACTER CODE				07	01893
			1894	* SCB(2) = CHARACTER				07	01894
			1895	*				07	01895
			1896	*****				07	01896
			1898	*****				07	01898
			1899	* GET CHAR FROM STRING *				07	01899
			1900	*****				07	01900
001612	036021	A	1901	ICC	LDX	ASCB, B	POINT X AT SCB	07	01901
001613	015000	A	1902		LDA	0, X	GET CURRENT POINTER	07	01902
001614	045000	A	1903		INR	0, X	BUMP CURRENT POINTER	07	01903
001615	007401	A	1904	SDF	SUF			07	01904
001616	004257	A	1905		LRLA	15	CONVERT BYTE TO WORD COUNT	07	01905
001617	003004	A	1906		XAN	RDF	OVFL SET IF HIGH BYTE	07	01906
001620	002170	R							
001621	150460	A	1907		ANA	BR15	CLEAR SIGN BIT	07	01907
001622	125001	A	1908		ADD	1, X	ADD STRING START ADDRESS	07	01908
001623	003014	A	1909		TAX		POINT X AT WORD	07	01909
001624	015000	A	1910		LBP	0, X	GET WORD	07	01910
001625	003001	A	1911		XDF	LSRAB	RIGHT JUSTIFY BYTE	07	01911
001626	001710	R							
001627	150463	A	1912		ANA	RHW	CLEAR HIGH BYTE	07	01912
001630	036021	A	1913		LDX	ASCB, B	POINT X AT SCB	07	01913
001631	055002	A	1914		STA	2, X	STORE CHAR IN SCB	07	01914
			1915	*****				07	01915
			1916	* CLASSIFY CHAR *				07	01916
			1917	*****				07	01917
			1918		IFF	NUC		FG	07 01918
			1919		GOTO	NV2NUC		FG	07 01919
			1920		IFT	VII		FG	07 01920
			1921		OME	MAP, V\$ST0	SET EXEC STATE TO 00	V2	07 01921
			1922	NV2NUC	CONT			FG	07 01922
001632	034010	A	1923		LDX	ICCCT		07	01923
001633	005144	A	1924	ICCLP	IXR		POINT X AT CLASSIFICATION TABLE	07	01924
001634	145000	A	1925		SUB	0, X		07	01925
001635	001002	A	1926		JAP	ICCLP		07	01926
001636	001633	R							
001637	015022	A	1927		LDA	ICCCT1-ICCCT, X	GET CHARACTER CLASSIFICATION CODE	07	01927
			1928		IFF	NUC		FG	07 01928
			1929		GOTO	NV2NUC		FG	07 01929
			1930		IFT	VII		FG	07 01930
			1931		OME	MAP, V\$ST3	SET EXEC MODE TO NN	V2	07 01931
			1932	NV2NUC	CONT			FG	07 01932
001640	036021	A	1933		LDX	ASCB, B	POINT X AT SCB	07	01933
001641	055003	A	1934		STA	3, X	A = SCB(3) = CODE	07	01934
001642	105065	A	1935		POPJ		EXIT	FG	07 01935
			1936	*****				07	01936
			1937	* CLASSIFICATION TABLE - CHARS *				07	01937
			1938	*****				07	01938
001643	001643	R	1939	ICCCT	PZE	*		07	01939
001644	000240	A	1940		DATA	0240	SPECIAL CHAR	07	01940
001645	000001	A	1941		DATA	0241-0240	BLANK	07	01941
001646	000006	A	1942		DATA	0247-0241	SPECIAL CHAR	07	01942



```

001647 000001 A 1943 DATA 0250-0247 * QUOTE 07 01943
001650 000001 A 1944 DATA 0251-0250 *(< LEFT PAREN 07 01944
001651 000001 A 1945 DATA 0252-0251 *) RIGHT PAREN 07 01945
001652 000001 A 1946 DATA 0253-0252 SPECIAL CHAR 07 01946
001653 000001 A 1947 DATA 0254-0253 *+ PLUS SIGN 07 01947
001654 000001 A 1948 DATA 0255-0254 *, COMMA 07 01948
001655 000001 A 1949 DATA 0256-0255 *- MINUS SIGN 07 01949
001656 000001 A 1950 DATA 0257-0256 *. PERIOD 07 01950
001657 000001 A 1951 DATA 0260-0257 */ SLASH 07 01951
001660 000012 A 1952 DATA 0272-0260 NUMERIC 07 01952
001661 000007 A 1953 DATA 0301-0272 SPECIAL CHAR 07 01953
001662 000017 A 1954 DATA 0300-0301 ALPHA 07 01954
001663 000001 A 1955 DATA 0321-0320 P 07 01955
001664 000012 A 1956 DATA 0333-0321 ALPHA 07 01956
001665 000045 A 1957 DATA 0400-0333 SPECIAL CHAR 07 01957
1959 *****
1960 * CLASSIFICATION TABLE - CODES * 07 01960
1961 *****
001666 001665 R 1962 ICCCT1 EQU *-1 07 01962
001666 000000 A 1963 DATA 0 SPECIAL CHAR 07 01963
001667 000002 A 1964 DATA 2 BLANK 07 01964
001670 000000 A 1965 DATA 0 SPECIAL CHAR 07 01965
001671 001000 A 1966 DATA 01000 * QUOTE 07 01966
001672 000010 A 1967 DATA 010 *(< LEFT PAREN 07 01967
001673 002000 A 1968 DATA 02000 *) RIGHT PAREN 07 01968
001674 000000 A 1969 DATA 0 SPECIAL CHAR 07 01969
001675 000100 A 1970 DATA 0100 *+ PLUS SIGN 07 01970
001676 000004 A 1971 DATA 4 *, COMMA 07 01971
001677 000020 A 1972 DATA 020 *- MINUS SIGN 07 01972
001700 000400 A 1973 DATA 0400 *. PERIOD 07 01973
001701 004000 A 1974 DATA 04000 */ SLASH 07 01974
001702 000040 A 1975 DATA 040 NUMERIC 07 01975
001703 000000 A 1976 DATA 0 SPECIAL CHAR 07 01976
001704 000001 A 1977 DATA 1 ALPHA 07 01977
001705 000200 A 1978 DATA 0200 P 07 01978
001706 000001 A 1979 DATA 1 ALPHA 07 01979
001707 000000 A 1980 DATA 0 SPECIAL CHAR 07 01980
001710 004350 A 1981 LSRAB EQU 3 07 01981
1982 EQU 3
1983 *****
1984 * INPUT NUMERIC FORMAT FIELD (IFF) * 07 01984
1985 * FUNCTION: TO INPUT AND CONVERT AN ASCII DECIMAL STRING FROM A * 07 01985
1986 * FORMAT FIELD * 07 01986
1987 * ENTRY: 1ST DIGIT IN FCHAR * 07 01987
1988 * EXIT: BINARY EQUIVALENT IN NFF * 07 01988
1989 * ERRORS: ER1 IF NUMBER .GT. 2**16 - 1 * 07 01989
1990 *****
1991 IFF EQU NFF CLEAR COUNTER 07 01991
001711 005001 A 1999 ***** 07 01999
001712 056126 A 2000 * INPUT/CONVERT LOOP * 07 02000
2001 *****
2002 IFFL EQU BBB FCHAR, AZER, FCHAR CONVERT ASCII DIGIT TO BINARY V2 07 02002
001713 016064 A 001714 146177 A 001715 056064 A
001716 016126 A 2003 LDA NFF, B GET COUNTER 07 02003
001717 006140 A 2004 SUBI 3277 TEST IF IT CAN BE MULTIPLIED BY 10 V2 07 02004
001720 006315 A 001721 001002 A 2005 JAP ER1 ERROR 1/ NUMBER TOO LARGE V 07 02005
001722 005157 R 001723 016126 A 2006 LDA NFF, B RESTORE COUNTER IN A 07 02006
001724 005024 A 2007 TBX SAVE BASE REGISTER IN X 07 02007
001725 004560 A 2008 LLSR 16 07 02008
001726 160471 A 2009 MUL 25X 07 02009
001727 005021 A 2010 TBA 07 02010
001730 005042 A 2011 TBX RESTORE BASE REGISTER B 07 02011
001731 007400 A 2012 RCF CLEAR DVFL 07 02012
001732 126064 A 2013 ADD FCHAR, B ADD IN NEW DIGIT 07 02013
001733 001001 A 2014 JCF CR1 ERROR 1/ NUMBER TOO LARGE V 07 02014
001734 005157 R 001735 055126 A 2015 STA NFF, X UPDATE COUNTER 07 02015
2016 IFFL1 PUSHJ TOX INPUT NEXT FORMAT CHARACTER V2 07 02016
001736 105025 A 001737 001612 R 001740 006405 A 2017 RT ASET+NM, IFFL LOOP ON NUMERIC 07 02017
001741 001713 R 001742 006401 A 2018 BT ASET+BL, IFFL1 IGNORE BLANKS 07 02018
001743 001736 R 2019 POPJ EXIT ON NON-NUMERIC FG 07 02019
001744 105065 A 2020 EQU 07 02020
2021 *****
2022 * INPUT NON-BLANK FORMAT CHARACTER (INF) * 07 02022
2023 * * 07 02023
2024 * * 07 02024

```



```

2025 * FUNCTION: TO SCAN THRU A FORMAT CHAR STRING TO A NON-BLANK          * 07 02025
2026 *                                                                    * 07 02026
2027 * ENTRY: NO SPECIAL CONDITIONS                                         * 07 02027
2028 *                                                                    * 07 02028
2029 * EXIT : A = FCODE = NON-BLANK FORMAT CHAR CODE                       * 07 02029
2030 *       FCHAR = FORMAT CHAR                                           * 07 02030
2031 *                                                                    * 07 02031
2032 * *****                                                                * 07 02032
2034 INF  MOVAB  AFSCB,ASCB      SET SCB TO FORMAT STRING                  07 02034

001745 016011 A
001746 056021 A
2035 INFLP PUSHJ  ICC          INPUT/CLASSIFY CHARACTER                   V2 07 02035

001747 105025 A
101750 001612 R
001751 006401 A
001752 001747 R
2036 BT      ASET+BL,INFLP     LOOP TILL NON-BLANK INPUT                07 02036

001753 105063 A
2037 POPJ          EXIT                                               FG 07 02037

2038 EJECT                                                                07 02038
2039 *****                                                                07 02039
2040 *                                                                    * 07 02040
2041 *   P R O C E S S   I   O   U   T   D   E   S   C   R   I   P   T   O   R   (   I   O   U   )   * 07 02041
2042 *                                                                    * 07 02042
2043 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTOR: RIW       * 07 02043
2044 *                                                                    * 07 02044
2045 * ENTRY: DIRECT TO IOUT                                               * 07 02045
2046 *       NUMBER IN (CHB,DEXP,SGFL) WHERE                               * 07 02046
2047 *                                                                    * 07 02047
2048 *       CHB = 14-WORD ARRAY OF BINARY DECIMAL DIGITS                 * 07 02048
2049 *       DEXP = DECIMAL EXPONENT                                       * 07 02049
2050 *       SGFL .EQ. 0 +                                                * 07 02050
2051 *       .NE. 0 -                                                    * 07 02051
2052 *                                                                    * 07 02052
2053 * EXIT : DIRECT TO DNF                                               * 07 02053
2054 *       IFW = DEXP                                                    * 07 02054
2055 *                                                                    * 07 02055
2056 * *****                                                                * 07 02056
001754 R
2058 IOUT  EQU      *                                                    07 02058
2060 MOVAB  DEXP,COUNT                                                    07 02060

001754 016053 A
001755 056052 A
2061 PUSHJ  RND          ROUND TO DEXP DIGITS                           V2 07 02061

001756 105025 A
001757 005302 R
2062 MOVAB  DEXP,IFW        SET INTEGER COUNT TO DEXP                    07 02062

001760 016053 A
001761 056100 A
001762 001000 A
001763 002471 R
2063 JMP      DNF          OUTPUT NUMERIC FIELD                          07 02063

2064 EJECT                                                                07 02064
2065 *****                                                                07 02065
2066 *                                                                    * 07 02066
2067 *   I   N   P   U   T   E   X   T   E   R   N   A   L   N   U   M   E   R   I   C   F   I   E   L   D   (   I   X   N   )   * 07 02067
2068 *                                                                    * 07 02068
2069 * FUNCTION: TO INPUT/CONVERT AN EXTERNAL NUMERIC FIELD               * 07 02069
2070 *                                                                    * 07 02070
2071 * ENTRY: ACC(0,1,2,3) = 0                                             * 07 02071
2072 *       PTFI = 0                                                       * 07 02072
2073 *       S = SCALE FACTOR                                               * 07 02073
2074 *       SCF = 0 FOR I FORMAT DESCRIPTOR                               * 07 02074
2075 *       SGFL = 0                                                       * 07 02075
2076 *       WT = W = FIELD WIDTH IN CHARACTERS                           * 07 02076
2077 *                                                                    * 07 02077
2078 * EXIT : INPUT NUMBER = (SGFL,ACC,BEXP) , WHERE                       * 07 02078
2079 *       SGFL = SIGN FLAG = 0 FOR +                                     * 07 02079
2080 *       = 1 FOR -                                                    * 07 02080
2081 *       ACC = NORMALIZED BINARY FRACTION                             * 07 02081
2082 *       BEXP = BINARY EXPONENT                                         * 07 02082
2083 *                                                                    * 07 02083
2084 * *****                                                                * 07 02084
2086 * *****                                                                * 07 02086
2087 * CLEAR FLAGS AND COUNTERS *                                         * 07 02087
2088 * *****                                                                * 07 02088
2089 IXN  ZAB  EDEXP        CLEAR EXPLICIT DECIMAL EXPONENT              07 02089

001764 005001 A
001765 056057 A
001766 056077 A
001767 056124 A
001770 056175 A
001771 006010 A
001772 000074 A
001773 056024 A
2090 STA  IDEXP,B          CLEAR IMPLICIT DECIMAL EXPONENT              07 02090
2091 STA  NDV,B           CLEAR MULTIPLY OVERFLOW FLAG                   07 02091
2092 STA  XSG,B          CLEAR EXPONENT SIGN FLAG                         07 02092
2093 LDAI  GC                                                    V2 07 02093

001774 006010 A
001775 000566 A
001776 056053 A
2094 STA  BEXP,B          BIAS ACC AS INTEGER ACCUMULATOR              V2 07 02094
2095 *****                                                                07 02095
2096 * INPUT INTEGER AND FRACTIONAL PART *                                * 07 02096
2097 * *****                                                                * 07 02097
001777 016171 A
002000 001010 A
002001 002161 R
2098 LDAI  0566          ENABLE BLANK/','/'-'/'NUMERIC/'+'/'.' V2 07 02098

001777 016171 A
002000 001010 A
002001 002161 R
2099 STA  CVFL,B          07 02099
2100 IXNL1 TZAB  NT,IXN50  EXIT IF FIELD EXHAUSTED                      07 02100

2101 PUSHJ  CBC          INPUT BUFFER CHARACTER                          V2 07 02101
    
```



Address	Hex	Op	Op1	Op2	Description	Page	Line	
002002	105025	A						
002003	000070	R						
002004	156053	A	2102	ANA	CVFL,B		07 02102	
002005	001010	A	2103	JAZ	ERG	ERROR 3/ ILLEGAL CHAR /	07 02103	
002006	005155	R						
002007	016031	A	2104	LDA	BCODE,B	RELOAD CHARACTER CODE	07 02104	
002010	006402	A	2105	DI	ASET+CM,IXN50	STOP SCAN ON '.'	07 02105	
002011	002161	R						
002012	006400	A	2106	BT	ASET+AL,IXN15	TEST ALPHA	07 02106	
002013	002071	R						
			2107	*****			07 02107	
			2108	* PROCESS BLANK CHAR *			07 02108	
			2109	*****			07 02109	
002014	006441	A	2110	BT	ARST+RL,IXN4	TEST FOR BLANK	07 02110	
002015	002022	R						
			2111	MOVAB	AZER,BCHAR	REPLACE ASCII BLANK WITH ASCII ZERO	V2 07 02111	
002016	016177	A						
002017	056030	A						
002020	001000	A	2112	JMP	IXN10		07 02112	
002021	002062	R						
002022	016053	A	2113	IXN4	LDA	CVFL,B	NON-BLANK INPUT	
002023	150445	A	2114	ANA	PR4	DISABLE '-'	07 02114	
002024	150447	A	2115	ANA	SP6	DISABLE '+'	07 02115	
002025	056053	A	2116	STA	CVFL,B		07 02116	
			2117	*****			07 02117	
			2118	* PROCESS '+' AND '-' *			07 02118	
			2119	*****			07 02119	
002026	016031	A	2120	LDA	BCODE,B	RELOAD CHAR CODE	07 02120	
002027	006406	A	2121	BT	ASET+PL,IXN5	TEST '+'	07 02121	
002030	002041	R						
002031	006444	A	2122	BT	ARST+MN,IXN6	TEST '-'	07 02122	
002032	002046	R						
002033	016053	A	2123	LDA	CVFL,B		07 02123	
002034	006414	A	2124	BT	ASET+B12,IXN18	'-' IS EXPONENT IF BIT 12 SET	07 02124	
002035	002125	R						
002036	046157	A	2125	INR	SGFL,B	SET '-' FLAG	07 02125	
002037	001000	A	2126	JMP	IXN11	CONTINUE SCAN	07 02126	
002040	001777	R						
002041	016053	A	2127	IXN5	LDA	CVFL,B	07 02127	
002042	006414	A	2128	BT	ASET+B12,IXN18	'+' IS EXPONENT IF BIT 12 SET	07 02128	
002043	002125	R						
002044	001000	A	2129	JMP	IXN11	CONTINUE SCAN	07 02129	
002045	001777	R						
002046	000450	A	2130	IXN6	BT	ARST+PT,IXN8	TEST '.'	07 02130
002047	002056	R						
002050	046147	A	2131	INR	CVFL,B	'.' INPUT. SET FLAG	07 02131	
002051	016053	A	2132	LDA	CVFL,B		07 02132	
002052	150451	A	2133	ANA	ERG	DISABLE '.'	07 02133	
002053	056053	A	2134	STA	CVFL,B		07 02134	
002054	001000	A	2135	JMP	IXN11	CONTINUE SCAN	07 02135	
002055	001777	R						
			2136	*****			07 02136	
			2137	* PROCESS NUMERIC CHAR *			07 02137	
			2138	*****			07 02138	
002056	016053	A	2139	IXN8	LDA	CVFL,B	07 02139	
002057	006110	A	2140	ORAI	010121	ENABLE ALPHA/EXPONENT SIGN	V2 07 02140	
002060	010121	A						
002061	056053	A	2141	STA	CVFL,B		07 02141	
002062	016030	A	2142	IXN10	LDA	BCHAR,B	GET INPUT NUMERIC CHAR	
002063	146177	A	2143	SUB	ASCP,B	CONVERT ASCII DIGIT TO BINARY	V2 07 02143	
002064	056166	A	2144	STA	TERM,B		07 02144	
			2145	PUSHJ	010	ACC = ACC*10 + TERM	V2 07 02145	
002065	105025	A						
002066	002326	R						
002067	001000	A	2146	JMP	IXN11	CONTINUE SCAN	07 02146	
002070	001777	R						
			2147	*****			07 02147	
			2148	* ALPHA CHAR INPUT *			07 02148	
			2149	*****			07 02149	
002071	016030	A	2150	IXN15	LDA	BCHAR,B	07 02150	
002072	006140	A	2151	SUBI	1304		V2 07 02151	
002073	000304	A						
002074	001000	A	2152	JAN	ERG	ERROR 3/ NOT 'D' OR 'E' /	07 02152	
002075	005155	R						
002076	140422	A	2153	SUB	010		07 02153	
002077	001000	A	2154	JAP	ERG	ERROR 3/ NOT 'D' OR 'E' /	07 02154	
002100	005155	R						
			2155	*****			07 02155	
			2156	* PROCESS EXPONENT FIELD *			07 02156	
			2157	*****			07 02157	
002101	006010	A	2158	LRRI	0166		V2 07 02158	
002102	000166	A						
002103	056053	A	2159	STA	CVFL,B	ENABLE BLANK/'+'/'-'/'.'/NUMERIC	V2 07 02159	
			2160	IXN12	CLPS	BT,IXN30	EXIT IF FIELD EXHAUSTED	
002104	016171	A						
002105	001010	A						
002106	002157	R						
			2161	PUSHJ	010	INPUT BUFFER CHARACTER	V2 07 02161	
002107	105025	A						
002110	000070	R						
002111	156053	A	2162	ANA	CVFL,B		07 02162	
002112	001010	A	2163	JAZ	ERG	ERROR 3/ ILLEGAL CHAR /	07 02163	
002113	005155	R						



002114	016031	A	2164	LDA	BCODE,B	RELOAD CHARACTER CODE	07	02164	
002115	006402	A	2165	BT	ASET+CM,IXN30	STOP SCAN ON ','	07	02165	
002116	002157	R							
002117	006441	A	2166	BT	ARST+BL,IXN20	TEST FOR BLANK	07	02166	
002120	002130	R							
			2167	MOV8AB	AZER,BCHAR	REPLACE BLANK WITH ZERO	V2	07 02167	
002121	016177	A							
002122	056030	A							
002123	001000	A	2168	JMP	IXN25		07	02168	
002124	002144	R							
002125	006010	A	2169	IXN18	LDAI 0166		V2	07 02169	
002126	000166	A							
002127	056053	A	2170	STA	CVFL,B	ENABLE BLANK/NUMERIC	V2	07 02170	
002130	016053	A	2171	IXN20	LDA CVFL,B	NON-BLANK INPUT	07	02171	
002131	150445	A	2172	ANA	BR4	DISABLE '-'	07	02172	
002132	150447	A	2173	ANA	BR6	DISABLE '+'	07	02173	
002133	056053	A	2174	STA	CVFL,B		07	02174	
			2175	*****				07	02175
			2176	* PROCESS EXPONENT '+' OR '-' *				07	02176
			2177	*****				07	02177
002134	016031	A	2178	LDA	BCODE,B	RELOAD BUFFER CHARACTER CODE	07	02178	
002135	006406	A	2179	BT	ASET+PL,IXNL2	CONTINUE SCAN ON '+'	07	02179	
002136	002104	R							
002137	006444	A	2180	BT	ARST+MN,IXN25	TEST FOR '-'	07	02180	
002140	002144	R							
002141	046175	A	2181	INR	XSG,B	SET '-' EXPONENT SIGN FLAG	07	02181	
002142	001000	A	2182	JMP	IXNL2	CONTINUE SCAN	07	02182	
002143	002104	R							
			2183	*****				07	02183
			2184	* PROCESS NUMERIC EXPONENT DIGIT *				07	02184
			2185	*****				07	02185
002144	016030	A	2186	IXN25	LDA BCHAR,B	GET ASCII DIGIT	07	02186	
002145	146177	A	2187	SUB	AZER,B	CONVERT TO BINARY	V2	07 02187	
002146	005024	A	2188	TBX		SAVE BASE REGISTER SETTING IN X	07	02188	
002147	025057	A	2189	LDB	EDEXP,X		07	02189	
002150	160471	A	2190	MUL	TEN		07	02190	
002151	065057	A	2191	STB	EDEXP,X	UPDATE EXPLICIT DECIMAL EXPONENT	07	02191	
002152	005042	A	2192	TXB		RESTORE BASE REGISTER B	07	02192	
002153	001016	A	2193	JANZ	ER3	ERROR 3/ EXPONENT TOO LARGE /	07	02193	
002154	005155	R							
002155	001000	A	2194	JMP	IXNL2	CONTINUE SCAN	07	02194	
002156	002104	R							
			2195	IXN30	ZAB	SCF	DISABLE SCALE FACTOR IF EXTERNAL EXPONENT	07	02195
002157	005001	A							
002160	056156	A							
			2196	*****				07	02196
			2197	* CONVERT TO STANDARD FORM *				07	02197
			2198	*****				07	02198
002161	036001	A	2199	IXN50	LDB ACC,B	POINT X AT ACC	07	02199	
002162	015000	A	2200	LDA	0,X		07	02200	
002163	115001	A	2201	DRA	1,X		07	02201	
002164	115002	A	2202	DRA	2,X		07	02202	
002165	115003	A	2203	DRA	3,X		07	02203	
002166	001010	A	2204	JAZ	IXN57	EXIT IF ACC=0	FG	07 02204	
002167	002224	R							
002170	007400	A	2205	RDF	RDF		07	02205	
			2206	TZAB	XSG,IXN52	IS EXPONENT SIGN FLAG SET ?	V2	07 02206	
002171	016175	A							
002172	001010	A							
002173	002177	R							
002174	005001	A	2207	TZA		YES	07	02207	
002175	146057	A	2208	SUB	EDEXP,B	NEGATE EXPLICIT DECIMAL EXPONENT	07	02208	
002176	056057	A	2209	STA	EDEXP,B		07	02209	
			2210	IXN52	TNZAB	PTFL,IXN53	V2	07 02210	
002177	016147	A							
002200	001016	A							
002201	002205	R							
			2211	SUTBBB	IDEXP,D,IDEXP	NO. DECREMENT EXPONENT BY D	07	02211	
002202	016077	A							
002203	146054	A							
002204	056077	A							
			2212	IXN53	TZAB	SCF,IXN55	V2	07 02212	
002205	016156	A							
002206	001010	A							
002207	002212	R							
002210	005001	A	2213	TZA		YES	07	02213	
002211	146155	A	2214	SUB	S,B		07	02214	
002212	126077	A	2215	IXN55	ADD IDEXP,B	ADD IMPLICIT DECIMAL EXPONENT	V2	07 02215	
002213	126057	A	2216	ADD	EDEXP,B	ADD EXPLICIT DECIMAL EXPONENT	07	02216	
002214	056055	A	2217	STA	DEXP,B	STORE IN DEXP	07	02217	
002215	001001	A	2218	JDF	ER3	ERROR 3/ EXPONENT TOO LARGE /	07	02218	
002216	005155	R							
			2219	IXNL3	PUSHJ	NRM	V2	07 02219	
002217	105025	A							
002220	002371	R							
			2220	TNZAB	DEXP,IXN58		FG	07 02220	
002221	016055	A							
002222	001016	A							
002223	002225	R							
			2221	IXN57	POPJ	EXIT WHEN DEXP=0	FG	07 02221	
002224	105065	A							
002225	001002	A	2222	IXN58	JAP	IXN60	FG	07 02222	
002226	002234	R							



```

2223 *****
2224 * NEGATIVE DECIMAL EXPONENT *
2225 *****
002227 105025 A 2226 PUSHJ D10 ACC = ACC/10 V2 07 02226
002230 000260 R
002231 046055 A 2227 INR DEXP,B BUMP DEXP 07 02227
002232 001000 A 2228 JMP IXNL3 CONTINUE CONVERSION 07 02228
002233 002217 R
2229 *****
2230 * POSITIVE DECIMAL EXPONENT *
2231 *****
002234 010423 A 2232 IXN60 MOVFAB FOUR,COUNT SET RIGHT SHIFT COUNT TO 4 07 02232
002235 056052 A
002236 126024 A 2233 ADD BEXP,B BUMP BINARY EXPONENT 07 02233
002237 056024 A 2234 STA BEXP,B 07 02234
2235 PUSHJ SH4 SHIFT ACC RIGHT 4 V2 07 02235
002240 105025 A
002241 003444 R 2236 PUSHJ W10 ACC = ACC*10 V2 07 02236
002242 105025 A
002243 002326 R 2237 DAB BEXP DRUP DEXP 07 02237
002244 016055 A
002245 005311 A
002246 056055 A 2238 JMP IXNL3 CONTINUE CONVERSION 07 02238
002247 001000 A
002250 002217 R
2239 EJEC
2240 *****
2241 *
2242 * P R O C E S S L I N P U T D E S C R I P T O R S ( L I N ) *
2243 *
2244 * FUNCTION: TO PROCESS THE INPUT FORMAT DESCRIPTOR: RLW
2245 *
2246 * ENTRY: DIRECT FROM FRS
2247 * WT = W = TOTAL FIELD WIDTH
2248 * ITEMAD = ADDRESS OF LIST ITEM
2249 *
2250 * EXIT : DIRECT TO FRS
2251 * (ITEMAD) = -1 IF 1ST CHAR 'T'
2252 * = 0 IF 1ST CHAR 'F'
2253 *
2254 * ERRORS: ER3 IF 1ST NON-BLANK CHAR NOT 'T' OR 'F'
2255 *
2256 *****
002251 016171 A 2258 LIN TAB WT,ER3 ERROR 3/ BLANK FIELD / 07 02258
002252 001010 R
002253 005155 R
2259 PUSHJ DBC INPUT BUFFER CHARACTER V2 07 02259
002254 105025 A
002255 000070 R
002256 006401 A 2260 BT AWT+BL,LIN SLUR THRU BLANKS 07 02260
002257 002251 R
002260 036113 A 2261 LDX ITEMAD,B POINT X AT LIST ITEM 07 02261
002261 005301 A 2262 JECR 1 07 02262
002262 055000 A 2263 STA B,X SET LIST ITEM TO .FALSE. (-1) 07 02263
002263 016030 A 2264 LDR BCHAR,B GET INPUT CHAR 07 02264
002264 006140 A 2265 SUBT J024 V2 07 02265
002265 000324 A
002266 001010 A 2266 JAZ LINK EXIT TO FORMAT SCAN IF 'T' 07 02266
002267 002275 R
002270 045000 A 2267 INP B,X SET LIST ITEM TO .FALSE. (0) 07 02267
002271 006120 A 2268 ADDI B16 TEST FOR 'T' V2 07 02268
002272 000016 A
002273 001016 A 2269 JAZZ ER2 ERROR 3/ 1ST CHAR NOT 'T' OR 'F' / 07 02269
002274 005155 R
2270 LINK MOVFAB WT,COUNT LOAD REMAINING FIELD WIDTH AS REPEAT COUNT 07 02270
002275 016171 A
002276 056052 A
2271 PUSHJ RCR GOBBLE REST OF FIELD V2 07 02271
002277 105025 A
002300 004715 R
002301 001000 A 2272 JMP FRO65 EXIT TO FORMAT SCAN 07 02272
002302 001000 R
2273 EJEC
2274 *****
2275 *
2276 * P R O C E S S L O U T P U T D E S C R I P T O R S ( L O U ) *
2277 *
2278 * FUNCTION: TO PROCESS THE OUTPUT FORMAT DESCRIPTOR: RLW
2279 *
2280 * ENTRY: DIRECT FROM FRS
2281 * WT = W = TOTAL FIELD WIDTH
2282 * ITEMAD = ADDRESS OF LIST ITEM
2283 *
2284 * EXIT : TO FRS THRU DBC
2285 * WT-1 LEADING BLANKS OUTPUT
2286 * 'F' OUTPUT IF (ITEMAD) EQ.ZERO
2287 * 'T' OUTPUT OTHERWISE
2288 *

```



```

2289 *****
002303 016202 A 2291 LDUT MOVBA8 BLNK1,BCHAR LOAD BLANK AS FILL CHARACTER V2 07 02289
002304 056030 A
2292 DABB WT,COUNT SET COUNT TO WT-1 07 02292
002305 016171 A
002306 005311 A
002307 056052 A
2293 PUSHJ RCH OUTPUT WT-1 LEADING BLANKS V2 07 02293
002310 105025 A
002311 004715 R
002312 006010 A 2294 LDAI 0306 V2 07 02294
002313 000306 A
002314 056030 A 2295 STA BCHAR,B LOAD 'F' AS OUTPUT CHARACTER V2 07 02295
002315 036113 A 2296 LDX ITEMAD,B POINT X AT LIST ITEM 07 02296
2297 TZAX 0,LDU4 TEST LIST ITEM = 0 (FALSE) 07 02297
002316 015000 A
002317 001010 A
002320 002324 R
002321 006010 A 2298 LDAI 0324 SET OUTPUT CHAR TO 'T' IF NOT V2 07 02298
002322 000324 A
002323 056030 A 2299 STA BCHAR,B V2 07 02299
2300 LDU4 PUSHJ DCB OUTPUT 'T' OR 'F'/EXIT V2 07 02300
002324 105025 A
002325 002441 R
2301 EJEC 07 02301
2302 ***** 07 02302
2303 * 07 02303
2304 * MULT I P L Y B Y 1 0 ( N 1 0 ) * 07 02304
2305 * * 07 02305
2306 * FUNCTION: MULTIPLIES A 4-WORD FIELD ACC BY 10 AND ADDS AN INTEGER I * 07 02306
2307 * TO THE PRODUCT. MONITORS OVERFLOW AND DECIMAL EXPONENT * 07 02307
2308 * * 07 02308
2309 * ENTRY: TERM = I * 07 02309
2310 * PTFL = 1 IF A '.' HAS BEEN PASSED, 0 IF NOT * 07 02310
2311 * MOV = 1 IF OVERFLOW ALLOWED, 0 IF NOT * 07 02311
2312 * * 07 02312
2313 * EXIT : ACC=ACC*10 + I * 07 02313
2314 * A = OVERFLOW DIGIT * 07 02314
2315 * IDEXP INCREMENTED ON OVERFLOW IF PTFL = 0 * 07 02315
2316 * IDEXP DECREMENTED IF NO OVFL AND PTFL .NE. 0 * 07 02316
2317 * * 07 02317
2318 ***** 07 02318
002326 005024 A 2320 M10 TBX LOAD X AS BASE REGISTER 07 02320
002327 015003 A 2321 LDA ACC,X 07 02321
002330 006140 A 2322 SUBI 3276 V2 07 02322
002331 006314 A
002332 001004 A 2323 JAN M104 CAN ACC BE MULTIPLIED BY 10 ? 07 02323
002333 002344 R
002334 015124 A 2324 LDA MOV,X NO 07 02324
002335 001016 A 2325 JANZ M104 MULTIPLY ANYWAY IF MOV SET 07 02325
002336 002344 R
002337 015147 A 2326 LDA PTFL,X EXIT IF '.' PASSED FG 07 02326
002340 001016 A 2327 JANZ M10X OTHERWISE BUMP IMPLICIT DECIMAL EXPONENT 07 02327
002341 002370 R
002342 045077 A 2328 INR IDEXP,X AND EXIT FG 07 02328
2329 POPJ
002343 105065 A 2330 M104 LDA TERM,X LOAD I 07 02330
002344 015166 A 2331 LDB ACC+3,X ACC(3)=ACC(3)*10 + I 07 02331
002345 025006 A 2332 MUL TEN 07 02332
002346 160471 A 2333 STB ACC+3,X 07 02333
002347 065006 A 2334 LDB ACC+2,X ACC(2)=ACC(2)*10 + OVFL(3) 07 02334
002350 025005 A 2335 MUL TEN 07 02335
002351 160471 A 2336 STB ACC+2,X 07 02336
002352 065005 A 2337 LDB ACC+1,X ACC(1)=ACC(1)*10 + OVFL(2) 07 02337
002353 025004 A 2338 MUL TEN 07 02338
002354 160471 A 2339 STB ACC+1,X 07 02339
002355 065004 A 2340 LDB ACC,X ACC(0)=ACC(0)*10 + OVFL(1) 07 02340
002356 025003 A 2341 MUL TEN 07 02341
002357 160471 A 2342 STB ACC,X RESTORE BASE REGISTER B 07 02342
002360 065003 A 2343 TXB 07 02343
002361 005042 A 2344 LDX PTFL,B HAS A '.' BEEN PASSED ? FG 07 02344
002362 036147 A 2345 JXZ M10X YES 07 02345
002363 001040 A
002364 002370 R
002365 036077 A 2346 LDX IDEXP,B DECREMENT IMPLICIT DECIMAL EXPONENT 07 02346
002366 005344 A 2347 DXR 07 02347
002367 076077 A 2348 STX IDEXP,B 07 02348
2349 M10X POPJ EXIT FG 07 02349
002370 105065 A
2350 EJEC 07 02350
2351 ***** 07 02351
2352 * 07 02352
2353 * N O R M A L I Z E A C C U M U L A T O R ( N R M ) * 07 02353
2354 * * 07 02354
2355 * FUNCTION: TO NORMALIZE THE 4-WORD ACCUMULATOR ACC WITH BINARY * 07 02355
2356 * EXPONENT BEXP. * 07 02356
2357 * * 07 02357
2358 * ENTRY: ACC.NE.0 * 07 02358
2359 * * 07 02359
2360 * EXIT : (ACC,BEXP) NORMALIZED * 07 02360
2361 * * 07 02361
2362 ***** 07 02362

```



```

002371 005024 A 2364 NRM TBX LOAD X AS BASE REGISTER 07 02364
002372 015003 A 2365 NRML LDA ACC,X 07 02365
002373 004241 A 2366 LRLA 1 07 02366
002374 001004 A 2367 JAN NRMX EXIT WHEN NORMALIZED 07 02367
002375 002437 R 07 02375
002376 001016 A 2368 JANZ NRM4 ACC(0) = 0 ? 07 02368
002377 002415 R 07 02377
2369 MOVXAX ACC+1,ACC YES, SHIFT 1 WORD 07 02369
002400 015004 A 07 02400
002401 055003 A 2370 MOVXAX ACC+2,ACC+1 07 02370
002402 015005 A 07 02402
002403 055004 A 2371 MOVXAX ACC+3,ACC+2 07 02371
002404 015006 A 07 02404
002405 055005 A 2372 ZAX ACC+3 07 02372
002406 005001 A 07 02406
002407 055006 A 07 02407
002410 016024 A 2373 LDA BEXP,B 07 02373
002411 140472 A 2374 SUB 015 07 02374
002412 056024 A 2375 STA BEXP,B 07 02375
002413 001000 A 2376 JMP NRML 07 02376
002414 002372 R 07 02414
002415 015003 A 2377 NRM4 LDA ACC,X 07 02377
002416 025004 A 2378 LDB ACC+1,X 07 02378
002417 004401 A 2379 LASL 1 07 02379
002420 055003 A 2380 STA ACC,X SHIFT ACC(0) LEFT 1 07 02380
002421 015004 A 2381 LDA ACC+1,X 07 02381
002422 025005 A 2382 LDB ACC+2,X 07 02382
002423 004401 A 2383 LASL 1 07 02383
002424 055004 A 2384 STA ACC+1,X SHIFT ACC(1) LEFT 1 07 02384
002425 015005 A 2385 LDA ACC+2,X 07 02385
002426 025006 A 2386 LDB ACC+3,X 07 02386
002427 004401 A 2387 LASL 1 07 02387
002430 055005 A 2388 STA ACC+2,X SHIFT ACC(2) LEFT 1 07 02388
002431 065006 A 2389 STA ACC+3,X SHIFT ACC(3) LEFT 1 07 02389
002432 015024 A 2390 LDA BEXP,X 07 02390
002433 005311 A 2391 DAR DECREMENT BINARY EXPONENT BEXP 07 02391
002434 055024 A 2392 STA BEXP,X 07 02392
002435 001000 A 2393 JMP NRML CONTINUE NORMALIZE LOOP 07 02393
002436 002372 R 07 02436
002437 005042 A 2394 NRMX TXB RESTORE BASE REGISTER B 07 02394
2395 POPJ EXIT FG 07 02395
002440 105065 A 07 02440
2396 EJECT 07 02396
2397 ***** 07 02397
2398 * 07 02398
2399 * OUTPUT CHARACTER TO BUFFER (DCB) * 07 02399
2400 * * 07 02400
2401 * FUNCTION: TO OUTPUT A CHARACTER TO THE BUFFER * 07 02401
2402 * * 07 02402
2403 * ENTRY: BCHAR = CHARACTER TO BE OUTPUT * 07 02403
2404 * ASFL.NE.0 IF FIELD IS TO BE TERMINATED BY AN '*' * 07 02404
2405 * WT = FIELD WIDTH * 07 02405
2406 * * 07 02406
2407 * EXIT: '**' OUTPUT IF ASFL.NE.0 AND WT=1 * 07 02407
2408 * DIRECT TO FRS IF WT=0 * 07 02408
2409 * * 07 02409
2410 ***** 07 02410
2412 DCB TZAB ASFL,DCB4 IS '*' FLAG SET ? 07 02412
002441 016022 A 07 02441
002442 001010 A 07 02442
002443 002453 R 07 02443
002444 016171 A 2413 LDA WT,B YES 07 02413
002445 005311 A 2414 DAR 07 02414
002446 001016 A 2415 JANZ DCB4 WT = 1 ? 07 02415
002447 002453 R 07 02447
002450 006010 A 2416 LDAB DCB2 V2 07 02416
002451 000252 A 07 02451
002452 056030 A 2417 STA BCHAR,B YES, LOAD '*' AS OUTPUT CHARACTER V2 07 02417
2418 DCB4 PASHJ OUTPUT CHARACTER TO BUFFER V2 07 02418
002453 105025 A 07 02453
002454 000073 R 2419 TZAB WT,DCB6 FIELD EXHAUSTED ? FG 07 02419
002455 016171 A 07 02455
002456 001010 A 07 02456
002457 002461 R 2420 POPJ NO. RETURN FG 07 02420
002460 105065 A 2421 DCB6 MOVAB ADPSTK,DPSTKP YES, CLEAR STACK FG 07 02421
002461 016017 A 07 02461
002462 056000 A 2422 LDA PDLKEY,B 07 02422
002463 016061 A 2423 SUB RIGHT 07 02423
002464 140424 A 2424 JAR FRSE SCAN FOR NEXT FORMAT CHAR ON H/X 07 02424
002465 001002 R 07 02465
002466 000430 R 07 02466
002467 001000 A 2425 JMP FRSS5 RETURN TO FORMAT SCAN 07 02425
002470 001000 R 07 02470
2426 EJECT 07 02426
2427 ***** 07 02427
2428 * 07 02428
2429 * OUTPUT NUMERIC FIELD (DNF) * 07 02429

```



```

2430 *
2431 * FUNCTION: TO OUTPUT A STRING OF CHARS REPRESENTING A DECIMAL NUMBER * 07 02430
2432 *
2433 * ENTRY: OUTPUT NUMBER = (SGFL,CHB,DEXP) ,WHERE: * 07 02431
2434 *
2435 *          SGFL = SIGN = 0 FOR '+' * 07 02432
2436 *          = -1 FOR '-' * 07 02433
2437 *
2438 *          CHB = ARRAY OF BINARY DECIMAL DIGITS * 07 02434
2439 *          = NORMALIZED FRACTIONAL PART OF NUMBER * 07 02435
2440 *
2441 *          DEXP = DECIMAL EXPONENT * 07 02436
2442 *
2443 *          WT = FIELD WIDTH * 07 02437
2444 *          IFW = INTEGER FIELD WIDTH * 07 02438
2445 *          PTFL = 1 IF '.' TO BE OUTPUT, 0 OTHERWISE * 07 02439
2446 *          DT = FRACTIONAL FIELD WIDTH * 07 02440
2447 *          ZFW = WIDTH OF LEADING ZERO FIELD * 07 02441
2448 *          XFL = 1 IF EXPONENT FIELD PRESENT, 0 OTHERWISE * 07 02442
2449 *          XFW = EXPONENT FIELD WIDTH * 07 02443
2450 *
2451 * EXIT : TO FRS THRU DCB * 07 02444
2452 *
2453 * ***** * 07 02445
2454 * ***** * 07 02446
2455 * ***** * 07 02447
2456 * ***** * 07 02448
2457 * ***** * 07 02449
002471 016171 A 2458 DNF LDA WT,B GET FIELD WIDTH * 07 02450
002472 126157 A 2459 ADD SGFL,B SUBTRACT '-' * 07 02451
002473 146100 A 2460 SUB IFW,B SUBTRACT WIDTH OF INTEGER FIELD * 07 02452
002474 146147 A 2461 SUB PTFL,B SUBTRACT SPACE FOR '.' * 07 02453
002475 146056 A 2462 SUB DT,B SUBTRACT WIDTH OF FRACTIONAL FIELD * 07 02454
002476 146174 A 2463 SUB XFW,B SUBTRACT WIDTH OF EXPONENT FIELD * 07 02455
002477 056032 A 2464 STA COUNT,B STORE LEADING BLANK COUNT * 07 02456
002500 001002 A 2465 JAP DNFS TEST FOR FIELD OVERFLOW * 07 02457
002501 002521 R
2466 * ***** * 07 02458
2467 * FIELD OVERFLOW * * 07 02459
2468 * ***** * 07 02460
002502 005311 A 2469 DAR ALLOW 1 SPACE FOR '*' * 07 02461
002503 056022 A 2470 STA ASFL,B SET '*' FLAG * 07 02462
002504 126056 A 2471 ADD DT,B * 07 02463
002505 056056 A 2472 STA DT,B REDUCE FRACTIONAL FIELD * 07 02464
002506 001002 A 2473 JAP DNFS DOES FIELD STILL OVERFLOW ? * 07 02465
002507 002521 R
002510 005004 A 2474 TZX YES * 07 02466
002511 076056 A 2475 STX DT,B SET FRACTIONAL FIELD WIDTH = 0 * 07 02467
002512 126147 A 2476 ADD PTFL,B DELETE '.' * 07 02468
002513 076147 A 2477 STX PTFL,B * 07 02469
002514 126100 A 2478 ADD IFW,B * 07 02470
002515 056100 A 2479 STA IFW,B REDUCE INTEGER FIELD WIDTH * 07 02471
002516 001002 A 2480 JAP DNFS DOES FIELD STILL OVERFLOW ? * 07 02472
002517 002521 R
002520 076100 A 2481 STX IFW,B YES, SET INTEGER FIELD WIDTH = 0 * 07 02473
002521 016202 A 2482 DNF5 MOVEBAB BLNK1,BCHAR LOAD BLANK AS REPEAT CHARACTER * 07 02474
002522 056030 A
2483 PUSHJ RCH OUTPUT COUNT BLANKS * 07 02475
002523 105025 A
002524 004715 R
2484 * ***** * 07 02476
2485 * OUTPUT SIGN * * 07 02477
2486 * ***** * 07 02478
2487 TZAB SGFL,DNF20 DONT OUTPUT '+' SIGN * 07 02479
002525 016157 A
002526 001010 A
002527 002535 R
002530 006010 A 2488 LDAT 0255 * 07 02480
002531 000255 A
002532 056030 A 2489 STA BCHAR,B * 07 02481
002533 105025 A 2490 PUSHJ DCB OUTPUT '-' * 07 02482
002534 002441 R
2491 * ***** * 07 02483
2492 * OUTPUT INTEGER FIELD * * 07 02484
2493 * ***** * 07 02485
2494 DNF20 MOVEBAB IFW,COUNT LOAD LOOP COUNT * 07 02486
002535 016100 A
002536 056052 A
2495 MOVEBAB ACHB,CHBPT INITIALIZE CHB ARRAY POINTER * 07 02487
002537 016007 A
002540 056050 A
002541 016052 A 2496 DNFL1 LDA COUNT,B * 07 02488
002542 005311 A 2497 DAR DECREMENT COUNT * 07 02489
002543 001004 A 2498 JAN DNFS0 EXIT WHEN FINISHED * 07 02490
002544 002566 R
002545 056052 A 2499 STA COUNT,B * 07 02491
002546 036050 A 2500 LDX CHBPT,B * 07 02492
002547 046050 A 2501 INR CHBPT,B BUMP CHB POINTER * 07 02493
002550 015000 A 2502 LDA 0,X GET DIGIT * 07 02494
002551 126177 A 2503 ADD AZER,B CONVERT TO ASCII * 07 02495
002552 056030 A 2504 STA BCHAR,B * 07 02496
2505 PUSHJ DCB OUTPUT CHARACTER TO BUFFER * 07 02497

```



002553	105025	A							
002554	002441	R							
002555	016050	A	2506	LDA	CHPT,B			07	02506
002556	146007	A	2507	SUB	ACPB,B			07	02507
002557	146200	A	2508	SUB	BD14,B			V2	07 02508
002558	001004	A	2509	JAN	DNFL1			07	02509
002559	002341	R							
			2510	MOVBB	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER		V2	07 02510
002562	016177	A							
002563	056030	A							
			2511	PUSHJ	RCB	OUTPUT '0' FILL		V2	07 02511
002564	105025	A							
002565	004715	R							
			2512	*****				07	02512
			2513	* OUTPUT '.' *				07	02513
			2514	*****				07	02514
			2515	DNF30	TZAB	PTFL,DNF40	SKIP IF NO '.'	07	02515
002566	016147	A							
002567	001010	A							
002570	002634	R							
002571	006010	A	2516	LDAI	0256			V2	07 02516
002572	000256	A							
002573	056030	A							
			2517	STA	BCHAR,B	LOAD '.' AS OUTPUT CHARACTER		V2	07 02517
			2518	PUSHJ	RCB	OUTPUT '.'		V2	07 02518
002574	103025	A							
002575	002441	R							
			2519	*****				07	02519
			2520	* OUTPUT LEADING ZEROS IN FRACTIONAL FIELD *				07	02520
			2521	*****				07	02521
			2522	MOVBB	ZFN,COUNT	LOAD LEADING ZERO COUNT		07	02522
002576	016173	A							
002577	056052	A							
			2523	MOVBB	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER		V2	07 02523
002600	016177	A							
002601	056030	A							
			2524	PUSHJ	RCB	OUTPUT LEADING ZEROS		V2	07 02524
002602	105025	A							
002603	004715	R							
			2525	*****				07	02525
			2526	* OUTPUT FRACTIONAL PART *				07	02526
			2527	*****				07	02527
			2528	SUTBB	BT,ZFN,COUNT	LOAD COUNTER		07	02528
002604	016056	A							
002605	146176	A							
002606	056052	A							
002607	016052	A	2529	DNFL2	LDA	COUNT,B		07	02529
002610	005311	A	2530	VAR		DECREMENT COUNT		07	02530
002611	001004	A	2531	JAN	DNF40	EXIT WHEN FINISHED		07	02531
002612	002634	R							
002613	056052	A	2532	STA	COUNT,B			07	02532
002614	036050	A	2533	LDA	CHPT,B	POINT X AT DIGIT		07	02533
002615	046050	A	2534	INR	CHPT,B	BUMP CHB POINTER		07	02534
002616	015000	A	2535	LDA	0,X	GET DIGIT		07	02535
002617	126177	A	2536	ADD	0,IP,B	CONVERT TO ASCII		V2	07 02536
002620	056030	A	2537	POP	BCHAR,B			07	02537
			2538	PUSHJ	RCB	OUTPUT CHAR TO BUFFER		V2	07 02538
002621	105025	A							
002622	002441	R							
002623	016050	A	2539	LDA	CHPT,B			07	02539
002624	146007	A	2540	SUB	ACPB,B			07	02540
002625	146200	A	2541	SUB	BD14,B			V2	07 02541
002626	001004	A	2542	JAN	DNFL2			07	02542
002627	002607	R							
			2543	MOVBB	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER		V2	07 02543
002630	016177	A							
002631	056030	A							
			2544	PUSHJ	RCB	OUTPUT '0' FILL		V2	07 02544
002632	105025	A							
002633	004715	R							
			2545	DNF40	TNZAB	NFL,DNF50	TEST EXPONENT FLAG	V2	07 02545
002634	016173	A							
002635	001010	A							
002636	002645	R							
			2546	*****				07	02546
			2547	* OUTPUT BLANK EXPONENT FIELD *				07	02547
			2548	*****				07	02548
			2549	MOVBB	BLNK1,COUNT	SET BLANK COUNT TO 4		07	02549
002637	010423	A							
002640	056052	A							
			2550	MOVBB	BLNK1,BCHAR			V2	07 02550
002641	016202	A							
002642	056030	A							
			2551	PUSHJ	RCB	OUTPUT 4 BLANKS AND EXIT		V2	07 02551
002643	105025	A							
002644	004715	R							
			2552	*****				07	02552
			2553	* OUTPUT EXPONENT FIELD *				07	02553
			2554	*****				07	02554
002645	006010	A	2555	DNF50	LDAI	0255		V2	07 02555
002646	000305	A							
002647	056030	A	2556	STA	BCHAR,B	SET EXPONENT CHARACTER TO 'E'		V2	07 02556
			2557	INPAB	BLKEY,DNF52	IS FORMAT DESCRIPTOR 'D' ?		V2	07 02557
002650	016061	A							



```

002651 001016 A
002652 002656 R
2558 DAB BCHAR YES. LOAD 'D' V2 07 02558
002653 016030 A
002654 005311 A
002655 056030 A
2559 DNF32 PUSHJ OCB OUTPUT 'D' OR 'E' V2 07 02559
002656 105025 A
002657 002441 R
2560 MOVBAB BLNK1,BCHAR LOAD BLANK FOR PLUS V2 07 02560
002660 016202 A
002661 056030 A
2561 TPAB DEXP,DNF55 IS EXPONENT NEGATIVE ? 07 02561
002662 016055 A
002663 001002 A
002664 002673 R
002665 005211 A 2562 CPA YES 07 02562
002666 005111 A 2563 IAR CONVERT TO ABS 07 02563
002667 056055 A 2564 STA DEXP,B 07 02564
002670 006010 A 2565 LDAI 0255 V2 07 02565
002671 000255 A
002672 056030 A 2566 STA BCHAR,B LOAD '-' V2 07 02566
2567 DNF55 PUSHJ OCB OUTPUT EXPONENT SIGN V2 07 02567
002673 105025 A
002674 002441 R
002675 005024 A 2568 TBX LOAD X AS BASE REGISTER 07 02568
002676 005001 A 2569 TZA 07 02569
002677 025055 A 2570 LDB DEXP,X GET EXPONENT 07 02570
002700 170471 A 2571 DIV TEN GET DECIMAL DIGITS 07 02571
002701 055055 A 2572 STA DEXP,X 07 02572
002702 005021 A 2573 TBA GET TENS DIGIT IN A 07 02573
002703 005042 A 2574 TXB RESTORE BASE REGISTER B 07 02574
002704 126177 A 2575 ADD AZER,B CONVERT TO ASCII V2 07 02575
002705 056030 A 2576 STA BCHAR,B V2 07 02576
2577 PUSHJ OCB OUTPUT TENS DIGIT OF EXPONENT V2 07 02577
002706 105025 A
002707 002441 R
002710 016055 A 2578 LDA DEXP,B RESTORE UNITS DIGIT 07 02578
002711 126177 A 2579 ADD AZER,B CONVERT TO ASCII V2 07 02579
002712 056030 A 2580 STA BCHAR,B 07 02580
2581 DNF60 PUSHJ OCB OUTPUT UNITS DIGIT/ '*' / EXIT V2 07 02581
002713 105025 A
002714 002441 R
002715 001000 A 2582 JMP DNF60 07 02582
002716 002713 R
2583 EJEC 07 02583
2584 ***** 07 02584
2585 * 07 02585
2586 * OPEN FILE ( OPEN ) * 07 02586
2587 * 07 02587
2588 * FUNCTION: TO PROCESS CALLS TO OPEN AN RMD FILE * 07 02588
2589 * 07 02589
2590 * ENTRY: DIRECT FROM RBE * 07 02590
2591 * UNIT = FORTRAN UNIT NUMBER U * 07 02591
2592 * RETURN = CALL SEQUENCE ADDRESS * 07 02592
2593 * RETURN(5) = ADDRESS OF LOGICAL UNIT NUMBER L * 07 02593
2594 * RETURN(6) = ADDRESS OF FCB ARRAY * 07 02594
2595 * RETURN(7) = MODE(REWIND OR LEAVE) OF V&IOC OPEN CALL * 07 02595
2596 * 07 02596
2597 * FOR LOGICAL FILES ONLY: * 07 02597
2598 * 07 02598
2599 * RETURN(8) = ADDRESS OF LOGICAL RECORD SIZE * 07 02599
2600 * RETURN(9) = ADDRESS OF I/O BUFFER ARRAY * 07 02600
2601 * RETURN(10) = ADDRESS OF READ BEFORE WRITE FLAG * 07 02601
2602 * 07 02602
2603 * EXIT : FCB LINKED TO CHAIN * 07 02603
2604 * ADFCB = ADDRESS OF FCB * 07 02604
2605 * FCB(0) = LOGICAL RECORD SIZE * 07 02605
2606 * FCB(1) = BUFFER ADDRESS * 07 02606
2607 * FCB OPENED BY V&IOC OPEN CALL * 07 02607
2608 * FCB(11) = U = FORTRAN UNIT NUMBER * 07 02608
2609 * FCB(12)(BITS 0-7) = L = LOGICAL UNIT NUMBER * 07 02609
2610 * 07 02610
2611 * LOGICAL FILES ONLY: * 07 02611
2612 * 07 02612
2613 * FCB(3) = CURRENT LOGICAL RECORD NUMBER * 07 02613
2614 * FCB(12)(BIT RB) = 1 ENABLE READ BEFORE WRITE V2* 07 02614
2615 * = 0 DISABLE READ BEFORE WRITE V2* 07 02615
2616 * (BIT LF) = 1 LOGICAL FILE V2* 07 02616
2617 * 0 NOT LOGICAL FILE V2* 07 02617
2618 * (BIT RM) = 1 RMD DEVICE V2* 07 02618
2619 * 0 NOT RMD DEVICE V2* 07 02619
2620 * (BIT GF) = 1 GLOBAL FCB V2* 07 02620
2621 * 0 NOT GLOBAL FCB V2* 07 02621
2622 * FCB(13) = 0 * 07 02622
2623 * 07 02623
2624 ***** 07 02624
2625 ***** 07 02625
2626 ***** V2 07 02626
2627 * INITIALIZE * V2 07 02627
2628 ***** V2 07 02628
2629 DPN LOG TEMP,B GET DP V2 07 02629
2630 SUBI COPY BIAS IT V2 07 02630
002717 016164 A
002720 006140 A
002721 000016 A

```



E.2 VORTEX LISTING

V9RERF

PROGRAM PAGE

36

LISTING PAGE ( 829)

002722	001010	A	2631	JAZ	*+3	LOGICAL FILE ?	V2	07	02631
002723	002725	R							
002724	010422	A	2632	LDA	LE5	YES, SET FLAG	V2	07	02632
002725	110427	A	2633	OPN	INC	SET INITIALIZE FLAG	V2	07	02633
002726	056154	A	2634	STB	AN-L,B	STORE FLAG WORD	V2	07	02634
002727	036016	A	2635	LDM	ANR8,B	POINT X AT V9FRTIO DATA BLOCK	07		02635
			2636	MOVXAB	SYSBF,SAVE+3	STORE #8BUF AS BUFFER ADDRESS	07		02636
002730	015162	A							
002731	056035	A							
			2637	*****				07	02637
			2638	* MOVE PARAMETERS FROM CALL SEQ TO DATA BLOCK *				07	02638
			2639	*****				07	02639
002732	036151	A	2640	LDM	RETURN,B	POINT X AT CALL SEQ	07		02640
			2641	MOVXAB	5,SAVE	MOVE ADDRESS OF LOGICAL UNIT NUMBER L	07		02641
002733	015003	A							
002734	056032	A							
			2642	MOVXAB	6,SAVE+6	MOVE ADDRESS OF FCB ARRAY	V2	07	02642
002735	015006	A							
002736	056040	A							
			2643	MOVXAB	7,SAVE+1	MOVE ADDRESS OF OPEN MODE PARAMETER	07		02643
002737	015007	A							
002740	056033	A							
			2644	OPN2	DNFL,LF,OPN4	LOGICAL FILE ?	V2	07	02644
002741	016154	A							
002742	006441	A							
002743	002752	R							
			2645	MOVXAB	8,SAVE+2	YES, MOVE ADDRESS OF LOGICAL RECORD SIZE	07		02645
002744	015010	A							
002745	056034	A							
			2646	MOVXAB	9,SAVE+3	MOVE BUFFER ADDRESS	07		02646
002746	015011	A							
002747	056035	A							
			2647	MOVXAB	10,SAVE+4	SAVE ADDRESS OF READ BEFORE WRITE FLAG	07		02647
002750	015012	A							
002751	056036	A							
			2648	*****				07	02648
			2649	* PROCESS PARAMETERS *				07	02649
			2650	*****				07	02650
	002752	R	2651	OPN4	EQU	*	V2	07	02651
			2652		LF5	NUC	FG	07	02652
			2653		OPN0	NUC1	FG	07	02653
			2654		LF1	V11	FG	07	02654
			2655		OPN0	V111	FG	07	02655
			2656		IZAP	ALOC,OPN5	E.1	07	02656
			2657		LDA	SAVE+6,B	D.1	07	02657
			2658		JSR	TBK,X	V2	07	02658
			2659		ADD	OP14,B	V2	07	02659
			2660		JSR	TBK,X	V2	07	02660
			2661	OPN5	EQU	*	E.1	07	02661
			2662	V111	CONT		FG	07	02662
			2663	NUC1	CONT		FG	07	02663
002752	036032	A	2664	LDM	SAVE,B	GET ADDRESS OF LOGICAL UNIT NUMBER L	V2	07	02664
			2665	MOVXAB	9,SAVE	GET L	07		02665
002753	015000	A							
002754	056032	A							
			2666	PUSHJ	OPN	PROCESS UNIT NUMBERS U,L	V2	07	02666
002755	105025	A							
002756	003720	R							
002757	036033	A	2667	LDM	SAVE+1,B	POINT X AT OPEN MODE (CREWIB,LEAVE)	07		02667
002760	015000	A	2668	LDA	1,X	GET M	07		02668
002761	001010	A	2669	JAZ	*+3		07		02669
002762	002764	R							
002763	010435	A	2670	LDA	AS12	SET LEAVE BIT	07		02670
002764	116032	A	2671	OPN	SAVE,B	MERGE IN L	07		02671
002765	006110	A	2672	OPN1	01000	MERGE IN SPEC FTON OF I/O OPEN CNT UD	V2	07	02672
002766	003000	A							
002767	036016	A	2673	LDM	ANR8,B	POINT X AT V9FRTIO	07		02673
002770	055104	A	2674	STB	IOCONT,X	STORE I/O CONTROL WORD IN V9FRTIO	07		02674
			2675	MOVXAB	SAVE+6,ADFCB	GET FCB ADDRESS	V2	07	02675
002771	016040	A							
002772	056010	A							
002773	055010	A	2676	STB	IOFCB,X	ALSO IN V9FRTIO	V2	07	02676
002774	005014	A	2677	TAX		POINT X AT FCB	07		02677
			2678	MOVXAB	OP120,0	SET FCB(0) = 120 WORDS	V2	07	02678
002775	016201	A							
002776	055000	A							
			2679	MOVXAB	SAVE+3,1	LOAD BUFFER ADDRESS INTO FCB(1)	07		02679
002777	016035	A							
003000	055001	A							
003001	015002	A	2680	LDA	0,X	GET KEY WORD	07		02680
003002	150463	A	2681	LDA	0,X	CLEAR UPPER BYTE	07		02681
003003	006110	A	2682	OPN1	01100	SET MODE TO SECIDENTAL	V2	07	02682
003004	001400	A							
003005	055002	A	2683	STB	0,X		07		02683
			2684	*****				07	02684
			2685	* MAKE I/O OPEN CALL *				07	02685
			2686	*****				07	02686
003006	010464	A	2687	LDA	OPN		V2	07	02687
003007	006505	A	2688	STB	ADFCB	CALL V9FRTIO TO DO I/O OPEN	V2	07	02688
003016	004515	P							
			2689	*****				07	02689
			2690	* LINK FOR ON CHAIN *				07	02690
			2691	*****				07	02691



```

003011 036146 A 2692 LDX PRLINK,B POINT X AT LAST LINK OF FCB CHAIN 07 02692
                2693 MOVYBAX ADFCB,10 LINK FCB ON CHAIN 07 02693
003012 016010 A
003013 055012 A
003014 036016 A 2694 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK 07 02694
003015 045120 A 2695 INR LNKCNT,X BUMP LINK COUNT 07 02695
                2696 *****
                2697 * LOAD PARAMETERS INTO FCB ARRAY * 07 02697
                2698 ***** 07 02698
003016 005014 A 2699 TAX POINT X AT FCB(U) 07 02699
                2700 MOVYBAX UNIT,11 MOVE FORTRAN UNIT NUMBER U TO FCB(11) 07 02700
003017 016167 A
003020 055013 A
003021 016154 A 2701 LDA RWFL,B GET FLAG WORD V2 07 02701
003022 150447 A 2702 ANA INR CLEAR INITIALIZE FLAG V2 07 02702
003023 004254 A 2703 LRLA SH POSITION V2 07 02703
003024 116032 A 2704 ORA SAVE,B MERGE IN LOGICAL UNIT NUMBER L V2 07 02704
003025 055014 A 2705 STA 12,X STORE IN FCB(12) V2 07 02705
003026 006455 A 2706 BT ARST+FLF,OPN30 TEST IF LOGICAL FILE V2 07 02706
003027 003067 R
                2707 ***** 07 02707
                2708 * PROCESS LOGICAL FILE PARAMETERS * 07 02708
                2709 ***** 07 02709
003030 036034 A 2710 LDX SAVE+2,B 07 02710
                2711 MOVYBAX 0,SAVE+2 SAVE LOGICAL RECORD SIZE 07 02711
003031 015000 A
003032 056034 A
003033 036010 A 2712 LDX ADFCB,B POINT X AT FCB 07 02712
003034 055000 A 2713 STA 0,X STORE LOGICAL RECORD SIZE IN FCB(0) 07 02713
                2714 TRAB RWFL,RM,OPN30 EXIT IF NOT RND V2 07 02714
003035 016154 A
003036 006440 A
003037 003067 R
003040 036036 A 2715 LDX SAVE+4,B POINT X AT ADDR OF READ BEFORE WRITE FLAG 07 02715
003041 015000 A 2716 LDA 0,X GET FLAG 07 02716
003042 001010 A 2717 JAZ #43 07 02717
003043 003045 R
003044 010440 A 2718 LDA FRBS, SET READ BEFORE WRITE FLAG V2 07 02718
003045 036010 A 2719 LDX ADFCB,B POINT X AT FCB 07 02719
003046 115014 A 2720 ORA 12,X MERGE WITH L 07 02720
003047 055014 A 2721 STA 12,X STORE IN FCB(12) 07 02721
                2722 ZAX 13 SET FCB(13)=0 TO MARK BUFFER EMPTY 07 02722
003050 005001 A
003051 055015 A
003052 015003 A 2723 LDA 3,X GET CURRENT RECNO 07 02723
003053 005311 A 2724 DAR CHANGE FROM PAGE 1 TO BASE 0 07 02724
003054 001010 A 2725 JAZ OPN30 EXIT IF AT START OF FILE 07 02725
003055 003067 R
                2726 ***** 07 02726
                2727 * CONVERT PHYSICAL RECNO TO LOGICAL RECNO IN FCB(3) * 07 02727
                2728 ***** 07 02728
003056 005024 A 2729 TBX SAVE BASE REGISTER IN X 07 02729
003057 004560 A 2730 LLSR 16 07 02730
003060 165201 A 2731 MUL B0120,X V2 07 02731
003061 175034 A 2732 DIV SAVE+2,X CONVERT PHYSICAL POSITION TO LOGICAL 07 02732
003062 005021 A 2733 TRA 07 02733
003063 005042 A 2734 TXB RESTORE BASE REGISTER B 07 02734
003064 036010 A 2735 LDX ADFCB,B POINT X AT FCB 07 02735
003065 005111 A 2736 IAR CHANGE FROM BASE 0 TO BASE 1 07 02736
003066 055003 A 2737 STA 3,X STORE LOGICAL RECORD POSITION IN FCB(3) 07 02737
003067 010422 A 2738 OPN30 LDA CEX 07 02738
                2739 PUSHF PUSH EXIT OP DNTD V$FORTIO STACK 07 02739
003070 036016 A
003071 035000 A
003072 005344 A
003073 055000 A
003074 005041 A
003075 036016 A
003076 055000 A
003077 001000 A 2740 JMP CAN EXIT TO V$FORTIO 07 02740
003100 000065 R
                2741 EJEC 07 02741
                2742 ***** 07 02742
                2743 * 07 02743
                2744 * PROCESS AUXILIARY I/O (PAX) * 07 02744
                2745 * 07 02745
                2746 * FUNCTION: TO PROCESS THE FORTRAN AUXILIARY I/O STATEMENTS: * 07 02746
                2747 * 07 02747
                2748 * BACKSPACE U 07 02748
                2749 * ENDFILE U 07 02749
                2750 * REWIND U 07 02750
                2751 * 07 02751
                2752 * ENTRY: DIRECT FROM RBE 07 02752
                2753 * UNIT = FORTRAN UNIT NUMBER U 07 02753
                2754 * TEMP = OP = 6 BACKSPACE 07 02754
                2755 * = 7 ENDFILE 07 02755
                2756 * = 8 REWIND 07 02756
                2757 * 07 02757
                2758 * EXIT : TO V$FORTIO WITH EXIT OP STACKED 07 02758
                2759 * I/O AND EXIT OPS STACKED 07 02759
                2760 * 07 02760
                2761 ***** 07 02761
                2762 PAX SUBBP,TEMP,CBK,SAVE+1 GET BIASED OP V2 07 02763

```



E.2 VORTEX LISTING

V\$RERF

PROGRAM PAGE 38

LISTING PAGE ( 831 )

```

003101 016164 A
003102 140467 A
003103 056033 A
2764 ZAB RWFL CLEAR FLAG WORD 07 02764
003104 005001 A
003105 056154 A
2765 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER U V2 07 02765
003106 105025 A
003107 003720 R
2766 TRAB RWFL, RM, PAX50 TEST IF RMD V2 07 02766
003110 016154 A
003111 006440 A
003112 003236 R
2767 *****
2768 * U IS RMD *
2769 *****
2770 TRAB SAVE+1, PAX10 BACKSPACE 07 02767
003113 016033 A
003114 001010 A
003115 003123 R
003116 005311 A 2771 DAR NO 07 02771
003117 001010 A 2772 JAZ PAX15 ENDFILE ? 07 02772
003120 003137 R
003121 001000 A 2773 JMP PAX30 NO. REWIND 07 02773
003122 003222 R
2774 *****
2775 * BACKSPACE RMD *
2776 *****
2777 PAX10 TRAB RWFL, GF, PAX50 CALL V$IDC BACKSPACE, IF GLOBAL FCBV2 07 02774
003123 016154 A
003124 006407 A
003125 003236 R
2778 *****
2779 * BACKSPACE BY SETTING FCB(3) = FCB(3)-1 *
2780 *****
003126 036010 A 2781 LDX ADFCB, B POINT X AT FCB 07 02781
2782 DAX 3 DECREMENT CURRENT RECORD NUMBER IN FCB(3) 07 02782
003127 015003 A
003130 005311 A
003131 055003 A
003132 005311 A 2783 DAR 07 02783
003133 001004 A 2784 JAN PAX30 DO REWIND IF FCB(3).LT.1 07 02784
003134 003222 R
003135 001000 A 2785 JMP PAX70 EXIT 07 02785
003136 003246 R
2786 *****
2787 * ENDFILE RMD *
2788 *****
2789 PAX15 TRAB RWFL, PD, PAX16 POST BIT SET ? V2 07 02789
003137 016154 A
003140 006442 A
003141 003144 R
2790 PUSHJ PSB YES. POST BUFFER V2 07 02790
003142 105025 A
003143 004465 A
003144 006010 A 2791 PAX16 LDAI 013400 GET SKELETON CLOSE/UPDATE CONTROL WD V2 07 02791
003145 013400 A
003146 116167 A 2792 ORA UNIT, B MERGE IN LOGICAL UNIT NUMBER 07 02792
003147 036016 A 2793 LDX ANRB, B POINT X AT V$FRTID DATA BLOCK 07 02793
003150 055104 A 2794 STA IDCNT, X STORE IDC CONTROL WORD IN V$FRTID 07 02794
003151 016154 A 2795 LDA RWFL, B 07 02795
003152 006441 A 2796 BT ARST+LF, PAX20 LOGICAL FILE ? 07 02796
003153 003175 R
003154 036010 A 2797 LDX ADFCB, B YES. POINT X AT FCB 07 02797
2798 MOVBAV BB120, 0 SET RECORD SIZE FCB(0) = 120 WORDS V2 07 02798
003155 016201 A
003156 055000 A
003157 016121 A 2799 LDA LRECND, B 07 02799
003160 005311 A 2800 DAR CONVERT FROM BASE 1 TO BASE 0 07 02800
003161 005024 A 2801 YEX SAVE BASE REGISTER IN X 07 02801
003162 004560 A 2802 LLSR 16 07 02802
003163 165122 A 2803 MUL LRSZ, X GET WORD COUNT 07 02803
003164 175201 A 2804 DIV TD120, X CONVERT TO 120-WORD PHYSICAL REC CNT V2 07 02804
003165 001010 A 2805 JAZ *+3 07 02805
003167 005122 A 2806 IRR BUMP 1 FOR PARTIAL RECORD 07 02806
003170 005122 A 2807 IRR BUMP 1 TO CONVERT TO BASE 1 07 02807
003171 005021 A 2808 TRB 07 02808
003172 005042 A 2809 TRB RESTORE BASE REGISTER B 07 02809
003173 036010 A 2810 LDX ADFCB, B POINT X AT FCB 07 02810
003174 055003 A 2811 STA 7, X STORE CURRENT PHYSICAL RECND IN FCB(3) 07 02811
003175 010464 A 2812 PAX20 LDA CID V2 07 02812
003176 006505 A 2813 JSR PSJ, X CALL V$IDC FOR CLOSE/UPDATE V2 07 02813
003177 004515 R
003200 006010 A 2814 LDAI 013000 GET IDC OPEN/LEAVE SKELETON CONTROL WD V2 07 02814
003201 013000 A
003202 116167 A 2815 ORA UNIT, B MERGE IN LOGICAL UNIT NUMBER 07 02815
003203 036016 A 2816 LDX ANRB, B POINT X AT V$FRTID 07 02816
003204 055104 A 2817 STA IDCNT, X STORE IDC CONTROL WORD IN V$FRTID 07 02817
003205 010464 A 2818 LDA CID V2 07 02818
003206 006505 A 2819 JSR PSJ, X CALL V$IDC FOR OPEN/LEAVE V2 07 02819
003207 004515 R
2820 TRAB RWFL, LF, PAX70 EXIT IF NOT LOGICAL FILE V2 07 02820

```



```

003210 016154 A
003211 006441 A
003212 003246 R
003213 036010 A 2821 LDX ADFCB,B POINT X AT FCB 07 02821
2822 MOV BAX LRSZ,0 RESTORE LOGICAL RECORD SIZE IN FCB(0) 07 02822
003214 016122 A
003215 055000 A 2823 MOV BAX LRECNO,3 RESTORE CURR LOG RECORD NUMBER IN FCB(3) 07 02823
003216 016121 A
003217 055003 A
003220 001000 A 2824 JMP PAX70 EXIT 07 02824
003221 003246 R
2825 *****
2826 * REWIND RMD *
2827 *****
2828 PAX30 TRAB RWFL,GF,PAX33 GLOBAL FCB ? V2 07 02828
003222 016154 A
003223 006447 A
003224 003231 R
003225 006010 A 2829 LDAI 03000 YES. CALL V$IDC OPEN/REWIND V2 07 02829
003226 003000 A
003227 001000 A 2830 JMP PAX55 07 02830
003230 003241 R
003231 036010 A 2831 PAX33 LDX ADFCB,B POINT X AT FCB 07 02831
003232 005101 A 2832 INCR 1 07 02832
003233 055003 A 2833 STA 3,X SET CURRENT RECORD NUMBER TO 1 07 02833
003234 001000 A 2834 JMP PAX70 EXIT 07 02834
003235 003246 R
2835 *****
2836 * CALL V$IDC TO DO OP *
2837 *****
003236 036033 A 2838 PAX50 LDX SAVE+1,B GET BIASED OP IN X V2 07 02838
2839 IFF NUC 07 02839
2840 GOTO NV2NUC FG 07 02840
2841 IFT VII FG 07 02841
2842 DME MAP,V$STO V2 07 02842
2843 NV2NUC CONT SET EXEC STATE TO 00 FG 07 02843
2844 LDAE PAXTAB,X GET IDC CONTROL WORD MODEL 07 02844
003237 006015 A
003240 003273 R
2845 IFF NUC FG 07 02845
2846 GOTO NV2NUC FG 07 02846
2847 IFT VII FG 07 02847
2848 DME MAP,V$ST3 V2 07 02848
2849 NV2NUC CONT SET EXEC STATE TO NN FG 07 02849
003241 116167 A
003242 036016 A 2850 PAX55 CRA UNIT,B MERGE IN LOGICAL UNIT NUMBER 07 02850
003243 055104 A 2851 LDX ANRB,B 07 02851
003244 007400 A 2852 STA IOCONT,X STORE AS IDC CONTROL WORD 07 02852
003245 001006 A 2853 RDE 07 02853
003246 007401 A 2854 DATA 01006 07 02854
003247 010422 A 2855 PAX70 SDF 07 02855
2856 LDA CEX 07 02856
2857 PUSHF 07 02857
003250 036016 A
003251 035000 A
003252 005344 A
003253 055000 A
003254 005041 A
003255 036016 A
003256 055000 A
003257 001001 A 2858 JDF CAN EXIT IF DONE 07 02858
003260 000065 R
003261 010464 A 2859 LDA CIO 07 02859
2860 PUSHF 07 02860
003262 036016 A
003263 035000 A
003264 005344 A
003265 055000 A
003266 005041 A
003267 036016 A
003270 055000 A
003271 001000 A 2861 JMP CAN EXIT 07 02861
003272 000065 R
2862 *****
2863 * AUXILIARY I/O CONTROL WORD TABLE *
2864 *****
003273 012000 A 2865 PAXTAB DATA 012000 BACKSPACE 07 02865
003274 001000 A 2866 DATA 01000 WRITE EOF 07 02866
003275 001400 A 2867 DATA 01400 REWIND 07 02867
2868 EJEC 07 02868
2869 *****
2870 *
2871 * PUT CHARACTER ( P C H ) *
2872 *
2873 * FUNCTION: TO STORE A CHARACTER *
2874 *
2875 * ENTRY: ASCB = ADDRESS OF STRING CONTROL BLOCK SCB *
2876 *
2877 * SCB(0): CURRENT CHARACTER COUNTER *
2878 * SCB(1): STRING START ADDRESS *
2879 * SCB(2): CHARACTER TO BE STORED *
2880 *
2881 * EXIT : SCB(0) = SCB(0)+1 *
2882 *

```



```

003276 036021 A 2883 *****
2885 PCH LDX ASCB,B POINT X AT SCB 07 02885
2886 MOVXAB 2,TEMP SAVE CHAR 07 02886

003277 015002 H
003300 056164 A
003301 015000 A 2887 LDA 0,X GET CURRENT POINTER 07 02887
003302 045000 A 2888 INR 0,X BUMP CURRENT POINTER 07 02888
003303 007401 A 2889 SOF 07 02889
003304 004257 A 2890 LRLA 15 CONVERT BYTE TO WORD COUNT 07 02890
003305 003004 A 2891 XAN R0F DVFL SET IF HIGH BYTE 07 02891
003306 002170 R
003307 150460 A 2892 ANA BR15 CLEAR SIGN BIT 07 02892
003310 125001 A 2893 ADD 1,X ADD STRING START ADDRESS 07 02893
003311 005014 A 2894 TAX POINT X AT WORD 07 02894
003312 015000 A 2895 LDA 0,X GET WORD 07 02895
003313 001007 A 2896 JOFN *+4 HIGH BYTE ? 07 02896
003314 003317 R
003315 007401 A 2897 SOF YES 07 02897
003316 004250 A 2898 LRLAB LRLA 8 SWAP BYTES 07 02898
003317 150462 A 2899 ANA LHW CLEAR UNWANTED BYTE 07 02899
003320 116164 A 2900 ORA TEMP,B MERGE IN NEW CHARACTER 07 02900
003321 003001 A 2901 XOF LRLAB SWAP BYTES IF HIGH BYTE 07 02901
003322 003316 R
003323 055000 A 2902 STA 0,X STORE IN MEMORY 07 02902
2903 POPJ EXIT FG 07 02903

003324 105065 A
2904 EJEC 07 02904
2905 ***** 07 02905
2906 * 07 02906
2907 * PROCESS NUMERIC INPUT DESCRIPTOR * 07 02907
2908 * ( P N I ) * 07 02908
2909 * 07 02909
2910 * FUNCTION: TO PROCESS THE INPUT FORMAT DESCRIPTORS: * 07 02910
2911 * 07 02911
2912 * 07 02912
2913 * SRDE.D * 07 02913
2914 * SREW.D * 07 02914
2915 * SRFN.D * 07 02915
2916 * SRGW.D * 07 02916
2917 * RIW * 07 02917
2918 * 07 02918
2919 * ENTRY: (ACC,BEXP,SGFL) = INPUT NUMBER, WHERE * 07 02919
2920 * ACC = NORMALIZED BINARY FRACTION * 07 02920
2921 * BEXP = BINARY EXPONENT * 07 02921
2922 * SGFL = SIGN .EQ. 0 + * 07 02922
2923 * .NE. 0 - * 07 02923
2924 * ITEMAD = ADDRESS OF LIST ITEM * 07 02924
2925 * IWSZ = WORD COUNT OF LIST ITEM * 07 02925
2926 * ITMODE = LIST ITEM MODE * 07 02926
2927 * = 0 1-WORD INTEGER/LOGICAL * 07 02927
2928 * = 1 2-WORD INTEGER/LOGICAL * 07 02928
2929 * = 2 REAL * 07 02929
2930 * = 3 DOUBLE PRECISION * 07 02930
2931 * = 4 COMPLEX * 07 02931
2932 * 07 02932
2933 * EXIT : DIRECT TO FRS * 07 02933
2934 * 07 02934
2935 ***** 07 02935
003325 R 2937 DIN EQU * 07 02937
003325 R 2938 EIN EQU * 07 02938
003325 R 2939 FIN EQU * 07 02939
003325 R 2940 GIN EQU * 07 02940
003325 R 2941 IIN EQU * 07 02941
2942 ***** 07 02942
2943 ***** 07 02943
2944 * TEST FOR ZERO * 07 02944
2945 ***** 07 02945
003325 007401 A 2946 SOF 07 02946
003326 016004 A 2947 LDA ACC+1,B 07 02947
003327 116005 A 2948 ORA ACC+2,B 07 02948
003330 116006 A 2949 ORA ACC+3,B 07 02949
003331 003010 A 2950 XAZ R0F DVFL RESET IF ACC(1)=ACC(2)=ACC(3)=0 07 02950
003332 002170 R
003333 116003 A 2951 ORA ACC,B 07 02951
003334 001010 A 2952 JAZ PNI50 EXIT IF ACC=0 07 02952
003335 003530 R
003336 016116 A 2953 LDA ITMODE,B 07 02953
003337 140422 A 2954 SUB TWD 07 02954
003340 001002 A 2955 JAP PHJ4 TEST INTEGER LIST ITEM 07 02955
003341 003410 R
2956 ***** 07 02956
2957 * INTEGER LIST ITEM * 07 02957
2958 ***** 07 02958
003342 001001 A 2959 JOF ER3 ERROR 3/ NOT INTEGER / 07 02959
003343 005155 R
003344 016024 A 2960 LDA BEXP,B GET BINARY EXPONENT 07 02960
003345 005311 A 2961 ORA ER3 07 02961
003346 001004 A 2962 JAN ER3 ERROR 3/ NOT INTEGER / 07 02962
003347 005155 R
003350 140472 A 2963 SUB B15 07 02963
003351 001002 A 2964 JAP ER3 ERROR 3/ NOT INTEGER / 07 02964
003352 005155 R
2965 MOVBAB ACC,TEMP SAVE LEFT-JUSTIFIED INTEGER 07 02965
003353 016003 A

```



Address	Label	Operation	Description	Page
003354	056164	A		
2966	ZAB	ACC	CLEAR ACCUMULATOR ACC	07 02966
003355	005001	A		
003356	056003	A		
2967	*****			07 02967
2968	* INTEGER SHIFT LOOP *			07 02968
2969	*****			07 02969
003357	005024	A		
2970	TBX		USE X AS BASE REGISTER	07 02970
2971	PNIL1 DAX	BEXP	DECREMENT BINARY EXPONENT	07 02971
003360	015024	A		
003361	005311	A		
003362	055024	A		
003363	001004	A		
2972	JAN	PNIL1X	EXIT ON FINISH	07 02972
003364	003374	R		
003365	015003	A		
2973	LDA	ACC,X		07 02973
003366	025164	A		
2974	LDB	TEMP,X		07 02974
003367	004401	A		
2975	LASL	1	SHIFT INTEGER INTO ACC	07 02975
003370	055003	A		
2976	STA	ACC,X		07 02976
003371	065164	A		
2977	STB	TEMP,X		07 02977
003372	001000	A		
2978	JMP	PNIL1	CONTINUE TILL DONE	07 02978
003373	003360	R		
003374	001026	A		
2979	PNIL1X JBNZ	ER3	ERROR 3/ NOT INTEGER /	V2 07 02979
003375	005155	R		
003376	005042	A		
2980	TXB		RESTORE BASE REGISTER B	V2 07 02980
2981	TZAB	SGFL,PNI50	IS SIGN NEGATIVE ?	07 02981
003377	016157	A		
003400	001010	A		
003401	003530	R		
003402	016003	A		
2982	LDA	ACC,B	YES	07 02982
003403	005211	A		
2983	CPA		NEGATE INTEGER	07 02983
003404	005111	A		
2984	IAR			07 02984
003405	056003	A		
2985	STA	ACC,B		07 02985
003406	001000	A		
2986	JMP	PNI50		07 02986
003407	003530	R		
003410	130464	A		
2987	PNI4 ERA	THREE		07 02987
003411	001010	A		
2988	JAZ	PNI60	D.P. INTEGER	07 02988
003412	003553	R		
003413	140422	A		
2989	SUB	TWO		07 02989
003414	001010	A		
2990	JAZ	PNI8	D.P.	07 02990
003415	003452	R		
2991	*****			07 02991
2992	* CONSTRUCT REAL *			07 02992
2993	*****			07 02993
003416	016004	A		
2994	LDA	ACC+1,B	GET 2ND MANTISSA WORD	07 02994
003417	120430	A		
2995	ADD	BS7	ROUND UPWARD	07 02995
003420	007400	A		
2996	RDF			07 02996
003421	001002	A		
2997	JAP	*+4	OVERFLOW ?	07 02997
003422	003425	R		
003423	005001	A		
2998	TZA		YES. CLEAR WORD	07 02998
003424	046003	A		
2999	INR	ACC,B	BUMP WORD 0	07 02999
003425	056004	A		
3000	STA	ACC+1,B		07 03000
003426	001007	A		
3001	JDFN	*+5	OVERFLOW ?	07 03001
003427	003433	R		
003430	046024	A		
3002	INR	BEXP,B	YES. BUMP BINARY EXPONENT	07 03002
3003	MOVPA8	BS14,ACC	SHIFT FIELD	07 03003
003431	010437	A		
003432	056003	A		
003433	005024	A		
3004	TBX		LOAD X AS BASE REGISTER	07 03004
003434	015024	A		
3005	LDA	BEXP,X	GET BINARY EXPONENT IN A	07 03005
003435	120430	A		
3006	ADD	RXBIAS	ADD BINARY EXPONENT BIAS	V2 07 03006
003436	025003	A		
3007	LDB	ACC,X	GET HIGH WORD OF MANTISSA IN B	07 03007
003437	004407	A		
3008	LASL	7	POSITION AS TO MAKE 1ST WORD OF REAL	07 03008
003440	055164	A		
3009	STA	TEMP,X	SAVE 1ST WORD OF REAL	07 03009
003441	015003	A		
3010	LDA	ACC,X	GET 1ST MANTISSA WORD IN A	07 03010
003442	025004	A		
3011	LDB	ACC+1,X	GET 2ND MANTISSA WORD IN B	07 03011
003443	004407	A		
3012	LASL	7	POSITION AS 2ND WORD OF REAL	07 03012
003444	055004	A		
3013	STA	ACC+1,X	STORE IN ACC	07 03013
003445	005042	A		
3014	TXB		RESTORE BASE REGISTER B	07 03014
3015	MOVBA8	TEMP,ACC	LOAD 1ST WORD OF REAL INTO ACC(0)	07 03015
003446	016164	A		
003447	056003	A		
003450	001000	A		
3016	JMP	PNI19		07 03016
003451	003513	R		
3017	*****			07 03017
3018	* CONSTRUCT DOUBLE PRECISION *			07 03018
3019	*****			07 03019
003452	016006	A		
3020	PNI8 LDA	ACC+3,B		07 03020
003453	004241	A		
3021	LRLA	1		07 03021
003454	001002	A		
3022	JAP	PNI18	OVERFLOW ?	07 03022
003455	003501	R		
003456	046005	A		
3023	INR	ACC+2,B	YES. BUMP WORD 2	07 03023
003457	016005	A		
3024	LDA	ACC+2,B	GET WORD	07 03024
003460	001002	A		
3025	JAP	PNI18	OVERFLOW ?	07 03025
003461	003501	R		
003462	046004	A		
3026	INR	ACC+1,B	YES. BUMP WORD 1	07 03026
003463	005001	A		
3027	TZA		CLEAR WORD 2	07 03027
003464	056005	A		
3028	STA	ACC+2,B	GET WORD 1	07 03028
003465	016004	A		
3029	LDA	ACC+1,B	GET WORD 1	07 03029
003466	001002	A		
3030	JAP	PNI18	OVERFLOW ?	07 03030
003467	003501	R		
003470	046003	A		
3031	INR	ACC,B	YES. BUMP WORD 0	07 03031
003471	005001	A		
3032	TZA			07 03032
003472	055004	A		
3033	STA	ACC+1,B	CLEAR WORD 1	07 03033



003473	016003	A	3034	LDA	ACC,B	GET WORD 0		07	03034	
003474	001002	A	3035	JAP	PNI18	OVERFLOW ?		07	03035	
003475	003501	R								
003476	046024	A	3036	INR	BEXP,B	YES. BUMP BINARY EXPONENT		07	03036	
003477	010437	A	3037	LDA	BS14	AND SHIFT OVERFLOW BIT		07	03037	
003500	056003	A	3038	STA	ACC,B	STORE WORD 0		07	03038	
			3039	PNI18	MOV BAB	ACC+2,ACC+3	SHIFT FIELD	07	03039	
003501	016005	A								
003502	056006	A								
			3040		MOV BAB	ACC+1,ACC+2		07	03040	
003503	016004	A								
003504	056003	A								
			3041		MOV BAB	ACC,ACC+1		07	03041	
003505	016003	A								
003506	056004	A								
003507	016024	A	3042	LDA	BEXP,B	GET BINARY EXPONENT		07	03042	
003510	120430	A	3043	ADD	BXBIAS	ADD BINARY EXPONENT BIAS	V2	07	03043	
003511	056003	A	3044	STA	ACC,B	STORE IN WORD 0		07	03044	
003512	005124	A	3045	INCR	024	POINT X AT BASE+1		07	03045	
003513	016157	A	3046	PNI19	LDA	SGFL,B		07	03046	
003514	001010	A	3047	JAZ	PNI20	IS SIGN FLAG SET ?		07	03047	
003515	003521	R								
003516	015003	A	3048	LDA	ACC,X	YES		07	03048	
003517	005211	A	3049	CPA		NEGATE NUMBER		07	03049	
003520	055003	A	3050	STA	ACC,X			07	03050	
			3051		*****			07	03051	
			3052		* CHECK EXPONENT RANGE *			07	03052	
			3053		*****			07	03053	
003521	016024	A	3054	PNI20	LDA	BEXP,B	GET BINARY EXPONENT		07	03054
003522	120430	A	3055	ADD	BXBIAS	ADD BINARY EXPONENT BIAS	V2	07	03055	
003523	001004	A	3056	JAN	ER3	ERROR 3/ UNDERFLOW /		07	03056	
003524	005155	R								
003525	150462	A	3057	ANA	LHW			07	03057	
003526	001016	A	3058	JANZ	ER3	ERROR 3/ OVERFLOW /		07	03058	
003527	005155	R								
			3059		*****			07	03059	
			3060		* LOAD LIST ITEM *			07	03060	
			3061		*****			07	03061	
003530	005001	A	3062	PNI50	ZAB	COUNT	CLEAR COUNTER	07	03062	
003531	056052	A								
			3063		MOV BAB	ACC,TEMP	INITIALIZE ACC POINTER	07	03063	
003532	016001	A								
003533	056164	A								
			3064		MOV BAB	ITEMAD,BEXP	INITIALIZE LIST ITEM POINTER	07	03064	
003534	016113	A								
003535	056024	A								
003536	036164	A	3065	PNI12	LDX	TEMP,B	POINT X AT ACC	07	03065	
003537	015000	A	3066	LDA	0,X	GET WORD		07	03066	
003540	036024	A	3067	LDB	BEXP,B	POINT X AT LIST ITEM		07	03067	
003541	055000	A	3068	STA	0,X	STORE DATA IN LIST ITEM		07	03068	
003542	046164	A	3069	INR	TEMP,B	BUMP ACC POINTER		07	03069	
003543	046024	A	3070	INR	BEXP,B	BUMP LIST ITEM POINTER		07	03070	
003544	046052	A	3071	INR	COUNT,B	BUMP LOOP COUNT		07	03071	
003545	016052	A	3072	LDA	COUNT,B			07	03072	
003546	146102	A	3073	SUB	IWSZ,B			07	03073	
003547	001004	A	3074	JAN	PNI12	LOOP TILL ITEM FILLED		07	03074	
003550	003536	R								
003551	001000	A	3075	JMP	FRS55	EXIT TO FRS		07	03075	
003552	001003	R								
			3077		* PROCESS	DOUBLE PRECISION INTEGER	*	07	03077	
003553	016005	A	3078	PNI60	LDA	ACC+2,B		07	03078	
003554	116006	A	3079	ORA	ACC+3,B			07	03079	
003555	001016	A	3080	JANZ	ER3	NOT INTEGER		07	03080	
003556	005155	R								
003557	016024	A	3081	LDA	BEXP,B			07	03081	
003560	005311	A	3082	BAR				07	03082	
003561	001004	A	3083	JAN	ER3	NOT INTEGER		07	03083	
003562	005155	R								
003563	006140	A	3084	SUBI	30			07	03084	
003564	000036	A								
003565	001002	A	3085	JAP	ER3	NOT INTEGER		07	03085	
003566	005155	R								
003567	005024	A	3086	TSX				07	03086	
003570	005111	A	3087	PNI62	IAR	POSITION VALUE		07	03087	
003571	001002	A	3088	JAP	PNI64	DONE		07	03088	
003572	003604	R								
003573	055024	A	3089	STA	BEXP,X			07	03089	
003574	015003	A	3090	LDA	ACC,X			07	03090	
003575	025004	A	3091	LDB	ACC+1,X			07	03091	
003576	004501	A	3092	LASR	1			07	03092	
003577	055003	A	3093	STA	ACC,X			07	03093	
003578	065004	A	3094	STB	ACC+1,X			07	03094	
003601	015024	A	3095	LDA	BEXP,X			07	03095	
003602	001000	A	3096	JMP	PNI62			07	03096	
003603	003570	R								
003604	005042	A	3097	PNI64	TXB	RESTORE BASE REGISTER B		07	03097	
			3098	YZAB	SGFL,PNI50	POSITIVE SIGN		07	03098	
003605	016157	A								
003606	001010	A								
003607	003530	R								
003610	015004	A	3099	LDA	ACC+1,X	NEGATE VALUE		07	03099	
003611	025003	A	3100	LDB	ACC,X			07	03100	



```

003612 005211 A 3101      CPA
003613 005222 A 3102      CPB
003614 005111 A 3103      IAR
003615 001002 A 3104      JAP          PNI66
003616 003621 R
003617 130440 A 3105      CRA          3315
003620 005122 A 3106      IER
003621 005004 A 3107 PNI66      STA          ACC+1,X
003622 065003 A 3108      STB          ACC,X
003623 005042 A 3109      TXB
003624 001000 A 3110      JMP          PNI50
003625 003530 R
3111      EJEC
3112 *****
3113 *
3114 *          P O P / J U M P ( P O J )
3115 *
3116 * FUNCTION: TO PROVIDE A POP/JUMP CAPABILITY
3117 *
3118 * ENTRY: DPSTKP = DP STACK POINTER
3119 *
3120 * EXIT : DIRECT TO ROUTINE SPECIFIED BY DP
3121 *          DPSTKP INCREMENTED
3122 *
3123 *****
003626 036000 A 3125 PDJ      LDX          DPSTKP,B      POINT X AT DP
003627 035000 A 3126      LDX          0,X          GET DP IN X
003630 046000 A 3127      INR          DPSTKP,B      BUMP STACK POINTER
003631 006705 A 3128      IJMP         0,X          EXIT
003632 000000 A
3129      EJEC
3130 *****
3131 *
3132 *          P R O C E S S   E N C O D E / D E C O D E
3133 *
3134 * FUNCTION: TO PROCESS THE FORTRAN STATEMENTS
3135 *          ENCODE(S,F,B,C)
3136 *          DECODE(S,F,B,C)
3137 *
3138 * ENTRY: DIRECT FROM RBE
3139 *          RETURN = ADDRESS OF PARAMETER LIST
3140 *          UNIT = BUFFER SIZE
3141 *          TEMP = DP = CDC DECODE
3142 *          CEN ENCODE
3143 *
3144 * EXIT: ENCODE - BUFFER BLANKED
3145 *          FRMT = ADDRESS OF FORMAT STRING
3146 *          XFFL = 1 PARAMETER XFER ENABLED
3147 *          ITEMWC = 0 COUNT OF WORDS REMAINING IN LIST ITEM
3148 *          DIRECT TO FRS TO START FORMAT SCAN
3149 *
3150 *****
003633 016164 A 3151 PRD      LDA          TEMP,B
003634 006140 A 3152      SUBI         CDC
003635 000020 A
003636 004250 A 3153      LRLA         8          POSITION READ/WRITE FLAG
003637 056104 A 3154      STA          IDCONT,B
003640 001010 A 3155      JAZ          **3
003641 003643 R
003642 010432 A 3156      LDA          WRS          SET WRITE BIT
003643 110431 A 3157      ORA          BFS          SET FILL FLAG
003644 006110 A 3158      ORAI         02000      SET ENCODE/DECODE BIT
003645 002000 A
003646 056154 A 3159      STA          RWFL,B      INITIALIZE READ/WRITE FLAG WORD
003647 036151 A 3160      LDX          RETURN,B     POINT X TO PARAMETER LIST
3161      MOVXAB      5,FRMT      SAVE FOR MAT STRING ADDRESS
003650 015005 A
003651 056063 A
3162      MOVXAB      6,DPBF     BUFFER ADDRESS
003652 015006 A
003653 056020 A
003654 056027 A 3163      STA          ALBF,B
003655 005311 A 3164      DAR
003656 056025 A 3165      STA          BFWPT,B
003657 015007 A 3166      LDA          7,X          CHARACTER-PROCESSED COUNT ADDRESS
003660 056152 A 3167      STA          RETURN+1,B   NO COUNT FIELD
003661 001010 A 3168      JAZ          PRD1
003662 003667 R
003663 005014 A 3169      TAX
003664 005001 A 3170      TZA
003665 055000 A 3171      STA          0,X          INITIALIZE COUNT VARIABLE
003666 036151 A 3172      LDX          RETURN,B
003667 016167 A 3173 PRD1     LDA          UNIT,B      BUFFER SIZE
003670 005111 A 3174      IAR
003671 004301 A 3175      ASRA         1          MAKE BUFFER COUNT WORDS
003672 056143 A 3176      STA          PRSZ,B
003673 056144 A 3177      STA          PRWC,B
003674 056122 A 3178      STA          LRSZ,B
003675 056123 A 3179      STA          LRWC,B
003676 005001 A 3180      TZA
003677 056167 A 3181      STA          UNIT,B      SET NO UNIT
003700 035016 A 3182      LDX          999B,X      POINT X AT V4FORTIO DATA BLOCK
003701 010435 A 3183      LDA          BS12      IDC MODE IS ASCII

```



```

003702 115104 A 3184   ORA   IDCONT,X
003703 055104 A 3185   STA   IDCONT,X
                                3186   MOVBAZ RWFL,RWFL
                                PD 07 03186
003704 016154 A
003705 055154 A
                                3187   IFF   NUC
                                3188   GOTO  NUC1
                                3189   IFT   VII
                                3190   GOTO  VII1
                                3191   TZAB  ALOC,PRD2   ALOC ENTRY FROM BACKGROUND
                                3192   LDA   APBF,X     YES
                                3193   JSR   TBK,X     TEST BUFFER START ADDRESS
                                3194   ADD   PBSZ,B
                                3195   DAR
                                3196   JSR   TBK,X     TEST BUFFER END ADDRESS
                                3197   VII1  CONT
                                3198   NUC1  CONT
                                3199   PRD2  ZAB      CLEAR BUFFER CHARACTER POINTER
                                PD 07 03199
003706 005001 A
003707 056026 A
                                3200   TRAB  RWFL,WR,PRD4  WRITE?
                                PD 07 03200
003710 016154 A
003711 006451 A
003712 003715 R
                                3201   PUSHJ CLR      YES, CLEAR BUFFER
                                PD 07 03201
003713 105025 A
003714 000116 R
003715 046172 A
003716 001000 A
003717 000377 R
                                3202   PRD4  INR   XFEL,B     ENABLE PARAMETER XFER
                                3203   JMP   FRS      TO FORMAT SCAN
                                PD 07 03202
                                PD 07 03203
                                3204   EJEC
                                07 03204
                                3205 *****
                                07 03205
                                3206 *
                                * 07 03206
                                3207 *
                                * 07 03207
                                3208 *
                                * 07 03208
                                3209 * FUNCTION: TO PROCESS A FORTRAN UNIT NUMBER U
                                * 07 03209
                                3210 *
                                * 07 03210
                                3211 * ENTRY: UNIT = FORTRAN UNIT NUMBER U
                                * 07 03211
                                3212 *
                                * 07 03212
                                3213 *
                                * 07 03213
                                3214 *
                                * 07 03214
                                3215 *
                                * 07 03215
                                3216 *
                                * 07 03216
                                3217 *
                                * 07 03217
                                3218 *
                                * 07 03218
                                3219 *
                                * 07 03219
                                3220 *
                                * 07 03220
                                3221 *
                                * 07 03221
                                3222 *
                                * 07 03222
                                3223 *
                                * 07 03223
                                3224 *
                                * 07 03224
                                3225 *
                                * 07 03225
                                3226 *
                                * 07 03226
                                3227 *
                                * 07 03227
                                3228 *
                                * 07 03228
                                3229 *
                                * 07 03229
                                3230 *
                                * 07 03230
                                3231 *
                                * 07 03231
                                3232 *
                                * 07 03232
                                3233 *
                                * 07 03233
                                3234 *
                                * 07 03234
                                3235 *
                                * 07 03235
                                3236 *
                                * 07 03236
                                3237 *
                                * 07 03237
                                3238 *
                                * 07 03238
                                3239 *
                                * 07 03239
                                3240 *
                                * 07 03240
                                3241 *
                                * 07 03241
                                3242 *
                                * 07 03242
                                3243 *
                                * 07 03243
                                3244 *
                                * 07 03244
                                3245 *
                                * 07 03245
                                3246 *
                                * 07 03246
                                3247 *
                                * 07 03247
                                3248 *
                                * 07 03248
                                3249 *
                                * 07 03249
                                3250 *
                                * 07 03250
                                3251 *
                                * 07 03251
                                3252 *****
                                07 03252
                                3253 *****
                                07 03253
                                3254 *
                                * 07 03254
                                3255 *
                                * 07 03255
                                3256 *****
                                07 03256
                                003720 016167 A
                                003721 150462 A
                                003722 001016 A
                                003723 005154 R
                                3257   PRU   LDA   UNIT,B     GET U
                                3258   ANA   LVM
                                3259   JANZ  ER4      ERROR 4/ U NOT IN (1,255)
                                07 03257
                                07 03258
                                07 03259
                                3260 *****
                                07 03260
                                3261 * SEARCH FCB CHAIN FOR U ALREADY DEFINED *
                                07 03261
                                3262 *****
                                07 03262
                                3263   TRAB  RWFL,DA,PRU0
                                07 03263
003724 016154 A
003725 006453 A
003726 003733 R

```



Address	Label	Op	Op2	Op3	Description	Flags	Page	
003727	036151	A	3264	LDX	RETURN,B	DIRECT ACCESS	07 03264	
003730	015011	A	3265	LDA	3,X	FCB ADDRESS	07 03265	
003731	001000	A	3266	JMP	PRU05		07 03266	
003732	003737	R						
			3267	PRU0	PUSHJ	SCH	SEARCH FCB CHAIN	07 03267
003733	105025	A						
003734	005415	R						
003735	001010	A	3268	JAZ	PRU5		07 03268	
003736	004043	R						
			3269		*****		07 03269	
			3270		* U IS ON FCB CHAIN *		07 03270	
			3271		*****		07 03271	
003737	056010	A	3272	PRU05	STA	ADFCB,B	STORE FCB ADDRESS	07 03272
003740	036016	A	3273	LDX	ANRB,B		E 07 03273	
003741	055010	A	3274	STA	ADFCB,X	ALSO IN V\$FORTID	E 07 03274	
003742	005014	A	3275	TAX		POINT X AT FCB	07 03275	
			3276	TSAB	RWFL,IN,ER4	ERROR 4/ OPEN CALL FINDS U ON CHAIN /	V2 07 03276	
003743	016154	A						
003744	006406	A						
003745	005154	R						
			3277		MOVXAB	3,SVRECN	SAVE RECORD NO	07 03277
003746	015003	A						
003747	056160	A						
			3278		MOVXAB	0,LRSZ	SET LOGICAL RECORD SIZE = FCB(0)	07 03278
003750	015000	A						
003751	056122	A						
003752	056143	A	3279	STA	PBSZ,B	ALSO PHYSICAL RECORD SIZE	07 03279	
			3280	MOVXAB	1,APBF	SET PHYSICAL BUFFER ADDRESS = FCB(1)	07 03280	
003753	015001	A						
003754	056020	A						
003755	056027	A	3281	STA	ALBF,B	ALSO LOGICAL BUFFER ADDRESS	07 03281	
003756	015014	A	3282	LDA	12,X	GET L	07 03282	
003757	150463	A	3283	ANA	RHW		07 03283	
003760	056167	A	3284	STA	UNIT,B	STORE LOGICAL UNIT NUMBER L IN UNIT	07 03284	
003761	015014	A	3285	LDA	12,X	GET FLAGS FROM FCB	07 03285	
003762	004354	A	3286	LSRA	SH	POSITION	V2 07 03286	
003763	116154	A	3287	ORA	RWFL,B	MERGE INTO READ/WRITE FLAG	07 03287	
003764	056154	A	3288	STA	RWFL,B		07 03288	
003765	006441	A	3289	BY	ARST+LF,PRU50	EXIT ON NON-LOGICAL FILE	FG 07 03289	
003766	004312	R						
003767	006400	A	3290	BT	ASET+RM,PRU1	RMD ?	V2 07 03290	
003770	003774	R						
003771	150451	A	3291	ANA	BFR	NO. CLEAR FILL FLAG	V2 07 03291	
003772	056154	A	3292	STA	RWFL,B		V2 07 03292	
			3293	POPJ		EXIT	FG 07 03293	
003773	105065	A						
			3294		*****		V2 07 03294	
			3295		* U IS AN RMD LOGICAL FILE *		V2 07 03295	
			3296		*****		V2 07 03296	
			3297	PRU1	EDU	*	V2 07 03297	
			3298		MOVXAB	3,LRECNO	LOAD LOGICAL RECORD NUMBER	07 03298
003774	015003	A						
003775	056121	A						
003776	016122	A	3299	LDA	LRSZ,B	GET LOGICAL RECORD SIZE	07 03299	
003777	005024	A	3300	TBX		SAVE BASE POINTER IN X	07 03300	
004000	145201	A	3301	SUB	BD120,X		V2 07 03301	
004001	001002	A	3302	JAP	PRU2	IS LOGICAL RECORD SIZE .LT. 120 WORDS ?	07 03302	
004002	004011	R						
004003	015201	A	3303	LDA	BD120,X	YES	V2 07 03303	
004004	004560	A	3304	LLSR	16		07 03304	
004005	175122	A	3305	DIV	LRSZ,X		07 03305	
004006	005102	A	3306	INCR	B	SET BUFFER SIZE TO 1 RECORD	07 03306	
004007	001000	A	3307	JMP	PRU3		07 03307	
004010	004020	R						
004011	015122	A	3308	PRU2	LDA	LRSZ,X	07 03308	
004012	004560	A	3309	LLSR	16		07 03309	
004013	175201	A	3310	DIV	BD120,X	GET COUNT OF PHYSICAL RECS IN LOG REC	V2 07 03310	
004014	001010	A	3311	JAZ	PRU4	ANY REMAINDER ?	07 03311	
004015	004023	R						
004016	005122	A	3312	IBR		YES. BUMP ALLOCATION	07 03312	
004017	005311	A	3313	DAR			07 03313	
004020	001010	A	3314	PRU3	JAZ	*+3	07 03314	
004021	004023	R						
004022	005122	A	3315	IBR		BUMP COUNT IF NOT FACTOR OR MULTIPLE	07 03315	
004023	065142	A	3316	PRU4	STB	PBRC,X	STORE PHYSICAL RECORD COUNT	07 03316
004024	005001	A	3317	TEA			07 03317	
004025	165201	A	3318	MUL	BD120,X	GET PHYSICAL BUFFER SIZE	V2 07 03318	
004026	065143	A	3319	STB	PBSZ,X	STORE	07 03319	
004027	015121	A	3320	LDA	LRECNO,X	GET LOGICAL RECORD NUMBER	07 03320	
004030	005311	A	3321	DAR		CONVERT FROM BASE 1 TO BASE 0	07 03321	
004031	004560	A	3322	LLSR	16		07 03322	
004032	165122	A	3323	MUL	LRSZ,X	GET WORD COUNT TO START OF LRECNO	07 03323	
004033	175201	A	3324	DIV	BD120,X	GET PHYSICAL RECORD COUNT TO LRECNO	V2 07 03324	
004034	005122	A	3325	IBR		CONVERT FROM BASE 0 TO BASE 1	07 03325	
004035	065145	A	3326	STB	PRECNO,X	SAVE PHYSICAL RECORD NUMBER	07 03326	
004036	055123	A	3327	STB	LEOV,X	STORE OVERFLOW	07 03327	
004037	125020	A	3328	ADD	APBF,X		07 03328	
004040	055027	A	3329	STB	ALBF,X	STORE ADDRESS OF LOGICAL BUFFER	07 03329	
004041	005042	A	3330	TXB		RESTORE BASE REGISTER B	07 03330	
			3331	POPJ		EXIT	FG 07 03331	
004042	105065	A						
			3332		*****		07 03332	
			3333		* U NOT ON FCB CHAIN - SET L=U *		07 03333	



```

3334 *****
004043 036016 A 3335 PRU5 LDX ANRB,B POINT X AT VSFORTID DATA BLOCK 07 03334
3336 MOVXAB ASYSDC,ADFCB USE VSFORTID SYSTEM DCB 07 03335
004044 015023 A
004045 056010 A
004046 055010 A 3337 STA ANFCB,X 07 03337
004047 005014 A 3338 TAX 07 03338
3339 MOVXAB 1,APBF USE VSFORTID SYSTEM BUFFER $BUF 07 03339
004050 015001 A
004051 056020 A
004052 056027 A 3340 STA ALBF,B 07 03340
3341 MOVXAB 5D120,0 SET RECORD SIZE TO 120 WORDS V2 07 03341
004053 016201 A
004054 055000 A
004055 056143 A 3342 STA PBSZ,B 07 03342
3343 STA LRSZ,B 07 03343
3344 ***** 07 03344
3345 * TEST VALIDITY OF L * 07 03345
3346 ***** 07 03346
004057 036032 A 3347 LDX SAVE,B L = SAVE ON OPEN CALL V2 07 03347
3348 TSAB RWFL,IN,PRU6 OPEN CALL ? V2 07 03348
004060 016154 A
004061 006406 A
004062 004064 R
004063 036167 A 3349 LDX UNIT,B NO. L=UNIT V2 07 03349
004064 005041 A 3350 PRU6 TXA GET L IN A V2 07 03350
004065 001010 A 3351 JAZ PRU50 EXIT IF L=0 FG 07 03351
004066 004312 R
004067 006030 A 3352 LDNI V$LUT1 POINT X AT LUN POINTER TABLE V2 07 03352
004070 000400 A
004071 005311 A 3353 DAR 1ST BLOCK BIASED BASE 1 07 03353
004072 056164 A 3354 SYA TEMP,B SAVE 07 03354
004073 005111 A 3355 IAK RESTORE L IN A V2 07 03355
004074 006140 A 3356 SUBI 101 V2 07 03356
004075 000145 A
004076 001004 A 3357 JAN PRU10 IS L IN BLOCK 1(1-100) ? 07 03357
004077 004110 R
004100 005144 A 3358 IXR NO. BUMP BLOCK POINTER 07 03358
004101 056164 A 3359 STA TEMP,B SAVE BIASED LUN 07 03359
004102 006140 A 3360 SUBI 79 V2 07 03360
004103 000117 A
004104 001004 A 3361 JAN PRU10 IS L IN BLOCK 2(101-180) ? 07 03361
004105 004110 R
004106 005144 A 3362 IXR NO. BUMP BLOCK POINTER 07 03362
004107 056164 A 3363 STA TEMP,B SAVE BIASED L 07 03363
004110 016164 A 3364 PRU10 LDA TEMP,B GET BIASED L 07 03364
004111 035000 A 3365 LDX 0,X POINT X AT BLOCK POINTER 07 03365
004112 143000 A 3366 SUB 0,X COMPUTE BIASED L WITH BLOCK SIZE 07 03366
004113 001002 R 3367 JAF 0RA ERROR 4/ INVALID LUN / 07 03367
004114 005154 R
3368 ***** 07 03368
3369 * GET DST INFO * 07 03369
3370 ***** 07 03370
004115 005141 A 3371 INCR 041 07 03371
004116 126164 A 3372 ADD TEMP,B 07 03372
004117 005014 A 3373 TAX POINT X AT LOGICAL UNIT TABLE ENTRY 07 03373
004120 015000 A 3374 LDR 0,X 07 03374
004121 150463 A 3375 AND RAR GET DST INCREMENT FROM LUT 07 03375
004122 056037 A 3376 STA SAVE+5,B SAVE V2 07 03376
004123 001010 A 3377 JAZ PRU50 EXIT IF L=DUMMY FG 07 03377
004124 004312 R
004125 005024 A 3378 TEX SAVE BASE POINTER IN X 07 03378
004126 005312 A 3379 DECR 012 BIASED DST COUNT TO B 07 03379
004127 010355 A 3380 LDA V$DSTB A = BASE OF DST TABLES 07 03380
004130 160464 A 3381 MUL THREE B = DST ADDRESS 07 03381
004131 005041 A 3382 TXA A = BASE REGISTER 07 03382
004132 005024 A 3383 TEX POINT X AT DST 07 03383
004133 005012 A 3384 TAX RESTORE BASE REGISTER B 07 03384
3385 ***** 07 03385
3386 * TEST IF L ASSIGNED TO RMD * 07 03386
3387 ***** 07 03387
004134 015002 A 3388 LDA 0,X 07 03388
004135 004345 A 3389 LSRA 6 07 03389
004136 150473 A 3390 AND RM32 07 03390
004137 001010 A 3391 JAZ RM2 V2 07 03391
004140 004142 R
004141 010421 A 3392 LDA RMS SET RMD FLAG V2 07 03392
004142 116154 A 3393 DRB RWFL,B V2 07 03393
004143 056154 A 3394 STA RWFL,B V2 07 03394
004144 006406 A 3395 AT ACET+IN,PRU50 EXIT ON OPEN CALL FG 07 03395
004145 004312 R
004146 006409 A 3396 PT ACST+RM,PRU30 V2 07 03396
004147 004222 R
3397 ***** 07 03397
3398 * L NOT RMD * 07 03398
3399 ***** 07 03399
3400 LDRS PRU15 FORMATTED I/O ? V2 07 03400
004150 016063 A
004151 001010 A
004152 004154 R
004153 015001 A 3401 LDA 1,X YES. GET 1ST TWO CHARS OF NAME V2 07 03401
004154 004154 R 3402 PRU15 EQU * V2 07 03402
004154 076032 A 3403 STX SAVE,B SAVE DST ADDR E.1 07 03403

```



```

3404      IFF      NUC
3405      GOTO     NV2NUC
3406      IFT      VII
3407      DME      MAP,V$STO      SET EXEC STATE TO 00
3408 NV2NUC  CONT
3409      LDX      PRUDTB      POINT X AT DEVICE TABLE
004155 034147 A 3410 *****
3411 * LOOP TO IDENTIFY DEVICE *
3412 *****
004156 005144 A 3413 PRUL1  IXR      BUMP TABLE POINTER
004157 145000 A 3414      SUB      0,X
004160 001010 A 3415      JAZ      PRU20      EXIT ON MATCH
004161 004166 R 3416      JAP      PRUL1      LOOP TILL DONE
004162 001002 A 3417      LDXI     PRUDTE     POINT X AT END IF NO FIND
004163 004156 R
004164 006030 A 3418 PRU20  LDA      PRUDTE-PRUDTB,X  GET DEVICE PARAMS FROM TABLE
004165 004334 R 3419      JAN      PRU25      IF SPOOL UNIT
004166 015007 A
004167 001004 A 3420      TAX
004170 004211 R 3421      JAN      PRU25      SAVE
004171 005014 A
004172 001004 A 3422      IFF      NUC
004173 004211 R 3423      GOTO     NV2NUC
3424      IFT      VII
3425      DME      MAP,V$ST3     SET EXEC STATE TO NN
3426 NV2NUC  CONT
3427      ANA      BFC
004174 150431 A 3428      STA      TEMP,B      SAVE
004175 056164 A 3429      TXA      RESTORE A
004176 005041 A 3430      LDX      ADFCB,B      POINT X AT DCB
004177 036010 A 3431      ANA      RHW      GET RECORD SIZE
004200 150463 A 3432      STA      0,X      STORE IN DCB
004201 055000 A 3433      STA      PBSZ,B      ALSO AS PHYSICAL BUFFER SIZE
004202 056143 A 3434      STA      LRSZ,B      ALSO LOGICAL BUFFER SIZE
004203 056122 A 3435      LDA      RWFL,B
004204 016154 A 3436      ANA      BFR
004205 150451 A 3437      DRA      TEMP,B      MERGE FILL FLAG
004206 116164 A 3438      STA      RWFL,B      INTO READ/WRITE FLAGS
004207 056154 A 3439      POPJ
3440 PRU25  EQU      *
3441      IFF      NUC
3442      GOTO     NV2NUC
3443      IFT      VII
3444      DME      MAP,V$ST3     SET EXEC STATE TO NN
3445 NV2NUC  CONT
004211 036032 A 3446      LDX      SAVE,B      DST ADDR
004212 015000 A 3447      LDA      0,X      DSUNAM (BITS 12-4)
004213 004352 A 3448      LSRA      10      POSITION MSR
004214 150467 A 3449      ANA      SEVEN
004215 006120 A 3450      ADDI     180      SET TO LUN 18N
004216 000264 A
004217 005014 A 3451      TAX
004220 001000 A 3452      JMP      PRU6
004221 004064 R
3453 *****
3454 * RMD FILE *
3455 *****
004222 010301 A 3456 PRU30  LDA      V$CPL      GET PRIORITY LEVEL
004223 140422 A 3457      SUB      TWO
004224 001002 A 3458      JAP      ER4      ERROR 4/ FOREGROUND RMD FILE NOT OPEN /
004225 005154 R
3459 *****
3460 * BACKGROUND PROGRAM - CHECK GLOBAL FCB'S *
3461 *****
004226 016167 A 3462      LDA      UNIT,B      GET L
004227 006110 A 3463      DRAI     01400      MERGE IOLINK SKELETON CONTROL WORD
004230 001400 A
004231 056105 A 3464      STA      IOLNK,B      IOLINK CONTROL WORD FOR L GLOBAL FCB
004232 016167 A 3465      LDA      UNIT,B      GET L
004233 140422 A 3466      SUB      TWO
004234 001004 A 3467      JAN      PRU35      IGNORE L=1
004235 004251 R
004236 140470 A 3468      SUB      NINE
004237 001002 A 3469      JAP      PRU35      NO GLOBAL FCB.GT.10
004240 004251 R
3470      IFF      NUC
3471      GOTO     NV2NUC
3472      IFT      VII
3473      DME      MAP,V$STO     SET EXEC STATE TO 00
3474 NV2NUC  CONT
004241 124062 A 3475      ADD      PRUST      ADD TABLE ADDRESS
004242 005014 A 3476      TAX      POINT X AT GLOBAL FCB TABLE
004243 035000 A 3477      LDX      0,X      POINT X AT GLOBAL FCB
3478      IFF      NUC
3479      GOTO     NV2NUC
3480      IFT      VII
3481      DME      MAP,V$ST3     SET EXEC STATE TO NN
3482 NV2NUC  CONT
004244 001042 A 3483      JXZ      PRU35      *SD* HAS NO GLOBAL FCB
004245 004251 R

```



```

004246 013005 A 3484 LDA 5,X TEST GLOBAL FCB ENABLED 07 03484
004247 001016 A 3485 JANZ PRU40 07 03485
004250 004276 R 3486 *****
3487 * NO GLOBAL FCB - TEST U=SI * 07 03486
3488 ***** 07 03487
004251 030400 A 3489 PRU35 LDX V$LUT1 07 03488
004252 015002 A 3490 LDA 2,X GET SI ASSIGNMENT 07 03489
004253 146037 A 3491 SUB SAVE+5,B COMPARE WITH L ASSIGNMENT V2 07 03490
004254 150463 A 3492 ANA RHW 07 03491
004255 001016 A 3493 JANZ ER4 ERROR 4/ RND FILE NOT OPEN / 07 03492
004256 005154 R 3494 LDA TPG L = SI 07 03494
004260 006110 A 3495 DRAI 01400 MERGE IOLINK SKELETON CONTROL WORD V2 07 03495
004261 001400 A 3496 STA IOLNK,B IOLINK CONTROL WORD FOR SIFCB 07 03496
004262 056105 A 3497 LDAI 40 V2 07 03497
004264 000050 A 3498 STA WBSZ,B ALSO PHYSICAL BUFFER SIZE 07 03498
004266 056122 A 3499 STA LRSZ,B ALSO LOGICAL BUFFER SIZE 07 03499
004267 036010 A 3500 LDX *OFQB,B POINT X AT V$FORTIO DATA BLOCK 07 03500
004270 055000 A 3501 STA 0,X SET RECORD SIZE DCB(0) = 40 WORDS 07 03501
004271 006030 A 3502 LDXI SIFCB POINT X AS SI GLOBAL FCB V2 07 03502
004272 000000 E 3503 LDA 5,X 07 03503
004273 015005 A 3504 JAZ ER4 ERROR 4/ RND NOT OPEN / 07 03504
004275 005154 R 3505 PRU40 TXA GET FCB ADDRESS IN A 07 03505
004277 056010 A 3506 STA ADFCB,B STORE 07 03506
004300 036016 A 3507 LDX ANRB,B POINT X AT V$FORTIO 07 03507
004301 055010 A 3508 STA ADFCB,X STORE IN V$FORTIO 07 03508
3509 MOVBA IOLNK,IOLNK MOVE IOLINK CONTROL WORD TO V$FORTIO 07 03509

004302 016105 A 3510 LDA RWFL,B V2 07 03510
004303 055105 A 3511 DRA GFS SET GLOBAL FCB FLAG V2 07 03511
004305 110430 A 3512 STA RWFL,B V2 07 03512
004306 056154 A 3513 LDA CX0 V2 07 03513
004307 010420 A 3514 JSR PCJ,X PUSH IOLINK DP V2 07 03514
004311 004515 R 3515 PRU50 POPJ EXIT FG 07 03515
004312 105065 A 3516 ***** 07 03516
3517 * GLOBAL FCB POINTERS * 07 03517
3518 ***** 07 03518
004313 004272 E 3519 PRUASI PZE SIFCB SIC(2) GLOBAL FCB 07 03519
004314 000000 A 3520 DATA 0 SOC(3) NO GLOBAL FCB 07 03520
004315 000000 E 3521 PZE RIFCB PIC(4) GLOBAL FCB 07 03521
004316 000000 E 3522 PZE LOFCB LOC(5) GLOBAL FCB 07 03522
004317 000000 E 3523 PZE RIFCB BIC(6) GLOBAL FCB 07 03523
004320 000000 E 3524 PZE SDFCB SOC(7) GLOBAL FCB 07 03524
004321 000000 E 3525 PZE SSFCB SSC(8) GLOBAL FCB 07 03525
004322 000000 E 3526 PZE GDFCB GOC(9) GLOBAL FCB 07 03526
004323 000000 E 3527 PZE RDFCB POC(10) GLOBAL FCB 07 03527
004324 004324 R 3528 PRUGT PZE * 07 03528
3529 ***** 07 03529
3530 * DEVICE TABLE * 07 03530
3531 ***** 07 03531
004325 004325 R 3532 PRUDTB PZE * 07 03532
004326 141720 A 3533 DATA *CP* 1ST 2 CHARS OF DEVICE NAME 07 03533
004327 000002 A 3534 DATA 2 *CR* V2 07 03534
004330 000002 A 3535 DATA 2 *CT* V2 07 03535
004331 004374 A 3536 DATA 04374 *LP* V2 07 03536
004332 003400 A 3537 DATA 03400 :SP: E.1 07 03537
004333 000411 A 3538 DATA 0411 :TY: E.1 07 03538
004334 077777 A 3539 DATA 077777 TABLE END MARKER V2 07 03539
004335 004334 R 3540 PRUDE EQU *-1 07 03540
004336 000050 A 3541 DATA 40 CONSOLE FLAG/BUFFER SIZE 07 03541
004337 000050 A 3542 DATA 40 V2 07 03542
004338 000450 A 3543 DATA 403FA V2 07 03543
004340 000102 A 3544 DATA 66 07 03544
004341 177777 A 3545 DATA -1 SPOOL UNIT INDICATOR E.1 07 03545
004342 000450 A 3546 DATA 403FA V2 07 03546
004343 000074 A 3547 DATA 60 07 03547
3548 EQUED 07 03548
3549 ***** 07 03549
3550 * 07 03550
3551 * PROCESS READ/WRITE (PRU) * 07 03551
3552 * 07 03552
3553 * FUNCTION: TO PROCESS THE FORTRAN STATEMENTS: * 07 03553
3554 * 07 03554
3555 * READ(U) * 07 03555
3556 * READ(U,F) * 07 03556
3557 * WRITE(U) * 07 03557
3558 * WRITE(U,F) * 07 03558
3559 * 07 03559
3560 * 07 03560
3561 * ENTRY: DIRECT FROM RBE * 07 03561
3562 * RETURN - ADDRESS OF PARAMETER LIST * 07 03562
3563 * RETURN(5) = 0 IF UNFORMATTED * 07 03563
3564 * UNIT = FORTRAN UNIT NUMBER U * 07 03564
3565 * TEMP = CP = CRD READ V2* 07 03565
3566 * ORR WRITE V2* 07 03566

```



```

3567 * * 07 03567
3568 * EXIT : READ : 1ST RECORD READ * 07 03568
3569 * WRITE: BUFFER CLEARED * 07 03569
3570 * FRMT = ADDRESS OF FORMAT STRING * 07 03570
3571 * 0 IF UNFORMATTED * 07 03571
3572 * XFFL = 1 PARAMETER XFER ENABLED * 07 03572
3573 * ITEMWC = 0 = COUNT OF WORDS REMAINING IN LIST ITEM * 07 03573
3574 * UNFORMATTED: DIRECT TO J10 * 07 03574
3575 * FORMATTED : DIRECT TO FRS TO START FORMAT SCAN * 07 03575
3576 * IDCONT = IOC CONTROL WORD * 07 03576
3577 * * 07 03577
3578 ***** * 07 03578
004344 016164 A 3580 PRW LDA TEMP,B GET UP * 07 03580
004345 140471 A 3581 SUB CRD V2 07 03581
004346 004250 A 3582 LRLA 8 POSITION READ/WRITE FLAG * 07 03582
004347 056104 A 3583 STA IDCONT,B FOR IOC CALL CONTROL WORD * 07 03583
004350 001010 A 3584 JAZ *+3 V2 07 03584
004351 004353 R
004352 010432 A 3585 LDA WRS SET WRITE BIT V2 07 03585
004353 110431 A 3586 ORA BFS SET FILL FLAG V2 07 03586
004354 056154 A 3587 STA RWFL,B INITIALIZE READ/WRITE FLAG WORD * 07 03587
004355 036151 A 3588 PRW05 LDX RETURN,B * 07 03588
004356 015003 A 3589 LDA 3,X GET READ/WRITE PARAMETER COUNT * 07 03589
004357 140422 A 3590 SUB TWO * 07 03590
004360 001016 A 3591 JANZ PRW0 WAS PROGRAM COMPILED WITH 'G' COMPILER ? * 07 03591
004361 004366 R
004362 056152 A 3592 STA RETURN+1,B NO. CLEAR 'END' EXIT ADDRESS * 07 03592
004363 056153 A 3593 STA RETURN+2,B CLEAR 'ERR' EXIT ADDRESS * 07 03593
004364 001000 A 3594 JMP PRW1 * 07 03594
004365 004372 R
004366 015007 A 3595 PRW0 LDA 7,X PROGRAM WAS COMPILED BY 'G' COMPILER * 07 03595
004367 056152 A 3596 STA RETURN+1,B SAVE 'END' EXIT ADDRESS * 07 03596
004370 015010 A 3597 LDA 8,X GET 'ERR' EXIT ADDRESS * 07 03597
004371 056153 A 3598 STA RETURN+2,B SAVE * 07 03598
004372 004372 R 3599 PRW1 EQU * * 07 03599
004373 056063 A 3600 MOVXAB 5,FRMT SAVE FORMAT STRING ADDRESS(0 IF NONE) * 07 03600
004374 105025 A 3601 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER V2 07 03601
004375 003720 R
004376 016063 A 3602 TZAB FRMT,PRW2 IOC MODE IS SYS BINARY FOR UNFORMATTED V2 07 03602
004377 001010 A
004400 004402 R
004401 010435 A 3603 LDA BS12 IOC MODE IS ASCII FOR FORMATTED * 07 03603
004402 036016 A 3604 PRW2 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK V2 07 03604
004403 116167 A 3605 ORA UNIT,B MERGE IN LOGICAL UNIT NUMBER L * 07 03605
004404 116104 A 3606 ORA IDCONT,B MERGE IN READ/WRITE BIT * 07 03606
004405 055104 A 3607 STA IDCONT,X STORE IN V$FORTIO * 07 03607
004406 016154 A 3608 MOVXAB RWFL,RWFL MOVE FLAG WORD TO V$FORTIO * 07 03608
004407 055154 A
004410 016152 A 3609 LDA RETURN+1,B MOVE RETURN ADDRESSES TO V$FORTIO PD 07 03609
004411 055152 A 3610 STA RETURN+1,X PD 07 03610
004412 016153 A 3611 LDA RETURN+2,B PD 07 03611
004413 055153 A 3612 STA RETURN+2,X PD 07 03612
3613 IFF TWO FG 07 03613
3614 GOTO NUC1 FG 07 03614
3615 IFT VII FG 07 03615
3616 GOTO VII1 FG 07 03616
3617 TZAB QIDC,PRW4 ALLOC ENTRY FROM BACKGROUND ? V2 07 03617
3618 LDA APBF,B YES * 07 03618
3619 JSR TBK,X TEST BUFFER START ADDRESS * 07 03619
3620 ADD PBSZ,B * 07 03620
3621 IAR * 07 03621
3622 JSR TBK,X TEST BUFFER END ADDRESS * 07 03622
3623 VII1 CNT FG 07 03623
3624 NUC1 CNT FG 07 03624
3625 PRW4 ZAB BFPT CLEAR BUFFER CHARACTER POINTER * 07 03625
004414 005001 A
004415 056026 A 3626 TRAB RWFL,LF,PRW6 LOGICAL FILE ? * 07 03626
004416 016154 A
004417 006441 A
004420 004424 R
004421 036010 A 3627 LDX ADFCB,B YES * 07 03627
004422 016143 A 3628 MOVXAB PBSZ,0 SET FCB(0) = PHYSICAL BUFFER SIZE * 07 03628
004423 055000 A
004424 105025 A 3629 PRW6 PUSHJ RFL REPOSITION FILE V2 07 03629
004425 005174 R
004426 016154 A 3630 TRAB RWFL,WR,PRW10 WRITE ? V2 07 03630
004427 006451 A
004430 004434 R 3631 PUSHJ CLR YES. CLEAR BUFFER V2 07 03631
004431 105025 A
004432 000110 R
004433 001006 A 3632 DATA 01006 SKIP * 07 03632
004434 046121 A 3633 PRW10 INR LRECND,B BUMP LOGICAL RECORD NUMBER ON READ * 07 03633
004434 046121 A 3634 MOVXAB LRS2,LRWC UPDATE LRWC FOR SHORT RECORD V2 07 03634

```



```

004435 016122 A
004436 056123 A
004437 046172 A 3635      INR      XFFL,B      ENABLE PARAMETER XFER      07 03635
                                3636      TZAB      FRMT,UIO    PROCESS UNFORMATTED I/O IF FRMT=0 07 03636

004440 016063 A
004441 001010 A
004442 005701 R
004443 001000 A 3637      JMP      FRS      EXIT TO FORMAT SCAN IF FORMATTED      07 03637
004444 000377 R
                                3638      EJEC
                                3639 *****
                                3640 *
                                3641 *      P R O C E S S   D I R E C T   A C C E S S   ( P R X )
                                3642 *
                                3643 *****
004445 016164 A 3645      PRX      LDA      TEMP,B
004446 006140 A 3646      SUBI     CRA
                                3647      LRLA     S      POSITION READ/WRITE FLAG      07 03647
004451 056104 A 3648      STA      IDCONT,B
004452 001010 A 3649      JAZ      *43
                                3650      LDA      HRS
                                3651      ORA      BFS
                                3652      ORA      SS11    SET DIRECT ACCESS FLAG      07 03652
004457 056154 A 3653      STA      RWFL,B
004460 016164 A 3654      LDA      TEMP,B
004461 140424 A 3655      SUB     EIGHT
004462 056164 A 3656      STA      TEMP,B    SET TO READ/WRITE      07 03656
004463 001000 A 3657      JMP     PRH05
004464 004355 R
                                3658      EJEC
                                3659 *****
                                3660 *
                                3661 *      P O S T   B U F F E R   ( P S B )
                                3662 *
                                3663 *      FUNCTION: TO WRITE OUT BUFFER TO RMD
                                3664 *
                                3665 *      ENTRY: ADFCB = FCB ADDRESS
                                3666 *             FCB(13) = PHYSICAL RECORD NUMBER CORRESPONDING TO BUFFER
                                3667 *
                                3668 *      EXIT : BUFFER WRITTEN OUT TO RMD
                                3669 *             RWFL(BIT 1) = FCB(12)(BIT 14) = 0 = POST BITS
                                3670 *
                                3671 *****
004465 016154 A 3673      PSB     LDA      RWFL,B
004466 150443 A 3674      ANA     PSB      CLEAR POST BIT IN FLAG WORD      V2 07 03674
004467 056154 A 3675      STA     RWFL,B
004470 036010 A 3676      LDX     ADFCB,B
004471 015014 A 3677      LDA     12,X
004472 150457 A 3678      ANA     PSB      CLEAR POST BIT IN FCB(12)      V2 07 03678
004473 055014 A 3679      STA     12,X
                                3680      MOVXAX 13,B    LOAD PHYSICAL RECORD NUMBER INTO FCB(3) 07 03680

004474 015015 A
004475 055003 A
004476 036016 A 3681      LDX     ANRB,B    POINT X AT VSFORTID DATA BLOCK      07 03681
004477 015104 A 3682      LDA     IDCONT,X
004500 110431 A 3683      ORA     BSS      SET WRITE BIT IN VSI00 CONTROL WORD 07 03683
004501 055104 A 3684      STA     IDCONT,X
004502 010464 A 3685      LDA     CID      PUSH I/O DP      V2 07 03685
004503 006505 A 3686      JSR     PSJ,X    WRITE OUT BUFFER      V2 07 03686
004504 004515 R
                                3687      TSAB     RWFL,WR,PSBX  EXIT ON WRITE      FG 07 03687

004505 016154 A
004506 006411 A
004507 004514 R
004510 036016 A 3688      LDX     ANRB,B    POINT X AT VSFORTID DATA BLOCK      07 03688
004511 015104 A 3689      LDA     IDCONT,X
004512 150451 A 3690      ANA     PRB      CLEAR WRITE BIT IN VSI00 CONTROL WORD 07 03690
004513 055104 A 3691      STA     IDCONT,X
004514 105065 A 3692      PSBX   POPJ      EXIT      FG 07 03692

                                3693      EJEC
                                3694 *****
                                3695 *
                                3696 *      P U S H / J U M P   ( P S J )
                                3697 *
                                3698 *      FUNCTION: TO STACK RETURN ADDRESSES AND OPS, AND EXIT TO CALLED
                                3699 *      ROUTINE
                                3700 *
                                3701 *      ENTRY: X = RETURN ADDRESS
                                3702 *             A = CALL ADDRESS OR DP
                                3703 *
                                3704 *             .GE. 0100 ADDRESS(WITHIN REENTRANT RUN-TIME)
                                3705 *             .LT. 0100 DP
                                3706 *
                                3707 *      EXIT : RETURN STACKED
                                3708 *             A = ADDRESS: DIRECT JUMP TO (A)
                                3709 *             A = DP: STACK CRB DP, THEN CALLED DP, THEN EXIT TO VSFORTID
                                3710 *
                                3711 *****
004515 056164 A 3713      PSJ     STA     TEMP,B    SAVE EXIT      07 03713
004516 005041 A 3714      TXA

```



Address	Mode	Instruction	Comment	Flags	Target
004517	A	LDX UPSTKP,B	POINT X AT STACK		07 03715
004520	A	DXR	DROP STACK POINTER	FG	07 03716
004521	A	STX DPSTKP,B		FG	07 03717
004522	A	STA 0,X	PUSH RETURN		07 03718
004523	A	LDA TEMP,B	RESTORE A		07 03719
004524	A	TAX			07 03720
004525	A	LSRA 8			07 03721
004526	A	JAZ *14	EXTERNAL REQUEST ?		07 03722
004527	R				
004530	A	IJMP 0,X	NO. JUMP DIRECTLY TO INTERNAL SUBROUTINE		07 03723
004531	A				
004532	A	LDA CRB			07 03724
		PUSHF	PUSH RETURN TO V\$RERR		07 03725
004533	A				
004534	A				
004535	A				
004536	A				
004537	A				
004540	A				
004541	A				
004542	A	LDA TEMP,B	RESTORE CALLED DP		07 03726
		PUSHF	PUSH V\$FORTID DP		07 03727
004543	A				
004544	A				
004545	A				
004546	A				
004547	A				
004550	A				
004551	A				
004552	A	JMP CAN	EXIT TO V\$FORTID		07 03728
004553	R				
3729		EJEC			07 03729
3730		*****			07 03730
3731		*			07 03731
3732		PARAMETER TRANSFER ( P X F )			07 03732
3733		*			07 03733
3734		FUNCTION: TO PROCESS ENTRIES TO XFER DATA TO/FROM AN I/O LIST			07 03734
3735		*			07 03735
3736		ENTRY: ITMODE = 0 1-WORD INTEGER/LOGICAL			07 03736
3737		= 1 2-WORD INTEGER/LOGICAL			07 03737
3738		= 2 REAL			07 03738
3739		= 3 DOUBLE PRECISION			07 03739
3740		= 4 COMPLEX			07 03740
3741		= 5 DOUBLE PRECISION INTEGER			07 03741
3742		*			07 03742
3743		EXIT : IIWSZ = INDIVIDUAL ITEM WORD SIZE			07 03743
3744		= 1 FOR 1-WORD INTEGER/LOGICALS			07 03744
3745		= 2 FOR 2-WORD INTEGER/LOGICALS			07 03745
3746		= 2 FOR REALS			07 03746
3747		= 4 FOR DOUBLE PRECISIONS			07 03747
3748		= 2 FOR COMPLEXES			07 03748
3749		= 2 FOR DOUBLE PRECISION INTEGER			07 03749
3751		IIBSZ = 2*IIWSZ = INDIVIDUAL ITEM BYTE SIZE			07 03751
3752		ITMINC = INDIVIDUAL ITEM ALLOCATION IN WORDS			07 03752
3753		= IIWSZ FOR ALL ITEMS EXCEPT 2-WORD INTEGER/LOGICALS			07 03753
3754		= 2 FOR 2-WORD INTEGER/LOGICALS			07 03754
3755		ITEMAD = ADDRESS OF LIST ITEM			07 03755
3756		ITEMWC = TOTAL WORD COUNT ALLOCATED TO LIST ITEM			07 03756
3757		*			07 03757
3758		ERRORS: ER2 IF ILLEGAL CALL TO \$I1,\$I2,...		V2*	07 03758
3759		*			07 03759
3760		*****			07 03760
004554	A	PXF LDA XFFL,B			07 03762
004555	A	JAZ LR2	ERROR 2/ ILLEGAL CALL TO \$IX /		07 03763
004556	R				
004557	A	LDX ANRB,B	POINT X AT V\$FORTID		07 03764
004560	A	LDA ITMODE,X			07 03765
004561	A	STA ITMODE,B	MOVE MODE FROM V\$FORTID TO V\$RERR		07 03766
004562	A	LDA FRMT,B			07 03767
004563	A	TZX	SET ITEM WORD SIZE TO 1		07 03768
004564	A	JAZ PXFS	ITEM WORD SIZE = 1 FOR UNFORMATTED		07 03769
004565	R				
004566	A	LDX ITMODE,B			07 03770
	R	PXFS EQU *		V2	07 03771
		IFF NUC		FG	07 03772
		GOVD NV2NUC		FG	07 03773
		IFT VII		FG	07 03774
		OME MAP,V\$ST0	SET EXEC STATE TO 00	V2	07 03775
		NV2NUC CONT		FG	07 03776
004567	A	LDAE PXFSZT,X	GET ITEM WORD SIZE FROM TABLE	V2	07 03777
004570	R				
		IFF NUC		FG	07 03778
		GOVD NV2NUC		FG	07 03779
		IFT VII		FG	07 03780
		OME MAP,V\$ST3	SET EXEC STATE TO NN	V2	07 03781
		NV2NUC CONT		FG	07 03782
004571	A	STA IIWSZ,B	STORE		07 03783
004572	A	STA ITMINC,B	ALSO ITEM INCREMENT		07 03784
004573	A	LRLA 1	GET ITEM BYTE SIZE		07 03785
004574	A	STA IIBSZ,B	STORE IN TABLE		07 03786
004575	A	DXR			07 03787
004576	A	JXNZ *+3	2-WORD INTEGER/LOGICAL ?	V2	07 03788
004577	R				



```

004600 046115 A 3789      INR      I$MINC,B      YES. SET INCREMENT TO 2
004601 016063 A 3790      LDA      FRMT,B
004602 001010 A 3791      JAZ      PXF10      ALL MODES OK FOR UNFORMATTED
004603 004617 R
004604 016061 A 3792      LDA      FDLKEY,B
004605 140423 A 3793      SUB      FOUR
004606 001016 A 3794      JANZ     PXF10      I FORMAT DESCRIPTOR ?
004607 004617 R
004610 016116 A 3795      LDA      ITMODE,B    YES
004611 140422 A 3796      SUB      TWO
004612 001004 A 3797      JANZ     PXF10      INTEGER ITEM
004613 004617 R
004614 140464 A 3798      SUB      THREE
004615 001016 A 3799      JANZ     ER2      ERR 2/NON-INTEG. ITEM/
004616 005156 R
004617 036151 A 3800 PXF10  LDZ      RETURN,B    POINT X AT CALL SEQUENCE
3801      MOVXAB  4,ITEMWC    SAVE LIST ITEM WORD COUNT
004620 015004 A
004621 056114 A 3802      MOVXAB  5,ITEMAD    SAVE LIST ITEM ADDRESS
004622 015005 A
004623 056113 A
3803      IFF      NUC
3804      GOTO     NUC1
3805      IFT      VII
3806      GOTO     VIII
3807      TZAB   ALOC,PXF20  EXIT IF NOT VORTEX BKGND CALLING NUC
3808      LDA      ITEMAD,B
3809      JSR     1BK,X      TEST START OF ITEM ADDRESS
3810      ADD     ITEMWC,B
3811      DAB
3812      JSR     1BK,X      TEST END OF ITEM ADDRESS
3813 VIII  CONT
3814 NUC1  CONT
3815 PXF20 POPJ      EXIT
004624 105065 A
3816 *****
3817 * TABLE OF ITEM SIZES IN WORDS *
3818 *****
004625 000001 A 3819 PXFSZT  DATA 1      1-WORD INTEGER/LOGICAL
004626 000001 A 3820      DATA 2      2-WORD INTEGER/LOGICAL
004627 000002 A 3821      DATA 2      REAL
004630 000004 A 3822      DATA 4      DOUBLE PRECISION
004631 000002 A 3823      DATA 2      COMPLEX
004632 000002 A 3824      DATA 2      DOUBLE PRECISION INTEGER
3825      EJEC
3826 *****
3827 *
3828 * REENTRANT BLOCK ENTRY (RBE)
3829 *
3830 * FUNCTION: TO PROVIDE AN ENTRY INTO MODULE V$RERR
3831 *
3832 * ENTRY: B = V$PORTIO DATA BLOCK ADDRESS
3833 * INFL .NE. 0 ON INITIAL ENTRY
3834 * .EQ. 0 ON CONTINUATION ENTRY
3835 * TO LABEL V$RERR VIA ALOC IF:
3836 *
3837 * VORTEX: BACKGROUND CALLING NUCLEUS V$RERR
3838 * VORTEX II: ANYBODY CALLING NUCLEUS V$RERR
3839 *
3840 * TO LABEL V$RERR1 VIA DIRECT JUMP OTHERWISE
3841 *
3842 * EXIT : TO PDJ IF TOP OP IS .GE. 0100(ADDRESS OPERAND)
3843 * TO OP PROCESSOR OTHERWISE
3844 * ALOC = 1 IF ENTRY THRU V$RERR
3845 * 0 IF ENTRY THRU V$RERR1
3846 * INFL = 0
3847 *
3848 * ERRORS: ER4 IF ILLEGAL OP CODE
3849 *
3850 *****
3851 *****
3852 *****
3853 * REENTRANT MODULE CALLED BY ALOC
3854 *****
004633 R 3855 V$RERR  EQU  A      ALOC ENTRY
3856      IFF      NUC
3857      GOTO     NUC1
3858      DATA  0
3859      IFT      VII
3860      GOTO     VIII
3861      EXOR   0500+MAP
3862      DMC    1MP,V$ST3  SET EXEC STATE TO RN
3863      LDA      INFL,B
3864      JANZ   NBE1
3865 *****
3866 *****
3867 * VORTEX II CONTINUATION *
3868 *****
3869      LDA      V$OPL
3870      JANZ   RBE4      TEST IF BACKGROUND
3871 *****
3872 * RESTORE STACK ADDRESSES FROM V$PERR TO V$PORTIO
3873 *****
3874      LDA      ANNS,B

```



```

3875      DME      MAP,V$ST1      SET EXEC STATE TO ON          V2 07 03875
3876      ADDI     OPSTK+STKSZ-1    FG 07 03876
3877      LDXI     BASE             POINT X AT V$RERR STACK BASE   V2 07 03877
3878      SUB      ROPSTP,X          FG 07 03878
3879      TAB      POINT B AT V$FORTIO STACK   V2 07 03879
3880      LDA      ROPSTP,X          GET COUNT           FG 07 03880
3881      JAN      RDEX             EXIT IF NO MOVE       V2 07 03881
3882      CPA      FG 07 03882
3883      INCR     014              SET X = -(COUNT-1)     FG 07 03883
3884      RBEL1   LDAE             BASE+STKSZ-1,X     FG 07 03884
3885      STA      0,B             V2 07 03885
3886      JXZ     RDEX             EXIT WHEN DONE       V2 07 03886
3887      IBR     BUMP POINTERS     FG 07 03887
3888      IXR     FG 07 03888
3889      JMP     RBEL1            V2 07 03889
3890      RBEX   LDX      V$CRS      V2 07 03890
3891      LDB     BR,X            V2 07 03891
3892      DME     MAP,V$ST3       SET EXEC STATE TO NN     V2 07 03892
3893      VIII1  CONT           FG 07 03893
3894      *****
3895      * INITIALIZE *          V2 07 03895
3896      *****
3897      RBE1   EQU      *          V2 07 03897
3898      IFT     VII           FG 07 03898
3899      ZAB     IMFL          CLEAR INITIAL ENTRY FLAG V2* 07 03899
3900      IFT     VII           FG 07 03900
3901      GOTO   VIII1          FG 07 03901
3902      LDXI   BASE             POINT X AT V$RERR DATA BLOCK   V2 07 03902
3903      STB    ANRB,X          SAVE ADDRESS OF NON-REENTRANT BLOCK 07 03903
3904      ZAX     ERN            CLEAR ERROR COUNTER          07 03904
3905      *****
3906      * TEST V$FORTIO STACK EMPTY * 07 03906
3907      *****
3908      LDA     OPSTKP,B        07 03908
3909      SUB     OPSTKP,B        07 03909
3910      JANZ   RBES           07 03910
3911      *****
3912      * V$FORTIO STACK EMPTY - RESUME EXECUTION FROM V$RERR STACK * 07 03912
3913      *****
3914      LDA     OPSTKP,X        07 03914
3915      SUB     OPSTKP,X        07 03915
3916      JAZ    RBE90          ERROR/ V$RERR STACK EMPTY / 07 03916
3917      TXB    LOAD BASE REGISTER B 07 03917
3918      POPJ   RESUME EXECUTION FROM V$RERR STACK FG 07 03918
3919      *****
3920      * V$FORTIO STACK HAS OP - TEST VALIDITY * 07 03920
3921      *****
3922      RBES   LDX     OPSTKP,B 07 03922
3923      LDA     0,X           GET OP           07 03923
3924      SUBI   13           PD 07 03924
3925      JAN    RBE90        ERROR/ ILLEGAL OP / 07 03925
3926      SUBI   11           V2 07 03926
3927      JAP    RBE90        ERROR/ ILLEGAL OP / 07 03927
3928      ADD    D16          RESTORE OP       07 03928
3929      LDX    RBE90        POINT X AT V$RERR DATA BLOCK 07 03929
3930      STA    TEMP,X      SAVE OP         07 03930
3931      SUB    CXF           V2 07 03931
3932      JAZ    RBE10        PARAMETER XFER ? 07 03932
3933      LDA    OPSTKP,X     NO. INITIALIZE V$RERR STACK 07 03933
3934      DATA  01006       SKIP            07 03934
3935      RBE10 LDA    OPSTKP,X 07 03935
3936      DAB    FG 07 03936
3937      STA    OPSTKP,X     PUSH V$RERR STACK 07 03937
3938      TAB    07 03938
3939      LDB    RBE90        POINT B AT V$RERR DATA BLOCK 07 03939
3940      LDA    TEMP,B       RELOAD OP       07 03940
3941      STA    0,X          PUSH OP ONTO V$RERR STACK 07 03941
3942      LDB    ANRB,B       POINT B AT V$FORTIO DATA BLOCK 07 03942
3943      LDX    RBE90        POINT X AT V$RERR DATA BLOCK 07 03943
3944      SPAC  07 03944
3945      *****
3946      * MOVE ADDRESSES FROM NON-REENTRANT MODULE TO REENTRANT * 07 03946
3947      *****
3948      SPAC  07 03948
3949      LDA    RETURN,B     07 03949
3950      STA    RETURN,X     MOVE CALL SEQ ADDRESS 07 03950
3951      JSR    TRK,X        TEST RETURN ADDRESS IN BACKGROUND 07 03951
3952      ADD    TEN          07 03952
3953      JSR    TRK,X        TEST PARAMETER LIST IN BACKGROUND 07 03953
3954      TAB    07 03954
3955      JSR    TRK,X        TEST 1ST WORD OF DATA BLOCK IN BACKGRND 07 03955
3956      ADDI   YYY-1       V2 07 03956
3957      JSR    TRK,X        TEST LAST WORD OF DATA BLOCK IN BACKGRND 07 03957
3958      LDX    RBE90        07 03958
3959      LDA    ANRDJ,B      07 03959
3960      STA    ANRDJ,X     MOVE NON-REENTRANT POP/JUMP ADDRESS 07 03960
3961      JSR    TRK,X        TEST NON-REENTRANT POP/JUMP IN BACKGROUND 07 03961
3962      LDX    RBE90        POINT X AT REENTRANT BLOCK 07 03962
3963      LDA    OPSTKP,B     07 03963
3964      SUB    ANRB,X       07 03964
3965      SUBI   VOPSTK-BASE  COMPARE WITH BOTTOM OF STACK V2 07 03965
3966      JAN    RBE90        ERROR/ PROTECTION / 07 03966
3967      SUBI   STKSZ       V2 07 03967

```



```

3968 JAP RBE90 ERROR/ PROTECTION /
3969 INR DPSTKP,B POP VSFORTIO STACK FG 07 03969
3970 LDR RBE8 POINT B AT VSRERR DATA BLOCK 07 03970
3971 LDA TEMP,B RELOAD OP 07 03971
3972 SUB DXF V2 07 03972
3973 JANZ RBE4 IS OP PARAMETER XFER ? V2 07 03973
3974 LDA XFFL,B YES. GET XFER ENABLE FLAG 07 03974
3975 JAZ RBE90 EXIT IF ILLEGAL OP 07 03975
3976 VIII1 COM1 FG 07 03976
3977 RBE4 EDU * V2 07 03977
3978 IFF VORTEX-2 V2 07 03978
3979 OME MAP,VSST3 SET EXEC STATE TO NN V2 07 03979
3980 INCR 1 SET ALOC ENTRY FLAG V2 07 03980
3981 DATA 01006 V2 07 03981
3982 NUC1 COM1 FG 07 03982
3983 *****
3984 * REENTRANT MODULE CALLED BY DIRECT JUMP * 07 03984
3985 *****
004633 R 004633 3986 VSRER1 EDU * 07 03986
004633 005001 A 3987 TZA RESET ALOC ENTRY FLAG V2 07 03987
004634 056014 A 3988 STA ALOC,B V2 07 03988
3989 *****
3990 * TEST OP * 07 03990
3991 *****
004635 036000 A 3992 LDX DPSTKP,B V2 07 03992
004636 015000 A 3993 LDA 0,X GET OP IN A 07 03993
004637 056164 A 3994 STA TEMP,B SAVE 07 03994
004640 004346 A 3995 LSRA 6 07 03995
004641 001010 A 3996 JAZ RBE15 IS OP RETURN ADDRESS ? FG 07 03996
004642 004644 R 3997 POPJ YES. RETURN FG 07 03997
004643 105065 A 3998 RBE15 LDA 0,X RELOAD OP FG 07 03998
004644 015000 A 3999 IXR POP STACK FG 07 03999
004646 076000 A 4000 STX DPSTKP,B 07 04000
004647 140465 A 4001 SUB CTR V2 07 04001
004650 001004 A 4002 JAN ER4 ERROR 4/ILLEGAL OP/ 07 04002
004651 005154 R 4003 JAZ RBE25 NO UNIT ASSOCIATED WITH TERMINATE CALL 07 04003
004652 001010 A 4004 DAR NO UNIT ASSOCIATED WITH PARAM XFER CALL V2 07 04004
004653 004667 R 4005 JAZ RBE30 NO UNIT ASSOCIATED WITH PARAM XFER CALL 07 04005
004654 005311 A 4006 SUBI RBEJTE-RBEJT-1 V2 07 04006
004655 001010 A 4007 JAP ER4 ERROR 4/ILLEGAL OP/ 07 04007
004662 005154 R 4008 LDX RETURN,B 07 04008
004663 036151 A 4009 LDX 4,X POINT X AT FORTRAN UNIT NUMBER 07 04009
004664 035004 A 4010 LDA 0,X GET FORTRAN UNIT NUMBER 07 04010
004666 056167 A 4011 STA UNIT,B STORE 07 04011
004667 005001 A 4012 RBE25 TZA 07 04012
004670 056172 A 4013 STA XFFL,B DISABLE PARAMETER XFER 07 04013
004671 036164 A 4014 RBE30 LDX TEMP,B LOAD OP AS JUMP TABLE INDEX V2 07 04014
4015 IFF NUC FG 07 04015
4016 GOTO NV2NUC FG 07 04016
4017 IFT VII FG 07 04017
4018 OME MAP,VSST0 SET EXEC STATE TO 00 V2 07 04018
4019 NV2NUC COM1 FG 07 04019
004672 006035 A 4020 LDXE RBEJT-CTRV,X GET PROCESSOR ADDRESS V2 07 04020
004673 004671 R 4021 IFF NUC FG 07 04021
4022 GOTO NV2NUC FG 07 04022
4023 IFT VII FG 07 04023
4024 OME MAP,VSST3 SET EXEC STATE TO NN V2 07 04024
004674 006705 A 4025 NV2NUC COM1 FG 07 04025
004675 000000 A 4026 IJMP 0,X EXIT TO PROCESSOR 07 04026
4027 *****
4028 * PROTECTION ERROR * 07 04028
4029 *****
4030 IFF NUC FG 07 04030
4031 GOTO NUC1 FG 07 04031
4032 IFT VII FG 07 04032
4033 GOTO VIII1 FG 07 04033
4034 RBE90 TZA 07 04034
4035 JMP TBK FORCE TBK ERROR 07 04035
4036 VIII1 COM1 FG 07 04036
4037 NUC1 COM1 FG 07 04037
4038 *****
4039 * EXIT JUMP TABLE * 07 04039
4040 *****
004676 005611 R 4041 RBEJT PZE IOM TERMINATE 07 04041
004677 004554 R 4042 PZE PKV PARAMETER XFER V2 07 04042
004700 003101 R 4043 PZE PAK BACKSPACE 07 04043
004701 003101 R 4044 PZE PAK WRITE EOF 07 04044
004702 003101 R 4045 PZE PAK REWIND 07 04045
004703 004344 R 4046 PZE PRN READ 07 04046
004704 004344 R 4047 PZE PRN WRITE 07 04047
004705 000152 R 4048 PZE CLS CLOSE RMD FILE 07 04048
004706 000152 R 4049 PZE CLS CLOSE RMD FILE 07 04049
004707 002717 R 4050 PZE UPN OPEN RMD FILE 07 04050
004710 002717 R 4051 PZE UPN OPEN RMD FILE 07 04051

```



```

004711 003633 R 4052 PZE PRD DECODE PD 07 04052
004712 003633 R 4053 PZE PRD ENCODE PD 07 04053
004713 004445 R 4054 PZE PRX READ - DIRECT ACCESS 07 04054
004714 004445 R 4055 PZE PRX WRITE - DIRECT ACCESS 07 04055
004715 R 4056 RBEJTE EQU * V2 07 04056
4057 IFT VII FG 07 04057
4058 GOTO VIII FG 07 04058
4059 IFF NUC FG 07 04059
4060 GOTO NUC1 FG 07 04060
4061 RBEB DATA BASE V2 07 04061
4062 NUC1 CONT FG 07 04062
4063 VIII CONT FG 07 04063
4064 EJEC 07 04064
4065 ***** 07 04065
4066 * 07 04066
4067 * REPEAT CHARACTER I/O (RCH) * 07 04067
4068 * 07 04068
4069 * FUNCTION: TO REPEAT A CHARACTER I/O OPERATION N TIMES * 07 04069
4070 * 07 04070
4071 * ENTRY: COUNT = N * 07 04071
4072 * BCHAR = CHARACTER TO BE OUTPUT * 07 04072
4073 * 07 04073
4074 * EXIT : NO SPECIAL CONDITIONS * 07 04074
4075 * 07 04075
4076 ***** 07 04076
004715 016052 A 4078 RCH LDA COUNT,B 07 04078
004716 005311 A 4079 DAR DECREMENT COUNT 07 04079
004717 001002 A 4080 JAP RCH2 FG 07 04080
004720 004722 R 4081 POPJ EXIT IF COUNT .LE. 0 FG 07 04081
004721 105065 A 4082 RCH2 STA COUNT,B FG 07 04082
004722 056052 A 4083 LDA ASCB,B 07 04083
004723 016021 A 4084 SUB ABSCB,B 07 04084
004724 146002 A 4085 ROF V2 07 04085
004725 007400 A 4086 XAZ SOF SET OVFL IF BUFFER SOB V2 07 04086
004726 003010 A 4087 TSAB RWFL,WR,RCH10 V2 07 04087
004727 001615 R
004730 016154 A 4088 ***** 07 04088
004731 006411 A 4089 * INPUT * 07 04089
004732 004745 R 4090 ***** 07 04090
004733 001001 A 4091 JOF RCH5 V2 07 04091
004734 004741 R 4092 ***** 07 04092
4093 * INPUTTING FROM NON-BUFFER * 07 04093
4094 ***** 07 04094
4095 PUSHJ JCB INPUT CHARACTER V2 07 04095
004735 105025 A 4096 JMP RCH LOOP TILL DONE 07 04096
004736 001612 R 4097 ***** 07 04097
004737 001000 A 4098 * INPUTTING FROM BUFFER * 07 04098
004740 004715 R 4099 ***** 07 04099
4100 RCH5 PUSHJ DCB INPUT CHARACTER FROM BUFFER V2 07 04100
004741 105025 A 4101 JMP RCH LOOP TILL DONE 07 04101
004742 000070 R 4102 ***** 07 04102
004743 001000 A 4103 * OUTPUT * 07 04103
004744 004715 R 4104 ***** 07 04104
004745 001001 A 4105 RCH10 JOF RCH15 V2 07 04105
004746 004753 R 4106 ***** 07 04106
4107 * OUTPUT TO NON-BUFFER * 07 04107
4108 ***** 07 04108
4109 PUSHJ RCH PUT CHARACTER V2 07 04109
004747 105025 A 4110 JMP RCH LOOP TILL DONE 07 04110
004750 003276 R 4111 ***** 07 04111
004751 001000 A 4112 * OUTPUT TO BUFFER * 07 04112
004752 004713 R 4113 ***** 07 04113
4114 RCH15 PUSHJ DCB OUTPUT CHARACTER TO BUFFER V2 07 04114
004753 105025 A 4115 JMP RCH LOOP TILL DONE 07 04115
004754 002441 R 4116 EJEC 07 04116
004755 001000 A 4117 ***** 07 04117
004756 004715 R 4118 * 07 04118
4119 * RECYCLE LOGICAL BUFFER (PCL) * 07 04119
4120 * 07 04120
4121 * FUNCTION: TO MOVE FORWARD TO NEXT LOGICAL RECORD * 07 04121
4122 * 07 04122
4123 * ENTRY: LRWC = COUNT OF WORDS REMAINING IN LOGICAL RECORD * 07 04123
4124 * 07 04124
4125 * EXIT : LRWC = LRSZ * 07 04125

```



```

4126 *
4127 *****
4129 RCL TRAB RWFL,LF,RCL5 LOGICAL FILE ? V2 07 04129
004757 016154 A
004760 006441 A
004761 004764 R
004762 006400 A 4130 BT ASET+RM,RCL10 YES. RMD ? D.1 07 04130
004763 004771 R
4131 RCL5 ZAB LRWC NO. FORCE RECYCLE V2 07 04131
004764 005001 A
004765 056123 A
004766 056144 A 4132 STA PBWC,B CLEAR WORD COUNTS 07 04132
004767 001000 A 4133 JMP RCL15 D.1 07 04133
004770 005000 R
004771 006444 A 4134 RCL10 BT ARST+TR,RCL15 TERMINATE LOGICAL RMD ? D.1 07 04134
004772 005000 R
4135 TNZAB LRWC,RCL15 YES. END OF LOGICAL RECORD ? D.1 07 04135
004773 016123 A
004774 001016 A
004775 005000 R
004776 046121 A 4136 INR LRECND,B YES. BUMP LOGICAL RECORD NUMBER D.1 07 04136
4137 POPJ EXIT FG 07 04137
004777 105065 A
4138 RCL15 PUSHJ RBA STEP THRU LOGICAL BUFFER D.1 07 04138
005000 105025 A
005001 001072 R
005002 016123 A 4139 LDA LRWC,B 07 04139
005003 005111 A 4140 IAR 07 04140
005004 146122 A 4141 SUB LRSZ,B 07 04141
005005 001004 A 4142 JAN RCL LOOP TILL LOGICAL BOUNDARY PASSED D.1 07 04142
005006 004757 R
005007 046123 A 4143 INR LRWC,B RESTORE WORD COUNTS 07 04143
005010 046144 A 4144 INR PBWC,B 07 04144
4145 DAB BFWPT AND BUFFER POINTER 07 04145
005011 016025 A
005012 005311 A
005013 056025 A
4146 POPJ EXIT FG 07 04146
005014 105065 A
4147 EJEC 07 04147
4148 ***** 07 04148
4149 * 07 04149
4150 * R E C Y C L E P H Y S I C A L B U F F E R ( R O P ) * 07 04150
4151 * * 07 04151
4152 * FUNCTION: TO RECYCLE A PHYSICAL BUFFER * 07 04152
4153 * * 07 04153
4154 * ENTRY: PBSZ = PHYSICAL BUFFER SIZE IN WORDS * 07 04154
4155 * APBF = PHYSICAL BUFFER START ADDRESS * 07 04155
4156 * IN = 1 IF INITIALIZING V2* 07 04156
4157 * PD = 1 IF BUFFER MUST BE POSTED V2* 07 04157
4158 * * 07 04158
4159 * EXIT : IN = 1 V2* 07 04159
4160 * V2* 07 04160
4161 * BUFFER POSTED IF PD SET V2* 07 04161
4162 * I/O SUPPRESSED V2* 07 04162
4163 * V2* 07 04163
4164 * IN = 0 V2* 07 04164
4165 * V2* 07 04165
4166 * PBWC = PBSZ V2* 07 04166
4167 * BUFFER CLEARED BEFORE NON-RMD READ V2* 07 04167
4168 * * 07 04168
4169 ***** 07 04169
005015 R 4171 RCP EQU * V2 07 04171
4172 TRAB RWFL,IN,RCP5 INITIALIZING ? V2 07 04172
005015 016154 A
005016 006446 A
005017 005031 R
005020 006442 A 4173 BT ARST+PD,RCP3 YES. ANY UNPOSTED DATA ? 07 04173
005021 005025 R
4174 PUSHJ RBA YES. POST BUFFER V2 07 04174
005022 105025 A
005023 004465 R
005024 016154 A 4175 LDA RWFL,B RESTORE FLAG WORD 07 04175
005025 006451 A 4176 RCP3 BT ARST+WR,RCP15 READ ? V2 07 04176
005026 005053 R
005027 001000 A 4177 JMP RCP25 07 04177
005030 005076 R
4178 RCP5 MOVBAW PBSZ,PBWC RELOAD PHYSICAL WORD COUNT 07 04178
005031 016143 A
005032 056144 A
005033 016027 A 4179 LDA ALBF,B D.1 07 04179
005034 146025 A 4180 SUB BFWPT,B D.1 07 04180
005035 005311 A 4181 DAB D.1 07 04181
005036 126020 A 4182 ADD APBF,B D.1 07 04182
005037 056027 A 4183 STA ALBF,B UPDATE ADDRESS OF LOGICAL BUFFER D.1 07 04183
4184 DABB APBF,BFWPT INITIALIZE BUFFER POINTER D.1 07 04184
005040 016020 A
005041 005311 A
005042 056025 A
4185 TSAB RWFL,WR,RCP20 READ ? V2 07 04185
005043 016154 A
005044 006411 A
005045 005071 R

```



005046	006442	A	4186	BT	ARST+PD,RCP15	YES. ANY UNPOSTED DATA ?	C.1 07 04186
005047	005053	R	4187	PUSHJ	PSB	YES. POST BUFFER	V2 07 04187
005050	105025	A	4188	LDA	RWFL,B	RESTORE FLAG WORD	V2 07 04188
005051	004465	R	4189	*****			V2 07 04189
005052	016154	A	4190	* CLEAR BUFFER ON NON-RMD READ *			V2 07 04190
			4191	*****			07 04191
005053	006400	A	4192	RCP15	BT	ASET+RM,RCP20 RMD ?	V2 07 04192
005054	005071	R	4193	TZAB	UNIT,RCP20	NO. DONT CLEAR IF L=0	D.1 07 04193
005055	016167	A	4194	LDX	ADFCB,B		D.1 07 04194
005056	001010	A	4195	MOVBB	LRWC,SAVE+2	SAVE LRWC	07 04195
005057	005071	R	4196	MOVXAB	0,LRWC	SET LOGICAL WORD COUNT = FCB(0)	07 04196
005061	016123	A	4197	PUSHJ	CLB	CLEAR BUFFER	V2 07 04197
005062	056034	A	4198	MOVBB	SAVE+2,LRWC	RESTORE LRWC	07 04198
005063	015000	A	4199	*****			V2 07 04199
005064	056123	A	4200	* READ/WRITE PHYSICAL RECORD *			V2 07 04200
005065	105025	A	4201	*****			V2 07 04201
005066	000116	R	4202	RCP20	PUSHJ	RFB REFRESH PHYSICAL BUFFER	V2 07 04202
005067	016034	A	4203	TRAB	RWFL,WR,RCP50	READ ?	V2 07 04203
005070	056123	A	4204	RCP25	BT	ARST+LF,RCP40 NO. WRITE. LOGICAL FILE ?	D.1 07 04204
005071	105025	A	4205	LDX	ADFCB,B	YES. POINT X AT FCB	V2 07 04205
005072	005354	R	4206	BT	ARST+RM,RCP40	RMD ?	D.1 07 04206
005073	016154	A	4207	DRA	POS	YES. SET POST FLAG	D.1 07 04207
005074	006451	A	4208	STA	RWFL,B		07 04208
005075	005147	R	4209	LDA	12,X		07 04209
005076	006441	A	4210	DRA	FPOS	ALSO IN FCB(12)	V2 07 04210
005077	005140	R	4211	STA	12,X		07 04211
005100	036010	A	4212	TRAB	RWFL,RB,RCP35	IS READ BEFORE WRITE ENABLED ?	07 04212
005101	006440	A	4213	LDX	ANRB,B	YES. POINT X AT V\$FORTID DATA BLOCK	07 04213
005102	005140	R	4214	LDA	IDCONT,X		07 04214
005103	110423	A	4215	ANA	BRS	CLEAR WRITE BIT IN V\$IDC CONTROL WORD	07 04215
005104	056154	A	4216	STA	IDCONT,X		07 04216
005105	015014	A	4217	PUSHJ	RFB	READ NEXT PHYSICAL RECORD	V2 07 04217
005106	110437	A	4218	SUTBB	PRECND,PBRC,PRECND	RESTORE PHYSICAL RECORD NUMBER	07 04218
005107	055014	A	4219	LDX	ANRB,B	POINT X AT V\$FORTID DATA BLOCK	07 04219
005110	016154	A	4220	LDA	IDSTAT,X	GET STATUS OF READ	07 04220
005111	006443	A	4221	DAR			07 04221
005112	005135	R	4222	JAN	*43	TEST FOR EOF	07 04222
005113	036016	A	4223	STA	IDSTAT,X	CLEAR EOF FLAG ON READ BEFORE WRITE	07 04223
005114	015104	A	4224	LDA	IDCONT,X		07 04224
005115	150451	A	4225	DRA	BRS	RESTORE WRITE BIT IN V\$IDC CONTROL WORD	07 04225
005116	055104	A	4226	STA	IDCONT,X		07 04226
005117	105025	A	4227	RCP35	LDX	ADFCB,B	07 04227
005118	005354	R	4228	MOVBB	PRECND,13	UPDATE FCB(13)	07 04228
005120	005354	R	4229	RCP40	TSAB	RWFL,IN,RCP50 EXIT ON INITIALIZE	D.1 07 04229
005121	016145	A	4230	BT	ASET+SC,RCP50		D.1 07 04230
005122	146142	A	4231	PUSHJ	CLB	CLEAR BUFFER AFTER WRITE	D.1 07 04231
005123	056145	A	4232	RCP50	LDA	RWFL,B	D.1 07 04232
005124	036016	A	4233	ANA	SCR	CLEAR CLEAR SUPPRESS FLAG	D.1 07 04233
005125	015106	A	4234	ANA	INR	CLEAR INITIALIZE FLAG	V2 07 04234
005126	005311	A	4235	STA	RWFL,B		07 04235
005127	001004	A	4236	PUPJ		EXIT	FG 07 04236
005128	005132	R	4237	EJEC			07 04237
005129	055106	A	4238	*****			07 04238



```

4239 *
4240 *   R E E N T R A N T   E R R O R   P R O C E S S O R ( R E R )
4241 *
4242 *   FUNCTION: TO PROCESS ERRORS IN V$RERR
4243 *
4244 *   ENTRY: ER1 FORMAT
4245 *           ER2 MODE
4246 *           ER3 DATA
4247 *           ER4 I/O ERROR
4248 *
4249 *   EXIT : DIRECT TO CAN
4250 *           ERN = ERROR NUMBER-1
4251 *           ERROR DP PUSHED
4252 *
4253 *****
005154 046060 A 4255 ER4   INR   ERN,B   I/O
005155 046060 A 4256 ER3   INR   ERN,B   DATA
005156 046060 A 4257 ER2   INR   ERN,B   MODE
005157 036016 A 4258 ER1   LDX   ANRB,B   POINT X AT V$FORTIO DATA BLOCK
005160 016060 A 4259     LDA   ERN,B
005161 055060 A 4260     STA   ERN,X   MOVE ERROR NUMBER
005162 010421 A 4261     LDA   CLR     GET ERROR DP
4262     PUSHF
005163 036016 A
005164 035000 A
005165 005344 A
005166 055000 A
005167 005041 A
005170 036016 A
005171 055000 A
005172 001000 A 4263     JMP   CAN     EXIT TO V$FORTIO
005173 000065 R
4264     EJECT
4265 *****
4266 *
4267 *   R E P O S I T I O N   F I L E ( R F L )
4268 *
4269 *   FUNCTION: TO REPOSITION A FILE AT START OF A READ OR WRITE, OR IF
4270 *           A T FORMAT SPECIFIER REQUIRES A PHYSICAL BACKSPACE
4271 *
4272 *   ENTRY: ADFCB = ADDRESS OF DCB/FCB
4273 *           APBF = ADDRESS OF PHYSICAL BUFFER
4274 *           ALBF = ADDRESS OF LOGICAL BUFFER
4275 *           PBSZ = PHYSICAL BUFFER SIZE IN WORDS
4276 *           LRSZ = LOGICAL RECORD SIZE IN WORDS
4277 *           PRECND = PHYSICAL RECORD NUMBER
4278 *
4279 *   EXIT : READ : 1ST RECORD IN BUFFER
4280 *           WRITE: BUFFER CLEARED
4281 *
4282 *****
005174 016122 A 4284 RFL   MOVBA B LRSZ,LRWC   INITIALIZE LOGICAL WORD COUNT
005175 056123 A
4285     DAB B   ALBF,BFHP   INITIALIZE BUFFER WORD POINTER
005176 016027 A
005177 005311 A
005200 056025 A
4286     MOVBA B PBSZ,PBWC   INITIALIZE PHYSICAL WORD COUNT
005201 016143 A
005202 056144 A
4287     TRAB   RWFL,LF,RFL5   LOGICAL FILE ?
005203 016154 A
005204 006441 A
005205 005210 R
005206 006400 A 4288     BT     ASET+RM,RFL10   YES. TEST IF RMD
005207 005214 R
4289 *****
4290 * NOT LOGICAL RMD FILE *
4291 *****
005210 006411 A 4292 RFL5   BT     ASET+WR,RFL40   READ ?
005211 005274 R
005212 001000 A 4293     JMP   RCP     YES. RECYCLE PHYSICAL BUFFER
005213 005015 R
4294 *****
4295 * LOGICAL RMD FILE *
4296 *****
005214 016020 A 4297 RFL10  LDA   APBF,B
005215 126143 A 4298     ADD   PBSZ,B
005216 146027 A 4299     SUB   ALBF,D
005217 056144 A 4300     STA   PBWC,B   INITIALIZE PHYSICAL WORD COUNT
4301 *****
4302 * TEST IF LRECND IN BUFFER *
4303 *****
005220 036010 A 4304     LDX   ADFCB,B
005221 015015 A 4305     LDA   13,X
005222 001010 A 4306     JAZ   RFL50   TEST IF BUFFER EMPTY
005223 005275 R
005224 146145 A 4307     SUB   PRECND,B   COMPARE BUFFER ADDRESS WITH PRECND
005225 001010 A 4308     JAZ   RFL20   LRECND RESIDENT IF EQUAL
005226 005257 R
005227 001002 A 4309     JAP   RFL50
005230 005275 R

```



005231	056164	A	4310	STA	TEMP,B	SAVE -(RECORD INCREMENT)	07	04310	
005232	126142	A	4311	ADD	PBRC,B		07	04311	
005233	005311	A	4312	DAR			07	04312	
005234	001004	A	4313	JAN	RFL50		07	04313	
005235	005275	R							
			4314	*****				07	04314
			4315	* LRECND IS RESIDENT *				07	04315
			4316	*****				07	04316
			4317	MOVXAB	13,PRECND	UPDATE PHYSICAL RECORD NUMBER	07	04317	
005236	015015	A							
005237	056145	A							
005240	005024	A	4318	TBX		SAVE BASE REGISTER	07	04318	
005241	005001	A	4319	TZA			07	04319	
005242	146164	A	4320	SUB	TEMP,B	GET RECORD INCREMENT	07	04320	
005243	004560	A	4321	LLSR	16		07	04321	
005244	165201	A	4322	MUL	BD120,X	CONVERT TO WORD INCREMENT	V2	07 04322	
005245	065164	A	4323	STB	TEMP,X		07	04323	
005246	005042	A	4324	TXB		RESTORE BASE REGISTER B	07	04324	
005247	016027	A	4325	LDA	ALBF,B		07	04325	
005250	126164	A	4326	ADD	TEMP,B	BUMP LOGICAL BUFFER ADDRESS	07	04326	
005251	056027	A	4327	STA	ALBF,B		07	04327	
005252	005311	A	4328	DAR			07	04328	
005253	056025	A	4329	STA	BFWPT,B	ALSO BUFFER WORD POINTER	07	04329	
005254	016144	A	4330	LDA	PBWC,B		07	04330	
005255	146164	A	4331	SUB	TEMP,B	DECREMENT PHYSICAL WORD COUNT	07	04331	
005256	056144	A	4332	STA	PBWC,B		07	04332	
			4333	RFL20	TSAB	RWFL,WR,RFL30	V2	07 04333	
005257	016154	A							
005260	006411	A							
005261	005266	R							
			4334	ADBBB	PRECND,PBRC,PRECND	YES. BUMP PHYSICAL RECND	V2	07 04334	
005262	016145	A							
005263	126142	A							
005264	056145	A							
			4335	POPJ		AND EXIT	FG	07 04335	
005265	105065	A							
005266	110423	A	4336	RFL30	DRA	POS	V2	07 04336	
005267	056154	A	4337	STA	RWFL,B	SET POST FLAG ON WRITE	V2	07 04337	
005270	036010	A	4338	LIX	ADFCB,B	POINT X AT FCB	V2	07 04338	
005271	015014	A	4339	LDA	12,X		V2	07 04339	
005272	110437	A	4340	DRA	FPOS	ALSO IN FCB	V2	07 04340	
005273	055014	A	4341	STA	12,X		V2	07 04341	
			4342	RFL40	POPJ	AND EXIT	FG	07 04342	
005274	105065	A							
			4343	*****				07	04343
			4344	* LRECND NOT IN BUFFER *				07	04344
			4345	*****				07	04345
005275	016154	A	4346	RFL50	LDA	RWFL,B		07 04346	
005276	110427	A	4347	DRA	INS	SET INITIALIZE FLAG	V2	07 04347	
005277	056154	A	4348	STA	RWFL,B		07	04348	
005300	001000	A	4349	JMP	RCP	RECYCLE PHYSICAL BUFFER	07	04349	
005301	005015	R							
			4350	EJEC			07	04350	
			4351	*****				07	04351
			4352	*****				07	04352
			4353	R O U N D D E C I M A L P R R A Y ( R N D )				07	04353
			4354	*****				07	04354
			4355	* FUNCTION: TO ROUND DECIMAL DIGIT STRING IN ARRAY CHB, PROPAGATING				07	04355
			4356	CARRIES FORWARD				07	04356
			4357	*****				07	04357
			4358	* ENTRY: ARRAY CHB CONTAINS BINARY EQUIVALENTS OF DECIMAL DIGITS				07	04358
			4359	COUNT = ROUND POSITION				07	04359
			4360	DEXP = DECIMAL EXPONENT				07	04360
			4361	ACC = BINARY FRACTION REMAINING AFTER 14 DIGITS				V2	07 04361
			4362	*****				07	04362
			4363	* EXIT : DEXP = DEXP+1 ON FIELD OVERFLOW				07	04363
			4364	*****				07	04364
			4365	*****				07	04365
005302	005302	R	4367	RNA	EQU	*	07	04367	
005303	016052	A	4368	RND	LDA	COUNT,B	07	04368	
005304	001004	A	4369	JAN	RNDX	EXIT IF COUNT NEGATIVE	FG	07 04369	
005305	146200	A	4370	SUB	BD14,B		V2	07 04370	
005306	001004	A	4371	JAN	RND5	IS COUNT .GE. 14 ?	07	04371	
005307	005321	R							
005310	016007	A	4372	LDA	ACMB,B	YES	07	04372	
005311	126200	A	4373	ADD	BD14,B		V2	07 04373	
005312	005314	A	4374	DPCR	014	POINT X AT LAST DIGIT	07	04374	
005313	016003	A	4375	LDA	ACC,B		07	04375	
005314	004241	A	4376	LRLA	1		07	04376	
005315	001002	A	4377	JAP	RNDX	EXIT IF NO BUMP	FG	07 04377	
005316	005353	R							
005317	001000	A	4378	JMP	RNDL	OTHERWISE PROPAGATE CARRY	07	04378	
005320	005335	R							
005321	016007	A	4379	RND5	LDA	ACMB,B	07	04379	
005322	126052	A	4380	ADD	COUNT,B		07	04380	
005323	005314	A	4381	DECR	014	POINT X AT ROUND POSITION-1	07	04381	
005324	015001	A	4382	LDA	1,X	GET DECIMAL DIGIT	07	04382	
005325	140465	A	4383	SUB	FIVE		07	04383	
005326	001004	A	4384	JAN	RNDX	EXIT IF NO CARRY	FG	07 04384	
005327	005353	R							
			4385	TZAB	COUNT,RND10	TEST COUNT=0	07	04385	
005330	016052	A							



```

005331 001010 A
005332 005350 R
4386 ZAX ! CLEAR LAST DIGIT IN CASE OF OVERFLOW 07 04386
005333 005001 A
005334 055001 A
4387 *****
4388 * LOOP TO PROPAGATE CARRIES *
4389 *****
005335 045000 A 4390 RNDL INR 0,X BUMP PRECEDING DIGIT 07 04389
005336 015000 A 4391 LDA 0,X 07 04390
005337 140471 A 4392 SUB TEN 07 04391
005340 001004 A 4393 JAN RNDX EXIT IF NO CARRY FG 07 04392
005341 005353 R
005342 005001 A 4394 TZA 07 04394
005343 055000 A 4395 STA 0,X CLEAR DIGIT 07 04395
005344 005345 A 4396 RECR 045 DECREMENT CHB ARRAY POINTER 07 04396
005345 146007 A 4397 SUB ACHE,B 07 04397
005346 001002 A 4398 JAP RNDL IS CARRY PROPAGATED OUT OF CHB ? 07 04398
005347 005335 R
005350 046055 A 4399 RND10 INR DEXP,B YES. BUMP DECIMAL EXPONENT 07 04399
005351 005101 A 4400 INCR 1 07 04400
005352 055001 A 4401 STA 1,X SHIFT CHB RIGHT 1 07 04401
4402 RNDX POPJ EXIT FG 07 04402
005353 105065 A
4403 EJEC 07 04403
4404 ***** 07 04404
4405 * 07 04405
4406 * REFRESH PHYSICAL BUFFER (R P B) * 07 04406
4407 * 07 04407
4408 * FUNCTION: TO READ OR WRITE A PHYSICAL BUFFER * 07 04408
4409 * 07 04409
4410 * ENTRY: ADFCB = ADDRESS OF DCB/FCB * 07 04410
4411 * 07 04411
4412 * LOGICAL FILES ONLY: * 07 04412
4413 * 07 04413
4414 * PRECND = CURRENT PHYSICAL RECORD NUMBER * 07 04414
4415 * PERC = COUNT OF 120-WORD RECORDS IN PHYSICAL BUFFER * 07 04415
4416 * 07 04416
4417 * EXIT : PBWC = PHYSICAL WORD COUNT * 07 04417
4418 * PRECND = PRECND + PERC * 07 04418
4419 * 07 04419
4420 ***** 07 04420
4422 RPB TRAB RWFL,LF,RPB10 TEST IF LOGICAL FILE 07 04422
005354 016154 A
005355 006441 A
005356 005363 R
4423 ***** 07 04423
4424 * LOGICAL FILE - SET UP FCB * 07 04424
4425 ***** 07 04425
005357 036010 A 4426 LDX ADFCB,B POINT X AT FCB 07 04426
4427 MOVBAK PRECND,3 MOVE PHYSICAL RECNO TO FCB(3) 07 04427
005360 016145 A
005361 055003 A
005362 055015 A 4428 STA 13,X ALSO FCB(13) 07 04428
4429 ***** 07 04429
4430 * CALL IDC TO DO I/O * 07 04430
4431 ***** 07 04431
005363 010464 A 4432 RPB10 LDA CID CALL VSIDC TO DO I/O V2 07 04432
005364 006505 A 4433 JSR PSJ,X V2 07 04433
005365 004515 R
4434 TRAB RWFL,IN,RPB11 INITIALIZING I E.1 07 04434
005366 016154 A
005367 006446 A
005370 005376 R
005371 016020 A 4435 LDA APBF,B YES E.1 07 04435
005372 126143 A 4436 ADD PBRZ,B E.1 07 04436
005373 146027 A 4437 SUB PLBF,B COMPUTE REMAINING PHYSICAL WORD COUNT E.1 07 04437
005374 001000 A 4438 JMP RPB12 E.1 07 04438
005375 005400 R
005376 036016 A 4439 RPB11 LDX ANRB,B NOT INITIALIZING E.1 07 04439
005377 015144 A 4440 LDA PBWC,X XFER I/O WORD COUNT FROM VSFORTIO E.1 07 04440
005400 056144 A 4441 RPB12 STA PBWC,B E.1 07 04441
4442 TRAB RWFL,LF,RPB15 LOGICAL FILE ? V2 07 04442
005401 016154 A
005402 006441 A
005403 005406 R
005404 006400 A 4443 BT ASET+RM,RPB20 YES. RMD ? V2 07 04443
005405 005411 R
4444 RPB15 MOVBAK PBWC,LRSZ NO. UPDATE LOGICAL WORD COUNT V2 07 04444
005406 016144 A
005407 056121 A
4445 POPJ EXIT FG 07 04445
005410 105065 A
4446 RPB20 ATBBB PRECND,PERC,PRECND BUMP PHYSICAL RECORD NUMBER 07 04446
005411 016145 A
005412 126142 A
005413 056145 A
4447 POPJ EXIT FG 07 04447
005414 105065 A
4448 EJEC 07 04448
4449 ***** 07 04449
4450 * 07 04450
4451 * SEARCH FCB CHAIN (SCH) * 07 04451

```



```

4452 * * 07 04452
4453 * FUNCTION: TO SEARCH AN FCB CHAIN FOR A GIVEN FORTRAN UNIT NUMBER U * 07 04453
4454 * * 07 04454
4455 * ENTRY: UNIT = U * 07 04455
4456 * LNKCNT = COUNT OF FCB'S ON CHAIN V2 07 04456
4457 * EACH CHAIN ITEM XFCB HAS FORMAT: * 07 04457
4458 * XFCB(10) = ADDRESS OF NEXT FCB ON CHAIN * 07 04458
4459 * XFCB(11) = U(XFCB) * 07 04459
4460 * ALOC .NE. 0 IF V$RERR ENTERED BY ALOC V2 07 04460
4461 * * 07 04461
4462 * EXIT : A = ADDRESS OF FCB ARRAY, IF U ON CHAIN * 07 04462
4463 * = 0 IF U NOT ON CHAIN * 07 04463
4464 * PRLINK = ADDRESS OF PREVIOUS CHAIN LINK * 07 04464
4465 * * 07 04465
4466 * ***** * 07 04466
4468 * ***** * 07 04468
4469 * INITIALIZE SEARCH LOOP * 07 04469
4470 * ***** * 07 04470
005415 036016 A 4471 SCH LDX ANRB,B * 07 04471
005416 005041 A 4472 TXA GET DATA BLOCK ADDRESS * 07 04472
005417 006120 A 4473 ADDI CHNHDR-10 ADD BIAS V2 07 04473
005420 000037 A * * *
005421 056146 A 4474 STA PRLINK,B POINT PREVIOUS LINK AT CHAIN HEADER * 07 04474
005422 013120 A 4475 LDA LNKCNT,X GET LINK COUNT * 07 04475
005423 056052 A 4476 STA COUNT,B STORE AS LOOP COUNT * 07 04476
005424 035051 A 4477 LDX CHNHDR,X POINT X AT HEAD OF CHAIN * 07 04477
4478 * ***** * 07 04478
4479 * SEARCH LOOP * 07 04479
4480 * ***** * 07 04480
005425 016052 A 4481 SCHLP LDA COUNT,B * 07 04481
005426 001010 A 4482 JAZ SCHY FLAG NO FIND BY EXIT WITH A=0 FG 07 04482
005427 005443 R * * *
005430 005311 A 4483 DAB DECREMENT COUNT * 07 04483
005431 056052 A 4484 STA COUNT,B * 07 04484
4485 IFF NUP * 07 04485
4486 GOTO NUC1 FG 07 04486
4487 IFT VII FG 07 04487
4488 GOTO VII1 FG 07 04488
4489 TZAB ALOC,SCH5 VORTEX BKGND CALLING NUCLEUS ? V2 07 04489
4490 STX TEMP,B YES. SAVE X * 07 04490
4491 TXA * 07 04491
4492 JSR TBK,X TEST FCB(0) IN BACKGROUND * 07 04492
4493 ADD DIS * 07 04493
4494 JSR TBK,X TEST FCB(14) IN BACKGROUND * 07 04494
4495 LDX TEMP,B RESTORE X * 07 04495
4496 NUC1 CONT FG 07 04496
4497 VII1 CONT FG 07 04497
005432 015013 A 4498 SCH5 LDA 11,X * 07 04498
005433 146167 A 4499 SUB UNIT,B COMPARE WITH U * 07 04499
005434 001010 A 4500 JAZ SCHX EXIT ON FIND WITH X=FCB ADDRESS * 07 04500
005435 005442 R * * *
005436 076146 A 4501 STX PRLINK,B UPDATE PREVIOUS LINK * 07 04501
005437 035012 A 4502 LDX 10,X POINT X AT NEXT LINK * 07 04502
005440 001000 A 4503 JMP SCHLP LOOP TILL CHAIN EXHAUSTED * 07 04503
005441 005425 R * * *
005442 005041 A 4504 SCHX TXA FLAG FIND BY A.NE.0 (FCB ADDRESS) * 07 04504
4505 SCHY POPJ EXIT FG 07 04505
005443 105065 A * * *
4506 EJEC * 07 04506
4507 * ***** * 07 04507
4508 * * 07 04508
4509 * S H I F T A C C U M U L A T O R A C C ( S H A ) * 07 04509
4510 * * 07 04510
4511 * FUNCTION: TO SHIFT THE 4-WORD ACCUMULATOR ACC * 07 04511
4512 * * 07 04512
4513 * ENTRY: COUNT = + SHIFT RIGHT COUNT * 07 04513
4514 * = - SHIFT LEFT 1 * 07 04514
4515 * * 07 04515
4516 * EXIT : NO SPECIAL CONDITIONS * 07 04516
4517 * * 07 04517
005444 005024 A 4518 * ***** * 07 04518
4520 SHA TBX LOAD X AS CASE POINTER * 07 04520
4521 SHAL TNAX COUNT,SHA50 TEST DIRECTION OF SHIFT V2 07 04521
005445 015052 A * * *
005446 001004 A * * *
005447 005473 R * * *
005450 001010 A 4522 JAZ SHAX EXIT WHEN FINISHED * 07 04522
005451 005510 R * * *
005452 005311 A 4523 DAB DECREMENT SHIFT COUNT * 07 04523
005453 055052 A 4524 STA COUNT,X * 07 04524
4525 * ***** * 07 04525
4526 * RIGHT SHIFT * 07 04526
4527 * ***** * 07 04527
005454 025006 A 4528 LDB ACC+3,X * 07 04528
005455 015005 A 4529 LDA ACC+2,X * 07 04529
005456 004501 A 4530 LASR 1 * 07 04530
005457 065006 A 4531 STB ACC+3,X SHIFT ACC(3) * 07 04531
005460 025005 A 4532 LDB ACC+2,X * 07 04532
005461 015004 A 4533 LDA ACC+1,X * 07 04533
005462 004501 A 4534 LASR 1 * 07 04534
005463 065005 A 4535 STB ACC+2,X SHIFT ACC(2) * 07 04535
005464 025004 A 4536 LDB ACC+1,X * 07 04536
005465 015003 A 4537 LDA ACC,X * 07 04537

```



```

005466 004501 A 4538      LASR      1
005467 065004 A 4539      STB       ACC+1,X      SHIFT ACC(1)
005470 055003 A 4540      STA       ACC,X        SHIFT ACC(0)
005471 001000 R 4541      JMP       SHAL         LOOP TILL DONE
005472 005445 R
4542 *****
4543 * LEFT SHIFT *
4544 *****
005473 015003 A 4545      SHA50    LDA       ACC,X
005474 025004 A 4546      LDB       ACC+1,X
005475 004401 A 4547      LASL     1
005476 055003 A 4548      STA       ACC,X        SHIFT ACC(0)
005477 015004 A 4549      LDA       ACC+1,X
005500 025003 A 4550      LDB       ACC+2,X
005501 004401 A 4551      LASL     1
005502 055004 A 4552      STA       ACC+1,X      SHIFT ACC(1)
005503 015005 A 4553      LDA       ACC+2,X
005504 025006 A 4554      LDB       ACC+3,X
005505 004401 A 4555      LASL     1
005506 055005 A 4556      STA       ACC+2,X      SHIFT ACC(2)
005507 065006 A 4557      STB       ACC+3,X      SHIFT ACC(3)
005510 005042 A 4558      SHAX     TXB          RESTORE BASE REGISTER B
4559      POPJ          EXIT
005511 105065 A
4560      EJEC
4561      IFF       NUC
4562      GO TO   NUC1
4563      IFT     VII
4564      GO TO   VIII
4565 *****
4566 *
4567 *          T E S T   B A C K G R O U N D   A D D R E S S ( T B K )
4568 *
4569 * FUNCTION: TO TEST IF AN ADDRESS IS IN THE BACKGROUND
4570 *
4571 * ENTRY: A = TEST ADDRESS
4572 *
4573 * CALLING SEQUENCE: JSR TBK,X
4574 *
4575 * EXIT : IF OK, RETURN WITH A UNCHANGED
4576 *          OTHERWISE, SET UP A MEMORY PROTECT ERROR
4577 *
4578 *****
4579      SPAC
4580      TBK     SUB       V$LUP
4581      JAM     TBK10    ERROR IF A.LT.V$LUP
4582      ADD     V$LUP    RESTORE A
4583      SUB     V$LLUP
4584      JAZ     #+4
4585      JAF     TBK10    ERROR IF A.GT.V$LLUP
4586      ADD     V$LLUP    RESTORE A
4587      IJMP   0,X      RETURN IF OK
4588 *****
4589 * ERROR - CONSTRUCT MEMORY PROTECT VIOLATION *
4590 *****
4591      TBK10  LDX       V$LUP    POINT V AT 1ST BACKGROUND WORD
4592      LDA     TBKJMP
4593      STA     0,X
4594      TZA
4595      STA     1,X      STORE 'JMP 0' IN BACKGROUND
4596      LDB     V$CRS    POINT B AT STACK
4597      STX     PR,B     SET DEALOC ADDRESS TO 1ST BACKGROUND WORD
4598      DEALOC
4599      TBKJMP SET     BS9
4600      VIII   CONT
4601      NUC1   CONT
4602      EJEC
4603 *****
4604 *
4605 *          P R O C E S S   T   F O R M A T   D E S C R I P T O R ( T I D )
4606 *
4607 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTOR: TN
4608 *
4609 * ENTRY: DIRECT FROM FRS
4610 *          BFPT = CURRENT BUFFER CHARACTER POSITION(BASE 0)
4611 *          W = SPECIFIED BUFFER CHARACTER POSITION(BASE 1)
4612 *
4613 * EXIT : DIRECT TO FRS
4614 *          BFPT = W-1
4615 *          BFWPT = ALBF + BFPT/2
4616 *          BUFL(BIT 50) = 1 IF LOGICAL FILE PHYSICALLY POSITIONED BACKV2
4617 *
4618 * ERRORS: ERI IF W OUTSIDE LOGICAL RECORD
4619 *
4620 *****
005512 R 4622      TIN     EQU     *
005512 R 4623      TOUT    EQU     *
4625      MOVBA  BFPT,SAVE    SAVE CURRENT VALUE OF BUFFER CHAR PTR
005512 016026 A 4626      LDA     W,B          GET W
005513 056032 A 4627      DAR
005514 016170 A 4627      DAR          CONVERT FROM BASE 1 TO BASE 0
005515 005311 A 4627      STA     BFPT,B       STORE AS BUFFER CHARACTER POINTER
005516 056026 A 4628

```



```

005517 146032 A 4629 SUB SAVE,B
005520 001004 A 4630 JAN TIO10 TEST DIRECTION OF REPOSITION V2 07 04629
005521 005531 R 4631 ***** V2 07 04630
4632 * POSITION FORWARD * V2 07 04631
4633 ***** V2 07 04632
005522 016122 A 4634 LDA LRSZ,B YES 07 04633
005523 004241 A 4635 LRLA 1 GET LOGICAL RECORD BYTE COUNT 07 04634
005524 146170 A 4636 SUB M,B 07 04635
005525 001004 A 4637 JAN ER1 ERROR 1/ W OUTSIDE RECORD / 07 04636
005526 005157 R 4638 ***** 07 04637
005527 001000 A 4638 JMP TIO1P 07 04638
005530 005574 R 4639 ***** V2 07 04639
4640 * POSITION BACKWARD * V2 07 04640
4641 ***** V2 07 04641
005531 016026 A 4642 TIO10 LDA BFPT,B 07 04642
005532 004341 A 4643 LSRA 1 GET WORD POSITION 07 04643
005533 126027 A 4644 ADD ALBF,B GET ADDRESS 07 04644
005534 146020 A 4645 SUB APBF,B COMPARE WITH BUFFER START ADDRESS 07 04645
005535 001002 A 4646 JAP TIO20 EXIT IF STILL IN BUFFER 07 04646
005536 005561 R 4647 ***** 07 04647
4648 * REPOSITION BUFFER * 07 04648
4649 ***** 07 04649
005537 036010 A 4650 LDX ADFCB,B 07 04650
005540 015015 A 4651 LDA 13,X GET BUFFER RECORD NUMBER 07 04651
005541 146142 A 4652 SUB PBRC,B 07 04652
005542 056145 A 4653 STA PRECND,B BACK UP FILE 07 04653
4654 ADDBB ALBF,PBSZ,ALBF BUMP LOGICAL BUFFER ADDRESS 07 04654
005543 016027 A 4655 ***** 07 04655
005544 126143 A 4655 MOVBBB RWFL,SAVE+1 SAVE FLAG WORD 07 04655
005545 056027 A 4656 ***** 07 04656
005546 016154 A 4656 BT ARST+WR,TIO15 WRITE ? V2 07 04656
005547 056033 A 4657 ***** 07 04657
005550 006451 A 4658 ORA RBS YES. SET READ BEFORE WRITE FLAG V2 07 04658
005551 005554 R 4659 TIO15 STA RWFL,B REPOSITION FILE V2 07 04659
005552 110424 A 4660 ***** 07 04660
005553 056154 A 4660 ORA SCS RESTORE FLAG WORD V2 07 04661
005554 105025 A 4661 STA RWFL,B SET CLEAR SUPPRESS FLAG 07 04662
005555 005174 R 4662 TIO20 DABB ALBF,BFWPT INITIALIZE BUFFER WORD POINTER 07 04663
005556 016033 A 4663 ***** 07 04664
005557 110426 A 4664 LDA APBF,B 07 04665
005558 056154 A 4665 ADD PBSZ,B 07 04666
005559 056144 A 4666 SUB ALBF,B 07 04667
005560 056144 A 4667 STA PBRC,B REINITIALIZE PHYSICAL WORD COUNT 07 04668
005561 016027 A 4668 MOVBBB LRSZ,LRWC ALSO LOGICAL WORD COUNT 07 04669
005562 005311 A 4669 ***** 07 04670
005563 056025 A 4669 ZAB SAVE ALSO CHAR COUNTER 07 04671
005564 016020 A 4670 ***** 07 04672
005565 126143 A 4671 * POSITION LOOP * 07 04673
005566 146027 A 4672 ***** 07 04674
005567 056144 A 4673 TIO1P LDA BFPT,B 07 04675
005570 016122 A 4674 SUB SAVE,B 07 04676
005571 056123 A 4675 JAZ PRS85 EXIT TO FORMAT SCAN WHEN DONE 07 04677
005572 005001 A 4676 ***** 07 04678
005573 056032 A 4676 LDA SAVE,B BUMP CHAR COUNTER 07 04679
005574 016026 A 4677 INR SAVE,B 07 04680
005575 146032 A 4678 LRLA 15 WORD BOUNDARY ? 07 04681
005576 001010 A 4679 JAN TIO1P YES. GET NEXT BUFFER ADDRESS V2 07 04682
005577 001020 R 4680 ***** 07 04683
005578 001020 R 4680 PUSHJ GBA LOOP TILL DONE 07 04684
005579 001010 A 4681 ***** 07 04685
005580 016032 A 4681 ***** 07 04686
005581 046032 A 4682 ***** 07 04687
005582 004257 A 4683 ***** 07 04688
005583 001004 A 4684 ***** 07 04689
005584 005574 R 4685 ***** 07 04690
005585 105025 A 4686 ***** 07 04691
005586 001072 R 4687 ***** 07 04692
005587 001000 A 4688 ***** 07 04693
005588 005574 R 4689 ***** 07 04694
005589 005574 R 4690 ***** 07 04695
005590 005574 R 4691 ***** 07 04696
005591 005574 R 4692 ***** 07 04697
005592 005574 R 4693 ***** 07 04698
005593 005574 R 4694 ***** 07 04699
005594 005574 R 4695 ***** 07 04700
005595 005574 R 4696 ***** 07 04701
005596 005574 R 4697 ***** 07 04702
005597 005574 R 4698 ***** 07 04703
005598 005574 R 4699 ***** 07 04704
005599 005574 R 4700 ***** 07 04705
005600 005574 R 4701 ***** 07 04706
005601 005574 R 4702 ***** 07 04707
005602 005574 R 4703 ***** 07 04708
005603 005574 R 4704 ***** 07 04709
005604 005574 R 4705 ***** 07 04710
005605 005574 R 4706 ***** 07 04711
005606 005574 R 4707 ***** 07 04712
005607 005574 R 4708 ***** 07 04713
005608 005574 R 4709 ***** 07 04714
005609 005574 R 4710 ***** 07 04715
005610 005574 R 4711 ***** 07 04716
005611 016154 A 4697 TRM LDA RWFL,B SET TERMINATE FLAG V2 07 04697
005612 110425 A 4698 ORA TRS 07 04698

```



```

005613 056154 A 4699      STA      RWFL,B
005614 006441 A 4700      BT       ARST+LF,TRM20      TEST LOGICAL FILE
005615 005641 R
4701 *****
4702 * LOGICAL FILE *
4703 *****
005616 006440 A 4704      BT       ARST+RM,TRM20      RMD ?
005617 005641 R
005620 006451 A 4705      BT       ARST+WR,TRM10     YES. WRITE ?
005621 005625 R
005622 056154 A 4706      STA      RWFL,B
4707      PUSHJ   RCL              YES. RECYCLE LOGICAL BUFFER
005623 105025 A
005624 004757 R
005625 036010 A 4708 TRM10  LDX      ADFCB,B          POINT X AT FCB
4709      MOVBA  LRSZ,0          LOAD FCB(0) WITH LOGICAL RECORD SIZE
005626 016122 A
005627 055000 A
005630 015002 A 4710      LDA      R,X              GET ACCESS MODE FROM FCB
005631 007401 A 4711      SDF
005632 006410 A 4712      BT       ASET+8,*+3       SET OVFL IF SEQUENTIAL
005633 005635 R
005634 007400 A 4713      RDF
005635 016160 A 4714      LDA      SVRECNO,B        RESTORE RECORD NUMBER IF DIRECT
005636 003001 A 4715      XDF      TRMI             OTHERWISE UPDATE
005637 005700 R
005640 055003 A 4716 TRM20  STA      R,X              STORE IN FCB
4717      LDA      CEX
4718      PUSHF
005642 036016 A
005643 035000 A
005644 005344 A
005645 055000 A
005646 005041 A
005647 036016 A
005650 055000 A
4719      TRAB   RWFL,LF,TRM30  LOGICAL ?
005651 016154 A
005652 006441 A
005653 005661 R
005654 006400 A 4720      BT       ASET+RM,CAN      YES. EXIT IF RMD
005655 000065 R
005656 036010 A 4721      LDX      ADFCB,B
4722      MOVBA  PBSZ,0          IF NON-RMD, SET FCB(0) = PBSZ
005657 016143 A
005660 055000 A
4723 TRM30  TRAB   RWFL,WR,CAN  EXIT ON READ
005661 016154 A
005662 006451 A
005663 000065 R
005664 006412 A 4724      BT       EC,CAN          EXIT FOR ENCODE/DECODE
005665 000065 R
005666 010464 A 4725      LDA      CID
4726      PUSHF
005667 036016 A
005670 035000 A
005671 005344 A
005672 055000 A
005673 005041 A
005674 036016 A
005675 055000 A
005676 001000 A 4727      JMP      CAN              EXIT TO V$SORTID
005677 000065 R
005700 016121 A 4728 TRMI   LDA      LRECNO,B
4729      EJECT
4730 *****
4731 *
4732 * UNFORMATTED INPUT/OUTPUT (UID) *
4733 *
4734 * FUNCTION: TO PROCESS UNFORMATTED I/O CALLS *
4735 *
4736 * ENTRY: ITEMAD = LIST ITEM ADDRESS *
4737 *          BFWPT = ADDRESS OF DATA WORD IN BUFFER *
4738 *
4739 * EXIT : TO V$SORTID THRU GNL *
4740 *
4741 *****
4742 *****
4743 *****
4744 * TRANSFER LOOP *
4745 *****
4746 UID   PUSHJ   GNL          GET NEXT LIST ITEM ADDRESS/EXIT
005701 105025 A
005702 001436 R
4747      PUSHJ   GRA          GET BUFFER ADDRESS
005703 105025 A
005704 001072 R
4748      TSAB   RWFL,WR,UID4  TEST INPUT OR OUTPUT
005705 016154 A
005706 006411 A
005707 005716 R
4749 *****
4750 * INPUT *
4751 *****

```

```

V2 07 04699
V2 07 04700
07 04701
07 04702
07 04703
V2 07 04704
V2 07 04705
07 04706
V2 07 04707
07 04708
07 04709
07 04710
07 04711
07 04712
07 04713
07 04714
07 04715
07 04716
07 04717
07 04718
V2 07 04719
V2 07 04720
V2 07 04721
V2 07 04722
D.1 07 04723
PD 07 04724
07 04725
07 04726
07 04727
07 04728
07 04729
07 04730
07 04731
07 04732
07 04733
07 04734
07 04735
07 04736
07 04737
07 04738
07 04739
07 04740
07 04741
07 04742
07 04743
07 04744
07 04745
V2 07 04746
V2 07 04747
V2 07 04748
07 04749
07 04750
07 04751

```



```

005710 036025 A 4752 LDX BFWPT,B POINT X AT DATA WORD IN BUFFER 07 04752
005711 015000 A 4753 LDA 0,X GET DATA WORD 07 04753
005712 036113 A 4754 LDX ITEMAD,B POINT X AT LIST ITEM 07 04754
005713 055000 A 4755 STA 0,X STORE INPUT DATA WORD IN LIST ITEM 07 04755
005714 001000 A 4756 JMP UID LOOP UNTIL DONE 07 04756
005715 005701 R
4757 ***** 07 04757
4758 * OUTPUT * 07 04758
4759 ***** 07 04759
005716 036113 A 4760 UID4 LDX ITEMAD,B POINT X AT LIST ITEM 07 04760
005717 015000 A 4761 LDA 0,X GET DATA WORD 07 04761
005720 036025 A 4762 LDX BFWPT,B POINT X AT DATA WORD IN BUFFER 07 04762
005721 055000 A 4763 STA 0,X STORE DATA WORD IN OUTPUT BUFFER 07 04763
005722 001000 A 4764 JMP UID LOOP UNTIL DONE 07 04764
005723 005701 R
4765 EJEC 07 04765
4766 ***** 07 04766
4767 * 07 04767
4768 * P R O C E S S X F O R M A T D E S C R I P T O R ( X I D ) * 07 04768
4769 * 07 04769
4770 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTOR: NX 07 04770
4771 * 07 04771
4772 * ENTRY: DIRECT FROM FRS 07 04772
4773 * N = FIELD WIDTH 07 04773
4774 * 07 04774
4775 * EXIT : TO FRS 07 04775
4776 * 07 04776
4777 ***** 07 04777
005724 R 4779 XIN EQU * 07 04779
005724 R 4780 XOUT EQU * 07 04780
4782 MOVBAB BLNK1,BCHAR LOAD BLANK AS REPEAT CHARACTER V2 07 04782
005724 016202 A
005725 056030 A
4783 MOVBAB N,COUNT SET REPEAT COUNT TO N 07 04783
005726 016125 A
005727 056052 A
4784 MOVBAB ABSOB,ASOB SET SOB TO BUFFER 07 04784
005730 016002 A
005731 056021 A
4785 PUSHJ RCH REPEAT CHARACTER I/O N TIMES V2 07 04785
005732 105025 A
005733 004715 R
005734 001000 A
005735 000430 R
4786 JMP FRS5 RESUME FORMAT SCAN 07 04786
4787 EJEC 07 04787
4788 ***** 07 04788
4789 * 07 04789
4790 * P R O C E S S Z D E S C R I P T O R ( Z I N / Z O U T ) * 07 04790
4791 * 07 04791
4792 * FUNCTION: TO PROCESS THE Z FORMAT DESCRIPTOR: RZM 07 04792
4793 * 07 04793
4794 * ENTRY: DIRECT FROM FRS 07 04794
4795 * WT = N TOTAL FIELD WIDTH 07 04795
4796 * IIBSZ = BYTE COUNT OF SINGLE LIST ITEM 07 04796
4797 * ITEMAD = ADDRESS OF LIST ITEM 07 04797
4798 * RWFL(BIT WR) = 0 READ 07 04798
4799 * = 1 WRITE 07 04799
4800 * 07 04800
4801 * EXIT: INPUT : DIRECT TO FRS 07 04801
4802 * OUTPUT: DIRECT TO FRS THRU OBC 07 04802
4803 * 07 04803
4804 ***** 07 04804
005736 R 4806 ZIN EQU * 07 04806
005736 R 4807 ZOUT EQU * 07 04807
4809 ZAB AIBUF-1 SET LIST ITEM SCB(0)=0 (BYTE COUNT) 07 04809
005736 005001 A
005737 056107 A
4810 MOVBAB ITEMAD,AIBUF SET LIST ITEM SCB(1)=ITEM ADDRESS 07 04810
005740 016113 A
005741 056110 A
005742 016171 A
005743 005111 A
005744 004301 A
005745 146101 A
005746 056052 A
4811 LDA NT,B 07 04811
4812 IAR 07 04812
4813 ASRA 1 (A)=BYTES TO PROCESS 07 04813
4814 SUB IIBSZ,B 07 04814
4815 STA COUNT,B EXCESS BYTES 07 04815
4816 MOVBAB BLNK1,BCHAR SLEN THRU W/2-IIBSZ CHAR 07 04816
005747 016202 A
005750 056030 A
4817 PUSHJ RCH 07 04817
005751 105025 A
005752 004715 R
4818 TSAB RWFL,HR,ZID4 I/O TEST 07 04818
005753 016154 A
005754 006411 A
005755 006010 R
4820 * INPUT 07 04820
4821 ZID1 PUSHJ OBC GET BUFFER CHARACTER 07 04821
005756 105025 A
005757 000070 R
4822 PUSHJ ZID6 INPUT CHARACTER TEST 07 04822
005760 105025 A
005761 006031 R
4823 MOVBAB BCHAR,ICAR 07 04823

```



```

005762 016030 A
005763 056111 A
4824 TZAB WT,ZI02 FIELD WIDTH EXHAUSTED 07 04824
005764 016171 A
005765 001010 A
005766 005777 R
4825 PUSHJ CBC GET NEXT CHARACTER 07 04825
005767 105025 A
005770 000070 R
4826 PUSHJ ZI06 INPUT CHARACTER TEST 07 04826
005771 105025 A
005772 006031 R
005773 016111 A 4827 LDA ICHAR,B APPEND RT HALF 07 04827
005774 004204 A 4828 ASLA 4 07 04828
005775 126030 A 4829 ADD BCHAR,B 07 04829
005776 056111 A 4830 STA ICHAR,B 07 04830
4831 ZI02 MOVBAB AISC,BASCB SET SCB TO LIST ITEM 07 04831
005777 016013 A
006000 056021 A
4832 PUSHJ PCH PUT CHARACTER IN ITEM 07 04832
006001 105025 A
006002 003276 R
4833 TNZAB WT,ZI01 LOOP UNTILL FIELD WIDTH EXHAUSTED 07 04833
006003 016171 A
006004 001016 A
006005 005756 R
006006 001000 A 4834 JMP FR365 TO FORMAT SCAN 07 04834
006007 001003 R
4836 * OUTPUT
4837 ZI04 MOVBAB AISC,BASCB SET SCB TO LIST ITEM 07 04836
006010 016013 A
006011 056021 A
4838 PUSHJ ICC INPUT CHARACTER FROM LIST ITEM 07 04838
006012 105025 A
006013 001612 R
4839 PUSHJ ZI08 OUTPUT CHARACTER 07 04839
006014 105025 A
006015 006054 R
006016 016111 A 4840 LDA ICHAR,B 07 04840
006017 004304 A 4841 ASRA 4 07 04841
006020 016111 A 4842 LDA ICHAR,B 07 04842
006021 006150 A 4843 ANAI 0177 GET RT HALF 07 04843
006022 000177 A
4844 PUSHJ ZI08 OUTPUT CHARACTER 07 04844
006023 105025 A
006024 006054 R
4845 PUSHJ DCB OUTPUT CHARACTER TO BUFFER 07 04845
006025 105025 A
006026 002441 R
006027 001000 A 4846 JMP ZI04 LOOP UNTILL DONE 07 04846
006030 006010 R
4848 * TEST INPUT CHARACTER
4849 ZI06 LDA BCHAR,B 07 04848
006032 006140 A 4850 SUBI '0' 07 04849
006033 000260 A
006034 001004 A 4851 JAN ER3 07 04851
006035 005155 R
006036 056030 A 4852 STA BCHAR,B 07 04852
006037 140471 A 4853 SUB TEN 07 04853
006040 001004 A 4854 JAN ZI07 0-9 07 04854
006041 006053 R
006042 140467 A 4855 SUB SEVEN 07 04855
006043 001004 A 4856 JAN ER3 07 04856
006044 005155 R
006045 140467 A 4857 SUB SEVEN 07 04857
006046 001002 A 4858 JAP FR3 07 04858
006047 005155 R
006050 006120 A 4859 ADDI 020 07 04859
006051 000020 A
006052 056030 A 4860 STA BCHAR,B 07 04860
4861 ZI07 POPJ EXIT 07 04861
006053 105065 A
4863 * GENERATE CHARACTER
4864 ZI08 LDA ICHAR,B 07 04863
006054 016111 A 4865 ADDI '0' 07 04864
006055 006120 A
006056 000260 A
006057 056111 A 4866 STA ICHAR,B 07 04866
006060 006140 A 4867 SUBI 0272 07 04867
006061 000272 A
006062 001004 A 4868 JAN ZI09 07 04868
006063 006068 R
006064 120467 A 4869 ADD SEVEN 07 04869
006065 056111 A 4870 STA ICHAR,B 07 04870
4871 ZI09 POPJ EXIT 07 04871
006066 105065 A
4872 EJEC 07 04872
4873 ***** 07 04873
4874 * 07 04874
4875 * V $ R E R R D A T A B L O C K V2* 07 04875
4876 * 07 04876
4877 ***** 07 04877
006067 R 4879 BASE EQU * BASE ADDRESS OF DATA BLOCK 07 04879
4880 IFF NUC FG 07 04880
    
```



4881	GOTO	HUC1			FG	07	04881
4882	IFT	VII			FG	07	04882
4883	GOTO	VIII			FG	07	04883
4884	VOPSTP	BSS	1	OP STACK POINTER	FG	07	04884
4885	VAACC	PZE	VACC	ADDRESS OF ACCUMULATOR ACC		07	04885
4886	VABSCB	PZE	VBSCB	ADDRESS OF BUFFER SCB		07	04886
4887	VACC	BSS	4	4-WORD ACCUMULATOR		07	04887
4888	VACHB	PZE	VCHB	ADDRESS OF DECIMAL DIGIT ARRAY		07	04888
4889	VADFCB	BSS	1	DCB/FCB ADDRESS		07	04889
4890	VAFSCB	PZE	VFSCB	ADDRESS OF FORMAT SCB		07	04890
4891	VAGPAR	PZE	VGDRP-1	ADDRESS OF '*' GROUP BLOCK		07	04891
4892	VAISCB	PZE	VISCB	ADDRESS OF LIST ITEM SCB		07	04892
4893	VALDC	BSS	1	ALDC ENTRY FLAG	V2	07	04893
4894	VANPOJ	DATA	0	ADDRESS OF V\$FORTIO POP/JUMP	V2	07	04894
4895	VANRB	BSS	1	ADDRESS OF V\$FORTIO DATA BLOCK	V2	07	04895
4896	VADPST	PZE	VOPSTK+STKSZ	ADDRESS OF OP STACK	FG	07	04896
4897	VAPBF	BSS	1	ADDRESS OF PHYSICAL BUFFER		07	04897
4898	VASCB	BSS	1	SCAN BLOCK ADDRESS		07	04898
4899	VASFL	BSS	1	'*' FLAG		07	04899
4900	VASYSB	PZE	VSYSDC	ADDRESS OF SYSTEM DCB		07	04900
4901	VBEXP	BSS	1	BINARY EXPONENT		07	04901
4902	VBFWPT	BSS	1	BUFFER WORD POINTER		07	04902
4903	VBSCB	BSS	4	BUFFER SCB		07	04903
4904	VCHB	BSS	14	DECIMAL DIGIT ARRAY		07	04904
4905	VCHBPT	BSS	1	CHB ARRAY POINTER		07	04905
4906	VCHNHD	BSS	1	FCB CHAIN HEADER		07	04906
4907	VCOUN	BSS	1	COUNTER		07	04907
4908	VCVFL	BSS	1	CHARACTER VALIDITY FLAGS		07	04908
4909	VD	BSS	1	FRACTIONAL FIELD WIDTH		07	04909
4910	VDEXP	BSS	1	DECIMAL EXPONENT		07	04910
4911	VDT	BSS	1	WORKING FRACTIONAL FIELD WIDTH		07	04911
4912	VEDEXP	BSS	1	EXPLICIT DECIMAL EXPONENT		07	04912
4913	VERN	DATA	0	ERROR NUMBER		07	04913
4914	VFDLKY	BSS	1	FIELD DESCRIPTOR LETTER KEY		07	04914
4915	VFSCB	BSS	4	FORMAT STRING SCB		07	04915
4916	VGDRP	BSS	9	'*' GROUP DYNAMIC REPEAT COUNT		07	04916
4917	VIDEXP	BSS	1	IMPLICIT DECIMAL EXPONENT		07	04917
4918	VIFW	BSS	1	INTEGER FIELD WIDTH		07	04918
4919	VIIISZ	BSS	1	INDIVIDUAL ITEM BYTE SIZE		07	04919
4920	VIIISZ	DATA	1	INDIVIDUAL ITEM WORD SIZE		07	04920
4921	VINFL	BSS	1	INITIAL ENTRY FLAG	V2	07	04921
4922	VIQCON	BSS	1	I/O CONTROL WORD		07	04922
4923	VIOLNK	BSS	1	IOLINK CONTROL WORD		07	04923
4924	VIESTA	DATA	0	I/O STATUS		07	04924
4925	VISCB	BSS	4	LIST ITEM SCB		07	04925
4926	VITEMA	BSS	1	ADDRESS OF LIST ITEM		07	04926
4927	VITEMW	BSS	1	COUNT OF WORDS REMAINING IN ITEM		07	04927
4928	VITMIN	BSS	1	LIST ITEM WORD INCREMENT		07	04928
4929	VITMOD	BSS	1	LIST ITEM MODE		07	04929
4930	VLISTF	BSS	1	LIST DATA XFER FLAG		07	04930
4931	VLNKC	BSS	1	FCB CHAIN LINK COUNT		07	04931
4932	VLRECN	BSS	1	LOGICAL RECORD NUMBER		07	04932
4933	VLRSSZ	BSS	1	LOGICAL RECORD SIZE		07	04933
4934	VLRWC	BSS	1	LOGICAL RECORD REMAINING WORD COUNT		07	04934
4935	VMOV	BSS	1	MULTIPLY OVERFLOW SWITCH		07	04935
4936	VN	BSS	1	H/T/X FIELD WIDTH		07	04936
4937	VNFF	BSS	1	NUMERIC FORMAT FIELD		07	04937
4938	VIII	CONT			FG	07	04938
4939	VOPSTK	BSS	STKSZ	OP STACK		07	04939
4940	VPARLV	BSS	1	FORMAT '*' GROUP LEVEL COUNT	FG	07	04940
4941	IFT	VII			FG	07	04941
4942	GOTO	VIII			FG	07	04942
4943	VPBRC	BSS	1	PHYSICAL BUFFER RECORD COUNT		07	04943
4944	VPBSZ	BSS	1	PHYSICAL BUFFER SIZE		07	04944
4945	VPBWC	BSS	1	PHYSICAL BUFFER REMAINING WORD COUNT		07	04945
4946	VPRECN	BSS	1	PHYSICAL RECORD NUMBER		07	04946
4947	VPRLIN	BSS	1	PREVIOUS LINK OF FCB CHAIN		07	04947
4948	VPTFL	BSS	1	'.' POINT FLAG		07	04948
4949	VQFL	BSS	1	QUOTE FLAG		07	04949
4950	VRETUR	BSS	1	RETURN ADDRESS		07	04950
4951	VRWFL	BSS	1	FLAG WORD	V2	07	04951
4952	VS	BSS	1	SCALE FACTOR		07	04952
4953	VSCF	BSS	1	SCALE FACTOR FLAG		07	04953
4954	VSGFL	BSS	1	'-' SIGN FLAG		07	04954
4955	VSVREC	BSS	1	SAVE RECORD NO		07	04955
4956	VSYSDC	DATA	0,0,0	SYSTEM DCB		07	04956
4957	VTEMP	BSS	1	TEMP STORE		07	04957
4958	VTEMP1	BSS	1	TEMP STORE		07	04958
4959	VTERM	BSS	1	PRODUCT TERM		07	04959
4960	VUNIT	BSS	1	I/O UNIT NUMBER		07	04960
4961	VW	BSS	1	FIELD WIDTH		07	04961
4962	VWT	BSS	1	WORKING VALUE OF W		07	04962
4963	VXFFL	DATA	0	PARAMETER XFER ENABLE FLAG		07	04963
4964	VXFL	BSS	1	EXPONENT FIELD NON-BLANK FLAG		07	04964
4965	VXFW	BSS	1	EXPONENT FIELD WIDTH		07	04965
4966	VXSG	BSS	1	EXPONENT SIGN FLAG		07	04966
4967	VZFW	BSS	1	LEADING ZERO FIELD WIDTH		07	04967
4968		DATA	0260	ASCII ZERO	V2	07	04968
4969		DATA	14	DECIMAL 14	V2	07	04969
4970		DATA	120	DECIMAL 120	V2	07	04970
4971		DATA	0240	ASCII BLANK	V2	07	04971
4972		DATA		ASCII BLANK WORD	V2	07	04972
4973	VIII	CONT			FG	07	04973



ENTRY NAMES	006067 R	4974 NUC1	CONT	*	END OF DATA BLOCK
		4975 VZZZ	EQU		
		4976	END		
004633 R VSRER1	000000	R V\$RERF	000000	A V\$RERN	004633 R V\$RERR
EXTERNAL NAMES					
004317 E BIFCB	004320	E BDFCB	004322	E GDFCB	004316 E LDFCB
004315 E PIFCB	004323	E PDFCB	004313	E SIFCB	004321 E SSFCB
000000 E V\$EXEC					
SYMBOLS					
000001 A AACC	000002	A ABSC2	000003	A ACC	000007 A ACHB
000010 A ADFCB	000011	A AFSCB	000012	A AGPAR	000110 A AIBUF
000000 R AIN	000016	R AIDL1	000053	R AIDL2	000013 A AISCB
000000 A AL	000027	A ALBF	000014	A ALDC	000015 A ANPOJ
000016 A ANR3	000017	A ADPSTK	000000	R ADUT	000020 A APBF
000040 A ARST	000021	A ASCB	000000	A ASET	000022 A ASFL
000023 A ASYSDC	000177	A AZER	000002	A B	000000 A B0
000001 A B1	000014	A B12	000015	A B13	000016 A B14
000017 A B15	000002	A B2	000003	A B3	000004 A B4
000005 A B5	000006	A B6	006067	R BASE	000030 A BCHAR
000031 A BCDE	000201	A BD120	000200	A BD14	000024 A BEXP
000010 A BF	000400	A BFA	000026	A BFPT	000451 A BFR
000431 A BFS	000025	A BFWPT	004317	E BIFCB	000001 A BL
000202 A BLNK1	000203	A BLNK2	000472	A BM17	000473 A BM37
000474 A BM77	004320	E BDFCB	000001	A BR	000441 A BR0
000442 A BR1	000454	A BR11	000455	A BR12	000457 A BR14
000460 A BR15	000443	A BR2	000444	A BR3	000445 A BR4
000446 A BR5	000447	A BR6	000450	A BR7	000451 A BR8
000421 A BS0	000422	A BS1	000433	A BS10	000434 A BS11
000435 A BS12	000437	A BS14	000440	A BS15	000423 A BS2
000424 A BS3	000425	A BS4	000426	A BS5	000430 A BS7
000431 A BS8	000432	A BS9	000026	A BSCE	000430 A BXBAS
000065 R CAN	000070	R CAN1	000070	R CBC	000077 R CBC4
000111 R CBC6	000467	A CBK	000020	A CDC	000421 A CEF
000021 A CEN	000421	A CER	000422	A CEX	000032 A CHB
000050 A CHEPT	000051	A CHNHDR	000464	A CID	000116 R CLB
000125 R CLB4	000137	R CLB8	000141	R CLBLP	000151 R CLBX
000152 R CLS	000202	R CLS10	000212	R CLS15	000214 R CLS20
000243 R CLS30	000002	A CM	000016	A COPV	000052 A COMNT
000022 A CRA	000423	A CRB	000471	A CRD	000470 A CRN
000465 A CTR	000005	A CTRV	000053	A CVFL	000420 A CXC
000466 A CXF	000054	A D	000200	R D10	000472 A D15
000425 A D16	000013	A DA	000300	R DEF	000305 R DEF4
000310 R DEF8	000335	R DED10	000333	R DED5	000005 A DEXP
003325 R DIN	000313	R DOUT	000006	A DT	000012 A EC
000057 A EDEXP	000424	A EIGHT	003325	R EIN	000313 R EDUT
005157 R ER1	005156	R ER2	005155	R ER3	005154 R ER4
000060 A ERN	000064	A FCHAR	000065	A FCDDE	000061 A FDLKEY
003325 R FIN	000465	A FIVE	000015	A FLF	000062 A FMPT
000423 A FOUR	000364	R FOUT	000016	A FPD	000457 A FPDR
000437 A FPOS	000017	A FRB	000440	A FRES	000014 A FRM
000063 A FRMT	000062	A FRPT	000077	R FRS	000442 R FRS10
000500 R FRS15	000552	R FRS19	000413	R FRS2	000533 R FRS20
000563 R FRS25	000611	R FRS30	000624	R FRS35	000640 R FRS40
000651 R FRS45	000664	R FRS46	000707	R FRS47	000400 R FRS5
000722 R FRS50	000766	R FRS55	000770	R FRS60	001000 R FRS65
001012 R FRS70	001016	R FRS75	001000	R FRS85	001031 R FRS90
001044 R FRSJT	000627	R FRSL1	000002	A FSCB	001072 R GBA
001103 R GBA50	001113	R GBA55	001124	R GBA60	001132 R GBA70
001141 R GBA80	000066	A GDRPC	000007	A GF	000071 A GFRPT
000430 A GFS	003325	R GIN	001147	R GNI	001304 R GNI10
001166 R GNI2	001331	R GNI20	001374	R GNI25	001403 R GNI30
001173 R GNI4	001420	R GNI50	001227	R GNI8	001252 R GNI9
001300 R GNI9A	001315	R GNIL1	001423	R GNIL2	001436 R GNL
001465 R GNL2	004322	E GDFCB	001471	R GUUT	000074 A GSRPC
001521 R HIN	001566	R HID10	001600	R HID15	001532 R HID2
001553 R HID4	001556	R HID6	001521	R HOUT	001612 R IOC
001643 R ICCCT	001665	R ICCCT1	001633	R ICCLP	000111 A ICHAD
000077 A IDEXP	001711	R IFF	001710	R IFFL	001733 R IFFLI
000100 A IFW	000101	A IIBS7	003325	R IIN	000102 A IIN2
000000 A IN	001745	R INF	000103	A INFL	001747 R INFLP
000447 A INR	000427	A INS	000104	A IOCONT	000105 A IOLNK
000106 A IOSTAT	001754	R IOUT	000107	A ISCS	000113 A ITEMAD
000114 A ITEMWC	000115	A ITMINC	000110	R ITMODE	001764 R IXN
002062 R IXN10	002071	R IXN15	002125	R IXN18	002100 R IXN20
002144 R IXN25	002157	R IXN30	002022	R IXN4	002041 R IXN5
002161 R IXN50	002172	R IXN52	002205	R IXN53	002212 R IXN55
002224 R IXN57	002225	R IXN58	002046	R IXN6	002234 R IXN60
002056 R IXN8	001777	R IXNL1	002104	R IXNL2	002217 R IXNL3
000537 R IXR	000300	A LC	000001	A LF	000422 A LFS
000123 A LGDV	000462	A LHW	002251	R LIN	002275 R LINK
000117 A LISTFL	000120	A LNKONT	000244	A LDC	004316 E LDFCB
002324 R LDU4	002303	R LDUT	000003	A LP	000131 A LRECD
003316 R LRLA9	000122	A LRSZ	000123	A LRWC	001710 R LORAS
002326 R M10	002344	R M104	002370	R M10X	000040 A MAP
000004 A MN	000124	A MOV	000420	A MT	000135 A N
000126 A NFF	000470	A NINE	000005	A NM	002371 R NRH
002415 R NRM4	002372	R NRML	002437	R NRMX	000000 R NUC
002441 R DCB	002453	R DCB4	002461	R DCB6	000421 A ONE
002471 R ONF	002535	R ONF20	002566	R ONF30	002634 R ONF40
002521 R ONF5	002645	R ONF50	002656	R ONF52	002670 R ONF55
002713 R ONF60	002541	R ONFL1	002607	R ONFL2	002717 R OPN
003067 R OPN30	002752	R OPN4	000127	A OPSTK	000000 R OPSTKP

FG 07 04974  
07 04975  
07 04976



```

000141 A PARLV 003101 R PAX 003123 R PAX10 003137 R PAX15
003144 R PAX16 003175 R PAX20 003222 R PAX30 003231 R PAX33
003236 R PAX50 003241 R PAX55 003246 R PAX70 003273 R PAXTAB
000142 A PERC 000143 A PBSZ 000144 A PBWC 003276 R PCH
004313 E PIFCB 000006 A PL 003501 R PNI18 003513 R PNI19
003521 R PNI20 003410 R PNI4 003530 R PNI50 003553 R PNI60
003570 R PNI62 003604 R PNI64 003621 R PNI66 003452 R PNI8
003360 R PNIL1 003374 R PNIL1X 003536 R PNIL2 000002 A PD
004323 E PDFCB 003626 R PDJ 000443 A PDR 000423 A PDS
000003 A PR 003633 R PRD 003667 R PRD1 003706 R PRD2
003713 R PRD4 000145 A PRECND 000146 A PRLINK 003720 R PRU
003733 R PRU0 003737 R PRU05 003774 R PRU1 004110 R PRU10
004154 R PRU15 004011 R PRU2 004166 R PRU20 004211 R PRU25
004020 R PRU3 004222 R PRU30 004251 R PRU35 004023 R PRU4
004276 R PRU40 004043 R PRU5 004312 R PRU50 004064 R PRU6
004313 R PRUAS1 004325 R PRUDTB 004334 R PRUDE 004324 R PRUGT
004156 R PRUL1 004344 R PRW 004366 R PRW0 004355 R PRW05
004372 R PRW1 004434 R PRW10 004402 R PRW2 004414 R PRW4
004424 R PRW6 004445 R PRX 000007 A PS 004465 R PSB
004514 R PSBX 004515 R PSJ 000010 A PT 000147 A PTFL
004554 R PXF 004617 R PXF10 004624 R PXF20 004567 R PXF5
004625 R PXFSZT 000150 A QFL 000011 A QT 000125 A R
000003 A RB 004644 R RBE15 004667 R RBE25 004671 R RBE30
004676 R RBEJT 004715 R RBEJTE 000424 A RES 004715 R RCH
004745 R RCH10 004753 R RCH15 004722 R RCH2 004741 R RCH5
004757 R RCL 004771 R RCL10 005000 R RCL15 004764 R RCL5
005013 R RCP 005053 R RCP15 005071 R RCP20 005076 R RCP25
005025 R RCP3 005135 R RCP35 005140 R RCP40 005031 R RCP5
005147 R RCP50 000151 A RETURN 005174 R RFL 005214 R RFL10
005257 R RFL20 005266 R RFL30 005274 R RFL40 005210 R RFL5
005275 R RFL50 000463 A RHW 000000 A RM 000421 A RMS
005302 R RNA 005302 R RND 005350 R RND10 005321 R RND5
005335 R RNDL 005353 R RNDX 002170 R RDF 000012 A ROPSTP
000012 A RP 005354 R RP 005367 R RPB10 005376 R RPB11
005400 R RPB12 005406 R RPB15 005411 R RPB20 000154 R RWFL
000153 A S 000032 A SAVE 000005 A SC 000156 A SCF
005415 R SCH 005432 R SCH5 005425 R SCHLP 005442 R SCHX
005443 R SCHY 000446 A SCR 000426 A SCS 000467 A SEVEN
000157 A SGFL 000014 A SH 005444 R SHA 005473 R SHA50
005445 R SHAL 005510 R SHAX 004313 E SIFCB 000466 A SIX
000013 A SL 001615 R SDF 004321 E SSFCB 000012 A STKSZ
000160 A SVRECND 000162 A TENSBF 000161 A SYSDCB 000164 A TEMP
000165 A TEMPI 000471 A TEN 000166 A TERM 000464 A THREE
005512 R TIN 005531 R TID10 005554 R TID15 005561 R TID20
005574 R TIDL 005512 R TOUT 000004 A TR 005611 R TRM
005625 R TRM10 005641 R TRM20 005661 R TRM30 005700 R TRMI
000425 A TRS 000422 A TWO 005701 R UID 005716 R UID4
000167 A UNIT 000414 A V$BVN 000301 A V$CPL 000302 A V$CRS
000355 A V$DSTB 000000 E V$EXEC 000317 A V$LLUP 000316 A V$LUP
000400 A V$LUT1 000401 A V$LUT2 000402 A V$LUT3 004633 R V$RER1
000000 R V$RERF 000000 A V$RERN 004633 R V$RERR 000000 R V$RERS
000334 A V$ST0 000335 A V$ST1 000336 A V$ST2 000337 A V$ST3
000000 A VII 000004 A VORTEX 006067 R VZZZ 000170 A W
000001 A WCS 000011 A WR 000452 A WRR 000432 A WRS
000171 A WT 000001 A X 000172 A XFFL 000173 A XFL
000174 A XFW 005724 R XIN 005724 R XOUT 000175 A XSG
000177 A YYY 000420 A ZERO 000176 A ZFW 005736 R ZIN
005756 R ZID1 005777 R ZID2 006010 R ZID4 006001 R ZID6
006053 R ZID7 006054 R ZID8 006006 R ZID9 005736 R ZOUT
000204 A ZZZ

```

0 ERRORS ASSEMBLY COMPLETE

494	AACC	2199	3063							
496	ABSCB	871	1384	4084	4784					
498	ACC	1014	1016	1017	1019	1020	1022	1023	1025	1371
		1372	1373	1374	1599	1622	1626	1628	1644	1647
		1657	1659	1662	1663	1666	1672	1676	1677	1678
		1705	1709	1713	1717	2321	2331	2333	2334	2336
		2337	2339	2340	2342	2365	2369	2369	2370	2370
		2371	2371	2372	2377	2378	2380	2381	2382	2384
		2385	2386	2388	2389	2947	2948	2949	2951	2965
		2966	2973	2976	2982	2985	2994	2999	3000	3003
		3007	3010	3011	3013	3015	3020	3023	3024	3026
		3028	3029	3031	3033	3034	3038	3039	3039	3040
		3040	3041	3041	3044	3042	3050	3078	3079	3090
		3091	3093	3094	3099	3100	3107	3108	4375	4528
		4529	4531	4532	4533	4535	4536	4537	4539	4540
		4545	4546	4548	4549	4550	4552	4553	4554	4556
		4557								
500	ACHB	1741	1748	2495	2507	2540	4372	4379	4397	
502	ADFCB	954	964	984	2675	2676	2693	2712	2719	2735
		2781	2797	2810	2821	2831	3272	3274	3336	3337
		3430	3560	3506	3508	3627	3676	4194	4205	4227
		4304	4338	4426	4650	4708	4721			
504	AFSCB	1850	1869	1876	2034					
506	AGPAR	1176	1222	1240						
508	AIBUF	707	708	4809	4810					
704	AIN	1431								
719	AIDL1	723								
739	AIDL2	715	743							
509	AISCB	721	739	4831	4837					
175	AL	1213	1229	2106						



E.2 VORTEX LISTING

VSRERF

PROGRAM PAGE 70

LISTING PAGE ( 863 )

511	ALBF	1541	1557	3163	3281	3329	3340	4179	4183	4285
		4299	4325	4327	4437	4644	4654	4654	4663	4666
512	ALDC	775	2656	3191	3617	3807	3988	4489		
514	ANPOJ	767	3959	3960						
516	ANRE	358	363	841	952	979	2635	2673	2694	2793
		2816	2851	3182	3273	3335	3507	3604	3681	3688
		3764	3874	3903	3942	3964	4213	4219	4256	4439
		4471								
518	ADPSTK	819	835	2421	3909	3915	3933			
705	ADUT	1482								
520	APBF	3162	3192	3280	3328	3339	3618	4182	4184	4297
		4435	4645	4664						
66	ARST	445	956	957	961	1168	1259	1267	1289	1346
		1358	1360	1852	1854	2110	2122	2130	2166	2180
		2706	2796	3289	4134	4173	4176	4186	4204	4206
		4656	4700	4704	4705					
522	ASCB	721	739	872	1384	1850	1869	1876	1901	1913
		1933	2034	2885	4083	4784	4831	4837		
67	ASET	453	874	1207	1208	1209	1210	1211	1212	1213
		1288	1440	1441	1442	1545	2017	2019	2036	2105
		2106	2121	2124	2125	2165	2179	2260	3290	3395
		3396	4130	4192	4230	4288	4292	4443	4712	4720
524	ASFL	1197	1375	2412	2470					
526	ASYSDC	3336								
674	AZER	2002	2111	2143	2167	2187	2503	2510	2523	2536
		2542	2575	2579						
68	B	241	242	243	250	252	259	261	277	278
		285	294	310	339	340	348	349	358	363
		386	387	394	395	396	403	405	412	423
		436	444	452	460	477	728	730	732	734
		767	775	799	812	819	835	841	844	871
		872	878	901	907	908	909	917	918	945
		952	954	964	972	978	979	984	991	1050
		1054	1055	1088	1089	1094	1095	1098	1101	1104
		1105	1109	1110	1130	1131	1132	1133	1135	1136
		1137	1161	1162	1163	1164	1166	1172	1173	1176
		1177	1179	1182	1192	1194	1196	1197	1198	1201
		1206	1214	1216	1222	1223	1237	1240	1242	1247
		1252	1257	1266	1271	1272	1273	1277	1279	1286
		1287	1294	1329	1331	1337	1342	1342	1349	1351
		1357	1362	1363	1368	1372	1373	1374	1375	1376
		1377	1378	1379	1380	1381	1382	1383	1385	1392
		1406	1409	1439	1522	1533	1534	1540	1549	1584
		1587	1588	1599	1612	1634	1638	1641	1644	1647
		1653	1657	1659	1662	1663	1666	1672	1676	1677
		1678	1681	1687	1693	1702	1705	1709	1713	1717
		1724	1725	1732	1733	1742	1744	1747	1748	1749
		1770	1774	1775	1804	1806	1811	1812	1814	1848
		1857	1901	1913	1933	2003	2006	2013	2090	2191
		2092	2094	2099	2102	2104	2113	2116	2120	2123
		2125	2127	2131	2132	2134	2139	2141	2142	2143
		2144	2150	2159	2162	2164	2170	2171	2174	2178
		2181	2186	2187	2199	2208	2209	2214	2215	2216
		2217	2227	2233	2234	2261	2264	2295	2296	2299
		2344	2346	2348	2373	2375	2413	2417	2422	2458
		2459	2460	2461	2462	2463	2464	2470	2471	2472
		2475	2476	2477	2478	2479	2481	2483	2496	2499
		2500	2501	2503	2504	2506	2507	2508	2517	2529
		2532	2533	2534	2536	2537	2539	2540	2541	2556
		2564	2566	2575	2576	2578	2579	2580	2629	2634
		2635	2640	2657	2659	2664	2667	2671	2672	2692
		2694	2701	2704	2710	2712	2715	2719	2735	2781
		2792	2793	2795	2797	2799	2810	2815	2816	2821
		2831	2838	2850	2851	2885	2900	2947	2948	2949
		2951	2953	2960	2982	2985	2994	2999	3000	3002
		3020	3023	3034	3026	3028	3029	3031	3032	3034
		3036	3038	3042	3044	3046	3054	3065	3067	3069
		3070	3071	3072	3073	3078	3079	3081	3123	3127
		3151	3154	3159	3160	3163	3165	3167	3172	3173
		3176	3177	3178	3179	3181	3194	3202	3257	3264
		3272	3273	3279	3281	3284	3287	3298	3299	3299
		3306	3335	3340	3342	3343	3347	3349	3354	3359
		3363	3364	3372	3376	3393	3394	3403	3423	3430
		3433	3434	3435	3437	3438	3446	3462	3464	3465
		3491	3496	3498	3499	3500	3506	3507	3518	3512
		3580	3583	3587	3588	3592	3593	3596	3598	3604
		3635	3606	3609	3611	3613	3620	3627	3633	3635
		3645	3648	3653	3654	3656	3673	3675	3676	3681
		3683	3713	3715	3717	3719	3726	3762	3764	3766
		3767	3770	3783	3784	3786	3789	3790	3792	3795
		3800	3808	3810	3864	3874	3885	3908	3909	3922
		3940	3942	3949	3958	3963	3969	3971	3974	3988
		3992	3994	4000	4008	4011	4013	4014	4075	4082
		4083	4084	4132	4136	4139	4141	4142	4144	4175
		4179	4180	4182	4183	4188	4194	4205	4208	4213
		4219	4227	4232	4235	4255	4256	4257	4250	4259
		4297	4298	4299	4300	4304	4307	4310	4311	4320
		4325	4326	4327	4329	4330	4331	4332	4337	4338
		4346	4348	4368	4370	4372	4373	4375	4379	4380
		4397	4399	4426	4435	4436	4437	4439	4441	4471
		4474	4476	4481	4484	4490	4495	4499	4501	4597
		4626	4628	4629	4634	4636	4642	4644	4645	4650
		4652	4653	4658	4660	4662	4664	4665	4666	4667







216	CTRV	4020								
545	CVFL	1192	1201	1279	2099	2102	2113	2116	2123	2127
		2132	2134	2139	2141	2159	2162	2170	2171	2174
210	CXC	3513								
217	CXF	3931	3972							
547	D	1085	1089	1132	1196	1363	1370	1806	2211	
1012	D10	1694	2226							
122	D15	1600	2374	2963	4493					
109	D16	3928								
203	DA	3263								
1049	DEF	1102	1103	1111	1138	1818				
1052	DEF4	1049								
1055	DEF8	1051								
1096	DEE10	1086	1091	1093						
1094	DEE5	1087								
549	DEXP	1099	1099	1131	1135	1137	1376	1681	1693	1702
		1736	1804	1812	1817	2060	2062	2217	2220	2227
		2237	2561	2564	2570	2572	2578	4399		
2937	DIN	1467								
1083	DOUT	1468								
551	DT	1094	1104	1109	1370	1809	1811	1814	2462	2471
		2472	2475	2528						
202	EC	877	1525	4724						
553	EDEXP	2089	2189	2208	2209	2216				
133	EIGHT	219	1217	1338	2423	3655				
2938	EIN	1469								
1084	EDUT	1470	1805	1808	1813					
4258	ER1	1168	1175	1202	1238	1259	1265	1284	1289	1308
		1320	1336	1344	1346	1350	1358	1360	1443	2005
		2014	4637							
4257	ER2	3763	3799							
4256	ER3	1598	1667	2103	2152	2154	2163	2193	2218	2258
		2269	2959	2962	2964	2979	3056	3058	3080	3083
		3085	4851	4856	4858					
4255	ER4	950	3259	3276	3367	3458	3493	3504	4002	4007
555	ERN	3904	4255	4256	4257	4259	4260			
557	FCHAR	1294	1870	1878	2002	2002	2013			
558	FCDDE	1206	1266	1287	1357	1439				
559	FDLKEY	1217	1232	1329	1334	1337	1351	1385	1406	2422
		2557	3792							
2939	FIN	1471								
123	FIVE	215	1386	4383						
124	FLF	956	2706							
561	FMPT	1855	1858							
125	FOUR	214	1100	1174	1335	1352	1354	1731	1815	2232
		2549	3793							
1128	FOUT	1472								
126	FPO	127	128	961						
127	FPOR	3678								
128	FPOS	4210	4340							
129	FRB	130								
130	FRBS	2718								
131	FRM	957								
562	FRMT	906	3167	3400	3600	3602	3636	3767	3790	
563	FRPT	1160	1182	1252						
1160	FRS	3203	3637							
1199	FRS10	1207	1230							
1222	FRS15	1209	1442							
1251	FRS19	1226	1246							
1172	FRS2	1208	1288							
1257	FRS20	1210								
1263	FRS25	1212								
1284	FRS30	1267								
1293	FRS35	1213								
1319	FRS39	1311								
1322	FRS40	1302								
1337	FRS45	1333								
1345	FRS46	1333								
1357	FRS47	1353								
1191	FRS5	1253	1434	1440	1863	2424	4786			
1367	FRS50	1355	1428							
1402	FRS55	1393								
1406	FRS60	1218	1341	1356	1387	1398				
1427	FRS65	726	735	2872	2425	3075	4834			
1433	FRS70	1211	1441							
1438	FRS75	1223								
1439	FRS85	1429	1854	4675						
1447	FRSCHT	1300	1301							
1466	FRSJT	1300	1417							
1301	FRSL1	1314								
564	FSCB	557	558	561	562	563				
1522	GBA	875	4138	4600	4747					
1533	GBA50	1524								
1542	GBA55	1538								
1553	GBA70	1536	1544	1545						
1556	GBA80	1525								
566	GDRPC	569	569	1181	1180	1243	1245	1249	1251	
198	GF	132	2777	2828						
568	GFRPT	1183	1251							
132	GFS	3511								
2940	GIN	1473								
1584	GNI	1402								
1676	GNI10	1601	1628	1640	1660	1668				



1599	GNI2	1595									
1699	GNI20	1689									
1723	GNI25	1701	1704	1708	1712	1716					
1733	GNI30	1700	1707	1711	1715	1719					
1602	GNI4	1590									
1741	GNI50	1682	1688	1727							
1632	GNI8	1603									
1652	GNI9	1605									
1669	GNI9A	1665									
1686	GNIL1	1679	1695	1737							
1743	GNIL2	1750									
1769	GNL	1233	1367	4746							
1781	GNL2	1772	1773								
0	GOFCB	59	3526								
1804	GOUT	1474									
569	GSRPC	1161	1181	1243	1245	1249					
1839	HIN	1483	1872								
1868	HID10	1849									
1876	HID15	1856	1864								
1850	HID2	1847									
1858	HID4	1852									
1862	HID6	1842									
1840	HOUT	1484	1880								
1901	ICC	740	881	1851	1853	1877	2016	2035	4095	4838	
1939	ICCCT	1923	1927								
1962	ICCCT1	1927									
1924	ICCLP	1926									
570	ICHR	720	727	741	4823	4827	4830	4840	4842	4864	
		4866	4870								
571	IDEXP	2090	2211	2211	2215	2328	2346	2348			
1998	IFF	1263	1347	1361							
2002	IFFL	2017									
2016	IFFL1	2018									
573	IFW	1050	1377	1817	2062	2460	2478	2479	2481	2494	
575	IIBS2	709	724	3786	4814						
2941	IIN	1475									
577	IIMSZ	3073	3783								
197	IN	134	135	3276	3348	3395	4172	4229	4434		
2034	INF	1167	1200	1258	1345	1359	1438				
579	INFL	3864	3899								
2035	INFLP	2036									
134	INR	2702	4234								
135	INS	2633	4347								
581	IDCONT	953	980	2674	2794	2817	2852	3154	3184	3185	
		3583	3606	3607	3648	3682	3684	3689	3691	4214	
		4216	4224	4226							
583	IDLNK	3464	3496	3509	3509						
585	IDSTAT	4220	4223								
2058	IDUT	1476									
587	ISCB	508	570								
589	ITEMAD	708	1234	1234	1584	1769	1769	2261	2296	3064	
		3802	3808	4754	4760	4810					
591	ITEMHC	1235	1235	1770	1781	1781	3801	3810			
593	ITMINC	1234	1235	1769	1781	3784	3789				
595	ITMODE	1588	2953	3765	3766	3770	3795				
2089	IXN	1397									
2142	IXN10	2112									
2150	IXN15	2106									
2169	IXN18	2124	2128								
2171	IXN20	2166									
2186	IXN25	2168	2180								
2195	IXN30	2160	2165								
2113	IXN4	2110									
2127	IXN5	2121									
2199	IXN50	2100	2105								
2210	IXN52	2206									
2212	IXN53	2210									
2215	IXN55	2212									
2221	IXN57	2204									
2222	IXN58	2220									
2130	IXN6	2122									
2232	IXN60	2222									
2139	IXN8	2130									
2100	IXNL1	2126	2129	2135	2146						
2160	IXNL2	2179	2182	2194							
2219	IXNL3	2228	2238								
1241	IXR	1411									
86	LC	155	156	157	158	159	160	161	162	163	
		164	165	166	167						
191	LF	124	136	985	2641	2796	2820	3289	3626	4129	
		4204	4287	4422	4442	4700	4719				
136	LFS	2632									
597	LGOV	966	3327								
137	LHW	2899	3057	3258							
2258	LIN	1479	2260								
2270	LINX	2266									
598	LISTFL	1162	1237	1239	1368						
600	LNKCNT	981	2695	4475							
493	LDC	494	495	496	497	498	499	500	501	502	
		503	504	505	506	507	509	510	512	513	
		514	515	516	517	518	519	520	521	522	
		523	524	525	526	527	530	531	533	534	
		535	536	537	538	539	540	541	542	543	















0	SSFCB	58	3525								
209	STKSZ	615	634	842	845	3876	3884	3967	4896	4939	
646	SVRECN	3277	4714								
648	SYSEF	2636									
649	SYSDCB	648									
4580	TBK	2658	2660	3193	3196	3619	3622	3809	3812	3951	
		3953	3955	3957	3961	4035	4492	4494			
4591	TBK10	4581	4585								
4599	TBKJMP	1592									
651	TEMP	908	915	1612	1617	1618	1623	2629	2763	2886	
		2900	2965	2974	2977	3009	3015	3963	3065	3069	
		3151	3354	3359	3363	3364	3372	3428	3437	3580	
		3645	3654	3656	3713	3719	3726	3930	3940	3971	
		3994	4014	4310	4320	4323	4326	4331	4490	4495	
653	TEMP1	900	903	904	918						
151	TEN	221	1015	1018	1021	1024	2009	2190	2332	2335	
		2338	2341	2571	3952	4392	4853				
655	TERM	1383	2144	2330							
152	THREE	213	1699	2987	3381	3798					
4622	TIN	1487									
4642	TID10	4630									
4659	TID15	4656									
4663	TID20	4646									
4673	TIDL	4638	4679	4681							
4623	TOUT	1488									
195	TR	153	1545	4134							
4697	TRM	4041									
4708	TRM10	4705									
4717	TRM20	4700	4704								
4723	TRM30	4719									
4728	TRMI	4715									
153	TRS	4698									
154	TWO	212	1340	1343	1589	1604	2153	2954	2989	3457	
		3466	3494	3590	3796						
4746	UID	3636	4756	4764							
4760	UID4	4748									
657	UNIT	953	978	2700	2792	2815	2850	3173	3181	3257	
		3284	3349	3462	3465	3605	4011	4193	4499		
156	VSCPL	3456	3869	4596							
157	VSCRS	798	3890	4596							
158	VSDSTB	3380									
0	VSEXEC	61									
160	VSLUP	4583	4586	4591							
159	VSLUP	4580	4582	4591							
161	VSLUT1	3352	3489								
3986	VSRER1	34									
43	VSRERF	28	40								
46	VSRERN	35									
3856	VSRERR	33									
42	VSRERS	26	38								
164	V\$ST0	1298	1415	1921	2842	3407	3473	3775	4018		
165	V\$ST1	3875									
166	V\$ST2	796									
167	V\$ST3	1319	1326	1421	1931	2848	3425	3444	3481	3781	
		3863	3892	3979	4024						
4887	VACC	4885									
4903	VBSCB	4886									
4904	VCHB	4888									
4915	VFSCB	4890									
4916	VGDRP	4891									
21	VII	22	23	772	795	801	1297	1305	1317	1325	
		1414	1420	1920	1930	2654	2841	2847	3189	3406	
		3424	3443	3472	3488	3615	3774	3790	3805	3860	
		3898	3900	4017	4023	4032	4057	4487	4563	4882	
		4941									
850	VIII	802	2655	3190	3616	3806	3861	3901	4033	4058	
		4488	4564	4883	4942						
1310	VIINUC	1306									
4925	VISCB	4892									
4939	VDPSTK	3965	4896								
1	VORTEX	19	21	3978							
4956	VSYSDC	4900									
659	W	724	1349	1369	4626	4636					
19	WCS	20	25	27	37	39	326	371			
330	WCS1	327	372								
332	WCS2	329	375								
201	WR	168	169	715	881	1393	1544	1806	1864	3200	
		3630	3687	4087	4176	4185	4203	4292	4333	4656	
		4705	4723	4748	4818						
168	HRR	733									
169	HRS	729	944	1410	3156	3585	3650				
661	WT	709	723	876	1216	1286	1369	2100	2160	2258	
		2270	2292	2413	2419	2458	4811	4824	4833		
81	X	268	270	285	302	309	317	318	341	351	
		359	361	364	378	420	468	484	783	811	
		821	824	838	845	873	880	955	973	974	
		980	983	990	992	1014	1016	1017	1019	1020	
		1022	1023	1025	1180	1181	1183	1243	1244	1245	
		1249	1250	1251	1301	1417	1423	1585	1594	1609	
		1613	1617	1618	1621	1622	1623	1626	1632	1635	
		1639	1642	1645	1654	1658	1745	1777	1902	1903	
		1908	1910	1914	1925	1927	1934	2015	2189	2191	
		2200	2201	2202	2203	2263	2267	2321	2324	2326	







```

000006 A 1 VORTEX SET 6 PUT LAST FOR VORTEX 07 00001
2 * 07 00002
3 ***** 07 00003
4 * 07 00004
5 * RE EN TR AN T R U N - T I M E I / O 07 00005
6 * 07 00006
7 * NAME: SOFTWARE: V$RERS 07 00007
8 * FIRMWARE: V$RERF 07 00008
9 * 07 00009
10 * BITS IN FLAG WORD 'VORTEX' ARE DEFINED THUS: 07 00010
11 * 07 00011
12 * BIT 0: SET FOR VORTEX II 07 00012
13 * BIT 1: SET IF V$RERR IN NUCLEUS 07 00013
14 * BIT 2: SET IF WCS AVAILABLE 07 00014
15 * 07 00015
16 * 07 00016
17 ***** 07 00017
19 WCS SET VORTEX/4 SET WCS=BIT 2 OF VORTEX FG 07 00019
000004 A 20 NUC SET WCS*4 FG 07 00020
000002 A 21 VII SET VORTEX-NUC FG 07 00021
000001 A 22 NUC SET VII/2 SET NUC=BIT 1 OF VORTEX FG 07 00022
000000 A 23 VII SET VII-NUC-NUC SET VII=BIT 0 OF VORTEX FG 07 00023
25 IFF WCS 07 00025
26 TITLE V$RERS SOFTWARE NAME 07 00026
27 IFT WCS 07 00027
28 TITLE V$RERF FIRMWARE NAME 07 00028
30 ***** 07 00030
31 * ENTRIES * 07 00031
32 ***** 07 00032
33 NAME V$RERR ALGC ENTRY 07 00033
34 NAME V$RER1 NON-ALGC ENTRY 07 00034
35 NAME V$RERN V$RERR NUCLEUS FLAG V2 07 00035
37 IFF WCS 07 00037
38 NAME V$RERS SOFTWARE NAME 07 00038
39 IFT WCS 07 00039
40 NAME V$RERF FIRMWARE NAME 07 00040
000000 R 42 V$RERS EQU * SOFTWARE NAME 07 00042
000000 R 43 V$RERF EQU * FIRMWARE NAME 07 00043
45 IFT NUC FG 07 00045
000001 A 46 V$RERN EQU 1 V$RERN = 1 IF V$RERR IN NUCLEUS FG 07 00046
47 IFT NUC FG 07 00047
48 V$RERN EQU 0 V$RERN = 0 IF V$RERR IN OM FG 07 00048
50 ***** 07 00050
51 * EXTERNALS * 07 00051
52 ***** 07 00052
53 EXT SIFCB 07 00053
54 EXT PIFCB 07 00054
55 EXT LOFCB 07 00055
56 EXT LIFCB 07 00056
57 EXT BOFCB 07 00057
58 EXT SSFCB 07 00058
59 EXT GOFCB 07 00059
60 EXT POFCB 07 00060
61 EXT V$EXEC VORTEX EXEC 07 00061
63 ***** 07 00063
64 * VDM 620/I INSTRUCTION SYMBOLS * 07 00064
65 ***** 07 00065
000040 A 66 ARST SET 040 A-REG BIT RESET 07 00066
000000 A 67 ASET SET 0 A-REG BIT SET 07 00067
000002 A 68 B SET 2 B-REGISTER 07 00068
000000 A 69 B0 SET 0 07 00069
000001 A 70 B1 SET 1 07 00070
000002 A 71 B2 SET 2 07 00071
000003 A 72 B3 SET 3 07 00072
000004 A 73 B4 SET 4 07 00073
000005 A 74 B5 SET 5 07 00074
000006 A 75 B6 SET 6 07 00075
000014 A 76 B12 SET 12 07 00076
000015 A 77 B13 SET 13 07 00077
000016 A 78 B14 SET 14 07 00078
000017 A 79 B15 SET 15 07 00079
000046 A 80 MAP SET 046 MAP DEVICE ADDRESS V2 07 00080
000001 A 81 X SET 1 X-REGISTER 07 00081
83 ***** 07 00083
84 * VORTEX LOW-CORE SYMBOLS * 07 00084
85 ***** 07 00085
000300 A 86 LC SET 0300 07 00086
000420 A 87 MT SET 0420 07 00087
000472 A 88 BM17 SET MT+42 07 00088
000473 A 89 BM37 SET MT+43 07 00089
000474 A 90 BM77 SET MT+44 07 00090
000441 A 91 BR0 SET MT+17 07 00091
000442 A 92 BR1 SET MT+18 07 00092
000443 A 93 BR2 SET MT+19 07 00093
000444 A 94 BR3 SET MT+20 07 00094
000445 A 95 BR4 SET MT+21 07 00095
000446 A 96 BR5 SET MT+22 07 00096
000447 A 97 BR6 SET MT+23 07 00097
000450 A 98 BR7 SET MT+24 07 00098
000451 A 99 BR8 SET MT+25 07 00099
000454 A 100 BR11 SET MT+28 07 00100
000455 A 101 BR12 SET MT+29 07 00101
000457 A 102 BR14 SET MT+31 07 00102

```



000460	A	103	BR15	SET	MT+32				07	00103	
000421	A	104	BS0	SET	MT+1			V2	07	00104	
000422	A	105	BS1	SET	MT+2				07	00105	
000424	A	106	BS2	SET	MT+4				07	00106	
000425	A	107	BS4	SET	MT+5				07	00107	
000426	A	108	BS5	SET	MT+6				07	00108	
000425	A	109	D16	SET	PS4				07	00109	
000423	A	110	BS2	SET	MT+3				07	00110	
000430	A	111	BS7	SET	MT+8				07	00111	
000431	A	112	BS3	SET	MT+9				07	00112	
000432	A	113	BS9	SET	MT+10				07	00113	
000433	A	114	BS10	SET	MT+11				07	00114	
000434	A	115	BS11	SET	MT+12				07	00115	
000435	A	116	BS12	SET	MT+13				07	00116	
000437	A	117	BS14	SET	MT+15				07	00117	
000440	A	118	BS15	SET	MT+16				07	00118	
000451	A	119	BFR	SET	BR0+BF	RESET BF FLAG		V2	07	00119	
000431	A	120	BFS	SET	BS0+BF	SET BF FLAG		V2	07	00120	
000430	A	121	BXBIAS	SET	BS7	BINARY EXPONENT BIAS		V2	07	00121	
000472	A	122	D15	SET	PM17				07	00122	
000465	A	123	FIVE	SET	MT+37				07	00123	
000015	A	124	FLF	SET	SH+LF	FCB LF FLAG		V2	07	00124	
000423	A	125	FOUR	SET	MT+3				07	00125	
000016	A	126	FPU	SET	SH+PO	FCB PD FLAG		V2	07	00126	
000457	A	127	FPOR	SET	BR0+FPD	RESET FCB PD FLAG		V2	07	00127	
000437	A	128	FPUS	SET	BS0+FPD	SET FCB PD FLAG		V2	07	00128	
000017	A	129	FRB	SET	SH+RB	FCB RB FLAG		V2	07	00129	
000440	A	130	FRBS	SET	BS0+FRB	SET FCB RB FLAG		V2	07	00130	
000014	A	131	FRM	SET	SH+RM	FCB RM FLAG		V2	07	00131	
000430	A	132	GFS	SET	BS0+GF	SET GLOBAL FCB FLAG		V2	07	00132	
000424	A	133	EIGHT	EDU	MT+4				07	00133	
000447	A	134	INR	SET	BR0+IN	RESET IN BIT		V2	07	00134	
000427	A	135	INS	SET	BS0+IN	SET IN FLAG		V2	07	00135	
000422	A	136	LFS	SET	BS0+LF	SET LF FLAG		V2	07	00136	
000462	A	137	LHW	SET	MT+34				07	00137	
000470	A	138	NINE	SET	MT+40				07	00138	
000421	A	139	ONE	SET	MT+1				07	00139	
000443	A	140	PDR	SET	BR0+PD	RESET PD FLAG		V2	07	00140	
000423	A	141	PDS	SET	BS0+PD	SET PD FLAG		V2	07	00141	
000424	A	142	RBS	SET	BS0+RB	SET RB BIT		V2	07	00142	
000463	A	143	RHW	SET	MT+35				07	00143	
000446	A	144	SCR	SET	BR0+SC	RESET SC BIT		V2	07	00144	
000467	A	145	SEVEN	SET	MT+39				07	00145	
000466	A	146	SIX	SET	MT+38				07	00146	
000001	A	147	BR	SET	1	STACK B-REGISTER		V2	07	00147	
000003	A	148	PR	SET	2	STACK P-REGISTER		V2	07	00148	
000421	A	149	RMS	SET	BS0+RM	SET RM BIT		V2	07	00149	
000426	A	150	SCS	SET	BS0+SC	SET SC BIT		V2	07	00150	
000471	A	151	TEN	SET	MT+41				07	00151	
000464	A	152	THREE	SET	MT+36				07	00152	
000425	A	153	TRB	SET	BS0+TR	SET TR BIT		V2	07	00153	
000422	A	154	TWO	SET	MT+2				07	00154	
000414	A	155	VSBVN	SET	LC+76	BOTTOM OF VORTEX NUCLEUS			07	00155	
000301	A	156	VSCPL	SET	LC+1	CURRENT PRIORITY LEVEL			07	00156	
000302	A	157	VSCRS	SET	LC+2	POINTER TO REENRANT STACK			07	00157	
000355	A	158	VSDSTB	SET	LC+45				07	00158	
000316	A	159	VSLUP	SET	LC+14	1ST WORD OF BACKGROUND			07	00159	
000317	A	160	VLLUP	SET	LC+15	LAST WORD OF BACKGROUND			07	00160	
000400	A	161	VSLUT1	SET	LC+64				07	00161	
000401	A	162	VSLUT2	SET	LC+65				07	00162	
000402	A	163	VSLUT3	SET	LC+66				07	00163	
000334	A	164	VST0	SET	LC+28	EXEC STATE 0		V2	07	00164	
000335	A	165	VST1	SET	LC+29	EXEC STATE 1		V2	07	00165	
000336	A	166	VST2	SET	LC+30	EXEC STATE 2		V2	07	00166	
000337	A	167	VST3	SET	LC+31	EXEC STATE 3		V2	07	00167	
000452	A	168	WRB	SET	BR0+WR	RESET WR BIT		V2	07	00168	
000432	A	169	WRB	SET	BS0+WR	SET WR BIT		V2	07	00169	
000420	A	170	ZERO	EDU	BT				07	00170	
		172	*****							07	00172
		173	* CHARACTER TYPE FLAGS *							07	00173
		174	*****							07	00174
000000	A	175	AL	SET	0	ALPHA CHAR BIT (EXCEPT P)			07	00175	
000001	A	176	BL	SET	1	BLANK CHAR BIT			07	00176	
000002	A	177	CM	SET	2	'.' CHAR BIT			07	00177	
000003	A	178	LP	SET	3	'(' CHAR BIT			07	00178	
000004	A	179	KN	SET	4	'-' CHAR FLAG			07	00179	
000005	A	180	NM	SET	5	NUMERIC CHAR BIT			07	00180	
000006	A	181	PL	SET	6	'+' CHAR BIT			07	00181	
000007	A	182	PS	SET	7	'P' SCALE FACTOR			07	00182	
000010	A	183	PT	SET	8	'.' CHAR BIT			07	00183	
000011	A	184	QT	SET	9	' ' CHAR BIT			07	00184	
000012	A	185	RP	SET	10	'>' CHAR BIT			07	00185	
000013	A	186	SL	SET	11	'/' CHAR BIT			07	00186	
		187	*****							07	00187
		188	* READ/WRITE FLAGS *							07	00188
		189	*****							07	00189
000000	A	190	RM	SET	0	RMD FLAG		V2	07	00190	
000001	A	191	LF	SET	1	LOGICAL FILE FLAG		V2	07	00191	
000002	A	192	PD	SET	2	BUFFER POSTING FLAG		V2	07	00192	
000003	A	193	RB	SET	3	READ BEFORE WRITE FLAG		V2	07	00193	
000014	A	194	SH	SET	15-RB	FCB CONTROL FLAG SHIFT		V2	07	00194	
000004	A	195	TR	SET	4	TERMINATE FLAG		V2	07	00195	
000005	A	196	CC	SET	5	SUPPRESS CLEAR		V2	07	00196	



```

000006 A 197 IN SET 6 INITIALIZE FLAG V2 07 00197
000007 A 198 GF SET 7 GLOBAL FCB FLAG V2 07 00198
000010 A 199 BF SET 8 BUFFER FILL FLAG V2 07 00199
000400 A 200 BFA SET 0400 BF ABS VALUE V2 07 00200
000011 A 201 WR SET 9 WRITE FLAG V2 07 00201
000012 A 202 EC SET 10 ENCODE/DECODE FLAF PD 07 00202
000013 A 203 DA SET 11 DIRECT ACCESS FLAG 07 00203
204 07 00204
206 *****
207 * STACK OPS *
208 *****
000012 A 209 STKSZ SET 10 STACK SIZE 07 00208
000420 A 210 CXC SET ZERO CALL EXEC FOR IOLINK 07 00209
000421 A 211 CER SET ONE CALL ERROR 07 00210
000422 A 212 CEX SET TWO CALL EXIT 07 00211
000464 A 213 CIO SET THREE CALL I/O 07 00212
000423 A 214 CRB SET FOUR CALL REENTRANT BLOCK 07 00213
000463 A 215 CTR SET FIVE TERMINATE 07 00214
000005 A 216 CTRV SET 5 07 00215
000466 A 217 CXF SET SIX PARAMETER XFER V2 07 00216
000467 A 218 CBK SET SEVEN BACKSPACE V2 07 00217
000424 A 219 CEF SET EIGHT ENDFILE V2 07 00218
000470 A 220 CRW SET NINE REWIND V2 07 00219
000471 A 221 CRD SET TEN READ V2 07 00220
222 *CWR SET ELEVEN WRITE V2 07 00221
223 *CCL SET TWELVE CLOSE FILE V2 07 00222
224 *CCB SET THIRTEEN CLOSE BLOCKED FILE V2 07 00223
225 *COP SET FOURTEEN OPEN FILE V2 07 00224
000016 A 226 COPV SET 14 V2 07 00225
227 *COB SET FIFTEEN OPEN BLOCKED FILE V2 07 00226
228 CDC SET 16 DECODE PD 07 00227
000020 A 229 CEN SET 17 ENCODE PD 07 00228
000021 A 230 CRA SET 18 DIRECT ACCESS READ 07 00229
000022 A 231 *CWA SET 19 DIRECT ACCESS WRITE 07 00230
232 07 00231
233 *****
234 * MACROS *
235 *****
237 *****
238 * ADD B-REF TO A-REF INTO B-REF *
239 *****
240 AD3BB MAC
241 LDA P(1),B
242 ADD P(2),B
243 STA P(3),B
244 EMAC
246 *****
247 * DECREMENT/IN A/B-REF *
248 *****
249 DAB MAC
250 LDA P(1),B
251 DAR
252 STA P(1),B
253 EMAC
255 *****
256 * DECREMENT B-REF/IN A/TO B-REF *
257 *****
258 DABB MAC
259 LDA P(1),B
260 DAR
261 STA P(2),B
262 EMAC
264 *****
265 * DECREMENT/IN A/X-REF *
266 *****
267 DAX MAC
268 LDA P(1),X
269 DAR
270 STA P(1),X
271 EMAC
273 *****
274 * MOVE B-REF OP TO B-REF OP THRU A *
275 *****
276 MOVBAB MAC
277 LDA P(1),B
278 STA P(2),B
279 EMAC
281 *****
282 * MOVE B-REF TO X-REF THRU A *
283 *****
284 MOVBA X MAC
285 LDA P(1),B
286 STA P(2),X
287 EMAC
289 *****
290 * MOVE P-REF OP TO B-REF OP THRU A *
291 *****
292 MOVPA B MAC
293 LDA P(1)
294 STA P(2),B
295 EMAC
297 *****
298 * MOVE P-REF/ THRU A/ TO X-REF *
299 *****

```



```

300 MOVPAK MAC
301 LDA P(1)
302 STA P(2),X
303 EMAC
304 *****
305 * MOVE X REF TO B-REF THRU A *
306 *****
307 MOVXAB MAC
308 LDA P(1),X
309 STA P(2),B
310 ENAC
311 *****
312 * MOVE X-REF TO X-REF THRU A *
313 *****
314 MOVXAX MAC
315 LDA P(1),X
316 STA P(2),X
317 ENAC
318 *****
319 * POP/JUMP *
320 *****
321 POPJ MAC
322 IFF WCS
323 GOTO WCS1
324 DATA 0105065
325 GOTO WCS2
326 WCS1 CONT
327 JMP POJ
328 WCS2 CONT
329 EMAC
330 *****
331 * POP OP TO X *
332 *****
333 POPX MAC
334 LDX OPSTKP,B
335 INR OPSTKP,B
336 LDX 0,X
337 EMAC
338 *****
339 * PUSH P(1) *
340 *****
341 PUSH MAC
342 INR OPSTKP,B
343 LDX OPSTKP,B
344 LDA P(1)
345 STA 0,X
346 EMAC
347 *****
348 * PUSH OP ONTO V$FORTID STACK *
349 *****
350 PUSHF MAC
351 LDX ANRB,B
352 LDX OPSTKP,X
353 DXR
354 STA 0,X
355 TXA
356 LDX ANRB,B
357 STA OPSTKP,X
358 EMAC
359 *****
360 * PUSH/JUMP TO P(1) *
361 *****
362 PUSHJ MAC
363 IFF WCS
364 GOTO WCS1
365 DATA 0105025
366 DATA P(1)
367 GOTO WCS2
368 WCS1 CONT
369 LDAI P(1)
370 JSR PSJ,X
371 WCS2 CONT
372 EMAC
373 *****
374 * SUBTRACT B-REF MINUS B-REF *
375 *****
376 SUTBB MAC
377 LDA P(1),B
378 SUB P(2),B
379 EMAC
380 *****
381 * SUBTRACT B-REF MINUS B-REF TO B-REF *
382 *****
383 SUTBBB MAC
384 LDA P(1),B
385 SUB P(2),B
386 STA P(3),B
387 ENAC
388 *****
389 * SUBTRACT B-REF MINUS P-REF TO B-REF *
390 *****
391 SUTBPB MAC
392 LDA P(1),B

```

```

07 00300
07 00301
07 00302
07 00303
07 00305
07 00306
07 00307
07 00308
07 00309
07 00310
07 00311
07 00313
07 00314
07 00315
07 00316
07 00317
07 00318
07 00319
FG 07 00321
FG 07 00322
FG 07 00323
FG 07 00325
FG 07 00326
FG 07 00327
FG 07 00328
FG 07 00329
FG 07 00330
FG 07 00331
FG 07 00332
FG 07 00333
V2 07 00335
V2 07 00336
V2 07 00337
07 00338
07 00339
FG 07 00340
FG 07 00341
07 00342
V2 07 00344
V2 07 00345
V2 07 00346
07 00347
07 00348
07 00349
07 00350
07 00351
07 00352
07 00353
07 00354
07 00355
07 00357
07 00358
07 00359
FG 07 00360
07 00361
FG 07 00362
FG 07 00363
FG 07 00364
07 00365
07 00367
V2 07 00368
07 00369
07 00370
FG 07 00371
FG 07 00372
FG 07 00373
FG 07 00374
FG 07 00375
FG 07 00376
V2 07 00377
07 00378
FG 07 00379
07 00380
07 00383
07 00384
07 00385
07 00386
07 00387
07 00388
07 00390
07 00391
07 00392
07 00393
07 00394
07 00395
07 00396
07 00397
07 00399
07 00400
07 00401
07 00402
07 00403

```







000013	A	507	LOC	SET	LOC+1		V2	07	00507
0000110	A	508	AIRUF	SET	ISCB+1	LIST ITEM ADDRESS	V2	07	00508
000013	A	509	AISCB	SET	LOC	ADDRESS OF LIST ITEM SCB	V2	07	00509
000014	A	510	LOC	SET	LOC+1		V2	07	00510
000027	A	511	ALBF	SET	BSCB+1	ADDRESS OF LOGICAL BUFFER	V2	07	00511
000014	A	512	ALOC	SET	LOC	ALOC ENTRY FLAG	V2	07	00512
000015	A	513	LOC	SET	LOC+1		V2	07	00513
000015	A	514	ANPOJ	SET	LOC	ADDRESS OF V\$FORTIO POP/JUMP	V2	07	00514
000016	A	515	LOC	SET	LOC+1		V2	07	00515
000016	A	516	ANRB	SET	LOC	ADDRESS OF V\$FORTIO DATA BLOCK	V2	07	00516
000017	A	517	LOC	SET	LOC+1		V2	07	00517
000017	A	518	ADPSTK	SET	LOC	ADDRESS OF DP STACK	V2	07	00519
000020	A	519	LOC	SET	LOC+1		V2	07	00519
000020	A	520	APBF	SET	LOC	ADDRESS OF PHYSICAL BUFFER	V2	07	00520
000021	A	521	LOC	SET	LOC+1		V2	07	00521
000021	A	522	ASCB	SET	LOC	SCAN BLOCK ADDRESS	V2	07	00522
000022	A	523	LOC	SET	LOC+1		V2	07	00523
000022	A	524	ASFL	SET	LOC	'*' FLAG	V2	07	00524
000023	A	525	LOC	SET	LOC+1		V2	07	00525
000023	A	526	ASYSDC	SET	LOC	ADDRESS OF SYSTEM DCB	V2	07	00526
000024	A	527	LOC	SET	LOC+1		V2	07	00527
000030	A	528	BCHAR	SET	BSCB+2	BUFFER CHARACTER	V2	07	00528
000031	A	529	BCODE	SET	BSCB+3	BUFFER CHARACTER CODE	V2	07	00529
000024	A	530	BEXP	SET	LOC	BINARY EXPONENT	V2	07	00530
000025	A	531	LOC	SET	LOC+1		V2	07	00531
000026	A	532	BFPT	SET	BSCB	BUFFER CHARACTER POINTER	V2	07	00532
000025	A	533	BFUPT	SET	LOC	BUFFER WORD POINTER	V2	07	00533
000026	A	534	LOC	SET	LOC+1		V2	07	00534
000026	A	535	BSCB	SET	LOC	BUFFER SCB	V2	07	00535
000032	A	536	LOC	SET	LOC+4		V2	07	00536
000032	A	537	CHB	SET	LOC	DECIMAL DIGIT ARRAY	V2	07	00537
000050	A	538	LOC	SET	LOC+14		V2	07	00538
000050	A	539	CHBPT	SET	LOC	CHB ARRAY POINTER	V2	07	00539
000051	A	540	LOC	SET	LOC+1		V2	07	00540
000051	A	541	CHNHDR	SET	LOC	FCB CHAIN HEADER	V2	07	00541
000052	A	542	LOC	SET	LOC+1		V2	07	00542
000052	A	543	COUNT	SET	LOC	COUNTER	V2	07	00543
000033	A	544	LOC	SET	LOC+1		V2	07	00544
000053	A	545	CVFL	SET	LOC	CHARACTER VALIDITY FLAGS	V2	07	00545
000054	A	546	LOC	SET	LOC+1		V2	07	00546
000054	A	547	D	SET	LOC	FRACTIONAL FIELD WIDTH	V2	07	00547
000055	A	548	LOC	SET	LOC+1		V2	07	00548
000055	A	549	DEXP	SET	LOC	DECIMAL EXPONENT	V2	07	00549
000056	A	550	LOC	SET	LOC+1		V2	07	00550
000056	A	551	DT	SET	LOC	WORKING FRACTIONAL FIELD WIDTH	V2	07	00551
000057	A	552	LOC	SET	LOC+1		V2	07	00552
000057	A	553	EDEXP	SET	LOC	EXPLICIT DECIMAL EXPONENT	V2	07	00553
000060	A	554	LOC	SET	LOC+1		V2	07	00554
000060	A	555	ERN	SET	LOC	ERRDR NUMBER	V2	07	00555
000061	A	556	LOC	SET	LOC+1		V2	07	00556
000064	A	557	FCHAR	SET	FSCB+2	FORMAT CHARACTER	V2	07	00557
000065	A	558	FCODE	SET	FSCB+3	FORMAT CHARACTER CODE	V2	07	00558
000061	A	559	FDLKEY	SET	LOC	FIELD DESCRIPTOR KEY	V2	07	00559
000062	A	560	LOC	SET	LOC+1		V2	07	00560
000062	A	561	FMPT	SET	FSCB	FORMAT STRING POINTER	V2	07	00561
000063	A	562	FRMT	SET	FSCB+1	ADDRESS OF FORMAT STRING(0 IF NONE)	V2	07	00562
000062	A	563	FRPT	SET	FSCB	FORMAT STRING CURRENT POINTER	V2	07	00563
000062	A	564	FSCB	SET	LOC	FORMAT STRING SCB	V2	07	00564
000066	A	565	LOC	SET	LOC+4		V2	07	00565
000066	A	566	GSRPC	SET	LOC	'*' GROUP DYNAMIC REPEAT COUNT	V2	07	00566
000077	A	567	LOC	SET	LOC+9		V2	07	00567
000071	A	568	GFRPT	SET	GSRPC+3	'*' GROUP FORMAT POINTER	V2	07	00568
000074	A	569	GSRPC	SET	GSRPC+6	'*' GROUP STATIC REPEAT COUNT	V2	07	00569
000111	A	570	ICHR	SET	ISCB+2	LIST ITEM CHARACTER	V2	07	00570
000077	A	571	IDEXP	SET	LOC	IMPLICIT DECIMAL EXPONENT	V2	07	00571
000100	A	572	LOC	SET	LOC+1		V2	07	00572
000100	A	573	IFW	SET	LOC	INTEGER FIELD WIDTH	V2	07	00573
000101	A	574	LOC	SET	LOC+1		V2	07	00574
000101	A	575	IISZ	SET	LOC	INDIVIDUAL ITEM BYTE SIZE	V2	07	00575
000102	A	576	LOC	SET	LOC+1		V2	07	00576
000102	A	577	IISZ	SET	LOC	INDIVIDUAL ITEM WORD SIZE	V2	07	00577
000103	A	578	LOC	SET	LOC+1		V2	07	00578
000103	A	579	INFL	SET	LOC	INITIAL ENTRY FLAG	V2	07	00579
000104	A	580	LOC	SET	LOC+1		V2	07	00580
000104	A	581	IDCNT	SET	LOC	V\$IDC CONTROL WORD	V2	07	00581
000105	A	582	LOC	SET	LOC+1		V2	07	00582
000105	A	583	IDLNK	SET	LOC	IDLINK CONTROL WORD	V2	07	00583
000106	A	584	LOC	SET	LOC+1		V2	07	00584
000106	A	585	IDSTAT	SET	LOC	I/O STATUS	V2	07	00585
000107	A	586	LOC	SET	LOC+1		V2	07	00586
000107	A	587	ISCB	SET	LOC	ITEM SCB	V2	07	00587
000113	A	588	LOC	SET	LOC+4		V2	07	00588
000110	A	589	ITEMAD	SET	LOC	ADDRESS OF LIST ITEM	V2	07	00589
000114	A	590	LOC	SET	LOC+1		V2	07	00590
000114	A	591	ITEMWC	SET	LOC	COUNT OF WORDS REMAINING IN ITEM	V2	07	00591
000115	A	592	LOC	SET	LOC+1		V2	07	00592
000115	A	593	ITMINC	SET	LOC	LIST ITEM WORD INCREMENT	V2	07	00593
000116	A	594	LOC	SET	LOC+1		V2	07	00594
000116	A	595	ITMODE	SET	LOC	LIST ITEM MODE	V2	07	00595
000117	A	596	LOC	SET	LOC+1		V2	07	00596
000123	A	597	LGOV	SET	LRWC	LOGICAL RECORD OVERLAP	V2	07	00597
000117	A	598	LJSTFL	SET	LOC	LIST DATA XFER FLAG	V2	07	00598
000120	A	599	LOC	SET	LOC+1		V2	07	00599



000120	A	600	LNKCNT	SET	LDC	LINK COUNT	V2	07	00600
000121	A	601	LDC	SET	LDC+1		V2	07	00601
000121	A	602	LRECND	SET	LDC	LOGICAL RECRD NUMBER	V2	07	00602
000122	A	603	LDC	SET	LDC+1		V2	07	00603
000122	A	604	LRSZ	SET	LDC	LOGICAL RECORD SIZE	V2	07	00604
000123	A	605	LDC	SET	LDC+1		V2	07	00605
000123	A	606	LRHC	SET	LDC	LOGICAL RECORD REMAINING WORD COUNT	V2	07	00606
000124	A	607	LDC	SET	LDC+1		V2	07	00607
000124	A	608	MDV	SET	LDC	MULTIPLY OVERFLOW SWITCH	V2	07	00608
000125	A	609	LDC	SET	LDC+1		V2	07	00609
000125	A	610	N	SET	LDC	H/T/X FIELD WIDTH	V2	07	00610
000126	A	611	LDC	SET	LDC+1		V2	07	00611
000126	A	612	NFF	SET	LDC	NUMERIC FORMAT FIELD VALUE	V2	07	00612
000127	A	613	LDC	SET	LDC+1		V2	07	00613
000127	A	614	DPSTK	SET	LDC	DP STACK	V2	07	00614
000141	A	615	LDC	SET	LDC+STKSZ		V2	07	00615
000000	A	616	DPSTKP	SET	0	DP STACK POINTER	FG	07	00616
000141	A	617	PARLV	SET	LDC	FORMAT 'C' GROUP LEVEL COUNT	V2	07	00617
000142	A	618	LDC	SET	LDC+1		V2	07	00618
000142	A	619	PBRC	SET	LDC	PHYSICAL BUFFER RECRD COUNT	V2	07	00619
000143	A	620	LDC	SET	LDC+1		V2	07	00620
000143	A	621	PBSZ	SET	LDC	PHYSICAL BUFFER SIZE	V2	07	00621
000144	A	622	LDC	SET	LDC+1		V2	07	00622
000144	A	623	PBWC	SET	LDC	PHYSICAL BUFFER REMAINING WORD COUNT	V2	07	00623
000145	A	624	LDC	SET	LDC+1		V2	07	00624
000145	A	625	PRECND	SET	LDC	PHYSICAL RECORD NUMBER	V2	07	00625
000146	A	626	LDC	SET	LDC+1		V2	07	00626
000146	A	627	PRLINK	SET	LDC	PREVIOUS FCB LINK	V2	07	00627
000147	A	628	LDC	SET	LDC+1		V2	07	00628
000147	A	629	PTFL	SET	LDC	'.' FLAG	V2	07	00629
000150	A	630	LDC	SET	LDC+1		V2	07	00630
000150	A	631	QFL	SET	LDC	QUOTE FLAG	V2	07	00631
000151	A	632	LDC	SET	LDC+1		V2	07	00632
000125	A	633	R	SET	N	REPEAT COUNT	V2	07	00633
000012	A	634	ROPSTP	SET	STKSZ	V\$RERR DP STACK POINTER	V2	07	00634
000151	A	635	RETURN	SET	LDC	RETURN ADDR/'END' ADDR/'ERR' ADDR	PD	07	00635
000154	A	636	LDC	SET	LDC+3		PD	07	00636
000154	A	637	RWFL	SET	LDC	FLAG WORD	V2	07	00637
000155	A	638	LDC	SET	LDC+1		V2	07	00638
000155	A	639	S	SET	LDC	SCALE FACTOR	V2	07	00639
000156	A	640	LDC	SET	LDC+1		V2	07	00640
000032	A	641	SAVE	SET	CHB	SAVE PARAMETERS	V2	07	00641
000156	A	642	SCF	SET	LDC	SCALE FACTOR FLAG	V2	07	00642
000157	A	643	LDC	SET	LDC+1		V2	07	00643
000157	A	644	SGFL	SET	LDC	SIGN FLAG	V2	07	00644
000160	A	645	LDC	SET	LDC+1		V2	07	00645
000160	A	646	SVRECND	SET	LDC	SAVE RECORD NO		07	00646
000161	A	647	LDC	SET	LDC+1			07	00647
000162	A	648	SYSBF	SET	SYSDCB+1	ADDRESS OF SYSTEM BUFFER \$BUF	V2	07	00648
000161	A	649	SYSDCB	SET	LDC	SYSTEM DCB	V2	07	00649
000164	A	650	LDC	SET	LDC+3		V2	07	00650
000164	A	651	TEMP	SET	LDC	TEMP STORE	V2	07	00651
000165	A	652	LDC	SET	LDC+1		V2	07	00652
000165	A	653	TEMP1	SET	LDC	TEMP STORE		07	00653
000166	A	654	LDC	SET	LDC+1			07	00654
000166	A	655	TERM	SET	LDC	PRODUCT TERM	V2	07	00655
000167	A	656	LDC	SET	LDC+1		V2	07	00656
000167	A	657	UNIT	SET	LDC	I/O UNIT NUMBER	V2	07	00657
000170	A	658	LDC	SET	LDC+1		V2	07	00658
000170	A	659	W	SET	LDC	FIELD WIDTH	V2	07	00659
000171	A	660	LDC	SET	LDC+1		V2	07	00660
000171	A	661	WT	SET	LDC	WORKING VALUE OF W	V2	07	00661
000172	A	662	LDC	SET	LDC+1		V2	07	00662
000172	A	663	XFFL	SET	LDC	PARAMETER XFER ENABLE FLAG	V2	07	00663
000173	A	664	LDC	SET	LDC+1		V2	07	00664
000173	A	665	XFL	SET	LDC	EXPONENT FIELD NON-BLANK FLAG	V2	07	00665
000174	A	666	LDC	SET	LDC+1		V2	07	00666
000174	A	667	XFW	SET	LDC	EXPONENT FIELD WIDTH	V2	07	00667
000175	A	668	LDC	SET	LDC+1		V2	07	00668
000175	A	669	XSG	SET	LDC	EXPONENT SIGN FLAG	V2	07	00669
000176	A	670	LDC	SET	LDC+1		V2	07	00670
000176	A	671	ZFW	SET	LDC	LEADING ZERO FIELD WIDTH	V2	07	00671
000177	A	672	LDC	SET	LDC+1		V2	07	00672
000177	A	673	YYY	SET	LDC	END OF SAVE BLOCK	V2	07	00673
000177	A	674	AZER	SET	LDC	ASCIT ZERO	V2	07	00674
000200	A	675	LDC	SET	LDC+1		V2	07	00675
000200	A	676	BD14	SET	LDC	DECIMAL 14	V2	07	00676
000201	A	677	LDC	SET	LDC+1		V2	07	00677
000201	A	678	BD120	SET	LDC	DECIMAL 120	V2	07	00678
000202	A	679	LDC	SET	LDC+1		V2	07	00679
000202	A	680	BLNK1	SET	LDC	ASCII BLANK CHARACTER	V2	07	00680
000203	A	681	LDC	SET	LDC+1		V2	07	00681
000203	A	682	BLNK2	SET	LDC	ASCII BLANK WORD	V2	07	00682
000204	A	683	LDC	SET	LDC+1		V2	07	00683
000204	A	684	ZZZ	SET	LDC	END OF DATA BLOCK	V2	07	00684
685			EJEC					07	00685
686			*****					07	00686
687			*					07	00687
688			* PROCESS A FORMAT DESCRIPTOR (A I O)					07	00688
689			*					07	00689
690			* FUNCTION: TO PROCESS THE A FORMAT DESCRIPTOR: RAW					07	00690
691			*					07	00691
692			* ENTRY: DIRECT FROM FRS					07	00692



```

693 *          WT = W = TOTAL FIELD WIDTH          * 07 00693
694 *          IIBSZ = BYTE COUNT OF SINGLE LIST ITEM * 07 00694
695 *          ITEMAD = ADDRESS OF LIST ITEM        * 07 00695
696 *          RWFL(BIT WR) = 0 READ                * 07 00696
697 *          = 1 WRITE                            * 07 00697
698 *
699 * EXIT : INPUT : DIRECT TO FRS                  * 07 00699
700 *          OUTPUT: DIRECT TO FRS THRU GBC       * 07 00700
701 *
702 * *****
000000 R 704 AIN EQU *
000000 R 705 AOUT EQU *
000000 005001 A 707 ZAB AIBUF-1 SET LIST ITEM SCB(0) = 0 (BYTE COUNT) 07 00702
000001 056107 A
000002 016113 A 708 MOVBAB ITEMAD,AIBUF SET LIST ITEM SCB(1) = ITEM ADDRESS 07 00708
000003 056110 A
000004 016171 A 709 SUTBBB WT,IIBSZ,COUNT GET EXCESS CHAR COUNT WT-IIBSZ 07 00709
000005 146101 A
000006 056052 A
710 * *****
711 * SLEW THRU W-IIBSZ CHARS *
712 * *****
000007 016202 A 713 MOVBAB BLNK1,BCHAR LOAD BLANK AS REPEAT CHARACTER V2 07 00713
000010 056030 A
000011 105025 A 714 PUSHJ RCH REPEAT CHARACTER I/O V2 07 00714
000012 005125 R
000013 016154 A 715 TSAB RWFL,WR,AIDL2 TEST IF INPUT OR OUTPUT 07 00715
000014 006411 A
000015 000053 R
716 * *****
717 * INPUT *
718 * *****
000016 105025 A 719 AIDL1 PUSHJ GBC INPUT BUFFER CHARACTER V2 07 00719
000017 000101 R
000020 016030 A 720 MOVBAB BCHAR,ICHAR MOVE CHAR FROM BUFF SCB TO ITEM SCB 07 00720
000021 056111 A
000022 016013 A 721 MOVBAB AISC,BASC SET SCB TO LIST ITEM 07 00721
000023 056021 A
000024 105025 A 722 PUSHJ PCH PUT CHARACTER IN ITEM V2 07 00722
000025 003320 R
000026 016171 A 723 TNZAB WT,AIDL1 LOOP TILL FIELD WIDTH WT EXHAUSTED 07 00723
000027 001016 A
000030 000016 R
000031 016101 A 724 SUTBBB IIBSZ,W,COUNT GET COUNT OF EXCESS CHARS IN ITEM 07 00724
000032 146170 A
000033 056052 A
000034 005311 A 725 DAR
000035 001004 A 726 JAN FRS65 EXIT TO FRS IF LIST ITEM FILLED 07 00726
000036 001014 R
000037 016202 A 727 MOVBAB BLNK1,ICHAR LOAD BLANK AS FILL CHARACTER V2 07 00727
000040 056111 A
000041 016154 A 728 LDA RWFL,B
000042 110432 A 729 ORA WRS SET WRITE FLAG V2 07 00729
000043 056154 A 730 STA RWFL,B
731 PUSHJ RCH FILL OUT ITEM WITH BLANKS V2 07 00731
000044 105025 A
000045 005125 R
000046 016154 A 732 LDA RWFL,B
000047 150452 A 733 ORR WRS RESTORE I/O MODE TO READ V2 07 00733
000050 056154 A 734 STA RWFL,B
000051 001000 A 735 JMP FRS65 AND RETURN TO FORMAT SCAN 07 00735
000052 001014 R
736 * *****
737 * OUTPUT *
738 * *****
000053 016013 A 739 AIDL2 MOVBAB AISC,BASC SET SCB TO LIST ITEM 07 00739
000054 056021 A
000055 105025 A 740 PUSHJ GBC INPUT CHARACTER FROM LIST ITEM V2 07 00740
000056 001623 R
000057 016111 A 741 MOVBAB ICHAR,BCHAR MOVE CHAR FROM LIST SCB TO BUFF SCB 07 00741
000060 056030 A
000061 105025 A 742 PUSHJ GCB OUTPUT CHARACTER TO BUFFER/EXIT V2 07 00742
000062 002452 R
000063 001000 A 743 JMP AIDL2 LOOP TILL DONE 07 00743
000064 000053 R
744 EIEC 07 00744

```



```

745 ***** 07 00745
746 * 07 00746
747 * CALL NON-REENTRANT BLOCK(CAN) 07 00747
748 * 07 00748
749 * FUNCTION: TO RETURN TO V$FORTIO 07 00749
750 * 07 00750
751 * ENTRY: ALOC .NE. 0 IF V$RERR ENTERED BY ALOC V2* 07 00751
752 * .EQ. 0 IF V$RERR ENTERED BY DIRECT JUMP V2* 07 00752
753 * 07 00753
754 * V$CRS = CURRENT REENTRANT STACK POINTER 07 00754
755 * V$CRS(PR) = LOCATION WHERE P-REG(RETURN ADDRESS) IS STORED 07 00755
756 * 07 00756
757 * EXIT : TO V$FORTIO POP/JUMP ADDRESS IN ANPOJ 07 00757
758 * 07 00758
759 * VIA DEALOC IF ENTERED BY ALOC V2* 07 00759
760 * VIA DIRECT JUMP IF ENTERED BY DIRECT JUMP V2* 07 00760
761 * V2* 07 00761
762 * RETURN ADDRESSES IN V$FORTIO STACK SAVED IN V$RERR IF 07 00762
763 * VORTEX II CALL FROM BACKGROUND TO NUCLEUS. 07 00763
764 * 07 00764
765 ***** 07 00765
000065 036015 A 767 CAN LDX ANPOJ,B POINT X AT V$FORTIO POP/JUMP V2 07 00767
768 IFF NUC FG 07 00768
770 GOTO NUC1 FG 07 00770
772 IFT VII FG 07 00772
773 GOTO NUC2 FG 07 00773
000066 016014 A 775 LDA ALOC,B GET ALOC ENTRY FLAG FG 07 00775
000067 001016 A 776 JANZ CAN1 TEST VORTEX BACKGROUND CALL TO NUCLEUS FG 07 00776
000070 000073 R
778 ***** 07 00778
779 * EXIT TO V$FORTIO VIA DIRECT JUMP * FG 07 00779
780 ***** 07 00780
000071 006705 A 782 NUC1 CONT FG 07 00782
000072 000000 A 783 IJMP 0,X FG 07 00783
784 NUC2 CONT FG 07 00784
786 ***** FG 07 00786
787 * EXIT TO V$FORTIO VIA DEALOC * FG 07 00787
788 ***** FG 07 00788
000073 R 790 CAN1 EQU * FG 07 00790
792 IFF NUC FG 07 00792
793 GOTO NUC1 FG 07 00793
795 IFT VII FG 07 00795
796 DME MAP,V$ST2 SET EXEC STATE TO NO V2 07 00796
797 TEA SAVE 3 V2 07 00797
000073 005021 A 798 LDE V$CRS POINT B AT ALOC STACK V2 07 00798
000074 020302 A 799 STX PR,B STORE POP/JUMP ADDR IN P-REG FIELD V2 07 00799
000075 076003 A 801 IFF VII FG 07 00801
802 GOTO VII1 FG 07 00802
803 SPAC FG 07 00803
804 ***** FG 07 00804
805 * V$RERR IS IN VORTEX II NUCLEUS * FG 07 00805
806 ***** FG 07 00806
807 SPAC FG 07 00807
808 TAB RESTORE B V2 07 00808
809 LDXI BASE V2 07 00809
810 DECR ! V2 07 00810
811 STA ROPSTK,X INITIALIZE COUNT TO -1 V2 07 00811
812 LDX OPSTKP,B V2 07 00812
813 SPAC FG 07 00813
814 ***** FG 07 00814
815 * LOOP TO FIND TOP OF RETURN ADDRESSES IN V$FORTIO STACK * FG 07 00815
816 ***** FG 07 00816
817 SPAC FG 07 00817
818 TXA FG 07 00818
819 CANL1 SUB AOPSTK,B FG 07 00819
820 JAP CANC END OF STACK ? FG 07 00820
821 LDA 0,X NO. GET OP FROM STACK FG 07 00821
822 SUB CEX V2 07 00822
823 JAZ CAN5 DONT SAVE STACK WITH EXIT OP V2 07 00823
824 LDA 0,X LOAD OP V2 07 00824
825 LSRA 6 V2 07 00825
826 JANZ CAN2 EXIT ON ADDRESS OP V2 07 00826
827 INCR 045 BUMP POINTER FG 07 00827
828 JMP CANL1 AND CONTINUE V2 07 00828
829 SPAC FG 07 00829
830 ***** FG 07 00830
831 * TOP OF RETURN ADDRESS STACK FOUND - MOVE FROM V$FORTIO TO V$RERR * FG 07 00831
832 ***** FG 07 00832
833 SPAC FG 07 00833
834 CAN2 TXA FG 07 00834
835 SUB AOPSTK,B V2 07 00835
836 CPA FG 07 00836
837 LDXI BASE V2 07 00837
838 STA ROPSTK,X STORE STACK ITEM COUNT-1 FG 07 00838
839 CPA FG 07 00839
840 INCR 014 SET X = -(STACK ITEM COUNT-1) FG 07 00840
841 ADD ANR,B,V2 07 00841
842 ADDI OPSTK+STKSZ FG 07 00842
843 TAB POINT B AT V$FORTIO STACK V2 07 00843
844 CANL2 LDA 0,B MOVE STACK ADDRESSES V2 07 00844
845 STAE BASE+STKSZ-1,X FG 07 00845
846 JXZ CAN5 EXIT AT END V2 07 00846

```



```

847     IBR          BUMP POINTERS          FG 07 00847
848     IXR          FG 07 00848
849     JMP          CANL2          LOOP TILL DONE          V2 07 00849
850     VIII1       CONT          FG 07 00850
851     CAN5       DEALOC          RETURN TO V$FURTIO VIA DEALOC          V2 07 00851

000076 006505 A
000077 000000 E
000100 000700 A

852     NUC1       CONT          FG 07 00852
853     EJEK          FG 07 00853
854     *****
855     *
856     *           C Y C L E   B U F F E R   C H A R A C T E R ( C B C )
857     *
858     * FUNCTION: TO HANDLE CHARACTER I/O FROM/TO BUFFER          * 07 00858
859     *
860     * ENTRY:  BUFFER SCB(0) = CURRENT CHAR COUNT          * 07 00860
861     *         RWFL(BIT WR) = 0 READ          V2 07 00861
862     *         = 1 WRITE          * 07 00862
863     *         WT = WIDTH REMAINING IN FORMAT FIELD          * 07 00863
864     *
865     * EXIT :  RWFL(BIT WR) = 0 DIRECT TO ICC(OUTPUT)          V2 07 00865
866     *         = 1 DIRECT TO PCH(OUTPUT)          * 07 00866
867     *         WT = WT-1          * 07 00867
868     *
869     *****
000101 036002 A 871     CBC       LDX          ABSCB,B          07 00871
000102 076021 A 872     STX          ASCB,B          SET SCB TO BUFFER          07 00872
000103 015000 A 873     LDA          0,X          GET CURRENT CHAR COUNT          07 00873
000104 006400 A 874     BT           ASET+B0,CBC4          ON WORD BOUNDARY ?          07 00874
000105 000110 R
875     PUSHJ       SBA          YES. GET NEXT BUFFER ADDRESS          V2 07 00875
000106 105025 A
000107 001103 R
876     CBC4       DAB          WT          DECREMENT REMAINING FIELD WIDTH          07 00876
000110 016171 A
000111 005311 A
000112 056171 A
877     TRAB       RWFL,EC,CBC6          JUMP IF NOT ENCODE/DECODE          PD 07 00877
000113 016154 A
000114 006452 A
000115 000122 R
000116 036152 A 878     LDX          RETURN+1,B          PD 07 00878
000117 001040 A 879     JXZ          CBC6          NO COUNT ADDRESS          PD 07 00879
000120 000122 R
000121 045000 A 880     INR          0,X          BUMP CHARACTER-PROCESSED COUNT          PD 07 00880
881     CBC6       TRAB       RWFL,WR,ICC          READ: EXIT TO INPUT CHAR FROM BUFFER          PD 07 00881
000122 016154 A
000123 006451 A
000124 001623 R
000125 001000 A 882     JMP          PCH          WRITE: EXIT TO PUT CHAR IN BUFFER          07 00882
000126 003320 R
883     EJEK          07 00883
884     *****
885     *
886     *           C L E A R   B U F F E R ( C L B )
887     *
888     * FUNCTION: TO CLEAR A BUFFER          * 07 00888
889     *
890     * ENTRY:  FRMT = 0 IF UNFORMATTED          * 07 00890
891     *         BFWPT = ADDRESS OF PREVIOUS BUFFER WORD          V2 07 00891
892     *         LRWC = LOGICAL RECORD REMAINING WORD COUNT          * 07 00892
893     *         PBWC = PHYSICAL BUFFER REMAINING WORD COUNT          * 07 00893
894     *
895     * EXIT :  BUFFER = BLANKS ON FORMATTED I/O          * 07 00895
896     *         = 0 ON UNFORMATTED I/O          * 07 00896
897     *
898     *****
900     CLB       MOVBA8          LRWC,TEMP1          07 00900
000127 016123 A
000130 056165 A
000131 146144 A 901     SUB          PBWC,B          07 00901
000132 001004 A 902     JAN          CLR4          SET COUNT = MINIMUM(LRWC,PBWC)          07 00902
000133 000136 R
903     MOVBA8       PBWC,TEMP1          07 00903
000134 016144 A
000135 056165 A
904     CLB4       TZAB       TEMP1,CLBX          EXIT IF COUNT=0          07 00904
000136 016165 A
000137 001010 A
000140 000162 R
905     TSAB       RWFL,RB,CLBX          DONT CLEAR IF READ-BEFORE-WRITE FLAG SET          07 00905
000141 016154 A
000142 006403 A
000143 000162 R
906     TZAB       FRMT,CLB8          CLEAR TO ZEROS ON UNFORMATTED          V2 07 00906
000144 016063 A
000145 001010 A
000146 000150 R
000147 016203 A 907     LDA          BLNK2,B          CLEAR TO BLANKS ON FORMATTED          V2 07 00907
000150 056164 A 908     CLB8       STA          TEMP,B          V2 07 00908
000151 036025 A 909     LDX          BFWPT,B          V2 07 00909
910     *****

```



```

911 * FILL LOOP *
912 *****
000152 000152 R 913 CLBLP EQU *
000152 005144 A 914 IXR LOAD X AS BUFFER POINTER
915 MOVBAK TEMP,0 MOVE FILL WORD TO BUFFER
000153 016164 A 916 TXA
000154 055000 A 917 SUB BFWPT,B
000155 005041 A 918 SUB TEMP1,B
000156 146025 A 919 JAN CLRLP LOOP TILL DONE
000157 146165 A
000160 001004 A
000161 000152 R
000162 105065 A 920 CLBX POPJ EXIT
921 EJEC
922 *****
923 *
924 * CLOSE FILE (CLS)
925 *
926 * FUNCTION: TO PROCESS CALLS TO CLOSE AN RMD FILE
927 *
928 * ENTRY: DIRECT FROM RBE
929 * TEMP = OP = CCL CLOSE NORMAL RMD FILE
930 * CCB CLOSE BLOCKED(LOGICAL) FILE
931 * RETURN = CALL SEQUENCE ADDRESS
932 * RETURN(5) = ADDRESS OF UPDATE/LEAVE CLOSE PARAMETER
933 *
934 * EXIT : FCB REMOVED FROM CHAIN
935 * BUFFER FLUSHED IF LOGICAL FILE
936 *
937 * ERRORS: ER4 IF U NOT ON CHAIN
938 *
939 *****
941 *****
942 * SET UP CONTROL *
943 *****
000163 010432 A 944 CLS LDA MRS SET WRITE FLAG
000164 056154 A 945 STA RWFL,B
946 *****
947 * SEARCH FCB CHAIN FOR U *
948 *****
000165 105025 A 949 PUSHJ SCH SEARCH FCB CHAIN
000166 005625 R
000167 001010 A 950 JAZ ER4 ERROR 4/ FCB(U) NOT ON CHAIN /
000170 005364 R 951 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER U
000171 105025 A
000172 003754 R
000173 036016 A 952 LDX ANRB,B
953 MOVBAK UNIT,IOCNT INITIALIZE IOC CONTROL WORD
000174 016167 A
000175 055104 A
000176 036010 A 954 LDX ADFCB,B POINT X AT FCB
000177 015014 A 955 LDA 12,X
000200 006455 A 956 BT ARST+FLF,CLS20 TEST FOR LOGICAL FILE
000201 000225 R
000202 006454 A
000203 000225 R 957 BT ARST+FRM,CLS20 AND RMD
958 *****
959 * U IS RMD LOGICAL FILE *
960 *****
000204 006456 A 961 BT ARST+FPD,CLS10 ANY UNPOSTED DATA ?
000205 000213 R
962 MOVBAK PBSZ,0 YES. LOAD FCB(0) WITH PHYSICAL BUFF SIZE
000206 016143 A
000207 055000 A 963 PUSHJ PSB AND POST BUFFER
000210 105025 A
000211 004533 R
000212 036010 A 964 LDX ADFCB,B RESTORE X
965 CLS10 MOVBAK BD120,0 SET FCB(0) = 120 WORDS
000213 016201 A
000214 055000 A 966 TZAB LGDV,CLS15 LOGICAL RECORD OVERLAP ?
000215 016123 A
000216 001010 A
000217 000223 R 967 ABBBB PRECND,PBRC,PRECND YES. BUMP PHYSICAL RECORD NUMBER
000220 016145 A
000221 126142 A
000222 056145 A 968 CLS15 MOVBAK PRECND,3 SET FCB(3) = PHYSICAL RECORD NUMBER
000223 016145 A
000224 055003 A
969 *****
970 * CALL IOC TO CLOSE FILE *
971 *****
000225 036151 A 972 CLS20 LDX RETURN,B POINT X AT CALL SEQUENCE
000226 035005 A 973 LDX G,X POINT X AT UPDATE/LEAVE PARAMETER
000227 015000 A 974 LDA 0,X GET UPDATE/LEAVE PARAMETER
000230 001010 A 975 JAZ *+3
000231 000233 R

```



```

000232 010435 A 976 LDA BS12 SET FLAG FOR UPDATE 07 00976
000233 006110 A 977 DRAI 03400 MERGE IN IDC CLOSE SKELETON WORD V2 07 00977
000234 003400 A
000235 116167 A 978 DRA UNIT,B OR IN LUN 07 00978
000236 036016 A 979 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK 07 00979
000237 055104 A 980 STA IDCNT,X STORE IDC CONTROL WORD IN V$FORTIO 07 00980
000238 055104 A 981 DAX LNKCNT DECREMENT LINK COUNT 07 00981

000240 015120 A
000241 005311 A
000242 055120 A
000243 010464 A 982 LDA CID V2 07 00982
000244 006505 A 983 JSR PSJ,X CALL IDC V2 07 00983
000245 004563 R
000246 036010 A 984 LDX ADFCB,B POINT X AT FCB 07 00984
000247 016154 A 985 TRAB RWFL,LF,CLS30 LOGICAL FILE ? 07 00985

000250 006441 A
000251 000254 R
000252 016122 A 986 MOVBA LRSZ,0 YES. RESTORE LOGICAL REC SIZE IN FCB(0) 07 00986
000253 055000 A

987 ***** 07 00987
988 * TAKE FCB OFF CHAIN * 07 00988
989 ***** 07 00989
000254 015012 A 990 CLS30 LDA 10,X GET FORWARD LINK 07 00990
000255 036146 A 991 LDX PRLINK,B HOOK TO PREVIOUS LINK 07 00991
000256 055012 A 992 STA 10,X 07 00992
993 ***** 07 00993
994 * EXIT * 07 00994
995 ***** 07 00995
000257 010422 A 996 LDA CEX 07 00996
997 PUSHF PUSH EXIT OF ONTO V$FORTIO STACK 07 00997

000260 036016 A
000261 035000 A
000262 005344 A
000263 055000 A
000264 005041 A
000265 036016 A
000266 055000 A
000267 001000 A 998 JMP CAN EXIT TO V$FORTIO 07 00998
000270 000065 R

999 EJEC 07 00999
1000 ***** 07 01000
1001 * 07 01001
1002 * 4 - W O R D D I V I D E B Y 1 0 ( D 1 0 ) * 07 01002
1003 * 07 01003
1004 * FUNCTION: TO DIVIDE A 4-WORD NUMBER BY 10 * 07 01004
1005 * 07 01005
1006 * ENTRY: ACC = DIVIDEND * 07 01006
1007 * 07 01007
1008 * EXIT : ACC = ACC/10 * 07 01008
1009 * 07 01009
1010 ***** 07 01010
000271 005024 A 1012 D10 TBX LOAD X AS BASE REGISTER 07 01012
000272 005001 A 1013 TZA CLEAR HIGH-ORDER WORD OF DIVIDEND 07 01013
000273 025003 A 1014 LDB ACC,X 07 01014
000274 170471 A 1015 DIV TEN ACC(0)=ACC(0)/10 07 01015
000275 065003 A 1016 STB ACC,X 07 01016
000276 025004 A 1017 LDB ACC+1,X 07 01017
000277 170471 A 1018 DIV TEN ACC(1)=(ACC(1)+REM(0))/10 07 01018
000300 065004 A 1019 STB ACC+1,X 07 01019
000301 025005 A 1020 LDB ACC+2,X 07 01020
000302 170471 A 1021 DIV TEN ACC(2)=(ACC(2)+REM(1))/10 07 01021
000303 065005 A 1022 STB ACC+2,X 07 01022
000304 025006 A 1023 LDB ACC+3,X 07 01023
000305 170471 A 1024 DIV TEN ACC(3)=(ACC(3)+REM(2))/10 07 01024
000306 065006 A 1025 STB ACC+3,X 07 01025
000307 005042 A 1026 TXB RESTORE BASE REGISTER B 07 01026
000310 105065 A 1027 PUPJ AND EXIT FG 07 01027

1028 EJEC 07 01028
1029 ***** 07 01029
1030 * 07 01030
1031 * P R O C E S S D / E / F O U T P U T D E S C R I P T O R S * 07 01031
1032 * 07 01032
1033 * ( D E F ) * 07 01033
1034 * 07 01034
1035 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTORS: SRDW,D * 07 01035
1036 * SREW,D * 07 01036
1037 * SRFW,D * 07 01037
1038 * SRGW,D * 07 01038
1039 * 07 01039
1040 * ENTRY: A = INTEGER FIELD COUNT * 07 01040
1041 * 07 01041
1042 * EXIT : DIRECT TO DNF * 07 01042
1043 * PTFW = 1 = ' ' FLAG * 07 01043
1044 * IF A.GE.0 IFW = A = INTEGER FIELD WIDTH * 07 01044
1045 * IF A.LT.0 ZFW = -A = ZERO FILL FIELD WIDTH * 07 01045
1046 * 07 01046
1047 ***** 07 01047
000311 001004 A 1049 DEF JAN DEF4 IS A .GE. ZERO ? 07 01049
000312 000316 R
000313 056100 A 1050 STA IFW,B YES. STORE AS INTEGER FIELD WIDTH 07 01050

```



```

000314 001000 A 1051      JMP      DEF8                      07 01051
000315 000321 R
000316 003211 A 1052  DEF4  CPA                      A NEGATIVE          07 01052
000317 005111 A 1053      IAR
000320 056176 A 1054      STA      ZFW,B                    LOAD LEADING ZERO FILL COUNT 07 01054
000321 046147 A 1055  DEF8  INR      PTFW,B                D/E/F HAVE A "."          07 01055
000322 001000 A 1056      JMP      ONF                      EXIT TO OUTPUT NUMERIC FIELD 07 01056
000323 002502 R
1057      EJEC                      07 01057
1058 *****
1059 *
1060 *   P R O C E S S   D / E   O U T P U T   D E S C R I P T O R S   * 07 01060
1061 *
1062 *           ( D E D )
1063 *
1064 *   FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTORS: SRDW.D  * 07 01064
1065 *                                           SREW.D  * 07 01065
1066 *                                           SRGW.D  * 07 01066
1067 *
1068 *   ENTRY: DIRECT FROM FRS
1069 *           TO DOUT FOR 'D' FORMAT DESCRIPTOR
1070 *           TO EDUT FOR 'E' FORMAT DESCRIPTOR
1071 *           TO EDUT FOR 'G' FORMAT DESCRIPTOR
1072 *           S = SCALE FACTOR
1073 *
1074 *   EXIT : DIRECT TO DEF
1075 *           A = S
1076 *           DEXP = DEXP - S = DECIMAL EXPONENT
1077 *           XFL = 1 = EXPONENT FIELD FLAG
1078 *           XFW = 4 = EXPONENT FIELD WIDTH
1079 *           IF S .GT. 0, DT = MAX(0,DT-S+1)
1080 *
1081 *****
000324 R 1083  DOUT  EQU      *
000324 R 1084  EDUT  EQU      *
1085      MOVBA B D,COUNT          $SET SIGNIFICANT DIGIT COUNT TO D 07 01085
000324 016054 A
000325 056052 A
1086      TZAB   S,DED10          EXIT IF NO SCALE FACTOR          07 01086
000326 016155 A
000327 001010 A
000330 000346 R
000331 001004 A 1087      JAN      DECS                      07 01087
000332 000344 R
000333 046052 A 1088      INR      COUNT,B                    SCALE FACTOR IS +. BUMP COUNT TO D+1 07 01088
000334 146054 A 1089      SUB      D,B
000335 005311 A 1090      DAR
000336 001004 A 1091      JAN      DEO10                    OK IF D.GE.S                07 01091
000337 000346 R
1092      MOVBA B S,COUNT          OTHERWISE, GET S SIGNIFICANT DIGITS 07 01092
000340 016155 A
000341 056052 A
000342 001000 A 1093      JMP      DEO10                      07 01093
000343 000346 R
000344 126056 A 1094  DECS  ADD      DT,B                    SCALE FACTOR IS -. SET COUNT TO DT-S 07 01094
000345 056052 A 1095      STA      COUNT,B
1096  DEO10  PUSHJ   RND                    ROUND DECIMAL FIELD          V2 07 01096
000346 105025 A
000347 005512 R
000350 046173 A 1098      INR      XFL,B                      'D' AND 'E' BOTH HAVE EXPONENT FIELDS 07 01098
000351 016055 A 1099      SUTBBB  DEXP,S,DEXP                SET DEXP = DEXP - S        07 01099
000352 146155 A
000353 056055 A
1100      MOVPA B FOUR,XFW          EXPONENT FIELD IS 4 CHARS WIDE 07 01100
000354 010423 A
000355 056174 A
000356 016155 A 1101      LDA      S,B
000357 001004 A 1102      JAN      DEF
000360 000311 R
000361 001010 A 1103      JAZ      DEF                      S .GT. 0 ?                  07 01103
000362 000311 R
000363 016056 A 1104      LDA      DT,B                      YES                          07 01104
000364 146155 A 1105      SUB      S,B
000365 005111 A 1106      IAR
000366 001002 A 1107      JAP      *+3                      SET DT = MAX(0,DT-S+1)     07 01107
000367 000371 R
000370 005001 A 1108      TZA
000371 056056 A 1109      STA      DT,B
000372 016155 A 1110      LDA      S,B                      EXIT WITH A = S            07 01110
000373 001000 A 1111      JMP      DEF                      PROCESS S                   07 01111
000374 000311 R
1112      EJEC                      07 01112
1113 *****
1114 *
1115 *   P R O C E S S   F   O U T P U T   D E S C R I P T O R   ( F O U )   * 07 01115
1116 *
1117 *   FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTOR: SRFW.D  * 07 01117
1118 *
1119 *   ENTRY: DIRECT FROM FRS
1120 *           DEXP = DECIMAL EXPONENT
1121 *           S = SCALE FACTOR
1122 *

```







```

1203 *****
1204 * TEST CHAR *
1205 *****
000462 016065 A 1206 LDA FCODE,B RELOAD FORMAT CHARACTER CODE
000463 006402 A 1207 BT ASET+CM,FRS10 TEST FOR ','
000464 000453 R
000465 006403 A 1208 BT ASET+LP,FRS2 TEST FOR '('
000466 000424 R
000467 006412 A 1209 BT ASET+RP,FRS15 TEST FOR ')'
000470 000511 R
000471 006404 A 1210 BT ASET+MN,FRS20 TEST FOR '-'
000472 000567 R
000473 006413 A 1211 BT ASET+SL,FRS70 TEST FOR '/'
000474 001023 R
000475 006405 A 1212 BT ASET+NM,FRS25 TEST FOR NUMERIC
000476 000574 R
000477 006400 A 1213 BT ASET+AL,FRS35 TEST FOR ALPHA
000500 000635 R
000501 046150 A 1214 INR QFL,B MUST BE QUOTE. SET FLAG
1215 MOVPA8 BR15,N SET FIELD WIDTH TO MAX INTEGER
000502 010460 A
000503 056125 A
000504 056171 A 1216 STA NT,B V2 07 01216
1217 MOVPA8 EIGHT,FDLKEY LOAD 'H' DESCRIPTOR KEY
000505 010424 A
000506 056061 A
000507 001000 A 1218 JMP FRS60 EXIT
000510 001001 R
1219 *****
1220 * ')' INPUT *
1221 *****
000511 016012 A 1222 FRS15 LDA AGPAR,B
000512 126141 A 1223 ADD PARLV,B
000513 005014 A 1224 TAX POINT X AT '(' GROUP REPEAT COUNT
1225 DAX 0 DECREMENT DYNAMIC '(' REPEAT COUNT
000514 015000 A
000515 005311 A
000516 055000 A
000517 001016 A 1226 JANZ FRS19 IS '(' GROUP FINISHED ?
000520 000563 R 1227 DAB PARLV YES. DECREMENT '(' LEVEL
000521 016141 A
000522 005311 A
000523 056141 A
000524 001016 A 1228 JANZ FRS75 CONTINUE SCAN IF NOT LAST ')'
000525 001027 R
1229 *****
1230 * PROCESS RIGHTMOST ')' *
1231 *****
000526 005001 A 1232 ZAB FDLKEY DISABLE PXF MODE TEST
000527 056061 A
1233 PUSHJ ENL GET ADDRESS OF NEXT LIST ITEM V2 07 01233
000530 105025 A
000531 001447 R 1234 SUTBBB ITEMAD,ITMINC,ITEMAD REINITIALIZE LIST CONTROL
000532 016113 A
000533 146113 A
000534 056113 A 1235 ADBBB ITEMWC,ITMINC,ITEMWC
000535 016114 A
000536 126115 A
000537 056114 A 1236 PUSHJ RCL RECYCLE LOGICAL BUFFER V2 07 01236
000540 105025 A
000541 005167 R
000542 016117 A 1237 LDA LISTFL,B
000543 001010 A 1238 JAZ ER1 ERROR 1/ NO DATA XFER DESCRIPTORS /
000544 005367 R 1239 ZAB LISTFL CLEAR LIST DATA XFER FLAG
000545 005001 A
000546 056117 A 1240 LDX AGPAR,B
000547 036012 A 1241 IXR IXR POINT X AT '(' LEVEL 1
000550 005144 A 1242 INR PARLV,B ALSO LEVEL COUNTER
000551 046141 A 1243 LDA GSRPC-GDRPC,X
000552 015006 A 1244 STA 0,X RELOAD LEVEL 1 DYNAMIC REPEAT COUNT
000553 055000 A 1245 LDA GSRPC-GDRPC+1,X
000554 015007 A 1246 JAZ FRS19 IS THERE A 2ND LEVEL ?
000555 001010 A
000556 000563 R
000557 046141 A 1247 INR PARLV,B YES
000560 005144 A 1248 IXR IXR USE 2ND '(' LEVEL
000561 015006 A 1249 LDA GSRPC-GDRPC,X GET STATIC REPEAT COUNT
000562 055000 A 1250 STA 0,X RELOAD DYNAMIC REPEAT COUNT
000563 015003 A 1251 FRS19 LDA GFRPT-GDRPC,X
000564 056062 A 1252 STA FRPT,B BACK UP SCAN TO '('
000565 001000 A 1253 JMP FRS5 RESUME SCAN AFTER CORRESPONDING '('
000566 000441 R
1254 *****
1255 * '-' INPUT *
1256 *****
000567 046157 A 1257 FRS20 INR SGFL,B SET SIGN FLAG
1258 PUSHJ INF INPUT NON-BLANK FOLLOWING '-' V2 07 01258

```



```

000570 105025 A
000571 001756 R
000572 006445 A 1259          BT          ARST+NM,ER1  ERROR 1/ NOT NUMERIC /          07 01259
000573 005367 R
1260 *****
1261 * NUMERIC CHAR INPUT *          07 01261
1262 *****          07 01262
1263 FRS25  PUSHJ  IFF          INPUT NUMERIC FORMAT FIELD          V2 07 01263

000574 105025 A
000575 001722 R
000576 006150 A 1264          ANAI      0211          ENABLE 'P'/'C'/ALPHA          V2 07 01264
000577 000211 A
000600 001010 A 1265          JAZ      ER1          ERROR 1/ ILLEGAL TERMINATOR /          07 01265
000601 005367 R
000602 016065 A 1266          LDA      FCODE,B          07 01266
000603 006447 A 1267          BT      ARST+PS,FRS30      TEST IF TERMINATOR IS 'P'          07 01267
000604 000622 R
1268 *****          07 01268
1269 * DESCRIPTOR HAS 'P' FIELD *          07 01269
1270 *****          07 01270
000605 046156 A 1271          INR      SCF,B          SET SCALE FACTOR FLAG          07 01271
000606 016126 A 1272          LDA      NFF,B          GET SCALE FACTOR ABS VALUE IN A          07 01272
000607 036157 A 1273          LDX      SGFL,B          GET SIGN FLAG IN X          07 01273
000610 001040 A 1274          JXZ      *+4          07 01274
000611 000614 R
000612 005211 A 1275          CPA          NEGATE A IF SIGN FLAG SET          07 01275
000613 005111 A 1276          IAR          07 01276
000614 056155 A 1277          STA      S,B          LOAD SCALE FACTOR S          07 01277
000615 006010 A 1278          LDAI     041          V2 07 01278
000616 000041 A
000617 056053 A 1279          STA      CVFL,B          ENABLE ONLY NUMERIC/ALPHA          V2 07 01279
000620 001000 A 1280          JMP      FRS10          07 01280
000621 000453 R
1281 *****          07 01281
1282 * NUMERIC - NOT SCALE FACTOR *          07 01282
1283 *****          07 01283
1284 FRS30  TNZAB  SGFL,ER1  ERROR 1/ '-' PRECEDES REPEAT COUNT /          07 01284

000622 016157 A
000623 001016 A
000624 005367 R
1285          MOVBAB  NFF,R          LOAD REPEAT COUNT          07 01285

000625 016126 A
000626 056125 A
000627 056171 A 1286          STA      HT,B          ALSO AS FIELD WIDTH FOR H/X          07 01286
000630 016065 A 1287          LDA      FCODE,B          07 01287
000631 006403 A 1288          BT      ASET+LP,FRS2  TEST FOR 'C'          07 01288
000632 000424 A
000633 006440 A 1289          BT      ARST+AL,ER1  ERROR 1/ TERMINATOR NOT ALPHA /          07 01289
000634 005367 R
1290 *****          07 01290
1291 * ALPHABETIC CHAR INPUT *          07 01291
1292 *****          07 01292
000635 000635 R 1293 FRS35  EQU      *          V2 07 01293
000635 016064 A 1294          LDA      FCHAR,B          GET FORMAT DESCRIPTOR CHARACTER          V2 07 01294
1295          IFF      NUC          FG 07 01295
1296          GOTO    NV2NUC          FG 07 01296
1297          IFT      VII          FG 07 01297
1298          OME    MAP,V$ST0      SET EXEC STATE TO 00          V2 07 01298
1299 NV2NUC  CONT          FG 07 01299
1300          LDXI    FRSJUT-FRSCHT-1  GET TABLE COUNT IN X          V2 07 01300

000636 006030 A
000637 000012 A
000640 006145 A 1301 FRSL1  SUBE    FRSCHT,X          V2 07 01301
000641 001042 R
000642 001010 A 1302          JAZ      FRS40          MATCH ?          07 01302
000643 000651 R
1303          IFF      NUC          FG 07 01303
1304          GOTO    NV2NUC          FG 07 01304
1305          IFT      VII          FG 07 01305
1306          GOTO    VIINUC          FG 07 01306
1307 NV2NUC  CONT          FG 07 01307
1308          JXZ      ER1          ERROR 1/ ILLEGAL FORMAT CHAR /          V2 07 01308

000644 001040 A
000645 005367 R
1309          GOTO    NV2NUC          FG 07 01309
1310          VIINUC  CONT          FG 07 01310
1311          JXZ      FRS39          V2 07 01311
1312 NV2NUC  CONT          FG 07 01312
000646 005344 A 1313          BXR          DROP TABLE COUNT          V2 07 01313
000647 001000 A 1314          JMP      FRSL1          AND CONTINUE COMPARISON          07 01314
000650 000640 R
1315          IFF      NUC          FG 07 01315
1316          GOTO    NV2NUC          FG 07 01316
1317          IFF      VII          FG 07 01317
1318          GOTO    NV2NUC          FG 07 01318
1319 FRS39  OME    MAP,V$ST3      SET EXEC STATE TO NN          V2 07 01319
1320          JMP      FRI          V2 07 01320
1321 NV2NUC  CONT          FG 07 01321
000651 R 1322 FRS40  EQU      *          V2 07 01322
1323          IFF      NUC          FG 07 01323
1324          GOTO    NV2NUC          FG 07 01324
1325          IFT      VII          FG 07 01325
1326          OME    MAP,V$ST3      SET EXEC STATE TO NN          V2 07 01326
1327 NV2NUC  CONT          FG 07 01327
000651 005041 A 1328          TXA          V2 07 01328

```



```

000652 056061 A 1329 STA FDLKEY,B SAVE AS DESCRIPTOR KEY 07 01329
1330 *****
1331 * SCAN BEYOND DESCRIPTOR LETTER * 07 01330
1332 ***** 07 01331
1333 TZAB SCF,FRS45 DOES DESCRIPTOR HAVE A SCALE FACTOR ? 07 01332
000653 016156 A 1334 LDA FDLKEY,B YES 07 01334
000654 001010 A 1335 SUB FOUR 07 01335
000655 000662 R 1336 JAP ER1 ERROR 1/ ILLEGAL SCALE FACTOR / 07 01336
000656 016061 A 1337 FRS45 LDA FDLKEY,B 07 01337
000657 140423 A 1338 SUB EIGHT 07 01338
000658 001002 A 1339 JAN FRS46 07 01339
000659 005367 R 1340 SUB TWO 07 01340
000660 016061 A 1341 JANZ FRS60 SCAN FINISHED FOR H/X 07 01341
000661 001016 A 1342 LDA R,B 07 01342
000662 140422 A 1343 SUB TWO 07 01343
000663 001002 A 1344 JAP ER1 ERROR 1/ 'T' DESCRIPTOR HAS REPEAT COUNT 07 01344
000664 005367 R 1345 FRS46 PUSHJ INF INPUT NON-BLANK FORMAT CHARACTER V2 07 01345
000665 105025 A 1346 BT ARST+NM,ER1 ERROR 1/ NON-NUM AFTER DESCRIPTOR LETTER / 07 01346
000666 001756 R 1347 PUSHJ IFF INPUT NUMERIC FIELD V2 07 01347
000667 006445 A 1348 LDA NFF,B 07 01348
000668 005367 R 1349 STA W,B LOAD FIELD WIDTH W 07 01349
000669 105025 A 1350 JAZ ER1 ERROR 1/ ZERO FIELD WIDTH / 07 01350
000670 001722 R 1351 LDA FDLKEY,B 07 01351
000671 016126 A 1352 SUB FOUR 07 01352
000672 056170 A 1353 JAN FRS47 CONTINUE SCAN FOR D/E/F/G 07 01353
000673 001010 A 1354 SUB FOUR 07 01354
000674 000733 R 1355 JAN FRS50 NO FRACTIONAL D FIELD FOR I/L/A V2 07 01355
000675 001000 A 1356 JMP FRS60 SCAN FINISHED FOR T 07 01356
000676 001001 R 1357 FRS47 LDA FCODE,B 07 01357
000677 016065 A 1358 BT ARST+PT,ER1 ERROR 1/ TERMINATOR NOT '.' / 07 01358
000678 006450 A 1359 PUSHJ INF INPUT NON-BLANK FORMAT CHARACTER V2 07 01359
000679 005367 R 1360 BT ARST+NM,ER1 ERROR 1/ NON-NUMERIC AFTER LETTER / 07 01360
000680 105025 A 1361 PUSHJ IFF INPUT NUMERIC FIELD V2 07 01361
000681 001722 R 1362 LDA NFF,B 07 01362
000682 001756 R 1363 STA D,B STORE DECIMAL FIELD WIDTH D 07 01363
000683 016126 A 1364 ***** 07 01364
000684 056054 A 1365 * DESCRIPTOR REQUIRES LIST ITEM * 07 01365
000685 ***** 07 01366
000686 1366 ***** 07 01366
000687 FRS50 PUSHJ GNL GET ADDRESS OF NEXT LIST ITEM/EXIT V2 07 01367
000688 105025 A 1368 INR LISTFL,B SET LIST FLAG 07 01368
000689 001447 R 1369 MOVBAB W,WT SET WT=W 07 01369
000690 046117 A 1370 MOVBAB D,DT SET DT=D 07 01370
000691 016170 A 1371 ZAB ACC CLEAR ACCUMULATOR ACC 07 01371
000692 056171 A 1372 STA ACC+1,B 07 01372
000693 016054 A 1373 STA ACC+2,B 07 01373
000694 056056 A 1374 STA ACC+3,B 07 01374
000695 056022 A 1375 STA ASFL,B CLEAR '*' FLAG 07 01375
000696 056055 A 1376 STA DEXP,B CLEAR DECIMAL EXPONENT 07 01376
000697 056100 A 1377 STA IFW,B CLEAR INTEGER FIELD WIDTH 07 01377
000698 056147 A 1378 STA PTFB,B CLEAR '.' FLAG 07 01378
000699 056157 A 1379 STA SGFL,B CLEAR SIGN FLAG 07 01379
000700 056173 A 1380 STA XFL,B CLEAR EXPONENT FIELD FLAG 07 01380
000701 056174 A 1381 STA XFW,B SET EXPONENT FIELD WIDTH TO ZERO 07 01381
000702 056176 A 1382 STA ZFW,B CLEAR ZERO FILL FIELD WIDTH 07 01382
000703 056166 A 1383 STA TERM,B CLEAR TERMINATING DIGIT V2 07 01383
000704 016002 A 1384 MOVBAB ABSCB,ASCB SET SCB TO BUFFER 07 01384
000705 056021 A 1385 LDA FDLKEY,B 07 01385
000706 016061 A 1386 SUB FIVE 07 01386
000707 140465 A 1387 JAP FRS60 EXIT ON NON-NUMERIC DESCRIPTOR 07 01387
000708 001001 R 1388 ***** 07 01388

```



```

1389 * NUMERIC DESCRIPTOR *
1390 *****
000766 005111 A 1391 IAR
000767 056156 A 1392 STA SCF,B DISABLE SCALE FACTOR FOR I INPUT
1393 TSAB RWFL,WR,FRS55 TEST READ OR WRITE V2 07 01393

000770 016154 A
000771 006411 A
000772 000777 R

1394 *****
1395 * READ *
1396 *****
000773 105025 A 1397 PUSHJ IXN INPUT EXTERNAL NUMERIC FIELD V2 07 01397
000774 001775 R
000775 001000 A 1398 JMP FRS60 07 01398
000776 001001 R

1399 *****
1400 * WRITE *
1401 *****
000777 105025 A 1402 FRS55 PUSHJ GNI GET NUMERIC LIST ITEM V2 07 01402
001000 001160 R

1403 *****
1404 * EXIT TO PROCESSOR *
1405 *****
001001 016061 A 1406 FRS60 LDA FDLKEY,B
001002 004241 A 1407 LRLA 1
001003 005014 A 1408 TAX SET X = DESCRIPTOR READ KEY
001004 016154 A 1409 LDA RWFL,B
001005 150432 A 1410 ANA WRS V2 07 01410
001006 003016 A 1411 XANZ INR BUMP KEY FOR WRITE V2 07 01411
001007 000550 R

1412 IFF NUC FG 07 01412
1413 GOTO NV2NUC FG 07 01413
1414 IFT VII FG 07 01414
1415 DME MAP,V$ST0 SET EXEC STATE TO 00 V2 07 01415
1416 NV2NUC CONT FG 07 01416
001010 006035 A 1417 LDXE FRSJT,X GET PROCESSOR ADDRESS FROM TABLE
001011 001055 R

1418 IFF NUC FG 07 01418
1419 GOTO NV2NUC FG 07 01419
1420 IFT VII FG 07 01420
1421 DME MAP,V$ST3 SET EXEC STATE TO NN V2 07 01421
1422 NV2NUC CONT FG 07 01422
001012 006705 A 1423 IJMP 0,X EXIT TO PROCESSOR
001013 000000 R

1424 *****
1425 * TEST REPEAT COUNT *
1426 *****
001014 016125 A 1427 FRS65 DAB R DECREMENT REPEAT COUNT
001015 005311 A
001016 056125 A
001017 001016 A 1428 JANZ FRS50 REPEAT DESCRIPTOR R TIMES 07 01428
001020 000733 R
001021 001000 A 1429 JMP FRS85 THEN RESUME SCAN 07 01429
001022 001031 R

1430 *****
1431 * PROCESS '/' *
1432 *****
001023 105025 A 1433 FRS70 PUSHJ RCL RECYCLE LOGICAL BUFFER V2 07 01433
001024 005167 R
001025 001000 A 1434 JMP FRS5 AND SCAN FORWARD FOR NEXT DESCRIPTOR 07 01434
001026 000441 R

1435 *****
1436 * PROCESS FIELD SEPARATOR *
1437 *****
001027 105025 A 1438 FRS75 PUSHJ IMF GET TERMINATING CHARACTER V2 07 01438
001030 001756 R
001031 016065 A 1439 FRS85 LDA FCODE,B GET CHAR CODE 07 01439
001032 006402 A 1440 BT ASET+CM,FRS5 TEST FOR ',' 07 01440
001033 000441 R
001034 006413 A 1441 BT ASET+SL,FRS70 TEST FOR '/' 07 01441
001035 001023 R
001036 006412 A 1442 BT ASET+RP,FRS15 TEST FOR '>' 07 01442
001037 000511 R
001040 001000 A 1443 JMP 2R1 ERROR 1/ ILLEGAL TERMINATOR / 07 01443
001041 005367 R

1444 *****
1445 * TABLE OF VALID FORMAT SPEC CHARS *
1446 *****
001042 001042 R 1447 FRSCHT EQU * V2 07 01447
001042 177777 A 1448 DATA -1 SRDW,B V2 07 01448
001043 177777 A 1449 DATA -1 SREW,B V2 07 01449
001044 177777 A 1450 DATA -1 SRFW,B V2 07 01450
001045 177776 A 1451 DATA -2 SRGW,B V2 07 01451
001046 177757 A 1453 DATA -021 RIW 07 01453
001047 000016 A 1455 DATA 016 RZW 07 01455
001050 000013 A 1456 DATA 013 RLW V2 07 01456
001051 177771 A 1457 DATA -7 RAW V2 07 01457
001052 177760 A 1459 DATA -020 NH... V2 07 01459

```



```

001053 000004 A 1460          DATA      4          NX
001054 000324 A 1461          DATA      0324         TN
1463 *****
1464 * JUMP TABLE *
1465 *****
001055 001055 R 1466 FRSJT EQU *
001056 003347 R 1467          PZE      DIN
001057 003347 R 1468          PZE      DOUT
001060 000324 R 1470          PZE      EIN
001061 003347 R 1471          PZE      EDUT
001062 000375 R 1472          PZE      FIN
001063 003347 R 1473          PZE      FOUT
001064 001502 R 1474          PZE      GIN
001065 003347 R 1475          PZE      GOUT
001066 001765 R 1476          PZE      IIN
001067 006207 R 1477          PZE      IDUT
001070 006207 R 1478          PZE      IOUT
001071 002262 R 1479          PZE      ZIN
001072 002314 R 1480          PZE      ZOUT
001073 000000 R 1481          PZE      LIN
001074 000000 R 1482          PZE      LOUT
001075 001532 R 1483          PZE      AIN
001076 001532 R 1484          PZE      AOUT
001077 006175 R 1485          PZE      HIN
001100 006175 R 1486          PZE      HOUT
001101 005763 R 1487          PZE      XIN
001102 005763 R 1488          PZE      XOUT
1489          PZE      TIN
1490          PZE      TOUT
1491          EJECT
1492 *****
1493 *
1494 *          GET BUFFER ADDRESS ( G B A )
1495 * FUNCTION: TO GET ADDRESS OF NEXT BUFFER WORD, AND HANDLE CROSSING
1496 *          OF LOGICAL AND PHYSICAL RECORD BOUNDARIES
1497 *
1498 * ENTRY: PBWC = COUNT OF WORDS REMAINING IN PHYSICAL BUFFER
1499 *          LRWC = COUNT OF WORDS REMAINING IN LOGICAL BUFFER
1500 *          BFWPT = ADDRESS OF PREVIOUS BUFFER WORD
1501 *          RWFL(TR) = 1 ON TERMINATE CALL
1502 *
1503 * EXIT : IF PBWC .LE. 0
1504 *          RCP CALLED TO RECYCLE PHYSICAL BUFFER
1505 *
1506 *          BFWPT = BFWPT+1
1507 *
1508 *          IF LRWC .LE. 0
1509 *              LRECNO = LRECNO+1
1510 *              ALBF = BFWPT
1511 *              LRWC = LRSZ
1512 *              BFPT = 0
1513 *              CLB CALLED ON WRITE IF TR=0
1514 *              PBWC = PBWC-1
1515 *              LRWC = LRWC-1
1516 *
1517 *****
1519 *****
1520 * TEST FOR END OF PHYSICAL BUFFER *
1521 *****
001103 016144 A 1522 GBA LDA PBWC,B
001104 005311 A 1523 DAR
001105 001002 A 1524 JAP GBAS0
001106 001114 R 1525 TSAB RWFL,EC,GBAS0
001107 016154 A
001110 006412 A
001111 001152 R
1526 *****
1527 * END OF PHYSICAL BUFFER *
1528 *****
1529 PUSHJ RCP RECYCLE PHYSICAL BUFFER
001112 105025 A
001113 005225 R
1530 *****
1531 * TEST FOR END OF LOGICAL RECORD *
1532 *****
001114 046025 A 1533 GBAS0 INR BFWPT,B BUMP BUFFER WORD POINTER
001115 016123 A 1534 LDA LRWC,B
001116 005311 A 1535 DAR
001117 001002 A 1536 JAP GBAS0
001120 001143 R
1537 *****
1538 * END OF LOGICAL RECORD *
1539 *****
001121 046121 A 1540 INR LRECNO,B BUMP LOGICAL RECORD NUMBER
001122 016025 A 1541 MOVAB BFWPT,ALBF UPDATE LOGICAL BUFFER ADDRESS
001123 056027 A
1542 GBAS5 MOVAB LRSZ,LRWC RELOAD REMAINING WORD COUNT
001124 016122 A
001125 056123 A
1543 ZAB BFPT CLEAR BUFFER CHARACTER POINTER
001126 005001 A

```



```

001127 056026 A      1544      TRAB      RWFL,WR,GBA70      WRITE ?      07 01544
001130 016134 A
001131 006451 A
001132 001143 R
001133 006404 A      1545      BT      ASET+TR,GBA70      YES. TERMINATE ?      07 01545
001134 001143 R
      001135 R      1546 GBA60 EQU      *
      1547      DAB      BFWPT      NO. SET UP CL3      V2 07 01546
      V2 07 01547
001135 016025 A
001136 005311 A
001137 056025 A      1548      PUSHJ   CLB      CLEAR LOGICAL BUFFER      V2 07 01548
001140 105025 A
001141 000127 R
001142 046025 A      1549      INR     BFWPT,B      RESTORE BFWPT      V2 07 01549
      1550 *****
      1551 * DECREMENT REMAINING WORD COUNTERS *      07 01550
      1552 *****
      1553 GBA70 DAB      PBWC      07 01551
      07 01552
      07 01553
001143 016144 A
001144 005311 A
001145 056144 A      1554      DAB      LRWC      07 01554
001146 016123 A
001147 005311 A
001150 056123 A      1555      POPJ      EXIT      FG 07 01555
001151 105065 A      1556 GBA80 MOVEAB PESZ,PBWC      RESET ENCODE/DECODE POINTERS      PD 07 01556
001152 016143 A
001153 056144 A      1557      MOVEAB  ALBF,BFWPT      PD 07 01557
001154 016027 A
001155 056025 A
001156 001000 A      1558      JMP      GBA55      PD 07 01558
001157 001124 R
      1559 EJEJ      07 01559
      1560 *****
      1561 *
      1562 *      GET NUMERIC ITEM ( GNI )
      1563 *
      1564 * FUNCTION: TO GET A LIST ITEM AND CONVERT IT TO A CHAR STRING
      1565 *
      1566 * ENTRY: ITEMAD = ADDRESS OF LIST ITEM
      1567 *      ITMODE = MODE OF LIST ITEM:
      1568 *      = 0 1-WORD INTEGER/LOGICAL
      1569 *      = 1 2-WORD INTEGER/LOGICAL
      1570 *      = 2 REAL
      1571 *      = 3 DOUBLE PRECISION
      1572 *      = 4 COMPLEX
      1573 *      > 5 DOUBLE PRECISION INTEGER
      1574 *
      1575 * EXIT : CHB = FRACTIONAL PART(NORMALIZED STRING OF DECIMAL DIGITS)
      1576 *      DEXP = DECIMAL EXPONENT(=1 IF CHB=0)
      1577 *      SGFL = 0 POSITIVE ITEM
      1578 *      = -1 NEGATIVE ITEM
      1579 *
      1580 * ERRORS: ER3 IF INTEGER ITEM = 2**15
      1581 *
      1582 *****
      1583 *****
001160 036113 A      1584 GNI      LDX      ITEMAD,B      POINT X AT ITEM
001161 015000 A      1585      LDA      0,X      GET 1ST WORD OF ITEM
001162 004317 A      1586      ASRA    15
001163 056157 A      1587      STA      SGFL,B      SAVE SIGN
001164 016116 A      1588      LDA      ITMODE,B
001165 140422 A      1589      SUB     TWO
001166 001002 A      1590      JAP     GNI4      TEST FOR INTEGER LIST ITEM
001167 001204 R
      1591 *****
      1592 * INTEGER ITEM *
      1593 *****
001170 015000 A      1594      LDA      0,X      GET INTEGER
001171 001002 A      1595      JAP     GNI2      V2 07 01594
      07 01595
001172 001177 R
001173 005211 A      1596      CPA
001174 005111 A      1597      IAR
001175 001004 A      1598      JAN     ER3      ERROR 3/ INVALID INTEGER /
001176 005365 R
001177 056003 A      1599 GNI2    STA      ACC,B      STORE IN ACC
      1600      MOVFAB DIS,BEXP    LOAD INTEGER BIAS AS BINARY EXPONENT      V2 07 01599
      07 01600
001200 010472 A
001201 056024 A
001202 001000 A      1601      JMP     GNT10
001203 001315 R
001204 005311 A      1602 GNI4    DAR
001205 001010 A      1603      JAZ     GNI8      DOUBLE PRECISION #
001206 001240 R
001207 140422 A      1604      SUB     TWO      NO
001210 001010 A      1605      JAZ     GNI9      TEST DP INTEGER
001211 001263 R
      1606 *****
      1607 * REAL ITEM *

```



Address	Code	Label	Op	Op2	Description	Line	Page
1608					*****	07	01608
001212	015000	A	LDA	0,X	GET 1ST WORD OF REAL ITEM	07	01609
001213	001002	A	JAP	*+3	CONVERT TO ABS	07	01610
001214	001216	R					
001215	005211	A	CPA		SAVE	07	01611
001216	056164	A	STA	TEMP,B	SAVE	07	01612
001217	015001	A	LDA	1,X	GET 2ND WORD OF REAL ITEM	07	01613
001220	150460	A	ANA	BR15	CLEAR B15	D.1	07 01614
001221	005024	A	TBX		LOAD X AS BASE REGISTER	07	01615
001222	005012	A	TAB		2ND WORD TO B-REG	07	01616
001223	015164	A	LDA	TEMP,X	1ST WORD TO A-REG	07	01617
001224	063164	A	STB	TEMP,X	SAVE 2ND WORD	07	01618
001225	004507	A	LASR	7	GET BINARY EXPONENT	07	01619
001226	140430	A	SUB	BXBIAS	UNBIAS IT	V2	07 01620
001227	055024	A	STA	BEXP,X	SAVE	07	01621
001230	065003	A	STB	ACC,X	STORE 1ST MANTISSA WORD	07	01622
001231	015164	A	LDA	TEMP,X	RESTORE 2ND WORD	07	01623
001232	005002	A	TZB		CLEAR B	07	01624
001233	004507	A	LASR	7		07	01625
001234	065004	A	STB	ACC+1,X	SAVE	07	01626
001235	005042	A	TXB		RESTORE BASE REGISTER B	07	01627
001236	001000	A	JMP	GNI10		07	01628
001237	001315	R					
1629					*****	07	01629
1630					* DOUBLE PRECISION ITEM *	07	01630
1631					*****	07	01631
001240	015001	A	GNI8	LDA 1,X	GET 1ST MANTISSA WORD	07	01632
001241	004317	A	ASRA	15		07	01633
001242	056157	A	STA	SGFL,B	GET SIGN	07	01634
001243	015001	A	LDA	1,X	RELOAD WORD 1	07	01635
001244	001002	A	JAP	*+3	IS ITEM NEGATIVE ?	V2	07 01636
001245	001247	R					
001246	005211	A	CPA		YES. GET ABS VALUE	07	01637
001247	056003	A	STA	ACC,B	LOAD WORD 0 OF ACCUMULATOR	07	01638
001250	015000	A	LDA	0,X	GET BINARY EXPONENT	07	01639
001251	140430	A	SUB	BXBIAS	UNBIAS IT	V2	07 01640
001252	056024	A	STA	BEXP,B	SAVE	07	01641
001253	015002	A	LDA	2,X	GET WORD 2	D.1	07 01642
001254	150460	A	ANA	BR15	CLEAR B15	D.1	07 01643
001255	056004	A	STA	ACC+1,B		D.1	07 01644
001256	015003	A	LDA	3,X	GET WORD 3	D.1	07 01645
001257	150460	A	ANA	BR15	CLEAR B15	D.1	07 01646
001260	056005	A	STA	ACC+2,B		D.1	07 01647
001261	001000	A	JMP	GNI10		07	01648
001262	001315	R					
1649					*****	07	01649
1650					* DP INTEGER *	07	01650
1651					*****	07	01651
001263	006010	A	GNI9	LDAI 30		07	01652
001264	000036	A					
001265	056024	A	STA	BEXP,B	LOAD BIAS IN BINARY EXPONENT	07	01653
001266	015001	A	LDA	1,X	GET 2ND WORD	07	01654
001267	150460	A	ANA	BR15	CLEAR HIGH BIT	07	01655
001270	050000	A	STA			07	01656
001271	056004	A	STA	ACC+1,B	STORE	07	01657
001272	015000	A	LDA	0,X	GET 1ST WORD	07	01658
001273	056003	A	STA	ACC,B	SAVE	07	01659
001274	001002	A	JAP	GNI10	NEGATIVE #	07	01660
001275	001315	R					
001276	005211	A	CPA		YES. TAKE 1-COMP	07	01661
001277	056003	A	STA	ACC,B		07	01662
001300	016004	A	LDA	ACC+1,B		07	01663
001301	007400	A	RDF			07	01664
001302	001016	A	JANZ	GNI9A	IS WORD 2 ZERO #	07	01665
001303	001311	R					
001304	046003	A	INR	ACC,B	YES. 2-COMP WORD 1	07	01666
001305	001001	A	JOF	ERR	ERROR 3/INVALID NUMBER/	07	01667
001306	005365	A					
001307	001000	A	JMP	GNI10		07	01668
001310	001315	R					
001311	005211	A	GNI9A	CPA	TAKE 2-COMP OF WORD 2	07	01669
001312	005111	A	IAR			07	01670
001313	150460	A	ANA	BR15		07	01671
001314	056004	A	STA	ACC+1,B		07	01672
1673					*****	07	01673
1674					* TEST FOR ZERO *	07	01674
1675					*****	07	01675
001315	016003	A	GNI10	LDA ACC,B		07	01676
001316	116004	A	DRA	ACC+1,B		07	01677
001317	116005	A	DRA	ACC+2,B		07	01678
001320	001016	A	JANZ	GNI11	IS ITEM = ZERO ?	07	01679
001321	001326	R					
001322	005101	A	INCR	1	YES	07	01680
001323	056055	A	STA	BEXP,B	YES. SET DECIMAL EXPONENT TO 1	07	01681
001324	001000	A	JMP	GNI50		07	01682
001325	001431	R					
1683					*****	07	01683
1684					* CONVERT TO NORMALIZED FRACTION AND DECIMAL EXPONENT *	07	01684
1685					*****	07	01685
001326	105025	A	GNI11	PUSHJ BR0	NORMALIZE MANTISSA	V2	07 01686
001327	002402	R					
001330	016024	A	LDA	BEXP,B		07	01687



Address	Op	Op	Op	Op	Op	Op	Op	Op	Op	
001331	001010	A	1688	JAZ	GNI50	FINISHED IF BINARY EXPONENT = ZERO		07	01688	
001332	001431	R								
001333	001004	A	1689	JAN	GNI20			07	01689	
001334	001342	R								
			1690			*****		07	01690	
			1691			* (ACC,BEXP).GE.1 DIVIDE BY 10 *		07	01691	
			1692			*****		07	01692	
001335	046055	A	1693	INR	BEXP,B	BUMP DECIMAL EXPONENT		07	01693	
			1694	PUSHJ	D10	ACC = ACC/10	V2	07	01694	
001336	105025	A								
001337	000271	R								
001340	001000	A	1695	JMP	GNI11	LOOP TILL DONE		07	01695	
001341	001326	R								
			1696			*****		07	01696	
			1697			* (ACC,BEXP).LT.1 TEST IF .GE. .1 *		07	01697	
			1698			*****		07	01698	
001342	120464	A	1699	GNI20	ADD	THREE		07	01699	
001343	001004	A	1700	JAN	GNI30	(ACC,BEXP) .LT. .1 IF BEXP .LT. -3		07	01700	
001344	001414	R								
001345	001016	A	1701	JANZ	GNI25	(ACC,BEXP) .GT. .1 IF BEXP .GT. -3		07	01701	
001346	001405	R								
001347	016055	A	1702	LDA	BEXP,B			07	01702	
001350	005311	A	1703	DAR				07	01703	
001351	001002	A	1704	JAP	GNI25	DONT OSCILLATE		07	01704	
001352	001405	R								
001353	016003	A	1705	LDA	ACC,B			07	01705	
001354	006140	A	1706	SUBI	063146		V2	07	01706	
001355	063146	A								
001356	001004	A	1707	JAN	GNI30	TEST WORD 0.LT..1		07	01707	
001357	001414	R								
001360	001016	A	1708	JANZ	GNI25			07	01708	
001361	001405	R								
001362	016004	A	1709	LDA	ACC+1,B			07	01709	
001363	006140	A	1710	SUBI	031463		V2	07	01710	
001364	031463	A								
001365	001004	A	1711	JAN	GNI30	TEST WORD 1.LT..1		07	01711	
001366	001414	R								
001367	001016	A	1712	JANZ	GNI25			07	01712	
001370	001405	R								
001371	016005	A	1713	LDA	ACC+2,B			07	01713	
001372	006140	A	1714	SUBI	014631		V2	07	01714	
001373	014631	A								
001374	001004	A	1715	JAN	GNI30	TEST WORD 2.LT..1		07	01715	
001375	001414	R								
001376	001016	A	1716	JANZ	GNI25			07	01716	
001377	001405	R								
001400	016006	A	1717	LDA	ACC+3,B			07	01717	
001401	006140	A	1718	SUBI	046315		V2	07	01718	
001402	046315	A								
001403	001004	A	1719	JAN	GNI30	TEST WORD 3.LT..1		07	01719	
001404	001414	R								
			1720			*****		07	01720	
			1721			* .1 .LE. (ACC,BEXP) .LT. 1 SHIFT ACC TO POSITION *		07	01721	
			1722			*****		07	01722	
001405	005001	A	1723	GNI25	TZA			07	01723	
001406	146024	A	1724	SUB	BEXP,B			07	01724	
001407	056052	A	1725	STA	COUNT,B	LOAD SHIFT COUNT		07	01725	
			1726	PUSHJ	SHA	SHIFT ACC TO POSITION	V2	07	01726	
001410	105025	A								
001411	005667	R								
001412	001000	A	1727	JMP	GNI50			07	01727	
001413	001431	R								
			1728			*****		07	01728	
			1729			* (ACC,BEXP) .LT. .1 MULTIPLY BY 10 *		07	01729	
			1730			*****		07	01730	
			1731	GNI30	MOVPA8	FOUR,COUNT	SET SHIFT COUNT TO 4	07	01731	
001414	010423	A								
001415	056052	A								
001416	126024	A	1732	ADD	BEXP,B	BUMP BINARY EXPONENT BY 4		07	01732	
001417	056024	A	1733	STA	BEXP,B			07	01733	
			1734	PUSHJ	SHA	SHIFT ACC RIGHT 4	V2	07	01734	
001420	105025	A								
001421	005667	R								
			1735	PUSHJ	M10	ACC = ACC*10	V2	07	01735	
001422	105025	A								
001423	002337	R								
			1736	DAB	BEXP	DROP DECIMAL EXPONENT		07	01736	
001424	016055	A								
001425	005311	A								
001426	056055	A								
001427	001000	A	1737	JMP	GNI11	LOOP TILL DONE		07	01737	
001430	001326	R								
			1738			*****		07	01738	
			1739			* GENERATE DECIMAL DIGITS *		07	01739	
			1740			*****		07	01740	
			1741	GNI50	MOVBA8	AC8B,C8PT	INITIALIZE C8B POINTER	07	01741	
001431	016007	A								
001432	056050	A								
001433	046124	A	1742	INR	MOV,B	SET MULTIPLY OVERFLOW FLAG		07	01742	
			1743	GNI12	PUSHJ	M10	ACC = ACC*10	V2	07	01743
001434	105025	A								
001435	002337	R								
001436	036050	A	1744	LDB	C8PT,B	POINT X AT ARRAY C8B		07	01744	



```

001437 055000 A 1745 STA 0,X STORE DECIMAL DIGIT IN ARRAY CHB 07 01745
001440 005145 A 1746 INCR 045 BUMP ARRAY POINTER 07 01746
001441 076050 A 1747 STX CHBPT,B 07 01747
001442 146007 A 1748 SUB ACHB,B 07 01748
001443 146200 A 1749 SUB BD14,B V2 07 01749
001444 001004 A 1750 JAN GNIL2 LOOP TILL 14 DECIMAL DIGITS GENERATED 07 01750
001445 001434 R 1751 POPJ EXIT FG 07 01751
001446 105065 A 1752 EJEC 07 01752
1753 ***** 07 01753
1754 * 07 01754
1755 * GET NEXT LIST ADDRESS (GNL) * 07 01755
1756 * * 07 01756
1757 * FUNCTION: TO GET ADDRESS OF NEXT ITEM ON I/O LIST * 07 01757
1758 * * 07 01758
1759 * ENTRY: ITEMAD = ADDRESS OF PREVIOUS LIST ITEM * 07 01759
1760 * ITMINC = WORD INCREMENT BETWEEN ELEMENTS OF LIST ITEM * 07 01760
1761 * ITEMWC = COUNT OF WORDS REMAINING IN LIST ITEM * 07 01761
1762 * * 07 01762
1763 * EXIT : ITEMAD = ITEMAD+ITMINC * 07 01763
1764 * IF ITEMWC.LE.0 EXIT TO USER PROGRAM * 07 01764
1765 * ITEMWC = ITEMWC-ITMINC * 07 01765
1766 * * 07 01766
1767 ***** 07 01767
1769 GNL ADBBB ITEMAD,ITMINC,ITEMAD BUMP LIST ITEM ADDRESS 07 01769

001447 016113 A 001450 126113 A 001451 056113 A
001452 016114 A 1770 LDA ITEMWC,B 07 01770
001453 005311 A 1771 DAR 07 01771
001454 001002 A 1772 JAP GNIL2 LIST ITEM FINISHED ? 07 01772
001455 001476 R 001456 006010 A 1773 LDAI GNIL2 YES V2 07 01773
001457 001476 R 001460 036000 A 1774 LDX DPSTKP,B V2 07 01774
001461 005344 A 1775 DXR FG 07 01775
001462 076000 A 1776 STX DPSTKP,B FG 07 01776
001463 055000 A 1777 STA 0,X V2 07 01777
001464 010422 A 1778 LDA CEX 07 01778
1779 PUSHF PUSH EXIT OP 07 01779

001465 036016 A 001466 035000 A 001467 005344 A
001470 055000 A 001471 005041 A 001472 036016 A
001473 055000 A 001474 001000 A 1780 JMP CAN EXIT TO V#FORTID 07 01780
001475 000065 R 1781 GNL2 SUTBBB ITEMWC,ITMINC,ITEMWC DECREMENT LIST ITEM WORD COUNT 07 01781

001476 016114 A 001477 146115 A 001500 056114 A
1782 FUPJ EXIT FG 07 01782
001501 105065 A 1783 EJEC 07 01783
1784 ***** 07 01784
1785 * 07 01785
1786 * PROCESS G OUTPUT DESCRIPTOR (GDU) * 07 01786
1787 * * 07 01787
1788 * FUNCTION: TO PROCESS OUTPUT UNDER THE G FORMAT DESCRIPTOR: SRGW.D * 07 01788
1789 * * 07 01789
1790 * ENTRY: DIRECT FROM FRS * 07 01790
1791 * OUTPUT NUMBER IN (ACC,DEXP) * 07 01791
1792 * WT = W = TOTAL FIELD WIDTH * 07 01792
1793 * DT = D = FRACTIONAL FIELD WIDTH * 07 01793
1794 * * 07 01794
1795 * EXIT : DIRECT TO EDUT IF (ACC,DEXP) .LT. .1 OR .GE. 10**DT * 07 01795
1796 * OTHERWISE DIRECT TO DNF WITH * 07 01796
1797 * DT = DT-DEXP * 07 01797
1798 * IFW = DEXP * 07 01798
1799 * XFW = 4 * 07 01799
1800 * XFL = 0 * 07 01800
1801 * * 07 01801
1802 ***** 07 01802
001502 016055 A 1804 GOUT LDA DEXP,B GET DECIMAL EXPONENT 07 01804
001503 001004 A 1805 JAN EDUT PROCESS AS 'E' IF DEXP .LT. ZERO 07 01805
001504 000324 R 001505 146054 A 1806 SUB D,B 07 01806
001506 005311 A 1807 DAR 07 01807
001507 001002 A 1808 JAP EDUT PROCESS AS 'E' IF DEXP .GE. D 07 01808
001510 000324 R 1809 MOVBBB DT,COUNT LOAD SIGNIFICANT DIGIT COUNT 07 01809

001511 016056 A 001512 056052 A 1810 PUSHJ RND ROUND DECIMAL DIGIT STRING V2 07 01810

001513 105025 A 001514 005512 R 001515 016056 A 1811 LDA DT,B 07 01811
001516 146055 A 1812 SUB DEXP,B DECREMENT FRACTIONAL FIELD 07 01812
001517 001004 A 1813 JAN FOUT PROCESS AS 'E' ON ROUNDING OVERFLOW 07 01813
001520 000324 R
    
```



Address	Code	Label	Operation	Description	Page
001521	056056	A	1814 STA DT,B		07 01814
			1815 MOVPAE FOUR,XFW	SET EXPONENT FIELD WIDTH TO 4	07 01815
001522	010423	A			
001523	056174	A	1816 ZAB XFL	SET FLAG TO BLANK OUT EXPONENT FIELD	07 01816
001524	005001	A			
001525	056173	A	1817 MOVBAE DEXP,IFW	LOAD INTEGER FIELD WIDTH	07 01817
001526	016055	A			
001527	056100	A			
001530	001000	A	1818 JMP DEF	PROCESS AS 'F' DESCRIPTOR	07 01818
001531	000311	R			
			1819 E.IEC		07 01819
			1820 *****		07 01820
			1821 *		07 01821
			1822 * P R O C E S S H D E S C R I P T O R ( H I D )		07 01822
			1823 *		07 01823
			1824 * FUNCTION: TO PROCESS THE FORMAT DESCRIPTORS		07 01824
			1825 *		07 01825
			1826 * NH..		07 01826
			1827 * .....		07 01827
			1828 *		07 01828
			1829 * ENTRY: N = FIELD WIDTH( = 2**15-1 FOR '...' DESCRIPTOR)		07 01829
			1830 * HIN : INPUT ENTRY		07 01830
			1831 * HOUT : OUTPUT ENTRY		07 01831
			1832 * QFL = 0 NH.. SPECIFIER		07 01832
			1833 * = 1 '...' SPECIFIER		07 01833
			1834 *		07 01834
			1835 * EXIT : DIRECT TO FRS		07 01835
			1836 *		07 01836
			1837 *****		07 01837
001532		R	1839 HIN EQU *		07 01839
001532		R	1840 HOUT EQU *		07 01840
			1842 TZAB QFL,HID6	TEST IF H OR '...' DESCRIPTOR	07 01842
001532	016150	A			
001533	001010	A			
001534	001567	R			
			1843 *****		07 01843
			1844 * '...' SPECIFIER *		07 01844
			1845 *****		07 01845
001535	005311	A	1846 DAB		07 01846
001536	001010	A	1847 JAZ HID2	QFL = 2 ?	07 01847
001537	001543	R			
001540	056150	A	1848 STA QFL,B	YES. SET QFL = 1	07 01848
001541	001000	A	1849 JMP HID10	AND INPUT OVER 2ND QUOTE OF PAIR	07 01849
001542	001577	R			
			1850 HID2 MOVBAE AFSCB,ASCB	SET SCB TO FORMAT STRING	07 01850
001543	016011	A			
001544	056021	A			
			1851 PUSHJ ICC	INPUT FORMAT CHARACTER	V2 07 01851
001545	105025	A			
001546	001623	R			
001547	006451	A	1852 BT ARST+QT,HID4	IS CHAR A QUOTE ?	07 01852
001550	001564	R			
			1853 PUSHJ ICC	YES. INPUT NEXT CHARACTER	V2 07 01853
001551	105025	A			
001552	001623	R			
001553	006451	A	1854 BT ARST+QT,FRS85	EXIT TO FORMAT SCAN ON SINGLE QUOTE	07 01854
001554	001031	R			
			1855 DAB EMPT	2 CONSECUTIVE QUOTES - BACK UP FORMAT PTR	07 01855
001555	016062	A			
001556	005311	A			
001557	056062	A			
			1856 TSAB RWFL,WR,HID15	READ ?	07 01856
001560	016154	A			
001561	006411	A			
001562	001611	R			
001563	046150	A	1857 INR QFL,B	YES. SET QFL = 2	07 01857
			1858 HID4 DAB EMPT	BACK UP FORMAT POINTER	07 01858
001564	016062	A			
001565	005311	A			
001566	056062	A			
			1859 *****		07 01859
			1860 * NH.. SPECIFIER *		07 01860
			1861 *****		07 01861
			1862 HID6 DAB N	DECREMENT FIELD WIDTH N	07 01862
001567	016125	A			
001570	005311	A			
001571	056125	A			
001572	001004	A	1863 JAN FRS3	EXIT WHEN FIELD EXHAUSTED	07 01863
001573	000441	R			
			1864 TSAB RWFL,WR,HID15		V2 07 01864
001574	016154	A			
001575	006411	A			
001576	001611	R			
			1865 *****		07 01865
			1866 * INPUT *		07 01866
			1867 *****		07 01867
			1868 HID10 PUSHJ CBC	INPUT BUFFER CHARACTER	V2 07 01868
001577	105025	A			
001600	000101	R			
			1869 MOVBAE AFSCB,ASCB	SET SCB TO FORMAT STRING	07 01869
001601	016011	A			



Address	OpCode	OpName	OpArgs	Description	Flags	Page
001602	056021	A				
1870	MOV BAB	BCHAR, FCHAR		MOVE CHAR FROM BUFFER SCB TO FORMAT SCB	07	01870
001603	016030	A				
001604	056064	A				
1871	PUSHJ	PCH		PUT CHARACTER IN FORMAT STRING	V2	07 01871
001605	105025	A				
001606	003320	R				
001607	001000	A				
001610	001532	R				
1872	JMP	HIN		PROCESS NEXT CHAR		07 01872
1873	*****					07 01873
1874	* OUTPUT *					07 01874
1875	*****					07 01875
1876	HID15	MOV BAB	AFSCB, ASCB	SET SCB TO FORMAT STRING		07 01876
001611	016011	A				
001612	056021	A				
1877	PUSHJ	ICC		INPUT FORMAT CHARACTER	V2	07 01877
001613	105025	A				
001614	001623	R				
1878	MOV BAB	FCHAR, BCHAR		MOVE CHAR FROM FORMAT SCB TO BUFFER SCB		07 01878
001615	016064	A				
001616	056030	A				
1879	PUSHJ	OCB		OUTPUT FORMAT CHARACTER TO BUFFER	V2	07 01879
001617	105025	A				
001620	002452	R				
001621	001000	A				
001622	001532	R				
1880	JMP	HOUT		PROCESS NEXT CHAR		07 01880
1881	EJEC					07 01881
1882	*****					07 01882
1883	*****					07 01883
1884	* INPUT / CLASSIFY CHARACTER ( ICC ) *					07 01884
1885	*****					07 01885
1886	* FUNCTION: TO INPUT AND CLASSIFY A CHARACTER FROM A STRING. *					07 01886
1887	*****					07 01887
1888	* ENTRY: ASCB = ADDRESS OF STRING CONTROL BLOCK SCB *					07 01888
1889	*****					07 01889
1890	* SCB(0): CURRENT CHARACTER COUNTER *					07 01890
1891	* SCB(1): STRING START ADDRESS *					07 01891
1892	*****					07 01892
1893	* EXIT : A = SCB(3) = CHARACTER CODE *					07 01893
1894	* SCB(2) = CHARACTER *					07 01894
1895	*****					07 01895
1896	*****					07 01896
1898	*****					07 01898
1899	* GET CHAR FROM STRING *					07 01899
1900	*****					07 01900
001623	036021	A				
1901	ICC	LDX	ASCB, B	POINT X AT SCB		07 01901
001624	015000	A				
1902	LDA	0, X		GET CURRENT POINTER		07 01902
001625	045000	A				
1903	INR	0, X		BUMP CURRENT POINTER		07 01903
001626	007401	A				
1904	SDF	SDF				07 01904
001627	004257	A				
1905	LRLA	15		CONVERT BYTE TO WORD COUNT		07 01905
001630	003004	A				
1906	XAN	ROF		OVFL SET IF HIGH BYTE		07 01906
001631	002201	R				
001632	150460	A				
1907	ANA	BR15		CLEAR SIGN BIT		07 01907
001633	125001	A				
1908	ADD	1, X		ADD STRING START ADDRESS		07 01908
001634	005014	A				
1909	TAX			POINT X AT WORD		07 01909
001635	015000	A				
1910	LDA	0, X		GET WORD		07 01910
001636	003001	A				
1911	XDF	LSRAB		RIGHT JUSTIFY BYTE		07 01911
001637	001721	R				
001640	150463	A				
1912	ANA	RHW		CLEAR HIGH BYTE		07 01912
001641	036021	A				
1913	LDX	ASCB, B		POINT X AT SCB		07 01913
001642	055002	A				
1914	STA	2, X		STORE CHAR IN SCB		07 01914
1915	*****					07 01915
1916	* CLASSIFY CHAR *					07 01916
1917	*****					07 01917
1918	IFF	NUC			FG	07 01918
1919	GOTB	NV2NUC			FG	07 01919
1920	IFT	VII			FG	07 01920
1921	OME	MAP, VSST0		SET EXEC STATE TO 00	V2	07 01921
1922	NV2NUC	CONT			FG	07 01922
001643	034010	A				
1923	LDX	ICCCT		POINT X AT CLASSIFICATION TABLE		07 01923
001644	005144	A				
1924	ICCLP	IXR				07 01924
001645	145000	A				
1925	SUB	0, X				07 01925
001646	001002	A				
1926	JAP	ICCLP				07 01926
001647	001644	R				
001650	015022	A				
1927	LDA	ICCCT1-ICCCT, X		GET CHARACTER CLASSIFICATION CODE		07 01927
1928	IFF	NUC			FG	07 01928
1929	GOTB	NV2NUC			FG	07 01929
1930	IFT	VII			FG	07 01930
1931	OME	MAP, VSST3		SET EXEC MODE TO NN	V2	07 01931
1932	NV2NUC	CONT			FG	07 01932
001651	036021	A				
1933	LDX	ASCB, B		POINT X AT SCB		07 01933
001652	055003	A				
1934	STA	3, X		A = SCB(3) = CODE		07 01934
1935	POPJ			EXIT	FG	07 01935
001653	105065	A				
1936	*****					07 01936
1937	* CLASSIFICATION TABLE - CHARS *					07 01937
1938	*****					07 01938
001654	001654	R				
1939	ICCCT	PZE	*			07 01939
001655	000240	A				
1940	DATA	0240		SPECIAL CHAR		07 01940
001656	000001	A				
1941	DATA	0241-0240		BLANK		07 01941
001657	000006	A				
1942	DATA	0247-0241		SPECIAL CHAR		07 01942
001660	000001	A				
1943	DATA	0250-0247		' QUOTE		07 01943
001661	000001	A				
1944	DATA	0251-0250		'( LEFT PAREN		07 01944



001662	000001	A	1945	DATA	0252-0251	*)	RIGHT PAREN	07	01945
001663	000001	A	1946	DATA	0253-0252	SPECIAL	CHAR	07	01946
001664	000001	A	1947	DATA	0254-0253	+	PLUS SIGN	07	01947
001665	000001	A	1948	DATA	0255-0254	,	COMMA	07	01948
001666	000001	A	1949	DATA	0256-0255	-	MINUS SIGN	07	01949
001667	000001	A	1950	DATA	0257-0256	.	PERIOD	07	01950
001670	000001	A	1951	DATA	0260-0257	/	SLASH	07	01951
001671	000012	A	1952	DATA	0272-0260		NUMERIC	07	01952
001672	000007	A	1953	DATA	0301-0272		SPECIAL CHAR	07	01953
001673	000017	A	1954	DATA	0320-0301		ALPHA	07	01954
001674	000001	A	1955	DATA	0321-0320	P		07	01955
001675	000012	A	1956	DATA	0333-0321		ALPHA	07	01956
001676	000045	A	1957	DATA	0400-0333		SPECIAL CHAR	07	01957
1959				*****				07	01959
1960				*****				07	01960
1961				*****				07	01961
1962				*****				07	01962
001677	000000	A	1963	DATA	0		SPECIAL CHAR	07	01963
001700	000002	A	1964	DATA	2		BLANK	07	01964
001701	000000	A	1965	DATA	0		SPECIAL CHAR	07	01965
001702	001000	A	1966	DATA	01000	'	QUOTE	07	01966
001703	000010	A	1967	DATA	010	(	LEFT PAREN	07	01967
001704	002000	A	1968	DATA	02000	)	RIGHT PAREN	07	01968
001705	000000	A	1969	DATA	0		SPECIAL CHAR	07	01969
001706	000100	A	1970	DATA	0100	+	PLUS SIGN	07	01970
001707	000004	A	1971	DATA	4	,	COMMA	07	01971
001710	000020	A	1972	DATA	020	-	MINUS SIGN	07	01972
001711	000400	A	1973	DATA	0400	.	PERIOD	07	01973
001712	004000	A	1974	DATA	04000	/	SLASH	07	01974
001713	000040	A	1975	DATA	040		NUMERIC	07	01975
001714	000000	A	1976	DATA	0		SPECIAL CHAR	07	01976
001715	000001	A	1977	DATA	1		ALPHA	07	01977
001716	000200	A	1978	DATA	0200	P		07	01978
001717	000001	A	1979	DATA	1		ALPHA	07	01979
001720	000000	A	1980	DATA	0		SPECIAL CHAR	07	01980
001721	004350	A	1981	LSR#8	LSRA	8		07	01981
1982				EJEC				07	01982
1983				*****				07	01983
1984				*****				07	01984
1985				*****				07	01985
1986				*****				07	01986
1987				*****				07	01987
1988				*****				07	01988
1989				*****				07	01989
1990				*****				07	01990
1991				*****				07	01991
1992				*****				07	01992
1993				*****				07	01993
1994				*****				07	01994
1995				*****				07	01995
1996				*****				07	01996
1998				*****				07	01998
001722	005001	A		IFF	ZAB	NFF	CLEAR COUNTER	07	01998
001723	056126	A							
1999				*****				07	01999
2000				*****				07	02000
2001				*****				07	02001
2002				*****				07	02002
001724	016064	A							
001725	146177	A							
001726	056064	A							
001727	016126	A	2003	LDA	NFF,B		GET COUNTER	07	02003
001730	006140	A	2004	SUBI	0277		TEST IF IT CAN BE MULTIPLIED BY 10	V2	07 02004
001731	006315	A							
001732	001002	A	2005	JAP	ERI		ERROR 1/ NUMBER TOO LARGE /	07	02005
001733	005367	R							
001734	016126	A	2006	LDA	NFF,B		RESTORE COUNTER IN A	07	02006
001735	005024	A	2007	IBX			SAVE BASE REGISTER IN X	07	02007
001736	004560	A	2008	LLSR	16			07	02008
001737	160471	A	2009	MUL	10N			07	02009
001740	005021	A	2010	TBA				07	02010
001741	005042	A	2011	TXB			RESTORE BASE REGISTER B	07	02011
001742	007400	A	2012	ROF			CLEAR OVFL	07	02012
001743	126064	A	2013	ADD	FCHAR,B		ADD IN NEW DIGIT	07	02013
001744	001001	A	2014	JOF	ERI		ERROR 1/ NUMBER TOO LARGE /	07	02014
001745	005367	R							
001746	055126	A	2015	STA	NFF,X		UPDATE COUNTER	07	02015
			2016	IFFL1	PUSHJ	100	INPUT NEXT FORMAT CHARACTER	V2	07 02016
001747	105025	A							
001750	001623	R							
001751	006405	A	2017	BT	ASET+NM,IFFL		LOOP ON NUMERIC	07	02017
001752	001724	R							
001753	006401	A	2018	BT	ASET+BL,IFFL1		IGNORE BLANKS	07	02018
001754	001747	R							
001755	105055	A	2019	POPJ			EXIT ON NON-NUMERIC	FG	07 02019
2020				EJEC				07	02020
2021				*****				07	02021
2022				*****				07	02022
2023				*****				07	02023
2024				*****				07	02024
2025				*****				07	02025
2026				*****				07	02026



```

2027 * ENTRY: NO SPECIAL CONDITIONS * 07 02027
2028 * * 07 02028
2029 * EXIT : A = FCODE = NON-BLANK FORMAT CHAR CODE * 07 02029
2030 * FCHAR = FORMAT CHAR * 07 02030
2031 * * 07 02031
2032 ***** * 07 02032
2034 INF MOVBAB AFSCB,ASCB SET SCB TO FORMAT STRING 07 02034

001756 016011 A
001757 056021 A

2035 INFLP PUSHJ ICC INPUT/CLASSIFY CHARACTER V2 07 02035

001760 105025 A
001761 001623 R
001762 006401 A
001763 001760 R
2036 BT ASET+BL,INFLP LOOP TILL NON-BLANK INPUT 07 02036

2037 POPJ EXIT FG 07 02037

001764 105065 A
2038 EJEC 07 02038
2039 ***** 07 02039
2040 * * 07 02040
2041 * PROCESS I OUTPUT DESCRIPTOR ( I O U ) * 07 02041
2042 * * 07 02042
2043 * FUNCTION: TO PROCESS OUTPUT UNDER THE FORMAT DESCRIPTOR: RIW * 07 02043
2044 * * 07 02044
2045 * ENTRY: DIRECT TO IOU * 07 02045
2046 * NUMBER IN (CHB,DEXP,SGFL) WHERE * 07 02046
2047 * * 07 02047
2048 * CHB = 14-WORD ARRAY OF BINARY DECIMAL DIGITS * 07 02048
2049 * DEXP = DECIMAL EXPONENT * 07 02049
2050 * SGFL .EQ. 0 + * 07 02050
2051 * .NE. 0 - * 07 02051
2052 * * 07 02052
2053 * EXIT : DIRECT TO ONF * 07 02053
2054 * IFW = DEXP * 07 02054
2055 * * 07 02055
2056 ***** 07 02056
001765 R
2058 IOU EQU * 07 02058
2060 MOVBAB DEXP,COUNT 07 02060

001765 016055 A
001766 056052 A
2061 PUSHJ RND ROUND TO DEXP DIGITS V2 07 02061

001767 105025 A
001770 005512 R
2062 MOVBAB DEXP,IFW SET INTEGER COUNT TO DEXP 07 02062

001771 016055 A
001772 056100 A
001773 001000 A
001774 002502 R
2063 JMP ONF OUTPUT NUMERIC FIELD 07 02063

2064 EJEC 07 02064
2065 ***** 07 02065
2066 * * 07 02066
2067 * INPUT EXTERNAL NUMERIC FIELD ( I X N ) * 07 02067
2068 * * 07 02068
2069 * FUNCTION: TO INPUT/CONVERT AN EXTERNAL NUMERIC FIELD * 07 02069
2070 * * 07 02070
2071 * ENTRY: ACC(0,1,2,3) = 0 * 07 02071
2072 * PTFI = 0 * 07 02072
2073 * S = SCALE FACTOR * 07 02073
2074 * SCF = 0 FOR I FORMAT DESCRIPTOR * 07 02074
2075 * SGFL = 0 * 07 02075
2076 * WT = W = FIELD WIDTH IN CHARACTERS * 07 02076
2077 * * 07 02077
2078 * EXIT : INPUT NUMBER = (SGFL,ACC,BEXP) , WHERE * 07 02078
2079 * SGFL = SIGN FLAG = 0 FOR + * 07 02079
2080 * = 1 FOR - * 07 02080
2081 * ACC = NORMALIZED BINARY FRACTION * 07 02081
2082 * BEXP = BINARY EXPONENT * 07 02082
2083 * * 07 02083
2084 ***** 07 02084
2086 ***** 07 02086
2087 * CLEAR FLAGS AND COUNTERS * 07 02087
2088 ***** 07 02088
2089 IXN ZAB EDEXP CLEAR EXPLICIT DECIMAL EXPONENT 07 02089

001775 005001 A
001776 056057 A
001777 056077 A
002000 056124 A
002001 056175 A
002002 006010 A
002003 000074 A
002004 056024 A
2090 STA IDEXP,B CLEAR IMPLICIT DECIMAL EXPONENT 07 02090
2091 STA MOV,B CLEAR MULTIPLY OVERFLOW FLAG 07 02091
2092 STA ASG,B CLEAR EXPONENT SIGN FLAG 07 02092
2093 LDAI 60 V2 07 02093

2094 STA BEXP,B BIAS ACC AS INTEGER ACCUMULATOR V2 07 02094
2095 ***** 07 02095
2096 * INPUT INTEGER AND FRACTIONAL PART * 07 02096
2097 ***** 07 02097
002005 006010 A
002006 000566 A
002007 056053 A
2098 LDAI 0566 ENABLE BLANK/','/'-'/'NUMERIC/'+'/'.' V2 07 02098

2099 STA CVFL,B 07 02099
2100 IXNL1 TZAB WT,IXN50 EXIT IF FIELD EXHAUSTED 07 02100

002010 016171 A
002011 001010 A
002012 002172 R
2101 PUSHJ CBC INPUT BUFFER CHARACTER V2 07 02101

002013 105025 A
002014 000101 R

```



Address	Code	Label	Op	Opnd	Description	Page
002015	156053	A	2102	ANA CVFL,B		07 02102
002016	001010	A	2103	JAZ ER3	ERROR 3/ ILLEGAL CHAR /	07 02103
002017	005365	R				
002020	016031	A	2104	LDA BCODE,B	RELOAD CHARACTER CODE	07 02104
002021	006402	A	2105	BT ASET+CM,IXN50	STOP SCAN ON ','	07 02105
002022	002172	R				
002023	006400	A	2106	BT ASET+AL,IXN15	TEST ALPHA	07 02106
002024	002102	R				
			2107	*****		07 02107
			2108	* PROCESS BLANK CHAR *		07 02108
			2109	*****		07 02109
002025	006441	A	2110	BT ARST+BL,IXN4	TEST FOR BLANK	07 02110
002026	002033	R				
			2111	MOVBAZ AZER,BCHAR	REPLACE ASCII BLANK WITH ASCII ZERO	V2 07 02111
002027	016177	A				
002030	056030	A				
002031	001000	A	2112	JMP IXN10		07 02112
002032	002073	R				
002033	016053	A	2113	IXN4 LDA CVFL,B	NON-BLANK INPUT	07 02113
002034	150445	A	2114	ANA BR4	DISABLE '-'	07 02114
002035	150447	A	2115	ANA BR6	DISABLE '+'	07 02115
002036	056053	A	2116	STA CVFL,B		07 02116
			2117	*****		07 02117
			2118	* PROCESS '+' AND '-' *		07 02118
			2119	*****		07 02119
002037	016031	A	2120	LDA BCODE,B	RELOAD CHAR CODE	07 02120
002040	006403	A	2121	BT ASET+PL,IXN5	TEST '+'	07 02121
002041	002052	R				
002042	006444	A	2122	BT ARST+MN,IXN6	TEST '-'	07 02122
002043	002057	R				
002044	016053	A	2123	LDA CVFL,B		07 02123
002045	006414	A	2124	BT ASET+B12,IXN18	'-' IS EXPONENT IF BIT 12 SET	07 02124
002046	002136	R				
002047	046157	A	2125	IHR SGFL,B	SET '-' FLAG	07 02125
002050	001000	A	2126	JMP IXNL1	CONTINUE SCAN	07 02126
002051	002010	R				
002052	016053	A	2127	IXN5 LDA CVFL,B		07 02127
002053	006414	A	2128	BT ASET+B12,IXN18	'+' IS EXPONENT IF BIT 12 SET	07 02128
002054	002136	R				
002055	001000	A	2129	JMP IXNL1	CONTINUE SCAN	07 02129
002056	002010	R				
002057	006450	A	2130	IXN6 BT ARST+PT,IXN8	TEST '.'	07 02130
002060	002067	R				
002061	046147	A	2131	IHR PTFI,B	'.' INPUT. SET FLAG	07 02131
002062	016053	A	2132	LDA CVFL,B		07 02132
002063	150451	A	2133	ANA BR8	DISABLE '.'	07 02133
002064	056053	A	2134	STA CVFL,B		07 02134
002065	001000	A	2135	JMP IXNL1	CONTINUE SCAN	07 02135
002066	002010	R				
			2136	*****		07 02136
			2137	* PROCESS NUMERIC CHAR *		07 02137
			2138	*****		07 02138
002067	016053	A	2139	IXN8 LDA CVFL,B		07 02139
002070	006110	A	2140	ORAI 010121	ENABLE ALPHA/EXPONENT SIGN	V2 07 02140
002071	010121	A				
002072	056053	A	2141	STA CVFL,B		07 02141
002073	016030	A	2142	IXN10 LDA BCHAR,B	GET INPUT NUMERIC CHAR	07 02142
002074	146177	A	2143	SUB AZER,B	CONVERT ASCII DIGIT TO BINARY	V2 07 02143
002075	056166	A	2144	STA TERM,B		07 02144
			2145	PUSHJ NI0	ACC = ACC*10 + TERM	V2 07 02145
002076	105025	A				
002077	002337	R				
002100	001000	A	2146	JMP IXNL1	CONTINUE SCAN	07 02146
002101	002010	R				
			2147	*****		07 02147
			2148	* ALPHA CHAR INPUT *		07 02148
			2149	*****		07 02149
002102	016030	A	2150	IXN15 LDA BCHAR,B		07 02150
002103	006140	A	2151	SUBI 0004		V2 07 02151
002104	000304	A				
002105	001004	A	2152	JAN ER3	ERROR 3/ NOT 'D' OR 'E' /	07 02152
002106	005365	R				
002107	140422	A	2153	SUB TWO		07 02153
002110	001002	A	2154	JAP ER3	ERROR 3/ NOT 'D' OR 'E' /	07 02154
002111	005365	R				
			2155	*****		07 02155
			2156	* PROCESS EXPONENT FIELD *		07 02156
			2157	*****		07 02157
002112	006010	A	2158	LDAI 0166		V2 07 02158
002113	000160	A				
002114	056053	A	2159	IXNL2 STA CVFL,B	ENABLE BLANK/+'/'-'/'./NUMERIC	V2 07 02159
			2160	TZAB MT,IXN30	EXIT IF FIELD EXHAUSTED	07 02160
002115	016177	A				
002116	001010	A				
002117	002170	R				
			2161	PUSHJ OBC	INPUT BUFFER CHARACTER	V2 07 02161
002120	105025	A				
002121	000101	A				
002122	156053	A	2162	ANA CVFL,B		07 02162
002123	001010	A	2163	JAZ ER3	ERROR 3/ ILLEGAL CHAR /	07 02163
002124	005365	R				
002125	016031	A	2164	LDA BCODE,B	RELOAD CHARACTER CODE	07 02164
002126	006402	A	2165	BT ASET+CM,IXN30	STOP SCAN ON ','	07 02165



002127	002170	R								
002130	006441	A	2166	BT	ARST+BL,IXN20	TEST FOR BLANK		07	02166	
002131	002141	R								
			2167	MOVAB	AZER,BCHAR	REPLACE BLANK WITH ZERO	V2	07	02167	
002132	016177	A								
002133	056030	A								
002134	001000	A	2168	JMP	IXN25			07	02168	
002135	002155	R								
002136	006010	A	2169	IXN18	LDAI	0166	V2	07	02169	
002137	000166	A								
002140	056053	A	2170	STA	CVFL,B	ENABLE BLANK/NUMERIC	V2	07	02170	
002141	016053	A	2171	IXN20	LDA	CVFL,B		07	02171	
002142	150445	A	2172	ANA	BR4	NON-BLANK INPUT		07	02172	
002143	150447	A	2173	ANA	BR6	DISABLE '-'		07	02173	
002144	056053	A	2174	STA	CVFL,B	DISABLE '+'		07	02174	
			2175	*****				07	02175	
			2176	* PROCESS EXPONENT '+' OR '-' *				07	02176	
			2177	*****				07	02177	
002145	016031	A	2178	LDA	BCODE,B	RELOAD BUFFER CHARACTER CODE		07	02178	
002146	006406	A	2179	BT	ASET+PL,IXNL2	CONTINUE SCAN ON '+'		07	02179	
002147	002115	R								
002150	006444	A	2180	BT	ARST+MN,IXN25	TEST FOR '-'		07	02180	
002151	002155	R								
002152	046175	A	2181	INR	XSG,B	SET '-' EXPONENT SIGN FLAG		07	02181	
002153	001000	A	2182	JMP	IXNL2	CONTINUE SCAN		07	02182	
002154	002115	R								
			2183	*****				07	02183	
			2184	* PROCESS NUMERIC EXPONENT DIGIT *				07	02184	
			2185	*****				07	02185	
002155	016030	A	2186	IXN25	LDA	BCHAR,B	GET ASCII DIGIT			
002156	146177	A	2187	SUB	AZER,B	CONVERT TO BINARY	V2	07	02187	
002157	005024	A	2188	TBX		SAVE BASE REGISTER SETTING IN X		07	02188	
002160	025057	A	2189	LDB	EDEXP,X			07	02189	
002161	160471	A	2190	MUL	TEN			07	02190	
002162	065057	A	2191	STB	EDEXP,X	UPDATE EXPLICIT DECIMAL EXPONENT		07	02191	
002163	005042	A	2192	TXB		RESTORE BASE REGISTER B		07	02192	
002164	001016	A	2193	JANZ	ER3	ERROR 3/ EXPONENT TOO LARGE /		07	02193	
002165	005365	R								
002166	001000	A	2194	JMP	IXNL2	CONTINUE SCAN		07	02194	
002167	002115	R								
			2195	IXN30	ZAB	SCF	DISABLE SCALE FACTOR IF EXTERNAL EXPONENT	07	02195	
002170	005001	A								
002171	056156	A								
			2196	*****				07	02196	
			2197	* CONVERT TO STANDARD FORM *				07	02197	
			2198	*****				07	02198	
002172	036001	A	2199	IXN50	LDB	AACC,B	POINT X AT ACC			
002173	015000	A	2200	LDA	0,X			07	02200	
002174	115001	A	2201	DRA	1,X			07	02201	
002175	115002	A	2202	DRA	2,X			07	02202	
002176	115003	A	2203	DRA	3,X			07	02203	
002177	001010	A	2204	JAZ	IXN57	EXIT IF ACC=0	FG	07	02204	
002200	002235	R								
002201	007400	A	2205	RDF				07	02205	
			2206	RDF	TZAB	XSG,IXN52	IS EXPONENT SIGN FLAG SET ?	V2	07	02206
002202	016175	A								
002203	001010	A								
002204	002210	R								
002205	005001	A	2207	TZA		YES		07	02207	
002206	146057	A	2208	SUB	EDEXP,B	NEGATE EXPLICIT DECIMAL EXPONENT		07	02208	
002207	056057	A	2209	STA	EDEXP,B			07	02209	
			2210	IXN52	TNZAB	PTFL,IXN53	HAS A '.' BEEN INPUT ?	V2	07	02210
002210	016147	A								
002211	001016	A								
002212	002216	R								
			2211	SUTBBB	IDEXP,D,IDEXP	NO. DECREMENT EXPONENT BY D		07	02211	
002213	016077	A								
002214	146054	A								
002215	056077	A								
			2212	IXN53	TZAB	SCF,IXN55	IS SCALE FACTOR ENABLED ?	V2	07	02212
002216	016156	A								
002217	001010	A								
002220	002223	R								
002221	005001	A	2213	TZA		YES		07	02213	
002222	146155	A	2214	SUB	S,B			07	02214	
002223	126077	A	2215	IXN55	ADD	IDEXP,B	ADD IMPLICIT DECIMAL EXPONENT	V2	07	02215
002224	126057	A	2216	ADD	EDEXP,B	ADD EXPLICIT DECIMAL EXPONENT		07	02216	
002225	056055	A	2217	STA	DEXP,B	STORE IN DEXP		07	02217	
002226	001001	A	2218	JMF	ER3	ERROR 3/ EXPONENT TOO LARGE /		07	02218	
002227	005365	R								
			2219	IXNL3	PUSHJ	NRM	NORMALIZE ACC	V2	07	02219
002230	105025	A								
002231	002402	R								
			2220	TNZAB	DEXP,IXN58			FG	07	02220
002232	016055	A								
002233	001016	A								
002234	002236	R								
			2221	IXN57	POPJ		EXIT WHEN DEXP=0	FG	07	02221
002235	105065	A	2222	IXN58	JAP	IXN60	TEST SIGN OF DEXP	FG	07	02222
002236	001002	A								
002237	002245	R								
			2223	*****				07	02223	
			2224	* NEGATIVE DECIMAL EXPONENT *				07	02224	



```

2225 *****
2226          PUSHJ   D10          ACC = ACC/10          V2  07 02225
002240 105025 A
002241 000271 R
002242 046055 A 2227          INR     DEXP,B          BUMP DEXP          07 02227
002243 001000 A 2228          JMP     IXNL3         CONTINUE CONVERSION 07 02228
002244 002230 R
2229 *****
2230 * POSITIVE DECIMAL EXPONENT *
2231 *****
2232 IXN60 MOVVAB FOUR,COUNT SET RIGHT SHIFT COUNT TO 4 07 02229
002245 010423 A
002246 056052 A 2233          ADD     BEXP,B          BUMP BINARY EXPONENT 07 02233
002247 126024 A 2234          STA     BLXP,B          07 02234
002250 056024 A 2235          PUSHJ  SHA            SHIFT ACC RIGHT 4  V2  07 02235
002251 105025 A
002252 005667 R
2236          PUSHJ   M10          ACC = ACC*10          V2  07 02236
002253 105025 A
002254 002337 R
2237          DAB     DEXP          DROP DEXP          07 02237
002255 016055 A
002256 005311 A
002257 056055 A
002260 001000 A 2238          JMP     IXNL3         CONTINUE CONVERSION 07 02238
002261 002230 R
2239          EJEC
2240 *****
2241 *
2242 * P R O C E S S   L   I N P U T   D E S C R I P T O R S ( L I N ) *
2243 *
2244 * FUNCTION: TO PROCESS THE INPUT FORMAT DESCRIPTOR: RLW
2245 *
2246 * ENTRY: DIRECT FROM FRS
2247 *         WT = W = TOTAL FIELD WIDTH
2248 *         ITEMAD = ADDRESS OF LIST ITEM
2249 *
2250 * EXIT : DIRECT TO FRS
2251 *         (ITEMAD) = -1 IF 1ST CHAR 'T'
2252 *                 = 0 IF 1ST CHAR 'F'
2253 *
2254 * ERRORS: ER3 IF 1ST NON-BLANK CHAR NOT 'T' OR 'F'
2255 *
2256 *****
2258 LIN  TZAB  WT,ER3  ERROR 3/ BLANK FIELD / 07 02258
002262 016171 A
002263 001010 A
002264 005365 R
2259          PUSHJ  OBC          INPUT BUFFER CHARACTER  V2  07 02259
002265 105025 A
002266 000101 R
002267 006401 A 2260          BT     ASET+BL,LIN  SLEW THRU BLANKS 07 02260
002270 002262 R
002271 036113 A 2261          LDX     ITEMAD,B      POINT X AT LIST ITEM 07 02261
002272 005301 A 2262          DECR  1              07 02262
002273 055000 A 2263          STA     B,X          SET LIST ITEM TO .TRUE. (-1) 07 02263
002274 016030 A 2264          LDA     BCHAR,B      GET INPUT CHAR 07 02264
002275 006140 A 2265          SUBI   0324          V2  07 02265
002276 000324 A
002277 001010 A 2266          JAZ   LINX          EXIT TO FORMAT SCAN IF 'T' 07 02266
002300 002306 R
002301 045000 A 2267          INR   J,X          SET LIST ITEM TO .FALSE. (0) 07 02267
002302 006120 A 2268          ADDI  016          TEST FOR 'F'  V2  07 02268
002303 000016 A
002304 001016 A 2269          JANZ  ER3          ERROR 3/ 1ST CHAR NOT 'T' OR 'F' / 07 02269
002305 005365 R
2270 LINX  MOVVAB WT,COUNT LOAD REMAINING FIELD WIDTH AS REPEAT COUNT 07 02270
002306 016171 A
002307 056052 A
2271          PUSHJ  RCH          GOBLE REST OF FIELD  V2  07 02271
002310 105025 A
002311 005125 R
002312 001000 A 2272          JMP   FRS65         EXIT TO FORMAT SCAN 07 02272
002313 001014 R
2273          EJEC
2274 *****
2275 *
2276 * P R O C E S S   L   O U T P U T   D E S C R I P T O R S ( L O U ) *
2277 *
2278 * FUNCTION: TO PROCESS THE OUTPUT FORMAT DESCRIPTOR: RLW
2279 *
2280 * ENTRY: DIRECT FROM FRS
2281 *         WT = W = TOTAL FIELD WIDTH
2282 *         ITEMAD = ADDRESS OF LIST ITEM
2283 *
2284 * EXIT : TO FRS THRU OBC
2285 *         WT-1 LEADING BLANKS OUTPUT
2286 *         'F' OUTPUT IF (ITEMAD).EQ.ZERO
2287 *         'T' OUTPUT OTHERWISE
2288 *
2289 *****
2291 LOUT  MOVVAB BLNK1,BCHAR LOAD BLANK AS FILL CHARACTER  V2  07 02291

```



```

002314 016202 A
002315 056030 A
      2292      DABB      WT,COUNT      SET COUNT TO WT-1      07 02292
002316 016171 A
002317 005311 A
002320 056052 A
      2293      PUSHJ     RCH          OUTPUT WT-1 LEADING BLANKS      V2 07 02293
002321 105025 A
002322 005125 R
002323 006010 A
002324 000306 A
      2294      LDAI      0306          V2 07 02294
002325 056030 A
002326 036113 A
      2295      STA      BCHAR,B      LOAD 'F' AS OUTPUT CHARACTER      V2 07 02295
      2296      LDX      ITEMAD,B      POINT X AT LIST ITEM      07 02296
      2297      TZAX      0,LOU4          TEST LIST ITEM = 0 (FALSE)      07 02297
002327 015000 A
002330 001010 A
002331 002335 R
002332 006010 A
      2298      LDAI      0324          SET OUTPUT CHAR TO 'T' IF NOT      V2 07 02298
002333 000324 A
002334 056030 A
      2299      STA      BCHAR,B      V2 07 02299
      2300      LDU4     PUSHJ     DCB          OUTPUT 'T' OR 'F'/EXIT      V2 07 02300
002335 105025 A
002336 002452 R
      2301      EJEC
      2302      *****
      2303      *
      2304      *           M U L T I P L Y   B Y   1 0   ( M 1 0 )
      2305      *
      2306      * FUNCTION: MULTIPLIES A 4-WORD FIELD ACC BY 10 AND ADDS AN INTEGER I
      2307      *           TO THE PRODUCT. MONITORS OVERFLOW AND DECIMAL EXPONENT
      2308      *
      2309      * ENTRY:  TERM = I
      2310      *           PTFL = 1 IF A '.' HAS BEEN PASSED, 0 IF NOT
      2311      *           MOV = 1 IF OVERFLOW ALLOWED, 0 IF NOT
      2312      *
      2313      * EXIT :  ACC=ACC*10 + I
      2314      *           A = OVERFLOW DIGIT
      2315      *           IDEXP INCREMENTED ON OVERFLOW IF PTFL = 0
      2316      *           IDEXP DECREMENTED IF NO OVFL AND PTFL .NE. 0
      2317      *
      2318      *****
002337 005024 A
002340 015003 A
002341 006140 A
002342 006314 A
002343 001004 A
      2320      M10     TBX          LOAD X AS BASE REGISTER      07 02320
002344 002355 R
002345 015124 A
002346 001016 A
002347 002355 R
      2321      LDA      ACC,X
      2322      SUBI      3276          V2 07 02321
002348 002355 A
      2323      JAN      M104          CAN ACC BE MULTIPLIED BY 10 ?      07 02323
002349 002355 R
002350 015147 A
002351 001016 A
002352 002401 R
002353 045077 A
      2324      LDA      MOV,X          NO
      2325      JANZ     M104          MULTIPLY ANYWAY IF MOV SET      07 02324
      2326      LDA      PTFL,X
      2327      JANZ     M10X          EXIT IF '.' PASSED      FG 07 02327
      2328      INR      IDEXP,X      OTHERWISE BUMP IMPLICIT DECIMAL EXPONENT 07 02328
      2329      POPJ
      2329      AND EXIT      FG 07 02329
002354 105065 A
002355 015166 A
002356 025000 A
002357 160471 A
002360 065006 A
002361 025005 A
002362 160471 A
002363 065005 A
002364 025004 A
002365 160471 A
002366 065004 A
002367 025003 A
002370 160471 A
002371 065003 A
002372 005042 A
002373 036147 A
002374 001040 A
002375 002401 R
002376 036077 A
002377 005344 A
002400 076077 A
      2330      M104     LDA      TERM,X      LOAD I      07 02330
      2331      LDB      ACC+3,X
      2332      MUL      TEN          ACC(3)=ACC(3)*10 + I      07 02331
      2333      STB      ACC+3,X
      2334      LDB      ACC+2,X
      2335      MUL      TEN          ACC(2)=ACC(2)*10 + OVFL(3)      07 02332
      2336      STB      ACC+2,X
      2337      LDB      ACC+1,X
      2338      MUL      TEN          ACC(1)=ACC(1)*10 + OVFL(2)      07 02333
      2339      STB      ACC+1,X
      2340      LDB      ACC,X
      2341      MUL      TEN          ACC(0)=ACC(0)*10 + OVFL(1)      07 02334
      2342      STB      ACC,X
      2343      TXB          RESTORE BASE REGISTER B      07 02335
      2344      LDX      PTFL,B
      2345      JXZ      M10X          HAS A '.' BEEN PASSED ?      FG 07 02336
      2346      LDX      IDEXP,B      YES      07 02337
      2347      DXR          DECREMENT IMPLICIT DECIMAL EXPONENT      07 02338
      2348      STX      IDEXP,B
      2349      M10X     POPJ          EXIT      FG 07 02339
002401 105065 A
      2350      EJEC
      2351      *****
      2352      *
      2353      *           N O R M A L I Z E   A C C U M U L A T O R   ( N R M )
      2354      *
      2355      * FUNCTION: TO NORMALIZE THE 4-WORD ACCUMULATOR ACC WITH BINARY
      2356      *           EXPONENT BEXP.
      2357      *
      2358      * ENTRY:  ACC.NE.0
      2359      *
      2360      * EXIT :  (ACC,BEXP) NORMALIZED
      2361      *
      2362      *****
002402 005024 A
002403 015003 A
      2364      NRM      TBX          LOAD X AS BASE REGISTER      07 02364
      2365      NRML     LDA      ACC,X

```



```

002404 004241 A 2366      LRLA      1
002405 001004 A 2367      JAN      NRMX      EXIT WHEN NORMALIZED
002406 002450 R
002407 001016 A 2368      JANZ      NRM4      ACC(0) = 0 ?
002410 002426 R
2369      MOVXAX   ACC+1,ACC   YES. SHIFT 1 WORD
002411 015004 A
002412 055003 A
2370      MOVXAX   ACC+2,ACC+1
002413 015005 A
002414 055004 A
2371      MOVXAX   ACC+3,ACC+2
002415 015006 A
002416 055005 A
2372      ZAX      ACC+3
002417 005001 A
002420 055006 A
002421 016024 A 2373      LDA      BEXP,B
002422 140472 A 2374      SUB      D15
002423 056024 A 2375      STA      BEXP,B
002424 001000 A 2376      JMP      NRML
002425 002403 R
002426 015003 A 2377 NRM4    LDA      ACC,X
002427 025004 A 2378      LDB     ACC+1,X
002430 004401 A 2379      LASL   1
002431 055003 A 2380      STA      ACC,X      SHIFT ACC(0) LEFT 1
002432 015004 A 2381      LDA      ACC+1,X
002433 025005 A 2382      LDB     ACC+2,X
002434 004401 A 2383      LASL   1
002435 055004 A 2384      STA      ACC+1,X   SHIFT ACC(1) LEFT 1
002436 015005 A 2385      LDA      ACC+2,X
002437 025006 A 2386      LDB     ACC+3,X
002440 004401 A 2387      LASL   1
002441 055005 A 2388      STA      ACC+2,X   SHIFT ACC(2) LEFT 1
002442 065006 A 2389      STB     ACC+3,X   SHIFT ACC(3) LEFT 1
002443 015024 A 2390      LDA      BEXP,X
002444 005311 A 2391      DAR
002445 055024 A 2392      STA      BEXP,X   DECREMENT BINARY EXPONENT BEXP
002446 001000 A 2393      JMP      NRML      CONTINUE NORMALIZE LOOP
002447 002403 R
002450 005042 A 2394 NRMX    TXB
2395      POPJ      RESTORE BASE REGISTER B
002451 105065 A 2395      EXIT      FG
2396      EJEC
2397 *****
2398 *
2399 *      O U T P U T   C H A R   T O   B U F F E R   (   D   C   B   )
2400 *
2401 *  FUNCTION: TO OUTPUT A CHARACTER TO THE BUFFER
2402 *
2403 *  ENTRY: BCHAR = CHAR TO BE OUTPUT
2404 *          ASFL.NE.0 IF FIELD IS TO BE TERMINATED BY AN '*'
2405 *          WT = FIELD WIDTH
2406 *
2407 *  EXIT : '*' OUTPUT IF ASFL.NE.0 AND WT=1
2408 *          DIRECT TO FRS IF WT=0
2409 *
2410 *****
2412 DCB   TZAB   ASFL,DCB4   IS '*' FLAG SET ?
002452 016022 A
002453 001010 A
002454 002464 R
002455 016171 A 2413      LDA      WT,B      YES
002456 005311 A 2414      DAR
002457 001016 A 2415      JANZ      DCB4      WT = 1 ?
002460 002464 R
002461 006010 A 2416      LDAI    0252      V2
002462 000252 A
002463 056030 A 2417      STA      BCHAR,B   YES. LOAD '*' AS OUTPUT CHARACTER
2418 DCB4    PUSHJ   CBC   OUTPUT CHAR TO BUFFER      V2
002464 105025 A
002465 000101 R
2419      TZAB   WT,DCB6   FIELD EXHAUSTED ?      FG
002466 016171 A
002467 001010 A
002470 002472 R
2420      POPJ      NO. RETURN      FG
002471 105065 A
2421 DCB5    MOVBAB  ADPSTK,DPSTKP  YES. CLEAR STACK      FG
002472 016017 A
002473 056000 A
002474 016061 A 2422      LDA      FDLKEY,B
002475 140424 A 2423      SUB      EIGHT
002476 001002 A 2424      JAR      FRS5      SCAN FOR NEXT FORMAT CHAR ON H/X
002477 000441 R
002500 001000 A 2425      JMP      FRS65     RETURN TO FORMAT SCAN
002501 001010 R
2426      EJEC
2427 *****
2428 *
2429 *      O U T P U T   N U M E R I C   F I E L D   (   D   N   F   )
2430 *
2431 *  FUNCTION: TO OUTPUT A STRING OF CHARS REPRESENTING A DECIMAL NUMBER *

```



```

2432 *
2433 * ENTRY: OUTPUT NUMBER = (SGFL,CHB,DEXP) ,WHERE:
2434 *
2435 *          SGFL = SIGN = 0 FOR '+'
2436 *                   = -1 FOR '-'
2437 *
2438 *          CHB = ARRAY OF BINARY DECIMAL DIGITS
2439 *                   = NORMALIZED FRACTIONAL PART OF NUMBER
2440 *
2441 *          DEXP = DECIMAL EXPONENT
2442 *
2443 *          WT = FIELD WIDTH
2444 *          IFW = INTEGER FIELD WIDTH
2445 *          PTFL = 1 IF '.' TO BE OUTPUT, 0 OTHERWISE
2446 *          DT = FRACTIONAL FIELD WIDTH
2447 *          ZFW = WIDTH OF LEADING ZERO FIELD
2448 *          XFL = 1 IF EXPONENT FIELD PRESENT, 0 OTHERWISE
2449 *          XFW = EXPONENT FIELD WIDTH
2450 *
2451 * EXIT : TO FRS THRU OCB
2452 *
2453 * *****
2454 * *****
2455 * *****
2456 * OUTPUT LEADING BLANKS *
2457 * *****
002502 016171 A 2458 ONF LDA WT,B GET FIELD WIDTH
002503 126157 A 2459 ADD SGFL,B SUBTRACT '-'
002504 146100 A 2460 SUB IFW,B SUBTRACT WIDTH OF INTEGER FIELD
002505 146147 A 2461 SUB PTFL,B SUBTRACT SPACE FOR '.'
002506 146056 A 2462 SUB DT,B SUBTRACT WIDTH OF FRACTIONAL FIELD
002507 146174 A 2463 SUB XFW,B SUBTRACT WIDTH OF EXPONENT FIELD
002510 056052 A 2464 STA COUNT,B STORE LEADING BLANK COUNT
002511 001002 A 2465 JAP ONF5 TEST FOR FIELD OVERFLOW
002512 002532 R
2466 *****
2467 * FIELD OVERFLOW *
2468 *****
002513 005311 A 2469 DAR ALLOW 1 SPACE FOR '**'
002514 056022 A 2470 STA ASFL,B SET '**' FLAG
002515 126056 A 2471 ADD DT,B
002516 056056 A 2472 STA DT,B REDUCE FRACTIONAL FIELD
002517 001002 A 2473 JAP ONF5 DOES FIELD STILL OVERFLOW ?
002520 002532 R
002521 005004 A 2474 TZX YES
002522 076056 A 2475 STX DT,B SET FRACTIONAL FIELD WIDTH = 0
002523 126147 A 2476 ADD PTFL,B DELETE '.'
002524 076147 A 2477 STX PTFL,B
002525 126100 A 2478 ADD IFW,B
002526 056100 A 2479 STA IFW,B REDUCE INTEGER FIELD WIDTH
002527 001002 A 2480 JAP ONF5 DOES FIELD STILL OVERFLOW ?
002530 002532 R
002531 076100 A 2481 STX IFW,B YES. SET INTEGER FIELD WIDTH = 0
2482 ONF5 MOVBAB BLNK1,BCHAR LOAD BLANK AS REPEAT CHARACTER
002532 016202 A
002533 056030 A
2483 PUSHJ RCH OUTPUT COUNT BLANKS
002534 105025 A
002535 005125 R
2484 *****
2485 * OUTPUT SIGN *
2486 *****
002536 016157 A 2487 TZAB SGFL,ONF20 DONT OUTPUT '+' SIGN
002537 001010 A
002540 002546 R
002541 006010 A 2488 LDAI 0255
002542 000255 A
002543 056030 A 2489 STA BCHAR,B
2490 PUSHJ OCB OUTPUT '-'
002544 105025 A
002545 002452 R
2491 *****
2492 * OUTPUT INTEGER FIELD *
2493 *****
002546 016100 A 2494 ONF20 MOVBAB IFW,COUNT LOAD LOOP COUNT
002547 056052 A
2495 MOVBAB ACHB,CHBPT INITIALIZE CHB ARRAY POINTER
002550 016007 A
002551 056050 A
002552 016052 A 2496 ONFL1 LDA COUNT,B
002553 005311 A 2497 DAR DECREMENT COUNT
002554 001004 A 2498 JAN ONF30 EXIT WHEN FINISHED
002555 002577 R
002556 056052 A 2499 STA COUNT,B
002557 036050 A 2500 LDX CHBPT,B
002560 046050 A 2501 INR CHBPT,B BUMP CHB POINTER
002561 015000 A 2502 LDA 0,X GET DIGIT
002562 126177 A 2503 ADD AZER,B CONVERT TO ASCII
002563 056030 A 2504 STA BCHAR,B
2505 PUSHJ OCB OUTPUT CHARACTER TO BUFFER
002564 105025 A
002565 002452 R

```



002566	016050	A	2506	LDA	CHBPT,B			07	02506	
002567	146007	A	2507	SUB	ACHB,B			07	02507	
002570	146200	A	2508	SUB	BD14,B		V2	07	02508	
002571	001004	A	2509	JAN	DNFL1			07	02509	
002572	002552	R								
			2510	MOVBAB	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER	V2	07	02510	
002573	016177	A								
002574	056030	A								
			2511	PUSHJ	RCH	OUTPUT '0' FILL	V2	07	02511	
002575	105025	A								
002576	005125	R								
			2512	*****				07	02512	
			2513	* OUTPUT '.' *				07	02513	
			2514	*****				07	02514	
			2515	DNF30	TZAB	PTFL,DNF40	SKIP IF NO '.'	07	02515	
002577	016147	A								
002600	001010	A								
002601	002645	R								
002602	006010	A	2516	LDAI	0256		V2	07	02516	
002603	000256	A								
002604	056030	A	2517	STA	BCHAR,B	LOAD '.' AS OUTPUT CHARACTER	V2	07	02517	
			2518	PUSHJ	DCB	OUTPUT '.'	V2	07	02518	
002605	105025	A								
002606	002452	R								
			2519	*****				07	02519	
			2520	* OUTPUT LEADING ZEROS IN FRACTIONAL FIELD *				07	02520	
			2521	*****				07	02521	
			2522	MOVBAB	ZFW,COUNT	LOAD LEADING ZERO COUNT		07	02522	
002607	016176	A								
002610	056052	A								
			2523	MOVBAB	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER	V2	07	02523	
002611	016177	A								
002612	056030	A								
			2524	PUSHJ	RCH	OUTPUT LEADING ZEROS	V2	07	02524	
002613	105025	A								
002614	005125	R								
			2525	*****				07	02525	
			2526	* OUTPUT FRACTIONAL PART *				07	02526	
			2527	*****				07	02527	
			2528	SUTBBB	DT,ZFW,COUNT	LOAD COUNTER		07	02528	
002615	016056	A								
002616	146176	A								
002617	056052	A								
002620	016052	A	2529	DNFL2	LDA	COUNT,B		07	02529	
002621	005311	A	2530	DAR		DECREMENT COUNT		07	02530	
002622	001004	A	2531	JAN	DNF40	EXIT WHEN FINISHED		07	02531	
002623	002645	R								
002624	056052	A	2532	STA	COUNT,B			07	02532	
002625	036050	A	2533	LDX	CHBPT,B	POINT X AT DIGIT		07	02533	
002626	046050	A	2534	INR	CHBPT,B	BUMP CHB POINTER		07	02534	
002627	015000	A	2535	LDA	0,X	GET DIGIT		07	02535	
002630	126177	A	2536	ADD	AZER,B	CONVERT TO ASCII	V2	07	02536	
002631	056030	A	2537	STA	BCHAR,B			07	02537	
			2538	PUSHJ	DCB	OUTPUT CHAR TO BUFFER	V2	07	02538	
002632	105025	A								
002633	002452	R								
002634	016050	A	2539	LDA	CHBPT,B			07	02539	
002635	146007	A	2540	SUB	ACHB,B			07	02540	
002636	146200	A	2541	SUB	BD14,B		V2	07	02541	
002637	001004	A	2542	JAN	DNFL2			07	02542	
002640	002620	R								
			2543	MOVBAB	AZER,BCHAR	LOAD '0' AS REPEAT CHARACTER	V2	07	02543	
002641	016177	A								
002642	056030	A								
			2544	PUSHJ	RCH	OUTPUT '0' FILL	V2	07	02544	
002643	105025	A								
002644	005125	R								
			2545	DNF40	TNZAB	XFL,DNF50	TEST EXPONENT FLAG	V2	07	02545
002645	016173	A								
002646	001016	A								
002647	002656	R								
			2546	*****				07	02546	
			2547	* OUTPUT BLANK EXPONENT FIELD *				07	02547	
			2548	*****				07	02548	
			2549	MOVPAB	FOUR,COUNT	SET BLANK COUNT TO 4		07	02549	
002650	010423	A								
002651	056052	A								
			2550	MOVBAB	BLNK1,BCHAR		V2	07	02550	
002652	016202	A								
002653	056030	A								
			2551	PUSHJ	RCH	OUTPUT 4 BLANKS AND EXIT	V2	07	02551	
002654	105025	A								
002655	005125	R								
			2552	*****				07	02552	
			2553	* OUTPUT EXPONENT FIELD *				07	02553	
			2554	*****				07	02554	
			2555	DNF50	LDAI	0305		V2	07	02555
002656	006010	A								
002657	000305	A								
002660	056030	A	2556	STA	BCHAR,B	SET EXPONENT CHARACTER TO 'E'	V2	07	02556	
			2557	TNZAB	FDLKEY,DNF52	IS FORMAT DESCRIPTOR 'D' ?	V2	07	02557	
002661	016061	A								
002662	001016	A								
002663	002667	R								



Address	Op	Op	Op	Op	Op	Op	Op	Op
002664	016030	A	2558	DAB	BCHAR	YES. LOAD 'D'	V2	07 02558
002665	005311	A						
002666	056030	A	2559	DNF52	PUSHJ	OCB	OUTPUT 'D' OR 'E'	V2 07 02559
002667	105025	A						
002670	002452	R						
002671	016202	A	2560	MOVBA	BLNK1,BCHAR	LOAD BLANK FOR PLUS	V2	07 02560
002672	056030	A						
002673	016055	A	2561	TPAB	DEXP,DNF55	IS EXPONENT NEGATIVE ?		07 02561
002674	001002	A						
002675	002704	R						
002676	005211	A	2562	CPA		YES		07 02562
002677	005111	A	2563	IAR		CONVERT TO ABS		07 02563
002700	056055	A	2564	STA	DEXP,B			07 02564
002701	006010	A	2565	LDAI	0255		V2	07 02565
002702	000255	A						
002703	056030	A	2566	STA	BCHAR,B	LOAD '--'	V2	07 02566
002704	105025	A	2567	DNF55	PUSHJ	OCB	OUTPUT EXPONENT SIGN	V2 07 02567
002705	002452	R						
002706	005024	A	2568	TBX		LOAD X AS BASE REGISTER		07 02568
002707	005001	A	2569	TZA				07 02569
002710	025055	A	2570	LDB	DEXP,X	GET EXPONENT		07 02570
002711	170471	A	2571	DIV	TEN	GET DECIMAL DIGITS		07 02571
002712	055055	A	2572	STA	DEXP,X			07 02572
002713	005021	A	2573	TBA		GET TENS DIGIT IN A		07 02573
002714	005042	A	2574	TXB		RESTORE BASE REGISTER B		07 02574
002715	126177	A	2575	ADD	AZER,B	CONVERT TO ASCII	V2	07 02575
002716	056030	A	2576	STA	BCHAR,B			07 02576
002717	105025	A	2577	PUSHJ	OCB	OUTPUT TENS DIGIT OF EXPONENT	V2	07 02577
002720	002452	R						
002721	016055	A	2578	LDA	DEXP,B	RESTORE UNITS DIGIT		07 02578
002722	126177	A	2579	ADD	AZER,B	CONVERT TO ASCII	V2	07 02579
002723	056030	A	2580	STA	BCHAR,B			07 02580
002724	105025	A	2581	DNF60	PUSHJ	OCB	OUTPUT UNITS DIGIT/ '*' / EXIT	V2 07 02581
002725	002452	R						
002726	001000	A						
002727	002724	R	2582	JMP	DNF60			07 02582
2583			2583	EJEC				07 02583
2584			2584	*****				07 02584
2585			2585	*				07 02585
2586			2586	OPEN FILE (OPN)				07 02586
2587			2587	*				07 02587
2588			2588	* FUNCTION: TO PROCESS CALLS TO OPEN AN RMD FILE				07 02588
2589			2589	*				07 02589
2590			2590	* ENTRY: DIRECT FROM RBE				07 02590
2591			2591	* UNIT = FORTRAN UNIT NUMBER U				07 02591
2592			2592	* RETURN = CALL SEQUENCE ADDRESS				07 02592
2593			2593	* RETURN(5) = ADDRESS OF LOGICAL UNIT NUMBER L				07 02593
2594			2594	* RETURN(6) = ADDRESS OF FCB ARRAY				07 02594
2595			2595	* RETURN(7) = MODE(REWIND OR LEAVE) OF V\$IDC OPEN CALL				07 02595
2596			2596	*				07 02596
2597			2597	* FOR LOGICAL FILES ONLY:				07 02597
2598			2598	*				07 02598
2599			2599	* RETURN(8) = ADDRESS OF LOGICAL RECORD SIZE				07 02599
2600			2600	* RETURN(9) = ADDRESS OF I/O BUFFER ARRAY				07 02600
2601			2601	* RETURN(10) = ADDRESS OF READ BEFORE WRITE FLAG				07 02601
2602			2602	*				07 02602
2603			2603	* EXIT : FCB LINKED TO CHAIN				07 02603
2604			2604	* ADFCB = ADDRESS OF FCB				07 02604
2605			2605	* FCB(0) = LOGICAL RECORD SIZE				07 02605
2606			2606	* FCB(1) = BUFFER ADDRESS				07 02606
2607			2607	* FCB OPENED BY V\$IDC OPEN CALL				07 02607
2608			2608	* FCB(11) = U = FORTRAN UNIT NUMBER				07 02608
2609			2609	* FCB(12)(BITS 0-7) = L = LOGICAL UNIT NUMBER				07 02609
2610			2610	*				07 02610
2611			2611	* LOGICAL FILES ONLY:				07 02611
2612			2612	*				07 02612
2613			2613	* FCB(3) = CURRENT LOGICAL RECORD NUMBER				07 02613
2614			2614	* FCB(12)(BIT RB) = 1 ENABLE READ BEFORE WRITE			V2*	07 02614
2615			2615	* = 0 DISABLE READ BEFORE WRITE			V2*	07 02615
2616			2616	* (BIT LF) = 1 LOGICAL FILE			V2*	07 02616
2617			2617	* 0 NOT LOGICAL FILE			V2*	07 02617
2618			2618	* (BIT RM) = 1 RMD DEVICE			V2*	07 02618
2619			2619	* 0 NOT RMD DEVICE			V2*	07 02619
2620			2620	* (BIT GF) = 1 GLOBAL FCB			V2*	07 02620
2621			2621	* 0 NOT GLOBAL FCB			V2*	07 02621
2622			2622	* FCB(13) = 0			*	07 02622
2623			2623	*			*	07 02623
2624			2624	*****			*	07 02624
2625			2625	*****			V2	07 02625
2626			2626	*****			V2	07 02626
2627			2627	* INITIALIZE *			V2	07 02627
2628			2628	*****			V2	07 02628
002730	016164	A	2629	DPN	LDA	TEMP,B	GET DP	V2 07 02629
002731	006140	A	2630		SUBI	CPV	BIAS IT	V2 07 02630
002732	000016	A						
002733	001010	A	2631	JAZ	+3	LOGICAL FILE ?	V2	07 02631
002734	002736	R						



002735	010422	A	2632	LDA	LFS	YES. SET FLAG	V2	07	02632
002736	110427	A	2633	DRA	INS	SET INITIALIZE FLAG	V2	07	02633
002737	056154	A	2634	STA	RWFL,B	STORE FLAG WORD	V2	07	02634
002740	036016	A	2635	LDX	ANRB,B	POINT X AT V\$FORTIO DATA BLOCK		07	02635
			2636	MOVXAB	SYSBF,SAVE+3	STORE =\$BUF AS BUFFER ADDRESS		07	02636
002741	015162	A							
002742	056035	A							
			2637	*****				07	02637
			2638	* MOVE PARAMETERS FROM CALL SEQ TO DATA BLOCK *				07	02638
			2639	*****				07	02639
002743	036151	A	2640	LDX	RETURN,B	POINT X AT CALL SEQ		07	02640
			2641	MOVXAB	5,SAVE	MOVE ADDRESS OF LOGICAL UNIT NUMBER L		07	02641
002744	015005	A							
002745	056032	A							
			2642	MOVXAB	6,SAVE+6	MOVE ADDRESS OF FCB ARRAY	V2	07	02642
002746	015006	A							
002747	056040	A							
			2643	MOVXAB	7,SAVE+1	MOVE ADDRESS OF OPEN MODE PARAMETER		07	02643
002750	015007	A							
002751	056033	A							
			2644	TRAB	RWFL,LF,DPN4	LOGICAL FILE ?	V2	07	02644
002752	016154	A							
002753	006441	A							
002754	002763	R							
			2645	MOVXAB	8,SAVE+2	YES. MOVE ADDRESS OF LOGICAL RECORD SIZE		07	02645
002755	015010	A							
002756	056034	A							
			2646	MOVXAB	9,SAVE+3	MOVE BUFFER ADDRESS		07	02646
002757	015011	A							
002760	056035	A							
			2647	MOVXAB	10,SAVE+4	SAVE ADDRESS OF READ BEFORE WRITE FLAG		07	02647
002761	015012	A							
002762	056036	A							
			2648	*****				07	02648
			2649	* PROCESS PARAMETERS *				07	02649
			2650	*****				07	02650
	002763	R	2651	DPN4	EQU *		V2	07	02651
			2652		IFF NUC		FG	07	02652
			2653		GOTO NUC1		FG	07	02653
			2654		IFT VII		FG	07	02654
			2655		GOTO VII1		FG	07	02655
			2656		TZAB ALQC,DPN5	SKIP BOUNDS TEST IF NOT BACKGROUND	E.1	07	02656
002763	016014	A							
002764	001010	A							
002765	002774	R							
002766	016040	A	2657	LDA	SAVE+6,B		D.1	07	02657
002767	006505	A	2658	JSR	TBK,X	TEST FCB IN BACKGROUND	V2	07	02658
002770	005735	R							
002771	126200	A	2659	ADD	BD14,B		V2	07	02659
002772	006505	A	2660	JSR	TBK,X		V2	07	02660
002773	005735	R							
	002774	R	2661	DPN5	EQU *		E.1	07	02661
			2662	VII1	CONT		FG	07	02662
			2663	NUC1	CONT		FG	07	02663
002774	036032	A	2664	LDX	SAVE,B	GET ADDRESS OF LOGICAL UNIT NUMBER L	V2	07	02664
			2665	MOVXAB	0,SAVE	GET L		07	02665
002775	015000	A							
002776	056032	A							
			2666	PUSHJ	PRU	PROCESS UNIT NUMBERS U,L	V2	07	02666
002777	105025	A							
003000	003734	R							
003001	036033	A	2667	LDX	SAVE+1,B	POINT X AT OPEN MODE M(REWIND,LEAVE)		07	02667
003002	015000	A	2668	LDA	0,X	GET M		07	02668
003003	001010	A	2669	JAZ	*+3			07	02669
003004	003006	R							
003005	010435	A	2670	LDA	RS12	SET LEAVE BIT		07	02670
003006	116032	A	2671	GRA	SAVE,B	MERGE IN L		07	02671
003007	006110	A	2672	DRAI	03000	MERGE IN SKELETON OF IDC OPEN CONT WD	V2	07	02672
003010	003000	A							
003011	036016	A	2673	LDX	ANRB,B	POINT X AT V\$FORTIO		07	02673
003012	055104	A	2674	STA	IDCONT,X	STORE I/O CONTROL WORD IN V\$FORTIO		07	02674
			2675	MOVXAB	SAVE+6,ADFCB	GET FCB ADDRESS	V2	07	02675
003013	016040	A							
003014	056010	A							
003015	055010	A	2676	STA	ADFCB,X	ALSO IN V\$FORTIO	V2	07	02676
003016	005014	A	2677	TAX		POINT X AT FCB		07	02677
			2678	MOVXAB	BD120,0	SET FCB(0) = 120 WORDS	V2	07	02678
003017	016201	A							
003020	055000	A							
			2679	MOVXAB	SAVE+3,1	LOAD BUFFER ADDRESS INTO FCB(1)		07	02679
003021	016035	A							
003022	055001	A							
003023	015002	A	2680	LDA	2,X	GET KEY WORD		07	02680
003024	150463	A	2681	ANA	PHW	CLEAR UPPER BYTE		07	02681
003025	006110	A	2682	DRAI	01400	SET MODE TO SEQUENTIAL	V2	07	02682
003026	001400	A							
003027	055002	A	2683	STA	2,X			07	02683
			2684	*****				07	02684
			2685	* MAKE IDC OPEN CALL *				07	02685
			2686	*****				07	02686
003030	010464	A	2687	LDA	010		V2	07	02687
003031	006505	A	2688	JSR	PSJ,X	CALL V\$FORTIO TO DO IDC OPEN	V2	07	02688
003032	004563	R							



```

2689 *****
2690 * LINK FCB ON CHAIN *
2691 *****
003033 036146 A 2692 LDX PRLINK,B POINT X AT LAST LINK OF FCB CHAIN
2693 MOVXAB ADFCB,10 LINK FCB ON CHAIN
003034 016010 A
003035 055012 A
003036 036016 A 2694 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK
003037 045120 A 2695 INR LNKCNT,X BUMP LINK COUNT
2696 *****
2697 * LOAD PARAMETERS INTO FCB ARRAY *
2698 *****
003040 005014 A 2699 TAX POINT X AT FCB(U)
2700 MOVXAB UNIT,11 MOVE FORTRAN UNIT NUMBER U TO FCB(11)
003041 016167 A
003042 055013 A
003043 016154 A 2701 LDA RWFL,B GET FLAG WORD V2 07 02701
003044 150447 A 2702 ANA INR CLEAR INITIALIZE FLAG V2 07 02702
003045 004254 A 2703 LRLA SH POSITION V2 07 02703
003046 116032 A 2704 ORA SAVE,B MERGE IN LOGICAL UNIT NUMBER L V2 07 02704
003047 055014 A 2705 STA 12,X STORE IN FCB(12) V2 07 02705
003050 006455 A 2706 BT ARST+FLF,DPN30 TEST IF LOGICAL FILE V2 07 02706
003051 003111 R
2707 *****
2708 * PROCESS LOGICAL FILE PARAMETERS *
2709 *****
003052 036034 A 2710 LDX SAVE+2,B
2711 MOVXAB 0,SAVE+2 SAVE LOGICAL RECORD SIZE
003053 015000 A
003054 056034 A
003055 036010 A 2712 LDX ADFCB,B POINT X AT FCB
003056 055000 A 2713 STA 0,X STORE LOGICAL RECORD SIZE IN FCB(0)
2714 TRAB RWFL,RM,DPN30 EXIT IF NOT RMD V2 07 02714
003057 016154 A
003060 006440 A
003061 003111 R
003062 036036 A 2715 LDX SAVE+4,B POINT X AT ADDR OF READ BEFORE WRITE FLAG
003063 015000 A 2716 LDA 0,X GET FLAG
003064 001010 A 2717 JAZ #+3
003065 003067 R
003066 010440 A 2718 LDA FRBS SET READ BEFORE WRITE FLAG V2 07 02718
003067 036010 A 2719 LDX ADFCB,B POINT X AT FCB
003070 115014 A 2720 ORA 12,X MERGE WITH L
003071 055014 A 2721 STA 12,X STORE IN FCB(12)
2722 ZAX 13 SET FCB(13)=0 TO MARK BUFFER EMPTY
003072 005001 A
003073 055015 A
003074 015003 A 2723 LDA 3,X GET CURRENT RECNO
003075 005311 A 2724 DAR CHANGE FROM BASE 1 TO BASE 0
003076 001010 A 2725 JAZ DPN30 EXIT IF AT START OF FILE
003077 003111 R
2726 *****
2727 * CONVERT PHYSICAL RECNO TO LOGICAL RECNO IN FCB(3) *
2728 *****
003100 005024 A 2729 TBX
003101 004560 A 2730 LLSR 16 SAVE BASE REGISTER IN X
003102 165201 A 2731 MUL BD120,X V2 07 02731
003103 175034 A 2732 DIV SAVE+2,X CONVERT PHYSICAL POSITION TO LOGICAL
003104 005021 A 2733 TBA
003105 005042 A 2734 TXB RESTORE BASE REGISTER B
003106 036010 A 2735 LDX ADFCB,B POINT X AT FCB
003107 005111 A 2736 IAR CHANGE FROM BASE 0 TO BASE 1
003110 055003 A 2737 STA 3,X STORE LOGICAL RECORD POSITION IN FCB(3)
003111 010422 A 2738 DPN30 LDA CEX
2739 PUSHF PUSH EXIT OP ONTO V$FORTIO STACK
003112 036016 A
003113 035000 A
003114 005344 A
003115 055000 A
003116 005041 A
003117 036016 A
003120 055000 A
003121 001000 A 2740 JMP CAN EXIT TO V$FORTIO
003122 000065 R
2741 EJEC
2742 *****
2743 *
2744 * P R O C E S S A U X I L I A R Y I / O ( P A X )
2745 *
2746 * FUNCTION: TO PROCESS THE FORTRAN AUXILIARY I/O STATEMENTS:
2747 *
2748 * BACKSPACE U
2749 * ENDFILE U
2750 * REWIND U
2751 *
2752 * ENTRY: DIRECT FROM RBE
2753 * UNIT = FORTRAN UNIT NUMBER U
2754 * TEMP = OP = 6 BACKSPACE
2755 * = 7 ENDFILE
2756 * = 8 REWIND
2757 *
2758 * EXIT : TO V$FORTIO WITH EXIT OP STACKED
2759 *

```



```

2760 *
2761 *****
2763 PAX SUTBPB TEMP,CBK,SAVE+1 GET BIASED OP V2 07 02763
003123 016164 A
003124 140467 A
003125 056033 A
2764 ZAB RWFL CLEAR FLAG WORD 07 02764
003126 005001 A
003127 056154 A
2765 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER U V2 07 02765
003130 105025 A
003131 003754 R
2766 TRAB RWFL,RM,PAX50 TEST IF RMD V2 07 02766
003132 016154 A
003133 006440 A
003134 003260 R
2767 ***** 07 02767
2768 * U IS RMD * 07 02768
2769 ***** 07 02769
2770 TZAB SAVE+1,PAX10 BACKSPACE 07 02770
003135 016033 A
003136 001010 A
003137 003145 R
003140 005311 A
003141 001010 A
003142 003161 R
003143 001000 A
003144 003244 R
2771 DAR NO 07 02771
2772 JAZ PAX15 ENDFILE ? 07 02772
2773 JMP PAX30 NO. REWIND 07 02773
2774 ***** 07 02774
2775 * BACKSPACE RMD * 07 02775
2776 ***** 07 02776
2777 PAX10 TSAB RWFL,GF,PAX50 CALL V$IOC BACKSPACE IF GLOBAL FCBV2 07 02777
003145 016154 A
003146 006407 A
003147 003260 R
2778 ***** 07 02778
2779 * BACKSPACE BY SETTING FCB(3) = FCB(3)-1 * 07 02779
2780 ***** 07 02780
003150 036010 A
2781 LDX ADFCB,B POINT X AT FCB 07 02781
2782 DAX 3 DECREMENT CURRENT RECORD NUMBER IN FCB(3) 07 02782
003151 015003 A
003152 005311 A
003153 055003 A
003154 005311 A
003155 001004 A
003156 003244 R
003157 001000 A
003160 003270 R
2783 DAR 07 02783
2784 JAN PAX30 DD REWIND IF FCB(3).LT.1 07 02784
2785 JMP PAX70 EXIT 07 02785
2786 ***** 07 02786
2787 * ENDFILE RMD * 07 02787
2788 ***** 07 02788
2789 PAX15 TRAB RWFL,PD,PAX16 POST BIT SET ? V2 07 02789
003161 016154 A
003162 006442 A
003163 003166 R
2790 PUSHJ PSB YES. POST BUFFER V2 07 02790
003164 105025 A
003165 004533 R
003166 006010 A
003167 013400 A
003170 116167 A
003171 036016 A
003172 055104 A
003173 016154 A
003174 006441 A
003175 003217 R
003176 036010 A
2791 PAX16 LDAI 013400 GET SKELETON CLOSE/UPDATE CONTROL WD V2 07 02791
2792 ORA UNIT,B MERGE IN LOGICAL UNIT NUMBER 07 02792
2793 LDX ANRB,B POINT X AT V$FORTIO DATA BLOCK 07 02793
2794 STA IOCONT,X STORE IOC CONTROL WORD IN V$FORTIO 07 02794
2795 LDA RWFL,B 07 02795
2796 BT ARST+LF,PAX20 LOGICAL FILE ? 07 02796
2797 LDX ADFCB,B YES. POINT X AT FCB 07 02797
2798 MOVBAX ED120,0 SET RECORD SIZE FCB(0) = 120 WORDS V2 07 02798
003177 016201 A
003200 055000 A
003201 016121 A
003202 005311 A
003203 005024 A
003204 004560 A
003205 165122 A
003206 175201 A
003207 001010 A
003210 003212 R
003211 005122 A
003212 005122 A
003213 005021 A
003214 005042 A
003215 036010 A
003216 055003 A
003217 010464 A
003220 006505 A
003221 004563 R
003222 006010 A
003223 013000 A
003224 116167 A
003225 036010 A
003226 055104 A
003227 010464 A
2799 LDA LRECNQ,B 07 02799
2800 DAR CONVERT FROM BASE 1 TO BASE 0 07 02800
2801 TBX SAVE BASE REGISTER IN X 07 02801
2802 LLSR 16 07 02802
2803 MUL LR52,X GET WORD COUNT 07 02803
2804 DIV ED120,X CONVERT TO 120-WORD PHYSICAL REC CNT V2 07 02804
2805 JAZ *30 07 02805
2806 IBR BUMP 1 FOR PARTIAL RECORD 07 02806
2807 IBR BUMP 1 TO CONVERT TO BASE 1 07 02807
2808 TRA 07 02808
2809 TXB RESTORE BASE REGISTER B 07 02809
2810 LDX ADFCB,B POINT X AT FCB 07 02810
2811 STA 3,X STORE CURRENT PHYSICAL RECNO IN FCB(3) 07 02811
2812 LDA CIO V2 07 02812
2813 JSR PCSJ,X CALL V$IOC FOR CLOSE/UPDATE V2 07 02813
2814 LDAI 013000 GET IOC OPEN/LEAVE SKELETON CONTROL WD V2 07 02814
2815 ORA UNIT,B MERGE IN LOGICAL UNIT NUMBER 07 02815
2816 LDX ANRB,B POINT X AT V$FORTIO 07 02816
2817 STA IOCONT,X STORE IOC CONTROL WORD IN V$FORTIO 07 02817
2818 LDA CIO V2 07 02818

```



```

003230 006505 A 2819      JSR      PSJ,X          CALL VSIOC FOR OPEN/LEAVE          V2 07 02819
003231 004563 R          TRAB      RWFL,LF,PAX70      EXIT IF NOT LOGICAL FILE          V2 07 02820
003232 016154 A          LDX      ADFCB,B        POINT X AT FCB                      07 02821
003233 006441 A          MOVBA   LRSZ,0         RESTORE LOGICAL RECORD SIZE IN FCB(0) 07 02822
003234 003270 R          MOVBA   LRECNO,3       RESTORE CURR LOG RECORD NUMBER IN FCB(3) 07 02823
003235 036010 A          JMP      PAX70         EXIT                                  07 02824
003236 016122 A          *****
003237 055000 A          *****
2825 *****
2826 * REWIND RMD *
2827 *****
2828 PAX30 TRAB      RWFL,GF,PAX33      GLOBAL FCB ?                      V2 07 02828
003244 016154 A          LDAI    03000         YES. CALL VSIOC OPEN/REWIND        V2 07 02829
003245 006447 A          JMP      PAX55         EXIT                                  07 02830
003246 003253 R          PAX33  LDX      ADFCB,B        POINT X AT FCB                      07 02831
003247 006010 A          INCR    1             SET CURRENT RECORD NUMBER TO 1      07 02832
003248 003000 A          STA     3,X          SET CURRENT RECORD NUMBER TO 1      07 02833
003249 001000 A          JMP      PAX70         EXIT                                  07 02834
003250 003000 A          *****
003251 001000 A          *****
003252 003263 R          *****
003253 036010 A          *****
003254 005101 A          *****
003255 055003 A          *****
003256 001000 A          *****
003257 003270 R          *****
2835 *****
2836 * CALL VSIOC TO DO OP *
2837 *****
003260 036033 A          PAX50  LDX      SAVE+1,B       GET BIASED OP IN X                  V2 07 02836
2838 *****
2839 *****
2840 *****
2841 *****
2842 *****
2843 NV2NUC  CONT     MAP,VSST0      SET EXEC STATE TO 00                V2 07 02842
2844 *****
003261 006015 A          LDAE    PAXTAB,X      GET IOC CONTROL WORD MODEL          V2 07 02843
003262 003315 R          *****
2845 *****
2846 *****
2847 *****
2848 *****
2849 NV2NUC  CONT     MAP,VSST3      SET EXEC STATE TO NH                V2 07 02848
2850 *****
003263 116167 A          PAX55  ORA      UNIT,B        MERGE IN LOGICAL UNIT NUMBER        07 02850
003264 036016 A          LDX      ANRB,B       STORE AS IOC CONTROL WORD          07 02851
003265 055104 A          STA     IOCNT,X      STORE AS IOC CONTROL WORD          07 02852
003266 007400 A          RDE     DATA        01006        07 02853
003267 001006 A          DATA   01006        07 02854
003270 007401 A          PAX70  SOF          07 02855
003271 010422 A          LDA     CEX          07 02856
2857 *****
003272 036016 A          PUSHF          07 02857
003273 035000 A
003274 005344 A
003275 055000 A
003276 005041 A
003277 036016 A
003300 055000 A
003301 001001 A          JDF      CAN          EXIT IF DONE                          07 02858
003302 000065 R          LDA     CID          07 02859
003303 010464 A          PUSHF          07 02860
003304 036016 A
003305 035000 A
003306 005344 A
003307 055000 A
003310 005041 A
003311 036016 A
003312 055000 A
003313 001000 A          JMP      CAN          EXIT                                  07 02861
003314 000065 R          *****
2862 *****
2863 * AUXILIARY I/O CONTROL WORD TABLE *
2864 *****
003315 012000 A          PAXTAB  DATA        012000      BACKSPACE                          07 02865
003316 001000 A          DATA   01000        WRITE EOF                          07 02866
003317 001400 A          DATA   01400        REWIND                             07 02867
2868 *****
2869 *****
2870 *****
2871 *****
2872 *****
2873 *****
2874 *****
2875 *****
2876 *****
2877 *****
2878 *****
2879 *****
          SCB(0): CURRENT CHARACTER COUNTER
          SCB(1): STRING START ADDRESS
          SCB(2): CHARACTER TO BE STORED
    
```



```

2880 *
2881 * EXIT : SCB(0) = SCB(0)+1
2882 *
2883 *****
003320 036021 A 2885 PCH LDX ASCB,B POINT X AT SCB
2886 MOVXAB 2,TEMP SAVE,CHAR
07 02886

003321 015002 A
003322 056164 A
003323 015000 A 2887 LDA 0,X GET CURRENT POINTER
003324 045000 A 2888 INR 0,X BUMP CURRENT POINTER
07 02888
003325 007401 A 2889 SDF
07 02889
003326 004257 A 2890 LRLA 15 CONVERT BYTE TO WORD COUNT
003327 003004 A 2891 XAN R0F DVFL SET IF HIGH BYTE
07 02891
003330 002201 R
003331 150460 A 2892 ANA BR15 CLEAR SIGN BIT
003332 125001 A 2893 ADD 1,X ADD STRING START ADDRESS
07 02893
003333 005014 A 2894 TAX POINT X AT WORD
07 02894
003334 015000 A 2895 LDA 0,X GET WORD
07 02895
003335 001007 A 2896 JDFN *+4 HIGH BYTE ?
07 02896
003336 003341 R
003337 007401 A 2897 SDF YES
07 02897
003340 004250 A 2898 LRLAB LRLA 8 SWAP BYTES
07 02898
003341 150462 A 2899 ANA LHW CLEAR UNWANTED BYTE
07 02899
003342 116164 A 2900 DRA TEMP,B MERGE IN NEW CHARACTER
07 02900
003343 003001 A 2901 XDF LRLAB SWAP BYTES IF HIGH BYTE
07 02901
003344 003340 R
003345 055000 A 2902 STA 0,X STORE IN MEMORY
07 02902
2903 POPJ EXIT
FG 07 02903
003346 105065 A
2904 EJEC
07 02904
2905 *****
07 02905
2906 *
07 02906
2907 * PROCESS NUMERIC INPUT DESCRIPTOR
07 02907
2908 * ( P N I )
07 02908
2909 *
07 02909
2910 * FUNCTION: TO PROCESS THE INPUT FORMAT DESCRIPTORS:
07 02910
2911 *
07 02911
2912 *
07 02912
2913 * SRDE.D
07 02913
2914 * SREW.D
07 02914
2915 * SRFW.D
07 02915
2916 * SRGW.D
07 02916
2917 * RIW
07 02917
2918 *
07 02918
2919 * ENTRY: (ACC,BEXP,SGFL) = INPUT NUMBER, WHERE
07 02919
2920 * ACC = NORMALIZED BINARY FRACTION
07 02920
2921 * BEXP = BINARY EXPONENT
07 02921
2922 * SGFL = SIGN .EQ. 0 +
07 02922
2923 * .NE. 0 -
07 02923
2924 *
07 02924
2925 * ITEMAD = ADDRESS OF LIST ITEM
07 02925
2926 * IIWSZ = WORD COUNT OF LIST ITEM
07 02926
2927 * ITMODE = LIST ITEM MODE
07 02927
2928 * = 0 1-WORD INTEGER/LOGICAL
07 02928
2929 * = 1 2-WORD INTEGER/LOGICAL
07 02929
2930 * = 2 REAL
07 02930
2931 * = 3 DOUBLE PRECISION
07 02931
2932 * = 4 COMPLEX
07 02932
2933 * EXIT : DIRECT TO FRS
07 02933
2934 *
07 02934
2935 *****
07 02935
003347 R 2937 DIN EQU *
07 02937
003347 R 2938 EIN EQU *
07 02938
003347 R 2939 FIN EQU *
07 02939
003347 R 2940 GIN EQU *
07 02940
003347 R 2941 IIN EQU *
07 02941
2943 *****
07 02943
2944 * TEST FOR ZERO *
07 02944
2945 *****
07 02945
003347 007401 A 2946 SDF
07 02946
003350 016004 A 2947 LDA ACC+1,B
07 02947
003351 116005 A 2948 DRA ACC+2,B
07 02948
003352 116006 A 2949 DRA ACC+3,B
07 02949
003353 003010 A 2950 XAZ R0F DVFL RESET IF ACC(1)=ACC(2)=ACC(3)=0
07 02950
003354 002201 R
003355 116003 A 2951 DRA ACC,B
07 02951
003356 001010 A 2952 JAZ PNI50 EXIT IF ACC=0
07 02952
003357 003552 R
003360 016116 A 2953 LDA ITMODE,B
07 02953
003361 140422 A 2954 SUB TWO
07 02954
003362 001002 A 2955 JAP PNI4 TEST INTEGER LIST ITEM
07 02955
003363 003432 R
2956 *****
07 02956
2957 * INTEGER LIST ITEM *
07 02957
2958 *****
07 02958
003364 001001 A 2959 JDF ER3 ERROR 3/ NOT INTEGER /
07 02959
003365 005365 R
003366 016024 A 2960 LDA BEXP,B GET BINARY EXPONENT
07 02960
003367 005311 A 2961 DAR
07 02961
003370 001004 A 2962 JAN ER3 ERROR 3/ NOT INTEGER /
07 02962
003371 005365 R
003372 140472 A 2963 SUB D15
07 02963
003373 001002 A 2964 JAP ER3 ERROR 3/ NOT INTEGER /
07 02964

```



Address	Label	Op/Reg	Description	Page
003374	005365	R		
2965	MOV BAB	ACC, TEMP	SAVE LEFT-JUSTIFIED INTEGER	07 02965
003375	016003	A		
003376	056164	A		
2966	ZAB	ACC	CLEAR ACCUMULATOR ACC	07 02966
003377	005001	A		
003400	056003	A		
2967	*****			07 02967
2968	* INTEGER SHIFT LOOP *			07 02968
2969	*****			07 02969
003401	005024	A		
2970	TBX		USE X AS BASE REGISTER	07 02970
2971	PNIL1	DAX BEXP	DECREMENT BINARY EXPONENT	07 02971
003402	015024	A		
003403	005311	A		
003404	055024	A		
003405	001004	A		
2972	JAN	PNIL1X	EXIT ON FINISH	07 02972
003406	003416	R		
003407	015003	A		
2973	LDA	ACC, X		07 02973
003410	025164	A		
2974	LDB	TEMP, X		07 02974
003411	004401	A		
2975	LASL	1	SHIFT INTEGER INTO ACC	07 02975
003412	053003	A		
2976	STA	ACC, X		07 02976
003413	065164	A		
2977	STB	TEMP, X		07 02977
003414	001000	A		
2978	JMP	PNIL1	CONTINUE TILL DONE	07 02978
003415	003402	R		
003416	001026	A		
2979	PNIL1X	JBNZ ER3	ERROR 3/ NOT INTEGER /	V2 07 02979
003417	005365	R		
003420	005042	A		
2980	TXB		RESTORE BASE REGISTER B	V2 07 02980
2981	TZAB	SGFL, PNIS0	IS SIGN NEGATIVE ?	07 02981
003421	016157	A		
003422	001010	A		
003423	003552	R		
003424	016003	A		
2982	LDA	ACC, B	YES	07 02982
003425	005211	A		
2983	CPA		NEGATE INTEGER	07 02983
003426	005111	A		
2984	IAR			07 02984
003427	056003	A		
2985	STA	ACC, B		07 02985
003430	001000	A		
2986	JMP	PNIS0		07 02986
003431	003552	R		
003432	130464	A		
2987	PNI4	ERA THREE		07 02987
003433	001010	A		
2988	JAZ	PNI60	D.P. INTEGER	07 02988
003434	003575	R		
003435	140422	A		
2989	SUB	TWO		07 02989
003436	001010	A		
2990	JAZ	PNIS	D.P.	07 02990
003437	003474	R		
2991	*****			07 02991
2992	* CONSTRUCT REAL *			07 02992
2993	*****			07 02993
003440	016004	A		
2994	LDA	ACC+1, B	GET 2ND MANTISSA WORD	07 02994
003441	120430	A		
2995	ADD	BS7	ROUND UPWARD	07 02995
003442	007400	A		
2996	RDF			07 02996
003443	001002	A		
2997	JAP	*+4	OVERFLOW ?	07 02997
003444	003447	R		
003445	005001	A		
2998	TZA		YES. CLEAR WORD	07 02998
003446	046003	A		
2999	INR	ACC, B	BUMP WORD 0	07 02999
003447	056004	A		
3000	STA	ACC+1, B		07 03000
003450	001007	A		
3001	JOFN	*+5	OVERFLOW ?	07 03001
003451	003455	R		
003452	046024	A		
3002	INR	BEXP, B	YES. BUMP BINARY EXPONENT	07 03002
3003	MOV BAB	BS14, ACC	SHIFT FIELD	07 03003
003453	010437	A		
003454	056003	A		
003455	005024	A		
3004	TBX		LOAD X AS BASE REGISTER	07 03004
003456	015024	A		
3005	LDA	BEXP, X	GET BINARY EXPONENT IN A	07 03005
003457	120430	A		
3006	ADD	BXBIAS	ADD BINARY EXPONENT BIAS	V2 07 03006
003460	025003	A		
3007	LDB	ACC, X	GET HIGH WORD OF MANTISSA IN B	07 03007
003461	004407	A		
3008	LASL	7	POSITION AS TO MAKE 1ST WORD OF REAL	07 03008
003462	055164	A		
3009	STA	TEMP, X	SAVE 1ST WORD OF REAL	07 03009
003463	015003	A		
3010	LDA	ACC, X	GET 1ST MANTISSA WORD IN A	07 03010
003464	025004	A		
3011	LDB	ACC+1, X	GET 2ND MANTISSA WORD IN B	07 03011
003465	004407	A		
3012	LASL	7	POSITION AS 2ND WORD OF REAL	07 03012
003466	055004	A		
3013	STA	ACC+1, X	STORE IN ACC	07 03013
003467	005042	A		
3014	TXB		RESTORE BASE REGISTER B	07 03014
3015	MOV BAB	TEMP, ACC	LOAD 1ST WORD OF REAL INTO ACC(0)	07 03015
003470	016164	A		
003471	056003	A		
003472	001000	A		
3016	JMP	PNI19		07 03016
003473	003535	R		
3017	*****			07 03017
3018	* CONSTRUCT DOUBLE PRECISION *			07 03018
3019	*****			07 03019
003474	016006	A		
3020	PNIS	LDA ACC+3, B		07 03020
003475	004241	A		
3021	LRLA	1		07 03021
003476	001002	A		
3022	JAP	PNI18	OVERFLOW ?	07 03022
003477	003523	R		
003500	046005	A		
3023	INR	ACC+2, B	YES. BUMP WORD 2	07 03023
003501	016005	A		
3024	LDA	ACC+2, B	GET WORD	07 03024
003502	001002	A		
3025	JAP	PNI18	OVERFLOW ?	07 03025
003503	003523	R		
003504	046004	A		
3026	INR	ACC+1, B	YES. BUMP WORD 1	07 03026
003505	005001	A		
3027	TZA			07 03027
003506	056005	A		
3028	STA	ACC+2, B	CLEAR WORD 2	07 03028
003507	016004	A		
3029	LDA	ACC+1, B	GET WORD 1	07 03029
003510	001002	A		
3030	JAP	PNI18	OVERFLOW ?	07 03030
003511	003523	R		



Address	Label	Op	Op	Op	Op	Op	Op	Op	Op
003512	046003	A	3031	INR	ACC,B	YES, BUMP WORD 0			07 03031
003513	005001	A	3032	TZA					07 03032
003514	056004	A	3033	STA	ACC+1,B	CLEAR WORD 1			07 03033
003515	016003	A	3034	LDA	ACC,B	GET WORD 0			07 03034
003516	001002	A	3035	JAP	PN118	OVERFLOW ?			07 03035
003517	003523	R							
003520	046024	A	3036	INR	BEXP,B	YES, BUMP BINARY EXPONENT			07 03036
003521	010437	A	3037	LDA	BS14	AND SHIFT OVERFLOW BIT			07 03037
003522	056003	A	3038	STA	ACC,B	STORE WORD 0			07 03038
			3039	PN118	MOV BAB	ACC+2,ACC+3	SHIFT FIELD		07 03039
003523	016005	A							
003524	056006	A							
			3040		MOV BAB	ACC+1,ACC+2			07 03040
003525	016004	A							
003526	056005	A							
			3041		MOV BAB	ACC,ACC+1			07 03041
003527	016003	A							
003530	056004	A							
003531	016024	A	3042	LDA	BEXP,B	GET BINARY EXPONENT			07 03042
003532	120430	A	3043	ADD	BXBIAS	ADD BINARY EXPONENT BIAS	V2		07 03043
003533	056003	A	3044	STA	ACC,B	STORE IN WORD 0			07 03044
003534	005124	A	3045	INCR	024	POINT X AT BASE+1			07 03045
003535	016157	A	3046	PN119	LDA	SGFL,B			07 03046
003536	001010	A	3047	JAZ	PN120	IS SIGN FLAG SET ?			07 03047
003537	003543	R							
003540	015003	A	3048	LDA	ACC,X	YES			07 03048
003541	005211	A	3049	CPA		NEGATE NUMBER			07 03049
003542	055003	A	3050	STA	ACC,X				07 03050
			3051	*****					07 03051
			3052	* CHECK EXPONENT RANGE *					07 03052
			3053	*****					07 03053
003543	016024	A	3054	PN120	LDA	BEXP,B	GET BINARY EXPONENT		07 03054
003544	120430	A	3055	ADD	BXBIAS	ADD BINARY EXPONENT BIAS	V2		07 03055
003545	001004	A	3056	JAN	ER3	ERROR 3/ UNDERFLOW /			07 03056
003546	005365	R							
003547	150462	A	3057	ANA	LHW				07 03057
003550	001016	A	3058	JANZ	ER3	ERROR 3/ OVERFLOW /			07 03058
003551	005365	R							
			3059	*****					07 03059
			3060	* LOAD LIST ITEM *					07 03060
			3061	*****					07 03061
			3062	PN150	ZAB	COUNT	CLEAR COUNTER		07 03062
003552	005001	A							
003553	056052	A							
			3063		MOV BAB	AACC,TEMP	INITIALIZE ACC POINTER		07 03063
003554	016001	A							
003555	056164	A							
			3064		MOV BAB	ITEMAD,BEXP	INITIALIZE LIST ITEM POINTER		07 03064
003556	016113	A							
003557	056024	A							
003560	036164	A	3065	PN112	LDX	TEMP,B	POINT X AT ACC		07 03065
003561	015000	A	3066	LDA	0,X	GET WORD			07 03066
003562	036024	A	3067	LDX	BEXP,B	POINT X AT LIST ITEM			07 03067
003563	055000	A	3068	STA	0,X	STORE DATA IN LIST ITEM			07 03068
003564	046164	A	3069	INR	TEMP,B	BUMP ACC POINTER			07 03069
003565	046024	A	3070	INR	BEXP,B	BUMP LIST ITEM POINTER			07 03070
003566	046052	A	3071	INR	COUNT,B	BUMP LOOP COUNT			07 03071
003567	016052	A	3072	LDA	COUNT,B				07 03072
003570	146102	A	3073	SUB	IWSZ,B				07 03073
003571	001004	A	3074	JAN	PN112	LOOP TILL ITEM FILLED			07 03074
003572	003560	R							
003573	001000	A	3075	JMP	FRS65	EXIT TO FRS			07 03075
003574	001014	R							
			3077	* PN160	PROCESS	DOUBLE PRECISION INTEGER			* 07 03077
003575	016005	A	3078	PN160	LDA	ACC+2,B			07 03078
003576	116006	A	3079	ORA	ACC+3,B				07 03079
003577	001016	A	3080	JANZ	ER3	NOT INTEGER			07 03080
003600	005365	R							
003601	016024	A	3081	LDA	BEXP,B				07 03081
003602	005311	A	3082	JAR					07 03082
003603	001004	A	3083	JAN	ER3	NOT INTEGER			07 03083
003604	005365	R							
003605	006140	A	3084	SUBI	30				07 03084
003606	000036	A							
003607	001002	A	3085	JAP	ER3	NOT INTEGER			07 03085
003610	005365	R							
003611	005024	A	3086	TBX					07 03086
003612	005111	A	3087	PN162	IAR	POSITION VALUE			07 03087
003613	001002	A	3088	JAP	PN164	DONE			07 03088
003614	003626	R							
003615	055024	A	3089	STA	BEXP,X				07 03089
003616	015003	A	3090	LDA	ACC,X				07 03090
003617	025004	A	3091	LDB	ACC+1,X				07 03091
003620	004501	A	3092	LASR	1				07 03092
003621	055003	A	3093	STA	ACC,X				07 03093
003622	065004	A	3094	STB	ACC+1,X				07 03094
003623	015024	A	3095	LDA	BEXP,X				07 03095
003624	001000	A	3096	JMP	PN162				07 03096
003625	003612	R							
003626	005042	A	3097	PN164	TXB	RESTORE BASE REGISTER B			07 03097
			3098	TZAB	SGFL,PN150	POSITIVE SIGN			07 03098
003627	016157	A							
003630	001010	A							



```

003631 003552 R
003632 015004 A 3099 LDA ACC+1,X NEGATE VALUE 07 03099
003633 025003 A 3100 LDB ACC,X 07 03100
003634 005211 A 3101 CPA 07 03101
003635 005222 A 3102 CPB 07 03102
003636 005111 A 3103 IAR 07 03103
003637 001002 A 3104 JAP PNI66 07 03104
003640 003643 R
003641 130440 A 3105 ERA BS15 07 03105
003642 005122 A 3106 IBR 07 03106
003643 055004 A 3107 PNI66 STA ACC+1,X 07 03107
003644 065003 A 3108 STB ACC,X 07 03108
003645 005042 A 3109 TXB 07 03109
003646 001000 A 3110 JMP PNI50 07 03110
003647 003552 R
3111 EJEC 07 03111
3112 ***** 07 03112
3113 * 07 03113
3114 * POP / JUMP ( P O J ) * 07 03114
3115 * 07 03115
3116 * FUNCTION: TO PROVIDE A POP/JUMP CAPABILITY * 07 03116
3117 * 07 03117
3118 * ENTRY: OPSTKP = DP STACK POINTER * 07 03118
3119 * 07 03119
3120 * EXIT : DIRECT TO ROUTINE SPECIFIED BY OP * 07 03120
3121 * OPSTKP INCREMENTED * 07 03121
3122 * 07 03122
3123 ***** 07 03123
003650 036000 A 3125 PDJ LDX OPSTKP,B POINT X AT DP 07 03125
003651 035000 A 3126 LDX 0,X GET DP IN X FG 07 03126
003652 046000 A 3127 INR OPSTKP,B BUMP STACK POINTER FG 07 03127
003653 006705 A 3128 IJMP 0,X EXIT 07 03128
003654 000000 A
3129 EJEC PD 07 03129
3130 ***** PD 07 03130
3131 * PD 07 03131
3132 * PROCESS ENCODE / DECODE * PD 07 03132
3133 * PD 07 03133
3134 * FUNCTION: TO PROCESS THE FORTRAN STATEMENTS * PD 07 03134
3135 * ENCODE(S,F,B,C) * PD 07 03135
3136 * DECODE(S,F,B,C) * PD 07 03136
3137 * PD 07 03137
3138 * ENTRY: DIRECT FROM RBE * PD 07 03138
3139 * RETURN = ADDRESS OF PARAMETER LIST * PD 07 03139
3140 * UNIT = BUFFER SIZE * PD 07 03140
3141 * TEMP = OP = CDC DECODE * PD 07 03141
3142 * CEN ENCODE * PD 07 03142
3143 * PD 07 03143
3144 * EXIT: ENCODE - BUFFER BLANKED * PD 07 03144
3145 * FRMT = ADDRESS OF FORMAT STRING * PD 07 03145
3146 * XFFL = 1 PARAMETER XFER ENABLED * PD 07 03146
3147 * ITEMWC = 0 COUNT OF WORDS REMAINING IN LIST ITEM * PD 07 03147
3148 * DIRECT TO FRS TO START FORMAT SCAN * PD 07 03148
3149 * PD 07 03149
3150 ***** PD 07 03150
003655 016164 A 3151 PRD LDA TEMP,B PD 07 03151
003656 006140 A 3152 SUBI CDC PD 07 03152
003657 000020 A
003660 004250 A 3153 LRLA 8 POSITION READ/WRITE FLAG PD 07 03153
003661 056104 A 3154 STA IDCONT,B PD 07 03154
003662 001010 A 3155 JAZ *+3 PD 07 03155
003663 003665 R
003664 010432 A 3156 LDA NRS SET WRITE BIT PD 07 03156
003665 110431 A 3157 ORA BFS SET FILL FLAG PD 07 03157
003666 006110 A 3158 ORAI U2000 SET ENCODE/DECODE BIT PD 07 03158
003667 002000 A
003670 056154 A 3159 STA RWFL,B INITIALIZE READ/WRITE FLAG WORD PD 07 03159
003671 036151 A 3160 LDX RETURN,B POINT X TO PARAMETER LIST PD 07 03160
3161 MOVXAB 3,FRMT SAVE FOR MAT STRING ADDRESS PD 07 03161
003672 015005 A
003673 056063 A
3162 MOVXAB 6,APBF BUFFER ADDRESS PD 07 03162
003674 015006 A
003675 056020 A
003676 056027 A 3163 STA ALBF,B PD 07 03163
003677 005311 A 3164 IAR 07 03164
003700 036025 A 3165 STA BFWPT,B PD 07 03165
003701 015007 A 3166 LDA 7,X CHARACTER-PROCESSED COUNT ADDRESS PD 07 03166
003702 056152 A 3167 STA RETURN+1,B PD 07 03167
003703 001010 A 3168 JAZ PRD1 NO COUNT FIELD PD 07 03168
003704 003711 R
003705 005014 A 3169 TAX PD 07 03169
003706 005001 A 3170 TZA PD 07 03170
003707 055000 A 3171 STA 0,X INITIALIZE COUNT VARIABLE PD 07 03171
003710 036151 A 3172 LDX RETURN,B PD 07 03172
003711 016167 A 3173 PRD1 LDA UNIT,B BUFFER SIZE PD 07 03173
003712 005111 A 3174 IAR PD 07 03174
003713 004301 A 3175 ACRA 1 MAKE BUFFER COUNT WORDS PD 07 03175
003714 056143 A 3176 STA PBSZ,B PD 07 03176
003715 056144 A 3177 STA PRWC,B PD 07 03177
003716 056122 A 3178 STA LRSZ,B PD 07 03178
003717 056123 A 3179 STA LRWC,B PD 07 03179
003720 005001 A 3180 TZA PD 07 03180

```



```

003721 056167 A 3181 STA UNIT,B SET NO UNIT PD 07 03181
003722 035016 A 3182 LDX ANRB,X POINT X AT V$FORTIO DATA BLOCK PD 07 03182
003723 010435 A 3183 LDA BS12 IOC MODE IS ASCII PD 07 03183
003724 115104 A 3184 ORA IOCONT,X PD 07 03184
003725 055104 A 3185 STA IOCONT,X PD 07 03185
3186 MOV BAX RWFL,RWFL PD 07 03186

003726 016154 A 3187 IFF NUC FG 07 03187
003727 055154 A 3188 GOTO NUC1 FG 07 03188
3189 IFT VII FG 07 03189
3190 GOTO VII1 FG 07 03190
3191 TZAB ALOC,PRD2 ALOC ENTRY FROM BACKGROUND PD 07 03191

003730 016014 A 3192 LDA APBF,X YES PD 07 03192
003731 001010 A 3193 JSR TBK,X TEST BUFFER START ADDRESS PD 07 03193
003732 003742 R 3194 ADD PBSZ,B PD 07 03194
003733 015020 A 3195 DAR PD 07 03195
003734 006505 A 3196 JSR TBK,X TEST BUFFER END ADDRESS PD 07 03196
003735 005735 R 3197 VIII1 CONT FG 07 03197
003736 126143 A 3198 NUC1 CONT FG 07 03198
003737 005311 A 3199 PRD2 ZAB BFPT CLEAR BUFFER CHARACTER POINTER PD 07 03199
003741 005735 R 3200 TRAB RWFL,WR,PRD4 WRITE? PD 07 03200
003742 005001 A 3201 PUSHJ CLB YES, CLEAR BUFFER PD 07 03201
003743 056026 A 3202 PRD4 INR XFFL,B ENABLE PARAMETER XFER PD 07 03202
003744 016154 A 3203 JMP FRS TO FORMAT SCAN PD 07 03203
003745 006451 A
003746 003751 R
003747 103025 A
003750 000127 R
003751 046172 A
003752 001000 A
003753 000410 R

3204 EJEC 07 03204
3205 ***** 07 03205
3206 * 07 03206
3207 * PROCESS UNIT NUMBER ( PRU ) * 07 03207
3208 * * 07 03208
3209 * FUNCTION: TO PROCESS A FORTRAN UNIT NUMBER U * 07 03209
3210 * * 07 03210
3211 * ENTRY: UNIT = FORTRAN UNIT NUMBER U * 07 03211
3212 * RWFL(BF) = 1 V2 07 03212
3213 * RWFL(IN) = 1 IF OPEN CALL V2* 07 03213
3214 * FCB CHAIN ITEM XFCB HAS FORMAT: * 07 03214
3215 * XFCB(12)(BITS 0-7) = L(XFCB) * 07 03215
3216 * XFCB(12)(BIT 12) = 1 RMD FILE V2 07 03216
3217 * 0 NOT RMD FILE V2 07 03217
3218 * XFCB(12)(BIT 13) = 1 LOGICAL FILE V2* 07 03218
3219 * 0 NOT LOGICAL FILE V2* 07 03219
3220 * XFCB(12)(BIT 14) = 1 UNPOSTED DATA IN BUFFER * 07 03220
3221 * = 0 NO UNPOSTED DATA IN FILE * 07 03221
3222 * XFCB(12)(BIT 15) = 1 ENABLE READ BEFORE WRITE * 07 03222
3223 * = 0 DISABLE READ BEFORE WRITE * 07 03223
3224 * XFCB(13) = PHYSICAL RECORD NUMBER IN BUFFER(0 IF NONE) * 07 03224
3225 * * 07 03225
3226 * EXIT : ADPCB = ADDRESS OF DCB/FCB * 07 03226
3227 * UNIT = LOGICAL UNIT NUMBER L * 07 03227
3228 * LRSZ = FCB(0) = LOGICAL RECORD SIZE IN WORDS * 07 03228
3229 * APBF = ADDRESS OF PHYSICAL BUFFER * 07 03229
3230 * ALBF = ADDRESS OF LOGICAL BUFFER * 07 03230
3231 * PBSZ = PHYSICAL BUFFER SIZE IN WORDS * 07 03231
3232 * RWFL(BIT RM) = FCB(12)(BIT 12) RMD FLAG V2 07 03232
3233 * RWFL(BIT LF) = FCB(12)(BIT 13) LOGICAL FILE FLAG V2 07 03233
3234 * RWFL(BIT PD) = FCB(12)(BIT 14) POST FLAG V2 07 03234
3235 * RWFL(BIT RB) = FCB(12)(BIT 15) READ BEFORE WRITE FLAG V2 07 03235
3236 * RWFL(BIT BF) = 0 IF READ IS TO RETURN I/O WORD COUNT V2 07 03236
3237 * 1 IF READ IS TO RETURN FULL BUFF(BLANK FILL) V2 07 03237
3238 * RWFL(BIT GF) = 1 IF GLOBAL FCB V2* 07 03238
3239 * * 07 03239
3240 * THE FOLLOWING APPLY ONLY TO LOGICAL FILES: * 07 03240
3241 * * 07 03241
3242 * LGQV = INCREMENT FROM START OF PHYSICAL TO START OF LOGICAL * 07 03242
3243 * LRECND = FCB(3) = LOGICAL RECORD NUMBER * 07 03243
3244 * PBRC = COUNT OF 120-WORD RECORDS IN PHYSICAL BUFFER * 07 03244
3245 * * 07 03245
3246 * ERRORS: ER4 IF U NOT IN RANGE 1-255 * 07 03246
3247 * ER4 IF L INVALID * 07 03247
3248 * ER4 IF FOREGROUND RMD NOT OPENED * 07 03248
3249 * ER4 IF BACKGROUND RMD NOT OPENED NOR W/GLOBAL FCB * 07 03249
3250 * ER4 IF U ALREADY ON CHAIN FOR OPEN CALL V2* 07 03250
3251 * * 07 03251
3252 ***** 07 03252
3253 ***** 07 03253
3254 ***** 07 03254
3255 * TEST RANGE OF U * 07 03255
3256 ***** 07 03256
003754 016167 A 3257 PRU LDA UNIT,B GET U 07 03257
003755 150462 A 3258 ANA LHW 07 03258
003756 001016 A 3259 JANZ ER4 ERROR 4/ U NOT IN (1,255) / 07 03259

```



Address	Label	Op	Op2	Op3	Description	Flags	Line
003757	005364	R					
3260					*****		07 03260
3261					* SEARCH FCB CHAIN FOR U ALREADY DEFINED *		07 03261
3262					*****		07 03262
3263			TRAB	RWFL,DA,PRU0			07 03263
003760	016154	A					
003761	006453	A					
003762	003767	R					
003763	036151	A	3264	LDX	RETURN,B	DIRECT ACCESS	07 03264
003764	015011	A	3265	LDA	9,X	FCB ADDRESS	07 03265
003765	001000	A	3266	JMP	PRU05		07 03266
003766	003773	R					
3267	PRU0		PUSHJ	SCH		SEARCH FCB CHAIN	07 03267
003767	105025	A					
003770	005625	R					
003771	001010	A	3268	JAZ	PRU5		07 03268
003772	004077	R					
3269					*****		07 03269
3270					* U IS ON FCB CHAIN *		07 03270
3271					*****		07 03271
003773	056010	A	3272	PRU05	STA	ADFCB,B	STORE FCB ADDRESS
003774	036016	A	3273		LDA	ANRB,B	E 07 03273
003775	055010	A	3274		STA	ADFCB,X	E 07 03274
003776	005014	A	3275		TAX		07 03275
			3276		TSAB	RWFL,IN,ER4	ERROR 4/ OPEN CALL FINDS U ON CHAIN / V2 07 03276
003777	016154	A					
004000	006406	A					
004001	005364	R					
3277			MOVXAB	3,SVREC		SAVE RECORD NO	07 03277
004002	015003	A					
004003	056160	A					
3278			MOVXAB	0,LRSZ		SET LOGICAL RECORD SIZE = FCB(0)	07 03278
004004	015000	A					
004005	056122	A					
004006	056143	A	3279		STA	PBSZ,B	ALSO PHYSICAL RECORD SIZE 07 03279
			3280		MOVXAB	1,APBF	SET PHYSICAL BUFFER ADDRESS = FCB(1) 07 03280
004007	015001	A					
004010	056020	A					
004011	056027	A	3281		STA	ALBF,B	ALSO LOGICAL BUFFER ADDRESS 07 03281
004012	015014	A	3282		LDA	12,X	GET L 07 03282
004013	150463	A	3283		ANA	RHW	07 03283
004014	056167	A	3284		STA	UNIT,B	STORE LOGICAL UNIT NUMBER L IN UNIT 07 03284
004015	015014	A	3285		LDA	12,X	GET FLAGS FROM FCB 07 03285
004016	004354	A	3286		LSRA	SH	POSITION V2 07 03286
004017	116154	A	3287		ORA	RWFL,B	MERGE INTO READ/WRITE FLAG 07 03287
004020	056154	A	3288		STA	RWFL,B	07 03288
004021	006441	A	3289		BT	ARST*LF,PRU50	EXIT ON NON-LOGICAL FILE FG 07 03289
004022	004346	R					
004023	006400	A	3290		BT	ASET+RM,PRU1	RMD ? V2 07 03290
004024	004030	R					
004025	150451	A	3291		ANA	BFR	NO. CLEAR FILL FLAG V2 07 03291
004026	056154	A	3292		STA	RWFL,B	V2 07 03292
			3293		POPJ		EXIT FG 07 03293
004027	105065	A					
3294					*****		V2 07 03294
3295					* U IS AN RMD LOGICAL FILE *		V2 07 03295
3296					*****		V2 07 03296
004030	R		3297	PRU1	EQU	*	V2 07 03297
			3298		MOVXAB	3,LRECNO	LOAD LOGICAL RECORD NUMBER 07 03298
004030	015003	A					
004031	056121	A					
004032	016122	A	3299		LDA	LRSZ,B	GET LOGICAL RECORD SIZE 07 03299
004033	005024	A	3300		TBX		SAVE BASE POINTER IN X 07 03300
004034	145201	A	3301		SUB	BD120,X	V2 07 03301
004035	001002	A	3302		JAP	PRU2	IS LOGICAL RECORD SIZE .LT. 120 WORDS ? 07 03302
004036	004045	R					
004037	015201	A	3303		LDA	BD120,X	YES V2 07 03303
004040	004560	A	3304		LLSR	16	07 03304
004041	175122	A	3305		DIV	LRSZ,X	07 03305
004042	005102	A	3306		INCR	E	SET BUFFER SIZE TO 1 RECORD 07 03306
004043	001000	A	3307		JMP	PRU3	07 03307
004044	004054	R					
004045	015122	A	3308	PRU2	LDA	LRSZ,X	07 03308
004046	004560	A	3309		LLSR	16	07 03309
004047	175201	A	3310		DIV	BI120,X	GET COUNT OF PHYSICAL RECS IN LOG REC V2 07 03310
004050	001010	A	3311		JAZ	PRU4	ANY REMAINDER ? 07 03311
004051	004057	R					
004052	005122	A	3312		IBR		YES. BUMP ALLOCATION 07 03312
004053	005311	A	3313		DAR		07 03313
004054	001010	A	3314	PRU3	JAZ	*+3	07 03314
004055	004057	R					
004056	005122	A	3315		IBR		BUMP COUNT IF NOT FACTOR OR MULTIPLE 07 03315
004057	065142	A	3316	PRU4	STB	PBRC,X	STORE PHYSICAL RECORD COUNT 07 03316
004060	005001	A	3317		TZA		07 03317
004061	165201	A	3318		MUL	BD120,X	GET PHYSICAL BUFFER SIZE V2 07 03318
004062	065143	A	3319		STB	PBSZ,X	STORE 07 03319
004063	015121	A	3320		LDA	LRECNO,X	GET LOGICAL RECORD NUMBER 07 03320
004064	005311	A	3321		DAR		CONVERT FROM BASE 1 TO BASE 0 07 03321
004065	004560	A	3322		LLSR	16	07 03322
004066	165122	A	3323		MUL	LRSZ,X	GET WORD COUNT TO START OF LRECNO 07 03323
004067	175201	A	3324		DIV	BD120,X	GET PHYSICAL RECORD COUNT TO LRECNO V2 07 03324
004070	005122	A	3325		IBR		CONVERT FROM BASE 0 TO BASE 1 07 03325
004071	065145	A	3326		STB	PRECNO,X	SAVE PHYSICAL RECORD NUMBER 07 03326



Address	Label	Op	Op2	Op3	Description	Flags	Page
004072	055123	A	3327	STA	LGOV,X		07 03327
004073	125020	A	3328	ADD	APBF,X		07 03328
004074	055027	A	3329	STA	ALBF,X		07 03329
004075	005042	A	3330	TXB			07 03330
			3331	POPU			07 03331
004076	105065	A				FG	
			3332	*****			07 03332
			3333	* U NOT ON FCB CHAIN - SET L=U *			07 03333
			3334	*****			07 03334
004077	036016	A	3335	PRU5	LDX ANRB,B		07 03335
			3336	MOVXAB	ASYSDB,ADFCB		07 03336
004100	015023	A					
004101	056010	A					
004102	055010	A	3337	STA	ADFCB,X		07 03337
004103	005014	A	3338	TAX			07 03338
			3339	MOVXAB	1,APBF		07 03339
004104	015001	A					
004105	056020	A					
004106	056027	A	3340	STA	ALBF,B		07 03340
			3341	MOVBAX	BD120,0		07 03341
004107	016201	A				V2	
004110	055000	A					
004111	056143	A	3342	STA	PBSZ,B		07 03342
004112	056122	A	3343	STA	LRSZ,B		07 03343
			3344	*****			07 03344
			3345	* TEST VALIDITY OF L *			07 03345
			3346	*****			07 03346
004113	036032	A	3347	LDX	SAVE,B		07 03347
			3348	TSAB	RWFL,IN,PRU6		07 03348
004114	016154	A				V2	
004115	006406	A					
004116	004120	R					
004117	036167	A	3349	LDX	UNIT,B		07 03349
004120	005041	A	3350	PRU6	TXA		07 03350
004121	001010	A	3351	JAZ	PRU50		07 03351
004122	004346	R				FG	
004123	006030	A	3352	LDXI	V\$LUT1		07 03352
004124	000400	A					
004125	005311	A	3353	DAR			07 03353
004126	056164	A	3354	STA	TEMP,B		07 03354
004127	005111	A	3355	IAR			07 03355
004130	006140	A	3356	SUBI	101		07 03356
004131	000145	A					
004132	001004	A	3357	JAN	PRU10		07 03357
004133	004144	R					
004134	005144	A	3358	IXR			07 03358
004135	056164	A	3359	STA	TEMP,B		07 03359
004136	006140	A	3360	SUBI	79		07 03360
004137	000117	A					
004140	001004	A	3361	JAN	PRU10		07 03361
004141	004144	R					
004142	005144	A	3362	IXR			07 03362
004143	056164	A	3363	STA	TEMP,B		07 03363
004144	016164	A	3364	PRU10	LDA TEMP,B		07 03364
004145	035000	A	3365	LDX	0,X		07 03365
004146	145000	A	3366	SUB	0,X		07 03366
004147	001002	A	3367	JAP	ER4		07 03367
004150	005364	R					
			3368	*****			07 03368
			3369	* GET DST INFO *			07 03369
			3370	*****			07 03370
004151	005141	A	3371	INCR	041		07 03371
004152	126164	A	3372	ADD	TEMP,B		07 03372
004153	005014	A	3373	TAX			07 03373
004154	015000	A	3374	LDA	0,X		07 03374
004155	150463	A	3375	ANA	RHW		07 03375
004156	056037	A	3376	STA	SAVE+5,B		07 03376
004157	001010	A	3377	JAZ	PRU50		07 03377
004160	004346	R				FG	
004161	005024	A	3378	TBX			07 03378
004162	005312	A	3379	DECR	012		07 03379
004163	010355	A	3380	LDA	V\$DSTB		07 03380
004164	160464	A	3381	MUL	THREE		07 03381
004165	005041	A	3382	TXA			07 03382
004166	005024	A	3383	TBX			07 03383
004167	005012	A	3384	TAB			07 03384
			3385	*****			07 03385
			3386	* TEST IF L ASSIGNED TO RMD *			07 03386
			3387	*****			07 03387
004170	015002	A	3388	LDA	0,X		07 03388
004171	004346	A	3389	LCRA	6		07 03389
004172	150473	A	3390	ANA	AM07		07 03390
004173	001010	A	3391	JAZ	*+3		07 03391
004174	004176	R				V2	
004175	010421	A	3392	LDP	RMS		07 03392
004176	116154	A	3393	DRA	RWFL,B		07 03393
004177	056154	A	3394	STA	RWFL,B		07 03394
004200	006406	A	3395	BT	ASET+IN,PRU50		07 03395
004201	004346	R				FG	
004202	006400	A	3396	BT	ASET+RM,PRU30		07 03396
004203	004256	R				V2	
			3397	*****			07 03397
			3398	* L NOT RMD *			07 03398



```

3399 *****
3400          TZAB      FRMT,PRU15  FORMATTED I/O ?          V2  07 03399
004204 016063 A          3401          LDA      1,X          YES. GET 1ST TWO CHARS OF NAMR  V2  07 03401
004205 001010 A          3402 PRU15  EQU      *          V2  07 03402
004206 004210 R          3403          STX      SAVE,B      SAVE DST ADDR          E.1 07 03403
004207 015001 A          3404          IFF      NUC          FG  07 03404
004210 076032 A          3405          GOTO     NV2NUC      FG  07 03405
          3406          IFT      VII          FG  07 03406
          3407          OME     MAP,V$ST0  SET EXEC STATE TO 00      V2  07 03407
004211 034147 A          3408 NV2NUC  CONT          MAP,V$ST0  SET EXEC STATE TO 00      FG  07 03408
          3409          LDX      PRUDTB  POINT X AT DEVICE TABLE  07 03409
          3410          *****
          3411 * LOOP TO IDENTIFY DEVICE *          07 03410
          3412          *****          07 03411
004212 005144 A          3413 PRU11  IXR          BUMP TABLE POINTER          07 03412
004213 145000 A          3414          SUB      0,X          V2  07 03413
004214 001010 A          3415          JAZ      PRU20      EXIT ON MATCH          V2  07 03414
004215 004222 R          3416          JAP      PRU11      LOOP TILL DONE          V2  07 03416
004216 001002 A          3417          LDXI     PRUDE      POINT X AT END IF NO FIND  V2  07 03417
004217 004212 R          3418 PRU20  LDA      PRUDE-PRUDTB,X  GET DEVICE PARAMS FROM TABLE  07 03418
004220 006030 A          3419          JAN      PRU25      IF SPOOL UNIT          E.1 07 03419
004221 004370 R          3420          TAX          SAVE          V2  07 03420
004222 015007 A          3421          JAN      PRU25      IF SPOOL UNIT          E.1 07 03421
004223 001004 A          3422          IFF      NUC          FG  07 03422
004224 004245 R          3423          GOTO     NV2NUC      FG  07 03423
004225 005014 A          3424          IFT      VII          FG  07 03424
004226 001004 A          3425          OME     MAP,V$ST3  SET EXEC STATE TO NN      V2  07 03425
004227 004245 R          3426 NV2NUC  CONT          MAP,V$ST3  SET EXEC STATE TO NN      FG  07 03426
004230 150431 A          3427          ANA     BFS          V2  07 03427
004231 056164 A          3428          STA     TEMP,B      SAVE          07 03428
004232 005041 A          3429          TXA          RESIDRE A          V2  07 03429
004233 036010 A          3430          LDX     ADFCB,B      POINT X AT DCB          07 03430
004234 150463 A          3431          ANA     RHW          GET RECORRD SIZE          07 03431
004235 055000 A          3432          STA     0,X          STORE IN DCB          07 03432
004236 056143 A          3433          STA     PBSZ,B      ALSO AS PHYSICAL BUFFER SIZE  07 03433
004237 056122 A          3434          STA     LRSZ,B      ALSO LOGICAL BUFFER SIZE     07 03434
004240 016154 A          3435          LDA     RWFL,B      V2  07 03435
004241 150451 A          3436          ANA     BFR          V2  07 03436
004242 116164 A          3437          DRA     TEMP,B      MERGE FILL FLAG          V2  07 03437
004243 056154 A          3438          STA     RWFL,B      INTO READ/WRITE FLAGS      07 03438
          3439          POPJ          EXIT          FG  07 03439
004244 105065 A          3440 PRU25  EQU      *          E.207 03440
          004245 R          3441          IFF      NUC          E.207 03441
          3442          GOTO     NV2NUC      E.207 03442
          3443          IFT      VII          E.207 03443
          3444          OME     MAP,V$ST3  SET EXEC STATE TO NN      E.207 03444
          3445 NV2NUC  CONT          MAP,V$ST3  SET EXEC STATE TO NN      E.207 03445
004245 036032 A          3446          LDX     SAVE,B      DST ADDR          E.207 03446
004246 015000 A          3447          LDA     0,X          DSUNAM (BITS 12-4)      E.1 07 03447
004247 004352 A          3448          LSR     10          POSITION MSB          E.1 07 03448
004250 150467 A          3449          ANA     SEVEN       E.1 07 03449
004251 006120 A          3450          ADDI    180         SET TO LUN 18N          E.1 07 03450
004252 000264 A          3451          TAX          E.1 07 03451
004253 005014 A          3452          JMP     PRU6        E.1 07 03452
004254 001000 A          3453          *****          07 03453
004255 004120 R          3454 * RMD FILE *          07 03454
          3455          *****          07 03455
004256 010301 A          3456 PRU30  LDA     V$CPL  GET PRIORITY LEVEL          07 03456
004257 140422 A          3457          SUB     TWO         07 03457
004260 001002 A          3458          JAP     ER4         ERPOR 4/ FOREGROUND RMD FILE NOT OPEN / 07 03458
004261 005364 R          3459          *****          07 03459
          3460 * BACKGROUND PROGRAM - CHECK GLOBAL FCB'S *          07 03460
          3461          *****          07 03461
004262 016167 A          3462          LDA     UNIT,B      GET L          07 03462
004263 006110 A          3463          DRAI    01400      MERGE IOLINK SKELETON CONTROL WORD  V2  07 03463
004264 001400 A          3464          STA     IOLNK,B      IOLINK CONTROL WORD FOR L GLOBAL FCB  07 03464
004265 056105 A          3465          LDA     UNIT,B      GET L          07 03465
004266 016167 A          3466          SUB     TWO         07 03466
004267 140422 A          3467          JAN     PRU35      IGNORE L=1          07 03467
004270 001004 A          3468          SUB     NINE        07 03468
004271 004305 R          3469          JAP     PRU35      NO GLOBAL FCB.GT.10      07 03469
004272 140470 A          3470          IFF     NUC          FG  07 03470
004273 001002 A          3471          GOTO     NV2NUC      FG  07 03471
004274 004305 R          3472          IFT     VII          FG  07 03472
          3473          OME     MAP,V$ST0  SET EXEC STATE TO 00      V2  07 03473
          3474 NV2NUC  CONT          MAP,V$ST0  SET EXEC STATE TO 00      07 03474
004275 124062 A          3475          ADD     PRUGT      ADD TABLE ADDRESS          07 03475
004276 005014 A          3476          TAX          POINT X AT GLOBAL FCB TABLE  07 03476

```



```

004277 035000 A 3477 LDX 0,X POINT X AT GLOBAL FCB 07 03477
3478 IFF NUC FG 07 03478
3479 GOTO NV2NUC NV2NUC FG 07 03479
3480 IFT VII FG 07 03480
3481 OME MAP,V$ST3 SET EXEC STATE TO NN 07 03481
3482 NV2NUC CONT 3482 NV2NUC CONT 07 03482
3483 JXZ PRU35 'SD' HAS NO GLOBAL FCB FG 07 03483
004300 001040 A 3484 LDA S,X TEST GLOBAL FCB ENABLED 07 03484
004301 004305 R 3485 JANZ PRU40 07 03485
004302 015005 A 3486 ***** 07 03486
004303 001016 A 3487 * NO GLOBAL FCB - TEST U=SI * 07 03487
004304 004332 R 3488 ***** 07 03488
3489 PRU35 LDX V$LUT1 07 03489
004305 030400 A 3490 LDA 2,X GET SI ASSIGNMENT 07 03490
004306 015002 A 3491 SUB SAVE+5,B COMPARE WITH L ASSIGNMENT V2 07 03491
004307 146037 A 3492 ANA RHW 07 03492
004310 150463 A 3493 JANZ ER4 ERROR 4/ RMD FILE NOT OPEN / 07 03493
004311 001016 A 3494 LDA TWD L = SI 07 03494
004312 005364 R 3495 URAI 01400 MERGE IOLINK SKELETON CONTROL WORD V2 07 03495
004313 010422 A 3496 STA IOLNK,B IOLINK CONTROL WORD FOR SIFCB 07 03496
004314 006110 A 3497 LDRAI 40 V2 07 03497
004315 001400 A 3498 STA P$SZ,B ALSO PHYSICAL BUFFER SIZE 07 03498
004316 056105 A 3499 STA LRSZ,B ALSO LOGICAL BUFFER SIZE 07 03499
004317 006010 A 3500 LDX ADFCB,B POINT X AT V$FORTIO DATA BLOCK 07 03500
004320 000050 A 3501 STA 0,X SET RECORD SIZE DCB(0) = 40 WORDS 07 03501
004321 056143 A 3502 LDXI SIFCB POINT X AS SI GLOBAL FCB V2 07 03502
004322 056122 A 3503 LDA S,X 07 03503
004323 036010 A 3504 JAZ ER4 ERROR 4/ RMD NOT OPEN / 07 03504
004324 055000 A 3505 PRU40 TXA GET FCB ADDRESS IN A 07 03505
004325 006030 A 3506 STA ADFCB,B STORE 07 03506
004326 000000 E 3507 LDX ANRB,B POINT X AT V$FORTIO 07 03507
004327 015005 A 3508 STA ADFCB,X STORE IN V$FORTIO 07 03508
004328 001010 A 3509 MOVBAI IOLNK,IOLNK MOVE IOLINK CONTROL WORD TO V$FORTIO 07 03509
004330 001010 A 3510 LDA RWFL,B V2 07 03510
004331 005364 R 3511 ORA GFS SET GLOBAL FCB FLAG V2 07 03511
004332 005041 A 3512 STA RWFL,B V2 07 03512
004333 056010 A 3513 LDA CXC V2 07 03513
004334 036016 A 3514 JSR PSJ,X PUSH IOLINK DP V2 07 03514
004335 055010 A 3515 PRU50 POPJ EXIT FG 07 03515
004346 105065 A 3516 ***** 07 03516
3517 * GLOBAL FCB POINTERS * 07 03517
3518 ***** 07 03518
004347 004326 E 3519 PRUASI PZE SIFCB S( 2) GLOBAL FCB 07 03519
004350 000000 A 3520 DATA 0 S( 3) NO GLOBAL FCB 07 03520
004351 000000 E 3521 PZE PIFCB P( 4) GLOBAL FCB 07 03521
004352 000000 E 3522 PZE LOFCB L( 5) GLOBAL FCB 07 03522
004353 000000 E 3523 PZE BIFCB B( 6) GLOBAL FCB 07 03523
004354 000000 E 3524 PZE BOFCB B( 7) GLOBAL FCB 07 03524
004355 000000 E 3525 PZE SSFCB S( 8) GLOBAL FCB 07 03525
004356 000000 E 3526 PZE SOFCB G( 9) GLOBAL FCB 07 03526
004357 000000 E 3527 PZE POFCB P(10) GLOBAL FCB 07 03527
004360 004360 R 3528 PRUGT PZE * 07 03528
3529 ***** 07 03529
3530 * DEVICE TABLE * 07 03530
3531 ***** 07 03531
004361 004361 R 3532 PRUDTB PZE * 07 03532
004362 141720 A 3533 DATA 'CP' 1ST 2 CHARS OF DEVICE NAME 07 03533
004363 000002 A 3534 DATA 2 'CR' V2 07 03534
004364 000002 A 3535 DATA 2 'CT' V2 07 03535
004365 004374 A 3536 DATA 04374 'LP' V2 07 03536
004366 003400 A 3537 DATA 03400 :SP: E.1 07 03537
004367 000411 A 3538 DATA 0411 :TY: E.1 07 03538
004370 077777 A 3539 PRUDTE EQU 077777 TABLE END MARKER V2 07 03539
004371 000050 A 3540 DATA *-1 07 03540
004372 000050 A 3541 DATA 40 CONSOLE FLAG/BUFFER SIZE 07 03541
004373 000450 A 3542 DATA 40 07 03542
004374 000102 A 3543 DATA 40+BFA V2 07 03543
004375 177777 A 3544 DATA 66 07 03544
004376 000450 A 3545 DATA -1 SPOOL UNIT INDICATOR E.1 07 03545
004377 000074 A 3546 DATA 40+BFA V2 07 03546
3547 DATA 60 07 03547
3548 EJEC 07 03548
3549 ***** 07 03549
3550 * 07 03550
3551 * PROCESS READ/WRITE (PRW) * 07 03551
3552 * 07 03552
3553 * FUNCTION: TO PROCESS THE FORTRAN STATEMENTS: * 07 03553
3554 * 07 03554
3555 * READ(U) * 07 03555
3556 * READ(U,F) * 07 03556
3557 * WRITE(U) * 07 03557
3558 * WRITE(U,F) * 07 03558

```



```

3559 *
3560 *
3561 * ENTRY: DIRECT FROM RBE
3562 * RETURN = ADDRESS OF PARAMETER LIST
3563 * RETURN(5) = 0 IF UNFORMATTED
3564 * UNIT = FURTRAN UNIT NUMBER U
3565 * TEMP = DP = CRD READ
3566 * CWB WRITE
3567 *
3568 * EXIT : READ : 1ST RECORD READ
3569 * WRITE: BUFFER CLEARED
3570 * FRMT = ADDRESS OF FORMAT STRING
3571 * 0 IF UNFORMATTED
3572 * XFFL = 1 PARAMETER XFER ENABLED
3573 * ITEMWC = 0 = COUNT OF WORDS REMAINING IN LIST ITEM
3574 * UNFORMATTED: DIRECT TO UID
3575 * FORMATTED : DIRECT TO FRS TO START FORMAT SCAN
3576 * IOCONT = IOC CONTROL WORD
3577 *
*****
004400 016164 A 3580 PRW LDA TEMP,B GET DP
004401 140471 A 3581 SUB CRD
004402 004250 A 3582 LRLA 8 POSITION READ/WRITE FLAG
004403 056104 A 3583 STA IOCONT,B FOR IOC CALL CONTROL WORD
004404 001010 A 3584 JAZ *+3
004405 004407 R
004406 010432 A 3585 LDA WRS SET WRITE BIT
004407 110431 A 3586 ORA BFS SET FILL FLAG
004410 056154 A 3587 STA RWFL,B INITIALIZE READ/WRITE FLAG WORD
004411 036151 A 3588 PRW05 LDX RETURN,B
004412 015003 A 3589 LDA 3,X GET READ/WRITE PARAMETER COUNT
004413 140422 A 3590 SUB TWO
004414 001016 A 3591 JANZ PRW0 WAS PROGRAM COMPILED WITH 'G' COMPILER ?
004415 004422 R
004416 056152 A 3592 STA RETURN+1,B NO. CLEAR 'END' EXIT ADDRESS
004417 056153 A 3593 STA RETURN+2,B CLEAR 'ERR' EXIT ADDRESS
004420 001000 A 3594 JMP PRW1
004421 004426 R
004422 015007 A 3595 PRW0 LDA 7,X PROGRAM WAS COMPILED BY 'G' COMPILER
004423 056152 A 3596 STA RETURN+1,B SAVE 'END' EXIT ADDRESS
004424 015010 A 3597 LDA 8,X GET 'ERR' EXIT ADDRESS
004425 056153 A 3598 STA RETURN+2,B SAVE
004426 004426 R 3599 PRW1 EQU *
3600 MOVXAB 5,FRMT SAVE FORMAT STRING ADDRESS(0 IF NONE)
004426 015005 A
004427 056063 A
3601 PUSHJ PRU PROCESS FORTRAN UNIT NUMBER
004430 105025 A
004431 003754 R
3602 TZAB FRMT,PRW2 IOC MODE IS SYS BINARY FOR UNFORMATTED
004432 016063 A
004433 001010 A
004434 004436 R
004435 010435 A 3603 PRW2 LDA BS12 IOC MODE IS ASCII FOR FORMATTED
004436 036016 A 3604 LDX ANRB,B POINT X AT VSFORTIO DATA BLOCK
004437 116167 A 3605 ORA UNIT,B MERGE IN LOGICAL UNIT NUMBER L
004440 116104 A 3606 ORA IOCONT,B MERGE IN READ/WRITE BIT
004441 055104 A 3607 STA IOCONT,X STORE IN VSFORTIO
3608 MOVXAB RWFL,RWFL MOVE FLAG WORD TO VSFORTIO
004442 016154 A
004443 055154 A
004444 016152 A 3609 LDA RETURN+1,B MOVE RETURN ADDRESSES TO VSFORTIO
004445 055152 A 3610 STA RETURN+1,X
004446 016153 A 3611 LDA RETURN+2,B
004447 055153 A 3612 STA RETURN+2,X
3613 IFF NUC
3614 GOTO NUC1
3615 IFT VII
3616 GOTO VII1
3617 TZAB ALDC,PRW4 ALDC ENTRY FROM BACKGROUND ?
004450 016014 A
004451 001010 A
004452 004462 R
004453 016020 A 3618 LDA APDF,B YES
004454 006505 A 3619 JSR TBK,X TEST BUFFER START ADDRESS
004455 005735 R
004456 126143 A 3620 ADD PBSZ,B
004457 005311 A 3621 DAR
004460 006505 A 3622 JSR TBK,X TEST BUFFER END ADDRESS
004461 005735 R
3623 VII1 CONT
3624 NUC1 CONT
3625 PRW4 ZAB BEPT CLEAR BUFFER CHARACTER POINTER
004462 005001 A
004463 056026 A
3626 TRAB RWFL,LF,PRW6 LOGICAL FILE ?
004464 016154 A
004465 006441 A
004466 004472 R
004467 036010 A 3627 LDX ANFCB,B YES
3628 MOVXAB PBSZ,0 SET FCB(0) = PHYSICAL BUFFER SIZE
004470 016143 A
004471 035000 A
    
```



Address	Label	Operation	Comments	Flags
004472	105025	A	3629 PRW6 PUSHJ RFL REPOSITION FILE	V2 07 03629
004473	005404	R	3630 TRAB RWFL,WR,PRW10 WRITE ?	V2 07 03630
004474	016154	A	3631 PUSHJ CLP YES. CLEAR BUFFER	V2 07 03631
004475	006451	A		
004476	004502	R		
004477	105025	A		
004500	000127	R		
004501	001006	A	3632 PRW10 DATA 01006 SKIP	07 03632
004502	046121	A	3633 INR LRECD,B BUMP LOGICAL RECORD NUMBER ON READ	07 03633
		R	3634 MOVBA B LRSZ,LRWC UPDATE LRWC FOR SHORT RECORD	V2 07 03634
004503	016122	A		
004504	036123	A		
004505	046172	A	3635 INR XFFL,B ENABLE PARAMETER XFER	07 03635
		R	3636 TZAB FRMT,UID PROCESS UNFORMATTED I/O IF FRMT=0	07 03636
004506	016063	A		
004507	001010	A		
004510	006152	R		
004511	001000	A	3637 JMP FRS EXIT TO FORMAT SCAN IF FORMATTED	07 03637
004512	000410	R		
			3638 EJECT	07 03638
			3639 *****	07 03639
			3640 * P R O C E S S D I R E C T A C C E S S ( P R X )	* 07 03640
			3641 * *****	* 07 03641
			3642 * P R O C E S S D I R E C T A C C E S S ( P R X )	* 07 03642
			3643 * *****	* 07 03643
004513	016164	A	3645 PRX LDA TEMP,B	07 03645
004514	006140	A	3646 SUBI CRA	07 03646
004515	000022	A		
004516	004250	A	3647 LRLA S POSITION READ/WRITE FLAG	07 03647
004517	036104	A	3648 STA IOCONT,B	07 03648
004520	001010	A	3649 JAZ *+3	07 03649
004521	004523	R		
004522	010432	A	3650 LDA WRS	07 03650
004523	110431	A	3651 ORA BFS	07 03651
004524	110434	A	3652 ORA BS11 SET DIRECT ACCESS FLAG	07 03652
004525	056154	A	3653 STA RWFL,B	07 03653
004526	016164	A	3654 LDA TEMP,B	07 03654
004527	140424	A	3655 SUB EIGHT	07 03655
004530	056164	A	3656 STA TEMP,B SET TO READ/WRITE	07 03656
004531	001000	A	3657 JMP PRW05	07 03657
004532	004411	R		
			3658 EJECT	07 03658
			3659 *****	07 03659
			3660 * P O S T B U F F E R ( P S B )	* 07 03660
			3661 * *****	* 07 03661
			3662 * F U N C T I O N : T O W R I T E O U T B U F F E R T O R M D	* 07 03662
			3663 * *****	* 07 03663
			3664 * E N T R Y : A D F C B = F C B A D D R E S S	* 07 03664
			3665 * F C B ( 1 3 ) = P H Y S I C A L R E C O R D N U M B E R C O R R E S P O N D I N G T O B U F F E R	* 07 03665
			3666 * *****	* 07 03666
			3667 * E X I T : B U F F E R W R I T T E N O U T T O R M D	* 07 03667
			3668 * R W F L ( B I T 1 ) = F C B ( 1 2 ) ( B I T 1 4 ) = 0 = P O S T B I T S	* 07 03668
			3669 * *****	* 07 03669
			3670 * P S B	* 07 03670
			3671 *****	* 07 03671
004533	016154	A	3673 PSB LDA RWFL,B	07 03673
004534	150443	A	3674 ANA FDR CLEAR POST BIT IN FLAG WORD	V2 07 03674
004535	056154	A	3675 STA RWFL,B	07 03675
004536	036010	A	3676 LDX ADFCB,B	07 03676
004537	015014	A	3677 LDA 12,X	07 03677
004540	150457	A	3678 ANA FDR CLEAR POST BIT IN FCB(12)	V2 07 03678
004541	055014	A	3679 STA 12,X	07 03679
		R	3680 MOVXAX 13,3 LOAD PHYSICAL RECORD NUMBER INTO FCB(3)	07 03680
004542	015015	A		
004543	055003	A		
004544	036016	A	3681 LDX ANR2,B POINT X AT V\$FORTID DATA BLOCK	07 03681
004545	015104	A	3682 LDA IOCONT,X	07 03682
004546	110431	A	3683 ORA BS8 SET WRITE BIT IN V\$IOC CONTROL WORD	07 03683
004547	055104	A	3684 STA IOCONT,X	07 03684
004550	010464	A	3685 LDA CIO PUSH I/O ON	V2 07 03685
004551	006505	A	3686 JSR PSJ,X WRITE OUT BUFFER	V2 07 03686
004552	004563	R		
			3687 TSAB RWFL,WR,PSBX EXIT ON WRITE	FG 07 03687
004553	016154	A		
004554	006411	A		
004555	004562	R		
004556	036016	A	3688 LDX ANR2,B POINT X AT V\$FORTID DATA BLOCK	07 03688
004557	015104	A	3689 LDA IOCONT,X	07 03689
004560	150451	A	3690 ANA BS8 CLEAR WRITE BIT IN V\$IOC CONTROL WORD	07 03690
004561	055104	A	3691 STA IOCONT,X	07 03691
		R	3692 PSBX POPJ EXIT	FG 07 03692
004562	105065	A		
			3693 EJECT	07 03693
			3694 *****	07 03694
			3695 * P U S H / J U M P ( P S J )	* 07 03695
			3696 * *****	* 07 03696
			3697 * F U N C T I O N : T O S T A C K R E T U R N A D D R E S S E S A N D O P S , A N D E X I T T O C A L L E D	* 07 03697
			3698 * R O U T I N E	* 07 03698
			3699 * *****	* 07 03699
			3700 *	* 07 03700



```

3701 * ENTRY: X = RETURN ADDRESS * 07 03701
3702 * A = CALL ADDRESS OR DP * 07 03702
3703 * * 07 03703
3704 * .GE. 0100 ADDRESS(WITHIN REENTRANT RUN-TIME) * 07 03704
3705 * .LT. 0100 DP * 07 03705
3706 * * 07 03706
3707 * EXIT : RETURN STACKED * 07 03707
3708 * A = ADDRESS: DIRECT JUMP TO (A) * 07 03708
3709 * A = DP: STACK CRB DP, THEN CALLED DP, THEN EXIT TO V$FORTIO * 07 03709
3710 * * 07 03710
3711 * ***** * 07 03711
004563 056164 A 3713 PSJ STA TEMP,B SAVE EXIT * 07 03713
004564 005041 A 3714 TXA * 07 03714
004565 036000 A 3715 LDX DPSTKP,B POINT X AT STACK * 07 03715
004566 005344 A 3716 DXR DROP STACK POINTER * 07 03716
004567 076000 A 3717 STX DPSTKP,B FG * 07 03717
004570 055000 A 3718 STA 0,X PUSH RETURN * 07 03718
004571 016164 A 3719 LDA TEMP,B RESTORE A * 07 03719
004572 005014 A 3720 TAX * 07 03720
004573 004346 A 3721 LSRA 6 * 07 03721
004574 001010 A 3722 JAZ *+4 EXTERNAL REQUEST ? * 07 03722
004575 004600 R * * *
004576 006705 A 3723 IJMP 0,X NO. JUMP DIRECTLY TO INTERNAL SUBROUTINE * 07 03723
004577 000000 A * * *
004600 010423 A 3724 LDA CRB * 07 03724
3725 PUSHF PUSH RETURN TO V$RERR * 07 03725

004601 036016 A * * *
004602 035000 A * * *
004603 005344 A * * *
004604 055000 A * * *
004605 005041 A * * *
004606 036016 A * * *
004607 055000 A * * *
004610 016164 A 3726 LDA TEMP,B RESTORE CALLED DP * 07 03726
3727 PUSHF PUSH V$FORTIO DP * 07 03727

004611 036016 A * * *
004612 035000 A * * *
004613 005344 A * * *
004614 055000 A * * *
004615 005041 A * * *
004616 036016 A * * *
004617 055000 A * * *
004620 001000 A 3728 JMP CAN EXIT TO V$FORTIO * 07 03728
004621 000065 R * * *

3729 EJEC * 07 03729
3730 * ***** * 07 03730
3731 * * 07 03731
3732 * P A R A M E T E R T R A N S F E R ( P X F ) * 07 03732
3733 * * 07 03733
3734 * FUNCTION: TO PROCESS ENTRIES TO XFER DATA TO/FROM AN I/O LIST * 07 03734
3735 * * 07 03735
3736 * ENTRY: ITMODE = 0 1-WORD INTEGER/LOGICAL * 07 03736
3737 * = 1 2-WORD INTEGER/LOGICAL * 07 03737
3738 * = 2 REAL * 07 03738
3739 * = 3 DOUBLE PRECISION * 07 03739
3740 * = 4 COMPLEX * 07 03740
3741 * = 5 DOUBLE PRECISION INTEGER * 07 03741
3742 * * 07 03742
3743 * EXIT : IIWSZ = INDIVIDUAL ITEM WORD SIZE * 07 03743
3744 * = 1 FOR 1-WORD INTEGER/LOGICALS * 07 03744
3745 * = 2 FOR 2-WORD INTEGER/LOGICALS * 07 03745
3746 * = 2 FOR REALS * 07 03746
3747 * = 4 FOR DOUBLE PRECISIONS * 07 03747
3748 * = 2 FOR COMPLEXES * 07 03748
3749 * = 2 FOR DOUBLE PRECISION INTEGER * 07 03749
3751 * IIBSZ = 2*IIWSZ = INDIVIDUAL ITEM BYTE SIZE * 07 03751
3752 * ITMINC = INDIVIDUAL ITEM ALLOCATION IN WORDS * 07 03752
3753 * = IIWSZ FOR ALL ITEMS EXCEPT 2-WORD INTEGER/LOGICALS * 07 03753
3754 * = 2 FOR 2-WORD INTEGER/LOGICALS * 07 03754
3755 * ITEMAD = ADDRESS OF LIST ITEM * 07 03755
3756 * ITEMWC = TOTAL WORD COUNT ALLOCATED TO LIST ITEM * 07 03756
3757 * * 07 03757
3758 * ERRORS: ER2 IF ILLEGAL CALL TO $I1,$I2,... * 07 03758
3759 * * 07 03759
3760 * ***** * 07 03760
004622 016172 A 3762 PXF LDA XFFL,B * 07 03762
004623 001010 A 3763 JAZ ER2 ERROR 2/ ILLEGAL CALL TO $IX / * 07 03763
004624 005366 R * * *
004625 036016 A 3764 LDX AMRB,B POINT X AT V$FORTIO * 07 03764
004626 015116 A 3765 LDA ITMODE,X * 07 03765
004627 056116 A 3766 STA ITMODE,B MOVE MODE FROM V$FORTIO TO V$RERR * 07 03766
004630 016063 A 3767 LDA FRMT,B * 07 03767
004631 005004 A 3768 TZX * 07 03768
004632 001010 A 3769 JAZ PXF5 ITEM WORD SIZE = 1 FOR UNFORMATTED * 07 03769
004633 004635 R * * *
004634 036116 A 3770 LDX ITMODE,B * 07 03770
004635 004635 R 3771 PXF5 EQU * V2 * 07 03771
3772 IFF NUC FG * 07 03772
3773 GOTO NV2NUC FG * 07 03773
3774 IFT VII FG * 07 03774
3775 DME MAP,V$STO SET EXEC STATE TO 00 * 07 03775
3776 NV2NUC CNT FG * 07 03776
004635 006015 A 3777 LDAE PXF5ZT,X GET ITEM WORD SIZE FROM TABLE * 07 03777

```



```

004636 004705 R
3778 IFF NUC FG 07 03778
3779 GOTO NV2NUC FG 07 03779
3780 IFT VII FG 07 03780
3781 DME MAP,VSS3 SET EXEC STATE TO NN V2 07 03781
3782 NV2NUC CONT FG 07 03782
004637 056102 A 3783 STA IISZ,B STORE 07 03783
004640 056115 A 3784 STA ITMNC,B ALSO ITEM INCREMENT 07 03784
004641 004241 A 3785 LRLA 1 GET ITEM BYTE SIZE 07 03785
004642 056101 A 3786 STA IISZ,B STORE IN TABLE 07 03786
004643 005344 A 3787 JXR 07 03787
004644 001046 A 3788 JXNZ *+3 2-WORD INTEGER/LOGICAL ? V2 07 03788
004645 004647 R
004646 046115 A 3789 INR ITMNC,B YES. SET INCREMENT TO 2 07 03789
004647 016063 A 3790 LDA FRMT,B V2 07 03790
004650 001010 A 3791 JAZ PXF10 ALL MODES OK FOR UNFORMATTED V2 07 03791
004651 004665 R
004652 016061 A 3792 LDA FDLKEY,B 07 03792
004653 140423 A 3793 SUB FOUR 07 03793
004654 001016 A 3794 JANZ PXF10 I FORMAT DESCRIPTOR ? 07 03794
004655 004665 R
004656 016116 A 3795 LDA ITMODE,B YES 07 03795
004657 140422 A 3796 SUB TWO 07 03796
004660 001004 A 3797 JAN PXF10 INTEGER ITEM 07 03797
004661 004665 R
004662 140464 A 3798 SUB THREE 07 03798
004663 001016 A 3799 JANZ ER2 ERR 2/NON-INTEGGER ITEM/ 07 03799
004664 005366 R
004665 036151 A 3800 PXF10 LDX RETURN,B POINT X AT CALL SEQUENCE 07 03800
3801 MOVXAB 4,ITEMWC SAVE LIST ITEM WORD COUNT 07 03801
004666 015004 A
004667 056114 A 3802 MOVXAB 5,ITEMAD SAVE LIST ITEM ADDRESS 07 03802
004670 015005 A
004671 056113 A 3803 IFF NUC FG 07 03803
3804 GOTO NUC1 FG 07 03804
3805 IFT VII FG 07 03805
3806 GOTO VIII1 FG 07 03806
3807 TZAB ALOC,PF20 EXIT IF NOT VORTEX BKGND CALLING NUC FG 07 03807
004672 016014 A
004673 001010 A
004674 004704 R
004675 016113 A 3808 LDA ITEMAD,B 07 03808
004676 006505 A 3809 JSR TBK,X TEST START OF ITEM ADDRESS 07 03809
004677 005735 R
004700 126114 A 3810 ADD ITEMWC,B 07 03810
004701 005311 A 3811 DAR 07 03811
004702 006505 A 3812 JSR TBK,X TEST END OF ITEM ADDRESS 07 03812
004703 005735 R
3813 VIII1 CONT FG 07 03813
3814 NUC1 CONT FG 07 03814
3815 PFX20 POPJ EXIT FG 07 03815
004704 105065 A
3816 *****
3817 * TABLE OF ITEM SIZES IN WORDS *
3818 *****
004705 000001 A 3819 PFXSZT DATA 1 1-WORD INTEGER/LOGICAL 07 03819
004706 000001 A 3820 DATA 1 2-WORD INTEGER/LOGICAL 07 03820
004707 000002 A 3821 DATA 2 REAL 07 03821
004710 000004 A 3822 DATA 4 DOUBLE PRECISION 07 03822
004711 000002 A 3823 DATA 2 COMPLEX 07 03823
004712 000002 A 3824 DATA 2 DOUBLE PRECISION INTEGER 07 03824
3825 EJEC 07 03825
3826 *****
3827 *
3828 * REENTRANT BLOCK ENTRY (RBE) *
3829 *
3830 * FUNCTION: TO PROVIDE AN ENTRY INTO MODULE VSRERR V2* 07 03830
3831 *
3832 * ENTRY: B = VSFORTIO DATA BLOCK ADDRESS V2* 07 03831
3833 * INFL .NE. 0 ON INITIAL ENTRY V2* 07 03832
3834 * .EQ. 0 ON CONTINUATION ENTRY V2* 07 03833
3835 * TO LABEL VSRERR VIA ALOC IF: V2* 07 03834
3836 *
3837 * VORTEX: BACKGROUND CALLING NUCLEUS VSRERR V2* 07 03835
3838 * VORTEX II: ANYBODY CALLING NUCLEUS VSRERR V2* 07 03836
3839 *
3840 * TO LABEL VSRERR1 VIA DIRECT JUMP OTHERWISE V2* 07 03837
3841 *
3842 * EXIT : TO POP IF TOP OP IS .GE. 0100(ADDRESS OPERAND) V2* 07 03838
3843 * TO OP PROCESSOR OTHERWISE V2* 07 03839
3844 * ALOC = 1 IF ENTRY THRU VSRERR V2* 07 03840
3845 * 0 IF ENTRY THRU VSRERR1 V2* 07 03841
3846 * INFL = 0 V2* 07 03842
3847 *
3848 * ERRORS: ER4 IF ILLEGAL OP CODE *
3849 *
3850 *****
3851 *****
3852 *****
3853 * REENTRANT MODULE CALLED BY ALOC *
3854 *****
004713 R 3855 VSRERR EQU * ALOC ENTRY V2 07 03855

```



	3857	IFF	NUC			FG	07	03857	
	3858	GOTO	NUC1			FG	07	03858	
004713	000005	A	3859	DATA	5	V2	07	03859	
	3860	IFF	VII			FG	07	03860	
	3861	GOTO	VIII			FG	07	03861	
	3862	EXC2	0500+MAP			V2	07	03862	
	3863	OME	MAP,V\$ST3	SET EXEC STATE TO NN		V2	07	03863	
	3864	LDA	INFL,B			V2	07	03864	
	3865	JANZ	RBE1			V2	07	03865	
	3866	*****	*****			V2	07	03866	
	3867	* VORTEX II CONTINUATION *				V2	07	03867	
	3868	*****	*****			V2	07	03868	
	3869	LDA	V\$CPL			V2	07	03869	
	3870	JANZ	RBE4	TEST IF BACKGROUND		V2	07	03870	
	3871	*****	*****			V2	07	03871	
	3872	* RESTORE STACK ADDRESSES FROM V\$RERR TO V\$FORTID *				V2	07	03872	
	3873	*****	*****			V2	07	03873	
	3874	LDA	ANRB,B			V2	07	03874	
	3875	OME	MAP,V\$ST1	SET EXEC STATE TO ON		V2	07	03875	
	3876	ADDI	OPSTK+STKSZ-1			FG	07	03876	
	3877	LDXI	BASE	POINT X AT V\$RERR STACK BASE		V2	07	03877	
	3878	SUB	ROPSTP,X			FG	07	03878	
	3879	TAB		POINT B AT V\$FORTID STACK		V2	07	03879	
	3880	LDA	ROPSTP,X	GET COUNT		FG	07	03880	
	3881	JAN	R\$EX	EXIT IF NO MOVE		V2	07	03881	
	3882	CPA				FG	07	03882	
	3883	INCR	014	SET X = -(COUNT-1)		FG	07	03883	
	3884	RBE1	LDAE	BASE+STKSZ-1,X		FG	07	03884	
	3885	STA	0,B			V2	07	03885	
	3886	JXZ	R\$EX	EXIT WHEN DONE		V2	07	03886	
	3887	IBR		BUMP POINTERS		FG	07	03887	
	3888	IXR				FG	07	03888	
	3889	JMP	RBE1			V2	07	03889	
	3890	RBE\$	LDX	V\$CRS		V2	07	03890	
	3891	LDB	BR,X	RESTORE B		V2	07	03891	
	3892	OME	MAP,V\$ST3	SET EXEC STATE TO NN		V2	07	03892	
	3893	VIII	CONT			FG	07	03893	
	3894	*****	*****			07	03894		
	3895	* INITIALIZE *				V2	07	03895	
	3896	*****	*****			V2	07	03896	
	004714	R	3897	RBE1	EQU *	V2	07	03897	
			3898	IFT	VII	FG	07	03898	
			3899	ZAB	INFL	V2*	07	03899	
			3900	IFT	VII	FG	07	03900	
			3901	GOTO	VIII	FG	07	03901	
004714	006030	A	3902	LDXI	BASE	V2	07	03902	
004715	006340	R							
004716	065016	A	3903	STB	ANRB,X	07	03903		
			3904	ZAX	ERN	07	03904		
004717	005001	A							
004720	055060	A							
			3905	*****	*****	07	03905		
			3906	* TEST V\$FORTID STACK EMPTY *		07	03906		
			3907	*****	*****	07	03907		
004721	016000	A	3908	LDA	OPSTK,B	07	03908		
004722	146017	A	3909	SUB	ADPSTK,B	07	03909		
004723	001016	A	3910	JANZ	RBE5	07	03910		
004724	004733	R							
			3911	*****	*****	07	03911		
			3912	* V\$FORTID STACK EMPTY - RESUME EXECUTION FROM V\$RERR STACK *		07	03912		
			3913	*****	*****	07	03913		
004725	015000	A	3914	LDA	OPSTK,X	07	03914		
004726	145017	A	3915	SUB	ADPSTK,X	07	03915		
004727	001010	A	3916	JAZ	RBE90	07	03916		
004730	005102	R							
004731	005042	A	3917	TXB		07	03917		
			3918	POPJ		FG	07	03918	
004732	105065	A							
			3919	*****	*****	07	03919		
			3920	* V\$FORTID STACK HAS OP - TEST VALIDITY *		07	03920		
			3921	*****	*****	07	03921		
004733	036000	A	3922	RBE5	LDX	OPSTK,B	07	03922	
004734	015000	A	3923	LDA	0,X	GET OP	07	03923	
004735	006140	A	3924	SUBI	13	PD	07	03924	
004736	000015	A							
004737	001004	A	3925	JAN	RBE90	ERROR/ ILLEGAL OP /	07	03925	
004740	005102	R							
004741	006140	A	3926	SUBI	11	V2	07	03926	
004742	000013	A							
004743	001002	A	3927	JAP	RBE90	ERROR/ ILLEGAL OP /	07	03927	
004744	005102	R							
004745	120425	A	3928	ADD	D16	RESTORE OP	07	03928	
004746	034155	A	3929	LDX	RBE\$	POINT X AT V\$RERR DATA BLOCK	07	03929	
004747	055164	A	3930	STA	TEMP,X	SAVE OP	07	03930	
004750	140466	A	3931	SUB	0XF	V2	07	03931	
004751	001010	A	3932	JAZ	RBE10	PARAMETER XFER ?	07	03932	
004752	004755	R							
004753	015017	A	3933	LDA	ADPSTK,X	NO. INITIALIZE V\$RERR STACK	07	03933	
004754	001006	A	3934	DATA	01006	SKIP	07	03934	
004755	015000	A	3935	RBE10	LDA	OPSTK,X	07	03935	
004756	005311	A	3936	DAR		PUSH V\$RERR STACK	FG	07	03936
004757	055000	A	3937	STA	OPSTK,X	07	03937		
004760	005014	A	3938	TAX		07	03938		



004761	024142	A	3939	LDB	RBE3	POINT B AT VSRERR DATA BLOCK	07	03939	
004762	016164	A	3940	LDA	TEMP,B	RELOAD OP	07	03940	
004763	055000	A	3941	STA	0,X	PUSH OP ONTO VSRERR STACK	07	03941	
004764	026016	A	3942	LDB	ANR3,B	POINT B AT VSRERR DATA BLOCK	07	03942	
004765	034136	A	3943	LDX	RBE3	POINT X AT VSRERR DATA BLOCK	07	03943	
			3945	*****				07	03945
			3946	* MOVE ADDRESSES FROM NON-REENTRANT MODULE TO REENTRANT *				07	03946
			3947	*****				07	03947
004766	016151	A	3949	LDA	RETURN,B		07	03949	
004767	055151	A	3950	STA	RETURN,X	MOVE CALL SEQ ADDRESS	07	03950	
004770	006505	A	3951	JSR	TBK,X	TEST RETURN ADDRESS IN BACKGROUND	07	03951	
004771	005735	R							
004772	120471	A	3952	ADD	TEN		07	03952	
004773	006505	A	3953	JSR	TBK,X	TEST PARAMETER LIST IN BACKGROUND	07	03953	
004774	005735	R							
004775	005021	A	3954	TBA			07	03954	
004776	006505	A	3955	JSR	TBK,X	TEST 1ST WORD OF DATA BLOCK IN BACKGRND	07	03955	
004777	005735	R							
005000	006120	A	3956	ADDI	YYY-1		V2	07 03956	
005001	000176	A							
005002	006505	A	3957	JSR	TBK,X	TEST LAST WORD OF DATA BLOCK IN BACKGRND	07	03957	
005003	005735	R							
005004	034117	A	3958	LDX	RBE3		07	03958	
005005	016015	A	3959	LDA	ANPOJ,B		07	03959	
005006	055015	A	3960	STA	ANPOJ,X	MOVE NON-REENTRANT POP/JUMP ADDRESS	07	03960	
005007	006505	A	3961	JSR	TBK,X	TEST NON-REENTRANT POP/JUMP IN BACKGROUND	07	03961	
005010	005735	R							
005011	034112	A	3962	LDX	RBE3	POINT X AT REENTRANT BLOCK	07	03962	
005012	016000	A	3963	LDA	OPSTKP,B		07	03963	
005013	145016	A	3964	SUB	ANR3,X		07	03964	
005014	006140	A	3965	SUBI	WOPSTK-BASE	COMPARE WITH BOTTOM OF STACK	V2	07 03965	
005015	000127	A							
005016	001004	A	3966	JAN	RBE98	ERROR/ PROTECTION /	07	03966	
005017	005102	R							
005020	006140	A	3967	SUBI	STKSZ		V2	07 03967	
005021	000012	A							
005022	001002	A	3968	JAP	RBE90	ERROR/ PROTECTION /	07	03968	
005023	005102	R							
005024	046000	A	3969	INR	OPSTKP,B	POP VSRERR STACK	FG	07 03969	
005025	024076	A	3970	LDB	RBE3	POINT B AT VSRERR DATA BLOCK	07	03970	
005026	016164	A	3971	LDA	TEMP,B	RELOAD OP	07	03971	
005027	140466	A	3972	SUB	CMF		V2	07 03972	
005030	001016	A	3973	JANZ	RBE4	IS OP PARAMETER XFER ?	V2	07 03973	
005031	005035	R							
005032	016172	A	3974	LDA	OFFL,B	YES. GET XFER ENABLE FLAG	07	03974	
005033	001010	A	3975	JAZ	RBE90	EXIT IF ILLEGAL OP	07	03975	
005034	005102	R							
			3976	VII1	CONT		FG	07 03976	
			3977	RBE4	EQU	*	V2	07 03977	
			3978	IFB	VORTEX-2		V2	07 03978	
			3979	OME	MAP,VST3	SET EXEC STATE TO MN	V2	07 03979	
005035	005101	A	3980	INCR	1	SET ALOC ENTRY FLAG	V2	07 03980	
005036	001006	A	3981	DATA	01006		V2	07 03981	
			3982	NUC1	CONT		FG	07 03982	
			3983	*****				07	03983
			3984	* REENTRANT MODULE CALLED BY DIRECT JUMP *				07	03984
			3985	*****				07	03985
			3986	VSRER1	EQU	*	07	03986	
005037	005001	R	3987	TZA		RESET ALOC ENTRY FLAG	V2	07 03987	
005040	056014	A	3988	STA	ALOC,B		V2	07 03988	
			3989	*****				07	03989
			3990	* TEST OP *				07	03990
			3991	*****				07	03991
005041	036000	A	3992	LDX	OPSTKP,B		V2	07 03992	
005042	015000	A	3993	LDA	0,X	GET OP IN A	07	03993	
005043	056164	A	3994	STA	TEMP,B	SAVE	07	03994	
005044	004346	A	3995	LSRA	6		07	03995	
005045	001010	A	3996	JAZ	RBE15	IS OP RETURN ADDRESS ?	FG	07 03996	
005046	005050	R							
			3997	POPJ		YES. RETURN	FG	07 03997	
005047	105065	A							
005050	015000	A	3998	RBE15	LDA	0,X	FG	07 03998	
005051	005144	A	3999	IXR		POP STACK	FG	07 03999	
005052	076000	A	4000	STX	OPSTKP,B		07	04000	
005053	140465	A	4001	SUB	CTR		V2	07 04001	
005054	001004	A	4002	JAN	ER4	ERROR 4/ILLEGAL OP/	07	04002	
005055	005364	R							
005056	001010	A	4003	JAZ	RBE25	NO UNIT ASSOCIATED WITH TERMINATE CALL	07	04003	
005057	005073	R							
005060	005311	A	4004	BAR			V2	07 04004	
005061	001010	A	4005	JAZ	RBE30	NO UNIT ASSOCIATED WITH PARAM XFER CALL	07	04005	
005062	005075	R							
005063	006140	A	4006	SUBI	RBEJTE-RBEJT-1		V2	07 04006	
005064	000016	A							
005065	001002	A	4007	JAP	ER4	ERROR 4/ILLEGAL OP/	07	04007	
005066	005364	R							
005067	036151	A	4008	LDX	RETURN,B		07	04008	
005070	035004	A	4009	LDX	0,X	POINT X AT FORTRAN UNIT NUMBER	07	04009	
005071	015000	A	4010	LDA	0,X	GET FORTRAN UNIT NUMBER	07	04010	
005072	056167	A	4011	STA	UNIT,B	STORE	07	04011	
005073	005001	A	4012	RBE25	TZA		07	04012	
005074	056172	A	4013	STA	XFFL,B	DISABLE PARAMETER XFER	07	04013	
005075	036164	A	4014	RBE30	LDX	LOAD OP AS JUMP TABLE INDEX	V2	07 04014	



```

4015      IFF      NUC      FG 07 04015
4016      GOTO     NV2NUC   FG 07 04016
4017      IFT      VII      FG 07 04017
4018      DME      MAP,V$ST0 SET EXEC STATE TO 00 V2 07 04018
005076 006035 A 4019 NV2NUC CONT          FG 07 04019
005077 005100 R 4020 LDXE      RBEJT-CTRV,X   GET PROCESSOR ADDRESS V2 07 04020

4021      IFF      NUC      FG 07 04021
4022      GOTO     NV2NUC   FG 07 04022
4023      IFT      VII      FG 07 04023
4024      DME      MAP,V$ST3 SET EXEC STATE TO NN V2 07 04024
005100 006705 A 4025 NV2NUC COMT          FG 07 04025
005101 000000 A 4026 IJMP     0,X           EXIT TO PROCESSOR      07 04026

4027 *****
4028 * PROTECTION ERROR *
4029 *****
4030      IFF      NUC      FG 07 04030
4031      GOTO     NUC1     FG 07 04031
4032      IFT      VII      FG 07 04032
4033      GOTO     VII1     FG 07 04033
005102 005001 A 4034 RBE90  TZA           07 04034
005103 001000 A 4035 JMP      TBK           FORCE TBK ERRDR       07 04035
005104 005735 R

4036 VIII1  CONT          FG 07 04036
4037 NUC1   CONT          FG 07 04037
4038 *****
4039 * EXIT JUMP TABLE *
4040 *****
005105 006062 R 4041 RBEJT  PZE      TRM      TERMINATE
005106 004622 RR 4042      PZE      PXF      PARAMETER XFER V2 07 04042
005107 003123 R 4043      PZE      PAX      BACKSPACE      07 04043
005110 003123 RR 4044      PZE      PAX      WRITE EOF       07 04044
005111 003123 R 4045      PZE      PAX      REWIND         07 04045
005112 004400 R 4046      PZE      PRW      READ           07 04046
005113 004400 R 4047      PZE      PRH      WRITE          07 04047
005114 000163 R 4048      PZE      CLS      CLOSE RMD FILE 07 04048
005115 000163 R 4049      PZE      CLS      CLOSE RMD FILE 07 04049
005116 002730 R 4050      PZE      OPN      OPEN RMD FILE  07 04050
005117 002730 R 4051      PZE      OPN      OPEN RMD FILE  07 04051
005120 003655 R 4052      PZE      PRD      DECODE         PD 07 04052
005121 003655 R 4053      PZE      PRD      ENCODE         PD 07 04053
005122 004513 R 4054      PZE      PRX      READ - DIRECT ACCESS 07 04054
005123 004513 R 4055      PZE      PRX      WRITE - DIRECT ACCESS 07 04055
005124 005124 R 4056 RBEJTE EQU      * V2 07 04056
4057      IFT      VII      FG 07 04057
4058      GOTO     VII1     FG 07 04058
4059      IFF      NUC      FG 07 04059
4060      GOTO     NUC1     FG 07 04060
005124 006340 R 4061 RBEB   DATA     BASE V2 07 04061
4062 NUC1   CONT          FG 07 04062
4063 VIII1  CONT          FG 07 04063
4064      EJECT
4065 *****
4066 *
4067 * REPEAT CHARACTER I/O (RCH) *
4068 *
4069 * FUNCTION: TO REPEAT A CHARACTER I/O OPERATION N TIMES *
4070 *
4071 * ENTRY: COUNT = N *
4072 *          BCHAR = CHARACTER TO BE OUTPUT *
4073 *
4074 * EXIT : NO SPECIAL CONDITIONS *
4075 *
4076 *****
005125 016052 A 4078 RCH   LDA      COUNT,B  07 04078
005126 005311 A 4079      DAR          DECREMENT COUNT 07 04079
005127 001002 A 4080      JAP      RCH2          FG 07 04080
005130 005132 R

4081      PUPJ          EXIT IF COUNT .LE. 0 FG 07 04081

005131 105065 A 4082 RCH2  STA      COUNT,B  FG 07 04082
005132 056052 A 4083      LDA      ASCB,B    07 04083
005133 016021 A 4084      LDA      ASCB,B    07 04084
005134 146002 A 4085      SUB      ASCB,B    07 04085
005135 007400 A 4086      ROF          V2 07 04086
005136 003010 A 4086      XAZ          SET OVFL IF BUFFER SCB V2 07 04086
005137 001626 R

4087      TSAB      RWFL,WR,RCH10 V2 07 04087

005140 016154 A
005141 006411 A
005142 005155 R

4088 *****
4089 * INPUT *
4090 *****
005143 001001 A 4091      JDF      RCH5          V2 07 04091
005144 005151 R

4092 *****
4093 * INPUTTING FROM NON-BUFFER *
4094 *****
4095      PUSHJ     ICC      INPUT CHARACTER V2 07 04095

005145 105025 A
005146 001623 R
005147 001000 A 4096      JMP      RCH          LOOP TILL DONE      07 04096

```



```

005150 005125 R
4097 *****
4098 * INPUTTING FROM BUFFER *
4099 *****
4100 RCH5 PUSHJ CBC INPUT CHARACTER FROM BUFFER V2 07 04100

005151 105025 A
005152 000101 R
005153 001000 A 4101 JMP RCH LOOP TILL DONE 07 04101
005154 005125 R
4102 ***** 07 04102
4103 * OUTPUT * 07 04103
4104 ***** 07 04104
005155 001001 A 4105 RCH10 JDF RCH15 V2 07 04105
005156 005153 R
4106 ***** 07 04106
4107 * OUTPUT TO NON-BUFFER * 07 04107
4108 ***** 07 04108
4109 PUSHJ PCH PUT CHARACTER V2 07 04109

005157 105025 A
005160 003320 R
005161 001000 A 4110 JMP RCH LOOP TILL DONE 07 04110
005162 005125 R
4111 ***** 07 04111
4112 * OUTPUT TO BUFFER * 07 04112
4113 ***** 07 04113
4114 RCH15 PUSHJ DCB OUTPUT CHARACTER TO BUFFER V2 07 04114

005163 105025 A
005164 002452 R
005165 001000 A 4115 JMP RCH LOOP TILL DONE 07 04115
005166 005125 R
4116 EJEC 07 04116
4117 ***** 07 04117
4118 * 07 04118
4119 * RECYCLE LOGICAL BUFFER (RCL) * 07 04119
4120 * 07 04120
4121 * FUNCTION: TO MOVE FORWARD TO NEXT LOGICAL RECORD * 07 04121
4122 * 07 04122
4123 * ENTRY: LRWC = COUNT OF WORDS REMAINING IN LOGICAL RECORD * 07 04123
4124 * 07 04124
4125 * EXIT : LRWC = LRSZ * 07 04125
4126 * 07 04126
4127 ***** 07 04127
4129 RCL TRAB RWFL,LF,RCL5 LOGICAL FILE ? V2 07 04129

005167 016154 A
005170 006441 A
005171 005174 R
005172 006400 A 4130 BT ASET+RM,RCL10 YES. RMD ? D.1 07 04130
005173 005201 R
4131 RCL5 ZAB LRWC NO. FORCE RECYCLE V2 07 04131

005174 005001 A
005175 056123 A
005176 056144 A 4132 STA PWOC,B CLEAR WORD COUNTS 07 04132
005177 001000 A 4133 JMP RCL15 D.1 07 04133
005200 005210 R
005201 006444 A 4134 RCL10 BT ARST+TR,RCL15 TERMINATE LOGICAL RMD ? D.1 07 04134
005202 005210 R
4135 TNZAB LRWC,RCL15 YES. END OF LOGICAL RECORD ? D.1 07 04135

005203 016123 A
005204 001016 A
005205 005210 R
005206 046121 A 4136 INR LRECND,B YES. BUMP LOGICAL RECORD NUMBER D.1 07 04136
4137 POPJ EXIT FG 07 04137

005207 105065 A
4138 RCL15 PUSHJ GBA STEP THRU LOGICAL BUFFER D.1 07 04138

005210 105025 A
005211 001103 R
005212 016123 A 4139 LDA LRWC,B 07 04139
005213 005111 A 4140 IAR 07 04140
005214 146122 A 4141 SUB LRSZ,B 07 04141
005215 001004 A 4142 JAN PCL LOOP TILL LOGICAL BOUNDARY PASSED D.1 07 04142
005216 005167 R
005217 046123 A 4143 INR LRWC,B RESTORE WORD COUNTS 07 04143
005220 046144 A 4144 INR PWOC,B 07 04144
4145 DAB BFWPT AND BUFFER POINTER 07 04145

005221 016025 A
005222 005311 A
005223 056025 A
4146 POPJ EXIT FG 07 04146

005224 105065 A
4147 EJEC 07 04147
4148 ***** 07 04148
4149 * 07 04149
4150 * RECYCLE PHYSICAL BUFFER (RCP) * 07 04150
4151 * 07 04151
4152 * FUNCTION: TO RECYCLE A PHYSICAL BUFFER * 07 04152
4153 * 07 04153
4154 * ENTRY: PBSZ = PHYSICAL BUFFER SIZE IN WORDS * 07 04154
4155 * APBF = PHYSICAL BUFFER START ADDRESS * 07 04155
4156 * IN = 1 IF INITIALIZING V2* 07 04156
4157 * PD = 1 IF BUFFER MUST BE POSTED V2* 07 04157
4158 * 07 04158
4159 * EXIT : IN = 1 V2* 07 04159
4160 * V2* 07 04160

```



```

4161 *          BUFFER POSTED IF PD SET          V2* 07 04161
4162 *          I/O SUPPRESSED                   V2* 07 04162
4163 *                                           V2* 07 04163
4164 *          IN = 0                             V2* 07 04164
4165 *                                           V2* 07 04165
4166 *          PBWC = PBSZ                        V2* 07 04166
4167 *          BUFFER CLEARED BEFORE NON-RMD READ V2* 07 04167
4168 *                                           * 07 04168
4169 *                                           * 07 04169
005225 R 4171 RCP EQU *****
4172 TRAB RWFL,IN,RCP5 INITIALIZING ? V2 07 04171
V2 07 04172
005225 016154 A
005226 006446 A
005227 005241 R
005230 006442 A 4173 BT ARST+PD,RCP3 YES. ANY UNPOSTED DATA ? 07 04173
005231 005235 R 4174 PUSHJ PSB YES. POST BUFFER V2 07 04174
005232 105025 A
005233 004533 R
005234 016154 A 4175 LDA RWFL,B RESTORE FLAG WORD 07 04175
005235 006451 A 4176 RCP3 BT ARST+WR,RCP15 READ ? V2 07 04176
005236 005263 R
005237 001000 A 4177 JMP RCP25 NO. WRITE 07 04177
005240 005306 R 4178 RCP5 MOVBAB PBSZ,PBWC RELOAD PHYSICAL WORD COUNT 07 04178
005241 016143 A
005242 056144 A
005243 016027 A 4179 LDA ALBF,B D.1 07 04179
005244 146025 A 4180 SUB BFWPT,B D.1 07 04180
005245 005311 A 4181 DAR D.1 07 04181
005246 126020 A 4182 ADD APBF,B D.1 07 04182
005247 056027 A 4183 STA ALBF,B UPDATE ADDRESS OF LOGICAL BUFFER D.1 07 04183
4184 DAB B APBF,BFWPT INITIALIZE BUFFER POINTER D.1 07 04184
005250 016020 A
005251 005311 A
005252 056025 A 4185 TSAB RWFL,WR,RCP20 READ ? V2 07 04185
005253 016154 A
005254 006411 A
005255 005301 R
005256 006442 A 4186 BT ARST+PD,RCP15 YES. ANY UNPOSTED DATA ? C.1 07 04186
005257 005263 R 4187 PUSHJ PSB YES. POST BUFFER V2 07 04187
005260 105025 A
005261 004533 R
005262 016154 A 4188 LDA RWFL,B RESTORE FLAG WORD V2 07 04188
4189 ***** V2 07 04189
4190 * CLEAR BUFFER ON NON-RMD READ * V2 07 04190
4191 ***** V2 07 04191
005263 006400 A 4192 RCP15 BT ASET+RM,RCP20 RMD ? V2 07 04192
005264 005301 R 4193 TZAB UNIT,RCP20 NO. DONT CLEAR IF L=0 D.1 07 04193
005265 016167 A
005266 001010 A
005267 005301 R
005270 036010 A 4194 LDX ADFCB,B D.1 07 04194
4195 MOVBAB LRWC,SAVE+2 SAVE LRWC 07 04195
005271 016123 A
005272 056034 A 4196 MOVXAB 0,LRWC SET LOGICAL WORD COUNT = FCB(0) 07 04196
005273 015000 A
005274 056123 A 4197 PUSHJ CLB CLEAR BUFFER V2 07 04197
005275 105025 A
005276 000127 R 4198 MOVBAB SAVE+2,LRWC RESTORE LRWC 07 04198
005277 016034 A
005300 056123 A 4199 ***** V2 07 04199
4200 * READ/WRITE PHYSICAL RECORD * V2 07 04200
4201 ***** V2 07 04201
4202 RCP20 PUSHJ RPB REFRESH PHYSICAL BUFFER V2 07 04202
005301 105025 A
005302 005564 R 4203 TRAB RWFL,WR,RCP30 READ ? V2 07 04203
005303 016154 A
005304 006451 A
005305 005357 R
005306 006441 A 4204 RCP25 BT ARST+LF,RCP40 NO. WRITE LOGICAL FILE ? D.1 07 04204
005307 005350 R
005310 036010 A 4205 LDX ADFCB,B YES. POINT X AT FCB V2 07 04205
005311 006443 A 4206 BT ARST+RM,RCP40 RMD ? D.1 07 04206
005312 005350 R
005313 110423 A 4207 ORA PDS YES. SET POST FLAG D.1 07 04207
005314 056154 A 4208 STA RWFL,B 07 04208
005315 015014 A 4209 LDA 12,X 07 04209
005316 110437 A 4210 ORA FPOS ALSO IN FCB(12) V2 07 04210
005317 055014 A 4211 STA 12,X 07 04211
4212 TRAB RWFL,RB,RCP35 IS READ BEFORE WRITE ENABLED ? 07 04212
005320 016154 A
005321 006443 A
005322 005345 R
005323 036016 A 4213 LDX ANRD,B YES. POINT X AT V$FORTIO DATA BLOCK 07 04213

```



```

005324 015104 A 4214 LDA IOCONT,X 07 04214
005325 150451 A 4215 ANA BR8 CLEAR WRITE BIT IN V$IOC CONTROL WORD 07 04215
005326 055104 A 4216 STA IOCONT,X 07 04216
4217 PUSHJ RPB READ NEXT PHYSICAL RECORD V2 07 04217
005327 105025 A
005330 005564 R
4218 SUT8BB PRECND,PBRC,PRECND RESTORE PHYSICAL RECORD NUMBER 07 04218
005331 016145 A
005332 146142 A
005333 056143 A
005334 036016 A 4219 LDX ANRB,B POINT X AT V$FORTID DATA BLOCK 07 04219
005335 015106 A 4220 LDA IOSTAT,X GET STATUS OF READ 07 04220
005336 005311 A 4221 DAR 07 04221
005337 001004 A 4222 JAN *+3 TEST FOR EOF 07 04222
005340 005342 R
005341 055106 A 4223 STA IOSTAT,X CLEAR EOF FLAG ON READ BEFORE WRITE 07 04223
005342 015104 A 4224 LDA IOCONT,X 07 04224
005343 110431 A 4225 ORA BR8 RESTORE WRITE BIT IN V$IOC CONTROL WORD 07 04225
005344 055104 A 4226 STA IOCONT,X 07 04226
005345 036010 A 4227 RCP35 LDX ADFCB,B 07 04227
4228 MOVBAK PRECND,13 UPDATE FCB(13) 07 04228
005346 016145 A
005347 055015 A
4229 RCP40 TSAB RWFL,IN,RCP50 EXIT ON INITIALIZE D.1 07 04229
005350 016154 A
005351 006406 A
005352 005357 R
005353 006403 A 4230 BT ASET+SC,RCP50 D.1 07 04230
005354 005357 R
4231 PUSHJ CLB CLEAR BUFFER AFTER WRITE D.1 07 04231
005355 105025 A
005356 000127 R
005357 016154 A 4232 RCP50 LDA RWFL,B D.1 07 04232
005360 150446 A 4233 ANA SCR CLEAR CLEAR SUPPRESS FLAG D.1 07 04233
005361 150447 A 4234 ANA INR CLEAR INITIALIZE FLAG V2 07 04234
005362 056154 A 4235 STA RWFL,B 07 04235
4236 PUPJ EXIT FG 07 04236
005363 105065 A
4237 EJEC 07 04237
4238 ***** 07 04238
4239 * 07 04239
4240 * REENTRANT ERROR PROCESSOR (RER) * 07 04240
4241 * 07 04241
4242 * FUNCTION: TO PROCESS ERRORS IN VSRERR V2* 07 04242
4243 * 07 04243
4244 * ENTRY: ER1 FORMAT * 07 04244
4245 * ER2 MODE * 07 04245
4246 * ER3 DATA * 07 04246
4247 * ER4 I/O ERROR * 07 04247
4248 * 07 04248
4249 * EXIT : DIRECT TO CAN * 07 04249
4250 * ERN = ERROR NUMBER-1 * 07 04250
4251 * ERROR BP PUSHED V2* 07 04251
4252 * 07 04252
4253 ***** 07 04253
005364 046060 A 4255 ER4 INR ERN,B I/O 07 04255
005365 046060 A 4256 ER3 INR ERN,B DATA 07 04256
005366 046060 A 4257 ER2 INR ERN,B MODE 07 04257
005367 036016 A 4258 ER1 LDX ANRB,B POINT X AT V$FORTID DATA BLOCK 07 04258
005370 016060 A 4259 LDA ERN,B 07 04259
005371 055060 A 4260 STA ERN,X MOVE ERROR NUMBER 07 04260
005372 010421 A 4261 LDA CER GET ERROR BP 07 04261
4262 PUSHF 07 04262
005373 036016 A
005374 035000 A
005375 005344 A
005376 055000 A
005377 005041 A
005400 036016 A
005401 055000 A
005402 001000 A 4263 JMP CAN EXIT TO V$FORTID 07 04263
005403 000065 R
4264 EJEC 07 04264
4265 ***** 07 04265
4266 * 07 04266
4267 * REPOSITION FILE (RFL) * 07 04267
4268 * 07 04268
4269 * FUNCTION: TO REPOSITION A FILE AT START OF A READ OR WRITE, OR IF * 07 04269
4270 * A T FORMAT SPECIFIER REQUIRES A PHYSICAL BACKSPACE * 07 04270
4271 * 07 04271
4272 * ENTRY: ADFCB = ADDRESS OF DCB/FCB * 07 04272
4273 * APBF = ADDRESS OF PHYSICAL BUFFER * 07 04273
4274 * ALBF = ADDRESS OF LOGICAL BUFFER * 07 04274
4275 * PBSZ = PHYSICAL BUFFER SIZE IN WORDS * 07 04275
4276 * LRSZ = LOGICAL RECORD SIZE IN WORDS * 07 04276
4277 * PRECND = PHYSICAL RECORD NUMBER * 07 04277
4278 * 07 04278
4279 * EXIT : READ : 1ST RECORD IN BUFFER * 07 04279
4280 * WRITE: BUFFER CLEARED * 07 04280
4281 * 07 04281
4282 ***** 07 04282
4284 RFL MOVBAK LRSZ,LRWC INITIALIZE LOGICAL WORD COUNT 07 04284
005404 016122 A

```



005405	056123	A	4285	DABB	ALBF,BFNP	INITIALIZE BUFFER WORD POINTER	V2	07	04285	
005406	016027	A								
005407	005311	A								
005410	056025	A	4286	MOVBB	PBSZ,PBWC	INITIALIZE PHYSICAL WORD COUNT		07	04286	
005411	016143	A								
005412	056144	A	4287	TRAB	RWFL,LF,RFL5	LOGICAL FILE ?	V2	07	04287	
005413	016154	A								
005414	006441	A								
005415	005420	R								
005416	006400	A	4288	BT	ASET+RM,RFL10	YES. TEST IF RMD	V2	07	04288	
005417	005424	R	4289	*****			V2	07	04289	
			4290	* NOT LOGICAL RMD FILE *			V2	07	04290	
			4291	*****			V2	07	04291	
005420	006411	A	4292	RFL5	BT	ASET+WR,RFL40	READ ?	FG	07	04292
005421	005504	R								
005422	001000	A	4293	JMP	RCP	YES. RECYCLE PHYSICAL BUFFER		07	04293	
005423	005225	R	4294	*****			V2	07	04294	
			4295	* LOGICAL RMD FILE *			V2	07	04295	
			4296	*****			V2	07	04296	
005424	016020	A	4297	RFL10	LDA	APBF,B		07	04297	
005425	126143	A	4298		ADD	PBSZ,B		07	04298	
005426	146027	A	4299		SUB	ALBF,B		07	04299	
005427	056144	A	4300		STA	PBWC,B	INITIALIZE PHYSICAL WORD COUNT	07	04300	
			4301	*****				07	04301	
			4302	* TEST IF LRECNO IN BUFFER *				07	04302	
			4303	*****				07	04303	
005430	036010	A	4304	LDX	ADFCB,B			07	04304	
005431	015015	A	4305	LDA	13,X			07	04305	
005432	001010	A	4306	JAZ	RFL50	TEST IF BUFFER EMPTY		07	04306	
005433	005505	R								
005434	146145	A	4307	SUB	PRECNO,B	COMPARE BUFFER ADDRESS WITH PRECNO		07	04307	
005435	001010	A	4308	JAZ	RFL20	LRECNO RESIDENT IF EQUAL		07	04308	
005436	005467	R								
005437	001002	A	4309	JAP	RFL50			07	04309	
005440	005505	R								
005441	056164	A	4310	STA	TEMP,B	SAVE -(RECORD INCREMENT)		07	04310	
005442	126142	A	4311	ADD	PBRC,B			07	04311	
005443	005311	A	4312	DAR				07	04312	
005444	001004	A	4313	JAN	RFL50			07	04313	
005445	005505	R	4314	*****				07	04314	
			4315	* LRECNO IS RESIDENT *				07	04315	
			4316	*****				07	04316	
			4317	MOVXAB	13,PRECNO	UPDATE PHYSICAL RECORD NUMBER		07	04317	
005446	015015	A								
005447	056145	A								
005450	005024	A	4318	TBX		SAVE BASE REGISTER		07	04318	
005451	005001	A	4319	TZA				07	04319	
005452	146164	A	4320	SUB	TEMP,B	GET RECORD INCREMENT		07	04320	
005453	004560	A	4321	LLSR	16			07	04321	
005454	165201	A	4322	MUL	BD120,X	CONVERT TO WORD INCREMENT	V2	07	04322	
005455	065164	A	4323	STB	TEMP,X			07	04323	
005456	005042	A	4324	TXB		RESTORE BASE REGISTER B		07	04324	
005457	016027	A	4325	LDA	ALBF,B			07	04325	
005460	126164	A	4326	ADD	TEMP,B	BUMP LOGICAL BUFFER ADDRESS		07	04326	
005461	056027	A	4327	STA	ALBF,B			07	04327	
005462	005311	A	4328	DAR				07	04328	
005463	056025	A	4329	STA	BFNP,B	ALSO BUFFER WORD POINTER		07	04329	
005464	016144	A	4330	LDA	PBWC,B			07	04330	
005465	146164	A	4331	SUB	TEMP,B	DECREMENT PHYSICAL WORD COUNT		07	04331	
005466	056144	A	4332	STA	PBWC,B			07	04332	
			4333	RFL20	TSAB	RWFL,WR,RFL30	READ ?	V2	07	04333
005467	016154	A								
005470	006411	A								
005471	005476	R	4334	ADBBB	PRECNO,PBRC,PRECNO	YES. BUMP PHYSICAL RECNO	V2	07	04334	
005472	016145	A								
005473	126142	A								
005474	056145	A	4335	POPJ		AND EXIT	FG	07	04335	
005475	105065	A								
005476	110423	A	4336	RFL30	DRA	PJS	SET POST FLAG ON WRITE	V2	07	04336
005477	056154	A	4337	STA	RWFL,B			V2	07	04337
005500	036010	A	4338	LDX	ADFCB,B	POINT X AT FCX		V2	07	04338
005501	015014	A	4339	LDA	12,X			V2	07	04339
005502	110437	A	4340	DRA	FPOS	ALSO IN FCX		V2	07	04340
005503	055014	A	4341	STA	12,X			V2	07	04341
			4342	RFL40	POPJ			FG	07	04342
005504	105065	A	4343	*****				07	04343	
			4344	* LRECNO NOT IN BUFFER *				07	04344	
			4345	*****				07	04345	
005505	016154	A	4346	RFL50	LDA	RWFL,B		07	04346	
005506	110427	A	4347	DRA	INS	SET INITIALIZE FLAG	V2	07	04347	
005507	056154	A	4348	STA	RWFL,B			07	04348	
005510	001000	A	4349	JMP	RCP	RECYCLE PHYSICAL BUFFER		07	04349	
005511	005225	R	4350	EJEC				07	04350	



```

4351 *****
4352 *
4353 *           R O U N D   D E C I M A L   A R R A Y ( R N D )
4354 *
4355 * FUNCTION: TO ROUND DECIMAL DIGIT STRING IN ARRAY CHB, PROPAGATING
4356 *           CARRIES FORWARD
4357 *
4358 * ENTRY:  ARRAY CHB CONTAINS BINARY EQUIVALENTS OF DECIMAL DIGITS
4359 *           COUNT = ROUND POSITION
4360 *           DEXP = DECIMAL EXPONENT
4361 *           ACC = BINARY FRACTION REMAINING AFTER 14 DIGITS
4362 *
4363 * EXIT :  DEXP = DEXP+1 ON FIELD OVERFLOW
4364 *
4365 *****
005512 005512 R 4367 RNA EQU *
005513 016052 A 4368 RND LDA COUNT,B
005514 001004 R 4369 JAN RNDX EXIT IF COUNT NEGATIVE FG 07 04369
005515 146200 A 4370 SUB BD14,B
005516 001004 A 4371 JAN RNDX IS COUNT .GE. 14 ? V2 07 04371
005517 005531 R
005520 016007 A 4372 LDA ACHB,B YES 07 04372
005521 126200 A 4373 ADD BD14,B V2 07 04373
005522 005314 A 4374 DECR 014 POINT X AT LAST DIGIT 07 04374
005523 016003 A 4375 LDA ACC,B 07 04375
005524 004241 A 4376 LRLA 1 07 04376
005525 001002 A 4377 JAP RNDX EXIT IF NO BUMP FG 07 04377
005526 005563 R
005527 001000 A 4378 JMP RNDL OTHERWISE PROPAGATE CARRY 07 04378
005530 005543 R
005531 016007 A 4379 RND5 LDA ACHB,B 07 04379
005532 126052 A 4380 ADD COUNT,B 07 04380
005533 005314 A 4381 DECR 014 POINT X AT ROUND POSITION-1 07 04381
005534 015001 A 4382 LDA 1,X GET DECIMAL DIGIT 07 04382
005535 140465 A 4383 SUB FIVE 07 04383
005536 001004 A 4384 JAN RNDX EXIT IF NO CARRY FG 07 04384
005537 005563 R
4385 TZAB COUNT,RND10 TEST COUNT=0 07 04385
005540 016052 A
005541 001010 A
005542 005560 R
4386 ZAX 1 CLEAR LAST DIGIT IN CASE OF OVERFLOW 07 04386
005543 005001 A
005544 035001 A
4387 *****
4388 * LOOP TO PROPAGATE CARRIES *
4389 *****
005545 045000 A 4390 RNDL INR 0,X BUMP PRECEDING DIGIT 07 04390
005546 015000 A 4391 LDA 0,X 07 04391
005547 140471 A 4392 SUB TEN 07 04392
005550 001004 A 4393 JAN RNDX EXIT IF NO CARRY FG 07 04393
005551 005563 R
005552 005001 A 4394 TZA 07 04394
005553 035000 A 4395 STA 0,X CLEAR DIGIT 07 04395
005554 005345 A 4396 DECR 045 DECREMENT CHB ARRAY POINTER 07 04396
005555 146007 A 4397 SUB ACHB,B 07 04397
005556 001002 A 4398 JAP RNDL IS CARRY PROPAGATED OUT OF CHB ? 07 04398
005557 005545 R
005560 046055 A 4399 RND10 INR DEXP,B YES. BUMP DECIMAL EXPONENT 07 04399
005561 005101 A 4400 INCR 1 07 04400
005562 055001 A 4401 STA 1,X SHIFT CHB RIGHT 1 07 04401
4402 RNDX POPJ EXIT FG 07 04402
005563 105065 A
4403 EJEC
4404 *****
4405 *
4406 *           R E F R E S H   P H Y S I C A L   B U F F E R ( R P B )
4407 *
4408 * FUNCTION: TO READ OR WRITE A PHYSICAL BUFFER
4409 *
4410 * ENTRY:  ADFCB = ADDRESS OF DCB/FCB
4411 *
4412 *           LOGICAL FILES ONLY:
4413 *
4414 *           PRECNO = CURRENT PHYSICAL RECORD NUMBER
4415 *           PERC = COUNT OF 120-WORD RECORDS IN PHYSICAL BUFFER
4416 *
4417 * EXIT :  PBWC = PHYSICAL WORD COUNT
4418 *           PRECNO = PRECNO + PBWC
4419 *
4420 *****
4422 RPS TRAB RWFL,LF,RPB10 TEST IF LOGICAL FILE 07 04422
005564 016154 A
005565 006401 A
005566 005570 R
4423 *****
4424 * LOGICAL FILE - SET UP FCB *
4425 *****
005567 036010 A 4426 LDX ADFCB,B POINT X AT FCB 07 04426
4427 MOVEAX PRECNO,3 MOVE PHYSICAL RECNO TO FCB(3) 07 04427
005570 016105 A
005571 055003 A

```



```

005572 055015 A 4428      STA      13,X          ALSO FCB(13)          07 04428
4429 *****
4430 * CALL IOC TO DO I/O *          07 04429
4431 *****
005573 010464 A 4432 RPB10 LDA      CIO          CALL V$IOC TO DO I/O    V2 07 04432
005574 006505 A 4433      JSR      PSJ,X          V2 07 04433
005575 004563 R 4434      TRAB     RWFL,IN,RPB11  INITIALIZING [        E.1 07 04434

005576 016154 A 4435      LDA      APBF,B          YES                      E.1 07 04435
005577 006446 A 4436      ADD      PBSZ,B          E.1 07 04436
005600 005606 R 4437      SUB      ALBF,B          COMPUTE REMAINING PHYSICAL WORD COUNT E.1 07 04437
005601 016020 A 4438      JMP      RPB12          E.1 07 04438
005602 126143 A 4439 RPB11 LDX      ANRB,B          NOT INITIALIZING        E.1 07 04439
005603 146027 A 4440      LDA      PBWC,X          XFER I/O WORD COUNT FROM V$FORTIO E.1 07 04440
005604 001000 A 4441 RPB12 STA      PBWC,B          E.1 07 04441
005605 005610 R 4442      TRAB     RWFL,LF,RPB15  LOGICAL FILE ?         V2 07 04442

005611 016154 A 4443      BT       ASET+RM,RPB20  YES. RMD ?             V2 07 04443
005612 006441 A 4444 RPB15 MOVBAB PBWC,LRSZ      NO. UPDATE LOGICAL WORD COUNT      V2 07 04444
005613 005616 R 4445      POPJ                                EXIT                      FG 07 04445
005614 006400 A 4446 RPB20 ADBBB  PRECND,PBRC,PRECND  BUMP PHYSICAL RECORD NUMBER        07 04446
005615 005621 R 4447      POPJ                                EXIT                      FG 07 04447

005616 016144 A 4448      EJEC                                07 04448
005617 056122 A 4449 *****                    07 04449
4450 *                               * 07 04450
4451 *           S E A R C H   F C B   C H A I N ( S C H )           * 07 04451
4452 *                               * 07 04452
4453 * FUNCTION: TO SEARCH AN FCB CHAIN FOR A GIVEN FORTRAN UNIT NUMBER U * 07 04453
4454 *                               * 07 04454
4455 * ENTRY: UNIT = U                               * 07 04455
4456 *       LNKCNT = COUNT OF FCB'S ON CHAIN          V2 07 04456
4457 *       EACH CHAIN ITEM XFCB HAS FORMAT:          * 07 04457
4458 *           XFCB(10) = ADDRESS OF NEXT FCB ON CHAIN * 07 04458
4459 *           XFCB(11) = U(XFCB)                   * 07 04459
4460 *       ALOC .NE. 0 IF V$RERR ENTERED BY ALOC      V2 07 04460
4461 *                               * 07 04461
4462 * EXIT : A = ADDRESS OF FCB ARRAY, IF U ON CHAIN * 07 04462
4463 *       = 0 IF U NOT ON CHAIN                     * 07 04463
4464 *       PRLINK = ADDRESS OF PREVIOUS CHAIN LINK   * 07 04464
4465 *                               * 07 04465
4466 *****                    07 04466
4467 *****                    07 04467
4468 * INITIALIZE SEARCH LOOP *                          07 04468
4469 *****                    07 04469
4470 *****                    07 04470

005625 036016 A 4471 SCH   LDX      ANRB,B          GET DATA BLOCK ADDRESS. 07 04471
005626 005041 A 4472      TXA                                ADD BIAS                  V2 07 04472
005627 006120 A 4473      ADDI     CHNHDR-10      07 04473
005630 000037 A 4474      STA      PRLINK,B          POINT PREVIOUS LINK AT CHAIN HEADER 07 04474
005631 056146 A 4475      LDA      LNKCNT,X          GET LINK COUNT           07 04475
005632 015120 A 4476      STA      COUNT,B          STORE AS LOOP COUNT      07 04476
005633 056052 A 4477      LDX      CHNHDR,X          POINT X AT HEAD OF CHAIN 07 04477
005634 035051 A 4478 *****                    07 04478
4479 * SEARCH LOOP *                          07 04479
4480 *****                    07 04480

005635 016052 A 4481 SCHLP LDA      COUNT,B          FLAG NO FIND BY EXIT WITH A=0      FG 07 04481
005636 001010 A 4482      JAZ      SCHY              07 04482
005637 005666 R 4483      DAR                                DECREMENT COUNT          07 04483
005640 005311 A 4484      STA      COUNT,B          07 04484
005641 056052 A 4485      IFF      NUC              FG 07 04485
4486      GOTO    NUC1            FG 07 04486
4487      IFT      VII          FG 07 04487
4488      GOTO    VIII         FG 07 04488
4489      TZAB     ALOC,SCH5    VORTEX BKGND CALLING NUCLEUS ? V2 07 04489

005642 016014 A 4490      STX      TEMP,B          YES. SAVE X              07 04490
005643 001010 A 4491      TXA                                07 04491
005644 005655 R 4492      JSR      TBK,X          TEST FCB(0) IN BACKGROUND 07 04492
005645 076164 A 4493      ADD      D15             07 04493
005646 005041 A 4494      JSR      TBK,X          TEST FCB(14) IN BACKGROUND 07 04494
005647 006505 A 4495      LDX      TEMP,B          RESTORE X                07 04495
005650 005735 R 4496      NUC1     CONT            FG 07 04496
005651 120472 A 4497      VIII    CONT            FG 07 04497
005652 006505 A 4498      SCH5    LDA      11,X          07 04498
005653 005735 R 4499
005654 036164 A
005655 015013 A

```



Address	Label	Op	Op2	Op3	Description	Page	Line
005656	146167	A	4499	SUB	UNIT,B	07	04499
005657	001010	A	4500	JAZ	SCHX	07	04500
005660	005665	R			COMPARE WITH U EXIT ON FIND WITH X=FCB ADDRESS		
005661	076146	A	4501	STX	PRLINK,B	07	04501
005662	035012	A	4502	LDX	10,X	07	04502
005663	001000	A	4503	JMP	SCHLP	07	04503
005664	005635	R			LOOP TILL CHAIN EXHAUSTED		
005665	005041	A	4504	SCHX	TXA	07	04504
			4505	SCHY	POPJ	FG	07 04505
005666	105065	A			FLAG FIND BY A.NE.0 (FCB ADDRESS)		
			4506	EJEC	EXIT	07	04506
			4507		*****	07	04507
			4508		*****	07	04508
			4509		SHIFT ACCUMULATOR ACC(SHA)	07	04509
			4510		*****	07	04510
			4511		FUNCTION: TO SHIFT THE 4-WORD ACCUMULATOR ACC	07	04511
			4512		*****	07	04512
			4513		ENTRY: COUNT = + SHIFT RIGHT COUNT	07	04513
			4514		= - SHIFT LEFT 1	07	04514
			4515		*****	07	04515
			4516		EXIT : NO SPECIAL CONDITIONS	07	04516
			4517		*****	07	04517
			4518		*****	07	04518
005667	005024	A	4520	SHA	TXB	07	04520
			4521	SHAL	TMAX	V2	07 04521
					LOAD X AS BASE POINTER TEST DIRECTION OF SHIFT		
005670	015052	A					
005671	001004	A					
005672	005716	R					
005673	001010	A	4522	JAZ	SHAX	07	04522
005674	005733	R			EXIT WHEN FINISHED		
005675	005311	A	4523	DAR		07	04523
005676	055052	A	4524	STA	COUNT,X	07	04524
			4525		*****	07	04525
			4526		RIGHT SHIFT	07	04526
			4527		*****	07	04527
005677	025006	A	4528	LDB	ACC+3,X	07	04528
005700	015005	A	4529	LDA	ACC+2,X	07	04529
005701	004501	A	4530	LASR	1	07	04530
005702	065006	A	4531	STB	ACC+3,X	07	04531
005703	025005	A	4532	LDB	ACC+2,X	07	04532
005704	015004	A	4533	LDA	ACC+1,X	07	04533
005705	004501	A	4534	LASR	1	07	04534
005706	065005	A	4535	STB	ACC+2,X	07	04535
005707	025004	A	4536	LDB	ACC+1,X	07	04536
005710	015003	A	4537	LDA	ACC,X	07	04537
005711	004501	A	4538	LASR	1	07	04538
005712	065004	A	4539	STB	ACC+1,X	07	04539
005713	055003	A	4540	STA	ACC,X	07	04540
005714	001000	A	4541	JMP	SHAL	07	04541
005715	005670	R			LOOP TILL DONE		
			4542		*****	07	04542
			4543		LEFT SHIFT	07	04543
			4544		*****	07	04544
005716	015003	A	4545	SHA50	LDA	07	04545
005717	025004	A	4546	LDB	ACC+1,X	07	04546
005720	004401	A	4547	LASL	1	07	04547
005721	055003	A	4548	STA	ACC,X	07	04548
005722	015004	A	4549	LDA	ACC+1,X	07	04549
005723	025005	A	4550	LDB	ACC+2,X	07	04550
005724	004401	A	4551	LASL	1	07	04551
005725	055004	A	4552	STA	ACC+1,X	07	04552
005726	015005	A	4553	LDA	ACC+2,X	07	04553
005727	025006	A	4554	LDB	ACC+3,X	07	04554
005730	004401	A	4555	LASL	1	07	04555
005731	055005	A	4556	STA	ACC+2,X	07	04556
005732	065006	A	4557	STB	ACC+3,X	07	04557
005733	005042	A	4558	SHAX	TXB	07	04558
			4559	POPJ		FG	07 04559
005734	105065	A			RESTORE BASE REGISTER B EXIT		
			4560	EJEC		07	04560
			4561	IFF	NUC	FG	07 04561
			4562	GOTO	NUC1	07	04562
			4563	IFT	VII	FG	07 04563
			4564	GOTO	VIII	07	04564
			4565		*****	07	04565
			4566		*****	07	04566
			4567		TEST BACKGROUND ADDRESS (TBK)	07	04567
			4568		*****	07	04568
			4569		FUNCTION: TO TEST IF AN ADDRESS IS IN THE BACKGROUND	07	04569
			4570		*****	07	04570
			4571		ENTRY: A = TEST ADDRESS	07	04571
			4572		*****	07	04572
			4573		CALLING SEQUENCE: JSR TBK,X	07	04573
			4574		*****	07	04574
			4575		EXIT : IF OK, RETURN WITH A UNCHANGED	07	04575
			4576		OTHERWISE, SET UP A MEMORY PROTECT ERROR	07	04576
			4577		*****	07	04577
			4578		*****	07	04578
005735	140316	A	4580	TBK	SUB	07	04580
005736	001004	A	4581	JAN	TBK10	07	04581
005737	005751	R			ERROR IF A.LT.V\$LUP		
005740	120316	A	4582	ADD	V\$LUP	07	04582
005741	140317	A	4583	SUB	V\$LLUP	07	04583



```

005742 001010 A 4584      JAZ      *+4
005743 005746 R
005744 001002 A 4585      JAP      TBK10      ERROR IF A.GT.V$LLUP
005745 005751 R
005746 120317 A 4586      ADD      V$LLUP      RESTORE A
005747 006705 A 4587      IJMP     0,X        RETURN IF OK
005750 000000 A
4588 *****
4589 * ERROR - CONSTRUCT MEMORY PROTECT VIOLATION *
4590 *****
005751 030316 A 4591 TBK10 LDX      V$LUP      POINT X AT 1ST BACKGROUND WORD
005752 010432 A 4592      LDA      TBKJMP
005753 055000 A 4593      STA      0,X
005754 005001 A 4594      TZA
005755 055001 A 4595      STA      1,X        STORE 'JMP 0' IN BACKGROUND
005756 020302 A 4596      LDB      V$CRS      POINT B AT STACK
005757 076003 A 4597      STX      PR,B       SET DEALOC ADDRESS TO 1ST BACKGROUND WORD
4598      DEALOC
005760 006505 A
005761 000077 E
005762 000700 A
000432 A 4599 TBKJMP SET      BS9
4600 VIII  CONT      FG 07 04600
4601 NUC1  CONT      FG 07 04601
4602      EJEC
4603 *****
4604 *
4605 * P R O C E S S T F O R M A T D E S C R I P T O R ( T I D ) *
4606 *
4607 * F U N C T I O N : T O P R O C E S S T H E F O R M A T D E S C R I P T O R : T W *
4608 *
4609 * E N T R Y : D I R E C T F R O M F R S *
4610 *       BFPT = CURRENT BUFFER CHARACTER POSITION(BASE 0) *
4611 *       W = SPECIFIED BUFFER CHARACTER POSITION(BASE 1) *
4612 *
4613 * E X I T : D I R E C T T O F R S *
4614 *       BFPT = W-1 *
4615 *       BFPT = ALBF + BFPT/2 *
4616 *       RWFL(BIT SC) = 1 IF LOGICAL FILE PHYSICALLY POSITIONED BACKV2 *
4617 *
4618 * E R R O R S : E R 1 I F W O U T S I D E L O G I C A L R E C O R D *
4619 *
4620 *****
005763 R 4622 TIN      EQU      *
005763 R 4623 TOUT     EQU      *
4625      MOVBAB  BFPT,SAVE      SAVE CURRENT VALUE OF BUFFER CHAR PTR
005763 016026 A
005764 056032 A
005765 016170 A 4626      LDA      W,B        GET W
005766 005311 A 4627      DAR
005767 056026 A 4628      STA      BFPT,B     CONVERT FROM BASE 1 TO BASE 0
005770 146032 A 4629      SUB      SAVE,B     STORE AS BUFFER CHARACTER POINTER
005771 001004 A 4630      JAN
005772 006002 R
4631 *****
4632 * P O S I T I O N F O R W A R D *
4633 *****
005773 016122 A 4634      LDA      LRSZ,B     YES
005774 004241 A 4635      LRLA     1          GET LOGICAL RECORD BYTE COUNT
005775 146170 A 4636      SUB      W,B
005776 001004 A 4637      JAN      ER1       ERROR 1/ W OUTSIDE RECORD /
005777 005367 R
006000 001000 A 4638      JMP      TIQLP
006001 006045 R
4639 *****
4640 * P O S I T I O N B A C K W A R D *
4641 *****
006002 016026 A 4642 TIQ10 LDA      BFPT,B
006003 004341 A 4643      LSR     1          GET WORD POSITION
006004 126027 A 4644      ADD     ALBF,B     GET ADDRESS
006005 146020 A 4645      SUB     APBF,B     COMPARE WITH BUFFER START ADDRESS
006006 001002 A 4646      JAP     TIQ20     EXIT IF STILL IN BUFFER
006007 006032 R
4647 *****
4648 * R E P O S I T I O N B U F F E R *
4649 *****
006010 036010 A 4650      LDX     ABFCB,B
006011 015015 A 4651      LDA     13,X       GET BUFFER RECORD NUMBER
006012 146142 A 4652      SUB     P$RC,B
006013 056145 A 4653      STA     PRECND,B   BACK UP FILE
4654      ADRBB  ALBF,PBSZ,ALBF  BUMP LOGICAL BUFFER ADDRESS
006014 016027 A
006015 126143 A
006016 056027 A 4655      MOVBAB  RWFL,SAVE+1  SAVE FLAG WORD
006017 016154 A
006020 056033 A
006021 006451 A 4656      BT      ARST+WR,TIQ15  WRITE ?
006022 006025 R
006023 110424 A 4657      DRA     RBS        YES. SET READ BEFORE WRITE FLAG
006024 056154 A 4658      STA     RWFL,B
4659 TIQ15 PUSHJ    RFL        REPOSITION FILE
006025 105025 A

```







```

006127 036010 A 4721      LDX      ADFCB,B
4722      MOVBA  PBSZ,0      IF NON-RMD, SET FCB(0) = PBSZ      V2 07 04721
006130 016143 A
006131 055000 A
4723 TRM30 TRAB      RWFL,WR,CAN      EXIT ON READ      D.1 07 04723
006132 016154 A
006133 006431 A
006134 000065 R
006135 006412 A 4724      BT      EC,CAN      EXIT FOR ENCODE/DECODE      PD 07 04724
006136 000065 R
006137 010464 A 4725      LDA      CID
4726      PUSHF      WRITE LAST NON-LOGICAL RECORD      07 04725
006140 036016 A
006141 035000 A
006142 005344 A
006143 055000 A
006144 005041 A
006145 036016 A
006146 055000 A
006147 001000 A 4727      JMP      CAN      EXIT TO V$FORTIO      07 04727
006150 000065 R
006151 016121 A 4728 TRMI      LDA      LRECNO,B
4729      EJEC
4730 *****
4731 *
4732 *      U N F O R M A T T E D   I N P U T / O U T P U T ( U I D )
4733 *
4734 *      F U N C T I O N :   T O   P R O C E S S   U N F O R M A T T E D   I / O   C A L L S
4735 *
4736 *      E N T R Y :   I T E M A D = L I S T   I T E M   A D D R E S S
4737 *                   B F W P T = A D D R E S S   O F   D A T A   W O R D   I N   B U F F E R
4738 *
4739 *      E X I T   :   T O   V $ F O R T I O   T H R U   G N L
4740 *
4741 *****
4742 *****
4743 *****
4744 *      T R A N S F E R   L O O P
4745 *****
4746 UID      PUSHJ   GNL      GET NEXT LIST ITEM ADDRESS/EXIT      V2 07 04746
006152 105025 A
006153 001447 R
4747      PUSHJ   GBA      GET BUFFER ADDRESS      V2 07 04747
006154 105025 A
006155 001103 R
4748      TSAB      RWFL,WR,UID4      TEST INPUT OR OUTPUT      V2 07 04748
006156 016154 A
006157 006411 A
006160 006167 R
4749 *****
4750 *      I N P U T
4751 *****
006161 036025 A 4752      LDX      BFWPT,B      POINT X AT DATA WORD IN BUFFER
006162 015000 A 4753      LDA      0,X      GET DATA WORD
006163 036113 A 4754      LDX      ITEMAD,B      POINT X AT LIST ITEM
006164 055000 A 4755      STA      0,X      STORE INPUT DATA WORD IN LIST ITEM
006165 001000 A 4756      JMP      UID      LOOP UNTIL DONE
006166 006152 R
4757 *****
4758 *      O U T P U T
4759 *****
006167 036113 A 4760 UID4      LDX      ITEMAD,B      POINT X AT LIST ITEM
006170 015000 A 4761      LDA      0,X      GET DATA WORD
006171 036025 A 4762      LDX      BFWPT,B      POINT X AT DATA WORD IN BUFFER
006172 055000 A 4763      STA      0,X      STORE DATA WORD IN OUTPUT BUFFER
006173 001000 A 4764      JMP      UID      LOOP UNTIL DONE
006174 006152 R
4765      EJEC
4766 *****
4767 *
4768 *      P R O C E S S   X   F O R M A T   D E S C R I P T O R ( X I D )
4769 *
4770 *      F U N C T I O N :   T O   P R O C E S S   T H E   F O R M A T   D E S C R I P T O R :   N X
4771 *
4772 *      E N T R Y :   D I R E C T   F R O M   F R S
4773 *                   N = F I E L D   W I D T H
4774 *
4775 *      E X I T   :   T O   F R S
4776 *
4777 *****
006175 R 4779 XIN      EQU      *
006175 R 4780 XOUT     EQU      *
4782      MOVBA  BLNK1,BCHAR      LOAD BLANK AS REPEAT CHARACTER      V2 07 04782
006175 016202 A
006176 056030 A
4783      MOVBA  N,COUNT      SET REPEAT COUNT TO N      07 04783
006177 016125 A
006200 056052 A
4784      MOVBA  ABSOB,ASCB      SET SCB TO BUFFER      07 04784
006201 016002 A
006202 056021 A
4785      PUSHJ   RCH      REPEAT CHARACTER I/O N TIMES      V2 07 04785
006203 105025 A
006204 005125 R

```



```

006205 001000 A 4786      JMP      FR55      RESUME FORMAT SCAN      07 04786
006206 000441 R      4787      EJEC      07 04787
4788 ***** 07 04788
4789 * 07 04789
4790 *   P R O C E S S   Z   D E S C R I P T O R   ( Z I N / Z O U T )  * 07 04790
4791 * 07 04791
4792 *   F U N C T I O N :   T O   P R O C E S S   T H E   Z   F O R M A T   D E S C R I P T O R :   R Z W  * 07 04792
4793 * 07 04793
4794 *   E N T R Y :   D I R E C T   F R O M   F R S  * 07 04794
4795 *           W T = W T O T A L   F I E L D   W I D T H  * 07 04795
4796 *           I I B S Z = B Y T E   C O U N T   O F   S I N G L E   L I S T   I T E M  * 07 04796
4797 *           I T E M A D = A D D R E S S   O F   L I S T   I T E M  * 07 04797
4798 *           R W F L ( B I T   W R ) = 0   R E A D  * 07 04798
4799 *           = 1   W R I T E  * 07 04799
4800 * 07 04800
4801 *   E X I T :   I N P U T   :   D I R E C T   T O   F R S  * 07 04801
4802 *           O U T P U T :   D I R E C T   T O   F R S   T H R U   O B C  * 07 04802
4803 * 07 04803
4804 ***** 07 04804
006207 R 4806 ZIN EQU * 07 04806
006207 R 4807 ZOUT EQU * 07 04807
4809 ZAB AIBUF-1 SET LIST ITEM SCB(0)=0 (BYTE COUNT) 07 04809

006207 005001 A 4810      MOV BAB ITEMAD,AIBUF SET LIST ITEM SCB(1)=ITEM ADDRESS 07 04810
006210 056107 A
006211 016113 A 4811      LDA      WT,B 07 04811
006212 056110 A 4812      IOR 07 04812
006213 016171 A 4813      ASRA    1 (A)=BYTES TO PROCESS 07 04813
006214 005111 A 4814      SUB     IIBSZ,B 07 04814
006215 004301 A 4815      STA     COUNT,B EXCESS BYTES 07 04815
006216 146101 A 4816      MOV BAB BLNK1,BCHAR SLEW THRU W/2-IIBSZ CHAR 07 04816
006217 056052 A
006220 016202 A 4817      PUSHJ  RCH 07 04817
006221 056030 A
006222 105025 A 4818      TSAB   RWFL,WR,ZI04 I/O TEST 07 04818
006223 005125 R
006224 016154 A 4820 * INPUT 07 04820
006225 006411 A 4821 ZI01 PUSHJ ARC GET BUFFER CHARACTER 07 04821
006226 006261 R
006227 105025 A 4822      PUSHJ  ZI06 INPUT CHARACTER TEST 07 04822
006228 000101 R
006231 105025 A 4823      MOV BAB BCHAR,ICAR 07 04823
006232 006302 R
006233 016030 A 4824      TZAB   WT,ZI02 FIELD WIDTH EXHAUSTED 07 04824
006234 056111 A
006235 016171 A 4825      PUSHJ  CBC GET NEXT CHARACTER 07 04825
006236 001010 A
006237 006250 R
006240 105025 A 4826      PUSHJ  ZI06 INPUT CHARACTER TEST 07 04826
006241 000101 R
006242 105025 A 4827      LDA     ICHAR,B APPEND RT HALF 07 04827
006243 006302 R 4828      ASLA   4 07 04828
006244 016111 A 4829      ADD    BCHAR,B 07 04829
006245 004204 A 4830      STA    ICHAR,B 07 04830
006246 126030 A 4831 ZI02 MOV BAB AISC B,ASCB SET SCB TO LIST ITEM 07 04831
006247 056111 A
006250 016013 A 4832      PUSHJ  PCH PUT CHARACTER IN ITEM 07 04832
006251 056021 A
006252 105025 A 4833      TNZAB  WT,ZI01 LOOP UNTILL FIELD WIDTH EXHAUSTED 07 04833
006253 003320 R
006254 016171 A 4834      JMP     FR565 TO FORMAT SCAN 07 04834
006255 001016 A
006256 006227 R 4836 * OUTPUT 07 04836
006257 001000 A 4837 ZI04 MOV BAB AISC B,ASCB SET SCB TO LIST ITEM 07 04837
006260 001014 R
006261 016013 A 4838      PUSHJ  ICC INPUT CHARACTER FROM LIST ITEM 07 04838
006262 056021 A
006263 105025 A 4839      PUSHJ  ZI08 OUTPUT CHARACTER 07 04839
006264 001623 R
006265 105025 A 4840      LDA     ICHAR,B 07 04840
006266 006325 R 4841      ASRA   4 07 04841
006267 016111 A 4842      LDA    ICHAR,B 07 04842
006270 004304 A 4843      ANAI   0177 GET RT HALF 07 04843
006271 016111 A
006272 006150 A

```







006445		4923	VIDLNK	BSS	1		IOLINK CONTROL WORD	07	04923
006446	000000	A 4924	VIDSTA	DATA	0		I/O STATUS	07	04924
006447		4925	VISCB	BSS	4		LIST ITEM SCB	07	04925
006453		4926	VITEMA	BSS	1		ADDRESS OF LIST ITEM	07	04926
006454		4927	VITEMW	BSS	1		COUNT OF WORDS REMAINING IN ITEM	07	04927
006455		4928	VITMIN	BSS	1		LIST ITEM WORD INCREMENT	07	04928
006456		4929	VITMOD	BSS	1		LIST ITEM MODE	07	04929
006457		4930	VLISTF	BSS	1		LIST DATA XFER FLAG	07	04930
006460		4931	VLNKN	BSS	1		FCB CHAIN LINK COUNT	07	04931
006461		4932	VLRECN	BSS	1		LOGICAL RECORD NUMBER	07	04932
006462		4933	VLRSZ	BSS	1		LOGICAL RECORD SIZE	07	04933
006463		4934	VLRWC	BSS	1		LOGICAL RECORD REMAINING WORD COUNT	07	04934
006464		4935	VMOV	BSS	1		MULTIPLY OVERFLOW SWITCH	07	04935
006465		4936	VN	BSS	1		H/T/X FIELD WIDTH	07	04936
006466		4937	VNFF	BSS	1		NUMERIC FORMAT FIELD	07	04937
		4938	VIII	CONT				FG	07 04938
006467		4939	VDPSTK	BSS	STKSZ		DP STACK	FG	07 04939
006501		4940	VPARLV	BSS	1		FORMAT '*' GROUP LEVEL COUNT	FG	07 04940
		4941			VII			FG	07 04941
		4942			VIII			FG	07 04942
006502		4943	VPBRC	BSS	1		PHYSICAL BUFFER RECORD COUNT		07 04943
006503		4944	VPBSZ	BSS	1		PHYSICAL BUFFER SIZE		07 04944
006504		4945	VPBWC	BSS	1		PHYSICAL BUFFER REMAINING WORD COUNT		07 04945
006505		4946	VPRECN	BSS	1		PHYSICAL RECORD NUMBER		07 04946
006506		4947	VRLIN	BSS	1		PREVIOUS LINK OF FCB CHAIN		07 04947
006507		4948	VPTFL	BSS	1		'.' POINT FLAG		07 04948
006510		4949	VQFL	BSS	1		QUOTE FLAG		07 04949
006511		4950	VRETUR	BSS	1		RETURN ADDRESS		07 04950
006512		4951	VRWFL	BSS	1		FLAG WORD	V2	07 04951
006513		4952	VS	BSS	1		SCALE FACTOR		07 04952
006514		4953	VSCF	BSS	1		SCALE FACTOR FLAG		07 04953
006515		4954	VSGFL	BSS	1		'-' SIGN FLAG		07 04954
006516		4955	VSVREC	BSS	1		SAVE RECORD NO		07 04955
006517	000000	A 4956	VSYSDC	DATA	0,0,0		SYSTEM DCB		07 04956
006520	000000	A							
006521	000000	A							
006522		4957	VTEMP	BSS	1		TEMP STORE		07 04957
006523		4958	VTEMP1	BSS	1		TEMP STORE		07 04958
006524		4959	VTERM	BSS	1		PRODUCT TERM		07 04959
006525		4960	VUNIT	BSS	1		I/O UNIT NUMBER		07 04960
006526		4961	VN	BSS	1		FIELD WIDTH		07 04961
006527		4962	VWT	BSS	1		WORKING VALUE OF W		07 04962
006530	000000	A 4963	VXFFL	DATA	0		PARAMTER XFER ENABLE FLAG		07 04963
006531		4964	VXFL	BSS	1		EXPONENT FIELD NON-BLANK FLAG		07 04964
006532		4965	VXFW	BSS	1		EXPONENT FIELD WIDTH		07 04965
006533		4966	VXSG	BSS	1		EXPONENT SIGN FLAG		07 04966
006534		4967	VZFW	BSS	1		LEADING ZERO FIELD WIDTH		07 04967
006535	000260	A 4968		DATA	0260		ASCII ZERO	V2	07 04968
006536	000016	A 4969		DATA	14		DECIMAL 14	V2	07 04969
006537	000170	A 4970		DATA	120		DECIMAL 120	V2	07 04970
006540	000240	A 4971		DATA	0240		ASCII BLANK	V2	07 04971
006541	120240	A 4972		DATA	' '		ASCII BLANK WORD	V2	07 04972
		4973	VIII	CONT				FG	07 04973
		4974	NUC1	CONT				FG	07 04974
006542	R	4975	VZZZ	EQU	*		END OF DATA BLOCK		07 04975
		4976		END					07 04976

ENTRY NAMES

005037 R VSRER1 000000 R VSRERF 000001 A VSRERN 004713 R VSRERR

EXTERNAL NAMES

004353 E BIFCB 004354 E BDFCB 004356 E GDFCB 004352 E LOFCB

004351 E PIFCB 004357 E PDFCB 004347 E SIFCB 004355 E SSFCB

SYMBOLS

000001	A	AACC	000002	A	ABSCB	000003	A	ACC	000007	A	ACHB
000010	A	ADFCB	000011	A	AFSCB	000012	A	AGPAR	000110	A	AIBUF
000000	R	AIN	000016	R	AIOL1	000053	R	AIOL2	000013	A	AISCB
000000	A	AL	000027	A	ALBF	000014	A	ALDC	000015	A	ANPOJ
000016	A	ANRB	000017	A	ADPSTK	000000	R	ADUT	000020	A	AFBF
000040	A	ARST	000021	A	ASCB	000000	A	ASET	000022	A	ASFL
000023	A	ASYSDC	000177	A	AZER	000002	A	B	000000	A	B0
000001	A	B1	000014	A	B12	000015	A	B13	000016	A	B14
000017	A	B15	000002	A	B2	000003	A	B3	000004	A	B4
000005	A	B5	000005	A	B6	006340	R	BASE	000030	A	BCHAR
000031	A	BODDE	000201	A	BD120	000200	A	BD14	000024	A	BEXP
000010	A	BF	000400	A	BFA	000026	A	BFPT	000451	A	BFR
000431	A	BFS	000023	A	BFWPT	004353	E	BIFCB	000001	A	BL
000202	A	BLNK1	000203	A	BLNK2	000472	A	BM17	000473	A	BM37
000474	A	BM77	004354	E	BDFCB	000001	A	BR	000441	A	BR0
000442	A	BR1	000454	A	BR11	000455	A	BR12	000457	A	BR14
000460	A	BR15	000443	A	BR2	000444	A	BR3	000445	A	BR4
000446	A	BR5	000447	A	BR6	000450	A	BR7	000451	A	BR8
000421	A	BS0	000422	A	BS1	000433	A	BS10	000434	A	BS11
000435	A	BS12	000437	A	BS14	000440	A	BS15	000423	A	BS2
000424	A	BS3	000425	A	BS4	000426	A	BS5	000430	A	BS7
000431	A	BS8	000432	A	BS9	000026	A	BSCB	000430	A	BXBIAS
000065	R	CAN	000073	R	CAN1	000076	R	CAN5	000101	R	CBC
000110	R	CBC4	000122	R	CBC6	000467	A	CBK	000020	A	CDC
000424	A	CEF	000021	A	CEN	000421	A	CER	000422	A	CEX
000032	A	CH8	000050	A	CHEPT	000051	A	CHNHDR	000454	A	CID
000127	R	CLB	000136	R	CLB4	000150	R	CLB8	000152	R	CLBLP
000162	R	CLPX	000163	R	CLS	000213	R	CLS10	000223	R	CLS15
000223	R	CLS20	000254	R	CLS30	000002	A	CM	000016	A	CPY
000052	A	COUNT	000022	A	CRA	000423	A	CRB	000471	A	CRD



000470	A	CRW	000465	A	CTR	000005	A	CTRV	000053	A	CVFL
000420	A	CXC	000466	A	CXF	000054	A	D	000271	R	D10
000472	A	D15	000425	A	D16	000013	A	DA	000311	R	DEF
000316	R	DEF4	000321	R	DEF8	000346	R	DED10	000344	R	DED5
000055	A	DEXP	003347	R	DIN	000324	R	DDUT	000056	A	DT
000012	A	EC	000057	A	EDEXP	000424	A	EIGHT	003347	R	EIN
000324	R	EDUT	005367	R	ER1	005366	R	ER2	005365	R	ER3
005364	R	ER4	000060	A	ERN	000064	A	FCHAR	000065	A	FCDDE
000061	A	FDLKEY	003347	R	FIN	000465	A	FIVE	000015	A	FLF
000062	A	FMPT	000423	A	FDR	000375	R	FOUT	000016	A	FPD
000457	A	FPDR	000437	A	FPOS	000017	A	FRB	000440	A	FRBS
000014	A	FRM	000063	A	FRMT	000062	A	FRPT	000410	R	FRS
000453	R	FRS10	000511	R	FRS15	000563	R	FRS19	000424	R	FRS2
000567	R	FRS20	000574	R	FRS25	000622	R	FRS30	000635	R	FRS35
000651	R	FRS40	000662	R	FRS45	000675	R	FRS46	000720	R	FRS47
000441	R	FRS5	000733	R	FRS50	000777	R	FRS55	001001	R	FRS60
001014	R	FRS65	001023	R	FRS70	001027	R	FRS75	001031	R	FRS85
001042	R	FRSCHT	001055	R	FRSJT	000640	R	FRSL1	000062	A	FSCB
001103	R	GBA	001114	R	GBA50	001124	R	GBA55	001135	R	GBA60
001143	R	GBA70	001152	R	GBA80	000066	A	GDRPC	000007	A	GF
000071	A	GFRPT	000430	A	GFS	003347	R	GIN	001160	R	GNI
001315	R	GNI10	001177	R	GNI2	001342	R	GNI20	001405	R	GNI25
001414	R	GNI30	001204	R	GNI4	001431	R	GNI50	001240	R	GNI8
001263	R	GNI9	001311	R	GNI9A	001326	R	GNIL1	001434	R	GNIL2
001447	R	GNL	001476	R	GNL2	004336	E	GDFCB	001332	R	GDUT
000074	A	GSRPC	001532	R	HIN	001577	R	HID10	001611	R	HID15
001543	R	HID2	001564	R	HID4	001567	R	HID6	001532	R	HOUT
001623	R	ICC	001654	R	ICCCCT	001676	R	ICCCCT1	001644	R	ICCLP
000111	A	ICHAR	000077	A	IDEXP	001722	R	IFF	001724	R	IFFL
001747	R	IFFL1	000100	A	IFW	000101	A	IIBSZ	003347	R	IIN
000102	A	IISZ	000006	A	IN	001756	R	INF	000103	A	INFL
001760	R	INFLP	000447	A	INR	000427	A	INS	000104	A	IDCONT
000105	A	IDENK	000106	A	IDSTAT	001765	R	IDUT	000107	A	ISCB
000113	A	IDEMAD	000114	A	IDEMWC	000115	A	ITMNC	000116	A	ITMODE
001775	R	IXN	002073	R	IXN10	002102	R	IXN15	002136	R	IXN18
002141	R	IXN20	002155	R	IXN25	002170	R	IXN30	002033	R	IXN4
002052	R	IXN5	002172	R	IXN50	002210	R	IXN52	002216	R	IXN53
002223	R	IXN55	002235	R	IXN57	002236	R	IXN58	002057	R	IXN6
002245	R	IXN60	002067	R	IXN8	002010	R	IXNL1	002115	R	IXNL2
002230	R	IXNL3	000550	R	IXR	000300	A	LC	000001	A	LF
000422	A	LFS	000123	A	LGOV	000462	A	LHW	002262	R	LIN
002306	R	LINX	000117	A	LISTFL	000120	A	LNKCNT	000204	A	LOC
004352	E	LDFCB	002335	R	LOU4	002314	R	LQUT	000003	A	LP
000121	A	LRECND	003340	R	LRLA8	000122	A	LRSZ	000123	A	LRWC
001721	R	LSRA8	002337	R	M10	002355	R	M104	002401	R	M10X
000046	A	MAP	000004	A	MH	000124	A	MOV	000420	A	MT
000125	A	M	000126	A	NFF	000470	A	NINE	000005	A	NM
002402	R	NRM	002426	R	NRM4	002403	R	NRML	002450	R	NRMX
000001	A	NJC	002452	R	OCB	002464	R	OCB4	002472	R	OCB6
000421	A	ONE	002502	R	DNF	002546	R	DNF20	002577	R	DNF30
002645	R	DNF40	002532	R	DNF5	002656	R	DNF50	002667	R	DNF52
002704	R	DNF55	002724	R	DNF60	002552	R	DNFL1	002620	R	DNFL2
002730	R	DPN	003111	A	DPN30	002763	R	DPN4	002774	R	DPN5
000127	A	DPSTK	000000	A	DPSTKP	000141	A	PARLV	003123	R	PAX
003145	R	PAX10	003161	R	PAX15	003166	R	PAX16	003217	R	PAX20
003244	R	PAX30	003253	R	PAX33	003260	R	PAX50	003263	R	PAX55
003270	R	PAX70	003315	R	PAXTAB	000142	A	PBRC	000143	A	PBSZ
000144	A	PBWC	003320	R	PNI	004351	E	PIFCB	000006	A	PL
003323	R	PNI18	003335	R	PNI19	003343	R	PNI20	003432	R	PNI4
003552	R	PNI50	003575	R	PNI60	003612	R	PNI62	003626	R	PNI64
003643	R	PNI66	003474	R	PNI8	003402	R	PNIL1	003416	R	PNIL1X
003560	R	PNIL2	000002	A	PO	004357	E	PDFCB	003650	R	POJ
000443	A	PDR	000423	A	POS	000003	A	PR	003655	R	PRD
003711	R	PRD1	003742	R	PRD2	003751	R	PRD4	000145	A	PRECND
000146	A	PRLINK	003754	R	PRU	003767	R	PRU0	003773	R	PRU05
004030	R	PRU1	004144	R	PRU10	004210	R	PRU15	004045	R	PRU2
004222	R	PRU20	004245	R	PRU25	004054	R	PRU3	004256	R	PRU30
004305	R	PRU35	004057	R	PRU4	004332	R	PRU40	004077	R	PRU5
004346	R	PRU50	004120	R	PRU6	004347	R	PRUAS1	004361	R	PRUDTB
004370	R	PRUDE	004360	R	PRUGT	004212	R	PRUL1	004400	R	PRW
004422	R	PRW0	004411	R	PRW05	004426	R	PRW1	004502	R	PRW10
004436	R	PRW2	004462	R	PRW4	004472	R	PRW6	004513	R	PRX
000007	A	PS	004533	R	PSB	004562	R	PSEX	004563	R	PSJ
000010	A	PT	000147	A	PTFL	004622	R	PXF	004665	R	PXF10
004704	R	PXF20	004635	R	PXF5	004705	R	PXF5ZT	000150	A	QFL
000011	A	QT	000125	A	R	000003	A	RE	004714	R	RBE1
004735	R	RBE10	005050	R	RBE15	005073	R	RBE25	005075	R	RBE30
005035	R	RBE4	004733	R	RBE5	005102	R	RBE90	005124	R	RBE8
005105	R	RBEJT	005124	R	RBEJTE	000424	A	RBS	005125	R	RCH
005155	R	RCH10	005163	R	RCH15	005132	R	RCH2	005151	R	RCH5
005167	R	RCL	005201	R	RCL10	005210	R	RCL15	005174	R	RCL5
005225	R	RCP	005263	R	RCP15	005301	R	RCP20	005306	R	RCP25
005235	R	RCP3	005345	R	RCP35	005350	R	RCP40	005241	R	RCP5
005357	R	RCP50	000151	A	RETURN	005404	R	RFL	005424	R	RFL10
005467	R	RFL20	005476	R	RFL30	005504	R	RFL40	005420	R	RFL5
005503	R	RFL50	000463	A	RHW	000000	A	RM	000421	A	RMS
005512	R	RNA	005512	R	RND	005560	R	RND10	005531	R	RND5
005545	R	RNDL	005563	R	RNDX	002201	R	RDF	000012	A	RDPSTP
000012	A	RP	005564	R	RPB	005573	R	RPB10	005606	R	RPB11
005610	R	RPB12	005616	R	RPB15	005621	R	RPB20	000154	A	RWFL
000155	A	S	000032	A	SAVE	000005	A	SC	000156	A	SCF
005625	R	SCH	005655	R	SCH5	005635	R	SCHLP	005665	R	SCHX
005666	R	SCHY	000446	A	SCR	000426	A	SCS	000467	A	SEVEN



000157	A	SGFL	000014	A	SH	005667	R	SHA	005716	R	SHA50
003670	R	SHAL	005733	R	SHAX	004347	E	SIFCB	000466	A	SIX
000013	A	SL	001626	R	SDF	004355	E	SSFCB	000012	A	STKSZ
000160	A	SVRECN	000162	A	SYSBF	000161	A	SYSDCB	005735	R	TBK
005751	R	TBK10	000432	A	TBKJMP	000164	A	TEMP	000165	A	TEMP1
000471	A	TEN	000166	A	TERM	000464	A	THREE	005763	R	TIN
006002	R	TID10	006025	R	TID15	006032	R	TID20	006045	R	TIDL1
005763	R	TOUT	000004	A	TR	006062	R	TRM	006076	R	TRM10
006112	R	TRM20	006132	R	TRM30	006151	R	TRMI	000425	A	TRS
000422	A	TWO	006152	R	UID	006167	R	UID4	000167	A	UNIT
000414	A	V#BVN	000301	A	V#CPL	000302	A	V#CRS	000355	A	V#DSTB
005761	E	V#EXEC	000317	A	V#LLUP	000316	A	V#LUP	000400	A	V#LUT1
000401	A	V#LUT2	000402	A	V#LUT3	005037	R	V#RER1	000000	R	V#RERF
000001	A	V#RERN	004713	R	V#RERR	000000	R	V#RERS	000334	A	V#STO
000335	A	V#ST1	000336	A	V#ST2	000337	A	V#ST3	006341	R	V#ACC
006342	R	V#BSCB	006343	R	V#ACC	006347	R	V#ACHB	006350	R	V#DFCB
006351	R	V#FSCB	006352	R	V#AGPAR	006353	R	V#AISCB	006354	R	V#ALOC
006355	R	V#ANPOJ	006356	R	V#ANRB	006357	R	V#ADPST	006360	R	V#APBF
006361	R	V#ASCB	006362	R	V#ASFL	006363	R	V#ASYS	006364	R	V#BEXP
006365	R	V#BAPT	006366	R	V#BSCB	006372	R	V#CHB	006410	R	V#CHBPT
006411	R	V#CHHD	006412	R	V#CDUN	006413	R	V#CVFL	006414	R	V#D
006415	R	V#DEXP	006416	R	V#DT	006417	R	V#DEEXP	006420	R	V#ERN
006421	R	V#FDLKY	006422	R	V#FSCB	006426	R	V#GDRP	006437	R	V#IDEXP
006440	R	V#IFW	000000	A	V#II	006441	R	V#IIBSZ	006442	R	V#IIWSZ
006443	R	V#INFL	006444	R	V#IOCDN	006445	R	V#IOLNK	006446	R	V#IOSTA
006447	R	V#ISCB	006453	R	V#ITEMA	006454	R	V#ITEMW	006455	R	V#ITMIN
006456	R	V#ITMOD	006457	R	V#LISTF	006460	R	V#LNKCN	006461	R	V#LRECN
006462	R	V#LRZ	006463	R	V#LRHC	006464	R	V#MDV	006465	R	V#N
006466	R	V#NFF	006467	R	V#OPSTK	006340	R	V#OPSTP	000006	A	VORTEX
006501	R	V#PARLV	006502	R	V#PBRC	006503	R	V#PBSZ	006504	R	V#PWC
006505	R	V#PRECN	006506	R	V#PRLIN	006507	R	V#PTFL	006510	R	V#QFL
006511	R	V#RETUR	006512	R	V#RWFL	006513	R	V#S	006514	R	V#SCF
006515	R	V#SGFL	006516	R	V#SVREC	006517	R	V#SYSDC	006522	R	V#TEMP
006523	R	V#TEMP1	006524	R	V#TERM	006525	R	V#UNIT	006526	R	V#W
006527	R	V#T	006530	R	V#XFFL	006531	R	V#XFL	006532	R	V#XFW
006533	R	V#XSG	006534	R	V#ZFW	006542	R	V#ZZZ	000170	A	W
000001	A	WCS	000011	A	WR	000452	A	WRR	000432	A	WRS
000171	A	WT	000001	A	X	000172	A	XFFL	000173	A	XFL
000174	A	XFW	006175	R	XIN	006175	R	XOUT	000175	A	XSG
000177	A	YYY	000420	A	ZERO	000176	A	ZFW	006207	R	ZIN
006227	R	ZID1	006250	R	ZID2	006261	R	ZID4	006302	R	ZID6
006324	R	ZID7	006325	R	ZID8	006337	R	ZID9	006207	R	ZDUT
000204	A	ZZZ									

0 ERRORS ASSEMBLY COMPLETE

494	AACC	2199	3063								
496	ABSCB	871	1384	4084	4784						
498	ACC	1014	1016	1017	1019	1020	1022	1023	1025	1371	
		1372	1373	1374	1599	1622	1626	1638	1644	1647	
		1657	1659	1662	1663	1666	1672	1676	1677	1678	
		1705	1709	1713	1717	2321	2331	2333	2334	2336	
		2337	2339	2340	2342	2365	2369	2369	2370	2370	
		2371	2371	2372	2377	2378	2380	2381	2382	2384	
		2385	2386	2388	2389	2947	2948	2949	2951	2965	
		2966	2973	2976	2982	2985	2994	2999	3000	3003	
		3007	3010	3011	3013	3015	3020	3023	3024	3026	
		3028	3029	3031	3033	3034	3038	3039	3039	3040	
		3040	3041	3041	3041	3048	3050	3078	3079	3090	
		3091	3093	3094	3099	3100	3107	3108	4375	4528	
		4529	4531	4532	4533	4535	4536	4537	4539	4540	
		4545	4546	4548	4549	4550	4552	4553	4554	4556	
		4557									
500	ACHB	1741	1748	2495	2507	2540	4372	4379	4397		
502	ADFCB	954	964	984	2675	2676	2693	2712	2719	2735	
		2781	2787	2810	2821	2831	3272	3274	3336	3337	
		3430	3500	3506	3508	3627	3676	4194	4205	4227	
		4304	4338	4426	4650	4708	4721				
504	AFSCB	1850	1869	1876	2034						
506	AGPAR	1176	1822	1840							
508	AIBUF	707	708	4809	4810						
704	AIN	1481									
719	AIDL1	723									
739	AIDL2	715	743								
509	AISCB	721	739	4831	4837						
175	AL	1213	1289	2106							
511	ALBF	1541	1557	3163	3281	3329	3340	4179	4183	4285	
		4299	4325	4327	4437	4644	4654	4674	4680	4666	
512	ALOC	775	2656	3191	3617	3807	3988	4489			
514	ANPOJ	767	3959	3960							
516	ANRB	358	363	841	952	979	2635	2673	2694	2793	
		2816	2851	3182	3273	3335	3507	3604	3681	3688	
		3764	3874	3903	3942	3964	4213	4219	4258	4439	
		4471									
518	ADPSTK	819	835	2421	3909	3915	3933				
705	ADUT	1482									
520	APBF	3162	3192	3280	3328	3339	3618	4182	4184	4297	
		4435	4645	4664							
66	ARST	445	956	957	961	1168	1259	1267	1289	1346	
		1358	1360	1852	1854	2110	2122	2130	2166	2180	
		2706	2796	3289	4134	4173	4176	4186	4204	4206	
		4656	4700	4704	4705						
522	ASCB	721	739	872	1384	1850	1869	1876	1901	1913	



67	ASET	1933	2034	2085	4083	4784	4831	4837		
		453	874	1207	1208	1209	1210	1211	1212	1213
		1288	1440	1441	1442	1545	2017	2018	2036	2105
		2106	2121	2124	2128	2165	2179	2260	3290	3395
		3396	4130	4192	4230	4288	4292	4443	4712	4720
524	ASFL	1197	1375	2412	2470					
526	ASYSDC	3336								
674	AZER	2002	2111	2143	2167	2187	2503	2510	2523	2536
		2543	2575	2579						
68	B	241	242	243	250	252	259	261	277	278
		285	294	310	339	340	348	349	358	363
		386	387	394	395	396	403	405	412	428
		436	444	452	460	477	728	730	732	734
		767	775	799	812	819	835	841	844	871
		872	878	901	907	908	909	917	918	945
		952	954	964	972	978	979	984	991	1050
		1054	1055	1088	1089	1094	1095	1098	1101	1104
		1105	1109	1110	1130	1131	1132	1133	1135	1136
		1137	1161	1162	1163	1164	1166	1172	1173	1176
		1177	1179	1182	1192	1194	1196	1197	1198	1201
		1206	1214	1216	1222	1223	1237	1240	1242	1247
		1252	1257	1266	1271	1272	1273	1277	1279	1286
		1287	1294	1329	1334	1337	1342	1348	1349	1351
		1357	1362	1363	1368	1372	1373	1374	1375	1376
		1377	1378	1379	1380	1381	1382	1383	1385	1392
		1406	1409	1439	1522	1533	1534	1540	1549	1584
		1587	1588	1599	1612	1634	1638	1641	1644	1647
		1653	1657	1659	1662	1663	1666	1672	1676	1677
		1678	1681	1687	1693	1702	1705	1709	1713	1717
		1724	1725	1732	1733	1742	1744	1747	1748	1749
		1770	1774	1776	1804	1806	1811	1812	1814	1848
		1857	1901	1913	1933	2003	2006	2013	2090	2091
		2092	2094	2099	2102	2104	2113	2116	2120	2123
		2125	2127	2131	2132	2134	2139	2141	2142	2143
		2144	2150	2159	2162	2164	2170	2171	2174	2178
		2181	2186	2187	2199	2208	2209	2214	2215	2216
		2217	2227	2233	2234	2261	2264	2295	2296	2299
		2344	2346	2348	2373	2375	2413	2417	2422	2458
		2459	2460	2461	2462	2463	2464	2470	2471	2472
		2475	2476	2477	2478	2479	2481	2489	2496	2499
		2500	2501	2503	2504	2506	2507	2508	2517	2529
		2532	2533	2534	2536	2537	2539	2540	2541	2556
		2564	2566	2575	2576	2578	2579	2580	2629	2634
		2635	2640	2657	2659	2664	2667	2671	2672	2692
		2694	2701	2704	2710	2712	2715	2719	2735	2781
		2792	2793	2795	2797	2799	2810	2815	2816	2821
		2831	2838	2850	2851	2885	2900	2947	2948	2949
		2951	2953	2960	2982	2985	2994	2999	3000	3002
		3020	3023	3024	3026	3028	3029	3031	3033	3034
		3036	3038	3042	3044	3046	3054	3065	3067	3069
		3070	3071	3072	3073	3078	3079	3081	3125	3127
		3151	3154	3159	3160	3163	3165	3167	3172	3173
		3176	3177	3178	3179	3181	3194	3202	3257	3264
		3272	3273	3279	3281	3284	3287	3288	3292	3299
		3306	3305	3340	3342	3343	3347	3349	3354	3359
		3363	3364	3372	3376	3393	3394	3403	3428	3430
		3433	3434	3435	3437	3438	3446	3462	3464	3465
		3491	3496	3498	3499	3500	3506	3507	3510	3512
		3580	3583	3587	3588	3592	3593	3596	3598	3604
		3605	3606	3609	3611	3618	3620	3627	3633	3635
		3645	3648	3653	3654	3656	3673	3675	3676	3681
		3688	3713	3715	3717	3719	3726	3762	3764	3766
		3767	3770	3783	3784	3786	3789	3790	3792	3795
		3800	3808	3810	3864	3874	3885	3908	3909	3922
		3940	3942	3949	3959	3963	3969	3971	3974	3988
		3992	3994	4000	4008	4011	4013	4014	4078	4082
		4083	4084	4132	4136	4139	4141	4143	4144	4173
		4179	4180	4182	4183	4188	4194	4205	4208	4213
		4219	4227	4232	4235	4255	4256	4257	4258	4259
		4297	4298	4299	4300	4304	4307	4310	4311	4320
		4325	4326	4327	4329	4330	4331	4332	4337	4338
		4346	4348	4368	4370	4372	4373	4375	4379	4380
		4397	4399	4426	4435	4436	4437	4439	4441	4471
		4474	4476	4481	4484	4490	4495	4499	4501	4597
		4626	4628	4629	4634	4636	4642	4644	4645	4656
		4652	4653	4658	4660	4662	4664	4665	4666	4667
		4673	4674	4676	4677	4697	4699	4706	4708	4714
		4721	4728	4752	4754	4760	4762	4811	4814	4815
		4827	4829	4830	4840	4842	4849	4852	4860	4864
		4866	4870							
69	B0	874								
76	B12	2124	2128							
4879	BASE	809	837	845	3877	3884	3902	3965	4061	
528	BCHAR	713	720	741	1870	1878	2111	2142	2150	2167
		2186	2264	2291	2295	2299	2417	2482	2489	2504
		2510	2517	2523	2537	2543	2550	2556	2558	2560
		2566	2576	2580	4782	4816	4823	4829	4849	4852
		4860								
529	BCODE	2104	2120	2164	2178					
678	BD120	965	2678	2731	2798	2804	3301	3303	3310	3318
		3324	3341	4322						
676	BD14	1749	2508	2541	2659	4370	4373			



E.2 VORTEX LISTING

VORREF

PROGRAM PAGE 72

LISTING PAGE ( 948 )

530	BEXP	1600	1621	1641	1653	1687	1724	1732	1733	2094
		2233	2234	2373	2375	2390	2392	2950	2971	3002
		3005	3036	3042	3054	3064	3067	3070	3081	3089
		3095								
199	BF	119	120							
200	BFA	3543	3546							
532	BFPT	1543	3199	3625	4625	4628	4642	4673		
119	BFR	3291	3436							
120	BFS	3157	3427	3586	3651					
533	BFWPT	909	917	1533	1541	1547	1549	1557	3165	4145
		4180	4184	4285	4329	4663	4752	4762		
0	BIFCB	56	3523							
176	BL	2018	2036	2110	2166	2260				
680	BLNK1	713	727	2291	2482	2550	2560	4782	4816	
682	BLNK2	907								
88	BM17	122								
89	BM37	3390								
0	EDFCB	57	3524							
147	BR	3891								
91	BR0	119	127	134	140	144	168			
103	BR15	1215	1614	1643	1646	1655	1671	1907	2892	
95	BR4	2114	2172							
97	BR6	2115	2173							
99	BR8	2133	3630	4215						
104	BS0	120	128	130	132	135	136	141	142	149
		150	153	169						
115	BS11	3652								
116	BS12	976	2670	3183	3603					
117	BS14	3003	3037							
118	BS15	3105								
107	BS4	109								
111	BS7	121	2995							
112	BS8	3683	4225							
113	BS9	4599								
535	BSCB	511	528	529	532					
121	BXBIA5	1620	1640	3006	3043	3055				
767	CAN	998	1780	2740	2858	2861	3728	4263	4720	4723
		4724	4727							
790	CAN1	776								
834	CAN2	826								
851	CAN5	820	823	846						
819	CANL1	828								
844	CANL2	849								
871	CBC	719	1868	2101	2161	2259	2418	4100	4821	4825
876	CBC4	874								
881	CBC6	877	879							
218	CBK	2763								
228	CDC	3152								
211	CER	4261								
212	CEX	822	996	1778	2738	2856	4717			
537	CHB	641								
539	CHBPT	1741	1744	1747	2495	2500	2501	2506	2533	2534
		2539								
541	CHNHDR	4473	4477							
213	CID	982	2687	2812	2818	2859	3685	4432	4725	
900	CLB	1548	3201	3631	4197	4231				
904	CLB4	902								
908	CLB8	906								
913	CLBLP	919								
920	CLBX	904	905							
944	CLS	4048	4049							
965	CLS10	961								
968	CLS15	966								
972	CLS20	956	957							
990	CLS30	985								
177	CM	1207	1440	2105	2163					
226	COFV	2630								
543	COUNT	709	724	1085	1088	1092	1095	1133	1725	1731
		1809	2060	2232	2270	2292	2464	2494	2496	2499
		2532	2528	2329	2532	2549	3062	3071	3072	4078
		4082	4068	4380	4385	4476	4481	4484	4521	4524
		4783	4815							
230	CRA	3646								
214	CRB	3724								
221	CRD	3581								
215	CTR	4001								
216	CTRV	4020								
545	CVFL	1192	1201	1279	2099	2102	2113	2116	2123	2127
		2132	2134	2139	2141	2159	2162	2170	2171	2174
210	CXC	3513								
217	CXF	3931	3972							
547	D	1085	1089	1132	1196	1363	1370	1806	2211	
1012	D10	1694	2236							
122	D15	1600	2374	2963	4493					
109	D16	3928								
203	DA	3263								
1049	DEF	1102	1103	1111	1138	1818				
1052	DEF4	1049								
1055	DEF8	1051								
1096	DED10	1086	1091	1093						
1094	DED5	1087								
549	DEXP	1099	1099	1131	1135	1137	1376	1631	1693	1702
		1736	1804	1812	1817	2060	2062	2217	2229	2227



E.2 VORTEX LISTING

V#REF

PROGRAM PAGE

73

LISTING PAGE ( 944)

2937	DIN	2237	2561	2564	2570	2572	2578	4399		
1083	DOUT	1467								
551	DT	1094	1104	1109	1370	1809	1811	1814	2462	2471
		2472	2475	2528						
202	EC	877	1525	4724						
553	EDEXP	2089	2189	2191	2208	2209	2216			
133	EIGHT	219	1217	1338	2423	3655				
2938	EIN	1469								
1084	EDUT	1470	1805	1808	1813					
4258	ER1	1168	1175	1202	1238	1259	1265	1284	1289	1308
		1320	1336	1344	1346	1350	1358	1360	1443	2005
		2014	4637							
4257	ER2	3763	3799							
4256	ER3	1598	1667	2103	2152	2154	2163	2193	2218	2258
		2269	2959	2962	2964	2979	3056	3058	3080	3083
		3085	4851	4856	4858					
4255	ER4	950	3259	3276	3367	3458	3493	3504	4002	4007
555	ERN	3904	4255	4256	4257	4259	4260			
557	FCHAR	1294	1870	1878	2002	2002	2013			
558	FCDDE	1206	1266	1287	1357	1439				
559	FDLKEY	1217	1232	1329	1334	1337	1351	1385	1406	2422
		2557	3792							
2939	FIN	1471								
123	FIVE	215	1386	4383						
124	FLF	956	2706							
561	FMPT	1855	1858							
125	FOUR	214	1100	1174	1335	1352	1354	1731	1815	2232
		2549	3793							
1128	FOUT	1472								
126	FPO	127	128	961						
127	FPDR	3678								
128	FPOS	4210	4340							
129	FR3	130								
130	FR5	2718								
131	FRM	957								
562	FRMT	906	3161	3400	3600	3602	3636	3767	3790	
563	FRPT	1160	1182	1252						
1160	FRS	3203	3637							
1199	FRS10	1207	1280							
1222	FRS15	1209	1442							
1251	FRS19	1226	1246							
1172	FRS2	1208	1288							
1257	FRS20	1210								
1263	FRS25	1212								
1284	FRS30	1267								
1293	FRS35	1213								
1319	FRS39	1311								
1322	FRS40	1302								
1337	FRS45	1333								
1345	FRS46	1339								
1357	FRS47	1353								
1191	FRS5	1253	1434	1440	1863	2424	4786			
1367	FRS50	1355	1428							
1402	FRS55	1393								
1406	FRS60	1218	1341	1356	1387	1398				
1427	FRS65	728	735	2272	2425	3075	4834			
1433	FRS70	1211	1441							
1438	FRS75	1228								
1439	FRS85	1429	1854	4675						
1447	FRSHT	1300	1301							
1466	FRSJT	1300	1417							
1301	FRSL1	1314								
564	FSCB	557	558	561	562	563				
1522	GBA	875	4138	4680	4747					
1533	GBA50	1524								
1542	GBA55	1558								
1553	GBA70	1536	1544	1545						
1556	GBA80	1525								
566	GDRPC	568	569	1181	1183	1243	1245	1249	1251	
198	GF	132	2777	2828						
568	GFRPT	1183	1251							
132	GFS	3511								
2940	GIN	1473								
1584	GNI	1402								
1676	GNI10	1601	1629	1648	1660	1668				
1599	GNI12	1595								
1699	GNI20	1689								
1723	GNI25	1701	1704	1708	1712	1716				
1731	GNI30	1700	1707	1711	1715	1719				
1602	GNI4	1590								
1741	GNI50	1682	1688	1727						
1632	GNI8	1603								
1652	GNI9	1605								
1669	GNI9A	1665								
1686	GNIL1	1679	1695	1737						
1743	GNIL2	1750								
1769	GNL	1233	1367	4746						
1781	GNL2	1772	1773							
0	GDFCB	59	3526							
1804	GDUT	1474								
569	GSRPC	1161	1181	1243	1245	1249				



1839	HIN	1483	1872							
1868	HID10	1849								
1876	HID15	1856	1864							
1850	HID2	1847								
1858	HID4	1852								
1862	HID6	1842								
1840	HOUT	1484	1880							
1901	ICC	740	881	1851	1853	1877	2016	2035	4095	4838
1939	ICCT	1923	1927							
1962	ICCT1	1927								
1924	ICCLP	1926								
570	ICHR	720	727	741	4823	4827	4830	4840	4842	4864
		4866	4870							
571	IDEXP	2090		2211	2215	2328	2346	2348		
1998	IFF	1263	1347	1361						
2002	IFFL	2017								
2016	IFFL1	2018								
573	IFW	1050	1377	1817	2062	2460	2478	2479	2481	2494
575	IIBSZ	709	724	3786	4814					
2941	IIN	1475								
577	IIBSZ	3073	3783							
197	IN	134	135	3276	3348	3395	4172	4229	4434	
2034	INF	1167	1200	1258	1345	1359	1438			
579	INFL	3864	3899							
2035	INFLP	2036								
134	INR	2702	4234							
135	INS	2633	4347							
581	IOCONT	953	980	2674	2794	2817	2852	3154	3184	3185
		3583	3606	3607	3648	3682	3684	3689	3691	4214
		4216	4224	4226						
583	IOLNK	3464	3496	3509	3509					
585	IOWAT	4220	4223							
2058	IDUT	1476								
587	ISCB	508	570							
589	ITEMAD	708	1234	1234	1584	1769	1769	2261	2296	3064
		3802	3808	4754	4760	4810				
591	ITEMWC	1235	1235	1770	1781	1781	3801	3810		
593	ITMWC	1234	1235	1769	1781	3784	3789			
595	ITMODE	1588	2953	3765	3766	3770	3795			
2089	IXN	1397								
2142	IXN10	2112								
2150	IXN15	2106								
2169	IXN18	2124	2128							
2171	IXN20	2166								
2186	IXN25	2168	2180							
2195	IXN30	2160	2165							
2113	IXN4	2110								
2127	IXN5	2121								
2199	IXN50	2100	2105							
2210	IXN52	2206								
2212	IXN53	2210								
2215	IXN55	2212								
2221	IXN57	2204								
2222	IXN58	2220								
2130	IXN6	2122								
2232	IXN60	2222								
2139	IXN8	2130								
2100	IXNL1	2126	2129	2135	2146					
2160	IXNL2	2179	2182	2194						
2219	IXNL3	2228	2238							
1241	IXR	1411								
86	LC	155	156	157	158	159	160	161	162	163
		164	165	166	167					
191	LF	124	136	985	2644	2796	2820	3289	3626	4129
		4204	4287	4422	4442	4700	4719			
136	LFS	2632								
597	LGOV	966	3327							
137	LHW	2899	3057	3258						
2258	LIN	1479	2260							
2270	LINX	2266								
598	LISTFL	1162	1237	1239	1368					
600	LNKCNT	981	2695	4475						
493	LOC	494	495	496	497	498	499	500	501	502
		503	504	505	506	507	509	510	512	513
		514	515	516	517	518	519	520	521	522
		523	524	525	526	527	530	531	533	534
		535	536	537	538	539	540	541	542	543
		544	545	546	547	548	549	550	551	552
		553	554	555	556	559	560	564	565	566
		567	571	572	573	574	575	576	577	578
		579	580	581	582	583	584	585	586	587
		588	589	590	591	592	593	594	595	596
		598	599	600	601	602	603	604	605	606
		607	608	609	610	611	612	613	614	615
		617	618	619	620	621	622	623	624	625
		626	627	628	629	630	631	632	633	636
		637	638	639	640	642	643	644	645	646
		647	649	650	651	652	653	654	655	656
		657	658	659	660	661	662	663	664	665
		666	667	668	669	670	671	672	673	674
		675	676	677	678	679	680	681	682	683
		684								
0	LDLFB	55	3522							











4134	RCL10	4130									
4138	RCL15	4133	4134	4135							
4131	RCL5	4129									
4171	RCP	1529	4293	4349							
4192	RCP15	4176	4186								
4202	RCP20	4185	4192	4193							
4204	RCP25	4177									
4176	RCP3	4173									
4227	RCP35	4212									
4229	RCP40	4204	4206								
4178	RCP5	4172									
4232	RCP50	4203	4229	4230							
635	RETURN	878	972	2640	3160	3167	3172	3264	3588	3592	
		3593	3596	3598	3609	3610	3611	3612	3800	3949	
		3950	4008								
		3629	4659								
4284	RFL	4288									
4297	RFL10	4308									
4333	RFL20	4333									
4336	RFL30	4292									
4342	RFL40	4287									
4292	RFL5	4306	4309	4313							
4346	RFL50	1912	2681	3283	3375	3431	3492				
143	RHW	131	149	2714	2766	3290	3396	4130	4192	4206	
190	RM	4288	4443	4704	4720						
		3392									
149	RMS	1096	1134	1810	2061						
4368	RND	4385									
4399	RND10	4371									
4379	RND5	4378	4398								
4390	RNDL	4369	4377	4384	4393						
4402	RNDX	1906	2891	2950							
2205	ROF	811	838	3878	3880						
634	ROPSTP	1209	1442								
185	RP	4202	4217								
4422	RPB	4422									
4432	RPB10	4434									
4439	RPB11	4438									
4441	RPB12	4442									
4444	RPB15	4443									
4446	RPB20	715	728	730	732	734	877	881	905	945	
637	RWFL	985	1393	1409	1525	1544	1856	1864	2634	2644	
		2701	2714	2764	2766	2777	2789	2795	2820	2828	
		3159	3186	3186	3200	3263	3276	3287	3288	3292	
		3348	3393	3394	3435	3438	3510	3512	3587	3608	
		3608	3626	3630	3653	3673	3675	3687	4087	4129	
		4172	4175	4185	4188	4203	4208	4212	4229	4232	
		4235	4287	4333	4337	4346	4348	4422	4434	4442	
		4655	4658	4662	4697	4699	4706	4719	4723	4748	
		4818									
639	S	1086	1092	1099	1101	1105	1110	1130	1136	1164	
		1277	2214								
641	SAVE	2636	2641	2642	2643	2645	2646	2647	2657	2664	
		2665	2667	2671	2675	2679	2704	2710	2711	2715	
		2732	2763	2770	2838	3347	3376	3403	3446	3491	
		4195	4198	4625	4629	4655	4660	4669	4674	4676	
		4677									
196	SC	144	150	4230							
642	SCF	1195	1271	1333	1392	2195	2212				
4471	SCH	949	3267								
4498	SCH5	4489									
4481	SCHLP	4503									
4504	SCHX	4500									
4505	SCHY	4482									
144	SCR	4233									
150	SCS	4661									
145	SEVEN	218	3449	4855	4857	4869					
644	SGFL	1199	1257	1273	1284	1379	1587	1634	2125	2459	
		2487	2981	3046	3098						
194	SH	124	126	129	131	2703	3286				
4520	SHA	1726	1734	2235							
4545	SHA50	4521									
4521	SHAL	4541									
4558	SHAX	4522									
0	SIFCB	53	3502	3519							
146	SIX	217									
186	SL	1211	1441								
1904	SOF	4086									
0	SSFCB	58	3525								
209	STKSZ	615	634	842	845	3876	3884	3967	4896	4939	
646	SVRECN	3277	4714								
648	SYSBF	2636									
649	SYSDCB	648									
4580	TBK	2658	2660	3193	3196	3619	3622	3809	3812	3951	
		3953	3955	3957	3961	4035	4492	4494			
4591	TBK10	4581	4585								
4599	TBKJMP	4592									
651	TEMP	908	915	1612	1617	1618	1623	2629	2763	2886	
		2900	2965	2974	2977	3009	3015	3063	3065	3069	
		3151	3354	3359	3363	3364	3372	3428	3437	3580	
		3645	3654	3656	3713	3719	3726	3930	3940	3971	
		3994	4014	4310	4320	4323	4326	4331	4490	4495	
653	TEMP1	900	903	904	918						



E.2 VORTEX LISTING

V\$RERF

PROGRAM PAGE

78

LISTING PAGE ( 949 )

151	TEM	221	1015	1018	1021	1024	2009	2190	2332	2335
		2338	2341	2571	3952	4392	4853			
655	TERM	1383	2144	2330						
152	THREE	213	1699	2987	3381	3798				
4622	TIN	1487								
4642	TID10	4630								
4659	TID15	4656								
4663	TID20	4646								
4673	TIDLP	4638	4679	4681						
4623	TOUT	1488								
195	TR	153	1545	4134						
4697	TRM	4041								
4708	TRM10	4705								
4717	TRM20	4700	4704							
4723	TRM30	4719								
4728	TRMI	4715								
153	TRS	4698								
154	TWD	212	1340	1343	1589	1604	2153	2954	2989	3457
		3466	3494	3590	3796					
4746	UID	3636	4756	4764						
4760	UID4	4748								
657	UNIT	953	978	2700	2792	2815	2850	3173	3181	3257
		3284	3349	3462	3465	3605	4011	4193	4499	
156	V\$CPL	3456	3869							
157	V\$CRS	798	3890	4596						
158	V\$DSTB	3380								
0	V\$EXEC	61								
160	V\$LLUP	4583	4586							
159	V\$LUP	4580	4582	4591						
161	V\$LUT1	3352	3469							
3986	V\$RER1	34								
43	V\$RERF	28	40							
46	V\$RERN	35								
3856	V\$RERR	33								
42	V\$RERS	26	38							
164	V\$ST0	1298	1415	1921	2842	3407	3473	3775	4018	
165	V\$ST1	3875								
166	V\$ST2	796								
167	V\$ST3	1319	1326	1421	1931	2848	3425	3444	3481	3781
		3863	3892	3979	4024					
4887	VACC	4885								
4903	VBSCB	4886								
4904	VCHB	4888								
4915	VFSCB	4890								
4916	VGDRP	4891								
21	VII	22	23	772	795	801	1297	1305	1317	1325
		1414	1420	1920	1930	2654	2841	2847	3189	3406
		3424	3443	3472	3480	3615	3774	3780	3895	3860
		3898	3900	4017	4023	4032	4057	4487	4563	4882
		4941								
850	VIII	802	2655	3190	3616	3806	3861	3901	4033	4058
		4488	4564	4883	4942					
1310	VIINUC	1306								
4925	VISCB	4892								
4939	VDPSTK	3965	4896							
1	VORTEX	19	21	3978						
4956	VSYSDC	4900								
659	H	724	1349	1369	4626	4636				
19	WCS	20	25	27	37	39	326	371		
330	WCS1	327	372							
332	WCS2	329	375							
201	WR	168	169	715	881	1393	1544	1856	1864	3200
		3630	3687	4087	4176	4185	4203	4292	4333	4656
		4705	4723	4748	4818					
168	WRR	733								
169	WRS	729	944	1410	3156	3585	3650			
661	WT	709	723	876	1216	1286	1369	2100	2160	2258
		2270	2292	2413	2419	2458	4811	4824	4833	
81	X	268	270	286	302	309	317	318	341	351
		359	361	364	378	420	468	484	783	811
		821	824	838	845	873	880	955	973	974
		980	983	990	992	1014	1016	1017	1019	1020
		1022	1023	1025	1180	1181	1183	1243	1244	1245
		1249	1250	1251	1301	1417	1423	1585	1594	1609
		1613	1617	1618	1621	1622	1623	1626	1632	1635
		1639	1642	1645	1654	1658	1745	1777	1902	1903
		1908	1910	1914	1925	1927	1934	2015	2189	2191
		2200	2201	2202	2203	2263	2267	2321	2324	2326
		2328	2330	2331	2332	2334	2336	2337	2339	2340
		2342	2365	2377	2378	2380	2381	2392	2384	2385
		2386	2388	2389	2390	2392	2392	2535	2570	2572
		2658	2660	2668	2674	2676	2680	2683	2688	2695
		2705	2713	2716	2720	2721	2723	2731	2732	2737
		2794	2803	2804	2811	2813	2817	2819	2833	2844
		2852	2887	2888	2893	2895	2902	2973	2974	2976
		2977	3005	3007	3009	3010	3011	3013	3048	3050
		3066	3068	3089	3090	3091	3093	3094	3095	3099
		3100	3107	3108	3126	3128	3166	3171	3182	3184
		3185	3192	3193	3196	3265	3274	3282	3285	3301
		3303	3305	3308	3310	3316	3318	3319	3320	3323
		3324	3326	3327	3328	3329	3337	3365	3366	3374



